

Carnet: 00026124

A: 24

B: 83

Red base asignada: 10.24.83.0/24

R1

```
R1(config)#show ip router
^
% Invalid input detected at '^' marker.
R1(config)#exit
R1#sh
*Mar 1 00:23:35.127: NSVS-5-CONFIG-I: Configured from console by console
R1#show ip route
^
% Invalid input detected at '^' marker.

R1#show ip route
Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       I - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, * - candidate default, U - per-user static route
       o - ODR, P - periodic downloaded static route

Gateway of last resort is not set

  10.0.0.0/8 is variably subnetted, 3 subnets, 3 masks
  C    10.24.83.64/27 is directly connected, FastEthernet1/0
  C    10.24.83.96/28 is directly connected, FastEthernet2/0
  C    10.24.83.0/26 is directly connected, FastEthernet0/0
R1#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
R1(config)#ip route 10.24.83.125 255.255.255.248 10.24.83.122
R1(config)#ip route 10.24.83.124 255.255.255.252 10.24.83.122
R1(config)#end
R1#
*Mar 1 00:25:27.895: NSVS-5-CONFIG-I: Configured from console by console
R1#show ip interface brief
Interface                IP-Address      OK? Method Status      Protocol
FastEthernet0/0          10.24.83.1      YES manual up          up
Serial10/0                unassigned      YES unset   administratively down down
FastEthernet0/1          unassigned      YES unset   administratively down down
Serial10/1                unassigned      YES unset   administratively down down
FastEthernet1/0          10.24.83.65     YES manual up          up
FastEthernet2/0          10.24.83.97     YES manual up          up
R1#show ip interface brief
^
% Invalid input detected at '^' marker.
R1#
```

R2

```
R2#
R2(config-if)#exit
R2(config)#interface fastEthernet 0/1
R2(config-if)#ip address 10.24.83.125 255.255.255.252
R2(config-if)#no shutdown
R2(config-if)#
*Mar 1 00:21:24.875: XLINK-3-UPDOWN: Interface FastEthernet0/1, changed state to up
*Mar 1 00:21:25.875: XLINKPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/1, changed state to up
R2#
R2(config-if)#exit
R2(config)#ip route 10.24.83.0 255.255.255.192 10.24.83.121
R2(config)#ip route 10.24.83.64 255.255.255.224 10.24.83.121
R2(config)#ip route 10.24.83.96 255.255.255.240 10.24.83.121
R2(config)#ip route 10.24.83.112 255.255.255.248 10.24.83.126
R2(config)#end
R2#
*Mar 1 00:21:52.431: NSVS-5-CONF16-I: Configured from console by console
R2#show ip interface brief
Interface                IP-Address      OK? Method Status      Protocol
FastEthernet0/0          10.24.83.122     YES manual up          up
Serial10/0                unassigned      YES unset   administratively down down
FastEthernet0/1          10.24.83.125     YES manual up          up
Serial10/1                unassigned      YES unset   administratively down down
Serial11/0                unassigned      YES unset   administratively down down
Serial11/1                unassigned      YES unset   administratively down down
Serial11/2                unassigned      YES unset   administratively down down
Serial11/3                unassigned      YES unset   administratively down down
R2#show ip route
Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       I - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, * - candidate default, U - per-user static route
       o - ODR, P - periodic downloaded static route

Gateway of last resort is not set

  10.0.0.0/8 is variably subnetted, 6 subnets, 5 masks
  S    10.24.83.64/27 [1/0] via 10.24.83.121
  S    10.24.83.96/28 [1/0] via 10.24.83.121
  S    10.24.83.112/29 [1/0] via 10.24.83.126
  C    10.24.83.120/30 is directly connected, FastEthernet0/0
  C    10.24.83.120/30 is directly connected, FastEthernet0/1
  S    10.24.83.0/26 [1/0] via 10.24.83.121
R2#
```

R3

```

R1 R2 R3 PC1 PC2 PC3 PC4
*Mar 1 00:22:10.615: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0, changed state to u
p
R3(config)#interface fa0/1
R3(config-if)# ip address 10.24.83.113 255.255.255.248
R3(config-if)# no shutdown
R3(config-if)#
*Mar 1 00:22:41.183: %LINK-3-UPDOWN: Interface FastEthernet0/1, changed state to up
*Mar 1 00:22:42.183: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/1, changed state to u
p
R3(config-if)#exit
R3(config)#ip route 10.24.83.0 255.255.255.192 10.24.83.125
R3(config)#ip route 10.24.83.64 255.255.255.224 10.24.83.125
R3(config)#ip route 10.24.83.96 255.255.255.240 10.24.83.125
R3(config)#ip route 10.24.83.120 255.255.255.252 10.24.83.125
R3(config)#end
R3#
*Mar 1 00:23:17.719: %SYS-5-CONFIG-I: Configured from console by console
R3#show ip interface brief
Interface IP-Address OK? Method Status Protocol
FastEthernet0/0 10.24.83.126 YES manual up up
Serial0/0 unassigned YES unset administratively down down
FastEthernet0/1 10.24.83.113 YES manual up up
Serial0/1 unassigned YES unset administratively down down
Serial1/0 unassigned YES unset administratively down down
Serial1/1 unassigned YES unset administratively down down
Serial1/2 unassigned YES unset administratively down down
Serial1/3 unassigned YES unset administratively down down
R3#show ip route
Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
        D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
        N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
        E1 - OSPF external type 1, E2 - OSPF external type 2
        I - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
        ia - IS-IS inter area, * - candidate default, U - per-user static route
        o - ODR, P - periodic downloaded static route

Gateway of last resort is not set

10.0.0.0/8 is variably subnetted, 6 subnets, 5 masks
S    10.24.83.64/27 [1/0] via 10.24.83.125
S    10.24.83.96/28 [1/0] via 10.24.83.125
C    10.24.83.112/29 is directly connected, FastEthernet0/1
S    10.24.83.120/30 [1/0] via 10.24.83.125
C    10.24.83.124/30 is directly connected, FastEthernet0/0
S    10.24.83.0/26 [1/0] via 10.24.83.125
R3#
```

PC1

```

R1 R2 R3 PC1 PC2 PC3 PC4
Press '?' to get help.
Executing the startup file

PC1> ip 10.24.83.62 255.255.255.192 10.24.83.1
Checking for duplicate address...
PC1 : 10.24.83.62 255.255.255.192 gateway 10.24.83.1

PC1> save
Saving startup configuration to startup.vpc
: done

PC1> clear ip
IPv4 address/mask, gateway, DNS, and DHCP cleared

PC1> ip 10.24.83.2 255.255.255.192 10.24.83.1
Checking for duplicate address...
PC1 : 10.24.83.2 255.255.255.192 gateway 10.24.83.1

PC1> save
Saving startup configuration to startup.vpc
: done

PC1> ping 10.24.83.118
*10.24.83.1 icmp_seq=1 ttl=255 time=45.852 ms (ICMP type:3, code:1, Destination host unreachable)
*10.24.83.1 icmp_seq=2 ttl=255 time=15.778 ms (ICMP type:3, code:1, Destination host unreachable)
*10.24.83.1 icmp_seq=3 ttl=255 time=15.182 ms (ICMP type:3, code:1, Destination host unreachable)
*10.24.83.1 icmp_seq=4 ttl=255 time=16.110 ms (ICMP type:3, code:1, Destination host unreachable)
*10.24.83.1 icmp_seq=5 ttl=255 time=15.722 ms (ICMP type:3, code:1, Destination host unreachable)

PC1> trace to 10.24.83.118
trace HOST [OPTION ...]
Print the path packets take to the network HOST. HOST can be an ip address or
name.
Options:
-P protocol Use IP protocol in trace packets
              1 - icmp, 17 - udp (default), 6 - tcp
-m ttl       Maximum ttl, default 8

Notes: 1. Using names requires DNS to be set.
       2. Use Ctrl+C to stop the command.

PC1> 
```

PC2

10.24.83.024		prof requerido	red asigrech	muestre	primer sp otcl	ultimo sp otcl	bradcast
PC 1	50		10.24.83.0	258.265.265.192/26	10.24.83.7	10.24.83.62	10.24.83.63
PC 2	25		10.24.83.64	248.255.255.255/29	10.24.83.65	10.24.83.94	10.24.83.95
PC 3	12		10.24.83.96	255.255.255.240/26	10.24.83.97	10.24.83.110	10.24.83.111
PC 4	6		10.24.83.112	255.255.255.248/29	10.24.83.113	10.24.83.116	10.24.83.119
R1-P2	2		10.24.83.120	248.255.255.252/30	10.24.83.121	10.24.83.122	10.24.83.123
P2-R3	2		10.24.83.124	248.255.255.252/30	10.24.83.125	10.24.83.126	10.24.83.127

2. Tabla de direccionamiento

Dispositivo	Interfaz	Direccion IP	Notas de Subnet	Gate way
1 R1	fa 0/0	10.24.83.7	255.255.255.192	
PC1	e 0/0	10.24.83.2	255.255.255.192	10.24.83.1
P1	fa 0/1	10.24.83.121	255.255.255.252	X
P2	fa 0/0	10.24.83.122	255.255.255.252	X
P2	fa 0/1	10.24.83.125	255.255.255.252	
X R3	fa 0/0	10.24.83.126	255.255.255.252	
X R3	fa 0/1	10.24.83.113	255.255.255.248	
PC4	e 0/0	10.24.83.114	255.255.255.248	10.24.83.113
P1	fa 1/0	10.24.83.65	255.255.255.224	
PC2	e 0/0	10.24.83.66	255.255.255.224	10.24.83.65
P1	fa 2/0	10.24.83.97	255.255.255.240	
PC3	e 0/0	10.24.83.98	255.255.255.240	10.24.83.97

```

Welcome to Virtual PC Simulator, version 0.6.2
Dedicated to Daling.
Build time: Apr 10 2019 02:42:20
Copyright (c) 2007-2014, Paul Meng (mirnshi@gmail.com)
All rights reserved.

VPCS is free software, distributed under the terms of the "BSD" licence.
Source code and license can be found at vpcs.sf.net.
For more information, please visit wiki.freecode.com.cn.

Press '?' to get help.

Executing the startup file

PC2> ip 10.24.83.66 255.255.255.224 10.24.83.65
Checking for duplicate address...
PC1 : 10.24.83.66 255.255.255.224 gateway 10.24.83.65

PC2> save
Saving startup configuration to startup.vpc
.. done

PC2> ping 10.24.83.118
*10.24.83.65 icmp_seq=1 ttl=255 time=14.942 ms (ICMP type:3, code:1, Destination host unreachable)
*10.24.83.65 icmp_seq=2 ttl=255 time=15.505 ms (ICMP type:3, code:1, Destination host unreachable)
*10.24.83.65 icmp_seq=3 ttl=255 time=15.338 ms (ICMP type:3, code:1, Destination host unreachable)
*10.24.83.65 icmp_seq=4 ttl=255 time=15.272 ms (ICMP type:3, code:1, Destination host unreachable)
*10.24.83.65 icmp_seq=5 ttl=255 time=15.228 ms (ICMP type:3, code:1, Destination host unreachable)

PC2> trace to 10.24.83.118
trace HOST [OPTION ...]
Print the path packets take to the network HOST. HOST can be an ip address or
name.
Options:
  -P protocol      Use IP protocol in trace packets
                   1 - icmp, 17 - udp (default), 6 - tcp
  -m ttl           Maximum ttl, default 8

Notes: 1. Using names requires DNS to be set.
       2. Use Ctrl+C to stop the command.

PC2> 
```

PC3

```

Welcome to Virtual PC Simulator, version 0.6.2
Dedicated to Daling.
Build time: Apr 10 2019 02:42:20
Copyright (c) 2007-2014, Paul Meng (mirnshi@gmail.com)
All rights reserved.

VPCS is free software, distributed under the terms of the "BSD" licence.
Source code and license can be found at vpcs.sf.net.
For more information, please visit wiki.freecode.com.cn.

Press '?' to get help.

Executing the startup file

PC3> ip 10.24.83.98 255.255.255.240 10.24.83.97
Checking for duplicate address...
PC1 : 10.24.83.98 255.255.255.240 gateway 10.24.83.97

PC3> save
Saving startup configuration to startup.vpc
.. done

PC3> trace to 10.24.83.118
trace HOST [OPTION ...]
Print the path packets take to the network HOST. HOST can be an ip address or
name.
Options:
  -P protocol      Use IP protocol in trace packets
                   1 - icmp, 17 - udp (default), 6 - tcp
  -m ttl           Maximum ttl, default 8

Notes: 1. Using names requires DNS to be set.
       2. Use Ctrl+C to stop the command.

PC3>
PC3> 
```

PC4

```
PC4>
PC4>
PC4>
PC4>
PC4>
PC4>
PC4>
PC4>
PC4>
PC4>
PC4>
PC4>
PC4>
PC4>
PC4>
PC4> ip 10.24.83.114 255.255.255.248 10.24.83.113
Checking for duplicate address...
PC1 : 10.24.83.114 255.255.255.248 gateway 10.24.83.113
.
PC4> save
Saving startup configuration to startup.vpc
. done
.
PC4> ping 10.24.83.114
10.24.83.114 icmp_seq=1 ttl=64 time=0.001 ms
10.24.83.114 icmp_seq=2 ttl=64 time=0.001 ms
10.24.83.114 icmp_seq=3 ttl=64 time=0.001 ms
10.24.83.114 icmp_seq=4 ttl=64 time=0.001 ms
10.24.83.114 icmp_seq=5 ttl=64 time=0.001 ms
PC4> 
```