

BrewMaster 300 Filter Coffee Machine — Instruction Manual

Model BM-300 · 230 V ~ 50 Hz · 1000 W · Please read these instructions carefully and keep them for future reference.

1. Safety instructions

- Only connect the appliance to an earthed socket with the voltage shown on the rating plate.
- Never immerse the base, cable or plug in water or any other liquid.
- The hotplate and the jug become hot during use. Hold the jug by its handle only.
- Children must not play with the appliance. Cleaning must not be done by children without supervision.
- Unplug the machine before cleaning and when it is not in use for a long time.

2. Parts

No.	Part	No.	Part
1	Water tank lid	6	Glass jug with lid
2	Water tank with level gauge	7	Hotplate
3	Filter holder (swing-out)	8	On/off switch with light
4	Permanent filter	9	Aroma selector
5	Drip stop valve	10	Cable storage

3. Before first use

Rinse the jug, lid and permanent filter in warm soapy water. Fill the tank to the MAX mark with fresh water and run the machine twice without coffee to clean the internal pipes.

4. Making coffee

1. Open the lid and fill the tank with cold water to the desired number of cups (2–10).
2. Swing out the filter holder and insert the permanent filter or a size 1x4 paper filter.
3. Add ground coffee: one level measuring spoon (about 6 g) per cup.
4. Close the filter holder and place the jug on the hotplate.
5. Choose the aroma setting: MILD for a lighter cup, STRONG for slower brewing.
6. Press the on/off switch. Brewing takes about 1 minute per cup.
7. The hotplate keeps the coffee warm for 40 minutes and then switches off automatically.

Drip stop: you can remove the jug during brewing for up to 30 seconds; the valve stops the flow.

5. Cleaning and care

After each use, empty the filter and rinse the jug. Wipe the base with a damp cloth. The jug and permanent filter are dishwasher-safe on the top rack. Do not use abrasive cleaners.

6. Descaling

Descale every 40 brewing cycles, or every 20 in hard-water areas. Fill the tank with a mixture of 0.5 l water and 0.25 l white vinegar, or a commercial descaler following its instructions. Run half the solution through, switch off for 15 minutes, then run the rest. Rinse by running the machine twice

with clean water.

7. Troubleshooting

Problem	Possible cause	Solution
Coffee runs over the filter	Jug not in place, or filter blocked	Check the jug position; use less finely ground coffee
Brewing takes much longer	Scale build-up	Descale the machine (section 6)
Coffee is not hot enough	Jug was cold	Rinse the jug with hot water before brewing
Machine does not start	No power	Check plug, socket and fuse

8. Warranty and disposal

This appliance is guaranteed for two years from the date of purchase against defects in materials and workmanship. Keep your receipt as proof of purchase. At the end of its life, do not dispose of the appliance with household waste; take it to a recycling point for electrical equipment.