More questions in Kinetis Microcontrollers

I cannot successfully compile a project, I give in - please help!! :(

Question asked by **Justin Reina** on Jul 23, 2016
Latest reply on Jul 25, 2016 by Daniel Chen

Like • 0 Comment • 1

Hi,
I just purchased a Freedom KL25Z dev unit (FRDM-KL25Z) and am trying to use it. I am following NXP's provided Getting Started Guide located here

Getting Started Guide
FRDM-KL25Z|Freedom Development Platform|Kinetis MCU|NXP

Current State (Stuck!)
I have installed the IDE and Toolchain and have gotten to try to build my own project. I can build the lib (ksdk_platform_lib_KL25Z4), but the Linker fails on all attempts (hello_world attempt)!

See attached *'getting started procedure - trial 1.txt'* for fairly detailed notes on my procedure leading up to failure. I've re-tried this a second time, and it failed again.

Request
Help, please!! What am I doing wrong, and how to correct?

This is like "Hello World 101", and is embarassing that I am stuck. Any and all help is Greatly appreciated!!

-Justin

ATTACHMENTS

getting started procedure - trial 1.txt.zip
1.2 K

I also have this question • 0

Visibility: Kinetis Microcontrollers • **52 Views**
Last modified on Jul 23, 2016 3:16 PM
Tags: kl25z
Categories: Kinetis K Series MCUs

1 Comment

Daniel Chen

Jul 25, 2016 3:47 AM

Hi Justin:

Sorry, this Getting started guide link you provided is very old, it direct you to install KSDK1.3 and the instructions is based on KSDK1.2, maybe there are some mismatch with the KSDK version and IDE version. Thank you for your feedback about this, I will inform the relative engineers to update it.

The latest KSDK version is version 2.0, it is much easier to use.
you need to download the KSDK for FRDM-KL25Z and install it. Please check the below link for how to install it
How to: install KSDK 2.0

After you install it , you can see the getting started document in the installation folder
[...]\SDK_2.0_FRDM-KL25Z\docs

Regards
Daniel

Actions

Like • 0

Recommended Content

I would like the LAY-27962_C.brd file in ASCII (ALG) or already imported into Altium Designer

Simple GPIO Example - quandry

Sink/source current of i.MX6UL I/O

what is value of GPIO source/sink current per pin on i.MX6?

Migration from MPC8270 to MPC8271

ABOUT NXP
Investors
Partners
Careers

RESOURCES
Mobile Apps
Press, News, Blogs
Contact Us

FOLLOW US

NEWS 11 Jan 2016
Photo Advisory -- US Secretary of Transportation, Anthony Foxx, Meets With NXP CEO Rick Clemmer at CES 2016
Read More

Privacy | Terms of Use | Terms of Sale | Feedback

©2006-2016 NXP Semiconductors. All rights reserved.

Home | Top of page | Help

© 2016 Jive Software | Powered by jive