

450W Spark Machine



1.Introduction:

This mini stage spark effect machine is a lightweight and highly adaptable stage atmosphere device. Adopting resistance heating technology and equipped with a 6-key wireless remote control system, it features simple operation, stable spark output, safe performance, and quiet running.

Compact in size and light in weight, the machine is extremely portable. It is widely applicable to indoor and outdoor events such as wedding ceremonies, stage performances, galas, and commercial press conferences. Capable of creating bright and vivid cold spark effects, it greatly enhances the on-stage atmosphere, making it an ideal choice for medium- and small-scale stage effect arrangements.

11-Feature:

- Environmental protection, safety: no gunpowder and no irritant
- Support wireless control and DMX, operation is more easy and convenient.
- Maintenance:
- Please clean the machine regularly. It will reduce the replacement and repair cost of spare parts.
- Do not use for a long time, to clean the machine and make extra powder out.
- E1: Probe error E2: Not heating E3: Overtemperature E4: Brushless fan error

2. Safety instructions

To ensure normal operation of the equipment as well as personal and venue safety, please strictly follow the specifications below before use. You shall be fully liable for any damage or safety incidents caused by improper operation.

Electrical Safety: Verify that the on-site supply voltage matches the equipment before use. Never operate the device under overvoltage. The equipment must be properly grounded. Do not disassemble the power cord or modify the circuit arbitrarily. Avoid circuit overload and use a dedicated power socket exclusively for the unit.

Venue Safety: Place the equipment on a flat, stable, and dry surface. Do not use it in tilted or suspended positions. Keep no flammables, ceiling decorations, or lighting fixtures within 2 to 5 meters above the device. Keep fabrics, paper, aerosols, and other flammable and explosive materials away within a 1-meter radius.

Operation Safety: Do not touch the hot sections or spark outlet while the equipment is running or heating. Keep children and unauthorized personnel away from the operating area. Assign a dedicated operator to supervise the device at all times; never leave it unattended during operation.

Consumables Usage: Only use dedicated stage effect consumables for this equipment. Do not add powder impurities or non-compliant consumables, which may clog the outlet and cause malfunctions. Do not overfill the hopper; follow the rated capacity of 60 grams strictly.

Environmental Requirements: Do not use the device in rainy, damp, waterlogged areas, or under direct intense sunlight. Ensure good ventilation for indoor use; avoid prolonged operation in confined narrow spaces.

Malfunction Precautions: Immediately cut off the power and stop operation if abnormal noise, overheating, spark failure, or power anomalies occur. Do not

continue using a faulty unit. Unauthorized disassembly and repair by non-professionals are prohibited.

- Keep away from humidity, water, and dust! Avoid placing the device in a location with high humidity or excessive dust.
- Place the device on a firm ground!
- To avoid vibrations, always place the device on a firm surface.
- Do not use chemicals for cleaning!
- Use a clean and dry cleaning rag to remove dust. Metal parts can be cleaned with a damp cleaning rag. Before cleaning, always unplug the device from the power supply.
- If the device is not working properly,
- If problems occur, unplug the device from the power supply. The user should not try to service the device independently. All repairs and service must be performed by a qualified technician.
- Eye Protection
- The eye protection warning icon is shown to indicate that you must protect your eyes when close to the machine during machine operation.
- The safety distance from the audience must be two meters
- Never aim the nozzle at people and keep a distance of 1 meter from the nozzle. Don't spray on food.
- Damages caused by the disregard of this user manual are not subject to warranty. The dealer will not accept liability for any consequent secondary failures. Only skilled workers are allowed to carry out the electrical connections. All electrical and mechanical connections have to be carried out according to the European safety standards.
- Outdoor powder cannot be used indoors! When using outdoor powder, there should be no carpet around the spark machine, and other inflammable articles!
- The powder should not be exposed to the air. If a bag of powder is not used up, it should be kept in a sealed condition and not exposed to open fire.
- NOTE: The machine must be vertical if it has powder in the tank. It must take out all the powder when the machine is shipped.

3-Equipment Operation Steps

Equipment Preparation Place the unit steadily in the working area. Inspect the main body, power cord, and fuse for any damage. Open the material box and fill it with dedicated effect consumables (maximum capacity: 60 g). Close the lid tightly to prevent powder leakage.

Power-on & Preheating Connect to a compatible power supply and turn on the main switch. The device will enter standby mode. Activate the heating function via remote control; the unit starts preheating at 365 W. Do not start the spark spraying

function until preheating is finished and the device is ready.

Gear Adjustment & Spark Spraying Three spray modes are available for flexible selection according to on-site needs:

Gear 1 (400W): Low spray height, ideal for short-range small-scale atmospheric scenes.

Gear 2 (425W): Moderate spray height, suitable for regular stage performances.

Gear 3 (480W): The spray height reaches 2–4 meters for enhanced visual effects.

Use the 6-key wireless remote control to switch gears, start or stop spraying with one click. It features easy operation and quick response.

Shutdown & Post-operation Handling After use, stop the spark spraying first. Wait for the device to cool down, then turn off the main power and disconnect the power cord. When the unit is fully cooled, clean residual consumables inside the material box and dust on the body, then store the equipment properly.

4-Daily Maintenance

After each use, clean residual powder and debris from the material box and spark outlet. Accumulated dirt may cause clogging, impair performance, and shorten service life.

Regularly inspect the power cord, plug, and fuse. Replace with compatible parts promptly if there is wire aging, a blown fuse, or loose connections.

Store the equipment in a dry, ventilated, and dust-free place. Keep it away from moisture, compression, and direct sunlight. Cut off power and empty all consumables for long-term storage, and run a test periodically.

The unit is made of iron and stainless steel. Wipe it with a dry cloth only. Do not rinse directly with water to prevent circuit short circuit and damage

5. Technical data

Wireless RF Controllers N-1 Receiver/Dip

Switch + W-9 Usage Instructions:

When the heating is complete, the indicator light is green ; when the heating is not finished, the indicator light is red . The machine is not effective until the heating is complete. The amount and height of the spark is controlled by the remote control.



ON: Equipment heating

OFF: Turn off heating

1: Spray height 1

2: Spray height 2

3: Spray height 3

STOP: Stop spraying

Specification :

Rated voltage (US)	AC100-120 V
Rated voltage (EU)	AC220-240 V
Rated power	450 W
Fuse	10 A
Pre-heating time	3-4 min
Spark max height	2-4M
Spark height change	support
Wireless controller distance	0-20M
Display screen	Digital display board
DMX	support
DMX channel	1CH
DMX range	1-512
Net weight	2.45kg
Gross weight	7.8 Kg
Machine size	3.1kg
Carton size	19.5*19.5*26cm
Operating noise	> 65dB

6. Operation

Before using:

- Never stand directly below the device when it is being mounted, removed, or serviced. Have a qualified technician
- Check the device annually and additionally before placing it into service if it has been stored for an extended period of time.
- Install the device in a secure location that is inaccessible to unauthorized persons. This machine can only be used by adults.
- Make sure there is no flammable material within a 10 ft radius of the device. There can be no objects blocking the use of the machine.
- Be sure that the local power outlet matches that or the required voltage for your machine.
- Can not join any flammable liquid, such as oil and gas.
- Be sure the lid is well covered before using the machine, or the spark will splash out.

Usage method:

- Place the unit on a flat, dry surface. The machine can not be sideways. Please pay attention to keep upright. Otherwise, the spark will not be vertical and will probably damage the machine.
- Fill the powder reservoir with our powder only then tighten the cap .
- The device starts to heat up. This process takes 5 minutes. Meanwhile, the display shows “UP”.
- The heating process is finished. The display shows “READ”

READY:	The green light indicates that the machine is ready to work.	
HEAT:	Orange Indicates that the machine is ready to heat.	
DMX:	Blue light flashes to indicate a successful DMX connection and displays the current address code.	
FAUL:	The red light indicates an error alarm.	
Catalog function		
DMX	001-512	DMX512 Address
Mode	DMX	DMX mode
	AUTO	AUTO mode
TEMP	360-460	Temperature regulation range360-460°
Dev	HF251216	version number
Reset	OK	Reset (ineffective)

7. DMX CHANNELS

When using the DMX mode, one channels are occupied.

1 CH DMX Channel		
CH1	0-9	No function
	10-255	Spark low to high on

8. Warranty Instructions

- ◆ Warranty period: one year (the date of purchase)
- ◆ IF the buyers do not use the same supplier's powder, the machine warranty period will be 3 months. The buyer will pay for the expenses if there are any component changes.
- ◆ In such In the following cases, the product will not be guaranteed:
 - A: the product has been incorrectly operated and used inadvertently, for example, over load, over pressure, and firing;
 - B: the product was broken because of careless handling;
 - C: due to poor use of environmental factors and sound quality problems, such as: humidity, voltage instability, etc.;
 - D: products have been modified by non-factory personnel.
- ◆ Products that comply with the warranty provisions will not be charged maintenance fees and accessory costs for more than the warranty period of the product, only the corresponding parts and finished goods costs.
- ◆ The contents of this warranty card are subject to interpretation by the company. If the user is unknown, please contact the local distributors.
- ◆ Not covered by the warranty include: packing box, packaging, product shell and hanger, remote control transmitter battery.