

DRV8825 connections.

		EN	1	16	- V _M (Ext supply)	
			2 M0	15	- GND	
used for microstepping	{		3 M1	14	for coils, connection with motor.	B ₂
			4 M2	13		B ₁
		RST	5	12		A ₂
		STEP	6	11		A ₁
Arduino {		Pin 2 - Step -	7	10		
		Pin 3 - Direct -	8	9	- GND Arduino	