

KIOSK POSTER · PRINT AT EVERY STATION

Five Things the System Will Refuse

These are quality rules enforced by the server — not errors, and not the kiosk being broken. There are no operator overrides. Here is what each one means and what to do.

1

Scrap needs a reason

Any scrap quantity without a reason is rejected — on production reports **and** on clock-outs. Zero scrap needs nothing.

Say it like this: "Pick the reason tile — then it goes through."

2

Out of tolerance is not recorded

The server refuses the value; the on-screen preview is advisory only. Re-measure — or if the part truly is out, tap **HOLD + FILE NCR**: it files a pre-filled NCR, holds the job, clocks out everyone's open labor, and shows the NCR number big enough to tag the part.

Say it like this: "The red strip isn't an error — it's a decision point."

3

Gauge refused

Gauge-required steps demand scanning a calibration-current gauge first. Out-of-cal, inactive, unknown, or no-due-date gauges are refused before the value is even checked.

Say it like this: "Get a current gauge — don't retype the same code."

4

"Previous operations must be completed first"

Sequence gating blocks clock-in while earlier operations at **other** work centers are still open. Earlier operations at your own work center do not block you — **unless one of them is ON HOLD**, which stops the whole group at that machine until the hold is resolved.

Say it like this: "The job isn't ready for you yet — check with your lead."

5

COMPLETE can be refused — clock-out never is

Completing with required step records missing is refused with a list of exactly what is owed. But clocking out at target always saves your time and counts — the job just stays in progress until the steps exist.

Say it like this: "Your hours are never trapped. Finish the steps, then complete."

KIOSK FACTS · idle logout ~4 min (single-operator) · crew badge sessions last 5 min — re-scan is normal · corrections = CORRECT with a reason, never retype · OFFLINE = nothing queues; use the paper form · supervisors resume holds from the desktop, not the kiosk