

Piezoelectric MEMS Speaker

This model analyzes a piezoelectric microelectromechanical system (MEMS) speaker presented in Ref. 1, 2, and 3. The speaker, composed of four triangular membranes, uses a layer of lead zirconate titanate (PZT) material with two electrodes on opposing faces as actuator. The triangular membranes are separated by narrow gaps of air that allow for larger deflections of the membrane. The thermoviscous losses in the gaps limit the airflow, thus allowing the four actuators to behave acoustically as a single membrane.

Model Definition

The PZT material, which seats on top of a silicon layer, is excited with a voltage that makes the membrane move and create sound. Figure 1 shows a schematic view of the speaker. The four triangular membranes are separated by narrow gaps of air. The acoustic behavior in the gaps (shown in green) is modeled with the full thermoviscous acoustic formulation using the Thermoviscous Acoustics, Frequency Domain physics interface.




Figure 1: Schematic representation of the piezoelectric MEMS speaker, with the areas where thermoviscous losses are relevant highlighted in green.

The four triangular membranes form a square with approximately 4 mm sides. The membrane is backed by a back volume of roughly 24 mm³. The volume acts as a spring (compliance) changing the acoustic properties of the speaker.

The tutorial takes advantage of the existing symmetries to model only a quarter of the speaker and represent the rest by using symmetry features. The speaker is located in an infinite baffle and uses a voltage difference acting between the faces of the PZT material to create vibrations that will propagate as acoustic perturbations. The acting voltage contains a constant component, usually called the bias voltage (DC) and an alternating voltage (AC or perturbation contribution), following

$$V_0 = V_{DC} + V_{AC} \cos(2\pi f \cdot t) \tag{1}$$

where V_0 is the terminal voltage, $V_{\rm DC}$ is the bias voltage, $V_{\rm AC}$ is the alternating voltage, f is the driving frequency, and t is the time. Due to the piezoelectric effect, the PZT material excited with this voltage will induce deformations in the membranes. The piezoelectric material and structures are modeled with the *Solid Mechanics* and the *Electrostatics* physics interfaces, coupled with the *Piezoelectric Effect* multiphysics coupling and associated material models.

The air gap between the membranes is $9 \mu m$ wide, and this gap is in the order of magnitude of the viscous boundary layer in air (at the frequencies studied here). The boundary layer thickness is given by

$$\delta_{\rm v} = \sqrt{\frac{2\mu}{\omega\rho}} = 0.22 \text{ mm} \cdot \sqrt{\frac{100 \text{ Hz}}{f}}$$
 (2)

where δ_v is the viscous boundary layer thickness (in the second equation the material properties of air have been entered). At the resonance frequency of 9 kHz, δ_v takes the value of 23.2 μ m, on the same order of magnitude as the gap. This indicates that the thermoviscous losses are likely to modify the response of the speaker at the driving frequency. To capture the losses, the *Thermoviscous Acoustics, Frequency Domain* is used to model the acoustics in the air gaps and a small surrounding volume.

The rest of the acoustic domains are captured using the *Pressure Acoustics*, *Frequency Domain* physics interface. Here the thermoviscous boundary layers are captured through the *Thermoviscous Boundary Layer Impedance* boundary condition. The open domain conditions surrounding the speaker is modeled with a *Perfectly Matched Layer*. The *Exterior Field Calculation* feature is used to obtain the acoustic field at any point in the exterior domain.

The harmonic component of the displacement of the membrane is shown in Figure 2. Note how the excitation produces displacement perpendicular to the plane of the membrane through bending.




Figure 2: Harmonic part of the displacement magnitude at the membranes.

Figure 3 shows the distribution of the electric potential in the membranes. The electric potential variation takes place almost exclusively in the vertical direction. As seen in Figure 4, the small dimensions of the speaker means that the computational domain does not even capture a full wavelength at the highest frequency analyzed, 20 kHz.




Figure 3: Harmonic variation of the electric potential. freq(19)=20000 Hz Volume: Acoustic pressure (Pa)




Figure 4: Total acoustic pressure at 20 kHz.

Figure 5 shows the instantaneous acoustic velocity around the air gaps. The high velocity gradients present in the air gaps create viscous shear losses that damp the natural frequency of the membranes. Note that the section shown is close to the center of the membrane, so the complete section has a velocity larger than 0.




Figure 5: Instantaneous local velocity at 9 kHz.

The logarithmic thermoviscous losses, shown in Figure 6 demonstrate how most of the thermoviscous losses are concentrated in the air gap, suggesting that a Narrow Region Acoustics feature (using the slit option) in Pressure Acoustics could potentially be enough to capture the losses caused by the air gap. This requires that the gap is not significantly modified during operation. This is discussed further in the Notes About the COMSOL Implementation section below.




Figure 6: Logarithmic volumetric thermoviscous losses around the air gap.

Figure 7 shows the magnitude and phase of the electric impedance of the speaker. The electric impedance shows excellent agreement with the experimental results in Ref. 1, 2, and 3.




Figure 7: Electric impedance of the speaker, magnitude and phase.

Notes About the COMSOL Implementation

The model uses the Small-Signal Analysis to analyze the static effect of the bias voltage and the harmonic perturbation caused by the alternating voltage. To include the effects of the DC part (prestress and deformation) it is important that the **Include geometric** nonlinearity is selected in the Frequency Domain Perturbation study step.

The model is solved in the frequency domain which assumes small deformations (small signal assumption). This means that, for example, topological changes of the air gap are not captured (the gap effectively remains the same) in the simulation. This is an assumption made when working in the frequency domain. At the resonance the maximum deflection is a bout 4 µm which is on top of the static DC deformation of about 3 µm, see Figure 8. The gap width is 9 µm and the gap height is 17 µm, so at resonance the small signal assumption is probably not fully valid. The topological changes can be included in the model by using the Moving Mesh functionality. Including the dynamic topology changes on top of the DC deformation requires solving a transient model.






Figure 8: Stationary deformation of the membrane due to the DC bias voltage.

The model uses the Added Mass feature under Solid Mechanics to represent the masses of the electrodes, which have a significant effect on the resonance frequencies.

References

- 1. F. Stoppel, A. Männchen, F. Niekiel, D. Beer, T. Giese, and B. Wagner, "New integrated full-range MEMS speaker for in-ear applications," IEEE Micro Electro Mechanical Systems (MEMS), 2018.
- 2. A.Männchen, F. Stoppel, D. Beer, F. Niekiel, and B. Wagner, "In-ear headphone system with piezoelectric MEMS driver," Audio Engineering Society, 2018.
- 3. A.Männchen, F. Stoppel, T. Brocks, F. Niekiel, D. Beer, and B. Wagner, "Design and electroacoustic analysis of a piezoelectric MEMS in-ear headphone," Audio Engineering Society, 2018.

Application Library path: Acoustics Module/Electroacoustic Transducers/ piezo_mems_speaker

Modeling Instructions

From the File menu, choose New.

In the New window, click Model Wizard.

MODEL WIZARD

- I In the Model Wizard window, click **3D**.
- 2 In the Select Physics tree, select Structural Mechanics>Electromagnetics-Structure Interaction>Piezoelectricity>Piezoelectricity, Solid.
- 3 Click Add.
- 4 In the Select Physics tree, select Acoustics>Pressure Acoustics>Pressure Acoustics, Frequency Domain (acpr).
- 5 Click Add.
- 6 In the Select Physics tree, select Acoustics>Thermoviscous Acoustics> Thermoviscous Acoustics, Frequency Domain (ta).
- 7 Click Add.
- 8 Click Study.
- 9 In the Select Study tree, select Preset Studies for Selected Physics Interfaces> Electrostatics>Small-Signal Analysis, Frequency Domain.
- 10 Click Done.

GEOMETRY I

Adjust the units of the model to um.

- I In the Model Builder window, under Component I (compl) click Geometry I.
- 2 In the Settings window for Geometry, locate the Units section.
- 3 From the Length unit list, choose μm .

Import the parameters from an external file. This file contains parameters like dimensions, maximum frequency and voltage that define the current model.

GLOBAL DEFINITIONS

Parameters 1

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.
- 3 Click **Load from File**.
- 4 Browse to the model's Application Libraries folder and double-click the file piezo_mems_speaker_parameters.txt.


Import the geometry from an external file.

GEOMETRY I

- I In the Geometry toolbar, click Insert Sequence and choose Insert Sequence.
- 2 Browse to the model's Application Libraries folder and double-click the file piezo_mems_speaker_geom_sequence.mph.
- 3 In the Geometry toolbar, click **Build All**.
- 4 Click the Show Grid button in the Graphics toolbar.
- **5** Click the **Transparency** button in the **Graphics** toolbar.

The picture should like this.

6 In the Model Builder window, under Component I (compl) click Geometry I.



7 Click the Transparency button in the Graphics toolbar.

DEFINITIONS

Linear Extrusion I (linext I)

- I In the Definitions toolbar, click / Nonlocal Couplings and choose Linear Extrusion. Add a **Linear Extrusion** feature for use when generating result plots later on.
- 2 In the Settings window for Linear Extrusion, locate the Source Selection section.
- 3 From the Geometric entity level list, choose Edge.
- **4** Select Edges 36, 91, and 141 only.
- 5 Locate the Source Vertices section. Click to select the Activate Selection toggle button.
- **6** Select Point 11 only.
- 7 Click to select the Activate Selection toggle button.
- **8** Select Point 65 only.
- **9** Locate the **Destination Vertices** section. Click to select the **Activate Selection** toggle button.

- 10 Select Point 11 only.
- II Click to select the **Activate Selection** toggle button.
- **12** Select Point 65 only.

Perfectly Matched Layer I (pml1)

- I In the Definitions toolbar, click MP Perfectly Matched Layer.
- 2 In the Settings window for Perfectly Matched Layer, locate the Domain Selection section.
- 3 From the Selection list, choose PML Domains.
- 4 Locate the Geometry section. From the Type list, choose Cylindrical.
- 5 Locate the Scaling section. From the Physics list, choose Pressure Acoustics, Frequency Domain (acpr).

GEOMETRY I

In the Model Builder window, collapse the Component I (compl)>Geometry I node.

MATERIALS

Apply materials to the model. Use the Air and Silicon materials from the Built-in category and the PZT material from the Piezoelectric category.

ADD MATERIAL

- I In the Home toolbar, click **Add Material** to open the Add Material window.
- 2 Go to the Add Material window.
- 3 In the tree, select Built-in>Air.
- 4 Click Add to Component in the window toolbar.
- 5 In the tree, select Piezoelectric>Lead Zirconate Titanate (PZT-4).
- 6 Click Add to Component in the window toolbar.
- 7 In the tree, select Built-in>Silicon.
- **8** Click **Add to Component** in the window toolbar.
- 9 In the Home toolbar, click 👯 Add Material to close the Add Material window.

MATERIALS

Silicon (mat3)

- I In the Settings window for Material, locate the Geometric Entity Selection section.
- 2 From the Selection list, choose Silicon Domains.

Lead Zirconate Titanate (PZT-4) (mat2)

- I In the Model Builder window, click Lead Zirconate Titanate (PZT-4) (mat2).
- 2 In the Settings window for Material, locate the Geometric Entity Selection section.
- 3 From the Selection list, choose PZT Domains.

Air (mat I)

- I In the Model Builder window, click Air (mat I).
- 2 In the Settings window for Material, locate the Geometric Entity Selection section.
- 3 From the Selection list, choose Air Domains.

SOLID MECHANICS (SOLID)

- I In the Model Builder window, under Component I (compl) click Solid Mechanics (solid).
- 2 In the Settings window for Solid Mechanics, locate the Domain Selection section.
- 3 From the Selection list, choose Structural Domains.

Add the Piezoelectric Material feature to the PZT domain so the piezoelectric forces are computed correctly.

Piezoelectric Material I

- I In the Model Builder window, under Component I (compl)>Solid Mechanics (solid) click Piezoelectric Material I.
- 2 In the Settings window for Piezoelectric Material, locate the Domain Selection section.
- 3 From the Selection list, choose PZT Domains.

Fixed Constraint I

- I In the Physics toolbar, click **Boundaries** and choose **Fixed Constraint**.
- 2 In the Settings window for Fixed Constraint, locate the Boundary Selection section.
- 3 Click Clear Selection.
- **4** Select Boundaries 45, 46, 111, 113, 142–144, and 146 only.

Symmetry I

- I In the Physics toolbar, click **Boundaries** and choose Symmetry.
- 2 In the Settings window for Symmetry, locate the Boundary Selection section.
- 3 From the Selection list, choose Symmetric Boundaries.

Add the mass representing the electrodes as this mass influences the eigenfrequencies of the system.

Added Mass - Pt Electrode

- I In the Physics toolbar, click **Boundaries** and choose Added Mass.
- 2 In the Settings window for Added Mass, type Added Mass Pt Electrode in the Label text field.
- 3 Locate the Boundary Selection section. From the Selection list, choose Ground.
- **4** Locate the **Added Mass** section. In the ρ_A text field, type rho_pt*th_pt.

Added Mass - Au Electrode

- I In the Physics toolbar, click Boundaries and choose Added Mass.
- 2 In the Settings window for Added Mass, type Added Mass Au Electrode in the Label text field.
- 3 Locate the Boundary Selection section. From the Selection list, choose Terminal.
- **4** Locate the **Added Mass** section. In the ρ_A text field, type rho_au*th_au.

To reduce the computation time of the model, only model the electrostatics effects in the membrane and the air around the gap.

ELECTROSTATICS (ES)

- I In the Model Builder window, under Component I (compl) click Electrostatics (es).
- 2 In the Settings window for Electrostatics, locate the Domain Selection section.
- 3 From the Selection list, choose Electrostatics Domains.

Charge Conservation, Piezoelectric I

- I In the Model Builder window, under Component I (compl)>Electrostatics (es) click Charge Conservation, Piezoelectric I.
- 2 In the Settings window for Charge Conservation, Piezoelectric, locate the Domain Selection section.
- 3 From the Selection list, choose PZT Domains.

Ground I

- I In the Physics toolbar, click **Boundaries** and choose **Ground**.
- 2 In the Settings window for Ground, locate the Boundary Selection section.
- 3 From the Selection list, choose Ground.

Terminal I

- I In the Physics toolbar, click **Boundaries** and choose Terminal.
- 2 In the Settings window for Terminal, locate the Boundary Selection section.
- **3** From the **Selection** list, choose **Terminal**.

- 4 Locate the Terminal section. From the Terminal type list, choose Voltage.
- **5** In the V_0 text field, type V_DC+linper(V_AC).

The speaker has a bias voltage that will be considered in the **Stationary** step of the analysis. Use the linper operator to discern the variable part of the voltage that will be used in the Frequency Domain Perturbation step.

PRESSURE ACOUSTICS, FREQUENCY DOMAIN (ACPR)

- I In the Model Builder window, under Component I (compl) click Pressure Acoustics, Frequency Domain (acpr).
- 2 In the Settings window for Pressure Acoustics, Frequency Domain, locate the Domain Selection section.
- 3 From the Selection list, choose Pressure Acoustics Domains.
- **4** Click to expand the **Discretization** section.

Symmetry I

- I In the Physics toolbar, click **Boundaries** and choose Symmetry.
- 2 In the Settings window for Symmetry, locate the Boundary Selection section.
- 3 From the Selection list, choose Symmetric Boundaries.

Exterior Field Calculation I

- I In the Physics toolbar, click **Boundaries** and choose **Exterior Field Calculation**.
- 2 In the Settings window for Exterior Field Calculation, locate the Boundary Selection section.
- 3 From the Selection list, choose Exterior Field Boundaries.
- 4 Locate the Exterior Field Calculation section. From the Condition in the $x = x_0$ plane list, choose Symmetric/Infinite sound hard boundary.
- 5 From the Condition in the $y = y_0$ plane list, choose Symmetric/ Infinite sound hard boundary.
- 6 From the Condition in the $z = z_0$ plane list, choose Symmetric/ Infinite sound hard boundary.

Thermoviscous Boundary Layer Impedance 1

- I In the **Physics** toolbar, click **Boundaries** and choose Thermoviscous Boundary Layer Impedance.
- 2 In the Settings window for Thermoviscous Boundary Layer Impedance, locate the Fluid Properties section.
- 3 From the Fluid material list, choose Air (mat1).

4 Select Boundaries 3, 44, 47, and 141 only.

THERMOVISCOUS ACOUSTICS, FREQUENCY DOMAIN (TA)

- I In the Model Builder window, under Component I (compl) click Thermoviscous Acoustics, Frequency Domain (ta).
- 2 In the Settings window for Thermoviscous Acoustics, Frequency Domain, locate the **Domain Selection** section.
- 3 From the Selection list, choose Thermoviscous Domains.

Symmetry 1

- I In the Physics toolbar, click **Boundaries** and choose Symmetry.
- 2 In the Settings window for Symmetry, locate the Boundary Selection section.
- 3 From the Selection list, choose Symmetric Boundaries.

Add the missing multiphysics couplings that will handle the interaction between the different physics. Thermoviscous acoustics to the structure, pressure acoustics to the structure, and the coupling between thermoviscous acoustics and pressure acoustics.

MULTIPHYSICS

Thermoviscous Acoustic-Structure Boundary I (tsb1)

- I In the Physics toolbar, click Multiphysics Couplings and choose Boundary> Thermoviscous Acoustic-Structure Boundary.
- 2 In the Settings window for Thermoviscous Acoustic-Structure Boundary, locate the **Boundary Selection** section.
- 3 From the Selection list, choose All boundaries.

Acoustic—Thermoviscous Acoustic Boundary I (atb1)

- I In the Physics toolbar, click Authority Multiphysics Couplings and choose Boundary>Acoustic— Thermoviscous Acoustic Boundary.
- 2 In the Settings window for Acoustic-Thermoviscous Acoustic Boundary, locate the **Boundary Selection** section.
- 3 From the Selection list, choose All boundaries.

Acoustic-Structure Boundary I (asb1)

- I In the Physics toolbar, click Authorities Couplings and choose Boundary>Acoustic— Structure Boundary.
- 2 In the Settings window for Acoustic-Structure Boundary, locate the Boundary Selection section.

3 From the Selection list, choose All boundaries.

The thermoviscous boundary layer impedance includes the viscous and thermal losses in the thin boundary layers.

Thermoviscous Boundary Layer Impedance I (tvbI)

- I In the Physics toolbar, click 🖳 Attributes and choose Thermoviscous Boundary Layer Impedance.
- 2 In the Settings window for Thermoviscous Boundary Layer Impedance, locate the **Boundary Selection** section.
- 3 From the Selection list, choose All Boundaries.
- 4 Locate the Fluid Properties section. From the Fluid material list, choose Air (mat1).

MESH I

In this model, the mesh is set up manually. Proceed by directly adding the desired mesh component.

Mapped I

- I In the Mesh toolbar, click A More Generators and choose Mapped.
- 2 Click the Wireframe Rendering button in the Graphics toolbar.
- **3** Select Boundaries 36, 73, 81, 90, and 121 only.
- 4 In the Settings window for Mapped, click to expand the Reduce Element Skewness section.
- 5 Select the Adjust edge mesh check box.

Size 1

- I Right-click Mapped I and choose Size.
- 2 In the Settings window for Size, locate the Element Size section.
- 3 Click the **Custom** button.
- 4 Locate the Element Size Parameters section.
- 5 Select the Maximum element size check box. In the associated text field, type dvisc*4.

Distribution I

- I In the Model Builder window, right-click Mapped I and choose Distribution.
- 2 Select Edge 35 only.
- 3 In the Settings window for Distribution, locate the Distribution section.
- 4 From the Distribution type list, choose Predefined.
- 5 In the Element ratio text field, type 2.

6 Select the **Symmetric distribution** check box.

Distribution 2

- I Right-click Mapped I and choose Distribution.
- **2** Select Edge 102 only.
- 3 In the Settings window for Distribution, locate the Distribution section.
- 4 From the Distribution type list, choose Predefined.
- 5 In the Element ratio text field, type 3.

Distribution 3

- I Right-click Mapped I and choose Distribution.
- 2 Select Edge 81 only.
- 3 In the Settings window for Distribution, locate the Distribution section.
- 4 From the Distribution type list, choose Predefined.
- 5 In the Element ratio text field, type 3.
- 6 Select the Reverse direction check box.

Distribution 4

- I Right-click Mapped I and choose Distribution.
- **2** Select Edges 72 and 141 only.
- 3 In the Settings window for Distribution, locate the Distribution section.
- 4 In the Number of elements text field, type 3.

Size

In general, 5 to 6 second-order elements per wavelength are needed to resolve the waves. For more details, see *Meshing (Resolving the Waves)* in the *Acoustics Module User's Guide*. In this model, use 6 elements per wavelength.

- I In the Model Builder window, under Component I (compl)>Mesh I click Size.
- 2 In the Settings window for Size, locate the Element Size section.
- **3** Click the **Custom** button.
- 4 Locate the Element Size Parameters section. In the Maximum element size text field, type lambda_min/6.
- 5 In the Minimum element size text field, type dvisc/2.
- 6 In the Maximum element growth rate text field, type 1.3.
- 7 Click III Build All.


Free Triangular I

- I In the Mesh toolbar, click More Generators and choose Free Triangular.
- **2** Select Boundaries 16, 35, 43, 63, 97, 108, 130, and 140 only.

Size 1

- I Right-click Free Triangular I and choose Size.
- 2 In the Settings window for Size, locate the Element Size section.
- **3** Click the **Custom** button.
- 4 Locate the Element Size Parameters section.
- **5** Select the **Maximum element size** check box. In the associated text field, type dvisc*15.
- 6 Select the Maximum element growth rate check box. In the associated text field, type 1.2.
- 7 Click Build Selected.

The mesh should look like this.



Swebt I


- I In the Mesh toolbar, click A Swept.
- 2 In the Settings window for Swept, locate the Domain Selection section.
- 3 From the Geometric entity level list, choose Domain.

4 Select Domains 3, 4, 8–13, 16, 17, 19–28, 30, and 32–37 only.

Distribution I

- I Right-click Swept I and choose Distribution.
- **2** Select Domains 4, 10, 11, 13, 17, 20, 23, 25, 27, 30, 33, 35, and 37 only.
- 3 In the Settings window for Distribution, locate the Distribution section.
- 4 In the Number of elements text field, type 2.
- 5 Click Build Selected.

The mesh will be swept through the thermoviscous acoustics domains. This will reduce the computational cost of the analysis. The mesh should look like this.



Free Tetrahedral I

- I In the Mesh toolbar, click A Free Tetrahedral.
- 2 In the Settings window for Free Tetrahedral, locate the Domain Selection section.
- 3 From the Geometric entity level list, choose Domain.
- **4** Select Domains 1, 2, 5, 6, 29, and 31 only.
- 5 Click Build Selected.

Swebt 2

In the Mesh toolbar, click A Swept.

Distribution I

- I Right-click Swept 2 and choose Distribution.
- 2 In the Settings window for Distribution, locate the Distribution section.
- 3 In the Number of elements text field, type 8.
- 4 Click **Build Selected**.

Boundary Layers 1

I In the Mesh toolbar, click Boundary Layers.

Add a boundary layer of a single element on the exterior field calculation boundary. This will guarantee that the gradients are computed correctly.

- 2 In the Settings window for Boundary Layers, locate the Geometric Entity Selection section.
- 3 From the Geometric entity level list, choose Domain.
- **4** Select Domain 6 only.
- 5 Click to expand the Transition section. Clear the Smooth transition to interior mesh check box.

Boundary Layer Properties

- I In the Model Builder window, click Boundary Layer Properties.
- 2 In the Settings window for Boundary Layer Properties, locate the Boundary Selection section.
- 3 From the Selection list, choose Exterior Field Boundaries.
- 4 Locate the Layers section. In the Number of layers text field, type 1.
- 5 Click | Build Selected.

STUDY I

Step 2: Frequency-Domain Perturbation

- I In the Model Builder window, under Study I click Step 2: Frequency-Domain Perturbation.
- 2 In the Settings window for Frequency-Domain Perturbation, locate the Study Settings section.
- **3** In the **Frequencies** text field, type 10 5000 6000 7000 8000 9000 9200 9400 9475 9550 9600 9650 9725 9800 10000 10200 11000 12000 20000.
- 4 Select the Include geometric nonlinearity check box.

It is important to set this option in order for the prestress to be included in the frequency domain perturbation study step.

Solution I (soll)

- 2 In the Model Builder window, expand the Solution I (soll) node.
- 3 In the Model Builder window, expand the Study I>Solver Configurations> Solution I (soll)>Stationary Solver 2 node.
- 4 Right-click Study I>Solver Configurations>Solution I (sol1)>Stationary Solver 2> Suggested Iterative Solver (GMRES with Direct Precon.) (pzel_tsbl_asbl_atbl) and choose Enable.

The iterative solver is more efficient for large models like this one.

5 In the Settings window for Iterative, click **Compute**.

RESULTS

Sound Pressure Level (acpr)

In the Model Builder window, under Results right-click Sound Pressure Level (acpr) and choose Delete.

Acoustic Pressure (ta)

I In the Model Builder window, under Results right-click Acoustic Pressure (ta) and choose Delete.

These plots are not needed for the analysis.

Electric Potential (es)

- I In the Model Builder window, under Results click Electric Potential (es).
- 2 In the Settings window for 3D Plot Group, locate the Selection section.
- 3 From the Geometric entity level list, choose Domain.
- 4 From the Selection list, choose Electrostatics Domains.
- 5 Select the Apply to dataset edges check box.
- **6** Locate the **Color Legend** section. Select the **Show units** check box.
- 7 In the Electric Potential (es) toolbar, click Plot.

Multislice 1

- I In the Model Builder window, expand the Electric Potential (es) node, then click Multislice I.
- 2 In the Settings window for Multislice, locate the Multiplane Data section.
- 3 Find the x-planes subsection. From the Entry method list, choose Number of planes.
- 4 In the Planes text field, type 0.

- 5 Find the y-planes subsection. From the Entry method list, choose Number of planes.
- 6 In the Planes text field, type 5.
- 7 Find the z-planes subsection. From the Entry method list, choose Number of planes.
- 8 In the Planes text field, type 0.

Streamline Multislice 1

- I In the Model Builder window, click Streamline Multislice I.
- 2 In the Settings window for Streamline Multislice, locate the Multiplane Data section.
- 3 Find the x-planes subsection. From the Entry method list, choose Number of planes.
- 4 In the Planes text field, type 0.
- 5 Find the y-planes subsection. From the Entry method list, choose Number of planes.
- 6 In the Planes text field, type 5.
- 7 Find the z-planes subsection. From the Entry method list, choose Number of planes.
- 8 In the Planes text field, type 0.
- 9 In the Electric Potential (es) toolbar, click **Plot**.

The image should look like that in Figure 3.

Acoustic Pressure (ta+acbr)

- I In the Model Builder window, under Results click Acoustic Pressure (acpr).
- 2 In the Settings window for 3D Plot Group, type Acoustic Pressure (ta+acpr) in the Label text field.
- 3 Locate the Selection section. From the Geometric entity level list, choose Domain.
- 4 From the Selection list, choose All except PML.
- 5 Select the Apply to dataset edges check box.

Surface 1

- I In the Model Builder window, expand the Acoustic Pressure (ta+acpr) node.
- 2 Right-click Surface I and choose Delete.

Volume 1

- I In the Model Builder window, right-click Acoustic Pressure (ta+acpr) and choose Volume.
- 2 In the Settings window for Volume, click Replace Expression in the upper-right corner of the Expression section. From the menu, choose Component I (compl)>Multiphysics> atbl.p_t - Total acoustic pressure - Pa.
- **3** Locate the **Expression** section.
- 4 Select the **Description** check box. In the associated text field, type Acoustic pressure.

- 5 Locate the Coloring and Style section. Click Change Color Table.
- 6 In the Color Table dialog box, select Wave>Wave in the tree.
- 7 Click OK.
- 8 In the Settings window for Volume, locate the Coloring and Style section.
- **9** From the Scale list, choose Linear symmetric.

Filter I

- I Right-click Volume I and choose Filter.
- 2 In the Settings window for Filter, locate the Element Selection section.
- 3 In the Logical expression for inclusion text field, type (x < y).

The image should look like that in Figure 4.


Acoustic Pressure, Isosurfaces (ta+acpr)

- I In the Model Builder window, under Results click Acoustic Pressure, Isosurfaces (acpr).
- 2 In the Settings window for 3D Plot Group, type Acoustic Pressure, Isosurfaces (ta+acpr) in the Label text field.
- 3 Locate the Selection section. From the Geometric entity level list, choose Domain.
- 4 From the Selection list, choose All except PML.
- 5 Select the Apply to dataset edges check box.

Isosurface I

- I In the Model Builder window, expand the Acoustic Pressure, Isosurfaces (ta+acpr) node, then click Isosurface I.
- 2 In the Settings window for Isosurface, click Replace Expression in the upper-right corner of the Expression section. From the menu, choose Component I (compl)>Multiphysics> atbl.p_t - Total acoustic pressure - Pa.
- 3 Locate the Expression section.
- 4 Select the **Description** check box. In the associated text field, type Acoustic pressure.

5 In the Acoustic Pressure, Isosurfaces (ta+acpr) toolbar, click Plot. The image should look like this.



Acoustic Velocity (ta)

- I In the Model Builder window, under Results click Acoustic Velocity (ta).
- 2 In the Settings window for 3D Plot Group, locate the Data section.
- 3 From the Parameter value (freq (Hz)) list, choose 9600.
- 4 Locate the Selection section. From the Geometric entity level list, choose Domain.
- 5 From the Selection list, choose Thermoviscous Domains.
- 6 Select the Apply to dataset edges check box.
- 7 Locate the Plot Settings section. Clear the Plot dataset edges check box.
- 8 In the Acoustic Velocity (ta) toolbar, click Plot.

Slice

- I In the Model Builder window, expand the Acoustic Velocity (ta) node, then click Slice.
- 2 In the Settings window for Slice, locate the Plane Data section.
- 3 From the Plane type list, choose General.
- 4 From the Plane entry method list, choose Point and normal vector.

- **5** Find the **Point** subsection. In the **x** text field, type 20.
- 6 In the y text field, type 20.
- 7 Find the Normal vector subsection. In the x text field, type 1.
- 8 In the y text field, type 1.
- **9** In the **z** text field, type 0.
- 10 Select the Additional parallel planes check box.
- II In the Planes text field, type 10.
- 12 In the Acoustic Velocity (ta) toolbar, click Plot.

The image should look like that in Figure 5.

Temperature Variation (ta)

- I In the Model Builder window, under Results click Temperature Variation (ta).
- 2 In the Settings window for 3D Plot Group, locate the Data section.
- 3 From the Parameter value (freq (Hz)) list, choose 9600.
- 4 Locate the Selection section. From the Geometric entity level list, choose Domain.
- 5 From the Selection list, choose Thermoviscous Domains.
- 6 Select the Apply to dataset edges check box.
- 7 Locate the Plot Settings section. Clear the Plot dataset edges check box.
- 8 In the Temperature Variation (ta) toolbar, click **Plot**.

Multislice


- I In the Model Builder window, expand the Temperature Variation (ta) node.
- **2** Right-click **Multislice** and choose **Delete**.

Slice 1

- I In the Model Builder window, right-click Temperature Variation (ta) and choose Slice.
- 2 In the Settings window for Slice, locate the Expression section.
- **3** In the **Expression** text field, type ta.T t.
- 4 Locate the Plane Data section. From the Plane type list, choose General.
- 5 From the Plane entry method list, choose Point and normal vector.
- 6 Find the **Point** subsection. In the x text field, type 20.
- 7 In the y text field, type 20.
- **8** Find the **Normal vector** subsection. In the **x** text field, type 1.
- **9** In the **y** text field, type 1.

- **IO** In the **z** text field, type **0**.
- II Select the Additional parallel planes check box.
- 12 In the Planes text field, type 10.
- 13 Locate the Coloring and Style section. Click Change Color Table.
- 14 In the Color Table dialog box, select Thermal>ThermalWave in the tree.
- I5 Click OK.
- 16 In the Settings window for Slice, locate the Coloring and Style section.
- 17 From the Scale list, choose Linear symmetric.
- 18 In the Temperature Variation (ta) toolbar, click **Plot**.

The image should look like this.



Temperature Variation (ta)

Right-click Temperature Variation (ta) and choose Duplicate.

Logarithmic Thermoviscous Losses (ta)

- I In the Model Builder window, under Results click Temperature Variation (ta) I.
- 2 In the Settings window for 3D Plot Group, type Logarithmic Thermoviscous Losses (ta) in the Label text field.

Slice 1

- I In the Model Builder window, expand the Logarithmic Thermoviscous Losses (ta) node, then click **Slice 1**.
- 2 In the Settings window for Slice, locate the Expression section.
- 3 In the Expression text field, type log10(ta.diss tot).
- 4 Select the **Description** check box. In the associated text field, type log10(Thermoviscous losses).
- **5** Click to expand the **Range** section. Select the **Manual color range** check box.
- 6 In the Minimum text field, type 6.1.
- 7 In the Maximum text field, type 8.1.
- 8 Locate the Coloring and Style section. Click Change Color Table.
- 9 In the Color Table dialog box, select Thermal>HeatCameraLight in the tree.
- IO Click OK.
- II In the Settings window for Slice, locate the Coloring and Style section.
- 12 From the Scale list, choose Linear.

The image should look like that in Figure 6.

Terminal Impedance

- I In the Home toolbar, click Add Plot Group and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Terminal Impedance in the Label text field.
- **3** Click to expand the **Title** section. From the **Title type** list, choose **Label**.
- 4 Locate the Plot Settings section. Select the Two y-axes check box.
- 5 Locate the Axis section. Select the Manual axis limits check box.
- 6 In the x minimum text field, type 18.
- 7 In the x maximum text field, type 20000.
- **8** In the **y minimum** text field, type **0.1**.
- 9 In the y maximum text field, type 150.
- 10 In the Secondary y minimum text field, type -91.
- II In the Secondary y maximum text field, type -20.
- 12 Select the x-axis log scale check box.
- **I3** Select the **y-axis log scale** check box.
- 14 Locate the Legend section. From the Position list, choose Lower left.

Global I

- I Right-click Terminal Impedance and choose Global.
- 2 In the Settings window for Global, locate the y-Axis Data section.
- **3** In the table, enter the following settings:

Expression	Unit	Description
abs(1/es.Y11)/4	kΩ	Magnitude

4 In the Terminal Impedance toolbar, click Plot.

Global 2

- I In the Model Builder window, right-click Terminal Impedance and choose Global.
- 2 In the Settings window for Global, locate the y-Axis section.
- 3 Select the Plot on secondary y-axis check box.
- **4** Locate the **y-Axis Data** section. In the table, enter the following settings:

Expression	Unit	Description
arg((1/es.Y11))	deg	Phase

5 In the Terminal Impedance toolbar, click Plot.

The image should look like that in Figure 7.

Study 1/Solution 1 (3) (sol1)

In the **Results** toolbar, click **More Datasets** and choose **Solution**.

Selection

- I Right-click Study I/Solution I (3) (soll) and choose Selection.
- 2 In the Settings window for Selection, locate the Geometric Entity Selection section.
- 3 From the Geometric entity level list, choose Domain.
- 4 From the Selection list, choose Electrostatics Domains.

Sector 3D I

- I In the Results toolbar, click More Datasets and choose Sector 3D.
- 2 In the Settings window for Sector 3D, locate the Data section.
- 3 From the Dataset list, choose Study I/Solution I (3) (soll).
- 4 Locate the Symmetry section. In the Number of sectors text field, type 4.
- 5 From the Transformation list, choose Rotation and reflection.

Model Thumbnail

- I In the Results toolbar, click **3D Plot Group**.
- 2 In the Settings window for 3D Plot Group, type Model Thumbnail in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Sector 3D 1.
- 4 From the Parameter value (freq (Hz)) list, choose 9600.
- 5 Locate the Plot Settings section. Clear the Plot dataset edges check box.
- **6** Locate the **Color Legend** section. Select the **Show units** check box.
- 7 In the Model Thumbnail toolbar, click **Plot**.
- 8 Click the | | Show Grid button in the Graphics toolbar.
- **9** Click the **Zoom Extents** button in the **Graphics** toolbar.

Volume 1

Right-click Model Thumbnail and choose Volume.

Deformation I

- I In the Model Builder window, right-click Volume I and choose Deformation.
- 2 In the Settings window for Deformation, locate the Scale section.
- 3 Select the Scale factor check box. In the associated text field, type 100.
- 4 In the Model Thumbnail toolbar, click Plot.

Slice 1

- I In the Model Builder window, right-click Model Thumbnail and choose Slice.
- 2 In the Settings window for Slice, locate the Expression section.
- 3 In the Expression text field, type ta.v inst.
- 4 Locate the Plane Data section. From the Plane type list, choose General.
- 5 From the Plane entry method list, choose Point and normal vector.
- 6 Find the Normal vector subsection. In the x text field, type 1.
- 7 In the y text field, type 1.
- **8** In the **z** text field, type 0.
- 9 Select the Additional parallel planes check box.
- 10 In the Planes text field, type 20.
- II Locate the Coloring and Style section. Clear the Color legend check box.
- 12 Click Change Color Table.
- 13 In the Color Table dialog box, select Traffic>Traffic in the tree.

- 14 Click OK.
- 15 In the Settings window for Slice, click to expand the Inherit Style section.
- 16 From the Plot list, choose Volume 1.
- 17 Clear the Color check box.
- **18** Clear the Color and data range check box.
- 19 In the Model Thumbnail toolbar, click Plot.

Deformation I

- I Right-click Slice I and choose Deformation.
- 2 In the Settings window for Deformation, locate the Expression section.
- **3** In the **x-component** text field, type **0**.
- **4** In the **y-component** text field, type **0**.
- 5 In the **z-component** text field, type linext1(w).

Slice 1

In the Model Builder window, right-click Slice I and choose Duplicate.

Slice 2

- I In the Model Builder window, click Slice 2.
- 2 In the Settings window for Slice, locate the Plane Data section.
- 3 Find the Normal vector subsection. In the x text field, type -1.
- 4 Click to expand the Title section. From the Title type list, choose None.
- 5 In the Model Thumbnail toolbar, click **Plot**.
- 6 Click the Go to Default View button in the Graphics toolbar.

Line 1


- I In the Model Builder window, right-click Model Thumbnail and choose Line.
- 2 In the Settings window for Line, locate the Expression section.
- **3** In the **Expression** text field, type **0**.
- 4 Click to expand the **Title** section. From the **Title type** list, choose **None**.
- 5 Locate the Coloring and Style section. From the Coloring list, choose Uniform.
- 6 From the Color list, choose Black.
- 7 Click to expand the Inherit Style section. From the Plot list, choose Volume 1.
- **8** Clear the **Color** check box.
- 9 Clear the Color and data range check box.

Deformation I

Right-click Line I and choose Deformation.

Model Thumbnail

- I In the Model Thumbnail toolbar, click **Plot**. The image should look like this.
- 2 In the Model Builder window, under Results click Model Thumbnail.



Stationary Deformation (prestress)

- I In the Home toolbar, click Add Plot Group and choose 3D Plot Group.
- 2 In the Settings window for 3D Plot Group, type Stationary Deformation (prestress) in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Study I/Solution Store I (sol2).
- 4 Click to expand the **Title** section. From the **Title type** list, choose **Label**.
- **5** Locate the **Color Legend** section. Select the **Show units** check box.

Surface I


- I Right-click Stationary Deformation (prestress) and choose Surface.
- 2 In the Settings window for Surface, locate the Expression section.
- 3 In the Expression text field, type abs (w).

Deformation I

- I Right-click Surface I and choose Deformation.

The stationary deformation should look like this. Note that the stationary deformation is only 3[um] at the center (the displacement scale is exaggerated in the plot). The deformation is small compared to the total membrane thickness of 17[um]. This indicates that the effects of topology changes, that could be captured by the introduction of a Moving Mesh feature, can be disregarded.

3 In the Model Builder window, click Deformation 1.



On-Axis Response at 10 cm


- I In the Home toolbar, click **Add Plot Group** and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type On-Axis Response at 10 cm in the Label text field.
- 3 Locate the Title section. From the Title type list, choose Label.

Octave Band I

- I In the On-Axis Response at 10 cm toolbar, click \to More Plots and choose Octave Band.
- 2 In the Settings window for Octave Band, locate the Selection section.
- 3 From the Geometric entity level list, choose Global.

- 4 Locate the y-Axis Data section. In the Expression text field, type pext (0,0,10[cm]).
- 5 Locate the Plot section. From the Quantity list, choose Continuous power spectral density.
- 6 In the On-Axis Response at 10 cm toolbar, click Plot.

The on-axis response, 10 cm above the speaker, should look like this.



ADD PREDEFINED PLOT

- In the Home toolbar, click Add Predefined Plot to open the Add Predefined Plot window.
- 2 Go to the Add Predefined Plot window.
- 3 In the tree, select Study I/Solution I (I) (soll)>Solid Mechanics>Displacement (solid).
- 4 Click Add Plot in the window toolbar.


RESULTS

Displacement (solid)

- I In the Settings window for 3D Plot Group, locate the Data section.
- 2 From the Parameter value (freq (Hz)) list, choose 9600.
- 3 Locate the Plot Settings section. Clear the Plot dataset edges check box.
- **4** Locate the **Color Legend** section. Select the **Show units** check box.

5 In the Displacement (solid) toolbar, click Plot.

The image should look like that in Figure 2.



Appendix: Geometry Sequence Instructions

From the File menu, choose New.

NEW

In the New window, click Model Wizard.

MODEL WIZARD

- I In the Model Wizard window, click **3D**.
- 2 Click M Done.

GEOMETRY I

Adjust the units of the model to µm.

- I In the Model Builder window, under Component I (compl) click Geometry I.
- 2 In the Settings window for Geometry, locate the Units section.

3 From the Length unit list, choose μm .

Import the parameters from an external file. This file contains parameters like dimensions, maximum frequency and voltage that define the current model.

GLOBAL DEFINITIONS

Parameters 1

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.
- **3** In the table, enter the following settings:

Name	Expression	Value	Description
l_speaker	4 [mm]	0.004 m	Side of the speaker
th_si	15[um]	1.5E-5 m	Thickness of the silicon layer
th_pzt	2[um]	2E-6 m	Thickness of the PZT layer
air_gap	9[um]	9E-6 m	Air gap between the actuators
d_speaker	1.5[mm]	0.0015 m	Back cavity depth

Create a **Work Plane** where the main features of the speaker will be defined. The model uses symmetry to only model one fourth of the geometry. This reduces the computation time.

GEOMETRY I

Click the Show Grid button in the Graphics toolbar.

Work Plane I (wbl)

In the Geometry toolbar, click Work Plane.

Work Plane I (wb I)>Plane Geometry

In the Model Builder window, click Plane Geometry.

Work Plane I (wpl)>Square I (sql)

- I In the Work Plane toolbar, click Square.
- 2 In the Settings window for Square, locate the Size section.
- 3 In the Side length text field, type 1_speaker/2.
- 4 Click | Build Selected.
- 5 Click the **Zoom Extents** button in the **Graphics** toolbar.

Work Plane I (wp I)>Rectangle I (r I)

I In the Work Plane toolbar, click Rectangle.

Create a rectangle that represents the air gap in the membrane. This gap will be modeled using Thermoviscous Acoustics.

- 2 In the Settings window for Rectangle, locate the Size and Shape section.
- 3 In the Width text field, type sqrt(2)/2*1 speaker-air gap.
- 4 In the **Height** text field, type 12*air gap.
- 5 Locate the Position section. From the Base list, choose Center.
- 6 In the xw text field, type 1 speaker/4.
- 7 In the yw text field, type 1 speaker/4.
- 8 Locate the Rotation Angle section. In the Rotation text field, type 45.
- **9** Click to expand the **Layers** section. In the table, enter the following settings:

Layer name	Thickness (µm)
Layer 1	5.5*air_gap

- 10 Select the Layers on top check box.
- II Click Pauld Selected.

Create a new rectangle so that a swept mesh can be generated in the Thermoviscous Acoustics domains.

Work Plane I (wp I)>Rectangle 2 (r2)

- I In the Work Plane toolbar, click Rectangle.
- 2 In the Settings window for Rectangle, locate the Size and Shape section.
- 3 In the Width text field, type sqrt(2)/2*1 speaker-16*air gap.
- 4 In the Height text field, type 12*air gap.
- **5** Locate the **Position** section. From the **Base** list, choose **Center**.
- 6 In the xw text field, type 1_speaker/4.
- 7 In the yw text field, type 1 speaker/4.
- 8 Locate the Rotation Angle section. In the Rotation text field, type 45.

Work Plane I (wpl)>Union I (unil)

- I In the Work Plane toolbar, click Booleans and Partitions and choose Union.
- 2 Click in the **Graphics** window and then press Ctrl+A to select all objects.
- 3 In the Settings window for Union, click **Parallel Selected**.

Work Plane I (wpl)>Delete Entities I (dell)

- I Right-click Plane Geometry and choose Delete Entities.
- 2 In the Settings window for Delete Entities, locate the Entities or Objects to Delete section.
- 3 From the Geometric entity level list, choose Domain.
- 4 On the object unil, select Domains 1, 6, 13, and 17 only.
- 5 Click Pauld Selected.

Extrude the Work Plane I to create the 3D geometry that represents the silicon and the PZT Layers of the membrane.

Extrude | (extl)


- I In the Model Builder window, under Component I (compl)>Geometry I right-click Work Plane I (wpl) and choose Extrude.
- 2 In the Settings window for Extrude, locate the Distances section.
- **3** In the table, enter the following settings:

Distances (µm)		
th_si		
th_si+th_pzt		

4 Select the Reverse direction check box.

5 Click | Build Selected.

The geometry should look like this.



Add a cylinder that will be used for the Thermoviscous Acoustics domains.

Cylinder I (cyll)

- I In the Geometry toolbar, click (Cylinder.
- 2 In the Settings window for Cylinder, locate the Size and Shape section.
- 3 In the Radius text field, type 6*air gap.
- 4 In the **Height** text field, type sqrt(2)/2*1_speaker.
- 5 Locate the Axis section. From the Axis type list, choose Cartesian.
- 6 In the x text field, type 1.
- 7 In the y text field, type 1.
- 8 In the z text field, type 0.
- **9** Click to expand the **Layers** section. In the table, enter the following settings:

Layer name	Thickness (µm)
Layer 1	8*air_gap

10 Clear the Layers on side check box.

- II Select the Layers on bottom check box.
- 12 Select the Layers on top check box.
- 13 Click | Build Selected.

Split the cylinder in two halves and move them to the right location in the following steps.

Partition Objects I (parl)

- I In the Geometry toolbar, click | Booleans and Partitions and choose Partition Objects.
- **2** Select the object **cyll** only.
- 3 In the Settings window for Partition Objects, locate the Partition Objects section.
- 4 From the Partition with list, choose Work plane.
- 5 Click | Build Selected.

Move I (movI)

- I In the Geometry toolbar, click \(\sum_{\text{transforms}} \) Transforms and choose Move.
- **2** Select the object **parl** only.
- 3 In the Settings window for Move, locate the Displacement section.
- 4 In the z text field, type -th_pzt-th_si.
- 5 Locate the Input section. Select the Keep input objects check box.
- 6 Click | Build Selected.

Delete Entities I (dell)

- I In the Model Builder window, right-click Geometry I and choose Delete Entities.
- 2 In the Settings window for Delete Entities, locate the Entities or Objects to Delete section.
- 3 From the Geometric entity level list, choose Domain.
- 4 On the object mov1, select Domains 2, 4, and 6 only.
- 5 On the object parl, select Domains 1, 3, and 5 only.
- 6 Click | Build Selected.

Add a cylinder that represents an infinite domain in front of the speaker.

Cylinder 2 (cyl2)

- I In the Geometry toolbar, click Cylinder.
- 2 In the Settings window for Cylinder, locate the Size and Shape section.
- 3 In the Radius text field, type 1.2*1_speaker.
- 4 In the Height text field, type 1.2*1 speaker.

- 5 Locate the Position section. In the z text field, type -0.6*1 speaker.
- **6** Locate the **Layers** section. In the table, enter the following settings:

Layer name	Thickness (µm)
Layer 1	l_speaker/4

- 7 Select the Layers on bottom check box.
- 8 Select the Layers on top check box.
- 9 Click | Build Selected.
- 10 Click the Wireframe Rendering button in the Graphics toolbar.

Wireframe Rendering simplifies the selection of boundaries in the geometry.

Partition Objects 2 (par2)

- I In the Geometry toolbar, click Booleans and Partitions and choose Partition Objects.
- **2** Select the object **cyl2** only.
- 3 In the Settings window for Partition Objects, locate the Partition Objects section.
- 4 From the Partition with list, choose Work plane.
- 5 Click | Build Selected.

Delete Entities 2 (del2)

- I Right-click Geometry I and choose Delete Entities.
- 2 In the Settings window for Delete Entities, locate the Entities or Objects to Delete section.
- 3 From the Geometric entity level list, choose Domain.
- **4** On the object **par2**, select Domains 1–4, 9, 10, 13, 14, 17, and 18 only.
- 5 Click **Pail Build Selected**.

Block I (blk I)

I In the **Geometry** toolbar, click **Block**.

This block represents the back volume of the speaker.

- 2 In the Settings window for Block, locate the Size and Shape section.
- 3 In the Width text field, type 1_speaker/2.
- 4 In the **Depth** text field, type 1 speaker/2.
- 5 In the Height text field, type d_speaker.
- 6 Locate the Position section. In the z text field, type -th_si-th_pzt-d_speaker.
- 7 Click **Build Selected**.

Work Plane 2 (wp2)

I In the Geometry toolbar, click Work Plane.

This is the first symmetry plane.

- 2 In the Settings window for Work Plane, locate the Plane Definition section.
- 3 From the Plane list, choose yz-plane.

Work Plane 3 (wb3)

I In the Geometry toolbar, click \to Work Plane.

This is the second symmetry plane.

- 2 In the Settings window for Work Plane, locate the Plane Definition section.
- 3 From the Plane list, choose zx-plane.

Union I (uni I)

- I In the Geometry toolbar, click Booleans and Partitions and choose Union.
- 2 Select the object del2 only.
- **3** Click in the **Graphics** window and then press Ctrl+A to select all objects.
- 4 In the Settings window for Union, click | Build Selected.

Partition Objects 3 (par3)

- I In the Geometry toolbar, click Booleans and Partitions and choose Partition Objects.
- **2** Select the object **unil** only.
- 3 In the Settings window for Partition Objects, locate the Partition Objects section.
- 4 From the Partition with list, choose Work plane.
- 5 From the Work plane list, choose Work Plane 2 (wp2).
- 6 Click Pauld Selected.

Partition Objects 4 (par4)

- I In the Geometry toolbar, click Booleans and Partitions and choose Partition Objects.
- **2** Select the object **par3** only.
- 3 In the Settings window for Partition Objects, locate the Partition Objects section.
- 4 From the Partition with list, choose Work plane.
- 5 Click **P** Build Selected.


Delete Entities 3 (del3)

I Right-click Geometry I and choose Delete Entities.

Delete the domains outside of the first quadrant xy-plane.

- 2 In the Settings window for Delete Entities, locate the Entities or Objects to Delete section.
- 3 From the Geometric entity level list, choose Domain.
- **4** On the object **par4**, select Domains 1–14, 17, 21, 48, and 55 only.
- 5 Click | Build Selected.
- 6 Click the **Zoom Extents** button in the **Graphics** toolbar.

The geometry should look like this.



Thermoviscous Domain I

- I In the Geometry toolbar, click 🔓 Selections and choose Cylinder Selection. This selection includes the domains that will be represented using the Thermoviscous Acoustics, Frequency Domain interface.
- 2 In the Settings window for Cylinder Selection, type Thermoviscous Domain 1 in the Label text field.
- 3 Locate the Size and Shape section. In the Outer radius text field, type 6*air gap.
- 4 Locate the Axis section. From the Axis type list, choose Cartesian.
- 5 In the x text field, type 1.
- 6 In the y text field, type 1.
- 7 In the z text field, type 0.

- 8 Locate the Output Entities section. From the Include entity if list, choose All vertices inside cylinder.
- **9** Right-click Thermoviscous Domain I and choose Duplicate.

Thermoviscous Domain 2

- I In the Model Builder window, under Component I (compl)>Geometry I click Thermoviscous Domain 1.1 (cylsel2).
- 2 In the Settings window for Cylinder Selection, type Thermoviscous Domain 2 in the Label text field.
- 3 Locate the Position section. In the z text field, type -th_si-th_pzt.
- 4 Click | Build Selected.

Thermoviscous Domains

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Union Selection.
- 2 In the Settings window for Union Selection, type Thermoviscous Domains in the Label text field.
- 3 Locate the Input Entities section. Click + Add.
- 4 In the Add dialog box, in the Selections to add list, choose Thermoviscous Domain I and Thermoviscous Domain 2.
- 5 Click OK.
- **6** In the **Settings** window for **Union Selection**, locate the **Color** section.
- 7 From the Color list, choose Color 5.

Silicon Laver With Air

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Box Selection.
- 2 In the Settings window for Box Selection, type Silicon Layer With Air in the Label text field.
- 3 Locate the Box Limits section. In the z minimum text field, type -th_si.
- 4 In the z maximum text field, type 0.
- 5 Locate the Output Entities section. From the Include entity if list, choose Entity inside box.

PZT Laver With Air

- I In the Geometry toolbar, click **Selections** and choose Box Selection.
- 2 In the Settings window for Box Selection, type PZT Layer With Air in the Label text field.

- 3 Locate the Box Limits section. In the z minimum text field, type -th si-th pzt.
- 4 In the **z maximum** text field, type -th si.
- 5 Locate the Output Entities section. From the Include entity if list, choose Entity inside box.

Silicon Domains

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Difference Selection.
- 2 In the Settings window for Difference Selection, type Silicon Domains in the Label text field.
- 3 Locate the Input Entities section. Click the + Add button for Selections to add.
- 4 In the Add dialog box, select Silicon Layer With Air in the Selections to add list.
- 5 Click OK.
- 6 In the Settings window for Difference Selection, locate the Input Entities section.
- 7 Click the + Add button for Selections to subtract.
- 8 In the Add dialog box, select Thermoviscous Domains in the Selections to subtract list.
- 9 Click OK.
- 10 In the Settings window for Difference Selection, locate the Color section.
- II From the Color list, choose Color 8.
- 12 Click Build Selected.

PZT Domains

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Difference Selection.
- 2 In the Settings window for Difference Selection, type PZT Domains in the Label text field.
- 3 Locate the Input Entities section. Click the + Add button for Selections to add.
- 4 In the Add dialog box, select PZT Layer With Air in the Selections to add list.
- 5 Click OK.
- 6 In the Settings window for Difference Selection, locate the Input Entities section.
- 7 Click the + Add button for Selections to subtract.
- 8 In the Add dialog box, select Thermoviscous Domains in the Selections to subtract list.
- 9 Click OK.
- 10 In the Settings window for Difference Selection, locate the Color section.
- II From the Color list, choose Color 12.

Structural Domains

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Union Selection.
- 2 In the Settings window for Union Selection, type Structural Domains in the Label text field.
- 3 Locate the Input Entities section. Click + Add.
- 4 In the Add dialog box, in the Selections to add list, choose Silicon Domains and **PZT Domains**.
- 5 Click OK.

All Domains

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Ball Selection.
- 2 In the Settings window for Ball Selection, type All Domains in the Label text field.
- 3 Locate the Ball Radius section. In the Radius text field, type 2*1 speaker.
- 4 Click | Build Selected.

Inner Domains

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Cylinder Selection.
- 2 In the Settings window for Cylinder Selection, type Inner Domains in the Label text field.
- 3 Locate the Size and Shape section. In the Outer radius text field, type 0.8*1 speaker.
- 4 In the Top distance text field, type 0.3*1_speaker.
- 5 Click **Pauld Selected**.

PML Domains

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Difference Selection.
- 2 In the Settings window for Difference Selection, type PML Domains in the Label text field.
- 3 Locate the Input Entities section. Click the + Add button for Selections to add.
- 4 In the Add dialog box, select All Domains in the Selections to add list.
- 5 Click OK.
- 6 In the Settings window for Difference Selection, locate the Input Entities section.
- 7 Click the + Add button for Selections to subtract.
- 8 In the Add dialog box, select Inner Domains in the Selections to subtract list.
- 9 Click OK.
- 10 In the Settings window for Difference Selection, click | Build Selected.
- II Click | Build Selected.

Pressure Acoustics Domains

- I In the Geometry toolbar, click 🔓 Selections and choose Difference Selection.
- 2 In the Settings window for Difference Selection, type Pressure Acoustics Domains in the Label text field.
- 3 Locate the Input Entities section. Click the + Add button for Selections to add.
- 4 In the Add dialog box, select All Domains in the Selections to add list.
- 5 Click OK.
- 6 In the Settings window for Difference Selection, locate the Input Entities section.
- 7 Click the + Add button for Selections to subtract.
- 8 In the Add dialog box, in the Selections to subtract list, choose Thermoviscous Domains and Structural Domains.
- 9 Click OK.
- 10 In the Settings window for Difference Selection, locate the Color section.
- II From the Color list, choose Color 10.
- 12 Click **Build Selected**.

Electrostatics Domains

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Union Selection.
- 2 In the Settings window for Union Selection, type Electrostatics Domains in the Label text field.
- 3 Locate the **Input Entities** section. Click + Add.
- 4 In the Add dialog box, in the Selections to add list, choose Thermoviscous Domains and Structural Domains.
- 5 Click OK.

Air Domains

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Union Selection.
- 2 In the Settings window for Union Selection, type Air Domains in the Label text field.
- 3 Locate the Input Entities section. Click + Add.
- 4 In the Add dialog box, in the Selections to add list, choose Thermoviscous Domains and **Pressure Acoustics Domains.**
- 5 Click OK.

All Boundaries

I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Box Selection.

- 2 In the Settings window for Box Selection, type All Boundaries in the Label text field.
- 3 Locate the Geometric Entity Level section. From the Level list, choose Boundary.

Nonsymmetric Boundaries

- I In the Geometry toolbar, click 🔓 Selections and choose Box Selection.
- 2 In the Settings window for Box Selection, type Nonsymmetric Boundaries in the Label text field.
- 3 Locate the Geometric Entity Level section. From the Level list, choose Boundary.
- 4 Locate the Box Limits section. In the x minimum text field, type 0.01.
- **5** In the **y minimum** text field, type 0.01.

Symmetric Boundaries

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Difference Selection.
- 2 In the Settings window for Difference Selection, type Symmetric Boundaries in the Label text field.
- 3 Locate the Geometric Entity Level section. From the Level list, choose Boundary.
- **4** Locate the **Input Entities** section. Click the + **Add** button for **Selections to add**.
- 5 In the Add dialog box, select All Boundaries in the Selections to add list.
- 6 Click OK.
- 7 In the Settings window for Difference Selection, locate the Input Entities section.
- 8 Click the + Add button for Selections to subtract.
- 9 In the Add dialog box, select Nonsymmetric Boundaries in the Selections to subtract list.
- IO Click OK.

Exterior Field Boundaries

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Explicit Selection.
- 2 In the Settings window for Explicit Selection, type Exterior Field Boundaries in the Label text field.
- 3 Locate the Entities to Select section. From the Geometric entity level list, choose
- 4 On the object del3, select Boundaries 23 and 49 only.

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Explicit Selection.
- 2 In the Settings window for Explicit Selection, type Ground in the Label text field.

- 3 Locate the Entities to Select section. From the Geometric entity level list, choose Boundary.
- 4 On the object del3, select Boundaries 33, 42, 62, 71, 89, 96, 107, and 129 only.

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Explicit Selection.
- 2 In the Settings window for Explicit Selection, type Terminal in the Label text field.
- 3 Locate the Entities to Select section. From the Geometric entity level list, choose Boundary.
- **4** On the object **del3**, select Boundaries 28, 39, 59, 67, 86, 93, 102, and 126 only.

All except PML

- I In the Geometry toolbar, click \(\frac{1}{2} \) Selections and choose Complement Selection.
- 2 In the Settings window for Complement Selection, type All except PML in the Label text field.
- 3 Locate the **Input Entities** section. Click + Add.
- 4 In the Add dialog box, select PML Domains in the Selections to invert list.
- 5 Click OK.