

SM2A-03-BLOCK II-(1)
APOLLO OPERATIONS HANDBOOK

SYSTEMS DATA

<u>Indicator/Display</u>	<u>Function</u>
KEY REL light	Lighted when an internal display desires the use of the DSKY and the astronaut is using the DSKY or the astronaut presses a key (exceptions: PRO, RSET and ENTR) when an internal flashing display is currently on the DSKY or the astronaut presses a key (exceptions: PRO, RSET and ENTR) on top of his Monitor Verb display.
OPR ERR light	On when the operator performs an improper sequence of key depressions.
TEMP light	Lighted when the CMC receives a signal from the IMU temperature control that the stable member is outside of the temperature range of 126.3 to 134.3°F.
GIMBAL LOCK light	On when the middle gimbal angle exceeds $\pm 70^\circ$ from its zero position.
PROG light	Lighted when the internal program detects computational difficulty.
RESTART light	On when the CMC detects a temporary hardware or software failure.
TRACKER light	Lighted when the CMC receives a signal from the OCDU indicating a failure or the rendezvous navigation program reads VHF range information but the Data Good discrete is missing.
COMP ACTY light	On when the CMC is occupied with an internal sequence.
PROG display	Provides a decimal display of the current mission program in sequence.
VERB display	Provides a decimal display of the verb (action) being performed.

G&N