

Pitco Fryers

This guide offers step-by-step instructions for operating and programming Pitco Fryers, making it an essential resource for anyone looking to optimize their frying process. With clear directions on adjusting cook temperatures, times, and hold settings, users can ensure consistent food quality and efficiency. Whether you're adjusting settings for a single or dual-vat model, this guide simplifies the process, allowing for quick adaptations to meet specific cooking needs. Viewing this guide will empower users to maximize their fryer's capabilities with confidence.

1 Step 1: Enter programming mode

Press the "P" key to start programming the unit. The screen will read "PROGRAM" when the unit is ready.

2

Step 2: Access temperature control

Engage the temperature setting by tapping the thermometer key once for single-vat or twice for dual-vat models. The display will show "SET -F TEMP."

3

Step 3: Set the temperature

Use the product keys to enter the desired temperate.

4

Step 4: Save the new temperature

Press the "P" key to save the cook temperature.

5

Step 5: Exit Programming mode

Tap the "P" key again to leave programming mode.

6

Step 6: Resume normal operation

When both the left and right screens display the word "READY," you can use the unit normally.

7

Step 1: Access time programming mode

Press the "P" key and then the clock icon in order to engage the proper mode. The words "SELECT PRODUCT" will be displayed on the screen when the unit is ready.

8

Step 2: Select the product

Press the desired product key for the product you wish to edit. The display will then read "CKI - TIME" and show the current cook time in minutes.

9

Step 3: Set the new time

Use the product keys to enter the desired time.

10

Step 4: Save the new cook time

Use the product keys to enter the desired time.

Step 5: Leave programming mode

Press the "P" key until the display reads "READY," "HEATING" or "MELT."

Note: You may have to press the "P" key more than once.

12

Step 6: Use the unit normally

Once the unit is out of programming mode, you may resume normal operation

Step 1: Initiate time programming mode

Press the “P” key and then the clock key to start programming the fryer. Once the words “SELECT PRODUCT” appear on the screen, you may proceed to the next step.

14

Step 2: Choose the product

Tap the product key for the product you wish to edit. The display should read “CKI — TIME”.

Press the clock key again in order to engage the shake time setting. The screen will show “SHI — TIME,” indicating the current shake time for that product.

16

Step 4: Set the shake time

Use the product keys to enter the desired time.

17

Step 5: Save the new shake time

Confirm the new setting by pressing the clock key three times until the screen once again says "SELECT PRODUCT."

Step 6: Exit time programming mode

Finish programming by tapping the “P” key until the display reads “READY,” “HEATING” or “MELT.” Note that you may have to press the “P” key more than once.

19

Step 7: Resume normal operation

You may now use the unit normally.

Step 1: Start time programming mode

Push the “P” key and then the clock button to begin programming the machine. The screen will read “SELECT PRODUCT” when the unit is in the proper mode.

5

Step 5: Exit Programming mode

Tap the "P" key again to leave programming mode.

26

Step 7: Use the fryer normally

Now you may resume normal operation of the unit.

Step 1: Enable time programming mode

Press the “P” key and then tap the clock key to begin programming the fryer. The words “SELECT PRODUCT” will be displayed on the screen when the unit enters the correct mode.

28

Step 2: Choose the product

Tap the product key for the product you wish to edit. The display will read “CKI — TIME”.

Step 3: Access the hold pre-alarm

Push the clock icon three times to advance to the hold pre-alarm setting. The screen will display the words “PAI — TIME,” showing the current hold pre-alarm time for that product.

Use the product keys to set the new time for the alarm.

31

Step 5: Save the new hold pre-alarm time

Tap the clock icon to confirm the new setting. The display will read “SELECT PRODUCT” once the new setting is saved.

Step 6: Leave time programming mode

Conclude programming the unit by pressing the “P” button repeatedly until the display reads “READY,” “HEATING” or “MELT.” Remember that you will have to press the “P” key more than once.

Now you may resume normal operation of the fryer.