

# Router User Manual

1. To reset the router, press and hold the reset button for 10 seconds.
2. To turn on the router, connect the power cable and press the power button.
3. If the internet is not working, restart the router.
4. Router lights guide: Green means connected, Red means disconnected.
5. To improve signal strength, place the router in an open area.
6. Default WiFi password is printed on the back of the router.
7. Contact customer support if the router keeps disconnecting.