## INT 10,E - Write Text in Teletype Mode

```
AL = ASCII character to write
BH = page number (text modes)
BL = foreground pixel color (graphics modes)
```

## returns nothing

- cursor advances after write
   characters BEL (7), BS (8), LF (A), and CR (D) are treated as control codes
- for some older BIOS (10/19/81), the BH register must point
- to the currently displayed page
   on CGA adapters this function can disable the video signal while performing the output which causes flitter.

1 of 1 01/24/2007 02:34 PM