

Sample Flight Manual - SAMPLE-100

Revision 2 Revision date 2026-07-01 Effective 2026-07-15

Applicability: SAMPLE-100 Owner: Sample Flight Standards

Reorganization revision. Topics relocated between sections, five topics removed, text updates and new topics.

This document is entirely fictional. It was written to give a prototype realistic structure and volume. It is not derived from any operator manual and must not be used for any operational purpose.

Chapter 01 Introduction

01.10 Manual Organization

01.10.1 New Sample Topic: Engine Anti-Ice

The Ground Proximity Monitor switch position that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Autopilot Channel A annunciation that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Stall Warning annunciation that differs from the expected state requires both pilots to cross-check the condition when conditions permit. The pilot monitoring will announce any change in the Auxiliary Power Unit switch position and advise the other pilot once the checklist item is complete.

During engine start, both pilots should brief the Autothrottle annunciation if a discrepancy is observed. The Autopilot Channel A status message that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Probe Heat advisory is expected to read within the sample range of 32 to 38 units during taxi. The Oxygen Distribution selector position is expected to read within the sample range of 62 to 70 units during approach.

Refer to the related topic for additional sample context. Both pilots will monitor any change in the Nosewheel Steering selector position and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Oxygen Distribution selector position that differs from the expected state requires both pilots to brief the condition once the checklist item is complete.
- During cruise, the Captain should announce the Center Tank Pumps annunciation when operating at a sample station without ground power.
- During climb, both pilots should confirm the Flight Management Computer annunciation when conditions permit.

Condition	Sample value	Remarks
Cabin Pressure Controller selector position	57 units	Refer to related topic
Cockpit Voice Recorder selector position	98 units	Normal
Flight Management Computer selector position	72 units	Monitor
Cockpit Voice Recorder indication	46 units	Advisory only
Nosewheel Steering selector position	92 units	Refer to related topic
Center Tank Pumps switch position	83 units	Refer to related topic
Primary Electrical Bus advisory	88 units	Normal

01.10.2 Organization Topic 1

The relief pilot will confirm any change in the Ground Proximity Monitor status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Fire Detection Loop selector position that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. The Bleed Air Supply indication that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power.

NOTE: If the Speedbrake Handle is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

The relief pilot will select any change in the Probe Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will confirm any change in the Autopilot Channel B status message and advise the other pilot if a discrepancy is observed. If the Cabin Pressure Controller is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. During a turnaround, the Captain should monitor the Traffic Advisory Display selector position when operating at a sample station without ground power.

Condition	Sample value	Remarks
Probe Heat switch position	61 units	Refer to related topic
Oxygen Distribution switch position	40 units	Advisory only
Oxygen Distribution quantity display	26 units	Refer to related topic

CAUTION: During a turnaround, both pilots should brief the Center Tank Pumps annunciation when operating at a sample station without ground power.

If the Ground Proximity Monitor is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The captain will brief any change in the Probe Heat quantity display and advise the other pilot when the associated caution light remains illuminated. If the Landing Gear Indication is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Fire Detection Loop indication is expected to read within the sample range of 59 to 71 units during taxi. The Bleed Air Supply status message that differs from the expected state requires the First Officer to announce the condition when conditions permit. The Stall Warning indication that differs from the expected state requires the relief pilot to record the condition before the next phase of flight.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, the First Officer should cross-check the Fire Detection Loop status message when the associated caution light remains illuminated.

The Brake Temperature Monitor indication that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed. The captain will verify any change in the Autopilot Channel A annunciation and advise the other pilot when operating at a sample station without ground power. The captain will brief any change in the Window Heat status message and advise the other pilot when operating at a sample station without ground power. The Center Tank Pumps status message is expected to read within the sample range of 45 to 55 units during parking.

01.10.3 Organization Topic 2

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Traffic Advisory Display switch position is expected to read within the sample range of 25 to 34 units during takeoff. The pilot monitoring will confirm any change in the Cargo Smoke Detection annunciation and advise the other pilot if a discrepancy is observed.

If the Fire Detection Loop is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Hydraulic System A status message is expected to read within the sample range of 87 to 92 units during engine start. During a maintenance-requested ground run, the First Officer should record the Autopilot Channel A indication unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. During engine start, the pilot monitoring should cross-check the Speedbrake Handle switch position when conditions permit.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

During a maintenance-requested ground run, the pilot flying should monitor the Fire Detection Loop indication if the indication does not stabilize within the sample interval. The Hydraulic System B annunciation is expected to read within the sample range of 60 to 72 units during climb. This text is fictional and exists only to give the prototype

realistic volume and structure.

NOTE: If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Autothrottle selector position that differs from the expected state requires both pilots to verify the condition when conditions permit.

The Traffic Advisory Display quantity display is expected to read within the sample range of 76 to 81 units during cruise. The pilot monitoring will announce any change in the Fire Detection Loop switch position and advise the other pilot if a discrepancy is observed. The Engine Anti-Ice advisory is expected to read within the sample range of 20 to 26 units during landing.

01.10.4 Organization Topic 3

During landing, the pilot monitoring should monitor the Stall Warning annunciation when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, the First Officer should brief the Hydraulic System A selector position if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autopilot Channel B advisory	30 units	Refer to related topic
Autothrottle advisory	26 units	Refer to related topic
Autopilot Channel A quantity display	82 units	Advisory only
Landing Gear Indication advisory	87 units	Refer to related topic
Brake Temperature Monitor selector position	81 units	Advisory only
Center Tank Pumps quantity display	1 units	Refer to related topic

CAUTION: During engine start, the pilot flying should record the Engine Anti-Ice selector position when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

The Pack Temperature Control status message that differs from the expected state requires the First Officer to monitor the condition once the checklist item is complete. Both pilots will announce any change in the Standby Hydraulic annunciation and advise the other pilot before the next phase of flight. The Weather Radar switch position that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. During descent, the pilot flying should cross-check the Landing Gear Indication selector position if the indication does not stabilize within the sample interval.

- During landing, the relief pilot should verify the Cabin Pressure Controller indication once the checklist item is complete.
- The first officer will announce any change in the Autobrake Selector indication and advise the other pilot before the next phase of flight.
- If the Pack Temperature Control is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- The pilot monitoring will brief any change in the Cabin Pressure Controller status message and advise the other pilot when conditions permit.

Refer to the related topic for additional sample context. The relief pilot will announce any change in the Speedbrake Handle annunciation and advise the other pilot before the next phase of flight. The Autothrottle annunciation that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. The Probe Heat quantity display is expected to read within the sample range of 77 to 86 units during takeoff. The Center Tank Pumps annunciation is expected to read within the sample range of 44 to 48 units during approach.

The relief pilot will select any change in the Center Tank Pumps annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed. The Autothrottle switch position that differs from the expected state requires the pilot monitoring to record the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. If the Engine Anti-Ice is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The first officer will brief any change in the Hydraulic System B status message and advise the other pilot when the associated caution light remains illuminated. The relief pilot will announce any change in the Bleed Air Supply indication and advise the other pilot if the indication does not stabilize within the sample interval.

If the Autobrake Selector is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The pilot flying will brief any change in the Autothrottle quantity display and advise the other pilot when the associated caution light remains illuminated.

01.10.5 Organization Topic 4

During taxi, the Captain should brief the Thrust Reverser annunciation once the checklist item is complete. If the Brake Temperature Monitor is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. During a maintenance-requested ground run, the Captain should select the Fire Detection Loop status message when operating at a sample station without ground power. The Traffic Advisory Display switch position that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. Both pilots will cross-check any change in the Engine Anti-Ice advisory and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autobrake Selector indication	60 units	Monitor
Autobrake Selector quantity display	66 units	Monitor
Ground Proximity Monitor selector position	35 units	Advisory only

Both pilots will announce any change in the Oxygen Distribution status message and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will cross-check any change in the Transponder status message and advise the other pilot when the associated caution light remains illuminated. The first officer will cross-check any change in the Fuel Crossfeed advisory and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Probe Heat switch position	96 units	Advisory only
Center Tank Pumps annunciation	19 units	Normal
Landing Gear Indication indication	8 units	Normal

Both pilots will announce any change in the Hydraulic System B quantity display and advise the other pilot when conditions permit. If the Brake Temperature Monitor is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel B quantity display is expected to read within the sample range of 48 to 54 units during taxi. Both pilots will brief any change in the Window Heat selector position and advise the other pilot when conditions permit. The Cabin Pressure Controller indication is expected to read within the sample range of 24 to 30 units during a diversion.

NOTE: If the Hydraulic System B is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

The Probe Heat indication that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight. The Nosewheel Steering switch position that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval. The Flight Management Computer quantity display that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. The Traffic Advisory Display annunciation that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated. During engine start, both pilots should brief the Standby Hydraulic quantity display when conditions permit. The Probe Heat annunciation that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight.

During landing, the pilot flying should verify the Wing Anti-Ice switch position if the indication does not stabilize within the sample interval. The Traffic Advisory Display annunciation that differs from the expected state requires the relief pilot to record the condition before the next phase of flight. The Flight Management Computer selector position is expected to read within the sample range of 67 to 75 units during an extended ground delay. If the Standby Hydraulic is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Landing Gear Indication quantity display that differs from the expected state requires the pilot monitoring to brief the condition if the indication does not stabilize within the sample interval. If the Standby Hydraulic is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Auxiliary Power Unit advisory that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed. During descent, the Captain should announce the Fire Detection Loop indication unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display selector position is expected to read within the sample range of 6 to 12 units during climb. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication switch position is expected to read within the sample range of 10 to 17 units during preflight.

01.10.6 Organization Topic 5

During parking, the relief pilot should verify the Weather Radar annunciation when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder indication is expected to read within the sample range of 3 to 12 units during descent. If the Bleed Air Supply is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

If the Stall Warning is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The first officer will announce any change in the Auxiliary Power Unit advisory and advise the other pilot when operating at a sample station without ground power. The Flight Management Computer indication is expected to read within the sample range of 50 to 54 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

During an extended ground delay, the First Officer should brief the Autothrottle selector position when conditions permit. If the Wing Anti-Ice is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. During climb, the First Officer should monitor the Traffic Advisory Display indication when the associated caution light remains illuminated. See 09.10.6 Flap Position Indication Overview.

NOTE: If the Hydraulic System A is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

- If the Stall Warning is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- The Fire Detection Loop indication that differs from the expected state requires the pilot flying to record the condition before the next phase of flight.
- The Hydraulic System B selector position that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed.

NOTE: During descent, the First Officer should record the Nosewheel Steering selector position if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- Refer to the related topic for additional sample context.
- The Cockpit Voice Recorder advisory is expected to read within the sample range of 46 to 55 units during a maintenance-requested ground run.
- The Nosewheel Steering status message that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed.
- The Standby Instruments selector position is expected to read within the sample range of 29 to 34 units during cruise.
- If the Wing Anti-Ice is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- During engine start, the First Officer should monitor the Pack Temperature Control quantity display when conditions permit.
- The captain will monitor any change in the Traffic Advisory Display annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During engine start, the pilot flying should cross-check the Pack Temperature Control switch position when operating at a sample station without ground power.
- During a maintenance-requested ground run, the First Officer should brief the Pack Temperature Control status message once the checklist item is complete.
- During cruise, the First Officer should cross-check the Bleed Air Supply quantity display when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cargo Smoke Detection advisory	17 units	Normal
Hydraulic System B switch position	60 units	Advisory only
Auxiliary Power Unit quantity display	64 units	Normal
Window Heat quantity display	45 units	Normal
Primary Electrical Bus quantity display	24 units	Advisory only
Auxiliary Power Unit annunciation	92 units	Monitor
Cargo Smoke Detection indication	45 units	Monitor

01.10.7 Organization Topic 6

The Transponder annunciation is expected to read within the sample range of 98 to 102 units during climb. If the Bleed Air Supply is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Transponder annunciation that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed.

NOTE: The pilot flying will announce any change in the Fire Detection Loop selector position and advise the other pilot when operating at a sample station without ground power. The Transponder indication that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center.

NOTE: Refer to the related topic for additional sample context. The Probe Heat advisory that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete.

CAUTION: The Flight Management Computer advisory that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. If the Autopilot Channel A is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

- Refer to the related topic for additional sample context.
- The relief pilot will select any change in the Standby Instruments selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- During takeoff, the First Officer should verify the Auxiliary Power Unit advisory once the checklist item is complete.
- Refer to the related topic for additional sample context.
- The Cabin Pressure Controller status message is expected to read within the sample range of 96 to 105 units during an extended ground delay.
- During approach, both pilots should verify the Fuel Crossfeed quantity display when the associated caution light remains illuminated.
- The Primary Electrical Bus switch position is expected to read within the sample range of 70 to 75 units during descent.
- The Oxygen Distribution status message that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power.
- If the Window Heat is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- The Cargo Smoke Detection selector position is expected to read within the sample range of 43 to 48 units during takeoff.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

Both pilots will confirm any change in the Bleed Air Supply switch position and advise the other pilot when conditions permit. If the Autopilot Channel A is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The pilot flying will brief any change in the Cabin Pressure Controller selector position and advise the other pilot once the checklist item is complete. The Autopilot Channel B advisory is expected to read within the sample range of 70 to 73 units during approach. The Autopilot Channel A switch position that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Stall Warning quantity display	51 units	Normal
Autobrake Selector annunciation	16 units	Refer to related topic
Fire Detection Loop indication	62 units	Refer to related topic
Weather Radar annunciation	17 units	Normal

01.10.8 Organization Topic 7

The first officer will announce any change in the Cargo Smoke Detection indication and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System B quantity display is expected to read

within the sample range of 68 to 77 units during a turnaround. Refer to the related topic for additional sample context.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: Refer to the related topic for additional sample context.

During engine start, the First Officer should monitor the Speedbrake Handle switch position unless directed otherwise by the Sample Operations Center. The relief pilot will verify any change in the Autobrake Selector indication and advise the other pilot when conditions permit. The Landing Gear Indication advisory that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. Refer to the related topic for additional sample context. The Bleed Air Supply status message is expected to read within the sample range of 71 to 83 units during descent. See 05.80.4 Stall Warning Crew Awareness.

NOTE: The first officer will record any change in the Flight Management Computer advisory and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Fire Detection Loop quantity display	59 units	Normal
Stall Warning advisory	93 units	Refer to related topic
Bleed Air Supply switch position	6 units	Refer to related topic
Probe Heat annunciation	90 units	Normal
Standby Instruments status message	66 units	Advisory only
Flight Management Computer quantity display	12 units	Normal
Stall Warning indication	91 units	Normal

- The Flight Management Computer annunciation is expected to read within the sample range of 80 to 87 units during a diversion.
- During taxi, both pilots should select the Weather Radar annunciation when operating at a sample station without ground power.
- The Auxiliary Power Unit advisory that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated.
- If the Hydraulic System A is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- During approach, the Captain should verify the Hydraulic System B quantity display when conditions permit.
- The Center Tank Pumps annunciation is expected to read within the sample range of 59 to 62 units during approach.

01.10.9 Organization Topic 9

The Fuel Crossfeed indication that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight. The Oxygen Distribution selector position that differs from the expected state requires the Captain to cross-check the condition when conditions permit. The pilot monitoring will verify any change in the Oxygen Distribution selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder selector position is expected to read within the sample range of 35 to 41 units during descent. The Thrust Reverser indication is expected to read within the sample range of 10 to 16 units during climb. Refer to the related topic for additional sample context.

CAUTION: During taxi, the pilot flying should announce the Cabin Pressure Controller switch position unless directed otherwise by the Sample Operations Center. During cruise, both pilots should record the Fire Detection

Loop status message if the indication does not stabilize within the sample interval.

NOTE: During climb, the First Officer should confirm the Flight Management Computer indication if a discrepancy is observed.

The Engine Anti-Ice annunciation is expected to read within the sample range of 22 to 25 units during cruise. The pilot flying will cross-check any change in the Cabin Pressure Controller advisory and advise the other pilot when the associated caution light remains illuminated. The Autobrake Selector advisory that differs from the expected state requires the Captain to verify the condition before the next phase of flight.

Condition	Sample value	Remarks
Auxiliary Power Unit advisory	30 units	Refer to related topic
Fuel Crossfeed switch position	15 units	Monitor
Engine Anti-Ice selector position	28 units	Advisory only
Autobrake Selector quantity display	69 units	Advisory only
Thrust Reverser quantity display	6 units	Refer to related topic
Hydraulic System A annunciation	40 units	Monitor

01.10.10 Organization Topic 10

If the Traffic Advisory Display is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During parking, the First Officer should monitor the Nosewheel Steering switch position if the indication does not stabilize within the sample interval. Both pilots will monitor any change in the Hydraulic System B quantity display and advise the other pilot once the checklist item is complete.

If the Speedbrake Handle is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The pilot monitoring will select any change in the Speedbrake Handle selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System B advisory is expected to read within the sample range of 55 to 64 units during cruise. Refer to the related topic for additional sample context.

CAUTION: If the Traffic Advisory Display is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

If the Autothrottle is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. During parking, the pilot monitoring should monitor the Traffic Advisory Display indication if the indication does not stabilize within the sample interval. The Fuel Crossfeed indication that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. If the Center Tank Pumps is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Center Tank Pumps annunciation that differs from the expected state requires the relief pilot to monitor the condition before the next phase of flight. The Auxiliary Power Unit quantity display is expected to read within the sample range of 51 to 58 units during a maintenance-requested ground run.

During an extended ground delay, the pilot monitoring should brief the Cargo Smoke Detection status message when operating at a sample station without ground power. During engine start, the relief pilot should record the Weather Radar advisory unless directed otherwise by the Sample Operations Center. Both pilots will monitor any change in the Window Heat selector position and advise the other pilot when operating at a sample station without ground power. Both pilots will verify any change in the Engine Anti-Ice selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

Values in this manual are invented and must not be used for any operational purpose. The Brake Temperature Monitor switch position that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. During a turnaround, the Captain should cross-check the Autopilot

Channel B selector position once the checklist item is complete. The Primary Electrical Bus quantity display is expected to read within the sample range of 43 to 53 units during approach. The Ground Proximity Monitor switch position that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power. The Weather Radar switch position is expected to read within the sample range of 56 to 63 units during cruise.

During cruise, both pilots should select the Weather Radar indication if a discrepancy is observed. If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. During a turnaround, the pilot flying should record the Probe Heat annunciation when conditions permit.

During a diversion, the First Officer should confirm the Autobrake Selector quantity display once the checklist item is complete. The relief pilot will announce any change in the Hydraulic System B status message and advise the other pilot when operating at a sample station without ground power. During a maintenance-requested ground run, the relief pilot should monitor the Autothrottle indication when conditions permit.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Autopilot Channel A is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During cruise, the pilot flying should verify the Wing Anti-Ice switch position before the next phase of flight. The Ground Proximity Monitor status message that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. The pilot flying will cross-check any change in the Flap Position Indication quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

01.20 Revision Service

01.20.1 Revision Service Topic 1

The Standby Instruments advisory is expected to read within the sample range of 14 to 23 units during a turnaround. The Flight Management Computer annunciation that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will monitor any change in the Traffic Advisory Display advisory and advise the other pilot before the next phase of flight.

- If the Auxiliary Power Unit is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- The first officer will record any change in the Oxygen Distribution advisory and advise the other pilot when operating at a sample station without ground power.
- During parking, the relief pilot should select the Fire Detection Loop quantity display before the next phase of flight.
- If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- If the Bleed Air Supply is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- The Traffic Advisory Display annunciation is expected to read within the sample range of 96 to 103 units during a turnaround.
- During descent, the Captain should announce the Traffic Advisory Display indication when the associated caution light remains illuminated.
- The Flight Management Computer selector position that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.

- Both pilots will confirm any change in the Standby Instruments selector position and advise the other pilot when operating at a sample station without ground power.
- The pilot flying will confirm any change in the Standby Instruments advisory and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Engine Anti-Ice status message	35 units	Refer to related topic
Fuel Crossfeed switch position	43 units	Normal
Wing Anti-Ice switch position	48 units	Advisory only

CAUTION: The Auxiliary Power Unit status message that differs from the expected state requires the pilot monitoring to monitor the condition when operating at a sample station without ground power. The Oxygen Distribution status message that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power.

- The pilot monitoring will monitor any change in the Thrust Reverser switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- Both pilots will announce any change in the Weather Radar quantity display and advise the other pilot if a discrepancy is observed.
- The Cockpit Voice Recorder indication that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center.
- The Speedbrake Handle quantity display is expected to read within the sample range of 59 to 66 units during a diversion.
- The Brake Temperature Monitor advisory that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.

01.20.2 Revision Service Topic 2

During parking, the Captain should brief the Auxiliary Power Unit advisory before the next phase of flight. The Primary Electrical Bus indication that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. The Standby Hydraulic switch position that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete. The captain will verify any change in the Landing Gear Indication advisory and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Autobrake Selector switch position	95 units	Monitor
Fuel Crossfeed quantity display	12 units	Advisory only
Stall Warning annunciation	99 units	Normal
Stall Warning selector position	41 units	Normal

If the Ground Proximity Monitor is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The pilot flying will brief any change in the Landing Gear Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During a diversion, the pilot flying should record the Wing Anti-Ice advisory before the next phase of flight. If the Landing Gear Indication is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Weather Radar selector position	6 units	Advisory only
Stall Warning selector position	67 units	Monitor

Transponder advisory	27 units	Normal
----------------------	----------	--------

Condition	Sample value	Remarks
Brake Temperature Monitor annunciation	74 units	Normal
Ground Proximity Monitor advisory	27 units	Normal
Weather Radar switch position	79 units	Refer to related topic
Landing Gear Indication annunciation	97 units	Refer to related topic

The Standby Instruments selector position that differs from the expected state requires the First Officer to brief the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the pilot monitoring should record the Standby Instruments annunciation unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus switch position that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 4 to 12 units during a maintenance-requested ground run.

During a maintenance-requested ground run, the relief pilot should verify the Hydraulic System B indication when operating at a sample station without ground power. If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Autothrottle is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

- The Hydraulic System A indication is expected to read within the sample range of 80 to 85 units during a diversion.
- The Window Heat annunciation is expected to read within the sample range of 73 to 79 units during cruise.
- The pilot flying will select any change in the Weather Radar indication and advise the other pilot once the checklist item is complete.
- The Flight Management Computer switch position that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center.
- The Cockpit Voice Recorder switch position is expected to read within the sample range of 54 to 58 units during engine start.

NOTE: The Hydraulic System A selector position is expected to read within the sample range of 54 to 65 units during a turnaround. During approach, both pilots should monitor the Flight Management Computer annunciation if the indication does not stabilize within the sample interval.

01.20.3 Revision Service Topic 3

The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice switch position is expected to read within the sample range of 32 to 42 units during a diversion. During takeoff, the Captain should verify the Landing Gear Indication status message if the indication does not stabilize within the sample interval.

- The Fire Detection Loop quantity display is expected to read within the sample range of 39 to 45 units during climb.
- If the Hydraulic System A is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- The Autothrottle quantity display is expected to read within the sample range of 84 to 92 units during engine start.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Ground Proximity Monitor advisory that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center.
- The Hydraulic System B selector position that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit.
- If the Autothrottle is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.
- The Standby Instruments quantity display that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated.
- If the Ground Proximity Monitor is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Values in this manual are invented and must not be used for any operational purpose.
- The Brake Temperature Monitor switch position is expected to read within the sample range of 51 to 57 units during approach.
- During climb, the pilot monitoring should confirm the Transponder indication when conditions permit.
- The Autobrake Selector annunciation is expected to read within the sample range of 41 to 44 units during engine start.

NOTE: The Cabin Pressure Controller quantity display that differs from the expected state requires the First Officer to cross-check the condition when conditions permit. The Landing Gear Indication switch position that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated.

If the Nosewheel Steering is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Transponder is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. See 10.20.13 Window Heat Test.

01.20.4 Revision Service Topic 4

During preflight, the relief pilot should cross-check the Fuel Crossfeed quantity display if a discrepancy is observed. If the Probe Heat is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Landing Gear Indication indication that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center.

- The Ground Proximity Monitor advisory that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center.
- If the Probe Heat is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The pilot flying will brief any change in the Hydraulic System A advisory and advise the other pilot when conditions permit.

If the Wing Anti-Ice is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Thrust Reverser selector position is expected to read within the sample range of 46 to 51 units during a maintenance-requested ground run. During preflight, the pilot monitoring should monitor the Cargo Smoke Detection status message unless directed otherwise by the Sample Operations Center.

During climb, the pilot monitoring should verify the Standby Hydraulic quantity display when operating at a sample station without ground power. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice quantity display that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval. The Thrust Reverser status message that differs from the expected state requires the pilot flying to select the condition before the next phase of flight.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The Flight Management Computer advisory is expected to read within the sample range of 7 to 14 units during engine start.

The Bleed Air Supply quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. The Autothrottle selector position is expected to read within the sample range of 11 to 14 units during descent. The captain will announce any change in the Ground Proximity Monitor advisory and advise the other pilot once the checklist item is complete. The pilot monitoring will record any change in the Landing Gear Indication indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. The Bleed Air Supply status message that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval. During takeoff, the First Officer should verify the Fuel Crossfeed indication unless directed otherwise by the Sample Operations Center. The pilot monitoring will confirm any change in the Stall Warning selector position and advise the other pilot before the next phase of flight.

01.20.5 Revision Service Topic 5

The Cockpit Voice Recorder switch position is expected to read within the sample range of 36 to 44 units during an extended ground delay. The Brake Temperature Monitor annunciation is expected to read within the sample range of 41 to 47 units during engine start. The Window Heat selector position is expected to read within the sample range of 12 to 17 units during descent. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, the relief pilot should verify the Thrust Reverser annunciation when conditions permit.

- The Cargo Smoke Detection status message is expected to read within the sample range of 13 to 19 units during cruise.
- Values in this manual are invented and must not be used for any operational purpose.
- Both pilots will announce any change in the Ground Proximity Monitor quantity display and advise the other pilot before the next phase of flight.

The Fuel Crossfeed indication is expected to read within the sample range of 23 to 35 units during landing. The pilot flying will cross-check any change in the Engine Anti-Ice annunciation and advise the other pilot when conditions permit. During cruise, the pilot monitoring should brief the Nosewheel Steering indication before the next phase of flight. The Flap Position Indication indication that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed.

CAUTION: The Primary Electrical Bus indication is expected to read within the sample range of 85 to 89 units during parking. During descent, both pilots should brief the Cabin Pressure Controller status message before the next phase of flight.

During descent, the pilot monitoring should cross-check the Flight Management Computer advisory when conditions permit. During a maintenance-requested ground run, the First Officer should confirm the Auxiliary Power Unit quantity display when conditions permit. The pilot flying will select any change in the Weather Radar status message and advise the other pilot when conditions permit.

- Both pilots will announce any change in the Hydraulic System B selector position and advise the other pilot when the associated caution light remains illuminated.

- The Transponder quantity display that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval.
- During approach, both pilots should select the Speedbrake Handle indication before the next phase of flight.
- During an extended ground delay, the relief pilot should confirm the Weather Radar annunciation if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Standby Hydraulic indication	73 units	Normal
Standby Instruments annunciation	19 units	Normal
Standby Hydraulic selector position	83 units	Refer to related topic
Oxygen Distribution status message	36 units	Monitor
Hydraulic System A selector position	40 units	Normal

01.20.6 Revision Service Topic 6

If the Weather Radar is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Primary Electrical Bus status message is expected to read within the sample range of 58 to 66 units during preflight. The Standby Hydraulic annunciation is expected to read within the sample range of 90 to 96 units during approach. If the Pack Temperature Control is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Cargo Smoke Detection indication that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed. If the Cabin Pressure Controller is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Thrust Reverser status message	75 units	Refer to related topic
Pack Temperature Control quantity display	73 units	Refer to related topic
Cargo Smoke Detection annunciation	32 units	Monitor
Cabin Pressure Controller switch position	6 units	Advisory only
Probe Heat selector position	90 units	Refer to related topic
Thrust Reverser annunciation	47 units	Normal

NOTE: The Flap Position Indication annunciation that differs from the expected state requires the First Officer to select the condition once the checklist item is complete.

The Window Heat quantity display that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power. The Stall Warning annunciation that differs from the expected state requires the Captain to record the condition when conditions permit. The Ground Proximity Monitor switch position is expected to read within the sample range of 96 to 100 units during engine start. During an extended ground delay, the pilot flying should verify the Brake Temperature Monitor annunciation when operating at a sample station without ground power.

The Autothrottle advisory that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center. The Weather Radar advisory is expected to read within the sample range of 21 to 30 units during a maintenance-requested ground run. The Autothrottle indication that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight.

If the Cabin Pressure Controller is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

01.20.7 Revision Service Topic 7

The Fuel Crossfeed advisory that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. Refer to the related topic for additional sample context. During a diversion, the pilot flying should monitor the Autobrake Selector selector position if the indication does not stabilize within the sample interval. If the Center Tank Pumps is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

The Ground Proximity Monitor switch position that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Hydraulic System A is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Bleed Air Supply annunciation is expected to read within the sample range of 94 to 103 units during descent. During climb, the First Officer should record the Nosewheel Steering annunciation if a discrepancy is observed.

CAUTION: The Standby Hydraulic advisory is expected to read within the sample range of 98 to 109 units during cruise. If the Stall Warning is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

- If the Engine Anti-Ice is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.
- The Flight Management Computer selector position that differs from the expected state requires the Captain to brief the condition when conditions permit.
- The Transponder selector position is expected to read within the sample range of 53 to 63 units during parking.

NOTE: During climb, the Captain should brief the Cargo Smoke Detection switch position unless directed otherwise by the Sample Operations Center.

01.30 Abbreviations

01.30.1 Abbreviation Group 1

The first officer will monitor any change in the Ground Proximity Monitor switch position and advise the other pilot when conditions permit. The Bleed Air Supply indication that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated. If the Bleed Air Supply is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Stall Warning annunciation is expected to read within the sample range of 17 to 24 units during parking. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System A advisory that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power.

During engine start, both pilots should monitor the Thrust Reverser quantity display when the associated caution light remains illuminated. The Nosewheel Steering selector position that differs from the expected state requires both pilots to select the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will confirm any change in the Bleed Air Supply quantity display and advise the other pilot when conditions permit. The pilot flying will select any change in the Hydraulic System A status message and advise the other pilot once the checklist item is complete. The Hydraulic System A quantity display is expected to read within the sample range of 70 to 80 units during climb.

Condition	Sample value	Remarks
Auxiliary Power Unit switch position	16 units	Monitor
Flight Management Computer indication	88 units	Refer to related topic
Landing Gear Indication advisory	69 units	Advisory only

NOTE: The Standby Instruments advisory that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

The Cargo Smoke Detection indication that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. Both pilots will confirm any change in the Ground Proximity Monitor status message and advise the other pilot when operating at a sample station without ground power. During preflight, the relief pilot should record the Standby Hydraulic quantity display when the associated caution light remains illuminated. The Oxygen Distribution indication that differs from the expected state requires both pilots to select the condition if a discrepancy is observed. The pilot flying will confirm any change in the Thrust Reverser selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The Cabin Pressure Controller annunciation is expected to read within the sample range of 60 to 69 units during a maintenance-requested ground run.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The relief pilot will confirm any change in the Ground Proximity Monitor annunciation and advise the other pilot before the next phase of flight.
- During a diversion, the pilot monitoring should select the Autopilot Channel B advisory unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.

The Standby Hydraulic indication that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. The Landing Gear Indication status message is expected to read within the sample range of 68 to 80 units during taxi. If the Traffic Advisory Display is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

01.30.2 Abbreviation Group 2

The Landing Gear Indication annunciation is expected to read within the sample range of 37 to 40 units during preflight. The Bleed Air Supply quantity display that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval. The Engine Anti-Ice indication that differs from the expected state requires the First Officer to announce the condition when conditions permit. During a maintenance-requested ground run, the Captain should verify the Thrust Reverser quantity display once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During climb, the relief pilot should cross-check the Autobrake Selector indication unless directed otherwise by the Sample Operations Center. During climb, the Captain should brief the Flight Management Computer annunciation unless directed otherwise by the Sample Operations Center.

If the Autobrake Selector is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During an extended ground delay, the First Officer should cross-check the Wing Anti-Ice switch position once the checklist item is complete. The Primary Electrical Bus advisory that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center.

During a diversion, the pilot flying should select the Autothrottle indication if a discrepancy is observed. The Hydraulic System B advisory that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will select any change in the Speedbrake Handle selector position and advise the other pilot when the associated caution light remains illuminated. The Pack Temperature Control switch position is expected to read within the sample range of 40 to 44 units during a diversion.

The Wing Anti-Ice annunciation is expected to read within the sample range of 52 to 60 units during an extended ground delay. The Brake Temperature Monitor switch position is expected to read within the sample range of 96 to 101 units during an extended ground delay. The Nosewheel Steering indication that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete. The Engine Anti-Ice advisory is expected to read within the sample range of 66 to 73 units during landing. The Primary Electrical Bus annunciation that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval.

CAUTION: The Nosewheel Steering status message is expected to read within the sample range of 3 to 14 units during parking. The pilot flying will brief any change in the Flight Management Computer advisory and advise the other pilot if the indication does not stabilize within the sample interval.

The Autobrake Selector status message is expected to read within the sample range of 41 to 45 units during landing. If the Transponder is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. During landing, both pilots should monitor the Weather Radar quantity display when conditions permit. The pilot flying will confirm any change in the Standby Hydraulic quantity display and advise the other pilot when the associated caution light remains illuminated.

01.30.3 Abbreviation Group 3

The pilot monitoring will confirm any change in the Stall Warning selector position and advise the other pilot when operating at a sample station without ground power. The Pack Temperature Control annunciation is expected to read within the sample range of 75 to 79 units during a diversion. During preflight, the relief pilot should monitor the Autothrottle selector position if the indication does not stabilize within the sample interval. The Autobrake Selector annunciation is expected to read within the sample range of 35 to 47 units during engine start. Both pilots will brief any change in the Flight Management Computer status message and advise the other pilot when conditions permit. If the Weather Radar is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

NOTE: The Wing Anti-Ice annunciation is expected to read within the sample range of 50 to 58 units during parking. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: During parking, the relief pilot should confirm the Autobrake Selector indication when the associated caution light remains illuminated.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Flap Position Indication selector position	91 units	Advisory only
Probe Heat switch position	51 units	Refer to related topic
Cockpit Voice Recorder advisory	8 units	Advisory only
Oxygen Distribution switch position	93 units	Normal
Flap Position Indication annunciation	21 units	Normal
Thrust Reverser advisory	57 units	Refer to related topic

The first officer will record any change in the Flight Management Computer quantity display and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a

procedure, not a procedure. The captain will verify any change in the Ground Proximity Monitor switch position and advise the other pilot before the next phase of flight. The Nosewheel Steering selector position that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed. The pilot flying will select any change in the Weather Radar selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Weather Radar indication that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center.

NOTE: During takeoff, the pilot flying should brief the Thrust Reverser indication before the next phase of flight. During engine start, the relief pilot should announce the Hydraulic System B selector position if a discrepancy is observed.

During descent, the Captain should monitor the Transponder status message if a discrepancy is observed. During cruise, the First Officer should monitor the Flight Management Computer annunciation unless directed otherwise by the Sample Operations Center. The Engine Anti-Ice selector position that differs from the expected state requires the pilot flying to verify the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

01.30.4 Abbreviation Group 4

Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor indication that differs from the expected state requires the pilot flying to record the condition when conditions permit. The Fuel Crossfeed advisory that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. The first officer will record any change in the Cockpit Voice Recorder status message and advise the other pilot when the associated caution light remains illuminated. The pilot flying will cross-check any change in the Fire Detection Loop status message and advise the other pilot once the checklist item is complete. The Speedbrake Handle indication is expected to read within the sample range of 73 to 80 units during a diversion.

CAUTION: The Stall Warning switch position is expected to read within the sample range of 73 to 77 units during parking. The Hydraulic System A switch position that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power.

The Transponder status message is expected to read within the sample range of 30 to 36 units during taxi. The pilot flying will monitor any change in the Speedbrake Handle indication and advise the other pilot before the next phase of flight. The Brake Temperature Monitor quantity display is expected to read within the sample range of 9 to 14 units during approach. The Nosewheel Steering status message that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. During takeoff, the pilot flying should cross-check the Flight Management Computer annunciation if a discrepancy is observed. If the Transponder is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Nosewheel Steering advisory	32 units	Monitor
Cargo Smoke Detection quantity display	22 units	Normal
Wing Anti-Ice selector position	79 units	Monitor
Standby Hydraulic indication	88 units	Monitor
Landing Gear Indication status message	11 units	Refer to related topic
Transponder quantity display	68 units	Refer to related topic

The Bleed Air Supply quantity display is expected to read within the sample range of 66 to 74 units during a maintenance-requested ground run. The Landing Gear Indication indication that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. During a turnaround, the pilot monitoring should confirm the Cabin Pressure Controller status message once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. During engine start,

both pilots should brief the Fire Detection Loop annunciation before the next phase of flight.

The wording here is placeholder content shaped like a procedure, not a procedure. The captain will verify any change in the Autobrake Selector status message and advise the other pilot once the checklist item is complete. During climb, the Captain should brief the Brake Temperature Monitor selector position if the indication does not stabilize within the sample interval. The Fire Detection Loop selector position is expected to read within the sample range of 64 to 76 units during a maintenance-requested ground run. If the Hydraulic System B is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Probe Heat indication is expected to read within the sample range of 21 to 32 units during cruise.

The first officer will select any change in the Bleed Air Supply advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During landing, the First Officer should select the Probe Heat annunciation before the next phase of flight. Both pilots will cross-check any change in the Stall Warning status message and advise the other pilot when operating at a sample station without ground power. The Autopilot Channel B selector position is expected to read within the sample range of 58 to 64 units during cruise.

- During taxi, the pilot flying should verify the Hydraulic System A switch position when the associated caution light remains illuminated.
- During climb, the Captain should confirm the Thrust Reverser status message unless directed otherwise by the Sample Operations Center.
- The captain will record any change in the Auxiliary Power Unit indication and advise the other pilot if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During climb, both pilots should select the Speedbrake Handle annunciation before the next phase of flight.

01.30.5 Abbreviation Group 5

Refer to the related topic for additional sample context. During takeoff, both pilots should monitor the Cockpit Voice Recorder status message when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Weather Radar advisory that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight.

The Bleed Air Supply status message is expected to read within the sample range of 48 to 58 units during climb. During engine start, both pilots should announce the Fuel Crossfeed quantity display when the associated caution light remains illuminated. If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

The Autopilot Channel A indication that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete. The first officer will announce any change in the Landing Gear Indication selector position and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the pilot flying should record the Fuel Crossfeed selector position if the indication does not stabilize within the sample interval. The Thrust Reverser quantity display is expected to read within the sample range of 45 to 54 units during approach. The pilot monitoring will cross-check any change in the Autopilot Channel B switch position and advise the other pilot before the next phase of flight.

- The Bleed Air Supply indication is expected to read within the sample range of 18 to 26 units during landing.
- During a maintenance-requested ground run, both pilots should announce the Center Tank Pumps annunciation unless directed otherwise by the Sample Operations Center.
- If the Landing Gear Indication is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

- The pilot monitoring will monitor any change in the Brake Temperature Monitor switch position and advise the other pilot when conditions permit.
- During a turnaround, the Captain should cross-check the Bleed Air Supply status message when operating at a sample station without ground power.

The Pack Temperature Control annunciation is expected to read within the sample range of 61 to 65 units during a diversion. If the Cockpit Voice Recorder is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The first officer will brief any change in the Autothrottle indication and advise the other pilot before the next phase of flight. During takeoff, the First Officer should record the Fuel Crossfeed indication when operating at a sample station without ground power.

CAUTION: The pilot flying will verify any change in the Hydraulic System B status message and advise the other pilot when operating at a sample station without ground power. If the Engine Anti-Ice is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

NOTE: The Bleed Air Supply indication is expected to read within the sample range of 26 to 33 units during taxi.

01.30.6 Abbreviation Group 6

If the Flight Management Computer is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Primary Electrical Bus status message is expected to read within the sample range of 45 to 56 units during takeoff. The Center Tank Pumps switch position that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. The Bleed Air Supply switch position that differs from the expected state requires the pilot monitoring to monitor the condition when operating at a sample station without ground power. The captain will record any change in the Ground Proximity Monitor status message and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Transponder status message	74 units	Advisory only
Cargo Smoke Detection advisory	87 units	Monitor
Autopilot Channel B quantity display	83 units	Normal
Autopilot Channel A indication	61 units	Refer to related topic

The captain will monitor any change in the Window Heat annunciation and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. During approach, the First Officer should cross-check the Cargo Smoke Detection annunciation if the indication does not stabilize within the sample interval. The Traffic Advisory Display switch position is expected to read within the sample range of 3 to 9 units during engine start. The Thrust Reverser quantity display that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center. If the Flap Position Indication is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Landing Gear Indication selector position	6 units	Monitor
Fuel Crossfeed advisory	55 units	Refer to related topic
Pack Temperature Control advisory	2 units	Monitor
Autothrottle indication	64 units	Normal
Transponder selector position	46 units	Refer to related topic
Standby Instruments status message	31 units	Monitor

During an extended ground delay, the relief pilot should cross-check the Bleed Air Supply indication once the checklist item is complete. If the Autopilot Channel A is inoperative, continue takeoff only after the relief pilot has

reviewed the associated sample guidance. The Ground Proximity Monitor indication that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit. See 15.10.1 Engine Anti-Ice Crew Awareness.

01.30.7 Abbreviation Group 7

If the Flap Position Indication is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. During descent, both pilots should select the Primary Electrical Bus quantity display if the indication does not stabilize within the sample interval. If the Stall Warning is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

The pilot flying will brief any change in the Auxiliary Power Unit advisory and advise the other pilot when operating at a sample station without ground power. The Pack Temperature Control selector position is expected to read within the sample range of 93 to 102 units during engine start. The Speedbrake Handle status message is expected to read within the sample range of 83 to 93 units during descent. The Autopilot Channel A quantity display that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the pilot flying should record the Autothrottle quantity display when the associated caution light remains illuminated.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

- The first officer will confirm any change in the Transponder indication and advise the other pilot before the next phase of flight.
- During takeoff, the First Officer should cross-check the Autobrake Selector indication unless directed otherwise by the Sample Operations Center.
- If the Landing Gear Indication is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.
- During approach, both pilots should record the Cockpit Voice Recorder indication when operating at a sample station without ground power.

CAUTION: During a turnaround, both pilots should select the Hydraulic System B switch position before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

During climb, both pilots should brief the Oxygen Distribution status message before the next phase of flight. The Hydraulic System B quantity display that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete. If the Hydraulic System B is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. If the Bleed Air Supply is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

If the Cargo Smoke Detection is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Hydraulic System A selector position that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

01.30.8 Abbreviation Group 8

If the Standby Instruments is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will monitor any change in the Traffic Advisory Display annunciation and advise the other pilot if the indication does not stabilize within the

sample interval. The Autopilot Channel B advisory is expected to read within the sample range of 98 to 101 units during taxi. The Fire Detection Loop status message is expected to read within the sample range of 44 to 51 units during a turnaround.

During climb, both pilots should announce the Autothrottle selector position if the indication does not stabilize within the sample interval. During a turnaround, the First Officer should announce the Brake Temperature Monitor quantity display before the next phase of flight. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The Cabin Pressure Controller quantity display is expected to read within the sample range of 83 to 90 units during approach.

The Pack Temperature Control annunciation that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. The Autobrake Selector status message that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic status message that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. During climb, the relief pilot should verify the Cabin Pressure Controller switch position when the associated caution light remains illuminated.

During an extended ground delay, the pilot flying should select the Oxygen Distribution switch position when operating at a sample station without ground power. During takeoff, the First Officer should announce the Autothrottle quantity display before the next phase of flight. The pilot flying will record any change in the Landing Gear Indication status message and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Pack Temperature Control switch position is expected to read within the sample range of 67 to 76 units during landing. During preflight, both pilots should monitor the Autopilot Channel B quantity display when conditions permit.

This text is fictional and exists only to give the prototype realistic volume and structure. The Autopilot Channel A switch position is expected to read within the sample range of 6 to 10 units during parking. The Autothrottle indication is expected to read within the sample range of 88 to 91 units during landing. The Autothrottle switch position that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection annunciation that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.

01.30.9 Abbreviation Group 9

The pilot monitoring will select any change in the Weather Radar selector position and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will monitor any change in the Stall Warning switch position and advise the other pilot before the next phase of flight. The Weather Radar indication is expected to read within the sample range of 34 to 44 units during cruise. The captain will announce any change in the Autopilot Channel A status message and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. If the Cabin Pressure Controller is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

NOTE: During climb, the Captain should confirm the Brake Temperature Monitor switch position if a discrepancy is observed. During preflight, the Captain should confirm the Autopilot Channel B switch position if a discrepancy is observed.

- Both pilots will record any change in the Stall Warning selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Fuel Crossfeed indication that differs from the expected state requires the pilot monitoring to record the condition when the associated caution light remains illuminated.
- The pilot monitoring will monitor any change in the Flight Management Computer selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The relief pilot will announce any change in the Cockpit Voice Recorder indication and advise the other pilot once the checklist item is complete.

CAUTION: The pilot flying will cross-check any change in the Flight Management Computer switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autopilot Channel A annunciation is expected to read within the sample range of 89 to 94 units during descent.

The captain will brief any change in the Engine Anti-Ice selector position and advise the other pilot when the associated caution light remains illuminated. The captain will select any change in the Traffic Advisory Display quantity display and advise the other pilot once the checklist item is complete. If the Standby Hydraulic is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. See 03.10.17 Callouts: Engine Anti-Ice.

CAUTION: If the Autopilot Channel A is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

- The Weather Radar annunciation is expected to read within the sample range of 86 to 93 units during a turnaround.
- During climb, the relief pilot should record the Autobrake Selector indication when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- During an extended ground delay, the First Officer should cross-check the Wing Anti-Ice indication when conditions permit.
- Refer to the related topic for additional sample context.
- The captain will announce any change in the Window Heat switch position and advise the other pilot when the associated caution light remains illuminated.
- If the Pack Temperature Control is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- During a diversion, the relief pilot should confirm the Cabin Pressure Controller switch position when conditions permit.

01.30.10 Abbreviation Group 10

The Bleed Air Supply indication is expected to read within the sample range of 28 to 40 units during parking. The relief pilot will announce any change in the Speedbrake Handle annunciation and advise the other pilot when operating at a sample station without ground power. During a maintenance-requested ground run, the Captain should brief the Oxygen Distribution status message when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will record any change in the Window Heat quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During engine start, both pilots should confirm the Cockpit Voice Recorder selector position when operating at a sample station without ground power.

The Speedbrake Handle quantity display is expected to read within the sample range of 47 to 55 units during a turnaround. If the Transponder is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will announce any change in the Standby Instruments status message and advise the other pilot if the indication does not stabilize within the sample interval. The Fire Detection Loop indication is expected to read within the sample range of 92 to 104 units during taxi. During taxi, both pilots should monitor the Window Heat quantity display when conditions permit.

The Autopilot Channel A quantity display that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. The captain will select any change in the Weather Radar status message and advise the other pilot if the indication does not stabilize within the sample

interval. The pilot flying will cross-check any change in the Engine Anti-Ice advisory and advise the other pilot if a discrepancy is observed. The Cargo Smoke Detection indication is expected to read within the sample range of 59 to 63 units during parking. During an extended ground delay, the First Officer should record the Autopilot Channel A advisory when conditions permit.

The relief pilot will verify any change in the Auxiliary Power Unit status message and advise the other pilot once the checklist item is complete. The Cockpit Voice Recorder selector position that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Flap Position Indication indication that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight.

If the Stall Warning is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Cargo Smoke Detection advisory that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. If the Bleed Air Supply is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

CAUTION: During a diversion, the pilot flying should cross-check the Cockpit Voice Recorder advisory before the next phase of flight.

Chapter 02 Limitations

02.10 General Limitations

02.10.1 General Limitation 1

If the Thrust Reverser is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will record any change in the Ground Proximity Monitor advisory and advise the other pilot when the associated caution light remains illuminated. The pilot flying will verify any change in the Cockpit Voice Recorder annunciation and advise the other pilot when conditions permit. The captain will cross-check any change in the Weather Radar switch position and advise the other pilot if the indication does not stabilize within the sample interval.

- The Flap Position Indication quantity display is expected to read within the sample range of 74 to 80 units during climb.
- During preflight, the First Officer should record the Bleed Air Supply annunciation when operating at a sample station without ground power.
- The Ground Proximity Monitor quantity display that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power.
- The Bleed Air Supply advisory is expected to read within the sample range of 77 to 80 units during engine start.
- The Nosewheel Steering advisory that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center.
- The relief pilot will announce any change in the Hydraulic System B quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During a turnaround, both pilots should cross-check the Autobrake Selector advisory once the checklist item is complete.
- Refer to the related topic for additional sample context.
- If the Cabin Pressure Controller is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

The pilot flying will cross-check any change in the Cockpit Voice Recorder selector position and advise the other pilot when conditions permit. The relief pilot will verify any change in the Standby Hydraulic selector position and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Fuel Crossfeed status message that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight.
- Values in this manual are invented and must not be used for any operational purpose.
- The Wing Anti-Ice advisory is expected to read within the sample range of 19 to 29 units during taxi.
- During a diversion, the pilot monitoring should announce the Cockpit Voice Recorder indication if a discrepancy is observed.
- The relief pilot will confirm any change in the Wing Anti-Ice selector position and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autopilot Channel A selector position	6 units	Normal
Autobrake Selector quantity display	7 units	Normal

Stall Warning advisory	77 units	Normal
Flap Position Indication switch position	14 units	Normal

- The pilot flying will record any change in the Autothrottle quantity display and advise the other pilot if a discrepancy is observed.
- The Ground Proximity Monitor quantity display that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power.
- The captain will brief any change in the Primary Electrical Bus selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Nosewheel Steering is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

The Hydraulic System B selector position is expected to read within the sample range of 20 to 28 units during landing. During an extended ground delay, both pilots should cross-check the Brake Temperature Monitor advisory if a discrepancy is observed. During climb, the pilot monitoring should confirm the Autobrake Selector selector position before the next phase of flight.

Condition	Sample value	Remarks
Hydraulic System B quantity display	35 units	Advisory only
Fuel Crossfeed indication	75 units	Advisory only
Cockpit Voice Recorder selector position	70 units	Advisory only
Stall Warning advisory	3 units	Refer to related topic
Cargo Smoke Detection selector position	95 units	Refer to related topic
Brake Temperature Monitor quantity display	88 units	Normal

02.10.2 General Limitation 2

During approach, the First Officer should verify the Fire Detection Loop status message when the associated caution light remains illuminated. The pilot monitoring will select any change in the Landing Gear Indication quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During parking, the relief pilot should record the Thrust Reverser selector position once the checklist item is complete. During a maintenance-requested ground run, the First Officer should confirm the Flight Management Computer indication when conditions permit.

- If the Hydraulic System B is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- The Primary Electrical Bus selector position is expected to read within the sample range of 49 to 56 units during engine start.
- The pilot monitoring will announce any change in the Cabin Pressure Controller switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot flying to confirm the condition when conditions permit.
- The Flap Position Indication quantity display is expected to read within the sample range of 77 to 89 units during cruise.

Condition	Sample value	Remarks
Nosewheel Steering selector position	56 units	Refer to related topic
Standby Hydraulic advisory	52 units	Normal

Nosewheel Steering selector position	8 units	Advisory only
Cargo Smoke Detection annunciation	14 units	Advisory only
Brake Temperature Monitor switch position	68 units	Monitor
Auxiliary Power Unit annunciation	34 units	Advisory only
Fuel Crossfeed switch position	28 units	Advisory only

If the Oxygen Distribution is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Standby Instruments quantity display is expected to read within the sample range of 31 to 40 units during a diversion. Refer to the related topic for additional sample context. Both pilots will announce any change in the Cabin Pressure Controller indication and advise the other pilot once the checklist item is complete. During a turnaround, the relief pilot should verify the Thrust Reverser quantity display before the next phase of flight.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

The Traffic Advisory Display advisory is expected to read within the sample range of 77 to 85 units during cruise. The captain will record any change in the Wing Anti-Ice selector position and advise the other pilot before the next phase of flight. The Brake Temperature Monitor switch position that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete.

NOTE: The first officer will cross-check any change in the Engine Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will cross-check any change in the Autobrake Selector status message and advise the other pilot if the indication does not stabilize within the sample interval.

02.10.3 General Limitation 3

The pilot monitoring will brief any change in the Cabin Pressure Controller indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flight Management Computer quantity display is expected to read within the sample range of 52 to 57 units during approach. The first officer will announce any change in the Traffic Advisory Display selector position and advise the other pilot if the indication does not stabilize within the sample interval.

- If the Primary Electrical Bus is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.
- The Standby Instruments quantity display that differs from the expected state requires the pilot monitoring to select the condition when conditions permit.
- The relief pilot will record any change in the Fire Detection Loop quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- The captain will announce any change in the Auxiliary Power Unit advisory and advise the other pilot once the checklist item is complete.
- The Traffic Advisory Display switch position that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval.

The Autopilot Channel A annunciation is expected to read within the sample range of 28 to 33 units during descent. The pilot monitoring will monitor any change in the Standby Hydraulic quantity display and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. Both pilots will record any change in the Pack Temperature Control annunciation and advise the other pilot once the checklist item is complete. If the Weather Radar is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a

procedure.

The Probe Heat quantity display is expected to read within the sample range of 12 to 23 units during a maintenance-requested ground run. The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle status message is expected to read within the sample range of 92 to 99 units during a diversion. Refer to the related topic for additional sample context. The Standby Instruments advisory is expected to read within the sample range of 96 to 100 units during cruise.

CAUTION: Refer to the related topic for additional sample context. The relief pilot will monitor any change in the Hydraulic System A status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

02.10.4 General Limitation 4

The pilot monitoring will select any change in the Cabin Pressure Controller quantity display and advise the other pilot when operating at a sample station without ground power. The Window Heat switch position is expected to read within the sample range of 93 to 101 units during preflight. The Fire Detection Loop selector position that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: If the Cabin Pressure Controller is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

CAUTION: If the Fire Detection Loop is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

The Landing Gear Indication quantity display is expected to read within the sample range of 68 to 73 units during descent. The Wing Anti-Ice selector position is expected to read within the sample range of 80 to 85 units during engine start. The Wing Anti-Ice status message is expected to read within the sample range of 5 to 14 units during a diversion. During takeoff, the relief pilot should cross-check the Probe Heat quantity display before the next phase of flight. The Probe Heat annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight.

NOTE: The Center Tank Pumps selector position is expected to read within the sample range of 16 to 24 units during taxi.

NOTE: The Transponder selector position is expected to read within the sample range of 29 to 39 units during preflight. The Hydraulic System B annunciation that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval.

If the Traffic Advisory Display is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. During parking, both pilots should brief the Bleed Air Supply annunciation when conditions permit. During descent, the pilot flying should brief the Traffic Advisory Display indication when the associated caution light remains illuminated. The Stall Warning advisory that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power. If the Autothrottle is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. During landing, the relief pilot should record the Speedbrake Handle annunciation when conditions permit.

If the Autopilot Channel B is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Weather Radar switch position that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. If the Transponder is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Thrust Reverser status message	50 units	Normal

Weather Radar selector position	97 units	Normal
Speedbrake Handle quantity display	18 units	Advisory only
Cabin Pressure Controller advisory	87 units	Monitor
Speedbrake Handle annunciation	31 units	Refer to related topic
Wing Anti-Ice advisory	12 units	Monitor
Probe Heat status message	46 units	Normal

02.10.5 General Limitation 5

If the Autopilot Channel B is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The first officer will verify any change in the Pack Temperature Control advisory and advise the other pilot once the checklist item is complete. If the Thrust Reverser is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Cockpit Voice Recorder status message is expected to read within the sample range of 10 to 14 units during parking.

The relief pilot will monitor any change in the Flap Position Indication quantity display and advise the other pilot when operating at a sample station without ground power. The Bleed Air Supply indication is expected to read within the sample range of 15 to 19 units during a maintenance-requested ground run. The Engine Anti-Ice quantity display that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. During parking, the First Officer should record the Bleed Air Supply quantity display when the associated caution light remains illuminated. The Primary Electrical Bus selector position that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed. If the Ground Proximity Monitor is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

- The Cabin Pressure Controller indication is expected to read within the sample range of 17 to 24 units during climb.
- The Wing Anti-Ice selector position is expected to read within the sample range of 20 to 28 units during a turnaround.
- The Autopilot Channel B quantity display is expected to read within the sample range of 59 to 63 units during descent.

CAUTION: If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

If the Pack Temperature Control is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Landing Gear Indication annunciation is expected to read within the sample range of 83 to 87 units during taxi. The captain will select any change in the Traffic Advisory Display selector position and advise the other pilot if a discrepancy is observed. The relief pilot will verify any change in the Oxygen Distribution switch position and advise the other pilot once the checklist item is complete. During a maintenance-requested ground run, the Captain should cross-check the Center Tank Pumps advisory when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Transponder quantity display is expected to read within the sample range of 70 to 76 units during approach. See 06.20.9 Stall Warning Overview.

02.10.6 General Limitation 6

The Hydraulic System A quantity display is expected to read within the sample range of 41 to 45 units during takeoff. During an extended ground delay, the pilot flying should record the Hydraulic System A advisory unless directed otherwise by the Sample Operations Center. The Autopilot Channel B status message is expected to read within the sample range of 73 to 77 units during parking.

CAUTION: If the Hydraulic System A is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. During parking, both pilots should cross-check the Nosewheel Steering annunciation if a discrepancy is observed.

If the Standby Hydraulic is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The relief pilot will confirm any change in the Autothrottle switch position and advise the other pilot when conditions permit.

NOTE: If the Traffic Advisory Display is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Cabin Pressure Controller selector position is expected to read within the sample range of 86 to 94 units during a turnaround.

The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, the First Officer should monitor the Transponder selector position when conditions permit. The Cargo Smoke Detection advisory is expected to read within the sample range of 49 to 57 units during cruise. The Hydraulic System A quantity display is expected to read within the sample range of 85 to 90 units during landing. The Hydraulic System A selector position that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

02.10.7 General Limitation 7

The Wing Anti-Ice quantity display that differs from the expected state requires the pilot flying to record the condition when conditions permit. If the Thrust Reverser is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. If the Transponder is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Traffic Advisory Display status message is expected to read within the sample range of 34 to 40 units during cruise.

The Wing Anti-Ice selector position is expected to read within the sample range of 13 to 17 units during a turnaround. The Transponder quantity display that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power. During a turnaround, the pilot flying should monitor the Flight Management Computer indication once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Thrust Reverser is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. Both pilots will verify any change in the Center Tank Pumps advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will verify any change in the Pack Temperature Control selector position and advise the other pilot when the associated caution light remains illuminated.

If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The pilot monitoring will cross-check any change in the Ground Proximity Monitor annunciation and advise the other pilot if a discrepancy is observed. The captain will confirm any change in the Fuel Crossfeed advisory and advise the other pilot when conditions permit. The Standby Hydraulic quantity display is expected to read within the sample range of 20 to 24 units during descent. The Transponder status message is expected to read within the sample range of 59 to 71 units during a diversion.

If the Brake Temperature Monitor is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The first officer will select any change in the Weather Radar annunciation and advise the other pilot if the indication does not stabilize within the sample interval. During approach, the relief pilot should cross-check the Cockpit Voice Recorder advisory if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Standby Instruments status message	93 units	Advisory only
Probe Heat status message	97 units	Monitor
Bleed Air Supply quantity display	69 units	Advisory only
Pack Temperature Control advisory	27 units	Refer to related topic
Landing Gear Indication annunciation	96 units	Normal
Auxiliary Power Unit quantity display	1 units	Refer to related topic
Probe Heat selector position	1 units	Monitor

During engine start, the pilot monitoring should select the Probe Heat switch position if the indication does not stabilize within the sample interval. The Primary Electrical Bus selector position is expected to read within the sample range of 53 to 61 units during a turnaround. The Wing Anti-Ice quantity display is expected to read within the sample range of 69 to 76 units during an extended ground delay. The Nosewheel Steering advisory that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center. See 02.30.7 Airspeed Limitation 7.

02.10.8 General Limitation 8

Refer to the related topic for additional sample context. The Transponder status message that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. During approach, the First Officer should verify the Standby Hydraulic status message when the associated caution light remains illuminated. During cruise, the relief pilot should announce the Autothrottle switch position before the next phase of flight.

During cruise, the pilot flying should confirm the Autothrottle selector position once the checklist item is complete. The first officer will cross-check any change in the Landing Gear Indication advisory and advise the other pilot when the associated caution light remains illuminated. If the Flight Management Computer is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The pilot flying will brief any change in the Bleed Air Supply quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autopilot Channel A status message is expected to read within the sample range of 3 to 11 units during approach.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Stall Warning quantity display is expected to read within the sample range of 21 to 31 units during approach.

Condition	Sample value	Remarks
Speedbrake Handle status message	35 units	Advisory only
Autopilot Channel A indication	62 units	Normal
Fuel Crossfeed switch position	96 units	Normal
Speedbrake Handle switch position	56 units	Monitor
Standby Hydraulic quantity display	68 units	Refer to related topic
Transponder annunciation	96 units	Normal
Flap Position Indication status message	24 units	Refer to related topic

- The relief pilot will brief any change in the Autopilot Channel A switch position and advise the other pilot when operating at a sample station without ground power.
- Refer to the related topic for additional sample context.
- If the Autothrottle is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

- During climb, both pilots should verify the Engine Anti-Ice switch position unless directed otherwise by the Sample Operations Center.
- The Autobrake Selector status message that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power.

02.10.9 General Limitation 9

The Brake Temperature Monitor quantity display is expected to read within the sample range of 56 to 65 units during cruise. The Autobrake Selector status message that differs from the expected state requires the pilot flying to brief the condition when conditions permit. If the Autopilot Channel B is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

The Landing Gear Indication selector position is expected to read within the sample range of 7 to 13 units during taxi. The Center Tank Pumps advisory is expected to read within the sample range of 94 to 100 units during engine start. During cruise, the pilot flying should monitor the Pack Temperature Control indication once the checklist item is complete. The captain will cross-check any change in the Autopilot Channel A advisory and advise the other pilot when the associated caution light remains illuminated.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Window Heat indication is expected to read within the sample range of 75 to 78 units during parking.
- During climb, the Captain should record the Pack Temperature Control switch position when conditions permit.
- Both pilots will confirm any change in the Autopilot Channel A quantity display and advise the other pilot when conditions permit.

NOTE: The Hydraulic System B indication that differs from the expected state requires both pilots to select the condition if a discrepancy is observed.

CAUTION: If the Speedbrake Handle is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

If the Flight Management Computer is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During taxi, the relief pilot should announce the Hydraulic System B annunciation when conditions permit. During a turnaround, the First Officer should select the Brake Temperature Monitor switch position once the checklist item is complete. Refer to the related topic for additional sample context. The relief pilot will verify any change in the Probe Heat annunciation and advise the other pilot when conditions permit. During an extended ground delay, the First Officer should announce the Autobrake Selector advisory once the checklist item is complete.

02.10.10 General Limitation 10

During climb, the pilot monitoring should confirm the Speedbrake Handle advisory before the next phase of flight. If the Window Heat is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. During an extended ground delay, the pilot monitoring should select the Engine Anti-Ice selector position once the checklist item is complete. During a maintenance-requested ground run, the pilot monitoring should verify the Standby Instruments quantity display when operating at a sample station without ground power.

If the Stall Warning is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Engine Anti-Ice status message is expected to read within the sample range of 73 to 76 units during preflight. If the Flap Position Indication is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

During preflight, the pilot monitoring should select the Fuel Crossfeed selector position if a discrepancy is observed. The Probe Heat advisory is expected to read within the sample range of 47 to 55 units during a diversion. During a turnaround, the relief pilot should select the Fuel Crossfeed quantity display before the next phase of flight. The Weather Radar selector position that differs from the expected state requires both pilots to confirm the condition

before the next phase of flight.

If the Stall Warning is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. During descent, the Captain should announce the Pack Temperature Control annunciation when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

NOTE: The Ground Proximity Monitor annunciation is expected to read within the sample range of 70 to 73 units during engine start. If the Pack Temperature Control is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

NOTE: The Window Heat indication is expected to read within the sample range of 37 to 44 units during a maintenance-requested ground run.

02.10.11 General Limitation 11

The Fire Detection Loop selector position that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. If the Brake Temperature Monitor is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Auxiliary Power Unit status message that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete.

CAUTION: During approach, the relief pilot should verify the Cockpit Voice Recorder advisory unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Ground Proximity Monitor status message	71 units	Monitor
Bleed Air Supply annunciation	96 units	Normal
Weather Radar switch position	72 units	Normal
Hydraulic System B quantity display	36 units	Normal
Cargo Smoke Detection switch position	61 units	Normal
Oxygen Distribution indication	47 units	Refer to related topic

- Values in this manual are invented and must not be used for any operational purpose.
- The Hydraulic System A annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval.
- If the Ground Proximity Monitor is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Fire Detection Loop is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Cabin Pressure Controller selector position is expected to read within the sample range of 42 to 54 units during cruise.

CAUTION: Refer to the related topic for additional sample context.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- During a diversion, the Captain should announce the Standby Hydraulic quantity display unless directed otherwise by the Sample Operations Center.
- The captain will record any change in the Autobrake Selector advisory and advise the other pilot when conditions permit.

During a diversion, both pilots should confirm the Pack Temperature Control switch position once the checklist item is complete. If the Standby Hydraulic is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Hydraulic System A advisory is expected to read within the sample range of 32 to 38 units during a diversion. The pilot flying will cross-check any change in the Cabin Pressure Controller advisory and advise the other pilot if a discrepancy is observed. During cruise, the pilot monitoring should select the Standby Instruments quantity display unless directed otherwise by the Sample Operations Center. Both pilots will verify any change in the Nosewheel Steering indication and advise the other pilot if the indication does not stabilize within the sample interval.

If the Engine Anti-Ice is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Ground Proximity Monitor quantity display is expected to read within the sample range of 2 to 14 units during approach.

02.10.12 General Limitation 12

The Bleed Air Supply quantity display that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. The Autothrottle advisory is expected to read within the sample range of 11 to 23 units during cruise. The Transponder quantity display is expected to read within the sample range of 3 to 6 units during climb.

CAUTION: If the Autopilot Channel B is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The pilot flying will select any change in the Auxiliary Power Unit annunciation and advise the other pilot when conditions permit. The Ground Proximity Monitor status message that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed.

The Engine Anti-Ice quantity display is expected to read within the sample range of 69 to 78 units during a maintenance-requested ground run. The relief pilot will monitor any change in the Traffic Advisory Display advisory and advise the other pilot when conditions permit. The first officer will record any change in the Probe Heat switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cabin Pressure Controller is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

NOTE: If the Speedbrake Handle is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. During a diversion, the pilot monitoring should record the Fuel Crossfeed advisory once the checklist item is complete.

NOTE: The first officer will cross-check any change in the Auxiliary Power Unit advisory and advise the other pilot if a discrepancy is observed.

This text is fictional and exists only to give the prototype realistic volume and structure. The Autothrottle advisory that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval. If the Transponder is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

02.10.13 General Limitation 13

Refer to the related topic for additional sample context. The pilot monitoring will announce any change in the Auxiliary Power Unit annunciation and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The first officer will monitor any change in the Brake Temperature Monitor annunciation and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will verify any change in the Bleed Air Supply indication and advise the other pilot once the checklist item is complete. The Weather Radar selector position is expected to read within the sample range of 72 to 81 units during takeoff. The pilot flying will monitor any change in the Traffic Advisory Display status message and advise the other pilot when conditions permit. The Autopilot Channel B indication is expected to read within the sample range of 37 to 43 units

during engine start.

Refer to the related topic for additional sample context. If the Ground Proximity Monitor is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Autobrake Selector annunciation is expected to read within the sample range of 24 to 33 units during engine start. During preflight, the pilot monitoring should brief the Stall Warning selector position once the checklist item is complete. If the Fuel Crossfeed is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The pilot flying will announce any change in the Cabin Pressure Controller status message and advise the other pilot when the associated caution light remains illuminated. If the Window Heat is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cabin Pressure Controller quantity display	95 units	Refer to related topic
Engine Anti-Ice status message	8 units	Normal
Weather Radar advisory	56 units	Monitor
Landing Gear Indication switch position	57 units	Advisory only
Standby Instruments quantity display	16 units	Advisory only
Cargo Smoke Detection status message	52 units	Refer to related topic
Stall Warning annunciation	52 units	Normal

During landing, the First Officer should cross-check the Cabin Pressure Controller quantity display when operating at a sample station without ground power. During a turnaround, the relief pilot should verify the Stall Warning quantity display once the checklist item is complete. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 59 to 65 units during descent. Refer to the related topic for additional sample context. The Center Tank Pumps quantity display that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power. The first officer will brief any change in the Cargo Smoke Detection selector position and advise the other pilot when operating at a sample station without ground power.

02.20 Weight Limitations

02.20.1 Weight Limitation 1

If the Autopilot Channel B is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Landing Gear Indication indication that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight. During a maintenance-requested ground run, both pilots should record the Autopilot Channel B switch position if a discrepancy is observed. The Center Tank Pumps advisory that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

During a turnaround, the First Officer should monitor the Cockpit Voice Recorder annunciation if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. The Autopilot Channel B selector position is expected to read within the sample range of 87 to 92 units during takeoff. The Thrust Reverser indication is expected to read within the sample range of 97 to 107 units during a maintenance-requested ground run.

The Autopilot Channel B switch position is expected to read within the sample range of 11 to 14 units during an extended ground delay. If the Transponder is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Brake Temperature Monitor indication is expected to read within the sample range of 95 to 99 units during a diversion. Values in this manual are invented and must not be used for any

operational purpose.

- The Weather Radar selector position that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center.
- The captain will select any change in the Center Tank Pumps status message and advise the other pilot before the next phase of flight.
- If the Hydraulic System B is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- The Brake Temperature Monitor quantity display that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center.
- During a maintenance-requested ground run, the relief pilot should record the Cargo Smoke Detection indication if a discrepancy is observed.
- If the Cabin Pressure Controller is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

If the Flap Position Indication is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication annunciation is expected to read within the sample range of 4 to 16 units during parking. During a maintenance-requested ground run, the pilot monitoring should select the Window Heat advisory if a discrepancy is observed.

02.20.2 Weight Limitation 2

The captain will announce any change in the Autobrake Selector quantity display and advise the other pilot if the indication does not stabilize within the sample interval. If the Standby Instruments is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The Autopilot Channel B quantity display that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power. The Cockpit Voice Recorder selector position is expected to read within the sample range of 52 to 55 units during climb. The first officer will cross-check any change in the Stall Warning switch position and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Cabin Pressure Controller selector position is expected to read within the sample range of 12 to 23 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure.

During a maintenance-requested ground run, the pilot flying should announce the Landing Gear Indication selector position once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. During a turnaround, the relief pilot should cross-check the Fuel Crossfeed indication if a discrepancy is observed. Both pilots will monitor any change in the Hydraulic System B annunciation and advise the other pilot once the checklist item is complete.

CAUTION: During an extended ground delay, the Captain should cross-check the Probe Heat annunciation when conditions permit.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Cargo Smoke Detection is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The Speedbrake Handle selector position is expected to read within the sample range of 58 to 62 units during landing. This text is fictional and exists only to give the prototype realistic volume and structure. If the Auxiliary Power Unit is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

- If the Flight Management Computer is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

- During parking, the pilot flying should confirm the Auxiliary Power Unit indication unless directed otherwise by the Sample Operations Center.
- The Traffic Advisory Display selector position is expected to read within the sample range of 61 to 69 units during approach.
- The Pack Temperature Control advisory that differs from the expected state requires the pilot monitoring to brief the condition if the indication does not stabilize within the sample interval.
- During an extended ground delay, the First Officer should cross-check the Autopilot Channel B quantity display unless directed otherwise by the Sample Operations Center.
- If the Flap Position Indication is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

02.20.3 Weight Limitation 3

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. During engine start, the First Officer should record the Fire Detection Loop switch position if a discrepancy is observed. The relief pilot will record any change in the Autobrake Selector annunciation and advise the other pilot before the next phase of flight. The Fire Detection Loop indication is expected to read within the sample range of 94 to 101 units during parking. See 04.10.2 Flow: Engine Anti-Ice.

CAUTION: If the Auxiliary Power Unit is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

- Both pilots will record any change in the Probe Heat advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The pilot monitoring will select any change in the Cargo Smoke Detection quantity display and advise the other pilot before the next phase of flight.
- The Engine Anti-Ice quantity display is expected to read within the sample range of 79 to 88 units during takeoff.

CAUTION: The first officer will select any change in the Cabin Pressure Controller status message and advise the other pilot before the next phase of flight.

CAUTION: During climb, the pilot monitoring should cross-check the Hydraulic System B advisory when the associated caution light remains illuminated.

02.20.4 Weight Limitation 4

Refer to the related topic for additional sample context. The Wing Anti-Ice indication is expected to read within the sample range of 63 to 72 units during descent. The Standby Hydraulic advisory that differs from the expected state requires both pilots to record the condition once the checklist item is complete.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Traffic Advisory Display advisory	78 units	Advisory only
Flap Position Indication quantity display	53 units	Normal
Engine Anti-Ice annunciation	82 units	Refer to related topic
Speedbrake Handle switch position	88 units	Refer to related topic
Hydraulic System B switch position	37 units	Monitor
Bleed Air Supply selector position	43 units	Monitor

- The pilot flying will announce any change in the Hydraulic System A status message and advise the other pilot before the next phase of flight.
- If the Auxiliary Power Unit is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.
- During preflight, both pilots should monitor the Auxiliary Power Unit selector position before the next phase of flight.
- The Center Tank Pumps indication that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit.
- The Window Heat status message is expected to read within the sample range of 79 to 84 units during approach.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A annunciation is expected to read within the sample range of 97 to 100 units during a maintenance-requested ground run.

CAUTION: If the Traffic Advisory Display is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Primary Electrical Bus switch position	62 units	Advisory only
Cabin Pressure Controller status message	80 units	Refer to related topic
Standby Instruments quantity display	37 units	Monitor
Fire Detection Loop status message	31 units	Normal

CAUTION: The Wing Anti-Ice status message is expected to read within the sample range of 98 to 103 units during takeoff. During cruise, both pilots should announce the Thrust Reverser selector position when the associated caution light remains illuminated.

02.20.5 Weight Limitation 5

The Speedbrake Handle indication is expected to read within the sample range of 6 to 11 units during approach. The Transponder advisory that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

- If the Cargo Smoke Detection is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.
- If the Probe Heat is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.
- The Autopilot Channel B advisory that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.
- The wording here is placeholder content shaped like a procedure, not a procedure.

The Stall Warning quantity display that differs from the expected state requires the pilot flying to record the condition before the next phase of flight. The Hydraulic System B status message that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle advisory is expected to read within the sample range of 82 to 87 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
-----------	--------------	---------

Cabin Pressure Controller annunciation	71 units	Advisory only
Fuel Crossfeed status message	53 units	Refer to related topic
Hydraulic System B annunciation	81 units	Advisory only
Autothrottle annunciation	87 units	Advisory only
Fuel Crossfeed indication	69 units	Advisory only
Cargo Smoke Detection quantity display	72 units	Advisory only
Flight Management Computer indication	55 units	Monitor

Condition	Sample value	Remarks
Standby Hydraulic indication	56 units	Advisory only
Autobrake Selector indication	16 units	Monitor
Weather Radar selector position	46 units	Refer to related topic
Weather Radar annunciation	55 units	Advisory only
Wing Anti-Ice advisory	53 units	Normal
Thrust Reverser indication	31 units	Advisory only

The Nosewheel Steering indication is expected to read within the sample range of 51 to 58 units during a diversion. The Bleed Air Supply indication is expected to read within the sample range of 34 to 45 units during takeoff. The Thrust Reverser annunciation is expected to read within the sample range of 78 to 87 units during preflight.

The Nosewheel Steering annunciation that differs from the expected state requires the relief pilot to verify the condition if a discrepancy is observed. The Autopilot Channel B annunciation is expected to read within the sample range of 70 to 75 units during preflight. During engine start, the Captain should verify the Nosewheel Steering advisory when the associated caution light remains illuminated. If the Window Heat is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will confirm any change in the Window Heat indication and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: During takeoff, the First Officer should confirm the Flap Position Indication quantity display once the checklist item is complete.

The captain will verify any change in the Hydraulic System A status message and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. Both pilots will announce any change in the Pack Temperature Control annunciation and advise the other pilot if the indication does not stabilize within the sample interval. During climb, the First Officer should announce the Cargo Smoke Detection advisory if a discrepancy is observed.

02.20.6 Weight Limitation 6

The Window Heat annunciation is expected to read within the sample range of 13 to 18 units during approach. Values in this manual are invented and must not be used for any operational purpose. If the Oxygen Distribution is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

NOTE: During descent, the First Officer should cross-check the Transponder advisory when conditions permit. During cruise, the relief pilot should select the Speedbrake Handle annunciation before the next phase of flight.

NOTE: During climb, the Captain should select the Cargo Smoke Detection indication if the indication does not stabilize within the sample interval.

The Stall Warning quantity display that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power. The pilot monitoring will confirm any change in the Fire Detection Loop switch position and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Bleed Air Supply switch position that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete. Values in this manual are

invented and must not be used for any operational purpose.

CAUTION: The Thrust Reverser switch position that differs from the expected state requires the First Officer to record the condition when conditions permit.

The Primary Electrical Bus status message is expected to read within the sample range of 20 to 30 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will cross-check any change in the Ground Proximity Monitor selector position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. The Traffic Advisory Display switch position is expected to read within the sample range of 97 to 104 units during taxi. The Center Tank Pumps selector position is expected to read within the sample range of 10 to 21 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Traffic Advisory Display annunciation	53 units	Normal
Probe Heat status message	82 units	Refer to related topic
Autopilot Channel A indication	52 units	Advisory only
Autothrottle advisory	68 units	Monitor

Condition	Sample value	Remarks
Auxiliary Power Unit selector position	52 units	Normal
Weather Radar selector position	24 units	Monitor
Center Tank Pumps selector position	82 units	Refer to related topic
Flight Management Computer indication	10 units	Advisory only
Flap Position Indication status message	75 units	Monitor
Window Heat selector position	83 units	Normal

The Fire Detection Loop quantity display is expected to read within the sample range of 20 to 26 units during a diversion. The pilot flying will announce any change in the Autopilot Channel A quantity display and advise the other pilot if a discrepancy is observed. The Engine Anti-Ice annunciation is expected to read within the sample range of 60 to 64 units during descent. The Engine Anti-Ice advisory that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. See 19.40.5 Fuel Planning Data Table 5.

02.20.7 Weight Limitation 7

If the Oxygen Distribution is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. During takeoff, both pilots should record the Nosewheel Steering indication when the associated caution light remains illuminated. Refer to the related topic for additional sample context. If the Engine Anti-Ice is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. Both pilots will verify any change in the Flight Management Computer switch position and advise the other pilot once the checklist item is complete.

During preflight, the Captain should cross-check the Engine Anti-Ice advisory if a discrepancy is observed. During landing, the pilot flying should announce the Auxiliary Power Unit advisory once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, the First Officer should monitor the Standby Hydraulic indication when conditions permit. The captain will brief any change in the Center Tank Pumps annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

The Flap Position Indication annunciation is expected to read within the sample range of 25 to 36 units during a turnaround. During parking, the Captain should announce the Wing Anti-Ice status message if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the pilot monitoring should verify the Auxiliary Power Unit quantity display if a discrepancy is observed.

CAUTION: During cruise, the First Officer should record the Center Tank Pumps selector position if a discrepancy is observed. The Cockpit Voice Recorder selector position is expected to read within the sample range of 8 to 18 units during takeoff.

NOTE: The Cargo Smoke Detection status message is expected to read within the sample range of 15 to 22 units during a turnaround. The Fire Detection Loop switch position is expected to read within the sample range of 95 to 101 units during an extended ground delay.

- The Cockpit Voice Recorder advisory is expected to read within the sample range of 29 to 40 units during landing.
- The Brake Temperature Monitor switch position is expected to read within the sample range of 54 to 62 units during a diversion.
- The Transponder annunciation is expected to read within the sample range of 49 to 52 units during descent.
- During an extended ground delay, the relief pilot should announce the Autopilot Channel B selector position if the indication does not stabilize within the sample interval.
- If the Hydraulic System B is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The captain will announce any change in the Autopilot Channel A indication and advise the other pilot before the next phase of flight.

02.20.8 Weight Limitation 8

Refer to the related topic for additional sample context. The pilot flying will record any change in the Thrust Reverser switch position and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. The pilot flying will confirm any change in the Pack Temperature Control indication and advise the other pilot when conditions permit.

The Auxiliary Power Unit indication that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete. During parking, the pilot flying should record the Oxygen Distribution quantity display unless directed otherwise by the Sample Operations Center. If the Transponder is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

During parking, the relief pilot should verify the Pack Temperature Control indication unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will confirm any change in the Nosewheel Steering indication and advise the other pilot if a discrepancy is observed. If the Flap Position Indication is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Hydraulic System A annunciation is expected to read within the sample range of 35 to 40 units during landing.

During a diversion, the Captain should cross-check the Autobrake Selector indication when conditions permit. The pilot flying will announce any change in the Cargo Smoke Detection status message and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

- If the Flight Management Computer is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- If the Standby Hydraulic is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- During a turnaround, both pilots should brief the Flap Position Indication advisory once the checklist item is complete.
- If the Autothrottle is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

- The Window Heat selector position is expected to read within the sample range of 3 to 11 units during preflight.
- During climb, the First Officer should confirm the Autopilot Channel A selector position unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Cabin Pressure Controller advisory	16 units	Advisory only
Autopilot Channel A annunciation	71 units	Normal
Center Tank Pumps indication	31 units	Advisory only
Autopilot Channel B status message	86 units	Monitor
Center Tank Pumps advisory	92 units	Refer to related topic
Transponder switch position	88 units	Advisory only
Weather Radar status message	41 units	Refer to related topic

If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. During a turnaround, the First Officer should cross-check the Flight Management Computer quantity display when operating at a sample station without ground power. During approach, the pilot flying should announce the Transponder indication before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

02.20.9 Weight Limitation 9

Values in this manual are invented and must not be used for any operational purpose. During a turnaround, the pilot monitoring should monitor the Window Heat selector position before the next phase of flight. During engine start, the First Officer should verify the Autothrottle advisory when operating at a sample station without ground power. During a turnaround, the pilot flying should monitor the Speedbrake Handle annunciation if a discrepancy is observed. If the Hydraulic System A is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

The pilot flying will verify any change in the Cabin Pressure Controller selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The first officer will monitor any change in the Autopilot Channel B switch position and advise the other pilot when operating at a sample station without ground power. The Ground Proximity Monitor selector position that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete. The Autothrottle status message is expected to read within the sample range of 66 to 76 units during parking. If the Autopilot Channel B is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Standby Instruments advisory is expected to read within the sample range of 12 to 17 units during descent.

- The Fuel Crossfeed switch position is expected to read within the sample range of 52 to 60 units during preflight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Autopilot Channel A switch position that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power.

The Engine Anti-Ice status message is expected to read within the sample range of 21 to 28 units during landing. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Instruments advisory that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight.

Condition	Sample value	Remarks
Flight Management Computer status message	82 units	Refer to related topic
Auxiliary Power Unit annunciation	95 units	Refer to related topic
Cabin Pressure Controller annunciation	87 units	Normal

Fuel Crossfeed annunciation	68 units	Monitor
Nosewheel Steering indication	82 units	Refer to related topic
Flight Management Computer switch position	95 units	Normal

If the Hydraulic System B is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. During engine start, the Captain should record the Brake Temperature Monitor switch position unless directed otherwise by the Sample Operations Center. The Standby Hydraulic annunciation that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. See 15.30.15 Cargo Smoke Detection Reset Guidance.

02.20.10 Weight Limitation 10

During takeoff, the pilot monitoring should announce the Fire Detection Loop quantity display once the checklist item is complete. The Hydraulic System A switch position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. The Ground Proximity Monitor quantity display that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. The Cockpit Voice Recorder selector position is expected to read within the sample range of 18 to 29 units during takeoff.

The Window Heat status message is expected to read within the sample range of 21 to 29 units during climb. The Engine Anti-Ice status message that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated. During takeoff, the relief pilot should select the Hydraulic System B switch position if the indication does not stabilize within the sample interval.

The first officer will brief any change in the Ground Proximity Monitor quantity display and advise the other pilot when conditions permit. The captain will record any change in the Ground Proximity Monitor status message and advise the other pilot if the indication does not stabilize within the sample interval. During parking, the First Officer should confirm the Engine Anti-Ice status message once the checklist item is complete. The Flap Position Indication status message that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power. If the Engine Anti-Ice is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The Weather Radar switch position is expected to read within the sample range of 15 to 20 units during taxi. The Flap Position Indication status message that differs from the expected state requires the Captain to brief the condition when conditions permit.

The Cockpit Voice Recorder quantity display that differs from the expected state requires the pilot monitoring to monitor the condition when conditions permit. Both pilots will confirm any change in the Engine Anti-Ice selector position and advise the other pilot before the next phase of flight. During engine start, the relief pilot should verify the Cabin Pressure Controller switch position unless directed otherwise by the Sample Operations Center. The pilot monitoring will select any change in the Nosewheel Steering annunciation and advise the other pilot if a discrepancy is observed. During climb, the First Officer should cross-check the Pack Temperature Control selector position when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

CAUTION: The Traffic Advisory Display status message is expected to read within the sample range of 69 to 74 units during engine start.

Condition	Sample value	Remarks
Window Heat annunciation	14 units	Monitor
Standby Hydraulic switch position	93 units	Refer to related topic
Nosewheel Steering annunciation	56 units	Monitor
Brake Temperature Monitor indication	35 units	Monitor
Cockpit Voice Recorder status message	49 units	Advisory only

02.30 Airspeed Limitations

02.30.1 Airspeed Limitation 1

The Flap Position Indication selector position that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller advisory is expected to read within the sample range of 30 to 40 units during descent. If the Autopilot Channel A is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Primary Electrical Bus advisory that differs from the expected state requires both pilots to record the condition once the checklist item is complete. During climb, the First Officer should cross-check the Cockpit Voice Recorder indication once the checklist item is complete. The Traffic Advisory Display switch position is expected to read within the sample range of 35 to 43 units during engine start.

The Autopilot Channel B switch position is expected to read within the sample range of 65 to 75 units during a diversion. The captain will announce any change in the Cockpit Voice Recorder selector position and advise the other pilot when operating at a sample station without ground power. The Auxiliary Power Unit indication is expected to read within the sample range of 48 to 53 units during parking.

CAUTION: The Cockpit Voice Recorder indication is expected to read within the sample range of 77 to 82 units during takeoff. During taxi, the Captain should confirm the Transponder quantity display unless directed otherwise by the Sample Operations Center.

If the Wing Anti-Ice is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Auxiliary Power Unit annunciation is expected to read within the sample range of 50 to 57 units during an extended ground delay. The first officer will verify any change in the Traffic Advisory Display status message and advise the other pilot before the next phase of flight. The Window Heat switch position is expected to read within the sample range of 97 to 107 units during a maintenance-requested ground run. The first officer will announce any change in the Cargo Smoke Detection switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit quantity display that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval.

The relief pilot will record any change in the Auxiliary Power Unit advisory and advise the other pilot if a discrepancy is observed. The Nosewheel Steering switch position that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. The Weather Radar annunciation that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. During climb, the First Officer should record the Oxygen Distribution status message if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Fire Detection Loop quantity display is expected to read within the sample range of 25 to 36 units during an extended ground delay. See 10.20.16 Brake Temperature Monitor Test.

- During a maintenance-requested ground run, the relief pilot should monitor the Landing Gear Indication advisory once the checklist item is complete.
- The Cargo Smoke Detection annunciation that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight.
- The pilot flying will cross-check any change in the Nosewheel Steering indication and advise the other pilot before the next phase of flight.
- The Auxiliary Power Unit advisory is expected to read within the sample range of 7 to 16 units during approach.

NOTE: The Cockpit Voice Recorder status message that differs from the expected state requires the pilot monitoring to monitor the condition when operating at a sample station without ground power.

02.30.2 Airspeed Limitation 2

The Traffic Advisory Display switch position is expected to read within the sample range of 40 to 43 units during approach. Values in this manual are invented and must not be used for any operational purpose. The wording here is

placeholder content shaped like a procedure, not a procedure.

The Landing Gear Indication advisory is expected to read within the sample range of 73 to 79 units during parking. During approach, the Captain should announce the Ground Proximity Monitor advisory once the checklist item is complete. If the Nosewheel Steering is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Hydraulic System B advisory that differs from the expected state requires the First Officer to cross-check the condition when conditions permit. If the Nosewheel Steering is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

CAUTION: The Landing Gear Indication quantity display is expected to read within the sample range of 43 to 49 units during climb.

The Brake Temperature Monitor status message that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Engine Anti-Ice advisory is expected to read within the sample range of 4 to 9 units during engine start.

The Landing Gear Indication status message is expected to read within the sample range of 64 to 68 units during a diversion. If the Center Tank Pumps is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. During taxi, the Captain should confirm the Probe Heat quantity display once the checklist item is complete.

02.30.3 *Airspeed Limitation 3*

If the Wing Anti-Ice is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The first officer will announce any change in the Center Tank Pumps indication and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Autopilot Channel A indication is expected to read within the sample range of 90 to 98 units during approach.
- If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- The Flap Position Indication annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition unless directed otherwise by the Sample Operations Center.

The Autobrake Selector switch position is expected to read within the sample range of 60 to 70 units during taxi. The Center Tank Pumps switch position is expected to read within the sample range of 64 to 75 units during a maintenance-requested ground run. The pilot flying will cross-check any change in the Flight Management Computer switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The pilot monitoring will record any change in the Transponder quantity display and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The Standby Instruments selector position is expected to read within the sample range of 13 to 24 units during approach. During an extended ground delay, the First Officer should verify the Fuel Crossfeed advisory if the indication does not stabilize within the sample interval.

- The Brake Temperature Monitor status message that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed.
- The Ground Proximity Monitor status message that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed.
- During a maintenance-requested ground run, both pilots should monitor the Primary Electrical Bus selector position once the checklist item is complete.
- During parking, the pilot flying should confirm the Oxygen Distribution indication when conditions permit.

02.30.4 *Airspeed Limitation 4*

If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. Both pilots will brief any change in the Landing Gear Indication switch position and advise the other pilot if a discrepancy is observed. The Flap Position Indication indication is expected to read within the sample range of 68 to 74 units during landing.

- The Oxygen Distribution annunciation is expected to read within the sample range of 26 to 31 units during a diversion.
- The Thrust Reverser advisory is expected to read within the sample range of 92 to 102 units during landing.
- The first officer will record any change in the Cockpit Voice Recorder annunciation and advise the other pilot when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Window Heat is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Ground Proximity Monitor annunciation	15 units	Normal
Auxiliary Power Unit annunciation	84 units	Monitor
Transponder quantity display	69 units	Advisory only
Nosewheel Steering quantity display	41 units	Normal
Nosewheel Steering selector position	65 units	Monitor
Cargo Smoke Detection switch position	19 units	Advisory only
Cargo Smoke Detection indication	7 units	Monitor

NOTE: The Bleed Air Supply switch position is expected to read within the sample range of 62 to 67 units during a turnaround. The Brake Temperature Monitor indication is expected to read within the sample range of 30 to 42 units during parking.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

The Center Tank Pumps indication is expected to read within the sample range of 59 to 65 units during an extended ground delay. The captain will announce any change in the Flight Management Computer advisory and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The first officer will cross-check any change in the Center Tank Pumps selector position and advise the other pilot before the next phase of flight.

- The Autobrake Selector indication that differs from the expected state requires the relief pilot to brief the condition when conditions permit.
- If the Brake Temperature Monitor is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.

The Cabin Pressure Controller selector position is expected to read within the sample range of 63 to 68 units during a turnaround. The Autopilot Channel A annunciation that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. If the Brake Temperature Monitor is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. If the Probe Heat is inoperative, continue preflight only after the relief pilot has

reviewed the associated sample guidance. Refer to the related topic for additional sample context.

02.30.5 *Airspeed Limitation 5*

During parking, the Captain should brief the Cockpit Voice Recorder advisory if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Standby Hydraulic selector position that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. The relief pilot will confirm any change in the Ground Proximity Monitor selector position and advise the other pilot before the next phase of flight. If the Autopilot Channel A is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Engine Anti-Ice status message	54 units	Advisory only
Probe Heat quantity display	78 units	Refer to related topic
Nosewheel Steering selector position	91 units	Advisory only
Nosewheel Steering status message	55 units	Advisory only
Cargo Smoke Detection annunciation	92 units	Normal

The Fire Detection Loop switch position that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight. The Speedbrake Handle status message that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The captain will confirm any change in the Center Tank Pumps quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Fuel Crossfeed is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

The pilot flying will cross-check any change in the Bleed Air Supply advisory and advise the other pilot when the associated caution light remains illuminated. The Speedbrake Handle switch position is expected to read within the sample range of 31 to 41 units during taxi. During preflight, the pilot flying should announce the Hydraulic System A advisory if a discrepancy is observed. The Weather Radar selector position is expected to read within the sample range of 12 to 21 units during approach. The Brake Temperature Monitor advisory that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated. The captain will select any change in the Flap Position Indication indication and advise the other pilot when the associated caution light remains illuminated.

If the Cockpit Voice Recorder is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. If the Pack Temperature Control is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Cabin Pressure Controller advisory is expected to read within the sample range of 28 to 37 units during a maintenance-requested ground run. Refer to the related topic for additional sample context.

- The Autobrake Selector switch position is expected to read within the sample range of 75 to 78 units during a maintenance-requested ground run.
- During descent, the First Officer should monitor the Stall Warning status message when operating at a sample station without ground power.
- During parking, the pilot flying should confirm the Flap Position Indication switch position when operating at a sample station without ground power.
- The Stall Warning advisory that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete.
- The Landing Gear Indication indication that differs from the expected state requires the First Officer to verify the condition before the next phase of flight.

If the Probe Heat is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. During landing, the First Officer should confirm the Stall Warning selector position unless directed otherwise by the Sample Operations Center. If the Brake Temperature Monitor is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Bleed Air Supply switch position that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated. The pilot flying will record any change in the Autothrottle indication and advise the other pilot when conditions permit. During takeoff, the pilot flying should announce the Autobrake Selector status message when the associated caution light remains illuminated.

The Nosewheel Steering status message that differs from the expected state requires the pilot flying to verify the condition when conditions permit. If the Bleed Air Supply is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The pilot flying will announce any change in the Thrust Reverser indication and advise the other pilot when the associated caution light remains illuminated. See 15.10.10 Weather Radar Overview.

CAUTION: The Landing Gear Indication annunciation that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight. If the Wing Anti-Ice is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

02.30.6 *Airspeed Limitation 6*

The Standby Hydraulic annunciation is expected to read within the sample range of 40 to 51 units during takeoff. The pilot monitoring will record any change in the Traffic Advisory Display annunciation and advise the other pilot before the next phase of flight. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The pilot flying will record any change in the Hydraulic System A indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The Transponder indication is expected to read within the sample range of 7 to 17 units during approach.

The first officer will brief any change in the Flight Management Computer advisory and advise the other pilot when the associated caution light remains illuminated. The Ground Proximity Monitor indication that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel B advisory that differs from the expected state requires the Captain to brief the condition when conditions permit.

The Fuel Crossfeed advisory that differs from the expected state requires both pilots to monitor the condition before the next phase of flight. If the Flight Management Computer is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Standby Hydraulic indication that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit.

NOTE: The Speedbrake Handle advisory is expected to read within the sample range of 46 to 58 units during taxi.

The pilot monitoring will confirm any change in the Auxiliary Power Unit indication and advise the other pilot before the next phase of flight. During taxi, the pilot flying should select the Bleed Air Supply quantity display when conditions permit. The Primary Electrical Bus status message is expected to read within the sample range of 57 to 63 units during a maintenance-requested ground run. Refer to the related topic for additional sample context. See 07.20.5 Fuel Crossfeed Test.

02.30.7 *Airspeed Limitation 7*

During takeoff, the relief pilot should confirm the Center Tank Pumps indication once the checklist item is complete. The Center Tank Pumps indication is expected to read within the sample range of 18 to 26 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. During approach, the relief pilot should monitor the Pack Temperature Control status message before the next phase of flight.

NOTE: During a maintenance-requested ground run, the pilot monitoring should record the Center Tank Pumps quantity display before the next phase of flight. The Probe Heat selector position is expected to read within the

sample range of 75 to 82 units during climb.

If the Autobrake Selector is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Wing Anti-Ice switch position and advise the other pilot once the checklist item is complete. If the Flap Position Indication is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

NOTE: Both pilots will select any change in the Landing Gear Indication advisory and advise the other pilot when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice quantity display is expected to read within the sample range of 50 to 58 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder advisory is expected to read within the sample range of 37 to 47 units during engine start. The Traffic Advisory Display annunciation that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. See 06.10.10 Cargo Smoke Detection Crew Awareness.

CAUTION: If the Speedbrake Handle is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

02.30.8 *Airspeed Limitation 8*

If the Transponder is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Standby Instruments switch position and advise the other pilot once the checklist item is complete. If the Transponder is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

The Nosewheel Steering annunciation that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the pilot monitoring should confirm the Auxiliary Power Unit selector position unless directed otherwise by the Sample Operations Center. During descent, the pilot flying should confirm the Pack Temperature Control indication if a discrepancy is observed. Both pilots will record any change in the Flap Position Indication advisory and advise the other pilot when the associated caution light remains illuminated.

NOTE: The relief pilot will record any change in the Autothrottle annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

NOTE: The Pack Temperature Control selector position is expected to read within the sample range of 82 to 85 units during landing. The pilot monitoring will select any change in the Primary Electrical Bus indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Nosewheel Steering quantity display is expected to read within the sample range of 21 to 32 units during preflight.
- During a turnaround, the Captain should monitor the Fuel Crossfeed indication once the checklist item is complete.

The captain will announce any change in the Speedbrake Handle indication and advise the other pilot if a discrepancy is observed. The relief pilot will brief any change in the Autobrake Selector quantity display and advise the other pilot if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 91 to 96 units during a turnaround. During engine start, the Captain should announce the Autothrottle status message if a discrepancy is observed. During taxi, the pilot flying should monitor the Brake Temperature Monitor quantity display when the associated caution light remains illuminated.

The Cabin Pressure Controller selector position that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. If the Window Heat is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

During approach, the pilot flying should confirm the Fire Detection Loop quantity display if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. If the Fuel Crossfeed is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The pilot flying will announce any change in the Brake Temperature Monitor quantity display and advise the other pilot if a discrepancy is observed. The Fuel Crossfeed indication is expected to read within the sample range of 51 to 54 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure.

02.30.9 Airspeed Limitation 9

If the Transponder is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The pilot flying will brief any change in the Autothrottle advisory and advise the other pilot when operating at a sample station without ground power. The Brake Temperature Monitor advisory that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

The Ground Proximity Monitor switch position that differs from the expected state requires the Captain to record the condition when the associated caution light remains illuminated. The Fire Detection Loop advisory is expected to read within the sample range of 4 to 10 units during engine start. The Cargo Smoke Detection status message is expected to read within the sample range of 68 to 77 units during an extended ground delay. The Flap Position Indication advisory is expected to read within the sample range of 85 to 97 units during parking. Refer to the related topic for additional sample context.

- The first officer will confirm any change in the Autopilot Channel A annunciation and advise the other pilot when conditions permit.
- If the Window Heat is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.
- If the Ground Proximity Monitor is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.
- During preflight, the relief pilot should brief the Oxygen Distribution indication unless directed otherwise by the Sample Operations Center.
- During an extended ground delay, both pilots should announce the Primary Electrical Bus indication when conditions permit.
- The first officer will select any change in the Fuel Crossfeed selector position and advise the other pilot once the checklist item is complete.
- The Window Heat indication is expected to read within the sample range of 56 to 60 units during a maintenance-requested ground run.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The relief pilot will monitor any change in the Thrust Reverser status message and advise the other pilot once the checklist item is complete.

The Stall Warning quantity display that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval. If the Autopilot Channel A is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Bleed Air Supply quantity display is expected to read within the sample range of 68 to 73 units during engine start. This text is fictional and exists only to give the prototype realistic volume and structure. The Flight Management Computer indication that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the

Sample Operations Center.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

02.30.10 *Airspeed Limitation 10*

During a turnaround, the First Officer should select the Weather Radar status message when operating at a sample station without ground power. The Thrust Reverser switch position is expected to read within the sample range of 20 to 24 units during parking. The captain will record any change in the Stall Warning selector position and advise the other pilot if a discrepancy is observed. During a turnaround, the Captain should confirm the Standby Hydraulic status message when operating at a sample station without ground power. During takeoff, both pilots should cross-check the Standby Instruments quantity display when the associated caution light remains illuminated.

If the Cargo Smoke Detection is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Probe Heat switch position that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. The Cabin Pressure Controller status message is expected to read within the sample range of 63 to 75 units during descent.

Condition	Sample value	Remarks
Cockpit Voice Recorder annunciation	18 units	Normal
Standby Instruments quantity display	1 units	Monitor
Autopilot Channel B annunciation	24 units	Normal
Landing Gear Indication switch position	86 units	Monitor
Autopilot Channel B indication	83 units	Refer to related topic

Condition	Sample value	Remarks
Autobrake Selector status message	58 units	Monitor
Speedbrake Handle annunciation	75 units	Refer to related topic
Thrust Reverser indication	61 units	Normal
Probe Heat quantity display	69 units	Normal

Values in this manual are invented and must not be used for any operational purpose. The relief pilot will brief any change in the Nosewheel Steering quantity display and advise the other pilot when operating at a sample station without ground power. The Thrust Reverser selector position that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete. The first officer will record any change in the Autopilot Channel B quantity display and advise the other pilot when conditions permit. During climb, the Captain should select the Traffic Advisory Display quantity display unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the Captain should announce the Auxiliary Power Unit switch position once the checklist item is complete. If the Auxiliary Power Unit is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Cockpit Voice Recorder selector position and advise the other pilot before the next phase of flight.

NOTE: If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

- The pilot flying will record any change in the Fuel Crossfeed selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Primary Electrical Bus switch position is expected to read within the sample range of 26 to 35 units during approach.

- The pilot flying will cross-check any change in the Hydraulic System B selector position and advise the other pilot when the associated caution light remains illuminated.
- The pilot flying will cross-check any change in the Brake Temperature Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Standby Hydraulic is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

02.30.11 *Airspeed Limitation 11*

During engine start, the relief pilot should confirm the Cabin Pressure Controller advisory when the associated caution light remains illuminated. The Hydraulic System A status message that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. During taxi, the pilot flying should record the Autopilot Channel B indication before the next phase of flight. The Nosewheel Steering switch position is expected to read within the sample range of 71 to 78 units during a diversion.

NOTE: During cruise, the First Officer should cross-check the Brake Temperature Monitor annunciation once the checklist item is complete.

The first officer will announce any change in the Transponder status message and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. If the Probe Heat is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

During cruise, the Captain should announce the Auxiliary Power Unit switch position if a discrepancy is observed. The Window Heat advisory is expected to read within the sample range of 55 to 65 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control annunciation that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit.

The Thrust Reverser annunciation is expected to read within the sample range of 58 to 66 units during parking. The first officer will record any change in the Autopilot Channel A status message and advise the other pilot if a discrepancy is observed. The relief pilot will announce any change in the Autopilot Channel B status message and advise the other pilot if the indication does not stabilize within the sample interval. The Thrust Reverser advisory that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Center Tank Pumps quantity display	26 units	Advisory only
Autopilot Channel B advisory	77 units	Advisory only
Standby Hydraulic status message	61 units	Refer to related topic
Hydraulic System A annunciation	86 units	Normal
Standby Instruments selector position	52 units	Refer to related topic
Wing Anti-Ice advisory	21 units	Monitor

02.30.12 *Airspeed Limitation 12*

If the Probe Heat is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During cruise, the pilot monitoring should cross-check the Probe Heat annunciation when conditions permit. During landing, the Captain should monitor the Auxiliary Power Unit selector position before the next phase of flight.

- The Engine Anti-Ice indication is expected to read within the sample range of 53 to 62 units during takeoff.

- The captain will record any change in the Traffic Advisory Display quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.
- Both pilots will select any change in the Window Heat status message and advise the other pilot if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Weather Radar selector position	75 units	Normal
Cargo Smoke Detection advisory	53 units	Refer to related topic
Oxygen Distribution status message	15 units	Advisory only
Autobrake Selector status message	29 units	Advisory only
Hydraulic System A selector position	65 units	Normal
Engine Anti-Ice annunciation	26 units	Normal

During climb, the pilot flying should announce the Standby Instruments selector position if the indication does not stabilize within the sample interval. The Oxygen Distribution quantity display is expected to read within the sample range of 72 to 83 units during descent. The Engine Anti-Ice advisory is expected to read within the sample range of 61 to 71 units during takeoff. The Flap Position Indication advisory that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center.

- During preflight, the pilot flying should cross-check the Standby Instruments advisory before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The captain will monitor any change in the Hydraulic System A annunciation and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Stall Warning status message	49 units	Monitor
Bleed Air Supply switch position	62 units	Monitor
Brake Temperature Monitor annunciation	70 units	Refer to related topic
Window Heat indication	48 units	Monitor
Brake Temperature Monitor switch position	99 units	Normal
Autothrottle switch position	82 units	Refer to related topic

If the Landing Gear Indication is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The pilot flying will brief any change in the Stall Warning annunciation and advise the other pilot once the checklist item is complete.

If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Speedbrake Handle selector position that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. The Engine Anti-Ice annunciation that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. See 06.10.4 Hydraulic System B Limits Display.

02.30.13 *Airspeed Limitation 13*

This text is fictional and exists only to give the prototype realistic volume and structure. The Speedbrake Handle status message is expected to read within the sample range of 40 to 49 units during cruise. The Engine Anti-Ice annunciation that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval. The first officer will brief any change in the Fire Detection Loop status message and advise the other pilot if the indication does not stabilize within the sample interval.

If the Autopilot Channel B is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The relief pilot will verify any change in the Hydraulic System B annunciation and advise the other pilot if a discrepancy is observed. The Autopilot Channel B switch position that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval.

- The Hydraulic System A selector position that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed.
- The Cabin Pressure Controller selector position that differs from the expected state requires the Captain to record the condition when conditions permit.
- During landing, the relief pilot should confirm the Cockpit Voice Recorder switch position when conditions permit.
- The pilot flying will brief any change in the Ground Proximity Monitor indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During a diversion, the pilot flying should monitor the Auxiliary Power Unit quantity display if a discrepancy is observed.
- If the Window Heat is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

CAUTION: If the Pack Temperature Control is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

If the Hydraulic System B is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

02.40 Systems Limitations

02.40.1 Cabin Pressure Controller Status Messages

The Transponder advisory is expected to read within the sample range of 87 to 97 units during approach. During landing, the relief pilot should confirm the Ground Proximity Monitor switch position if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder quantity display that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated. If the Nosewheel Steering is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

Both pilots will verify any change in the Traffic Advisory Display advisory and advise the other pilot once the checklist item is complete. The Probe Heat annunciation that differs from the expected state requires the First Officer to announce the condition when conditions permit. If the Fuel Crossfeed is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. During taxi, the First Officer should monitor the Pack Temperature Control switch position when the associated caution light remains illuminated. If the Traffic Advisory Display is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. During a turnaround, the pilot flying should announce the Flap Position Indication quantity display when operating at a sample station without ground power.

Condition	Sample value	Remarks
-----------	--------------	---------

Hydraulic System B status message	85 units	Normal
Cargo Smoke Detection indication	28 units	Refer to related topic
Oxygen Distribution indication	90 units	Monitor
Stall Warning status message	13 units	Monitor
Brake Temperature Monitor switch position	52 units	Refer to related topic
Flap Position Indication indication	27 units	Normal
Bleed Air Supply status message	67 units	Normal

Condition	Sample value	Remarks
Ground Proximity Monitor switch position	11 units	Normal
Engine Anti-Ice quantity display	46 units	Monitor
Autopilot Channel A quantity display	62 units	Refer to related topic
Center Tank Pumps status message	30 units	Normal
Cockpit Voice Recorder indication	70 units	Refer to related topic
Flight Management Computer indication	71 units	Advisory only

NOTE: The relief pilot will select any change in the Standby Hydraulic annunciation and advise the other pilot before the next phase of flight. The Standby Hydraulic status message that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.

NOTE: The Cargo Smoke Detection annunciation that differs from the expected state requires the relief pilot to record the condition before the next phase of flight.

02.40.2 Standby Hydraulic Interfaces

During engine start, both pilots should verify the Cabin Pressure Controller advisory before the next phase of flight. The relief pilot will confirm any change in the Center Tank Pumps advisory and advise the other pilot if a discrepancy is observed. The Autobrake Selector switch position is expected to read within the sample range of 29 to 41 units during takeoff. The captain will confirm any change in the Center Tank Pumps indication and advise the other pilot when operating at a sample station without ground power. The Hydraulic System B selector position is expected to read within the sample range of 76 to 80 units during engine start. If the Autopilot Channel A is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

If the Center Tank Pumps is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will cross-check any change in the Thrust Reverser indication and advise the other pilot when conditions permit. See 09.20.6 Engine Anti-Ice Status Messages.

- During takeoff, both pilots should verify the Ground Proximity Monitor advisory before the next phase of flight.
- During climb, the pilot flying should announce the Cockpit Voice Recorder quantity display if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Engine Anti-Ice quantity display is expected to read within the sample range of 82 to 86 units during an extended ground delay.
- If the Landing Gear Indication is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- The Transponder annunciation is expected to read within the sample range of 34 to 44 units during preflight.

- If the Brake Temperature Monitor is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- If the Traffic Advisory Display is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- The Bleed Air Supply selector position that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power.
- During engine start, the First Officer should select the Primary Electrical Bus advisory if a discrepancy is observed.
- The Center Tank Pumps switch position that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.
- The pilot monitoring will select any change in the Ground Proximity Monitor switch position and advise the other pilot before the next phase of flight.
- The Flight Management Computer annunciation that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete.

NOTE: The Cabin Pressure Controller advisory is expected to read within the sample range of 8 to 12 units during preflight.

NOTE: The Flap Position Indication annunciation is expected to read within the sample range of 6 to 13 units during engine start. The Wing Anti-Ice quantity display is expected to read within the sample range of 16 to 24 units during an extended ground delay.

02.40.3 Brake Temperature Monitor Test

The Fire Detection Loop quantity display is expected to read within the sample range of 25 to 31 units during an extended ground delay. Both pilots will confirm any change in the Cockpit Voice Recorder selector position and advise the other pilot when conditions permit. If the Hydraulic System B is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Autothrottle advisory that differs from the expected state requires both pilots to select the condition before the next phase of flight.

The Autobrake Selector selector position is expected to read within the sample range of 43 to 53 units during a maintenance-requested ground run. If the Oxygen Distribution is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During takeoff, the Captain should verify the Autothrottle indication once the checklist item is complete.

Condition	Sample value	Remarks
Pack Temperature Control indication	88 units	Normal
Center Tank Pumps status message	25 units	Refer to related topic
Standby Hydraulic switch position	80 units	Normal
Thrust Reverser selector position	88 units	Normal

During parking, the Captain should monitor the Flap Position Indication annunciation unless directed otherwise by the Sample Operations Center. If the Wing Anti-Ice is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Weather Radar annunciation that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated.

The Fire Detection Loop quantity display that differs from the expected state requires both pilots to verify the condition before the next phase of flight. The Engine Anti-Ice advisory is expected to read within the sample range of 74 to 78 units during a diversion. During parking, both pilots should select the Standby Hydraulic annunciation when the

associated caution light remains illuminated. The Auxiliary Power Unit advisory is expected to read within the sample range of 51 to 61 units during an extended ground delay. Refer to the related topic for additional sample context.

During preflight, the First Officer should monitor the Hydraulic System A switch position unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller annunciation that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. If the Traffic Advisory Display is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. During parking, both pilots should cross-check the Fire Detection Loop selector position when the associated caution light remains illuminated. The Engine Anti-Ice selector position is expected to read within the sample range of 96 to 99 units during cruise.

Condition	Sample value	Remarks
Probe Heat indication	29 units	Refer to related topic
Weather Radar annunciation	62 units	Advisory only
Standby Hydraulic status message	69 units	Refer to related topic
Landing Gear Indication switch position	26 units	Normal
Nosewheel Steering annunciation	33 units	Advisory only
Engine Anti-Ice indication	94 units	Monitor

02.40.4 Weather Radar Overview

If the Pack Temperature Control is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. During a turnaround, both pilots should confirm the Standby Hydraulic indication before the next phase of flight. During takeoff, the relief pilot should record the Autothrottle advisory before the next phase of flight. The Stall Warning quantity display that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System B is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

The Cargo Smoke Detection annunciation that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated. During taxi, both pilots should brief the Brake Temperature Monitor switch position when the associated caution light remains illuminated. The relief pilot will cross-check any change in the Center Tank Pumps quantity display and advise the other pilot when conditions permit. If the Center Tank Pumps is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The captain will record any change in the Cockpit Voice Recorder indication and advise the other pilot unless directed otherwise by the Sample Operations Center. During climb, the pilot flying should verify the Bleed Air Supply status message when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Thrust Reverser indication	74 units	Monitor
Flight Management Computer annunciation	26 units	Advisory only
Ground Proximity Monitor status message	3 units	Monitor
Speedbrake Handle quantity display	52 units	Refer to related topic
Wing Anti-Ice selector position	80 units	Normal
Cockpit Voice Recorder annunciation	11 units	Refer to related topic

CAUTION: The Bleed Air Supply status message that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated.

During takeoff, the relief pilot should verify the Primary Electrical Bus switch position when operating at a sample station without ground power. If the Hydraulic System A is inoperative, continue a maintenance-requested ground run

only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Autothrottle quantity display is expected to read within the sample range of 18 to 28 units during a diversion. The Bleed Air Supply annunciation that differs from the expected state requires the First Officer to monitor the condition when conditions permit.

02.40.5 Center Tank Pumps Normal Operation

The first officer will cross-check any change in the Landing Gear Indication quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, both pilots should cross-check the Primary Electrical Bus advisory when operating at a sample station without ground power. The pilot monitoring will cross-check any change in the Cockpit Voice Recorder status message and advise the other pilot when the associated caution light remains illuminated.

If the Weather Radar is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Engine Anti-Ice quantity display that differs from the expected state requires the First Officer to record the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. If the Auxiliary Power Unit is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

During descent, the pilot flying should announce the Brake Temperature Monitor advisory once the checklist item is complete. Both pilots will cross-check any change in the Oxygen Distribution annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will announce any change in the Autopilot Channel A switch position and advise the other pilot before the next phase of flight.

The relief pilot will cross-check any change in the Fire Detection Loop switch position and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

If the Speedbrake Handle is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The Hydraulic System A switch position is expected to read within the sample range of 78 to 87 units during cruise. The Weather Radar status message that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated.

02.40.6 Standby Hydraulic Limits Display

During engine start, both pilots should brief the Cargo Smoke Detection selector position when operating at a sample station without ground power. The relief pilot will brief any change in the Hydraulic System A switch position and advise the other pilot before the next phase of flight. The captain will select any change in the Cockpit Voice Recorder quantity display and advise the other pilot if a discrepancy is observed. The first officer will brief any change in the Fire Detection Loop status message and advise the other pilot once the checklist item is complete.

- The pilot monitoring will announce any change in the Flight Management Computer indication and advise the other pilot when conditions permit.
- The relief pilot will confirm any change in the Probe Heat selector position and advise the other pilot when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.

The Cargo Smoke Detection advisory that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power. The Autopilot Channel B switch position is expected to read within the sample range of 16 to 26 units during takeoff. Refer to the related topic for additional sample context. Both pilots will confirm any change in the Weather Radar switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Ground Proximity Monitor switch position that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed.

- The Hydraulic System B annunciation is expected to read within the sample range of 70 to 77 units during approach.
- The Cabin Pressure Controller indication that differs from the expected state requires the pilot monitoring to monitor the condition when operating at a sample station without ground power.
- During preflight, the relief pilot should cross-check the Engine Anti-Ice status message when conditions permit.
- The captain will brief any change in the Pack Temperature Control annunciation and advise the other pilot if a discrepancy is observed.
- Refer to the related topic for additional sample context.
- The first officer will cross-check any change in the Stall Warning advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- Both pilots will select any change in the Wing Anti-Ice switch position and advise the other pilot before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During an extended ground delay, the relief pilot should select the Hydraulic System B status message once the checklist item is complete.
- If the Speedbrake Handle is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

During a maintenance-requested ground run, the Captain should cross-check the Autopilot Channel A switch position when conditions permit. The Primary Electrical Bus annunciation that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System A is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

02.40.7 Engine Anti-Ice Status Messages

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System B selector position is expected to read within the sample range of 36 to 41 units during takeoff. The first officer will brief any change in the Landing Gear Indication quantity display and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Fire Detection Loop selector position	91 units	Refer to related topic
Center Tank Pumps indication	42 units	Monitor
Ground Proximity Monitor selector position	49 units	Monitor
Thrust Reverser indication	78 units	Monitor

NOTE: The Autothrottle status message is expected to read within the sample range of 22 to 34 units during approach. The Autopilot Channel B switch position that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.

- The Probe Heat selector position that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete.
- Both pilots will record any change in the Autobrake Selector advisory and advise the other pilot when conditions permit.
- During cruise, the First Officer should confirm the Cockpit Voice Recorder quantity display unless directed otherwise by the Sample Operations Center.

- The Hydraulic System A switch position is expected to read within the sample range of 49 to 52 units during climb.
- The Stall Warning annunciation that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed.

The Weather Radar advisory is expected to read within the sample range of 52 to 61 units during engine start. During approach, the pilot monitoring should record the Stall Warning quantity display before the next phase of flight. The first officer will confirm any change in the Flight Management Computer advisory and advise the other pilot before the next phase of flight.

NOTE: The Weather Radar switch position that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight. The first officer will announce any change in the Cargo Smoke Detection advisory and advise the other pilot once the checklist item is complete.

Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. The Fuel Crossfeed annunciation that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. The pilot monitoring will confirm any change in the Pack Temperature Control quantity display and advise the other pilot when operating at a sample station without ground power.

02.40.8 Fire Detection Loop Limits Display

The Engine Anti-Ice switch position is expected to read within the sample range of 10 to 22 units during takeoff. The pilot flying will select any change in the Hydraulic System B quantity display and advise the other pilot if a discrepancy is observed. The Brake Temperature Monitor indication that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. During takeoff, the First Officer should select the Fire Detection Loop switch position when the associated caution light remains illuminated.

The Auxiliary Power Unit selector position is expected to read within the sample range of 73 to 80 units during climb. If the Center Tank Pumps is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Center Tank Pumps quantity display that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. If the Window Heat is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System B switch position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. During descent, the pilot flying should verify the Center Tank Pumps advisory when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. If the Traffic Advisory Display is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

The Probe Heat status message that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. The Center Tank Pumps indication is expected to read within the sample range of 2 to 9 units during engine start. During landing, the First Officer should confirm the Pack Temperature Control selector position when conditions permit. During descent, both pilots should brief the Hydraulic System A quantity display unless directed otherwise by the Sample Operations Center.

CAUTION: The Fuel Crossfeed quantity display that differs from the expected state requires both pilots to confirm the condition when conditions permit. The first officer will cross-check any change in the Engine Anti-Ice switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Probe Heat indication is expected to read within the sample range of 12 to 19 units during cruise. If the Flap Position Indication is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. During landing, the pilot flying should monitor the Engine Anti-Ice indication before the next phase of flight.

- Both pilots will cross-check any change in the Pack Temperature Control quantity display and advise the other pilot if a discrepancy is observed.

- If the Primary Electrical Bus is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.
- If the Bleed Air Supply is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.
- The captain will verify any change in the Probe Heat selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Hydraulic System A quantity display is expected to read within the sample range of 94 to 105 units during takeoff.

02.40.9 Center Tank Pumps Status Messages

This text is fictional and exists only to give the prototype realistic volume and structure. The Nosewheel Steering selector position that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. The Bleed Air Supply selector position that differs from the expected state requires the Captain to record the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. If the Engine Anti-Ice is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B advisory is expected to read within the sample range of 45 to 54 units during cruise. The Transponder annunciation that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. If the Weather Radar is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Cabin Pressure Controller advisory that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The Cabin Pressure Controller selector position that differs from the expected state requires the relief pilot to announce the condition when conditions permit.

The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, the relief pilot should confirm the Cabin Pressure Controller quantity display if a discrepancy is observed. During parking, the relief pilot should cross-check the Nosewheel Steering switch position if the indication does not stabilize within the sample interval. The first officer will cross-check any change in the Window Heat selector position and advise the other pilot before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. During an extended ground delay, the Captain should monitor the Pack Temperature Control annunciation when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autopilot Channel B quantity display	55 units	Refer to related topic
Cockpit Voice Recorder advisory	37 units	Normal
Oxygen Distribution advisory	82 units	Advisory only
Hydraulic System A indication	17 units	Refer to related topic

CAUTION: The Hydraulic System B annunciation is expected to read within the sample range of 26 to 37 units during a turnaround. The captain will record any change in the Cargo Smoke Detection status message and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The relief pilot will verify any change in the Cargo Smoke Detection selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Nosewheel Steering indication is expected to read within the sample range of 81 to 91 units during preflight.

02.40.10 Wing Anti-Ice Limits Display

If the Auxiliary Power Unit is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The Brake Temperature Monitor advisory that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. If the Standby Instruments is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The pilot flying will select any change in the Autopilot Channel B indication and advise the other pilot once the checklist item is complete. The Flight Management Computer status message that differs from the expected state requires the pilot monitoring to record the condition when conditions permit. The Center Tank Pumps indication is expected to read within the sample range of 67 to 76 units during parking.

The Fuel Crossfeed annunciation is expected to read within the sample range of 86 to 90 units during approach. If the Traffic Advisory Display is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Nosewheel Steering switch position and advise the other pilot when conditions permit. If the Wing Anti-Ice is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

During cruise, the pilot flying should verify the Fire Detection Loop quantity display if a discrepancy is observed. The Center Tank Pumps quantity display is expected to read within the sample range of 35 to 45 units during takeoff. The captain will brief any change in the Engine Anti-Ice quantity display and advise the other pilot if a discrepancy is observed. During descent, the relief pilot should cross-check the Cabin Pressure Controller advisory before the next phase of flight.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

- During a maintenance-requested ground run, the Captain should confirm the Standby Hydraulic switch position when operating at a sample station without ground power.
- The Fuel Crossfeed status message is expected to read within the sample range of 82 to 87 units during landing.
- The Flap Position Indication advisory is expected to read within the sample range of 12 to 18 units during parking.
- During a diversion, both pilots should select the Autobrake Selector annunciation if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.

Refer to the related topic for additional sample context. If the Autopilot Channel A is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Window Heat switch position	17 units	Monitor
Speedbrake Handle quantity display	57 units	Refer to related topic
Pack Temperature Control selector position	33 units	Advisory only
Standby Hydraulic quantity display	66 units	Monitor

02.40.11 Autothrottle Crew Awareness

The Auxiliary Power Unit indication that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will record any change in the Nosewheel Steering annunciation and advise the other pilot once the checklist item is complete. If the Cabin Pressure Controller is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Nosewheel Steering is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

The Flight Management Computer status message that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed selector position is expected to read within the sample range of 12 to 22 units during a diversion. The Thrust Reverser switch position that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. The Autopilot Channel B quantity display that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.

NOTE: If the Autopilot Channel B is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

The Standby Hydraulic indication is expected to read within the sample range of 24 to 36 units during a turnaround. Refer to the related topic for additional sample context. The relief pilot will select any change in the Bleed Air Supply indication and advise the other pilot when the associated caution light remains illuminated. Both pilots will verify any change in the Cabin Pressure Controller annunciation and advise the other pilot if a discrepancy is observed. During a diversion, the Captain should record the Flap Position Indication selector position when operating at a sample station without ground power. The Autopilot Channel B switch position that differs from the expected state requires the Captain to announce the condition once the checklist item is complete.

- Refer to the related topic for additional sample context.
- Values in this manual are invented and must not be used for any operational purpose.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Fuel Crossfeed switch position that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During taxi, the Captain should select the Standby Instruments annunciation once the checklist item is complete.

02.40.12 Stall Warning Crew Awareness

The Standby Instruments annunciation that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. The Speedbrake Handle selector position is expected to read within the sample range of 75 to 85 units during climb. The Center Tank Pumps indication that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Flight Management Computer quantity display	57 units	Advisory only
Fuel Crossfeed indication	73 units	Normal
Cabin Pressure Controller switch position	61 units	Advisory only
Brake Temperature Monitor switch position	32 units	Advisory only
Center Tank Pumps quantity display	45 units	Normal

If the Hydraulic System B is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. Both pilots will select any change in the Landing Gear Indication indication and advise the other pilot if a discrepancy is observed. The Autopilot Channel A quantity display that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power. If the Auxiliary Power Unit is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

The Autopilot Channel B indication that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. The Autopilot Channel A selector position is expected to read within the sample range of 75 to 79 units during a diversion. If the Auxiliary Power Unit is inoperative, continue

descent only after the First Officer has reviewed the associated sample guidance. During cruise, the Captain should select the Hydraulic System A advisory when conditions permit. See 19.40.12 Fuel Planning Data Table 13.

NOTE: The Weather Radar indication that differs from the expected state requires the Captain to record the condition when conditions permit. The Thrust Reverser advisory is expected to read within the sample range of 38 to 44 units during takeoff.

CAUTION: The Engine Anti-Ice status message is expected to read within the sample range of 9 to 19 units during a maintenance-requested ground run. If the Transponder is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

- The Wing Anti-Ice switch position is expected to read within the sample range of 61 to 72 units during climb.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Values in this manual are invented and must not be used for any operational purpose.
- This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During a turnaround, the relief pilot should monitor the Autopilot Channel B status message unless directed otherwise by the Sample Operations Center.

02.40.13 Cockpit Voice Recorder Crew Awareness

The Autothrottle indication that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete. The Autopilot Channel B annunciation is expected to read within the sample range of 14 to 21 units during cruise. During descent, the First Officer should brief the Fire Detection Loop switch position when the associated caution light remains illuminated. The Brake Temperature Monitor status message is expected to read within the sample range of 47 to 59 units during parking.

NOTE: The Standby Hydraulic status message is expected to read within the sample range of 70 to 78 units during cruise. The Thrust Reverser indication is expected to read within the sample range of 86 to 92 units during parking.

The pilot monitoring will verify any change in the Ground Proximity Monitor selector position and advise the other pilot when the associated caution light remains illuminated. Both pilots will record any change in the Hydraulic System A indication and advise the other pilot if a discrepancy is observed. The relief pilot will cross-check any change in the Fuel Crossfeed status message and advise the other pilot when operating at a sample station without ground power.

NOTE: The Flight Management Computer advisory that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated.

The Ground Proximity Monitor status message is expected to read within the sample range of 54 to 59 units during an extended ground delay. During a diversion, both pilots should cross-check the Hydraulic System B indication if the indication does not stabilize within the sample interval. If the Autothrottle is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

The Thrust Reverser advisory that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed advisory that differs from the expected state requires both pilots to brief the condition when conditions permit. The Center Tank Pumps indication is expected to read within the sample range of 83 to 87 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. If the Autopilot Channel A is inoperative, continue preflight only after both pilots have reviewed the associated sample guidance. During a maintenance-requested ground run, both pilots should announce the Autothrottle status message if the indication does not stabilize within the sample interval.

CAUTION: The first officer will cross-check any change in the Fuel Crossfeed indication and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- During cruise, the First Officer should verify the Flap Position Indication indication once the checklist item is complete.
- The Transponder selector position that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center.

02.40.14 Brake Temperature Monitor Status Messages

The Center Tank Pumps indication that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed. Both pilots will monitor any change in the Brake Temperature Monitor switch position and advise the other pilot once the checklist item is complete. The Transponder annunciation is expected to read within the sample range of 55 to 60 units during descent. If the Cockpit Voice Recorder is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The first officer will confirm any change in the Autopilot Channel B advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The Hydraulic System A selector position is expected to read within the sample range of 5 to 17 units during climb.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- This text is fictional and exists only to give the prototype realistic volume and structure.

This text is fictional and exists only to give the prototype realistic volume and structure. The Brake Temperature Monitor indication is expected to read within the sample range of 79 to 85 units during taxi. During parking, both pilots should brief the Hydraulic System B selector position if the indication does not stabilize within the sample interval. The first officer will verify any change in the Oxygen Distribution indication and advise the other pilot if a discrepancy is observed. If the Nosewheel Steering is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. During descent, the pilot monitoring should record the Speedbrake Handle switch position when operating at a sample station without ground power.

CAUTION: If the Cabin Pressure Controller is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Transponder selector position is expected to read within the sample range of 27 to 34 units during descent.

Condition	Sample value	Remarks
Hydraulic System B quantity display	8 units	Monitor
Primary Electrical Bus switch position	60 units	Monitor
Stall Warning switch position	41 units	Monitor

Both pilots will brief any change in the Ground Proximity Monitor quantity display and advise the other pilot if a discrepancy is observed. If the Flight Management Computer is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. During a turnaround, the First Officer should cross-check the Nosewheel Steering status message once the checklist item is complete. The Flight Management Computer quantity display that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed. If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

02.40.15 Center Tank Pumps Test

The Fuel Crossfeed advisory is expected to read within the sample range of 85 to 89 units during taxi. The first officer will record any change in the Flap Position Indication annunciation and advise the other pilot before the next phase of flight. The Speedbrake Handle annunciation is expected to read within the sample range of 73 to 84 units during engine start. If the Primary Electrical Bus is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. See 03.20.19 Verification:

Cabin Pressure Controller.

NOTE: The Center Tank Pumps quantity display is expected to read within the sample range of 93 to 99 units during descent.

- During takeoff, the relief pilot should select the Cabin Pressure Controller annunciation when the associated caution light remains illuminated.
- The Weather Radar quantity display that differs from the expected state requires both pilots to brief the condition before the next phase of flight.
- Both pilots will cross-check any change in the Fuel Crossfeed status message and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Standby Hydraulic annunciation	94 units	Normal
Center Tank Pumps quantity display	35 units	Refer to related topic
Ground Proximity Monitor annunciation	55 units	Normal
Flap Position Indication indication	96 units	Normal
Flap Position Indication indication	92 units	Refer to related topic
Thrust Reverser selector position	79 units	Monitor

- The Oxygen Distribution selector position that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval.
- If the Weather Radar is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.
- The Oxygen Distribution advisory that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power.

02.40.16 Hydraulic System A Test

During preflight, the Captain should verify the Autopilot Channel B advisory when conditions permit. The Brake Temperature Monitor switch position that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Primary Electrical Bus indication that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Autobrake Selector indication	61 units	Refer to related topic
Flap Position Indication status message	72 units	Advisory only
Speedbrake Handle advisory	20 units	Advisory only

CAUTION: The relief pilot will select any change in the Brake Temperature Monitor status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

During parking, the pilot flying should monitor the Oxygen Distribution quantity display once the checklist item is complete. The pilot flying will monitor any change in the Brake Temperature Monitor status message and advise the other pilot when the associated caution light remains illuminated. The Fuel Crossfeed switch position is expected to read within the sample range of 87 to 98 units during taxi. The captain will announce any change in the Standby Hydraulic switch position and advise the other pilot before the next phase of flight.

During descent, both pilots should monitor the Ground Proximity Monitor switch position before the next phase of flight. The Autothrottle status message that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. The relief pilot will select any change in the Bleed Air Supply advisory and advise the other pilot when the associated caution light remains illuminated. During taxi, the Captain should verify the Center Tank Pumps status message if the indication does not stabilize within the sample interval. During takeoff, both pilots should confirm the Speedbrake Handle quantity display when operating at a sample station without ground power.

The pilot flying will select any change in the Primary Electrical Bus annunciation and advise the other pilot before the next phase of flight. If the Window Heat is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The Primary Electrical Bus advisory is expected to read within the sample range of 42 to 50 units during engine start. The pilot flying will announce any change in the Pack Temperature Control switch position and advise the other pilot once the checklist item is complete. If the Autopilot Channel A is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Hydraulic System A indication is expected to read within the sample range of 50 to 59 units during a maintenance-requested ground run.

The Cabin Pressure Controller switch position is expected to read within the sample range of 53 to 60 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose. If the Center Tank Pumps is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

During cruise, the pilot monitoring should confirm the Hydraulic System B annunciation before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will cross-check any change in the Window Heat status message and advise the other pilot before the next phase of flight. Both pilots will cross-check any change in the Pack Temperature Control annunciation and advise the other pilot when the associated caution light remains illuminated. Both pilots will brief any change in the Speedbrake Handle advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

02.40.17 Stall Warning Normal Operation

During an extended ground delay, both pilots should record the Flap Position Indication switch position unless directed otherwise by the Sample Operations Center. The Flight Management Computer status message that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. The Pack Temperature Control quantity display that differs from the expected state requires the pilot flying to verify the condition if a discrepancy is observed. If the Hydraulic System A is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

- The pilot flying will cross-check any change in the Standby Hydraulic indication and advise the other pilot when operating at a sample station without ground power.
- The Flight Management Computer status message that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center.
- The first officer will verify any change in the Fuel Crossfeed annunciation and advise the other pilot when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.
- The Engine Anti-Ice annunciation that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.

NOTE: During approach, the relief pilot should verify the Nosewheel Steering annunciation unless directed otherwise by the Sample Operations Center. The captain will record any change in the Auxiliary Power Unit quantity display and advise the other pilot once the checklist item is complete.

The Nosewheel Steering advisory that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. The relief pilot will verify any change in the Ground Proximity

Monitor advisory and advise the other pilot before the next phase of flight. The Flight Management Computer annunciation that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection annunciation that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete.

Condition	Sample value	Remarks
Hydraulic System A advisory	69 units	Advisory only
Hydraulic System A advisory	66 units	Advisory only
Brake Temperature Monitor selector position	17 units	Advisory only
Autobrake Selector annunciation	94 units	Monitor

NOTE: If the Autopilot Channel B is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

During engine start, the pilot monitoring should confirm the Autothrottle advisory unless directed otherwise by the Sample Operations Center. The Thrust Reverser switch position is expected to read within the sample range of 3 to 10 units during approach. The Autobrake Selector annunciation that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. The Flight Management Computer status message that differs from the expected state requires the Captain to select the condition before the next phase of flight.

02.40.18 Fire Detection Loop Power Sources

During engine start, the Captain should select the Speedbrake Handle annunciation unless directed otherwise by the Sample Operations Center. The Ground Proximity Monitor status message that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power. If the Window Heat is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The Bleed Air Supply switch position is expected to read within the sample range of 26 to 31 units during cruise. Both pilots will confirm any change in the Nosewheel Steering advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The first officer will select any change in the Standby Hydraulic quantity display and advise the other pilot when operating at a sample station without ground power.

The Fire Detection Loop switch position that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. The Autopilot Channel B indication that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Autothrottle advisory that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center.
- If the Autopilot Channel A is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.
- The Ground Proximity Monitor advisory is expected to read within the sample range of 48 to 55 units during landing.
- The Flight Management Computer selector position is expected to read within the sample range of 36 to 45 units during a turnaround.
- During taxi, the pilot monitoring should verify the Oxygen Distribution annunciation when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cockpit Voice Recorder selector position	33 units	Monitor

Bleed Air Supply selector position	97 units	Normal
Fuel Crossfeed switch position	78 units	Refer to related topic
Fire Detection Loop switch position	72 units	Normal
Primary Electrical Bus annunciation	88 units	Advisory only

The pilot monitoring will record any change in the Thrust Reverser advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Engine Anti-Ice advisory that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. If the Autothrottle is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. During preflight, the First Officer should verify the Autobrake Selector annunciation if a discrepancy is observed.

02.40.19 Flight Management Computer Reset Guidance

During preflight, the relief pilot should monitor the Primary Electrical Bus switch position if the indication does not stabilize within the sample interval. The captain will cross-check any change in the Hydraulic System B selector position and advise the other pilot when the associated caution light remains illuminated. The pilot flying will confirm any change in the Hydraulic System A advisory and advise the other pilot if a discrepancy is observed. The Standby Instruments selector position that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight.

NOTE: During a turnaround, the Captain should record the Bleed Air Supply status message unless directed otherwise by the Sample Operations Center.

The Standby Hydraulic indication is expected to read within the sample range of 74 to 82 units during approach. The Nosewheel Steering status message is expected to read within the sample range of 25 to 36 units during an extended ground delay. The Cabin Pressure Controller selector position is expected to read within the sample range of 82 to 94 units during a maintenance-requested ground run. The Center Tank Pumps annunciation that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval. The Brake Temperature Monitor quantity display is expected to read within the sample range of 39 to 45 units during a diversion.

If the Fuel Crossfeed is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. During a maintenance-requested ground run, the First Officer should verify the Ground Proximity Monitor advisory when operating at a sample station without ground power. The Engine Anti-Ice advisory is expected to read within the sample range of 92 to 104 units during engine start. If the Bleed Air Supply is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Cargo Smoke Detection advisory and advise the other pilot before the next phase of flight. The Stall Warning selector position that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Autothrottle selector position is expected to read within the sample range of 76 to 81 units during an extended ground delay.

The Nosewheel Steering quantity display that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. The Autothrottle selector position that differs from the expected state requires the Captain to announce the condition when conditions permit. The Hydraulic System A advisory is expected to read within the sample range of 17 to 21 units during approach. The Standby Instruments quantity display that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval.

- If the Fire Detection Loop is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- During a diversion, the pilot flying should select the Wing Anti-Ice switch position when the associated caution light remains illuminated.

- During takeoff, the pilot flying should brief the Brake Temperature Monitor switch position when the associated caution light remains illuminated.
- During an extended ground delay, the Captain should cross-check the Center Tank Pumps advisory when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.

The Cargo Smoke Detection quantity display is expected to read within the sample range of 35 to 42 units during engine start. The captain will verify any change in the Auxiliary Power Unit advisory and advise the other pilot when operating at a sample station without ground power. The Stall Warning quantity display that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval. The first officer will brief any change in the Speedbrake Handle switch position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Standby Instruments selector position	74 units	Refer to related topic
Traffic Advisory Display annunciation	26 units	Monitor
Oxygen Distribution switch position	49 units	Normal
Thrust Reverser indication	6 units	Monitor
Fuel Crossfeed advisory	90 units	Monitor
Oxygen Distribution advisory	24 units	Monitor
Speedbrake Handle indication	28 units	Refer to related topic

02.40.20 Flight Management Computer Status Messages

During a maintenance-requested ground run, the pilot monitoring should verify the Autothrottle quantity display when the associated caution light remains illuminated. During engine start, the pilot monitoring should record the Autopilot Channel A quantity display unless directed otherwise by the Sample Operations Center. The captain will select any change in the Thrust Reverser status message and advise the other pilot once the checklist item is complete. If the Nosewheel Steering is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Traffic Advisory Display annunciation is expected to read within the sample range of 17 to 20 units during approach. The Autopilot Channel A quantity display is expected to read within the sample range of 29 to 32 units during descent.

- The relief pilot will select any change in the Fuel Crossfeed advisory and advise the other pilot when operating at a sample station without ground power.
- The first officer will monitor any change in the Bleed Air Supply switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- During parking, the pilot monitoring should monitor the Standby Hydraulic advisory if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Values in this manual are invented and must not be used for any operational purpose.

The Window Heat switch position is expected to read within the sample range of 25 to 34 units during a turnaround. The Primary Electrical Bus status message that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated. If the Auxiliary Power Unit is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

NOTE: The pilot flying will brief any change in the Fire Detection Loop indication and advise the other pilot when operating at a sample station without ground power.

The Hydraulic System A advisory is expected to read within the sample range of 62 to 65 units during approach. The Autothrottle indication that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete. The Speedbrake Handle selector position that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval. During a diversion, the pilot flying should select the Auxiliary Power Unit selector position when the associated caution light remains illuminated.

02.40.21 Probe Heat Test

Values in this manual are invented and must not be used for any operational purpose. The Stall Warning selector position that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed.

The Bleed Air Supply switch position that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. During landing, the pilot flying should verify the Flight Management Computer status message when conditions permit. The pilot monitoring will announce any change in the Landing Gear Indication switch position and advise the other pilot when the associated caution light remains illuminated. The Traffic Advisory Display selector position is expected to read within the sample range of 2 to 6 units during approach. The Autopilot Channel B switch position is expected to read within the sample range of 24 to 32 units during cruise.

Refer to the related topic for additional sample context. During a maintenance-requested ground run, the Captain should cross-check the Pack Temperature Control advisory once the checklist item is complete. If the Autobrake Selector is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. During descent, the pilot monitoring should select the Flight Management Computer status message when the associated caution light remains illuminated. The Speedbrake Handle quantity display that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight. During landing, both pilots should confirm the Window Heat advisory if a discrepancy is observed. If the Fuel Crossfeed is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Probe Heat indication	21 units	Refer to related topic
Nosewheel Steering selector position	67 units	Monitor
Traffic Advisory Display switch position	96 units	Normal
Fuel Crossfeed annunciation	35 units	Monitor
Thrust Reverser selector position	85 units	Normal

Condition	Sample value	Remarks
Ground Proximity Monitor switch position	48 units	Monitor
Transponder advisory	4 units	Monitor
Autopilot Channel B status message	44 units	Monitor

02.40.22 Flap Position Indication Indications

During descent, the pilot flying should confirm the Weather Radar status message before the next phase of flight. The Hydraulic System B indication is expected to read within the sample range of 22 to 30 units during a diversion. If the Primary Electrical Bus is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat advisory that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete. If the Probe Heat is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

The Autopilot Channel A annunciation is expected to read within the sample range of 11 to 23 units during descent. The Speedbrake Handle indication is expected to read within the sample range of 25 to 30 units during an extended ground delay. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will monitor any change in the Standby Hydraulic annunciation and advise the other pilot if a discrepancy is observed. The Thrust Reverser status message that differs from the expected state requires both pilots to cross-check the condition when conditions permit.

- During engine start, the Captain should monitor the Autopilot Channel A quantity display when the associated caution light remains illuminated.
- If the Hydraulic System A is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- The Weather Radar status message is expected to read within the sample range of 56 to 66 units during cruise.

The Window Heat advisory is expected to read within the sample range of 66 to 72 units during landing. The captain will cross-check any change in the Probe Heat selector position and advise the other pilot if a discrepancy is observed. The pilot flying will verify any change in the Standby Hydraulic indication and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Traffic Advisory Display selector position that differs from the expected state requires the Captain to record the condition once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector switch position is expected to read within the sample range of 59 to 70 units during landing. The pilot monitoring will monitor any change in the Flight Management Computer status message and advise the other pilot before the next phase of flight. The Bleed Air Supply annunciation is expected to read within the sample range of 59 to 62 units during cruise. If the Primary Electrical Bus is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. During taxi, the pilot flying should select the Hydraulic System B indication when operating at a sample station without ground power.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the pilot monitoring should brief the Hydraulic System A quantity display when conditions permit. Refer to the related topic for additional sample context. If the Primary Electrical Bus is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector selector position is expected to read within the sample range of 3 to 10 units during an extended ground delay.

02.40.23 Oxygen Distribution Status Messages

During parking, the relief pilot should confirm the Primary Electrical Bus annunciation if a discrepancy is observed. The Cockpit Voice Recorder indication is expected to read within the sample range of 23 to 26 units during an extended ground delay. The Standby Instruments advisory is expected to read within the sample range of 51 to 59 units during climb.

NOTE: If the Hydraulic System B is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

The pilot flying will monitor any change in the Autopilot Channel B quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The relief pilot will select any change in the Center Tank Pumps quantity display and advise the other pilot if a discrepancy is observed. During cruise, both pilots should record the Primary Electrical Bus switch position if the indication does not stabilize within the sample interval. During takeoff, the pilot monitoring should monitor the Cabin Pressure Controller advisory before the next phase of flight.

Condition	Sample value	Remarks
Probe Heat advisory	84 units	Advisory only

Ground Proximity Monitor advisory	68 units	Advisory only
Nosewheel Steering annunciation	36 units	Refer to related topic
Cabin Pressure Controller indication	26 units	Advisory only
Autopilot Channel A switch position	16 units	Monitor
Fire Detection Loop selector position	10 units	Monitor

During climb, the pilot monitoring should announce the Ground Proximity Monitor quantity display if a discrepancy is observed. The Stall Warning status message that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. The Fire Detection Loop selector position that differs from the expected state requires both pilots to select the condition when conditions permit.

During taxi, both pilots should announce the Brake Temperature Monitor selector position before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Weather Radar status message that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. The first officer will select any change in the Weather Radar indication and advise the other pilot if a discrepancy is observed. The Speedbrake Handle annunciation that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. The Flight Management Computer status message is expected to read within the sample range of 54 to 61 units during climb.

CAUTION: During approach, the pilot flying should confirm the Ground Proximity Monitor switch position unless directed otherwise by the Sample Operations Center.

02.40.24 Autobrake Selector Interfaces

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will verify any change in the Bleed Air Supply annunciation and advise the other pilot when conditions permit. The Probe Heat annunciation that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete. The Speedbrake Handle quantity display that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Nosewheel Steering indication	11 units	Refer to related topic
Pack Temperature Control indication	79 units	Advisory only
Cargo Smoke Detection annunciation	41 units	Refer to related topic
Standby Instruments annunciation	44 units	Advisory only
Transponder status message	83 units	Refer to related topic

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. During cruise, the First Officer should confirm the Fire Detection Loop switch position if the indication does not stabilize within the sample interval.

The pilot monitoring will monitor any change in the Traffic Advisory Display selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Ground Proximity Monitor status message is expected to read within the sample range of 54 to 65 units during landing. The Speedbrake Handle advisory that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. See 11.10.5 Cargo Smoke Detection Crew Awareness.

Condition	Sample value	Remarks
Engine Anti-Ice annunciation	48 units	Normal

Standby Instruments switch position	42 units	Advisory only
Traffic Advisory Display switch position	3 units	Monitor
Cockpit Voice Recorder advisory	70 units	Advisory only
Traffic Advisory Display quantity display	30 units	Monitor
Bleed Air Supply status message	98 units	Advisory only

02.40.25 Autobrake Selector Normal Operation

Both pilots will select any change in the Autopilot Channel B indication and advise the other pilot before the next phase of flight. The Cabin Pressure Controller quantity display is expected to read within the sample range of 21 to 32 units during preflight. The captain will announce any change in the Fire Detection Loop selector position and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Autopilot Channel B quantity display	30 units	Normal
Flight Management Computer advisory	29 units	Advisory only
Pack Temperature Control quantity display	54 units	Advisory only
Center Tank Pumps quantity display	4 units	Monitor
Hydraulic System A advisory	78 units	Monitor

Condition	Sample value	Remarks
Cockpit Voice Recorder status message	43 units	Monitor
Ground Proximity Monitor annunciation	32 units	Normal
Ground Proximity Monitor status message	76 units	Normal
Brake Temperature Monitor advisory	64 units	Monitor
Pack Temperature Control quantity display	27 units	Monitor
Center Tank Pumps switch position	97 units	Advisory only
Pack Temperature Control status message	70 units	Advisory only

The Wing Anti-Ice status message that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel B annunciation is expected to read within the sample range of 35 to 43 units during taxi. Both pilots will select any change in the Autopilot Channel A selector position and advise the other pilot if a discrepancy is observed. During a turnaround, both pilots should confirm the Pack Temperature Control annunciation if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Ground Proximity Monitor selector position	39 units	Monitor
Nosewheel Steering switch position	67 units	Normal
Fire Detection Loop quantity display	39 units	Normal
Thrust Reverser advisory	42 units	Advisory only

02.40.26 Center Tank Pumps Status Messages

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. If the Standby Instruments is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During cruise, the relief pilot should select the Hydraulic System B indication when operating at

a sample station without ground power.

The Autobrake Selector quantity display that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power. If the Center Tank Pumps is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The Fire Detection Loop selector position is expected to read within the sample range of 57 to 61 units during taxi. The Speedbrake Handle quantity display is expected to read within the sample range of 10 to 20 units during climb. If the Cabin Pressure Controller is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Standby Hydraulic annunciation is expected to read within the sample range of 47 to 58 units during preflight.

NOTE: During climb, the pilot monitoring should confirm the Primary Electrical Bus indication unless directed otherwise by the Sample Operations Center. During a diversion, the pilot flying should cross-check the Weather Radar status message before the next phase of flight.

During a turnaround, the pilot monitoring should record the Window Heat switch position when operating at a sample station without ground power. During climb, the pilot monitoring should announce the Bleed Air Supply indication when operating at a sample station without ground power. The Pack Temperature Control advisory that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated. During engine start, the First Officer should verify the Window Heat quantity display once the checklist item is complete.

NOTE: The pilot flying will monitor any change in the Pack Temperature Control advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Transponder switch position that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autopilot Channel B advisory	89 units	Refer to related topic
Oxygen Distribution annunciation	25 units	Normal
Standby Hydraulic annunciation	43 units	Advisory only
Bleed Air Supply quantity display	17 units	Advisory only
Wing Anti-Ice status message	77 units	Advisory only
Transponder advisory	54 units	Monitor
Standby Instruments advisory	22 units	Normal

- The Weather Radar advisory that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight.
- If the Landing Gear Indication is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- If the Autothrottle is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- During landing, the pilot flying should select the Nosewheel Steering advisory if a discrepancy is observed.

NOTE: During preflight, the relief pilot should announce the Primary Electrical Bus quantity display when the associated caution light remains illuminated. If the Engine Anti-Ice is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

02.40.27 Oxygen Distribution Interfaces

The wording here is placeholder content shaped like a procedure, not a procedure. If the Bleed Air Supply is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The Fuel Crossfeed quantity display that differs from the expected state requires the pilot monitoring to cross-check the

condition if the indication does not stabilize within the sample interval. The Engine Anti-Ice quantity display that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

The Oxygen Distribution selector position is expected to read within the sample range of 77 to 81 units during engine start. The first officer will announce any change in the Bleed Air Supply switch position and advise the other pilot when the associated caution light remains illuminated. The pilot flying will select any change in the Window Heat indication and advise the other pilot when the associated caution light remains illuminated. The Pack Temperature Control switch position is expected to read within the sample range of 42 to 51 units during preflight. The Flight Management Computer advisory is expected to read within the sample range of 56 to 67 units during a turnaround. If the Cockpit Voice Recorder is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Engine Anti-Ice switch position is expected to read within the sample range of 46 to 57 units during an extended ground delay.

The Autopilot Channel A annunciation that differs from the expected state requires both pilots to brief the condition once the checklist item is complete. The captain will verify any change in the Hydraulic System B switch position and advise the other pilot if a discrepancy is observed. During landing, the First Officer should record the Brake Temperature Monitor status message before the next phase of flight. See 05.70.3 Stall Warning Interfaces.

- Values in this manual are invented and must not be used for any operational purpose.
- The Center Tank Pumps advisory that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center.
- The Probe Heat advisory that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval.

CAUTION: If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Cabin Pressure Controller advisory is expected to read within the sample range of 80 to 83 units during climb.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

02.40.28 Ground Proximity Monitor Indications

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution selector position that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. The Autothrottle annunciation is expected to read within the sample range of 81 to 84 units during engine start. If the Pack Temperature Control is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Fire Detection Loop indication that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center.

CAUTION: The pilot flying will announce any change in the Autopilot Channel B advisory and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: During landing, the Captain should confirm the Ground Proximity Monitor annunciation before the next phase of flight. The Traffic Advisory Display selector position that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated.

If the Autothrottle is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The captain will select any change in the Ground Proximity Monitor switch position and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Stall Warning annunciation that differs from the expected state requires

the Captain to confirm the condition once the checklist item is complete. If the Brake Temperature Monitor is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

The Engine Anti-Ice advisory is expected to read within the sample range of 18 to 28 units during landing. If the Wing Anti-Ice is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Autopilot Channel B status message that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. During parking, the pilot flying should brief the Oxygen Distribution advisory once the checklist item is complete. The pilot monitoring will brief any change in the Autopilot Channel A indication and advise the other pilot if the indication does not stabilize within the sample interval. The Standby Hydraulic status message is expected to read within the sample range of 13 to 25 units during a diversion.

- The Traffic Advisory Display quantity display that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval.
- If the Autobrake Selector is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- The Autothrottle advisory is expected to read within the sample range of 86 to 93 units during parking.
- The captain will confirm any change in the Stall Warning selector position and advise the other pilot if a discrepancy is observed.
- The Nosewheel Steering advisory that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated.

The Oxygen Distribution advisory is expected to read within the sample range of 69 to 75 units during taxi. The Standby Instruments selector position is expected to read within the sample range of 77 to 82 units during climb. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 91 to 99 units during takeoff. During descent, the pilot monitoring should confirm the Hydraulic System B advisory before the next phase of flight.

The Auxiliary Power Unit indication is expected to read within the sample range of 60 to 71 units during landing. Refer to the related topic for additional sample context. If the Engine Anti-Ice is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Window Heat quantity display	10 units	Normal
Cockpit Voice Recorder annunciation	18 units	Advisory only
Autopilot Channel B advisory	50 units	Monitor

02.40.29 Standby Hydraulic Interfaces

During an extended ground delay, the First Officer should cross-check the Traffic Advisory Display switch position if the indication does not stabilize within the sample interval. The Oxygen Distribution advisory that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed. The pilot monitoring will select any change in the Cargo Smoke Detection switch position and advise the other pilot before the next phase of flight.

The Fuel Crossfeed status message that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete. During climb, the Captain should brief the Primary Electrical Bus switch position if a discrepancy is observed. If the Primary Electrical Bus is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

NOTE: If the Weather Radar is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Autothrottle selector position that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. This text is fictional and exists only to give

the prototype realistic volume and structure.

CAUTION: The Traffic Advisory Display annunciation that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center.

02.40.30 Landing Gear Indication Reset Guidance

The captain will confirm any change in the Ground Proximity Monitor selector position and advise the other pilot if a discrepancy is observed. The Ground Proximity Monitor annunciation is expected to read within the sample range of 24 to 30 units during parking. If the Stall Warning is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. During takeoff, the Captain should announce the Pack Temperature Control annunciation once the checklist item is complete. During landing, the First Officer should select the Wing Anti-Ice indication if a discrepancy is observed.

The Flap Position Indication selector position that differs from the expected state requires the pilot flying to confirm the condition when conditions permit. The Nosewheel Steering advisory is expected to read within the sample range of 51 to 55 units during parking. The relief pilot will record any change in the Cargo Smoke Detection advisory and advise the other pilot when operating at a sample station without ground power.

During preflight, the pilot monitoring should select the Cargo Smoke Detection indication when conditions permit. During a maintenance-requested ground run, both pilots should record the Flap Position Indication selector position once the checklist item is complete. If the Weather Radar is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The captain will confirm any change in the Center Tank Pumps selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Oxygen Distribution annunciation is expected to read within the sample range of 29 to 39 units during taxi. The Autopilot Channel A indication is expected to read within the sample range of 77 to 86 units during engine start.

NOTE: The pilot flying will monitor any change in the Wing Anti-Ice switch position and advise the other pilot when conditions permit. The Window Heat quantity display is expected to read within the sample range of 12 to 22 units during a diversion.

- The Oxygen Distribution selector position is expected to read within the sample range of 45 to 54 units during taxi.
- The Speedbrake Handle indication that differs from the expected state requires the pilot flying to confirm the condition when conditions permit.
- If the Stall Warning is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.
- The Autopilot Channel B indication is expected to read within the sample range of 52 to 60 units during climb.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During a turnaround, the First Officer should confirm the Probe Heat selector position once the checklist item is complete.

Both pilots will cross-check any change in the Hydraulic System A status message and advise the other pilot before the next phase of flight. The Oxygen Distribution switch position is expected to read within the sample range of 94 to 105 units during a diversion. If the Fire Detection Loop is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The Autothrottle status message that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. The Flap Position Indication advisory that differs from the expected state requires the First Officer to announce the condition when conditions permit. The first officer will brief any change in the Fuel Crossfeed annunciation and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Traffic Advisory Display advisory	3 units	Advisory only
Weather Radar advisory	10 units	Refer to related topic

Bleed Air Supply annunciation	62 units	Refer to related topic
Cockpit Voice Recorder switch position	41 units	Normal
Ground Proximity Monitor selector position	41 units	Normal

The pilot monitoring will cross-check any change in the Center Tank Pumps selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flight Management Computer quantity display that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

02.40.31 Flap Position Indication Reset Guidance

If the Autopilot Channel B is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments advisory that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. The Thrust Reverser quantity display that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. The pilot flying will cross-check any change in the Ground Proximity Monitor advisory and advise the other pilot when conditions permit.

Values in this manual are invented and must not be used for any operational purpose. During landing, the First Officer should verify the Wing Anti-Ice selector position unless directed otherwise by the Sample Operations Center. If the Autobrake Selector is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Traffic Advisory Display quantity display	70 units	Refer to related topic
Transponder advisory	59 units	Normal
Wing Anti-Ice selector position	52 units	Normal
Probe Heat quantity display	44 units	Normal
Bleed Air Supply quantity display	66 units	Monitor

NOTE: The Standby Instruments quantity display that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed.

NOTE: If the Brake Temperature Monitor is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Fire Detection Loop indication is expected to read within the sample range of 21 to 28 units during preflight. The first officer will cross-check any change in the Oxygen Distribution indication and advise the other pilot when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Stall Warning is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will monitor any change in the Ground Proximity Monitor selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. See 05.40.8 Center Tank Pumps Test.

- During taxi, the pilot monitoring should record the Flap Position Indication status message when conditions permit.
- The Weather Radar status message is expected to read within the sample range of 37 to 46 units during landing.
- During takeoff, both pilots should select the Cabin Pressure Controller status message if a discrepancy is observed.

- The wording here is placeholder content shaped like a procedure, not a procedure.

02.40.32 Fuel Crossfeed Interfaces

During takeoff, the pilot monitoring should cross-check the Hydraulic System A advisory when the associated caution light remains illuminated. The Primary Electrical Bus indication that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete. During takeoff, the First Officer should announce the Autobrake Selector advisory before the next phase of flight.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- Both pilots will confirm any change in the Auxiliary Power Unit quantity display and advise the other pilot once the checklist item is complete.
- The Fire Detection Loop quantity display is expected to read within the sample range of 88 to 95 units during landing.
- The wording here is placeholder content shaped like a procedure, not a procedure.

During preflight, the Captain should confirm the Center Tank Pumps status message once the checklist item is complete. The Stall Warning annunciation that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. The Pack Temperature Control selector position that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power.

- During taxi, both pilots should record the Stall Warning advisory before the next phase of flight.
- The Brake Temperature Monitor advisory that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.
- During takeoff, both pilots should cross-check the Wing Anti-Ice switch position if a discrepancy is observed.
- If the Standby Hydraulic is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.
- The Oxygen Distribution switch position that differs from the expected state requires the pilot flying to verify the condition when conditions permit.
- The Primary Electrical Bus status message is expected to read within the sample range of 90 to 94 units during engine start.

Condition	Sample value	Remarks
Fuel Crossfeed indication	72 units	Normal
Autopilot Channel B advisory	80 units	Monitor
Stall Warning advisory	52 units	Monitor

02.40.33 Standby Hydraulic Indications

The Cabin Pressure Controller advisory that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot flying should brief the Autopilot Channel B indication if a discrepancy is observed.

The Nosewheel Steering quantity display that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. If the Center Tank Pumps is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. If the Transponder is inoperative, continue takeoff only after the

Captain has reviewed the associated sample guidance. The Autobrake Selector switch position that differs from the expected state requires the relief pilot to verify the condition once the checklist item is complete. The Fire Detection Loop annunciation is expected to read within the sample range of 76 to 83 units during approach.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Cargo Smoke Detection switch position that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. Refer to the related topic for additional sample context. If the Flight Management Computer is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. During a maintenance-requested ground run, the relief pilot should select the Engine Anti-Ice annunciation once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: During landing, the First Officer should select the Center Tank Pumps advisory when conditions permit.

The Wing Anti-Ice indication that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight. The Thrust Reverser advisory that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power. The first officer will brief any change in the Weather Radar quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autopilot Channel A advisory is expected to read within the sample range of 79 to 90 units during engine start.

CAUTION: If the Hydraulic System B is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

- Values in this manual are invented and must not be used for any operational purpose.
- The captain will cross-check any change in the Hydraulic System B indication and advise the other pilot when operating at a sample station without ground power.
- The Fuel Crossfeed status message that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed.
- The captain will cross-check any change in the Wing Anti-Ice advisory and advise the other pilot when operating at a sample station without ground power.
- The first officer will announce any change in the Window Heat advisory and advise the other pilot once the checklist item is complete.

The captain will confirm any change in the Cockpit Voice Recorder quantity display and advise the other pilot when operating at a sample station without ground power. The Standby Hydraulic switch position is expected to read within the sample range of 74 to 86 units during a diversion. If the Flap Position Indication is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

Chapter 03 Normal Procedures

03.10 Preflight

03.10.1 Briefing: Fuel Crossfeed

The Center Tank Pumps annunciation that differs from the expected state requires both pilots to select the condition before the next phase of flight. The Fire Detection Loop indication that differs from the expected state requires the relief pilot to verify the condition if a discrepancy is observed. If the Stall Warning is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The Ground Proximity Monitor status message that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. The Oxygen Distribution status message is expected to read within the sample range of 77 to 89 units during a diversion. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: During a turnaround, the pilot monitoring should monitor the Brake Temperature Monitor status message if the indication does not stabilize within the sample interval.

During descent, the pilot monitoring should monitor the Standby Instruments quantity display when operating at a sample station without ground power. The Standby Hydraulic selector position that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight. The pilot monitoring will select any change in the Auxiliary Power Unit indication and advise the other pilot when conditions permit. The Autothrottle quantity display is expected to read within the sample range of 74 to 80 units during descent. If the Cockpit Voice Recorder is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Pack Temperature Control switch position that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center.

The Speedbrake Handle selector position is expected to read within the sample range of 89 to 93 units during parking. If the Autopilot Channel A is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. During taxi, the pilot monitoring should monitor the Traffic Advisory Display indication unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice selector position that differs from the expected state requires both pilots to verify the condition before the next phase of flight. The Autopilot Channel B switch position is expected to read within the sample range of 37 to 49 units during takeoff. During cruise, the First Officer should select the Auxiliary Power Unit quantity display if the indication does not stabilize within the sample interval.

03.10.2 Flow: Wing Anti-Ice

The Cargo Smoke Detection indication is expected to read within the sample range of 31 to 37 units during parking. If the Autopilot Channel B is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The captain will select any change in the Landing Gear Indication switch position and advise the other pilot when operating at a sample station without ground power. The Brake Temperature Monitor selector position that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. The Standby Hydraulic quantity display is expected to read within the sample range of 38 to 42 units during a diversion. The Pack Temperature Control selector position that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete.

- During landing, both pilots should confirm the Speedbrake Handle switch position when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Thrust Reverser annunciation that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated.
- The Traffic Advisory Display quantity display is expected to read within the sample range of 14 to 26 units during preflight.

- The Standby Instruments indication that differs from the expected state requires both pilots to select the condition when conditions permit.
- If the Speedbrake Handle is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- The Transponder status message is expected to read within the sample range of 62 to 73 units during a turnaround.
- The relief pilot will record any change in the Transponder advisory and advise the other pilot when operating at a sample station without ground power.
- If the Standby Hydraulic is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

The Nosewheel Steering switch position is expected to read within the sample range of 16 to 24 units during an extended ground delay. If the Primary Electrical Bus is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During a turnaround, the pilot flying should announce the Engine Anti-Ice selector position unless directed otherwise by the Sample Operations Center. If the Autopilot Channel A is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. During parking, the Captain should announce the Standby Instruments indication before the next phase of flight.

NOTE: The Autobrake Selector advisory is expected to read within the sample range of 11 to 16 units during a diversion. The Cockpit Voice Recorder selector position is expected to read within the sample range of 47 to 58 units during takeoff.

The Landing Gear Indication selector position that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. The Autopilot Channel B selector position that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Cockpit Voice Recorder switch position is expected to read within the sample range of 93 to 102 units during an extended ground delay.

03.10.3 Briefing: Cargo Smoke Detection

The Autobrake Selector advisory is expected to read within the sample range of 68 to 76 units during landing. If the Cabin Pressure Controller is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The Cabin Pressure Controller advisory is expected to read within the sample range of 45 to 49 units during a diversion. Both pilots will cross-check any change in the Brake Temperature Monitor switch position and advise the other pilot if the indication does not stabilize within the sample interval.

If the Thrust Reverser is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. During engine start, both pilots should announce the Oxygen Distribution advisory when conditions permit. During approach, the pilot monitoring should select the Standby Hydraulic selector position when operating at a sample station without ground power. If the Flight Management Computer is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. During a turnaround, the relief pilot should brief the Brake Temperature Monitor selector position when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. During preflight, the pilot flying should cross-check the Hydraulic System B advisory when operating at a sample station without ground power. If the Traffic Advisory Display is inoperative, continue engine start only after the relief pilot has reviewed the associated

sample guidance. The Autothrottle indication that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight. The Cargo Smoke Detection switch position is expected to read within the sample range of 50 to 62 units during taxi. The Cockpit Voice Recorder advisory is expected to read within the sample range of 64 to 68 units during a turnaround.

- If the Traffic Advisory Display is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.
- During descent, the pilot monitoring should monitor the Brake Temperature Monitor advisory before the next phase of flight.
- The Landing Gear Indication indication that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center.
- During approach, both pilots should verify the Ground Proximity Monitor selector position if a discrepancy is observed.
- The pilot flying will verify any change in the Standby Hydraulic indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The first officer will brief any change in the Fuel Crossfeed status message and advise the other pilot when conditions permit.
- The Autobrake Selector quantity display that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval.
- During parking, the First Officer should verify the Standby Hydraulic indication if the indication does not stabilize within the sample interval.
- During cruise, the pilot monitoring should monitor the Autothrottle indication before the next phase of flight.
- During a diversion, the relief pilot should confirm the Center Tank Pumps quantity display once the checklist item is complete.
- Refer to the related topic for additional sample context.
- During a diversion, the Captain should cross-check the Landing Gear Indication quantity display when operating at a sample station without ground power.
- Both pilots will brief any change in the Fuel Crossfeed quantity display and advise the other pilot when conditions permit.
- Refer to the related topic for additional sample context.
- During a diversion, the relief pilot should monitor the Flight Management Computer advisory before the next phase of flight.
- The Flight Management Computer status message is expected to read within the sample range of 44 to 52 units during parking.
- During a maintenance-requested ground run, the relief pilot should verify the Hydraulic System B indication if a discrepancy is observed.
- During takeoff, the First Officer should record the Fire Detection Loop status message when conditions permit.

The Flap Position Indication selector position that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. The first officer will cross-check any change in the Brake Temperature Monitor advisory and advise the other pilot if a discrepancy is observed. The Brake Temperature Monitor switch position is expected to read within the sample range of 52 to 58 units during taxi.

Challenge	Response
-----------	----------

Cabin Pressure Controller	Armed
Standby Instruments	Closed
Autothrottle	On
Speedbrake Handle	Set
Traffic Advisory Display	Armed
Transponder	As required
Cargo Smoke Detection	Verified
Oxygen Distribution	Armed
Autothrottle	Closed
Cargo Smoke Detection	Verified
Nosewheel Steering	Off

03.10.4 Verification: Standby Instruments

The pilot flying will select any change in the Autopilot Channel A status message and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Engine Anti-Ice advisory that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center.
- The Bleed Air Supply advisory is expected to read within the sample range of 5 to 12 units during landing.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Fuel Crossfeed is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- During engine start, both pilots should cross-check the Autothrottle quantity display unless directed otherwise by the Sample Operations Center.
- Refer to the related topic for additional sample context.

NOTE: The Primary Electrical Bus annunciation is expected to read within the sample range of 92 to 97 units during an extended ground delay.

If the Probe Heat is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Weather Radar is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

The Hydraulic System B selector position that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. If the Autopilot Channel B is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Standby Instruments annunciation is expected to read within the sample range of 69 to 73 units during takeoff.

03.10.5 Callouts: Probe Heat

The pilot flying will announce any change in the Transponder annunciation and advise the other pilot if a discrepancy is observed. During climb, the First Officer should announce the Flight Management Computer annunciation if the indication does not stabilize within the sample interval. If the Hydraulic System B is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to

give the prototype realistic volume and structure. During takeoff, the Captain should monitor the Window Heat quantity display if the indication does not stabilize within the sample interval.

CAUTION: Both pilots will announce any change in the Weather Radar quantity display and advise the other pilot once the checklist item is complete. The relief pilot will monitor any change in the Standby Hydraulic advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The Landing Gear Indication switch position that differs from the expected state requires the Captain to confirm the condition when conditions permit. The relief pilot will brief any change in the Landing Gear Indication quantity display and advise the other pilot before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will record any change in the Cabin Pressure Controller switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The first officer will record any change in the Speedbrake Handle quantity display and advise the other pilot when the associated caution light remains illuminated. The Traffic Advisory Display annunciation is expected to read within the sample range of 75 to 85 units during parking. If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Pack Temperature Control quantity display	23 units	Normal
Traffic Advisory Display switch position	56 units	Normal
Brake Temperature Monitor quantity display	89 units	Monitor
Standby Hydraulic status message	14 units	Normal
Thrust Reverser status message	99 units	Normal
Brake Temperature Monitor indication	42 units	Monitor

Condition	Sample value	Remarks
Nosewheel Steering indication	52 units	Advisory only
Oxygen Distribution selector position	64 units	Monitor
Ground Proximity Monitor advisory	53 units	Monitor
Fire Detection Loop annunciation	12 units	Refer to related topic
Standby Instruments selector position	74 units	Monitor
Autothrottle selector position	87 units	Refer to related topic
Hydraulic System A advisory	27 units	Advisory only

The relief pilot will cross-check any change in the Primary Electrical Bus switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Stall Warning selector position is expected to read within the sample range of 79 to 91 units during approach. The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot flying to verify the condition if a discrepancy is observed.

This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Instruments switch position is expected to read within the sample range of 78 to 81 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, both pilots should select the Cockpit Voice Recorder selector position when operating at a sample station without ground power.

Challenge	Response
Window Heat	Checked
Bleed Air Supply	Verified
Flap Position Indication	Verified
Cabin Pressure Controller	Off

Flap Position Indication	Checked
Probe Heat	Set
Hydraulic System B	Off
Oxygen Distribution	On

03.10.6 Callouts: Landing Gear Indication

During takeoff, the Captain should record the Cockpit Voice Recorder annunciation when conditions permit. Refer to the related topic for additional sample context. The Thrust Reverser selector position that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed. During an extended ground delay, the pilot flying should record the Bleed Air Supply quantity display when the associated caution light remains illuminated.

NOTE: During approach, the First Officer should record the Weather Radar annunciation before the next phase of flight. The captain will monitor any change in the Ground Proximity Monitor quantity display and advise the other pilot when the associated caution light remains illuminated.

NOTE: The first officer will select any change in the Speedbrake Handle advisory and advise the other pilot when conditions permit.

CAUTION: Both pilots will confirm any change in the Wing Anti-Ice quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

The Engine Anti-Ice selector position that differs from the expected state requires the pilot monitoring to brief the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. If the Oxygen Distribution is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Auxiliary Power Unit annunciation is expected to read within the sample range of 51 to 56 units during landing. The captain will confirm any change in the Brake Temperature Monitor status message and advise the other pilot if the indication does not stabilize within the sample interval.

03.10.7 Verification: Bleed Air Supply

Refer to the related topic for additional sample context. The Flight Management Computer quantity display that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed. If the Autopilot Channel B is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. The pilot monitoring will confirm any change in the Pack Temperature Control indication and advise the other pilot when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. The first officer will confirm any change in the Standby Hydraulic status message and advise the other pilot once the checklist item is complete. During cruise, both pilots should cross-check the Standby Hydraulic indication when operating at a sample station without ground power.

During climb, the Captain should record the Standby Hydraulic status message once the checklist item is complete. During cruise, the pilot monitoring should record the Fire Detection Loop selector position when conditions permit. The Window Heat indication that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. The Engine Anti-Ice quantity display is expected to read within the sample range of 97 to 107 units during parking. The Hydraulic System A switch position that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.

NOTE: The Window Heat advisory that differs from the expected state requires the Captain to record the condition when the associated caution light remains illuminated.

If the Speedbrake Handle is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Cabin Pressure Controller is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The

Window Heat annunciation that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. The Primary Electrical Bus annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

Challenge	Response
Flight Management Computer	Verified
Speedbrake Handle	On
Primary Electrical Bus	On
Traffic Advisory Display	Checked
Cabin Pressure Controller	Set
Speedbrake Handle	Set
Landing Gear Indication	Off
Standby Hydraulic	As required
Cabin Pressure Controller	Set
Primary Electrical Bus	On
Autobrake Selector	Verified

03.10.8 Flow: Ground Proximity Monitor

This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. The Cockpit Voice Recorder selector position is expected to read within the sample range of 4 to 10 units during preflight. During a turnaround, the pilot flying should select the Stall Warning switch position if the indication does not stabilize within the sample interval. The Engine Anti-Ice advisory that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. The pilot monitoring will select any change in the Standby Instruments status message and advise the other pilot when conditions permit.

- The Auxiliary Power Unit status message is expected to read within the sample range of 52 to 57 units during preflight.
- Both pilots will cross-check any change in the Brake Temperature Monitor switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- During takeoff, the pilot flying should announce the Probe Heat quantity display before the next phase of flight.
- During preflight, both pilots should cross-check the Hydraulic System B indication when operating at a sample station without ground power.
- The Window Heat annunciation that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Stall Warning advisory	45 units	Refer to related topic
Weather Radar advisory	84 units	Normal
Flight Management Computer quantity display	49 units	Advisory only
Autothrottle status message	10 units	Monitor

CAUTION: During approach, the pilot flying should cross-check the Oxygen Distribution switch position if the indication does not stabilize within the sample interval.

During taxi, both pilots should select the Probe Heat indication if a discrepancy is observed. During parking, the pilot monitoring should cross-check the Autopilot Channel A selector position when operating at a sample station without ground power. During an extended ground delay, the pilot monitoring should select the Flight Management Computer quantity display if the indication does not stabilize within the sample interval. The Hydraulic System B selector position is expected to read within the sample range of 59 to 62 units during taxi. If the Flight Management Computer is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

CAUTION: During a turnaround, the First Officer should select the Landing Gear Indication advisory when operating at a sample station without ground power.

The Primary Electrical Bus status message that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. The Wing Anti-Ice quantity display that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center. The Standby Hydraulic status message that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. If the Stall Warning is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Nosewheel Steering indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

Challenge	Response
Standby Hydraulic	Off
Auxiliary Power Unit	Armed
Flap Position Indication	Set
Ground Proximity Monitor	As required
Cargo Smoke Detection	Off
Hydraulic System B	Set
Wing Anti-Ice	As required
Weather Radar	Checked
Cargo Smoke Detection	Set
Bleed Air Supply	Verified
Standby Hydraulic	Verified

03.10.9 Briefing: Engine Anti-Ice

The Traffic Advisory Display switch position that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval. The Speedbrake Handle status message that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. If the Bleed Air Supply is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Ground Proximity Monitor selector position that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. If the Speedbrake Handle is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autobrake Selector selector position	97 units	Advisory only
Landing Gear Indication switch position	43 units	Monitor
Center Tank Pumps indication	27 units	Refer to related topic
Primary Electrical Bus indication	32 units	Refer to related topic
Hydraulic System A selector position	20 units	Monitor

- The Flap Position Indication selector position is expected to read within the sample range of 74 to 79 units during a turnaround.
- The Bleed Air Supply selector position that differs from the expected state requires the relief pilot to brief the condition unless directed otherwise by the Sample Operations Center.
- The relief pilot will record any change in the Bleed Air Supply selector position and advise the other pilot if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Brake Temperature Monitor is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.
- The Brake Temperature Monitor selector position that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power.
- During a turnaround, both pilots should select the Fire Detection Loop switch position when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Probe Heat quantity display that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval.
- If the Center Tank Pumps is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Standby Hydraulic indication that differs from the expected state requires the relief pilot to brief the condition unless directed otherwise by the Sample Operations Center.

The Auxiliary Power Unit indication is expected to read within the sample range of 75 to 79 units during parking. The Transponder indication that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. If the Center Tank Pumps is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Probe Heat quantity display	64 units	Refer to related topic
Transponder indication	97 units	Normal
Window Heat selector position	51 units	Refer to related topic
Nosewheel Steering annunciation	84 units	Monitor
Traffic Advisory Display switch position	77 units	Refer to related topic
Engine Anti-Ice switch position	59 units	Refer to related topic
Flight Management Computer annunciation	70 units	Advisory only

The Hydraulic System B switch position is expected to read within the sample range of 50 to 57 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure. During parking, the First Officer should cross-check the Autopilot Channel B selector position unless directed otherwise by the Sample Operations Center.

The Thrust Reverser advisory is expected to read within the sample range of 79 to 82 units during parking. The pilot monitoring will select any change in the Fuel Crossfeed advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Oxygen Distribution selector position is expected to read within the sample range of 58 to 64 units during climb. If the Transponder is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue cruise only after the pilot

flying has reviewed the associated sample guidance. See 02.40.11 Autothrottle Crew Awareness.

03.10.10 Crew Coordination: Flap Position Indication

During an extended ground delay, the Captain should select the Ground Proximity Monitor advisory when operating at a sample station without ground power. If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Autobrake Selector switch position	34 units	Normal
Bleed Air Supply advisory	18 units	Monitor
Autothrottle selector position	87 units	Monitor
Cockpit Voice Recorder advisory	82 units	Monitor
Transponder indication	80 units	Monitor

During taxi, the Captain should select the Auxiliary Power Unit indication if a discrepancy is observed. If the Stall Warning is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Autopilot Channel B selector position that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cargo Smoke Detection switch position	13 units	Monitor
Speedbrake Handle switch position	65 units	Advisory only
Oxygen Distribution quantity display	39 units	Normal
Engine Anti-Ice selector position	65 units	Monitor
Hydraulic System B indication	22 units	Normal

NOTE: The first officer will monitor any change in the Autothrottle annunciation and advise the other pilot when conditions permit.

The Probe Heat selector position is expected to read within the sample range of 82 to 92 units during climb. During taxi, both pilots should verify the Nosewheel Steering status message when operating at a sample station without ground power. The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. The Ground Proximity Monitor advisory is expected to read within the sample range of 23 to 27 units during an extended ground delay. The Standby Hydraulic quantity display is expected to read within the sample range of 60 to 69 units during climb.

Condition	Sample value	Remarks
Auxiliary Power Unit quantity display	94 units	Normal
Stall Warning switch position	26 units	Advisory only
Fire Detection Loop switch position	18 units	Refer to related topic
Speedbrake Handle advisory	81 units	Normal
Autopilot Channel A annunciation	51 units	Refer to related topic
Speedbrake Handle status message	18 units	Monitor
Autothrottle annunciation	58 units	Normal

NOTE: The Ground Proximity Monitor status message that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

03.10.11 Verification: Brake Temperature Monitor

Both pilots will monitor any change in the Flight Management Computer selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will record any change in the Oxygen Distribution advisory and advise the other pilot if the indication does not stabilize within the sample interval. During a diversion, both pilots should brief the Speedbrake Handle indication once the checklist item is complete. During a maintenance-requested ground run, the First Officer should brief the Autopilot Channel B selector position before the next phase of flight. If the Nosewheel Steering is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The Landing Gear Indication indication is expected to read within the sample range of 34 to 43 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Oxygen Distribution indication	38 units	Monitor
Oxygen Distribution selector position	7 units	Normal
Autothrottle indication	7 units	Refer to related topic
Window Heat advisory	27 units	Normal
Thrust Reverser indication	1 units	Refer to related topic
Pack Temperature Control switch position	74 units	Normal

The Landing Gear Indication status message that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. The pilot monitoring will select any change in the Cargo Smoke Detection annunciation and advise the other pilot if a discrepancy is observed. The Cockpit Voice Recorder indication is expected to read within the sample range of 38 to 46 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder selector position is expected to read within the sample range of 12 to 15 units during takeoff. The Cargo Smoke Detection status message is expected to read within the sample range of 39 to 49 units during descent.

The captain will verify any change in the Brake Temperature Monitor switch position and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. If the Weather Radar is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The Autothrottle status message that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power. During landing, the pilot monitoring should monitor the Stall Warning status message when operating at a sample station without ground power. The Speedbrake Handle status message is expected to read within the sample range of 97 to 106 units during cruise.

The pilot monitoring will record any change in the Cockpit Voice Recorder annunciation and advise the other pilot once the checklist item is complete. During a turnaround, the Captain should confirm the Nosewheel Steering status message once the checklist item is complete. The pilot monitoring will confirm any change in the Standby Hydraulic annunciation and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

Challenge	Response
Engine Anti-Ice	As required
Pack Temperature Control	On
Fuel Crossfeed	Set
Cargo Smoke Detection	Off
Brake Temperature Monitor	Off

Pack Temperature Control	Checked
Hydraulic System B	On
Autopilot Channel B	Closed
Engine Anti-Ice	On
Hydraulic System A	Set
Thrust Reverser	Checked

03.10.12 Callouts: Nosewheel Steering

The Thrust Reverser indication that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. If the Wing Anti-Ice is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

NOTE: During taxi, the pilot monitoring should verify the Cabin Pressure Controller quantity display when conditions permit. The captain will record any change in the Standby Instruments annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

The first officer will confirm any change in the Weather Radar status message and advise the other pilot once the checklist item is complete. The pilot flying will monitor any change in the Oxygen Distribution advisory and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The captain will monitor any change in the Standby Hydraulic annunciation and advise the other pilot when the associated caution light remains illuminated.

The Stall Warning status message is expected to read within the sample range of 93 to 105 units during a diversion. The Autopilot Channel B switch position that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. During preflight, the Captain should cross-check the Auxiliary Power Unit advisory when the associated caution light remains illuminated.

During a maintenance-requested ground run, the First Officer should select the Flight Management Computer indication when the associated caution light remains illuminated. During a turnaround, the pilot flying should verify the Wing Anti-Ice advisory once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Thrust Reverser switch position that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop status message that differs from the expected state requires the Captain to brief the condition once the checklist item is complete.

NOTE: The first officer will select any change in the Nosewheel Steering quantity display and advise the other pilot if a discrepancy is observed. During parking, the Captain should cross-check the Thrust Reverser status message before the next phase of flight.

NOTE: The Probe Heat annunciation is expected to read within the sample range of 63 to 66 units during taxi.

The Thrust Reverser annunciation is expected to read within the sample range of 31 to 39 units during engine start. If the Standby Hydraulic is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Autopilot Channel B annunciation and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will verify any change in the Autothrottle annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

03.10.13 Checklist: Engine Anti-Ice

During taxi, the First Officer should cross-check the Fire Detection Loop selector position before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. During a

maintenance-requested ground run, the relief pilot should cross-check the Transponder advisory before the next phase of flight. The captain will select any change in the Window Heat advisory and advise the other pilot if a discrepancy is observed. If the Auxiliary Power Unit is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Thrust Reverser quantity display	39 units	Advisory only
Standby Hydraulic advisory	44 units	Advisory only
Hydraulic System B status message	5 units	Advisory only
Standby Hydraulic annunciation	42 units	Refer to related topic

The pilot monitoring will brief any change in the Center Tank Pumps selector position and advise the other pilot once the checklist item is complete. The Cargo Smoke Detection indication is expected to read within the sample range of 74 to 84 units during engine start. The Flap Position Indication indication is expected to read within the sample range of 88 to 99 units during taxi. During landing, the pilot monitoring should select the Cargo Smoke Detection indication if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Probe Heat quantity display	89 units	Advisory only
Bleed Air Supply indication	46 units	Monitor
Auxiliary Power Unit indication	65 units	Refer to related topic
Hydraulic System A status message	10 units	Refer to related topic
Oxygen Distribution quantity display	87 units	Monitor
Landing Gear Indication switch position	60 units	Normal
Brake Temperature Monitor switch position	79 units	Refer to related topic

Condition	Sample value	Remarks
Primary Electrical Bus annunciation	83 units	Advisory only
Primary Electrical Bus indication	10 units	Advisory only
Probe Heat advisory	35 units	Normal

CAUTION: The first officer will record any change in the Brake Temperature Monitor selector position and advise the other pilot when operating at a sample station without ground power.

The Autothrottle quantity display is expected to read within the sample range of 3 to 9 units during approach. The pilot flying will cross-check any change in the Cockpit Voice Recorder annunciation and advise the other pilot when conditions permit. The Autobrake Selector indication that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. During a diversion, the pilot flying should announce the Cargo Smoke Detection selector position when the associated caution light remains illuminated. The captain will confirm any change in the Cabin Pressure Controller switch position and advise the other pilot when operating at a sample station without ground power. The Flight Management Computer quantity display is expected to read within the sample range of 38 to 49 units during a turnaround.

NOTE: During taxi, the relief pilot should select the Flap Position Indication advisory if a discrepancy is observed.

03.10.14 Briefing: Transponder

If the Stall Warning is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The Transponder indication that differs from the expected state requires both pilots to brief the condition

when operating at a sample station without ground power. The Cabin Pressure Controller selector position is expected to read within the sample range of 27 to 33 units during landing. The Window Heat quantity display is expected to read within the sample range of 76 to 82 units during engine start. If the Window Heat is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

The pilot monitoring will brief any change in the Speedbrake Handle indication and advise the other pilot before the next phase of flight. The Nosewheel Steering switch position that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center. If the Autobrake Selector is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Ground Proximity Monitor switch position is expected to read within the sample range of 35 to 41 units during a maintenance-requested ground run. The relief pilot will confirm any change in the Cargo Smoke Detection indication and advise the other pilot if a discrepancy is observed.

- The Weather Radar switch position that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated.
- The Hydraulic System A switch position is expected to read within the sample range of 15 to 18 units during an extended ground delay.
- The Flight Management Computer quantity display is expected to read within the sample range of 15 to 25 units during climb.
- The Fire Detection Loop switch position that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete.
- The Speedbrake Handle status message is expected to read within the sample range of 80 to 88 units during takeoff.
- If the Nosewheel Steering is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Standby Instruments switch position is expected to read within the sample range of 9 to 17 units during a diversion. The Pack Temperature Control indication is expected to read within the sample range of 45 to 48 units during an extended ground delay.

CAUTION: If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Weather Radar indication is expected to read within the sample range of 12 to 18 units during cruise.

Challenge	Response
Pack Temperature Control	Closed
Center Tank Pumps	As required
Center Tank Pumps	Armed
Autopilot Channel A	Armed
Standby Instruments	Set
Cargo Smoke Detection	Off
Bleed Air Supply	Set
Autothrottle	Set
Flight Management Computer	On
Autothrottle	Closed

03.10.15 Crew Coordination: Primary Electrical Bus

During a turnaround, the pilot monitoring should record the Ground Proximity Monitor status message if the indication does not stabilize within the sample interval. The Nosewheel Steering status message that differs from the expected

state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center. The Window Heat indication that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Transponder is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The Brake Temperature Monitor advisory is expected to read within the sample range of 78 to 90 units during cruise. The Cargo Smoke Detection switch position is expected to read within the sample range of 24 to 27 units during a turnaround.

This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Instruments status message that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power. The Flight Management Computer advisory that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Cabin Pressure Controller indication	31 units	Refer to related topic
Transponder advisory	91 units	Refer to related topic
Wing Anti-Ice selector position	64 units	Advisory only
Center Tank Pumps switch position	46 units	Monitor
Brake Temperature Monitor advisory	46 units	Normal
Hydraulic System B annunciation	26 units	Advisory only

The Probe Heat annunciation is expected to read within the sample range of 40 to 49 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. If the Landing Gear Indication is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. During parking, both pilots should cross-check the Transponder switch position if the indication does not stabilize within the sample interval. If the Autopilot Channel A is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Oxygen Distribution quantity display that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center. The Window Heat quantity display that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. See 02.40.15 Center Tank Pumps Test.

Challenge	Response
Autopilot Channel A	On
Probe Heat	Closed
Weather Radar	Set
Window Heat	As required
Thrust Reverser	Verified
Brake Temperature Monitor	Armed
Bleed Air Supply	Off
Ground Proximity Monitor	On
Thrust Reverser	Checked
Center Tank Pumps	Checked

03.10.16 Verification: Hydraulic System A

Values in this manual are invented and must not be used for any operational purpose. The captain will select any change in the Landing Gear Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will verify any change in the Primary Electrical Bus selector position and advise the other pilot when the associated caution light remains illuminated. If the Brake Temperature Monitor is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Hydraulic System B advisory is expected to read within the sample range of 16 to 20 units during a maintenance-requested ground run.

If the Cargo Smoke Detection is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the Captain should verify the Probe Heat annunciation when operating at a sample station without ground power. During descent, the Captain should brief the Pack Temperature Control status message if a discrepancy is observed. The Autobrake Selector annunciation is expected to read within the sample range of 61 to 73 units during climb. During an extended ground delay, the First Officer should confirm the Hydraulic System A status message before the next phase of flight. Refer to the related topic for additional sample context.

The Engine Anti-Ice advisory is expected to read within the sample range of 86 to 96 units during preflight. During descent, the relief pilot should announce the Speedbrake Handle advisory unless directed otherwise by the Sample Operations Center. During approach, the relief pilot should brief the Autopilot Channel A quantity display unless directed otherwise by the Sample Operations Center. The relief pilot will monitor any change in the Hydraulic System A switch position and advise the other pilot when conditions permit. During taxi, the pilot monitoring should confirm the Standby Hydraulic annunciation when conditions permit. The Traffic Advisory Display selector position is expected to read within the sample range of 55 to 60 units during parking.

CAUTION: The Wing Anti-Ice selector position is expected to read within the sample range of 85 to 88 units during a diversion. The pilot flying will monitor any change in the Hydraulic System A switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Probe Heat is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The Weather Radar quantity display that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. The Window Heat annunciation is expected to read within the sample range of 45 to 52 units during a turnaround. During approach, both pilots should verify the Transponder quantity display unless directed otherwise by the Sample Operations Center. The relief pilot will select any change in the Traffic Advisory Display quantity display and advise the other pilot when the associated caution light remains illuminated.

CAUTION: Refer to the related topic for additional sample context.

03.10.17 Callouts: Engine Anti-Ice

During a turnaround, the pilot flying should announce the Autopilot Channel B status message when conditions permit. The Thrust Reverser switch position that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval. The pilot monitoring will monitor any change in the Primary Electrical Bus indication and advise the other pilot before the next phase of flight. If the Flap Position Indication is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Center Tank Pumps status message is expected to read within the sample range of 56 to 59 units during climb.

NOTE: The Standby Hydraulic indication that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete.

The Window Heat quantity display that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. The Thrust Reverser status message is expected to read within the sample range of 67 to 71 units during an extended ground delay. Both pilots will brief any change in the Autopilot Channel B status message and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic selector position is expected to read within the sample range of 90 to 96 units during descent. During a diversion, the Captain should announce the Oxygen Distribution quantity display if a discrepancy is observed.

The Brake Temperature Monitor annunciation is expected to read within the sample range of 58 to 69 units during a diversion. The Window Heat quantity display is expected to read within the sample range of 73 to 85 units during cruise. If the Transponder is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autothrottle quantity display	22 units	Normal
Hydraulic System A status message	44 units	Refer to related topic
Hydraulic System B indication	41 units	Refer to related topic
Standby Instruments advisory	69 units	Normal
Autopilot Channel B quantity display	80 units	Monitor

Condition	Sample value	Remarks
Window Heat indication	41 units	Normal
Window Heat quantity display	6 units	Monitor
Autobrake Selector annunciation	84 units	Monitor
Primary Electrical Bus annunciation	66 units	Normal
Cargo Smoke Detection quantity display	16 units	Refer to related topic
Primary Electrical Bus advisory	92 units	Normal

The Hydraulic System B selector position is expected to read within the sample range of 49 to 60 units during cruise. The Weather Radar advisory is expected to read within the sample range of 58 to 69 units during a maintenance-requested ground run. During parking, the First Officer should cross-check the Brake Temperature Monitor switch position when conditions permit. The Auxiliary Power Unit quantity display is expected to read within the sample range of 15 to 21 units during an extended ground delay.

03.10.18 Flow: Cockpit Voice Recorder

The pilot monitoring will confirm any change in the Autopilot Channel A switch position and advise the other pilot before the next phase of flight. During taxi, both pilots should brief the Traffic Advisory Display annunciation if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the pilot monitoring should brief the Cargo Smoke Detection indication if the indication does not stabilize within the sample interval.

If the Window Heat is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Autobrake Selector switch position that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval. The Autopilot Channel B status message is expected to read within the sample range of 54 to 57 units during a maintenance-requested ground run. The Oxygen Distribution selector position that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

During parking, the Captain should brief the Center Tank Pumps switch position unless directed otherwise by the Sample Operations Center. If the Standby Hydraulic is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The first officer will brief any change in the Standby Hydraulic switch position and advise the other pilot when conditions permit.

- Values in this manual are invented and must not be used for any operational purpose.
- The Thrust Reverser switch position is expected to read within the sample range of 90 to 99 units during parking.
- During a turnaround, the First Officer should confirm the Flap Position Indication switch position before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Both pilots will cross-check any change in the Engine Anti-Ice status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Cockpit Voice Recorder switch position is expected to read within the sample range of 19 to 23 units during takeoff.

CAUTION: The pilot monitoring will record any change in the Ground Proximity Monitor annunciation and advise the other pilot when the associated caution light remains illuminated. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

03.10.19 Checklist: Window Heat

During preflight, both pilots should record the Landing Gear Indication annunciation before the next phase of flight. The Hydraulic System B selector position is expected to read within the sample range of 63 to 73 units during a turnaround. The first officer will announce any change in the Autothrottle status message and advise the other pilot when the associated caution light remains illuminated.

- The Engine Anti-Ice annunciation is expected to read within the sample range of 28 to 36 units during an extended ground delay.
- The pilot monitoring will select any change in the Standby Hydraulic switch position and advise the other pilot once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.

NOTE: The pilot flying will select any change in the Cockpit Voice Recorder quantity display and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Window Heat indication	4 units	Advisory only
Autopilot Channel A annunciation	91 units	Advisory only
Oxygen Distribution advisory	37 units	Monitor
Autopilot Channel A indication	38 units	Normal
Center Tank Pumps switch position	13 units	Refer to related topic
Landing Gear Indication status message	21 units	Normal

The pilot flying will brief any change in the Thrust Reverser indication and advise the other pilot if the indication does not stabilize within the sample interval. During a diversion, the First Officer should select the Nosewheel Steering selector position before the next phase of flight. Both pilots will verify any change in the Speedbrake Handle annunciation and advise the other pilot when operating at a sample station without ground power. During a turnaround, the pilot monitoring should verify the Autopilot Channel A annunciation when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autothrottle annunciation	17 units	Monitor
Autopilot Channel A switch position	6 units	Advisory only
Traffic Advisory Display selector position	16 units	Normal
Center Tank Pumps advisory	35 units	Normal
Autopilot Channel B status message	22 units	Advisory only

NOTE: During engine start, the First Officer should monitor the Standby Instruments selector position if a discrepancy is observed.

NOTE: During taxi, the pilot flying should confirm the Autothrottle indication when operating at a sample station without ground power.

NOTE: The Speedbrake Handle quantity display is expected to read within the sample range of 6 to 11 units during cruise. The first officer will monitor any change in the Ground Proximity Monitor annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

Challenge	Response
Wing Anti-Ice	Armed
Fuel Crossfeed	On
Window Heat	Verified
Primary Electrical Bus	As required
Standby Instruments	Verified
Autothrottle	Checked
Brake Temperature Monitor	On
Probe Heat	Set

03.10.20 Crew Coordination: Cabin Pressure Controller

The Center Tank Pumps advisory is expected to read within the sample range of 89 to 96 units during engine start. The Cockpit Voice Recorder indication is expected to read within the sample range of 92 to 99 units during taxi. Values in this manual are invented and must not be used for any operational purpose. The first officer will monitor any change in the Cockpit Voice Recorder switch position and advise the other pilot when conditions permit.

The Landing Gear Indication selector position is expected to read within the sample range of 19 to 29 units during climb. Values in this manual are invented and must not be used for any operational purpose. The first officer will announce any change in the Fire Detection Loop status message and advise the other pilot if a discrepancy is observed. If the Engine Anti-Ice is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Autopilot Channel A switch position is expected to read within the sample range of 10 to 18 units during cruise. If the Window Heat is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

NOTE: The Landing Gear Indication quantity display that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated.

NOTE: The Autothrottle selector position that differs from the expected state requires both pilots to brief the condition when conditions permit. If the Cabin Pressure Controller is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

NOTE: During climb, both pilots should cross-check the Traffic Advisory Display switch position when operating at a sample station without ground power. The Hydraulic System A status message that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Stall Warning selector position	67 units	Advisory only
Bleed Air Supply annunciation	63 units	Monitor
Auxiliary Power Unit status message	27 units	Advisory only
Cargo Smoke Detection status message	44 units	Advisory only
Bleed Air Supply switch position	62 units	Monitor
Autobrake Selector advisory	76 units	Refer to related topic
Standby Hydraulic status message	73 units	Advisory only

NOTE: The Pack Temperature Control selector position is expected to read within the sample range of 21 to 30 units during descent. The Autobrake Selector status message that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated.

Challenge	Response
Autothrottle	Verified
Primary Electrical Bus	Closed
Pack Temperature Control	Verified
Engine Anti-Ice	Checked
Pack Temperature Control	On
Brake Temperature Monitor	Off

03.10.21 Briefing: Weather Radar

If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. During engine start, the First Officer should record the Transponder status message if a discrepancy is observed. During taxi, the Captain should select the Standby Hydraulic switch position when the associated caution light remains illuminated. If the Fire Detection Loop is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

- The Bleed Air Supply indication that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.
- The Cargo Smoke Detection quantity display is expected to read within the sample range of 41 to 45 units during climb.
- The Flight Management Computer selector position that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Autothrottle quantity display	4 units	Refer to related topic
Traffic Advisory Display status message	12 units	Refer to related topic
Engine Anti-Ice quantity display	41 units	Normal

Condition	Sample value	Remarks
Autopilot Channel A advisory	19 units	Refer to related topic
Speedbrake Handle advisory	17 units	Advisory only
Autopilot Channel B annunciation	89 units	Advisory only
Nosewheel Steering indication	48 units	Normal
Speedbrake Handle advisory	91 units	Monitor

Speedbrake Handle selector position	62 units	Refer to related topic
Autopilot Channel A quantity display	29 units	Monitor

The Speedbrake Handle quantity display that differs from the expected state requires the Captain to cross-check the condition when conditions permit. The relief pilot will cross-check any change in the Center Tank Pumps switch position and advise the other pilot if a discrepancy is observed. The Bleed Air Supply advisory is expected to read within the sample range of 92 to 100 units during taxi.

- If the Autobrake Selector is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.
- The Traffic Advisory Display indication that differs from the expected state requires the pilot flying to announce the condition when conditions permit.
- The first officer will cross-check any change in the Fuel Crossfeed quantity display and advise the other pilot when conditions permit.

03.10.22 Callouts: Flight Management Computer

Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. If the Autopilot Channel A is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Standby Hydraulic switch position is expected to read within the sample range of 3 to 11 units during approach.

The Flight Management Computer annunciation that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. During an extended ground delay, the Captain should confirm the Weather Radar advisory when the associated caution light remains illuminated. The Primary Electrical Bus quantity display that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center. The Autopilot Channel A switch position is expected to read within the sample range of 12 to 22 units during landing. During cruise, the pilot monitoring should monitor the Autopilot Channel A status message when conditions permit.

The first officer will announce any change in the Autopilot Channel A switch position and advise the other pilot when the associated caution light remains illuminated. If the Window Heat is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. If the Window Heat is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Standby Instruments annunciation is expected to read within the sample range of 17 to 21 units during descent. If the Oxygen Distribution is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

- If the Wing Anti-Ice is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.
- The Weather Radar annunciation is expected to read within the sample range of 41 to 45 units during taxi.
- During landing, both pilots should select the Nosewheel Steering selector position before the next phase of flight.
- The Cockpit Voice Recorder indication is expected to read within the sample range of 4 to 11 units during an extended ground delay.
- The Stall Warning advisory that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power.

CAUTION: During preflight, both pilots should select the Nosewheel Steering quantity display once the checklist item is complete. During an extended ground delay, the relief pilot should record the Oxygen Distribution indication once the checklist item is complete.

Condition	Sample value	Remarks
Cabin Pressure Controller indication	32 units	Refer to related topic
Speedbrake Handle quantity display	51 units	Refer to related topic
Cockpit Voice Recorder quantity display	11 units	Advisory only
Landing Gear Indication selector position	12 units	Normal
Weather Radar status message	7 units	Refer to related topic

The pilot flying will cross-check any change in the Autopilot Channel A quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will monitor any change in the Cabin Pressure Controller status message and advise the other pilot when the associated caution light remains illuminated. The Autopilot Channel A quantity display that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. During climb, the pilot flying should monitor the Autopilot Channel B status message once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. See 12.10.5 Primary Electrical Bus Interfaces.

03.10.23 Crew Coordination: Cockpit Voice Recorder

The Engine Anti-Ice selector position is expected to read within the sample range of 58 to 67 units during an extended ground delay. The captain will monitor any change in the Autopilot Channel B indication and advise the other pilot when conditions permit. If the Standby Instruments is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

CAUTION: The Traffic Advisory Display switch position is expected to read within the sample range of 62 to 68 units during takeoff. The Landing Gear Indication selector position is expected to read within the sample range of 83 to 95 units during climb.

CAUTION: If the Hydraulic System A is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The pilot flying will verify any change in the Autopilot Channel A status message and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The relief pilot will cross-check any change in the Brake Temperature Monitor quantity display and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The Autothrottle quantity display that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power. The Transponder quantity display is expected to read within the sample range of 50 to 53 units during engine start.

Challenge	Response
Engine Anti-Ice	Set
Window Heat	On
Standby Instruments	Off
Probe Heat	Set
Standby Instruments	Off
Traffic Advisory Display	Armed
Weather Radar	Checked

03.10.24 Checklist: Autopilot Channel A

The Thrust Reverser annunciation is expected to read within the sample range of 67 to 70 units during engine start. If the Cockpit Voice Recorder is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Hydraulic System A quantity display that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.

The first officer will monitor any change in the Hydraulic System A switch position and advise the other pilot when conditions permit. During a maintenance-requested ground run, the pilot flying should cross-check the Window Heat switch position when the associated caution light remains illuminated. During climb, the relief pilot should verify the Standby Hydraulic annunciation unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit status message is expected to read within the sample range of 61 to 65 units during a turnaround. The Center Tank Pumps quantity display that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power.

During preflight, the pilot monitoring should brief the Oxygen Distribution quantity display when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. If the Standby Instruments is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Standby Hydraulic quantity display is expected to read within the sample range of 57 to 64 units during taxi.

Condition	Sample value	Remarks
Hydraulic System B advisory	84 units	Advisory only
Landing Gear Indication switch position	19 units	Monitor
Brake Temperature Monitor status message	6 units	Normal
Center Tank Pumps quantity display	24 units	Refer to related topic
Cabin Pressure Controller annunciation	89 units	Normal

NOTE: The pilot flying will announce any change in the Hydraulic System A quantity display and advise the other pilot when conditions permit.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The relief pilot will verify any change in the Window Heat switch position and advise the other pilot when conditions permit.
- The Auxiliary Power Unit advisory is expected to read within the sample range of 8 to 17 units during engine start.
- During takeoff, the pilot flying should cross-check the Transponder annunciation once the checklist item is complete.
- The captain will announce any change in the Pack Temperature Control switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- Both pilots will verify any change in the Cockpit Voice Recorder advisory and advise the other pilot before the next phase of flight.

Refer to the related topic for additional sample context. The Flight Management Computer status message that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The captain will record any change in the Auxiliary Power Unit quantity display and advise the other pilot once the checklist item is complete. See 03.70.13 Crew Coordination: Standby Hydraulic.

03.10.25 Briefing: Pack Temperature Control

The pilot monitoring will cross-check any change in the Standby Hydraulic advisory and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Bleed Air Supply switch position is expected to read within the sample range of 30 to 38 units during a turnaround. The Auxiliary Power Unit status message is expected to read within the sample range of 66 to 77 units during taxi. The Autopilot Channel A quantity display is expected to read within the sample range of 29 to 37 units during landing. Values in this manual are invented and must not be used for any operational purpose.

If the Thrust Reverser is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

- If the Cabin Pressure Controller is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- The captain will cross-check any change in the Thrust Reverser quantity display and advise the other pilot when the associated caution light remains illuminated.
- The Center Tank Pumps annunciation is expected to read within the sample range of 19 to 29 units during preflight.
- The Auxiliary Power Unit indication is expected to read within the sample range of 47 to 57 units during descent.
- During parking, the pilot flying should monitor the Stall Warning status message if a discrepancy is observed.
- The Transponder switch position is expected to read within the sample range of 86 to 97 units during a turnaround.

Condition	Sample value	Remarks
Cabin Pressure Controller switch position	9 units	Monitor
Landing Gear Indication annunciation	7 units	Normal
Thrust Reverser quantity display	13 units	Refer to related topic

CAUTION: The first officer will announce any change in the Speedbrake Handle status message and advise the other pilot if the indication does not stabilize within the sample interval. If the Window Heat is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

If the Flap Position Indication is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Cargo Smoke Detection indication is expected to read within the sample range of 79 to 83 units during descent. If the Flight Management Computer is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Flap Position Indication advisory that differs from the expected state requires the pilot flying to announce the condition when conditions permit.

The first officer will brief any change in the Wing Anti-Ice advisory and advise the other pilot when operating at a sample station without ground power. The Thrust Reverser switch position is expected to read within the sample range of 96 to 101 units during preflight. If the Autobrake Selector is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

03.10.26 Checklist: Weather Radar

The Oxygen Distribution switch position is expected to read within the sample range of 69 to 79 units during landing. The Flap Position Indication quantity display is expected to read within the sample range of 76 to 84 units during approach. During takeoff, the pilot monitoring should confirm the Weather Radar indication once the checklist item is complete.

The Center Tank Pumps switch position is expected to read within the sample range of 59 to 64 units during climb. Values in this manual are invented and must not be used for any operational purpose. The Bleed Air Supply status message that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments quantity display is expected to read within the sample range of 11 to 20 units during a maintenance-requested ground run.

During cruise, both pilots should verify the Weather Radar advisory before the next phase of flight. During a diversion, the First Officer should record the Primary Electrical Bus annunciation unless directed otherwise by the Sample Operations Center. The Autopilot Channel B indication is expected to read within the sample range of 96 to 105 units

during descent. During a maintenance-requested ground run, the First Officer should select the Fire Detection Loop switch position if the indication does not stabilize within the sample interval. During a diversion, the pilot flying should confirm the Fire Detection Loop status message when operating at a sample station without ground power. The relief pilot will announce any change in the Fire Detection Loop advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Pack Temperature Control selector position is expected to read within the sample range of 92 to 100 units during preflight.
- The Cargo Smoke Detection switch position that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated.
- The Traffic Advisory Display quantity display is expected to read within the sample range of 74 to 78 units during parking.

NOTE: During takeoff, the Captain should monitor the Cabin Pressure Controller quantity display when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Center Tank Pumps status message	23 units	Monitor
Fire Detection Loop switch position	85 units	Normal
Autothrottle indication	26 units	Advisory only
Flap Position Indication status message	51 units	Advisory only

Challenge	Response
Window Heat	Verified
Fire Detection Loop	On
Fire Detection Loop	Closed
Stall Warning	Closed
Transponder	Verified
Bleed Air Supply	As required
Speedbrake Handle	On
Flap Position Indication	Set

03.10.27 Verification: Autopilot Channel A

Values in this manual are invented and must not be used for any operational purpose. The pilot flying will record any change in the Nosewheel Steering annunciation and advise the other pilot when the associated caution light remains illuminated. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

NOTE: The Cargo Smoke Detection indication is expected to read within the sample range of 96 to 105 units during taxi.

CAUTION: If the Wing Anti-Ice is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Hydraulic System B status message is expected to read within the sample range of 93 to 102 units during an extended ground delay.

Condition	Sample value	Remarks
Window Heat advisory	96 units	Normal

Nosewheel Steering indication	40 units	Refer to related topic
Transponder quantity display	74 units	Refer to related topic
Autothrottle annunciation	51 units	Refer to related topic
Probe Heat switch position	22 units	Advisory only
Brake Temperature Monitor switch position	22 units	Normal

If the Weather Radar is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. During approach, both pilots should monitor the Fire Detection Loop annunciation when operating at a sample station without ground power. The Brake Temperature Monitor quantity display is expected to read within the sample range of 96 to 104 units during approach. The Flight Management Computer indication that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed. If the Thrust Reverser is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The Center Tank Pumps annunciation is expected to read within the sample range of 22 to 26 units during taxi.

- Both pilots will confirm any change in the Cabin Pressure Controller switch position and advise the other pilot when conditions permit.
- The Autothrottle advisory is expected to read within the sample range of 68 to 72 units during descent.
- The captain will brief any change in the Transponder switch position and advise the other pilot before the next phase of flight.
- The Autopilot Channel A advisory is expected to read within the sample range of 35 to 40 units during preflight.

Challenge	Response
Probe Heat	Set
Autobrake Selector	Checked
Transponder	Closed
Flap Position Indication	Set
Thrust Reverser	Armed
Stall Warning	Checked
Cabin Pressure Controller	Checked
Wing Anti-Ice	On
Bleed Air Supply	Set
Transponder	Checked
Thrust Reverser	Verified
Window Heat	As required

03.10.28 Flow: Thrust Reverser

The Fuel Crossfeed annunciation that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center. During takeoff, the Captain should cross-check the Oxygen Distribution selector position when conditions permit. If the Ground Proximity Monitor is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

If the Oxygen Distribution is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During cruise, the pilot flying should select the Standby Instruments advisory when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

During parking, the First Officer should record the Fuel Crossfeed selector position when conditions permit. The relief pilot will monitor any change in the Cargo Smoke Detection status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Hydraulic System B switch position that differs from the expected state requires the relief pilot to monitor the condition before the next phase of flight. If the Pack Temperature Control is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The pilot flying will verify any change in the Transponder indication and advise the other pilot when the associated caution light remains illuminated.

CAUTION: If the Autobrake Selector is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Transponder quantity display is expected to read within the sample range of 65 to 76 units during landing.

The Speedbrake Handle annunciation that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. If the Auxiliary Power Unit is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. During cruise, the First Officer should select the Primary Electrical Bus switch position once the checklist item is complete. During approach, both pilots should brief the Autopilot Channel A status message if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. The Wing Anti-Ice advisory that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. The Landing Gear Indication status message is expected to read within the sample range of 39 to 48 units during climb. The Cargo Smoke Detection status message is expected to read within the sample range of 53 to 62 units during an extended ground delay.

03.10.29 Crew Coordination: Hydraulic System B

The wording here is placeholder content shaped like a procedure, not a procedure. The Landing Gear Indication annunciation that differs from the expected state requires the Captain to monitor the condition when conditions permit. If the Flap Position Indication is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

NOTE: The Traffic Advisory Display selector position that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval.

The Oxygen Distribution switch position that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated. The Traffic Advisory Display selector position is expected to read within the sample range of 34 to 46 units during a maintenance-requested ground run. The Standby Hydraulic annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight. During approach, the relief pilot should monitor the Oxygen Distribution indication when conditions permit. The Autopilot Channel A switch position that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power. If the Flap Position Indication is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

- The Thrust Reverser switch position is expected to read within the sample range of 90 to 95 units during an extended ground delay.
- The captain will brief any change in the Wing Anti-Ice advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Hydraulic System A selector position is expected to read within the sample range of 81 to 84 units during climb.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Bleed Air Supply is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Transponder switch position that differs from the expected state requires the pilot flying to confirm the condition if a

discrepancy is observed. If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Hydraulic System B quantity display is expected to read within the sample range of 27 to 35 units during cruise.

During a maintenance-requested ground run, the pilot flying should select the Bleed Air Supply advisory if the indication does not stabilize within the sample interval. If the Hydraulic System B is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The pilot flying will monitor any change in the Engine Anti-Ice status message and advise the other pilot if a discrepancy is observed.

NOTE: The Speedbrake Handle indication is expected to read within the sample range of 50 to 56 units during approach. The pilot monitoring will monitor any change in the Standby Instruments advisory and advise the other pilot if the indication does not stabilize within the sample interval.

During cruise, the relief pilot should monitor the Cockpit Voice Recorder switch position if a discrepancy is observed. The Standby Hydraulic switch position that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete. During taxi, the pilot flying should verify the Hydraulic System B switch position unless directed otherwise by the Sample Operations Center. During parking, the pilot flying should verify the Landing Gear Indication indication when the associated caution light remains illuminated. The Bleed Air Supply quantity display is expected to read within the sample range of 66 to 71 units during a maintenance-requested ground run. The Landing Gear Indication advisory that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power.

Challenge	Response
Bleed Air Supply	Verified
Weather Radar	Checked
Transponder	On
Speedbrake Handle	On
Probe Heat	On
Primary Electrical Bus	Checked
Standby Instruments	Off
Autopilot Channel A	Armed
Speedbrake Handle	On
Flight Management Computer	Off
Pack Temperature Control	Off

03.10.30 Briefing: Cabin Pressure Controller

If the Center Tank Pumps is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. During parking, the relief pilot should select the Probe Heat selector position unless directed otherwise by the Sample Operations Center. Both pilots will monitor any change in the Thrust Reverser indication and advise the other pilot if the indication does not stabilize within the sample interval.

The relief pilot will monitor any change in the Cargo Smoke Detection quantity display and advise the other pilot when conditions permit. The Primary Electrical Bus annunciation is expected to read within the sample range of 91 to 101 units during climb. Refer to the related topic for additional sample context. The Thrust Reverser selector position that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. The Oxygen Distribution advisory that differs from the expected state requires both pilots to confirm the condition before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the pilot monitoring should cross-check the Landing Gear Indication selector position when operating at a sample station without ground power. The pilot monitoring will announce any change in the Brake Temperature Monitor annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

- During takeoff, the Captain should verify the Engine Anti-Ice quantity display once the checklist item is complete.
- The Bleed Air Supply indication is expected to read within the sample range of 94 to 97 units during climb.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Fuel Crossfeed is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- If the Standby Hydraulic is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

If the Transponder is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Fire Detection Loop quantity display that differs from the expected state requires the pilot monitoring to record the condition when the associated caution light remains illuminated.

03.10.31 Checklist: Transponder

If the Thrust Reverser is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication status message that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. If the Flap Position Indication is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Window Heat status message is expected to read within the sample range of 51 to 58 units during landing. If the Cargo Smoke Detection is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Standby Hydraulic status message is expected to read within the sample range of 66 to 74 units during engine start. The Ground Proximity Monitor annunciation is expected to read within the sample range of 32 to 35 units during a turnaround.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Nosewheel Steering annunciation	67 units	Advisory only
Wing Anti-Ice quantity display	79 units	Advisory only
Wing Anti-Ice status message	45 units	Refer to related topic
Fuel Crossfeed switch position	31 units	Refer to related topic

NOTE: Refer to the related topic for additional sample context. If the Center Tank Pumps is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

During climb, both pilots should announce the Weather Radar selector position before the next phase of flight. During landing, the relief pilot should brief the Stall Warning advisory when conditions permit. During taxi, the pilot monitoring should record the Cargo Smoke Detection annunciation unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. If the Brake Temperature Monitor is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

CAUTION: If the Wing Anti-Ice is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will brief any change in the Traffic Advisory Display quantity display and advise the other pilot when operating at a sample station without ground power.

- The Thrust Reverser indication is expected to read within the sample range of 45 to 51 units during cruise.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During descent, the pilot monitoring should brief the Auxiliary Power Unit status message unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Hydraulic System A	As required
Speedbrake Handle	Armed
Weather Radar	Armed
Autobrake Selector	As required
Flap Position Indication	Checked
Thrust Reverser	Verified
Probe Heat	As required
Window Heat	Verified
Hydraulic System A	Verified
Standby Instruments	As required

03.10.32 Callouts: Traffic Advisory Display

This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. During parking, the First Officer should brief the Standby Hydraulic quantity display when conditions permit. The Bleed Air Supply selector position is expected to read within the sample range of 38 to 45 units during engine start. If the Standby Hydraulic is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The pilot flying will confirm any change in the Center Tank Pumps annunciation and advise the other pilot if a discrepancy is observed.

The pilot monitoring will select any change in the Standby Hydraulic annunciation and advise the other pilot when operating at a sample station without ground power. The pilot monitoring will brief any change in the Fuel Crossfeed status message and advise the other pilot when operating at a sample station without ground power. The Autopilot Channel B indication is expected to read within the sample range of 30 to 38 units during cruise. During climb, the pilot flying should monitor the Thrust Reverser quantity display when the associated caution light remains illuminated. If the Standby Hydraulic is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. Both pilots will confirm any change in the Autopilot Channel B switch position and advise the other pilot when operating at a sample station without ground power.

The Auxiliary Power Unit switch position is expected to read within the sample range of 64 to 67 units during parking. During a diversion, the pilot flying should select the Pack Temperature Control annunciation if a discrepancy is observed. The captain will brief any change in the Center Tank Pumps selector position and advise the other pilot once the checklist item is complete. During a turnaround, the pilot monitoring should verify the Landing Gear Indication indication once the checklist item is complete. During taxi, both pilots should monitor the Autobrake Selector status message if the indication does not stabilize within the sample interval.

If the Wing Anti-Ice is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. During taxi, the pilot monitoring should confirm the Weather Radar indication when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. If the Engine Anti-Ice is inoperative, continue an extended ground

delay only after the Captain has reviewed the associated sample guidance.

CAUTION: The Engine Anti-Ice selector position is expected to read within the sample range of 61 to 71 units during parking.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will verify any change in the Pack Temperature Control selector position and advise the other pilot if the indication does not stabilize within the sample interval.

If the Cabin Pressure Controller is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Thrust Reverser indication is expected to read within the sample range of 51 to 60 units during parking.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The captain will cross-check any change in the Probe Heat switch position and advise the other pilot before the next phase of flight.

Challenge	Response
Center Tank Pumps	Closed
Bleed Air Supply	Armed
Brake Temperature Monitor	Off
Flight Management Computer	On
Autobrake Selector	Off
Engine Anti-Ice	Set

03.10.33 Callouts: Cabin Pressure Controller

Refer to the related topic for additional sample context. The Traffic Advisory Display indication is expected to read within the sample range of 51 to 58 units during engine start. The Transponder selector position that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. During engine start, the pilot monitoring should monitor the Wing Anti-Ice quantity display if a discrepancy is observed. The Primary Electrical Bus indication that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center.

- The Landing Gear Indication annunciation that differs from the expected state requires both pilots to monitor the condition before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Primary Electrical Bus advisory that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete.
- The Wing Anti-Ice selector position is expected to read within the sample range of 14 to 19 units during parking.

The Engine Anti-Ice quantity display that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. If the Cabin Pressure Controller is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The pilot monitoring will brief any change in the Fire Detection Loop annunciation and advise the other pilot before the next phase of flight. During an extended ground delay, the pilot monitoring should confirm the Engine Anti-Ice indication when operating at a sample station without ground power.

The Standby Instruments advisory is expected to read within the sample range of 35 to 44 units during climb. During climb, the pilot monitoring should cross-check the Oxygen Distribution status message before the next phase of flight. The Nosewheel Steering selector position that differs from the expected state requires the pilot flying to select the

condition if a discrepancy is observed. The Center Tank Pumps status message is expected to read within the sample range of 43 to 46 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The pilot monitoring will monitor any change in the Auxiliary Power Unit advisory and advise the other pilot before the next phase of flight. The Flight Management Computer selector position is expected to read within the sample range of 90 to 93 units during approach.

The Autothrottle switch position that differs from the expected state requires both pilots to select the condition once the checklist item is complete. The Thrust Reverser indication is expected to read within the sample range of 83 to 94 units during approach. If the Wing Anti-Ice is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Engine Anti-Ice status message is expected to read within the sample range of 60 to 71 units during landing. If the Center Tank Pumps is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. During takeoff, the relief pilot should confirm the Stall Warning switch position when operating at a sample station without ground power.

03.20 Before Start and Engine Start

03.20.1 Callouts: Brake Temperature Monitor

The Cabin Pressure Controller quantity display is expected to read within the sample range of 70 to 78 units during a maintenance-requested ground run. The first officer will cross-check any change in the Autopilot Channel A annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit selector position that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete.

- The relief pilot will verify any change in the Traffic Advisory Display annunciation and advise the other pilot when operating at a sample station without ground power.
- If the Autothrottle is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.
- The Primary Electrical Bus switch position is expected to read within the sample range of 49 to 52 units during parking.

During cruise, the pilot monitoring should record the Pack Temperature Control switch position before the next phase of flight. The pilot flying will announce any change in the Cockpit Voice Recorder annunciation and advise the other pilot when conditions permit. The Autopilot Channel B quantity display that differs from the expected state requires the Captain to select the condition once the checklist item is complete.

If the Autobrake Selector is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The pilot flying will verify any change in the Bleed Air Supply advisory and advise the other pilot when operating at a sample station without ground power. The Autopilot Channel A indication is expected to read within the sample range of 44 to 54 units during taxi. During approach, the First Officer should brief the Speedbrake Handle indication once the checklist item is complete. If the Traffic Advisory Display is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

The Flight Management Computer status message is expected to read within the sample range of 31 to 43 units during takeoff. The Hydraulic System A quantity display is expected to read within the sample range of 75 to 82 units during taxi. The captain will confirm any change in the Hydraulic System B advisory and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. During approach, the relief pilot should monitor the Probe Heat advisory once the checklist item is complete. The first officer will announce any change in the Hydraulic System A selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

Challenge	Response
Probe Heat	Checked

Thrust Reverser	Set
Nosewheel Steering	Armed
Nosewheel Steering	As required
Probe Heat	Closed
Nosewheel Steering	Closed
Cargo Smoke Detection	On
Center Tank Pumps	Checked

03.20.2 Checklist: Standby Instruments

The Window Heat switch position that differs from the expected state requires both pilots to select the condition when conditions permit. The Flight Management Computer quantity display is expected to read within the sample range of 6 to 12 units during taxi. The captain will monitor any change in the Transponder switch position and advise the other pilot once the checklist item is complete. The pilot flying will record any change in the Flight Management Computer selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Fuel Crossfeed annunciation is expected to read within the sample range of 26 to 31 units during preflight. The Hydraulic System A switch position is expected to read within the sample range of 20 to 26 units during a diversion.

NOTE: During parking, the pilot flying should confirm the Autopilot Channel A status message unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Autopilot Channel A quantity display	19 units	Advisory only
Engine Anti-Ice indication	82 units	Normal
Window Heat selector position	22 units	Monitor
Hydraulic System B switch position	38 units	Monitor
Wing Anti-Ice indication	69 units	Monitor

NOTE: The Engine Anti-Ice indication is expected to read within the sample range of 3 to 12 units during preflight. During approach, the pilot monitoring should announce the Pack Temperature Control status message when operating at a sample station without ground power.

Condition	Sample value	Remarks
Ground Proximity Monitor status message	42 units	Advisory only
Cockpit Voice Recorder quantity display	45 units	Monitor
Auxiliary Power Unit annunciation	11 units	Refer to related topic
Engine Anti-Ice status message	57 units	Refer to related topic

Challenge	Response
Transponder	Verified
Standby Hydraulic	Checked
Oxygen Distribution	Closed
Engine Anti-Ice	As required
Brake Temperature Monitor	Closed
Pack Temperature Control	Closed
Center Tank Pumps	On
Autopilot Channel A	Verified

Center Tank Pumps

Checked

03.20.3 Briefing: Cockpit Voice Recorder

During takeoff, the First Officer should confirm the Wing Anti-Ice indication when the associated caution light remains illuminated. The Cockpit Voice Recorder advisory that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval. The Autothrottle indication is expected to read within the sample range of 30 to 41 units during climb. The Autopilot Channel B quantity display that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval. The Pack Temperature Control selector position is expected to read within the sample range of 82 to 92 units during preflight. The Autopilot Channel B annunciation is expected to read within the sample range of 84 to 88 units during an extended ground delay.

If the Autopilot Channel B is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. Both pilots will verify any change in the Autopilot Channel A annunciation and advise the other pilot when the associated caution light remains illuminated. The Autothrottle selector position that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval.

CAUTION: If the Fuel Crossfeed is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: If the Ground Proximity Monitor is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: Refer to the related topic for additional sample context.

03.20.4 Briefing: Brake Temperature Monitor

The Autothrottle indication is expected to read within the sample range of 61 to 67 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure. During engine start, the Captain should announce the Window Heat switch position before the next phase of flight. If the Thrust Reverser is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Wing Anti-Ice advisory is expected to read within the sample range of 17 to 20 units during descent. If the Traffic Advisory Display is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Flight Management Computer selector position is expected to read within the sample range of 35 to 41 units during cruise. The Thrust Reverser quantity display that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

Both pilots will cross-check any change in the Primary Electrical Bus annunciation and advise the other pilot when conditions permit. During descent, the First Officer should brief the Ground Proximity Monitor switch position when the associated caution light remains illuminated. The Autopilot Channel B selector position that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the Captain should record the Hydraulic System B advisory when the associated caution light remains illuminated. The Speedbrake Handle indication that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

- The captain will confirm any change in the Cabin Pressure Controller switch position and advise the other pilot before the next phase of flight.
- The Cabin Pressure Controller status message that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center.

- During descent, the First Officer should cross-check the Standby Instruments quantity display before the next phase of flight.
- If the Landing Gear Indication is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

Challenge	Response
Brake Temperature Monitor	As required
Cargo Smoke Detection	Set
Landing Gear Indication	Closed
Hydraulic System A	Verified
Hydraulic System B	Set
Primary Electrical Bus	Off
Standby Hydraulic	Armed
Wing Anti-Ice	On

03.20.5 Callouts: Engine Anti-Ice

If the Landing Gear Indication is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During a maintenance-requested ground run, the relief pilot should confirm the Probe Heat quantity display when conditions permit. If the Auxiliary Power Unit is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Autobrake Selector indication is expected to read within the sample range of 77 to 84 units during climb. Refer to the related topic for additional sample context.

If the Weather Radar is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Standby Instruments selector position is expected to read within the sample range of 22 to 30 units during approach. The Fuel Crossfeed indication is expected to read within the sample range of 62 to 69 units during engine start.

Condition	Sample value	Remarks
Speedbrake Handle switch position	63 units	Monitor
Center Tank Pumps status message	86 units	Advisory only
Brake Temperature Monitor switch position	82 units	Advisory only
Wing Anti-Ice status message	2 units	Normal

- If the Autopilot Channel A is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- During a turnaround, the Captain should brief the Cockpit Voice Recorder selector position when operating at a sample station without ground power.
- The Speedbrake Handle indication that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.
- The pilot flying will brief any change in the Autobrake Selector status message and advise the other pilot once the checklist item is complete.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will verify any change in the Cockpit Voice Recorder annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

If the Cabin Pressure Controller is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Autopilot Channel B annunciation is expected to read within the sample range of 90 to 102 units during taxi. The Flight Management Computer advisory that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. The Speedbrake Handle selector position is expected to read within the sample range of 77 to 82 units during an extended ground delay. See 05.20.14 Oxygen Distribution Indications.

03.20.6 Briefing: Auxiliary Power Unit

If the Fuel Crossfeed is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Fuel Crossfeed selector position that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center. The Flight Management Computer annunciation that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. If the Hydraulic System A is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

During climb, both pilots should record the Center Tank Pumps quantity display before the next phase of flight. Both pilots will cross-check any change in the Autopilot Channel A selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Flight Management Computer advisory is expected to read within the sample range of 69 to 77 units during parking.

The Speedbrake Handle annunciation is expected to read within the sample range of 97 to 101 units during a maintenance-requested ground run. The Auxiliary Power Unit status message is expected to read within the sample range of 54 to 66 units during parking. The Window Heat annunciation is expected to read within the sample range of 71 to 79 units during takeoff. If the Standby Instruments is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel B indication that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. If the Auxiliary Power Unit is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Flap Position Indication advisory	45 units	Normal
Probe Heat status message	93 units	Normal
Primary Electrical Bus advisory	75 units	Refer to related topic
Autobrake Selector selector position	2 units	Monitor

Refer to the related topic for additional sample context. The Autopilot Channel A annunciation is expected to read within the sample range of 54 to 59 units during a maintenance-requested ground run. Both pilots will cross-check any change in the Speedbrake Handle quantity display and advise the other pilot before the next phase of flight.

The Cabin Pressure Controller quantity display that differs from the expected state requires the First Officer to monitor the condition if the indication does not stabilize within the sample interval. If the Weather Radar is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Stall Warning is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

During an extended ground delay, both pilots should cross-check the Fire Detection Loop indication if a discrepancy is observed. If the Autobrake Selector is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Landing Gear Indication switch position that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated. If the Standby Hydraulic is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

Challenge	Response
Standby Hydraulic	As required
Transponder	Off
Stall Warning	Checked
Traffic Advisory Display	Verified
Cabin Pressure Controller	Verified
Bleed Air Supply	On
Transponder	Closed
Hydraulic System A	Checked
Cockpit Voice Recorder	On
Fuel Crossfeed	On
Traffic Advisory Display	Set
Autobrake Selector	Checked

03.20.7 Flow: Hydraulic System A

If the Engine Anti-Ice is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. Both pilots will confirm any change in the Hydraulic System B quantity display and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Ground Proximity Monitor selector position	64 units	Monitor
Hydraulic System A quantity display	4 units	Monitor
Pack Temperature Control advisory	63 units	Refer to related topic
Probe Heat quantity display	81 units	Refer to related topic
Hydraulic System B selector position	85 units	Refer to related topic
Standby Hydraulic quantity display	26 units	Monitor
Flap Position Indication selector position	33 units	Monitor

CAUTION: The Autopilot Channel B annunciation that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. The Primary Electrical Bus indication is expected to read within the sample range of 14 to 26 units during descent.

- During climb, the Captain should select the Brake Temperature Monitor switch position unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During engine start, the pilot flying should record the Ground Proximity Monitor quantity display when operating at a sample station without ground power.
- The Transponder advisory is expected to read within the sample range of 35 to 40 units during a maintenance-requested ground run.

NOTE: The Autobrake Selector switch position is expected to read within the sample range of 70 to 81 units during a turnaround.

During descent, the relief pilot should announce the Primary Electrical Bus advisory when conditions permit. If the Landing Gear Indication is inoperative, continue landing only after both pilots has reviewed the associated sample

guidance. If the Standby Instruments is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Weather Radar annunciation is expected to read within the sample range of 87 to 96 units during a diversion.

Challenge	Response
Brake Temperature Monitor	As required
Cargo Smoke Detection	Off
Traffic Advisory Display	Armed
Flight Management Computer	Armed
Bleed Air Supply	On
Stall Warning	Set
Standby Instruments	As required
Probe Heat	Set
Probe Heat	On

03.20.8 Callouts: Flap Position Indication

The Traffic Advisory Display annunciation is expected to read within the sample range of 63 to 71 units during engine start. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A advisory is expected to read within the sample range of 23 to 34 units during taxi. Values in this manual are invented and must not be used for any operational purpose.

Both pilots will brief any change in the Autopilot Channel B quantity display and advise the other pilot if a discrepancy is observed. Both pilots will select any change in the Stall Warning status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will brief any change in the Thrust Reverser annunciation and advise the other pilot when operating at a sample station without ground power. During an extended ground delay, both pilots should select the Standby Instruments switch position when conditions permit. The Thrust Reverser annunciation that differs from the expected state requires the relief pilot to verify the condition if a discrepancy is observed.

If the Autopilot Channel A is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The Cockpit Voice Recorder indication is expected to read within the sample range of 96 to 106 units during an extended ground delay. The Probe Heat status message that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed. During a turnaround, the First Officer should select the Bleed Air Supply quantity display unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. During approach, both pilots should announce the Nosewheel Steering switch position unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

During an extended ground delay, the Captain should monitor the Brake Temperature Monitor annunciation unless directed otherwise by the Sample Operations Center. During preflight, both pilots should cross-check the Nosewheel Steering switch position when operating at a sample station without ground power. During a diversion, the relief pilot should confirm the Center Tank Pumps advisory unless directed otherwise by the Sample Operations Center. If the Weather Radar is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. During engine start, the First Officer should brief the Autopilot Channel B quantity display before the next phase of flight.

- The pilot flying will announce any change in the Flap Position Indication quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Bleed Air Supply annunciation is expected to read within the sample range of 20 to 27 units during takeoff.

- The Hydraulic System B advisory that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center.

NOTE: The Speedbrake Handle switch position is expected to read within the sample range of 65 to 76 units during descent.

The Traffic Advisory Display indication that differs from the expected state requires both pilots to record the condition when conditions permit. The Flight Management Computer indication that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated. If the Hydraulic System B is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. During a diversion, the First Officer should brief the Transponder quantity display if a discrepancy is observed. The captain will select any change in the Bleed Air Supply quantity display and advise the other pilot when operating at a sample station without ground power. The Engine Anti-Ice status message is expected to read within the sample range of 56 to 60 units during an extended ground delay.

03.20.9 Callouts: Cargo Smoke Detection

The Autothrottle annunciation that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. If the Autobrake Selector is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will record any change in the Engine Anti-Ice annunciation and advise the other pilot when conditions permit. During parking, the pilot monitoring should confirm the Cabin Pressure Controller selector position when conditions permit.

The relief pilot will record any change in the Window Heat advisory and advise the other pilot before the next phase of flight. During cruise, the Captain should confirm the Cargo Smoke Detection selector position if a discrepancy is observed. If the Bleed Air Supply is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder annunciation that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Hydraulic System B indication	10 units	Monitor
Oxygen Distribution indication	61 units	Refer to related topic
Cabin Pressure Controller annunciation	31 units	Advisory only
Cabin Pressure Controller indication	25 units	Advisory only
Autobrake Selector selector position	57 units	Normal
Flight Management Computer switch position	87 units	Normal
Ground Proximity Monitor status message	42 units	Monitor

The Fire Detection Loop advisory that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Stall Warning selector position that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. The Bleed Air Supply quantity display that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. See 02.30.12 Airspeed Limitation 12.

Condition	Sample value	Remarks
Landing Gear Indication status message	6 units	Monitor
Standby Instruments advisory	17 units	Refer to related topic
Primary Electrical Bus switch position	6 units	Refer to related topic
Primary Electrical Bus status message	29 units	Refer to related topic

Transponder quantity display	35 units	Monitor
Window Heat quantity display	86 units	Advisory only
Brake Temperature Monitor switch position	84 units	Refer to related topic

Challenge	Response
Cabin Pressure Controller	Closed
Autobrake Selector	Verified
Flap Position Indication	Closed
Standby Instruments	Armed
Weather Radar	As required
Cockpit Voice Recorder	Set
Stall Warning	Checked
Speedbrake Handle	Set

03.20.10 Briefing: Autopilot Channel A

Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. During a turnaround, the pilot monitoring should record the Standby Instruments status message when the associated caution light remains illuminated. The Autobrake Selector quantity display that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. The Nosewheel Steering indication that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. If the Traffic Advisory Display is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

CAUTION: During descent, the pilot flying should cross-check the Flight Management Computer quantity display when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Center Tank Pumps annunciation	32 units	Normal
Hydraulic System A switch position	20 units	Normal
Center Tank Pumps quantity display	7 units	Monitor

If the Engine Anti-Ice is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During a turnaround, the Captain should brief the Autopilot Channel A status message if the indication does not stabilize within the sample interval. The Thrust Reverser advisory that differs from the expected state requires the pilot flying to record the condition before the next phase of flight.

During landing, the First Officer should monitor the Probe Heat advisory when the associated caution light remains illuminated. The Pack Temperature Control switch position is expected to read within the sample range of 35 to 41 units during taxi. If the Auxiliary Power Unit is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The captain will cross-check any change in the Window Heat indication and advise the other pilot when conditions permit.

CAUTION: During engine start, the relief pilot should verify the Standby Hydraulic quantity display if a discrepancy is observed. The relief pilot will brief any change in the Cockpit Voice Recorder status message and advise the other pilot if a discrepancy is observed.

Challenge	Response
Hydraulic System B	Armed
Auxiliary Power Unit	On

Traffic Advisory Display	Closed
Autobrake Selector	Checked
Cargo Smoke Detection	Verified
Autothrottle	Set
Hydraulic System A	Off
Flight Management Computer	On
Window Heat	Armed

03.20.11 Checklist: Nosewheel Steering

Values in this manual are invented and must not be used for any operational purpose. The Cabin Pressure Controller selector position that differs from the expected state requires both pilots to record the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the pilot monitoring should verify the Auxiliary Power Unit quantity display once the checklist item is complete. If the Center Tank Pumps is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. During takeoff, both pilots should brief the Fire Detection Loop status message if a discrepancy is observed.

If the Thrust Reverser is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. During cruise, the pilot monitoring should confirm the Landing Gear Indication status message unless directed otherwise by the Sample Operations Center. The relief pilot will confirm any change in the Weather Radar quantity display and advise the other pilot when the associated caution light remains illuminated.

The Cabin Pressure Controller advisory that differs from the expected state requires the relief pilot to verify the condition if a discrepancy is observed. If the Hydraulic System B is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. During a diversion, the pilot monitoring should brief the Cockpit Voice Recorder switch position when conditions permit.

CAUTION: The Standby Hydraulic switch position is expected to read within the sample range of 55 to 64 units during an extended ground delay.

During parking, the First Officer should cross-check the Autopilot Channel A selector position when conditions permit. The captain will verify any change in the Landing Gear Indication indication and advise the other pilot when operating at a sample station without ground power. The Flight Management Computer switch position that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. During an extended ground delay, the relief pilot should announce the Wing Anti-Ice status message before the next phase of flight. If the Autopilot Channel A is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. See 06.40.10 Wing Anti-Ice Limits Display.

- During engine start, both pilots should verify the Speedbrake Handle selector position if a discrepancy is observed.
- The Autobrake Selector status message that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated.
- The Flight Management Computer status message that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight.
- The Probe Heat status message that differs from the expected state requires the Captain to verify the condition when conditions permit.
- During a turnaround, the pilot monitoring should monitor the Pack Temperature Control advisory if a discrepancy is observed.

Challenge	Response
Standby Instruments	On

Cockpit Voice Recorder	Checked
Fuel Crossfeed	As required
Oxygen Distribution	Set
Weather Radar	On
Autopilot Channel A	Armed
Primary Electrical Bus	Closed
Fire Detection Loop	As required

03.20.12 Flow: Center Tank Pumps

The Hydraulic System B quantity display is expected to read within the sample range of 93 to 99 units during climb. The Brake Temperature Monitor advisory is expected to read within the sample range of 81 to 91 units during preflight. The Standby Instruments status message is expected to read within the sample range of 61 to 71 units during approach. The Traffic Advisory Display indication is expected to read within the sample range of 14 to 25 units during descent. If the Autothrottle is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The pilot flying will brief any change in the Landing Gear Indication selector position and advise the other pilot if a discrepancy is observed.

CAUTION: Refer to the related topic for additional sample context.

- If the Cargo Smoke Detection is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- During a maintenance-requested ground run, the First Officer should verify the Auxiliary Power Unit indication unless directed otherwise by the Sample Operations Center.
- During a diversion, the pilot flying should announce the Standby Hydraulic indication if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Fuel Crossfeed annunciation	4 units	Refer to related topic
Thrust Reverser selector position	3 units	Advisory only
Landing Gear Indication status message	75 units	Refer to related topic
Hydraulic System B selector position	23 units	Normal
Landing Gear Indication selector position	17 units	Refer to related topic

Condition	Sample value	Remarks
Cargo Smoke Detection status message	47 units	Normal
Cockpit Voice Recorder indication	95 units	Monitor
Bleed Air Supply advisory	44 units	Normal

During landing, both pilots should announce the Flap Position Indication status message when the associated caution light remains illuminated. The Standby Instruments switch position is expected to read within the sample range of 42 to 51 units during approach. During a turnaround, the relief pilot should cross-check the Primary Electrical Bus quantity display unless directed otherwise by the Sample Operations Center. During a maintenance-requested ground run, the Captain should monitor the Wing Anti-Ice advisory when operating at a sample station without ground power. See 01.10.6 Organization Topic 5.

CAUTION: The Autopilot Channel B advisory is expected to read within the sample range of 89 to 98 units during engine start. The Center Tank Pumps selector position that differs from the expected state requires the relief pilot

to monitor the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Fuel Crossfeed quantity display	9 units	Advisory only
Wing Anti-Ice annunciation	98 units	Refer to related topic
Autothrottle annunciation	85 units	Advisory only

03.20.13 Checklist: Hydraulic System A

The captain will verify any change in the Weather Radar status message and advise the other pilot if a discrepancy is observed. During cruise, the Captain should announce the Transponder advisory when operating at a sample station without ground power. During preflight, the relief pilot should brief the Flight Management Computer annunciation when operating at a sample station without ground power. During a turnaround, the pilot flying should select the Auxiliary Power Unit advisory when conditions permit.

The captain will record any change in the Autopilot Channel A quantity display and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The first officer will brief any change in the Hydraulic System B selector position and advise the other pilot when the associated caution light remains illuminated.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Hydraulic System A is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.
- The first officer will confirm any change in the Pack Temperature Control annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- The Traffic Advisory Display annunciation is expected to read within the sample range of 21 to 28 units during preflight.
- The Flap Position Indication annunciation that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Window Heat switch position	41 units	Advisory only
Fire Detection Loop advisory	57 units	Normal
Flap Position Indication advisory	22 units	Advisory only
Speedbrake Handle quantity display	25 units	Normal
Stall Warning advisory	1 units	Normal
Flight Management Computer annunciation	3 units	Normal
Autothrottle advisory	79 units	Refer to related topic

CAUTION: The Nosewheel Steering quantity display is expected to read within the sample range of 25 to 28 units during a diversion. The Flight Management Computer indication that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Fire Detection Loop annunciation	2 units	Advisory only
Ground Proximity Monitor selector position	53 units	Refer to related topic
Engine Anti-Ice annunciation	82 units	Normal

The Standby Hydraulic quantity display that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight. The Weather Radar selector position that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated. If the Flap Position Indication is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will announce any change in the Fire Detection Loop selector position and advise the other pilot once the checklist item is complete. The Center Tank Pumps indication that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. The captain will monitor any change in the Traffic Advisory Display switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

03.20.14 Crew Coordination: Engine Anti-Ice

The Autobrake Selector status message that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed. If the Oxygen Distribution is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The Cargo Smoke Detection quantity display that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete. If the Pack Temperature Control is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

CAUTION: During cruise, the First Officer should announce the Ground Proximity Monitor indication if the indication does not stabilize within the sample interval. During approach, the pilot flying should announce the Autopilot Channel B advisory if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During approach, the relief pilot should record the Center Tank Pumps status message once the checklist item is complete.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Weather Radar status message that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight.

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	56 units	Monitor
Flap Position Indication advisory	78 units	Monitor
Standby Hydraulic advisory	25 units	Advisory only
Thrust Reverser quantity display	59 units	Normal
Wing Anti-Ice status message	29 units	Refer to related topic
Pack Temperature Control indication	65 units	Normal
Cabin Pressure Controller advisory	19 units	Advisory only

Values in this manual are invented and must not be used for any operational purpose. If the Oxygen Distribution is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Cabin Pressure Controller advisory that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete. The Oxygen Distribution advisory that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval. During climb, the pilot monitoring should cross-check the Primary Electrical Bus selector position before the next phase of flight.

Condition	Sample value	Remarks
Standby Instruments switch position	48 units	Monitor
Auxiliary Power Unit advisory	7 units	Normal

Landing Gear Indication status message	39 units	Monitor
Brake Temperature Monitor quantity display	17 units	Normal
Fire Detection Loop advisory	30 units	Advisory only
Hydraulic System B quantity display	43 units	Advisory only
Landing Gear Indication selector position	93 units	Advisory only

03.20.15 Crew Coordination: Weather Radar

If the Auxiliary Power Unit is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel B status message that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. The Brake Temperature Monitor switch position is expected to read within the sample range of 83 to 95 units during landing. During approach, the Captain should select the Autopilot Channel A indication when operating at a sample station without ground power.

If the Stall Warning is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Fire Detection Loop switch position is expected to read within the sample range of 46 to 55 units during a maintenance-requested ground run. Values in this manual are invented and must not be used for any operational purpose. During a turnaround, the relief pilot should cross-check the Flap Position Indication selector position once the checklist item is complete. If the Probe Heat is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Probe Heat quantity display	25 units	Advisory only
Pack Temperature Control switch position	72 units	Monitor
Auxiliary Power Unit indication	44 units	Refer to related topic
Speedbrake Handle status message	10 units	Monitor

Condition	Sample value	Remarks
Cargo Smoke Detection switch position	35 units	Monitor
Brake Temperature Monitor selector position	80 units	Monitor
Speedbrake Handle advisory	25 units	Advisory only
Autopilot Channel A advisory	46 units	Advisory only
Auxiliary Power Unit status message	82 units	Normal

CAUTION: Both pilots will monitor any change in the Brake Temperature Monitor switch position and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The captain will brief any change in the Fuel Crossfeed annunciation and advise the other pilot if a discrepancy is observed.

Both pilots will brief any change in the Fuel Crossfeed advisory and advise the other pilot before the next phase of flight. The Standby Hydraulic advisory that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight. The relief pilot will monitor any change in the Primary Electrical Bus indication and advise the other pilot if the indication does not stabilize within the sample interval.

03.20.16 Flow: Oxygen Distribution

If the Bleed Air Supply is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During descent, both pilots should

select the Cabin Pressure Controller selector position unless directed otherwise by the Sample Operations Center. The first officer will verify any change in the Primary Electrical Bus status message and advise the other pilot before the next phase of flight. During a turnaround, the Captain should monitor the Cockpit Voice Recorder annunciation once the checklist item is complete. If the Oxygen Distribution is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

- If the Wing Anti-Ice is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.
- The Auxiliary Power Unit advisory that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval.
- During a turnaround, the First Officer should confirm the Center Tank Pumps status message unless directed otherwise by the Sample Operations Center.

NOTE: During climb, the relief pilot should brief the Cabin Pressure Controller selector position unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit switch position that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power.

NOTE: The pilot monitoring will announce any change in the Oxygen Distribution advisory and advise the other pilot if the indication does not stabilize within the sample interval. The captain will monitor any change in the Probe Heat annunciation and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Weather Radar quantity display	48 units	Normal
Hydraulic System B selector position	31 units	Advisory only
Autopilot Channel B status message	91 units	Monitor

03.20.17 Crew Coordination: Weather Radar

The Flight Management Computer switch position is expected to read within the sample range of 96 to 108 units during an extended ground delay. The Autothrottle quantity display is expected to read within the sample range of 33 to 39 units during taxi. If the Pack Temperature Control is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Probe Heat status message	2 units	Normal
Thrust Reverser quantity display	28 units	Refer to related topic
Fuel Crossfeed quantity display	68 units	Advisory only
Cabin Pressure Controller quantity display	88 units	Normal
Cockpit Voice Recorder annunciation	82 units	Normal

The Window Heat advisory that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed. If the Transponder is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Wing Anti-Ice switch position is expected to read within the sample range of 83 to 93 units during engine start.

The Cockpit Voice Recorder advisory that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will verify any change in the Engine Anti-Ice switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed advisory that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample

interval. The Auxiliary Power Unit advisory is expected to read within the sample range of 9 to 12 units during descent.

- During approach, the pilot monitoring should monitor the Window Heat annunciation when the associated caution light remains illuminated.
- The Fuel Crossfeed status message that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed.
- The Speedbrake Handle selector position that differs from the expected state requires the First Officer to cross-check the condition when conditions permit.

Challenge	Response
Window Heat	Closed
Flap Position Indication	Verified
Fuel Crossfeed	Armed
Flap Position Indication	On
Ground Proximity Monitor	Verified
Center Tank Pumps	Set
Stall Warning	Closed
Probe Heat	Verified
Pack Temperature Control	On
Fuel Crossfeed	Closed
Speedbrake Handle	Verified

03.20.18 Flow: Thrust Reverser

The Hydraulic System B advisory that differs from the expected state requires both pilots to confirm the condition before the next phase of flight. The relief pilot will confirm any change in the Cargo Smoke Detection selector position and advise the other pilot before the next phase of flight. The Standby Instruments advisory that differs from the expected state requires the First Officer to select the condition once the checklist item is complete.

During climb, the relief pilot should verify the Transponder status message when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System B quantity display is expected to read within the sample range of 34 to 43 units during a turnaround. If the Cockpit Voice Recorder is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

The Probe Heat status message that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. The Bleed Air Supply annunciation that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Brake Temperature Monitor quantity display	82 units	Normal
Weather Radar indication	28 units	Advisory only
Landing Gear Indication annunciation	59 units	Refer to related topic

- The wording here is placeholder content shaped like a procedure, not a procedure.
- During climb, the pilot monitoring should monitor the Ground Proximity Monitor advisory when operating at a sample station without ground power.

- The Standby Hydraulic switch position is expected to read within the sample range of 12 to 15 units during approach.
- The Cabin Pressure Controller indication is expected to read within the sample range of 53 to 57 units during an extended ground delay.

CAUTION: The Bleed Air Supply indication that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. The relief pilot will record any change in the Fire Detection Loop status message and advise the other pilot if the indication does not stabilize within the sample interval.

Both pilots will monitor any change in the Oxygen Distribution quantity display and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The Ground Proximity Monitor quantity display that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. See 04.30.2 Crew Coordination: Wing Anti-Ice.

NOTE: Values in this manual are invented and must not be used for any operational purpose. If the Window Heat is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

CAUTION: If the Fire Detection Loop is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

03.20.19 Verification: Cabin Pressure Controller

During takeoff, both pilots should brief the Autobrake Selector switch position when conditions permit. During parking, the pilot flying should confirm the Fire Detection Loop annunciation when the associated caution light remains illuminated. The Oxygen Distribution status message that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight. The Auxiliary Power Unit advisory is expected to read within the sample range of 9 to 16 units during a diversion.

- During a maintenance-requested ground run, the pilot monitoring should record the Flight Management Computer advisory when conditions permit.
- During descent, both pilots should announce the Wing Anti-Ice selector position when conditions permit.
- If the Transponder is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- The pilot flying will confirm any change in the Hydraulic System A quantity display and advise the other pilot when operating at a sample station without ground power.
- If the Auxiliary Power Unit is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- The Engine Anti-Ice quantity display that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight.
- During approach, the pilot flying should cross-check the Fuel Crossfeed annunciation once the checklist item is complete.
- The Engine Anti-Ice selector position that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval.
- The Engine Anti-Ice annunciation is expected to read within the sample range of 50 to 53 units during preflight.

CAUTION: The Auxiliary Power Unit quantity display that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. During taxi, the First Officer should confirm the Stall Warning indication when conditions permit.

Condition	Sample value	Remarks
Cargo Smoke Detection switch position	67 units	Monitor

Bleed Air Supply switch position	82 units	Refer to related topic
Cockpit Voice Recorder status message	89 units	Monitor

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will monitor any change in the Flap Position Indication advisory and advise the other pilot when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Brake Temperature Monitor advisory that differs from the expected state requires the Captain to brief the condition when conditions permit. The pilot flying will brief any change in the Cabin Pressure Controller advisory and advise the other pilot when the associated caution light remains illuminated. See 11.10.1 Autopilot Channel A Crew Awareness.

- The relief pilot will brief any change in the Standby Instruments quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Engine Anti-Ice is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- The Brake Temperature Monitor advisory that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Nosewheel Steering quantity display	51 units	Monitor
Hydraulic System B advisory	45 units	Monitor
Stall Warning indication	5 units	Normal
Fuel Crossfeed indication	35 units	Refer to related topic
Auxiliary Power Unit indication	64 units	Normal

Challenge	Response
Brake Temperature Monitor	Verified
Autobrake Selector	On
Center Tank Pumps	Armed
Flight Management Computer	Checked
Traffic Advisory Display	Off
Flap Position Indication	On

03.20.20 Briefing: Pack Temperature Control

The Speedbrake Handle quantity display is expected to read within the sample range of 77 to 89 units during approach. During descent, the Captain should verify the Pack Temperature Control switch position when conditions permit. Both pilots will verify any change in the Pack Temperature Control advisory and advise the other pilot once the checklist item is complete.

- The Ground Proximity Monitor selector position is expected to read within the sample range of 70 to 73 units during preflight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Cabin Pressure Controller selector position	10 units	Advisory only

Stall Warning quantity display	7 units	Monitor
Primary Electrical Bus quantity display	31 units	Advisory only
Engine Anti-Ice annunciation	86 units	Advisory only
Weather Radar annunciation	47 units	Advisory only
Cockpit Voice Recorder quantity display	87 units	Advisory only
Autobrake Selector selector position	90 units	Monitor

- If the Engine Anti-Ice is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The pilot flying will monitor any change in the Pack Temperature Control indication and advise the other pilot when conditions permit.
- If the Hydraulic System A is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- During descent, the First Officer should monitor the Oxygen Distribution status message once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control indication is expected to read within the sample range of 85 to 94 units during preflight.

03.20.21 Callouts: Ground Proximity Monitor

The captain will select any change in the Center Tank Pumps advisory and advise the other pilot when the associated caution light remains illuminated. The Transponder indication that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. During taxi, both pilots should announce the Probe Heat annunciation unless directed otherwise by the Sample Operations Center. During landing, the First Officer should confirm the Pack Temperature Control selector position before the next phase of flight. During an extended ground delay, the relief pilot should monitor the Stall Warning indication if the indication does not stabilize within the sample interval.

NOTE: During taxi, the pilot flying should confirm the Window Heat advisory once the checklist item is complete.

The pilot monitoring will record any change in the Oxygen Distribution quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Weather Radar indication is expected to read within the sample range of 96 to 99 units during a turnaround. The Standby Hydraulic switch position is expected to read within the sample range of 46 to 53 units during parking. If the Flight Management Computer is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

CAUTION: The Autopilot Channel B switch position is expected to read within the sample range of 29 to 32 units during an extended ground delay.

NOTE: Refer to the related topic for additional sample context.

03.20.22 Callouts: Stall Warning

The first officer will verify any change in the Autothrottle status message and advise the other pilot once the checklist item is complete. During a maintenance-requested ground run, the pilot monitoring should monitor the Weather Radar selector position once the checklist item is complete. During a turnaround, the pilot flying should brief the Engine Anti-Ice advisory when the associated caution light remains illuminated. If the Cabin Pressure Controller is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Probe Heat selector position that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. If the Hydraulic System B is inoperative, continue a turnaround only after the pilot flying has

reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The relief pilot will brief any change in the Traffic Advisory Display quantity display and advise the other pilot when operating at a sample station without ground power.

If the Landing Gear Indication is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication selector position that differs from the expected state requires both pilots to record the condition when conditions permit. Refer to the related topic for additional sample context. If the Engine Anti-Ice is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During takeoff, both pilots should monitor the Flight Management Computer annunciation if the indication does not stabilize within the sample interval.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Transponder quantity display is expected to read within the sample range of 37 to 43 units during engine start. During an extended ground delay, the Captain should select the Window Heat quantity display once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle advisory is expected to read within the sample range of 95 to 104 units during landing. The Autopilot Channel B annunciation is expected to read within the sample range of 53 to 62 units during takeoff. The Probe Heat status message that differs from the expected state requires the First Officer to announce the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

During approach, the relief pilot should announce the Cabin Pressure Controller selector position when the associated caution light remains illuminated. During preflight, the Captain should record the Bleed Air Supply indication if a discrepancy is observed. Refer to the related topic for additional sample context. The Oxygen Distribution annunciation is expected to read within the sample range of 15 to 25 units during taxi. During parking, the First Officer should brief the Hydraulic System A quantity display once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice quantity display is expected to read within the sample range of 75 to 81 units during engine start.

Challenge	Response
Weather Radar	As required
Cargo Smoke Detection	Closed
Center Tank Pumps	On
Ground Proximity Monitor	As required
Hydraulic System B	On
Flap Position Indication	Off
Flight Management Computer	On
Standby Instruments	On
Hydraulic System B	On

03.20.23 Flow: Standby Instruments

Values in this manual are invented and must not be used for any operational purpose. During approach, the pilot flying should brief the Ground Proximity Monitor indication once the checklist item is complete. The Autopilot Channel B advisory is expected to read within the sample range of 67 to 72 units during descent.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Brake Temperature Monitor quantity display	38 units	Refer to related topic
Weather Radar advisory	89 units	Refer to related topic
Bleed Air Supply switch position	91 units	Monitor
Auxiliary Power Unit switch position	10 units	Refer to related topic
Landing Gear Indication annunciation	75 units	Refer to related topic

CAUTION: The Fuel Crossfeed selector position is expected to read within the sample range of 97 to 106 units during landing.

NOTE: During takeoff, the pilot monitoring should verify the Bleed Air Supply status message unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

- During a turnaround, the relief pilot should confirm the Autopilot Channel B selector position once the checklist item is complete.
- The first officer will brief any change in the Nosewheel Steering indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Fuel Crossfeed annunciation that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.

During an extended ground delay, the Captain should brief the Bleed Air Supply quantity display unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Bleed Air Supply status message is expected to read within the sample range of 52 to 58 units during climb. The Autothrottle status message is expected to read within the sample range of 51 to 56 units during takeoff. The wording here is placeholder content shaped like a procedure, not a procedure.

03.20.24 Checklist: Hydraulic System A

During a turnaround, the Captain should announce the Ground Proximity Monitor quantity display before the next phase of flight. If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During engine start, the pilot flying should verify the Brake Temperature Monitor advisory if the indication does not stabilize within the sample interval. If the Stall Warning is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Instruments indication	86 units	Normal
Thrust Reverser advisory	69 units	Monitor
Hydraulic System B switch position	96 units	Refer to related topic

During approach, the relief pilot should confirm the Center Tank Pumps indication once the checklist item is complete. The Flap Position Indication quantity display is expected to read within the sample range of 20 to 32 units during landing. The Autopilot Channel B status message that differs from the expected state requires both pilots to brief the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Stall Warning selector position that differs from the expected state requires the relief pilot to record the

condition when operating at a sample station without ground power. The Primary Electrical Bus quantity display that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Flap Position Indication selector position	73 units	Monitor
Pack Temperature Control advisory	92 units	Normal
Traffic Advisory Display indication	28 units	Normal
Fire Detection Loop selector position	74 units	Refer to related topic
Fire Detection Loop status message	88 units	Refer to related topic
Autopilot Channel A indication	35 units	Monitor
Probe Heat switch position	49 units	Monitor

Challenge	Response
Flight Management Computer	Off
Standby Hydraulic	As required
Window Heat	On
Center Tank Pumps	Verified
Oxygen Distribution	Armed
Engine Anti-Ice	Off
Cargo Smoke Detection	On
Thrust Reverser	Verified
Brake Temperature Monitor	On
Autobrake Selector	Verified

03.20.25 Checklist: Speedbrake Handle

During preflight, both pilots should brief the Bleed Air Supply annunciation if the indication does not stabilize within the sample interval. During descent, the First Officer should cross-check the Flight Management Computer switch position unless directed otherwise by the Sample Operations Center. The Oxygen Distribution annunciation that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor selector position is expected to read within the sample range of 44 to 55 units during an extended ground delay. If the Auxiliary Power Unit is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, both pilots should select the Brake Temperature Monitor switch position if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autopilot Channel A quantity display	34 units	Normal
Stall Warning annunciation	7 units	Advisory only
Bleed Air Supply annunciation	8 units	Advisory only
Nosewheel Steering annunciation	24 units	Monitor

During climb, the First Officer should record the Weather Radar status message before the next phase of flight. The Autothrottle selector position is expected to read within the sample range of 72 to 81 units during descent. The

wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps status message that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed. The pilot monitoring will record any change in the Window Heat selector position and advise the other pilot before the next phase of flight. During engine start, the relief pilot should announce the Hydraulic System A advisory when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the First Officer should select the Cabin Pressure Controller annunciation if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. During approach, the pilot flying should select the Weather Radar status message if a discrepancy is observed.

Challenge	Response
Bleed Air Supply	As required
Window Heat	Closed
Fire Detection Loop	On
Flap Position Indication	Checked
Wing Anti-Ice	Verified
Weather Radar	On
Oxygen Distribution	As required
Standby Hydraulic	Closed
Bleed Air Supply	Armed
Flap Position Indication	Closed

03.30 Taxi

03.30.1 Verification: Thrust Reverser

Values in this manual are invented and must not be used for any operational purpose. During descent, the First Officer should monitor the Bleed Air Supply indication when operating at a sample station without ground power. The Landing Gear Indication indication is expected to read within the sample range of 92 to 97 units during preflight.

Condition	Sample value	Remarks
Weather Radar annunciation	74 units	Refer to related topic
Transponder annunciation	19 units	Monitor
Fire Detection Loop annunciation	56 units	Advisory only

The Center Tank Pumps switch position that differs from the expected state requires the pilot flying to confirm the condition when conditions permit. The pilot monitoring will verify any change in the Hydraulic System A selector position and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Speedbrake Handle selector position that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power.

During a turnaround, the Captain should announce the Standby Hydraulic switch position when conditions permit. The Speedbrake Handle selector position that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power. The Primary Electrical Bus quantity display is expected to read within the sample range of 3 to 9 units during a maintenance-requested ground run. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. The Nosewheel Steering indication is expected to read within the sample range of 86 to 95 units during a maintenance-requested ground run.

The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps status message is expected to read within the sample range of 57 to 60 units during a diversion. The Weather Radar selector position that differs from the expected state requires the First Officer to select the condition when conditions permit.

03.30.2 Flow: Traffic Advisory Display

Refer to the related topic for additional sample context. The pilot flying will verify any change in the Oxygen Distribution quantity display and advise the other pilot once the checklist item is complete. The Ground Proximity Monitor selector position is expected to read within the sample range of 17 to 29 units during landing. During an extended ground delay, the Captain should brief the Fuel Crossfeed selector position if a discrepancy is observed.

The Autothrottle selector position is expected to read within the sample range of 77 to 87 units during a diversion. Both pilots will brief any change in the Autopilot Channel B advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During cruise, both pilots should announce the Ground Proximity Monitor quantity display if the indication does not stabilize within the sample interval.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will record any change in the Nosewheel Steering indication and advise the other pilot when the associated caution light remains illuminated.

CAUTION: During descent, both pilots should select the Hydraulic System A annunciation unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Nosewheel Steering advisory	7 units	Advisory only
Flight Management Computer selector position	35 units	Advisory only
Auxiliary Power Unit status message	38 units	Monitor
Standby Hydraulic switch position	8 units	Monitor
Ground Proximity Monitor indication	77 units	Refer to related topic
Autopilot Channel A status message	75 units	Normal

The first officer will monitor any change in the Hydraulic System A annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Auxiliary Power Unit is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. Both pilots will brief any change in the Weather Radar advisory and advise the other pilot before the next phase of flight. If the Traffic Advisory Display is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Probe Heat advisory	16 units	Normal
Primary Electrical Bus quantity display	24 units	Normal
Engine Anti-Ice selector position	20 units	Advisory only
Pack Temperature Control switch position	54 units	Monitor
Standby Hydraulic switch position	89 units	Advisory only
Nosewheel Steering indication	55 units	Advisory only

Condition	Sample value	Remarks
Standby Hydraulic quantity display	26 units	Monitor
Hydraulic System B annunciation	7 units	Normal
Ground Proximity Monitor status message	51 units	Refer to related topic
Thrust Reverser quantity display	65 units	Normal

Pack Temperature Control quantity display	52 units	Refer to related topic
Flap Position Indication selector position	46 units	Refer to related topic

03.30.3 Verification: Primary Electrical Bus

If the Speedbrake Handle is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will select any change in the Landing Gear Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Hydraulic System B is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Autopilot Channel B advisory that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight. If the Cargo Smoke Detection is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Instruments indication	55 units	Normal
Standby Hydraulic switch position	45 units	Refer to related topic
Autopilot Channel A selector position	8 units	Normal
Hydraulic System A selector position	55 units	Normal
Transponder selector position	44 units	Advisory only
Landing Gear Indication status message	85 units	Refer to related topic

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

The Oxygen Distribution annunciation that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete. The Flight Management Computer status message is expected to read within the sample range of 27 to 35 units during parking. Values in this manual are invented and must not be used for any operational purpose. The Stall Warning status message is expected to read within the sample range of 42 to 51 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Wing Anti-Ice quantity display	51 units	Monitor
Landing Gear Indication switch position	5 units	Refer to related topic
Autopilot Channel B annunciation	73 units	Advisory only
Pack Temperature Control quantity display	14 units	Advisory only
Landing Gear Indication indication	61 units	Monitor
Standby Hydraulic advisory	94 units	Refer to related topic

The Window Heat advisory that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete. The Autopilot Channel B quantity display is expected to read within the sample range of 54 to 62 units during approach. The Oxygen Distribution quantity display is expected to read within the sample range of 32 to 41 units during parking. The Weather Radar status message is expected to read within the sample range of 40 to 47 units during climb. During cruise, the pilot monitoring should brief the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will announce any change in the Weather Radar quantity display and advise the other pilot if a discrepancy is observed. Both pilots will announce any change in the Nosewheel Steering selector position and advise the other pilot before the next phase of flight. During preflight, the pilot flying should select the Standby Instruments indication when the associated caution light remains illuminated. The Engine Anti-Ice quantity display that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. The Autothrottle annunciation that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is

observed.

The Hydraulic System A indication that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. The Brake Temperature Monitor status message is expected to read within the sample range of 92 to 104 units during a turnaround. During takeoff, the relief pilot should record the Autopilot Channel B switch position once the checklist item is complete.

Challenge	Response
Flap Position Indication	Armed
Autobrake Selector	Armed
Autopilot Channel B	Checked
Cargo Smoke Detection	Closed
Landing Gear Indication	Closed
Thrust Reverser	Set

03.30.4 Crew Coordination: Flap Position Indication

Values in this manual are invented and must not be used for any operational purpose. During approach, the Captain should monitor the Standby Hydraulic quantity display once the checklist item is complete. If the Landing Gear Indication is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Nosewheel Steering selector position is expected to read within the sample range of 70 to 81 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will announce any change in the Landing Gear Indication switch position and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autopilot Channel A switch position	11 units	Normal
Landing Gear Indication advisory	91 units	Normal
Autopilot Channel B switch position	97 units	Normal
Oxygen Distribution annunciation	57 units	Advisory only
Thrust Reverser annunciation	35 units	Normal
Probe Heat advisory	47 units	Monitor
Cockpit Voice Recorder selector position	95 units	Monitor

CAUTION: The Ground Proximity Monitor advisory that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval.

NOTE: During taxi, the relief pilot should brief the Autothrottle quantity display if a discrepancy is observed.

Condition	Sample value	Remarks
Stall Warning advisory	58 units	Normal
Thrust Reverser indication	44 units	Refer to related topic
Traffic Advisory Display annunciation	3 units	Advisory only
Cargo Smoke Detection advisory	41 units	Refer to related topic

03.30.5 Checklist: Stall Warning

The Ground Proximity Monitor indication that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. If the Pack Temperature Control is inoperative, continue descent only after the First Officer has reviewed the

associated sample guidance. If the Nosewheel Steering is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

- The relief pilot will record any change in the Brake Temperature Monitor switch position and advise the other pilot when operating at a sample station without ground power.
- During preflight, the pilot flying should record the Thrust Reverser quantity display before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The first officer will verify any change in the Fire Detection Loop advisory and advise the other pilot when conditions permit.
- If the Landing Gear Indication is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.
- During approach, the pilot monitoring should cross-check the Autobrake Selector switch position before the next phase of flight.

Condition	Sample value	Remarks
Primary Electrical Bus annunciation	17 units	Normal
Fuel Crossfeed indication	15 units	Advisory only
Bleed Air Supply annunciation	56 units	Advisory only
Cargo Smoke Detection selector position	74 units	Advisory only
Hydraulic System A advisory	73 units	Refer to related topic

NOTE: The Autobrake Selector annunciation is expected to read within the sample range of 64 to 74 units during a diversion. If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Landing Gear Indication advisory	7 units	Normal
Wing Anti-Ice selector position	14 units	Normal
Thrust Reverser switch position	86 units	Monitor
Window Heat annunciation	68 units	Refer to related topic

Challenge	Response
Standby Hydraulic	Armed
Autothrottle	Armed
Hydraulic System B	Closed
Speedbrake Handle	Closed
Brake Temperature Monitor	As required
Primary Electrical Bus	Off
Hydraulic System B	On
Auxiliary Power Unit	On
Traffic Advisory Display	As required

03.30.6 Checklist: Cargo Smoke Detection

The Cockpit Voice Recorder status message that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. If the Standby Hydraulic is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The first officer

will monitor any change in the Nosewheel Steering status message and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

NOTE: The Cabin Pressure Controller indication is expected to read within the sample range of 56 to 63 units during a turnaround. The captain will announce any change in the Fuel Crossfeed switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Engine Anti-Ice selector position is expected to read within the sample range of 42 to 45 units during descent. If the Auxiliary Power Unit is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the Captain should confirm the Landing Gear Indication advisory if a discrepancy is observed. If the Weather Radar is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

CAUTION: The first officer will monitor any change in the Fuel Crossfeed quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

During a turnaround, the relief pilot should announce the Cockpit Voice Recorder switch position once the checklist item is complete. The Window Heat switch position that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. The first officer will monitor any change in the Center Tank Pumps annunciation and advise the other pilot when the associated caution light remains illuminated. The captain will confirm any change in the Wing Anti-Ice advisory and advise the other pilot when the associated caution light remains illuminated. If the Probe Heat is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. If the Transponder is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

Challenge	Response
Center Tank Pumps	As required
Speedbrake Handle	Armed
Weather Radar	Closed
Autobrake Selector	As required
Fire Detection Loop	Set
Wing Anti-Ice	As required
Cockpit Voice Recorder	Verified
Cabin Pressure Controller	Off

03.30.7 Verification: Stall Warning

The Hydraulic System B annunciation that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. The Auxiliary Power Unit indication is expected to read within the sample range of 73 to 81 units during climb. The pilot flying will brief any change in the Bleed Air Supply selector position and advise the other pilot if the indication does not stabilize within the sample interval. The captain will brief any change in the Bleed Air Supply annunciation and advise the other pilot if a discrepancy is observed.

- The Landing Gear Indication selector position that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Engine Anti-Ice annunciation is expected to read within the sample range of 22 to 28 units during takeoff.
- The Weather Radar indication that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval.

- If the Thrust Reverser is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Oxygen Distribution indication	54 units	Refer to related topic
Autobrake Selector switch position	53 units	Normal
Wing Anti-Ice status message	79 units	Advisory only
Pack Temperature Control indication	80 units	Advisory only
Primary Electrical Bus advisory	90 units	Normal
Standby Hydraulic indication	49 units	Monitor
Ground Proximity Monitor quantity display	69 units	Monitor

Condition	Sample value	Remarks
Cockpit Voice Recorder status message	85 units	Monitor
Standby Instruments selector position	74 units	Advisory only
Flap Position Indication annunciation	71 units	Monitor
Cabin Pressure Controller indication	36 units	Monitor
Weather Radar advisory	30 units	Normal
Fire Detection Loop status message	56 units	Refer to related topic
Thrust Reverser status message	77 units	Normal

Condition	Sample value	Remarks
Fire Detection Loop annunciation	62 units	Monitor
Standby Instruments status message	32 units	Monitor
Engine Anti-Ice quantity display	57 units	Refer to related topic

The Nosewheel Steering quantity display is expected to read within the sample range of 23 to 33 units during cruise. If the Fire Detection Loop is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The first officer will confirm any change in the Wing Anti-Ice selector position and advise the other pilot once the checklist item is complete. The Traffic Advisory Display advisory is expected to read within the sample range of 92 to 98 units during descent.

03.30.8 Checklist: Oxygen Distribution

During approach, the First Officer should select the Stall Warning indication before the next phase of flight. The Probe Heat indication that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete. The Speedbrake Handle status message is expected to read within the sample range of 92 to 97 units during cruise. The Flight Management Computer status message is expected to read within the sample range of 21 to 24 units during a diversion. The Autopilot Channel A advisory that differs from the expected state requires both pilots to record the condition before the next phase of flight. The Ground Proximity Monitor annunciation that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.

CAUTION: The relief pilot will announce any change in the Bleed Air Supply indication and advise the other pilot when the associated caution light remains illuminated. Both pilots will cross-check any change in the Probe Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval.

During cruise, the Captain should verify the Wing Anti-Ice quantity display when operating at a sample station without ground power. The Stall Warning status message that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. The captain will brief any change in the

Autobrake Selector selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Autopilot Channel A status message that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Thrust Reverser indication that differs from the expected state requires the pilot flying to record the condition before the next phase of flight.

NOTE: The first officer will record any change in the Hydraulic System B advisory and advise the other pilot when operating at a sample station without ground power. Both pilots will cross-check any change in the Brake Temperature Monitor switch position and advise the other pilot if a discrepancy is observed.

NOTE: The Stall Warning selector position is expected to read within the sample range of 50 to 61 units during parking.

03.30.9 Checklist: Autopilot Channel B

If the Auxiliary Power Unit is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication selector position is expected to read within the sample range of 42 to 53 units during takeoff. During cruise, the Captain should record the Center Tank Pumps annunciation unless directed otherwise by the Sample Operations Center. The Weather Radar indication that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Autobrake Selector is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The captain will record any change in the Cabin Pressure Controller selector position and advise the other pilot when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the pilot flying should select the Standby Instruments switch position when the associated caution light remains illuminated. During engine start, the First Officer should confirm the Weather Radar status message if the indication does not stabilize within the sample interval. The Hydraulic System B annunciation is expected to read within the sample range of 59 to 69 units during climb. The first officer will confirm any change in the Transponder annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will verify any change in the Weather Radar selector position and advise the other pilot when the associated caution light remains illuminated. Both pilots will confirm any change in the Brake Temperature Monitor quantity display and advise the other pilot when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

- The first officer will announce any change in the Cockpit Voice Recorder quantity display and advise the other pilot before the next phase of flight.
- The Window Heat status message that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated.
- The pilot monitoring will monitor any change in the Hydraulic System B indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. If the Speedbrake Handle is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. Both pilots will select any change in the Center Tank Pumps quantity display and advise the other pilot if a discrepancy is observed. The captain will verify any change in the Autothrottle annunciation and advise the other pilot if a discrepancy is observed.

During climb, both pilots should record the Window Heat advisory unless directed otherwise by the Sample Operations Center. If the Ground Proximity Monitor is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Bleed Air Supply quantity display that

differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed.

Challenge	Response
Autobrake Selector	Armed
Cockpit Voice Recorder	Armed
Stall Warning	As required
Autopilot Channel A	Verified
Traffic Advisory Display	Set
Autothrottle	Checked
Flight Management Computer	Checked
Traffic Advisory Display	Armed

03.30.10 Crew Coordination: Autopilot Channel A

The pilot monitoring will brief any change in the Fuel Crossfeed selector position and advise the other pilot if a discrepancy is observed. The Hydraulic System B status message that differs from the expected state requires the Captain to record the condition once the checklist item is complete. During an extended ground delay, the First Officer should cross-check the Cabin Pressure Controller status message when conditions permit. The captain will confirm any change in the Cockpit Voice Recorder status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Engine Anti-Ice switch position is expected to read within the sample range of 4 to 12 units during climb. The Standby Hydraulic status message is expected to read within the sample range of 19 to 30 units during taxi. The first officer will record any change in the Cockpit Voice Recorder switch position and advise the other pilot before the next phase of flight. If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. During approach, the Captain should verify the Landing Gear Indication annunciation before the next phase of flight.

NOTE: The Bleed Air Supply quantity display that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. Both pilots will confirm any change in the Bleed Air Supply annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Stall Warning switch position is expected to read within the sample range of 3 to 7 units during preflight. Values in this manual are invented and must not be used for any operational purpose.

- The pilot monitoring will monitor any change in the Traffic Advisory Display status message and advise the other pilot once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The first officer will monitor any change in the Fire Detection Loop selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Landing Gear Indication switch position that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated.
- The captain will record any change in the Autopilot Channel A quantity display and advise the other pilot before the next phase of flight.

Challenge	Response
Autothrottle	As required
Cargo Smoke Detection	Checked
Probe Heat	Armed

Autopilot Channel B	Set
Stall Warning	Set
Window Heat	Set
Standby Instruments	On
Fire Detection Loop	Verified
Autobrake Selector	On
Brake Temperature Monitor	Verified
Window Heat	Set
Speedbrake Handle	Armed

03.30.11 Callouts: Weather Radar

The Bleed Air Supply advisory is expected to read within the sample range of 97 to 102 units during takeoff. The Primary Electrical Bus quantity display is expected to read within the sample range of 85 to 93 units during preflight. The pilot monitoring will verify any change in the Standby Hydraulic quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. During taxi, the pilot flying should record the Cabin Pressure Controller selector position before the next phase of flight. The pilot flying will select any change in the Cockpit Voice Recorder advisory and advise the other pilot when operating at a sample station without ground power. If the Autopilot Channel A is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The Cabin Pressure Controller indication is expected to read within the sample range of 32 to 38 units during preflight. Refer to the related topic for additional sample context. The Center Tank Pumps selector position that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center. If the Center Tank Pumps is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During a turnaround, the pilot monitoring should confirm the Standby Instruments advisory unless directed otherwise by the Sample Operations Center.

CAUTION: If the Engine Anti-Ice is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fire Detection Loop switch position	81 units	Advisory only
Oxygen Distribution status message	48 units	Monitor
Hydraulic System A quantity display	54 units	Refer to related topic
Auxiliary Power Unit status message	91 units	Normal
Standby Hydraulic switch position	30 units	Advisory only

Condition	Sample value	Remarks
Autopilot Channel B status message	53 units	Advisory only
Cabin Pressure Controller switch position	38 units	Normal
Center Tank Pumps annunciation	60 units	Refer to related topic
Landing Gear Indication quantity display	31 units	Advisory only

Condition	Sample value	Remarks
Transponder selector position	80 units	Advisory only
Primary Electrical Bus annunciation	26 units	Normal
Speedbrake Handle selector position	51 units	Advisory only

CAUTION: During preflight, the pilot flying should verify the Flap Position Indication selector position unless directed otherwise by the Sample Operations Center. The Standby Hydraulic annunciation that differs from the expected state requires the relief pilot to brief the condition when conditions permit.

- During a turnaround, the relief pilot should confirm the Autopilot Channel B annunciation unless directed otherwise by the Sample Operations Center.
- The captain will confirm any change in the Flap Position Indication annunciation and advise the other pilot when the associated caution light remains illuminated.
- During engine start, the pilot flying should select the Traffic Advisory Display quantity display if a discrepancy is observed.

03.30.12 Checklist: Hydraulic System A

The Stall Warning selector position that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed. During taxi, both pilots should verify the Bleed Air Supply annunciation if a discrepancy is observed. During climb, both pilots should select the Cockpit Voice Recorder advisory if a discrepancy is observed. The pilot flying will record any change in the Cargo Smoke Detection quantity display and advise the other pilot if a discrepancy is observed.

CAUTION: During engine start, the pilot flying should monitor the Autothrottle status message before the next phase of flight.

The Brake Temperature Monitor status message is expected to read within the sample range of 90 to 95 units during descent. During climb, the Captain should monitor the Ground Proximity Monitor advisory once the checklist item is complete. The Hydraulic System A status message that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. The first officer will record any change in the Traffic Advisory Display annunciation and advise the other pilot when conditions permit.

NOTE: The Cabin Pressure Controller switch position is expected to read within the sample range of 84 to 90 units during parking. The Fire Detection Loop selector position is expected to read within the sample range of 20 to 29 units during taxi.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

The Standby Instruments advisory is expected to read within the sample range of 96 to 107 units during takeoff. If the Standby Instruments is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Standby Instruments switch position that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight. During a turnaround, the relief pilot should cross-check the Nosewheel Steering switch position if the indication does not stabilize within the sample interval. If the Cabin Pressure Controller is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Bleed Air Supply indication	56 units	Normal
Flap Position Indication indication	57 units	Refer to related topic
Hydraulic System A status message	82 units	Monitor
Auxiliary Power Unit quantity display	62 units	Monitor
Speedbrake Handle indication	24 units	Advisory only
Standby Hydraulic selector position	80 units	Advisory only

The Primary Electrical Bus switch position is expected to read within the sample range of 13 to 17 units during approach. Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice

indication is expected to read within the sample range of 10 to 18 units during cruise. Values in this manual are invented and must not be used for any operational purpose. The Pack Temperature Control status message is expected to read within the sample range of 86 to 90 units during climb.

03.30.13 *Flow: Autothrottle*

The Engine Anti-Ice quantity display is expected to read within the sample range of 45 to 52 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B quantity display that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. The Autopilot Channel A indication that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated.

NOTE: The first officer will cross-check any change in the Autopilot Channel A switch position and advise the other pilot if a discrepancy is observed.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will monitor any change in the Traffic Advisory Display advisory and advise the other pilot once the checklist item is complete.

- The Pack Temperature Control switch position is expected to read within the sample range of 67 to 76 units during engine start.
- If the Flight Management Computer is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The Probe Heat switch position that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval.
- The Stall Warning indication that differs from the expected state requires both pilots to monitor the condition when conditions permit.
- During an extended ground delay, the First Officer should verify the Flap Position Indication advisory once the checklist item is complete.

During takeoff, the Captain should monitor the Ground Proximity Monitor indication when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. If the Window Heat is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

The pilot monitoring will select any change in the Primary Electrical Bus annunciation and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. Both pilots will select any change in the Cockpit Voice Recorder quantity display and advise the other pilot when operating at a sample station without ground power. If the Stall Warning is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

The Transponder quantity display that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed. The captain will record any change in the Window Heat status message and advise the other pilot if the indication does not stabilize within the sample interval. During takeoff, the relief pilot should brief the Flight Management Computer annunciation if a discrepancy is observed. Both pilots will cross-check any change in the Cabin Pressure Controller quantity display and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

- Refer to the related topic for additional sample context.
- If the Autopilot Channel B is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

- If the Speedbrake Handle is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.
- If the Cockpit Voice Recorder is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

The Wing Anti-Ice quantity display that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

03.30.14 Crew Coordination: Center Tank Pumps

The Autopilot Channel A advisory that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. The pilot flying will record any change in the Cargo Smoke Detection indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Weather Radar is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

The Standby Hydraulic indication is expected to read within the sample range of 35 to 44 units during climb. The Autothrottle advisory is expected to read within the sample range of 53 to 60 units during descent. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will verify any change in the Landing Gear Indication quantity display and advise the other pilot when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. The relief pilot will verify any change in the Nosewheel Steering quantity display and advise the other pilot when operating at a sample station without ground power. If the Fire Detection Loop is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The captain will announce any change in the Ground Proximity Monitor selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Transponder annunciation is expected to read within the sample range of 71 to 81 units during landing. The Oxygen Distribution selector position is expected to read within the sample range of 98 to 108 units during cruise. During parking, the pilot monitoring should announce the Ground Proximity Monitor selector position unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Landing Gear Indication status message is expected to read within the sample range of 56 to 59 units during descent. The wording here is placeholder content shaped like a procedure, not a procedure.

During preflight, both pilots should confirm the Traffic Advisory Display selector position when operating at a sample station without ground power. The Stall Warning annunciation that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power. During taxi, the First Officer should confirm the Hydraulic System A switch position before the next phase of flight. The Weather Radar indication is expected to read within the sample range of 13 to 25 units during a turnaround. The Nosewheel Steering quantity display is expected to read within the sample range of 32 to 35 units during descent.

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Engine Anti-Ice is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

CAUTION: During preflight, the relief pilot should cross-check the Probe Heat annunciation when conditions permit.

The Wing Anti-Ice selector position is expected to read within the sample range of 88 to 92 units during parking. The Autopilot Channel B status message that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder switch position is expected to read within the sample range of 45 to 54 units during a diversion. During landing, the Captain should select the Cockpit Voice Recorder annunciation unless directed otherwise by the Sample Operations Center.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

Challenge	Response
Traffic Advisory Display	Checked
Window Heat	Verified
Thrust Reverser	Checked
Ground Proximity Monitor	Set
Landing Gear Indication	On
Standby Instruments	Closed
Landing Gear Indication	On

03.30.15 Crew Coordination: Standby Instruments

The Autobrake Selector annunciation is expected to read within the sample range of 39 to 48 units during taxi. During a diversion, the First Officer should monitor the Flight Management Computer status message unless directed otherwise by the Sample Operations Center. During preflight, the Captain should record the Hydraulic System A annunciation once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Traffic Advisory Display is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Cargo Smoke Detection advisory that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power. If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During climb, the First Officer should cross-check the Nosewheel Steering annunciation unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. The Pack Temperature Control indication is expected to read within the sample range of 33 to 42 units during taxi. The Transponder advisory that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center. The Autothrottle switch position that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps annunciation that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval.

NOTE: The Speedbrake Handle annunciation is expected to read within the sample range of 76 to 87 units during engine start.

NOTE: The Ground Proximity Monitor status message that differs from the expected state requires both pilots to announce the condition before the next phase of flight.

The first officer will record any change in the Flight Management Computer quantity display and advise the other pilot once the checklist item is complete. The Brake Temperature Monitor advisory that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit. The pilot flying will confirm any change in the Cockpit Voice Recorder advisory and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will brief any change in the Autopilot Channel B annunciation and advise the other pilot if a discrepancy is observed. The Primary Electrical Bus quantity display that differs from the expected state requires the Captain to confirm the condition when conditions permit. See 02.10.9 General Limitation 9.

Challenge	Response
Autopilot Channel B	Closed
Traffic Advisory Display	On

Thrust Reverser	On
Weather Radar	Verified
Flight Management Computer	Armed
Transponder	Set
Thrust Reverser	Off
Flight Management Computer	As required

03.30.16 Crew Coordination: Traffic Advisory Display

The Cockpit Voice Recorder advisory that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed. During cruise, the pilot monitoring should monitor the Cargo Smoke Detection indication when operating at a sample station without ground power. The Pack Temperature Control indication that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated.

The captain will announce any change in the Hydraulic System A annunciation and advise the other pilot when operating at a sample station without ground power. The Landing Gear Indication advisory is expected to read within the sample range of 84 to 96 units during engine start. During takeoff, the Captain should select the Fire Detection Loop selector position if a discrepancy is observed.

CAUTION: The Autobrake Selector annunciation is expected to read within the sample range of 54 to 59 units during a turnaround.

Both pilots will confirm any change in the Fire Detection Loop advisory and advise the other pilot when conditions permit. The Landing Gear Indication advisory is expected to read within the sample range of 48 to 54 units during takeoff. The pilot monitoring will verify any change in the Engine Anti-Ice switch position and advise the other pilot if a discrepancy is observed. During a diversion, the First Officer should announce the Standby Instruments quantity display once the checklist item is complete. The Auxiliary Power Unit advisory that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval.

NOTE: The relief pilot will monitor any change in the Autopilot Channel B indication and advise the other pilot before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Cockpit Voice Recorder is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. During a maintenance-requested ground run, the Captain should select the Transponder quantity display before the next phase of flight.

03.40 Takeoff and Climb

03.40.1 Briefing: Wing Anti-Ice

If the Bleed Air Supply is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the pilot monitoring should verify the Flight Management Computer indication when conditions permit. The Cargo Smoke Detection selector position is expected to read within the sample range of 5 to 16 units during a turnaround.

The pilot flying will confirm any change in the Window Heat annunciation and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the relief pilot should announce the Center Tank Pumps switch position when the associated caution light remains illuminated. Both pilots will select any change in the Cargo Smoke Detection switch position and advise the other pilot when conditions permit.

- If the Traffic Advisory Display is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Fire Detection Loop is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- The pilot monitoring will confirm any change in the Hydraulic System B status message and advise the other pilot if a discrepancy is observed.
- The Traffic Advisory Display indication is expected to read within the sample range of 21 to 25 units during parking.

CAUTION: The Wing Anti-Ice indication that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power. The Standby Instruments indication is expected to read within the sample range of 89 to 101 units during approach.

The Primary Electrical Bus indication that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. If the Weather Radar is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will select any change in the Traffic Advisory Display annunciation and advise the other pilot when conditions permit. See 16.30.14 Flap Position Indication Power Sources.

Challenge	Response
Thrust Reverser	Set
Cargo Smoke Detection	Closed
Auxiliary Power Unit	Verified
Traffic Advisory Display	On
Standby Hydraulic	Off
Nosewheel Steering	Set

03.40.2 Callouts: Autopilot Channel A

If the Pack Temperature Control is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Speedbrake Handle selector position that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated. During cruise, the pilot monitoring should verify the Engine Anti-Ice switch position when the associated caution light remains illuminated.

Both pilots will record any change in the Cabin Pressure Controller selector position and advise the other pilot before the next phase of flight. The pilot monitoring will select any change in the Auxiliary Power Unit quantity display and advise the other pilot when operating at a sample station without ground power. The Autothrottle quantity display that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Landing Gear Indication status message	27 units	Monitor
Flight Management Computer quantity display	60 units	Monitor
Probe Heat status message	28 units	Monitor
Standby Hydraulic indication	53 units	Monitor
Bleed Air Supply status message	18 units	Normal

NOTE: If the Cargo Smoke Detection is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

The pilot monitoring will record any change in the Engine Anti-Ice indication and advise the other pilot before the next phase of flight. If the Hydraulic System B is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Cargo Smoke Detection indication that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center.

The Oxygen Distribution switch position is expected to read within the sample range of 55 to 63 units during taxi. The pilot flying will monitor any change in the Cockpit Voice Recorder quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Flight Management Computer selector position is expected to read within the sample range of 79 to 88 units during parking.

03.40.3 Briefing: Flap Position Indication

Refer to the related topic for additional sample context. The Pack Temperature Control annunciation is expected to read within the sample range of 34 to 45 units during takeoff. The Speedbrake Handle advisory that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The pilot flying will verify any change in the Cargo Smoke Detection status message and advise the other pilot when operating at a sample station without ground power. During landing, the pilot flying should cross-check the Ground Proximity Monitor indication if the indication does not stabilize within the sample interval.

CAUTION: During parking, the relief pilot should select the Cargo Smoke Detection advisory unless directed otherwise by the Sample Operations Center.

NOTE: The Flap Position Indication indication that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval.

If the Bleed Air Supply is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

Refer to the related topic for additional sample context. The captain will record any change in the Cabin Pressure Controller advisory and advise the other pilot when the associated caution light remains illuminated. The pilot flying will confirm any change in the Oxygen Distribution annunciation and advise the other pilot once the checklist item is complete.

NOTE: During climb, the pilot monitoring should monitor the Cockpit Voice Recorder status message when operating at a sample station without ground power.

The Autobrake Selector switch position is expected to read within the sample range of 60 to 65 units during parking. If the Speedbrake Handle is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During a turnaround, the Captain should announce the Cockpit Voice Recorder indication once the checklist item is complete.

If the Autobrake Selector is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The Traffic Advisory Display switch position that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. The Primary Electrical Bus quantity display is expected to read within the sample range of 25 to 36 units during cruise. The captain will verify any change in the Fire Detection Loop switch position and advise the other pilot when conditions permit.

Challenge	Response
Window Heat	Set
Hydraulic System A	Closed
Center Tank Pumps	Verified

Window Heat	Closed
Engine Anti-Ice	Off
Standby Instruments	Checked
Hydraulic System B	Armed
Fire Detection Loop	Off

03.40.4 Checklist: Weather Radar

The wording here is placeholder content shaped like a procedure, not a procedure. If the Landing Gear Indication is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Cabin Pressure Controller status message is expected to read within the sample range of 36 to 39 units during cruise. The pilot monitoring will verify any change in the Stall Warning quantity display and advise the other pilot when the associated caution light remains illuminated. The Speedbrake Handle indication is expected to read within the sample range of 45 to 55 units during cruise.

The Autothrottle indication is expected to read within the sample range of 86 to 94 units during preflight. Refer to the related topic for additional sample context. The Speedbrake Handle advisory is expected to read within the sample range of 40 to 49 units during takeoff. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will monitor any change in the Landing Gear Indication indication and advise the other pilot when conditions permit. The captain will cross-check any change in the Autobrake Selector indication and advise the other pilot when conditions permit.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System A advisory is expected to read within the sample range of 60 to 63 units during a diversion.

The Hydraulic System B status message that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete. During a diversion, the relief pilot should cross-check the Auxiliary Power Unit status message once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. If the Standby Instruments is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The Traffic Advisory Display indication that differs from the expected state requires the pilot flying to record the condition before the next phase of flight.

CAUTION: If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. During landing, the pilot flying should brief the Fire Detection Loop switch position when operating at a sample station without ground power.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Cargo Smoke Detection status message is expected to read within the sample range of 40 to 50 units during climb. Values in this manual are invented and must not be used for any operational purpose.

During parking, the First Officer should cross-check the Bleed Air Supply status message once the checklist item is complete. The Weather Radar status message that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. The Wing Anti-Ice advisory is expected to read within the sample range of 24 to 33 units during cruise. The Hydraulic System A advisory is expected to read within the sample range of 92 to 95 units during an extended ground delay. During landing, the relief pilot should verify the Window Heat indication unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

If the Cargo Smoke Detection is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will record any change in the Window Heat quantity display and advise the other pilot when operating at a sample station without ground power. If the Auxiliary Power Unit is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will record any change in the Hydraulic System A indication and advise the other pilot when the associated caution light remains illuminated. The Pack Temperature Control switch position is expected to read within the sample range of 95 to 102 units during taxi. If the Window Heat is inoperative, continue takeoff only after the Captain has reviewed

the associated sample guidance.

03.40.5 Briefing: Brake Temperature Monitor

If the Autobrake Selector is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Autopilot Channel B quantity display that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. The pilot flying will select any change in the Thrust Reverser quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will record any change in the Thrust Reverser selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

Both pilots will monitor any change in the Fire Detection Loop annunciation and advise the other pilot once the checklist item is complete. The Primary Electrical Bus advisory is expected to read within the sample range of 15 to 18 units during parking. The Traffic Advisory Display annunciation that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

- If the Engine Anti-Ice is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.
- During taxi, both pilots should brief the Window Heat switch position once the checklist item is complete.
- Refer to the related topic for additional sample context.
- The Auxiliary Power Unit switch position that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete.
- During climb, the pilot flying should monitor the Ground Proximity Monitor switch position before the next phase of flight.

Refer to the related topic for additional sample context. The pilot flying will monitor any change in the Hydraulic System A selector position and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will brief any change in the Ground Proximity Monitor indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Cargo Smoke Detection quantity display is expected to read within the sample range of 4 to 11 units during cruise. The captain will select any change in the Pack Temperature Control annunciation and advise the other pilot once the checklist item is complete. If the Traffic Advisory Display is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Fire Detection Loop switch position is expected to read within the sample range of 81 to 88 units during preflight.

If the Engine Anti-Ice is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Autopilot Channel B annunciation is expected to read within the sample range of 77 to 83 units during a turnaround. The Window Heat indication that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. During cruise, the pilot monitoring should confirm the Hydraulic System B indication once the checklist item is complete. The Traffic Advisory Display status message is expected to read within the sample range of 13 to 22 units during climb.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Stall Warning is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.
- The Fire Detection Loop quantity display that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.

- If the Speedbrake Handle is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

The pilot monitoring will confirm any change in the Hydraulic System B switch position and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Thrust Reverser indication is expected to read within the sample range of 51 to 62 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure.

03.40.6 Verification: Oxygen Distribution

If the Standby Hydraulic is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During a turnaround, the Captain should cross-check the Hydraulic System B selector position when operating at a sample station without ground power. If the Probe Heat is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

NOTE: During taxi, the pilot monitoring should brief the Traffic Advisory Display indication once the checklist item is complete.

The Flap Position Indication status message is expected to read within the sample range of 95 to 98 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution status message is expected to read within the sample range of 73 to 82 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. During parking, the pilot flying should confirm the Auxiliary Power Unit advisory unless directed otherwise by the Sample Operations Center.

Values in this manual are invented and must not be used for any operational purpose. The first officer will announce any change in the Cabin Pressure Controller quantity display and advise the other pilot before the next phase of flight. The Flap Position Indication annunciation is expected to read within the sample range of 93 to 100 units during taxi.

- During parking, both pilots should select the Brake Temperature Monitor indication once the checklist item is complete.
- During climb, both pilots should monitor the Oxygen Distribution indication when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.
- During takeoff, both pilots should announce the Traffic Advisory Display switch position when the associated caution light remains illuminated.
- If the Wing Anti-Ice is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- The Fuel Crossfeed status message is expected to read within the sample range of 5 to 9 units during engine start.

The Engine Anti-Ice indication that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. The Pack Temperature Control quantity display is expected to read within the sample range of 92 to 102 units during approach. During a maintenance-requested ground run, both pilots should record the Autobrake Selector status message unless directed otherwise by the Sample Operations Center. The Flight Management Computer annunciation is expected to read within the sample range of 3 to 13 units during engine start. The Fuel Crossfeed switch position that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval.

The Nosewheel Steering annunciation that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. Both pilots will monitor any change in the Ground Proximity Monitor indication and advise the other pilot once the checklist item is complete. The pilot monitoring will record any change in the Flap Position Indication indication and advise the other pilot if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The Weather Radar advisory is expected to read within the sample range of 23 to 34 units during a maintenance-requested ground run. The Ground Proximity Monitor annunciation is expected to read within the sample range of 3 to 14 units during descent. See 18.20.12 Flap Position Indication Overview.

Challenge	Response
Brake Temperature Monitor	Set
Thrust Reverser	Set
Ground Proximity Monitor	Armed
Cabin Pressure Controller	Off
Cockpit Voice Recorder	Closed
Primary Electrical Bus	As required
Ground Proximity Monitor	Checked
Hydraulic System B	Closed

03.40.7 Flow: Autopilot Channel B

Both pilots will select any change in the Fire Detection Loop advisory and advise the other pilot if the indication does not stabilize within the sample interval. If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will monitor any change in the Autothrottle status message and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. If the Fire Detection Loop is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

Both pilots will verify any change in the Cabin Pressure Controller indication and advise the other pilot when operating at a sample station without ground power. During takeoff, both pilots should monitor the Standby Instruments indication when operating at a sample station without ground power. The Oxygen Distribution annunciation is expected to read within the sample range of 52 to 60 units during preflight. The pilot flying will select any change in the Auxiliary Power Unit status message and advise the other pilot when the associated caution light remains illuminated.

- The Autopilot Channel A annunciation is expected to read within the sample range of 55 to 64 units during approach.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- If the Fuel Crossfeed is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.
- If the Brake Temperature Monitor is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- During takeoff, the relief pilot should confirm the Autopilot Channel B switch position before the next phase of flight.
- The Engine Anti-Ice advisory that differs from the expected state requires both pilots to monitor the condition before the next phase of flight.
- The Nosewheel Steering advisory is expected to read within the sample range of 60 to 70 units during a diversion.
- If the Ground Proximity Monitor is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

The Fire Detection Loop quantity display is expected to read within the sample range of 5 to 8 units during a maintenance-requested ground run. The Traffic Advisory Display annunciation is expected to read within the sample range of 31 to 42 units during approach. The captain will brief any change in the Hydraulic System B quantity display and advise the other pilot when operating at a sample station without ground power. The pilot monitoring will verify any change in the Cabin Pressure Controller advisory and advise the other pilot when operating at a sample station without ground power.

NOTE: If the Brake Temperature Monitor is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The Bleed Air Supply indication that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Cabin Pressure Controller selector position	49 units	Normal
Autopilot Channel A annunciation	26 units	Advisory only
Wing Anti-Ice indication	81 units	Normal

CAUTION: If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

During a turnaround, the Captain should select the Traffic Advisory Display switch position once the checklist item is complete. The Window Heat indication is expected to read within the sample range of 4 to 7 units during descent. The Primary Electrical Bus indication is expected to read within the sample range of 64 to 76 units during approach. The Oxygen Distribution advisory is expected to read within the sample range of 94 to 100 units during parking.

03.40.8 Briefing: Oxygen Distribution

If the Hydraulic System B is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, the First Officer should announce the Autothrottle advisory if the indication does not stabilize within the sample interval. The relief pilot will confirm any change in the Speedbrake Handle quantity display and advise the other pilot when conditions permit. The Bleed Air Supply switch position is expected to read within the sample range of 73 to 85 units during engine start. During climb, both pilots should announce the Window Heat annunciation unless directed otherwise by the Sample Operations Center.

During engine start, the relief pilot should announce the Speedbrake Handle advisory when operating at a sample station without ground power. If the Speedbrake Handle is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Center Tank Pumps indication that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight. During an extended ground delay, the relief pilot should verify the Window Heat switch position when operating at a sample station without ground power. The first officer will brief any change in the Auxiliary Power Unit advisory and advise the other pilot when conditions permit. The Landing Gear Indication selector position is expected to read within the sample range of 46 to 51 units during a diversion.

During landing, the First Officer should record the Weather Radar quantity display if the indication does not stabilize within the sample interval. The Primary Electrical Bus indication is expected to read within the sample range of 63 to 75 units during takeoff. If the Standby Instruments is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Pack Temperature Control switch position is expected to read within the sample range of 27 to 31 units during descent.

During climb, the pilot flying should brief the Cockpit Voice Recorder switch position when conditions permit. During parking, the pilot monitoring should confirm the Nosewheel Steering annunciation when conditions permit. The relief pilot will select any change in the Auxiliary Power Unit switch position and advise the other pilot when the associated caution light remains illuminated. The Autobrake Selector advisory that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Auxiliary Power Unit selector position	91 units	Refer to related topic
Autopilot Channel A switch position	79 units	Refer to related topic
Transponder indication	20 units	Advisory only
Autopilot Channel B quantity display	15 units	Normal

CAUTION: The Thrust Reverser indication is expected to read within the sample range of 55 to 61 units during descent. The Fire Detection Loop switch position is expected to read within the sample range of 43 to 53 units during taxi.

The Autothrottle annunciation that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

- The Fuel Crossfeed annunciation that differs from the expected state requires the relief pilot to select the condition when conditions permit.
- During a diversion, the relief pilot should monitor the Cockpit Voice Recorder switch position when conditions permit.
- During engine start, both pilots should record the Fire Detection Loop status message when the associated caution light remains illuminated.
- During approach, the relief pilot should brief the Speedbrake Handle selector position before the next phase of flight.
- During parking, both pilots should record the Thrust Reverser selector position when operating at a sample station without ground power.
- The Wing Anti-Ice indication that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center.

Both pilots will brief any change in the Nosewheel Steering switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Brake Temperature Monitor annunciation that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. The Autobrake Selector annunciation is expected to read within the sample range of 39 to 48 units during a diversion. The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Flight Management Computer	On
Fuel Crossfeed	On
Weather Radar	As required
Primary Electrical Bus	Verified
Hydraulic System B	Verified
Ground Proximity Monitor	Off
Oxygen Distribution	On
Wing Anti-Ice	Armed

03.40.9 Crew Coordination: Cabin Pressure Controller

If the Autopilot Channel A is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. During a turnaround, both pilots should confirm the Standby Hydraulic advisory unless directed

otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The captain will verify any change in the Primary Electrical Bus status message and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

The Hydraulic System B switch position is expected to read within the sample range of 48 to 54 units during a maintenance-requested ground run. The first officer will brief any change in the Standby Instruments quantity display and advise the other pilot before the next phase of flight. During descent, the pilot flying should select the Standby Hydraulic annunciation if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. If the Cabin Pressure Controller is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

CAUTION: If the Auxiliary Power Unit is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

CAUTION: If the Autopilot Channel B is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Window Heat annunciation	62 units	Monitor
Fire Detection Loop advisory	13 units	Normal
Flap Position Indication indication	45 units	Monitor
Pack Temperature Control annunciation	85 units	Normal
Landing Gear Indication status message	12 units	Normal
Weather Radar indication	19 units	Advisory only

- The Thrust Reverser advisory is expected to read within the sample range of 88 to 93 units during climb.
- The captain will announce any change in the Oxygen Distribution advisory and advise the other pilot when the associated caution light remains illuminated.
- During a diversion, the relief pilot should confirm the Autopilot Channel B indication when operating at a sample station without ground power.
- The Speedbrake Handle quantity display that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated.

Challenge	Response
Brake Temperature Monitor	As required
Probe Heat	Set
Standby Instruments	On
Probe Heat	Checked
Autopilot Channel B	Off
Transponder	Armed
Thrust Reverser	On

03.40.10 Flow: Window Heat

If the Window Heat is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. During takeoff, both pilots should brief the Cabin Pressure Controller status message before the next phase of flight. The Autopilot Channel B indication that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
-----------	--------------	---------

Transponder advisory	41 units	Advisory only
Speedbrake Handle status message	26 units	Advisory only
Cargo Smoke Detection selector position	92 units	Refer to related topic
Thrust Reverser selector position	82 units	Monitor
Fuel Crossfeed advisory	30 units	Monitor

The Hydraulic System A selector position that differs from the expected state requires the Captain to select the condition before the next phase of flight. The first officer will confirm any change in the Ground Proximity Monitor advisory and advise the other pilot when the associated caution light remains illuminated. The Cockpit Voice Recorder status message that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power. If the Cargo Smoke Detection is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Autothrottle advisory is expected to read within the sample range of 62 to 69 units during climb.

Condition	Sample value	Remarks
Center Tank Pumps status message	70 units	Normal
Auxiliary Power Unit advisory	15 units	Monitor
Flap Position Indication indication	15 units	Normal

Refer to the related topic for additional sample context. If the Autobrake Selector is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Fuel Crossfeed advisory that differs from the expected state requires the Captain to record the condition before the next phase of flight. The first officer will select any change in the Flap Position Indication advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

Challenge	Response
Cockpit Voice Recorder	Verified
Autopilot Channel A	On
Speedbrake Handle	Verified
Bleed Air Supply	As required
Cabin Pressure Controller	On
Engine Anti-Ice	As required
Landing Gear Indication	Set
Landing Gear Indication	Checked
Oxygen Distribution	Off
Cabin Pressure Controller	Set
Stall Warning	Verified
Weather Radar	On

03.40.11 Verification: Standby Instruments

If the Thrust Reverser is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. Both pilots will confirm any change in the Nosewheel Steering status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Fire Detection Loop annunciation that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.

Refer to the related topic for additional sample context. Both pilots will record any change in the Flight Management Computer indication and advise the other pilot when operating at a sample station without ground power. During cruise, the pilot monitoring should confirm the Engine Anti-Ice advisory once the checklist item is complete.

- The first officer will confirm any change in the Thrust Reverser selector position and advise the other pilot when conditions permit.
- The pilot flying will record any change in the Window Heat selector position and advise the other pilot when conditions permit.
- The Autobrake Selector advisory is expected to read within the sample range of 14 to 23 units during a turnaround.
- Refer to the related topic for additional sample context.
- The Landing Gear Indication annunciation that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center.

The Cargo Smoke Detection quantity display is expected to read within the sample range of 34 to 40 units during a maintenance-requested ground run. If the Center Tank Pumps is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Autopilot Channel B quantity display that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed.

If the Cockpit Voice Recorder is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Window Heat is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Center Tank Pumps advisory	56 units	Monitor
Wing Anti-Ice indication	54 units	Normal
Fire Detection Loop indication	74 units	Normal
Brake Temperature Monitor annunciation	66 units	Refer to related topic
Auxiliary Power Unit status message	55 units	Monitor
Wing Anti-Ice status message	77 units	Advisory only

- Values in this manual are invented and must not be used for any operational purpose.
- During an extended ground delay, the pilot flying should monitor the Primary Electrical Bus indication when the associated caution light remains illuminated.
- The Standby Instruments quantity display is expected to read within the sample range of 39 to 43 units during landing.
- If the Autobrake Selector is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

The Engine Anti-Ice status message that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit. During preflight, the pilot monitoring should select the Ground Proximity Monitor advisory before the next phase of flight. The Ground Proximity Monitor selector position that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated. The Stall Warning quantity display that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated.

03.40.12 *Callouts: Autopilot Channel B*

The captain will brief any change in the Hydraulic System A advisory and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The Autopilot Channel B switch position that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated. During an extended ground delay, the Captain should brief the Cockpit Voice Recorder quantity display if a discrepancy is observed. The Cargo Smoke Detection status message that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated.

The Thrust Reverser annunciation is expected to read within the sample range of 82 to 90 units during a turnaround. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System A advisory is expected to read within the sample range of 35 to 46 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice annunciation is expected to read within the sample range of 98 to 106 units during descent. If the Center Tank Pumps is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

- The Nosewheel Steering annunciation is expected to read within the sample range of 62 to 66 units during parking.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot flying will select any change in the Weather Radar indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Cargo Smoke Detection status message that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed.
- If the Stall Warning is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- During takeoff, both pilots should cross-check the Window Heat status message once the checklist item is complete.

CAUTION: The Cabin Pressure Controller status message is expected to read within the sample range of 71 to 83 units during an extended ground delay. During descent, the First Officer should verify the Engine Anti-Ice selector position before the next phase of flight.

During a maintenance-requested ground run, the First Officer should select the Autothrottle quantity display unless directed otherwise by the Sample Operations Center. The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The captain will monitor any change in the Transponder quantity display and advise the other pilot once the checklist item is complete.

- The Stall Warning quantity display is expected to read within the sample range of 12 to 22 units during descent.
- The Speedbrake Handle indication is expected to read within the sample range of 5 to 15 units during climb.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During descent, the relief pilot should cross-check the Transponder quantity display once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- Refer to the related topic for additional sample context.

03.40.13 *Checklist: Wing Anti-Ice*

The Brake Temperature Monitor quantity display that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval. During taxi, the Captain should confirm the

Thrust Reverser selector position unless directed otherwise by the Sample Operations Center. During approach, the relief pilot should record the Ground Proximity Monitor annunciation before the next phase of flight. Refer to the related topic for additional sample context.

CAUTION: During taxi, the Captain should select the Stall Warning selector position when operating at a sample station without ground power.

If the Fire Detection Loop is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Stall Warning annunciation that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. See 05.20.18 Pack Temperature Control Limits Display.

- The Hydraulic System B advisory that differs from the expected state requires both pilots to announce the condition before the next phase of flight.
- During a maintenance-requested ground run, the Captain should record the Oxygen Distribution advisory when the associated caution light remains illuminated.
- If the Primary Electrical Bus is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.
- The relief pilot will verify any change in the Hydraulic System B indication and advise the other pilot when conditions permit.
- The Ground Proximity Monitor selector position that differs from the expected state requires the First Officer to verify the condition when conditions permit.
- During approach, the pilot monitoring should monitor the Center Tank Pumps status message if a discrepancy is observed.

Condition	Sample value	Remarks
Ground Proximity Monitor switch position	34 units	Refer to related topic
Stall Warning selector position	27 units	Refer to related topic
Cargo Smoke Detection selector position	8 units	Advisory only
Nosewheel Steering quantity display	38 units	Normal
Hydraulic System A advisory	66 units	Refer to related topic
Standby Hydraulic advisory	23 units	Advisory only

CAUTION: During descent, the pilot flying should announce the Thrust Reverser quantity display if the indication does not stabilize within the sample interval. The Fire Detection Loop annunciation is expected to read within the sample range of 23 to 26 units during climb.

CAUTION: The Window Heat status message is expected to read within the sample range of 64 to 71 units during cruise. If the Primary Electrical Bus is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

03.40.14 Crew Coordination: Hydraulic System B

The Autopilot Channel B switch position that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. During a maintenance-requested ground run, the Captain should cross-check the Speedbrake Handle selector position when the associated caution light remains illuminated. If the Bleed Air Supply is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

The Fire Detection Loop selector position that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval. During climb, the Captain should select the Fuel Crossfeed advisory when the associated caution light remains illuminated. During takeoff, both pilots should cross-check the Cabin Pressure Controller selector position once the checklist item is complete. If the Window Heat is

inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The Landing Gear Indication switch position that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. The captain will cross-check any change in the Oxygen Distribution annunciation and advise the other pilot when operating at a sample station without ground power.

- The Oxygen Distribution selector position that differs from the expected state requires both pilots to monitor the condition before the next phase of flight.
- If the Pack Temperature Control is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.

The Cargo Smoke Detection switch position that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete. If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Fuel Crossfeed indication is expected to read within the sample range of 82 to 90 units during landing. The Autopilot Channel A status message that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. See 18.20.14 Cockpit Voice Recorder Test.

Condition	Sample value	Remarks
Transponder advisory	96 units	Refer to related topic
Fire Detection Loop selector position	72 units	Refer to related topic
Auxiliary Power Unit selector position	88 units	Refer to related topic
Cockpit Voice Recorder quantity display	43 units	Normal

03.40.15 Flow: Stall Warning

During taxi, the pilot monitoring should select the Cockpit Voice Recorder quantity display once the checklist item is complete. If the Probe Heat is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Fuel Crossfeed switch position that differs from the expected state requires the Captain to monitor the condition when conditions permit. The Flap Position Indication advisory that differs from the expected state requires the pilot flying to brief the condition when conditions permit. The Engine Anti-Ice quantity display is expected to read within the sample range of 32 to 35 units during descent. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

The Transponder annunciation that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. During an extended ground delay, the First Officer should verify the Pack Temperature Control indication before the next phase of flight. The Brake Temperature Monitor selector position is expected to read within the sample range of 83 to 86 units during preflight. If the Oxygen Distribution is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Cargo Smoke Detection switch position that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval. The captain will record any change in the Transponder switch position and advise the other pilot when operating at a sample station without ground power.

- During taxi, the pilot monitoring should monitor the Autothrottle indication when the associated caution light remains illuminated.

- During landing, the pilot flying should cross-check the Standby Hydraulic indication when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.
- The Transponder indication that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power.
- The Autopilot Channel B quantity display is expected to read within the sample range of 27 to 33 units during takeoff.
- The Stall Warning switch position is expected to read within the sample range of 13 to 20 units during cruise.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Engine Anti-Ice advisory that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Engine Anti-Ice switch position	41 units	Monitor
Wing Anti-Ice advisory	46 units	Advisory only
Speedbrake Handle indication	88 units	Normal
Stall Warning selector position	37 units	Advisory only
Center Tank Pumps status message	25 units	Normal
Center Tank Pumps selector position	22 units	Advisory only

Condition	Sample value	Remarks
Autopilot Channel B advisory	60 units	Monitor
Ground Proximity Monitor selector position	51 units	Advisory only
Cabin Pressure Controller switch position	56 units	Advisory only
Cockpit Voice Recorder status message	37 units	Refer to related topic

03.40.16 Verification: Window Heat

Values in this manual are invented and must not be used for any operational purpose. The Traffic Advisory Display selector position that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated. During preflight, the pilot flying should confirm the Traffic Advisory Display quantity display before the next phase of flight. The Standby Hydraulic selector position that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Stall Warning switch position	83 units	Monitor
Thrust Reverser quantity display	78 units	Normal
Engine Anti-Ice switch position	32 units	Normal
Fuel Crossfeed switch position	62 units	Normal
Fire Detection Loop advisory	56 units	Refer to related topic

CAUTION: The Auxiliary Power Unit quantity display that differs from the expected state requires both pilots to monitor the condition before the next phase of flight. The Hydraulic System A selector position is expected to read within the sample range of 62 to 70 units during approach.

During a turnaround, the Captain should verify the Landing Gear Indication quantity display when operating at a sample station without ground power. The Cargo Smoke Detection annunciation that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. During an extended ground delay, the pilot monitoring should record the Traffic Advisory Display annunciation if the indication does not stabilize within the sample interval. If the Oxygen Distribution is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autopilot Channel A status message	32 units	Advisory only
Flap Position Indication switch position	96 units	Normal
Standby Hydraulic quantity display	6 units	Normal
Speedbrake Handle switch position	26 units	Normal
Auxiliary Power Unit annunciation	84 units	Advisory only
Autobrake Selector selector position	55 units	Refer to related topic

NOTE: During a turnaround, the relief pilot should cross-check the Probe Heat status message if the indication does not stabilize within the sample interval.

If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Autopilot Channel B quantity display that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. The Autopilot Channel B annunciation that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. The Autopilot Channel A selector position is expected to read within the sample range of 88 to 91 units during climb. The first officer will select any change in the Stall Warning indication and advise the other pilot if the indication does not stabilize within the sample interval.

The Fire Detection Loop advisory that differs from the expected state requires both pilots to select the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The captain will brief any change in the Transponder switch position and advise the other pilot when conditions permit. During an extended ground delay, the pilot monitoring should record the Autopilot Channel A indication if the indication does not stabilize within the sample interval. The first officer will verify any change in the Window Heat annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The captain will brief any change in the Stall Warning quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

03.40.17 Briefing: Center Tank Pumps

If the Autopilot Channel A is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will monitor any change in the Weather Radar advisory and advise the other pilot when conditions permit. The Probe Heat quantity display that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. If the Standby Instruments is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

The captain will select any change in the Ground Proximity Monitor selector position and advise the other pilot when operating at a sample station without ground power. If the Nosewheel Steering is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. During descent, the Captain should announce the Autopilot Channel A status message when operating at a sample station without ground power. The relief pilot will confirm any change in the Thrust Reverser indication and advise the other pilot once the checklist item is complete.

The Thrust Reverser selector position is expected to read within the sample range of 85 to 94 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat status message is expected to read within the sample range of 56 to 64 units during preflight. The Nosewheel Steering status message that differs from the expected state requires both pilots to confirm the condition when conditions

permit.

- The Auxiliary Power Unit quantity display that differs from the expected state requires the First Officer to verify the condition when conditions permit.
- Both pilots will select any change in the Hydraulic System B status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The Hydraulic System B selector position that differs from the expected state requires the First Officer to select the condition once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. The first officer will record any change in the Center Tank Pumps quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. During cruise, the relief pilot should announce the Cockpit Voice Recorder status message when operating at a sample station without ground power. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

Both pilots will brief any change in the Autothrottle annunciation and advise the other pilot when conditions permit. The Standby Hydraulic annunciation that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. During a turnaround, the First Officer should brief the Hydraulic System B status message when operating at a sample station without ground power. The relief pilot will record any change in the Hydraulic System B advisory and advise the other pilot when operating at a sample station without ground power. If the Landing Gear Indication is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

The Engine Anti-Ice status message that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight. If the Transponder is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System B switch position is expected to read within the sample range of 19 to 26 units during landing. The Autothrottle advisory that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed. The Autopilot Channel A annunciation is expected to read within the sample range of 49 to 57 units during climb. The Autopilot Channel B advisory is expected to read within the sample range of 82 to 94 units during an extended ground delay.

03.40.18 Checklist: Bleed Air Supply

The Hydraulic System A status message that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. The relief pilot will verify any change in the Stall Warning selector position and advise the other pilot when operating at a sample station without ground power. If the Stall Warning is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Standby Instruments quantity display is expected to read within the sample range of 47 to 56 units during taxi.

The Hydraulic System B selector position that differs from the expected state requires the Captain to record the condition before the next phase of flight. The pilot monitoring will brief any change in the Stall Warning quantity display and advise the other pilot when operating at a sample station without ground power. The pilot monitoring will monitor any change in the Autothrottle indication and advise the other pilot before the next phase of flight. The Engine Anti-Ice status message that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. The relief pilot will verify any change in the Bleed Air Supply switch position and advise the other pilot when conditions permit.

During preflight, the pilot flying should confirm the Center Tank Pumps annunciation if the indication does not stabilize within the sample interval. During landing, the pilot monitoring should verify the Speedbrake Handle selector position if the indication does not stabilize within the sample interval. The Speedbrake Handle advisory is expected to read within the sample range of 42 to 49 units during a diversion. During taxi, the pilot monitoring should verify the Weather Radar quantity display if a discrepancy is observed. Refer to the related topic for additional sample context. During preflight, both pilots should monitor the Auxiliary Power Unit quantity display when conditions permit.

NOTE: The Wing Anti-Ice switch position that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.

The relief pilot will brief any change in the Window Heat switch position and advise the other pilot before the next phase of flight. The Flap Position Indication advisory is expected to read within the sample range of 16 to 24 units during descent. During landing, the relief pilot should monitor the Hydraulic System A switch position if a discrepancy is observed.

CAUTION: The pilot monitoring will confirm any change in the Autothrottle quantity display and advise the other pilot once the checklist item is complete. The Cockpit Voice Recorder advisory that differs from the expected state requires the First Officer to select the condition when conditions permit.

The Hydraulic System B switch position is expected to read within the sample range of 4 to 12 units during takeoff. Refer to the related topic for additional sample context. During parking, the pilot monitoring should monitor the Bleed Air Supply indication when operating at a sample station without ground power. If the Autothrottle is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

NOTE: The relief pilot will announce any change in the Transponder selector position and advise the other pilot if a discrepancy is observed. The first officer will select any change in the Primary Electrical Bus advisory and advise the other pilot if a discrepancy is observed.

NOTE: The pilot flying will cross-check any change in the Bleed Air Supply annunciation and advise the other pilot when operating at a sample station without ground power.

Challenge	Response
Primary Electrical Bus	Off
Thrust Reverser	Closed
Autopilot Channel A	On
Engine Anti-Ice	Armed
Bleed Air Supply	Checked
Landing Gear Indication	Off
Flight Management Computer	Set

03.40.19 Crew Coordination: Standby Instruments

The Primary Electrical Bus annunciation that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. If the Weather Radar is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Weather Radar advisory	36 units	Advisory only
Primary Electrical Bus advisory	80 units	Refer to related topic
Wing Anti-Ice switch position	43 units	Normal

The Fuel Crossfeed advisory is expected to read within the sample range of 7 to 15 units during landing. This text is fictional and exists only to give the prototype realistic volume and structure. The Flap Position Indication quantity display that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. The pilot flying will record any change in the Stall Warning indication and advise the other pilot once the checklist item is complete. The pilot monitoring will announce any change in the Engine Anti-Ice status message and advise the other pilot if the indication does not stabilize within the sample interval.

The Wing Anti-Ice indication that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. The captain will monitor any change in the Weather Radar selector position and advise the other pilot when operating at a sample station without ground power. If the Fire Detection Loop is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Auxiliary Power Unit annunciation that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight. If the Autopilot Channel B is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. If the Pack Temperature Control is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

- If the Bleed Air Supply is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- If the Autobrake Selector is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- If the Nosewheel Steering is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

The Hydraulic System A indication is expected to read within the sample range of 54 to 61 units during takeoff. During preflight, the pilot flying should cross-check the Window Heat switch position before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, both pilots should monitor the Cabin Pressure Controller switch position when conditions permit. During a maintenance-requested ground run, both pilots should select the Traffic Advisory Display indication before the next phase of flight.

Challenge	Response
Primary Electrical Bus	Verified
Transponder	Set
Brake Temperature Monitor	Off
Center Tank Pumps	Closed
Hydraulic System A	Verified
Thrust Reverser	Set
Weather Radar	Verified
Engine Anti-Ice	Closed

03.40.20 Checklist: Fire Detection Loop

The Ground Proximity Monitor indication is expected to read within the sample range of 66 to 70 units during taxi. If the Autopilot Channel B is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Traffic Advisory Display indication that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. If the Pack Temperature Control is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The captain will verify any change in the Transponder advisory and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Fuel Crossfeed selector position	41 units	Refer to related topic
Primary Electrical Bus selector position	65 units	Monitor
Autothrottle selector position	2 units	Refer to related topic

Landing Gear Indication indication	64 units	Monitor
Pack Temperature Control advisory	90 units	Advisory only

The pilot flying will select any change in the Cabin Pressure Controller annunciation and advise the other pilot before the next phase of flight. During preflight, the relief pilot should brief the Brake Temperature Monitor status message unless directed otherwise by the Sample Operations Center. The captain will select any change in the Autothrottle quantity display and advise the other pilot when conditions permit. During a turnaround, the Captain should cross-check the Speedbrake Handle annunciation when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. During descent, the pilot flying should monitor the Pack Temperature Control quantity display when operating at a sample station without ground power.

Challenge	Response
Autobrake Selector	Set
Fuel Crossfeed	As required
Autothrottle	Checked
Autothrottle	Verified
Engine Anti-Ice	Verified
Window Heat	Off
Probe Heat	As required
Fuel Crossfeed	As required
Landing Gear Indication	Off
Auxiliary Power Unit	Armed

03.50 Cruise

03.50.1 Briefing: Center Tank Pumps

This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat annunciation is expected to read within the sample range of 71 to 76 units during taxi. The Cockpit Voice Recorder annunciation that differs from the expected state requires the Captain to brief the condition before the next phase of flight. The Speedbrake Handle selector position that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight. The Primary Electrical Bus annunciation is expected to read within the sample range of 22 to 25 units during takeoff.

Condition	Sample value	Remarks
Autopilot Channel A switch position	93 units	Normal
Auxiliary Power Unit selector position	23 units	Normal
Standby Hydraulic quantity display	57 units	Monitor
Flap Position Indication status message	27 units	Monitor
Cockpit Voice Recorder indication	75 units	Advisory only
Fire Detection Loop status message	14 units	Advisory only

Condition	Sample value	Remarks
Oxygen Distribution switch position	65 units	Advisory only
Fuel Crossfeed status message	33 units	Advisory only

Traffic Advisory Display quantity display	78 units	Advisory only
---	----------	---------------

NOTE: The pilot flying will cross-check any change in the Traffic Advisory Display status message and advise the other pilot once the checklist item is complete. The Autopilot Channel A quantity display is expected to read within the sample range of 77 to 80 units during engine start. The Fire Detection Loop indication is expected to read within the sample range of 73 to 79 units during takeoff. The first officer will confirm any change in the Probe Heat selector position and advise the other pilot once the checklist item is complete. If the Fire Detection Loop is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Engine Anti-Ice quantity display that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center.

The pilot flying will select any change in the Cockpit Voice Recorder advisory and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. If the Landing Gear Indication is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

Challenge	Response
Thrust Reverser	As required
Hydraulic System B	Off
Autobrake Selector	Closed
Ground Proximity Monitor	Closed
Hydraulic System B	Verified
Pack Temperature Control	Verified

03.50.2 Checklist: Autopilot Channel A

The Speedbrake Handle selector position is expected to read within the sample range of 4 to 7 units during parking. The Stall Warning annunciation is expected to read within the sample range of 88 to 95 units during a maintenance-requested ground run. The pilot monitoring will announce any change in the Bleed Air Supply selector position and advise the other pilot once the checklist item is complete. Both pilots will verify any change in the Landing Gear Indication indication and advise the other pilot when conditions permit.

CAUTION: Both pilots will monitor any change in the Cabin Pressure Controller annunciation and advise the other pilot when conditions permit.

Both pilots will monitor any change in the Hydraulic System B indication and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. The Stall Warning switch position is expected to read within the sample range of 44 to 53 units during an extended ground delay.

- During landing, the pilot monitoring should select the Primary Electrical Bus selector position if a discrepancy is observed.
- The pilot monitoring will verify any change in the Pack Temperature Control quantity display and advise the other pilot once the checklist item is complete.
- The Primary Electrical Bus annunciation is expected to read within the sample range of 85 to 88 units during climb.

If the Primary Electrical Bus is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The pilot flying will announce any change in the Thrust Reverser indication and advise the other pilot when conditions permit. During preflight, the Captain should record the Autopilot Channel B switch position once the checklist item is complete. Refer to the related topic for additional sample context. If the Autobrake Selector is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

NOTE: During a diversion, the pilot monitoring should cross-check the Nosewheel Steering indication when conditions permit.

The pilot monitoring will confirm any change in the Hydraulic System A selector position and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The Transponder switch position is expected to read within the sample range of 12 to 22 units during taxi. The Cargo Smoke Detection switch position that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will brief any change in the Window Heat selector position and advise the other pilot once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. The captain will select any change in the Autobrake Selector status message and advise the other pilot if a discrepancy is observed. The captain will verify any change in the Thrust Reverser switch position and advise the other pilot if the indication does not stabilize within the sample interval. During cruise, both pilots should cross-check the Traffic Advisory Display selector position before the next phase of flight. The Autobrake Selector advisory is expected to read within the sample range of 28 to 31 units during preflight. Values in this manual are invented and must not be used for any operational purpose.

03.50.3 Flow: Landing Gear Indication

The Brake Temperature Monitor switch position that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. The Landing Gear Indication annunciation that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

During a maintenance-requested ground run, both pilots should verify the Hydraulic System B indication when the associated caution light remains illuminated. If the Auxiliary Power Unit is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, both pilots should confirm the Cabin Pressure Controller status message if the indication does not stabilize within the sample interval. The Autobrake Selector selector position is expected to read within the sample range of 79 to 88 units during takeoff.

CAUTION: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Center Tank Pumps annunciation	91 units	Refer to related topic
Autopilot Channel A selector position	67 units	Refer to related topic
Cargo Smoke Detection indication	72 units	Advisory only
Speedbrake Handle status message	71 units	Advisory only

NOTE: During approach, the Captain should brief the Probe Heat annunciation if the indication does not stabilize within the sample interval.

03.50.4 Verification: Speedbrake Handle

If the Autopilot Channel B is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Cargo Smoke Detection indication that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. If the Engine Anti-Ice is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Auxiliary Power Unit indication and advise the other pilot once the checklist item is complete. If the Engine Anti-Ice is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Thrust Reverser advisory that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated. The Ground Proximity Monitor indication that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Thrust Reverser status message	83 units	Advisory only
Hydraulic System A indication	35 units	Advisory only
Brake Temperature Monitor advisory	22 units	Advisory only

This text is fictional and exists only to give the prototype realistic volume and structure. The Autothrottle indication that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. During approach, both pilots should record the Standby Hydraulic annunciation when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The first officer will monitor any change in the Landing Gear Indication quantity display and advise the other pilot when conditions permit. During descent, both pilots should verify the Primary Electrical Bus selector position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Hydraulic System A switch position	7 units	Monitor
Cockpit Voice Recorder selector position	66 units	Refer to related topic
Flight Management Computer quantity display	47 units	Refer to related topic
Engine Anti-Ice selector position	65 units	Refer to related topic
Traffic Advisory Display selector position	89 units	Advisory only
Bleed Air Supply quantity display	40 units	Monitor
Transponder quantity display	53 units	Monitor

If the Traffic Advisory Display is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The captain will announce any change in the Center Tank Pumps indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autopilot Channel B annunciation that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight.

03.50.5 Checklist: Speedbrake Handle

The Fuel Crossfeed switch position is expected to read within the sample range of 84 to 88 units during engine start. During cruise, the Captain should select the Cargo Smoke Detection selector position once the checklist item is complete. The Center Tank Pumps annunciation that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete.

NOTE: The relief pilot will monitor any change in the Ground Proximity Monitor status message and advise the other pilot when conditions permit.

- The Hydraulic System A advisory that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete.
- The Fire Detection Loop indication is expected to read within the sample range of 41 to 50 units during cruise.
- During cruise, the relief pilot should cross-check the Speedbrake Handle quantity display unless directed otherwise by the Sample Operations Center.
- Refer to the related topic for additional sample context.

- The Traffic Advisory Display annunciation that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.

During landing, the pilot flying should announce the Pack Temperature Control switch position once the checklist item is complete. The Autopilot Channel A switch position is expected to read within the sample range of 6 to 9 units during preflight. If the Pack Temperature Control is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During landing, the Captain should record the Autopilot Channel A advisory when operating at a sample station without ground power. During a maintenance-requested ground run, the pilot flying should select the Standby Instruments quantity display when conditions permit.

NOTE: The Auxiliary Power Unit indication is expected to read within the sample range of 28 to 39 units during a diversion.

CAUTION: If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

NOTE: Both pilots will confirm any change in the Stall Warning status message and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Flight Management Computer	On
Window Heat	Set
Cockpit Voice Recorder	Set
Stall Warning	Armed
Auxiliary Power Unit	As required
Nosewheel Steering	Armed
Standby Instruments	Off

03.50.6 Verification: Autothrottle

The first officer will cross-check any change in the Stall Warning advisory and advise the other pilot before the next phase of flight. During cruise, the pilot flying should select the Brake Temperature Monitor status message before the next phase of flight. During a diversion, the First Officer should verify the Autopilot Channel A advisory if the indication does not stabilize within the sample interval. During engine start, the First Officer should monitor the Standby Hydraulic annunciation once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the pilot flying should verify the Hydraulic System B selector position if a discrepancy is observed.

CAUTION: During a maintenance-requested ground run, the pilot monitoring should record the Landing Gear Indication advisory if a discrepancy is observed.

- The Auxiliary Power Unit advisory that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.
- During taxi, the Captain should record the Cabin Pressure Controller advisory before the next phase of flight.
- The Landing Gear Indication quantity display that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated.
- The Autopilot Channel B status message is expected to read within the sample range of 43 to 46 units during an extended ground delay.

- If the Fire Detection Loop is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- The first officer will record any change in the Hydraulic System A annunciation and advise the other pilot once the checklist item is complete.
- During landing, the Captain should cross-check the Weather Radar annunciation before the next phase of flight.
- During preflight, the relief pilot should cross-check the Transponder advisory if the indication does not stabilize within the sample interval.
- If the Hydraulic System B is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: During a turnaround, the pilot monitoring should brief the Cabin Pressure Controller advisory if a discrepancy is observed.

Both pilots will select any change in the Traffic Advisory Display quantity display and advise the other pilot before the next phase of flight. The pilot monitoring will announce any change in the Fuel Crossfeed switch position and advise the other pilot if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

Challenge	Response
Oxygen Distribution	Armed
Autopilot Channel A	Set
Flight Management Computer	Armed
Brake Temperature Monitor	As required
Cargo Smoke Detection	Checked
Transponder	Verified
Cargo Smoke Detection	Off
Traffic Advisory Display	Checked

03.50.7 Crew Coordination: Center Tank Pumps

During cruise, the Captain should select the Hydraulic System B indication if a discrepancy is observed. The pilot flying will confirm any change in the Flight Management Computer indication and advise the other pilot unless directed otherwise by the Sample Operations Center. During a maintenance-requested ground run, the pilot monitoring should confirm the Flap Position Indication advisory if a discrepancy is observed. The pilot flying will record any change in the Auxiliary Power Unit switch position and advise the other pilot when conditions permit.

- If the Oxygen Distribution is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.
- During parking, the relief pilot should monitor the Standby Hydraulic switch position when the associated caution light remains illuminated.
- The Weather Radar annunciation that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval.
- If the Traffic Advisory Display is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

CAUTION: The pilot monitoring will confirm any change in the Autopilot Channel A switch position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Autopilot Channel B indication	65 units	Refer to related topic
Traffic Advisory Display advisory	43 units	Monitor
Standby Instruments switch position	19 units	Refer to related topic
Auxiliary Power Unit annunciation	46 units	Normal
Cargo Smoke Detection quantity display	72 units	Refer to related topic
Wing Anti-Ice status message	89 units	Normal
Center Tank Pumps indication	79 units	Advisory only

CAUTION: Values in this manual are invented and must not be used for any operational purpose. If the Center Tank Pumps is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cargo Smoke Detection quantity display	44 units	Monitor
Autopilot Channel A switch position	70 units	Normal
Speedbrake Handle advisory	75 units	Normal

The Autopilot Channel A indication that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. Refer to the related topic for additional sample context. The Probe Heat switch position that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight. The Wing Anti-Ice indication is expected to read within the sample range of 97 to 107 units during cruise.

During an extended ground delay, the Captain should verify the Landing Gear Indication selector position when conditions permit. The Wing Anti-Ice status message is expected to read within the sample range of 26 to 34 units during a diversion. The Window Heat indication that differs from the expected state requires both pilots to announce the condition when operating at a sample station without ground power. During parking, the Captain should monitor the Auxiliary Power Unit selector position before the next phase of flight. If the Weather Radar is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

Challenge	Response
Flap Position Indication	Off
Autopilot Channel A	Checked
Oxygen Distribution	Set
Probe Heat	On
Probe Heat	Set
Standby Instruments	Armed
Wing Anti-Ice	Checked
Speedbrake Handle	Armed
Traffic Advisory Display	Verified
Standby Instruments	Verified
Transponder	Off
Oxygen Distribution	Verified

03.50.8 Crew Coordination: Landing Gear Indication

The pilot monitoring will verify any change in the Flap Position Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autopilot Channel B is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Landing Gear Indication switch position	33 units	Refer to related topic
Wing Anti-Ice indication	28 units	Normal
Transponder quantity display	77 units	Monitor
Ground Proximity Monitor indication	75 units	Normal
Pack Temperature Control switch position	44 units	Normal
Traffic Advisory Display switch position	17 units	Advisory only
Hydraulic System A status message	25 units	Advisory only

The Weather Radar switch position that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder advisory that differs from the expected state requires the Captain to record the condition if a discrepancy is observed. If the Stall Warning is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Ground Proximity Monitor annunciation	95 units	Normal
Autopilot Channel A selector position	1 units	Refer to related topic
Nosewheel Steering quantity display	78 units	Monitor
Standby Hydraulic selector position	34 units	Refer to related topic
Flight Management Computer quantity display	27 units	Advisory only

NOTE: The Autopilot Channel A switch position is expected to read within the sample range of 26 to 30 units during preflight.

03.50.9 Checklist: Autopilot Channel B

Refer to the related topic for additional sample context. During preflight, the pilot monitoring should announce the Weather Radar selector position when the associated caution light remains illuminated. The pilot monitoring will brief any change in the Nosewheel Steering switch position and advise the other pilot when operating at a sample station without ground power. During landing, the Captain should brief the Standby Instruments switch position when the associated caution light remains illuminated. During approach, both pilots should cross-check the Brake Temperature Monitor selector position if the indication does not stabilize within the sample interval.

NOTE: During a turnaround, the pilot monitoring should confirm the Oxygen Distribution indication if the indication does not stabilize within the sample interval. If the Bleed Air Supply is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

The Landing Gear Indication quantity display is expected to read within the sample range of 88 to 93 units during a maintenance-requested ground run. The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle indication is expected to read within the sample range of 94 to 98 units during parking. If the Speedbrake Handle is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

During a maintenance-requested ground run, the First Officer should brief the Flight Management Computer advisory before the next phase of flight. The Engine Anti-Ice switch position that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power. The Probe Heat

selector position is expected to read within the sample range of 61 to 69 units during preflight.

CAUTION: If the Engine Anti-Ice is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

NOTE: The first officer will announce any change in the Bleed Air Supply advisory and advise the other pilot when operating at a sample station without ground power.

The Hydraulic System B indication is expected to read within the sample range of 39 to 43 units during a diversion. If the Stall Warning is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The captain will brief any change in the Weather Radar annunciation and advise the other pilot once the checklist item is complete. During taxi, the pilot monitoring should brief the Cockpit Voice Recorder advisory unless directed otherwise by the Sample Operations Center.

NOTE: During takeoff, the pilot flying should confirm the Autobrake Selector indication unless directed otherwise by the Sample Operations Center.

The Ground Proximity Monitor status message is expected to read within the sample range of 98 to 105 units during cruise. If the Primary Electrical Bus is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Pack Temperature Control selector position is expected to read within the sample range of 72 to 79 units during cruise. During a turnaround, the pilot monitoring should brief the Flight Management Computer advisory once the checklist item is complete. During an extended ground delay, the pilot monitoring should cross-check the Window Heat indication when the associated caution light remains illuminated.

03.50.10 Briefing: Landing Gear Indication

The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps advisory is expected to read within the sample range of 76 to 86 units during parking. The Traffic Advisory Display selector position that differs from the expected state requires the First Officer to cross-check the condition when operating at a sample station without ground power. If the Engine Anti-Ice is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will brief any change in the Center Tank Pumps selector position and advise the other pilot when conditions permit. If the Pack Temperature Control is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

During taxi, the Captain should brief the Fire Detection Loop switch position if a discrepancy is observed. If the Hydraulic System A is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During a diversion, the pilot monitoring should cross-check the Autothrottle advisory when conditions permit.

CAUTION: Both pilots will verify any change in the Traffic Advisory Display status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Traffic Advisory Display indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Nosewheel Steering advisory is expected to read within the sample range of 48 to 53 units during a diversion. The Fuel Crossfeed indication is expected to read within the sample range of 7 to 18 units during a diversion. The Hydraulic System B status message that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. The Standby Instruments status message is expected to read within the sample range of 40 to 50 units during takeoff. During parking, both pilots should monitor the Cabin Pressure Controller annunciation once the checklist item is complete.

During landing, the pilot monitoring should verify the Cabin Pressure Controller indication when operating at a sample station without ground power. The Autothrottle indication that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. See 09.30.14 Weather Radar Limits Display.

CAUTION: During a turnaround, both pilots should brief the Flight Management Computer status message when operating at a sample station without ground power. Refer to the related topic for additional sample context.

Challenge	Response
Center Tank Pumps	On
Hydraulic System A	Closed
Autopilot Channel B	On
Autobrake Selector	Set
Cabin Pressure Controller	Armed
Bleed Air Supply	Off
Cabin Pressure Controller	Checked
Fuel Crossfeed	Checked
Fire Detection Loop	Checked
Engine Anti-Ice	On
Window Heat	Closed

03.50.11 Verification: Autopilot Channel B

The Ground Proximity Monitor indication that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. The first officer will brief any change in the Cockpit Voice Recorder indication and advise the other pilot if a discrepancy is observed. During climb, both pilots should cross-check the Pack Temperature Control advisory once the checklist item is complete.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

- Values in this manual are invented and must not be used for any operational purpose.
- During cruise, the pilot monitoring should verify the Cargo Smoke Detection annunciation if a discrepancy is observed.
- The Autothrottle quantity display is expected to read within the sample range of 74 to 77 units during engine start.
- The first officer will record any change in the Cabin Pressure Controller quantity display and advise the other pilot when conditions permit.
- The Hydraulic System B indication that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Fuel Crossfeed quantity display	94 units	Advisory only
Probe Heat advisory	53 units	Monitor
Bleed Air Supply status message	21 units	Refer to related topic
Brake Temperature Monitor annunciation	40 units	Monitor

CAUTION: The Fire Detection Loop switch position is expected to read within the sample range of 66 to 78 units during an extended ground delay. Both pilots will brief any change in the Engine Anti-Ice indication and advise the other pilot if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. The Thrust Reverser selector position is expected to read within the sample range of 77 to 81 units during a diversion. The Standby Hydraulic switch position is expected to read within the sample range of 64 to 72 units during taxi. The Window Heat status message is expected to read within the sample range of 41 to 47 units during climb.

- The relief pilot will monitor any change in the Autothrottle status message and advise the other pilot when conditions permit.
- The Fire Detection Loop status message is expected to read within the sample range of 27 to 38 units during a diversion.
- If the Autopilot Channel B is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- If the Fuel Crossfeed is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- The pilot monitoring will confirm any change in the Center Tank Pumps annunciation and advise the other pilot before the next phase of flight.
- If the Fire Detection Loop is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

Challenge	Response
Autothrottle	Set
Probe Heat	Set
Thrust Reverser	Armed
Cockpit Voice Recorder	Off
Traffic Advisory Display	Checked
Hydraulic System B	Closed
Standby Hydraulic	Verified
Thrust Reverser	On
Primary Electrical Bus	Off

03.50.12 Checklist: Nosewheel Steering

During cruise, the First Officer should monitor the Flap Position Indication advisory before the next phase of flight. The Autobrake Selector status message is expected to read within the sample range of 47 to 52 units during landing. During approach, the First Officer should confirm the Pack Temperature Control quantity display when the associated caution light remains illuminated.

CAUTION: The Autobrake Selector switch position that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit. If the Speedbrake Handle is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle switch position that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center. During an extended ground delay, the relief pilot should brief the Hydraulic System A selector position if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

The Brake Temperature Monitor advisory that differs from the expected state requires both pilots to record the condition if a discrepancy is observed. The Speedbrake Handle selector position is expected to read within the sample range of 9 to 14 units during landing. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fuel Crossfeed selector position	95 units	Refer to related topic
Flight Management Computer selector position	85 units	Normal

Autothrottle switch position	72 units	Advisory only
Stall Warning indication	87 units	Refer to related topic
Window Heat indication	46 units	Monitor

CAUTION: The Flight Management Computer selector position is expected to read within the sample range of 89 to 97 units during engine start.

NOTE: If the Hydraulic System B is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

During a diversion, the pilot flying should announce the Fuel Crossfeed annunciation once the checklist item is complete. During climb, the relief pilot should monitor the Flight Management Computer selector position if a discrepancy is observed. The Probe Heat switch position that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.

The Stall Warning status message that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. If the Ground Proximity Monitor is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Cockpit Voice Recorder selector position is expected to read within the sample range of 61 to 67 units during cruise. During an extended ground delay, both pilots should cross-check the Fire Detection Loop switch position when conditions permit.

Challenge	Response
Traffic Advisory Display	Checked
Stall Warning	Set
Engine Anti-Ice	Set
Landing Gear Indication	Set
Engine Anti-Ice	As required
Fuel Crossfeed	Armed
Oxygen Distribution	Checked
Speedbrake Handle	Armed

03.50.13 Callouts: Brake Temperature Monitor

If the Traffic Advisory Display is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Stall Warning selector position that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power. The Primary Electrical Bus annunciation that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. The Cabin Pressure Controller annunciation that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed.

The Ground Proximity Monitor annunciation that differs from the expected state requires both pilots to record the condition once the checklist item is complete. The Fire Detection Loop quantity display that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated. The Standby Instruments annunciation is expected to read within the sample range of 68 to 77 units during approach. The first officer will verify any change in the Window Heat annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
-----------	--------------	---------

Ground Proximity Monitor indication	94 units	Monitor
Probe Heat quantity display	45 units	Refer to related topic
Stall Warning quantity display	43 units	Normal
Probe Heat indication	63 units	Advisory only
Weather Radar advisory	77 units	Normal
Ground Proximity Monitor status message	77 units	Monitor

The first officer will brief any change in the Flap Position Indication status message and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will brief any change in the Transponder status message and advise the other pilot when operating at a sample station without ground power. If the Speedbrake Handle is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

CAUTION: During an extended ground delay, both pilots should verify the Autothrottle indication before the next phase of flight.

NOTE: The Center Tank Pumps status message that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. The Transponder advisory is expected to read within the sample range of 92 to 104 units during cruise.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

03.50.14 Checklist: Autopilot Channel A

If the Speedbrake Handle is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will monitor any change in the Flight Management Computer selector position and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context.

During a diversion, the pilot monitoring should monitor the Oxygen Distribution annunciation when conditions permit. The Thrust Reverser selector position is expected to read within the sample range of 44 to 47 units during engine start. Refer to the related topic for additional sample context. The Stall Warning status message that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Engine Anti-Ice quantity display that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. During engine start, the First Officer should verify the Thrust Reverser status message when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will select any change in the Landing Gear Indication selector position and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: The Autothrottle status message that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power.

During a maintenance-requested ground run, the relief pilot should cross-check the Autothrottle switch position if a discrepancy is observed. If the Pack Temperature Control is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The Fuel Crossfeed indication that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. If the Cargo Smoke Detection is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. During descent, both pilots should monitor the Fuel Crossfeed indication unless directed otherwise by the Sample Operations Center.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

The pilot flying will brief any change in the Primary Electrical Bus advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During approach, the First Officer should record the Hydraulic System B indication unless directed otherwise by the Sample Operations Center. Both pilots will record any change in the Brake Temperature Monitor indication and advise the other pilot if the indication does not stabilize within the sample interval. The Brake Temperature Monitor advisory that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power. The pilot flying will cross-check any change in the Pack Temperature Control status message and advise the other pilot when conditions permit. The Nosewheel Steering switch position is expected to read within the sample range of 11 to 15 units during approach.

This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed quantity display that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. During approach, both pilots should record the Bleed Air Supply switch position unless directed otherwise by the Sample Operations Center.

- During a maintenance-requested ground run, the relief pilot should cross-check the Flap Position Indication annunciation if the indication does not stabilize within the sample interval.
- The Fire Detection Loop status message that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.
- The Cabin Pressure Controller selector position is expected to read within the sample range of 78 to 81 units during climb.

03.50.15 Flow: Autopilot Channel A

If the Cockpit Voice Recorder is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. Both pilots will monitor any change in the Wing Anti-Ice annunciation and advise the other pilot once the checklist item is complete. The pilot flying will verify any change in the Transponder selector position and advise the other pilot when conditions permit. If the Bleed Air Supply is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Probe Heat advisory is expected to read within the sample range of 42 to 50 units during a turnaround. The Autopilot Channel A indication that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will select any change in the Flight Management Computer switch position and advise the other pilot before the next phase of flight. The relief pilot will announce any change in the Hydraulic System A quantity display and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

- The pilot flying will confirm any change in the Stall Warning annunciation and advise the other pilot once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During engine start, both pilots should confirm the Thrust Reverser advisory once the checklist item is complete.
- The Autothrottle annunciation is expected to read within the sample range of 37 to 41 units during approach.
- Refer to the related topic for additional sample context.
- The Autothrottle annunciation is expected to read within the sample range of 56 to 60 units during cruise.

The Oxygen Distribution selector position that differs from the expected state requires the Captain to record the condition when conditions permit. The Flap Position Indication quantity display that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. The wording here is placeholder content

shaped like a procedure, not a procedure. During an extended ground delay, the Captain should confirm the Window Heat switch position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Hydraulic System B indication	98 units	Normal
Fire Detection Loop status message	39 units	Advisory only
Pack Temperature Control selector position	97 units	Refer to related topic

- During landing, the First Officer should select the Engine Anti-Ice indication if the indication does not stabilize within the sample interval.
- Both pilots will select any change in the Fire Detection Loop advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During an extended ground delay, both pilots should cross-check the Autopilot Channel A status message if the indication does not stabilize within the sample interval.
- If the Cargo Smoke Detection is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.
- The Bleed Air Supply advisory is expected to read within the sample range of 24 to 35 units during a maintenance-requested ground run.

Refer to the related topic for additional sample context. During a diversion, both pilots should brief the Bleed Air Supply annunciation if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Auxiliary Power Unit indication that differs from the expected state requires the Captain to verify the condition once the checklist item is complete. The Flap Position Indication quantity display is expected to read within the sample range of 17 to 24 units during cruise. The relief pilot will cross-check any change in the Bleed Air Supply status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

03.60 Descent and Approach

03.60.1 Briefing: Probe Heat

During descent, the Captain should brief the Nosewheel Steering selector position when the associated caution light remains illuminated. The Landing Gear Indication indication is expected to read within the sample range of 59 to 63 units during engine start. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will verify any change in the Center Tank Pumps status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

- Values in this manual are invented and must not be used for any operational purpose.
- The Pack Temperature Control status message is expected to read within the sample range of 63 to 66 units during a diversion.
- The Hydraulic System A status message that differs from the expected state requires the pilot flying to record the condition before the next phase of flight.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

The Hydraulic System A indication is expected to read within the sample range of 56 to 62 units during climb. If the Weather Radar is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will confirm any change in the Fuel Crossfeed annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The Standby Hydraulic selector position is expected to read within the sample range of 65 to 69 units during taxi. The Nosewheel Steering indication that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated.

NOTE: The Landing Gear Indication switch position that differs from the expected state requires both pilots to monitor the condition before the next phase of flight. During a diversion, the relief pilot should select the Brake Temperature Monitor selector position before the next phase of flight.

Challenge	Response
Ground Proximity Monitor	Off
Window Heat	Closed
Primary Electrical Bus	Off
Nosewheel Steering	Off
Bleed Air Supply	Verified
Flap Position Indication	Set
Probe Heat	On
Autothrottle	Closed
Hydraulic System A	Off
Standby Hydraulic	Verified
Engine Anti-Ice	On

03.60.2 Checklist: Nosewheel Steering

The Probe Heat switch position that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. The first officer will announce any change in the Pack Temperature Control indication and advise the other pilot when operating at a sample station without ground power. The Cockpit Voice Recorder selector position is expected to read within the sample range of 45 to 48 units during landing. The Wing Anti-Ice quantity display is expected to read within the sample range of 90 to 97 units during approach. The relief pilot will record any change in the Primary Electrical Bus indication and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Ground Proximity Monitor is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Ground Proximity Monitor status message that differs from the expected state requires the Captain to verify the condition once the checklist item is complete. Both pilots will record any change in the Weather Radar advisory and advise the other pilot when the associated caution light remains illuminated. The Fire Detection Loop selector position is expected to read within the sample range of 29 to 35 units during an extended ground delay.

Condition	Sample value	Remarks
Weather Radar advisory	37 units	Advisory only
Cockpit Voice Recorder annunciation	19 units	Advisory only
Primary Electrical Bus selector position	60 units	Refer to related topic

The captain will verify any change in the Wing Anti-Ice annunciation and advise the other pilot if a discrepancy is observed. If the Hydraulic System B is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

NOTE: Both pilots will monitor any change in the Nosewheel Steering selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Autothrottle is inoperative, continue takeoff

only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: If the Fire Detection Loop is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

The Auxiliary Power Unit quantity display that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. During descent, the relief pilot should select the Thrust Reverser indication when the associated caution light remains illuminated. The Auxiliary Power Unit annunciation is expected to read within the sample range of 59 to 67 units during an extended ground delay. The first officer will select any change in the Landing Gear Indication selector position and advise the other pilot when the associated caution light remains illuminated.

The Auxiliary Power Unit status message is expected to read within the sample range of 80 to 89 units during descent. During climb, the pilot monitoring should select the Ground Proximity Monitor selector position when conditions permit. The Flight Management Computer switch position that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete.

During takeoff, the pilot monitoring should brief the Ground Proximity Monitor annunciation when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will record any change in the Fire Detection Loop advisory and advise the other pilot when operating at a sample station without ground power. The Standby Instruments selector position that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Autopilot Channel B	On
Traffic Advisory Display	Closed
Ground Proximity Monitor	Off
Autopilot Channel A	Armed
Speedbrake Handle	As required
Engine Anti-Ice	On
Fuel Crossfeed	Armed
Weather Radar	On
Brake Temperature Monitor	Verified
Bleed Air Supply	On
Bleed Air Supply	On

03.60.3 Flow: Thrust Reverser

If the Fuel Crossfeed is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The Hydraulic System B annunciation is expected to read within the sample range of 48 to 57 units during approach. The Center Tank Pumps switch position that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Nosewheel Steering status message	27 units	Normal
Center Tank Pumps advisory	33 units	Monitor
Fire Detection Loop selector position	62 units	Advisory only

Cargo Smoke Detection indication	60 units	Advisory only
Thrust Reverser switch position	16 units	Monitor

CAUTION: If the Auxiliary Power Unit is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

- During a maintenance-requested ground run, the relief pilot should confirm the Speedbrake Handle indication when conditions permit.
- The Cabin Pressure Controller switch position that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete.
- The Cockpit Voice Recorder switch position is expected to read within the sample range of 7 to 14 units during takeoff.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

Both pilots will brief any change in the Pack Temperature Control switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Flight Management Computer switch position that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. The Oxygen Distribution status message that differs from the expected state requires the pilot flying to record the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. If the Standby Instruments is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Autopilot Channel B advisory that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.

Challenge	Response
Oxygen Distribution	On
Hydraulic System A	Closed
Window Heat	Checked
Traffic Advisory Display	On
Thrust Reverser	As required
Autopilot Channel A	As required
Nosewheel Steering	Checked

03.60.4 Callouts: Hydraulic System A

If the Autopilot Channel B is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Stall Warning is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. Both pilots will verify any change in the Autothrottle status message and advise the other pilot when operating at a sample station without ground power. The pilot flying will verify any change in the Transponder quantity display and advise the other pilot once the checklist item is complete.

The pilot flying will record any change in the Flap Position Indication indication and advise the other pilot when conditions permit. During climb, the relief pilot should record the Auxiliary Power Unit indication once the checklist item is complete. If the Standby Hydraulic is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

During cruise, both pilots should cross-check the Autothrottle selector position once the checklist item is complete. During preflight, the Captain should monitor the Flight Management Computer indication unless directed otherwise by

the Sample Operations Center. The Engine Anti-Ice selector position that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The pilot flying will confirm any change in the Center Tank Pumps quantity display and advise the other pilot if a discrepancy is observed. The Hydraulic System A quantity display is expected to read within the sample range of 4 to 9 units during approach.

NOTE: The Window Heat indication is expected to read within the sample range of 92 to 100 units during cruise. If the Probe Heat is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

During engine start, the Captain should select the Oxygen Distribution status message if the indication does not stabilize within the sample interval. The Brake Temperature Monitor switch position that differs from the expected state requires both pilots to confirm the condition when conditions permit. During a diversion, both pilots should select the Cabin Pressure Controller indication unless directed otherwise by the Sample Operations Center. If the Standby Hydraulic is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

NOTE: If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will select any change in the Autopilot Channel A advisory and advise the other pilot if the indication does not stabilize within the sample interval.

The Autopilot Channel A advisory is expected to read within the sample range of 41 to 49 units during descent. If the Engine Anti-Ice is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will select any change in the Fuel Crossfeed selector position and advise the other pilot before the next phase of flight. The Window Heat switch position is expected to read within the sample range of 82 to 86 units during engine start. The Nosewheel Steering switch position is expected to read within the sample range of 56 to 67 units during takeoff.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure.

03.60.5 Callouts: Bleed Air Supply

During a maintenance-requested ground run, the Captain should brief the Transponder advisory if the indication does not stabilize within the sample interval. The Transponder advisory that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. During cruise, the Captain should announce the Cabin Pressure Controller status message unless directed otherwise by the Sample Operations Center.

The pilot monitoring will monitor any change in the Autopilot Channel A status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flight Management Computer switch position that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. The Traffic Advisory Display quantity display is expected to read within the sample range of 2 to 6 units during approach. The Oxygen Distribution selector position is expected to read within the sample range of 77 to 82 units during a turnaround.

- During preflight, the pilot flying should brief the Cabin Pressure Controller annunciation unless directed otherwise by the Sample Operations Center.
- If the Ground Proximity Monitor is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- If the Fire Detection Loop is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

- The Autobrake Selector advisory is expected to read within the sample range of 67 to 70 units during a maintenance-requested ground run.
- The first officer will confirm any change in the Hydraulic System A indication and advise the other pilot when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: If the Autothrottle is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

During a diversion, the Captain should cross-check the Brake Temperature Monitor quantity display if a discrepancy is observed. The relief pilot will verify any change in the Transponder annunciation and advise the other pilot before the next phase of flight. If the Stall Warning is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Cargo Smoke Detection indication is expected to read within the sample range of 58 to 62 units during landing. The Ground Proximity Monitor status message that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center.

The Flap Position Indication annunciation is expected to read within the sample range of 90 to 101 units during cruise. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The Auxiliary Power Unit indication is expected to read within the sample range of 77 to 83 units during preflight. This text is fictional and exists only to give the prototype realistic volume and structure. The Thrust Reverser quantity display that differs from the expected state requires the Captain to record the condition if a discrepancy is observed.

If the Autopilot Channel A is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. Both pilots will confirm any change in the Landing Gear Indication switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Flap Position Indication advisory that differs from the expected state requires both pilots to select the condition once the checklist item is complete. The first officer will brief any change in the Wing Anti-Ice quantity display and advise the other pilot once the checklist item is complete. The Flap Position Indication annunciation is expected to read within the sample range of 95 to 98 units during a maintenance-requested ground run.

NOTE: The Stall Warning switch position is expected to read within the sample range of 57 to 66 units during approach. The Hydraulic System B status message is expected to read within the sample range of 76 to 81 units during approach.

The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, the Captain should confirm the Autothrottle advisory unless directed otherwise by the Sample Operations Center. The Oxygen Distribution selector position is expected to read within the sample range of 3 to 10 units during parking. During takeoff, the pilot monitoring should cross-check the Nosewheel Steering status message if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

03.60.6 Briefing: Fire Detection Loop

During approach, the First Officer should select the Auxiliary Power Unit annunciation before the next phase of flight. During takeoff, the relief pilot should brief the Thrust Reverser status message if a discrepancy is observed. If the Cockpit Voice Recorder is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Hydraulic System A annunciation that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center. The relief pilot will select any change in the Bleed Air Supply annunciation and advise the other pilot if a discrepancy is observed. If the Speedbrake Handle is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

If the Weather Radar is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will cross-check any change in the Nosewheel Steering advisory and advise the other

pilot when operating at a sample station without ground power. The relief pilot will record any change in the Hydraulic System B switch position and advise the other pilot when operating at a sample station without ground power. The Cargo Smoke Detection annunciation is expected to read within the sample range of 23 to 34 units during climb. During climb, the Captain should monitor the Landing Gear Indication selector position unless directed otherwise by the Sample Operations Center. During preflight, the Captain should record the Primary Electrical Bus annunciation before the next phase of flight.

NOTE: During engine start, the pilot flying should brief the Engine Anti-Ice quantity display before the next phase of flight.

During preflight, the pilot flying should verify the Weather Radar quantity display if a discrepancy is observed. The Engine Anti-Ice quantity display that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center. The captain will announce any change in the Primary Electrical Bus indication and advise the other pilot when the associated caution light remains illuminated. The Fuel Crossfeed advisory is expected to read within the sample range of 50 to 53 units during parking.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- Both pilots will verify any change in the Weather Radar annunciation and advise the other pilot when operating at a sample station without ground power.
- Refer to the related topic for additional sample context.
- The relief pilot will verify any change in the Hydraulic System B annunciation and advise the other pilot before the next phase of flight.
- Both pilots will announce any change in the Standby Hydraulic annunciation and advise the other pilot once the checklist item is complete.
- If the Traffic Advisory Display is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

During preflight, the First Officer should confirm the Hydraulic System B quantity display when operating at a sample station without ground power. If the Nosewheel Steering is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Hydraulic System A status message that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated.

NOTE: The pilot flying will cross-check any change in the Window Heat switch position and advise the other pilot if the indication does not stabilize within the sample interval. If the Fire Detection Loop is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

The Hydraulic System B advisory that differs from the expected state requires the pilot monitoring to record the condition when conditions permit. The Cabin Pressure Controller advisory that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. If the Landing Gear Indication is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The captain will confirm any change in the Window Heat indication and advise the other pilot when operating at a sample station without ground power. The Auxiliary Power Unit advisory that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval. Both pilots will confirm any change in the Oxygen Distribution switch position and advise the other pilot when conditions permit.

CAUTION: The Flight Management Computer switch position that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center. During takeoff, both pilots should monitor the Transponder indication unless directed otherwise by the Sample Operations Center.

03.60.7 Verification: Center Tank Pumps

If the Auxiliary Power Unit is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Nosewheel Steering quantity display is expected to read within the sample range of 27 to 35 units during parking. During climb, the First Officer should select the Weather Radar status message unless directed otherwise by the Sample Operations Center.

NOTE: During parking, the First Officer should announce the Hydraulic System B advisory once the checklist item is complete. If the Engine Anti-Ice is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

CAUTION: Both pilots will confirm any change in the Engine Anti-Ice selector position and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The pilot monitoring will verify any change in the Autothrottle selector position and advise the other pilot when operating at a sample station without ground power. The Brake Temperature Monitor selector position that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.

During cruise, the pilot flying should cross-check the Autopilot Channel B annunciation when conditions permit. During approach, the relief pilot should record the Flight Management Computer advisory when conditions permit. The Autobrake Selector switch position is expected to read within the sample range of 44 to 56 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose.

Challenge	Response
Center Tank Pumps	Closed
Bleed Air Supply	As required
Nosewheel Steering	As required
Cockpit Voice Recorder	On
Window Heat	Armed
Hydraulic System B	Off
Speedbrake Handle	Checked
Weather Radar	Set
Stall Warning	Off

03.60.8 Briefing: Engine Anti-Ice

The Hydraulic System B indication is expected to read within the sample range of 34 to 43 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will brief any change in the Fire Detection Loop indication and advise the other pilot when operating at a sample station without ground power.

NOTE: The Autothrottle selector position that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.

During an extended ground delay, the pilot monitoring should monitor the Oxygen Distribution annunciation once the checklist item is complete. The captain will confirm any change in the Cockpit Voice Recorder selector position and advise the other pilot when operating at a sample station without ground power. If the Standby Hydraulic is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The relief pilot will verify any change in the Oxygen Distribution quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. If the Traffic Advisory Display is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The captain will cross-check any change in the Probe Heat switch position and advise the other pilot when operating at a sample station without ground power. The Hydraulic System A advisory that differs from the expected state requires the pilot

monitoring to monitor the condition unless directed otherwise by the Sample Operations Center.

CAUTION: The Autopilot Channel B indication that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. If the Flap Position Indication is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. The pilot monitoring will cross-check any change in the Flight Management Computer indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Center Tank Pumps advisory that differs from the expected state requires the pilot flying to brief the condition when conditions permit. If the Auxiliary Power Unit is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Brake Temperature Monitor indication that differs from the expected state requires the First Officer to verify the condition when conditions permit. If the Fire Detection Loop is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

Challenge	Response
Center Tank Pumps	Closed
Fire Detection Loop	On
Weather Radar	On
Landing Gear Indication	Verified
Traffic Advisory Display	Verified
Cargo Smoke Detection	Verified
Primary Electrical Bus	As required

03.60.9 Checklist: Cargo Smoke Detection

During parking, the relief pilot should monitor the Flight Management Computer advisory when operating at a sample station without ground power. The Cockpit Voice Recorder indication that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. The Hydraulic System A quantity display that differs from the expected state requires the Captain to monitor the condition when conditions permit. If the Landing Gear Indication is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will record any change in the Flight Management Computer quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

The pilot monitoring will monitor any change in the Oxygen Distribution switch position and advise the other pilot before the next phase of flight. During engine start, both pilots should verify the Nosewheel Steering status message when the associated caution light remains illuminated. If the Bleed Air Supply is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The relief pilot will select any change in the Window Heat annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Thrust Reverser is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

During cruise, the First Officer should monitor the Ground Proximity Monitor advisory once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Thrust Reverser advisory is expected to read within the sample range of 28 to 40 units during climb. The Weather Radar annunciation that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power. The Autopilot Channel A switch position is expected to read within the sample range of 32 to 41 units during engine start.

NOTE: The Cabin Pressure Controller selector position that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed. The captain will record any change in the Center

Tank Pumps advisory and advise the other pilot if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure.

The pilot monitoring will select any change in the Nosewheel Steering selector position and advise the other pilot when operating at a sample station without ground power. The Weather Radar advisory is expected to read within the sample range of 87 to 98 units during taxi. During descent, the pilot flying should record the Ground Proximity Monitor advisory unless directed otherwise by the Sample Operations Center. If the Standby Instruments is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Auxiliary Power Unit switch position is expected to read within the sample range of 68 to 76 units during takeoff.
- During climb, the First Officer should confirm the Fire Detection Loop selector position when conditions permit.
- The Flight Management Computer selector position that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power.

If the Thrust Reverser is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Stall Warning selector position is expected to read within the sample range of 49 to 52 units during landing. Refer to the related topic for additional sample context. See 13.40.14 Fuel Crossfeed Status Messages.

Challenge	Response
Standby Hydraulic	On
Brake Temperature Monitor	Checked
Engine Anti-Ice	On
Ground Proximity Monitor	Armed
Autothrottle	Off
Hydraulic System B	Armed

03.60.10 Checklist: Cabin Pressure Controller

If the Ground Proximity Monitor is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot flying should monitor the Fire Detection Loop quantity display unless directed otherwise by the Sample Operations Center. The Brake Temperature Monitor indication that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center. During an extended ground delay, both pilots should monitor the Standby Instruments indication unless directed otherwise by the Sample Operations Center.

NOTE: During taxi, both pilots should cross-check the Hydraulic System B annunciation before the next phase of flight. During descent, the relief pilot should cross-check the Engine Anti-Ice indication when conditions permit.

NOTE: The Primary Electrical Bus annunciation that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed.

If the Speedbrake Handle is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Fuel Crossfeed status message is expected to read within the sample range of 27 to 30 units during an extended ground delay. During a diversion, the First Officer should announce the Bleed Air Supply indication when the associated caution light remains illuminated.

- The captain will select any change in the Flight Management Computer switch position and advise the other pilot once the checklist item is complete.
- The Hydraulic System A indication is expected to read within the sample range of 24 to 28 units during a diversion.
- Both pilots will brief any change in the Stall Warning selector position and advise the other pilot before the next phase of flight.
- The first officer will select any change in the Oxygen Distribution indication and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- The Standby Instruments switch position is expected to read within the sample range of 75 to 87 units during engine start.

Condition	Sample value	Remarks
Oxygen Distribution selector position	8 units	Refer to related topic
Cargo Smoke Detection selector position	74 units	Advisory only
Traffic Advisory Display annunciation	50 units	Advisory only

Values in this manual are invented and must not be used for any operational purpose. The first officer will monitor any change in the Fire Detection Loop advisory and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The first officer will cross-check any change in the Probe Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval.

Challenge	Response
Hydraulic System A	Off
Traffic Advisory Display	Off
Bleed Air Supply	Armed
Flight Management Computer	Off
Brake Temperature Monitor	On
Bleed Air Supply	On
Bleed Air Supply	Closed
Hydraulic System B	Off
Autobrake Selector	Armed
Fire Detection Loop	Verified

03.60.11 Checklist: Probe Heat

Both pilots will verify any change in the Engine Anti-Ice status message and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Center Tank Pumps is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Autopilot Channel B status message is expected to read within the sample range of 28 to 35 units during preflight.

- If the Flight Management Computer is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

- During a turnaround, the First Officer should announce the Ground Proximity Monitor status message unless directed otherwise by the Sample Operations Center.
- During takeoff, the relief pilot should confirm the Autobrake Selector status message if the indication does not stabilize within the sample interval.

During landing, the pilot monitoring should confirm the Bleed Air Supply advisory when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 81 to 85 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure. The Autopilot Channel A advisory that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval.

The Hydraulic System A indication is expected to read within the sample range of 63 to 70 units during climb. The Center Tank Pumps advisory that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

NOTE: The Thrust Reverser quantity display is expected to read within the sample range of 41 to 53 units during preflight.

During landing, the relief pilot should select the Hydraulic System A annunciation when the associated caution light remains illuminated. The relief pilot will monitor any change in the Landing Gear Indication switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The Cabin Pressure Controller status message is expected to read within the sample range of 72 to 82 units during a diversion.

Challenge	Response
Center Tank Pumps	As required
Auxiliary Power Unit	Set
Probe Heat	Closed
Autopilot Channel A	As required
Oxygen Distribution	As required
Brake Temperature Monitor	As required
Cabin Pressure Controller	Checked
Speedbrake Handle	Armed
Standby Instruments	Armed
Oxygen Distribution	Set
Fuel Crossfeed	Armed
Oxygen Distribution	Set

03.60.12 Crew Coordination: Cargo Smoke Detection

The Transponder status message that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. The Traffic Advisory Display advisory is expected to read within the sample range of 34 to 45 units during cruise. If the Center Tank Pumps is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

During preflight, the relief pilot should cross-check the Hydraulic System A annunciation when conditions permit. If the Stall Warning is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Weather Radar annunciation that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. The pilot flying will announce any change in the Wing Anti-Ice annunciation and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication indication is expected to read

within the sample range of 5 to 11 units during preflight.

- The Primary Electrical Bus switch position that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated.
- If the Pack Temperature Control is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.
- During parking, the pilot monitoring should confirm the Bleed Air Supply switch position before the next phase of flight.
- The Speedbrake Handle indication is expected to read within the sample range of 74 to 82 units during a turnaround.
- The Autopilot Channel B quantity display that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated.
- The Flight Management Computer advisory is expected to read within the sample range of 93 to 102 units during a turnaround.
- The Probe Heat advisory that differs from the expected state requires the pilot flying to select the condition when conditions permit.
- The Bleed Air Supply quantity display that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed.
- The relief pilot will confirm any change in the Auxiliary Power Unit status message and advise the other pilot once the checklist item is complete.
- The Autopilot Channel B indication is expected to read within the sample range of 76 to 83 units during an extended ground delay.
- The Flight Management Computer indication that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.
- The Autopilot Channel B advisory that differs from the expected state requires the Captain to select the condition if a discrepancy is observed.

If the Speedbrake Handle is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Standby Instruments quantity display that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight. Both pilots will record any change in the Ground Proximity Monitor annunciation and advise the other pilot once the checklist item is complete. If the Landing Gear Indication is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. During climb, the pilot monitoring should brief the Standby Hydraulic switch position when operating at a sample station without ground power. During approach, the pilot monitoring should select the Standby Hydraulic indication when conditions permit.

- The relief pilot will record any change in the Probe Heat advisory and advise the other pilot before the next phase of flight.
- If the Fuel Crossfeed is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.
- The first officer will brief any change in the Ground Proximity Monitor quantity display and advise the other pilot before the next phase of flight.
- The first officer will record any change in the Auxiliary Power Unit selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- During a turnaround, the Captain should cross-check the Window Heat advisory if the indication does not stabilize within the sample interval.

- The Auxiliary Power Unit indication that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power.
- The first officer will record any change in the Cabin Pressure Controller indication and advise the other pilot when operating at a sample station without ground power.
- The pilot monitoring will confirm any change in the Autothrottle switch position and advise the other pilot when conditions permit.
- The Primary Electrical Bus status message is expected to read within the sample range of 7 to 15 units during a diversion.

Challenge	Response
Fuel Crossfeed	Set
Fuel Crossfeed	Off
Bleed Air Supply	On
Hydraulic System B	Armed
Probe Heat	As required
Stall Warning	Checked
Transponder	On
Cabin Pressure Controller	Armed
Autothrottle	Set
Wing Anti-Ice	Checked
Cabin Pressure Controller	As required
Standby Instruments	Verified

03.60.13 Crew Coordination: Transponder

The wording here is placeholder content shaped like a procedure, not a procedure. The captain will verify any change in the Oxygen Distribution indication and advise the other pilot before the next phase of flight. The Transponder indication that differs from the expected state requires both pilots to verify the condition when conditions permit.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a diversion, both pilots should announce the Landing Gear Indication advisory when conditions permit.
- During descent, the pilot monitoring should select the Bleed Air Supply selector position when operating at a sample station without ground power.
- During preflight, the Captain should cross-check the Thrust Reverser quantity display when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Window Heat indication	54 units	Advisory only
Oxygen Distribution quantity display	52 units	Refer to related topic
Cabin Pressure Controller quantity display	10 units	Normal
Flight Management Computer advisory	56 units	Advisory only
Standby Hydraulic annunciation	22 units	Monitor
Traffic Advisory Display quantity display	83 units	Monitor

- During landing, the pilot monitoring should cross-check the Flight Management Computer advisory if a discrepancy is observed.

- During takeoff, the First Officer should announce the Weather Radar advisory when conditions permit.
- The Autobrake Selector quantity display that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated.
- The pilot flying will verify any change in the Cargo Smoke Detection quantity display and advise the other pilot once the checklist item is complete.
- If the Hydraulic System A is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.
- If the Autothrottle is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Instruments annunciation	38 units	Advisory only
Brake Temperature Monitor selector position	40 units	Monitor
Transponder quantity display	72 units	Advisory only

- Values in this manual are invented and must not be used for any operational purpose.
- The Autopilot Channel B status message is expected to read within the sample range of 50 to 53 units during takeoff.
- The first officer will monitor any change in the Window Heat quantity display and advise the other pilot when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- The Wing Anti-Ice quantity display that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power.
- If the Probe Heat is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

Challenge	Response
Autopilot Channel A	Verified
Engine Anti-Ice	On
Transponder	Checked
Speedbrake Handle	Verified
Standby Hydraulic	On
Transponder	Off
Bleed Air Supply	On
Bleed Air Supply	Armed
Flight Management Computer	As required
Auxiliary Power Unit	Off
Probe Heat	Off
Stall Warning	Closed

03.60.14 Briefing: Bleed Air Supply

The Weather Radar annunciation that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice quantity display is expected to read within the sample range of 6 to 9 units during preflight. If the Flap Position Indication is inoperative, continue

taxi only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. If the Brake Temperature Monitor is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The Stall Warning annunciation that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Thrust Reverser indication	67 units	Advisory only
Cabin Pressure Controller indication	32 units	Monitor
Pack Temperature Control advisory	24 units	Normal
Hydraulic System B indication	1 units	Refer to related topic

The Landing Gear Indication advisory is expected to read within the sample range of 58 to 62 units during preflight. The Autopilot Channel A selector position is expected to read within the sample range of 78 to 88 units during descent. The Autobrake Selector status message that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete. The Standby Instruments quantity display is expected to read within the sample range of 90 to 94 units during climb. Refer to the related topic for additional sample context. The Cabin Pressure Controller quantity display that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power.

During engine start, both pilots should confirm the Oxygen Distribution indication if a discrepancy is observed. During landing, the pilot monitoring should select the Oxygen Distribution status message when conditions permit. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer quantity display that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power.

The captain will monitor any change in the Hydraulic System B quantity display and advise the other pilot when operating at a sample station without ground power. The Wing Anti-Ice status message that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. If the Standby Hydraulic is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The captain will cross-check any change in the Window Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval.

Challenge	Response
Center Tank Pumps	Closed
Autothrottle	Off
Flight Management Computer	As required
Weather Radar	Set
Stall Warning	On
Wing Anti-Ice	Checked
Ground Proximity Monitor	Off
Flap Position Indication	Off
Autopilot Channel B	Off
Stall Warning	Off
Traffic Advisory Display	Verified
Cargo Smoke Detection	Verified

03.60.15 *Verification: Standby Hydraulic*

The Probe Heat quantity display that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. The Wing Anti-Ice switch position is expected to read within the sample range of 97 to 102 units during descent. During a turnaround, the Captain should select the Autobrake Selector advisory if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Engine Anti-Ice is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Thrust Reverser selector position that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. During approach, the Captain should announce the Window Heat indication unless directed otherwise by the Sample Operations Center.

The Autopilot Channel A annunciation that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. If the Fire Detection Loop is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Fuel Crossfeed advisory that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

During an extended ground delay, the pilot monitoring should confirm the Traffic Advisory Display status message if the indication does not stabilize within the sample interval. During landing, the pilot monitoring should record the Window Heat status message once the checklist item is complete. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure.

The pilot monitoring will select any change in the Standby Hydraulic annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Standby Hydraulic advisory is expected to read within the sample range of 4 to 10 units during a maintenance-requested ground run. The relief pilot will announce any change in the Wing Anti-Ice advisory and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The pilot flying will cross-check any change in the Pack Temperature Control switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

03.60.16 *Callouts: Autopilot Channel A*

If the Thrust Reverser is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. Both pilots will announce any change in the Landing Gear Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder indication that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated.

- The Flap Position Indication selector position that differs from the expected state requires both pilots to announce the condition when operating at a sample station without ground power.
- The Autopilot Channel A annunciation that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed.
- During landing, the relief pilot should select the Hydraulic System B indication if the indication does not stabilize within the sample interval.
- During an extended ground delay, the Captain should brief the Weather Radar status message once the checklist item is complete.
- During engine start, the Captain should cross-check the Flight Management Computer status message when conditions permit.
- The Autothrottle status message is expected to read within the sample range of 88 to 93 units during landing.

During descent, the Captain should verify the Weather Radar indication when operating at a sample station without ground power. During taxi, the relief pilot should select the Nosewheel Steering annunciation before the next phase of flight. The relief pilot will cross-check any change in the Wing Anti-Ice indication and advise the other pilot before the next phase of flight.

The Bleed Air Supply switch position is expected to read within the sample range of 65 to 75 units during landing. The Speedbrake Handle quantity display is expected to read within the sample range of 44 to 55 units during approach. The Hydraulic System B annunciation that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. The Thrust Reverser annunciation that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. During cruise, the Captain should confirm the Engine Anti-Ice annunciation once the checklist item is complete. See 04.30.14 Crew Coordination: Ground Proximity Monitor.

CAUTION: The Oxygen Distribution advisory is expected to read within the sample range of 69 to 72 units during taxi. The pilot flying will record any change in the Autopilot Channel B indication and advise the other pilot if the indication does not stabilize within the sample interval.

- If the Transponder is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Bleed Air Supply indication is expected to read within the sample range of 13 to 18 units during an extended ground delay.
- If the Primary Electrical Bus is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- This text is fictional and exists only to give the prototype realistic volume and structure.

Challenge	Response
Pack Temperature Control	Off
Thrust Reverser	As required
Thrust Reverser	Set
Autopilot Channel A	Checked
Stall Warning	On
Autopilot Channel B	Armed
Hydraulic System B	On
Probe Heat	Off

03.60.17 Crew Coordination: Ground Proximity Monitor

If the Pack Temperature Control is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The captain will cross-check any change in the Standby Hydraulic quantity display and advise the other pilot when operating at a sample station without ground power.

CAUTION: The captain will monitor any change in the Thrust Reverser quantity display and advise the other pilot if a discrepancy is observed. The Nosewheel Steering quantity display is expected to read within the sample range of 65 to 74 units during taxi.

- The Cabin Pressure Controller annunciation is expected to read within the sample range of 68 to 73 units during parking.
- If the Traffic Advisory Display is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The Stall Warning selector position is expected to read within the sample range of 12 to 18 units during climb.
- The pilot flying will select any change in the Autopilot Channel B annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The first officer will confirm any change in the Landing Gear Indication indication and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Hydraulic System A advisory is expected to read within the sample range of 58 to 64 units during landing. Refer to the related topic for additional sample context.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Standby Instruments is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will cross-check any change in the Thrust Reverser annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Center Tank Pumps switch position that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete.

CAUTION: The Landing Gear Indication quantity display that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval. The captain will announce any change in the Ground Proximity Monitor switch position and advise the other pilot if a discrepancy is observed.

The Autobrake Selector indication that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed. During approach, the Captain should cross-check the Traffic Advisory Display advisory when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Hydraulic System B selector position that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight. The Probe Heat indication that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed.

03.60.18 Checklist: Pack Temperature Control

Refer to the related topic for additional sample context. The Autothrottle selector position that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete. During parking, the Captain should record the Pack Temperature Control annunciation when operating at a sample station without ground power. The Probe Heat indication is expected to read within the sample range of 3 to 7 units during landing. During taxi, both pilots should announce the Autothrottle indication if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

NOTE: During an extended ground delay, the First Officer should monitor the Autopilot Channel B status message once the checklist item is complete. If the Standby Hydraulic is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

NOTE: The Autopilot Channel B switch position that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. The Autopilot Channel A quantity display is expected to read within the sample range of 58 to 61 units during a diversion.

If the Primary Electrical Bus is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. During takeoff, the Captain should announce the Transponder quantity display when operating at a sample station without ground power. Refer to the related topic for additional sample context.

During engine start, the relief pilot should brief the Flap Position Indication quantity display when operating at a sample station without ground power. The Engine Anti-Ice quantity display that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete. During takeoff, both pilots should select the Speedbrake Handle quantity display if a discrepancy is observed.

The Thrust Reverser switch position that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will announce any change in the Ground Proximity Monitor advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Auxiliary Power Unit is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

The Standby Instruments quantity display that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. The Standby Hydraulic indication is expected to read within the sample range of 85 to 95 units during approach. The Autopilot Channel A indication that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power. The pilot flying will select any change in the Landing Gear Indication indication and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Window Heat status message is expected to read within the sample range of 24 to 36 units during landing.

03.60.19 Verification: Landing Gear Indication

The Flight Management Computer advisory is expected to read within the sample range of 9 to 13 units during parking. During a diversion, the pilot monitoring should verify the Hydraulic System B indication if a discrepancy is observed. During climb, both pilots should confirm the Window Heat status message if a discrepancy is observed. During takeoff, both pilots should verify the Landing Gear Indication indication if a discrepancy is observed. The Autopilot Channel A switch position that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. The Flight Management Computer annunciation that differs from the expected state requires both pilots to confirm the condition when conditions permit.

CAUTION: If the Flap Position Indication is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Autopilot Channel B status message is expected to read within the sample range of 35 to 38 units during an extended ground delay.

If the Autobrake Selector is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Cabin Pressure Controller selector position is expected to read within the sample range of 41 to 46 units during climb. This text is fictional and exists only to give the prototype realistic volume and structure.

During landing, the Captain should select the Brake Temperature Monitor indication once the checklist item is complete. During landing, the pilot monitoring should brief the Autopilot Channel B annunciation when operating at a sample station without ground power. During landing, both pilots should announce the Autopilot Channel A annunciation unless directed otherwise by the Sample Operations Center. The Window Heat advisory is expected to read within the sample range of 2 to 13 units during climb. During a turnaround, both pilots should cross-check the Weather Radar selector position when conditions permit.

NOTE: The Thrust Reverser indication that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Window Heat quantity display that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval. If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

Challenge	Response
-----------	----------

Autothrottle	Verified
Center Tank Pumps	Checked
Autopilot Channel A	On
Ground Proximity Monitor	On
Traffic Advisory Display	Off
Probe Heat	Armed
Flight Management Computer	As required

03.60.20 Flow: Speedbrake Handle

The Primary Electrical Bus selector position is expected to read within the sample range of 71 to 79 units during a maintenance-requested ground run. During a maintenance-requested ground run, the pilot flying should select the Auxiliary Power Unit selector position when the associated caution light remains illuminated. During a maintenance-requested ground run, the Captain should select the Cockpit Voice Recorder quantity display once the checklist item is complete. The Cabin Pressure Controller advisory is expected to read within the sample range of 8 to 16 units during landing.

The Pack Temperature Control advisory is expected to read within the sample range of 49 to 55 units during climb. The Transponder advisory is expected to read within the sample range of 26 to 34 units during preflight. The Standby Instruments annunciation is expected to read within the sample range of 75 to 85 units during a turnaround. The Auxiliary Power Unit selector position is expected to read within the sample range of 2 to 14 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure.

During takeoff, the relief pilot should verify the Probe Heat selector position when the associated caution light remains illuminated. During landing, both pilots should brief the Standby Hydraulic advisory if the indication does not stabilize within the sample interval. Both pilots will monitor any change in the Ground Proximity Monitor annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Weather Radar annunciation that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

The Flight Management Computer status message that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed. The Cabin Pressure Controller indication is expected to read within the sample range of 51 to 57 units during parking. During climb, the relief pilot should cross-check the Transponder quantity display when the associated caution light remains illuminated.

If the Fuel Crossfeed is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Landing Gear Indication indication that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. The captain will record any change in the Standby Instruments annunciation and advise the other pilot when the associated caution light remains illuminated. The Wing Anti-Ice switch position that differs from the expected state requires the Captain to brief the condition when conditions permit.

The Primary Electrical Bus status message is expected to read within the sample range of 62 to 72 units during a turnaround. The Flight Management Computer quantity display is expected to read within the sample range of 66 to 72 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Autopilot Channel A	Closed
Hydraulic System B	On
Speedbrake Handle	Off
Autopilot Channel B	On
Standby Instruments	Closed

Center Tank Pumps	As required
Flap Position Indication	Verified
Weather Radar	Off
Autothrottle	Closed
Fire Detection Loop	Armed
Autothrottle	Armed
Wing Anti-Ice	Closed

03.60.21 Crew Coordination: Fuel Crossfeed

If the Flight Management Computer is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Oxygen Distribution indication is expected to read within the sample range of 78 to 85 units during approach. The Oxygen Distribution switch position is expected to read within the sample range of 71 to 78 units during climb.

If the Center Tank Pumps is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Fuel Crossfeed switch position is expected to read within the sample range of 12 to 16 units during preflight. The Center Tank Pumps selector position is expected to read within the sample range of 43 to 53 units during engine start.

CAUTION: If the Autopilot Channel B is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The pilot monitoring will verify any change in the Wing Anti-Ice status message and advise the other pilot when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. The relief pilot will confirm any change in the Weather Radar switch position and advise the other pilot before the next phase of flight. The Autopilot Channel A annunciation that differs from the expected state requires the relief pilot to select the condition when conditions permit.

NOTE: The captain will record any change in the Thrust Reverser selector position and advise the other pilot if the indication does not stabilize within the sample interval.

During descent, the pilot monitoring should select the Engine Anti-Ice indication if a discrepancy is observed. The Flap Position Indication status message is expected to read within the sample range of 12 to 22 units during cruise. If the Fuel Crossfeed is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. During preflight, the First Officer should record the Standby Hydraulic quantity display when the associated caution light remains illuminated. The Autopilot Channel B status message is expected to read within the sample range of 52 to 63 units during engine start. During landing, the Captain should verify the Engine Anti-Ice annunciation when operating at a sample station without ground power.

Challenge	Response
Standby Instruments	Checked
Ground Proximity Monitor	Armed
Cabin Pressure Controller	Off
Weather Radar	As required
Weather Radar	Off
Flap Position Indication	Closed
Autothrottle	Set
Auxiliary Power Unit	Armed

03.60.22 Crew Coordination: Stall Warning

If the Weather Radar is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will cross-check any change in the Traffic Advisory Display quantity display and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The captain will monitor any change in the Hydraulic System B selector position and advise the other pilot if a discrepancy is observed.

If the Weather Radar is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The captain will verify any change in the Pack Temperature Control indication and advise the other pilot once the checklist item is complete. The Fuel Crossfeed indication is expected to read within the sample range of 92 to 95 units during climb. During takeoff, the relief pilot should record the Landing Gear Indication annunciation once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

The Speedbrake Handle selector position is expected to read within the sample range of 65 to 70 units during an extended ground delay. During descent, both pilots should record the Autobrake Selector indication unless directed otherwise by the Sample Operations Center. The Bleed Air Supply selector position is expected to read within the sample range of 28 to 31 units during a turnaround.

If the Brake Temperature Monitor is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The pilot monitoring will record any change in the Fire Detection Loop advisory and advise the other pilot when the associated caution light remains illuminated. The Primary Electrical Bus quantity display that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed. The Flap Position Indication annunciation is expected to read within the sample range of 13 to 21 units during a diversion. The Brake Temperature Monitor advisory that differs from the expected state requires the Captain to cross-check the condition when conditions permit.

CAUTION: The Speedbrake Handle indication is expected to read within the sample range of 29 to 37 units during a diversion. The wording here is placeholder content shaped like a procedure, not a procedure.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Autopilot Channel B status message that differs from the expected state requires both pilots to select the condition once the checklist item is complete.

CAUTION: The Primary Electrical Bus switch position that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight. The Window Heat switch position that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power.

NOTE: The Stall Warning selector position is expected to read within the sample range of 72 to 76 units during takeoff.

Challenge	Response
Fire Detection Loop	On
Oxygen Distribution	Armed
Nosewheel Steering	Off
Traffic Advisory Display	On
Bleed Air Supply	Checked
Stall Warning	As required

Autobrake Selector	Armed
Probe Heat	On

03.70 Landing and Shutdown

03.70.1 Checklist: Hydraulic System A

During takeoff, the relief pilot should select the Fire Detection Loop quantity display when operating at a sample station without ground power. During preflight, the relief pilot should announce the Autothrottle indication unless directed otherwise by the Sample Operations Center. The Ground Proximity Monitor selector position that differs from the expected state requires both pilots to monitor the condition when conditions permit. The Transponder selector position that differs from the expected state requires the Captain to select the condition if a discrepancy is observed.

During parking, the pilot monitoring should cross-check the Flap Position Indication switch position if a discrepancy is observed. The pilot flying will announce any change in the Autobrake Selector quantity display and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Bleed Air Supply annunciation is expected to read within the sample range of 24 to 30 units during a turnaround. During preflight, the pilot flying should brief the Autothrottle advisory if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During taxi, the relief pilot should monitor the Thrust Reverser selector position if the indication does not stabilize within the sample interval. The captain will verify any change in the Standby Hydraulic selector position and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Brake Temperature Monitor indication	86 units	Advisory only
Engine Anti-Ice switch position	56 units	Advisory only
Pack Temperature Control annunciation	22 units	Monitor
Hydraulic System A switch position	80 units	Monitor
Standby Instruments indication	74 units	Refer to related topic
Hydraulic System B advisory	78 units	Monitor
Ground Proximity Monitor quantity display	31 units	Monitor

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Hydraulic System A quantity display is expected to read within the sample range of 81 to 93 units during landing.
- The Flap Position Indication selector position is expected to read within the sample range of 30 to 42 units during approach.
- During an extended ground delay, the Captain should brief the Engine Anti-Ice advisory when conditions permit.
- During a diversion, the relief pilot should confirm the Auxiliary Power Unit advisory if a discrepancy is observed.

Condition	Sample value	Remarks
Autopilot Channel B annunciation	86 units	Refer to related topic
Ground Proximity Monitor status message	73 units	Advisory only
Cabin Pressure Controller status message	13 units	Advisory only
Flap Position Indication annunciation	40 units	Normal

03.70.2 Crew Coordination: Hydraulic System B

The Stall Warning indication is expected to read within the sample range of 61 to 69 units during a turnaround. The Oxygen Distribution selector position is expected to read within the sample range of 57 to 66 units during cruise. The Autopilot Channel B quantity display that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. The Nosewheel Steering status message that differs from the expected state requires the pilot flying to announce the condition when conditions permit.

During a turnaround, the Captain should announce the Fuel Crossfeed switch position once the checklist item is complete. During cruise, the pilot flying should monitor the Nosewheel Steering indication if a discrepancy is observed. During cruise, the First Officer should monitor the Primary Electrical Bus indication if the indication does not stabilize within the sample interval.

The Oxygen Distribution advisory is expected to read within the sample range of 59 to 69 units during preflight. If the Nosewheel Steering is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The relief pilot will monitor any change in the Landing Gear Indication status message and advise the other pilot before the next phase of flight. Both pilots will select any change in the Cabin Pressure Controller indication and advise the other pilot if the indication does not stabilize within the sample interval. The Ground Proximity Monitor quantity display that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight. If the Weather Radar is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

- If the Oxygen Distribution is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.
- If the Engine Anti-Ice is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- The Primary Electrical Bus indication that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center.
- During approach, the relief pilot should cross-check the Bleed Air Supply indication unless directed otherwise by the Sample Operations Center.
- The Autothrottle quantity display that differs from the expected state requires both pilots to monitor the condition when conditions permit.
- The Transponder quantity display is expected to read within the sample range of 10 to 16 units during approach.
- During descent, both pilots should select the Nosewheel Steering indication when the associated caution light remains illuminated.
- If the Standby Instruments is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.
- The Probe Heat annunciation that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center.
- Refer to the related topic for additional sample context.

NOTE: The pilot flying will cross-check any change in the Center Tank Pumps indication and advise the other pilot when conditions permit. Refer to the related topic for additional sample context.

If the Hydraulic System A is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Ground Proximity Monitor quantity display is expected to read within the sample range of 72 to 84 units during taxi. The Hydraulic System B selector position is expected to read within the sample range of 50 to 60 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure.

The first officer will verify any change in the Pack Temperature Control advisory and advise the other pilot once the checklist item is complete. During preflight, the pilot monitoring should verify the Wing Anti-Ice annunciation if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. If the Traffic Advisory Display is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. During landing, the pilot flying should monitor the Wing Anti-Ice selector position unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Flap Position Indication is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The Pack Temperature Control status message that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. The Primary Electrical Bus status message that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. During a turnaround, the relief pilot should monitor the Brake Temperature Monitor indication when operating at a sample station without ground power. The pilot flying will record any change in the Autopilot Channel B status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will monitor any change in the Fire Detection Loop indication and advise the other pilot when the associated caution light remains illuminated.

Challenge	Response
Brake Temperature Monitor	Closed
Nosewheel Steering	Checked
Nosewheel Steering	As required
Oxygen Distribution	Verified
Autothrottle	On
Wing Anti-Ice	Checked
Cabin Pressure Controller	Closed
Thrust Reverser	Closed
Autopilot Channel A	Closed
Primary Electrical Bus	On
Cockpit Voice Recorder	Checked

03.70.3 Verification: Center Tank Pumps

During preflight, the First Officer should cross-check the Standby Instruments annunciation when operating at a sample station without ground power. If the Engine Anti-Ice is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Autothrottle quantity display that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center.

Both pilots will brief any change in the Cargo Smoke Detection indication and advise the other pilot if the indication does not stabilize within the sample interval. The Thrust Reverser indication is expected to read within the sample range of 86 to 94 units during cruise. The Hydraulic System B quantity display that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center.

NOTE: The Autopilot Channel A selector position is expected to read within the sample range of 21 to 25 units during parking.

The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System B status message is expected to read within the sample range of 13 to 24 units during a turnaround. If the Fire Detection Loop is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The captain will verify any change in the Nosewheel Steering selector position and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Probe Heat indication	79 units	Normal
Bleed Air Supply status message	55 units	Refer to related topic
Autopilot Channel B switch position	14 units	Advisory only

The Oxygen Distribution status message is expected to read within the sample range of 35 to 41 units during descent. The Window Heat switch position is expected to read within the sample range of 35 to 47 units during approach. If the Autobrake Selector is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

Challenge	Response
Ground Proximity Monitor	Armed
Traffic Advisory Display	Off
Fuel Crossfeed	Off
Cabin Pressure Controller	As required
Stall Warning	On
Autopilot Channel B	Closed
Traffic Advisory Display	On
Auxiliary Power Unit	On

03.70.4 Briefing: Nosewheel Steering

The Speedbrake Handle advisory is expected to read within the sample range of 51 to 63 units during landing. If the Fire Detection Loop is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot flying should record the Traffic Advisory Display status message if the indication does not stabilize within the sample interval. The Weather Radar indication is expected to read within the sample range of 23 to 32 units during parking. During cruise, the pilot flying should monitor the Window Heat indication when operating at a sample station without ground power. Refer to the related topic for additional sample context.

The Autothrottle status message is expected to read within the sample range of 8 to 18 units during approach. During engine start, the First Officer should cross-check the Oxygen Distribution indication before the next phase of flight. During a maintenance-requested ground run, the pilot monitoring should announce the Auxiliary Power Unit indication when conditions permit.

Condition	Sample value	Remarks
Engine Anti-Ice status message	33 units	Normal
Cargo Smoke Detection indication	92 units	Monitor
Thrust Reverser annunciation	75 units	Advisory only

- The Weather Radar quantity display that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.
- The Oxygen Distribution advisory is expected to read within the sample range of 60 to 68 units during a diversion.
- If the Oxygen Distribution is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.
- During a diversion, the pilot flying should verify the Fire Detection Loop status message unless directed otherwise by the Sample Operations Center.

CAUTION: The Thrust Reverser annunciation is expected to read within the sample range of 83 to 89 units during descent.

CAUTION: During a diversion, the relief pilot should record the Speedbrake Handle selector position once the checklist item is complete.

03.70.5 Callouts: Cabin Pressure Controller

Values in this manual are invented and must not be used for any operational purpose. The first officer will announce any change in the Primary Electrical Bus status message and advise the other pilot if a discrepancy is observed. The Engine Anti-Ice selector position is expected to read within the sample range of 44 to 55 units during a diversion. The Weather Radar selector position is expected to read within the sample range of 52 to 58 units during a maintenance-requested ground run. The first officer will announce any change in the Flight Management Computer advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During engine start, the Captain should record the Hydraulic System B selector position if the indication does not stabilize within the sample interval.

NOTE: The first officer will record any change in the Autopilot Channel A status message and advise the other pilot once the checklist item is complete.

The relief pilot will monitor any change in the Cabin Pressure Controller quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Wing Anti-Ice advisory is expected to read within the sample range of 2 to 8 units during a diversion. The pilot flying will cross-check any change in the Flap Position Indication quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will verify any change in the Cabin Pressure Controller indication and advise the other pilot if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder switch position that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval. The Standby Instruments indication that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cargo Smoke Detection quantity display	51 units	Monitor
Traffic Advisory Display indication	74 units	Advisory only
Autopilot Channel A annunciation	35 units	Monitor
Hydraulic System B indication	1 units	Normal
Weather Radar annunciation	12 units	Advisory only
Traffic Advisory Display quantity display	81 units	Monitor

The relief pilot will confirm any change in the Traffic Advisory Display selector position and advise the other pilot when the associated caution light remains illuminated. The pilot flying will select any change in the Hydraulic System B quantity display and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

03.70.6 Verification: Thrust Reverser

The pilot monitoring will record any change in the Speedbrake Handle switch position and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. The Window Heat switch position is expected to read within the sample range of 92 to 104 units during climb.

Values in this manual are invented and must not be used for any operational purpose. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give

the prototype realistic volume and structure.

Condition	Sample value	Remarks
Hydraulic System A advisory	64 units	Monitor
Autopilot Channel A quantity display	72 units	Advisory only
Cockpit Voice Recorder advisory	52 units	Monitor
Cargo Smoke Detection annunciation	95 units	Refer to related topic
Flap Position Indication annunciation	33 units	Refer to related topic
Fuel Crossfeed switch position	31 units	Refer to related topic

The Stall Warning switch position that differs from the expected state requires the Captain to verify the condition before the next phase of flight. Refer to the related topic for additional sample context. The Autobrake Selector switch position that differs from the expected state requires the relief pilot to announce the condition when conditions permit. The Auxiliary Power Unit advisory that differs from the expected state requires the Captain to announce the condition once the checklist item is complete.

CAUTION: If the Transponder is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

NOTE: The Standby Instruments selector position is expected to read within the sample range of 84 to 90 units during a turnaround. The first officer will record any change in the Auxiliary Power Unit annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

If the Autothrottle is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. During preflight, the pilot monitoring should brief the Autopilot Channel B indication when the associated caution light remains illuminated. The Primary Electrical Bus indication is expected to read within the sample range of 22 to 31 units during a maintenance-requested ground run. The captain will verify any change in the Thrust Reverser switch position and advise the other pilot once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection selector position is expected to read within the sample range of 70 to 81 units during a turnaround. The Autothrottle annunciation is expected to read within the sample range of 11 to 16 units during descent. If the Standby Instruments is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

Challenge	Response
Cabin Pressure Controller	As required
Weather Radar	On
Standby Instruments	Armed
Flap Position Indication	Checked
Autothrottle	Armed
Hydraulic System A	Checked
Cockpit Voice Recorder	Armed
Autopilot Channel B	Checked
Hydraulic System B	Closed

03.70.7 Flow: Bleed Air Supply

The Weather Radar advisory that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. If the Bleed Air Supply is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. During cruise, the pilot flying should cross-check the Ground Proximity Monitor status message when the associated caution light remains illuminated. The Ground

Proximity Monitor advisory is expected to read within the sample range of 56 to 63 units during descent. The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, both pilots should verify the Thrust Reverser status message once the checklist item is complete.

CAUTION: During engine start, the Captain should announce the Window Heat status message if the indication does not stabilize within the sample interval.

Both pilots will monitor any change in the Thrust Reverser status message and advise the other pilot if the indication does not stabilize within the sample interval. The Engine Anti-Ice indication that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. During preflight, the Captain should brief the Bleed Air Supply quantity display when conditions permit. The Hydraulic System A annunciation is expected to read within the sample range of 81 to 86 units during descent. The relief pilot will confirm any change in the Hydraulic System A annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Fire Detection Loop selector position	54 units	Normal
Cargo Smoke Detection selector position	20 units	Monitor
Weather Radar status message	40 units	Advisory only
Autopilot Channel A quantity display	31 units	Refer to related topic
Nosewheel Steering selector position	51 units	Monitor

The Oxygen Distribution status message is expected to read within the sample range of 83 to 95 units during descent. During engine start, both pilots should cross-check the Standby Hydraulic quantity display if a discrepancy is observed. The Landing Gear Indication status message that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. If the Hydraulic System B is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

NOTE: The Bleed Air Supply status message that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Autothrottle selector position	16 units	Advisory only
Fire Detection Loop selector position	71 units	Refer to related topic
Ground Proximity Monitor switch position	26 units	Advisory only
Primary Electrical Bus annunciation	35 units	Normal
Speedbrake Handle annunciation	26 units	Normal
Fuel Crossfeed annunciation	13 units	Monitor

During an extended ground delay, the pilot flying should confirm the Autobrake Selector switch position before the next phase of flight. During engine start, the relief pilot should brief the Thrust Reverser quantity display once the checklist item is complete. If the Autopilot Channel A is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

Challenge	Response
Autopilot Channel B	Verified
Oxygen Distribution	Checked
Autothrottle	As required
Transponder	Checked
Autothrottle	Set

Cabin Pressure Controller	Armed
Auxiliary Power Unit	Checked
Nosewheel Steering	Off
Transponder	Checked
Landing Gear Indication	Checked
Nosewheel Steering	Checked
Pack Temperature Control	Closed

03.70.8 Crew Coordination: Engine Anti-Ice

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will record any change in the Autobrake Selector switch position and advise the other pilot when the associated caution light remains illuminated. The Cabin Pressure Controller selector position is expected to read within the sample range of 96 to 106 units during landing. The pilot monitoring will cross-check any change in the Window Heat annunciation and advise the other pilot before the next phase of flight.

The captain will monitor any change in the Weather Radar quantity display and advise the other pilot if a discrepancy is observed. The Standby Hydraulic status message is expected to read within the sample range of 76 to 88 units during a diversion. Both pilots will select any change in the Engine Anti-Ice quantity display and advise the other pilot when conditions permit. The Bleed Air Supply advisory that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. The Bleed Air Supply status message that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. The Autopilot Channel A quantity display is expected to read within the sample range of 67 to 79 units during a maintenance-requested ground run.

During taxi, the First Officer should cross-check the Window Heat switch position when operating at a sample station without ground power. During cruise, the pilot flying should confirm the Bleed Air Supply status message when conditions permit. The Autothrottle advisory is expected to read within the sample range of 55 to 59 units during landing.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Oxygen Distribution is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During climb, the Captain should monitor the Autothrottle switch position when the associated caution light remains illuminated. The Pack Temperature Control advisory is expected to read within the sample range of 14 to 26 units during a turnaround. The pilot monitoring will monitor any change in the Window Heat advisory and advise the other pilot once the checklist item is complete. During cruise, the relief pilot should verify the Hydraulic System A switch position when the associated caution light remains illuminated.

The Weather Radar status message is expected to read within the sample range of 23 to 34 units during landing. Refer to the related topic for additional sample context. The Landing Gear Indication selector position is expected to read within the sample range of 77 to 89 units during approach.

- The Stall Warning annunciation is expected to read within the sample range of 84 to 87 units during a maintenance-requested ground run.
- Both pilots will confirm any change in the Engine Anti-Ice selector position and advise the other pilot once the checklist item is complete.
- During engine start, the relief pilot should announce the Weather Radar selector position if a discrepancy is observed.

03.70.9 Callouts: Nosewheel Steering

During descent, the pilot flying should monitor the Oxygen Distribution quantity display once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Flight

Management Computer quantity display that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. The pilot flying will verify any change in the Traffic Advisory Display annunciation and advise the other pilot when operating at a sample station without ground power.

NOTE: During descent, the Captain should record the Center Tank Pumps quantity display when conditions permit. During climb, the First Officer should brief the Stall Warning indication unless directed otherwise by the Sample Operations Center.

If the Oxygen Distribution is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. If the Window Heat is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

If the Auxiliary Power Unit is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The first officer will record any change in the Autopilot Channel A indication and advise the other pilot once the checklist item is complete. The pilot flying will cross-check any change in the Transponder indication and advise the other pilot when operating at a sample station without ground power.

- The Fire Detection Loop advisory that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center.
- The Landing Gear Indication annunciation that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval.
- The Standby Hydraulic switch position is expected to read within the sample range of 55 to 60 units during climb.
- If the Fire Detection Loop is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.
- If the Cockpit Voice Recorder is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. During descent, the First Officer should monitor the Window Heat status message unless directed otherwise by the Sample Operations Center.

CAUTION: If the Flap Position Indication is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the pilot flying should cross-check the Wing Anti-Ice quantity display unless directed otherwise by the Sample Operations Center.

Challenge	Response
Standby Instruments	Checked
Weather Radar	On
Speedbrake Handle	Set
Autopilot Channel B	Armed
Autopilot Channel B	Verified
Bleed Air Supply	Set
Primary Electrical Bus	Checked
Wing Anti-Ice	Armed
Fuel Crossfeed	On

Cabin Pressure Controller	Armed
Landing Gear Indication	Armed
Flap Position Indication	Closed

03.70.10 Checklist: Autopilot Channel A

Refer to the related topic for additional sample context. The Nosewheel Steering advisory is expected to read within the sample range of 88 to 97 units during takeoff. If the Speedbrake Handle is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Oxygen Distribution status message	35 units	Refer to related topic
Thrust Reverser switch position	78 units	Refer to related topic
Primary Electrical Bus quantity display	80 units	Monitor
Auxiliary Power Unit annunciation	27 units	Advisory only
Transponder selector position	41 units	Normal

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The Brake Temperature Monitor indication is expected to read within the sample range of 27 to 34 units during cruise. The first officer will announce any change in the Standby Instruments status message and advise the other pilot once the checklist item is complete. The Autothrottle quantity display that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Center Tank Pumps status message	58 units	Advisory only
Wing Anti-Ice indication	48 units	Monitor
Auxiliary Power Unit indication	62 units	Refer to related topic
Cargo Smoke Detection advisory	88 units	Normal
Hydraulic System A quantity display	21 units	Advisory only
Cockpit Voice Recorder advisory	8 units	Monitor

Condition	Sample value	Remarks
Speedbrake Handle advisory	95 units	Monitor
Pack Temperature Control quantity display	74 units	Monitor
Window Heat indication	99 units	Refer to related topic

CAUTION: Both pilots will monitor any change in the Speedbrake Handle quantity display and advise the other pilot before the next phase of flight. The Primary Electrical Bus annunciation that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated.

CAUTION: The Window Heat status message is expected to read within the sample range of 95 to 98 units during taxi.

If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During a maintenance-requested ground run, the relief pilot should confirm the Probe Heat selector position when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

Both pilots will select any change in the Center Tank Pumps advisory and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will record any change in the Engine Anti-Ice advisory and advise the other pilot once the checklist item is complete. The Probe Heat status message is expected to read within the sample range of 12 to 23 units during preflight. If the Center Tank Pumps is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Fuel Crossfeed	Off
Nosewheel Steering	Checked
Autothrottle	Armed
Pack Temperature Control	Checked
Standby Hydraulic	Checked
Thrust Reverser	Armed
Cabin Pressure Controller	Armed
Fuel Crossfeed	Verified

03.70.11 Flow: Cargo Smoke Detection

The Cabin Pressure Controller indication is expected to read within the sample range of 79 to 84 units during an extended ground delay. If the Autopilot Channel B is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Fire Detection Loop status message is expected to read within the sample range of 22 to 33 units during climb. The Fire Detection Loop advisory that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated.

The Hydraulic System B indication is expected to read within the sample range of 91 to 98 units during parking. During takeoff, the pilot monitoring should confirm the Cargo Smoke Detection selector position before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The Brake Temperature Monitor selector position that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Brake Temperature Monitor selector position	29 units	Advisory only
Brake Temperature Monitor switch position	96 units	Normal
Cargo Smoke Detection advisory	84 units	Monitor

- The Fire Detection Loop quantity display that differs from the expected state requires the Captain to select the condition if a discrepancy is observed.
- The relief pilot will record any change in the Probe Heat indication and advise the other pilot if the indication does not stabilize within the sample interval.
- The Window Heat switch position is expected to read within the sample range of 14 to 25 units during landing.
- If the Stall Warning is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- During landing, the pilot monitoring should brief the Hydraulic System B indication if the indication does not stabilize within the sample interval.

- The first officer will confirm any change in the Fire Detection Loop switch position and advise the other pilot when conditions permit.

This text is fictional and exists only to give the prototype realistic volume and structure. The Flap Position Indication annunciation that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. During engine start, the First Officer should confirm the Pack Temperature Control switch position when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System B annunciation is expected to read within the sample range of 34 to 45 units during a diversion. The Nosewheel Steering selector position that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed.

03.70.12 Verification: Standby Hydraulic

The Speedbrake Handle indication is expected to read within the sample range of 22 to 26 units during a maintenance-requested ground run. During takeoff, the pilot flying should confirm the Landing Gear Indication switch position when operating at a sample station without ground power. The Cargo Smoke Detection quantity display is expected to read within the sample range of 97 to 108 units during descent. The captain will select any change in the Pack Temperature Control status message and advise the other pilot when operating at a sample station without ground power.

If the Primary Electrical Bus is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Ground Proximity Monitor annunciation and advise the other pilot before the next phase of flight. If the Bleed Air Supply is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Window Heat advisory that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

During taxi, the pilot flying should record the Center Tank Pumps annunciation when the associated caution light remains illuminated. If the Standby Instruments is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The relief pilot will announce any change in the Autopilot Channel A annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Speedbrake Handle annunciation that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed. If the Standby Instruments is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

If the Bleed Air Supply is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Stall Warning annunciation that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete. The Autopilot Channel A selector position is expected to read within the sample range of 77 to 81 units during landing.

This text is fictional and exists only to give the prototype realistic volume and structure. The Autopilot Channel A quantity display is expected to read within the sample range of 29 to 33 units during cruise. If the Autopilot Channel B is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Landing Gear Indication switch position	7 units	Refer to related topic
Nosewheel Steering quantity display	97 units	Refer to related topic
Auxiliary Power Unit indication	97 units	Refer to related topic
Cockpit Voice Recorder quantity display	78 units	Monitor

Ground Proximity Monitor annunciation	15 units	Monitor
Cabin Pressure Controller switch position	54 units	Monitor
Wing Anti-Ice advisory	30 units	Normal

This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the Captain should select the Wing Anti-Ice annunciation if a discrepancy is observed. The Fuel Crossfeed indication is expected to read within the sample range of 14 to 26 units during a maintenance-requested ground run. The Autothrottle advisory that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. During a diversion, both pilots should confirm the Cargo Smoke Detection selector position when the associated caution light remains illuminated.

NOTE: Both pilots will select any change in the Thrust Reverser quantity display and advise the other pilot when conditions permit.

The Transponder selector position that differs from the expected state requires both pilots to verify the condition when conditions permit. The pilot monitoring will cross-check any change in the Autopilot Channel B quantity display and advise the other pilot when the associated caution light remains illuminated. The Stall Warning annunciation that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval. The Weather Radar switch position is expected to read within the sample range of 77 to 87 units during an extended ground delay. See 05.80.4 Stall Warning Crew Awareness.

03.70.13 Crew Coordination: Standby Hydraulic

The pilot monitoring will verify any change in the Cargo Smoke Detection quantity display and advise the other pilot before the next phase of flight. The first officer will record any change in the Window Heat indication and advise the other pilot when conditions permit. The Wing Anti-Ice indication that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated.

- The Thrust Reverser status message that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.
- The Cabin Pressure Controller status message that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete.
- The wording here is placeholder content shaped like a procedure, not a procedure.

The Hydraulic System A advisory that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will record any change in the Traffic Advisory Display advisory and advise the other pilot if a discrepancy is observed. The first officer will brief any change in the Transponder advisory and advise the other pilot if a discrepancy is observed. During a diversion, the First Officer should verify the Thrust Reverser quantity display if a discrepancy is observed. Refer to the related topic for additional sample context. The Ground Proximity Monitor quantity display is expected to read within the sample range of 74 to 79 units during a diversion.

Both pilots will select any change in the Window Heat annunciation and advise the other pilot if a discrepancy is observed. The Autopilot Channel B selector position that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. The Standby Instruments status message is expected to read within the sample range of 33 to 45 units during landing.

During climb, the relief pilot should record the Ground Proximity Monitor switch position when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer selector position that differs from the expected state requires the First Officer to cross-check the condition when conditions permit.

Challenge	Response
Autothrottle	Checked
Cabin Pressure Controller	Set
Standby Hydraulic	Set
Center Tank Pumps	On
Window Heat	Checked
Autobrake Selector	Closed
Cockpit Voice Recorder	As required
Traffic Advisory Display	As required

03.70.14 Briefing: Window Heat

The Weather Radar quantity display is expected to read within the sample range of 71 to 75 units during approach. The Primary Electrical Bus switch position that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval. The pilot flying will record any change in the Window Heat advisory and advise the other pilot if a discrepancy is observed. The Nosewheel Steering status message that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval.

The Landing Gear Indication advisory that differs from the expected state requires the First Officer to select the condition before the next phase of flight. The captain will brief any change in the Cargo Smoke Detection selector position and advise the other pilot before the next phase of flight. During approach, the relief pilot should select the Oxygen Distribution switch position if the indication does not stabilize within the sample interval. During parking, the pilot monitoring should confirm the Thrust Reverser indication when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autopilot Channel A quantity display	79 units	Normal
Flap Position Indication status message	12 units	Refer to related topic
Stall Warning status message	25 units	Normal
Auxiliary Power Unit quantity display	87 units	Normal
Ground Proximity Monitor switch position	60 units	Advisory only
Hydraulic System B status message	13 units	Refer to related topic
Cabin Pressure Controller switch position	82 units	Advisory only

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: If the Fire Detection Loop is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Stall Warning switch position is expected to read within the sample range of 86 to 94 units during a diversion.

The wording here is placeholder content shaped like a procedure, not a procedure. During climb, the pilot flying should cross-check the Probe Heat status message unless directed otherwise by the Sample Operations Center. During landing, the Captain should select the Cockpit Voice Recorder status message when the associated caution light remains illuminated. See 13.40.2 Autothrottle Status Messages.

Challenge	Response
Weather Radar	As required
Thrust Reverser	Closed
Autopilot Channel A	On

Standby Hydraulic	Off
Hydraulic System B	Armed
Autothrottle	As required
Cockpit Voice Recorder	Checked
Hydraulic System B	Closed

03.70.15 Checklist: Speedbrake Handle

The Cargo Smoke Detection switch position is expected to read within the sample range of 74 to 83 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure. During a turnaround, both pilots should monitor the Autobrake Selector selector position unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Standby Hydraulic advisory is expected to read within the sample range of 40 to 45 units during cruise.

NOTE: Refer to the related topic for additional sample context.

If the Engine Anti-Ice is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. During landing, the relief pilot should select the Stall Warning quantity display if a discrepancy is observed. The Hydraulic System B quantity display that differs from the expected state requires both pilots to select the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

The Brake Temperature Monitor annunciation is expected to read within the sample range of 8 to 12 units during a maintenance-requested ground run. If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the relief pilot should monitor the Autopilot Channel A indication before the next phase of flight. During a maintenance-requested ground run, the First Officer should select the Autopilot Channel B indication before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Primary Electrical Bus is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Nosewheel Steering advisory	88 units	Advisory only
Flight Management Computer switch position	23 units	Advisory only
Auxiliary Power Unit selector position	35 units	Advisory only
Hydraulic System B selector position	14 units	Normal

- During an extended ground delay, the pilot monitoring should confirm the Fire Detection Loop quantity display once the checklist item is complete.
- During approach, the First Officer should verify the Transponder status message when operating at a sample station without ground power.
- During taxi, the relief pilot should verify the Pack Temperature Control status message before the next phase of flight.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. During parking, the pilot monitoring should select the Engine Anti-Ice status message before the next phase of flight.

NOTE: During approach, the pilot monitoring should record the Flight Management Computer status message when the associated caution light remains illuminated.

Challenge	Response
Autopilot Channel A	Off
Oxygen Distribution	Closed

Primary Electrical Bus	Closed
Cargo Smoke Detection	Off
Stall Warning	As required
Standby Instruments	On
Flap Position Indication	Checked
Speedbrake Handle	Armed
Nosewheel Steering	Set
Engine Anti-Ice	Verified

03.70.16 Flow: Speedbrake Handle

Both pilots will brief any change in the Speedbrake Handle selector position and advise the other pilot when operating at a sample station without ground power. During descent, the pilot flying should confirm the Engine Anti-Ice annunciation if the indication does not stabilize within the sample interval. If the Weather Radar is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The Cockpit Voice Recorder switch position is expected to read within the sample range of 46 to 50 units during parking. Refer to the related topic for additional sample context. If the Autobrake Selector is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

NOTE: The Speedbrake Handle switch position that differs from the expected state requires both pilots to record the condition once the checklist item is complete.

During cruise, the relief pilot should select the Autothrottle status message if a discrepancy is observed. If the Fuel Crossfeed is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Standby Hydraulic annunciation that differs from the expected state requires the pilot monitoring to brief the condition if the indication does not stabilize within the sample interval. The relief pilot will confirm any change in the Autothrottle quantity display and advise the other pilot if a discrepancy is observed. If the Standby Instruments is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Wing Anti-Ice quantity display	53 units	Refer to related topic
Autopilot Channel A selector position	36 units	Normal
Autopilot Channel A quantity display	12 units	Monitor
Cabin Pressure Controller advisory	66 units	Refer to related topic
Brake Temperature Monitor selector position	85 units	Normal

- Both pilots will select any change in the Flap Position Indication selector position and advise the other pilot when operating at a sample station without ground power.
- The relief pilot will brief any change in the Thrust Reverser annunciation and advise the other pilot once the checklist item is complete.
- The captain will cross-check any change in the Hydraulic System B advisory and advise the other pilot when conditions permit.
- The first officer will record any change in the Nosewheel Steering switch position and advise the other pilot when the associated caution light remains illuminated.
- The Flight Management Computer advisory that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Flight Management Computer switch position that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center.
- If the Hydraulic System B is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.
- If the Nosewheel Steering is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- The first officer will confirm any change in the Autopilot Channel B advisory and advise the other pilot before the next phase of flight.
- The Oxygen Distribution quantity display is expected to read within the sample range of 43 to 54 units during engine start.
- The Autopilot Channel A status message is expected to read within the sample range of 88 to 94 units during parking.
- During engine start, the First Officer should confirm the Standby Hydraulic status message when operating at a sample station without ground power.
- If the Standby Hydraulic is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.
- The Probe Heat quantity display is expected to read within the sample range of 35 to 39 units during a diversion.
- The Stall Warning status message that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed.

03.70.17 Crew Coordination: Primary Electrical Bus

The Center Tank Pumps advisory that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed. The Fuel Crossfeed annunciation is expected to read within the sample range of 11 to 20 units during a diversion. Both pilots will confirm any change in the Fire Detection Loop advisory and advise the other pilot when conditions permit. The Standby Instruments indication is expected to read within the sample range of 68 to 78 units during preflight.

The Autopilot Channel A advisory that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power. The pilot flying will announce any change in the Stall Warning quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will announce any change in the Brake Temperature Monitor status message and advise the other pilot before the next phase of flight. During preflight, the Captain should monitor the Fire Detection Loop annunciation if a discrepancy is observed. If the Landing Gear Indication is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Thrust Reverser advisory	46 units	Advisory only
Probe Heat switch position	86 units	Advisory only
Landing Gear Indication quantity display	58 units	Advisory only

The Brake Temperature Monitor switch position is expected to read within the sample range of 62 to 70 units during a diversion. The captain will confirm any change in the Nosewheel Steering status message and advise the other pilot when the associated caution light remains illuminated. The Wing Anti-Ice status message is expected to read within the sample range of 32 to 38 units during a diversion. Values in this manual are invented and must not be used for any operational purpose.

- The first officer will select any change in the Cabin Pressure Controller selector position and advise the other pilot when operating at a sample station without ground power.
- The Thrust Reverser quantity display that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed.
- During parking, the Captain should monitor the Window Heat selector position once the checklist item is complete.
- Refer to the related topic for additional sample context.
- The Fire Detection Loop status message is expected to read within the sample range of 18 to 27 units during approach.
- If the Oxygen Distribution is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- If the Nosewheel Steering is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.
- During preflight, the Captain should confirm the Weather Radar switch position unless directed otherwise by the Sample Operations Center.

Challenge	Response
Thrust Reverser	Armed
Autothrottle	Armed
Fire Detection Loop	Set
Weather Radar	Verified
Flap Position Indication	Set
Fuel Crossfeed	Set
Landing Gear Indication	Armed
Window Heat	Set
Cargo Smoke Detection	Set
Landing Gear Indication	Checked
Ground Proximity Monitor	As required

03.70.18 Crew Coordination: Pack Temperature Control

During preflight, both pilots should record the Stall Warning selector position when conditions permit. The Autothrottle advisory that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval. The Pack Temperature Control advisory is expected to read within the sample range of 57 to 61 units during approach. During an extended ground delay, the pilot monitoring should announce the Thrust Reverser annunciation before the next phase of flight. The relief pilot will verify any change in the Oxygen Distribution advisory and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: If the Weather Radar is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. During cruise, both pilots should cross-check the Flap Position Indication quantity display when operating at a sample station without ground power.

Condition	Sample value	Remarks
Hydraulic System A advisory	67 units	Monitor
Speedbrake Handle status message	21 units	Monitor
Autobrake Selector quantity display	28 units	Monitor
Wing Anti-Ice selector position	94 units	Refer to related topic

CAUTION: If the Autopilot Channel B is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The Traffic Advisory Display selector position that differs from the expected state requires both pilots to confirm the condition when conditions permit.

The pilot flying will select any change in the Nosewheel Steering status message and advise the other pilot if the indication does not stabilize within the sample interval. The Fire Detection Loop switch position that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The captain will announce any change in the Fire Detection Loop advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

03.70.19 Crew Coordination: Weather Radar

The Autothrottle switch position is expected to read within the sample range of 85 to 90 units during landing. Refer to the related topic for additional sample context. During parking, the pilot flying should monitor the Autopilot Channel A selector position unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection quantity display is expected to read within the sample range of 15 to 26 units during cruise. The Engine Anti-Ice status message that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center.

Both pilots will verify any change in the Traffic Advisory Display quantity display and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. The Traffic Advisory Display switch position that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. The captain will confirm any change in the Window Heat switch position and advise the other pilot before the next phase of flight. If the Stall Warning is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

The relief pilot will record any change in the Pack Temperature Control switch position and advise the other pilot when the associated caution light remains illuminated. The Hydraulic System B status message that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. During cruise, the Captain should confirm the Landing Gear Indication quantity display when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autobrake Selector indication	92 units	Refer to related topic
Landing Gear Indication annunciation	9 units	Advisory only
Transponder switch position	77 units	Advisory only
Fuel Crossfeed selector position	34 units	Advisory only
Hydraulic System B switch position	28 units	Refer to related topic
Flap Position Indication switch position	59 units	Advisory only

The Hydraulic System A status message that differs from the expected state requires the First Officer to announce the condition when conditions permit. Refer to the related topic for additional sample context. The Flap Position Indication advisory that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. During a turnaround, both pilots should brief the Autopilot Channel B switch position if a discrepancy is observed.

03.70.20 Checklist: Primary Electrical Bus

If the Pack Temperature Control is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. During a diversion, the pilot monitoring should announce the Brake Temperature Monitor switch position if a discrepancy is observed. During descent, the pilot flying should announce the Standby Instruments indication when conditions permit. The Transponder annunciation is expected to read within the sample range of 98 to 103 units during taxi. If the Cockpit Voice Recorder is inoperative, continue takeoff only after the Captain has

reviewed the associated sample guidance. The Cockpit Voice Recorder indication that differs from the expected state requires the Captain to announce the condition when conditions permit.

If the Bleed Air Supply is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the pilot monitoring should brief the Flight Management Computer quantity display unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B indication that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center.

CAUTION: During takeoff, the pilot flying should confirm the Fire Detection Loop selector position when conditions permit.

The Standby Instruments indication that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed. The Wing Anti-Ice status message that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power. The pilot monitoring will monitor any change in the Flap Position Indication annunciation and advise the other pilot if a discrepancy is observed. The pilot flying will verify any change in the Pack Temperature Control indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Stall Warning is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

During descent, the pilot monitoring should monitor the Speedbrake Handle indication before the next phase of flight. The pilot monitoring will brief any change in the Hydraulic System B switch position and advise the other pilot before the next phase of flight. If the Flap Position Indication is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. Both pilots will record any change in the Wing Anti-Ice selector position and advise the other pilot when the associated caution light remains illuminated. The Transponder advisory is expected to read within the sample range of 33 to 40 units during parking.

Values in this manual are invented and must not be used for any operational purpose. If the Nosewheel Steering is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Wing Anti-Ice annunciation is expected to read within the sample range of 15 to 22 units during cruise. The Bleed Air Supply advisory that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 93 to 99 units during climb. The pilot monitoring will confirm any change in the Hydraulic System A quantity display and advise the other pilot before the next phase of flight.

Challenge	Response
Cockpit Voice Recorder	Set
Ground Proximity Monitor	On
Autopilot Channel A	Closed
Oxygen Distribution	Verified
Cockpit Voice Recorder	Off
Thrust Reverser	Checked
Bleed Air Supply	Armed
Flight Management Computer	On
Engine Anti-Ice	As required
Autopilot Channel B	On
Autopilot Channel A	On
Cockpit Voice Recorder	Closed

Chapter 04 Supplementary Procedures

04.10 Adverse Weather

04.10.1 Checklist: Nosewheel Steering

The pilot flying will select any change in the Cabin Pressure Controller selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will brief any change in the Weather Radar selector position and advise the other pilot when operating at a sample station without ground power. The Bleed Air Supply indication is expected to read within the sample range of 23 to 27 units during a turnaround. If the Cabin Pressure Controller is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autobrake Selector switch position	15 units	Refer to related topic
Hydraulic System A advisory	82 units	Refer to related topic
Bleed Air Supply annunciation	84 units	Monitor
Hydraulic System B quantity display	65 units	Advisory only
Brake Temperature Monitor annunciation	71 units	Monitor
Fuel Crossfeed quantity display	24 units	Advisory only

The Ground Proximity Monitor advisory is expected to read within the sample range of 46 to 58 units during takeoff. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Stall Warning quantity display that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. The Autopilot Channel B switch position is expected to read within the sample range of 39 to 51 units during a maintenance-requested ground run.

If the Center Tank Pumps is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice indication that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, the First Officer should confirm the Window Heat selector position if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The pilot flying will select any change in the Bleed Air Supply indication and advise the other pilot once the checklist item is complete.

- If the Center Tank Pumps is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- The Speedbrake Handle quantity display is expected to read within the sample range of 6 to 14 units during takeoff.
- The Fuel Crossfeed advisory is expected to read within the sample range of 92 to 96 units during cruise.
- The Weather Radar switch position is expected to read within the sample range of 11 to 16 units during taxi.
- If the Brake Temperature Monitor is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

NOTE: The Autothrottle advisory is expected to read within the sample range of 55 to 62 units during an extended ground delay.

Condition	Sample value	Remarks
Bleed Air Supply annunciation	74 units	Refer to related topic
Hydraulic System B indication	29 units	Advisory only
Traffic Advisory Display indication	2 units	Refer to related topic
Nosewheel Steering annunciation	64 units	Normal
Nosewheel Steering annunciation	73 units	Refer to related topic
Ground Proximity Monitor switch position	93 units	Advisory only

04.10.2 Flow: Engine Anti-Ice

The wording here is placeholder content shaped like a procedure, not a procedure. The Ground Proximity Monitor indication is expected to read within the sample range of 64 to 73 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will brief any change in the Pack Temperature Control switch position and advise the other pilot when operating at a sample station without ground power. The first officer will select any change in the Flap Position Indication indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Thrust Reverser selector position	18 units	Normal
Primary Electrical Bus advisory	21 units	Refer to related topic
Hydraulic System A advisory	4 units	Normal
Auxiliary Power Unit annunciation	96 units	Refer to related topic
Thrust Reverser quantity display	60 units	Normal
Pack Temperature Control advisory	97 units	Advisory only

- The Cockpit Voice Recorder annunciation is expected to read within the sample range of 23 to 33 units during cruise.
- During preflight, the First Officer should record the Window Heat annunciation when conditions permit.
- The Autobrake Selector annunciation is expected to read within the sample range of 40 to 47 units during taxi.
- Refer to the related topic for additional sample context.
- The first officer will confirm any change in the Center Tank Pumps indication and advise the other pilot once the checklist item is complete.
- The Bleed Air Supply selector position that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Brake Temperature Monitor switch position	3 units	Refer to related topic
Autopilot Channel B annunciation	20 units	Normal
Center Tank Pumps indication	50 units	Advisory only
Pack Temperature Control switch position	6 units	Normal
Standby Instruments annunciation	19 units	Normal
Auxiliary Power Unit switch position	64 units	Advisory only
Speedbrake Handle indication	54 units	Refer to related topic

During engine start, both pilots should select the Wing Anti-Ice quantity display when operating at a sample station without ground power. The Wing Anti-Ice indication that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat status message that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Stall Warning selector position that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.

NOTE: During a diversion, the pilot monitoring should monitor the Cockpit Voice Recorder quantity display if a discrepancy is observed. During a turnaround, the pilot monitoring should cross-check the Traffic Advisory Display quantity display if a discrepancy is observed.

If the Standby Instruments is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Oxygen Distribution status message is expected to read within the sample range of 11 to 14 units during preflight.

If the Flap Position Indication is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. During an extended ground delay, both pilots should monitor the Fuel Crossfeed switch position unless directed otherwise by the Sample Operations Center. During takeoff, the Captain should record the Thrust Reverser quantity display when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Weather Radar advisory	46 units	Monitor
Auxiliary Power Unit annunciation	73 units	Advisory only
Wing Anti-Ice indication	15 units	Monitor

04.10.3 Briefing: Landing Gear Indication

The Engine Anti-Ice annunciation is expected to read within the sample range of 31 to 42 units during cruise. The relief pilot will record any change in the Center Tank Pumps status message and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

Refer to the related topic for additional sample context. During landing, the pilot flying should select the Autopilot Channel B indication if the indication does not stabilize within the sample interval. During a diversion, the pilot monitoring should confirm the Thrust Reverser switch position before the next phase of flight.

CAUTION: The Center Tank Pumps advisory is expected to read within the sample range of 53 to 63 units during approach.

NOTE: If the Center Tank Pumps is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Probe Heat indication that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center.

The relief pilot will record any change in the Autothrottle selector position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the relief pilot should cross-check the Primary Electrical Bus quantity display when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Autobrake Selector selector position that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated.

The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, both pilots should select the Autopilot Channel B selector position when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

04.10.4 Verification: Pack Temperature Control

The Probe Heat quantity display is expected to read within the sample range of 10 to 16 units during an extended ground delay. Both pilots will verify any change in the Hydraulic System A status message and advise the other pilot when the associated caution light remains illuminated. During an extended ground delay, both pilots should cross-check the Nosewheel Steering quantity display if a discrepancy is observed. If the Primary Electrical Bus is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Hydraulic System A indication that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power.

The Center Tank Pumps quantity display is expected to read within the sample range of 33 to 41 units during climb. The Thrust Reverser selector position is expected to read within the sample range of 18 to 26 units during climb. During an extended ground delay, the First Officer should monitor the Traffic Advisory Display status message before the next phase of flight. The Cabin Pressure Controller selector position that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

- The Auxiliary Power Unit quantity display that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.
- Values in this manual are invented and must not be used for any operational purpose.
- The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Flight Management Computer quantity display that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval.

If the Cockpit Voice Recorder is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The first officer will announce any change in the Window Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Engine Anti-Ice advisory is expected to read within the sample range of 6 to 14 units during parking. The Autopilot Channel A selector position is expected to read within the sample range of 90 to 100 units during engine start. If the Standby Instruments is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

CAUTION: If the Autopilot Channel A is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Nosewheel Steering is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. During an extended ground delay, the relief pilot should verify the Window Heat quantity display if the indication does not stabilize within the sample interval. The Primary Electrical Bus indication that differs from the expected state requires the Captain to confirm the condition before the next phase of flight. If the Standby Instruments is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

04.10.5 Crew Coordination: Auxiliary Power Unit

The Autobrake Selector advisory that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. If the Hydraulic System B is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Cargo Smoke Detection status message is expected to read within the sample range of 24 to 35 units during a maintenance-requested ground run.

If the Brake Temperature Monitor is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will record any change in the Hydraulic

System B status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Landing Gear Indication status message is expected to read within the sample range of 93 to 102 units during descent.

Condition	Sample value	Remarks
Cabin Pressure Controller annunciation	35 units	Normal
Thrust Reverser quantity display	68 units	Normal
Primary Electrical Bus quantity display	59 units	Monitor
Standby Hydraulic selector position	35 units	Advisory only
Nosewheel Steering switch position	67 units	Monitor
Landing Gear Indication quantity display	3 units	Normal

CAUTION: The Weather Radar switch position is expected to read within the sample range of 93 to 99 units during an extended ground delay.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Autothrottle is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. If the Window Heat is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel B indication is expected to read within the sample range of 18 to 29 units during parking. The Fuel Crossfeed advisory that differs from the expected state requires the First Officer to verify the condition when conditions permit. If the Ground Proximity Monitor is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

Both pilots will monitor any change in the Hydraulic System A quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display advisory that differs from the expected state requires the relief pilot to verify the condition if a discrepancy is observed. The Hydraulic System B quantity display is expected to read within the sample range of 50 to 61 units during an extended ground delay. The Weather Radar switch position is expected to read within the sample range of 62 to 67 units during takeoff. The Autothrottle quantity display is expected to read within the sample range of 21 to 33 units during takeoff. The pilot monitoring will announce any change in the Oxygen Distribution annunciation and advise the other pilot when conditions permit.

04.10.6 Flow: Brake Temperature Monitor

This text is fictional and exists only to give the prototype realistic volume and structure. The Brake Temperature Monitor status message that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. During takeoff, the relief pilot should cross-check the Hydraulic System B selector position if the indication does not stabilize within the sample interval.

Refer to the related topic for additional sample context. The relief pilot will select any change in the Window Heat switch position and advise the other pilot when conditions permit. The relief pilot will brief any change in the Autobrake Selector annunciation and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. If the Oxygen Distribution is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Brake Temperature Monitor switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The Thrust Reverser switch position is expected to read within the sample range of 16 to 27 units during descent. The relief pilot will confirm any change in the Landing Gear Indication advisory and advise the other pilot once the checklist item is complete.

Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. The Cockpit Voice Recorder status message that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center. The Landing Gear Indication switch position is

expected to read within the sample range of 68 to 71 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure. The Cargo Smoke Detection status message is expected to read within the sample range of 76 to 86 units during an extended ground delay.

The Nosewheel Steering indication that differs from the expected state requires both pilots to brief the condition unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice annunciation that differs from the expected state requires both pilots to record the condition if a discrepancy is observed. The Stall Warning status message that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. During descent, both pilots should cross-check the Oxygen Distribution switch position once the checklist item is complete. During parking, the Captain should record the Weather Radar advisory when operating at a sample station without ground power.

Refer to the related topic for additional sample context. During climb, the pilot flying should verify the Standby Instruments selector position when conditions permit. The Pack Temperature Control switch position that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will brief any change in the Engine Anti-Ice indication and advise the other pilot when operating at a sample station without ground power. During preflight, the First Officer should cross-check the Brake Temperature Monitor selector position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Engine Anti-Ice annunciation	94 units	Refer to related topic
Thrust Reverser indication	90 units	Refer to related topic
Cockpit Voice Recorder selector position	52 units	Advisory only

04.10.7 Crew Coordination: Transponder

The pilot monitoring will record any change in the Stall Warning indication and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will announce any change in the Speedbrake Handle status message and advise the other pilot when the associated caution light remains illuminated. The Cockpit Voice Recorder annunciation that differs from the expected state requires the First Officer to monitor the condition if the indication does not stabilize within the sample interval. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The Nosewheel Steering switch position is expected to read within the sample range of 36 to 46 units during taxi. If the Brake Temperature Monitor is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The captain will monitor any change in the Fire Detection Loop switch position and advise the other pilot when conditions permit.

- Values in this manual are invented and must not be used for any operational purpose.
- Values in this manual are invented and must not be used for any operational purpose.
- The pilot flying will brief any change in the Autobrake Selector annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Oxygen Distribution is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- During preflight, the pilot monitoring should announce the Ground Proximity Monitor status message when the associated caution light remains illuminated.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The captain will cross-check any change in the Stall Warning status message and advise the other pilot if the indication does not stabilize within the sample interval.

- The Standby Hydraulic status message is expected to read within the sample range of 3 to 14 units during taxi.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Standby Instruments status message that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed.

04.10.8 Crew Coordination: Flight Management Computer

The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, the relief pilot should verify the Cabin Pressure Controller indication if a discrepancy is observed. If the Engine Anti-Ice is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Autopilot Channel B advisory is expected to read within the sample range of 58 to 61 units during cruise. During an extended ground delay, both pilots should announce the Hydraulic System B advisory once the checklist item is complete. The Oxygen Distribution quantity display that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval.

During engine start, the First Officer should brief the Stall Warning advisory when the associated caution light remains illuminated. The Hydraulic System B advisory that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. During taxi, the relief pilot should confirm the Speedbrake Handle selector position before the next phase of flight. The pilot flying will confirm any change in the Engine Anti-Ice annunciation and advise the other pilot once the checklist item is complete.

The Autopilot Channel A selector position that differs from the expected state requires both pilots to select the condition once the checklist item is complete. If the Fuel Crossfeed is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Pack Temperature Control switch position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Cargo Smoke Detection quantity display	42 units	Refer to related topic
Cabin Pressure Controller indication	73 units	Advisory only
Cabin Pressure Controller advisory	6 units	Advisory only
Cabin Pressure Controller status message	46 units	Normal
Cargo Smoke Detection quantity display	52 units	Normal
Bleed Air Supply selector position	57 units	Normal
Center Tank Pumps selector position	52 units	Normal

Condition	Sample value	Remarks
Cockpit Voice Recorder selector position	13 units	Monitor
Traffic Advisory Display annunciation	89 units	Normal
Bleed Air Supply indication	76 units	Normal
Traffic Advisory Display advisory	28 units	Advisory only

The Primary Electrical Bus status message that differs from the expected state requires the Captain to select the condition if a discrepancy is observed. Both pilots will select any change in the Flight Management Computer advisory and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will cross-check any change in the Standby Instruments switch position and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

04.10.9 Crew Coordination: Standby Hydraulic

The Traffic Advisory Display advisory is expected to read within the sample range of 4 to 13 units during preflight. If the Probe Heat is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. During preflight, the Captain should monitor the Brake Temperature Monitor switch position when operating at a sample station without ground power. The Auxiliary Power Unit annunciation that differs from the expected state requires both pilots to record the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. If the Stall Warning is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. During climb, the First Officer should confirm the Cockpit Voice Recorder selector position when operating at a sample station without ground power.

The Cockpit Voice Recorder selector position is expected to read within the sample range of 57 to 62 units during a diversion. The first officer will record any change in the Autobrake Selector indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed advisory is expected to read within the sample range of 73 to 84 units during engine start.

- The Autobrake Selector annunciation that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center.
- Both pilots will brief any change in the Autopilot Channel A advisory and advise the other pilot when conditions permit.
- If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.
- If the Cabin Pressure Controller is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

The Speedbrake Handle indication is expected to read within the sample range of 88 to 92 units during a diversion. During cruise, the relief pilot should brief the Ground Proximity Monitor quantity display if the indication does not stabilize within the sample interval. The Standby Instruments switch position is expected to read within the sample range of 6 to 14 units during approach. If the Nosewheel Steering is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. During a maintenance-requested ground run, the relief pilot should confirm the Autobrake Selector switch position when conditions permit.

The Center Tank Pumps status message is expected to read within the sample range of 15 to 18 units during climb. The Center Tank Pumps selector position is expected to read within the sample range of 89 to 98 units during engine start. The Cockpit Voice Recorder selector position is expected to read within the sample range of 4 to 16 units during a diversion. During taxi, the pilot flying should announce the Brake Temperature Monitor status message when the associated caution light remains illuminated. The Pack Temperature Control status message is expected to read within the sample range of 60 to 63 units during descent.

Condition	Sample value	Remarks
Landing Gear Indication quantity display	67 units	Normal
Cabin Pressure Controller advisory	33 units	Advisory only
Weather Radar advisory	62 units	Refer to related topic
Cargo Smoke Detection switch position	47 units	Normal

04.10.10 Checklist: Cabin Pressure Controller

If the Nosewheel Steering is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Hydraulic System A selector position that differs from the expected state requires the Captain to verify

the condition before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The pilot monitoring will record any change in the Autothrottle switch position and advise the other pilot if the indication does not stabilize within the sample interval. During engine start, the pilot monitoring should confirm the Hydraulic System A status message unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Center Tank Pumps is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

NOTE: The captain will announce any change in the Stall Warning switch position and advise the other pilot before the next phase of flight. If the Hydraulic System A is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

NOTE: The Weather Radar switch position that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Oxygen Distribution annunciation	58 units	Monitor
Wing Anti-Ice advisory	7 units	Refer to related topic
Autopilot Channel B indication	72 units	Advisory only
Autopilot Channel B status message	71 units	Refer to related topic

CAUTION: If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The pilot monitoring will record any change in the Hydraulic System B status message and advise the other pilot if a discrepancy is observed.

NOTE: The Cabin Pressure Controller advisory that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, the relief pilot should record the Flap Position Indication annunciation unless directed otherwise by the Sample Operations Center. The Engine Anti-Ice selector position that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. The Autopilot Channel A indication that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete.

CAUTION: The Speedbrake Handle indication is expected to read within the sample range of 84 to 90 units during descent. Refer to the related topic for additional sample context.

04.10.11 Briefing: Pack Temperature Control

If the Landing Gear Indication is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will select any change in the Autothrottle indication and advise the other pilot unless directed otherwise by the Sample Operations Center. During an extended ground delay, the relief pilot should record the Autothrottle quantity display if a discrepancy is observed.

NOTE: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Probe Heat selector position	80 units	Normal
Standby Instruments quantity display	76 units	Monitor
Cockpit Voice Recorder annunciation	23 units	Refer to related topic
Flight Management Computer status message	79 units	Monitor

Nosewheel Steering quantity display	58 units	Advisory only
Stall Warning advisory	53 units	Refer to related topic

- Values in this manual are invented and must not be used for any operational purpose.
- The Flight Management Computer annunciation is expected to read within the sample range of 14 to 25 units during a maintenance-requested ground run.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Engine Anti-Ice status message is expected to read within the sample range of 3 to 6 units during an extended ground delay.
- The pilot flying will confirm any change in the Brake Temperature Monitor annunciation and advise the other pilot when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Pack Temperature Control switch position that differs from the expected state requires both pilots to monitor the condition before the next phase of flight.
- During a diversion, the pilot flying should cross-check the Speedbrake Handle advisory when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Fire Detection Loop quantity display is expected to read within the sample range of 11 to 22 units during parking.
- The Speedbrake Handle quantity display is expected to read within the sample range of 23 to 34 units during taxi.
- If the Cargo Smoke Detection is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

The pilot monitoring will record any change in the Brake Temperature Monitor switch position and advise the other pilot when operating at a sample station without ground power. The Pack Temperature Control annunciation is expected to read within the sample range of 49 to 53 units during taxi. The Engine Anti-Ice annunciation is expected to read within the sample range of 38 to 46 units during preflight. During cruise, the pilot monitoring should announce the Fuel Crossfeed annunciation if a discrepancy is observed.

- The Auxiliary Power Unit indication is expected to read within the sample range of 88 to 94 units during parking.
- The captain will cross-check any change in the Flap Position Indication switch position and advise the other pilot if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Speedbrake Handle is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- The Center Tank Pumps advisory that differs from the expected state requires the Captain to brief the condition when conditions permit.
- The Ground Proximity Monitor switch position that differs from the expected state requires both pilots to verify the condition when conditions permit.

04.10.12 Crew Coordination: Oxygen Distribution

The Oxygen Distribution selector position is expected to read within the sample range of 93 to 101 units during engine start. Values in this manual are invented and must not be used for any operational purpose. During parking, the pilot monitoring should brief the Flight Management Computer selector position once the checklist item is

complete. During parking, the pilot monitoring should select the Flight Management Computer annunciation when the associated caution light remains illuminated.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- The Standby Hydraulic status message that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete.

CAUTION: The Standby Hydraulic switch position that differs from the expected state requires the Captain to select the condition once the checklist item is complete. The pilot flying will monitor any change in the Brake Temperature Monitor advisory and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Weather Radar selector position	56 units	Refer to related topic
Landing Gear Indication indication	45 units	Refer to related topic
Standby Instruments quantity display	57 units	Monitor
Thrust Reverser status message	48 units	Normal
Stall Warning status message	91 units	Normal

During preflight, the pilot monitoring should record the Oxygen Distribution annunciation when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The first officer will cross-check any change in the Flight Management Computer annunciation and advise the other pilot before the next phase of flight.

During engine start, the relief pilot should confirm the Transponder selector position when conditions permit. The Pack Temperature Control switch position is expected to read within the sample range of 68 to 72 units during landing. During climb, the relief pilot should verify the Autobrake Selector annunciation when conditions permit. The Hydraulic System A switch position is expected to read within the sample range of 35 to 40 units during climb. The Nosewheel Steering switch position that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. During cruise, the First Officer should verify the Stall Warning advisory when operating at a sample station without ground power.

NOTE: The Cabin Pressure Controller indication that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center.

CAUTION: During taxi, the First Officer should record the Bleed Air Supply status message when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. The relief pilot will cross-check any change in the Autobrake Selector annunciation and advise the other pilot if a discrepancy is observed. The Cockpit Voice Recorder quantity display that differs from the expected state requires the Captain to confirm the condition before the next phase of flight. During taxi, both pilots should brief the Cockpit Voice Recorder status message before the next phase of flight.

04.10.13 Flow: Hydraulic System A

The Autopilot Channel A switch position that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The Speedbrake Handle switch position that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. The Nosewheel Steering quantity display is expected to read within the sample range of 63 to 75 units during parking. The Speedbrake Handle advisory that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power.

- The first officer will cross-check any change in the Autopilot Channel B indication and advise the other pilot if a discrepancy is observed.
- The pilot monitoring will verify any change in the Primary Electrical Bus status message and advise the other pilot once the checklist item is complete.
- The pilot monitoring will verify any change in the Probe Heat indication and advise the other pilot when conditions permit.
- The Brake Temperature Monitor advisory is expected to read within the sample range of 15 to 18 units during takeoff.
- If the Flight Management Computer is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

The Brake Temperature Monitor status message that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval. The Wing Anti-Ice quantity display that differs from the expected state requires the relief pilot to record the condition before the next phase of flight. During a diversion, the pilot monitoring should cross-check the Cargo Smoke Detection status message when operating at a sample station without ground power. If the Autothrottle is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Cargo Smoke Detection selector position is expected to read within the sample range of 27 to 30 units during a diversion. If the Fire Detection Loop is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Standby Instruments selector position	46 units	Normal
Landing Gear Indication status message	54 units	Advisory only
Wing Anti-Ice annunciation	93 units	Advisory only
Fire Detection Loop selector position	90 units	Refer to related topic
Hydraulic System B annunciation	36 units	Refer to related topic
Cockpit Voice Recorder annunciation	38 units	Monitor

04.10.14 Verification: Fire Detection Loop

Refer to the related topic for additional sample context. The Cabin Pressure Controller status message that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed. The Landing Gear Indication annunciation is expected to read within the sample range of 16 to 21 units during an extended ground delay. During taxi, the First Officer should select the Autopilot Channel A quantity display if the indication does not stabilize within the sample interval.

- Both pilots will confirm any change in the Hydraulic System A indication and advise the other pilot when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During climb, the relief pilot should cross-check the Standby Instruments advisory if a discrepancy is observed.
- The Landing Gear Indication indication that differs from the expected state requires the First Officer to select the condition before the next phase of flight.
- The Weather Radar advisory that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated.
- The Window Heat quantity display is expected to read within the sample range of 57 to 66 units during approach.

The Traffic Advisory Display selector position that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. The Oxygen Distribution annunciation is expected to read within the sample range of 56 to 68 units during a diversion. The Landing Gear Indication status message that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. During engine start, the Captain should cross-check the Fire Detection Loop annunciation if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will confirm any change in the Primary Electrical Bus selector position and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Hydraulic System B switch position	15 units	Advisory only
Oxygen Distribution selector position	6 units	Advisory only
Thrust Reverser indication	16 units	Normal

- Values in this manual are invented and must not be used for any operational purpose.
- The first officer will announce any change in the Fuel Crossfeed switch position and advise the other pilot once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- During cruise, the Captain should record the Autopilot Channel A selector position when conditions permit.
- The Cargo Smoke Detection indication that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete.
- The first officer will record any change in the Bleed Air Supply status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

Values in this manual are invented and must not be used for any operational purpose. If the Standby Hydraulic is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. During landing, the First Officer should monitor the Hydraulic System A status message when conditions permit. During taxi, the pilot monitoring should announce the Autopilot Channel B selector position once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

The Auxiliary Power Unit switch position is expected to read within the sample range of 52 to 59 units during taxi. The Hydraulic System B annunciation that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

04.10.15 Briefing: Thrust Reverser

The captain will select any change in the Stall Warning annunciation and advise the other pilot before the next phase of flight. During taxi, the Captain should announce the Center Tank Pumps quantity display when conditions permit. If the Standby Hydraulic is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

- If the Hydraulic System A is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- The Standby Hydraulic selector position is expected to read within the sample range of 81 to 89 units during climb.
- Refer to the related topic for additional sample context.
- During cruise, the First Officer should record the Flap Position Indication selector position unless directed otherwise by the Sample Operations Center.
- The Stall Warning advisory is expected to read within the sample range of 6 to 17 units during taxi.
- Refer to the related topic for additional sample context.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During descent, both pilots should verify the Flap Position Indication status message when conditions permit.

During an extended ground delay, both pilots should announce the Standby Instruments selector position when conditions permit. The Ground Proximity Monitor indication is expected to read within the sample range of 48 to 53 units during a diversion. If the Standby Hydraulic is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Auxiliary Power Unit selector position is expected to read within the sample range of 36 to 45 units during a maintenance-requested ground run. The Center Tank Pumps quantity display that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete.

During preflight, the pilot flying should brief the Stall Warning quantity display when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. During descent, both pilots should verify the Nosewheel Steering status message if the indication does not stabilize within the sample interval.

04.10.16 Crew Coordination: Autopilot Channel B

The Hydraulic System A annunciation is expected to read within the sample range of 60 to 64 units during engine start. The Probe Heat annunciation is expected to read within the sample range of 80 to 87 units during descent. The Stall Warning selector position that differs from the expected state requires the First Officer to monitor the condition when conditions permit. The Autopilot Channel A switch position is expected to read within the sample range of 24 to 34 units during cruise.

The Weather Radar annunciation is expected to read within the sample range of 41 to 48 units during parking. The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat status message that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Bleed Air Supply status message	40 units	Refer to related topic
Oxygen Distribution annunciation	4 units	Normal
Transponder switch position	47 units	Normal
Stall Warning advisory	38 units	Monitor
Autothrottle selector position	56 units	Normal
Thrust Reverser quantity display	12 units	Advisory only

If the Ground Proximity Monitor is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Brake Temperature Monitor selector position is expected to read within the sample range of 36 to 42 units during a maintenance-requested ground run. If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

- The relief pilot will announce any change in the Nosewheel Steering indication and advise the other pilot if the indication does not stabilize within the sample interval.
- The Pack Temperature Control indication is expected to read within the sample range of 76 to 87 units during engine start.
- Refer to the related topic for additional sample context.

If the Weather Radar is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Transponder advisory is expected to read within the sample range of 69 to 74 units during engine start. This text is fictional and exists only to give the prototype realistic volume and structure. The Bleed Air Supply annunciation is expected to read within the sample range of 27 to 37 units during a diversion. The Hydraulic System

A advisory that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

04.10.17 Flow: Bleed Air Supply

The Fuel Crossfeed status message is expected to read within the sample range of 17 to 28 units during a diversion. The Ground Proximity Monitor switch position is expected to read within the sample range of 81 to 93 units during a diversion. The pilot flying will cross-check any change in the Autopilot Channel A selector position and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will verify any change in the Flap Position Indication advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

Refer to the related topic for additional sample context. If the Autopilot Channel A is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A quantity display that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. The Autothrottle advisory that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power.

CAUTION: Both pilots will select any change in the Traffic Advisory Display annunciation and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Fuel Crossfeed status message	68 units	Monitor
Standby Instruments quantity display	7 units	Refer to related topic
Hydraulic System B advisory	26 units	Advisory only
Window Heat annunciation	86 units	Monitor

Condition	Sample value	Remarks
Weather Radar annunciation	85 units	Normal
Hydraulic System B quantity display	75 units	Refer to related topic
Center Tank Pumps advisory	66 units	Monitor
Nosewheel Steering quantity display	79 units	Normal
Bleed Air Supply advisory	70 units	Refer to related topic
Thrust Reverser quantity display	44 units	Monitor

If the Autobrake Selector is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Standby Hydraulic quantity display is expected to read within the sample range of 72 to 75 units during an extended ground delay. The Oxygen Distribution indication that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated. The Probe Heat selector position is expected to read within the sample range of 14 to 17 units during taxi.

Refer to the related topic for additional sample context. The Transponder advisory is expected to read within the sample range of 90 to 93 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Center Tank Pumps quantity display	8 units	Monitor
Standby Instruments selector position	58 units	Refer to related topic
Standby Hydraulic indication	75 units	Advisory only
Flap Position Indication selector position	21 units	Monitor

The Flight Management Computer indication that differs from the expected state requires the First Officer to select the condition when conditions permit. The first officer will confirm any change in the Probe Heat advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During approach, the pilot flying should record the Brake Temperature Monitor advisory when operating at a sample station without ground power.

04.10.18 Briefing: Nosewheel Steering

Both pilots will select any change in the Fire Detection Loop selector position and advise the other pilot when operating at a sample station without ground power. The Nosewheel Steering switch position is expected to read within the sample range of 9 to 18 units during cruise. If the Autopilot Channel A is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

- The Wing Anti-Ice indication that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated.
- The captain will cross-check any change in the Flight Management Computer advisory and advise the other pilot when the associated caution light remains illuminated.
- The Pack Temperature Control quantity display is expected to read within the sample range of 32 to 39 units during engine start.
- The Standby Hydraulic switch position is expected to read within the sample range of 76 to 80 units during a maintenance-requested ground run.
- The relief pilot will record any change in the Weather Radar advisory and advise the other pilot once the checklist item is complete.

Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. If the Center Tank Pumps is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Standby Hydraulic selector position is expected to read within the sample range of 19 to 25 units during climb. Values in this manual are invented and must not be used for any operational purpose. The captain will select any change in the Primary Electrical Bus status message and advise the other pilot if a discrepancy is observed.

The Weather Radar advisory is expected to read within the sample range of 16 to 26 units during a maintenance-requested ground run. During an extended ground delay, the Captain should select the Hydraulic System A status message when conditions permit. The first officer will monitor any change in the Engine Anti-Ice switch position and advise the other pilot when the associated caution light remains illuminated.

During takeoff, the First Officer should brief the Thrust Reverser indication when operating at a sample station without ground power. If the Weather Radar is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The Primary Electrical Bus switch position is expected to read within the sample range of 27 to 35 units during descent.

Condition	Sample value	Remarks
Window Heat indication	48 units	Refer to related topic
Flap Position Indication selector position	55 units	Refer to related topic
Autopilot Channel A selector position	66 units	Refer to related topic
Autopilot Channel A quantity display	46 units	Advisory only
Autopilot Channel B switch position	60 units	Advisory only
Autopilot Channel B status message	12 units	Advisory only

04.10.19 Callouts: Wing Anti-Ice

During engine start, the relief pilot should confirm the Cockpit Voice Recorder advisory if the indication does not stabilize within the sample interval. If the Ground Proximity Monitor is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The first officer will announce any change in the Traffic Advisory Display switch position and advise the other pilot once the checklist item is complete. During an extended ground delay, the Captain should monitor the Brake Temperature Monitor selector position when operating at a sample station without ground power. If the Primary Electrical Bus is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

NOTE: The Hydraulic System B advisory that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

The first officer will verify any change in the Probe Heat indication and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

NOTE: The Brake Temperature Monitor indication is expected to read within the sample range of 16 to 23 units during an extended ground delay.

CAUTION: If the Cabin Pressure Controller is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. During cruise, the relief pilot should cross-check the Oxygen Distribution selector position when operating at a sample station without ground power.

If the Brake Temperature Monitor is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The first officer will select any change in the Cockpit Voice Recorder selector position and advise the other pilot when the associated caution light remains illuminated. The captain will brief any change in the Autopilot Channel B selector position and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Nosewheel Steering selector position	47 units	Refer to related topic
Wing Anti-Ice status message	56 units	Monitor
Flap Position Indication advisory	93 units	Advisory only
Autopilot Channel B annunciation	3 units	Monitor
Landing Gear Indication annunciation	80 units	Advisory only
Fuel Crossfeed selector position	90 units	Advisory only
Flap Position Indication selector position	10 units	Advisory only

The relief pilot will confirm any change in the Fire Detection Loop annunciation and advise the other pilot when conditions permit. The captain will announce any change in the Hydraulic System A quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will monitor any change in the Center Tank Pumps selector position and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder status message that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power. The pilot monitoring will verify any change in the Autobrake Selector quantity display and advise the other pilot when conditions permit.

04.10.20 Checklist: Oxygen Distribution

Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A advisory that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. If the Autopilot Channel B is inoperative, continue takeoff only after the pilot flying

has reviewed the associated sample guidance. During engine start, the Captain should monitor the Engine Anti-Ice selector position if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Stall Warning annunciation	42 units	Refer to related topic
Cockpit Voice Recorder annunciation	8 units	Normal
Autothrottle status message	25 units	Refer to related topic
Standby Instruments advisory	66 units	Refer to related topic
Hydraulic System A advisory	33 units	Normal
Autothrottle switch position	80 units	Advisory only

The Pack Temperature Control annunciation is expected to read within the sample range of 63 to 70 units during climb. The first officer will record any change in the Landing Gear Indication selector position and advise the other pilot when conditions permit. The captain will select any change in the Speedbrake Handle annunciation and advise the other pilot when conditions permit. The Ground Proximity Monitor annunciation that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight.

The Speedbrake Handle quantity display is expected to read within the sample range of 35 to 42 units during a maintenance-requested ground run. The Fuel Crossfeed advisory that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. If the Bleed Air Supply is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Center Tank Pumps quantity display is expected to read within the sample range of 64 to 75 units during climb.

The relief pilot will monitor any change in the Cabin Pressure Controller selector position and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Standby Instruments is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

The pilot monitoring will record any change in the Pack Temperature Control annunciation and advise the other pilot once the checklist item is complete. The first officer will confirm any change in the Engine Anti-Ice annunciation and advise the other pilot when conditions permit. The pilot monitoring will announce any change in the Traffic Advisory Display indication and advise the other pilot when the associated caution light remains illuminated. During takeoff, both pilots should cross-check the Autopilot Channel B annunciation when the associated caution light remains illuminated. The Nosewheel Steering selector position is expected to read within the sample range of 37 to 49 units during an extended ground delay. The Fuel Crossfeed annunciation that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated.

This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor status message is expected to read within the sample range of 56 to 66 units during preflight. The relief pilot will monitor any change in the Engine Anti-Ice advisory and advise the other pilot once the checklist item is complete. During climb, the First Officer should record the Flap Position Indication status message unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

04.10.21 Briefing: Cabin Pressure Controller

The Autothrottle selector position is expected to read within the sample range of 65 to 68 units during descent. During cruise, the pilot flying should announce the Cockpit Voice Recorder status message before the next phase of flight. The Ground Proximity Monitor switch position that differs from the expected state requires the First Officer to verify the condition when conditions permit.

The Cargo Smoke Detection advisory is expected to read within the sample range of 5 to 8 units during a diversion. During parking, the First Officer should select the Auxiliary Power Unit status message unless directed otherwise by

the Sample Operations Center. The relief pilot will brief any change in the Cockpit Voice Recorder indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will announce any change in the Fuel Crossfeed annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Flight Management Computer is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.
- The pilot monitoring will confirm any change in the Wing Anti-Ice status message and advise the other pilot when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Autothrottle is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.
- If the Flap Position Indication is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Both pilots will select any change in the Engine Anti-Ice switch position and advise the other pilot when conditions permit.

CAUTION: The Probe Heat status message that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated. If the Fire Detection Loop is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Landing Gear Indication annunciation	71 units	Refer to related topic
Window Heat status message	1 units	Normal
Probe Heat status message	35 units	Refer to related topic
Brake Temperature Monitor annunciation	7 units	Normal
Weather Radar advisory	99 units	Advisory only

04.10.22 Briefing: Brake Temperature Monitor

This text is fictional and exists only to give the prototype realistic volume and structure. If the Probe Heat is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Autothrottle quantity display that differs from the expected state requires the relief pilot to brief the condition when conditions permit. During descent, both pilots should confirm the Bleed Air Supply annunciation when conditions permit.

The captain will cross-check any change in the Stall Warning indication and advise the other pilot when conditions permit. The Probe Heat status message that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. If the Oxygen Distribution is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

- The Cockpit Voice Recorder quantity display that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center.
- Both pilots will monitor any change in the Speedbrake Handle selector position and advise the other pilot when operating at a sample station without ground power.

- The Traffic Advisory Display advisory is expected to read within the sample range of 37 to 42 units during climb.
- The relief pilot will monitor any change in the Transponder advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. The Wing Anti-Ice indication is expected to read within the sample range of 85 to 93 units during a maintenance-requested ground run. The first officer will monitor any change in the Center Tank Pumps advisory and advise the other pilot when the associated caution light remains illuminated. The pilot flying will cross-check any change in the Weather Radar status message and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Primary Electrical Bus annunciation	27 units	Refer to related topic
Brake Temperature Monitor status message	19 units	Monitor
Ground Proximity Monitor selector position	27 units	Normal

NOTE: During climb, both pilots should brief the Ground Proximity Monitor switch position when the associated caution light remains illuminated.

CAUTION: The Fire Detection Loop indication that differs from the expected state requires the pilot monitoring to select the condition when conditions permit.

04.10.23 Callouts: Flap Position Indication

If the Engine Anti-Ice is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel A annunciation that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. The captain will cross-check any change in the Autopilot Channel B advisory and advise the other pilot when conditions permit.

CAUTION: Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

- The Flight Management Computer advisory that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed.
- During cruise, both pilots should cross-check the Fuel Crossfeed advisory if the indication does not stabilize within the sample interval.
- During engine start, both pilots should select the Autopilot Channel A quantity display unless directed otherwise by the Sample Operations Center.
- The Bleed Air Supply indication that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete.
- The Fire Detection Loop quantity display is expected to read within the sample range of 46 to 53 units during an extended ground delay.

The Flight Management Computer status message that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed. The Thrust Reverser switch position is expected to read within the sample range of 86 to 97 units during cruise. The Thrust Reverser indication is expected to read within the sample range of 55 to 62 units during preflight. The pilot monitoring will monitor any change in the Oxygen Distribution selector position and advise the other pilot if a discrepancy is observed. The Oxygen Distribution quantity display that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed.

NOTE: Refer to the related topic for additional sample context. The Oxygen Distribution quantity display is expected to read within the sample range of 24 to 34 units during engine start.

NOTE: During landing, both pilots should cross-check the Flight Management Computer advisory when conditions permit.

The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, the pilot monitoring should announce the Primary Electrical Bus advisory before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. See 18.20.4 Center Tank Pumps Status Messages.

04.10.24 Briefing: Wing Anti-Ice

The Autopilot Channel B selector position is expected to read within the sample range of 15 to 19 units during a diversion. If the Flight Management Computer is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. During a maintenance-requested ground run, both pilots should record the Autothrottle selector position when the associated caution light remains illuminated. The Center Tank Pumps indication is expected to read within the sample range of 16 to 25 units during engine start.

The captain will cross-check any change in the Ground Proximity Monitor switch position and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will record any change in the Primary Electrical Bus switch position and advise the other pilot once the checklist item is complete.

CAUTION: The Nosewheel Steering selector position that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During preflight, the Captain should cross-check the Traffic Advisory Display selector position if the indication does not stabilize within the sample interval. If the Brake Temperature Monitor is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

The Brake Temperature Monitor advisory that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments quantity display that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed selector position that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. See 03.20.24 Checklist: Hydraulic System A.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. During climb, both pilots should cross-check the Autothrottle quantity display before the next phase of flight.

NOTE: During approach, both pilots should announce the Brake Temperature Monitor status message when conditions permit.

CAUTION: The Flight Management Computer advisory that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval. The first officer will announce any change in the Primary Electrical Bus switch position and advise the other pilot once the checklist item is complete.

04.10.25 Briefing: Autopilot Channel A

If the Auxiliary Power Unit is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel A quantity display that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed.

- If the Flight Management Computer is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.
- During an extended ground delay, the pilot flying should record the Ground Proximity Monitor advisory once the checklist item is complete.
- During descent, the First Officer should cross-check the Probe Heat advisory when operating at a sample station without ground power.
- If the Pack Temperature Control is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- The captain will select any change in the Hydraulic System A indication and advise the other pilot when the associated caution light remains illuminated.

The relief pilot will confirm any change in the Oxygen Distribution quantity display and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Traffic Advisory Display status message that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated. The Pack Temperature Control status message is expected to read within the sample range of 81 to 84 units during an extended ground delay. During a diversion, the First Officer should record the Stall Warning quantity display unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection indication is expected to read within the sample range of 13 to 21 units during landing.

NOTE: The Center Tank Pumps selector position that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval.

CAUTION: The pilot monitoring will cross-check any change in the Speedbrake Handle indication and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Standby Hydraulic advisory	64 units	Normal
Weather Radar quantity display	30 units	Advisory only
Cabin Pressure Controller status message	65 units	Advisory only
Autobrake Selector annunciation	84 units	Refer to related topic
Engine Anti-Ice switch position	98 units	Normal
Probe Heat annunciation	80 units	Monitor

Condition	Sample value	Remarks
Primary Electrical Bus selector position	69 units	Refer to related topic
Stall Warning selector position	44 units	Monitor
Autopilot Channel A selector position	62 units	Advisory only
Standby Instruments indication	96 units	Monitor
Autothrottle switch position	58 units	Advisory only
Standby Instruments selector position	83 units	Normal
Standby Instruments switch position	43 units	Advisory only

CAUTION: The Flap Position Indication selector position that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated. The pilot monitoring will brief any change in the Hydraulic System A status message and advise the other pilot when conditions permit.

04.20 Cold Weather Operations

04.20.1 Callouts: Primary Electrical Bus

During engine start, both pilots should monitor the Weather Radar advisory if a discrepancy is observed. If the Oxygen Distribution is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Flight Management Computer switch position is expected to read within the sample range of 81 to 93 units during takeoff. If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

- If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.
- The Engine Anti-Ice quantity display that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated.
- The Pack Temperature Control status message that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete.
- The captain will record any change in the Cargo Smoke Detection selector position and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: During preflight, both pilots should brief the Flap Position Indication switch position before the next phase of flight. The Auxiliary Power Unit advisory that differs from the expected state requires the relief pilot to select the condition before the next phase of flight.

Values in this manual are invented and must not be used for any operational purpose. Both pilots will announce any change in the Cargo Smoke Detection switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will verify any change in the Fuel Crossfeed status message and advise the other pilot when the associated caution light remains illuminated. The relief pilot will cross-check any change in the Cabin Pressure Controller switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The Autothrottle status message that differs from the expected state requires the First Officer to monitor the condition when conditions permit.
- During approach, the pilot flying should confirm the Ground Proximity Monitor status message if the indication does not stabilize within the sample interval.
- The pilot monitoring will select any change in the Ground Proximity Monitor selector position and advise the other pilot if a discrepancy is observed.

04.20.2 Verification: Cargo Smoke Detection

The Speedbrake Handle quantity display is expected to read within the sample range of 14 to 20 units during an extended ground delay. If the Speedbrake Handle is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Autobrake Selector switch position that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.

CAUTION: Refer to the related topic for additional sample context.

The captain will monitor any change in the Autopilot Channel B indication and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Traffic Advisory Display switch position that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to

give the prototype realistic volume and structure. During a maintenance-requested ground run, the relief pilot should verify the Fuel Crossfeed indication if a discrepancy is observed. If the Hydraulic System B is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System B quantity display is expected to read within the sample range of 95 to 105 units during landing. The pilot flying will cross-check any change in the Center Tank Pumps annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will monitor any change in the Cabin Pressure Controller indication and advise the other pilot once the checklist item is complete.

NOTE: If the Pack Temperature Control is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

NOTE: During takeoff, the relief pilot should cross-check the Nosewheel Steering annunciation before the next phase of flight.

04.20.3 Crew Coordination: Landing Gear Indication

During takeoff, the Captain should announce the Window Heat selector position unless directed otherwise by the Sample Operations Center. If the Engine Anti-Ice is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. During an extended ground delay, both pilots should announce the Traffic Advisory Display switch position when operating at a sample station without ground power. Both pilots will verify any change in the Engine Anti-Ice status message and advise the other pilot if a discrepancy is observed.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Cabin Pressure Controller switch position	91 units	Advisory only
Flight Management Computer status message	45 units	Normal
Cabin Pressure Controller indication	52 units	Refer to related topic
Standby Instruments selector position	42 units	Refer to related topic
Fuel Crossfeed advisory	43 units	Normal
Auxiliary Power Unit indication	84 units	Normal
Cockpit Voice Recorder indication	11 units	Monitor

Values in this manual are invented and must not be used for any operational purpose. The Auxiliary Power Unit quantity display is expected to read within the sample range of 98 to 103 units during an extended ground delay. The Fuel Crossfeed quantity display is expected to read within the sample range of 58 to 63 units during a turnaround. During approach, the Captain should record the Auxiliary Power Unit annunciation if a discrepancy is observed.

CAUTION: During landing, both pilots should record the Ground Proximity Monitor advisory when operating at a sample station without ground power. The captain will cross-check any change in the Landing Gear Indication status message and advise the other pilot if a discrepancy is observed.

If the Center Tank Pumps is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The captain will brief any change in the Autobrake Selector status message and advise the other pilot when operating at a sample station without ground power. The Cabin Pressure Controller annunciation is expected to read within the sample range of 57 to 62 units during a turnaround. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

The captain will record any change in the Pack Temperature Control status message and advise the other pilot when conditions permit. The Probe Heat switch position is expected to read within the sample range of 23 to 29 units during a maintenance-requested ground run. Refer to the related topic for additional sample context.

The Engine Anti-Ice annunciation is expected to read within the sample range of 49 to 56 units during engine start. The wording here is placeholder content shaped like a procedure, not a procedure. The Flap Position Indication status message is expected to read within the sample range of 25 to 31 units during an extended ground delay. The Wing Anti-Ice selector position that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval. If the Engine Anti-Ice is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During engine start, both pilots should brief the Landing Gear Indication indication if a discrepancy is observed.

If the Window Heat is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Thrust Reverser quantity display is expected to read within the sample range of 88 to 94 units during descent. The pilot monitoring will select any change in the Traffic Advisory Display status message and advise the other pilot if the indication does not stabilize within the sample interval. The Pack Temperature Control status message is expected to read within the sample range of 42 to 54 units during parking. If the Oxygen Distribution is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control indication is expected to read within the sample range of 64 to 74 units during engine start.

04.20.4 Checklist: Fuel Crossfeed

The wording here is placeholder content shaped like a procedure, not a procedure. During descent, both pilots should verify the Autobrake Selector quantity display once the checklist item is complete. The Autopilot Channel A switch position that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Autobrake Selector indication that differs from the expected state requires both pilots to brief the condition before the next phase of flight. The Hydraulic System B annunciation that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power.

- During parking, both pilots should brief the Weather Radar annunciation before the next phase of flight.
- The Hydraulic System B annunciation is expected to read within the sample range of 46 to 56 units during taxi.
- The relief pilot will verify any change in the Brake Temperature Monitor switch position and advise the other pilot when operating at a sample station without ground power.
- If the Nosewheel Steering is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will announce any change in the Cockpit Voice Recorder switch position and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Probe Heat selector position is expected to read within the sample range of 44 to 53 units during a maintenance-requested ground run.
- The captain will monitor any change in the Center Tank Pumps advisory and advise the other pilot when the associated caution light remains illuminated.
- If the Engine Anti-Ice is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

If the Hydraulic System A is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the First Officer should verify the Flap Position Indication indication when the associated caution light remains illuminated. If the Autobrake Selector is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

CAUTION: During an extended ground delay, the relief pilot should record the Primary Electrical Bus selector position when conditions permit.

Condition	Sample value	Remarks
Autopilot Channel B selector position	92 units	Normal
Thrust Reverser switch position	46 units	Monitor
Landing Gear Indication annunciation	66 units	Monitor

Condition	Sample value	Remarks
Weather Radar advisory	75 units	Advisory only
Cabin Pressure Controller selector position	7 units	Refer to related topic
Stall Warning annunciation	7 units	Advisory only
Cabin Pressure Controller switch position	99 units	Advisory only
Nosewheel Steering selector position	49 units	Monitor

04.20.5 Crew Coordination: Fuel Crossfeed

If the Stall Warning is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Landing Gear Indication advisory that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will monitor any change in the Autopilot Channel A status message and advise the other pilot before the next phase of flight. The Speedbrake Handle status message that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed.

The Bleed Air Supply advisory is expected to read within the sample range of 95 to 104 units during climb. During descent, the pilot flying should select the Flight Management Computer selector position when operating at a sample station without ground power. The first officer will select any change in the Ground Proximity Monitor annunciation and advise the other pilot when the associated caution light remains illuminated. The Speedbrake Handle switch position that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. If the Landing Gear Indication is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

- The relief pilot will brief any change in the Cabin Pressure Controller switch position and advise the other pilot when operating at a sample station without ground power.
- The Autopilot Channel A annunciation that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power.
- If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.
- The Autopilot Channel B advisory that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight.
- During preflight, the pilot flying should monitor the Weather Radar quantity display when the associated caution light remains illuminated.
- The captain will select any change in the Pack Temperature Control annunciation and advise the other pilot before the next phase of flight.
- The pilot monitoring will select any change in the Primary Electrical Bus switch position and advise the other pilot when conditions permit.
- The Stall Warning selector position that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.

- Refer to the related topic for additional sample context.
- The Speedbrake Handle annunciation is expected to read within the sample range of 60 to 65 units during engine start.

The Engine Anti-Ice indication is expected to read within the sample range of 45 to 50 units during a turnaround. The Cargo Smoke Detection advisory is expected to read within the sample range of 21 to 24 units during takeoff. Both pilots will confirm any change in the Pack Temperature Control status message and advise the other pilot once the checklist item is complete. If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

The Stall Warning selector position that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Traffic Advisory Display is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will announce any change in the Center Tank Pumps selector position and advise the other pilot once the checklist item is complete. The first officer will verify any change in the Pack Temperature Control indication and advise the other pilot before the next phase of flight. The captain will cross-check any change in the Stall Warning indication and advise the other pilot when the associated caution light remains illuminated. The relief pilot will cross-check any change in the Hydraulic System B indication and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Probe Heat selector position is expected to read within the sample range of 17 to 29 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: If the Weather Radar is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

04.20.6 Verification: Flap Position Indication

Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the pilot flying should select the Weather Radar selector position when conditions permit. If the Brake Temperature Monitor is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Auxiliary Power Unit status message	91 units	Normal
Autothrottle advisory	22 units	Refer to related topic
Nosewheel Steering quantity display	83 units	Normal
Probe Heat selector position	25 units	Advisory only
Traffic Advisory Display selector position	97 units	Refer to related topic

NOTE: The Transponder switch position that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight. During climb, the pilot monitoring should announce the Window Heat switch position if a discrepancy is observed.

- During takeoff, the First Officer should cross-check the Fuel Crossfeed indication before the next phase of flight.
- The Thrust Reverser indication is expected to read within the sample range of 15 to 24 units during descent.
- The pilot monitoring will record any change in the Cabin Pressure Controller indication and advise the other pilot before the next phase of flight.

If the Autopilot Channel A is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Engine Anti-Ice selector position is expected to read within the sample range of 49 to 53 units during approach. Refer to the related topic for additional sample context. The Fuel Crossfeed annunciation is expected to read within the sample range of 28 to 37 units during a turnaround. The pilot monitoring will announce any change in the Window Heat status message and advise the other pilot if the indication does not stabilize within the sample interval. The Autobrake Selector selector position is expected to read within the sample range of 74 to 80 units during a diversion.

CAUTION: The Auxiliary Power Unit status message that differs from the expected state requires the First Officer to select the condition before the next phase of flight.

04.20.7 Checklist: Wing Anti-Ice

During takeoff, both pilots should select the Pack Temperature Control annunciation if the indication does not stabilize within the sample interval. During a diversion, the pilot monitoring should announce the Cockpit Voice Recorder indication if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Traffic Advisory Display switch position that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

The captain will announce any change in the Traffic Advisory Display indication and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The first officer will select any change in the Nosewheel Steering advisory and advise the other pilot once the checklist item is complete.

- The first officer will verify any change in the Landing Gear Indication selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Autopilot Channel B is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Ground Proximity Monitor advisory that differs from the expected state requires both pilots to verify the condition once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Center Tank Pumps indication that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The first officer will verify any change in the Cockpit Voice Recorder quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- During cruise, the relief pilot should confirm the Autothrottle advisory unless directed otherwise by the Sample Operations Center.
- If the Pack Temperature Control is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.
- If the Center Tank Pumps is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- The Engine Anti-Ice annunciation that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete.

- The Autothrottle advisory is expected to read within the sample range of 77 to 80 units during parking.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Fuel Crossfeed is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

CAUTION: The captain will select any change in the Landing Gear Indication status message and advise the other pilot unless directed otherwise by the Sample Operations Center. During approach, both pilots should monitor the Fuel Crossfeed indication before the next phase of flight.

04.20.8 Crew Coordination: Nosewheel Steering

Refer to the related topic for additional sample context. During a turnaround, the pilot flying should select the Cockpit Voice Recorder indication when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. If the Pack Temperature Control is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Standby Instruments selector position that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

During a maintenance-requested ground run, both pilots should confirm the Stall Warning indication once the checklist item is complete. The Ground Proximity Monitor indication that differs from the expected state requires the relief pilot to record the condition when conditions permit. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The relief pilot will brief any change in the Probe Heat selector position and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Oxygen Distribution indication	55 units	Monitor
Thrust Reverser status message	54 units	Monitor
Pack Temperature Control advisory	31 units	Advisory only
Nosewheel Steering indication	95 units	Monitor

NOTE: The captain will cross-check any change in the Speedbrake Handle advisory and advise the other pilot before the next phase of flight. During descent, the pilot monitoring should monitor the Landing Gear Indication selector position when the associated caution light remains illuminated.

During cruise, the First Officer should record the Pack Temperature Control selector position if the indication does not stabilize within the sample interval. The Wing Anti-Ice quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed. The Speedbrake Handle status message that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval. The Transponder advisory that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. The captain will cross-check any change in the Autopilot Channel A selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

04.20.9 Verification: Standby Instruments

During a turnaround, the pilot monitoring should cross-check the Brake Temperature Monitor quantity display before the next phase of flight. The Primary Electrical Bus annunciation is expected to read within the sample range of 49 to 54 units during takeoff. During a turnaround, the pilot monitoring should confirm the Thrust Reverser advisory before the next phase of flight. The Auxiliary Power Unit advisory is expected to read within the sample range of 56 to 59 units during a maintenance-requested ground run. The Cabin Pressure Controller switch position is expected to read within the sample range of 43 to 52 units during taxi.

If the Cargo Smoke Detection is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During climb, the Captain should cross-check the Autopilot Channel B indication before the next phase of flight.

If the Fire Detection Loop is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Window Heat indication that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval. During takeoff, both pilots should confirm the Flight Management Computer quantity display once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Probe Heat annunciation	87 units	Refer to related topic
Autobrake Selector switch position	94 units	Normal
Autopilot Channel B quantity display	60 units	Monitor
Primary Electrical Bus indication	6 units	Refer to related topic
Hydraulic System A status message	41 units	Monitor

The Autopilot Channel A indication that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose.

- During a diversion, the relief pilot should confirm the Flap Position Indication annunciation if a discrepancy is observed.
- The relief pilot will brief any change in the Thrust Reverser status message and advise the other pilot when operating at a sample station without ground power.
- The Window Heat annunciation that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed.

04.20.10 Crew Coordination: Window Heat

During an extended ground delay, the Captain should verify the Window Heat status message when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The pilot monitoring will verify any change in the Cargo Smoke Detection advisory and advise the other pilot once the checklist item is complete. The Wing Anti-Ice status message is expected to read within the sample range of 42 to 51 units during descent. The Probe Heat selector position that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

The Autothrottle selector position that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. During a turnaround, the pilot flying should announce the Autopilot Channel B indication before the next phase of flight. If the Engine Anti-Ice is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Center Tank Pumps indication that differs from the expected state requires the First Officer to confirm the condition when conditions permit.
- The pilot flying will cross-check any change in the Brake Temperature Monitor status message and advise the other pilot if the indication does not stabilize within the sample interval.

- The pilot flying will cross-check any change in the Cargo Smoke Detection switch position and advise the other pilot if a discrepancy is observed.
- The Center Tank Pumps selector position that differs from the expected state requires the First Officer to confirm the condition when conditions permit.
- Both pilots will select any change in the Window Heat annunciation and advise the other pilot when conditions permit.
- Both pilots will brief any change in the Engine Anti-Ice indication and advise the other pilot when the associated caution light remains illuminated.

If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Primary Electrical Bus selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During parking, the relief pilot should cross-check the Autobrake Selector quantity display before the next phase of flight. The Transponder quantity display is expected to read within the sample range of 46 to 51 units during preflight.

NOTE: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Center Tank Pumps selector position	63 units	Advisory only
Probe Heat advisory	92 units	Normal
Autobrake Selector selector position	31 units	Normal
Auxiliary Power Unit advisory	92 units	Refer to related topic
Cockpit Voice Recorder advisory	66 units	Advisory only
Flap Position Indication selector position	38 units	Normal

The first officer will confirm any change in the Nosewheel Steering quantity display and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Cargo Smoke Detection switch position that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. The pilot flying will cross-check any change in the Autobrake Selector indication and advise the other pilot if a discrepancy is observed. Both pilots will select any change in the Standby Instruments advisory and advise the other pilot once the checklist item is complete. The Landing Gear Indication annunciation is expected to read within the sample range of 51 to 58 units during taxi.

CAUTION: The pilot monitoring will record any change in the Nosewheel Steering status message and advise the other pilot once the checklist item is complete.

CAUTION: The captain will record any change in the Transponder quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

04.20.11 Flow: Ground Proximity Monitor

The first officer will announce any change in the Stall Warning annunciation and advise the other pilot when the associated caution light remains illuminated. The Speedbrake Handle annunciation is expected to read within the sample range of 49 to 56 units during takeoff. The Engine Anti-Ice annunciation is expected to read within the sample range of 40 to 45 units during approach. The Nosewheel Steering status message is expected to read within the sample range of 98 to 106 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Fire Detection Loop status message	83 units	Refer to related topic
Cabin Pressure Controller switch position	91 units	Refer to related topic
Flight Management Computer status message	68 units	Advisory only

CAUTION: The Cockpit Voice Recorder advisory that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power.

If the Flap Position Indication is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The Brake Temperature Monitor indication is expected to read within the sample range of 82 to 88 units during cruise. The Thrust Reverser indication is expected to read within the sample range of 3 to 13 units during a diversion.

Condition	Sample value	Remarks
Engine Anti-Ice advisory	9 units	Monitor
Autopilot Channel A status message	76 units	Refer to related topic
Stall Warning annunciation	11 units	Advisory only

NOTE: The pilot flying will verify any change in the Window Heat annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

During parking, the relief pilot should select the Ground Proximity Monitor annunciation once the checklist item is complete. If the Standby Hydraulic is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Engine Anti-Ice status message that differs from the expected state requires both pilots to select the condition before the next phase of flight.

The pilot monitoring will brief any change in the Auxiliary Power Unit advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Ground Proximity Monitor is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Center Tank Pumps selector position that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. The Auxiliary Power Unit indication that differs from the expected state requires the pilot flying to verify the condition when conditions permit. The Wing Anti-Ice selector position is expected to read within the sample range of 22 to 28 units during taxi.

If the Bleed Air Supply is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Cockpit Voice Recorder indication and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Fuel Crossfeed status message is expected to read within the sample range of 38 to 41 units during a diversion.

04.20.12 Flow: Cabin Pressure Controller

If the Transponder is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the First Officer should confirm the Hydraulic System A status message when operating at a sample station without ground power. The captain will verify any change in the Auxiliary Power Unit status message and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

CAUTION: If the Bleed Air Supply is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System B is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During descent, both pilots should brief the Brake Temperature Monitor advisory when operating at a sample station without ground power.

CAUTION: During preflight, the pilot monitoring should monitor the Landing Gear Indication status message once the checklist item is complete.

The relief pilot will brief any change in the Thrust Reverser advisory and advise the other pilot when the associated caution light remains illuminated. The Pack Temperature Control advisory that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated. The Hydraulic System A advisory that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. The Ground Proximity Monitor quantity display is expected to read within the sample range of 97 to 101 units during a maintenance-requested ground run. The Probe Heat selector position that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed.

The Standby Hydraulic switch position is expected to read within the sample range of 42 to 54 units during parking. The pilot flying will select any change in the Hydraulic System A indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The first officer will monitor any change in the Fuel Crossfeed quantity display and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The Ground Proximity Monitor switch position is expected to read within the sample range of 79 to 91 units during engine start. During takeoff, the relief pilot should verify the Engine Anti-Ice annunciation unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will brief any change in the Autothrottle annunciation and advise the other pilot when the associated caution light remains illuminated. The first officer will cross-check any change in the Transponder advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Flap Position Indication is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

04.20.13 Crew Coordination: Auxiliary Power Unit

The captain will select any change in the Wing Anti-Ice switch position and advise the other pilot when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

During a turnaround, the pilot flying should cross-check the Cockpit Voice Recorder indication if a discrepancy is observed. The Cabin Pressure Controller advisory is expected to read within the sample range of 25 to 36 units during climb. Both pilots will record any change in the Weather Radar quantity display and advise the other pilot once the checklist item is complete. The pilot flying will brief any change in the Probe Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval. During landing, both pilots should monitor the Flight Management Computer indication once the checklist item is complete. During a turnaround, both pilots should confirm the Auxiliary Power Unit selector position when operating at a sample station without ground power.

CAUTION: If the Standby Instruments is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

NOTE: The Transponder selector position that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight.

- If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- During engine start, the First Officer should select the Nosewheel Steering annunciation unless directed otherwise by the Sample Operations Center.
- The Autopilot Channel A quantity display that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center.

- The Brake Temperature Monitor quantity display that differs from the expected state requires the pilot flying to brief the condition when conditions permit.
- If the Cockpit Voice Recorder is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- During parking, the pilot monitoring should monitor the Traffic Advisory Display advisory if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. The captain will record any change in the Autopilot Channel B advisory and advise the other pilot when the associated caution light remains illuminated. The Hydraulic System B indication that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed.

CAUTION: The Center Tank Pumps status message is expected to read within the sample range of 21 to 33 units during engine start.

Condition	Sample value	Remarks
Hydraulic System A advisory	88 units	Advisory only
Window Heat indication	68 units	Advisory only
Landing Gear Indication advisory	67 units	Normal

NOTE: The Hydraulic System A status message is expected to read within the sample range of 79 to 89 units during cruise. The captain will announce any change in the Thrust Reverser advisory and advise the other pilot if a discrepancy is observed.

04.20.14 Crew Coordination: Autothrottle

The relief pilot will monitor any change in the Hydraulic System A quantity display and advise the other pilot if a discrepancy is observed. The Bleed Air Supply quantity display is expected to read within the sample range of 8 to 14 units during takeoff. The Weather Radar annunciation is expected to read within the sample range of 98 to 108 units during approach.

NOTE: The Thrust Reverser advisory is expected to read within the sample range of 2 to 9 units during a turnaround. If the Hydraulic System A is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. During a diversion, both pilots should confirm the Autopilot Channel A quantity display when conditions permit. If the Transponder is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The pilot flying will brief any change in the Fire Detection Loop annunciation and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	23 units	Refer to related topic
Autopilot Channel B annunciation	90 units	Refer to related topic
Traffic Advisory Display quantity display	42 units	Advisory only
Traffic Advisory Display annunciation	27 units	Advisory only
Autopilot Channel A advisory	28 units	Refer to related topic

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

- Refer to the related topic for additional sample context.
- The relief pilot will monitor any change in the Weather Radar quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

- The Autopilot Channel A indication that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The relief pilot will verify any change in the Auxiliary Power Unit selector position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Autopilot Channel A quantity display	10 units	Refer to related topic
Center Tank Pumps quantity display	23 units	Advisory only
Flight Management Computer status message	14 units	Monitor
Brake Temperature Monitor annunciation	34 units	Monitor
Flap Position Indication indication	66 units	Monitor
Autothrottle quantity display	75 units	Refer to related topic
Nosewheel Steering status message	64 units	Monitor

- If the Wing Anti-Ice is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- The Autopilot Channel B switch position that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated.
- During landing, the pilot flying should cross-check the Primary Electrical Bus switch position when conditions permit.
- The Flap Position Indication advisory is expected to read within the sample range of 61 to 64 units during climb.
- The captain will cross-check any change in the Fuel Crossfeed indication and advise the other pilot once the checklist item is complete.
- The Center Tank Pumps switch position that differs from the expected state requires the pilot monitoring to monitor the condition when operating at a sample station without ground power.

CAUTION: The Autobrake Selector quantity display is expected to read within the sample range of 91 to 102 units during takeoff.

Condition	Sample value	Remarks
Wing Anti-Ice quantity display	54 units	Refer to related topic
Primary Electrical Bus quantity display	18 units	Refer to related topic
Cabin Pressure Controller annunciation	83 units	Normal
Window Heat indication	71 units	Normal
Bleed Air Supply advisory	69 units	Advisory only
Landing Gear Indication selector position	84 units	Normal

04.20.15 Crew Coordination: Standby Hydraulic

Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The Traffic Advisory Display selector position is expected to read within the sample range of 43 to 48 units during climb.

Condition	Sample value	Remarks
Autothrottle quantity display	59 units	Refer to related topic

Pack Temperature Control status message	51 units	Advisory only
Flap Position Indication switch position	4 units	Monitor
Thrust Reverser quantity display	66 units	Advisory only
Traffic Advisory Display advisory	13 units	Normal
Weather Radar selector position	37 units	Normal
Probe Heat indication	27 units	Advisory only

During an extended ground delay, the relief pilot should brief the Fire Detection Loop quantity display when the associated caution light remains illuminated. The pilot monitoring will record any change in the Autopilot Channel B quantity display and advise the other pilot before the next phase of flight. During taxi, the pilot flying should verify the Pack Temperature Control indication when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

The pilot monitoring will verify any change in the Stall Warning quantity display and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will brief any change in the Standby Hydraulic annunciation and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The Traffic Advisory Display quantity display that differs from the expected state requires the First Officer to cross-check the condition when conditions permit. Refer to the related topic for additional sample context.

If the Autothrottle is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Transponder is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Brake Temperature Monitor advisory that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated. The Hydraulic System B switch position that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated.

CAUTION: If the Autobrake Selector is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

- The Pack Temperature Control annunciation that differs from the expected state requires the Captain to announce the condition once the checklist item is complete.
- The relief pilot will record any change in the Autopilot Channel A advisory and advise the other pilot when the associated caution light remains illuminated.
- The relief pilot will brief any change in the Cargo Smoke Detection switch position and advise the other pilot when operating at a sample station without ground power.
- The Cabin Pressure Controller quantity display that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed.

NOTE: If the Autothrottle is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The relief pilot will record any change in the Center Tank Pumps switch position and advise the other pilot before the next phase of flight. The Speedbrake Handle annunciation is expected to read within the sample range of 7 to 16 units during preflight.

04.20.16 Crew Coordination: Thrust Reverser

During parking, the relief pilot should record the Brake Temperature Monitor switch position unless directed otherwise by the Sample Operations Center. Both pilots will cross-check any change in the Traffic Advisory Display indication and advise the other pilot if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

Both pilots will announce any change in the Bleed Air Supply indication and advise the other pilot if a discrepancy is observed. The Flap Position Indication selector position that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight. During a turnaround, the pilot monitoring should confirm the Probe Heat status message if a discrepancy is observed.

This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the Captain should brief the Cabin Pressure Controller annunciation if the indication does not stabilize within the sample interval. The Standby Hydraulic annunciation is expected to read within the sample range of 44 to 51 units during landing. The pilot monitoring will monitor any change in the Transponder quantity display and advise the other pilot once the checklist item is complete. If the Oxygen Distribution is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. During approach, the First Officer should monitor the Fire Detection Loop annunciation when conditions permit. If the Primary Electrical Bus is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A advisory that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight.

NOTE: The Probe Heat indication is expected to read within the sample range of 10 to 17 units during a turnaround.

- Both pilots will announce any change in the Cockpit Voice Recorder annunciation and advise the other pilot when operating at a sample station without ground power.
- Both pilots will confirm any change in the Autopilot Channel B advisory and advise the other pilot before the next phase of flight.
- During cruise, both pilots should monitor the Transponder indication once the checklist item is complete.
- The Weather Radar switch position is expected to read within the sample range of 10 to 18 units during taxi.
- The Pack Temperature Control status message is expected to read within the sample range of 40 to 48 units during parking.
- During landing, both pilots should monitor the Oxygen Distribution switch position when conditions permit.
- If the Autopilot Channel B is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- Refer to the related topic for additional sample context.

NOTE: The Fuel Crossfeed advisory that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval.

04.20.17 Flow: Hydraulic System B

During an extended ground delay, the First Officer should brief the Fuel Crossfeed status message before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution indication is expected to read within the sample range of 91 to 101 units during engine start. The Autothrottle status message is expected to read within the sample range of 18 to 23 units during engine start. During preflight, the pilot monitoring should monitor the Autobrake Selector selector position when conditions permit. During an extended ground delay, the First Officer should record the Ground Proximity Monitor annunciation once the checklist item is complete.

Condition	Sample value	Remarks
Autopilot Channel B quantity display	45 units	Refer to related topic

Window Heat indication	23 units	Refer to related topic
Speedbrake Handle status message	12 units	Normal

- If the Cockpit Voice Recorder is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.
- If the Cockpit Voice Recorder is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.
- The Wing Anti-Ice indication that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval.
- The relief pilot will brief any change in the Cargo Smoke Detection advisory and advise the other pilot when the associated caution light remains illuminated.

The Fire Detection Loop switch position that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. During preflight, the pilot monitoring should brief the Weather Radar switch position when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Nosewheel Steering advisory is expected to read within the sample range of 16 to 20 units during an extended ground delay. During a turnaround, both pilots should select the Nosewheel Steering indication when operating at a sample station without ground power. If the Flap Position Indication is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

- Values in this manual are invented and must not be used for any operational purpose.
- The Cargo Smoke Detection indication that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Autopilot Channel B annunciation is expected to read within the sample range of 85 to 93 units during a turnaround.

CAUTION: If the Autopilot Channel B is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: If the Traffic Advisory Display is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

The Center Tank Pumps quantity display is expected to read within the sample range of 42 to 45 units during a diversion. The Traffic Advisory Display advisory that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will monitor any change in the Transponder advisory and advise the other pilot if the indication does not stabilize within the sample interval.

04.20.18 Briefing: Center Tank Pumps

The pilot flying will brief any change in the Brake Temperature Monitor annunciation and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. During cruise, the pilot monitoring should verify the Wing Anti-Ice selector position when operating at a sample station without ground power. The Hydraulic System A quantity display is expected to read within the sample range of 8 to 18 units during climb. During takeoff, both pilots should record the Ground Proximity Monitor annunciation when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. The Fuel Crossfeed quantity display that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated. The Autothrottle status message that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented

and must not be used for any operational purpose. Refer to the related topic for additional sample context. During a diversion, the Captain should announce the Probe Heat advisory unless directed otherwise by the Sample Operations Center.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Autothrottle status message is expected to read within the sample range of 12 to 15 units during cruise.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Stall Warning switch position is expected to read within the sample range of 24 to 27 units during a turnaround.
- The Probe Heat status message that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Weather Radar advisory	29 units	Monitor
Bleed Air Supply switch position	83 units	Refer to related topic
Traffic Advisory Display selector position	57 units	Refer to related topic
Standby Instruments quantity display	67 units	Refer to related topic
Oxygen Distribution quantity display	37 units	Refer to related topic
Cargo Smoke Detection indication	47 units	Normal

- The Hydraulic System A advisory that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.
- The relief pilot will monitor any change in the Window Heat advisory and advise the other pilot when operating at a sample station without ground power.
- The Standby Instruments status message is expected to read within the sample range of 35 to 41 units during cruise.
- If the Stall Warning is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- During preflight, the pilot monitoring should brief the Wing Anti-Ice status message before the next phase of flight.
- The Bleed Air Supply status message that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center.

The Autopilot Channel A status message that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete. The captain will cross-check any change in the Nosewheel Steering quantity display and advise the other pilot before the next phase of flight. The pilot flying will select any change in the Weather Radar indication and advise the other pilot when the associated caution light remains illuminated. If the Fire Detection Loop is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Thrust Reverser indication is expected to read within the sample range of 49 to 59 units during a diversion. If the Auxiliary Power Unit is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. See 18.20.1 Landing Gear Indication Limits Display.

04.20.19 Verification: Primary Electrical Bus

During engine start, both pilots should announce the Hydraulic System A indication when conditions permit. The Autopilot Channel B quantity display is expected to read within the sample range of 30 to 41 units during approach. The Ground Proximity Monitor quantity display is expected to read within the sample range of 17 to 23 units during climb. The Fuel Crossfeed switch position is expected to read within the sample range of 71 to 81 units during a maintenance-requested ground run. The Probe Heat advisory is expected to read within the sample range of 58 to 64 units during descent.

NOTE: During descent, the First Officer should cross-check the Hydraulic System B indication when the associated caution light remains illuminated.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will record any change in the Cabin Pressure Controller indication and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Hydraulic System A selector position	33 units	Monitor
Traffic Advisory Display indication	3 units	Monitor
Primary Electrical Bus status message	92 units	Refer to related topic
Weather Radar selector position	98 units	Refer to related topic
Ground Proximity Monitor selector position	92 units	Normal
Hydraulic System A advisory	61 units	Monitor

- The relief pilot will monitor any change in the Pack Temperature Control status message and advise the other pilot if the indication does not stabilize within the sample interval.
- During descent, the relief pilot should announce the Ground Proximity Monitor advisory unless directed otherwise by the Sample Operations Center.
- The first officer will cross-check any change in the Stall Warning indication and advise the other pilot before the next phase of flight.
- During landing, the pilot flying should verify the Hydraulic System A annunciation when the associated caution light remains illuminated.

04.20.20 Checklist: Standby Instruments

If the Thrust Reverser is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will announce any change in the Landing Gear Indication indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will confirm any change in the Probe Heat status message and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Cockpit Voice Recorder advisory is expected to read within the sample range of 13 to 16 units during cruise. During engine start, the relief pilot should confirm the Hydraulic System B indication when conditions permit.

The Autothrottle indication is expected to read within the sample range of 80 to 86 units during climb. During engine start, the pilot monitoring should record the Nosewheel Steering selector position when conditions permit. The Probe Heat quantity display is expected to read within the sample range of 79 to 91 units during a maintenance-requested ground run.

- If the Autobrake Selector is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Nosewheel Steering advisory is expected to read within the sample range of 3 to 6 units during parking.

Refer to the related topic for additional sample context. The Nosewheel Steering quantity display is expected to read within the sample range of 13 to 18 units during a maintenance-requested ground run. The Fire Detection Loop indication is expected to read within the sample range of 31 to 43 units during engine start. The Autobrake Selector

switch position that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated.

The pilot monitoring will select any change in the Fuel Crossfeed annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autobrake Selector status message is expected to read within the sample range of 19 to 27 units during preflight. The Stall Warning annunciation is expected to read within the sample range of 9 to 17 units during parking. During preflight, the relief pilot should cross-check the Cargo Smoke Detection indication if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

During parking, the First Officer should cross-check the Autopilot Channel B selector position when the associated caution light remains illuminated. The Stall Warning indication that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. The Engine Anti-Ice selector position that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The relief pilot will monitor any change in the Engine Anti-Ice indication and advise the other pilot if the indication does not stabilize within the sample interval.

04.30 Hot Weather Operations

04.30.1 Checklist: Bleed Air Supply

The Flap Position Indication quantity display is expected to read within the sample range of 49 to 52 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure. If the Speedbrake Handle is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During descent, the relief pilot should verify the Nosewheel Steering quantity display if a discrepancy is observed.

NOTE: Refer to the related topic for additional sample context.

NOTE: During descent, both pilots should confirm the Brake Temperature Monitor annunciation before the next phase of flight.

The relief pilot will verify any change in the Autobrake Selector quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The captain will monitor any change in the Weather Radar annunciation and advise the other pilot if a discrepancy is observed. The Traffic Advisory Display quantity display is expected to read within the sample range of 68 to 79 units during climb. The Ground Proximity Monitor status message that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated. The Fire Detection Loop selector position is expected to read within the sample range of 26 to 36 units during cruise.

The Hydraulic System B selector position that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete. If the Transponder is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Standby Hydraulic advisory and advise the other pilot once the checklist item is complete. The Thrust Reverser status message is expected to read within the sample range of 35 to 46 units during preflight. The Cabin Pressure Controller selector position is expected to read within the sample range of 19 to 27 units during approach. The Ground Proximity Monitor quantity display is expected to read within the sample range of 5 to 10 units during a diversion.

04.30.2 Crew Coordination: Wing Anti-Ice

The Standby Instruments quantity display that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. If the Thrust Reverser is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

The first officer will verify any change in the Cockpit Voice Recorder selector position and advise the other pilot when the associated caution light remains illuminated. If the Stall Warning is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic

volume and structure. During descent, the pilot monitoring should verify the Stall Warning switch position unless directed otherwise by the Sample Operations Center.

The Center Tank Pumps advisory is expected to read within the sample range of 73 to 85 units during climb. During taxi, both pilots should announce the Fuel Crossfeed advisory unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, both pilots should confirm the Hydraulic System A indication when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: During a maintenance-requested ground run, the relief pilot should verify the Pack Temperature Control switch position if the indication does not stabilize within the sample interval.

NOTE: The Pack Temperature Control selector position that differs from the expected state requires the pilot flying to select the condition when conditions permit.

During preflight, the pilot flying should confirm the Brake Temperature Monitor status message if the indication does not stabilize within the sample interval. The Autobrake Selector indication is expected to read within the sample range of 52 to 60 units during engine start. During a maintenance-requested ground run, the pilot monitoring should select the Thrust Reverser selector position if a discrepancy is observed.

The Engine Anti-Ice switch position that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power. The Pack Temperature Control switch position that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete. The Traffic Advisory Display selector position is expected to read within the sample range of 17 to 26 units during landing.

Condition	Sample value	Remarks
Speedbrake Handle annunciation	6 units	Normal
Ground Proximity Monitor quantity display	6 units	Refer to related topic
Pack Temperature Control selector position	23 units	Normal

NOTE: The Flight Management Computer status message that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power.

04.30.3 Briefing: Flap Position Indication

Refer to the related topic for additional sample context. During an extended ground delay, the Captain should monitor the Standby Instruments annunciation when the associated caution light remains illuminated. The Nosewheel Steering annunciation is expected to read within the sample range of 52 to 63 units during a maintenance-requested ground run. During taxi, both pilots should cross-check the Wing Anti-Ice quantity display if a discrepancy is observed. See 05.10.14 Wing Anti-Ice Normal Operation.

CAUTION: During engine start, both pilots should record the Autopilot Channel B annunciation when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: Values in this manual are invented and must not be used for any operational purpose. If the Autopilot Channel B is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

CAUTION: During engine start, the First Officer should monitor the Thrust Reverser advisory if the indication does not stabilize within the sample interval. The Autopilot Channel B selector position that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated.

CAUTION: The first officer will brief any change in the Stall Warning advisory and advise the other pilot when conditions permit.

CAUTION: The Fire Detection Loop switch position is expected to read within the sample range of 76 to 85 units during preflight. The pilot flying will announce any change in the Hydraulic System A advisory and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Primary Electrical Bus annunciation	42 units	Normal
Wing Anti-Ice status message	98 units	Normal
Landing Gear Indication switch position	56 units	Monitor
Autobrake Selector selector position	64 units	Monitor
Thrust Reverser advisory	21 units	Monitor

04.30.4 Flow: Flap Position Indication

The Hydraulic System B annunciation is expected to read within the sample range of 3 to 6 units during descent. Values in this manual are invented and must not be used for any operational purpose. If the Ground Proximity Monitor is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

- If the Cabin Pressure Controller is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- The Cockpit Voice Recorder indication is expected to read within the sample range of 82 to 89 units during parking.
- If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.
- During preflight, both pilots should select the Traffic Advisory Display quantity display when the associated caution light remains illuminated.
- If the Brake Temperature Monitor is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- The Speedbrake Handle status message that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete.
- During engine start, both pilots should record the Speedbrake Handle selector position when the associated caution light remains illuminated.
- The relief pilot will cross-check any change in the Cockpit Voice Recorder quantity display and advise the other pilot once the checklist item is complete.
- The Standby Instruments switch position is expected to read within the sample range of 11 to 18 units during approach.
- Values in this manual are invented and must not be used for any operational purpose.
- During an extended ground delay, the Captain should verify the Ground Proximity Monitor indication when operating at a sample station without ground power.

If the Fire Detection Loop is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Transponder switch position is expected to read within the sample range of 76 to 80 units during an extended ground delay. Both pilots will record any change in the Autopilot Channel A status message and advise the other pilot if a discrepancy is observed. The Autothrottle quantity display that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

The Cargo Smoke Detection indication that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. During cruise, the First Officer should announce the Autopilot Channel A annunciation if the indication does not stabilize within the sample interval. The Primary Electrical Bus switch position that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. The Landing Gear Indication status message is expected to read within the sample range of 89 to 100 units during preflight. During climb, the pilot monitoring should monitor the Standby Hydraulic annunciation before the next phase of flight.

NOTE: The first officer will verify any change in the Window Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval. If the Auxiliary Power Unit is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

- If the Transponder is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.
- If the Brake Temperature Monitor is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- The pilot flying will cross-check any change in the Flap Position Indication selector position and advise the other pilot before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During engine start, the First Officer should confirm the Thrust Reverser advisory if the indication does not stabilize within the sample interval.

04.30.5 Verification: Autothrottle

Both pilots will monitor any change in the Hydraulic System A selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will cross-check any change in the Wing Anti-Ice advisory and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Hydraulic selector position is expected to read within the sample range of 59 to 69 units during landing.

CAUTION: During a maintenance-requested ground run, both pilots should confirm the Autothrottle switch position when the associated caution light remains illuminated. The Probe Heat status message that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	55 units	Refer to related topic
Wing Anti-Ice advisory	26 units	Advisory only
Flight Management Computer advisory	6 units	Refer to related topic
Probe Heat status message	48 units	Refer to related topic

- During climb, the pilot flying should select the Transponder status message when the associated caution light remains illuminated.
- The captain will brief any change in the Engine Anti-Ice status message and advise the other pilot if a discrepancy is observed.
- During taxi, the First Officer should record the Thrust Reverser indication if a discrepancy is observed.
- If the Autopilot Channel B is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.
- During a maintenance-requested ground run, the pilot flying should announce the Hydraulic System B status message if a discrepancy is observed.

- Both pilots will announce any change in the Primary Electrical Bus advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Weather Radar quantity display that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed.
- Refer to the related topic for additional sample context.
- Refer to the related topic for additional sample context.

04.30.6 *Flow: Bleed Air Supply*

Both pilots will select any change in the Auxiliary Power Unit status message and advise the other pilot before the next phase of flight. The Standby Instruments status message that differs from the expected state requires the Captain to record the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

The Thrust Reverser annunciation is expected to read within the sample range of 20 to 30 units during cruise. The Standby Hydraulic annunciation is expected to read within the sample range of 44 to 48 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System A is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

The Fire Detection Loop switch position is expected to read within the sample range of 51 to 61 units during a diversion. If the Oxygen Distribution is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. During descent, the pilot monitoring should select the Cargo Smoke Detection indication when conditions permit. If the Speedbrake Handle is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Weather Radar status message that differs from the expected state requires both pilots to verify the condition once the checklist item is complete.

NOTE: If the Landing Gear Indication is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display annunciation is expected to read within the sample range of 76 to 83 units during takeoff.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. During engine start, both pilots should select the Brake Temperature Monitor annunciation before the next phase of flight.

04.30.7 *Flow: Hydraulic System B*

If the Autopilot Channel B is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Probe Heat is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

During landing, the pilot flying should cross-check the Ground Proximity Monitor status message when conditions permit. The pilot monitoring will cross-check any change in the Primary Electrical Bus annunciation and advise the other pilot when operating at a sample station without ground power. The Cockpit Voice Recorder switch position that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center. If the Center Tank Pumps is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

- If the Pack Temperature Control is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- The Cabin Pressure Controller selector position that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.

- The relief pilot will record any change in the Cabin Pressure Controller quantity display and advise the other pilot when operating at a sample station without ground power.
- If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- The Traffic Advisory Display advisory that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.

NOTE: If the Engine Anti-Ice is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

If the Autopilot Channel A is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Flight Management Computer is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- Refer to the related topic for additional sample context.
- The Window Heat status message is expected to read within the sample range of 37 to 49 units during climb.
- The Thrust Reverser quantity display that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.
- The Standby Instruments switch position that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed.
- Both pilots will monitor any change in the Primary Electrical Bus annunciation and advise the other pilot if a discrepancy is observed.

04.30.8 Verification: Flight Management Computer

During taxi, the pilot monitoring should record the Center Tank Pumps quantity display if a discrepancy is observed. During a maintenance-requested ground run, the pilot flying should announce the Cockpit Voice Recorder indication before the next phase of flight. The Flight Management Computer switch position that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight. If the Thrust Reverser is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. During approach, the pilot flying should monitor the Standby Hydraulic advisory if the indication does not stabilize within the sample interval. During taxi, the First Officer should cross-check the Cabin Pressure Controller quantity display when operating at a sample station without ground power.

The first officer will monitor any change in the Cargo Smoke Detection switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. If the Window Heat is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. During a turnaround, both pilots should select the Cabin Pressure Controller quantity display once the checklist item is complete. During a maintenance-requested ground run, the pilot flying should brief the Autopilot Channel A indication if a discrepancy is observed.

CAUTION: The Pack Temperature Control selector position that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed.

During a maintenance-requested ground run, the Captain should cross-check the Flap Position Indication indication when operating at a sample station without ground power. The pilot flying will select any change in the Window Heat switch position and advise the other pilot if the indication does not stabilize within the sample interval. During an extended ground delay, the Captain should monitor the Autopilot Channel B annunciation when the associated caution light remains illuminated. The relief pilot will confirm any change in the Auxiliary Power Unit quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Speedbrake Handle indication that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Thrust Reverser quantity display	62 units	Monitor
Cabin Pressure Controller annunciation	48 units	Monitor
Engine Anti-Ice indication	68 units	Normal

- The first officer will record any change in the Weather Radar advisory and advise the other pilot when the associated caution light remains illuminated.
- The relief pilot will verify any change in the Autopilot Channel B indication and advise the other pilot if the indication does not stabilize within the sample interval.
- The Autopilot Channel B status message that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.

During descent, the pilot monitoring should announce the Fuel Crossfeed indication unless directed otherwise by the Sample Operations Center. The Hydraulic System A status message is expected to read within the sample range of 51 to 63 units during a diversion. The relief pilot will verify any change in the Landing Gear Indication quantity display and advise the other pilot when operating at a sample station without ground power. The Cabin Pressure Controller annunciation that differs from the expected state requires the Captain to announce the condition when conditions permit. During landing, the Captain should monitor the Oxygen Distribution advisory before the next phase of flight. See 03.60.16 Callouts: Autopilot Channel A.

04.30.9 Engine Anti-Ice Overview

This text is fictional and exists only to give the prototype realistic volume and structure. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. During takeoff, the relief pilot should monitor the Oxygen Distribution status message once the checklist item is complete.

The Speedbrake Handle indication that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. The Bleed Air Supply switch position is expected to read within the sample range of 17 to 28 units during taxi. During descent, the pilot monitoring should verify the Wing Anti-Ice indication if a discrepancy is observed. The Window Heat advisory is expected to read within the sample range of 68 to 72 units during parking.

NOTE: During approach, the Captain should record the Thrust Reverser quantity display if the indication does not stabilize within the sample interval.

CAUTION: The Standby Hydraulic indication that differs from the expected state requires the Captain to verify the condition when conditions permit.

The Flight Management Computer selector position is expected to read within the sample range of 73 to 82 units during a turnaround. If the Fire Detection Loop is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The pilot flying will verify any change in the Bleed Air Supply quantity display and advise the other pilot before the next phase of flight. The Nosewheel Steering annunciation that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval. The Autopilot Channel B switch position that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed.

CAUTION: The pilot monitoring will confirm any change in the Bleed Air Supply advisory and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: The Auxiliary Power Unit indication is expected to read within the sample range of 50 to 55 units during an extended ground delay.

04.30.10 Flow: Traffic Advisory Display

The Hydraulic System B status message is expected to read within the sample range of 43 to 54 units during landing. The Autothrottle status message is expected to read within the sample range of 94 to 103 units during preflight. The Engine Anti-Ice selector position that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated. The captain will announce any change in the Nosewheel Steering advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will announce any change in the Fuel Crossfeed status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Transponder quantity display that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval.

The Landing Gear Indication selector position that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. During parking, the relief pilot should cross-check the Primary Electrical Bus annunciation if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the pilot monitoring should record the Autothrottle selector position if the indication does not stabilize within the sample interval.

CAUTION: During descent, the pilot monitoring should brief the Oxygen Distribution status message if a discrepancy is observed. The Cargo Smoke Detection annunciation is expected to read within the sample range of 28 to 34 units during an extended ground delay.

The Traffic Advisory Display quantity display is expected to read within the sample range of 94 to 100 units during cruise. The pilot flying will confirm any change in the Nosewheel Steering status message and advise the other pilot when operating at a sample station without ground power. The relief pilot will announce any change in the Nosewheel Steering status message and advise the other pilot when operating at a sample station without ground power.

- If the Oxygen Distribution is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.
- The captain will record any change in the Hydraulic System B advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.

04.30.11 Verification: Cargo Smoke Detection

Values in this manual are invented and must not be used for any operational purpose. If the Standby Instruments is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The first officer will confirm any change in the Hydraulic System B switch position and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. If the Transponder is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. See 02.10.11 General Limitation 11.

Condition	Sample value	Remarks
Autopilot Channel A status message	22 units	Refer to related topic
Autothrottle selector position	88 units	Monitor
Flap Position Indication status message	1 units	Monitor
Weather Radar status message	70 units	Refer to related topic

CAUTION: During a diversion, the relief pilot should select the Window Heat selector position when the associated caution light remains illuminated.

NOTE: During a diversion, the First Officer should monitor the Hydraulic System A selector position when conditions permit.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During a diversion, both pilots should monitor the Ground Proximity Monitor status message once the checklist item is complete. If the Auxiliary Power Unit is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

CAUTION: The Primary Electrical Bus advisory that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power.

CAUTION: During engine start, the pilot flying should brief the Cargo Smoke Detection annunciation if the indication does not stabilize within the sample interval. The Wing Anti-Ice quantity display is expected to read within the sample range of 34 to 42 units during landing.

04.30.12 Crew Coordination: Hydraulic System B

Both pilots will monitor any change in the Probe Heat annunciation and advise the other pilot when the associated caution light remains illuminated. The Speedbrake Handle annunciation that differs from the expected state requires the First Officer to announce the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will confirm any change in the Nosewheel Steering selector position and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Traffic Advisory Display selector position is expected to read within the sample range of 66 to 73 units during takeoff.

If the Autobrake Selector is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During takeoff, the pilot monitoring should confirm the Engine Anti-Ice selector position once the checklist item is complete. The Fire Detection Loop switch position that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Speedbrake Handle selector position is expected to read within the sample range of 19 to 31 units during engine start.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.
- The Oxygen Distribution advisory is expected to read within the sample range of 71 to 83 units during an extended ground delay.
- During climb, the pilot flying should monitor the Ground Proximity Monitor advisory when operating at a sample station without ground power.

The pilot flying will confirm any change in the Flap Position Indication indication and advise the other pilot when the associated caution light remains illuminated. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During engine start, the pilot monitoring should brief the Transponder advisory when the associated caution light remains illuminated. During takeoff, the First Officer should cross-check the Autopilot Channel B selector position when the associated caution light remains illuminated.

04.30.13 Callouts: Hydraulic System A

If the Landing Gear Indication is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The relief pilot will monitor any change in the Oxygen Distribution quantity display and advise the other pilot when the associated caution light remains illuminated. Both pilots will record any change in the Bleed Air Supply advisory and advise the other pilot if the indication does not stabilize within the sample interval. If the Oxygen Distribution is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Primary Electrical Bus indication is expected to read within the sample range of 44

to 47 units during a maintenance-requested ground run.

CAUTION: The Pack Temperature Control indication that differs from the expected state requires both pilots to announce the condition when operating at a sample station without ground power.

CAUTION: The Wing Anti-Ice switch position that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated. If the Fuel Crossfeed is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autothrottle quantity display	45 units	Monitor
Autopilot Channel A status message	56 units	Normal
Wing Anti-Ice quantity display	70 units	Normal
Standby Instruments indication	48 units	Refer to related topic
Autobrake Selector switch position	50 units	Refer to related topic
Autobrake Selector switch position	7 units	Refer to related topic

The captain will verify any change in the Cockpit Voice Recorder advisory and advise the other pilot when conditions permit. If the Ground Proximity Monitor is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Cabin Pressure Controller selector position that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete. During engine start, both pilots should record the Standby Instruments status message unless directed otherwise by the Sample Operations Center.

04.30.14 Crew Coordination: Ground Proximity Monitor

If the Thrust Reverser is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Traffic Advisory Display selector position that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. The captain will cross-check any change in the Transponder advisory and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Wing Anti-Ice switch position	13 units	Advisory only
Transponder advisory	98 units	Normal
Oxygen Distribution indication	72 units	Refer to related topic
Window Heat quantity display	3 units	Refer to related topic
Auxiliary Power Unit advisory	23 units	Monitor

CAUTION: If the Primary Electrical Bus is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

Both pilots will cross-check any change in the Oxygen Distribution switch position and advise the other pilot when operating at a sample station without ground power. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will select any change in the Probe Heat advisory and advise the other pilot if a discrepancy is observed. The Auxiliary Power Unit annunciation that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete.

- The Transponder annunciation is expected to read within the sample range of 53 to 60 units during a diversion.
- If the Center Tank Pumps is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.

- The Pack Temperature Control selector position is expected to read within the sample range of 46 to 52 units during preflight.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Auxiliary Power Unit switch position that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Transponder selector position	30 units	Refer to related topic
Hydraulic System B status message	32 units	Refer to related topic
Auxiliary Power Unit advisory	17 units	Monitor
Probe Heat annunciation	13 units	Advisory only

CAUTION: The pilot flying will verify any change in the Wing Anti-Ice quantity display and advise the other pilot when operating at a sample station without ground power.

04.40 Engine Operations

04.40.1 Flow: Fire Detection Loop

If the Center Tank Pumps is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. During approach, both pilots should record the Autopilot Channel B annunciation when the associated caution light remains illuminated. The first officer will select any change in the Pack Temperature Control switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System B selector position is expected to read within the sample range of 71 to 77 units during approach. The Ground Proximity Monitor indication is expected to read within the sample range of 74 to 84 units during landing. The Autobrake Selector selector position is expected to read within the sample range of 27 to 38 units during approach.

NOTE: During a turnaround, the pilot flying should record the Fuel Crossfeed selector position when operating at a sample station without ground power.

During takeoff, the pilot monitoring should record the Bleed Air Supply status message if a discrepancy is observed. If the Hydraulic System A is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Transponder quantity display and advise the other pilot when operating at a sample station without ground power. The Cockpit Voice Recorder annunciation that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center.

During a turnaround, the relief pilot should verify the Autopilot Channel A annunciation when conditions permit. During approach, the pilot flying should record the Bleed Air Supply switch position once the checklist item is complete. The Primary Electrical Bus quantity display that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. During takeoff, the pilot monitoring should announce the Standby Instruments selector position when conditions permit. The first officer will announce any change in the Autothrottle status message and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will confirm any change in the Ground Proximity Monitor status message and advise the other pilot when conditions permit.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel B selector position is expected to read within the sample range of 88 to 91 units during takeoff.

If the Brake Temperature Monitor is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Flight Management Computer is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Center Tank Pumps annunciation	28 units	Monitor
Flap Position Indication quantity display	97 units	Advisory only
Cabin Pressure Controller selector position	76 units	Advisory only
Engine Anti-Ice advisory	32 units	Advisory only

The Thrust Reverser status message that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete. The Autopilot Channel B indication is expected to read within the sample range of 22 to 27 units during a turnaround. The Brake Temperature Monitor selector position that differs from the expected state requires both pilots to record the condition before the next phase of flight. If the Standby Instruments is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Probe Heat quantity display	92 units	Refer to related topic
Cockpit Voice Recorder switch position	78 units	Monitor
Fuel Crossfeed selector position	60 units	Normal
Cockpit Voice Recorder status message	39 units	Refer to related topic
Wing Anti-Ice quantity display	4 units	Advisory only

04.40.2 Callouts: Cargo Smoke Detection

During landing, the pilot monitoring should select the Hydraulic System B annunciation if a discrepancy is observed. During approach, the relief pilot should brief the Primary Electrical Bus annunciation when the associated caution light remains illuminated. If the Thrust Reverser is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

The Speedbrake Handle advisory that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. The pilot flying will announce any change in the Cargo Smoke Detection selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Autopilot Channel B status message that differs from the expected state requires the relief pilot to brief the condition when conditions permit. During descent, the First Officer should brief the Transponder advisory unless directed otherwise by the Sample Operations Center.

NOTE: The Bleed Air Supply indication that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated.

NOTE: The Cockpit Voice Recorder annunciation is expected to read within the sample range of 93 to 101 units during climb.

If the Probe Heat is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The pilot flying will announce any change in the Hydraulic System B switch position and advise the other pilot when operating at a sample station without ground power.

04.40.3 Verification: Brake Temperature Monitor

The pilot monitoring will verify any change in the Cargo Smoke Detection quantity display and advise the other pilot when conditions permit. The relief pilot will brief any change in the Window Heat indication and advise the other pilot when conditions permit. The Cockpit Voice Recorder switch position is expected to read within the sample range of 80 to 85 units during a turnaround. The relief pilot will select any change in the Traffic Advisory Display indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

If the Pack Temperature Control is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Transponder quantity display that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated. The Primary Electrical Bus status message is expected to read within the sample range of 74 to 79 units during landing. During approach, the relief pilot should select the Transponder annunciation when conditions permit.

The Brake Temperature Monitor switch position is expected to read within the sample range of 96 to 100 units during approach. The Autopilot Channel A annunciation is expected to read within the sample range of 33 to 42 units during climb. The Auxiliary Power Unit indication is expected to read within the sample range of 78 to 87 units during a diversion. See 09.30.1 Weather Radar Overview.

CAUTION: If the Hydraulic System B is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B indication is expected to read within the sample range of 23 to 33 units during descent.

CAUTION: If the Autopilot Channel B is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The first officer will monitor any change in the Flap Position Indication annunciation and advise the other pilot once the checklist item is complete. The Nosewheel Steering quantity display that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Fire Detection Loop status message is expected to read within the sample range of 2 to 13 units during takeoff.

04.40.4 Verification: Cockpit Voice Recorder

The Hydraulic System A indication is expected to read within the sample range of 48 to 55 units during landing. The relief pilot will cross-check any change in the Window Heat switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The captain will record any change in the Ground Proximity Monitor advisory and advise the other pilot before the next phase of flight. The Bleed Air Supply selector position that differs from the expected state requires the First Officer to cross-check the condition when operating at a sample station without ground power. During descent, the pilot monitoring should confirm the Wing Anti-Ice annunciation when the associated caution light remains illuminated.

NOTE: If the Transponder is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Window Heat switch position	70 units	Refer to related topic
Hydraulic System A switch position	28 units	Refer to related topic
Flap Position Indication quantity display	88 units	Normal
Hydraulic System B quantity display	39 units	Advisory only
Thrust Reverser switch position	57 units	Monitor
Pack Temperature Control status message	76 units	Monitor

If the Autopilot Channel B is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The first officer will announce any change in the Weather Radar advisory and advise the other pilot before the next phase of flight.

- The first officer will confirm any change in the Weather Radar indication and advise the other pilot if a discrepancy is observed.

- If the Window Heat is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.
- During descent, the Captain should record the Pack Temperature Control indication when conditions permit.
- The Stall Warning indication that differs from the expected state requires both pilots to confirm the condition when conditions permit.
- During approach, the First Officer should select the Brake Temperature Monitor indication when conditions permit.

NOTE: The Center Tank Pumps annunciation is expected to read within the sample range of 3 to 15 units during descent. If the Probe Heat is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The captain will monitor any change in the Standby Instruments switch position and advise the other pilot before the next phase of flight.

The first officer will record any change in the Standby Instruments switch position and advise the other pilot when the associated caution light remains illuminated. If the Window Heat is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will select any change in the Standby Hydraulic quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

04.40.5 Weather Radar Interfaces

The Flight Management Computer selector position that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. The Oxygen Distribution annunciation that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated. If the Transponder is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. During preflight, the pilot monitoring should record the Autopilot Channel A quantity display if a discrepancy is observed. The Thrust Reverser advisory that differs from the expected state requires both pilots to brief the condition once the checklist item is complete.

Condition	Sample value	Remarks
Hydraulic System A annunciation	3 units	Advisory only
Hydraulic System A selector position	37 units	Normal
Autopilot Channel A status message	32 units	Monitor
Landing Gear Indication status message	39 units	Monitor
Pack Temperature Control quantity display	54 units	Normal
Thrust Reverser advisory	87 units	Monitor
Weather Radar status message	46 units	Advisory only

Condition	Sample value	Remarks
Cargo Smoke Detection switch position	37 units	Refer to related topic
Speedbrake Handle quantity display	81 units	Refer to related topic
Cockpit Voice Recorder indication	13 units	Advisory only
Weather Radar switch position	74 units	Monitor
Cargo Smoke Detection annunciation	24 units	Normal

If the Hydraulic System A is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The relief pilot will select any change in the Center Tank Pumps annunciation and advise the other pilot if the indication does not stabilize within the sample interval. During approach, the relief pilot

should confirm the Cargo Smoke Detection switch position when operating at a sample station without ground power.

Condition	Sample value	Remarks
Hydraulic System A switch position	18 units	Advisory only
Hydraulic System A indication	87 units	Refer to related topic
Thrust Reverser annunciation	80 units	Advisory only
Cockpit Voice Recorder status message	6 units	Monitor
Wing Anti-Ice advisory	85 units	Refer to related topic
Autopilot Channel A advisory	59 units	Monitor
Stall Warning selector position	70 units	Refer to related topic

Condition	Sample value	Remarks
Oxygen Distribution switch position	47 units	Normal
Cabin Pressure Controller advisory	59 units	Normal
Thrust Reverser advisory	63 units	Refer to related topic
Probe Heat indication	26 units	Advisory only
Standby Instruments advisory	52 units	Advisory only
Thrust Reverser switch position	82 units	Monitor

04.40.6 Checklist: Fire Detection Loop

The relief pilot will verify any change in the Primary Electrical Bus status message and advise the other pilot unless directed otherwise by the Sample Operations Center. During preflight, the First Officer should cross-check the Autobrake Selector selector position when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

The Window Heat quantity display is expected to read within the sample range of 68 to 77 units during an extended ground delay. If the Weather Radar is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. During preflight, the relief pilot should cross-check the Ground Proximity Monitor indication before the next phase of flight. The Autopilot Channel B status message is expected to read within the sample range of 14 to 26 units during landing. During taxi, both pilots should select the Autobrake Selector annunciation if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Pack Temperature Control is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- The captain will select any change in the Primary Electrical Bus advisory and advise the other pilot once the checklist item is complete.
- If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- During taxi, the First Officer should verify the Window Heat switch position unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.

This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will verify any change in the Flight Management Computer advisory and advise the other pilot once the checklist item is complete. If the Center Tank Pumps is inoperative, continue takeoff only after the First Officer has reviewed the associated

sample guidance.

Condition	Sample value	Remarks
Pack Temperature Control advisory	42 units	Monitor
Hydraulic System A selector position	98 units	Refer to related topic
Standby Hydraulic switch position	87 units	Advisory only
Fire Detection Loop selector position	69 units	Monitor
Cargo Smoke Detection annunciation	3 units	Refer to related topic

- The relief pilot will cross-check any change in the Auxiliary Power Unit selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- Both pilots will confirm any change in the Flap Position Indication switch position and advise the other pilot when operating at a sample station without ground power.
- During landing, the pilot monitoring should monitor the Weather Radar indication when the associated caution light remains illuminated.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments advisory that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated.

The pilot monitoring will confirm any change in the Thrust Reverser indication and advise the other pilot once the checklist item is complete. The relief pilot will brief any change in the Cockpit Voice Recorder switch position and advise the other pilot once the checklist item is complete. During a diversion, the Captain should announce the Transponder switch position if a discrepancy is observed. During a diversion, the relief pilot should select the Cockpit Voice Recorder switch position once the checklist item is complete.

04.40.7 Crew Coordination: Brake Temperature Monitor

This text is fictional and exists only to give the prototype realistic volume and structure. If the Transponder is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Autobrake Selector switch position	20 units	Normal
Cockpit Voice Recorder switch position	93 units	Monitor
Autobrake Selector switch position	87 units	Advisory only
Oxygen Distribution status message	7 units	Advisory only
Flap Position Indication switch position	24 units	Normal
Brake Temperature Monitor advisory	22 units	Monitor
Fire Detection Loop annunciation	68 units	Monitor

The Oxygen Distribution advisory that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center. The Speedbrake Handle annunciation that differs from the expected state requires the First Officer to record the condition once the checklist item is complete. Both pilots will record any change in the Ground Proximity Monitor status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit switch position that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

- Refer to the related topic for additional sample context.

- The captain will brief any change in the Window Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- The Autopilot Channel A switch position is expected to read within the sample range of 19 to 23 units during takeoff.
- The pilot monitoring will confirm any change in the Ground Proximity Monitor status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Cockpit Voice Recorder switch position that differs from the expected state requires the Captain to announce the condition when conditions permit.

During cruise, the pilot monitoring should brief the Weather Radar advisory when operating at a sample station without ground power. The Standby Hydraulic quantity display is expected to read within the sample range of 8 to 20 units during a diversion. The Nosewheel Steering annunciation that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power. The pilot flying will cross-check any change in the Autobrake Selector advisory and advise the other pilot once the checklist item is complete. If the Fire Detection Loop is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The captain will select any change in the Landing Gear Indication switch position and advise the other pilot if a discrepancy is observed.

04.40.8 Briefing: Cargo Smoke Detection

The first officer will record any change in the Engine Anti-Ice annunciation and advise the other pilot once the checklist item is complete. The Center Tank Pumps selector position is expected to read within the sample range of 9 to 13 units during descent. The Engine Anti-Ice selector position that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. If the Cabin Pressure Controller is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The Traffic Advisory Display annunciation that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight. Both pilots will record any change in the Hydraulic System B advisory and advise the other pilot before the next phase of flight.

CAUTION: The Speedbrake Handle selector position that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. If the Brake Temperature Monitor is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Hydraulic System B annunciation	72 units	Normal
Traffic Advisory Display status message	83 units	Monitor
Autobrake Selector quantity display	32 units	Normal
Autopilot Channel B status message	57 units	Advisory only
Standby Hydraulic switch position	70 units	Advisory only
Cargo Smoke Detection switch position	25 units	Monitor
Pack Temperature Control switch position	43 units	Refer to related topic

Values in this manual are invented and must not be used for any operational purpose. The relief pilot will verify any change in the Landing Gear Indication status message and advise the other pilot when conditions permit. The Cockpit Voice Recorder switch position is expected to read within the sample range of 91 to 100 units during

approach.

The Hydraulic System A advisory that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval. The Probe Heat quantity display that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. If the Standby Hydraulic is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

- The Primary Electrical Bus selector position that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight.
- The Landing Gear Indication switch position that differs from the expected state requires the First Officer to verify the condition before the next phase of flight.
- During approach, both pilots should monitor the Bleed Air Supply annunciation when conditions permit.
- The relief pilot will announce any change in the Standby Instruments advisory and advise the other pilot once the checklist item is complete.
- The pilot monitoring will record any change in the Primary Electrical Bus indication and advise the other pilot before the next phase of flight.

If the Standby Hydraulic is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The captain will cross-check any change in the Auxiliary Power Unit quantity display and advise the other pilot when conditions permit. The Engine Anti-Ice advisory that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. The Autobrake Selector selector position that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. The Flap Position Indication status message that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center.

04.40.9 Callouts: Pack Temperature Control

The Autopilot Channel B status message that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center. The Standby Instruments advisory is expected to read within the sample range of 39 to 50 units during landing. During a turnaround, both pilots should confirm the Flight Management Computer status message before the next phase of flight. The pilot monitoring will announce any change in the Flap Position Indication status message and advise the other pilot once the checklist item is complete.

If the Hydraulic System A is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The Center Tank Pumps annunciation is expected to read within the sample range of 19 to 24 units during takeoff. The pilot flying will monitor any change in the Autopilot Channel B switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Bleed Air Supply annunciation is expected to read within the sample range of 78 to 86 units during takeoff. The relief pilot will verify any change in the Fire Detection Loop selector position and advise the other pilot when the associated caution light remains illuminated. The Flight Management Computer switch position is expected to read within the sample range of 75 to 85 units during takeoff.

Condition	Sample value	Remarks
Nosewheel Steering advisory	23 units	Refer to related topic
Traffic Advisory Display switch position	63 units	Monitor
Fuel Crossfeed quantity display	9 units	Refer to related topic
Cockpit Voice Recorder selector position	88 units	Advisory only
Bleed Air Supply indication	74 units	Advisory only

The pilot flying will record any change in the Fire Detection Loop selector position and advise the other pilot when conditions permit. If the Fire Detection Loop is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. During taxi, both pilots should announce the Window Heat annunciation when

conditions permit. Values in this manual are invented and must not be used for any operational purpose.

NOTE: During landing, the relief pilot should announce the Transponder annunciation if the indication does not stabilize within the sample interval.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Fuel Crossfeed is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- The first officer will select any change in the Fuel Crossfeed quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Landing Gear Indication is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	73 units	Monitor
Hydraulic System B quantity display	94 units	Normal
Standby Hydraulic selector position	42 units	Monitor
Flap Position Indication annunciation	88 units	Monitor
Traffic Advisory Display switch position	6 units	Normal
Auxiliary Power Unit advisory	20 units	Advisory only

04.40.10 Crew Coordination: Standby Hydraulic

If the Thrust Reverser is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. During taxi, the pilot flying should brief the Speedbrake Handle selector position if a discrepancy is observed. During a turnaround, the pilot flying should announce the Speedbrake Handle advisory when the associated caution light remains illuminated. The relief pilot will announce any change in the Brake Temperature Monitor switch position and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: During descent, both pilots should confirm the Standby Hydraulic quantity display before the next phase of flight. The Hydraulic System A annunciation that differs from the expected state requires both pilots to announce the condition once the checklist item is complete.

NOTE: The Engine Anti-Ice indication is expected to read within the sample range of 95 to 104 units during a turnaround.

- The pilot monitoring will record any change in the Fire Detection Loop advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Flap Position Indication indication that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed.
- The Weather Radar status message that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center.
- The Traffic Advisory Display selector position is expected to read within the sample range of 42 to 53 units during takeoff.

If the Stall Warning is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Probe Heat switch position that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete. If the Cargo Smoke Detection is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Stall Warning status message is expected to read within the sample range of 54 to 66 units

during a diversion. The captain will confirm any change in the Center Tank Pumps status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Window Heat quantity display that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. If the Weather Radar is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

04.40.11 Flow: Stall Warning

The Window Heat indication that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Bleed Air Supply annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Oxygen Distribution selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Cockpit Voice Recorder switch position	90 units	Advisory only
Landing Gear Indication quantity display	84 units	Refer to related topic
Fuel Crossfeed indication	87 units	Refer to related topic

During a diversion, the Captain should announce the Flight Management Computer quantity display unless directed otherwise by the Sample Operations Center. The captain will verify any change in the Auxiliary Power Unit advisory and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Autobrake Selector is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. If the Primary Electrical Bus is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

The Flap Position Indication switch position is expected to read within the sample range of 92 to 101 units during approach. During takeoff, the First Officer should select the Hydraulic System A indication if the indication does not stabilize within the sample interval. During approach, the Captain should monitor the Fuel Crossfeed advisory once the checklist item is complete. The pilot flying will record any change in the Standby Hydraulic quantity display and advise the other pilot before the next phase of flight. During engine start, the Captain should monitor the Bleed Air Supply advisory when operating at a sample station without ground power. During preflight, the Captain should record the Hydraulic System A annunciation unless directed otherwise by the Sample Operations Center.

- If the Bleed Air Supply is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.
- If the Autothrottle is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- If the Speedbrake Handle is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.
- The Flight Management Computer quantity display that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete.
- The Autopilot Channel B selector position is expected to read within the sample range of 41 to 51 units during preflight.

The Engine Anti-Ice indication is expected to read within the sample range of 85 to 90 units during landing. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel A indication is expected to read within the sample range of 10 to 20 units during taxi. During takeoff, the Captain should cross-check the Auxiliary Power Unit quantity display unless directed otherwise by the Sample Operations Center.

The Window Heat indication is expected to read within the sample range of 15 to 20 units during a maintenance-requested ground run. The wording here is placeholder content shaped like a procedure, not a procedure. During descent, the First Officer should verify the Center Tank Pumps switch position when conditions permit. The first officer will cross-check any change in the Autopilot Channel B status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

04.40.12 Flow: Standby Hydraulic

The Center Tank Pumps selector position that differs from the expected state requires the Captain to brief the condition before the next phase of flight. During a diversion, the First Officer should record the Primary Electrical Bus selector position unless directed otherwise by the Sample Operations Center. During preflight, the pilot flying should monitor the Autopilot Channel A status message if a discrepancy is observed.

The relief pilot will confirm any change in the Hydraulic System A advisory and advise the other pilot once the checklist item is complete. If the Autopilot Channel A is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Landing Gear Indication selector position is expected to read within the sample range of 43 to 54 units during an extended ground delay. The Weather Radar quantity display that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated. The captain will select any change in the Speedbrake Handle indication and advise the other pilot when operating at a sample station without ground power. The Fuel Crossfeed advisory that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Window Heat annunciation	83 units	Monitor
Autobrake Selector switch position	63 units	Advisory only
Primary Electrical Bus advisory	11 units	Normal

If the Landing Gear Indication is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The relief pilot will verify any change in the Wing Anti-Ice indication and advise the other pilot before the next phase of flight. If the Probe Heat is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Oxygen Distribution quantity display is expected to read within the sample range of 39 to 42 units during a maintenance-requested ground run.

During engine start, the relief pilot should record the Transponder switch position when conditions permit. The Window Heat switch position is expected to read within the sample range of 22 to 31 units during an extended ground delay. The Brake Temperature Monitor indication that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. The pilot monitoring will select any change in the Cabin Pressure Controller quantity display and advise the other pilot once the checklist item is complete.

CAUTION: During climb, both pilots should select the Oxygen Distribution quantity display once the checklist item is complete.

During a diversion, the pilot monitoring should select the Engine Anti-Ice indication unless directed otherwise by the Sample Operations Center. The Bleed Air Supply indication is expected to read within the sample range of 68 to 74 units during climb. The Thrust Reverser advisory that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed. The captain will verify any change in the Center Tank Pumps quantity display

and advise the other pilot before the next phase of flight. The Flap Position Indication advisory that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed.

The Autopilot Channel A quantity display that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center. The Pack Temperature Control quantity display that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center. The Window Heat quantity display that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated.

04.40.13 Flow: Stall Warning

This text is fictional and exists only to give the prototype realistic volume and structure. The Cargo Smoke Detection status message that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval. The first officer will verify any change in the Fuel Crossfeed quantity display and advise the other pilot when the associated caution light remains illuminated. The Window Heat annunciation that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete. The pilot monitoring will confirm any change in the Engine Anti-Ice indication and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Center Tank Pumps annunciation	36 units	Advisory only
Flap Position Indication selector position	33 units	Monitor
Hydraulic System A status message	68 units	Monitor
Primary Electrical Bus annunciation	1 units	Refer to related topic
Primary Electrical Bus status message	25 units	Refer to related topic
Autopilot Channel B indication	93 units	Advisory only
Auxiliary Power Unit selector position	38 units	Monitor

CAUTION: The Hydraulic System B indication that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed. The Oxygen Distribution advisory that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete.

The pilot flying will record any change in the Stall Warning annunciation and advise the other pilot once the checklist item is complete. The Fuel Crossfeed selector position is expected to read within the sample range of 22 to 26 units during takeoff. The pilot monitoring will record any change in the Cockpit Voice Recorder switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autobrake Selector annunciation is expected to read within the sample range of 55 to 65 units during engine start.

The first officer will record any change in the Center Tank Pumps advisory and advise the other pilot when conditions permit. The Ground Proximity Monitor annunciation that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. The first officer will cross-check any change in the Wing Anti-Ice quantity display and advise the other pilot once the checklist item is complete.

The Ground Proximity Monitor switch position that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Landing Gear Indication indication that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. The relief pilot will announce any change in the Speedbrake Handle selector position and advise the other pilot if a discrepancy is observed. See 14.30.5 Probe Heat Overview.

04.40.14 Briefing: Hydraulic System A

If the Cabin Pressure Controller is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. During parking, the First Officer should brief the Hydraulic System B indication unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit status message that differs from the expected

state requires the pilot flying to brief the condition once the checklist item is complete.

Condition	Sample value	Remarks
Nosewheel Steering indication	90 units	Normal
Nosewheel Steering annunciation	42 units	Monitor
Probe Heat status message	51 units	Refer to related topic

Refer to the related topic for additional sample context. The Cargo Smoke Detection status message that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. The Nosewheel Steering advisory that differs from the expected state requires the First Officer to monitor the condition when conditions permit. The Wing Anti-Ice indication is expected to read within the sample range of 22 to 32 units during a maintenance-requested ground run.

- If the Weather Radar is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- If the Bleed Air Supply is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- The Hydraulic System A status message is expected to read within the sample range of 16 to 24 units during landing.
- During cruise, the First Officer should select the Fire Detection Loop indication once the checklist item is complete.
- If the Autothrottle is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- Both pilots will monitor any change in the Fuel Crossfeed status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The captain will select any change in the Bleed Air Supply indication and advise the other pilot when conditions permit.
- If the Probe Heat is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

The Wing Anti-Ice selector position is expected to read within the sample range of 88 to 100 units during engine start. During a diversion, the pilot monitoring should record the Center Tank Pumps annunciation once the checklist item is complete. The Traffic Advisory Display status message is expected to read within the sample range of 81 to 85 units during descent. The Wing Anti-Ice status message is expected to read within the sample range of 43 to 55 units during descent.

NOTE: The Auxiliary Power Unit switch position is expected to read within the sample range of 87 to 94 units during engine start.

04.40.15 Verification: Stall Warning

The Thrust Reverser annunciation is expected to read within the sample range of 19 to 28 units during descent. Refer to the related topic for additional sample context. The Fire Detection Loop advisory is expected to read within the sample range of 13 to 23 units during landing.

The captain will announce any change in the Wing Anti-Ice indication and advise the other pilot if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Flight Management Computer selector position is expected to read within the sample range of 23 to 26 units during takeoff. The Probe Heat selector position is expected to read within the sample range of 40 to 44 units during landing. The relief pilot will record any change in the Fuel Crossfeed advisory and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The captain will confirm any change in the Bleed Air Supply status message and advise the other pilot when operating at a sample station without ground power. If the Center Tank Pumps is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

- During landing, the Captain should confirm the Center Tank Pumps switch position when operating at a sample station without ground power.
- The Bleed Air Supply annunciation that differs from the expected state requires the First Officer to announce the condition when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.
- The Cabin Pressure Controller switch position is expected to read within the sample range of 93 to 96 units during landing.
- If the Transponder is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Autobrake Selector advisory	2 units	Refer to related topic
Engine Anti-Ice annunciation	14 units	Refer to related topic
Transponder status message	51 units	Refer to related topic
Bleed Air Supply status message	61 units	Monitor
Autobrake Selector annunciation	31 units	Normal
Engine Anti-Ice advisory	5 units	Normal
Cabin Pressure Controller quantity display	78 units	Refer to related topic

04.40.16 Callouts: Fuel Crossfeed

The Bleed Air Supply annunciation is expected to read within the sample range of 18 to 22 units during takeoff. The first officer will monitor any change in the Engine Anti-Ice switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Pack Temperature Control quantity display is expected to read within the sample range of 30 to 33 units during preflight. If the Autobrake Selector is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Nosewheel Steering selector position is expected to read within the sample range of 50 to 56 units during approach.

- The Engine Anti-Ice advisory is expected to read within the sample range of 31 to 43 units during climb.
- If the Transponder is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: Refer to the related topic for additional sample context.

NOTE: The Window Heat annunciation is expected to read within the sample range of 65 to 69 units during a turnaround.

Condition	Sample value	Remarks
Standby Hydraulic annunciation	15 units	Advisory only
Window Heat selector position	51 units	Advisory only
Standby Instruments selector position	52 units	Normal
Wing Anti-Ice advisory	88 units	Advisory only

04.40.17 Checklist: Ground Proximity Monitor

The Bleed Air Supply status message is expected to read within the sample range of 87 to 99 units during a diversion. The Flap Position Indication indication is expected to read within the sample range of 81 to 90 units during preflight. During taxi, the relief pilot should monitor the Cargo Smoke Detection status message before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will record any change in the Brake Temperature Monitor annunciation and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context.

During engine start, the pilot monitoring should confirm the Autopilot Channel A advisory when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will monitor any change in the Brake Temperature Monitor selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Speedbrake Handle is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The pilot flying will record any change in the Engine Anti-Ice status message and advise the other pilot when operating at a sample station without ground power.

During descent, the First Officer should monitor the Traffic Advisory Display advisory if the indication does not stabilize within the sample interval. The Fire Detection Loop quantity display that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. The Bleed Air Supply switch position is expected to read within the sample range of 19 to 23 units during a maintenance-requested ground run. The Hydraulic System A switch position that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. The Thrust Reverser status message is expected to read within the sample range of 91 to 95 units during descent.

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Wing Anti-Ice status message that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. During a turnaround, the pilot flying should verify the Thrust Reverser advisory when conditions permit. During taxi, the pilot monitoring should record the Fire Detection Loop annunciation when the associated caution light remains illuminated. If the Center Tank Pumps is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

Chapter 05 Non-Normal Procedures

05.10 Air Systems

05.10.1 Auxiliary Power Unit Interfaces

Refer to the related topic for additional sample context. During a turnaround, the Captain should announce the Wing Anti-Ice advisory when conditions permit. The Fuel Crossfeed quantity display is expected to read within the sample range of 93 to 104 units during approach.

Refer to the related topic for additional sample context. The first officer will announce any change in the Hydraulic System B indication and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will cross-check any change in the Brake Temperature Monitor indication and advise the other pilot once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. During a maintenance-requested ground run, both pilots should announce the Engine Anti-Ice selector position when the associated caution light remains illuminated. Both pilots will verify any change in the Hydraulic System B advisory and advise the other pilot when operating at a sample station without ground power.

The Wing Anti-Ice indication is expected to read within the sample range of 72 to 75 units during takeoff. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will record any change in the Traffic Advisory Display quantity display and advise the other pilot when conditions permit. The Standby Instruments selector position is expected to read within the sample range of 52 to 56 units during engine start. The Cabin Pressure Controller switch position is expected to read within the sample range of 85 to 90 units during approach. The Bleed Air Supply selector position is expected to read within the sample range of 75 to 78 units during landing.

CAUTION: During a diversion, both pilots should select the Landing Gear Indication switch position when the associated caution light remains illuminated.

NOTE: Both pilots will brief any change in the Autopilot Channel A annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller quantity display is expected to read within the sample range of 32 to 40 units during climb.

- The Primary Electrical Bus annunciation that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power.
- The Nosewheel Steering indication that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight.
- The Brake Temperature Monitor quantity display is expected to read within the sample range of 89 to 94 units during preflight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The relief pilot will cross-check any change in the Primary Electrical Bus advisory and advise the other pilot if a discrepancy is observed.
- The Oxygen Distribution quantity display is expected to read within the sample range of 80 to 85 units during climb.

05.10.2 Cargo Smoke Detection Indications

The pilot monitoring will announce any change in the Oxygen Distribution indication and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will record any change in the Autobrake Selector annunciation and advise the other pilot when the associated caution light remains illuminated. The Autothrottle status message is expected to read within the sample range of 42 to 48 units during a diversion. Both pilots will verify any change in the Oxygen Distribution quantity display and advise the other pilot unless directed

otherwise by the Sample Operations Center. The Stall Warning quantity display is expected to read within the sample range of 23 to 32 units during a diversion.

- The Standby Hydraulic advisory is expected to read within the sample range of 42 to 53 units during preflight.
- The Traffic Advisory Display indication is expected to read within the sample range of 14 to 20 units during descent.
- If the Standby Hydraulic is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.
- If the Cabin Pressure Controller is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection quantity display is expected to read within the sample range of 98 to 107 units during engine start.

- During parking, the pilot monitoring should brief the Flap Position Indication status message when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.
- The Cabin Pressure Controller advisory is expected to read within the sample range of 73 to 76 units during approach.
- The Autopilot Channel A quantity display is expected to read within the sample range of 4 to 10 units during a turnaround.
- During cruise, the pilot flying should monitor the Primary Electrical Bus switch position when operating at a sample station without ground power.
- If the Engine Anti-Ice is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

CAUTION: The Standby Instruments indication that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. The Autopilot Channel A switch position is expected to read within the sample range of 21 to 26 units during a maintenance-requested ground run.

- During engine start, the relief pilot should brief the Stall Warning advisory before the next phase of flight.
- The Brake Temperature Monitor quantity display is expected to read within the sample range of 18 to 29 units during descent.
- The pilot flying will brief any change in the Cockpit Voice Recorder indication and advise the other pilot once the checklist item is complete.
- If the Cabin Pressure Controller is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- During descent, the pilot flying should select the Landing Gear Indication selector position if a discrepancy is observed.
- The Nosewheel Steering quantity display that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed.
- The pilot monitoring will monitor any change in the Bleed Air Supply quantity display and advise the other pilot when conditions permit.
- The Thrust Reverser switch position that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed.

- The Flight Management Computer quantity display that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Autopilot Channel B	Off
Pack Temperature Control	Closed
Landing Gear Indication	Set
Fuel Crossfeed	Armed
Brake Temperature Monitor	Set
Autobrake Selector	As required
Thrust Reverser	Checked
Autobrake Selector	Verified
Hydraulic System A	Armed
Cockpit Voice Recorder	Checked
Stall Warning	Set

05.10.3 Autopilot Channel B Test

The Fuel Crossfeed advisory is expected to read within the sample range of 27 to 37 units during cruise. The Cabin Pressure Controller selector position that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. The Wing Anti-Ice indication is expected to read within the sample range of 7 to 13 units during descent.

The Standby Instruments status message that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. The relief pilot will cross-check any change in the Stall Warning quantity display and advise the other pilot when the associated caution light remains illuminated. The Oxygen Distribution advisory is expected to read within the sample range of 56 to 64 units during takeoff.

CAUTION: The Center Tank Pumps switch position that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. The relief pilot will select any change in the Flap Position Indication annunciation and advise the other pilot before the next phase of flight. The Brake Temperature Monitor quantity display is expected to read within the sample range of 75 to 86 units during a maintenance-requested ground run. If the Autothrottle is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

NOTE: If the Thrust Reverser is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

The Hydraulic System B advisory is expected to read within the sample range of 20 to 29 units during parking. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System A is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

NOTE: The pilot monitoring will verify any change in the Flap Position Indication switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. During preflight, the First Officer should announce the Weather Radar quantity display if the indication does not stabilize within the sample interval.

If the Fuel Crossfeed is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The captain will brief

any change in the Stall Warning status message and advise the other pilot when the associated caution light remains illuminated. During a turnaround, the Captain should record the Transponder quantity display if the indication does not stabilize within the sample interval. The pilot flying will announce any change in the Weather Radar switch position and advise the other pilot when conditions permit.

CAUTION: The Engine Anti-Ice selector position that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. During an extended ground delay, the relief pilot should announce the Fire Detection Loop switch position once the checklist item is complete.

CAUTION: The Bleed Air Supply quantity display is expected to read within the sample range of 87 to 99 units during approach.

05.10.4 Center Tank Pumps Limits Display

The Speedbrake Handle status message that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center. The Oxygen Distribution indication is expected to read within the sample range of 69 to 72 units during a turnaround. The Speedbrake Handle status message that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Autobrake Selector advisory that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center.

CAUTION: The Window Heat annunciation that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

If the Standby Hydraulic is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During engine start, the pilot monitoring should select the Oxygen Distribution advisory if the indication does not stabilize within the sample interval. The first officer will confirm any change in the Cargo Smoke Detection indication and advise the other pilot when the associated caution light remains illuminated. The relief pilot will record any change in the Autopilot Channel B indication and advise the other pilot once the checklist item is complete. If the Brake Temperature Monitor is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

The Oxygen Distribution advisory that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated. If the Cargo Smoke Detection is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Auxiliary Power Unit selector position that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. During descent, the pilot monitoring should verify the Standby Instruments quantity display once the checklist item is complete. If the Fuel Crossfeed is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Stall Warning annunciation is expected to read within the sample range of 90 to 97 units during preflight.

CAUTION: The Transponder selector position is expected to read within the sample range of 80 to 91 units during cruise. The relief pilot will monitor any change in the Window Heat status message and advise the other pilot when conditions permit.

- The Hydraulic System B annunciation is expected to read within the sample range of 30 to 40 units during taxi.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Fuel Crossfeed status message is expected to read within the sample range of 30 to 42 units during takeoff.
- If the Stall Warning is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

- The Pack Temperature Control annunciation is expected to read within the sample range of 12 to 21 units during climb.
- The Primary Electrical Bus selector position that differs from the expected state requires both pilots to verify the condition when conditions permit.
- The captain will brief any change in the Autobrake Selector indication and advise the other pilot when operating at a sample station without ground power.
- The Autopilot Channel A indication that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated.
- The Cockpit Voice Recorder quantity display is expected to read within the sample range of 7 to 11 units during parking.
- The Ground Proximity Monitor status message that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Speedbrake Handle annunciation	16 units	Normal
Engine Anti-Ice quantity display	8 units	Advisory only
Fire Detection Loop annunciation	70 units	Normal
Autopilot Channel B selector position	61 units	Refer to related topic
Brake Temperature Monitor quantity display	59 units	Advisory only
Cargo Smoke Detection advisory	10 units	Refer to related topic
Probe Heat advisory	4 units	Advisory only

The relief pilot will record any change in the Bleed Air Supply advisory and advise the other pilot before the next phase of flight. The Window Heat switch position is expected to read within the sample range of 26 to 37 units during preflight. During engine start, the pilot monitoring should select the Standby Hydraulic status message when the associated caution light remains illuminated. The Probe Heat indication is expected to read within the sample range of 78 to 87 units during engine start. The wording here is placeholder content shaped like a procedure, not a procedure. The Oxygen Distribution advisory is expected to read within the sample range of 88 to 94 units during engine start.

05.10.5 Fuel Crossfeed Power Sources

The Fuel Crossfeed advisory that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated. During an extended ground delay, the First Officer should brief the Engine Anti-Ice switch position if the indication does not stabilize within the sample interval. The Flap Position Indication quantity display that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center.

The Nosewheel Steering indication is expected to read within the sample range of 33 to 39 units during an extended ground delay. This text is fictional and exists only to give the prototype realistic volume and structure. During engine start, the pilot monitoring should brief the Oxygen Distribution status message when operating at a sample station without ground power. If the Autobrake Selector is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Fuel Crossfeed is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The pilot flying will select any change in the Autothrottle quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Hydraulic System A switch position that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. The first officer will select any change in the Stall Warning quantity display and advise the other pilot when the associated caution light remains illuminated. If the Probe Heat is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot flying should monitor the Nosewheel Steering quantity display unless directed otherwise by the Sample Operations Center.

During descent, the Captain should record the Flight Management Computer annunciation once the checklist item is complete. Both pilots will confirm any change in the Standby Hydraulic annunciation and advise the other pilot when operating at a sample station without ground power. If the Landing Gear Indication is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Cockpit Voice Recorder switch position is expected to read within the sample range of 83 to 93 units during a maintenance-requested ground run. Both pilots will announce any change in the Flap Position Indication selector position and advise the other pilot if the indication does not stabilize within the sample interval.

The Fire Detection Loop selector position is expected to read within the sample range of 17 to 22 units during landing. The captain will confirm any change in the Fuel Crossfeed quantity display and advise the other pilot before the next phase of flight. The Landing Gear Indication quantity display that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. During an extended ground delay, both pilots should monitor the Pack Temperature Control status message unless directed otherwise by the Sample Operations Center. During engine start, the pilot monitoring should announce the Transponder switch position unless directed otherwise by the Sample Operations Center. See 10.30.8 Center Tank Pumps Interfaces.

- NOTE:** The Thrust Reverser indication is expected to read within the sample range of 22 to 27 units during a diversion.
- NOTE:** The Flight Management Computer annunciation that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete.

05.10.6 Autobrake Selector Reset Guidance

The Landing Gear Indication switch position is expected to read within the sample range of 34 to 41 units during cruise. The Cargo Smoke Detection indication that differs from the expected state requires the Captain to cross-check the condition when conditions permit. The Flap Position Indication advisory that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete. The Standby Hydraulic annunciation is expected to read within the sample range of 64 to 76 units during descent. The first officer will confirm any change in the Fire Detection Loop annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

- If the Hydraulic System A is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- The Primary Electrical Bus advisory is expected to read within the sample range of 52 to 55 units during taxi.
- During an extended ground delay, both pilots should verify the Bleed Air Supply switch position if a discrepancy is observed.
- The Wing Anti-Ice status message is expected to read within the sample range of 74 to 81 units during a turnaround.
- The first officer will brief any change in the Hydraulic System B selector position and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Flight Management Computer quantity display	40 units	Monitor
Traffic Advisory Display status message	48 units	Normal
Window Heat annunciation	31 units	Monitor
Brake Temperature Monitor switch position	10 units	Monitor

Cabin Pressure Controller switch position	48 units	Advisory only
Primary Electrical Bus quantity display	68 units	Monitor

The pilot monitoring will brief any change in the Autothrottle status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Landing Gear Indication quantity display is expected to read within the sample range of 75 to 87 units during a diversion. The Transponder status message is expected to read within the sample range of 90 to 98 units during takeoff. The Stall Warning annunciation is expected to read within the sample range of 4 to 16 units during descent.

The relief pilot will confirm any change in the Window Heat switch position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Thrust Reverser status message is expected to read within the sample range of 37 to 43 units during climb.

Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the pilot flying should cross-check the Standby Hydraulic indication if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

- If the Autopilot Channel B is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.
- The first officer will select any change in the Flight Management Computer indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Flight Management Computer is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The captain will cross-check any change in the Nosewheel Steering switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.

The Flight Management Computer switch position is expected to read within the sample range of 19 to 24 units during parking. During approach, the pilot monitoring should cross-check the Pack Temperature Control switch position when operating at a sample station without ground power. During engine start, the relief pilot should announce the Probe Heat indication when the associated caution light remains illuminated. If the Flap Position Indication is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

Challenge	Response
Speedbrake Handle	As required
Pack Temperature Control	On
Autopilot Channel A	On
Cockpit Voice Recorder	Closed
Nosewheel Steering	Set
Stall Warning	Off
Cargo Smoke Detection	On
Flap Position Indication	Checked
Autopilot Channel B	On
Landing Gear Indication	Set

05.10.7 Traffic Advisory Display Overview

The Nosewheel Steering quantity display that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete. The first officer will record any change in the Stall Warning switch position and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System A is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

If the Hydraulic System B is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Weather Radar status message is expected to read within the sample range of 85 to 89 units during landing. The Landing Gear Indication advisory that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power. Both pilots will record any change in the Transponder annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Autopilot Channel B is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

The Flap Position Indication selector position is expected to read within the sample range of 78 to 86 units during a maintenance-requested ground run. The wording here is placeholder content shaped like a procedure, not a procedure. If the Flap Position Indication is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Standby Instruments switch position	38 units	Refer to related topic
Nosewheel Steering indication	62 units	Normal
Nosewheel Steering status message	65 units	Refer to related topic

05.10.8 Standby Hydraulic Reset Guidance

If the Thrust Reverser is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Thrust Reverser switch position that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. If the Landing Gear Indication is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Autobrake Selector quantity display and advise the other pilot when conditions permit. The pilot monitoring will brief any change in the Autopilot Channel A quantity display and advise the other pilot when operating at a sample station without ground power. The Cargo Smoke Detection selector position that differs from the expected state requires the relief pilot to verify the condition when conditions permit.

The Primary Electrical Bus status message that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval. The pilot flying will select any change in the Nosewheel Steering switch position and advise the other pilot if the indication does not stabilize within the sample interval. The pilot flying will monitor any change in the Cargo Smoke Detection quantity display and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Wing Anti-Ice indication	86 units	Monitor
Brake Temperature Monitor switch position	46 units	Normal
Hydraulic System B switch position	83 units	Monitor
Hydraulic System A selector position	11 units	Normal
Autothrottle indication	98 units	Refer to related topic

CAUTION: If the Weather Radar is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During climb, the First Officer should confirm the Landing Gear

Indication switch position when operating at a sample station without ground power.

- The Oxygen Distribution switch position is expected to read within the sample range of 9 to 15 units during preflight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Hydraulic System A status message is expected to read within the sample range of 82 to 89 units during taxi.

The pilot flying will record any change in the Nosewheel Steering switch position and advise the other pilot if the indication does not stabilize within the sample interval. During an extended ground delay, the pilot flying should cross-check the Window Heat annunciation if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle advisory is expected to read within the sample range of 56 to 64 units during engine start. The Cargo Smoke Detection indication that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight.

NOTE: If the Cargo Smoke Detection is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Speedbrake Handle advisory	89 units	Monitor
Brake Temperature Monitor status message	62 units	Monitor
Primary Electrical Bus advisory	28 units	Normal
Weather Radar switch position	89 units	Monitor
Autobrake Selector switch position	71 units	Refer to related topic

NOTE: The pilot monitoring will verify any change in the Flap Position Indication advisory and advise the other pilot if a discrepancy is observed. During cruise, the pilot monitoring should cross-check the Flight Management Computer selector position when operating at a sample station without ground power.

CAUTION: The pilot flying will brief any change in the Fuel Crossfeed quantity display and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

05.10.9 Bleed Air Supply Indications

The first officer will record any change in the Autopilot Channel A switch position and advise the other pilot before the next phase of flight. The Stall Warning advisory is expected to read within the sample range of 69 to 73 units during takeoff. During parking, the relief pilot should select the Traffic Advisory Display selector position if a discrepancy is observed. The Thrust Reverser annunciation is expected to read within the sample range of 35 to 44 units during approach. The Autopilot Channel A status message that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. The Nosewheel Steering selector position that differs from the expected state requires both pilots to record the condition once the checklist item is complete.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The first officer will monitor any change in the Standby Hydraulic switch position and advise the other pilot when conditions permit.
- If the Flap Position Indication is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- The pilot flying will monitor any change in the Nosewheel Steering selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

During a maintenance-requested ground run, the pilot monitoring should confirm the Transponder status message if a discrepancy is observed. The pilot monitoring will confirm any change in the Autobrake Selector indication and advise the other pilot when the associated caution light remains illuminated. During climb, the pilot flying should confirm the Fuel Crossfeed advisory when conditions permit. If the Engine Anti-Ice is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Hydraulic System A indication that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated.

The Wing Anti-Ice annunciation is expected to read within the sample range of 21 to 31 units during climb. During approach, the Captain should brief the Standby Instruments selector position if a discrepancy is observed. The Stall Warning indication that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed. Both pilots will confirm any change in the Flap Position Indication quantity display and advise the other pilot before the next phase of flight.

The Engine Anti-Ice status message that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete. During landing, the relief pilot should select the Ground Proximity Monitor advisory unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Speedbrake Handle status message	34 units	Normal
Cargo Smoke Detection indication	13 units	Advisory only
Autobrake Selector status message	62 units	Advisory only
Speedbrake Handle status message	26 units	Normal
Engine Anti-Ice switch position	45 units	Advisory only

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop selector position is expected to read within the sample range of 47 to 54 units during an extended ground delay.

If the Oxygen Distribution is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Autobrake Selector quantity display that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power. The Center Tank Pumps switch position is expected to read within the sample range of 45 to 49 units during approach. The Thrust Reverser selector position is expected to read within the sample range of 88 to 98 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control status message is expected to read within the sample range of 31 to 34 units during descent.

During descent, the relief pilot should verify the Nosewheel Steering switch position when the associated caution light remains illuminated. If the Fire Detection Loop is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Fire Detection Loop selector position that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. If the Ground Proximity Monitor is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Brake Temperature Monitor status message that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power. See 06.10.3 Standby Hydraulic Reset Guidance.

Challenge	Response
Transponder	Set
Flap Position Indication	As required
Standby Hydraulic	Armed
Landing Gear Indication	Off
Weather Radar	On

Standby Hydraulic	On
Cabin Pressure Controller	Set

05.10.10 *Nosewheel Steering Overview*

During cruise, both pilots should cross-check the Weather Radar advisory once the checklist item is complete. Refer to the related topic for additional sample context. The relief pilot will confirm any change in the Pack Temperature Control status message and advise the other pilot once the checklist item is complete. The Thrust Reverser selector position that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval.

The Autopilot Channel B annunciation is expected to read within the sample range of 60 to 70 units during a turnaround. The Cabin Pressure Controller indication is expected to read within the sample range of 71 to 75 units during preflight. During landing, the First Officer should brief the Hydraulic System B selector position if a discrepancy is observed. If the Weather Radar is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Fuel Crossfeed annunciation is expected to read within the sample range of 16 to 23 units during engine start.

The pilot monitoring will monitor any change in the Weather Radar indication and advise the other pilot when operating at a sample station without ground power. If the Probe Heat is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. During a turnaround, both pilots should monitor the Brake Temperature Monitor indication unless directed otherwise by the Sample Operations Center. During climb, the pilot monitoring should cross-check the Autopilot Channel A quantity display if the indication does not stabilize within the sample interval. The Bleed Air Supply quantity display that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete.

The Bleed Air Supply switch position that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval. The first officer will confirm any change in the Cabin Pressure Controller annunciation and advise the other pilot once the checklist item is complete. If the Standby Instruments is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Flight Management Computer status message that differs from the expected state requires both pilots to verify the condition once the checklist item is complete.

NOTE: The Standby Instruments indication is expected to read within the sample range of 7 to 10 units during approach.

During takeoff, both pilots should monitor the Traffic Advisory Display quantity display when conditions permit. Refer to the related topic for additional sample context. If the Thrust Reverser is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel A indication is expected to read within the sample range of 54 to 61 units during climb. During a turnaround, the pilot monitoring should record the Autothrottle status message when the associated caution light remains illuminated. The Stall Warning indication is expected to read within the sample range of 91 to 95 units during landing.

Challenge	Response
Traffic Advisory Display	Closed
Autobrake Selector	Checked
Autothrottle	Verified
Autothrottle	Armed
Autopilot Channel B	Closed
Speedbrake Handle	Closed
Auxiliary Power Unit	Checked
Flight Management Computer	Off
Autopilot Channel A	Armed

Hydraulic System B	Off
--------------------	-----

05.10.11 Auxiliary Power Unit Indications

The Standby Hydraulic selector position is expected to read within the sample range of 15 to 22 units during cruise. The Window Heat indication is expected to read within the sample range of 3 to 6 units during engine start. The Thrust Reverser annunciation is expected to read within the sample range of 40 to 52 units during descent.

CAUTION: The pilot monitoring will confirm any change in the Landing Gear Indication status message and advise the other pilot when conditions permit.

The pilot monitoring will record any change in the Engine Anti-Ice quantity display and advise the other pilot when the associated caution light remains illuminated. The Window Heat quantity display is expected to read within the sample range of 3 to 13 units during a turnaround. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Fuel Crossfeed status message that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center. The Autopilot Channel A annunciation is expected to read within the sample range of 28 to 32 units during preflight. The Auxiliary Power Unit switch position is expected to read within the sample range of 6 to 18 units during landing.

Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A indication that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. The captain will monitor any change in the Pack Temperature Control status message and advise the other pilot when the associated caution light remains illuminated. The Flap Position Indication indication is expected to read within the sample range of 37 to 42 units during preflight. During climb, the First Officer should cross-check the Autopilot Channel B annunciation when the associated caution light remains illuminated.

- During descent, the relief pilot should select the Autothrottle switch position if the indication does not stabilize within the sample interval.
- During approach, the First Officer should cross-check the Flap Position Indication quantity display unless directed otherwise by the Sample Operations Center.
- Both pilots will announce any change in the Hydraulic System B quantity display and advise the other pilot when conditions permit.
- During climb, the First Officer should record the Ground Proximity Monitor advisory if the indication does not stabilize within the sample interval.
- During cruise, the pilot flying should announce the Cabin Pressure Controller switch position when operating at a sample station without ground power.

The captain will cross-check any change in the Pack Temperature Control selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During preflight, the First Officer should select the Autopilot Channel B status message when the associated caution light remains illuminated. The Traffic Advisory Display switch position that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. The Engine Anti-Ice advisory that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated. The first officer will select any change in the Oxygen Distribution indication and advise the other pilot when the associated caution light remains illuminated. During landing, the pilot flying should cross-check the Hydraulic System B status message if a discrepancy is observed.

The Engine Anti-Ice quantity display that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Ground Proximity Monitor switch position is expected to read within the sample range of 19 to 27 units during taxi. The Window Heat indication is expected to read within the sample range of 60 to 66 units during taxi.

The first officer will record any change in the Auxiliary Power Unit selector position and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System A is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Standby Instruments quantity display that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the First Officer should monitor the Oxygen Distribution selector position when conditions permit.

05.10.12 Wing Anti-Ice Crew Awareness

The Pack Temperature Control switch position is expected to read within the sample range of 82 to 90 units during a maintenance-requested ground run. If the Hydraulic System B is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System B quantity display that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated.

The Primary Electrical Bus switch position that differs from the expected state requires both pilots to cross-check the condition when conditions permit. During cruise, the pilot flying should verify the Flight Management Computer switch position if a discrepancy is observed. The Oxygen Distribution annunciation that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. The Autothrottle quantity display that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete. The Cabin Pressure Controller advisory that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power.

The Cargo Smoke Detection advisory that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed. During cruise, the First Officer should select the Ground Proximity Monitor status message if a discrepancy is observed. The Window Heat selector position is expected to read within the sample range of 19 to 29 units during descent. The Auxiliary Power Unit annunciation that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. If the Probe Heat is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

NOTE: If the Hydraulic System A is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

The Oxygen Distribution selector position that differs from the expected state requires both pilots to announce the condition when conditions permit. The Engine Anti-Ice advisory is expected to read within the sample range of 87 to 98 units during descent. If the Engine Anti-Ice is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Nosewheel Steering annunciation that differs from the expected state requires the Captain to select the condition when conditions permit. The Brake Temperature Monitor indication is expected to read within the sample range of 90 to 102 units during engine start.

Condition	Sample value	Remarks
Engine Anti-Ice advisory	55 units	Monitor
Autobrake Selector annunciation	12 units	Refer to related topic
Bleed Air Supply status message	16 units	Normal
Weather Radar switch position	49 units	Normal
Standby Instruments selector position	87 units	Monitor
Engine Anti-Ice advisory	1 units	Monitor
Hydraulic System A indication	74 units	Advisory only

The pilot monitoring will confirm any change in the Oxygen Distribution status message and advise the other pilot if the indication does not stabilize within the sample interval. The Oxygen Distribution quantity display is expected to read within the sample range of 28 to 34 units during a diversion. The pilot flying will brief any change in the Standby Hydraulic indication and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the relief pilot should announce the Nosewheel Steering annunciation before the next phase of flight. The captain will announce any change in the Ground Proximity Monitor status message and advise the other pilot before the next phase of flight.

05.10.13 Cockpit Voice Recorder Status Messages

During parking, the Captain should record the Brake Temperature Monitor advisory unless directed otherwise by the Sample Operations Center. The pilot monitoring will verify any change in the Autobrake Selector advisory and advise the other pilot when conditions permit. If the Bleed Air Supply is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. Both pilots will record any change in the Auxiliary Power Unit switch position and advise the other pilot when the associated caution light remains illuminated.

If the Stall Warning is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The pilot flying will record any change in the Flap Position Indication status message and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will monitor any change in the Stall Warning annunciation and advise the other pilot before the next phase of flight.

- If the Fire Detection Loop is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- The relief pilot will select any change in the Brake Temperature Monitor annunciation and advise the other pilot when operating at a sample station without ground power.
- If the Wing Anti-Ice is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.
- If the Wing Anti-Ice is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.
- The Primary Electrical Bus switch position that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval.
- During a diversion, the pilot monitoring should confirm the Fire Detection Loop annunciation unless directed otherwise by the Sample Operations Center.

NOTE: Refer to the related topic for additional sample context.

NOTE: The first officer will cross-check any change in the Fuel Crossfeed quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will confirm any change in the Window Heat advisory and advise the other pilot if a discrepancy is observed.

The Wing Anti-Ice annunciation that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Nosewheel Steering switch position that differs from the expected state requires the First Officer to record the condition before the next phase of flight. During taxi, the First Officer should select the Cargo Smoke Detection selector position when the associated caution light remains illuminated. If the Fuel Crossfeed is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context. The Center Tank Pumps annunciation that differs from the expected state requires the Captain to record the condition once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. Both pilots will select any change in the Cargo Smoke Detection advisory and advise the other pilot unless directed otherwise by the Sample

Operations Center. The Fire Detection Loop switch position is expected to read within the sample range of 49 to 54 units during a maintenance-requested ground run.

If the Transponder is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. During descent, the pilot flying should record the Brake Temperature Monitor quantity display before the next phase of flight.

05.10.14 Wing Anti-Ice Normal Operation

The pilot monitoring will announce any change in the Autopilot Channel A annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. During an extended ground delay, the Captain should verify the Pack Temperature Control advisory unless directed otherwise by the Sample Operations Center. If the Engine Anti-Ice is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Landing Gear Indication indication is expected to read within the sample range of 86 to 91 units during engine start.

- The relief pilot will cross-check any change in the Probe Heat advisory and advise the other pilot when conditions permit.
- During a diversion, the relief pilot should announce the Thrust Reverser status message if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.

Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A quantity display is expected to read within the sample range of 77 to 89 units during parking. The Autopilot Channel A switch position that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. If the Transponder is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. If the Pack Temperature Control is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Flight Management Computer annunciation is expected to read within the sample range of 64 to 74 units during preflight.

- During takeoff, both pilots should select the Flight Management Computer indication when conditions permit.
- The Autopilot Channel A indication that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power.
- If the Weather Radar is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- During approach, the First Officer should verify the Hydraulic System B selector position when operating at a sample station without ground power.
- The Landing Gear Indication switch position that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight.
- The Autopilot Channel A indication is expected to read within the sample range of 94 to 100 units during a maintenance-requested ground run.

The Cockpit Voice Recorder quantity display is expected to read within the sample range of 60 to 63 units during a diversion. The Nosewheel Steering status message is expected to read within the sample range of 66 to 74 units during preflight. Values in this manual are invented and must not be used for any operational purpose.

The wording here is placeholder content shaped like a procedure, not a procedure. The Fuel Crossfeed indication that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete. If the Cargo Smoke Detection is inoperative, continue parking only after both pilots has reviewed the associated sample

guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. The Transponder indication that differs from the expected state requires the First Officer to select the condition once the checklist item is complete.

- The Bleed Air Supply switch position that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval.
- During engine start, the First Officer should verify the Landing Gear Indication annunciation if a discrepancy is observed.
- During climb, the relief pilot should monitor the Brake Temperature Monitor status message once the checklist item is complete.

05.10.15 Stall Warning Reset Guidance

During takeoff, the relief pilot should announce the Primary Electrical Bus switch position if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Transponder advisory that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval. The Primary Electrical Bus quantity display is expected to read within the sample range of 21 to 30 units during a diversion. The relief pilot will announce any change in the Primary Electrical Bus switch position and advise the other pilot once the checklist item is complete.

During preflight, the pilot flying should brief the Window Heat quantity display when conditions permit. The pilot flying will select any change in the Center Tank Pumps selector position and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

The pilot flying will monitor any change in the Wing Anti-Ice selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Autopilot Channel B is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Autopilot Channel B switch position that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed.

The Engine Anti-Ice advisory is expected to read within the sample range of 72 to 80 units during descent. Refer to the related topic for additional sample context. During approach, the pilot monitoring should select the Autopilot Channel A annunciation when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Autothrottle switch position that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval.

NOTE: The Engine Anti-Ice selector position that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated. The Autobrake Selector switch position is expected to read within the sample range of 73 to 80 units during climb.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Cockpit Voice Recorder status message is expected to read within the sample range of 65 to 69 units during parking.
- If the Autothrottle is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The Standby Hydraulic advisory that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval.
- During a diversion, the pilot monitoring should confirm the Oxygen Distribution selector position if a discrepancy is observed.
- The Probe Heat quantity display is expected to read within the sample range of 50 to 57 units during descent.

Challenge	Response
Auxiliary Power Unit	Checked
Traffic Advisory Display	Verified

Autothrottle	As required
Center Tank Pumps	Verified
Autopilot Channel B	As required
Wing Anti-Ice	As required
Pack Temperature Control	Armed
Primary Electrical Bus	Verified
Bleed Air Supply	Off
Transponder	As required
Pack Temperature Control	Verified

05.10.16 Autothrottle Crew Awareness

Values in this manual are invented and must not be used for any operational purpose. If the Stall Warning is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Oxygen Distribution status message is expected to read within the sample range of 57 to 62 units during cruise. The Speedbrake Handle switch position that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will brief any change in the Cockpit Voice Recorder switch position and advise the other pilot when the associated caution light remains illuminated. See 11.20.1 Oxygen Distribution Crew Awareness.

NOTE: The Hydraulic System A annunciation is expected to read within the sample range of 34 to 41 units during climb.

- If the Flight Management Computer is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.
- During preflight, the Captain should record the Cockpit Voice Recorder quantity display if the indication does not stabilize within the sample interval.
- During taxi, the pilot flying should confirm the Probe Heat advisory when conditions permit.

CAUTION: Refer to the related topic for additional sample context.

NOTE: If the Thrust Reverser is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. During approach, the pilot flying should confirm the Probe Heat selector position before the next phase of flight.

Challenge	Response
Autothrottle	Checked
Thrust Reverser	Off
Probe Heat	Armed
Speedbrake Handle	On
Autobrake Selector	Verified
Window Heat	Checked
Hydraulic System B	Closed
Oxygen Distribution	Verified
Ground Proximity Monitor	Checked
Flap Position Indication	Verified
Hydraulic System A	Verified
Landing Gear Indication	Closed

05.10.17 Fire Detection Loop Overview

Refer to the related topic for additional sample context. The pilot monitoring will announce any change in the Hydraulic System A annunciation and advise the other pilot once the checklist item is complete. The Center Tank Pumps quantity display that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Fuel Crossfeed quantity display is expected to read within the sample range of 16 to 24 units during descent.

The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, the relief pilot should select the Window Heat selector position if a discrepancy is observed. The first officer will verify any change in the Autothrottle status message and advise the other pilot if the indication does not stabilize within the sample interval.

This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat quantity display that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will brief any change in the Transponder indication and advise the other pilot if the indication does not stabilize within the sample interval. The Traffic Advisory Display annunciation that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Landing Gear Indication status message	59 units	Refer to related topic
Autopilot Channel A annunciation	39 units	Monitor
Cargo Smoke Detection quantity display	50 units	Advisory only
Center Tank Pumps quantity display	55 units	Monitor

The relief pilot will confirm any change in the Ground Proximity Monitor selector position and advise the other pilot once the checklist item is complete. The Bleed Air Supply quantity display is expected to read within the sample range of 80 to 89 units during climb. The Standby Instruments selector position that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed. If the Pack Temperature Control is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. During approach, the First Officer should record the Center Tank Pumps indication once the checklist item is complete.

- The Wing Anti-Ice advisory is expected to read within the sample range of 4 to 15 units during a turnaround.
- Refer to the related topic for additional sample context.
- The Transponder annunciation that differs from the expected state requires the First Officer to verify the condition before the next phase of flight.

CAUTION: If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Oxygen Distribution is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During takeoff, the First Officer should select the Cargo Smoke Detection annunciation before the next phase of flight. During cruise, both pilots should brief the Auxiliary Power Unit annunciation when the associated caution light remains illuminated.

Challenge	Response
Wing Anti-Ice	Armed
Hydraulic System A	Checked
Nosewheel Steering	As required

Standby Instruments	Checked
Cargo Smoke Detection	On
Engine Anti-Ice	Closed
Landing Gear Indication	As required

05.10.18 Window Heat Power Sources

During a turnaround, the pilot monitoring should record the Brake Temperature Monitor indication unless directed otherwise by the Sample Operations Center. The pilot monitoring will select any change in the Stall Warning selector position and advise the other pilot when the associated caution light remains illuminated. During a turnaround, the pilot flying should brief the Standby Hydraulic switch position unless directed otherwise by the Sample Operations Center. If the Autothrottle is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. During approach, the pilot monitoring should announce the Fire Detection Loop quantity display once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Flight Management Computer selector position is expected to read within the sample range of 41 to 46 units during engine start. If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. If the Hydraulic System B is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Primary Electrical Bus switch position that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete. The Center Tank Pumps selector position is expected to read within the sample range of 82 to 90 units during takeoff. The Engine Anti-Ice status message is expected to read within the sample range of 55 to 62 units during a turnaround.

- The Hydraulic System B annunciation that differs from the expected state requires the Captain to cross-check the condition when conditions permit.
- The Landing Gear Indication status message that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated.
- The Flight Management Computer indication that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed.
- The relief pilot will verify any change in the Flap Position Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Brake Temperature Monitor is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

The Weather Radar status message is expected to read within the sample range of 85 to 91 units during a diversion. The pilot flying will verify any change in the Nosewheel Steering switch position and advise the other pilot once the checklist item is complete. During taxi, both pilots should confirm the Hydraulic System A switch position once the checklist item is complete. During takeoff, the Captain should confirm the Probe Heat annunciation if the indication does not stabilize within the sample interval. The Speedbrake Handle status message is expected to read within the sample range of 96 to 105 units during a diversion.

The relief pilot will brief any change in the Standby Instruments selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Fire Detection Loop annunciation is expected to read within the sample range of 80 to 84 units during climb. The Brake Temperature Monitor annunciation that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without

ground power.

CAUTION: During takeoff, the pilot flying should monitor the Auxiliary Power Unit selector position once the checklist item is complete.

During landing, the pilot monitoring should verify the Standby Instruments annunciation before the next phase of flight. Refer to the related topic for additional sample context. The Flight Management Computer status message is expected to read within the sample range of 60 to 65 units during cruise. The Autopilot Channel B quantity display that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

05.10.19 Autopilot Channel A Reset Guidance

If the Engine Anti-Ice is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Weather Radar status message that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed. The Pack Temperature Control annunciation is expected to read within the sample range of 23 to 32 units during landing.

CAUTION: The Autopilot Channel A advisory that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated.

The Window Heat selector position that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed. The pilot flying will select any change in the Weather Radar quantity display and advise the other pilot once the checklist item is complete. During preflight, the pilot flying should select the Standby Instruments annunciation before the next phase of flight. The Transponder advisory is expected to read within the sample range of 95 to 103 units during approach. During a turnaround, the pilot flying should monitor the Brake Temperature Monitor annunciation when conditions permit. The first officer will select any change in the Cargo Smoke Detection status message and advise the other pilot when conditions permit.

NOTE: Both pilots will brief any change in the Standby Instruments selector position and advise the other pilot once the checklist item is complete. If the Center Tank Pumps is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

The captain will confirm any change in the Engine Anti-Ice annunciation and advise the other pilot when operating at a sample station without ground power. During descent, the pilot monitoring should brief the Stall Warning advisory unless directed otherwise by the Sample Operations Center. The Oxygen Distribution annunciation that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete.

- The first officer will record any change in the Transponder status message and advise the other pilot when the associated caution light remains illuminated.
- The Cockpit Voice Recorder status message that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated.
- During approach, the pilot flying should confirm the Center Tank Pumps switch position if the indication does not stabilize within the sample interval.

The pilot flying will verify any change in the Wing Anti-Ice switch position and advise the other pilot once the checklist item is complete. During descent, the First Officer should monitor the Autothrottle selector position unless directed otherwise by the Sample Operations Center. During a turnaround, both pilots should announce the Bleed Air Supply indication when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

05.20 Electrical

05.20.1 Standby Instruments Interfaces

The first officer will cross-check any change in the Transponder quantity display and advise the other pilot if a discrepancy is observed. If the Landing Gear Indication is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During a maintenance-requested ground run, the relief pilot should record the Standby Hydraulic annunciation if a discrepancy is observed. If the Autopilot Channel B is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will brief any change in the Autopilot Channel B selector position and advise the other pilot if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. During climb, the pilot monitoring should select the Autobrake Selector switch position unless directed otherwise by the Sample Operations Center. If the Autopilot Channel A is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The Transponder selector position is expected to read within the sample range of 40 to 48 units during takeoff. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Engine Anti-Ice is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. During engine start, the First Officer should record the Pack Temperature Control indication before the next phase of flight. During approach, the First Officer should verify the Autothrottle status message when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autopilot Channel B switch position	56 units	Refer to related topic
Cabin Pressure Controller selector position	16 units	Refer to related topic
Bleed Air Supply annunciation	63 units	Monitor
Autopilot Channel A selector position	21 units	Monitor
Cabin Pressure Controller advisory	13 units	Refer to related topic

Condition	Sample value	Remarks
Autopilot Channel A switch position	62 units	Refer to related topic
Autothrottle annunciation	55 units	Advisory only
Bleed Air Supply annunciation	63 units	Monitor

CAUTION: The Fuel Crossfeed advisory is expected to read within the sample range of 93 to 100 units during taxi.

Challenge	Response
Cockpit Voice Recorder	Verified
Engine Anti-Ice	As required
Hydraulic System A	Checked
Brake Temperature Monitor	Closed
Pack Temperature Control	On
Hydraulic System B	Closed
Standby Hydraulic	Armed

05.20.2 Brake Temperature Monitor Limits Display

Both pilots will select any change in the Primary Electrical Bus status message and advise the other pilot if a discrepancy is observed. The pilot monitoring will select any change in the Hydraulic System B selector position and advise the other pilot when the associated caution light remains illuminated. During approach, the relief pilot should monitor the Probe Heat indication when operating at a sample station without ground power. The first officer will verify

any change in the Primary Electrical Bus advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Nosewheel Steering is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. During climb, both pilots should announce the Autobrake Selector quantity display when operating at a sample station without ground power. During landing, the pilot monitoring should monitor the Oxygen Distribution advisory unless directed otherwise by the Sample Operations Center. The Landing Gear Indication quantity display that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated.

- The Ground Proximity Monitor quantity display is expected to read within the sample range of 57 to 62 units during preflight.
- During a diversion, the First Officer should announce the Engine Anti-Ice switch position when the associated caution light remains illuminated.
- During a turnaround, the pilot flying should cross-check the Flight Management Computer quantity display when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- During taxi, the First Officer should confirm the Center Tank Pumps selector position if the indication does not stabilize within the sample interval.

The Landing Gear Indication annunciation is expected to read within the sample range of 65 to 71 units during approach. The first officer will record any change in the Hydraulic System B status message and advise the other pilot when operating at a sample station without ground power. Both pilots will brief any change in the Auxiliary Power Unit advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Speedbrake Handle is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

The pilot flying will record any change in the Nosewheel Steering selector position and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The pilot monitoring will cross-check any change in the Engine Anti-Ice quantity display and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: During preflight, the pilot monitoring should select the Flight Management Computer status message if a discrepancy is observed.

Condition	Sample value	Remarks
Landing Gear Indication status message	82 units	Monitor
Flight Management Computer selector position	21 units	Monitor
Speedbrake Handle annunciation	79 units	Refer to related topic
Fuel Crossfeed indication	87 units	Normal
Standby Hydraulic selector position	12 units	Monitor
Speedbrake Handle switch position	96 units	Monitor
Center Tank Pumps annunciation	90 units	Normal

During an extended ground delay, both pilots should confirm the Center Tank Pumps selector position once the checklist item is complete. The pilot monitoring will announce any change in the Oxygen Distribution quantity display and advise the other pilot if a discrepancy is observed. The Wing Anti-Ice annunciation that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed.

Challenge	Response
Nosewheel Steering	Armed
Weather Radar	Closed

Standby Instruments	Closed
Flap Position Indication	Closed
Window Heat	As required
Oxygen Distribution	As required
Center Tank Pumps	Verified
Autothrottle	Closed
Nosewheel Steering	Closed
Window Heat	Armed
Cargo Smoke Detection	Armed
Bleed Air Supply	Armed

05.20.3 Landing Gear Indication Interfaces

The Cabin Pressure Controller status message is expected to read within the sample range of 17 to 29 units during a turnaround. During cruise, the First Officer should record the Transponder quantity display when operating at a sample station without ground power. The Flap Position Indication quantity display that differs from the expected state requires the pilot flying to select the condition before the next phase of flight.

Condition	Sample value	Remarks
Center Tank Pumps annunciation	93 units	Refer to related topic
Autothrottle advisory	95 units	Refer to related topic
Hydraulic System B switch position	62 units	Normal
Hydraulic System A quantity display	57 units	Refer to related topic
Cabin Pressure Controller switch position	78 units	Monitor

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The Center Tank Pumps annunciation that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. The Speedbrake Handle switch position that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. The Landing Gear Indication advisory is expected to read within the sample range of 87 to 96 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: Refer to the related topic for additional sample context. During taxi, both pilots should record the Thrust Reverser advisory if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Fuel Crossfeed indication	51 units	Normal
Transponder switch position	76 units	Refer to related topic
Fuel Crossfeed status message	60 units	Monitor

- If the Oxygen Distribution is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- The Center Tank Pumps quantity display is expected to read within the sample range of 23 to 34 units during a maintenance-requested ground run.
- The relief pilot will confirm any change in the Center Tank Pumps indication and advise the other pilot if a discrepancy is observed.

- The Hydraulic System A status message that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed.
- The Window Heat indication that differs from the expected state requires both pilots to verify the condition before the next phase of flight.

CAUTION: The Traffic Advisory Display quantity display is expected to read within the sample range of 10 to 22 units during preflight.

Values in this manual are invented and must not be used for any operational purpose. The Flap Position Indication annunciation that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center. If the Fuel Crossfeed is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Autobrake Selector quantity display and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Primary Electrical Bus is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer selector position is expected to read within the sample range of 26 to 33 units during takeoff.

Challenge	Response
Autopilot Channel B	On
Wing Anti-Ice	Set
Autobrake Selector	Armed
Cockpit Voice Recorder	Set
Thrust Reverser	Set
Weather Radar	Checked
Stall Warning	Armed
Oxygen Distribution	As required
Hydraulic System A	Verified
Standby Hydraulic	As required
Thrust Reverser	Set
Bleed Air Supply	On

05.20.4 Ground Proximity Monitor Status Messages

The Autopilot Channel A selector position that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. If the Pack Temperature Control is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The Standby Instruments quantity display that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. Both pilots will verify any change in the Fire Detection Loop advisory and advise the other pilot when conditions permit. The captain will announce any change in the Ground Proximity Monitor quantity display and advise the other pilot once the checklist item is complete.

NOTE: The first officer will cross-check any change in the Autothrottle quantity display and advise the other pilot when operating at a sample station without ground power.

The Landing Gear Indication status message is expected to read within the sample range of 43 to 51 units during a diversion. The captain will verify any change in the Probe Heat annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Weather Radar indication that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Speedbrake Handle selector position that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight.
- The Weather Radar quantity display that differs from the expected state requires the pilot flying to record the condition when conditions permit.
- The Engine Anti-Ice annunciation is expected to read within the sample range of 59 to 71 units during engine start.
- The Wing Anti-Ice annunciation that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete.
- The Cockpit Voice Recorder annunciation that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power.
- The Speedbrake Handle advisory that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated.
- The Autopilot Channel A advisory is expected to read within the sample range of 81 to 84 units during parking.
- Values in this manual are invented and must not be used for any operational purpose.
- The captain will confirm any change in the Weather Radar annunciation and advise the other pilot if a discrepancy is observed.
- The Flap Position Indication indication is expected to read within the sample range of 42 to 47 units during approach.
- If the Fire Detection Loop is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Values in this manual are invented and must not be used for any operational purpose.
- The pilot monitoring will announce any change in the Standby Hydraulic status message and advise the other pilot when operating at a sample station without ground power.
- The Hydraulic System A indication is expected to read within the sample range of 22 to 33 units during landing.
- If the Cockpit Voice Recorder is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Oxygen Distribution status message	46 units	Monitor
Hydraulic System B quantity display	65 units	Refer to related topic
Bleed Air Supply indication	27 units	Monitor

The Flight Management Computer quantity display is expected to read within the sample range of 7 to 16 units during landing. If the Nosewheel Steering is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Oxygen Distribution advisory is expected to read within the sample range of 98 to 104 units during taxi.

Refer to the related topic for additional sample context. The Flap Position Indication advisory is expected to read within the sample range of 58 to 69 units during takeoff. The Landing Gear Indication annunciation is expected to read within the sample range of 69 to 78 units during cruise. The pilot monitoring will cross-check any change in the Autobrake Selector indication and advise the other pilot before the next phase of flight. If the Fire Detection Loop is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

Challenge	Response
Weather Radar	As required

Auxiliary Power Unit	Checked
Cockpit Voice Recorder	Off
Nosewheel Steering	Closed
Hydraulic System B	Closed
Autothrottle	Verified
Standby Instruments	Off
Standby Instruments	As required
Wing Anti-Ice	Closed

05.20.5 Nosewheel Steering Power Sources

The wording here is placeholder content shaped like a procedure, not a procedure. If the Fuel Crossfeed is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will monitor any change in the Window Heat switch position and advise the other pilot when conditions permit. If the Oxygen Distribution is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

During approach, both pilots should brief the Fire Detection Loop selector position once the checklist item is complete. The Engine Anti-Ice switch position that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. The pilot flying will announce any change in the Ground Proximity Monitor annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Nosewheel Steering is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Hydraulic System A quantity display is expected to read within the sample range of 85 to 88 units during cruise. If the Traffic Advisory Display is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Flight Management Computer advisory is expected to read within the sample range of 19 to 23 units during taxi. The Hydraulic System A indication that differs from the expected state requires both pilots to monitor the condition when conditions permit.

The Probe Heat switch position is expected to read within the sample range of 29 to 37 units during parking. The Engine Anti-Ice switch position that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. The Traffic Advisory Display selector position is expected to read within the sample range of 71 to 79 units during takeoff.

Refer to the related topic for additional sample context. The relief pilot will brief any change in the Transponder selector position and advise the other pilot once the checklist item is complete. The pilot monitoring will monitor any change in the Window Heat switch position and advise the other pilot once the checklist item is complete. The Standby Instruments switch position that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. The relief pilot will select any change in the Standby Instruments quantity display and advise the other pilot when the associated caution light remains illuminated. The pilot flying will cross-check any change in the Center Tank Pumps advisory and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Thrust Reverser status message that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight. If the Nosewheel Steering is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

- Values in this manual are invented and must not be used for any operational purpose.
- During landing, both pilots should brief the Fire Detection Loop switch position when the associated caution light remains illuminated.
- If the Speedbrake Handle is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

- The first officer will select any change in the Center Tank Pumps switch position and advise the other pilot when conditions permit.
- The Autobrake Selector switch position is expected to read within the sample range of 49 to 52 units during climb.
- The pilot monitoring will confirm any change in the Engine Anti-Ice selector position and advise the other pilot if a discrepancy is observed.
- During climb, both pilots should verify the Nosewheel Steering quantity display if a discrepancy is observed.
- The captain will confirm any change in the Ground Proximity Monitor annunciation and advise the other pilot if a discrepancy is observed.
- The Cabin Pressure Controller advisory is expected to read within the sample range of 14 to 17 units during preflight.
- The first officer will monitor any change in the Flight Management Computer quantity display and advise the other pilot when the associated caution light remains illuminated.
- The first officer will record any change in the Wing Anti-Ice indication and advise the other pilot once the checklist item is complete.

CAUTION: The pilot monitoring will record any change in the Flight Management Computer status message and advise the other pilot when operating at a sample station without ground power. The Flight Management Computer advisory that differs from the expected state requires the Captain to brief the condition when conditions permit.

Challenge	Response
Hydraulic System B	As required
Brake Temperature Monitor	As required
Flap Position Indication	Verified
Fuel Crossfeed	Armed
Autothrottle	Off
Oxygen Distribution	As required
Cargo Smoke Detection	Verified
Stall Warning	Verified
Thrust Reverser	Closed
Center Tank Pumps	Verified
Bleed Air Supply	As required
Fuel Crossfeed	Set

05.20.6 Center Tank Pumps Status Messages

The pilot flying will select any change in the Auxiliary Power Unit switch position and advise the other pilot if the indication does not stabilize within the sample interval. During takeoff, the pilot flying should verify the Pack Temperature Control status message if the indication does not stabilize within the sample interval. The Window Heat advisory is expected to read within the sample range of 64 to 68 units during descent. The Pack Temperature Control status message that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. The captain will cross-check any change in the Transponder quantity display and advise the other pilot if a discrepancy is observed.

The pilot monitoring will brief any change in the Standby Instruments advisory and advise the other pilot once the checklist item is complete. The Cargo Smoke Detection quantity display is expected to read within the sample range of 9 to 21 units during a turnaround. The Cargo Smoke Detection quantity display is expected to read within the

sample range of 93 to 96 units during takeoff.

The Primary Electrical Bus advisory is expected to read within the sample range of 7 to 19 units during parking. The relief pilot will select any change in the Nosewheel Steering switch position and advise the other pilot before the next phase of flight. If the Bleed Air Supply is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The captain will select any change in the Autopilot Channel B advisory and advise the other pilot if the indication does not stabilize within the sample interval.

The first officer will record any change in the Hydraulic System B switch position and advise the other pilot once the checklist item is complete. If the Ground Proximity Monitor is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Bleed Air Supply indication is expected to read within the sample range of 34 to 38 units during descent.

If the Brake Temperature Monitor is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will confirm any change in the Brake Temperature Monitor advisory and advise the other pilot once the checklist item is complete. During descent, the First Officer should cross-check the Wing Anti-Ice indication unless directed otherwise by the Sample Operations Center. If the Autopilot Channel B is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autopilot Channel A quantity display	48 units	Advisory only
Wing Anti-Ice advisory	2 units	Normal
Autothrottle advisory	40 units	Advisory only

NOTE: The Fire Detection Loop indication is expected to read within the sample range of 77 to 88 units during takeoff. During a turnaround, the First Officer should cross-check the Standby Instruments quantity display when operating at a sample station without ground power.

CAUTION: During cruise, the pilot monitoring should confirm the Auxiliary Power Unit annunciation if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The Thrust Reverser quantity display that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center. The Fire Detection Loop switch position that differs from the expected state requires both pilots to confirm the condition before the next phase of flight.

Challenge	Response
Center Tank Pumps	Closed
Transponder	On
Weather Radar	Closed
Ground Proximity Monitor	Off
Ground Proximity Monitor	Set
Hydraulic System A	Set
Probe Heat	On
Ground Proximity Monitor	Set
Autothrottle	On
Ground Proximity Monitor	Checked
Fuel Crossfeed	Armed

Thrust Reverser	On
-----------------	----

05.20.7 Engine Anti-Ice Overview

The Window Heat switch position that differs from the expected state requires the Captain to announce the condition when conditions permit. The Nosewheel Steering advisory is expected to read within the sample range of 63 to 69 units during landing. If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Primary Electrical Bus is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 76 to 85 units during an extended ground delay.

Condition	Sample value	Remarks
Hydraulic System B annunciation	37 units	Refer to related topic
Stall Warning switch position	2 units	Normal
Hydraulic System A indication	45 units	Monitor
Stall Warning selector position	31 units	Normal
Auxiliary Power Unit advisory	6 units	Refer to related topic
Autobrake Selector annunciation	86 units	Refer to related topic
Hydraulic System B advisory	26 units	Refer to related topic

The Flap Position Indication indication is expected to read within the sample range of 11 to 17 units during climb. The pilot flying will cross-check any change in the Ground Proximity Monitor advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Fire Detection Loop selector position is expected to read within the sample range of 41 to 50 units during a diversion. The Hydraulic System B advisory is expected to read within the sample range of 23 to 32 units during cruise. The Window Heat quantity display that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. The Autothrottle advisory that differs from the expected state requires the Captain to select the condition before the next phase of flight.

During a diversion, the First Officer should cross-check the Autopilot Channel B advisory before the next phase of flight. If the Primary Electrical Bus is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. During taxi, both pilots should select the Auxiliary Power Unit annunciation once the checklist item is complete. If the Primary Electrical Bus is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Hydraulic System B selector position is expected to read within the sample range of 94 to 103 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure.

05.20.8 Transponder Limits Display

The Hydraulic System A switch position is expected to read within the sample range of 84 to 88 units during climb. If the Hydraulic System A is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Flight Management Computer annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autopilot Channel B quantity display is expected to read within the sample range of 25 to 37 units during a turnaround.

Condition	Sample value	Remarks
Hydraulic System A switch position	76 units	Normal
Traffic Advisory Display switch position	95 units	Advisory only
Transponder quantity display	79 units	Normal

Thrust Reverser selector position	51 units	Normal
Thrust Reverser annunciation	58 units	Monitor

CAUTION: The relief pilot will monitor any change in the Cargo Smoke Detection annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Center Tank Pumps is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. During approach, the First Officer should cross-check the Autopilot Channel A selector position unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During landing, the pilot flying should confirm the Hydraulic System B status message when operating at a sample station without ground power. The Autobrake Selector advisory is expected to read within the sample range of 64 to 72 units during preflight.

The wording here is placeholder content shaped like a procedure, not a procedure. The Bleed Air Supply status message that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. If the Fuel Crossfeed is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

The Window Heat switch position is expected to read within the sample range of 92 to 98 units during climb. The Hydraulic System B selector position that differs from the expected state requires the First Officer to verify the condition when conditions permit. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	10 units	Normal
Ground Proximity Monitor annunciation	78 units	Advisory only
Primary Electrical Bus indication	39 units	Normal
Cargo Smoke Detection indication	24 units	Advisory only
Bleed Air Supply selector position	20 units	Monitor
Weather Radar status message	10 units	Monitor

The Landing Gear Indication annunciation is expected to read within the sample range of 22 to 27 units during taxi. During an extended ground delay, the Captain should record the Nosewheel Steering indication when operating at a sample station without ground power. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 6 to 17 units during an extended ground delay. The Standby Instruments quantity display is expected to read within the sample range of 15 to 21 units during parking. The Nosewheel Steering annunciation that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed.

05.20.9 Autobrake Selector Limits Display

If the Traffic Advisory Display is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. During taxi, the First Officer should cross-check the Cabin Pressure Controller switch position unless directed otherwise by the Sample Operations Center. The Transponder annunciation that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. The captain will select any change in the Flap Position Indication quantity display and advise the other pilot once the checklist item is complete. The pilot monitoring will verify any change in the Ground Proximity Monitor indication and advise the other pilot before the next phase of flight. During a maintenance-requested ground run, the pilot monitoring should brief the Auxiliary Power Unit advisory when the associated caution light remains illuminated.

CAUTION: During a turnaround, the relief pilot should verify the Engine Anti-Ice quantity display once the checklist item is complete.

Condition	Sample value	Remarks
-----------	--------------	---------

Wing Anti-Ice switch position	85 units	Refer to related topic
Pack Temperature Control selector position	20 units	Advisory only
Standby Hydraulic annunciation	9 units	Refer to related topic
Cargo Smoke Detection selector position	74 units	Monitor

- If the Autopilot Channel B is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.
- The Bleed Air Supply advisory is expected to read within the sample range of 5 to 11 units during descent.
- The Hydraulic System B indication that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power.
- If the Pack Temperature Control is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

CAUTION: The relief pilot will select any change in the Fuel Crossfeed quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

- During a turnaround, both pilots should confirm the Primary Electrical Bus selector position when operating at a sample station without ground power.
- During a turnaround, the pilot monitoring should monitor the Thrust Reverser advisory when conditions permit.
- During a maintenance-requested ground run, the pilot flying should announce the Pack Temperature Control status message before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

CAUTION: The Weather Radar status message that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. If the Standby Hydraulic is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

05.20.10 Cargo Smoke Detection Limits Display

The Flight Management Computer indication that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated. Both pilots will record any change in the Oxygen Distribution switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder quantity display that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. The Bleed Air Supply status message is expected to read within the sample range of 33 to 38 units during takeoff. During descent, the pilot monitoring should verify the Wing Anti-Ice selector position once the checklist item is complete.

The Cockpit Voice Recorder indication is expected to read within the sample range of 59 to 70 units during cruise. The pilot monitoring will select any change in the Ground Proximity Monitor status message and advise the other pilot when operating at a sample station without ground power. If the Autopilot Channel B is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

The Hydraulic System A status message that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed. The Oxygen Distribution annunciation is expected to read within the sample range of 56 to 60 units during parking. If the Cabin Pressure Controller is inoperative, continue taxi only after both

pilots has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. During climb, the pilot flying should verify the Window Heat selector position once the checklist item is complete. If the Standby Instruments is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. During engine start, the First Officer should brief the Standby Hydraulic indication once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The first officer will cross-check any change in the Autobrake Selector switch position and advise the other pilot if the indication does not stabilize within the sample interval.

- During takeoff, the pilot flying should brief the Speedbrake Handle indication unless directed otherwise by the Sample Operations Center.
- The Flight Management Computer annunciation that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated.
- The Speedbrake Handle switch position that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete.
- The Ground Proximity Monitor switch position that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed.
- If the Standby Hydraulic is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.
- The Speedbrake Handle switch position that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated.

CAUTION: The first officer will verify any change in the Hydraulic System B annunciation and advise the other pilot when the associated caution light remains illuminated.

05.20.11 Nosewheel Steering Interfaces

The Auxiliary Power Unit status message that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed. If the Wing Anti-Ice is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop annunciation that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. The Bleed Air Supply selector position that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power. If the Probe Heat is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

CAUTION: If the Weather Radar is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Weather Radar selector position that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic switch position is expected to read within the sample range of 22 to 30 units during a diversion. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Probe Heat indication	80 units	Normal
Autopilot Channel A switch position	99 units	Monitor
Standby Instruments status message	70 units	Refer to related topic

Condition	Sample value	Remarks
Bleed Air Supply quantity display	82 units	Normal

Flap Position Indication selector position	61 units	Refer to related topic
Flap Position Indication advisory	85 units	Normal
Center Tank Pumps selector position	86 units	Normal

- The Pack Temperature Control quantity display is expected to read within the sample range of 97 to 101 units during preflight.
- The Engine Anti-Ice status message that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Probe Heat is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

05.20.12 Autopilot Channel A Overview

If the Thrust Reverser is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Cargo Smoke Detection indication is expected to read within the sample range of 89 to 96 units during a diversion. During descent, the relief pilot should brief the Fire Detection Loop selector position before the next phase of flight. The Autopilot Channel B selector position is expected to read within the sample range of 72 to 82 units during a maintenance-requested ground run. The Fuel Crossfeed switch position that differs from the expected state requires the relief pilot to record the condition when conditions permit.

- Both pilots will cross-check any change in the Thrust Reverser switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.
- If the Speedbrake Handle is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- The Weather Radar advisory that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated.
- The Window Heat indication that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete.
- If the Pack Temperature Control is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Traffic Advisory Display status message	16 units	Advisory only
Speedbrake Handle switch position	17 units	Refer to related topic
Wing Anti-Ice quantity display	95 units	Refer to related topic

- The Brake Temperature Monitor advisory is expected to read within the sample range of 74 to 82 units during a turnaround.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During taxi, the pilot monitoring should brief the Autopilot Channel A quantity display unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.

- During preflight, the First Officer should select the Brake Temperature Monitor status message once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.

NOTE: The relief pilot will brief any change in the Primary Electrical Bus selector position and advise the other pilot if the indication does not stabilize within the sample interval.

The pilot monitoring will brief any change in the Center Tank Pumps status message and advise the other pilot when the associated caution light remains illuminated. If the Cargo Smoke Detection is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Cargo Smoke Detection selector position that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.

- Values in this manual are invented and must not be used for any operational purpose.
- During taxi, the pilot monitoring should record the Autopilot Channel B indication before the next phase of flight.
- If the Transponder is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a turnaround, the pilot monitoring should brief the Ground Proximity Monitor quantity display unless directed otherwise by the Sample Operations Center.
- The Autobrake Selector status message that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval.

Challenge	Response
Brake Temperature Monitor	Closed
Autopilot Channel B	Off
Wing Anti-Ice	Set
Hydraulic System A	On
Cockpit Voice Recorder	Verified
Window Heat	Closed
Fire Detection Loop	Off
Cabin Pressure Controller	As required

05.20.13 Weather Radar Status Messages

This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will record any change in the Standby Hydraulic annunciation and advise the other pilot if a discrepancy is observed. The Standby Instruments selector position is expected to read within the sample range of 41 to 51 units during descent. During takeoff, the First Officer should monitor the Standby Instruments annunciation once the checklist item is complete.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Cargo Smoke Detection status message is expected to read within the sample range of 31 to 36 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Probe Heat annunciation	41 units	Refer to related topic
Traffic Advisory Display advisory	20 units	Refer to related topic
Cargo Smoke Detection quantity display	12 units	Normal

Hydraulic System B switch position	30 units	Advisory only
------------------------------------	----------	---------------

CAUTION: During takeoff, the pilot monitoring should confirm the Thrust Reverser switch position before the next phase of flight. During an extended ground delay, the relief pilot should confirm the Cockpit Voice Recorder indication when conditions permit.

If the Standby Hydraulic is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The Standby Instruments indication that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval. If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The pilot monitoring will record any change in the Flight Management Computer selector position and advise the other pilot when operating at a sample station without ground power.

The Thrust Reverser selector position that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. During cruise, the pilot flying should confirm the Pack Temperature Control quantity display if a discrepancy is observed. The Flap Position Indication indication is expected to read within the sample range of 3 to 12 units during engine start. During engine start, both pilots should confirm the Primary Electrical Bus annunciation when conditions permit.

If the Landing Gear Indication is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Transponder annunciation that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power. During climb, the pilot flying should monitor the Cabin Pressure Controller annunciation before the next phase of flight.

If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. During parking, the Captain should confirm the Landing Gear Indication quantity display if the indication does not stabilize within the sample interval.

The Hydraulic System A quantity display is expected to read within the sample range of 26 to 37 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure. The Bleed Air Supply status message that differs from the expected state requires the Captain to confirm the condition when conditions permit. The relief pilot will announce any change in the Ground Proximity Monitor indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Bleed Air Supply quantity display is expected to read within the sample range of 78 to 85 units during approach.

05.20.14 Oxygen Distribution Indications

Refer to the related topic for additional sample context. The Stall Warning annunciation is expected to read within the sample range of 66 to 76 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will select any change in the Probe Heat advisory and advise the other pilot once the checklist item is complete. If the Flap Position Indication is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

The relief pilot will verify any change in the Autothrottle quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. During parking, the relief pilot should cross-check the Transponder status message when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The Bleed Air Supply indication that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Stall Warning switch position is expected to read within the sample range of 46 to 57 units during landing.

The Oxygen Distribution annunciation that differs from the expected state requires the First Officer to confirm the condition when conditions permit. The pilot flying will verify any change in the Oxygen Distribution quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Autobrake Selector advisory that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Cockpit Voice Recorder switch position that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. During a maintenance-requested ground run, the pilot monitoring should record the Hydraulic System A advisory when operating at a sample station without ground power. If the Autopilot Channel A is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Transponder indication is expected to read within the sample range of 74 to 79 units during a maintenance-requested ground run.

- The Cargo Smoke Detection switch position that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight.
- During an extended ground delay, both pilots should brief the Window Heat status message when the associated caution light remains illuminated.
- If the Cockpit Voice Recorder is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

- If the Autopilot Channel A is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- During preflight, the First Officer should confirm the Standby Hydraulic advisory when operating at a sample station without ground power.
- The Autobrake Selector selector position that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated.
- The Probe Heat indication that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval.
- The Primary Electrical Bus quantity display is expected to read within the sample range of 56 to 62 units during landing.
- Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Standby Instruments status message	21 units	Advisory only
Nosewheel Steering advisory	20 units	Advisory only
Flap Position Indication indication	20 units	Advisory only
Cockpit Voice Recorder indication	72 units	Monitor
Autopilot Channel B advisory	20 units	Normal
Bleed Air Supply advisory	34 units	Refer to related topic

CAUTION: The Auxiliary Power Unit indication is expected to read within the sample range of 12 to 18 units during an extended ground delay. The Speedbrake Handle status message is expected to read within the sample range of 36 to 42 units during taxi.

05.20.15 Weather Radar Normal Operation

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will record any change in the Wing Anti-Ice advisory and advise the other pilot before the next phase of flight. During landing, the pilot flying should brief the Flight Management Computer indication if a discrepancy is observed. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

The relief pilot will cross-check any change in the Auxiliary Power Unit indication and advise the other pilot once the checklist item is complete. During a turnaround, both pilots should confirm the Hydraulic System B switch position when operating at a sample station without ground power. The Probe Heat status message that differs from the expected state requires the relief pilot to record the condition when conditions permit. The Nosewheel Steering quantity display is expected to read within the sample range of 94 to 101 units during descent. The Hydraulic System A quantity display that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight.

During approach, the relief pilot should monitor the Hydraulic System A quantity display when operating at a sample station without ground power. If the Cargo Smoke Detection is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The first officer will record any change in the Flap Position Indication annunciation and advise the other pilot when conditions permit. The Primary Electrical Bus advisory is expected to read within the sample range of 75 to 80 units during a maintenance-requested ground run. If the Hydraulic System A is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

If the Autopilot Channel B is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The Cockpit Voice Recorder switch position is expected to read within the sample range of 88 to 93 units during landing. Values in this manual are invented and must not be used for any operational purpose. During landing, the pilot flying should brief the Pack Temperature Control annunciation once the checklist item is complete.

The Traffic Advisory Display advisory is expected to read within the sample range of 79 to 85 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure. If the Stall Warning is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Oxygen Distribution quantity display that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. The Cabin Pressure Controller annunciation that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. The pilot flying will monitor any change in the Cargo Smoke Detection switch position and advise the other pilot when conditions permit.

Challenge	Response
Engine Anti-Ice	Armed
Stall Warning	Verified
Cabin Pressure Controller	Closed
Thrust Reverser	On
Center Tank Pumps	Armed
Landing Gear Indication	Set
Standby Hydraulic	Off
Center Tank Pumps	Checked
Hydraulic System B	As required
Flight Management Computer	On
Speedbrake Handle	Closed

05.20.16 Thrust Reverser Status Messages

The Window Heat status message that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. The relief pilot will select any change in the Pack Temperature Control advisory and advise the other pilot before the next phase of flight. During landing, the pilot flying should select the Wing Anti-Ice

annunciation if the indication does not stabilize within the sample interval. If the Standby Instruments is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

CAUTION: The pilot monitoring will monitor any change in the Auxiliary Power Unit quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

The Engine Anti-Ice quantity display is expected to read within the sample range of 91 to 99 units during approach. The Fire Detection Loop annunciation is expected to read within the sample range of 6 to 18 units during takeoff. During parking, the Captain should select the Standby Hydraulic switch position when operating at a sample station without ground power. The Cargo Smoke Detection advisory that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. During taxi, both pilots should verify the Engine Anti-Ice status message when operating at a sample station without ground power. The Cockpit Voice Recorder switch position is expected to read within the sample range of 40 to 49 units during an extended ground delay. If the Transponder is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The relief pilot will select any change in the Standby Hydraulic status message and advise the other pilot if a discrepancy is observed.
- During takeoff, the relief pilot should cross-check the Wing Anti-Ice annunciation when conditions permit.
- The Autobrake Selector quantity display that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center.
- The pilot monitoring will brief any change in the Cockpit Voice Recorder advisory and advise the other pilot when operating at a sample station without ground power.

CAUTION: During a maintenance-requested ground run, the First Officer should verify the Bleed Air Supply selector position unless directed otherwise by the Sample Operations Center. During climb, the pilot flying should confirm the Flight Management Computer quantity display unless directed otherwise by the Sample Operations Center.

- If the Standby Instruments is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- The Flight Management Computer quantity display that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center.
- The Speedbrake Handle advisory is expected to read within the sample range of 98 to 105 units during an extended ground delay.

05.20.17 *Primary Electrical Bus Test*

The relief pilot will cross-check any change in the Bleed Air Supply selector position and advise the other pilot if a discrepancy is observed. The relief pilot will announce any change in the Nosewheel Steering selector position and advise the other pilot if the indication does not stabilize within the sample interval. During takeoff, the pilot monitoring should announce the Oxygen Distribution switch position if the indication does not stabilize within the sample interval. The Fuel Crossfeed indication is expected to read within the sample range of 21 to 33 units during descent. The pilot monitoring will verify any change in the Weather Radar status message and advise the other pilot when conditions permit.

NOTE: If the Pack Temperature Control is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Engine Anti-Ice annunciation is expected to read within the sample range of 21 to 24 units during takeoff. Values in this manual are invented and must not be used for any operational purpose.

NOTE: If the Hydraulic System B is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autobrake Selector advisory	82 units	Normal
Traffic Advisory Display status message	18 units	Monitor
Oxygen Distribution annunciation	74 units	Normal
Fire Detection Loop selector position	90 units	Advisory only

If the Probe Heat is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. Both pilots will cross-check any change in the Autobrake Selector quantity display and advise the other pilot when the associated caution light remains illuminated. The Traffic Advisory Display indication that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power. If the Center Tank Pumps is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

Challenge	Response
Autopilot Channel B	Off
Nosewheel Steering	On
Autothrottle	Armed
Stall Warning	On
Auxiliary Power Unit	Closed
Probe Heat	Closed
Nosewheel Steering	Checked
Traffic Advisory Display	On
Fuel Crossfeed	Armed
Center Tank Pumps	Off
Cockpit Voice Recorder	Checked
Cargo Smoke Detection	Off

05.20.18 Pack Temperature Control Limits Display

The Brake Temperature Monitor indication is expected to read within the sample range of 36 to 42 units during taxi. If the Primary Electrical Bus is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. During an extended ground delay, the pilot flying should record the Center Tank Pumps switch position when the associated caution light remains illuminated. During cruise, the First Officer should cross-check the Engine Anti-Ice indication if the indication does not stabilize within the sample interval.

CAUTION: The pilot monitoring will confirm any change in the Transponder quantity display and advise the other pilot when conditions permit. Both pilots will cross-check any change in the Flight Management Computer indication and advise the other pilot before the next phase of flight.

CAUTION: The Engine Anti-Ice annunciation that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed.

The Engine Anti-Ice advisory that differs from the expected state requires the pilot flying to verify the condition when conditions permit. Refer to the related topic for additional sample context. The Bleed Air Supply status message that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete. During a maintenance-requested ground run, both pilots should announce the Window Heat selector position once

the checklist item is complete. During approach, the relief pilot should monitor the Window Heat selector position when operating at a sample station without ground power.

The Cargo Smoke Detection switch position is expected to read within the sample range of 46 to 56 units during a maintenance-requested ground run. The first officer will select any change in the Cabin Pressure Controller advisory and advise the other pilot if a discrepancy is observed. The Landing Gear Indication switch position that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus annunciation that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed.

Challenge	Response
Autopilot Channel A	On
Traffic Advisory Display	Armed
Cabin Pressure Controller	Verified
Nosewheel Steering	Verified
Autopilot Channel B	Off
Flap Position Indication	Set

05.20.19 Autopilot Channel A Power Sources

The Transponder indication is expected to read within the sample range of 29 to 37 units during preflight. The pilot flying will record any change in the Fire Detection Loop advisory and advise the other pilot when operating at a sample station without ground power. If the Cargo Smoke Detection is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. During an extended ground delay, the Captain should cross-check the Brake Temperature Monitor selector position unless directed otherwise by the Sample Operations Center. The Autopilot Channel B switch position that differs from the expected state requires both pilots to select the condition when conditions permit. The Landing Gear Indication status message that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center.

CAUTION: Refer to the related topic for additional sample context.

The relief pilot will confirm any change in the Pack Temperature Control advisory and advise the other pilot before the next phase of flight. The Standby Hydraulic annunciation that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments status message is expected to read within the sample range of 69 to 74 units during parking. The Autobrake Selector quantity display that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Thrust Reverser is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display annunciation that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Speedbrake Handle annunciation	39 units	Refer to related topic
Auxiliary Power Unit quantity display	53 units	Advisory only
Landing Gear Indication switch position	6 units	Normal
Primary Electrical Bus selector position	43 units	Refer to related topic
Bleed Air Supply advisory	74 units	Refer to related topic

CAUTION: Refer to the related topic for additional sample context. During preflight, the First Officer should record the Weather Radar quantity display unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will select any change in the Hydraulic System B indication and advise the other pilot before the next phase of flight. During climb, the First Officer should cross-check the Window Heat annunciation once the checklist item is complete.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The Cockpit Voice Recorder status message that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete.

05.20.20 Speedbrake Handle Crew Awareness

Refer to the related topic for additional sample context. During descent, both pilots should brief the Fuel Crossfeed status message if a discrepancy is observed. The Flap Position Indication status message is expected to read within the sample range of 15 to 21 units during a diversion. During a turnaround, the Captain should verify the Hydraulic System B annunciation when conditions permit.

The Thrust Reverser switch position is expected to read within the sample range of 73 to 80 units during a maintenance-requested ground run. The relief pilot will confirm any change in the Autopilot Channel A status message and advise the other pilot when the associated caution light remains illuminated. Both pilots will monitor any change in the Stall Warning advisory and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Engine Anti-Ice annunciation	83 units	Monitor
Wing Anti-Ice selector position	96 units	Monitor
Auxiliary Power Unit quantity display	45 units	Normal
Bleed Air Supply selector position	25 units	Normal
Traffic Advisory Display advisory	21 units	Advisory only

Condition	Sample value	Remarks
Probe Heat switch position	73 units	Monitor
Engine Anti-Ice indication	69 units	Normal
Hydraulic System A annunciation	69 units	Refer to related topic
Fire Detection Loop selector position	62 units	Refer to related topic

- The Bleed Air Supply status message that differs from the expected state requires the Captain to record the condition once the checklist item is complete.
- The Fire Detection Loop switch position that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power.
- Refer to the related topic for additional sample context.

NOTE: The Engine Anti-Ice switch position is expected to read within the sample range of 89 to 101 units during landing.

The Stall Warning selector position that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. During climb, the pilot flying should record the Engine Anti-Ice switch position if the indication does not stabilize within the sample interval. During descent, the First Officer should cross-check the Wing Anti-Ice quantity display unless directed otherwise by the Sample Operations Center. The Transponder indication is expected to read within the sample range of 47 to 52 units during takeoff.

Challenge	Response
Center Tank Pumps	Closed
Traffic Advisory Display	Verified
Cargo Smoke Detection	Checked
Nosewheel Steering	Closed
Cargo Smoke Detection	Set
Cabin Pressure Controller	Set

05.30 Fuel

05.30.1 Ground Proximity Monitor Limits Display

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will announce any change in the Fire Detection Loop selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Thrust Reverser indication is expected to read within the sample range of 30 to 37 units during parking. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The captain will monitor any change in the Engine Anti-Ice advisory and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Wing Anti-Ice advisory that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.

- If the Primary Electrical Bus is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.
- During takeoff, the relief pilot should monitor the Stall Warning status message once the checklist item is complete.
- During a maintenance-requested ground run, the pilot monitoring should monitor the Hydraulic System B indication when the associated caution light remains illuminated.
- During a maintenance-requested ground run, the Captain should monitor the Flight Management Computer switch position before the next phase of flight.
- During a diversion, the pilot flying should verify the Autopilot Channel A status message unless directed otherwise by the Sample Operations Center.
- If the Ground Proximity Monitor is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The Bleed Air Supply quantity display that differs from the expected state requires the Captain to record the condition before the next phase of flight.
- The Pack Temperature Control annunciation that differs from the expected state requires the pilot flying to record the condition when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Traffic Advisory Display indication	44 units	Refer to related topic
Stall Warning switch position	56 units	Monitor
Flap Position Indication annunciation	79 units	Refer to related topic

CAUTION: If the Standby Hydraulic is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

During a diversion, the Captain should confirm the Brake Temperature Monitor selector position when conditions permit. If the Speedbrake Handle is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Autobrake Selector quantity display and advise the other pilot when operating at a sample station without ground power.

05.30.2 Oxygen Distribution Crew Awareness

If the Autopilot Channel B is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Fire Detection Loop status message that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete. The Transponder annunciation is expected to read within the sample range of 61 to 64 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat switch position that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. If the Autopilot Channel A is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context.

- The pilot monitoring will monitor any change in the Autopilot Channel A quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- The Autopilot Channel A status message is expected to read within the sample range of 28 to 32 units during a turnaround.
- During a maintenance-requested ground run, the Captain should select the Hydraulic System A advisory unless directed otherwise by the Sample Operations Center.
- If the Transponder is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Speedbrake Handle switch position is expected to read within the sample range of 98 to 108 units during climb.

During engine start, the pilot flying should brief the Weather Radar indication unless directed otherwise by the Sample Operations Center. The captain will confirm any change in the Cargo Smoke Detection selector position and advise the other pilot before the next phase of flight. During approach, the pilot monitoring should announce the Auxiliary Power Unit annunciation when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel A indication that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated. If the Cockpit Voice Recorder is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

CAUTION: During parking, the First Officer should select the Pack Temperature Control annunciation when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

- The Standby Hydraulic indication that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated.
- During taxi, the pilot monitoring should monitor the Flight Management Computer status message before the next phase of flight.
- During a maintenance-requested ground run, the First Officer should monitor the Weather Radar indication when operating at a sample station without ground power.

- If the Speedbrake Handle is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- If the Brake Temperature Monitor is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- During an extended ground delay, the Captain should record the Window Heat quantity display before the next phase of flight.

The Cabin Pressure Controller indication that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the First Officer should confirm the Stall Warning selector position if a discrepancy is observed.

05.30.3 Autopilot Channel B Overview

The Standby Hydraulic selector position is expected to read within the sample range of 82 to 88 units during landing. If the Auxiliary Power Unit is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Standby Hydraulic status message that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The Pack Temperature Control indication is expected to read within the sample range of 52 to 61 units during taxi. During parking, the Captain should confirm the Cargo Smoke Detection annunciation if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. During climb, the Captain should brief the Auxiliary Power Unit switch position once the checklist item is complete.

CAUTION: Both pilots will announce any change in the Autopilot Channel B selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Primary Electrical Bus annunciation	32 units	Refer to related topic
Nosewheel Steering indication	69 units	Advisory only
Fuel Crossfeed status message	78 units	Monitor
Engine Anti-Ice selector position	83 units	Advisory only
Flight Management Computer status message	40 units	Advisory only
Window Heat annunciation	95 units	Advisory only
Flight Management Computer switch position	3 units	Refer to related topic

NOTE: The captain will record any change in the Engine Anti-Ice selector position and advise the other pilot once the checklist item is complete. The Thrust Reverser annunciation is expected to read within the sample range of 10 to 20 units during taxi.

05.30.4 Engine Anti-Ice Normal Operation

The wording here is placeholder content shaped like a procedure, not a procedure. If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Auxiliary Power Unit status message that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. If the Stall Warning is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During climb, the First Officer should record the Cabin Pressure Controller advisory once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Flight Management Computer selector position that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed. The Autopilot Channel A quantity display is expected to read within the sample range of 96 to 101 units during engine start.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Cabin Pressure Controller quantity display	66 units	Normal
Ground Proximity Monitor advisory	93 units	Refer to related topic
Autopilot Channel A switch position	87 units	Refer to related topic

NOTE: During descent, the pilot monitoring should announce the Autothrottle quantity display before the next phase of flight.

- Refer to the related topic for additional sample context.
- During a diversion, the First Officer should announce the Speedbrake Handle annunciation once the checklist item is complete.
- The Thrust Reverser advisory that differs from the expected state requires the relief pilot to verify the condition if a discrepancy is observed.
- If the Wing Anti-Ice is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. During parking, the relief pilot should brief the Standby Instruments status message when the associated caution light remains illuminated. If the Standby Instruments is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Center Tank Pumps indication that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. The pilot flying will cross-check any change in the Primary Electrical Bus selector position and advise the other pilot if a discrepancy is observed.

Challenge	Response
Flap Position Indication	Armed
Brake Temperature Monitor	On
Brake Temperature Monitor	Verified
Oxygen Distribution	On
Standby Hydraulic	Verified
Speedbrake Handle	Checked
Wing Anti-Ice	As required
Flight Management Computer	As required
Autopilot Channel B	Off
Primary Electrical Bus	Verified
Window Heat	Checked

05.30.5 Fuel Crossfeed Crew Awareness

The Oxygen Distribution switch position is expected to read within the sample range of 10 to 13 units during engine start. Values in this manual are invented and must not be used for any operational purpose. The Thrust Reverser

annunciation is expected to read within the sample range of 23 to 33 units during climb. The Stall Warning quantity display that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autothrottle is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

The Fire Detection Loop status message is expected to read within the sample range of 25 to 29 units during takeoff. Both pilots will cross-check any change in the Autobrake Selector quantity display and advise the other pilot once the checklist item is complete. The relief pilot will announce any change in the Thrust Reverser selector position and advise the other pilot if the indication does not stabilize within the sample interval. See 07.10.1 Autopilot Channel A Overview.

NOTE: The Cargo Smoke Detection annunciation that differs from the expected state requires the pilot flying to record the condition before the next phase of flight. The Auxiliary Power Unit advisory that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated.

CAUTION: Refer to the related topic for additional sample context.

NOTE: Both pilots will select any change in the Pack Temperature Control status message and advise the other pilot before the next phase of flight. The Bleed Air Supply selector position that differs from the expected state requires the Captain to confirm the condition before the next phase of flight.

05.30.6 Hydraulic System B Reset Guidance

Values in this manual are invented and must not be used for any operational purpose. The Landing Gear Indication quantity display that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight. The captain will select any change in the Autothrottle status message and advise the other pilot when operating at a sample station without ground power.

The relief pilot will record any change in the Stall Warning annunciation and advise the other pilot when the associated caution light remains illuminated. During preflight, both pilots should confirm the Engine Anti-Ice indication when the associated caution light remains illuminated. The first officer will announce any change in the Wing Anti-Ice advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. During a maintenance-requested ground run, the First Officer should cross-check the Autothrottle switch position when conditions permit.

CAUTION: If the Fire Detection Loop is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Auxiliary Power Unit annunciation	93 units	Normal
Auxiliary Power Unit indication	71 units	Advisory only
Autobrake Selector status message	2 units	Refer to related topic
Nosewheel Steering status message	39 units	Monitor
Primary Electrical Bus selector position	28 units	Monitor
Autopilot Channel A switch position	80 units	Refer to related topic

05.30.7 Flap Position Indication Interfaces

If the Standby Hydraulic is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. If the Window Heat is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During landing, the First Officer should verify the Pack Temperature Control annunciation once the

checklist item is complete.

Condition	Sample value	Remarks
Cabin Pressure Controller annunciation	35 units	Refer to related topic
Traffic Advisory Display status message	10 units	Monitor
Cabin Pressure Controller indication	17 units	Refer to related topic

The captain will verify any change in the Flap Position Indication indication and advise the other pilot when operating at a sample station without ground power. The pilot flying will select any change in the Stall Warning indication and advise the other pilot once the checklist item is complete. The Autothrottle selector position that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. The Auxiliary Power Unit indication is expected to read within the sample range of 50 to 55 units during preflight. See 10.30.4 Hydraulic System B Status Messages.

Condition	Sample value	Remarks
Engine Anti-Ice switch position	72 units	Refer to related topic
Probe Heat quantity display	40 units	Advisory only
Autopilot Channel B status message	83 units	Advisory only

Condition	Sample value	Remarks
Cabin Pressure Controller indication	39 units	Advisory only
Autopilot Channel A status message	95 units	Advisory only
Cargo Smoke Detection switch position	56 units	Advisory only
Hydraulic System B status message	1 units	Monitor
Transponder selector position	95 units	Refer to related topic
Cabin Pressure Controller quantity display	84 units	Normal

Challenge	Response
Autopilot Channel B	As required
Weather Radar	Armed
Engine Anti-Ice	Set
Landing Gear Indication	Armed
Speedbrake Handle	Set
Speedbrake Handle	Set
Cargo Smoke Detection	Set

05.30.8 Autopilot Channel A Crew Awareness

If the Oxygen Distribution is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Hydraulic System A is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The Autobrake Selector quantity display that differs from the expected state requires the Captain to confirm the condition before the next phase of flight. Refer to the related topic for additional sample context. If the Brake Temperature Monitor is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

The Auxiliary Power Unit switch position is expected to read within the sample range of 12 to 24 units during engine start. The first officer will record any change in the Wing Anti-Ice switch position and advise the other pilot if a discrepancy is observed. If the Traffic Advisory Display is inoperative, continue engine start only after the First Officer

has reviewed the associated sample guidance.

During preflight, the pilot flying should confirm the Window Heat status message before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will confirm any change in the Hydraulic System A annunciation and advise the other pilot when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

The Window Heat indication is expected to read within the sample range of 77 to 86 units during preflight. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Center Tank Pumps switch position is expected to read within the sample range of 40 to 48 units during an extended ground delay. The Bleed Air Supply quantity display is expected to read within the sample range of 6 to 13 units during a diversion.

CAUTION: The pilot monitoring will select any change in the Transponder status message and advise the other pilot when the associated caution light remains illuminated.

The Fire Detection Loop advisory that differs from the expected state requires both pilots to brief the condition when conditions permit. The pilot flying will verify any change in the Autopilot Channel A annunciation and advise the other pilot if a discrepancy is observed. The Autothrottle quantity display that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated. The Stall Warning indication that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

05.30.9 Wing Anti-Ice Indications

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. During parking, the Captain should monitor the Probe Heat switch position when operating at a sample station without ground power. If the Flight Management Computer is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

The captain will select any change in the Landing Gear Indication annunciation and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The Center Tank Pumps selector position is expected to read within the sample range of 76 to 85 units during preflight.

CAUTION: Refer to the related topic for additional sample context. If the Center Tank Pumps is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. During descent, the Captain should verify the Flap Position Indication advisory when operating at a sample station without ground power.

NOTE: The Center Tank Pumps switch position that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power. The Autopilot Channel A advisory is expected to read within the sample range of 68 to 77 units during a diversion.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Cabin Pressure Controller is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Standby Hydraulic advisory is expected to read within the sample range of 61 to 70 units during landing. If the Autothrottle is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display quantity display that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Thrust Reverser	Armed
Engine Anti-Ice	As required

Landing Gear Indication	Armed
Fire Detection Loop	Checked
Cabin Pressure Controller	On
Nosewheel Steering	On
Probe Heat	Off

05.30.10 Fire Detection Loop Crew Awareness

This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System B is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. During a diversion, the Captain should record the Center Tank Pumps status message when conditions permit. The Wing Anti-Ice selector position is expected to read within the sample range of 69 to 75 units during cruise.

The Hydraulic System A selector position that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated. The captain will monitor any change in the Speedbrake Handle switch position and advise the other pilot when conditions permit. The Standby Instruments advisory that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. If the Autothrottle is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

NOTE: The pilot monitoring will announce any change in the Standby Instruments annunciation and advise the other pilot when the associated caution light remains illuminated. The Flight Management Computer status message that differs from the expected state requires the pilot flying to verify the condition when conditions permit.

The Brake Temperature Monitor annunciation that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. The Window Heat advisory that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated. During landing, the Captain should verify the Oxygen Distribution switch position when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, both pilots should monitor the Autopilot Channel B advisory when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autopilot Channel B status message	63 units	Advisory only
Bleed Air Supply status message	87 units	Advisory only
Primary Electrical Bus status message	32 units	Refer to related topic
Cabin Pressure Controller switch position	44 units	Monitor
Autopilot Channel A advisory	95 units	Refer to related topic

- The pilot monitoring will monitor any change in the Stall Warning indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Cabin Pressure Controller is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.
- During cruise, the relief pilot should brief the Bleed Air Supply indication before the next phase of flight.
- The Oxygen Distribution quantity display is expected to read within the sample range of 33 to 43 units during a maintenance-requested ground run.
- The first officer will record any change in the Cabin Pressure Controller advisory and advise the other pilot before the next phase of flight.

During landing, both pilots should select the Hydraulic System B status message if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat advisory is expected to read within the sample range of 20 to 30 units during cruise. Both pilots will cross-check any change in the Weather Radar annunciation and advise the other pilot when conditions permit. If the Speedbrake Handle is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cargo Smoke Detection annunciation	64 units	Normal
Autothrottle status message	68 units	Monitor
Probe Heat selector position	27 units	Refer to related topic
Landing Gear Indication annunciation	63 units	Monitor
Landing Gear Indication annunciation	43 units	Normal
Autobrake Selector selector position	19 units	Monitor
Bleed Air Supply status message	15 units	Normal

05.30.11 Nosewheel Steering Indications

During a turnaround, the First Officer should cross-check the Cockpit Voice Recorder advisory if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. During taxi, the First Officer should verify the Ground Proximity Monitor switch position if a discrepancy is observed. The Oxygen Distribution advisory is expected to read within the sample range of 57 to 68 units during landing.

The pilot flying will verify any change in the Fire Detection Loop switch position and advise the other pilot if a discrepancy is observed. The Nosewheel Steering selector position that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

The captain will cross-check any change in the Auxiliary Power Unit status message and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System B is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will brief any change in the Oxygen Distribution quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Autopilot Channel A switch position	84 units	Monitor
Probe Heat advisory	95 units	Monitor
Hydraulic System B quantity display	99 units	Monitor
Center Tank Pumps selector position	72 units	Monitor
Traffic Advisory Display advisory	67 units	Advisory only
Fuel Crossfeed annunciation	13 units	Advisory only

Condition	Sample value	Remarks
Autothrottle switch position	89 units	Refer to related topic
Thrust Reverser advisory	39 units	Monitor
Primary Electrical Bus selector position	17 units	Refer to related topic
Probe Heat quantity display	33 units	Advisory only

The Wing Anti-Ice quantity display that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power. The Auxiliary Power Unit advisory is expected to read within the sample range of 56 to 65 units during taxi. During approach, the relief pilot should brief the Hydraulic System B advisory when conditions permit. If the Speedbrake Handle is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

The Cockpit Voice Recorder switch position is expected to read within the sample range of 93 to 96 units during approach. The pilot flying will announce any change in the Standby Instruments status message and advise the other pilot if a discrepancy is observed. If the Primary Electrical Bus is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. During climb, the pilot flying should select the Autopilot Channel A advisory if a discrepancy is observed. The relief pilot will brief any change in the Window Heat status message and advise the other pilot once the checklist item is complete.

The Autothrottle switch position is expected to read within the sample range of 84 to 96 units during engine start. During parking, the relief pilot should record the Cabin Pressure Controller indication when the associated caution light remains illuminated. The first officer will record any change in the Cargo Smoke Detection switch position and advise the other pilot if a discrepancy is observed. See 17.10.3 Weather Radar Normal Operation.

05.30.12 Wing Anti-Ice Normal Operation

If the Center Tank Pumps is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Pack Temperature Control quantity display is expected to read within the sample range of 68 to 75 units during cruise. If the Hydraulic System B is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

- Both pilots will verify any change in the Wing Anti-Ice switch position and advise the other pilot when operating at a sample station without ground power.
- The first officer will monitor any change in the Window Heat indication and advise the other pilot when the associated caution light remains illuminated.
- The Pack Temperature Control annunciation that differs from the expected state requires the First Officer to brief the condition when conditions permit.
- The Transponder switch position is expected to read within the sample range of 4 to 15 units during parking.

During approach, the pilot monitoring should select the Brake Temperature Monitor selector position if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A indication that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed.

CAUTION: Refer to the related topic for additional sample context. The pilot flying will record any change in the Standby Instruments advisory and advise the other pilot when operating at a sample station without ground power.

NOTE: If the Hydraulic System A is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. During a maintenance-requested ground run, the First Officer should monitor the Flight Management Computer quantity display if a discrepancy is observed.

Condition	Sample value	Remarks
Auxiliary Power Unit annunciation	24 units	Normal
Nosewheel Steering selector position	15 units	Refer to related topic
Bleed Air Supply status message	99 units	Refer to related topic
Autothrottle advisory	47 units	Monitor
Cabin Pressure Controller annunciation	30 units	Refer to related topic

Challenge	Response
Auxiliary Power Unit	Armed
Autopilot Channel B	Set
Engine Anti-Ice	Off
Brake Temperature Monitor	As required
Cockpit Voice Recorder	Set
Landing Gear Indication	Off

05.30.13 Autothrottle Limits Display

If the Cockpit Voice Recorder is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. During a diversion, the relief pilot should monitor the Speedbrake Handle status message if a discrepancy is observed. The Stall Warning switch position that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Standby Hydraulic annunciation	46 units	Normal
Ground Proximity Monitor switch position	3 units	Normal
Nosewheel Steering quantity display	21 units	Monitor
Probe Heat annunciation	80 units	Advisory only
Primary Electrical Bus status message	2 units	Monitor

If the Weather Radar is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Thrust Reverser selector position is expected to read within the sample range of 90 to 102 units during takeoff. During an extended ground delay, the relief pilot should cross-check the Speedbrake Handle annunciation once the checklist item is complete.

If the Landing Gear Indication is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. Both pilots will verify any change in the Transponder quantity display and advise the other pilot if a discrepancy is observed. The Engine Anti-Ice indication is expected to read within the sample range of 50 to 54 units during a maintenance-requested ground run. The Bleed Air Supply quantity display that differs from the expected state requires the relief pilot to verify the condition once the checklist item is complete. See 08.10.15 Wing Anti-Ice Reset Guidance.

Condition	Sample value	Remarks
Pack Temperature Control status message	7 units	Refer to related topic
Ground Proximity Monitor advisory	95 units	Advisory only
Pack Temperature Control quantity display	49 units	Normal
Hydraulic System B indication	79 units	Normal
Brake Temperature Monitor status message	37 units	Monitor
Center Tank Pumps status message	9 units	Refer to related topic

05.30.14 Autobrake Selector Crew Awareness

During climb, the pilot monitoring should announce the Traffic Advisory Display advisory when conditions permit. The Autopilot Channel A advisory that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight. During a diversion, the pilot flying should verify the Standby Instruments quantity display before the next phase of flight. If the Traffic Advisory Display is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will select any change in the Cabin

Pressure Controller advisory and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The Transponder status message that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. The Oxygen Distribution selector position is expected to read within the sample range of 50 to 61 units during preflight.

The pilot monitoring will announce any change in the Window Heat switch position and advise the other pilot if a discrepancy is observed. If the Autothrottle is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Hydraulic System B is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: During engine start, both pilots should select the Thrust Reverser quantity display when operating at a sample station without ground power.

Condition	Sample value	Remarks
Speedbrake Handle selector position	65 units	Refer to related topic
Fire Detection Loop selector position	20 units	Monitor
Autopilot Channel A switch position	71 units	Refer to related topic
Standby Hydraulic indication	55 units	Advisory only
Bleed Air Supply indication	74 units	Normal
Oxygen Distribution selector position	11 units	Refer to related topic

The Wing Anti-Ice selector position that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. The Hydraulic System A quantity display that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval. If the Standby Instruments is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Hydraulic System B quantity display that differs from the expected state requires both pilots to select the condition once the checklist item is complete.

- During parking, the First Officer should monitor the Nosewheel Steering advisory if the indication does not stabilize within the sample interval.
- If the Traffic Advisory Display is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- If the Autopilot Channel A is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- The Bleed Air Supply indication is expected to read within the sample range of 10 to 14 units during descent.
- The Nosewheel Steering advisory is expected to read within the sample range of 11 to 23 units during takeoff.
- The Bleed Air Supply quantity display that differs from the expected state requires both pilots to select the condition when conditions permit.
- The Landing Gear Indication selector position that differs from the expected state requires the pilot monitoring to select the condition when conditions permit.
- During a diversion, the pilot monitoring should select the Center Tank Pumps quantity display if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During descent, both pilots should verify the Primary Electrical Bus advisory when operating at a sample station without ground power.

- The Flight Management Computer quantity display is expected to read within the sample range of 93 to 104 units during descent.
- Refer to the related topic for additional sample context.
- The pilot monitoring will record any change in the Fuel Crossfeed indication and advise the other pilot once the checklist item is complete.
- Both pilots will select any change in the Brake Temperature Monitor indication and advise the other pilot when operating at a sample station without ground power.
- The Landing Gear Indication quantity display is expected to read within the sample range of 75 to 81 units during descent.

05.30.15 Ground Proximity Monitor Interfaces

The relief pilot will verify any change in the Fuel Crossfeed switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Weather Radar status message is expected to read within the sample range of 67 to 76 units during descent. During landing, the pilot monitoring should record the Autothrottle annunciation when the associated caution light remains illuminated. The pilot flying will announce any change in the Transponder annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will confirm any change in the Wing Anti-Ice switch position and advise the other pilot once the checklist item is complete.

During cruise, the pilot flying should cross-check the Brake Temperature Monitor status message unless directed otherwise by the Sample Operations Center. The Thrust Reverser advisory is expected to read within the sample range of 24 to 31 units during parking. This text is fictional and exists only to give the prototype realistic volume and structure. If the Autobrake Selector is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

If the Hydraulic System B is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During a diversion, the pilot flying should brief the Engine Anti-Ice status message unless directed otherwise by the Sample Operations Center.

NOTE: Refer to the related topic for additional sample context. During preflight, the pilot flying should monitor the Autopilot Channel A selector position when the associated caution light remains illuminated.

During descent, the pilot monitoring should verify the Autobrake Selector selector position once the checklist item is complete. Refer to the related topic for additional sample context. The Weather Radar advisory that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval. The relief pilot will verify any change in the Window Heat switch position and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Transponder advisory	20 units	Normal
Bleed Air Supply selector position	77 units	Refer to related topic
Pack Temperature Control quantity display	8 units	Monitor
Fuel Crossfeed status message	75 units	Normal
Traffic Advisory Display advisory	34 units	Normal
Probe Heat selector position	77 units	Normal
Window Heat switch position	16 units	Monitor

Challenge	Response
Speedbrake Handle	As required

Window Heat	Armed
Flight Management Computer	Armed
Probe Heat	As required
Cockpit Voice Recorder	On
Engine Anti-Ice	Verified
Standby Hydraulic	Checked
Cabin Pressure Controller	Verified
Speedbrake Handle	Checked

05.30.16 Window Heat Interfaces

The Hydraulic System B switch position that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The pilot monitoring will verify any change in the Landing Gear Indication advisory and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Stall Warning status message is expected to read within the sample range of 67 to 77 units during taxi.
- The captain will announce any change in the Auxiliary Power Unit indication and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Primary Electrical Bus is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.
- The Hydraulic System A quantity display is expected to read within the sample range of 69 to 73 units during cruise.

If the Autothrottle is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the relief pilot should verify the Ground Proximity Monitor quantity display when the associated caution light remains illuminated. The pilot monitoring will announce any change in the Fire Detection Loop quantity display and advise the other pilot before the next phase of flight.

CAUTION: The Flight Management Computer advisory that differs from the expected state requires both pilots to monitor the condition when conditions permit. If the Stall Warning is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

During climb, the relief pilot should monitor the Standby Instruments annunciation unless directed otherwise by the Sample Operations Center. The pilot flying will verify any change in the Standby Instruments advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autothrottle status message that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. The Window Heat indication is expected to read within the sample range of 88 to 92 units during descent.

- The Traffic Advisory Display quantity display that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight.
- Both pilots will monitor any change in the Ground Proximity Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- During engine start, the pilot monitoring should cross-check the Autobrake Selector status message once the checklist item is complete.

- The Brake Temperature Monitor status message that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight.
- During a diversion, the Captain should brief the Flap Position Indication indication when the associated caution light remains illuminated.
- The Fuel Crossfeed quantity display that differs from the expected state requires the First Officer to record the condition when conditions permit.
- The captain will record any change in the Flap Position Indication quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During taxi, the Captain should confirm the Window Heat selector position once the checklist item is complete.
- The pilot flying will verify any change in the Cabin Pressure Controller advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Bleed Air Supply is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

05.30.17 Speedbrake Handle Indications

Refer to the related topic for additional sample context. During landing, the First Officer should record the Standby Instruments advisory once the checklist item is complete. During engine start, the First Officer should monitor the Window Heat advisory before the next phase of flight. During approach, both pilots should confirm the Cabin Pressure Controller annunciation if a discrepancy is observed.

The Brake Temperature Monitor selector position is expected to read within the sample range of 88 to 94 units during landing. The Standby Instruments status message that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. If the Probe Heat is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Nosewheel Steering indication is expected to read within the sample range of 43 to 54 units during an extended ground delay. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Center Tank Pumps is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The first officer will announce any change in the Fire Detection Loop switch position and advise the other pilot when the associated caution light remains illuminated. If the Wing Anti-Ice is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

- The Traffic Advisory Display annunciation that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.
- The pilot monitoring will brief any change in the Hydraulic System B status message and advise the other pilot when the associated caution light remains illuminated.
- If the Window Heat is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- Both pilots will monitor any change in the Hydraulic System A quantity display and advise the other pilot if a discrepancy is observed.

Challenge	Response
Landing Gear Indication	On
Hydraulic System A	Off
Landing Gear Indication	Closed

Cargo Smoke Detection	Set
Window Heat	Set
Window Heat	Off

05.30.18 Cabin Pressure Controller Test

If the Bleed Air Supply is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. During preflight, the pilot monitoring should select the Fire Detection Loop switch position if a discrepancy is observed. Both pilots will announce any change in the Hydraulic System B advisory and advise the other pilot when the associated caution light remains illuminated. During a maintenance-requested ground run, both pilots should record the Flap Position Indication switch position when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

The Oxygen Distribution quantity display is expected to read within the sample range of 80 to 91 units during descent. During takeoff, the relief pilot should confirm the Cargo Smoke Detection switch position if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. During a diversion, the First Officer should monitor the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. During a maintenance-requested ground run, both pilots should select the Autothrottle indication when conditions permit.

The Window Heat annunciation is expected to read within the sample range of 17 to 29 units during takeoff. During an extended ground delay, the pilot monitoring should cross-check the Hydraulic System A indication when conditions permit. The pilot flying will cross-check any change in the Autopilot Channel A status message and advise the other pilot when the associated caution light remains illuminated. If the Flap Position Indication is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Bleed Air Supply annunciation that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. The relief pilot will brief any change in the Autopilot Channel B quantity display and advise the other pilot once the checklist item is complete.

During descent, the pilot monitoring should cross-check the Cargo Smoke Detection quantity display if a discrepancy is observed. Both pilots will monitor any change in the Standby Hydraulic selector position and advise the other pilot if a discrepancy is observed. During landing, the First Officer should announce the Traffic Advisory Display advisory when conditions permit.

NOTE: The pilot flying will brief any change in the Fuel Crossfeed advisory and advise the other pilot once the checklist item is complete.

The relief pilot will confirm any change in the Wing Anti-Ice status message and advise the other pilot if a discrepancy is observed. The Cockpit Voice Recorder selector position is expected to read within the sample range of 30 to 39 units during approach. Values in this manual are invented and must not be used for any operational purpose. The Cabin Pressure Controller quantity display is expected to read within the sample range of 88 to 96 units during a diversion.

Challenge	Response
Flight Management Computer	Closed
Cabin Pressure Controller	Set
Traffic Advisory Display	Closed
Hydraulic System A	As required
Thrust Reverser	Verified
Traffic Advisory Display	Armed
Transponder	Checked

Autobrake Selector	As required
Flight Management Computer	Off
Brake Temperature Monitor	As required

05.30.19 Probe Heat Test

During descent, the pilot flying should brief the Thrust Reverser quantity display when conditions permit. The pilot flying will confirm any change in the Hydraulic System A switch position and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will record any change in the Fuel Crossfeed advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Brake Temperature Monitor indication that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated.

NOTE: The captain will announce any change in the Nosewheel Steering indication and advise the other pilot once the checklist item is complete. The Ground Proximity Monitor switch position that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The pilot flying will verify any change in the Primary Electrical Bus selector position and advise the other pilot if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Transponder is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- The Cockpit Voice Recorder annunciation that differs from the expected state requires the Captain to announce the condition once the checklist item is complete.
- During an extended ground delay, the First Officer should brief the Center Tank Pumps indication when operating at a sample station without ground power.

CAUTION: If the Autobrake Selector is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

The Fire Detection Loop quantity display is expected to read within the sample range of 69 to 81 units during takeoff. If the Cabin Pressure Controller is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The first officer will monitor any change in the Engine Anti-Ice advisory and advise the other pilot when operating at a sample station without ground power. If the Hydraulic System A is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

CAUTION: During parking, both pilots should confirm the Autopilot Channel A switch position if the indication does not stabilize within the sample interval.

05.30.20 Window Heat Limits Display

During a maintenance-requested ground run, the relief pilot should record the Pack Temperature Control selector position if the indication does not stabilize within the sample interval. During taxi, the relief pilot should monitor the Auxiliary Power Unit switch position before the next phase of flight. The Traffic Advisory Display advisory is expected to read within the sample range of 18 to 24 units during a maintenance-requested ground run. The Oxygen Distribution indication that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval. The Thrust Reverser advisory that differs from the expected state requires both pilots to brief the condition when conditions permit.

NOTE: The Flight Management Computer quantity display is expected to read within the sample range of 56 to 67 units during climb. If the Standby Instruments is inoperative, continue an extended ground delay only after the

Captain has reviewed the associated sample guidance.

- If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.
- The Autothrottle status message that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete.
- The pilot flying will announce any change in the Auxiliary Power Unit quantity display and advise the other pilot when conditions permit.
- The Cargo Smoke Detection indication that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed.
- The pilot monitoring will confirm any change in the Landing Gear Indication quantity display and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Pack Temperature Control quantity display	94 units	Refer to related topic
Cockpit Voice Recorder annunciation	83 units	Refer to related topic
Cargo Smoke Detection advisory	35 units	Monitor
Hydraulic System B indication	53 units	Monitor
Standby Hydraulic quantity display	28 units	Normal
Bleed Air Supply quantity display	2 units	Advisory only

The Wing Anti-Ice switch position that differs from the expected state requires the First Officer to select the condition when conditions permit. If the Autopilot Channel B is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Fuel Crossfeed annunciation that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle advisory is expected to read within the sample range of 57 to 64 units during an extended ground delay.

The Landing Gear Indication advisory that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Speedbrake Handle selector position that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. If the Nosewheel Steering is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

During climb, both pilots should monitor the Stall Warning annunciation if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. Both pilots will verify any change in the Cargo Smoke Detection annunciation and advise the other pilot when conditions permit. During landing, the First Officer should cross-check the Standby Instruments advisory if a discrepancy is observed.

NOTE: If the Pack Temperature Control is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Hydraulic System A status message is expected to read within the sample range of 93 to 103 units during a diversion.

Both pilots will announce any change in the Center Tank Pumps switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will brief any change in the Wing Anti-Ice switch position and advise the other pilot before the next phase of flight.

Challenge	Response
-----------	----------

Oxygen Distribution	Checked
Auxiliary Power Unit	Armed
Wing Anti-Ice	As required
Brake Temperature Monitor	Closed
Bleed Air Supply	As required
Traffic Advisory Display	On
Brake Temperature Monitor	Off
Fuel Crossfeed	Off
Cabin Pressure Controller	As required

05.40 Hydraulics

05.40.1 Standby Hydraulic Limits Display

If the Nosewheel Steering is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will verify any change in the Oxygen Distribution switch position and advise the other pilot if a discrepancy is observed. The pilot monitoring will record any change in the Hydraulic System B advisory and advise the other pilot once the checklist item is complete. If the Flap Position Indication is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

NOTE: During climb, both pilots should confirm the Autobrake Selector status message once the checklist item is complete. The Autopilot Channel A indication is expected to read within the sample range of 36 to 47 units during a turnaround.

NOTE: The Cargo Smoke Detection advisory that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

The Fire Detection Loop annunciation that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. If the Pack Temperature Control is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

CAUTION: The Hydraulic System A advisory that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed.

Challenge	Response
Flap Position Indication	As required
Bleed Air Supply	On
Primary Electrical Bus	Closed
Landing Gear Indication	Off
Autothrottle	On
Hydraulic System A	Armed
Engine Anti-Ice	On
Speedbrake Handle	Checked
Standby Instruments	Checked
Flap Position Indication	As required

05.40.2 Cargo Smoke Detection Power Sources

If the Center Tank Pumps is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Fuel Crossfeed selector position is expected to read within the sample range of 24 to 33 units during a turnaround. The Thrust Reverser status message is expected to read within the sample range of 78 to 85 units during approach.

The pilot monitoring will brief any change in the Pack Temperature Control advisory and advise the other pilot when the associated caution light remains illuminated. The Landing Gear Indication indication is expected to read within the sample range of 91 to 103 units during parking. The first officer will brief any change in the Probe Heat quantity display and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

- The first officer will cross-check any change in the Thrust Reverser indication and advise the other pilot before the next phase of flight.
- The Thrust Reverser indication that differs from the expected state requires the First Officer to announce the condition when conditions permit.
- The Flight Management Computer status message is expected to read within the sample range of 54 to 57 units during approach.
- During takeoff, the relief pilot should confirm the Cabin Pressure Controller advisory when operating at a sample station without ground power.
- The Engine Anti-Ice annunciation that differs from the expected state requires the relief pilot to verify the condition if a discrepancy is observed.
- The Fuel Crossfeed selector position that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power.

CAUTION: The Brake Temperature Monitor advisory is expected to read within the sample range of 21 to 32 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure.

During landing, the Captain should verify the Weather Radar quantity display unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder status message that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight. During climb, both pilots should verify the Primary Electrical Bus quantity display when conditions permit. The Oxygen Distribution status message that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center.

NOTE: The Cabin Pressure Controller quantity display is expected to read within the sample range of 30 to 40 units during climb. During approach, the pilot flying should brief the Window Heat annunciation unless directed otherwise by the Sample Operations Center.

CAUTION: The Fire Detection Loop switch position is expected to read within the sample range of 40 to 46 units during parking. The Autothrottle status message is expected to read within the sample range of 94 to 104 units during parking.

Condition	Sample value	Remarks
Flap Position Indication status message	16 units	Advisory only
Flight Management Computer status message	13 units	Advisory only
Primary Electrical Bus indication	54 units	Monitor
Landing Gear Indication switch position	15 units	Monitor
Oxygen Distribution status message	32 units	Refer to related topic
Standby Hydraulic selector position	55 units	Monitor

If the Window Heat is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. During preflight, the First Officer should confirm the Wing Anti-Ice switch position if the indication does not stabilize within the sample interval.

05.40.3 Thrust Reverser Reset Guidance

During climb, the pilot monitoring should verify the Landing Gear Indication quantity display when operating at a sample station without ground power. During cruise, the pilot flying should monitor the Landing Gear Indication advisory unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle selector position that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. During a diversion, the First Officer should announce the Autobrake Selector switch position if a discrepancy is observed. During climb, both pilots should brief the Fire Detection Loop selector position when conditions permit.

Condition	Sample value	Remarks
Cabin Pressure Controller indication	25 units	Refer to related topic
Traffic Advisory Display switch position	37 units	Normal
Cabin Pressure Controller selector position	58 units	Refer to related topic
Ground Proximity Monitor quantity display	18 units	Monitor

NOTE: The Flap Position Indication quantity display is expected to read within the sample range of 91 to 103 units during parking.

During landing, the pilot flying should confirm the Window Heat advisory when conditions permit. During a maintenance-requested ground run, both pilots should confirm the Stall Warning quantity display unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Fire Detection Loop quantity display	91 units	Refer to related topic
Ground Proximity Monitor advisory	1 units	Monitor
Hydraulic System B status message	61 units	Refer to related topic
Transponder selector position	27 units	Advisory only
Autopilot Channel A annunciation	75 units	Advisory only

NOTE: The pilot monitoring will select any change in the Autopilot Channel B status message and advise the other pilot before the next phase of flight. The Window Heat selector position is expected to read within the sample range of 73 to 83 units during takeoff.

CAUTION: The Brake Temperature Monitor quantity display that differs from the expected state requires both pilots to monitor the condition before the next phase of flight.

05.40.4 Autopilot Channel A Indications

This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. Both pilots will verify any change in the Wing Anti-Ice status message and advise the other pilot unless directed otherwise by the Sample Operations Center. During landing, the pilot monitoring should record the Cockpit Voice Recorder advisory once the checklist item is complete. If the Fire Detection Loop is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. During parking, the Captain should confirm the Pack Temperature Control indication before the next phase of flight.

Condition	Sample value	Remarks
-----------	--------------	---------

Oxygen Distribution quantity display	80 units	Normal
Flap Position Indication status message	34 units	Normal
Standby Instruments switch position	88 units	Refer to related topic

NOTE: Values in this manual are invented and must not be used for any operational purpose.

Values in this manual are invented and must not be used for any operational purpose. The Cockpit Voice Recorder indication is expected to read within the sample range of 28 to 35 units during taxi. The Center Tank Pumps quantity display that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

- The first officer will select any change in the Wing Anti-Ice selector position and advise the other pilot once the checklist item is complete.
- Refer to the related topic for additional sample context.
- The Landing Gear Indication selector position that differs from the expected state requires both pilots to select the condition if a discrepancy is observed.
- The Cockpit Voice Recorder indication is expected to read within the sample range of 70 to 82 units during taxi.

05.40.5 Autopilot Channel B Limits Display

If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Ground Proximity Monitor advisory is expected to read within the sample range of 29 to 40 units during climb. During taxi, the pilot monitoring should verify the Nosewheel Steering status message if the indication does not stabilize within the sample interval.

The Thrust Reverser quantity display that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated. Both pilots will cross-check any change in the Engine Anti-Ice selector position and advise the other pilot once the checklist item is complete. The first officer will brief any change in the Thrust Reverser switch position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Fuel Crossfeed annunciation	92 units	Monitor
Landing Gear Indication advisory	3 units	Refer to related topic
Thrust Reverser status message	69 units	Refer to related topic
Thrust Reverser switch position	79 units	Refer to related topic
Primary Electrical Bus quantity display	87 units	Normal

CAUTION: The Wing Anti-Ice annunciation that differs from the expected state requires both pilots to verify the condition before the next phase of flight.

If the Flap Position Indication is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic quantity display is expected to read within the sample range of 7 to 18 units during a turnaround. The Pack Temperature Control annunciation is expected to read within the sample range of 30 to 41 units during taxi. The captain will brief any change in the Transponder advisory and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

During taxi, both pilots should announce the Brake Temperature Monitor advisory once the checklist item is complete. The Window Heat switch position that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

Refer to the related topic for additional sample context. Both pilots will verify any change in the Autopilot Channel A annunciation and advise the other pilot when the associated caution light remains illuminated. The Engine Anti-Ice switch position that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. The Traffic Advisory Display annunciation that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

The pilot flying will cross-check any change in the Thrust Reverser quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. During a turnaround, the pilot flying should record the Traffic Advisory Display status message when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

Challenge	Response
Autopilot Channel B	Off
Hydraulic System A	Verified
Standby Instruments	Off
Autothrottle	Set
Transponder	Off
Weather Radar	Armed
Flight Management Computer	Closed
Brake Temperature Monitor	Checked
Autothrottle	As required
Probe Heat	Checked
Primary Electrical Bus	Off
Pack Temperature Control	Armed

05.40.6 *Flight Management Computer Normal Operation*

If the Stall Warning is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Oxygen Distribution selector position is expected to read within the sample range of 50 to 59 units during climb. Refer to the related topic for additional sample context. The Autobrake Selector indication that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. During a maintenance-requested ground run, the pilot monitoring should brief the Speedbrake Handle advisory unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display indication is expected to read within the sample range of 3 to 6 units during preflight.

CAUTION: The pilot flying will verify any change in the Cabin Pressure Controller annunciation and advise the other pilot when conditions permit. During approach, the relief pilot should brief the Transponder advisory if the indication does not stabilize within the sample interval.

CAUTION: If the Window Heat is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should select the Flight Management Computer annunciation if a discrepancy is observed.

If the Autothrottle is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The relief pilot will monitor any change in the Hydraulic System A quantity display and advise the other pilot when conditions permit. If the Standby Hydraulic is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

The Thrust Reverser annunciation is expected to read within the sample range of 3 to 6 units during descent. Both pilots will record any change in the Autobrake Selector indication and advise the other pilot if a discrepancy is observed. The captain will record any change in the Flight Management Computer advisory and advise the other pilot if a discrepancy is observed. If the Window Heat is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

NOTE: The Weather Radar advisory is expected to read within the sample range of 75 to 82 units during takeoff. The captain will monitor any change in the Hydraulic System B advisory and advise the other pilot when conditions permit.

CAUTION: During a diversion, the relief pilot should record the Flap Position Indication status message unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

If the Cargo Smoke Detection is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. During engine start, both pilots should confirm the Auxiliary Power Unit switch position when operating at a sample station without ground power. The Bleed Air Supply selector position is expected to read within the sample range of 49 to 59 units during engine start. The Window Heat switch position is expected to read within the sample range of 81 to 93 units during approach. If the Traffic Advisory Display is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cargo Smoke Detection status message	90 units	Monitor
Flight Management Computer indication	24 units	Normal
Hydraulic System B selector position	32 units	Advisory only
Wing Anti-Ice selector position	76 units	Advisory only
Autobrake Selector annunciation	60 units	Monitor
Autopilot Channel B annunciation	80 units	Refer to related topic
Traffic Advisory Display selector position	96 units	Normal

Challenge	Response
Bleed Air Supply	Off
Standby Hydraulic	On
Hydraulic System B	Off
Nosewheel Steering	On
Auxiliary Power Unit	As required
Oxygen Distribution	Verified
Oxygen Distribution	Armed
Weather Radar	Armed

05.40.7 Hydraulic System B Overview

If the Probe Heat is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Transponder selector position that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During descent, both pilots should select the Traffic Advisory Display status message when operating at a sample station without ground power.

- The pilot monitoring will cross-check any change in the Autobrake Selector status message and advise the other pilot if the indication does not stabilize within the sample interval.
- During parking, the Captain should record the Primary Electrical Bus indication when operating at a sample station without ground power.
- If the Fire Detection Loop is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.
- The Autopilot Channel A switch position is expected to read within the sample range of 39 to 43 units during a maintenance-requested ground run.

CAUTION: The relief pilot will brief any change in the Cargo Smoke Detection advisory and advise the other pilot when operating at a sample station without ground power.

The pilot monitoring will select any change in the Fuel Crossfeed advisory and advise the other pilot before the next phase of flight. Both pilots will verify any change in the Speedbrake Handle switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will select any change in the Cabin Pressure Controller advisory and advise the other pilot once the checklist item is complete.

- The pilot monitoring will select any change in the Fire Detection Loop switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Engine Anti-Ice annunciation is expected to read within the sample range of 5 to 11 units during climb.
- The Autothrottle selector position that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval.
- The Flight Management Computer status message is expected to read within the sample range of 2 to 10 units during engine start.
- Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Engine Anti-Ice status message	92 units	Monitor
Hydraulic System A switch position	89 units	Refer to related topic
Stall Warning switch position	31 units	Monitor
Landing Gear Indication indication	4 units	Advisory only
Traffic Advisory Display advisory	48 units	Advisory only

Condition	Sample value	Remarks
Auxiliary Power Unit indication	48 units	Normal
Autopilot Channel B switch position	31 units	Monitor
Landing Gear Indication annunciation	90 units	Normal

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Fuel Crossfeed advisory is expected to read within the sample range of 76 to 88 units during parking.

Challenge	Response
Auxiliary Power Unit	Checked
Speedbrake Handle	On
Flight Management Computer	Set
Autobrake Selector	Checked
Auxiliary Power Unit	Armed

Autopilot Channel B	On
Cargo Smoke Detection	Checked

05.40.8 Center Tank Pumps Test

If the Autobrake Selector is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the Captain should cross-check the Standby Hydraulic switch position when operating at a sample station without ground power. The Traffic Advisory Display selector position is expected to read within the sample range of 7 to 15 units during an extended ground delay. The Center Tank Pumps quantity display that differs from the expected state requires both pilots to brief the condition when conditions permit.

NOTE: If the Cabin Pressure Controller is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

Both pilots will monitor any change in the Landing Gear Indication advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Cargo Smoke Detection quantity display that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center. The Thrust Reverser status message that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. During climb, the Captain should verify the Pack Temperature Control selector position when the associated caution light remains illuminated. During cruise, the First Officer should verify the Probe Heat selector position when operating at a sample station without ground power. The Transponder status message is expected to read within the sample range of 44 to 52 units during approach. The Flap Position Indication indication that differs from the expected state requires the Captain to announce the condition when conditions permit.

Condition	Sample value	Remarks
Probe Heat annunciation	25 units	Monitor
Pack Temperature Control annunciation	15 units	Normal
Autopilot Channel B quantity display	71 units	Normal
Cargo Smoke Detection selector position	83 units	Monitor
Pack Temperature Control switch position	4 units	Normal
Thrust Reverser indication	3 units	Monitor

Condition	Sample value	Remarks
Cargo Smoke Detection annunciation	27 units	Refer to related topic
Autothrottle advisory	9 units	Refer to related topic
Autothrottle status message	5 units	Normal
Bleed Air Supply status message	42 units	Advisory only
Primary Electrical Bus advisory	59 units	Normal
Autopilot Channel B quantity display	67 units	Refer to related topic

CAUTION: During descent, the First Officer should monitor the Traffic Advisory Display quantity display when operating at a sample station without ground power. If the Transponder is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

NOTE: The pilot monitoring will brief any change in the Flap Position Indication status message and advise the other pilot when the associated caution light remains illuminated.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

Challenge	Response
Fire Detection Loop	Off
Weather Radar	Armed
Auxiliary Power Unit	Set
Fuel Crossfeed	Checked
Autothrottle	Closed
Window Heat	On
Landing Gear Indication	Set
Fuel Crossfeed	Set
Probe Heat	Off
Speedbrake Handle	On

05.40.9 Fire Detection Loop Limits Display

The first officer will monitor any change in the Flap Position Indication advisory and advise the other pilot before the next phase of flight. The pilot monitoring will brief any change in the Autobrake Selector indication and advise the other pilot when conditions permit. If the Speedbrake Handle is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The Bleed Air Supply switch position that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. The relief pilot will monitor any change in the Pack Temperature Control quantity display and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Weather Radar is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should record the Standby Instruments status message unless directed otherwise by the Sample Operations Center. During engine start, the relief pilot should announce the Standby Instruments indication if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autobrake Selector is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

If the Cargo Smoke Detection is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The captain will select any change in the Nosewheel Steering advisory and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. If the Traffic Advisory Display is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autothrottle advisory	16 units	Monitor
Autopilot Channel B selector position	17 units	Normal
Fuel Crossfeed indication	3 units	Normal
Weather Radar annunciation	89 units	Normal
Landing Gear Indication indication	99 units	Refer to related topic
Flap Position Indication annunciation	68 units	Monitor

Values in this manual are invented and must not be used for any operational purpose. If the Brake Temperature Monitor is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Wing Anti-Ice quantity display that differs from the expected state requires the relief pilot to select the condition

before the next phase of flight.

The captain will confirm any change in the Nosewheel Steering switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will monitor any change in the Standby Instruments annunciation and advise the other pilot when conditions permit. During approach, both pilots should announce the Autothrottle quantity display if a discrepancy is observed. The captain will verify any change in the Stall Warning quantity display and advise the other pilot if the indication does not stabilize within the sample interval. If the Landing Gear Indication is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cockpit Voice Recorder annunciation	4 units	Refer to related topic
Landing Gear Indication switch position	66 units	Refer to related topic
Pack Temperature Control annunciation	48 units	Advisory only
Fuel Crossfeed selector position	15 units	Refer to related topic

Challenge	Response
Speedbrake Handle	Armed
Hydraulic System B	Armed
Brake Temperature Monitor	Checked
Autobrake Selector	Verified
Auxiliary Power Unit	Off
Hydraulic System B	As required
Bleed Air Supply	Checked
Auxiliary Power Unit	As required
Cockpit Voice Recorder	Closed
Wing Anti-Ice	As required
Fire Detection Loop	Set

05.40.10 Brake Temperature Monitor Normal Operation

If the Cabin Pressure Controller is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The relief pilot will announce any change in the Autopilot Channel A advisory and advise the other pilot if a discrepancy is observed. If the Transponder is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

NOTE: During takeoff, the First Officer should select the Speedbrake Handle advisory if the indication does not stabilize within the sample interval.

If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. During landing, the relief pilot should confirm the Stall Warning advisory before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the pilot monitoring should announce the Primary Electrical Bus indication when conditions permit.

During parking, the relief pilot should verify the Oxygen Distribution status message when operating at a sample station without ground power. The Traffic Advisory Display status message that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. The relief pilot will verify any change in the Speedbrake Handle status message and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will select any change in the Standby Hydraulic annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The captain will monitor any

change in the Transponder advisory and advise the other pilot when conditions permit.

If the Fuel Crossfeed is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Oxygen Distribution advisory is expected to read within the sample range of 80 to 83 units during preflight. The pilot flying will confirm any change in the Transponder switch position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

The Standby Hydraulic advisory is expected to read within the sample range of 35 to 40 units during an extended ground delay. During cruise, the pilot flying should cross-check the Hydraulic System A quantity display unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. If the Autopilot Channel B is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Fire Detection Loop annunciation that differs from the expected state requires the relief pilot to verify the condition once the checklist item is complete. During a diversion, both pilots should verify the Cabin Pressure Controller annunciation if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 25 to 37 units during parking. The first officer will monitor any change in the Wing Anti-Ice switch position and advise the other pilot if a discrepancy is observed. The Oxygen Distribution indication that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval.

NOTE: Both pilots will brief any change in the Transponder quantity display and advise the other pilot when the associated caution light remains illuminated.

During descent, both pilots should monitor the Window Heat status message if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Window Heat selector position is expected to read within the sample range of 84 to 89 units during an extended ground delay. If the Standby Instruments is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

05.40.11 Primary Electrical Bus Normal Operation

The Autopilot Channel A indication that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. The Speedbrake Handle status message that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center. The pilot flying will cross-check any change in the Center Tank Pumps selector position and advise the other pilot before the next phase of flight.

The Fire Detection Loop switch position is expected to read within the sample range of 11 to 17 units during approach. The Autopilot Channel B indication is expected to read within the sample range of 77 to 80 units during preflight. If the Cargo Smoke Detection is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Traffic Advisory Display advisory is expected to read within the sample range of 10 to 17 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During parking, the pilot flying should announce the Fuel Crossfeed advisory if a discrepancy is observed.

NOTE: Both pilots will verify any change in the Oxygen Distribution selector position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The captain will confirm any change in the Autobrake Selector selector position and advise the other pilot once the checklist item is complete.
- The Engine Anti-Ice advisory that differs from the expected state requires the First Officer to monitor the condition when conditions permit.

- The Autothrottle status message that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power.
- The Nosewheel Steering status message that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center.

Challenge	Response
Pack Temperature Control	Verified
Cockpit Voice Recorder	Off
Oxygen Distribution	Closed
Pack Temperature Control	Set
Standby Instruments	Off
Flight Management Computer	Closed
Pack Temperature Control	Closed
Stall Warning	As required

05.40.12 Nosewheel Steering Power Sources

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Fuel Crossfeed annunciation is expected to read within the sample range of 10 to 13 units during taxi.

- If the Primary Electrical Bus is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The pilot monitoring will record any change in the Oxygen Distribution status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The captain will record any change in the Flight Management Computer selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Autopilot Channel A selector position that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Flight Management Computer is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.
- The relief pilot will verify any change in the Autopilot Channel A advisory and advise the other pilot when operating at a sample station without ground power.
- If the Hydraulic System A is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.
- If the Landing Gear Indication is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- During preflight, the pilot monitoring should announce the Wing Anti-Ice status message once the checklist item is complete.

NOTE: The Landing Gear Indication quantity display that differs from the expected state requires the pilot flying to announce the condition when conditions permit.

NOTE: The pilot monitoring will cross-check any change in the Autopilot Channel A advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During a maintenance-requested ground run, the relief pilot should confirm the Fire Detection Loop selector position unless directed otherwise by the Sample Operations Center.

Challenge	Response
Ground Proximity Monitor	Closed
Flap Position Indication	Set
Brake Temperature Monitor	Closed
Autobrake Selector	On
Autothrottle	Off
Autobrake Selector	Off
Primary Electrical Bus	On
Cargo Smoke Detection	Verified
Speedbrake Handle	Verified
Autobrake Selector	Off
Hydraulic System A	Off
Cockpit Voice Recorder	Set

05.40.13 Hydraulic System B Normal Operation

If the Flight Management Computer is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Wing Anti-Ice advisory and advise the other pilot once the checklist item is complete. The captain will brief any change in the Window Heat selector position and advise the other pilot if the indication does not stabilize within the sample interval. The pilot flying will select any change in the Cockpit Voice Recorder advisory and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

The first officer will record any change in the Auxiliary Power Unit quantity display and advise the other pilot once the checklist item is complete. If the Autobrake Selector is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Cargo Smoke Detection status message is expected to read within the sample range of 9 to 20 units during climb. During approach, the relief pilot should announce the Hydraulic System B advisory unless directed otherwise by the Sample Operations Center. If the Fuel Crossfeed is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Transponder indication that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center.

The captain will verify any change in the Autobrake Selector indication and advise the other pilot if the indication does not stabilize within the sample interval. During cruise, the Captain should record the Autothrottle advisory when the associated caution light remains illuminated. The Fire Detection Loop selector position that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. The Standby Instruments advisory is expected to read within the sample range of 38 to 42 units during descent. The Auxiliary Power Unit switch position that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight.

CAUTION: The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power.

- The relief pilot will verify any change in the Standby Instruments indication and advise the other pilot if the indication does not stabilize within the sample interval.

- The Autopilot Channel A switch position that differs from the expected state requires the Captain to record the condition when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Autopilot Channel B is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

The Fire Detection Loop switch position is expected to read within the sample range of 22 to 25 units during climb. The Nosewheel Steering indication that differs from the expected state requires the First Officer to confirm the condition when conditions permit. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. If the Ground Proximity Monitor is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

- The Flap Position Indication selector position is expected to read within the sample range of 77 to 88 units during parking.
- During climb, the pilot monitoring should confirm the Wing Anti-Ice indication unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The relief pilot will confirm any change in the Thrust Reverser selector position and advise the other pilot when conditions permit.

During descent, the Captain should confirm the Nosewheel Steering advisory when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control advisory is expected to read within the sample range of 22 to 28 units during taxi. If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

05.40.14 Cockpit Voice Recorder Test

During parking, the First Officer should monitor the Wing Anti-Ice switch position when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the Captain should cross-check the Cockpit Voice Recorder status message unless directed otherwise by the Sample Operations Center. During approach, the Captain should announce the Cockpit Voice Recorder advisory once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed advisory is expected to read within the sample range of 72 to 80 units during takeoff.

This text is fictional and exists only to give the prototype realistic volume and structure. The Auxiliary Power Unit switch position that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center. During a turnaround, the First Officer should brief the Window Heat quantity display unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The captain will record any change in the Fuel Crossfeed switch position and advise the other pilot before the next phase of flight. The pilot flying will select any change in the Cockpit Voice Recorder advisory and advise the other pilot once the checklist item is complete.

Both pilots will cross-check any change in the Cabin Pressure Controller quantity display and advise the other pilot when operating at a sample station without ground power. The Probe Heat status message is expected to read within the sample range of 65 to 70 units during an extended ground delay. If the Flap Position Indication is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. During takeoff, the relief pilot should confirm the Traffic Advisory Display annunciation if the indication does not stabilize within the sample interval. During a turnaround, both pilots should monitor the Auxiliary Power Unit advisory when conditions permit.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The wording here is placeholder content shaped like a procedure, not a procedure.

- The Standby Instruments quantity display is expected to read within the sample range of 5 to 13 units during takeoff.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. If the Brake Temperature Monitor is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

The pilot monitoring will select any change in the Fuel Crossfeed selector position and advise the other pilot once the checklist item is complete. Both pilots will select any change in the Flap Position Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Auxiliary Power Unit status message that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Flap Position Indication indication	6 units	Advisory only
Probe Heat switch position	11 units	Normal
Hydraulic System B advisory	89 units	Normal
Standby Instruments indication	28 units	Advisory only

The Oxygen Distribution advisory that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight. If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. During preflight, the Captain should select the Pack Temperature Control status message when operating at a sample station without ground power. Both pilots will verify any change in the Autobrake Selector advisory and advise the other pilot when conditions permit. The pilot flying will record any change in the Cargo Smoke Detection annunciation and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

During preflight, the relief pilot should announce the Probe Heat advisory if the indication does not stabilize within the sample interval. The Bleed Air Supply switch position that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. If the Standby Hydraulic is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

Challenge	Response
Transponder	Verified
Fuel Crossfeed	Off
Autopilot Channel A	Closed
Bleed Air Supply	Off
Flap Position Indication	Armed
Autopilot Channel B	On
Nosewheel Steering	As required
Nosewheel Steering	Closed
Engine Anti-Ice	Checked
Ground Proximity Monitor	Off
Ground Proximity Monitor	Set

05.40.15 Nosewheel Steering Reset Guidance

If the Speedbrake Handle is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During preflight, the pilot flying should brief the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center. The captain will monitor any change in the Flight Management Computer status message and advise the other pilot if the indication does not stabilize within the sample interval. The Transponder quantity display is expected to read within the sample range of 61 to 68 units during approach. If the Nosewheel Steering is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

The captain will announce any change in the Fire Detection Loop annunciation and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will confirm any change in the Autobrake Selector quantity display and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Hydraulic System B annunciation that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete.

Both pilots will brief any change in the Pack Temperature Control quantity display and advise the other pilot once the checklist item is complete. Both pilots will confirm any change in the Weather Radar annunciation and advise the other pilot when the associated caution light remains illuminated. During parking, both pilots should verify the Center Tank Pumps selector position when conditions permit. Refer to the related topic for additional sample context. The pilot monitoring will brief any change in the Cabin Pressure Controller status message and advise the other pilot when the associated caution light remains illuminated. During preflight, the Captain should confirm the Wing Anti-Ice annunciation when operating at a sample station without ground power.

The Flight Management Computer advisory that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit switch position is expected to read within the sample range of 4 to 16 units during cruise. The captain will monitor any change in the Fire Detection Loop selector position and advise the other pilot when operating at a sample station without ground power. During taxi, both pilots should select the Cargo Smoke Detection switch position once the checklist item is complete.

Refer to the related topic for additional sample context. The pilot monitoring will monitor any change in the Center Tank Pumps switch position and advise the other pilot before the next phase of flight. The first officer will brief any change in the Hydraulic System B advisory and advise the other pilot if a discrepancy is observed. If the Auxiliary Power Unit is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The relief pilot will record any change in the Autopilot Channel A advisory and advise the other pilot once the checklist item is complete. The pilot monitoring will confirm any change in the Flap Position Indication annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: During a diversion, the Captain should cross-check the Landing Gear Indication quantity display unless directed otherwise by the Sample Operations Center.

Challenge	Response
Bleed Air Supply	As required
Probe Heat	On
Fuel Crossfeed	Set
Cargo Smoke Detection	As required
Oxygen Distribution	Closed
Ground Proximity Monitor	On
Window Heat	Closed
Autobrake Selector	Closed
Probe Heat	Armed
Weather Radar	Set

Hydraulic System A	Off
Center Tank Pumps	Closed

05.40.16 Probe Heat Test

If the Nosewheel Steering is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The relief pilot will brief any change in the Autothrottle status message and advise the other pilot if a discrepancy is observed. The Transponder switch position is expected to read within the sample range of 35 to 47 units during a maintenance-requested ground run.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, the pilot monitoring should cross-check the Transponder selector position before the next phase of flight.

CAUTION: During an extended ground delay, both pilots should monitor the Hydraulic System B annunciation unless directed otherwise by the Sample Operations Center.

NOTE: The relief pilot will brief any change in the Auxiliary Power Unit switch position and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Nosewheel Steering quantity display	8 units	Advisory only
Hydraulic System B switch position	23 units	Normal
Stall Warning indication	15 units	Normal

During an extended ground delay, the pilot monitoring should verify the Hydraulic System A selector position when operating at a sample station without ground power. During a turnaround, the First Officer should record the Flight Management Computer switch position when operating at a sample station without ground power. The Weather Radar annunciation is expected to read within the sample range of 55 to 61 units during approach. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. If the Landing Gear Indication is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. See 17.10.2 Engine Anti-Ice Indications.

- The Primary Electrical Bus annunciation is expected to read within the sample range of 26 to 29 units during taxi.
- If the Transponder is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- During a diversion, the pilot flying should verify the Autopilot Channel A indication if the indication does not stabilize within the sample interval.
- If the Standby Instruments is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- The Stall Warning status message that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed.

05.40.17 Window Heat Test

The pilot monitoring will select any change in the Cargo Smoke Detection status message and advise the other pilot when conditions permit. If the Stall Warning is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The relief pilot will cross-check any change in the Pack Temperature Control switch position and advise the other pilot when conditions permit. During a maintenance-requested ground run, the First Officer should announce the Flap

Position Indication annunciation before the next phase of flight. If the Autopilot Channel B is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

NOTE: If the Flap Position Indication is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: During taxi, the pilot monitoring should select the Brake Temperature Monitor status message when conditions permit. During landing, the relief pilot should brief the Window Heat annunciation when conditions permit.

The Brake Temperature Monitor quantity display that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. The Flight Management Computer status message is expected to read within the sample range of 46 to 54 units during landing. The pilot flying will verify any change in the Standby Instruments selector position and advise the other pilot once the checklist item is complete. If the Primary Electrical Bus is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The pilot flying will monitor any change in the Ground Proximity Monitor quantity display and advise the other pilot when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: Refer to the related topic for additional sample context. The Flight Management Computer indication that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated.

- The Flap Position Indication switch position is expected to read within the sample range of 88 to 95 units during a turnaround.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Cabin Pressure Controller switch position that differs from the expected state requires both pilots to brief the condition unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.

05.40.18 Flight Management Computer Status Messages

Both pilots will confirm any change in the Pack Temperature Control advisory and advise the other pilot when the associated caution light remains illuminated. The Center Tank Pumps annunciation that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. The Probe Heat annunciation is expected to read within the sample range of 49 to 61 units during a maintenance-requested ground run.

The Stall Warning quantity display that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will confirm any change in the Cockpit Voice Recorder indication and advise the other pilot when operating at a sample station without ground power. The Thrust Reverser indication is expected to read within the sample range of 88 to 100 units during cruise. If the Ground Proximity Monitor is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

CAUTION: During landing, the First Officer should confirm the Window Heat selector position once the checklist item is complete.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. During a turnaround, both pilots should brief the Transponder switch position if the indication does not stabilize within the sample interval.

The Autopilot Channel B indication that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. If the Autothrottle is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Autothrottle advisory is expected to read within the sample range of 80 to 88 units during takeoff. The Flap Position Indication switch position that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the

Sample Operations Center.

05.40.19 Stall Warning Indications

If the Brake Temperature Monitor is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Hydraulic System B switch position that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. The pilot monitoring will select any change in the Wing Anti-Ice selector position and advise the other pilot when conditions permit. If the Autothrottle is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

The Traffic Advisory Display indication is expected to read within the sample range of 77 to 88 units during descent. The pilot monitoring will brief any change in the Probe Heat indication and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System B quantity display that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete. During engine start, both pilots should record the Landing Gear Indication advisory when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cabin Pressure Controller selector position	36 units	Normal
Thrust Reverser selector position	70 units	Refer to related topic
Primary Electrical Bus switch position	32 units	Monitor

NOTE: The Cabin Pressure Controller status message that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power. The captain will select any change in the Standby Instruments advisory and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Speedbrake Handle selector position that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. The pilot monitoring will verify any change in the Autothrottle switch position and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Autopilot Channel B selector position	27 units	Monitor
Center Tank Pumps selector position	6 units	Refer to related topic
Landing Gear Indication quantity display	21 units	Advisory only
Fuel Crossfeed annunciation	89 units	Advisory only
Probe Heat advisory	43 units	Advisory only

05.50 Flight Controls

05.50.1 Autothrottle Limits Display

This text is fictional and exists only to give the prototype realistic volume and structure. If the Weather Radar is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The captain will cross-check any change in the Ground Proximity Monitor quantity display and advise the other pilot when conditions permit. During a maintenance-requested ground run, the pilot flying should announce the Center Tank Pumps annunciation when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will confirm any change in the Auxiliary Power Unit selector position and advise the other pilot if the indication does not stabilize within the sample interval.

The Center Tank Pumps advisory is expected to read within the sample range of 90 to 100 units during landing. During descent, the pilot monitoring should monitor the Nosewheel Steering indication when conditions permit. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the pilot flying has

reviewed the associated sample guidance. The pilot monitoring will verify any change in the Bleed Air Supply advisory and advise the other pilot if a discrepancy is observed. If the Weather Radar is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Flap Position Indication switch position	34 units	Refer to related topic
Autopilot Channel A indication	35 units	Refer to related topic
Hydraulic System B indication	1 units	Normal
Center Tank Pumps quantity display	44 units	Advisory only
Hydraulic System B indication	19 units	Refer to related topic
Fire Detection Loop indication	52 units	Advisory only

CAUTION: If the Primary Electrical Bus is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. During descent, the pilot monitoring should confirm the Traffic Advisory Display advisory when operating at a sample station without ground power.

The Auxiliary Power Unit switch position that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight. If the Autobrake Selector is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Traffic Advisory Display indication is expected to read within the sample range of 64 to 67 units during a maintenance-requested ground run. Both pilots will announce any change in the Cockpit Voice Recorder switch position and advise the other pilot when operating at a sample station without ground power.

05.50.2 Nosewheel Steering Overview

The pilot flying will cross-check any change in the Thrust Reverser advisory and advise the other pilot when conditions permit. During engine start, the pilot flying should verify the Wing Anti-Ice indication if a discrepancy is observed. The Probe Heat indication that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete. During preflight, both pilots should monitor the Flight Management Computer quantity display unless directed otherwise by the Sample Operations Center.

CAUTION: If the Window Heat is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The first officer will monitor any change in the Weather Radar selector position and advise the other pilot before the next phase of flight.
- If the Nosewheel Steering is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

The pilot monitoring will announce any change in the Auxiliary Power Unit status message and advise the other pilot when the associated caution light remains illuminated. The relief pilot will monitor any change in the Flight Management Computer selector position and advise the other pilot once the checklist item is complete. The Window Heat quantity display is expected to read within the sample range of 33 to 42 units during a maintenance-requested ground run. The Autopilot Channel B switch position is expected to read within the sample range of 66 to 69 units during takeoff. See 03.50.11 Verification: Autopilot Channel B.

Condition	Sample value	Remarks
Cargo Smoke Detection status message	33 units	Normal
Stall Warning switch position	39 units	Advisory only
Auxiliary Power Unit indication	4 units	Refer to related topic
Hydraulic System B advisory	11 units	Monitor

Standby Hydraulic indication	43 units	Refer to related topic
Landing Gear Indication indication	13 units	Advisory only

NOTE: The Transponder annunciation is expected to read within the sample range of 21 to 32 units during climb.

Challenge	Response
Cargo Smoke Detection	Verified
Engine Anti-Ice	Armed
Stall Warning	Set
Stall Warning	On
Wing Anti-Ice	Armed
Speedbrake Handle	On
Hydraulic System A	Verified
Traffic Advisory Display	Armed

05.50.3 Standby Instruments Crew Awareness

The Hydraulic System B selector position is expected to read within the sample range of 30 to 37 units during parking. Values in this manual are invented and must not be used for any operational purpose. The Fuel Crossfeed indication that differs from the expected state requires the pilot flying to select the condition before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Wing Anti-Ice status message that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.

If the Hydraulic System B is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Thrust Reverser status message that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated. During taxi, the pilot flying should confirm the Speedbrake Handle selector position unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Primary Electrical Bus quantity display	15 units	Monitor
Cargo Smoke Detection status message	82 units	Monitor
Stall Warning status message	46 units	Advisory only

The Stall Warning switch position is expected to read within the sample range of 76 to 87 units during a maintenance-requested ground run. The Bleed Air Supply quantity display that differs from the expected state requires both pilots to announce the condition before the next phase of flight. The Hydraulic System B annunciation is expected to read within the sample range of 66 to 70 units during descent.

The Auxiliary Power Unit advisory is expected to read within the sample range of 80 to 91 units during preflight. During climb, the First Officer should confirm the Brake Temperature Monitor status message when operating at a sample station without ground power. If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

During climb, the First Officer should select the Traffic Advisory Display advisory if a discrepancy is observed. If the Bleed Air Supply is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Autothrottle annunciation that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval.

NOTE: If the Autopilot Channel B is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

05.50.4 *Flight Management Computer Power Sources*

The Hydraulic System B quantity display is expected to read within the sample range of 70 to 80 units during approach. The Bleed Air Supply advisory that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. During parking, both pilots should cross-check the Cockpit Voice Recorder advisory when operating at a sample station without ground power. The Engine Anti-Ice selector position is expected to read within the sample range of 77 to 89 units during parking. The Cargo Smoke Detection selector position is expected to read within the sample range of 20 to 31 units during cruise. The Cargo Smoke Detection quantity display is expected to read within the sample range of 25 to 36 units during takeoff.

The pilot monitoring will select any change in the Bleed Air Supply switch position and advise the other pilot when operating at a sample station without ground power. The first officer will monitor any change in the Nosewheel Steering indication and advise the other pilot when operating at a sample station without ground power. The Autopilot Channel B quantity display is expected to read within the sample range of 18 to 29 units during cruise. The Window Heat annunciation that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Brake Temperature Monitor switch position is expected to read within the sample range of 51 to 54 units during a turnaround.

If the Brake Temperature Monitor is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Cargo Smoke Detection selector position is expected to read within the sample range of 76 to 81 units during climb. The Autopilot Channel B selector position that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed. During climb, the First Officer should announce the Cockpit Voice Recorder selector position before the next phase of flight. The Primary Electrical Bus switch position is expected to read within the sample range of 8 to 16 units during parking.

The Oxygen Distribution indication that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power. The captain will select any change in the Standby Hydraulic switch position and advise the other pilot if a discrepancy is observed. The Landing Gear Indication advisory is expected to read within the sample range of 5 to 15 units during descent. The pilot monitoring will select any change in the Autopilot Channel A selector position and advise the other pilot when conditions permit. During landing, the Captain should record the Stall Warning indication if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

During preflight, the First Officer should confirm the Nosewheel Steering status message when conditions permit. If the Oxygen Distribution is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Ground Proximity Monitor status message is expected to read within the sample range of 14 to 25 units during a turnaround. The relief pilot will cross-check any change in the Hydraulic System A annunciation and advise the other pilot when conditions permit. The Wing Anti-Ice advisory is expected to read within the sample range of 65 to 73 units during takeoff. The Hydraulic System B indication is expected to read within the sample range of 88 to 98 units during taxi.

During a maintenance-requested ground run, the pilot flying should verify the Traffic Advisory Display quantity display unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, both pilots should cross-check the Engine Anti-Ice quantity display when the associated caution light remains illuminated. The first officer will monitor any change in the Wing Anti-Ice indication and advise the other pilot when conditions permit. During a maintenance-requested ground run, the pilot monitoring should record the Oxygen Distribution annunciation if a discrepancy is observed. See 05.20.8 Transponder Limits Display.

- The Stall Warning status message that differs from the expected state requires the pilot flying to verify the condition when conditions permit.
- The Cargo Smoke Detection advisory that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power.

- The pilot monitoring will brief any change in the Nosewheel Steering indication and advise the other pilot once the checklist item is complete.
- The Flight Management Computer status message is expected to read within the sample range of 58 to 66 units during cruise.
- The Autopilot Channel B indication that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight.
- The Wing Anti-Ice status message that differs from the expected state requires both pilots to brief the condition unless directed otherwise by the Sample Operations Center.

Challenge	Response
Pack Temperature Control	Closed
Speedbrake Handle	On
Autopilot Channel B	Closed
Nosewheel Steering	As required
Landing Gear Indication	Set
Traffic Advisory Display	Verified
Autobrake Selector	Set
Stall Warning	Checked

05.50.5 Engine Anti-Ice Test

During approach, the Captain should cross-check the Transponder selector position once the checklist item is complete. The Landing Gear Indication annunciation is expected to read within the sample range of 30 to 33 units during a turnaround. The pilot monitoring will cross-check any change in the Autopilot Channel B switch position and advise the other pilot once the checklist item is complete. During takeoff, the pilot flying should monitor the Auxiliary Power Unit indication if the indication does not stabilize within the sample interval. During a turnaround, both pilots should verify the Engine Anti-Ice indication when operating at a sample station without ground power.

- During a turnaround, the First Officer should announce the Transponder indication before the next phase of flight.
- The pilot monitoring will verify any change in the Ground Proximity Monitor annunciation and advise the other pilot if a discrepancy is observed.
- If the Bleed Air Supply is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- The Wing Anti-Ice selector position that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.
- Refer to the related topic for additional sample context.
- If the Primary Electrical Bus is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- During a diversion, both pilots should confirm the Flap Position Indication selector position once the checklist item is complete.
- If the Hydraulic System A is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- The pilot monitoring will verify any change in the Ground Proximity Monitor advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
-----------	--------------	---------

Stall Warning advisory	71 units	Refer to related topic
Landing Gear Indication status message	22 units	Advisory only
Flap Position Indication switch position	46 units	Monitor
Hydraulic System A selector position	12 units	Normal
Oxygen Distribution annunciation	96 units	Monitor
Fuel Crossfeed indication	63 units	Refer to related topic

The Transponder indication that differs from the expected state requires the First Officer to monitor the condition once the checklist item is complete. The Probe Heat quantity display is expected to read within the sample range of 50 to 62 units during engine start. Both pilots will select any change in the Fire Detection Loop advisory and advise the other pilot when conditions permit. The Flap Position Indication selector position is expected to read within the sample range of 64 to 69 units during an extended ground delay. If the Thrust Reverser is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Traffic Advisory Display switch position that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated.

Challenge	Response
Transponder	Armed
Cabin Pressure Controller	Set
Ground Proximity Monitor	As required
Standby Instruments	Set
Window Heat	Verified
Window Heat	Checked
Fuel Crossfeed	As required
Cargo Smoke Detection	Checked

05.50.6 Autopilot Channel A Indications

This text is fictional and exists only to give the prototype realistic volume and structure. The captain will confirm any change in the Auxiliary Power Unit status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Bleed Air Supply quantity display that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. If the Cockpit Voice Recorder is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

If the Landing Gear Indication is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B advisory that differs from the expected state requires the relief pilot to verify the condition when conditions permit.

CAUTION: During a turnaround, both pilots should confirm the Pack Temperature Control advisory when conditions permit.

The Center Tank Pumps status message that differs from the expected state requires both pilots to select the condition before the next phase of flight. The Fuel Crossfeed switch position is expected to read within the sample range of 81 to 86 units during cruise. During landing, the pilot flying should brief the Bleed Air Supply indication when the associated caution light remains illuminated. The Landing Gear Indication switch position is expected to read within the sample range of 41 to 52 units during approach. If the Flap Position Indication is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. See 08.20.3 Thrust Reverser Crew Awareness.

Condition	Sample value	Remarks
-----------	--------------	---------

Engine Anti-Ice quantity display	84 units	Monitor
Primary Electrical Bus indication	50 units	Advisory only
Brake Temperature Monitor indication	73 units	Refer to related topic
Cockpit Voice Recorder indication	88 units	Normal
Center Tank Pumps annunciation	36 units	Normal
Window Heat advisory	76 units	Refer to related topic
Center Tank Pumps advisory	27 units	Advisory only

Condition	Sample value	Remarks
Weather Radar quantity display	31 units	Monitor
Pack Temperature Control annunciation	37 units	Advisory only
Fuel Crossfeed switch position	94 units	Normal

CAUTION: The Cargo Smoke Detection switch position is expected to read within the sample range of 55 to 59 units during a maintenance-requested ground run.

Challenge	Response
Window Heat	As required
Flight Management Computer	Verified
Primary Electrical Bus	Closed
Autobrake Selector	Checked
Wing Anti-Ice	Off
Center Tank Pumps	As required
Autopilot Channel A	Off

05.50.7 Standby Instruments Power Sources

This text is fictional and exists only to give the prototype realistic volume and structure. The captain will verify any change in the Speedbrake Handle annunciation and advise the other pilot when operating at a sample station without ground power. If the Stall Warning is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Landing Gear Indication annunciation that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power.

NOTE: The first officer will monitor any change in the Fuel Crossfeed quantity display and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Nosewheel Steering switch position	95 units	Advisory only
Stall Warning switch position	17 units	Advisory only
Traffic Advisory Display annunciation	31 units	Monitor
Thrust Reverser quantity display	93 units	Advisory only

Condition	Sample value	Remarks
Pack Temperature Control quantity display	20 units	Advisory only
Cabin Pressure Controller quantity display	32 units	Monitor
Brake Temperature Monitor advisory	60 units	Normal

Traffic Advisory Display switch position	19 units	Advisory only
--	----------	---------------

If the Center Tank Pumps is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The relief pilot will verify any change in the Thrust Reverser selector position and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Fuel Crossfeed status message that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval.

The relief pilot will monitor any change in the Auxiliary Power Unit indication and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. During engine start, the Captain should announce the Flight Management Computer advisory if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. The pilot flying will monitor any change in the Flight Management Computer advisory and advise the other pilot before the next phase of flight. The Standby Hydraulic annunciation that differs from the expected state requires the pilot flying to verify the condition when conditions permit.

The Autobrake Selector indication is expected to read within the sample range of 40 to 45 units during approach. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will cross-check any change in the Hydraulic System A switch position and advise the other pilot when operating at a sample station without ground power.

NOTE: During a maintenance-requested ground run, the pilot monitoring should announce the Thrust Reverser advisory unless directed otherwise by the Sample Operations Center. The Thrust Reverser switch position is expected to read within the sample range of 21 to 29 units during preflight.

05.50.8 Autopilot Channel B Indications

The pilot monitoring will monitor any change in the Hydraulic System B advisory and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. If the Cockpit Voice Recorder is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Oxygen Distribution quantity display that differs from the expected state requires the First Officer to monitor the condition when conditions permit. If the Autopilot Channel B is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Window Heat indication that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. The first officer will confirm any change in the Cockpit Voice Recorder switch position and advise the other pilot if a discrepancy is observed.

- The captain will brief any change in the Flight Management Computer status message and advise the other pilot once the checklist item is complete.
- The Cockpit Voice Recorder selector position that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center.
- If the Nosewheel Steering is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.
- The Thrust Reverser status message that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed.
- The first officer will record any change in the Autothrottle annunciation and advise the other pilot when conditions permit.

- The first officer will cross-check any change in the Auxiliary Power Unit indication and advise the other pilot if a discrepancy is observed.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The captain will select any change in the Cockpit Voice Recorder selector position and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The relief pilot will verify any change in the Primary Electrical Bus advisory and advise the other pilot when conditions permit.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the Captain should verify the Bleed Air Supply switch position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Transponder selector position	72 units	Advisory only
Probe Heat annunciation	58 units	Refer to related topic
Nosewheel Steering advisory	56 units	Normal

CAUTION: The pilot flying will verify any change in the Autothrottle annunciation and advise the other pilot before the next phase of flight.

Challenge	Response
Transponder	On
Stall Warning	Set
Cabin Pressure Controller	As required
Center Tank Pumps	Off
Traffic Advisory Display	Set
Hydraulic System B	Set
Probe Heat	Off
Center Tank Pumps	Checked
Landing Gear Indication	As required
Standby Instruments	As required
Standby Instruments	Closed

05.50.9 Landing Gear Indication Overview

The Window Heat indication that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. The captain will cross-check any change in the Hydraulic System A switch position and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Nosewheel Steering advisory	9 units	Normal
Traffic Advisory Display quantity display	45 units	Normal
Transponder quantity display	89 units	Advisory only
Center Tank Pumps switch position	85 units	Monitor
Transponder advisory	98 units	Advisory only
Flight Management Computer quantity display	55 units	Advisory only

If the Brake Temperature Monitor is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. During a diversion, the First Officer should record the Thrust Reverser indication if the indication does not stabilize within the sample interval. During approach, the Captain should record the Probe Heat switch position when conditions permit. The pilot flying will verify any change in the Autothrottle indication and advise the other pilot before the next phase of flight. The captain will brief any change in the Thrust Reverser quantity display and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context.

During a turnaround, the pilot flying should cross-check the Autothrottle indication if a discrepancy is observed. If the Nosewheel Steering is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will verify any change in the Transponder advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Fuel Crossfeed is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. During climb, the pilot monitoring should brief the Standby Instruments indication if a discrepancy is observed. If the Hydraulic System B is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Landing Gear Indication status message is expected to read within the sample range of 48 to 52 units during approach. If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Nosewheel Steering indication is expected to read within the sample range of 3 to 13 units during taxi.

Refer to the related topic for additional sample context. If the Wing Anti-Ice is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Transponder switch position that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. If the Wing Anti-Ice is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

The Brake Temperature Monitor advisory that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete. The captain will select any change in the Center Tank Pumps status message and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

The pilot monitoring will announce any change in the Wing Anti-Ice quantity display and advise the other pilot before the next phase of flight. The relief pilot will monitor any change in the Engine Anti-Ice quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Transponder status message is expected to read within the sample range of 10 to 17 units during a diversion. During preflight, the pilot flying should monitor the Flight Management Computer quantity display if the indication does not stabilize within the sample interval. During approach, the relief pilot should verify the Wing Anti-Ice indication unless directed otherwise by the Sample Operations Center.

NOTE: If the Weather Radar is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

Challenge	Response
Ground Proximity Monitor	Closed
Center Tank Pumps	Closed
Stall Warning	On
Autobrake Selector	Checked
Cabin Pressure Controller	On
Thrust Reverser	Verified
Cargo Smoke Detection	On
Standby Instruments	Set

05.50.10 Auxiliary Power Unit Test

The Autopilot Channel B switch position is expected to read within the sample range of 38 to 50 units during cruise. During takeoff, the pilot monitoring should record the Cockpit Voice Recorder annunciation unless directed otherwise by the Sample Operations Center. During engine start, both pilots should select the Speedbrake Handle advisory when conditions permit. The Pack Temperature Control annunciation is expected to read within the sample range of 89 to 101 units during taxi. If the Flight Management Computer is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During a maintenance-requested ground run, the First Officer should select the Standby Instruments status message when operating at a sample station without ground power.

CAUTION: If the Landing Gear Indication is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. During preflight, the pilot monitoring should announce the Speedbrake Handle status message when operating at a sample station without ground power.

If the Thrust Reverser is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Stall Warning annunciation is expected to read within the sample range of 78 to 88 units during descent. The pilot monitoring will verify any change in the Standby Instruments advisory and advise the other pilot when the associated caution light remains illuminated. The Cargo Smoke Detection advisory is expected to read within the sample range of 12 to 18 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

Challenge	Response
Flight Management Computer	Closed
Engine Anti-Ice	Off
Cargo Smoke Detection	Verified
Auxiliary Power Unit	Verified
Cabin Pressure Controller	Checked
Window Heat	Verified
Hydraulic System A	Checked
Autopilot Channel B	Checked
Cabin Pressure Controller	As required
Window Heat	On

05.50.11 Oxygen Distribution Power Sources

During a diversion, the pilot monitoring should confirm the Window Heat advisory when conditions permit. The Fire Detection Loop advisory is expected to read within the sample range of 33 to 40 units during engine start. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will record any change in the Auxiliary Power Unit indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Hydraulic System A quantity display that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, both pilots should announce the Ground Proximity Monitor annunciation unless directed otherwise by the Sample Operations Center.

NOTE: The Weather Radar quantity display is expected to read within the sample range of 9 to 16 units during a maintenance-requested ground run.

NOTE: During a diversion, the relief pilot should confirm the Traffic Advisory Display advisory when conditions permit.

CAUTION: If the Thrust Reverser is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Oxygen Distribution annunciation is expected to read within the sample range of 12 to 15 units during an extended ground delay.

- The Transponder selector position that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power.
- The Stall Warning status message is expected to read within the sample range of 57 to 68 units during preflight.
- The Standby Hydraulic annunciation that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center.
- During taxi, the pilot flying should record the Nosewheel Steering switch position when the associated caution light remains illuminated.
- If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.
- The Standby Instruments quantity display that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Engine Anti-Ice selector position	21 units	Refer to related topic
Engine Anti-Ice switch position	94 units	Normal
Wing Anti-Ice selector position	47 units	Normal

Challenge	Response
Probe Heat	Checked
Fuel Crossfeed	Armed
Hydraulic System B	Closed
Cargo Smoke Detection	Verified
Standby Hydraulic	Closed
Hydraulic System A	Off
Window Heat	Checked
Landing Gear Indication	Checked
Cargo Smoke Detection	On
Pack Temperature Control	Verified
Standby Instruments	Set

05.50.12 Autothrottle Power Sources

The captain will record any change in the Window Heat indication and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, the pilot flying should record the Flight Management Computer advisory when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Flap Position Indication quantity display that differs from the expected state requires the Captain to brief the condition before the next phase of flight. During landing, the relief pilot should select the Engine Anti-Ice selector position when operating at a sample station without ground power.

CAUTION: The Hydraulic System A quantity display is expected to read within the sample range of 29 to 36 units during a turnaround. The Engine Anti-Ice status message is expected to read within the sample range of 43 to 55 units during cruise.

During engine start, the relief pilot should cross-check the Autopilot Channel A quantity display if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the relief pilot should monitor the Hydraulic System B selector position when operating at a sample station without ground power. The Autothrottle switch position that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power. During climb, both pilots should announce the Fire Detection Loop advisory when the associated caution light remains illuminated.

During cruise, the pilot flying should cross-check the Auxiliary Power Unit switch position if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. If the Traffic Advisory Display is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The pilot monitoring will record any change in the Standby Instruments selector position and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. If the Autothrottle is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

The first officer will record any change in the Autopilot Channel B switch position and advise the other pilot when operating at a sample station without ground power. The captain will cross-check any change in the Standby Instruments annunciation and advise the other pilot when operating at a sample station without ground power. If the Standby Hydraulic is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During a diversion, both pilots should verify the Cockpit Voice Recorder quantity display before the next phase of flight.

- The pilot flying will cross-check any change in the Fire Detection Loop switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The first officer will cross-check any change in the Fire Detection Loop status message and advise the other pilot before the next phase of flight.
- The Speedbrake Handle advisory that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated.
- During parking, the relief pilot should monitor the Hydraulic System B switch position unless directed otherwise by the Sample Operations Center.
- During a maintenance-requested ground run, the pilot monitoring should select the Speedbrake Handle advisory unless directed otherwise by the Sample Operations Center.
- The Landing Gear Indication quantity display is expected to read within the sample range of 66 to 69 units during takeoff.

During engine start, the First Officer should select the Autobrake Selector switch position unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The captain will monitor any change in the Fuel Crossfeed quantity display and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. During climb, the Captain should confirm the Bleed Air Supply status message once the checklist item is complete. See 18.10.17 Speedbrake Handle Normal Operation.

Condition	Sample value	Remarks
Transponder status message	8 units	Normal
Autopilot Channel B selector position	2 units	Refer to related topic
Flight Management Computer advisory	36 units	Refer to related topic
Auxiliary Power Unit advisory	36 units	Refer to related topic

Autopilot Channel A status message	46 units	Monitor
Ground Proximity Monitor selector position	70 units	Normal

Challenge	Response
Cabin Pressure Controller	Closed
Cargo Smoke Detection	Set
Wing Anti-Ice	On
Standby Hydraulic	On
Standby Hydraulic	Off
Oxygen Distribution	Set

05.50.13 Standby Instruments Normal Operation

If the Nosewheel Steering is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will select any change in the Ground Proximity Monitor annunciation and advise the other pilot when operating at a sample station without ground power. The Brake Temperature Monitor quantity display that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated. During takeoff, the First Officer should select the Cargo Smoke Detection status message if the indication does not stabilize within the sample interval. The Center Tank Pumps indication that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The Bleed Air Supply advisory is expected to read within the sample range of 29 to 35 units during a diversion.

During takeoff, both pilots should announce the Flap Position Indication switch position before the next phase of flight. The pilot flying will announce any change in the Standby Instruments quantity display and advise the other pilot when conditions permit. The Ground Proximity Monitor quantity display that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center. The Speedbrake Handle indication is expected to read within the sample range of 97 to 109 units during an extended ground delay. During a turnaround, the relief pilot should select the Thrust Reverser status message before the next phase of flight.

The relief pilot will confirm any change in the Standby Instruments advisory and advise the other pilot when operating at a sample station without ground power. The Fire Detection Loop status message that differs from the expected state requires the pilot flying to record the condition when conditions permit. The Stall Warning status message that differs from the expected state requires the pilot monitoring to cross-check the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The Fire Detection Loop quantity display is expected to read within the sample range of 18 to 26 units during an extended ground delay.

Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication advisory that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. During preflight, the Captain should announce the Cockpit Voice Recorder switch position once the checklist item is complete. If the Standby Hydraulic is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Flap Position Indication selector position is expected to read within the sample range of 68 to 74 units during parking.

NOTE: The Thrust Reverser switch position is expected to read within the sample range of 65 to 72 units during approach. If the Autopilot Channel B is inoperative, continue approach only after both pilots has reviewed the

associated sample guidance.

Challenge	Response
Flap Position Indication	On
Center Tank Pumps	Set
Pack Temperature Control	As required
Standby Instruments	Armed
Cabin Pressure Controller	Off
Traffic Advisory Display	Set
Traffic Advisory Display	As required
Standby Hydraulic	Set
Autopilot Channel A	Armed
Brake Temperature Monitor	Verified

05.50.14 Autopilot Channel B Status Messages

If the Autopilot Channel A is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. During descent, the First Officer should brief the Stall Warning switch position when the associated caution light remains illuminated. The Nosewheel Steering selector position that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. During a maintenance-requested ground run, the pilot flying should confirm the Nosewheel Steering switch position unless directed otherwise by the Sample Operations Center.

If the Engine Anti-Ice is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Transponder indication and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Fire Detection Loop quantity display	36 units	Advisory only
Engine Anti-Ice advisory	13 units	Refer to related topic
Stall Warning indication	25 units	Advisory only
Speedbrake Handle selector position	17 units	Monitor
Primary Electrical Bus selector position	37 units	Normal
Landing Gear Indication selector position	55 units	Refer to related topic
Stall Warning annunciation	38 units	Advisory only

If the Pack Temperature Control is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

NOTE: Both pilots will select any change in the Primary Electrical Bus indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: During climb, both pilots should record the Autothrottle quantity display when operating at a sample station without ground power.

The Fire Detection Loop quantity display is expected to read within the sample range of 16 to 19 units during climb. Refer to the related topic for additional sample context. The Standby Instruments annunciation is expected to read within the sample range of 75 to 83 units during takeoff.

This text is fictional and exists only to give the prototype realistic volume and structure. The Cargo Smoke Detection annunciation is expected to read within the sample range of 87 to 93 units during takeoff. During cruise, the Captain should confirm the Flight Management Computer status message if the indication does not stabilize within the sample interval. The Autopilot Channel A indication is expected to read within the sample range of 87 to 97 units during climb. The pilot monitoring will cross-check any change in the Brake Temperature Monitor selector position and advise the other pilot if a discrepancy is observed.

CAUTION: The Brake Temperature Monitor indication is expected to read within the sample range of 59 to 63 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Landing Gear Indication	Off
Traffic Advisory Display	Set
Stall Warning	Off
Hydraulic System B	On
Cargo Smoke Detection	On
Transponder	Armed
Engine Anti-Ice	On
Autopilot Channel B	As required
Cargo Smoke Detection	Armed
Standby Instruments	Closed
Hydraulic System B	Closed

05.50.15 Brake Temperature Monitor Reset Guidance

If the Fire Detection Loop is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Transponder switch position is expected to read within the sample range of 65 to 70 units during a maintenance-requested ground run.

If the Cockpit Voice Recorder is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. During a turnaround, the Captain should verify the Hydraulic System B selector position when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, the First Officer should cross-check the Primary Electrical Bus selector position if the indication does not stabilize within the sample interval. The Transponder selector position that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight.

The Landing Gear Indication status message is expected to read within the sample range of 21 to 28 units during cruise. If the Pack Temperature Control is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Brake Temperature Monitor advisory	37 units	Normal
Standby Hydraulic selector position	4 units	Refer to related topic
Autopilot Channel B status message	40 units	Advisory only
Landing Gear Indication selector position	68 units	Normal

The pilot monitoring will verify any change in the Autobrake Selector selector position and advise the other pilot if a discrepancy is observed. The Hydraulic System A advisory is expected to read within the sample range of 58 to 64 units during a diversion. The Autopilot Channel B status message that differs from the expected state requires the

relief pilot to monitor the condition once the checklist item is complete. The pilot monitoring will record any change in the Center Tank Pumps selector position and advise the other pilot when the associated caution light remains illuminated. The Autopilot Channel B switch position that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. During a turnaround, the First Officer should brief the Hydraulic System B indication when conditions permit.

Challenge	Response
Auxiliary Power Unit	Closed
Primary Electrical Bus	Set
Autopilot Channel A	As required
Autobrake Selector	As required
Fire Detection Loop	Set
Bleed Air Supply	Off

05.50.16 *Flight Management Computer Overview*

The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will cross-check any change in the Standby Instruments quantity display and advise the other pilot before the next phase of flight. The Fuel Crossfeed annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. The pilot flying will cross-check any change in the Weather Radar selector position and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Bleed Air Supply indication	66 units	Refer to related topic
Stall Warning switch position	36 units	Normal
Primary Electrical Bus quantity display	9 units	Normal
Standby Instruments switch position	28 units	Advisory only
Auxiliary Power Unit indication	85 units	Advisory only

NOTE: Values in this manual are invented and must not be used for any operational purpose. If the Pack Temperature Control is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

During cruise, the Captain should announce the Landing Gear Indication switch position unless directed otherwise by the Sample Operations Center. The pilot flying will record any change in the Standby Hydraulic selector position and advise the other pilot when the associated caution light remains illuminated. If the Stall Warning is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Transponder quantity display that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. If the Oxygen Distribution is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. See 12.20.13 Fuel Crossfeed Indications.

CAUTION: If the Flight Management Computer is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Autobrake Selector annunciation is expected to read within the sample range of 50 to 60 units during approach.

Condition	Sample value	Remarks
Wing Anti-Ice annunciation	24 units	Normal

Fuel Crossfeed switch position	51 units	Monitor
Landing Gear Indication quantity display	89 units	Refer to related topic

05.50.17 Wing Anti-Ice Crew Awareness

If the Flight Management Computer is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Fuel Crossfeed advisory is expected to read within the sample range of 10 to 13 units during a diversion. The Cargo Smoke Detection annunciation that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Stall Warning annunciation	25 units	Normal
Cargo Smoke Detection switch position	79 units	Advisory only
Traffic Advisory Display quantity display	76 units	Normal
Cockpit Voice Recorder annunciation	77 units	Normal
Wing Anti-Ice selector position	39 units	Normal
Nosewheel Steering advisory	23 units	Normal
Hydraulic System B status message	54 units	Advisory only

- The pilot monitoring will verify any change in the Autopilot Channel B selector position and advise the other pilot when operating at a sample station without ground power.
- During a diversion, the pilot flying should monitor the Standby Hydraulic selector position when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.

Refer to the related topic for additional sample context. The first officer will verify any change in the Oxygen Distribution quantity display and advise the other pilot once the checklist item is complete. The Standby Hydraulic status message is expected to read within the sample range of 21 to 29 units during descent. During an extended ground delay, the pilot flying should verify the Flap Position Indication switch position when operating at a sample station without ground power.

During preflight, the Captain should confirm the Pack Temperature Control quantity display when conditions permit. If the Primary Electrical Bus is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The Center Tank Pumps advisory that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete.

NOTE: The Pack Temperature Control indication that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.

CAUTION: During takeoff, the relief pilot should confirm the Transponder status message unless directed otherwise by the Sample Operations Center. During engine start, the pilot flying should announce the Landing Gear Indication selector position if the indication does not stabilize within the sample interval.

05.50.18 Thrust Reverser Interfaces

Refer to the related topic for additional sample context. The Autopilot Channel B status message that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. If the Ground Proximity Monitor is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. During takeoff, the pilot flying should announce the Cockpit Voice Recorder annunciation once the checklist item is complete. If the Landing Gear Indication is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. During an extended ground delay, the First Officer should cross-check the Landing Gear Indication indication if the indication does not stabilize within the sample

interval.

NOTE: The Fuel Crossfeed advisory that differs from the expected state requires both pilots to announce the condition once the checklist item is complete.

The Window Heat switch position is expected to read within the sample range of 5 to 12 units during a maintenance-requested ground run. The captain will select any change in the Autopilot Channel A quantity display and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. If the Wing Anti-Ice is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Stall Warning indication that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.

- Both pilots will brief any change in the Weather Radar quantity display and advise the other pilot before the next phase of flight.
- If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- During landing, the Captain should monitor the Brake Temperature Monitor quantity display when conditions permit.
- If the Hydraulic System B is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- The Hydraulic System B annunciation that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated.
- The Standby Hydraulic quantity display that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated.

If the Autothrottle is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. Both pilots will cross-check any change in the Nosewheel Steering selector position and advise the other pilot before the next phase of flight. The Probe Heat advisory is expected to read within the sample range of 64 to 68 units during engine start. The Ground Proximity Monitor status message that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. Both pilots will announce any change in the Autopilot Channel B indication and advise the other pilot before the next phase of flight. The pilot flying will confirm any change in the Cargo Smoke Detection indication and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. Both pilots will record any change in the Fire Detection Loop annunciation and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context.

Challenge	Response
Traffic Advisory Display	Closed
Fuel Crossfeed	As required
Fuel Crossfeed	Set
Oxygen Distribution	Off
Ground Proximity Monitor	Verified
Nosewheel Steering	Verified

05.50.19 Autobrake Selector Normal Operation

The Cabin Pressure Controller indication is expected to read within the sample range of 44 to 52 units during a diversion. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will brief any

change in the Brake Temperature Monitor selector position and advise the other pilot when operating at a sample station without ground power. During a diversion, the pilot flying should monitor the Pack Temperature Control annunciation when conditions permit.

Values in this manual are invented and must not be used for any operational purpose. The Autothrottle indication is expected to read within the sample range of 96 to 102 units during engine start. During engine start, the First Officer should verify the Transponder status message once the checklist item is complete. The Brake Temperature Monitor selector position is expected to read within the sample range of 91 to 102 units during an extended ground delay.

Condition	Sample value	Remarks
Cabin Pressure Controller indication	39 units	Advisory only
Cargo Smoke Detection status message	19 units	Refer to related topic
Cabin Pressure Controller status message	93 units	Refer to related topic
Ground Proximity Monitor indication	69 units	Advisory only

Condition	Sample value	Remarks
Flight Management Computer annunciation	89 units	Normal
Autopilot Channel A annunciation	61 units	Advisory only
Probe Heat switch position	43 units	Refer to related topic
Fuel Crossfeed switch position	76 units	Refer to related topic

- During a diversion, both pilots should record the Auxiliary Power Unit status message once the checklist item is complete.
- The Fuel Crossfeed selector position is expected to read within the sample range of 27 to 39 units during descent.
- The Stall Warning advisory that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight.
- If the Engine Anti-Ice is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

Challenge	Response
Probe Heat	Set
Nosewheel Steering	Closed
Oxygen Distribution	As required
Cockpit Voice Recorder	Off
Nosewheel Steering	Off
Nosewheel Steering	Off

05.60 Landing Gear and Brakes

05.60.1 Autopilot Channel A Normal Operation

During a maintenance-requested ground run, the Captain should cross-check the Auxiliary Power Unit quantity display when the associated caution light remains illuminated. The Speedbrake Handle advisory that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. The Transponder selector position that differs from the expected state requires the First Officer to record the condition before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop status message that differs from the expected state requires the pilot monitoring to cross-check the condition unless directed otherwise by the Sample Operations Center.

Values in this manual are invented and must not be used for any operational purpose. The Flight Management Computer status message that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed. If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Hydraulic advisory is expected to read within the sample range of 38 to 41 units during a maintenance-requested ground run.

The Wing Anti-Ice switch position that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. The Cargo Smoke Detection indication that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval. The Landing Gear Indication switch position is expected to read within the sample range of 11 to 15 units during cruise. During engine start, the Captain should monitor the Brake Temperature Monitor advisory before the next phase of flight.

CAUTION: If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. During takeoff, the pilot monitoring should monitor the Fuel Crossfeed advisory when the associated caution light remains illuminated.

NOTE: The pilot flying will confirm any change in the Hydraulic System B selector position and advise the other pilot when conditions permit.

The Transponder advisory is expected to read within the sample range of 94 to 106 units during a maintenance-requested ground run. During parking, the pilot flying should verify the Flap Position Indication indication when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Fire Detection Loop selector position	16 units	Monitor
Nosewheel Steering quantity display	25 units	Monitor
Window Heat switch position	93 units	Advisory only
Auxiliary Power Unit selector position	24 units	Refer to related topic

CAUTION: The Bleed Air Supply selector position that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated.

The pilot monitoring will announce any change in the Stall Warning status message and advise the other pilot if the indication does not stabilize within the sample interval. If the Standby Hydraulic is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The Flap Position Indication quantity display that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval.

Challenge	Response
Bleed Air Supply	Set
Ground Proximity Monitor	Armed
Wing Anti-Ice	Checked
Traffic Advisory Display	Off
Nosewheel Steering	Off
Cargo Smoke Detection	Set
Traffic Advisory Display	Off
Hydraulic System A	Checked
Cockpit Voice Recorder	Verified
Window Heat	Checked

Flight Management Computer	Set
Autothrottle	Off

05.60.2 New Sample Topic: Pack Temperature Control

If the Wing Anti-Ice is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Cockpit Voice Recorder annunciation that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. The pilot flying will monitor any change in the Standby Hydraulic advisory and advise the other pilot before the next phase of flight. The Oxygen Distribution annunciation is expected to read within the sample range of 11 to 23 units during preflight.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Oxygen Distribution is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Cabin Pressure Controller status message that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. During a diversion, the Captain should verify the Window Heat advisory once the checklist item is complete. The Flight Management Computer advisory is expected to read within the sample range of 39 to 43 units during a turnaround. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

CAUTION: If the Pack Temperature Control is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Stall Warning is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Stall Warning status message is expected to read within the sample range of 86 to 96 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. The Autobrake Selector quantity display is expected to read within the sample range of 34 to 38 units during engine start.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Stall Warning is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. During descent, the pilot monitoring should record the Flap Position Indication status message if the indication does not stabilize within the sample interval. The Cargo Smoke Detection advisory is expected to read within the sample range of 75 to 82 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Cabin Pressure Controller indication	66 units	Refer to related topic
Fire Detection Loop advisory	67 units	Refer to related topic
Autopilot Channel B status message	13 units	Normal
Center Tank Pumps indication	61 units	Monitor
Cockpit Voice Recorder selector position	29 units	Refer to related topic
Fire Detection Loop status message	14 units	Refer to related topic

If the Autothrottle is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The captain will select any change in the Hydraulic System B advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will cross-check any change in the Wing Anti-Ice switch position and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The Autobrake Selector quantity display is expected to read within the sample range of 2 to 13 units during climb. If the Ground Proximity Monitor is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

05.60.3 Window Heat Power Sources

The pilot monitoring will select any change in the Center Tank Pumps indication and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose.

If the Standby Instruments is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Pack Temperature Control selector position and advise the other pilot when the associated caution light remains illuminated. The Window Heat indication that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. The Ground Proximity Monitor advisory that differs from the expected state requires the Captain to record the condition once the checklist item is complete.

- The relief pilot will announce any change in the Fire Detection Loop annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- Refer to the related topic for additional sample context.
- The Standby Instruments annunciation is expected to read within the sample range of 19 to 25 units during preflight.
- If the Probe Heat is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

The Flap Position Indication selector position that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. The Standby Hydraulic quantity display is expected to read within the sample range of 62 to 70 units during engine start. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Fire Detection Loop is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The first officer will cross-check any change in the Autobrake Selector selector position and advise the other pilot when the associated caution light remains illuminated. The first officer will announce any change in the Ground Proximity Monitor indication and advise the other pilot once the checklist item is complete. If the Cargo Smoke Detection is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. See 07.30.7 Probe Heat Crew Awareness.

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	56 units	Refer to related topic
Primary Electrical Bus annunciation	64 units	Monitor
Bleed Air Supply switch position	46 units	Normal
Cabin Pressure Controller advisory	34 units	Monitor
Ground Proximity Monitor annunciation	68 units	Monitor
Thrust Reverser indication	83 units	Normal

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. During approach, both pilots should monitor the Primary Electrical Bus advisory when conditions permit.

Challenge	Response
Wing Anti-Ice	Closed
Autopilot Channel A	Verified

Fire Detection Loop	Armed
Ground Proximity Monitor	Off
Cabin Pressure Controller	As required
Thrust Reverser	As required
Cabin Pressure Controller	Set
Pack Temperature Control	Closed
Hydraulic System B	Armed
Stall Warning	Checked
Fire Detection Loop	Set
Fire Detection Loop	Armed

05.60.4 Standby Hydraulic Power Sources

The Bleed Air Supply switch position that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. If the Transponder is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The relief pilot will monitor any change in the Autopilot Channel A status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

- During takeoff, the Captain should cross-check the Brake Temperature Monitor indication when operating at a sample station without ground power.
- The relief pilot will confirm any change in the Bleed Air Supply annunciation and advise the other pilot before the next phase of flight.
- The Auxiliary Power Unit selector position that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete.
- The Ground Proximity Monitor quantity display is expected to read within the sample range of 2 to 14 units during approach.
- The Speedbrake Handle status message that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated.
- If the Cockpit Voice Recorder is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The first officer will announce any change in the Traffic Advisory Display indication and advise the other pilot when the associated caution light remains illuminated.
- The first officer will verify any change in the Oxygen Distribution switch position and advise the other pilot when conditions permit.
- Both pilots will cross-check any change in the Autobrake Selector advisory and advise the other pilot when conditions permit.
- The first officer will record any change in the Probe Heat selector position and advise the other pilot when operating at a sample station without ground power.
- The Fuel Crossfeed indication that differs from the expected state requires the pilot flying to brief the condition when conditions permit.
- If the Pack Temperature Control is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

- The Flight Management Computer annunciation that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- This text is fictional and exists only to give the prototype realistic volume and structure.

Refer to the related topic for additional sample context. The Probe Heat annunciation that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The relief pilot will confirm any change in the Auxiliary Power Unit quantity display and advise the other pilot once the checklist item is complete. The Flap Position Indication status message that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. During an extended ground delay, the relief pilot should monitor the Cabin Pressure Controller selector position once the checklist item is complete.

During descent, the First Officer should announce the Auxiliary Power Unit status message unless directed otherwise by the Sample Operations Center. The captain will announce any change in the Bleed Air Supply annunciation and advise the other pilot when the associated caution light remains illuminated. The Auxiliary Power Unit advisory that differs from the expected state requires the First Officer to record the condition before the next phase of flight. The Speedbrake Handle selector position that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated. The first officer will announce any change in the Stall Warning annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Landing Gear Indication quantity display that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power.
- The Hydraulic System A indication is expected to read within the sample range of 21 to 31 units during cruise.

05.60.5 Bleed Air Supply Overview

This text is fictional and exists only to give the prototype realistic volume and structure. The Flap Position Indication advisory that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

- Refer to the related topic for additional sample context.
- If the Center Tank Pumps is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- The pilot flying will record any change in the Nosewheel Steering status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The pilot flying will announce any change in the Center Tank Pumps indication and advise the other pilot when operating at a sample station without ground power.
- If the Cargo Smoke Detection is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.
- If the Oxygen Distribution is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

The captain will cross-check any change in the Bleed Air Supply status message and advise the other pilot when the associated caution light remains illuminated. During taxi, the Captain should monitor the Flight Management Computer quantity display once the checklist item is complete. The captain will cross-check any change in the Flap Position Indication selector position and advise the other pilot when conditions permit.

If the Pack Temperature Control is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. During climb, the Captain should monitor the Wing Anti-Ice advisory if the indication does not stabilize within the sample interval. The Hydraulic System A status message is

expected to read within the sample range of 22 to 33 units during approach.

- The Cargo Smoke Detection switch position is expected to read within the sample range of 27 to 38 units during a diversion.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a maintenance-requested ground run, the pilot monitoring should select the Weather Radar switch position if the indication does not stabilize within the sample interval.

05.60.6 Stall Warning Power Sources

During preflight, the relief pilot should verify the Ground Proximity Monitor indication when operating at a sample station without ground power. During a turnaround, the First Officer should record the Transponder advisory once the checklist item is complete. During landing, the Captain should select the Ground Proximity Monitor selector position when conditions permit. The Autothrottle indication that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval. If the Cabin Pressure Controller is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

This text is fictional and exists only to give the prototype realistic volume and structure. The Center Tank Pumps status message is expected to read within the sample range of 60 to 67 units during a turnaround. During cruise, the pilot flying should confirm the Engine Anti-Ice switch position when the associated caution light remains illuminated. The Autopilot Channel B status message that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. During engine start, the pilot monitoring should record the Fire Detection Loop status message when conditions permit. During takeoff, both pilots should select the Bleed Air Supply status message if a discrepancy is observed.

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	77 units	Refer to related topic
Transponder quantity display	45 units	Advisory only
Brake Temperature Monitor switch position	62 units	Normal
Probe Heat indication	45 units	Refer to related topic

CAUTION: The captain will brief any change in the Autopilot Channel A quantity display and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Standby Hydraulic status message that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. The Fire Detection Loop switch position is expected to read within the sample range of 6 to 14 units during takeoff.

Condition	Sample value	Remarks
Auxiliary Power Unit advisory	53 units	Advisory only
Autothrottle status message	37 units	Normal
Oxygen Distribution switch position	43 units	Monitor

Condition	Sample value	Remarks
Fuel Crossfeed switch position	80 units	Refer to related topic
Cockpit Voice Recorder indication	95 units	Advisory only
Cargo Smoke Detection switch position	22 units	Advisory only
Cockpit Voice Recorder indication	54 units	Normal
Autopilot Channel A annunciation	88 units	Advisory only
Bleed Air Supply switch position	45 units	Normal

Transponder advisory	46 units	Monitor
----------------------	----------	---------

Challenge	Response
Nosewheel Steering	On
Primary Electrical Bus	Closed
Window Heat	Set
Speedbrake Handle	Off
Cockpit Voice Recorder	Closed
Window Heat	Checked
Cockpit Voice Recorder	Armed
Thrust Reverser	Closed

05.60.7 Flap Position Indication Status Messages

During takeoff, the Captain should select the Fire Detection Loop indication if a discrepancy is observed. The Bleed Air Supply annunciation is expected to read within the sample range of 77 to 82 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The Weather Radar quantity display that differs from the expected state requires the Captain to select the condition before the next phase of flight. The pilot monitoring will select any change in the Probe Heat selector position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Traffic Advisory Display advisory	21 units	Normal
Stall Warning selector position	7 units	Advisory only
Speedbrake Handle advisory	70 units	Advisory only
Fuel Crossfeed advisory	31 units	Advisory only
Cabin Pressure Controller advisory	60 units	Advisory only
Autopilot Channel A status message	74 units	Advisory only
Standby Hydraulic status message	24 units	Refer to related topic

NOTE: During a turnaround, the pilot monitoring should verify the Fire Detection Loop switch position when the associated caution light remains illuminated. During descent, the Captain should monitor the Autobrake Selector quantity display if a discrepancy is observed.

Condition	Sample value	Remarks
Cabin Pressure Controller selector position	40 units	Normal
Autopilot Channel B annunciation	98 units	Advisory only
Primary Electrical Bus advisory	28 units	Advisory only

The Autobrake Selector status message that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. The Fire Detection Loop quantity display is expected to read within the sample range of 12 to 15 units during cruise. The captain will select any change in the Engine Anti-Ice indication and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	90 units	Refer to related topic
Flap Position Indication annunciation	85 units	Monitor
Autopilot Channel B switch position	41 units	Monitor

The Weather Radar switch position is expected to read within the sample range of 16 to 19 units during taxi. Both pilots will announce any change in the Autobrake Selector selector position and advise the other pilot when conditions permit. The Autothrottle annunciation that differs from the expected state requires the Captain to select the condition if a discrepancy is observed. The Ground Proximity Monitor switch position is expected to read within the sample range of 96 to 100 units during taxi.

NOTE: The relief pilot will select any change in the Auxiliary Power Unit quantity display and advise the other pilot if a discrepancy is observed.

CAUTION: During a turnaround, the Captain should announce the Cabin Pressure Controller annunciation if a discrepancy is observed. The pilot flying will announce any change in the Traffic Advisory Display status message and advise the other pilot when conditions permit.

05.60.8 Nosewheel Steering Interfaces

During a maintenance-requested ground run, the pilot monitoring should verify the Brake Temperature Monitor selector position if a discrepancy is observed. The pilot flying will record any change in the Transponder advisory and advise the other pilot when operating at a sample station without ground power. The Hydraulic System A selector position that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed. If the Probe Heat is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

NOTE: The Brake Temperature Monitor status message that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center.

During climb, both pilots should select the Cargo Smoke Detection switch position when the associated caution light remains illuminated. The Flap Position Indication status message is expected to read within the sample range of 51 to 55 units during takeoff. If the Pack Temperature Control is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will brief any change in the Cockpit Voice Recorder annunciation and advise the other pilot when the associated caution light remains illuminated.

If the Fuel Crossfeed is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Transponder switch position that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight. The relief pilot will brief any change in the Oxygen Distribution status message and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Autobrake Selector indication	65 units	Advisory only
Autopilot Channel B indication	66 units	Monitor
Primary Electrical Bus status message	76 units	Normal
Speedbrake Handle advisory	45 units	Refer to related topic

- If the Ground Proximity Monitor is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- The relief pilot will monitor any change in the Traffic Advisory Display switch position and advise the other pilot when the associated caution light remains illuminated.
- The Ground Proximity Monitor quantity display is expected to read within the sample range of 74 to 81 units during a diversion.
- The pilot monitoring will brief any change in the Speedbrake Handle switch position and advise the other pilot when operating at a sample station without ground power.

- The relief pilot will record any change in the Flap Position Indication selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.
- The first officer will brief any change in the Flap Position Indication status message and advise the other pilot when conditions permit.

CAUTION: The Speedbrake Handle annunciation that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power.

05.60.9 Thrust Reverser Overview

If the Center Tank Pumps is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The captain will brief any change in the Autobrake Selector advisory and advise the other pilot once the checklist item is complete. The Auxiliary Power Unit switch position is expected to read within the sample range of 86 to 92 units during parking. The Flight Management Computer annunciation is expected to read within the sample range of 91 to 98 units during parking.

If the Fire Detection Loop is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The captain will monitor any change in the Probe Heat status message and advise the other pilot before the next phase of flight.

If the Wing Anti-Ice is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Cargo Smoke Detection status message that differs from the expected state requires the Captain to announce the condition when conditions permit. During engine start, both pilots should monitor the Autobrake Selector selector position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Oxygen Distribution indication	67 units	Refer to related topic
Traffic Advisory Display annunciation	93 units	Refer to related topic
Fuel Crossfeed indication	77 units	Refer to related topic
Standby Hydraulic quantity display	38 units	Refer to related topic
Nosewheel Steering selector position	8 units	Normal
Wing Anti-Ice selector position	28 units	Monitor
Thrust Reverser status message	55 units	Refer to related topic

If the Landing Gear Indication is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed status message is expected to read within the sample range of 61 to 67 units during descent.

Challenge	Response
Bleed Air Supply	Set
Oxygen Distribution	Verified
Thrust Reverser	Checked
Hydraulic System A	As required
Transponder	Verified
Fuel Crossfeed	Verified
Pack Temperature Control	Closed
Ground Proximity Monitor	Set

Standby Hydraulic	Verified
Flight Management Computer	Closed
Traffic Advisory Display	Set

05.60.10 Stall Warning Interfaces

The pilot monitoring will announce any change in the Oxygen Distribution annunciation and advise the other pilot when the associated caution light remains illuminated. The Transponder switch position is expected to read within the sample range of 69 to 80 units during taxi. During descent, the First Officer should cross-check the Speedbrake Handle quantity display once the checklist item is complete. The pilot flying will confirm any change in the Auxiliary Power Unit selector position and advise the other pilot if a discrepancy is observed. The Autobrake Selector selector position is expected to read within the sample range of 6 to 17 units during takeoff. During takeoff, the pilot flying should record the Autobrake Selector quantity display once the checklist item is complete.

The Ground Proximity Monitor switch position is expected to read within the sample range of 14 to 23 units during a diversion. The Pack Temperature Control quantity display that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, the First Officer should confirm the Hydraulic System B indication if a discrepancy is observed. The pilot flying will brief any change in the Brake Temperature Monitor quantity display and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

During a maintenance-requested ground run, the Captain should confirm the Thrust Reverser switch position if the indication does not stabilize within the sample interval. The captain will verify any change in the Cargo Smoke Detection indication and advise the other pilot before the next phase of flight. The Fuel Crossfeed indication is expected to read within the sample range of 24 to 29 units during a maintenance-requested ground run. During descent, the Captain should confirm the Flap Position Indication annunciation before the next phase of flight.

During takeoff, the Captain should select the Bleed Air Supply status message when conditions permit. During engine start, the First Officer should monitor the Hydraulic System B status message when conditions permit. Both pilots will select any change in the Flight Management Computer switch position and advise the other pilot when conditions permit. The Weather Radar selector position that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. During takeoff, the Captain should brief the Weather Radar indication if the indication does not stabilize within the sample interval. If the Cabin Pressure Controller is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

- Both pilots will cross-check any change in the Standby Hydraulic quantity display and advise the other pilot when operating at a sample station without ground power.
- The Auxiliary Power Unit indication is expected to read within the sample range of 27 to 36 units during a diversion.
- The Brake Temperature Monitor annunciation that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed.

CAUTION: The Bleed Air Supply advisory is expected to read within the sample range of 21 to 24 units during climb.

The Cabin Pressure Controller advisory that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. During an extended ground delay, the pilot monitoring should confirm the Primary Electrical Bus status message once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

The pilot flying will record any change in the Engine Anti-Ice status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will announce any change in the Traffic

Advisory Display annunciation and advise the other pilot when conditions permit. During cruise, the Captain should record the Autothrottle advisory when operating at a sample station without ground power. If the Stall Warning is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. Both pilots will verify any change in the Cabin Pressure Controller indication and advise the other pilot when operating at a sample station without ground power. During parking, the relief pilot should select the Engine Anti-Ice quantity display when conditions permit.

05.60.11 Window Heat Interfaces

The Bleed Air Supply switch position is expected to read within the sample range of 93 to 96 units during an extended ground delay. If the Autopilot Channel B is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Brake Temperature Monitor switch position is expected to read within the sample range of 68 to 72 units during landing.

- The pilot flying will brief any change in the Primary Electrical Bus annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- During engine start, the relief pilot should announce the Weather Radar switch position when operating at a sample station without ground power.
- If the Oxygen Distribution is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Thrust Reverser annunciation that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.

The Flap Position Indication switch position is expected to read within the sample range of 82 to 85 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure. The Thrust Reverser annunciation is expected to read within the sample range of 79 to 91 units during approach. The Window Heat indication that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. The Center Tank Pumps annunciation that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed. If the Engine Anti-Ice is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The Flight Management Computer indication is expected to read within the sample range of 88 to 91 units during preflight.

- The relief pilot will brief any change in the Flap Position Indication quantity display and advise the other pilot when the associated caution light remains illuminated.
- During takeoff, both pilots should record the Transponder status message if a discrepancy is observed.
- The Pack Temperature Control selector position that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power.
- The Transponder status message that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center.
- The Thrust Reverser quantity display is expected to read within the sample range of 33 to 43 units during a diversion.

Challenge	Response
Standby Hydraulic	Off
Flap Position Indication	On

Primary Electrical Bus	Closed
Autopilot Channel B	Verified
Probe Heat	Set
Cabin Pressure Controller	Off

05.60.12 Standby Hydraulic Status Messages

Both pilots will confirm any change in the Speedbrake Handle quantity display and advise the other pilot before the next phase of flight. The Oxygen Distribution indication that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. The captain will verify any change in the Probe Heat quantity display and advise the other pilot when conditions permit. During a diversion, the relief pilot should announce the Hydraulic System B selector position once the checklist item is complete.

The Cabin Pressure Controller status message is expected to read within the sample range of 14 to 19 units during parking. If the Brake Temperature Monitor is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System B switch position that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will select any change in the Autopilot Channel B indication and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context.

CAUTION: The Nosewheel Steering quantity display is expected to read within the sample range of 46 to 56 units during a maintenance-requested ground run.

If the Auxiliary Power Unit is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Autopilot Channel A selector position that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval. If the Speedbrake Handle is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Wing Anti-Ice indication that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Autopilot Channel A quantity display	70 units	Monitor
Standby Instruments annunciation	19 units	Normal
Autopilot Channel B switch position	42 units	Normal
Flight Management Computer status message	69 units	Refer to related topic
Cockpit Voice Recorder annunciation	85 units	Normal

The Flap Position Indication selector position is expected to read within the sample range of 29 to 35 units during approach. During engine start, the pilot flying should record the Oxygen Distribution selector position if a discrepancy is observed. The Bleed Air Supply advisory that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit. If the Hydraulic System B is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the relief pilot should cross-check the Auxiliary Power Unit indication unless directed otherwise by the Sample Operations Center. See 02.40.22 Flap Position Indication Indications.

NOTE: The Window Heat advisory is expected to read within the sample range of 47 to 51 units during descent. During cruise, the pilot monitoring should confirm the Center Tank Pumps selector position when operating at a sample station without ground power.

Condition	Sample value	Remarks
Brake Temperature Monitor indication	29 units	Monitor
Stall Warning selector position	50 units	Monitor

Traffic Advisory Display advisory	37 units	Normal
Stall Warning quantity display	46 units	Monitor
Standby Hydraulic switch position	94 units	Monitor

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

05.60.13 Fuel Crossfeed Indications

Both pilots will monitor any change in the Probe Heat annunciation and advise the other pilot when the associated caution light remains illuminated. The Window Heat selector position is expected to read within the sample range of 35 to 47 units during cruise. Refer to the related topic for additional sample context.

During climb, the relief pilot should monitor the Standby Hydraulic selector position unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Primary Electrical Bus quantity display and advise the other pilot when conditions permit. The Engine Anti-Ice switch position is expected to read within the sample range of 67 to 76 units during preflight. The Engine Anti-Ice advisory is expected to read within the sample range of 31 to 39 units during a maintenance-requested ground run. During a turnaround, the First Officer should confirm the Wing Anti-Ice status message if a discrepancy is observed. The first officer will announce any change in the Pack Temperature Control selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. See 05.70.2 Flap Position Indication Normal Operation.

- The Cabin Pressure Controller quantity display is expected to read within the sample range of 86 to 96 units during a diversion.
- During climb, the pilot monitoring should verify the Autopilot Channel A selector position when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.

CAUTION: The Autobrake Selector advisory is expected to read within the sample range of 71 to 80 units during descent.

- The Flight Management Computer annunciation that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated.
- If the Hydraulic System B is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.
- The Autothrottle advisory is expected to read within the sample range of 40 to 44 units during a turnaround.
- If the Hydraulic System B is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- The Landing Gear Indication annunciation is expected to read within the sample range of 3 to 13 units during cruise.

05.60.14 Wing Anti-Ice Reset Guidance

During preflight, the Captain should brief the Stall Warning quantity display when conditions permit. If the Standby Hydraulic is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution indication is expected to read within the sample range of 64 to 73 units during parking.

Condition	Sample value	Remarks
Oxygen Distribution quantity display	77 units	Monitor
Center Tank Pumps indication	73 units	Advisory only

Autopilot Channel B indication	25 units	Normal
Landing Gear Indication advisory	51 units	Monitor
Brake Temperature Monitor selector position	15 units	Refer to related topic
Bleed Air Supply selector position	49 units	Normal
Ground Proximity Monitor quantity display	99 units	Refer to related topic

The Window Heat advisory that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. The Center Tank Pumps annunciation that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval. During cruise, the First Officer should announce the Autothrottle quantity display if a discrepancy is observed. The captain will confirm any change in the Autopilot Channel B advisory and advise the other pilot once the checklist item is complete.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Autopilot Channel B indication is expected to read within the sample range of 57 to 64 units during descent.
- The Nosewheel Steering switch position that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete.
- The relief pilot will brief any change in the Window Heat indication and advise the other pilot when conditions permit.
- The Hydraulic System B selector position is expected to read within the sample range of 70 to 81 units during a turnaround.

The pilot flying will monitor any change in the Thrust Reverser status message and advise the other pilot if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder switch position is expected to read within the sample range of 5 to 16 units during climb. If the Bleed Air Supply is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

During a turnaround, the pilot monitoring should brief the Traffic Advisory Display advisory before the next phase of flight. The Pack Temperature Control selector position that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval. The Standby Hydraulic quantity display is expected to read within the sample range of 84 to 95 units during climb. The pilot monitoring will cross-check any change in the Standby Hydraulic selector position and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Flight Management Computer switch position is expected to read within the sample range of 45 to 55 units during a turnaround.
- The captain will verify any change in the Fuel Crossfeed quantity display and advise the other pilot before the next phase of flight.
- If the Autothrottle is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.
- The captain will brief any change in the Cargo Smoke Detection annunciation and advise the other pilot once the checklist item is complete.
- The relief pilot will cross-check any change in the Cabin Pressure Controller switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Brake Temperature Monitor is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

- During an extended ground delay, the pilot monitoring should confirm the Wing Anti-Ice selector position when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During approach, the pilot monitoring should select the Standby Instruments switch position when operating at a sample station without ground power.
- If the Wing Anti-Ice is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- The Autopilot Channel B quantity display that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated.

05.60.15 Center Tank Pumps Interfaces

The relief pilot will select any change in the Autopilot Channel B status message and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Hydraulic quantity display is expected to read within the sample range of 11 to 20 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, the Captain should monitor the Cargo Smoke Detection selector position once the checklist item is complete. The pilot flying will record any change in the Autopilot Channel B annunciation and advise the other pilot before the next phase of flight.

CAUTION: During taxi, the pilot flying should verify the Wing Anti-Ice advisory unless directed otherwise by the Sample Operations Center.

The pilot monitoring will brief any change in the Probe Heat selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Probe Heat indication is expected to read within the sample range of 34 to 45 units during a diversion. The first officer will confirm any change in the Wing Anti-Ice selector position and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Primary Electrical Bus selector position	63 units	Monitor
Weather Radar indication	62 units	Monitor
Ground Proximity Monitor annunciation	46 units	Refer to related topic
Speedbrake Handle quantity display	36 units	Advisory only
Autobrake Selector advisory	49 units	Advisory only

Condition	Sample value	Remarks
Cabin Pressure Controller indication	64 units	Advisory only
Standby Hydraulic advisory	17 units	Refer to related topic
Autothrottle annunciation	2 units	Advisory only
Pack Temperature Control indication	39 units	Refer to related topic
Probe Heat indication	20 units	Refer to related topic
Nosewheel Steering status message	21 units	Monitor

- The first officer will select any change in the Brake Temperature Monitor annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Fire Detection Loop is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

- If the Auxiliary Power Unit is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The first officer will record any change in the Fire Detection Loop switch position and advise the other pilot once the checklist item is complete.
- The Transponder selector position that differs from the expected state requires the relief pilot to record the condition when conditions permit.

The Fire Detection Loop annunciation that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center. The pilot flying will announce any change in the Bleed Air Supply selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. If the Cargo Smoke Detection is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Bleed Air Supply is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

Challenge	Response
Traffic Advisory Display	Closed
Weather Radar	Off
Oxygen Distribution	Armed
Ground Proximity Monitor	On
Traffic Advisory Display	Checked
Flap Position Indication	Verified
Cockpit Voice Recorder	Armed
Pack Temperature Control	Checked
Hydraulic System A	Checked
Cabin Pressure Controller	Off

CAUTION: During climb, the First Officer should record the Autopilot Channel B quantity display once the checklist item is complete. The captain will monitor any change in the Center Tank Pumps status message and advise the other pilot when conditions permit.

05.60.16 Cabin Pressure Controller Normal Operation

This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System B switch position that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. During an extended ground delay, the pilot monitoring should announce the Flap Position Indication advisory when operating at a sample station without ground power. The pilot monitoring will cross-check any change in the Standby Instruments annunciation and advise the other pilot if a discrepancy is observed. The Nosewheel Steering indication that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center.

CAUTION: The Fire Detection Loop selector position that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center.

The pilot flying will brief any change in the Autobrake Selector advisory and advise the other pilot if a discrepancy is observed. The relief pilot will verify any change in the Cockpit Voice Recorder switch position and advise the other pilot if a discrepancy is observed. If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Transponder indication that differs from the expected state requires the relief pilot to record the condition when conditions permit. During descent, both

pilots should monitor the Auxiliary Power Unit annunciation when operating at a sample station without ground power.

- The first officer will select any change in the Cockpit Voice Recorder indication and advise the other pilot when the associated caution light remains illuminated.
- Both pilots will record any change in the Flap Position Indication annunciation and advise the other pilot when the associated caution light remains illuminated.
- If the Ground Proximity Monitor is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Thrust Reverser quantity display that differs from the expected state requires the relief pilot to verify the condition once the checklist item is complete. The Weather Radar switch position that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. If the Cabin Pressure Controller is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Weather Radar indication is expected to read within the sample range of 14 to 24 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure.

- During takeoff, the First Officer should record the Speedbrake Handle quantity display if a discrepancy is observed.
- If the Hydraulic System B is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.
- If the Standby Instruments is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

CAUTION: During a diversion, the Captain should record the Cabin Pressure Controller advisory if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

05.60.17 Bleed Air Supply Reset Guidance

Values in this manual are invented and must not be used for any operational purpose. The pilot flying will announce any change in the Cabin Pressure Controller indication and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will confirm any change in the Hydraulic System A annunciation and advise the other pilot when conditions permit. The Standby Instruments switch position that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will monitor any change in the Pack Temperature Control quantity display and advise the other pilot if a discrepancy is observed.

The pilot flying will announce any change in the Hydraulic System B indication and advise the other pilot when operating at a sample station without ground power. The pilot monitoring will cross-check any change in the Oxygen Distribution switch position and advise the other pilot when the associated caution light remains illuminated. The captain will select any change in the Primary Electrical Bus status message and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During descent, the pilot flying should monitor the Standby Hydraulic annunciation once the checklist item is complete.

CAUTION: The first officer will record any change in the Fuel Crossfeed quantity display and advise the other pilot once the checklist item is complete.

The Weather Radar indication is expected to read within the sample range of 39 to 49 units during climb. During descent, both pilots should monitor the Auxiliary Power Unit advisory before the next phase of flight. Refer to the related topic for additional sample context. If the Standby Hydraulic is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The Oxygen Distribution selector position that differs

from the expected state requires the pilot flying to monitor the condition before the next phase of flight.

The Standby Instruments quantity display is expected to read within the sample range of 78 to 85 units during descent. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the pilot flying should announce the Brake Temperature Monitor indication unless directed otherwise by the Sample Operations Center. The Autothrottle quantity display is expected to read within the sample range of 2 to 11 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B annunciation that differs from the expected state requires both pilots to confirm the condition when conditions permit.

If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer quantity display that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. The Oxygen Distribution status message that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval. The Fuel Crossfeed status message that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

The first officer will verify any change in the Landing Gear Indication switch position and advise the other pilot once the checklist item is complete. If the Cargo Smoke Detection is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Nosewheel Steering annunciation is expected to read within the sample range of 59 to 67 units during cruise. The Nosewheel Steering annunciation is expected to read within the sample range of 68 to 71 units during an extended ground delay. See 03.40.5 Briefing: Brake Temperature Monitor.

Challenge	Response
Auxiliary Power Unit	As required
Standby Instruments	Verified
Transponder	Closed
Pack Temperature Control	Verified
Autopilot Channel A	Verified
Auxiliary Power Unit	Armed
Hydraulic System B	Off
Stall Warning	As required
Cockpit Voice Recorder	Checked
Pack Temperature Control	Verified
Cabin Pressure Controller	On

05.60.18 Speedbrake Handle Indications

The captain will confirm any change in the Standby Hydraulic selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During a diversion, the relief pilot should verify the Autothrottle annunciation before the next phase of flight. If the Autopilot Channel A is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

The Transponder indication is expected to read within the sample range of 12 to 18 units during a diversion. The Fuel Crossfeed quantity display is expected to read within the sample range of 75 to 80 units during parking. During approach, both pilots should select the Cabin Pressure Controller quantity display when operating at a sample station without ground power.

The Speedbrake Handle quantity display is expected to read within the sample range of 40 to 43 units during cruise. Values in this manual are invented and must not be used for any operational purpose. The Flap Position Indication quantity display is expected to read within the sample range of 53 to 60 units during engine start.

CAUTION: If the Autopilot Channel A is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Ground Proximity Monitor switch position that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval.

CAUTION: If the Center Tank Pumps is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

- During cruise, the relief pilot should announce the Autobrake Selector status message unless directed otherwise by the Sample Operations Center.
- The captain will select any change in the Wing Anti-Ice advisory and advise the other pilot when operating at a sample station without ground power.
- The captain will select any change in the Center Tank Pumps quantity display and advise the other pilot if a discrepancy is observed.
- During climb, the relief pilot should verify the Landing Gear Indication quantity display if a discrepancy is observed.
- The Auxiliary Power Unit advisory is expected to read within the sample range of 2 to 8 units during landing.
- During takeoff, the First Officer should select the Transponder quantity display if a discrepancy is observed.

05.60.19 Pack Temperature Control Test

The first officer will record any change in the Autopilot Channel B switch position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. The Ground Proximity Monitor quantity display that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Ground Proximity Monitor annunciation is expected to read within the sample range of 24 to 32 units during approach.

The Auxiliary Power Unit indication is expected to read within the sample range of 54 to 58 units during parking. During climb, the First Officer should verify the Flight Management Computer indication once the checklist item is complete. During an extended ground delay, the pilot monitoring should verify the Standby Instruments status message when the associated caution light remains illuminated. The Engine Anti-Ice status message that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Autopilot Channel B switch position	76 units	Normal
Nosewheel Steering status message	92 units	Refer to related topic
Autopilot Channel A quantity display	48 units	Advisory only

Condition	Sample value	Remarks
Landing Gear Indication switch position	3 units	Advisory only
Auxiliary Power Unit advisory	91 units	Monitor
Wing Anti-Ice annunciation	82 units	Normal

The wording here is placeholder content shaped like a procedure, not a procedure. The Oxygen Distribution advisory that differs from the expected state requires both pilots to announce the condition before the next phase of flight. The captain will brief any change in the Cabin Pressure Controller quantity display and advise the other pilot when conditions permit. If the Standby Hydraulic is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Standby Hydraulic advisory is expected to read within the sample range of 45

to 51 units during an extended ground delay. The relief pilot will confirm any change in the Fuel Crossfeed status message and advise the other pilot before the next phase of flight.

Refer to the related topic for additional sample context. The relief pilot will cross-check any change in the Bleed Air Supply selector position and advise the other pilot once the checklist item is complete. The Fire Detection Loop indication is expected to read within the sample range of 24 to 27 units during climb. The Hydraulic System B selector position is expected to read within the sample range of 71 to 74 units during a diversion. If the Speedbrake Handle is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control quantity display is expected to read within the sample range of 86 to 90 units during approach.

CAUTION: The Traffic Advisory Display status message that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.

CAUTION: During cruise, the Captain should monitor the Window Heat advisory when conditions permit. The Fuel Crossfeed switch position is expected to read within the sample range of 82 to 94 units during parking.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

05.60.20 Center Tank Pumps Reset Guidance

This text is fictional and exists only to give the prototype realistic volume and structure. If the Engine Anti-Ice is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. During landing, the pilot flying should announce the Center Tank Pumps advisory once the checklist item is complete. The relief pilot will announce any change in the Probe Heat annunciation and advise the other pilot before the next phase of flight. During engine start, both pilots should record the Transponder switch position before the next phase of flight. The Flap Position Indication status message is expected to read within the sample range of 63 to 74 units during an extended ground delay.

NOTE: The Autothrottle switch position is expected to read within the sample range of 39 to 49 units during takeoff.

- The Landing Gear Indication advisory that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The first officer will confirm any change in the Wing Anti-Ice switch position and advise the other pilot when operating at a sample station without ground power.
- If the Autobrake Selector is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

The pilot monitoring will record any change in the Probe Heat advisory and advise the other pilot when the associated caution light remains illuminated. During approach, the relief pilot should record the Cockpit Voice Recorder selector position if the indication does not stabilize within the sample interval. The first officer will brief any change in the Flight Management Computer indication and advise the other pilot when the associated caution light remains illuminated.

The first officer will monitor any change in the Fire Detection Loop annunciation and advise the other pilot before the next phase of flight. The Window Heat advisory is expected to read within the sample range of 8 to 20 units during an extended ground delay. If the Engine Anti-Ice is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The Engine Anti-Ice quantity display that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed. The Weather Radar quantity display that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed.

The Speedbrake Handle switch position is expected to read within the sample range of 67 to 78 units during descent. The Thrust Reverser switch position that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center. If the Cargo Smoke Detection is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. Both pilots will brief any change in the Brake Temperature Monitor status message and advise the other pilot when conditions permit.

CAUTION: Refer to the related topic for additional sample context. The Bleed Air Supply quantity display that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power.

Challenge	Response
Flight Management Computer	Set
Wing Anti-Ice	Verified
Autothrottle	Set
Hydraulic System B	Set
Landing Gear Indication	Armed
Autothrottle	As required

05.60.21 Cockpit Voice Recorder Overview

The Speedbrake Handle advisory is expected to read within the sample range of 54 to 62 units during descent. If the Autobrake Selector is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will record any change in the Probe Heat selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will select any change in the Hydraulic System A switch position and advise the other pilot if a discrepancy is observed. The captain will confirm any change in the Autobrake Selector indication and advise the other pilot once the checklist item is complete.

- If the Hydraulic System A is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The Fuel Crossfeed status message is expected to read within the sample range of 5 to 16 units during approach.
- The Window Heat annunciation is expected to read within the sample range of 52 to 56 units during preflight.
- The Autopilot Channel B quantity display that differs from the expected state requires the Captain to brief the condition before the next phase of flight.
- During a maintenance-requested ground run, the First Officer should cross-check the Auxiliary Power Unit switch position when conditions permit.
- The Fire Detection Loop selector position is expected to read within the sample range of 47 to 53 units during preflight.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Thrust Reverser is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. See 04.40.12 Flow: Standby Hydraulic.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Landing Gear Indication switch position that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. The captain will select any change in the Fuel Crossfeed switch position and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Bleed Air Supply indication	81 units	Normal
Cargo Smoke Detection switch position	37 units	Monitor
Nosewheel Steering advisory	56 units	Advisory only
Autothrottle status message	43 units	Refer to related topic

Center Tank Pumps quantity display	2 units	Monitor
Autopilot Channel A quantity display	49 units	Monitor
Autopilot Channel B status message	46 units	Normal

Challenge	Response
Autopilot Channel B	Set
Flap Position Indication	Verified
Traffic Advisory Display	Verified
Nosewheel Steering	Checked
Stall Warning	Off
Stall Warning	On
Probe Heat	Verified
Cabin Pressure Controller	Checked
Flap Position Indication	Checked
Probe Heat	Closed
Transponder	Closed
Autopilot Channel B	Closed

05.70 Automatic Flight

05.70.1 Brake Temperature Monitor Limits Display

If the Standby Hydraulic is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication quantity display that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval. During cruise, both pilots should select the Autopilot Channel B advisory if a discrepancy is observed. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Landing Gear Indication indication is expected to read within the sample range of 80 to 88 units during landing.

During a maintenance-requested ground run, the pilot flying should announce the Autobrake Selector annunciation if a discrepancy is observed. The pilot monitoring will announce any change in the Ground Proximity Monitor switch position and advise the other pilot if a discrepancy is observed. During descent, both pilots should announce the Fuel Crossfeed quantity display when conditions permit. If the Transponder is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Bleed Air Supply status message	75 units	Refer to related topic
Engine Anti-Ice advisory	21 units	Advisory only
Probe Heat status message	45 units	Refer to related topic
Probe Heat status message	77 units	Normal
Flap Position Indication indication	73 units	Advisory only
Fire Detection Loop quantity display	52 units	Monitor
Flap Position Indication status message	3 units	Advisory only

Condition	Sample value	Remarks
Standby Instruments selector position	69 units	Refer to related topic
Autopilot Channel B selector position	82 units	Monitor

Standby Instruments quantity display	27 units	Advisory only
Fuel Crossfeed status message	15 units	Normal
Cockpit Voice Recorder selector position	6 units	Advisory only
Probe Heat indication	15 units	Monitor

CAUTION: During takeoff, the pilot flying should confirm the Pack Temperature Control selector position once the checklist item is complete.

Condition	Sample value	Remarks
Thrust Reverser selector position	19 units	Refer to related topic
Stall Warning annunciation	41 units	Refer to related topic
Cockpit Voice Recorder selector position	42 units	Advisory only
Window Heat quantity display	63 units	Advisory only
Autopilot Channel A selector position	27 units	Refer to related topic

Challenge	Response
Fire Detection Loop	Closed
Wing Anti-Ice	Armed
Window Heat	As required
Ground Proximity Monitor	On
Auxiliary Power Unit	Verified
Bleed Air Supply	As required
Primary Electrical Bus	Armed
Oxygen Distribution	On

05.70.2 Flap Position Indication Normal Operation

The wording here is placeholder content shaped like a procedure, not a procedure. If the Flap Position Indication is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. During climb, the Captain should monitor the Auxiliary Power Unit switch position once the checklist item is complete.

During a turnaround, the pilot flying should verify the Cargo Smoke Detection advisory if the indication does not stabilize within the sample interval. During descent, the relief pilot should announce the Autopilot Channel A advisory when operating at a sample station without ground power. The captain will select any change in the Pack Temperature Control annunciation and advise the other pilot when operating at a sample station without ground power.

NOTE: If the Standby Instruments is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Hydraulic status message	8 units	Refer to related topic
Autopilot Channel A status message	57 units	Normal
Nosewheel Steering quantity display	78 units	Advisory only

- The pilot flying will record any change in the Cargo Smoke Detection switch position and advise the other pilot before the next phase of flight.
- The Flap Position Indication quantity display is expected to read within the sample range of 17 to 20 units during a maintenance-requested ground run.

- The pilot flying will announce any change in the Probe Heat status message and advise the other pilot when operating at a sample station without ground power.
- Both pilots will confirm any change in the Oxygen Distribution switch position and advise the other pilot when operating at a sample station without ground power.
- The Fuel Crossfeed indication is expected to read within the sample range of 62 to 67 units during an extended ground delay.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The Thrust Reverser selector position is expected to read within the sample range of 91 to 98 units during approach.

Condition	Sample value	Remarks
Cargo Smoke Detection selector position	65 units	Advisory only
Thrust Reverser quantity display	21 units	Normal
Autopilot Channel B switch position	90 units	Normal
Auxiliary Power Unit quantity display	8 units	Monitor
Transponder switch position	63 units	Monitor

During a diversion, the pilot monitoring should monitor the Probe Heat advisory when the associated caution light remains illuminated. Refer to the related topic for additional sample context. If the Autobrake Selector is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Hydraulic System A status message that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power.

- If the Speedbrake Handle is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.
- During a diversion, the First Officer should record the Landing Gear Indication annunciation if a discrepancy is observed.
- The Cabin Pressure Controller indication that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval.
- During landing, the Captain should announce the Pack Temperature Control indication when conditions permit.
- The Autopilot Channel A annunciation is expected to read within the sample range of 90 to 94 units during taxi.

Challenge	Response
Transponder	On
Fuel Crossfeed	Verified
Standby Instruments	Armed
Stall Warning	Checked
Auxiliary Power Unit	As required
Transponder	On
Pack Temperature Control	Checked
Standby Instruments	Armed
Ground Proximity Monitor	Set
Fire Detection Loop	Off

05.70.3 Stall Warning Interfaces

Values in this manual are invented and must not be used for any operational purpose. During a turnaround, the pilot monitoring should cross-check the Autopilot Channel B advisory once the checklist item is complete. Refer to the related topic for additional sample context. If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Window Heat indication that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. If the Hydraulic System B is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

- During an extended ground delay, both pilots should select the Primary Electrical Bus switch position before the next phase of flight.
- If the Autopilot Channel A is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.
- The Window Heat switch position that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated.
- The Landing Gear Indication selector position is expected to read within the sample range of 60 to 69 units during cruise.
- If the Brake Temperature Monitor is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

NOTE: If the Thrust Reverser is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The Center Tank Pumps indication is expected to read within the sample range of 40 to 52 units during cruise.

NOTE: If the Speedbrake Handle is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

NOTE: The Hydraulic System A advisory that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center. The pilot flying will cross-check any change in the Engine Anti-Ice switch position and advise the other pilot when conditions permit.

During a turnaround, the pilot flying should cross-check the Oxygen Distribution annunciation once the checklist item is complete. The Bleed Air Supply status message that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. During taxi, the relief pilot should verify the Standby Hydraulic switch position if the indication does not stabilize within the sample interval.

The captain will cross-check any change in the Engine Anti-Ice switch position and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. If the Brake Temperature Monitor is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. During parking, the relief pilot should monitor the Autothrottle annunciation when operating at a sample station without ground power.

Challenge	Response
Speedbrake Handle	Armed
Autothrottle	Checked
Autothrottle	On
Standby Instruments	Closed
Standby Instruments	Set
Oxygen Distribution	Checked
Cockpit Voice Recorder	Checked
Oxygen Distribution	Set

05.70.4 Stall Warning Overview

The Standby Instruments indication is expected to read within the sample range of 14 to 26 units during engine start. During preflight, the pilot monitoring should select the Traffic Advisory Display selector position unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The first officer will cross-check any change in the Fire Detection Loop selector position and advise the other pilot when operating at a sample station without ground power. The first officer will cross-check any change in the Brake Temperature Monitor quantity display and advise the other pilot when conditions permit. The pilot flying will select any change in the Probe Heat quantity display and advise the other pilot if a discrepancy is observed.

The Thrust Reverser status message that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. If the Nosewheel Steering is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Ground Proximity Monitor quantity display that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. During parking, the First Officer should cross-check the Transponder status message when the associated caution light remains illuminated.

The Engine Anti-Ice indication that differs from the expected state requires the pilot flying to record the condition before the next phase of flight. If the Probe Heat is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Ground Proximity Monitor annunciation that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Traffic Advisory Display is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Brake Temperature Monitor advisory is expected to read within the sample range of 11 to 22 units during cruise. The relief pilot will record any change in the Auxiliary Power Unit advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flap Position Indication advisory is expected to read within the sample range of 59 to 68 units during taxi.

- The Weather Radar indication is expected to read within the sample range of 62 to 71 units during engine start.
- The Autothrottle advisory that differs from the expected state requires the relief pilot to announce the condition when conditions permit.
- The Cargo Smoke Detection indication is expected to read within the sample range of 92 to 98 units during climb.
- During engine start, the pilot monitoring should record the Fire Detection Loop annunciation once the checklist item is complete.
- During takeoff, the pilot monitoring should monitor the Bleed Air Supply selector position when conditions permit.
- If the Cabin Pressure Controller is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.
- The Flap Position Indication annunciation is expected to read within the sample range of 3 to 10 units during landing.

Condition	Sample value	Remarks
Landing Gear Indication quantity display	93 units	Refer to related topic
Traffic Advisory Display selector position	55 units	Advisory only
Stall Warning status message	4 units	Normal
Cockpit Voice Recorder switch position	30 units	Monitor
Bleed Air Supply advisory	24 units	Advisory only
Speedbrake Handle advisory	79 units	Monitor

The Nosewheel Steering selector position that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed. During taxi, the First Officer should monitor the Center Tank Pumps quantity

display when operating at a sample station without ground power. The Weather Radar annunciation is expected to read within the sample range of 71 to 77 units during a diversion. The Thrust Reverser indication is expected to read within the sample range of 3 to 10 units during engine start. If the Flap Position Indication is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

The relief pilot will confirm any change in the Auxiliary Power Unit status message and advise the other pilot if a discrepancy is observed. The Flap Position Indication switch position is expected to read within the sample range of 57 to 66 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the relief pilot should select the Weather Radar quantity display when operating at a sample station without ground power.

05.70.5 Wing Anti-Ice Reset Guidance

The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control switch position that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, both pilots should brief the Flap Position Indication status message when conditions permit.

Values in this manual are invented and must not be used for any operational purpose. The first officer will brief any change in the Engine Anti-Ice status message and advise the other pilot when conditions permit. During parking, the relief pilot should brief the Thrust Reverser status message when conditions permit.

The first officer will verify any change in the Landing Gear Indication switch position and advise the other pilot before the next phase of flight. The Thrust Reverser status message that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power. During a diversion, both pilots should cross-check the Auxiliary Power Unit switch position when the associated caution light remains illuminated. During descent, the Captain should cross-check the Cargo Smoke Detection advisory if the indication does not stabilize within the sample interval.

During approach, the pilot monitoring should verify the Traffic Advisory Display advisory if a discrepancy is observed. The Hydraulic System B switch position that differs from the expected state requires the Captain to brief the condition before the next phase of flight. The pilot monitoring will record any change in the Weather Radar switch position and advise the other pilot before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel A switch position that differs from the expected state requires the Captain to record the condition if a discrepancy is observed.

NOTE: The Cargo Smoke Detection switch position that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval. The Autobrake Selector advisory is expected to read within the sample range of 78 to 88 units during parking.

CAUTION: The Weather Radar advisory that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.

During a diversion, the relief pilot should announce the Traffic Advisory Display indication before the next phase of flight. The pilot monitoring will confirm any change in the Autopilot Channel A status message and advise the other pilot once the checklist item is complete. During climb, both pilots should record the Stall Warning status message if the indication does not stabilize within the sample interval. The captain will announce any change in the Engine Anti-Ice advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During a maintenance-requested ground run, both pilots should brief the Pack Temperature Control selector position unless directed otherwise by the Sample Operations Center. The Fire Detection Loop status message is expected to read within the sample range of 10 to 18 units during a diversion.

The Hydraulic System A status message that differs from the expected state requires the pilot flying to confirm the condition when conditions permit. During climb, the First Officer should select the Autobrake Selector switch position when operating at a sample station without ground power. Refer to the related topic for additional sample context.

05.70.6 Transponder Status Messages

If the Thrust Reverser is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. During preflight, both pilots should cross-check the Pack Temperature Control switch position when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will record any change in the Thrust Reverser selector position and advise the other pilot before the next phase of flight. The Fire Detection Loop advisory is expected to read within the sample range of 72 to 76 units during engine start.

- If the Stall Warning is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.
- The Autopilot Channel A annunciation is expected to read within the sample range of 51 to 56 units during descent.
- The pilot monitoring will confirm any change in the Cargo Smoke Detection quantity display and advise the other pilot once the checklist item is complete.
- The Pack Temperature Control switch position is expected to read within the sample range of 49 to 54 units during climb.
- During takeoff, the First Officer should cross-check the Autothrottle selector position when conditions permit.

The Autopilot Channel B advisory that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete. During a diversion, the First Officer should announce the Pack Temperature Control status message when conditions permit. If the Probe Heat is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Standby Instruments status message that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center.

The pilot flying will cross-check any change in the Autobrake Selector quantity display and advise the other pilot when the associated caution light remains illuminated. The Flap Position Indication switch position that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed. During a maintenance-requested ground run, the relief pilot should verify the Hydraulic System A status message once the checklist item is complete. Both pilots will record any change in the Pack Temperature Control annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Auxiliary Power Unit switch position that differs from the expected state requires the relief pilot to record the condition before the next phase of flight. If the Standby Instruments is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

- The Thrust Reverser advisory that differs from the expected state requires both pilots to brief the condition once the checklist item is complete.
- The Autobrake Selector advisory that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.
- During an extended ground delay, the First Officer should select the Weather Radar switch position before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Traffic Advisory Display is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

05.70.7 Flight Management Computer Status Messages

During a turnaround, the pilot monitoring should select the Cabin Pressure Controller selector position once the checklist item is complete. The Primary Electrical Bus switch position is expected to read within the sample range of 25 to 34 units during engine start. The Autobrake Selector annunciation is expected to read within the sample range

of 27 to 31 units during descent. During a maintenance-requested ground run, the Captain should record the Window Heat switch position before the next phase of flight.

CAUTION: If the Fuel Crossfeed is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

The Landing Gear Indication status message that differs from the expected state requires the First Officer to monitor the condition once the checklist item is complete. The Transponder advisory is expected to read within the sample range of 37 to 46 units during parking. During an extended ground delay, the relief pilot should monitor the Autopilot Channel A selector position when conditions permit. If the Standby Hydraulic is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. During cruise, the pilot flying should select the Autobrake Selector selector position if the indication does not stabilize within the sample interval.

NOTE: If the Oxygen Distribution is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

NOTE: Refer to the related topic for additional sample context.

The Autopilot Channel B switch position that differs from the expected state requires both pilots to confirm the condition when conditions permit. The captain will verify any change in the Autopilot Channel A status message and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will brief any change in the Standby Instruments status message and advise the other pilot once the checklist item is complete.

The Cargo Smoke Detection indication that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the relief pilot should brief the Fuel Crossfeed switch position if the indication does not stabilize within the sample interval. If the Hydraulic System B is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The relief pilot will verify any change in the Cabin Pressure Controller quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The pilot flying will announce any change in the Autopilot Channel A switch position and advise the other pilot if the indication does not stabilize within the sample interval.

05.70.8 Nosewheel Steering Limits Display

The pilot monitoring will cross-check any change in the Brake Temperature Monitor advisory and advise the other pilot if a discrepancy is observed. The captain will select any change in the Traffic Advisory Display annunciation and advise the other pilot once the checklist item is complete. During preflight, the pilot flying should confirm the Speedbrake Handle annunciation if a discrepancy is observed.

CAUTION: If the Cabin Pressure Controller is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Autothrottle advisory that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

The Cockpit Voice Recorder indication that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. The Thrust Reverser status message that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval. If the Landing Gear Indication is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

During parking, the First Officer should cross-check the Cabin Pressure Controller indication unless directed otherwise by the Sample Operations Center. The Weather Radar status message that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. If the Stall Warning is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

The Bleed Air Supply selector position that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval. The Brake Temperature Monitor quantity display that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. During taxi, the First Officer should monitor the Flight Management Computer quantity display when the associated caution light remains illuminated.

During descent, the relief pilot should cross-check the Bleed Air Supply quantity display when the associated caution light remains illuminated. The Cabin Pressure Controller indication that differs from the expected state requires both pilots to announce the condition when conditions permit. If the Autopilot Channel B is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. During takeoff, the pilot monitoring should announce the Bleed Air Supply selector position if a discrepancy is observed.

05.70.9 Cockpit Voice Recorder Power Sources

The pilot monitoring will select any change in the Bleed Air Supply indication and advise the other pilot when conditions permit. During climb, the First Officer should verify the Autobrake Selector switch position when the associated caution light remains illuminated. During engine start, the First Officer should cross-check the Brake Temperature Monitor quantity display before the next phase of flight. If the Wing Anti-Ice is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Landing Gear Indication selector position is expected to read within the sample range of 16 to 24 units during approach. During descent, the pilot monitoring should verify the Fire Detection Loop annunciation unless directed otherwise by the Sample Operations Center.

- During descent, the pilot flying should cross-check the Fuel Crossfeed quantity display when the associated caution light remains illuminated.
- The Nosewheel Steering selector position that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete.
- If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- The captain will confirm any change in the Fuel Crossfeed selector position and advise the other pilot when conditions permit.
- Refer to the related topic for additional sample context.
- The pilot monitoring will confirm any change in the Probe Heat status message and advise the other pilot when the associated caution light remains illuminated.

The Cabin Pressure Controller advisory that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated. The Cargo Smoke Detection status message is expected to read within the sample range of 44 to 51 units during approach. Values in this manual are invented and must not be used for any operational purpose. The captain will brief any change in the Cargo Smoke Detection annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Oxygen Distribution is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- The Cargo Smoke Detection switch position is expected to read within the sample range of 71 to 76 units during preflight.
- The Nosewheel Steering switch position is expected to read within the sample range of 84 to 89 units during climb.

If the Engine Anti-Ice is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 46 to 58 units during landing. The Cargo Smoke Detection annunciation is expected to read within the sample range of 17 to 23 units during parking. The pilot monitoring will confirm any change in the Transponder selector position and advise the other pilot when conditions permit. The Autothrottle indication is expected to read within the sample range of 14 to 18 units during descent. Refer to the related topic for additional sample context.

- The relief pilot will record any change in the Autopilot Channel A status message and advise the other pilot when conditions permit.
- During a diversion, both pilots should monitor the Transponder quantity display unless directed otherwise by the Sample Operations Center.
- The Autobrake Selector annunciation that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.
- If the Oxygen Distribution is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.
- If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.
- During takeoff, the relief pilot should record the Transponder selector position when the associated caution light remains illuminated.

The Fuel Crossfeed quantity display that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed. The Hydraulic System B advisory is expected to read within the sample range of 85 to 88 units during an extended ground delay. During descent, the relief pilot should announce the Center Tank Pumps quantity display once the checklist item is complete. The pilot flying will announce any change in the Hydraulic System A annunciation and advise the other pilot when the associated caution light remains illuminated. If the Center Tank Pumps is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Primary Electrical Bus annunciation is expected to read within the sample range of 31 to 36 units during engine start.
- During takeoff, both pilots should confirm the Cabin Pressure Controller status message if a discrepancy is observed.
- During taxi, the Captain should record the Autopilot Channel A switch position unless directed otherwise by the Sample Operations Center.

During landing, both pilots should select the Stall Warning advisory if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

Challenge	Response
Engine Anti-Ice	Checked
Auxiliary Power Unit	Verified
Ground Proximity Monitor	Off
Autobrake Selector	Checked
Traffic Advisory Display	As required
Hydraulic System B	Off

Primary Electrical Bus	Armed
Oxygen Distribution	On
Stall Warning	Armed
Flap Position Indication	Armed
Primary Electrical Bus	Set

05.70.10 Traffic Advisory Display Status Messages

The captain will monitor any change in the Window Heat indication and advise the other pilot when conditions permit. The Auxiliary Power Unit indication that differs from the expected state requires the pilot flying to announce the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will brief any change in the Probe Heat selector position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Cabin Pressure Controller indication that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated.
- The Auxiliary Power Unit annunciation that differs from the expected state requires the relief pilot to monitor the condition before the next phase of flight.
- The captain will brief any change in the Pack Temperature Control quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- During engine start, the pilot monitoring should announce the Speedbrake Handle quantity display when operating at a sample station without ground power.
- The Primary Electrical Bus indication that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center.

The Ground Proximity Monitor advisory is expected to read within the sample range of 21 to 32 units during a maintenance-requested ground run. During a turnaround, the pilot monitoring should announce the Cockpit Voice Recorder annunciation when conditions permit. During preflight, the First Officer should brief the Cockpit Voice Recorder status message before the next phase of flight. If the Traffic Advisory Display is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Center Tank Pumps indication is expected to read within the sample range of 13 to 25 units during approach. The Pack Temperature Control annunciation that differs from the expected state requires the relief pilot to verify the condition when conditions permit.

If the Fire Detection Loop is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Traffic Advisory Display switch position is expected to read within the sample range of 28 to 34 units during a diversion. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 2 to 14 units during parking. The first officer will brief any change in the Center Tank Pumps indication and advise the other pilot if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

CAUTION: If the Fire Detection Loop is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The Cargo Smoke Detection annunciation that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval.

Challenge	Response
Stall Warning	Verified
Autopilot Channel A	As required

Transponder	Armed
Auxiliary Power Unit	Off
Autothrottle	Verified
Cabin Pressure Controller	Armed
Autothrottle	Verified
Standby Instruments	Verified
Oxygen Distribution	Checked
Center Tank Pumps	Armed
Landing Gear Indication	Verified
Standby Instruments	Off

05.70.11 Brake Temperature Monitor Normal Operation

During a maintenance-requested ground run, the pilot flying should verify the Pack Temperature Control switch position when the associated caution light remains illuminated. If the Center Tank Pumps is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Standby Instruments status message is expected to read within the sample range of 26 to 31 units during a turnaround. The Autopilot Channel B switch position is expected to read within the sample range of 83 to 88 units during climb. During an extended ground delay, the Captain should cross-check the Stall Warning status message unless directed otherwise by the Sample Operations Center. During a diversion, the First Officer should cross-check the Bleed Air Supply switch position if a discrepancy is observed.

Condition	Sample value	Remarks
Flap Position Indication selector position	28 units	Advisory only
Transponder status message	64 units	Advisory only
Speedbrake Handle switch position	63 units	Normal
Thrust Reverser quantity display	14 units	Normal
Auxiliary Power Unit advisory	76 units	Monitor
Fire Detection Loop switch position	66 units	Monitor

CAUTION: If the Fuel Crossfeed is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

The Flight Management Computer status message is expected to read within the sample range of 79 to 84 units during cruise. If the Transponder is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. If the Window Heat is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will confirm any change in the Thrust Reverser status message and advise the other pilot if a discrepancy is observed.

05.70.12 Wing Anti-Ice Power Sources

If the Autopilot Channel A is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Auxiliary Power Unit switch position that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. If the Probe Heat is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. During parking, the relief pilot should verify the Flight Management Computer status message when conditions permit.

- CAUTION:** This text is fictional and exists only to give the prototype realistic volume and structure.
- NOTE:** The Thrust Reverser selector position is expected to read within the sample range of 73 to 81 units during engine start. During approach, both pilots should confirm the Standby Instruments indication when operating at a sample station without ground power.
- CAUTION:** During landing, the pilot monitoring should verify the Hydraulic System B advisory once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the First Officer should brief the Oxygen Distribution selector position when the associated caution light remains illuminated. The pilot flying will brief any change in the Ground Proximity Monitor advisory and advise the other pilot when operating at a sample station without ground power. If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. If the Window Heat is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

05.70.13 Standby Hydraulic Indications

During taxi, the pilot monitoring should record the Traffic Advisory Display switch position when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Wing Anti-Ice switch position that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. The pilot flying will monitor any change in the Flap Position Indication annunciation and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

The Flight Management Computer selector position is expected to read within the sample range of 2 to 8 units during landing. The first officer will verify any change in the Flight Management Computer advisory and advise the other pilot when the associated caution light remains illuminated. Both pilots will confirm any change in the Probe Heat quantity display and advise the other pilot once the checklist item is complete. The Pack Temperature Control switch position that differs from the expected state requires both pilots to verify the condition before the next phase of flight. During engine start, both pilots should select the Autopilot Channel A annunciation when the associated caution light remains illuminated. The relief pilot will record any change in the Ground Proximity Monitor quantity display and advise the other pilot when conditions permit.

The Autopilot Channel B quantity display that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. The Center Tank Pumps switch position that differs from the expected state requires both pilots to select the condition before the next phase of flight. If the Weather Radar is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During climb, the pilot monitoring should monitor the Cabin Pressure Controller advisory before the next phase of flight. If the Autopilot Channel A is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The Cabin Pressure Controller indication that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated.

The Weather Radar advisory that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. If the Transponder is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Fuel Crossfeed selector position is expected to read within the sample range of 73 to 81 units during a maintenance-requested ground run. The Hydraulic System A switch position that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight. The Primary Electrical Bus selector position that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. If the Fire Detection Loop is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

- CAUTION:** During cruise, both pilots should select the Brake Temperature Monitor quantity display when the associated caution light remains illuminated.

Challenge	Response
Probe Heat	Off

Hydraulic System A	Off
Bleed Air Supply	As required
Pack Temperature Control	Checked
Stall Warning	Set
Probe Heat	Verified
Speedbrake Handle	Armed
Transponder	Off
Autothrottle	Closed

05.70.14 Brake Temperature Monitor Limits Display

The Primary Electrical Bus switch position that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed. The Bleed Air Supply annunciation that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. If the Engine Anti-Ice is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

CAUTION: Both pilots will monitor any change in the Fuel Crossfeed selector position and advise the other pilot once the checklist item is complete. The Cockpit Voice Recorder indication that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autothrottle status message	10 units	Normal
Speedbrake Handle status message	36 units	Monitor
Oxygen Distribution selector position	80 units	Normal
Hydraulic System A indication	44 units	Normal
Wing Anti-Ice status message	61 units	Refer to related topic
Autopilot Channel B selector position	87 units	Normal

CAUTION: The Stall Warning selector position that differs from the expected state requires the Captain to monitor the condition when conditions permit. If the Cabin Pressure Controller is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Hydraulic advisory	29 units	Advisory only
Flap Position Indication quantity display	81 units	Monitor
Autothrottle status message	63 units	Advisory only
Brake Temperature Monitor quantity display	53 units	Advisory only
Autopilot Channel A indication	14 units	Advisory only

CAUTION: During climb, the pilot flying should brief the Primary Electrical Bus quantity display before the next phase of flight.

Condition	Sample value	Remarks
Hydraulic System B quantity display	97 units	Normal
Cockpit Voice Recorder annunciation	95 units	Monitor
Ground Proximity Monitor annunciation	42 units	Normal

If the Autopilot Channel A is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Speedbrake Handle advisory and advise the other pilot when operating at a sample station without ground power. During landing, both pilots should monitor the Flight Management Computer switch position before the next phase of flight. During a maintenance-requested ground run, the relief pilot should announce the Probe Heat selector position if the indication does not stabilize within the sample interval. During takeoff, the relief pilot should cross-check the Cockpit Voice Recorder quantity display if a discrepancy is observed. The Nosewheel Steering status message that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.

05.70.15 Cargo Smoke Detection Power Sources

If the Autobrake Selector is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The pilot flying will confirm any change in the Landing Gear Indication indication and advise the other pilot if a discrepancy is observed. The captain will brief any change in the Speedbrake Handle switch position and advise the other pilot if a discrepancy is observed.

The Autobrake Selector switch position that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. If the Standby Hydraulic is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Primary Electrical Bus indication that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power. If the Auxiliary Power Unit is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

NOTE: During takeoff, the pilot monitoring should announce the Fire Detection Loop switch position before the next phase of flight. During a maintenance-requested ground run, the pilot flying should select the Transponder annunciation once the checklist item is complete.

NOTE: The Ground Proximity Monitor quantity display that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight.

Condition	Sample value	Remarks
Fire Detection Loop switch position	4 units	Normal
Oxygen Distribution annunciation	23 units	Refer to related topic
Hydraulic System A indication	18 units	Normal

The pilot monitoring will record any change in the Primary Electrical Bus selector position and advise the other pilot when conditions permit. If the Stall Warning is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During climb, the pilot monitoring should monitor the Fuel Crossfeed quantity display if the indication does not stabilize within the sample interval. The pilot flying will verify any change in the Transponder indication and advise the other pilot if a discrepancy is observed.

The Stall Warning quantity display is expected to read within the sample range of 48 to 55 units during a turnaround. The Center Tank Pumps annunciation that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. The Cabin Pressure Controller quantity display that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. Both pilots will confirm any change in the Standby Hydraulic advisory and advise the other pilot if the indication does not stabilize within the sample interval. See 11.20.16 Flap Position Indication Limits Display.

Challenge	Response
Bleed Air Supply	On
Stall Warning	On
Nosewheel Steering	Verified
Transponder	Verified

Hydraulic System A	Off
Bleed Air Supply	Set
Thrust Reverser	Checked
Oxygen Distribution	As required
Autopilot Channel A	Off
Autopilot Channel A	On

05.70.16 Fire Detection Loop Test

The captain will cross-check any change in the Standby Instruments quantity display and advise the other pilot when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Window Heat annunciation that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. The Oxygen Distribution switch position that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval. The pilot monitoring will verify any change in the Primary Electrical Bus annunciation and advise the other pilot before the next phase of flight. The pilot monitoring will cross-check any change in the Pack Temperature Control selector position and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: If the Probe Heat is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. During engine start, the pilot flying should monitor the Hydraulic System A selector position if the indication does not stabilize within the sample interval.

CAUTION: The Fire Detection Loop selector position that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete. The pilot flying will confirm any change in the Hydraulic System A quantity display and advise the other pilot when the associated caution light remains illuminated.

During a diversion, both pilots should select the Transponder indication once the checklist item is complete. The Autopilot Channel A annunciation is expected to read within the sample range of 48 to 60 units during descent. The Thrust Reverser status message is expected to read within the sample range of 94 to 99 units during climb.

NOTE: The pilot flying will record any change in the Hydraulic System A annunciation and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Stall Warning annunciation	5 units	Normal
Autothrottle annunciation	20 units	Refer to related topic
Wing Anti-Ice selector position	21 units	Refer to related topic
Primary Electrical Bus status message	30 units	Normal

05.70.17 Cabin Pressure Controller Reset Guidance

If the Window Heat is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will cross-check any change in the Brake Temperature Monitor advisory and advise the other pilot if a discrepancy is observed.

Refer to the related topic for additional sample context. During taxi, the pilot flying should cross-check the Flight Management Computer annunciation unless directed otherwise by the Sample Operations Center. The Window Heat advisory is expected to read within the sample range of 25 to 30 units during a diversion. If the Oxygen Distribution is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. During a diversion, both pilots should record the Transponder indication once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

If the Fire Detection Loop is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. During a turnaround, both pilots should record the Pack Temperature Control switch position when operating at a sample station without ground power. If the Primary Electrical Bus is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. Both pilots will monitor any change in the Stall Warning quantity display and advise the other pilot when operating at a sample station without ground power.

CAUTION: Refer to the related topic for additional sample context. The pilot flying will brief any change in the Hydraulic System B indication and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Hydraulic System A status message	7 units	Normal
Standby Instruments advisory	26 units	Refer to related topic
Wing Anti-Ice quantity display	16 units	Normal
Engine Anti-Ice indication	7 units	Advisory only
Autopilot Channel A annunciation	96 units	Advisory only
Primary Electrical Bus status message	38 units	Refer to related topic
Auxiliary Power Unit switch position	87 units	Normal

The Auxiliary Power Unit indication that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center. During a turnaround, the First Officer should select the Fire Detection Loop annunciation if a discrepancy is observed. The Speedbrake Handle quantity display is expected to read within the sample range of 58 to 70 units during landing.

NOTE: The captain will confirm any change in the Thrust Reverser selector position and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Hydraulic System A selector position that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval.

05.70.18 Speedbrake Handle Power Sources

If the Transponder is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. During a maintenance-requested ground run, the relief pilot should cross-check the Ground Proximity Monitor advisory if a discrepancy is observed. The Ground Proximity Monitor selector position that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure.

The Standby Instruments quantity display that differs from the expected state requires the Captain to cross-check the condition when conditions permit. The relief pilot will confirm any change in the Pack Temperature Control quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. During takeoff, the pilot monitoring should brief the Cockpit Voice Recorder status message once the checklist item is complete. The Engine Anti-Ice quantity display that differs from the expected state requires both pilots to confirm the condition when conditions permit.

The Autopilot Channel A status message that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval. If the Flight Management Computer is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Cargo

Smoke Detection selector position is expected to read within the sample range of 47 to 57 units during descent.

Condition	Sample value	Remarks
Landing Gear Indication status message	75 units	Refer to related topic
Standby Hydraulic annunciation	76 units	Advisory only
Landing Gear Indication quantity display	61 units	Advisory only
Wing Anti-Ice quantity display	58 units	Monitor
Flight Management Computer switch position	53 units	Monitor

If the Weather Radar is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The Bleed Air Supply indication is expected to read within the sample range of 9 to 13 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure.

During climb, both pilots should select the Engine Anti-Ice switch position before the next phase of flight. During a maintenance-requested ground run, the First Officer should confirm the Brake Temperature Monitor indication once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. During engine start, the pilot flying should monitor the Fire Detection Loop selector position unless directed otherwise by the Sample Operations Center. If the Autopilot Channel B is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. See 18.20.9 Autothrottle Limits Display.

Challenge	Response
Nosewheel Steering	Off
Traffic Advisory Display	On
Brake Temperature Monitor	Verified
Speedbrake Handle	Off
Fuel Crossfeed	Closed
Window Heat	Armed
Brake Temperature Monitor	Closed
Fire Detection Loop	Checked
Wing Anti-Ice	Closed

05.70.19 Window Heat Indications

The Cargo Smoke Detection advisory that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. If the Standby Hydraulic is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The Autopilot Channel A indication that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed.

If the Speedbrake Handle is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will verify any change in the Stall Warning switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autobrake Selector quantity display that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. During engine start, the pilot flying should verify the Autopilot Channel A quantity display if the indication does not stabilize within the sample interval.

During cruise, both pilots should monitor the Brake Temperature Monitor selector position unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus advisory that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. The first officer will verify any change in the Oxygen Distribution annunciation and advise the other pilot once the checklist item is complete. The pilot monitoring will verify any change in the Wing Anti-Ice selector position and advise the other pilot when conditions

permit.

Condition	Sample value	Remarks
Landing Gear Indication quantity display	69 units	Refer to related topic
Wing Anti-Ice selector position	17 units	Refer to related topic
Traffic Advisory Display indication	26 units	Monitor
Hydraulic System B quantity display	65 units	Refer to related topic
Brake Temperature Monitor switch position	59 units	Normal
Engine Anti-Ice annunciation	67 units	Normal
Transponder advisory	1 units	Advisory only

Condition	Sample value	Remarks
Standby Instruments switch position	96 units	Monitor
Thrust Reverser advisory	1 units	Refer to related topic
Speedbrake Handle indication	57 units	Monitor
Thrust Reverser selector position	51 units	Monitor

NOTE: Both pilots will brief any change in the Nosewheel Steering indication and advise the other pilot when conditions permit.

If the Wing Anti-Ice is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Cargo Smoke Detection indication that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

The Primary Electrical Bus annunciation that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. The Engine Anti-Ice switch position is expected to read within the sample range of 87 to 90 units during descent. During a maintenance-requested ground run, both pilots should brief the Probe Heat switch position unless directed otherwise by the Sample Operations Center.

The Hydraulic System A annunciation is expected to read within the sample range of 33 to 36 units during parking. This text is fictional and exists only to give the prototype realistic volume and structure. During engine start, the Captain should confirm the Fuel Crossfeed status message once the checklist item is complete. The first officer will cross-check any change in the Autopilot Channel A status message and advise the other pilot once the checklist item is complete. The Cabin Pressure Controller status message that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. The pilot flying will announce any change in the Flap Position Indication advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. See 10.20.10 Auxiliary Power Unit Indications.

05.70.20 Traffic Advisory Display Limits Display

The relief pilot will confirm any change in the Pack Temperature Control selector position and advise the other pilot if a discrepancy is observed. The Fuel Crossfeed switch position that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete. The Hydraulic System A status message that differs from the expected state requires the relief pilot to brief the condition unless directed otherwise by the Sample Operations Center. If the Bleed Air Supply is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Fuel Crossfeed advisory that differs from the expected state requires the Captain to monitor the condition when conditions permit. If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

The Transponder status message is expected to read within the sample range of 57 to 61 units during parking. The Thrust Reverser switch position is expected to read within the sample range of 19 to 30 units during landing. If the

Flight Management Computer is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

- The pilot monitoring will confirm any change in the Oxygen Distribution status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The Landing Gear Indication status message that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete.
- During a diversion, the First Officer should brief the Ground Proximity Monitor annunciation if the indication does not stabilize within the sample interval.
- Both pilots will select any change in the Cargo Smoke Detection status message and advise the other pilot when conditions permit.
- During parking, both pilots should record the Autopilot Channel B status message before the next phase of flight.
- During preflight, the relief pilot should record the Primary Electrical Bus quantity display when conditions permit.
- During an extended ground delay, both pilots should cross-check the Weather Radar status message when operating at a sample station without ground power.
- The Transponder indication is expected to read within the sample range of 26 to 33 units during parking.
- Both pilots will monitor any change in the Wing Anti-Ice advisory and advise the other pilot once the checklist item is complete.
- The Autobrake Selector advisory that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center.
- The Engine Anti-Ice status message is expected to read within the sample range of 81 to 92 units during a maintenance-requested ground run.
- The Primary Electrical Bus indication is expected to read within the sample range of 80 to 90 units during takeoff.

NOTE: If the Hydraulic System A is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Standby Hydraulic quantity display is expected to read within the sample range of 40 to 52 units during climb. The Stall Warning advisory that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. The Autobrake Selector annunciation that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. The Autothrottle status message is expected to read within the sample range of 31 to 43 units during taxi.

CAUTION: The Window Heat annunciation is expected to read within the sample range of 4 to 13 units during taxi.

The Cabin Pressure Controller selector position that differs from the expected state requires both pilots to record the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. During a turnaround, the pilot flying should select the Autobrake Selector annunciation if the indication does not stabilize within the sample interval. The Auxiliary Power Unit status message is expected to read within the sample range of 29 to 40 units during an extended ground delay.

CAUTION: If the Autothrottle is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Oxygen Distribution quantity display and advise the other pilot once the checklist item is complete.

The Wing Anti-Ice advisory that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed. The Auxiliary Power Unit quantity display that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. During landing, the relief pilot should cross-check the Cabin Pressure Controller status message unless directed otherwise by the Sample Operations Center. See 03.30.8 Checklist: Oxygen Distribution.

05.80 Navigation

05.80.1 Flap Position Indication Limits Display

The Hydraulic System A quantity display is expected to read within the sample range of 60 to 65 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder indication is expected to read within the sample range of 64 to 72 units during cruise. During preflight, the pilot flying should verify the Autopilot Channel B status message if the indication does not stabilize within the sample interval. If the Ground Proximity Monitor is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The Autobrake Selector advisory that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated.

- The Stall Warning selector position is expected to read within the sample range of 53 to 59 units during landing.
- During taxi, the pilot monitoring should brief the Traffic Advisory Display status message if a discrepancy is observed.
- The Wing Anti-Ice quantity display that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed.

The captain will record any change in the Landing Gear Indication annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. During a turnaround, both pilots should confirm the Center Tank Pumps status message if a discrepancy is observed. The Hydraulic System B annunciation that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. The Weather Radar annunciation that differs from the expected state requires both pilots to select the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Stall Warning is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle quantity display that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel B selector position that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Brake Temperature Monitor advisory	69 units	Normal
Weather Radar indication	96 units	Normal
Cockpit Voice Recorder switch position	19 units	Refer to related topic
Autopilot Channel A indication	53 units	Monitor
Autopilot Channel A quantity display	91 units	Normal

Condition	Sample value	Remarks
Cabin Pressure Controller indication	45 units	Refer to related topic
Oxygen Distribution indication	25 units	Advisory only
Window Heat indication	38 units	Monitor
Auxiliary Power Unit quantity display	82 units	Advisory only
Speedbrake Handle annunciation	57 units	Monitor
Nosewheel Steering selector position	38 units	Monitor

05.80.2 Oxygen Distribution Status Messages

The Primary Electrical Bus indication is expected to read within the sample range of 20 to 31 units during landing. If the Window Heat is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During a turnaround, the relief pilot should announce the Thrust Reverser selector position if a discrepancy is observed. The Pack Temperature Control selector position that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. The Probe Heat quantity display that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. If the Landing Gear Indication is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

NOTE: If the Ground Proximity Monitor is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: During an extended ground delay, the First Officer should announce the Bleed Air Supply status message before the next phase of flight. The Autothrottle advisory is expected to read within the sample range of 74 to 86 units during a turnaround.

The Fuel Crossfeed selector position that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. The Hydraulic System B annunciation is expected to read within the sample range of 4 to 11 units during takeoff. The first officer will cross-check any change in the Traffic Advisory Display selector position and advise the other pilot when the associated caution light remains illuminated. During taxi, the relief pilot should brief the Standby Instruments indication before the next phase of flight.

During a diversion, the Captain should select the Ground Proximity Monitor indication once the checklist item is complete. During a maintenance-requested ground run, the relief pilot should announce the Speedbrake Handle quantity display when conditions permit. During taxi, the Captain should announce the Autothrottle annunciation when the associated caution light remains illuminated. During taxi, the Captain should announce the Pack Temperature Control status message unless directed otherwise by the Sample Operations Center. The Flap Position Indication advisory is expected to read within the sample range of 88 to 97 units during landing.

Challenge	Response
Cabin Pressure Controller	Checked
Hydraulic System B	Off
Flight Management Computer	As required
Standby Hydraulic	Off
Stall Warning	Armed
Traffic Advisory Display	Off
Flap Position Indication	Verified
Speedbrake Handle	Set
Engine Anti-Ice	On
Weather Radar	Checked
Probe Heat	As required

05.80.3 Cargo Smoke Detection Status Messages

The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, the First Officer should monitor the Engine Anti-Ice selector position once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Wing Anti-Ice selector position that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated.

- The captain will verify any change in the Flight Management Computer switch position and advise the other pilot when conditions permit.
- Refer to the related topic for additional sample context.
- Values in this manual are invented and must not be used for any operational purpose.
- The Center Tank Pumps advisory is expected to read within the sample range of 19 to 22 units during taxi.
- Values in this manual are invented and must not be used for any operational purpose.
- The pilot flying will confirm any change in the Nosewheel Steering quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Autopilot Channel B is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

If the Center Tank Pumps is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Cockpit Voice Recorder status message that differs from the expected state requires the pilot flying to cross-check the condition if a discrepancy is observed. If the Center Tank Pumps is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

- During an extended ground delay, both pilots should monitor the Autobrake Selector indication unless directed otherwise by the Sample Operations Center.
- The Hydraulic System B annunciation is expected to read within the sample range of 64 to 73 units during parking.
- If the Fuel Crossfeed is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- The Cargo Smoke Detection selector position that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight.
- The pilot flying will select any change in the Thrust Reverser quantity display and advise the other pilot once the checklist item is complete.
- The Autopilot Channel A quantity display that differs from the expected state requires the First Officer to cross-check the condition when conditions permit.

The Fire Detection Loop quantity display is expected to read within the sample range of 12 to 23 units during a turnaround. The Hydraulic System B status message that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. The Brake Temperature Monitor annunciation is expected to read within the sample range of 47 to 50 units during climb. The Autopilot Channel B status message is expected to read within the sample range of 46 to 49 units during descent. If the Nosewheel Steering is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Wing Anti-Ice status message	20 units	Normal
Cargo Smoke Detection status message	84 units	Monitor
Wing Anti-Ice indication	27 units	Advisory only

During takeoff, the relief pilot should brief the Center Tank Pumps advisory if the indication does not stabilize within the sample interval. If the Weather Radar is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Standby Instruments status message that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed. The Fuel Crossfeed status message that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power.

05.80.4 Stall Warning Crew Awareness

The Hydraulic System A quantity display that differs from the expected state requires both pilots to record the condition if a discrepancy is observed. Refer to the related topic for additional sample context. The Wing Anti-Ice status message is expected to read within the sample range of 58 to 69 units during descent. The pilot flying will monitor any change in the Pack Temperature Control annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flap Position Indication switch position is expected to read within the sample range of 61 to 67 units during landing. During engine start, the relief pilot should verify the Pack Temperature Control switch position if a discrepancy is observed.

- The relief pilot will announce any change in the Fuel Crossfeed selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Traffic Advisory Display switch position is expected to read within the sample range of 15 to 21 units during an extended ground delay.
- The Transponder quantity display that differs from the expected state requires the First Officer to announce the condition when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Primary Electrical Bus selector position is expected to read within the sample range of 38 to 50 units during approach.

CAUTION: During a turnaround, the pilot monitoring should brief the Window Heat status message when conditions permit. During a diversion, the Captain should verify the Thrust Reverser quantity display when conditions permit.

NOTE: During engine start, the First Officer should verify the Bleed Air Supply selector position if a discrepancy is observed.

Condition	Sample value	Remarks
Engine Anti-Ice indication	36 units	Advisory only
Flight Management Computer quantity display	35 units	Monitor
Standby Instruments annunciation	9 units	Monitor
Thrust Reverser selector position	57 units	Advisory only
Autothrottle switch position	55 units	Refer to related topic
Stall Warning selector position	46 units	Normal

05.80.5 Pack Temperature Control Status Messages

The first officer will verify any change in the Autothrottle indication and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will brief any change in the Engine Anti-Ice advisory and advise the other pilot when conditions permit. The pilot flying will cross-check any change in the Oxygen Distribution quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval.

During engine start, the pilot flying should select the Speedbrake Handle advisory unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. If the Probe Heat is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The pilot flying will announce any change in the Bleed Air Supply selector position and advise the other pilot if a discrepancy is observed.

The Autopilot Channel A indication that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. During preflight, the pilot monitoring should confirm the Auxiliary Power Unit switch

position if a discrepancy is observed. During an extended ground delay, the pilot monitoring should verify the Fire Detection Loop indication when operating at a sample station without ground power. The Landing Gear Indication advisory is expected to read within the sample range of 37 to 42 units during engine start.

Condition	Sample value	Remarks
Flight Management Computer switch position	17 units	Refer to related topic
Window Heat switch position	81 units	Refer to related topic
Cockpit Voice Recorder advisory	1 units	Normal
Auxiliary Power Unit status message	67 units	Normal
Ground Proximity Monitor annunciation	50 units	Monitor
Oxygen Distribution selector position	77 units	Refer to related topic
Auxiliary Power Unit quantity display	12 units	Monitor

- During a maintenance-requested ground run, the pilot flying should record the Cargo Smoke Detection quantity display once the checklist item is complete.
- During engine start, the pilot monitoring should monitor the Oxygen Distribution indication when operating at a sample station without ground power.
- During descent, the relief pilot should verify the Ground Proximity Monitor switch position unless directed otherwise by the Sample Operations Center.
- The Auxiliary Power Unit quantity display is expected to read within the sample range of 59 to 63 units during taxi.
- If the Center Tank Pumps is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Landing Gear Indication quantity display	29 units	Monitor
Flap Position Indication indication	70 units	Refer to related topic
Primary Electrical Bus quantity display	58 units	Normal

- The Standby Instruments selector position is expected to read within the sample range of 5 to 14 units during approach.
- If the Autothrottle is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.
- The Transponder selector position that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight.
- The pilot flying will verify any change in the Autopilot Channel A switch position and advise the other pilot if the indication does not stabilize within the sample interval.

Challenge	Response
Standby Hydraulic	Checked
Wing Anti-Ice	As required
Autopilot Channel A	Verified
Standby Instruments	Verified
Autopilot Channel A	Closed
Window Heat	Set
Landing Gear Indication	As required

Autobrake Selector	Closed
Nosewheel Steering	Armed
Auxiliary Power Unit	Verified
Primary Electrical Bus	Set
Hydraulic System B	Verified

05.80.6 Weather Radar Interfaces

During an extended ground delay, the Captain should announce the Autobrake Selector advisory before the next phase of flight. The Bleed Air Supply quantity display that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed. If the Standby Hydraulic is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

During approach, the relief pilot should monitor the Thrust Reverser quantity display when operating at a sample station without ground power. During descent, the pilot monitoring should record the Wing Anti-Ice advisory once the checklist item is complete. The Oxygen Distribution quantity display that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed. During a diversion, the pilot monitoring should record the Ground Proximity Monitor advisory when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Nosewheel Steering annunciation	23 units	Normal
Center Tank Pumps indication	29 units	Advisory only
Window Heat switch position	67 units	Refer to related topic
Fuel Crossfeed indication	19 units	Refer to related topic
Primary Electrical Bus annunciation	88 units	Normal

During an extended ground delay, the pilot monitoring should monitor the Bleed Air Supply switch position once the checklist item is complete. During an extended ground delay, the relief pilot should brief the Wing Anti-Ice status message unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Fuel Crossfeed advisory and advise the other pilot once the checklist item is complete.

The Nosewheel Steering status message is expected to read within the sample range of 81 to 85 units during approach. Refer to the related topic for additional sample context. During climb, the Captain should record the Center Tank Pumps status message unless directed otherwise by the Sample Operations Center. The Thrust Reverser advisory that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. The Cargo Smoke Detection quantity display is expected to read within the sample range of 28 to 38 units during cruise. The Brake Temperature Monitor annunciation that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure.

During preflight, both pilots should brief the Transponder selector position when conditions permit. Values in this manual are invented and must not be used for any operational purpose. During parking, the pilot monitoring should brief the Wing Anti-Ice annunciation unless directed otherwise by the Sample Operations Center. If the Fire Detection Loop is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. During approach, the relief pilot should verify the Auxiliary Power Unit advisory when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Autothrottle switch position is expected to read within the sample range of 48 to 51 units during cruise. The pilot monitoring will brief any change in the Traffic Advisory Display indication and advise the other

pilot if the indication does not stabilize within the sample interval.

The Autopilot Channel B annunciation is expected to read within the sample range of 59 to 71 units during parking. If the Oxygen Distribution is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will select any change in the Brake Temperature Monitor switch position and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. The first officer will verify any change in the Flight Management Computer advisory and advise the other pilot when operating at a sample station without ground power.

Challenge	Response
Cabin Pressure Controller	Verified
Oxygen Distribution	Armed
Pack Temperature Control	Verified
Window Heat	On
Traffic Advisory Display	Verified
Thrust Reverser	Closed
Speedbrake Handle	As required
Fire Detection Loop	Verified
Center Tank Pumps	Verified
Cockpit Voice Recorder	Armed
Window Heat	As required

05.80.7 Autothrottle Crew Awareness

The first officer will brief any change in the Autopilot Channel A indication and advise the other pilot before the next phase of flight. During a diversion, the pilot monitoring should brief the Autopilot Channel B annunciation when operating at a sample station without ground power. The pilot monitoring will record any change in the Autothrottle switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Brake Temperature Monitor switch position is expected to read within the sample range of 86 to 94 units during approach.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

During a diversion, the pilot monitoring should announce the Fuel Crossfeed advisory unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. During a diversion, the pilot flying should announce the Bleed Air Supply selector position unless directed otherwise by the Sample Operations Center. The Probe Heat switch position that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete. The relief pilot will confirm any change in the Flight Management Computer advisory and advise the other pilot before the next phase of flight. If the Weather Radar is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

CAUTION: The Speedbrake Handle switch position that differs from the expected state requires the First Officer to brief the condition before the next phase of flight.

If the Hydraulic System A is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will verify any change in the Stall Warning quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The Transponder status message is expected to read within the sample range of 53 to

56 units during a maintenance-requested ground run. Both pilots will brief any change in the Stall Warning quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flap Position Indication indication is expected to read within the sample range of 92 to 101 units during parking.

CAUTION: During engine start, the First Officer should monitor the Probe Heat annunciation once the checklist item is complete.

Challenge	Response
Autobrake Selector	Closed
Probe Heat	Checked
Primary Electrical Bus	As required
Window Heat	Off
Brake Temperature Monitor	Closed
Nosewheel Steering	Checked
Landing Gear Indication	As required
Stall Warning	As required
Ground Proximity Monitor	As required

05.80.8 Standby Instruments Status Messages

The first officer will announce any change in the Oxygen Distribution indication and advise the other pilot when operating at a sample station without ground power. The Primary Electrical Bus status message that differs from the expected state requires both pilots to confirm the condition when conditions permit. The first officer will brief any change in the Autothrottle switch position and advise the other pilot when the associated caution light remains illuminated.

Values in this manual are invented and must not be used for any operational purpose. The Pack Temperature Control quantity display is expected to read within the sample range of 39 to 45 units during takeoff. If the Hydraulic System A is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will record any change in the Autopilot Channel B advisory and advise the other pilot before the next phase of flight. The Hydraulic System A indication is expected to read within the sample range of 31 to 41 units during parking.

The Cargo Smoke Detection annunciation is expected to read within the sample range of 90 to 98 units during parking. The Hydraulic System A annunciation is expected to read within the sample range of 19 to 29 units during engine start. During takeoff, the pilot monitoring should announce the Autopilot Channel A indication once the checklist item is complete. If the Engine Anti-Ice is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The relief pilot will brief any change in the Cabin Pressure Controller annunciation and advise the other pilot when the associated caution light remains illuminated. During a turnaround, the relief pilot should select the Standby Instruments annunciation when operating at a sample station without ground power.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will select any change in the Autobrake Selector indication and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

05.80.9 Hydraulic System A Limits Display

During approach, the First Officer should confirm the Probe Heat status message if the indication does not stabilize within the sample interval. The Hydraulic System A indication is expected to read within the sample range of 11 to 19 units during a maintenance-requested ground run. The Bleed Air Supply advisory is expected to read within the sample range of 27 to 30 units during an extended ground delay. The Landing Gear Indication quantity display is

expected to read within the sample range of 72 to 84 units during an extended ground delay. The pilot flying will monitor any change in the Transponder quantity display and advise the other pilot when the associated caution light remains illuminated.

The Primary Electrical Bus indication that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval. During approach, the relief pilot should record the Landing Gear Indication annunciation when conditions permit. The pilot flying will verify any change in the Wing Anti-Ice status message and advise the other pilot once the checklist item is complete. The Fuel Crossfeed advisory that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit. If the Standby Hydraulic is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

NOTE: The captain will select any change in the Autobrake Selector indication and advise the other pilot when conditions permit. The Fuel Crossfeed indication that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Standby Hydraulic switch position	3 units	Advisory only
Hydraulic System B indication	45 units	Normal
Landing Gear Indication quantity display	72 units	Normal
Weather Radar selector position	26 units	Advisory only

The pilot flying will brief any change in the Autobrake Selector annunciation and advise the other pilot once the checklist item is complete. The Hydraulic System B advisory that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

05.80.10 Cargo Smoke Detection Interfaces

If the Stall Warning is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System A advisory is expected to read within the sample range of 29 to 40 units during taxi.

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will verify any change in the Flight Management Computer quantity display and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The Flap Position Indication indication that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight.

NOTE: The pilot flying will confirm any change in the Autobrake Selector switch position and advise the other pilot if a discrepancy is observed. The Speedbrake Handle switch position is expected to read within the sample range of 93 to 99 units during cruise. Values in this manual are invented and must not be used for any operational purpose. During engine start, the relief pilot should select the Hydraulic System A status message unless directed otherwise by the Sample Operations Center. The Autobrake Selector annunciation is expected to read within the sample range of 98 to 106 units during engine start. If the Probe Heat is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

NOTE: During climb, both pilots should record the Hydraulic System B status message when the associated caution light remains illuminated.

CAUTION: The Cargo Smoke Detection selector position is expected to read within the sample range of 40 to 49 units during landing. The Standby Instruments switch position that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated.

NOTE: The pilot monitoring will confirm any change in the Weather Radar status message and advise the other pilot when operating at a sample station without ground power.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The pilot flying will cross-check any change in the Landing Gear Indication status message and advise the other pilot once the checklist item is complete.
- The pilot flying will brief any change in the Cabin Pressure Controller indication and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Brake Temperature Monitor is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.
- Both pilots will select any change in the Primary Electrical Bus advisory and advise the other pilot once the checklist item is complete.

Challenge	Response
Oxygen Distribution	Off
Fire Detection Loop	Set
Thrust Reverser	Verified
Hydraulic System A	As required
Autopilot Channel B	Off
Engine Anti-Ice	Armed
Flight Management Computer	On
Window Heat	As required
Standby Instruments	Armed
Autopilot Channel A	Set

05.80.11 Transponder Crew Awareness

During landing, the Captain should verify the Weather Radar selector position before the next phase of flight. During takeoff, the relief pilot should cross-check the Ground Proximity Monitor selector position when operating at a sample station without ground power. The Autopilot Channel B switch position is expected to read within the sample range of 73 to 78 units during landing. The Center Tank Pumps annunciation that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. If the Engine Anti-Ice is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

The Transponder advisory is expected to read within the sample range of 65 to 75 units during landing. Values in this manual are invented and must not be used for any operational purpose. If the Flap Position Indication is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

- Values in this manual are invented and must not be used for any operational purpose.
- The Window Heat indication is expected to read within the sample range of 46 to 55 units during parking.
- The Engine Anti-Ice advisory is expected to read within the sample range of 93 to 97 units during taxi.

During preflight, both pilots should announce the Weather Radar indication once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection annunciation is expected to read within the sample range of 67 to 74 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will brief any change in the Transponder indication and advise the other pilot when operating at a sample station without ground power. This text is fictional

and exists only to give the prototype realistic volume and structure.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. If the Landing Gear Indication is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

If the Wing Anti-Ice is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. During climb, the First Officer should confirm the Landing Gear Indication selector position before the next phase of flight.

Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will announce any change in the Thrust Reverser switch position and advise the other pilot before the next phase of flight.

CAUTION: The Window Heat annunciation that differs from the expected state requires both pilots to brief the condition when conditions permit. If the Landing Gear Indication is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

Challenge	Response
Center Tank Pumps	Checked
Autopilot Channel A	As required
Hydraulic System B	Set
Wing Anti-Ice	On
Wing Anti-Ice	Closed
Autobrake Selector	Set
Brake Temperature Monitor	Closed
Flight Management Computer	Set
Hydraulic System B	Closed
Nosewheel Steering	Off
Autopilot Channel B	Armed

05.80.12 Fuel Crossfeed Limits Display

The relief pilot will brief any change in the Autobrake Selector selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Autopilot Channel B is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Weather Radar annunciation that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated. The relief pilot will monitor any change in the Autopilot Channel B quantity display and advise the other pilot before the next phase of flight.

The captain will verify any change in the Transponder annunciation and advise the other pilot if a discrepancy is observed. If the Transponder is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During an extended ground delay, the relief pilot should confirm the Cockpit Voice Recorder switch position once the checklist item is complete. The Pack Temperature Control quantity display is expected to read within the sample range of 63 to 70 units during climb. The Fuel Crossfeed advisory that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed.

CAUTION: The Autopilot Channel A indication is expected to read within the sample range of 95 to 99 units during descent.

Condition	Sample value	Remarks
Flap Position Indication annunciation	32 units	Advisory only
Autothrottle switch position	19 units	Normal
Nosewheel Steering advisory	12 units	Advisory only
Standby Instruments status message	14 units	Refer to related topic
Auxiliary Power Unit advisory	60 units	Monitor
Brake Temperature Monitor quantity display	10 units	Monitor
Autopilot Channel B switch position	96 units	Advisory only

CAUTION: During climb, the Captain should confirm the Auxiliary Power Unit annunciation when the associated caution light remains illuminated. The Standby Instruments indication that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete.

- The Hydraulic System A quantity display is expected to read within the sample range of 9 to 13 units during an extended ground delay.
- If the Wing Anti-Ice is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.
- The Autopilot Channel B quantity display is expected to read within the sample range of 39 to 48 units during taxi.

The Oxygen Distribution status message is expected to read within the sample range of 62 to 74 units during taxi. The captain will confirm any change in the Autobrake Selector selector position and advise the other pilot if a discrepancy is observed. Both pilots will select any change in the Traffic Advisory Display quantity display and advise the other pilot before the next phase of flight. During landing, the First Officer should monitor the Pack Temperature Control switch position once the checklist item is complete.

Condition	Sample value	Remarks
Nosewheel Steering switch position	29 units	Monitor
Oxygen Distribution selector position	85 units	Refer to related topic
Cabin Pressure Controller advisory	11 units	Advisory only
Primary Electrical Bus switch position	6 units	Advisory only
Hydraulic System B indication	67 units	Monitor
Stall Warning annunciation	16 units	Normal

The wording here is placeholder content shaped like a procedure, not a procedure. The Wing Anti-Ice advisory that differs from the expected state requires the First Officer to announce the condition when conditions permit. The Flap Position Indication indication that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. The captain will monitor any change in the Hydraulic System A advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed indication is expected to read within the sample range of 7 to 11 units during landing. If the Flap Position Indication is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

05.80.13 Flap Position Indication Indications

The Center Tank Pumps quantity display that differs from the expected state requires the Captain to record the condition before the next phase of flight. The Flap Position Indication switch position that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete. During approach, the Captain should verify the Bleed Air Supply switch position once the checklist item is complete. The Stall Warning status message that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval. During approach, the pilot flying should confirm the Nosewheel Steering

selector position when operating at a sample station without ground power. The Center Tank Pumps selector position is expected to read within the sample range of 50 to 55 units during a diversion.

- The Bleed Air Supply indication is expected to read within the sample range of 63 to 66 units during taxi.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Nosewheel Steering advisory is expected to read within the sample range of 62 to 71 units during a maintenance-requested ground run.
- The pilot flying will announce any change in the Thrust Reverser status message and advise the other pilot when conditions permit.
- The captain will record any change in the Center Tank Pumps indication and advise the other pilot before the next phase of flight.
- During approach, the First Officer should brief the Hydraulic System B indication when the associated caution light remains illuminated.

NOTE: The Transponder advisory that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete.

CAUTION: The Traffic Advisory Display annunciation that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit.

- If the Landing Gear Indication is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.
- The Standby Instruments status message is expected to read within the sample range of 58 to 64 units during takeoff.
- The Stall Warning selector position is expected to read within the sample range of 26 to 30 units during engine start.
- Values in this manual are invented and must not be used for any operational purpose.
- During descent, the pilot flying should select the Speedbrake Handle annunciation before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.

The Transponder quantity display that differs from the expected state requires the First Officer to brief the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the pilot flying should confirm the Ground Proximity Monitor annunciation if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

- The Stall Warning switch position is expected to read within the sample range of 5 to 16 units during an extended ground delay.
- If the Standby Instruments is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.
- If the Hydraulic System A is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

Challenge	Response
Thrust Reverser	Checked
Probe Heat	As required
Center Tank Pumps	Set
Autothrottle	Verified

Autopilot Channel B	Closed
Flap Position Indication	Armed
Flight Management Computer	Checked
Autobrake Selector	As required
Autothrottle	Armed
Ground Proximity Monitor	Checked
Fuel Crossfeed	Armed
Ground Proximity Monitor	Armed

05.80.14 *Flight Management Computer Indications*

The Fire Detection Loop annunciation that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. The captain will select any change in the Hydraulic System A switch position and advise the other pilot when operating at a sample station without ground power. The Landing Gear Indication indication is expected to read within the sample range of 13 to 18 units during climb. During landing, the relief pilot should select the Brake Temperature Monitor indication when the associated caution light remains illuminated.

NOTE: During a diversion, the Captain should announce the Flap Position Indication selector position if a discrepancy is observed. During descent, the pilot flying should select the Oxygen Distribution annunciation when the associated caution light remains illuminated.

NOTE: The Thrust Reverser annunciation that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit. The Ground Proximity Monitor status message that differs from the expected state requires the First Officer to announce the condition when conditions permit.

If the Nosewheel Steering is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Thrust Reverser switch position that differs from the expected state requires the Captain to cross-check the condition when conditions permit. During taxi, the First Officer should select the Cockpit Voice Recorder status message once the checklist item is complete.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: During engine start, the Captain should cross-check the Cabin Pressure Controller indication if the indication does not stabilize within the sample interval.

The Cockpit Voice Recorder selector position is expected to read within the sample range of 53 to 63 units during an extended ground delay. The Standby Instruments annunciation that differs from the expected state requires both pilots to select the condition when conditions permit. The Transponder selector position that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval. If the Hydraulic System A is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

The pilot monitoring will brief any change in the Standby Hydraulic quantity display and advise the other pilot when the associated caution light remains illuminated. If the Ground Proximity Monitor is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Hydraulic System A status message that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit.

Condition	Sample value	Remarks
Transponder annunciation	69 units	Advisory only
Speedbrake Handle advisory	53 units	Refer to related topic
Thrust Reverser selector position	87 units	Monitor
Fire Detection Loop status message	99 units	Advisory only

Auxiliary Power Unit quantity display	81 units	Refer to related topic
Pack Temperature Control quantity display	79 units	Monitor
Fire Detection Loop advisory	84 units	Normal

05.80.15 Center Tank Pumps Crew Awareness

The Flight Management Computer advisory that differs from the expected state requires the pilot flying to announce the condition when conditions permit. During a turnaround, the First Officer should confirm the Flight Management Computer advisory if the indication does not stabilize within the sample interval. The Transponder quantity display that differs from the expected state requires the pilot flying to record the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, both pilots should brief the Cabin Pressure Controller indication once the checklist item is complete.

CAUTION: If the Landing Gear Indication is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

CAUTION: During a diversion, the First Officer should record the Thrust Reverser switch position if the indication does not stabilize within the sample interval. The Landing Gear Indication switch position is expected to read within the sample range of 75 to 83 units during landing.

The Bleed Air Supply annunciation that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Landing Gear Indication switch position that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center. The relief pilot will select any change in the Stall Warning annunciation and advise the other pilot when the associated caution light remains illuminated. The Autothrottle indication that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated.

If the Wing Anti-Ice is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the pilot flying should verify the Primary Electrical Bus indication unless directed otherwise by the Sample Operations Center.

Challenge	Response
Flight Management Computer	Off
Center Tank Pumps	Checked
Bleed Air Supply	On
Ground Proximity Monitor	Verified
Flight Management Computer	Verified
Weather Radar	Set
Hydraulic System B	Off
Autobrake Selector	Closed

05.80.16 Auxiliary Power Unit Status Messages

During landing, the Captain should verify the Weather Radar quantity display when operating at a sample station without ground power. The Engine Anti-Ice switch position that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. If the Autobrake Selector is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

If the Stall Warning is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel B quantity display that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. The Oxygen Distribution

switch position is expected to read within the sample range of 74 to 82 units during taxi. If the Flight Management Computer is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Cargo Smoke Detection annunciation that differs from the expected state requires the pilot monitoring to select the condition when conditions permit.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Cockpit Voice Recorder indication is expected to read within the sample range of 2 to 6 units during climb.

During preflight, the relief pilot should cross-check the Landing Gear Indication selector position when conditions permit. The relief pilot will record any change in the Ground Proximity Monitor indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Speedbrake Handle annunciation is expected to read within the sample range of 37 to 47 units during a maintenance-requested ground run. If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Window Heat quantity display that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete. The Probe Heat indication is expected to read within the sample range of 71 to 78 units during taxi.

The wording here is placeholder content shaped like a procedure, not a procedure. The captain will select any change in the Bleed Air Supply indication and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Flap Position Indication annunciation	80 units	Monitor
Window Heat quantity display	90 units	Monitor
Autopilot Channel B indication	12 units	Normal
Autothrottle quantity display	69 units	Refer to related topic
Pack Temperature Control selector position	46 units	Monitor

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The captain will record any change in the Standby Hydraulic switch position and advise the other pilot when the associated caution light remains illuminated.

05.80.17 Cockpit Voice Recorder Normal Operation

The pilot monitoring will announce any change in the Wing Anti-Ice indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. If the Autobrake Selector is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Center Tank Pumps switch position	36 units	Advisory only
Stall Warning quantity display	88 units	Advisory only
Autothrottle annunciation	32 units	Refer to related topic
Primary Electrical Bus indication	44 units	Normal
Autobrake Selector quantity display	24 units	Normal
Brake Temperature Monitor selector position	80 units	Refer to related topic
Ground Proximity Monitor annunciation	50 units	Advisory only

CAUTION: If the Nosewheel Steering is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Transponder selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: If the Primary Electrical Bus is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

During takeoff, both pilots should brief the Autopilot Channel B status message if a discrepancy is observed. If the Hydraulic System A is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. Both pilots will record any change in the Brake Temperature Monitor switch position and advise the other pilot before the next phase of flight. The pilot monitoring will cross-check any change in the Brake Temperature Monitor switch position and advise the other pilot when conditions permit. The Hydraulic System B switch position is expected to read within the sample range of 46 to 49 units during a maintenance-requested ground run. The Cargo Smoke Detection quantity display that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight.

Challenge	Response
Thrust Reverser	As required
Fuel Crossfeed	As required
Traffic Advisory Display	Armed
Fire Detection Loop	As required
Fire Detection Loop	Off
Center Tank Pumps	Armed
Flap Position Indication	Armed
Transponder	Checked

05.80.18 Bleed Air Supply Power Sources

The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval. The Weather Radar switch position that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated. The Autopilot Channel A indication that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. The Hydraulic System B status message that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. The Wing Anti-Ice status message that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated.

During cruise, the relief pilot should monitor the Primary Electrical Bus annunciation before the next phase of flight. During a maintenance-requested ground run, the pilot monitoring should cross-check the Cockpit Voice Recorder annunciation when the associated caution light remains illuminated. The first officer will announce any change in the Probe Heat annunciation and advise the other pilot before the next phase of flight. During taxi, the Captain should confirm the Cockpit Voice Recorder status message unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice quantity display is expected to read within the sample range of 18 to 21 units during descent.

CAUTION: During descent, the First Officer should announce the Autopilot Channel A annunciation unless directed otherwise by the Sample Operations Center. The pilot monitoring will confirm any change in the Thrust Reverser annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

During cruise, both pilots should select the Autobrake Selector annunciation once the checklist item is complete. The Auxiliary Power Unit quantity display is expected to read within the sample range of 61 to 65 units during descent. If the Brake Temperature Monitor is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The pilot flying will cross-check any change in the Ground Proximity Monitor advisory and advise the other pilot once the checklist item is complete. The first officer will select any change in the Standby Hydraulic advisory and advise the other pilot when conditions permit. During landing, the pilot monitoring should confirm the Standby Hydraulic indication when operating at a sample station without ground power. If the Autopilot Channel A is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. See 07.20.10 Flight Management Computer Status Messages.

Challenge	Response
Flight Management Computer	Closed
Fire Detection Loop	Off
Probe Heat	Set
Speedbrake Handle	On
Standby Instruments	Set
Flight Management Computer	On
Standby Instruments	Off
Autopilot Channel A	Closed
Speedbrake Handle	Closed
Autothrottle	Armed
Hydraulic System B	Off
Standby Hydraulic	As required

05.80.19 Pack Temperature Control Interfaces

If the Standby Hydraulic is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. If the Window Heat is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. During an extended ground delay, the relief pilot should cross-check the Cockpit Voice Recorder selector position before the next phase of flight. If the Hydraulic System B is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The pilot flying will verify any change in the Center Tank Pumps advisory and advise the other pilot before the next phase of flight.

NOTE: The Flap Position Indication annunciation is expected to read within the sample range of 36 to 47 units during a diversion. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: Refer to the related topic for additional sample context.

- The Auxiliary Power Unit indication is expected to read within the sample range of 38 to 44 units during an extended ground delay.
- If the Stall Warning is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The Speedbrake Handle quantity display is expected to read within the sample range of 63 to 74 units during a maintenance-requested ground run.
- If the Speedbrake Handle is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Auxiliary Power Unit status message	97 units	Refer to related topic
Brake Temperature Monitor selector position	2 units	Normal
Cockpit Voice Recorder selector position	89 units	Normal

Wing Anti-Ice status message	94 units	Normal
Engine Anti-Ice indication	98 units	Normal
Cargo Smoke Detection indication	84 units	Normal

During taxi, both pilots should monitor the Oxygen Distribution quantity display before the next phase of flight. The Brake Temperature Monitor advisory that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

During preflight, the pilot monitoring should announce the Standby Hydraulic status message when the associated caution light remains illuminated. If the Engine Anti-Ice is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The Pack Temperature Control selector position is expected to read within the sample range of 85 to 90 units during taxi. If the Auxiliary Power Unit is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

The Autopilot Channel B annunciation that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed. The Hydraulic System A status message is expected to read within the sample range of 87 to 97 units during a maintenance-requested ground run. If the Standby Instruments is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The Ground Proximity Monitor annunciation is expected to read within the sample range of 84 to 91 units during descent.

If the Standby Instruments is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During a diversion, both pilots should verify the Cargo Smoke Detection indication once the checklist item is complete. The relief pilot will select any change in the Thrust Reverser switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autopilot Channel A status message that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval.

05.80.20 Hydraulic System A Indications

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will cross-check any change in the Probe Heat indication and advise the other pilot before the next phase of flight. The Fire Detection Loop switch position that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated.

If the Auxiliary Power Unit is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. Both pilots will verify any change in the Center Tank Pumps annunciation and advise the other pilot once the checklist item is complete. If the Transponder is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. During a maintenance-requested ground run, both pilots should select the Bleed Air Supply annunciation if a discrepancy is observed.

NOTE: The Autopilot Channel B quantity display that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Brake Temperature Monitor indication	35 units	Advisory only
Standby Instruments advisory	6 units	Refer to related topic
Cargo Smoke Detection switch position	72 units	Advisory only
Transponder quantity display	35 units	Advisory only
Autothrottle switch position	4 units	Advisory only

Hydraulic System B status message	22 units	Normal
-----------------------------------	----------	--------

- During cruise, the Captain should verify the Primary Electrical Bus status message unless directed otherwise by the Sample Operations Center.
- During an extended ground delay, the pilot monitoring should verify the Flap Position Indication switch position unless directed otherwise by the Sample Operations Center.
- The captain will confirm any change in the Traffic Advisory Display indication and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Pack Temperature Control selector position that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Bleed Air Supply	Verified
Primary Electrical Bus	As required
Cargo Smoke Detection	Closed
Ground Proximity Monitor	Closed
Probe Heat	Checked
Center Tank Pumps	Checked
Window Heat	Checked
Probe Heat	Off
Transponder	Verified

Chapter 06 Systems: Air Systems

06.10 Description

06.10.1 Landing Gear Indication Overview

The pilot flying will select any change in the Window Heat indication and advise the other pilot if a discrepancy is observed. The Hydraulic System B status message that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. The Wing Anti-Ice advisory is expected to read within the sample range of 58 to 63 units during parking.

The Transponder annunciation that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated. During a maintenance-requested ground run, the pilot flying should verify the Engine Anti-Ice selector position once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Autothrottle annunciation that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. The Flight Management Computer quantity display that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center.

CAUTION: The relief pilot will monitor any change in the Traffic Advisory Display selector position and advise the other pilot once the checklist item is complete.

During descent, the pilot monitoring should brief the Nosewheel Steering switch position unless directed otherwise by the Sample Operations Center. If the Cargo Smoke Detection is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Flap Position Indication annunciation and advise the other pilot once the checklist item is complete. The Engine Anti-Ice selector position that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Autothrottle is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Nosewheel Steering annunciation that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval. The Cabin Pressure Controller indication that differs from the expected state requires the First Officer to verify the condition when conditions permit.

The Landing Gear Indication switch position is expected to read within the sample range of 23 to 35 units during approach. The Transponder indication that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. If the Autothrottle is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector status message is expected to read within the sample range of 97 to 108 units during engine start.

CAUTION: If the Center Tank Pumps is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During approach, the relief pilot should cross-check the Hydraulic System A selector position when the associated caution light remains illuminated.

06.10.2 Ground Proximity Monitor Status Messages

The Standby Hydraulic switch position is expected to read within the sample range of 19 to 24 units during an extended ground delay. During a diversion, the pilot monitoring should confirm the Standby Hydraulic selector position unless directed otherwise by the Sample Operations Center. During taxi, the pilot flying should confirm the Autopilot Channel B selector position when operating at a sample station without ground power. The Weather Radar advisory that differs from the expected state requires the Captain to monitor the condition unless directed otherwise

by the Sample Operations Center. If the Cargo Smoke Detection is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

The Wing Anti-Ice status message is expected to read within the sample range of 5 to 10 units during an extended ground delay. If the Autobrake Selector is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Cabin Pressure Controller selector position is expected to read within the sample range of 52 to 64 units during approach. If the Flight Management Computer is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Cockpit Voice Recorder advisory is expected to read within the sample range of 69 to 81 units during a maintenance-requested ground run.

CAUTION: The Flap Position Indication annunciation is expected to read within the sample range of 49 to 59 units during approach. The Fuel Crossfeed advisory that differs from the expected state requires both pilots to verify the condition once the checklist item is complete.

NOTE: The Flap Position Indication selector position is expected to read within the sample range of 64 to 73 units during descent. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: Refer to the related topic for additional sample context. The Flap Position Indication status message that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power.

NOTE: Refer to the related topic for additional sample context.

The first officer will confirm any change in the Flight Management Computer selector position and advise the other pilot before the next phase of flight. The Center Tank Pumps annunciation is expected to read within the sample range of 54 to 62 units during takeoff. During an extended ground delay, the First Officer should verify the Landing Gear Indication selector position before the next phase of flight. The Nosewheel Steering indication that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. During climb, the relief pilot should brief the Thrust Reverser indication before the next phase of flight. If the Window Heat is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

06.10.3 Standby Hydraulic Reset Guidance

Both pilots will announce any change in the Center Tank Pumps indication and advise the other pilot when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. During cruise, the pilot monitoring should record the Weather Radar indication before the next phase of flight.

Values in this manual are invented and must not be used for any operational purpose. The Window Heat status message that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. If the Engine Anti-Ice is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Oxygen Distribution annunciation is expected to read within the sample range of 97 to 102 units during cruise. Refer to the related topic for additional sample context. The Ground Proximity Monitor annunciation that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps indication is expected to read within the sample range of 85 to 89 units during a diversion. The relief pilot will verify any change in the Engine Anti-Ice switch position and advise the other pilot when operating at a sample station without ground power. See 03.50.1 Briefing: Center Tank Pumps.

Condition	Sample value	Remarks
Engine Anti-Ice switch position	16 units	Monitor
Oxygen Distribution quantity display	4 units	Normal

Primary Electrical Bus annunciation	92 units	Advisory only
Thrust Reverser indication	35 units	Advisory only
Speedbrake Handle selector position	14 units	Monitor
Ground Proximity Monitor status message	35 units	Normal

NOTE: The Fire Detection Loop selector position that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. The Landing Gear Indication status message is expected to read within the sample range of 19 to 31 units during engine start.

06.10.4 Hydraulic System B Limits Display

The Weather Radar quantity display is expected to read within the sample range of 73 to 82 units during takeoff. The pilot flying will verify any change in the Standby Hydraulic advisory and advise the other pilot when the associated caution light remains illuminated. The Hydraulic System B advisory is expected to read within the sample range of 59 to 62 units during a maintenance-requested ground run. During approach, the Captain should record the Autothrottle selector position when the associated caution light remains illuminated.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. During a maintenance-requested ground run, both pilots should cross-check the Brake Temperature Monitor indication when conditions permit.

NOTE: Refer to the related topic for additional sample context.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

During cruise, the pilot flying should monitor the Oxygen Distribution selector position if a discrepancy is observed. If the Cargo Smoke Detection is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Cargo Smoke Detection advisory is expected to read within the sample range of 10 to 22 units during takeoff. During parking, the Captain should brief the Hydraulic System A selector position if a discrepancy is observed. During climb, the Captain should record the Center Tank Pumps quantity display if the indication does not stabilize within the sample interval.

- If the Cockpit Voice Recorder is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The Thrust Reverser annunciation is expected to read within the sample range of 72 to 84 units during engine start.
- The relief pilot will verify any change in the Traffic Advisory Display quantity display and advise the other pilot when the associated caution light remains illuminated.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Transponder is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. Both pilots will record any change in the Flap Position Indication quantity display and advise the other pilot when the associated caution light remains illuminated. During cruise, both pilots should confirm the Bleed Air Supply switch position before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the Captain should record the Standby Instruments indication when the associated caution light remains illuminated.

- The Cabin Pressure Controller advisory is expected to read within the sample range of 82 to 85 units during parking.
- The Standby Instruments advisory is expected to read within the sample range of 90 to 99 units during parking.
- The Cabin Pressure Controller advisory is expected to read within the sample range of 41 to 47 units during engine start.

- If the Traffic Advisory Display is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Thrust Reverser selector position	98 units	Refer to related topic
Hydraulic System B indication	2 units	Refer to related topic
Standby Instruments annunciation	14 units	Advisory only

06.10.5 Landing Gear Indication Overview

The wording here is placeholder content shaped like a procedure, not a procedure. The captain will monitor any change in the Auxiliary Power Unit indication and advise the other pilot when conditions permit. The Hydraulic System B quantity display is expected to read within the sample range of 27 to 38 units during a diversion. During approach, the Captain should cross-check the Wing Anti-Ice switch position unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will announce any change in the Nosewheel Steering selector position and advise the other pilot when operating at a sample station without ground power.

- The Autobrake Selector advisory that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete.
- The Primary Electrical Bus indication is expected to read within the sample range of 21 to 31 units during preflight.
- The Autothrottle selector position that differs from the expected state requires both pilots to confirm the condition before the next phase of flight.
- The Engine Anti-Ice indication is expected to read within the sample range of 42 to 53 units during engine start.
- The Hydraulic System A advisory is expected to read within the sample range of 40 to 46 units during taxi.
- The Standby Hydraulic quantity display that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight.
- The captain will verify any change in the Hydraulic System A advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- The relief pilot will cross-check any change in the Autobrake Selector quantity display and advise the other pilot once the checklist item is complete.
- The Fuel Crossfeed indication that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete.

During approach, the Captain should brief the Fuel Crossfeed selector position if a discrepancy is observed. The Fire Detection Loop selector position is expected to read within the sample range of 83 to 94 units during descent. During climb, the pilot monitoring should announce the Primary Electrical Bus quantity display if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will confirm any change in the Ground Proximity Monitor switch position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Cabin Pressure Controller annunciation	25 units	Normal
Cockpit Voice Recorder status message	63 units	Monitor
Nosewheel Steering indication	66 units	Monitor
Autopilot Channel A annunciation	40 units	Monitor

Condition	Sample value	Remarks
-----------	--------------	---------

Pack Temperature Control switch position	22 units	Monitor
Oxygen Distribution indication	77 units	Refer to related topic
Bleed Air Supply annunciation	60 units	Advisory only
Speedbrake Handle advisory	7 units	Monitor
Bleed Air Supply advisory	90 units	Monitor
Probe Heat status message	85 units	Refer to related topic
Flight Management Computer quantity display	42 units	Normal

NOTE: If the Nosewheel Steering is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The first officer will brief any change in the Primary Electrical Bus selector position and advise the other pilot before the next phase of flight.

NOTE: The relief pilot will monitor any change in the Standby Hydraulic advisory and advise the other pilot when operating at a sample station without ground power. Both pilots will verify any change in the Autopilot Channel B status message and advise the other pilot when the associated caution light remains illuminated.

- The Window Heat quantity display that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed.
- During descent, the pilot flying should cross-check the Ground Proximity Monitor quantity display when the associated caution light remains illuminated.
- During takeoff, both pilots should cross-check the Auxiliary Power Unit indication when operating at a sample station without ground power.
- If the Brake Temperature Monitor is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

06.10.6 Hydraulic System B Indications

The pilot flying will cross-check any change in the Fire Detection Loop selector position and advise the other pilot before the next phase of flight. If the Autobrake Selector is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Probe Heat selector position that differs from the expected state requires the First Officer to verify the condition before the next phase of flight. During a maintenance-requested ground run, both pilots should record the Probe Heat quantity display if a discrepancy is observed. During a maintenance-requested ground run, the Captain should announce the Nosewheel Steering switch position when operating at a sample station without ground power.

- If the Standby Instruments is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- During a turnaround, the pilot flying should select the Autopilot Channel B indication when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The captain will brief any change in the Autothrottle advisory and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, the Captain should verify the Cargo Smoke Detection quantity display once the checklist item is complete. The Autothrottle selector position that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Nosewheel Steering selector position	53 units	Refer to related topic

Brake Temperature Monitor status message	13 units	Monitor
Cabin Pressure Controller switch position	89 units	Advisory only

The pilot monitoring will monitor any change in the Cargo Smoke Detection status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The captain will verify any change in the Nosewheel Steering status message and advise the other pilot if the indication does not stabilize within the sample interval. If the Hydraulic System A is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During landing, the relief pilot should confirm the Flap Position Indication quantity display when the associated caution light remains illuminated. The Hydraulic System B status message is expected to read within the sample range of 13 to 24 units during cruise.

If the Wing Anti-Ice is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will record any change in the Thrust Reverser switch position and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments status message is expected to read within the sample range of 42 to 46 units during engine start.

06.10.7 Autobrake Selector Test

The pilot monitoring will announce any change in the Autopilot Channel B advisory and advise the other pilot if a discrepancy is observed. If the Weather Radar is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Window Heat selector position that differs from the expected state requires the Captain to select the condition if a discrepancy is observed.

NOTE: If the Flap Position Indication is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

- During parking, the pilot monitoring should cross-check the Speedbrake Handle indication when conditions permit.
- During a maintenance-requested ground run, the First Officer should confirm the Fuel Crossfeed status message when the associated caution light remains illuminated.
- If the Speedbrake Handle is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- The captain will verify any change in the Probe Heat selector position and advise the other pilot if a discrepancy is observed.
- Refer to the related topic for additional sample context.

If the Fuel Crossfeed is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Engine Anti-Ice indication that differs from the expected state requires the pilot flying to verify the condition when conditions permit. The Standby Hydraulic status message is expected to read within the sample range of 94 to 102 units during climb.

The pilot monitoring will brief any change in the Probe Heat advisory and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Autobrake Selector quantity display is expected to read within the sample range of 55 to 61 units during cruise. Both pilots will cross-check any change in the Autopilot Channel B indication and advise the other pilot if the indication does not stabilize within the sample interval. The Flap Position Indication status message is expected to read within the sample range of 47 to 51 units during cruise. The Bleed Air Supply status message is expected to read within the sample range of 33 to 40 units during takeoff.

06.10.8 Wing Anti-Ice Interfaces

The Nosewheel Steering advisory is expected to read within the sample range of 20 to 30 units during climb. The Oxygen Distribution selector position is expected to read within the sample range of 95 to 98 units during cruise.

During takeoff, the Captain should record the Hydraulic System A quantity display when conditions permit.

The Landing Gear Indication indication is expected to read within the sample range of 79 to 90 units during engine start. The captain will cross-check any change in the Center Tank Pumps switch position and advise the other pilot once the checklist item is complete. The captain will cross-check any change in the Autothrottle indication and advise the other pilot if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. During engine start, the pilot flying should verify the Wing Anti-Ice selector position when conditions permit.

Condition	Sample value	Remarks
Nosewheel Steering switch position	95 units	Monitor
Bleed Air Supply status message	1 units	Advisory only
Ground Proximity Monitor quantity display	15 units	Refer to related topic
Oxygen Distribution switch position	88 units	Refer to related topic
Window Heat quantity display	61 units	Normal
Weather Radar annunciation	33 units	Normal
Stall Warning selector position	22 units	Normal

NOTE: The Nosewheel Steering advisory that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated.

06.10.9 Thrust Reverser Normal Operation

If the Stall Warning is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. Both pilots will announce any change in the Oxygen Distribution annunciation and advise the other pilot if a discrepancy is observed. The Hydraulic System A selector position is expected to read within the sample range of 73 to 77 units during a maintenance-requested ground run. If the Pack Temperature Control is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

The Auxiliary Power Unit quantity display is expected to read within the sample range of 63 to 73 units during parking. The Transponder switch position is expected to read within the sample range of 34 to 43 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure. The Window Heat status message is expected to read within the sample range of 22 to 32 units during landing. If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Engine Anti-Ice selector position and advise the other pilot if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will verify any change in the Bleed Air Supply switch position and advise the other pilot if a discrepancy is observed. During a turnaround, the Captain should verify the Hydraulic System A switch position when operating at a sample station without ground power.

The Autobrake Selector status message is expected to read within the sample range of 48 to 58 units during an extended ground delay. If the Engine Anti-Ice is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. Both pilots will announce any change in the Autothrottle selector position and advise the other pilot when conditions permit. The Traffic Advisory Display selector position that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. The Stall Warning annunciation is expected to read within the sample range of 42 to 51 units during parking. During takeoff, both pilots should brief the Standby Hydraulic advisory before the next phase of flight.

The Window Heat status message that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power. The Flight Management Computer status message is

expected to read within the sample range of 63 to 73 units during engine start. The Autopilot Channel B annunciation that differs from the expected state requires both pilots to brief the condition once the checklist item is complete. If the Center Tank Pumps is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A status message is expected to read within the sample range of 33 to 45 units during descent.

CAUTION: The Primary Electrical Bus selector position is expected to read within the sample range of 24 to 32 units during landing. The captain will announce any change in the Bleed Air Supply switch position and advise the other pilot if a discrepancy is observed.

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed status message that differs from the expected state requires the Captain to select the condition once the checklist item is complete. The Nosewheel Steering switch position that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. The Flap Position Indication status message that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.

06.10.10 Cargo Smoke Detection Crew Awareness

If the Landing Gear Indication is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. Both pilots will brief any change in the Autopilot Channel B quantity display and advise the other pilot when conditions permit. During an extended ground delay, the pilot monitoring should select the Center Tank Pumps selector position if a discrepancy is observed. During parking, the Captain should verify the Autopilot Channel A quantity display when the associated caution light remains illuminated.

NOTE: The relief pilot will verify any change in the Auxiliary Power Unit status message and advise the other pilot when conditions permit. The pilot monitoring will monitor any change in the Weather Radar annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

During an extended ground delay, the pilot monitoring should select the Thrust Reverser selector position if a discrepancy is observed. The relief pilot will cross-check any change in the Probe Heat advisory and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. If the Speedbrake Handle is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

The Cargo Smoke Detection indication that differs from the expected state requires the First Officer to record the condition once the checklist item is complete. The Nosewheel Steering switch position is expected to read within the sample range of 49 to 54 units during a diversion. The Nosewheel Steering switch position that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval.

NOTE: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Standby Instruments selector position	92 units	Refer to related topic
Autopilot Channel B indication	58 units	Advisory only
Cargo Smoke Detection quantity display	99 units	Advisory only
Thrust Reverser quantity display	8 units	Advisory only
Autopilot Channel A selector position	7 units	Refer to related topic
Thrust Reverser indication	28 units	Monitor

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The relief pilot will monitor any change in the Auxiliary Power Unit selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

06.10.11 Engine Anti-Ice Interfaces

The Flap Position Indication advisory is expected to read within the sample range of 18 to 30 units during preflight. The Flap Position Indication advisory is expected to read within the sample range of 27 to 34 units during landing. During a maintenance-requested ground run, the relief pilot should monitor the Autopilot Channel A switch position if the indication does not stabilize within the sample interval. The Autopilot Channel B selector position is expected to read within the sample range of 64 to 71 units during descent.

The pilot flying will select any change in the Autothrottle annunciation and advise the other pilot when conditions permit. The Hydraulic System A quantity display that differs from the expected state requires the pilot monitoring to monitor the condition when conditions permit. The Hydraulic System A indication that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed.

If the Primary Electrical Bus is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The first officer will record any change in the Engine Anti-Ice switch position and advise the other pilot when operating at a sample station without ground power. The captain will confirm any change in the Flight Management Computer selector position and advise the other pilot once the checklist item is complete.

The pilot monitoring will record any change in the Window Heat status message and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Transponder indication is expected to read within the sample range of 61 to 73 units during an extended ground delay. The Cargo Smoke Detection quantity display that differs from the expected state requires the relief pilot to record the condition before the next phase of flight.

- The pilot flying will record any change in the Cockpit Voice Recorder quantity display and advise the other pilot when operating at a sample station without ground power.
- The Standby Hydraulic annunciation is expected to read within the sample range of 63 to 67 units during engine start.
- If the Weather Radar is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- The pilot flying will confirm any change in the Fuel Crossfeed annunciation and advise the other pilot when conditions permit.

The captain will monitor any change in the Transponder quantity display and advise the other pilot once the checklist item is complete. If the Center Tank Pumps is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The captain will brief any change in the Autothrottle advisory and advise the other pilot when conditions permit. The Cabin Pressure Controller quantity display is expected to read within the sample range of 13 to 22 units during parking. During climb, the relief pilot should monitor the Probe Heat quantity display when conditions permit.

- The Fire Detection Loop switch position that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete.
- During a diversion, the pilot flying should monitor the Speedbrake Handle advisory when the associated caution light remains illuminated.
- The Autobrake Selector annunciation is expected to read within the sample range of 5 to 15 units during descent.
- The pilot monitoring will brief any change in the Transponder quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The Center Tank Pumps indication that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed.

During an extended ground delay, the pilot monitoring should verify the Flap Position Indication advisory when the associated caution light remains illuminated. During a diversion, the Captain should confirm the Autobrake Selector quantity display when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will monitor any change in the Wing Anti-Ice status message and advise the other pilot when conditions permit.

06.10.12 Brake Temperature Monitor Normal Operation

During taxi, the pilot monitoring should monitor the Ground Proximity Monitor switch position unless directed otherwise by the Sample Operations Center. The Oxygen Distribution advisory that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit. During a maintenance-requested ground run, the pilot monitoring should verify the Flap Position Indication quantity display once the checklist item is complete. If the Fire Detection Loop is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Cockpit Voice Recorder status message that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center. If the Brake Temperature Monitor is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

During approach, the pilot flying should verify the Brake Temperature Monitor selector position once the checklist item is complete. The first officer will select any change in the Cabin Pressure Controller advisory and advise the other pilot when operating at a sample station without ground power. The first officer will record any change in the Nosewheel Steering status message and advise the other pilot if the indication does not stabilize within the sample interval. The Flap Position Indication indication that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center. The pilot flying will monitor any change in the Speedbrake Handle status message and advise the other pilot when the associated caution light remains illuminated.

CAUTION: If the Traffic Advisory Display is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Primary Electrical Bus switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Flap Position Indication switch position	23 units	Monitor
Nosewheel Steering selector position	93 units	Normal
Transponder status message	84 units	Normal
Brake Temperature Monitor selector position	89 units	Advisory only
Window Heat switch position	30 units	Advisory only

During a turnaround, the pilot monitoring should verify the Traffic Advisory Display advisory when operating at a sample station without ground power. The captain will cross-check any change in the Center Tank Pumps status message and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel A switch position is expected to read within the sample range of 8 to 15 units during descent.

CAUTION: The Oxygen Distribution annunciation that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed.

The relief pilot will verify any change in the Standby Instruments status message and advise the other pilot before the next phase of flight. During a turnaround, the First Officer should verify the Nosewheel Steering advisory when operating at a sample station without ground power. During taxi, both pilots should confirm the Bleed Air Supply indication when conditions permit. If the Transponder is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any

operational purpose. The first officer will confirm any change in the Bleed Air Supply switch position and advise the other pilot if the indication does not stabilize within the sample interval.

06.10.13 Standby Hydraulic Crew Awareness

The pilot flying will monitor any change in the Hydraulic System B quantity display and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Hydraulic System A indication is expected to read within the sample range of 22 to 30 units during preflight.

Condition	Sample value	Remarks
Oxygen Distribution switch position	9 units	Normal
Center Tank Pumps status message	90 units	Refer to related topic
Landing Gear Indication quantity display	24 units	Monitor
Autopilot Channel A selector position	63 units	Normal

NOTE: During a maintenance-requested ground run, the pilot monitoring should record the Pack Temperature Control quantity display if a discrepancy is observed. If the Autopilot Channel B is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

- The Autothrottle status message that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed.
- The Stall Warning selector position is expected to read within the sample range of 88 to 95 units during parking.
- During a turnaround, the Captain should cross-check the Fuel Crossfeed annunciation when the associated caution light remains illuminated.
- The Probe Heat status message is expected to read within the sample range of 34 to 43 units during a diversion.

NOTE: During takeoff, the pilot flying should brief the Fire Detection Loop annunciation before the next phase of flight. The Cabin Pressure Controller quantity display is expected to read within the sample range of 74 to 83 units during a diversion.

The Cabin Pressure Controller indication is expected to read within the sample range of 61 to 68 units during a maintenance-requested ground run. During descent, both pilots should announce the Ground Proximity Monitor status message once the checklist item is complete. During descent, the pilot flying should verify the Cockpit Voice Recorder advisory before the next phase of flight.

CAUTION: The Traffic Advisory Display advisory that differs from the expected state requires the pilot monitoring to select the condition when conditions permit.

06.10.14 Autobrake Selector Status Messages

If the Landing Gear Indication is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

If the Standby Hydraulic is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The first officer will cross-check any change in the Oxygen Distribution quantity display and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will monitor any change in the Center Tank Pumps status message and advise the other pilot before the next phase of flight. If the Landing Gear Indication is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Autobrake Selector indication is expected to read within the sample range of 31 to

38 units during taxi.

During parking, the pilot flying should verify the Ground Proximity Monitor advisory unless directed otherwise by the Sample Operations Center. During a turnaround, the relief pilot should cross-check the Bleed Air Supply annunciation before the next phase of flight. The Center Tank Pumps status message is expected to read within the sample range of 98 to 101 units during approach. If the Pack Temperature Control is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The relief pilot will announce any change in the Fire Detection Loop advisory and advise the other pilot if a discrepancy is observed.

- The Fire Detection Loop switch position is expected to read within the sample range of 69 to 77 units during takeoff.
- During preflight, the pilot flying should announce the Standby Hydraulic quantity display when operating at a sample station without ground power.
- The Cabin Pressure Controller quantity display is expected to read within the sample range of 77 to 84 units during taxi.

NOTE: During an extended ground delay, the relief pilot should announce the Primary Electrical Bus switch position when conditions permit. The Probe Heat switch position that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete.

CAUTION: The Flight Management Computer status message is expected to read within the sample range of 32 to 40 units during descent.

If the Autothrottle is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will brief any change in the Autobrake Selector advisory and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Pack Temperature Control indication that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power.
- The pilot monitoring will brief any change in the Wing Anti-Ice annunciation and advise the other pilot when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The Brake Temperature Monitor quantity display that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated. If the Flap Position Indication is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Auxiliary Power Unit advisory is expected to read within the sample range of 83 to 89 units during engine start. During climb, the First Officer should verify the Ground Proximity Monitor selector position once the checklist item is complete.

06.10.15 Probe Heat Test

The Thrust Reverser switch position is expected to read within the sample range of 84 to 89 units during a diversion. During landing, the relief pilot should cross-check the Wing Anti-Ice status message if the indication does not stabilize within the sample interval. The captain will record any change in the Wing Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Standby Hydraulic indication that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval. The relief pilot will record any change in the Center Tank Pumps annunciation and advise the other pilot when the associated caution light remains illuminated.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Window Heat is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample

guidance. During engine start, the relief pilot should brief the Auxiliary Power Unit indication when conditions permit. During taxi, the First Officer should select the Nosewheel Steering quantity display when the associated caution light remains illuminated. The Cabin Pressure Controller advisory is expected to read within the sample range of 41 to 46 units during preflight. The Center Tank Pumps annunciation that differs from the expected state requires the relief pilot to record the condition when conditions permit.

The Stall Warning annunciation that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. The first officer will monitor any change in the Hydraulic System B status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will brief any change in the Thrust Reverser status message and advise the other pilot before the next phase of flight. The Standby Instruments quantity display is expected to read within the sample range of 93 to 104 units during preflight.

This text is fictional and exists only to give the prototype realistic volume and structure. The captain will brief any change in the Center Tank Pumps switch position and advise the other pilot before the next phase of flight. If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. During taxi, both pilots should verify the Autopilot Channel A indication if the indication does not stabilize within the sample interval.

If the Autothrottle is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The first officer will monitor any change in the Hydraulic System B advisory and advise the other pilot before the next phase of flight. The Engine Anti-Ice indication that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit.

The Probe Heat advisory is expected to read within the sample range of 80 to 89 units during climb. The Cockpit Voice Recorder switch position is expected to read within the sample range of 82 to 93 units during descent. During climb, the pilot monitoring should brief the Cabin Pressure Controller advisory when operating at a sample station without ground power. During preflight, the First Officer should announce the Stall Warning quantity display when conditions permit. If the Weather Radar is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. During parking, the pilot monitoring should monitor the Engine Anti-Ice quantity display if a discrepancy is observed. See 08.20.15 Hydraulic System B Crew Awareness.

Condition	Sample value	Remarks
Autobrake Selector status message	95 units	Refer to related topic
Cabin Pressure Controller status message	22 units	Normal
Autobrake Selector indication	27 units	Refer to related topic
Center Tank Pumps indication	73 units	Refer to related topic
Autobrake Selector annunciation	2 units	Normal

06.10.16 Hydraulic System A Interfaces

The relief pilot will brief any change in the Fuel Crossfeed quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will select any change in the Cockpit Voice Recorder switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Flight Management Computer quantity display is expected to read within the sample range of 52 to 62 units during parking. The Autopilot Channel B quantity display is expected to read within the sample range of 96 to 106 units during approach.

- The Bleed Air Supply selector position that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Standby Instruments selector position is expected to read within the sample range of 16 to 22 units during engine start.

If the Bleed Air Supply is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During a maintenance-requested ground run, the First Officer should announce the Cargo Smoke Detection quantity display if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, both pilots should monitor the Cargo Smoke Detection selector position unless directed otherwise by the Sample Operations Center. The Weather Radar advisory is expected to read within the sample range of 92 to 98 units during a maintenance-requested ground run. The first officer will cross-check any change in the Oxygen Distribution quantity display and advise the other pilot when operating at a sample station without ground power.

CAUTION: If the Traffic Advisory Display is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Autobrake Selector status message is expected to read within the sample range of 85 to 97 units during approach.

The Weather Radar selector position that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. The Cargo Smoke Detection switch position that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. The pilot flying will announce any change in the Wing Anti-Ice annunciation and advise the other pilot before the next phase of flight.

Both pilots will verify any change in the Autobrake Selector advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Bleed Air Supply advisory that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. The Wing Anti-Ice annunciation that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The first officer will record any change in the Ground Proximity Monitor annunciation and advise the other pilot before the next phase of flight.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

06.20 Controls and Indicators

06.20.1 Cockpit Voice Recorder Power Sources

If the Brake Temperature Monitor is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During takeoff, the pilot monitoring should monitor the Hydraulic System A advisory unless directed otherwise by the Sample Operations Center. The Standby Instruments indication that differs from the expected state requires the pilot flying to brief the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Landing Gear Indication status message	21 units	Advisory only
Auxiliary Power Unit status message	20 units	Monitor
Flight Management Computer switch position	31 units	Advisory only
Flap Position Indication quantity display	77 units	Advisory only
Center Tank Pumps advisory	94 units	Advisory only
Fuel Crossfeed switch position	17 units	Normal
Traffic Advisory Display indication	38 units	Monitor

CAUTION: The Probe Heat indication is expected to read within the sample range of 26 to 32 units during cruise.

Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will verify any change in the Weather Radar advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During a turnaround, the Captain should monitor the Autopilot Channel A annunciation when conditions permit. If the Transponder is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The Oxygen Distribution selector position that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete.

During an extended ground delay, the First Officer should record the Hydraulic System A status message unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Standby Hydraulic status message that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center.

- The Autobrake Selector advisory that differs from the expected state requires both pilots to record the condition before the next phase of flight.
- If the Brake Temperature Monitor is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- During landing, the First Officer should announce the Speedbrake Handle selector position unless directed otherwise by the Sample Operations Center.
- The Landing Gear Indication advisory is expected to read within the sample range of 12 to 21 units during cruise.
- During landing, the pilot flying should record the Autopilot Channel B switch position unless directed otherwise by the Sample Operations Center.
- The captain will monitor any change in the Cockpit Voice Recorder annunciation and advise the other pilot when the associated caution light remains illuminated.

06.20.2 Fire Detection Loop Indications

The Speedbrake Handle switch position is expected to read within the sample range of 25 to 33 units during descent. The Window Heat selector position is expected to read within the sample range of 59 to 69 units during engine start. The Transponder quantity display is expected to read within the sample range of 62 to 67 units during climb.

NOTE: The Stall Warning indication that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval.

If the Stall Warning is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. During landing, the First Officer should announce the Nosewheel Steering selector position once the checklist item is complete. If the Traffic Advisory Display is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Oxygen Distribution annunciation is expected to read within the sample range of 95 to 104 units during engine start. The wording here is placeholder content shaped like a procedure, not a procedure. During descent, the pilot monitoring should monitor the Ground Proximity Monitor annunciation before the next phase of flight.

Refer to the related topic for additional sample context. Both pilots will confirm any change in the Fuel Crossfeed annunciation and advise the other pilot when the associated caution light remains illuminated. Both pilots will monitor any change in the Speedbrake Handle status message and advise the other pilot if a discrepancy is observed. During a maintenance-requested ground run, the pilot flying should verify the Wing Anti-Ice switch position before the next phase of flight. The Brake Temperature Monitor status message that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated. The pilot flying will monitor any change in the Autobrake Selector quantity display and advise the other pilot when the associated caution light remains illuminated.

If the Pack Temperature Control is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The relief pilot will confirm any change in the Autopilot Channel B quantity display and advise the other pilot when the associated caution light remains illuminated. During descent, the pilot monitoring should record the Hydraulic System B selector position unless directed otherwise by the Sample Operations Center. If the Hydraulic System A is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

NOTE: The Nosewheel Steering annunciation is expected to read within the sample range of 82 to 85 units during preflight. The first officer will confirm any change in the Transponder switch position and advise the other pilot when operating at a sample station without ground power.

The Probe Heat quantity display that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. The captain will select any change in the Autopilot Channel A advisory and advise the other pilot if the indication does not stabilize within the sample interval. During takeoff, the pilot flying should cross-check the Nosewheel Steering selector position when conditions permit. During cruise, the pilot flying should cross-check the Ground Proximity Monitor status message when conditions permit.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

06.20.3 Oxygen Distribution Reset Guidance

During climb, the Captain should monitor the Cabin Pressure Controller advisory before the next phase of flight. The Traffic Advisory Display indication that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated. The pilot monitoring will confirm any change in the Autopilot Channel B advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Probe Heat switch position is expected to read within the sample range of 68 to 74 units during parking. The pilot flying will select any change in the Weather Radar status message and advise the other pilot when conditions permit. If the Hydraulic System A is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

The pilot flying will verify any change in the Autopilot Channel A advisory and advise the other pilot when operating at a sample station without ground power. The Nosewheel Steering indication is expected to read within the sample range of 4 to 15 units during descent. The Autopilot Channel A indication that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Cockpit Voice Recorder is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System B indication that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Brake Temperature Monitor indication	18 units	Normal
Speedbrake Handle indication	53 units	Refer to related topic
Fuel Crossfeed status message	9 units	Normal

The Window Heat quantity display that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. If the Weather Radar is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During an extended ground delay, the Captain should brief the Bleed Air Supply status message once the checklist item is complete.

The first officer will record any change in the Brake Temperature Monitor indication and advise the other pilot once the checklist item is complete. The Window Heat indication is expected to read within the sample range of 55 to 63 units during preflight. During landing, the Captain should monitor the Cockpit Voice Recorder quantity display if the indication does not stabilize within the sample interval.

During a diversion, the Captain should verify the Engine Anti-Ice annunciation unless directed otherwise by the Sample Operations Center. During cruise, the pilot flying should brief the Fire Detection Loop switch position when the associated caution light remains illuminated. The relief pilot will verify any change in the Weather Radar selector position and advise the other pilot when operating at a sample station without ground power. The Fuel Crossfeed annunciation is expected to read within the sample range of 89 to 95 units during taxi.

Condition	Sample value	Remarks
Primary Electrical Bus quantity display	76 units	Advisory only
Stall Warning selector position	10 units	Advisory only
Traffic Advisory Display indication	51 units	Normal
Weather Radar quantity display	29 units	Monitor
Hydraulic System B status message	60 units	Normal

Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. The Cargo Smoke Detection advisory that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

06.20.4 Cargo Smoke Detection Reset Guidance

The pilot flying will cross-check any change in the Hydraulic System A status message and advise the other pilot before the next phase of flight. The Autothrottle quantity display is expected to read within the sample range of 40 to 52 units during cruise. During a maintenance-requested ground run, the Captain should brief the Nosewheel Steering switch position once the checklist item is complete. The pilot flying will verify any change in the Stall Warning advisory and advise the other pilot if the indication does not stabilize within the sample interval. If the Fire Detection Loop is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

- If the Bleed Air Supply is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- During approach, the First Officer should brief the Primary Electrical Bus selector position when conditions permit.
- The pilot monitoring will confirm any change in the Center Tank Pumps status message and advise the other pilot when the associated caution light remains illuminated.
- The Standby Instruments indication that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center.
- The captain will cross-check any change in the Standby Instruments selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: If the Nosewheel Steering is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

NOTE: If the Autopilot Channel B is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The relief pilot will monitor any change in the Probe Heat indication and advise the other pilot if the indication does not stabilize within the sample interval.

The first officer will select any change in the Window Heat switch position and advise the other pilot if a discrepancy is observed. During takeoff, the Captain should announce the Standby Instruments selector position when conditions permit. The Thrust Reverser advisory that differs from the expected state requires both pilots to record the condition before the next phase of flight. If the Oxygen Distribution is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. During an extended ground delay, both pilots should monitor the Autobrake Selector selector position if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 37 to 44 units during taxi.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- Values in this manual are invented and must not be used for any operational purpose.
- The captain will select any change in the Brake Temperature Monitor advisory and advise the other pilot if a discrepancy is observed.
- During a maintenance-requested ground run, the Captain should confirm the Center Tank Pumps quantity display before the next phase of flight.
- If the Hydraulic System B is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- During takeoff, both pilots should brief the Probe Heat switch position when conditions permit.
- The Nosewheel Steering quantity display is expected to read within the sample range of 51 to 61 units during an extended ground delay.
- The captain will record any change in the Speedbrake Handle selector position and advise the other pilot when operating at a sample station without ground power.
- The Stall Warning switch position is expected to read within the sample range of 21 to 30 units during descent.
- During parking, the relief pilot should verify the Autothrottle advisory when operating at a sample station without ground power.
- The Auxiliary Power Unit status message is expected to read within the sample range of 49 to 52 units during preflight.

The first officer will monitor any change in the Probe Heat selector position and advise the other pilot once the checklist item is complete. If the Fuel Crossfeed is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

If the Autobrake Selector is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The captain will verify any change in the Primary Electrical Bus switch position and advise the other pilot when conditions permit. The pilot flying will monitor any change in the Cockpit Voice Recorder quantity display and advise the other pilot once the checklist item is complete. If the Autothrottle is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

06.20.5 Thrust Reverser Overview

The Probe Heat indication is expected to read within the sample range of 31 to 37 units during parking. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will brief any change in the Wing Anti-Ice annunciation and advise the other pilot when conditions permit. The Weather Radar advisory is expected to read within the sample range of 79 to 85 units during a diversion. If the Window Heat is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The captain will cross-check any change in the Autopilot Channel A quantity display and advise the other pilot when operating at a sample station without ground power. If the Thrust Reverser is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Brake Temperature Monitor advisory	93 units	Monitor
Probe Heat indication	91 units	Monitor
Fire Detection Loop quantity display	86 units	Advisory only
Standby Instruments switch position	93 units	Advisory only

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

During takeoff, both pilots should verify the Cabin Pressure Controller quantity display if the indication does not stabilize within the sample interval. During an extended ground delay, both pilots should cross-check the Hydraulic System A selector position if a discrepancy is observed. The pilot flying will record any change in the Fuel Crossfeed selector position and advise the other pilot before the next phase of flight. The Center Tank Pumps switch position is expected to read within the sample range of 45 to 54 units during parking. Refer to the related topic for additional sample context.

The Auxiliary Power Unit selector position is expected to read within the sample range of 46 to 51 units during engine start. The Standby Instruments status message that differs from the expected state requires the relief pilot to verify the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Center Tank Pumps annunciation is expected to read within the sample range of 26 to 36 units during descent. During landing, the pilot monitoring should record the Center Tank Pumps switch position if the indication does not stabilize within the sample interval.

06.20.6 Traffic Advisory Display Overview

During climb, the First Officer should announce the Cargo Smoke Detection switch position before the next phase of flight. The pilot flying will monitor any change in the Speedbrake Handle advisory and advise the other pilot if a discrepancy is observed. If the Wing Anti-Ice is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Primary Electrical Bus annunciation is expected to read within the sample range of 81 to 93 units during preflight. The Probe Heat quantity display that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete. The Fire Detection Loop annunciation is expected to read within the sample range of 30 to 33 units during landing.

Condition	Sample value	Remarks
Autobrake Selector status message	20 units	Advisory only
Stall Warning quantity display	23 units	Monitor
Traffic Advisory Display selector position	77 units	Refer to related topic

Condition	Sample value	Remarks
Nosewheel Steering switch position	14 units	Refer to related topic
Wing Anti-Ice annunciation	10 units	Normal
Weather Radar annunciation	28 units	Refer to related topic
Pack Temperature Control advisory	61 units	Monitor
Traffic Advisory Display selector position	55 units	Normal
Cockpit Voice Recorder indication	44 units	Monitor
Transponder advisory	86 units	Refer to related topic

During taxi, the relief pilot should monitor the Hydraulic System A switch position when conditions permit. If the Flap Position Indication is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Primary Electrical Bus indication is expected to read within the sample range of 76 to 84 units during a maintenance-requested ground run. The Pack Temperature Control quantity display that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. The Engine Anti-Ice advisory is expected to read within the sample range of 66 to 75 units during landing.

The Autopilot Channel A status message is expected to read within the sample range of 8 to 13 units during engine start. The Wing Anti-Ice annunciation that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed. The captain will announce any change in the Cargo Smoke Detection status message and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

If the Autobrake Selector is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Nosewheel Steering switch position that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval. During descent, the Captain should cross-check the Flight Management Computer status message once the checklist item is complete. If the Flap Position Indication is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. See 05.50.11 Oxygen Distribution Power Sources.

NOTE: During landing, both pilots should brief the Fire Detection Loop quantity display unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit annunciation is expected to read within the sample range of 66 to 72 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Center Tank Pumps indication	65 units	Advisory only
Transponder advisory	67 units	Advisory only
Cargo Smoke Detection advisory	56 units	Normal
Oxygen Distribution selector position	42 units	Refer to related topic
Landing Gear Indication quantity display	2 units	Refer to related topic
Autobrake Selector annunciation	93 units	Advisory only

06.20.7 Center Tank Pumps Overview

The Oxygen Distribution selector position is expected to read within the sample range of 98 to 109 units during approach. The Window Heat status message is expected to read within the sample range of 76 to 79 units during preflight. Refer to the related topic for additional sample context. During descent, both pilots should verify the Center Tank Pumps selector position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Cockpit Voice Recorder switch position	66 units	Monitor
Engine Anti-Ice indication	63 units	Monitor
Pack Temperature Control selector position	95 units	Normal
Window Heat advisory	13 units	Normal
Standby Hydraulic indication	8 units	Normal
Fire Detection Loop indication	49 units	Advisory only

If the Transponder is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The first officer will brief any change in the Brake Temperature Monitor switch position and advise the other pilot once the checklist item is complete. The pilot monitoring will confirm any change in the Autopilot Channel B selector position and advise the other pilot before the next phase of flight. The Speedbrake Handle indication that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval.

During taxi, both pilots should brief the Autothrottle annunciation before the next phase of flight. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will confirm any change in the Standby Instruments annunciation and advise the other pilot when conditions permit.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Traffic Advisory Display status message is expected to read within the sample range of 49 to 61 units during a turnaround.

The Hydraulic System B quantity display that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. The Weather Radar indication is expected to read

within the sample range of 59 to 65 units during a turnaround. The relief pilot will confirm any change in the Landing Gear Indication annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Probe Heat status message is expected to read within the sample range of 92 to 95 units during a diversion. The Fire Detection Loop selector position that differs from the expected state requires the pilot flying to record the condition before the next phase of flight. The Fuel Crossfeed advisory that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval.

- If the Autopilot Channel A is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- During takeoff, the Captain should verify the Oxygen Distribution selector position before the next phase of flight.
- The first officer will announce any change in the Oxygen Distribution indication and advise the other pilot once the checklist item is complete.

06.20.8 Window Heat Overview

The pilot monitoring will monitor any change in the Wing Anti-Ice advisory and advise the other pilot once the checklist item is complete. The Stall Warning selector position is expected to read within the sample range of 50 to 56 units during engine start. The Flight Management Computer advisory that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete. The Speedbrake Handle advisory that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. The first officer will cross-check any change in the Pack Temperature Control indication and advise the other pilot when the associated caution light remains illuminated.

The pilot monitoring will verify any change in the Hydraulic System B quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The captain will announce any change in the Center Tank Pumps switch position and advise the other pilot when the associated caution light remains illuminated. Both pilots will confirm any change in the Thrust Reverser switch position and advise the other pilot when conditions permit. The Traffic Advisory Display indication that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. The Standby Hydraulic quantity display that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed.

During descent, the relief pilot should announce the Ground Proximity Monitor indication before the next phase of flight. During a diversion, the Captain should record the Flight Management Computer switch position once the checklist item is complete. The Fire Detection Loop annunciation that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Flap Position Indication quantity display	28 units	Monitor
Wing Anti-Ice status message	58 units	Monitor
Oxygen Distribution annunciation	58 units	Advisory only
Cockpit Voice Recorder quantity display	66 units	Refer to related topic
Wing Anti-Ice advisory	33 units	Normal
Cabin Pressure Controller advisory	61 units	Normal
Stall Warning selector position	26 units	Monitor

If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The first officer will brief any change in the Stall Warning selector position and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. During a turnaround, the pilot flying should verify the Center Tank Pumps selector position when the associated caution light remains illuminated. The first officer will select any change in the Primary Electrical Bus status message and advise the other pilot when conditions permit. If the Fire

Detection Loop is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The Cargo Smoke Detection annunciation that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight. During a diversion, the Captain should select the Primary Electrical Bus advisory once the checklist item is complete.

NOTE: If the Weather Radar is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

06.20.9 Stall Warning Overview

If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Fuel Crossfeed quantity display is expected to read within the sample range of 26 to 35 units during descent. The Hydraulic System B indication that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. If the Speedbrake Handle is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The first officer will verify any change in the Standby Instruments annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The Primary Electrical Bus selector position that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

If the Window Heat is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Speedbrake Handle selector position is expected to read within the sample range of 18 to 26 units during approach. The Flap Position Indication status message is expected to read within the sample range of 96 to 102 units during engine start. The captain will monitor any change in the Oxygen Distribution quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

During a maintenance-requested ground run, the pilot flying should brief the Cockpit Voice Recorder selector position unless directed otherwise by the Sample Operations Center. During landing, the pilot monitoring should monitor the Oxygen Distribution annunciation once the checklist item is complete. The Fuel Crossfeed switch position that differs from the expected state requires the First Officer to announce the condition when conditions permit. The Bleed Air Supply selector position that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete. The relief pilot will monitor any change in the Ground Proximity Monitor quantity display and advise the other pilot once the checklist item is complete.

NOTE: If the Autopilot Channel A is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Instruments selector position	38 units	Advisory only
Autobrake Selector status message	95 units	Normal
Fuel Crossfeed advisory	51 units	Refer to related topic
Flap Position Indication switch position	40 units	Advisory only
Auxiliary Power Unit selector position	65 units	Normal
Engine Anti-Ice status message	19 units	Refer to related topic

06.20.10 Autothrottle Crew Awareness

The Ground Proximity Monitor advisory is expected to read within the sample range of 89 to 96 units during engine start. During cruise, the relief pilot should monitor the Autobrake Selector selector position before the next phase of flight. The Bleed Air Supply advisory is expected to read within the sample range of 72 to 79 units during engine start. The Window Heat selector position is expected to read within the sample range of 90 to 101 units during takeoff. If the Bleed Air Supply is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Nosewheel Steering annunciation that differs from the expected state requires the pilot monitoring to record the condition when conditions permit.

CAUTION: The Hydraulic System B switch position is expected to read within the sample range of 6 to 15 units during a maintenance-requested ground run. If the Bleed Air Supply is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

During climb, the First Officer should confirm the Fuel Crossfeed selector position once the checklist item is complete. The Autopilot Channel A quantity display is expected to read within the sample range of 22 to 34 units during a maintenance-requested ground run. Values in this manual are invented and must not be used for any operational purpose. During preflight, the relief pilot should verify the Fuel Crossfeed quantity display if a discrepancy is observed. During approach, the pilot flying should brief the Autopilot Channel A switch position before the next phase of flight. The first officer will select any change in the Window Heat advisory and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Standby Hydraulic annunciation is expected to read within the sample range of 15 to 27 units during descent. The Stall Warning advisory that differs from the expected state requires the First Officer to verify the condition when conditions permit.

- The relief pilot will verify any change in the Fuel Crossfeed advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Standby Instruments switch position is expected to read within the sample range of 80 to 87 units during landing.
- The first officer will cross-check any change in the Autobrake Selector annunciation and advise the other pilot when operating at a sample station without ground power.
- During approach, the Captain should select the Oxygen Distribution annunciation when operating at a sample station without ground power.
- If the Standby Instruments is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

During takeoff, both pilots should monitor the Window Heat selector position when conditions permit. The captain will confirm any change in the Fire Detection Loop switch position and advise the other pilot once the checklist item is complete. The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power.

NOTE: If the Autobrake Selector is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

The Autopilot Channel B quantity display is expected to read within the sample range of 71 to 77 units during preflight. During parking, the relief pilot should announce the Flight Management Computer switch position when the associated caution light remains illuminated. The Standby Instruments switch position that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.

06.20.11 Autothrottle Crew Awareness

During taxi, the relief pilot should confirm the Bleed Air Supply quantity display when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. If the Cargo Smoke Detection is inoperative, continue a diversion only after both pilots has reviewed the associated sample

guidance.

During climb, the pilot flying should verify the Autothrottle advisory when operating at a sample station without ground power. During taxi, both pilots should select the Bleed Air Supply switch position when the associated caution light remains illuminated. If the Ground Proximity Monitor is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The Stall Warning quantity display is expected to read within the sample range of 60 to 66 units during takeoff. During approach, the relief pilot should verify the Flap Position Indication advisory once the checklist item is complete. If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Window Heat selector position that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated. If the Brake Temperature Monitor is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

During a diversion, the Captain should record the Wing Anti-Ice annunciation once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. During climb, the First Officer should confirm the Hydraulic System A status message before the next phase of flight. Refer to the related topic for additional sample context. The Standby Instruments indication is expected to read within the sample range of 33 to 39 units during landing.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will verify any change in the Autopilot Channel B quantity display and advise the other pilot when operating at a sample station without ground power.

The Window Heat status message is expected to read within the sample range of 89 to 100 units during climb. If the Cockpit Voice Recorder is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. During preflight, the First Officer should record the Ground Proximity Monitor advisory once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

NOTE: During a maintenance-requested ground run, the Captain should select the Stall Warning indication if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

06.20.12 Landing Gear Indication Reset Guidance

This text is fictional and exists only to give the prototype realistic volume and structure. If the Autothrottle is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Thrust Reverser annunciation is expected to read within the sample range of 79 to 87 units during descent. The Fuel Crossfeed advisory is expected to read within the sample range of 80 to 83 units during an extended ground delay.

If the Center Tank Pumps is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Cabin Pressure Controller status message that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. The Ground Proximity Monitor advisory that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed annunciation is expected to read within the sample range of 75 to 78 units during taxi. The first officer will record any change in the Autobrake Selector switch position and advise the other pilot before the next phase of flight. If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	52 units	Monitor
Autopilot Channel B selector position	17 units	Normal
Probe Heat status message	80 units	Refer to related topic

Autothrottle advisory	91 units	Advisory only
-----------------------	----------	---------------

CAUTION: The Cabin Pressure Controller selector position that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. The Brake Temperature Monitor annunciation that differs from the expected state requires the First Officer to brief the condition when conditions permit.

Condition	Sample value	Remarks
Hydraulic System A selector position	69 units	Monitor
Transponder advisory	4 units	Advisory only
Cargo Smoke Detection quantity display	5 units	Advisory only
Hydraulic System A indication	16 units	Monitor
Autopilot Channel A indication	51 units	Normal

Refer to the related topic for additional sample context. If the Ground Proximity Monitor is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. During climb, the First Officer should verify the Fire Detection Loop selector position when the associated caution light remains illuminated. During cruise, the Captain should verify the Autobrake Selector selector position if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

- If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- If the Engine Anti-Ice is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.
- The Bleed Air Supply switch position that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed.

If the Autopilot Channel A is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer indication that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed. The pilot monitoring will monitor any change in the Engine Anti-Ice indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller selector position that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated.

- The Flap Position Indication quantity display that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Autothrottle selector position is expected to read within the sample range of 26 to 30 units during landing.
- Values in this manual are invented and must not be used for any operational purpose.
- The captain will brief any change in the Speedbrake Handle quantity display and advise the other pilot if a discrepancy is observed.

06.20.13 Flap Position Indication Crew Awareness

The Nosewheel Steering annunciation that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control indication that differs from the expected state requires both pilots to record the condition before the next phase of flight. The Flight Management Computer quantity display that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed. Refer to the related topic for additional sample context. If the Oxygen Distribution is inoperative, continue

descent only after the pilot monitoring has reviewed the associated sample guidance.

If the Primary Electrical Bus is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. During takeoff, both pilots should record the Speedbrake Handle advisory when operating at a sample station without ground power. The Fire Detection Loop selector position that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. If the Fuel Crossfeed is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

If the Fire Detection Loop is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Hydraulic System B is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During approach, both pilots should cross-check the Auxiliary Power Unit annunciation unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. The Brake Temperature Monitor indication is expected to read within the sample range of 8 to 17 units during a turnaround. During an extended ground delay, the relief pilot should select the Traffic Advisory Display status message unless directed otherwise by the Sample Operations Center. The Standby Instruments status message is expected to read within the sample range of 54 to 59 units during taxi.

Condition	Sample value	Remarks
Standby Hydraulic advisory	28 units	Monitor
Wing Anti-Ice advisory	54 units	Advisory only
Hydraulic System B status message	84 units	Advisory only
Probe Heat selector position	52 units	Monitor

If the Probe Heat is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Wing Anti-Ice indication is expected to read within the sample range of 89 to 101 units during parking. If the Standby Instruments is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autobrake Selector annunciation	76 units	Normal
Transponder annunciation	51 units	Advisory only
Nosewheel Steering status message	19 units	Normal
Standby Hydraulic indication	49 units	Monitor
Landing Gear Indication status message	68 units	Advisory only
Stall Warning annunciation	50 units	Normal
Oxygen Distribution annunciation	16 units	Normal

06.20.14 Weather Radar Status Messages

The Flap Position Indication advisory that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. If the Hydraulic System B is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

- The Oxygen Distribution annunciation is expected to read within the sample range of 86 to 93 units during parking.
- If the Wing Anti-Ice is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

- Values in this manual are invented and must not be used for any operational purpose.
- If the Flight Management Computer is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

CAUTION: If the Standby Instruments is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Hydraulic System B quantity display	44 units	Monitor
Speedbrake Handle annunciation	48 units	Refer to related topic
Flap Position Indication selector position	29 units	Refer to related topic
Thrust Reverser annunciation	67 units	Normal
Auxiliary Power Unit quantity display	24 units	Refer to related topic
Window Heat switch position	82 units	Refer to related topic
Thrust Reverser selector position	7 units	Refer to related topic

The Fuel Crossfeed indication that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. The captain will confirm any change in the Engine Anti-Ice annunciation and advise the other pilot when conditions permit. During a turnaround, the Captain should monitor the Brake Temperature Monitor annunciation once the checklist item is complete. The Fuel Crossfeed selector position is expected to read within the sample range of 34 to 42 units during parking. Refer to the related topic for additional sample context.

During preflight, both pilots should select the Standby Hydraulic annunciation if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will confirm any change in the Window Heat quantity display and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. See 14.10.4 Stall Warning Crew Awareness.

Condition	Sample value	Remarks
Weather Radar indication	62 units	Advisory only
Autopilot Channel B status message	82 units	Normal
Flap Position Indication quantity display	28 units	Monitor

06.20.15 Stall Warning Overview

The Traffic Advisory Display selector position that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit. During a maintenance-requested ground run, the pilot flying should cross-check the Transponder advisory when the associated caution light remains illuminated. During parking, the pilot flying should cross-check the Thrust Reverser selector position if the indication does not stabilize within the sample interval. During cruise, the relief pilot should brief the Ground Proximity Monitor status message when the associated caution light remains illuminated.

The relief pilot will announce any change in the Center Tank Pumps annunciation and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. During cruise, the pilot flying should select the Landing Gear Indication quantity display if a discrepancy is observed.

- The Ground Proximity Monitor quantity display that differs from the expected state requires the relief pilot to record the condition before the next phase of flight.

- During a diversion, the pilot flying should brief the Cabin Pressure Controller selector position if the indication does not stabilize within the sample interval.
- The first officer will brief any change in the Bleed Air Supply quantity display and advise the other pilot if a discrepancy is observed.
- The Wing Anti-Ice annunciation that differs from the expected state requires the Captain to record the condition when conditions permit.
- The relief pilot will announce any change in the Autobrake Selector annunciation and advise the other pilot if a discrepancy is observed.
- If the Transponder is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

NOTE: If the Nosewheel Steering is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: During approach, the pilot flying should brief the Hydraulic System B switch position if a discrepancy is observed. The Pack Temperature Control selector position is expected to read within the sample range of 73 to 77 units during a turnaround.

The Hydraulic System B status message that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight. During taxi, the First Officer should announce the Cargo Smoke Detection selector position when the associated caution light remains illuminated. If the Engine Anti-Ice is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. During preflight, the pilot monitoring should confirm the Fuel Crossfeed indication if a discrepancy is observed.

06.20.16 Bleed Air Supply Reset Guidance

The Thrust Reverser status message that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. During descent, the relief pilot should verify the Autopilot Channel B indication when conditions permit. If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Pack Temperature Control is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

The Speedbrake Handle selector position that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. The Landing Gear Indication advisory is expected to read within the sample range of 80 to 85 units during engine start. During landing, the relief pilot should monitor the Thrust Reverser status message once the checklist item is complete.

CAUTION: If the Standby Hydraulic is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. The pilot monitoring will confirm any change in the Cockpit Voice Recorder switch position and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Cockpit Voice Recorder selector position that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. See 05.10.4 Center Tank Pumps Limits Display.

NOTE: The first officer will announce any change in the Speedbrake Handle advisory and advise the other pilot before the next phase of flight. The Ground Proximity Monitor switch position that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.

06.30 Operation

06.30.1 Autothrottle Test

The Probe Heat status message is expected to read within the sample range of 68 to 72 units during takeoff. The Stall Warning annunciation is expected to read within the sample range of 30 to 38 units during descent. The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle selector position is expected to read within the sample range of 54 to 57 units during a turnaround. If the Hydraulic System A is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

If the Hydraulic System B is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Stall Warning quantity display is expected to read within the sample range of 13 to 20 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. During approach, the relief pilot should record the Fire Detection Loop advisory if a discrepancy is observed. The Bleed Air Supply quantity display that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Bleed Air Supply status message is expected to read within the sample range of 45 to 48 units during a maintenance-requested ground run. Both pilots will announce any change in the Stall Warning selector position and advise the other pilot when conditions permit.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The pilot flying will confirm any change in the Engine Anti-Ice indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Brake Temperature Monitor is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- The Standby Instruments switch position is expected to read within the sample range of 14 to 26 units during taxi.

NOTE: The pilot flying will monitor any change in the Brake Temperature Monitor indication and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

The Autobrake Selector annunciation that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed. The Landing Gear Indication quantity display that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center. The relief pilot will announce any change in the Weather Radar annunciation and advise the other pilot if a discrepancy is observed. During cruise, the First Officer should announce the Bleed Air Supply indication before the next phase of flight.

- The Autothrottle selector position is expected to read within the sample range of 28 to 38 units during cruise.
- During approach, the relief pilot should select the Nosewheel Steering quantity display if the indication does not stabilize within the sample interval.
- During approach, the pilot monitoring should cross-check the Weather Radar indication if a discrepancy is observed.

NOTE: Refer to the related topic for additional sample context.

06.30.2 Flight Management Computer Reset Guidance

During a maintenance-requested ground run, both pilots should brief the Center Tank Pumps status message once the checklist item is complete. During parking, the Captain should brief the Autobrake Selector advisory before the next phase of flight. The Bleed Air Supply selector position that differs from the expected state requires the pilot flying

to monitor the condition when the associated caution light remains illuminated. The Ground Proximity Monitor quantity display is expected to read within the sample range of 94 to 105 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the Captain should announce the Probe Heat selector position when conditions permit.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- During approach, the pilot monitoring should verify the Hydraulic System B advisory unless directed otherwise by the Sample Operations Center.
- The pilot monitoring will brief any change in the Weather Radar advisory and advise the other pilot before the next phase of flight.

NOTE: During a diversion, the Captain should brief the Hydraulic System B quantity display when the associated caution light remains illuminated. The Cargo Smoke Detection status message is expected to read within the sample range of 94 to 106 units during a turnaround. Refer to the related topic for additional sample context. If the Primary Electrical Bus is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The Autothrottle quantity display is expected to read within the sample range of 13 to 16 units during cruise.

Condition	Sample value	Remarks
Flight Management Computer switch position	57 units	Normal
Primary Electrical Bus selector position	13 units	Monitor
Stall Warning advisory	24 units	Normal
Pack Temperature Control advisory	84 units	Refer to related topic
Cockpit Voice Recorder selector position	55 units	Monitor
Pack Temperature Control switch position	10 units	Refer to related topic
Transponder annunciation	42 units	Monitor

- Both pilots will brief any change in the Pack Temperature Control selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Speedbrake Handle advisory that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete.
- The relief pilot will announce any change in the Bleed Air Supply quantity display and advise the other pilot when conditions permit.
- The Hydraulic System A annunciation is expected to read within the sample range of 45 to 50 units during taxi.
- The pilot flying will verify any change in the Standby Instruments quantity display and advise the other pilot before the next phase of flight.
- During approach, the relief pilot should monitor the Autopilot Channel B indication once the checklist item is complete.

06.30.3 Fire Detection Loop Test

The pilot monitoring will brief any change in the Autopilot Channel A annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. If the Standby Instruments is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Speedbrake Handle indication is expected to read within the sample range of 19 to 29 units during a turnaround. Both pilots will brief any change in the Brake Temperature Monitor annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Flight Management Computer is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Wing Anti-Ice indication is expected to read within the sample range of 42 to 53 units during taxi. If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

If the Hydraulic System A is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will record any change in the Primary Electrical Bus annunciation and advise the other pilot if a discrepancy is observed. The Engine Anti-Ice advisory is expected to read within the sample range of 85 to 90 units during a maintenance-requested ground run. The pilot flying will brief any change in the Flap Position Indication selector position and advise the other pilot when conditions permit. During preflight, the pilot flying should brief the Window Heat annunciation when the associated caution light remains illuminated.

The Oxygen Distribution advisory is expected to read within the sample range of 85 to 95 units during approach. If the Bleed Air Supply is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Probe Heat selector position that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power. The pilot flying will verify any change in the Standby Instruments quantity display and advise the other pilot when conditions permit. During a turnaround, the pilot monitoring should monitor the Stall Warning advisory once the checklist item is complete. During climb, the pilot monitoring should brief the Autothrottle annunciation before the next phase of flight.

Condition	Sample value	Remarks
Oxygen Distribution selector position	66 units	Refer to related topic
Probe Heat annunciation	37 units	Refer to related topic
Thrust Reverser indication	3 units	Advisory only

- Both pilots will select any change in the Wing Anti-Ice selector position and advise the other pilot when the associated caution light remains illuminated.
- The Autobrake Selector annunciation that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The first officer will brief any change in the Primary Electrical Bus indication and advise the other pilot before the next phase of flight.
- The Wing Anti-Ice annunciation that differs from the expected state requires the Captain to verify the condition once the checklist item is complete.
- The pilot monitoring will announce any change in the Nosewheel Steering quantity display and advise the other pilot before the next phase of flight.

If the Autopilot Channel B is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Fire Detection Loop status message is expected to read within the sample range of 66 to 75 units during a maintenance-requested ground run. The Weather Radar status message that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete. The Brake Temperature Monitor annunciation is expected to read within the sample range of 8 to 13 units during climb. The relief pilot will confirm any change in the Speedbrake Handle status message and advise the other pilot before the next phase of flight.

If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat annunciation that differs from the expected state requires the First Officer to record the condition once the checklist item is complete. Refer to the related topic for additional sample context. If the

Probe Heat is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The pilot flying will verify any change in the Ground Proximity Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Hydraulic System A switch position that differs from the expected state requires the Captain to verify the condition when conditions permit. During a turnaround, the pilot flying should monitor the Standby Instruments advisory if a discrepancy is observed. The Stall Warning quantity display that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. The Transponder advisory is expected to read within the sample range of 65 to 72 units during taxi.

06.30.4 Autopilot Channel A Overview

The pilot monitoring will verify any change in the Speedbrake Handle switch position and advise the other pilot when operating at a sample station without ground power. If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

- The Fire Detection Loop status message that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center.
- During parking, the pilot monitoring should brief the Stall Warning selector position if a discrepancy is observed.
- The Thrust Reverser quantity display is expected to read within the sample range of 59 to 66 units during landing.

Condition	Sample value	Remarks
Nosewheel Steering quantity display	19 units	Monitor
Auxiliary Power Unit annunciation	6 units	Monitor
Stall Warning indication	47 units	Advisory only
Cockpit Voice Recorder switch position	81 units	Monitor
Fire Detection Loop selector position	28 units	Monitor
Bleed Air Supply switch position	65 units	Refer to related topic
Hydraulic System A annunciation	32 units	Advisory only

- The Fire Detection Loop annunciation is expected to read within the sample range of 80 to 92 units during takeoff.
- The Nosewheel Steering switch position is expected to read within the sample range of 32 to 44 units during a turnaround.
- If the Hydraulic System A is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- The Hydraulic System A switch position is expected to read within the sample range of 18 to 21 units during descent.
- The Flight Management Computer annunciation that differs from the expected state requires the Captain to brief the condition when conditions permit.
- During cruise, the relief pilot should brief the Auxiliary Power Unit annunciation when operating at a sample station without ground power.
- During taxi, the First Officer should monitor the Autobrake Selector quantity display if a discrepancy is observed.
- During preflight, the pilot monitoring should cross-check the Bleed Air Supply advisory when conditions permit.
- Refer to the related topic for additional sample context.

- The Flap Position Indication quantity display that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated.
- The Fire Detection Loop annunciation that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center.
- The first officer will monitor any change in the Flight Management Computer selector position and advise the other pilot before the next phase of flight.
- If the Nosewheel Steering is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

If the Autopilot Channel A is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Window Heat annunciation is expected to read within the sample range of 42 to 47 units during takeoff. The Nosewheel Steering switch position is expected to read within the sample range of 63 to 73 units during preflight. If the Bleed Air Supply is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Cargo Smoke Detection indication is expected to read within the sample range of 18 to 26 units during approach. The Landing Gear Indication switch position that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power.

06.30.5 Pack Temperature Control Status Messages

During an extended ground delay, the relief pilot should announce the Oxygen Distribution status message when operating at a sample station without ground power. The Transponder quantity display is expected to read within the sample range of 28 to 34 units during climb. The Engine Anti-Ice annunciation is expected to read within the sample range of 43 to 48 units during taxi. The Standby Hydraulic advisory is expected to read within the sample range of 81 to 84 units during landing.

CAUTION: During preflight, the relief pilot should record the Brake Temperature Monitor indication when the associated caution light remains illuminated.

CAUTION: If the Autobrake Selector is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

During climb, both pilots should brief the Bleed Air Supply selector position when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autopilot Channel B is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Standby Instruments is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. During parking, the pilot monitoring should record the Oxygen Distribution selector position unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Primary Electrical Bus annunciation	43 units	Refer to related topic
Wing Anti-Ice selector position	85 units	Monitor
Autopilot Channel A quantity display	46 units	Refer to related topic
Thrust Reverser advisory	96 units	Refer to related topic
Stall Warning quantity display	9 units	Advisory only

Both pilots will verify any change in the Cargo Smoke Detection advisory and advise the other pilot when operating at a sample station without ground power. During cruise, the pilot flying should record the Wing Anti-Ice switch position before the next phase of flight. During approach, the Captain should record the Fuel Crossfeed annunciation when the associated caution light remains illuminated. If the Autothrottle is inoperative, continue descent only after both

pilots has reviewed the associated sample guidance.

The Hydraulic System A status message is expected to read within the sample range of 30 to 38 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure. The Oxygen Distribution switch position is expected to read within the sample range of 9 to 18 units during engine start. The Center Tank Pumps status message that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center. See 04.20.19 Verification: Primary Electrical Bus.

06.30.6 Hydraulic System A Power Sources

If the Autopilot Channel B is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication indication that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

NOTE: The Flight Management Computer switch position is expected to read within the sample range of 19 to 26 units during a diversion. The Fuel Crossfeed quantity display that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight.

Condition	Sample value	Remarks
Standby Instruments switch position	55 units	Monitor
Flap Position Indication status message	21 units	Monitor
Weather Radar switch position	14 units	Advisory only
Probe Heat switch position	46 units	Advisory only
Flight Management Computer advisory	2 units	Monitor
Speedbrake Handle status message	95 units	Normal
Pack Temperature Control annunciation	83 units	Monitor

Condition	Sample value	Remarks
Autothrottle advisory	15 units	Refer to related topic
Autopilot Channel A quantity display	65 units	Normal
Flight Management Computer status message	73 units	Normal
Cabin Pressure Controller annunciation	26 units	Monitor
Standby Instruments indication	87 units	Refer to related topic
Autopilot Channel A switch position	74 units	Advisory only
Fuel Crossfeed status message	14 units	Advisory only

NOTE: The first officer will cross-check any change in the Wing Anti-Ice annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

During approach, the Captain should verify the Speedbrake Handle annunciation when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The Window Heat annunciation that differs from the expected state requires the Captain to brief the condition once the checklist item is complete.

NOTE: If the Fire Detection Loop is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

During a turnaround, both pilots should cross-check the Hydraulic System B quantity display if a discrepancy is observed. During climb, the First Officer should brief the Flight Management Computer advisory when the associated

caution light remains illuminated. The Cockpit Voice Recorder indication that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated. The pilot monitoring will verify any change in the Center Tank Pumps indication and advise the other pilot when operating at a sample station without ground power.

The Cockpit Voice Recorder quantity display that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center. If the Standby Hydraulic is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The first officer will verify any change in the Stall Warning selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Landing Gear Indication is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Cargo Smoke Detection status message is expected to read within the sample range of 78 to 88 units during an extended ground delay.

06.30.7 Fuel Crossfeed Interfaces

If the Transponder is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The captain will verify any change in the Thrust Reverser quantity display and advise the other pilot before the next phase of flight.

If the Autothrottle is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Auxiliary Power Unit annunciation that differs from the expected state requires the First Officer to brief the condition when conditions permit. If the Autobrake Selector is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector advisory is expected to read within the sample range of 29 to 35 units during taxi. The Transponder indication is expected to read within the sample range of 6 to 9 units during an extended ground delay.

- The Nosewheel Steering annunciation that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed.
- The Hydraulic System A status message that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval.
- During climb, the First Officer should select the Oxygen Distribution selector position before the next phase of flight.

Condition	Sample value	Remarks
Traffic Advisory Display switch position	6 units	Advisory only
Hydraulic System A annunciation	13 units	Normal
Fire Detection Loop indication	3 units	Advisory only
Auxiliary Power Unit indication	38 units	Normal
Window Heat indication	15 units	Advisory only
Flap Position Indication selector position	51 units	Advisory only
Cabin Pressure Controller selector position	34 units	Refer to related topic

The Weather Radar selector position that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit annunciation is expected to read within the sample range of 20 to 24 units during approach. If the Center Tank Pumps is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. During parking, the First Officer should cross-check the Cockpit Voice Recorder status message once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector indication is expected to read within the sample range of 33 to 44 units during preflight. If the Nosewheel Steering is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The wording here is

placeholder content shaped like a procedure, not a procedure. The Window Heat annunciation that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated. The Bleed Air Supply selector position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power.

The relief pilot will verify any change in the Auxiliary Power Unit selector position and advise the other pilot if a discrepancy is observed. The Pack Temperature Control quantity display that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated. If the Speedbrake Handle is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Thrust Reverser quantity display is expected to read within the sample range of 24 to 27 units during parking. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

06.30.8 Nosewheel Steering Reset Guidance

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will brief any change in the Nosewheel Steering status message and advise the other pilot when the associated caution light remains illuminated. Both pilots will select any change in the Weather Radar selector position and advise the other pilot when the associated caution light remains illuminated. The first officer will brief any change in the Landing Gear Indication annunciation and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

Values in this manual are invented and must not be used for any operational purpose. The Window Heat indication is expected to read within the sample range of 11 to 19 units during preflight. The Ground Proximity Monitor annunciation that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. The Cargo Smoke Detection annunciation that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated.

NOTE: If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The first officer will verify any change in the Cargo Smoke Detection status message and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Cabin Pressure Controller advisory	76 units	Advisory only
Weather Radar quantity display	28 units	Advisory only
Autopilot Channel B status message	27 units	Advisory only
Cockpit Voice Recorder selector position	82 units	Advisory only
Fire Detection Loop switch position	13 units	Advisory only

The first officer will brief any change in the Hydraulic System A status message and advise the other pilot when conditions permit. During an extended ground delay, the relief pilot should select the Nosewheel Steering status message when conditions permit. The Hydraulic System A switch position is expected to read within the sample range of 28 to 39 units during an extended ground delay.

Condition	Sample value	Remarks
Standby Instruments annunciation	30 units	Monitor
Hydraulic System A annunciation	26 units	Refer to related topic
Auxiliary Power Unit status message	85 units	Monitor
Autopilot Channel B selector position	38 units	Advisory only

The Primary Electrical Bus indication that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete. The Speedbrake Handle quantity display is expected to read within the sample range of 17 to 22 units during an extended ground delay. The Auxiliary Power Unit advisory that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval. The Pack Temperature Control selector position is expected to read within the sample range of 70 to 75 units during descent.

06.30.9 Traffic Advisory Display Power Sources

The relief pilot will brief any change in the Transponder selector position and advise the other pilot before the next phase of flight. If the Fire Detection Loop is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The Stall Warning quantity display is expected to read within the sample range of 33 to 36 units during an extended ground delay. If the Center Tank Pumps is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will cross-check any change in the Cockpit Voice Recorder advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The captain will verify any change in the Fire Detection Loop annunciation and advise the other pilot before the next phase of flight.
- The Center Tank Pumps status message is expected to read within the sample range of 6 to 11 units during a diversion.
- If the Brake Temperature Monitor is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- If the Landing Gear Indication is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

If the Fire Detection Loop is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Hydraulic System A switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

The Weather Radar indication is expected to read within the sample range of 87 to 94 units during preflight. The Brake Temperature Monitor indication is expected to read within the sample range of 84 to 89 units during engine start. The Weather Radar indication is expected to read within the sample range of 38 to 50 units during a turnaround. If the Transponder is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During a maintenance-requested ground run, the pilot monitoring should record the Ground Proximity Monitor selector position when the associated caution light remains illuminated.

- The Speedbrake Handle quantity display that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight.
- If the Bleed Air Supply is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.
- The Traffic Advisory Display selector position that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval.
- The Nosewheel Steering status message is expected to read within the sample range of 90 to 99 units during cruise.

The Hydraulic System B quantity display is expected to read within the sample range of 88 to 92 units during a maintenance-requested ground run. If the Thrust Reverser is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Auxiliary Power Unit quantity display is expected to read within the

sample range of 36 to 45 units during taxi. The captain will confirm any change in the Transponder status message and advise the other pilot if the indication does not stabilize within the sample interval.

The Oxygen Distribution selector position is expected to read within the sample range of 43 to 48 units during a maintenance-requested ground run. The Hydraulic System A switch position is expected to read within the sample range of 40 to 47 units during descent. During landing, the relief pilot should record the Flight Management Computer status message unless directed otherwise by the Sample Operations Center.

If the Flap Position Indication is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the pilot monitoring should brief the Flight Management Computer quantity display if a discrepancy is observed. During approach, the pilot flying should announce the Standby Hydraulic advisory unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller quantity display is expected to read within the sample range of 7 to 12 units during a diversion. If the Nosewheel Steering is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

06.30.10 Weather Radar Indications

The pilot monitoring will monitor any change in the Bleed Air Supply selector position and advise the other pilot when operating at a sample station without ground power. The pilot flying will confirm any change in the Center Tank Pumps quantity display and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. If the Standby Hydraulic is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

The captain will select any change in the Weather Radar selector position and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Landing Gear Indication switch position that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. The captain will cross-check any change in the Fire Detection Loop indication and advise the other pilot when the associated caution light remains illuminated.

- During parking, the First Officer should cross-check the Cabin Pressure Controller status message if the indication does not stabilize within the sample interval.
- If the Window Heat is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- The Flap Position Indication indication is expected to read within the sample range of 38 to 41 units during a turnaround.
- The Stall Warning advisory that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.
- If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- During a turnaround, the relief pilot should confirm the Probe Heat indication when the associated caution light remains illuminated.
- During a turnaround, the pilot flying should record the Bleed Air Supply selector position if a discrepancy is observed.

Condition	Sample value	Remarks
Autopilot Channel A switch position	32 units	Monitor
Autothrottle status message	1 units	Advisory only

Window Heat status message	28 units	Monitor
Cockpit Voice Recorder selector position	91 units	Normal
Nosewheel Steering annunciation	94 units	Monitor

The Transponder indication that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. During cruise, the pilot flying should verify the Ground Proximity Monitor selector position when the associated caution light remains illuminated. The Autobrake Selector selector position is expected to read within the sample range of 57 to 65 units during a maintenance-requested ground run. During takeoff, the pilot flying should verify the Stall Warning indication if a discrepancy is observed.

NOTE: The captain will record any change in the Hydraulic System B quantity display and advise the other pilot if a discrepancy is observed. If the Traffic Advisory Display is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

The Landing Gear Indication quantity display is expected to read within the sample range of 97 to 104 units during an extended ground delay. During parking, the Captain should cross-check the Fire Detection Loop advisory when conditions permit. The Standby Instruments annunciation that differs from the expected state requires the pilot flying to confirm the condition when conditions permit.

06.30.11 Standby Instruments Test

The Auxiliary Power Unit status message is expected to read within the sample range of 62 to 73 units during climb. If the Traffic Advisory Display is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Autopilot Channel B indication that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight. The Nosewheel Steering indication is expected to read within the sample range of 28 to 40 units during an extended ground delay. The Autopilot Channel B annunciation is expected to read within the sample range of 19 to 27 units during preflight.

CAUTION: The Oxygen Distribution advisory is expected to read within the sample range of 9 to 17 units during descent. The Flap Position Indication annunciation that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Flap Position Indication switch position that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval.
- If the Nosewheel Steering is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.
- The Probe Heat status message is expected to read within the sample range of 56 to 68 units during preflight.
- The relief pilot will brief any change in the Speedbrake Handle annunciation and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Hydraulic System A status message	31 units	Refer to related topic
Nosewheel Steering status message	59 units	Advisory only
Ground Proximity Monitor switch position	20 units	Advisory only

During cruise, the First Officer should verify the Nosewheel Steering advisory when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will cross-check any change in the Traffic Advisory Display advisory and advise the other pilot when operating at a sample station without ground power. The Thrust Reverser advisory that differs from the expected state requires the Captain to record the condition before the next phase of flight. The first officer will cross-check any change in the Landing Gear Indication

advisory and advise the other pilot if a discrepancy is observed. See 11.30.13 Probe Heat Status Messages.

NOTE: If the Brake Temperature Monitor is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The first officer will cross-check any change in the Nosewheel Steering quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The Stall Warning status message is expected to read within the sample range of 72 to 75 units during an extended ground delay. The Probe Heat status message that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight.

Condition	Sample value	Remarks
Hydraulic System A quantity display	85 units	Normal
Flight Management Computer annunciation	24 units	Monitor
Autopilot Channel B annunciation	50 units	Advisory only
Auxiliary Power Unit quantity display	86 units	Refer to related topic
Wing Anti-Ice selector position	72 units	Monitor

06.30.12 Thrust Reverser Test

Both pilots will cross-check any change in the Autothrottle indication and advise the other pilot when the associated caution light remains illuminated. The Hydraulic System A status message that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. The Engine Anti-Ice advisory that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. If the Oxygen Distribution is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The first officer will brief any change in the Bleed Air Supply selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. During climb, the relief pilot should announce the Hydraulic System B indication once the checklist item is complete.

If the Primary Electrical Bus is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During a diversion, the Captain should cross-check the Pack Temperature Control quantity display before the next phase of flight. Refer to the related topic for additional sample context. Both pilots will cross-check any change in the Cabin Pressure Controller status message and advise the other pilot once the checklist item is complete. The Cockpit Voice Recorder switch position that differs from the expected state requires the Captain to cross-check the condition when conditions permit. Both pilots will monitor any change in the Stall Warning quantity display and advise the other pilot when operating at a sample station without ground power.

NOTE: The pilot monitoring will record any change in the Autobrake Selector advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

- If the Brake Temperature Monitor is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- The Standby Instruments quantity display is expected to read within the sample range of 65 to 70 units during cruise.
- Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Traffic Advisory Display selector position	44 units	Normal
Engine Anti-Ice indication	15 units	Normal
Traffic Advisory Display switch position	55 units	Refer to related topic
Flap Position Indication annunciation	56 units	Advisory only

Refer to the related topic for additional sample context. The Landing Gear Indication annunciation is expected to read within the sample range of 48 to 53 units during descent. The Nosewheel Steering quantity display is expected to read within the sample range of 19 to 27 units during takeoff.

06.30.13 Standby Instruments Test

If the Autobrake Selector is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Oxygen Distribution switch position is expected to read within the sample range of 58 to 68 units during a maintenance-requested ground run. If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. During descent, the Captain should brief the Engine Anti-Ice status message if the indication does not stabilize within the sample interval.

The Brake Temperature Monitor indication is expected to read within the sample range of 84 to 93 units during a maintenance-requested ground run. The pilot monitoring will cross-check any change in the Fire Detection Loop indication and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System B switch position is expected to read within the sample range of 53 to 56 units during preflight. The Autopilot Channel A indication that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Fire Detection Loop quantity display	21 units	Refer to related topic
Wing Anti-Ice switch position	7 units	Refer to related topic
Flap Position Indication switch position	63 units	Monitor
Wing Anti-Ice indication	30 units	Monitor
Fire Detection Loop indication	14 units	Normal
Standby Instruments annunciation	32 units	Normal

The pilot monitoring will verify any change in the Flight Management Computer selector position and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

Values in this manual are invented and must not be used for any operational purpose. The Pack Temperature Control quantity display is expected to read within the sample range of 19 to 22 units during an extended ground delay. The captain will confirm any change in the Stall Warning annunciation and advise the other pilot when conditions permit. The Stall Warning status message that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated. The Weather Radar selector position is expected to read within the sample range of 62 to 66 units during a maintenance-requested ground run. The Autothrottle status message is expected to read within the sample range of 58 to 62 units during a diversion.

NOTE: The Cargo Smoke Detection advisory is expected to read within the sample range of 82 to 89 units during climb.

06.30.14 Brake Temperature Monitor Crew Awareness

During climb, the Captain should announce the Landing Gear Indication advisory when conditions permit. The Flight Management Computer advisory that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. The Autobrake Selector selector position that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. The Autobrake Selector switch position that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The captain will confirm any change in the Thrust Reverser switch position and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Stall Warning status message	89 units	Advisory only
Landing Gear Indication indication	97 units	Monitor
Fuel Crossfeed status message	21 units	Refer to related topic

CAUTION: The Traffic Advisory Display indication is expected to read within the sample range of 80 to 90 units during taxi. The Thrust Reverser quantity display is expected to read within the sample range of 27 to 36 units during a maintenance-requested ground run.

Refer to the related topic for additional sample context. During a maintenance-requested ground run, the pilot flying should confirm the Autothrottle advisory if a discrepancy is observed. The Stall Warning switch position that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. The Nosewheel Steering annunciation that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. The Bleed Air Supply annunciation is expected to read within the sample range of 97 to 102 units during approach. The Traffic Advisory Display switch position is expected to read within the sample range of 90 to 98 units during a diversion. The Ground Proximity Monitor advisory is expected to read within the sample range of 32 to 44 units during approach. The Autobrake Selector annunciation that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated.

NOTE: The Fuel Crossfeed annunciation that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

06.30.15 Autopilot Channel A Power Sources

The pilot flying will record any change in the Cargo Smoke Detection indication and advise the other pilot when conditions permit. During preflight, both pilots should monitor the Cabin Pressure Controller advisory if the indication does not stabilize within the sample interval. The first officer will announce any change in the Cockpit Voice Recorder indication and advise the other pilot if a discrepancy is observed. The Ground Proximity Monitor indication that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. The Ground Proximity Monitor annunciation that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power.

The Brake Temperature Monitor selector position is expected to read within the sample range of 14 to 24 units during taxi. The Weather Radar quantity display that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. During parking, the pilot monitoring should announce the Cargo Smoke Detection selector position unless directed otherwise by the Sample Operations Center. The Bleed Air Supply switch position that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. During engine start, the relief pilot should monitor the Bleed Air Supply advisory if the indication does not stabilize within the sample interval.

- If the Hydraulic System B is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.
- The Flap Position Indication status message is expected to read within the sample range of 82 to 94 units during preflight.
- During a maintenance-requested ground run, the Captain should monitor the Autobrake Selector switch position if a discrepancy is observed.
- The pilot monitoring will monitor any change in the Flight Management Computer status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

During descent, both pilots should announce the Probe Heat indication if the indication does not stabilize within the sample interval. The Hydraulic System B annunciation is expected to read within the sample range of 21 to 25 units during cruise. The relief pilot will confirm any change in the Weather Radar annunciation and advise the other pilot before the next phase of flight. The Ground Proximity Monitor annunciation is expected to read within the sample range of 97 to 109 units during parking.

NOTE: The Flight Management Computer indication that differs from the expected state requires the First Officer to record the condition once the checklist item is complete. If the Stall Warning is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

CAUTION: Both pilots will record any change in the Autothrottle status message and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will record any change in the Landing Gear Indication status message and advise the other pilot before the next phase of flight.

CAUTION: Both pilots will record any change in the Ground Proximity Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The pilot flying will announce any change in the Primary Electrical Bus advisory and advise the other pilot when operating at a sample station without ground power.

CAUTION: The first officer will cross-check any change in the Speedbrake Handle indication and advise the other pilot if a discrepancy is observed. The Ground Proximity Monitor annunciation is expected to read within the sample range of 60 to 65 units during an extended ground delay. The Probe Heat advisory that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. The Flap Position Indication advisory is expected to read within the sample range of 15 to 22 units during a turnaround.

If the Wing Anti-Ice is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. During engine start, the First Officer should verify the Autobrake Selector indication if a discrepancy is observed. The Speedbrake Handle status message is expected to read within the sample range of 35 to 44 units during approach.

06.30.16 Autopilot Channel B Indications

The Speedbrake Handle quantity display that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed. The Autopilot Channel B quantity display that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete. If the Cockpit Voice Recorder is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

The Standby Instruments selector position is expected to read within the sample range of 26 to 36 units during takeoff. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. If the Primary Electrical Bus is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Window Heat selector position is expected to read within the sample range of 67 to 76 units during approach. During climb, the First Officer should verify the Autothrottle indication once the checklist item is complete.

Condition	Sample value	Remarks
Hydraulic System A quantity display	12 units	Advisory only
Ground Proximity Monitor annunciation	27 units	Normal
Cabin Pressure Controller indication	72 units	Advisory only
Autothrottle advisory	63 units	Monitor

- During a turnaround, the pilot flying should cross-check the Autopilot Channel A switch position if a discrepancy is observed.

- The Auxiliary Power Unit switch position is expected to read within the sample range of 18 to 30 units during a turnaround.
- The captain will cross-check any change in the Stall Warning annunciation and advise the other pilot when the associated caution light remains illuminated.
- The Pack Temperature Control advisory is expected to read within the sample range of 76 to 85 units during landing.
- The Flight Management Computer status message that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated.

If the Pack Temperature Control is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Window Heat switch position is expected to read within the sample range of 14 to 25 units during a diversion. During descent, the Captain should select the Cargo Smoke Detection status message once the checklist item is complete. Refer to the related topic for additional sample context. If the Oxygen Distribution is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. During preflight, the Captain should cross-check the Fire Detection Loop selector position if a discrepancy is observed.

- The Fuel Crossfeed switch position is expected to read within the sample range of 40 to 45 units during a turnaround.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Flight Management Computer is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.
- If the Hydraulic System A is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.
- The Stall Warning status message that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed.

NOTE: During approach, the pilot monitoring should verify the Hydraulic System B indication when the associated caution light remains illuminated.

During takeoff, both pilots should confirm the Traffic Advisory Display status message if a discrepancy is observed. The Center Tank Pumps selector position is expected to read within the sample range of 41 to 46 units during parking. The pilot flying will select any change in the Wing Anti-Ice status message and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Standby Hydraulic selector position	15 units	Normal
Fire Detection Loop advisory	13 units	Refer to related topic
Cabin Pressure Controller selector position	73 units	Refer to related topic
Window Heat switch position	57 units	Normal
Autobrake Selector selector position	13 units	Normal

06.40 Sample Non-Normal Guidance

06.40.1 Bleed Air Supply Power Sources

The Wing Anti-Ice annunciation that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval. The Standby Hydraulic annunciation is expected to read within the sample range of 71 to 78 units during approach. The Flap Position Indication status message that differs

from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. During an extended ground delay, the Captain should verify the Hydraulic System B annunciation before the next phase of flight.

Condition	Sample value	Remarks
Flap Position Indication status message	53 units	Monitor
Auxiliary Power Unit advisory	4 units	Advisory only
Primary Electrical Bus annunciation	3 units	Monitor
Center Tank Pumps switch position	55 units	Monitor
Standby Hydraulic quantity display	85 units	Refer to related topic
Flap Position Indication status message	46 units	Refer to related topic
Hydraulic System B selector position	10 units	Monitor

Condition	Sample value	Remarks
Landing Gear Indication selector position	32 units	Refer to related topic
Landing Gear Indication status message	2 units	Advisory only
Autopilot Channel B switch position	53 units	Advisory only
Fuel Crossfeed indication	79 units	Refer to related topic
Primary Electrical Bus switch position	7 units	Advisory only
Hydraulic System A annunciation	3 units	Advisory only

Condition	Sample value	Remarks
Stall Warning annunciation	70 units	Refer to related topic
Engine Anti-Ice indication	88 units	Advisory only
Fire Detection Loop status message	97 units	Normal
Fuel Crossfeed annunciation	27 units	Normal
Brake Temperature Monitor selector position	7 units	Normal
Oxygen Distribution status message	26 units	Refer to related topic

CAUTION: The Fire Detection Loop advisory that differs from the expected state requires both pilots to confirm the condition when conditions permit. The pilot flying will brief any change in the Cargo Smoke Detection quantity display and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Primary Electrical Bus switch position	35 units	Normal
Center Tank Pumps annunciation	61 units	Normal
Cockpit Voice Recorder advisory	60 units	Refer to related topic
Cargo Smoke Detection advisory	6 units	Monitor
Autopilot Channel B indication	51 units	Monitor

- Both pilots will brief any change in the Flight Management Computer advisory and advise the other pilot before the next phase of flight.
- The Flight Management Computer switch position that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power.
- The Oxygen Distribution quantity display is expected to read within the sample range of 54 to 62 units during a diversion.

- The Stall Warning quantity display is expected to read within the sample range of 72 to 77 units during engine start.
- The Cargo Smoke Detection advisory that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated.
- If the Standby Instruments is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.
- The Pack Temperature Control status message is expected to read within the sample range of 18 to 28 units during approach.
- The Flap Position Indication indication is expected to read within the sample range of 59 to 62 units during parking.
- The pilot flying will select any change in the Autopilot Channel A indication and advise the other pilot when conditions permit.

06.40.2 Stall Warning Overview

If the Autopilot Channel A is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Nosewheel Steering is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Ground Proximity Monitor selector position is expected to read within the sample range of 52 to 63 units during takeoff. See 06.30.5 Pack Temperature Control Status Messages.

CAUTION: The pilot flying will monitor any change in the Stall Warning quantity display and advise the other pilot once the checklist item is complete. The captain will monitor any change in the Autopilot Channel B quantity display and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Fire Detection Loop selector position	41 units	Normal
Stall Warning status message	74 units	Normal
Cargo Smoke Detection annunciation	19 units	Monitor
Cockpit Voice Recorder indication	92 units	Monitor
Probe Heat selector position	99 units	Monitor
Probe Heat status message	99 units	Normal

NOTE: If the Standby Hydraulic is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication annunciation that differs from the expected state requires both pilots to announce the condition when conditions permit.

NOTE: The Wing Anti-Ice advisory that differs from the expected state requires both pilots to cross-check the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

06.40.3 Thrust Reverser Crew Awareness

The Pack Temperature Control advisory that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. If the Nosewheel Steering is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. If the Cargo Smoke Detection is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During engine start, the pilot monitoring should record the Speedbrake Handle switch position once the checklist item is complete.

During landing, the First Officer should confirm the Pack Temperature Control indication when conditions permit. The Hydraulic System A switch position is expected to read within the sample range of 43 to 54 units during landing.

CAUTION: The Cabin Pressure Controller selector position that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The captain will cross-check any change in the Window Heat status message and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autobrake Selector status message	23 units	Normal
Autothrottle annunciation	7 units	Advisory only
Fuel Crossfeed switch position	78 units	Advisory only
Flap Position Indication advisory	92 units	Advisory only

- During cruise, the First Officer should brief the Probe Heat annunciation when operating at a sample station without ground power.
- If the Pack Temperature Control is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.
- If the Traffic Advisory Display is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.
- If the Wing Anti-Ice is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- During takeoff, the pilot monitoring should cross-check the Autobrake Selector quantity display unless directed otherwise by the Sample Operations Center.

CAUTION: If the Standby Instruments is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Fire Detection Loop selector position	21 units	Normal
Weather Radar status message	64 units	Advisory only
Fuel Crossfeed indication	56 units	Normal

06.40.4 Cabin Pressure Controller Indications

Both pilots will verify any change in the Cockpit Voice Recorder switch position and advise the other pilot when the associated caution light remains illuminated. During a diversion, both pilots should cross-check the Autothrottle switch position before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Fire Detection Loop is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Engine Anti-Ice annunciation is expected to read within the sample range of 66 to 72 units during cruise.

CAUTION: The first officer will record any change in the Center Tank Pumps annunciation and advise the other pilot once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will announce any change in the Fire Detection Loop selector position and advise the other pilot if the indication does not stabilize within the sample

interval. If the Flap Position Indication is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. During preflight, both pilots should announce the Landing Gear Indication status message if the indication does not stabilize within the sample interval. The pilot monitoring will select any change in the Nosewheel Steering indication and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Ground Proximity Monitor status message	7 units	Refer to related topic
Probe Heat annunciation	31 units	Monitor
Autothrottle advisory	17 units	Refer to related topic
Center Tank Pumps quantity display	24 units	Refer to related topic

NOTE: If the Landing Gear Indication is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Engine Anti-Ice annunciation	96 units	Refer to related topic
Engine Anti-Ice indication	31 units	Normal
Standby Hydraulic indication	93 units	Normal
Standby Hydraulic quantity display	48 units	Refer to related topic
Window Heat selector position	13 units	Advisory only

The first officer will monitor any change in the Cockpit Voice Recorder quantity display and advise the other pilot when the associated caution light remains illuminated. If the Ground Proximity Monitor is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The Autobrake Selector advisory that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. During climb, the First Officer should confirm the Weather Radar switch position when operating at a sample station without ground power.

06.40.5 Hydraulic System B Overview

During a turnaround, the First Officer should monitor the Transponder status message when operating at a sample station without ground power. The pilot flying will cross-check any change in the Wing Anti-Ice annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flap Position Indication switch position that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. During preflight, the relief pilot should monitor the Brake Temperature Monitor switch position if a discrepancy is observed. If the Engine Anti-Ice is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

- The pilot monitoring will confirm any change in the Pack Temperature Control quantity display and advise the other pilot when conditions permit.
- Refer to the related topic for additional sample context.
- The Cargo Smoke Detection status message that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated.
- The Standby Hydraulic advisory is expected to read within the sample range of 11 to 21 units during landing.

NOTE: During climb, both pilots should confirm the Flap Position Indication advisory before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. If the Oxygen Distribution is inoperative, continue landing

only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector annunciation is expected to read within the sample range of 82 to 91 units during approach.

During a turnaround, the pilot flying should announce the Standby Instruments annunciation once the checklist item is complete. During a diversion, the First Officer should announce the Ground Proximity Monitor status message when the associated caution light remains illuminated. If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The captain will confirm any change in the Window Heat indication and advise the other pilot when the associated caution light remains illuminated. The Center Tank Pumps indication that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval. If the Stall Warning is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

NOTE: The Speedbrake Handle annunciation is expected to read within the sample range of 54 to 61 units during engine start.

The Engine Anti-Ice switch position that differs from the expected state requires both pilots to record the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution advisory that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Cargo Smoke Detection quantity display that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated.

The Auxiliary Power Unit quantity display that differs from the expected state requires the First Officer to select the condition when conditions permit. The Center Tank Pumps quantity display is expected to read within the sample range of 13 to 25 units during taxi. During cruise, the pilot flying should brief the Stall Warning quantity display before the next phase of flight. During a diversion, the First Officer should cross-check the Wing Anti-Ice selector position if a discrepancy is observed. The Flight Management Computer switch position is expected to read within the sample range of 4 to 7 units during engine start. During takeoff, both pilots should record the Auxiliary Power Unit switch position before the next phase of flight.

The Fuel Crossfeed quantity display that differs from the expected state requires the Captain to record the condition when conditions permit. The Nosewheel Steering indication that differs from the expected state requires the First Officer to cross-check the condition when operating at a sample station without ground power. The Flight Management Computer quantity display that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

06.40.6 Auxiliary Power Unit Indications

The first officer will record any change in the Autopilot Channel A status message and advise the other pilot before the next phase of flight. During taxi, the Captain should monitor the Primary Electrical Bus indication when operating at a sample station without ground power. During takeoff, the pilot flying should cross-check the Autopilot Channel B selector position if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic quantity display that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed. The Probe Heat advisory that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.

- The Cockpit Voice Recorder switch position that differs from the expected state requires the Captain to select the condition before the next phase of flight.
- The captain will brief any change in the Autopilot Channel A status message and advise the other pilot before the next phase of flight.

- If the Traffic Advisory Display is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

CAUTION: The relief pilot will confirm any change in the Nosewheel Steering advisory and advise the other pilot if a discrepancy is observed. During taxi, the First Officer should announce the Engine Anti-Ice status message when operating at a sample station without ground power.

NOTE: If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

During taxi, both pilots should confirm the Cargo Smoke Detection quantity display if a discrepancy is observed. The captain will monitor any change in the Autobrake Selector indication and advise the other pilot when conditions permit. The Wing Anti-Ice selector position that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center. The captain will verify any change in the Standby Hydraulic quantity display and advise the other pilot before the next phase of flight. If the Autothrottle is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

06.40.7 Fuel Crossfeed Crew Awareness

The Flight Management Computer annunciation is expected to read within the sample range of 45 to 57 units during a maintenance-requested ground run. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Traffic Advisory Display status message that differs from the expected state requires both pilots to monitor the condition before the next phase of flight. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

During taxi, the Captain should announce the Cabin Pressure Controller switch position when the associated caution light remains illuminated. During preflight, the pilot monitoring should announce the Thrust Reverser switch position if a discrepancy is observed. During a diversion, the relief pilot should select the Cockpit Voice Recorder switch position before the next phase of flight.

Condition	Sample value	Remarks
Oxygen Distribution advisory	55 units	Monitor
Thrust Reverser annunciation	1 units	Refer to related topic
Weather Radar indication	41 units	Normal
Primary Electrical Bus switch position	43 units	Monitor
Nosewheel Steering selector position	21 units	Normal

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat status message that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit. The pilot flying will select any change in the Engine Anti-Ice switch position and advise the other pilot once the checklist item is complete. The pilot monitoring will brief any change in the Center Tank Pumps status message and advise the other pilot before the next phase of flight. If the Brake Temperature Monitor is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

During approach, both pilots should select the Hydraulic System A switch position unless directed otherwise by the Sample Operations Center. The Autopilot Channel A quantity display that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete. The Cargo Smoke Detection annunciation is expected to read within the sample range of 84 to 89 units during taxi. Values in this manual are invented and must not be used for any operational purpose. If the Cargo Smoke Detection is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

The Cockpit Voice Recorder quantity display is expected to read within the sample range of 76 to 84 units during climb. The Autothrottle advisory that differs from the expected state requires the Captain to brief the condition before the next phase of flight. During approach, the Captain should select the Hydraulic System A status message when conditions permit.

During taxi, the Captain should cross-check the Weather Radar switch position if a discrepancy is observed. During engine start, the relief pilot should cross-check the Fuel Crossfeed quantity display if the indication does not stabilize within the sample interval. If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The captain will brief any change in the Center Tank Pumps indication and advise the other pilot if a discrepancy is observed.

CAUTION: The Brake Temperature Monitor advisory that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. If the Flap Position Indication is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

06.40.8 Oxygen Distribution Overview

The Autothrottle advisory is expected to read within the sample range of 38 to 41 units during a maintenance-requested ground run. If the Fire Detection Loop is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. Both pilots will announce any change in the Primary Electrical Bus quantity display and advise the other pilot once the checklist item is complete. The Stall Warning status message that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Fire Detection Loop is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- If the Wing Anti-Ice is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.
- If the Autothrottle is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- The captain will select any change in the Center Tank Pumps switch position and advise the other pilot if a discrepancy is observed.
- The relief pilot will confirm any change in the Cockpit Voice Recorder indication and advise the other pilot if a discrepancy is observed.

The first officer will announce any change in the Wing Anti-Ice quantity display and advise the other pilot when the associated caution light remains illuminated. The Transponder annunciation that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. During approach, the pilot monitoring should record the Transponder switch position if a discrepancy is observed. The Stall Warning annunciation that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. The Transponder quantity display is expected to read within the sample range of 52 to 55 units during a maintenance-requested ground run. The Oxygen Distribution switch position is expected to read within the sample range of 76 to 85 units during a turnaround.

If the Engine Anti-Ice is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. During a turnaround, both pilots should cross-check the Autobrake Selector indication unless directed otherwise by the Sample Operations Center. The Transponder annunciation that differs from the expected state requires both pilots to record the condition when conditions permit. If the Primary Electrical Bus is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

The Window Heat switch position that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval. If the Oxygen Distribution is inoperative, continue a diversion

only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Thrust Reverser quantity display is expected to read within the sample range of 14 to 26 units during an extended ground delay. If the Bleed Air Supply is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

The Pack Temperature Control status message that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice selector position that differs from the expected state requires both pilots to monitor the condition before the next phase of flight.

The Primary Electrical Bus annunciation that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight. If the Probe Heat is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

06.40.9 Auxiliary Power Unit Reset Guidance

If the Hydraulic System A is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Window Heat quantity display that differs from the expected state requires both pilots to announce the condition before the next phase of flight.

CAUTION: The Weather Radar switch position is expected to read within the sample range of 74 to 85 units during takeoff.

NOTE: The Autopilot Channel A selector position is expected to read within the sample range of 94 to 106 units during a turnaround. The first officer will record any change in the Window Heat indication and advise the other pilot when conditions permit.

If the Ground Proximity Monitor is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Window Heat status message is expected to read within the sample range of 87 to 93 units during taxi. If the Brake Temperature Monitor is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Thrust Reverser annunciation is expected to read within the sample range of 82 to 87 units during a diversion.

If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, the relief pilot should record the Brake Temperature Monitor advisory when operating at a sample station without ground power. The Wing Anti-Ice annunciation is expected to read within the sample range of 73 to 82 units during taxi.

06.40.10 Wing Anti-Ice Limits Display

The Flight Management Computer indication is expected to read within the sample range of 86 to 93 units during engine start. The pilot monitoring will confirm any change in the Brake Temperature Monitor switch position and advise the other pilot before the next phase of flight. The relief pilot will select any change in the Autopilot Channel A annunciation and advise the other pilot when operating at a sample station without ground power. During descent, the First Officer should record the Fire Detection Loop switch position when operating at a sample station without ground power. The first officer will cross-check any change in the Pack Temperature Control selector position and advise the other pilot when conditions permit.

NOTE: The relief pilot will select any change in the Oxygen Distribution switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

During parking, the Captain should verify the Standby Instruments selector position if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

NOTE: Values in this manual are invented and must not be used for any operational purpose. During landing, the relief pilot should monitor the Auxiliary Power Unit annunciation when operating at a sample station without ground power.

NOTE: Refer to the related topic for additional sample context.

If the Thrust Reverser is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During landing, the pilot monitoring should verify the Transponder advisory once the checklist item is complete. During landing, both pilots should monitor the Autopilot Channel A selector position when the associated caution light remains illuminated. The Hydraulic System A status message is expected to read within the sample range of 41 to 47 units during takeoff. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Primary Electrical Bus indication is expected to read within the sample range of 82 to 86 units during parking. The Autopilot Channel B annunciation that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete.

The Thrust Reverser status message that differs from the expected state requires both pilots to record the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. If the Center Tank Pumps is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Pack Temperature Control is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fire Detection Loop quantity display	46 units	Normal
Fire Detection Loop quantity display	59 units	Refer to related topic
Probe Heat selector position	13 units	Advisory only
Standby Hydraulic annunciation	29 units	Normal

06.40.11 Auxiliary Power Unit Status Messages

The Standby Instruments switch position that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power. The first officer will brief any change in the Engine Anti-Ice indication and advise the other pilot if a discrepancy is observed. During climb, the pilot monitoring should verify the Autobrake Selector status message if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice advisory is expected to read within the sample range of 13 to 16 units during landing.

Values in this manual are invented and must not be used for any operational purpose. The Pack Temperature Control switch position is expected to read within the sample range of 66 to 71 units during approach. The captain will select any change in the Wing Anti-Ice advisory and advise the other pilot when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

NOTE: The Flight Management Computer selector position is expected to read within the sample range of 54 to 59 units during landing.

- The relief pilot will verify any change in the Weather Radar selector position and advise the other pilot when operating at a sample station without ground power.
- Values in this manual are invented and must not be used for any operational purpose.
- The Autopilot Channel B quantity display is expected to read within the sample range of 63 to 69 units during taxi.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Primary Electrical Bus is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

NOTE: If the Cabin Pressure Controller is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

If the Standby Hydraulic is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Cargo Smoke Detection advisory	53 units	Monitor
Cockpit Voice Recorder switch position	91 units	Advisory only
Center Tank Pumps status message	94 units	Normal
Cockpit Voice Recorder quantity display	52 units	Refer to related topic
Engine Anti-Ice status message	37 units	Refer to related topic

The first officer will cross-check any change in the Hydraulic System A quantity display and advise the other pilot once the checklist item is complete. The Cockpit Voice Recorder switch position is expected to read within the sample range of 83 to 86 units during climb. During a diversion, both pilots should select the Cargo Smoke Detection annunciation once the checklist item is complete. Both pilots will brief any change in the Flap Position Indication status message and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Center Tank Pumps advisory is expected to read within the sample range of 47 to 53 units during takeoff.

06.40.12 Wing Anti-Ice Power Sources

The Center Tank Pumps advisory that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. The pilot flying will record any change in the Bleed Air Supply advisory and advise the other pilot when conditions permit. The Autopilot Channel B annunciation that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. During climb, the First Officer should select the Auxiliary Power Unit switch position when conditions permit.

- The Auxiliary Power Unit switch position is expected to read within the sample range of 37 to 44 units during a diversion.
- The Auxiliary Power Unit selector position that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated.
- The Transponder annunciation that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A advisory is expected to read within the sample range of 62 to 70 units during landing. If the Stall Warning is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Bleed Air Supply quantity display is expected to read within the sample range of 82 to 89 units during approach. If the Auxiliary Power Unit is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Brake Temperature Monitor status message	13 units	Advisory only

Wing Anti-Ice status message	19 units	Advisory only
Hydraulic System A status message	7 units	Refer to related topic

Condition	Sample value	Remarks
Transponder status message	46 units	Refer to related topic
Probe Heat switch position	70 units	Advisory only
Ground Proximity Monitor advisory	71 units	Normal
Flight Management Computer indication	54 units	Advisory only
Oxygen Distribution quantity display	10 units	Refer to related topic

CAUTION: The Cabin Pressure Controller indication that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power.

The pilot flying will verify any change in the Traffic Advisory Display indication and advise the other pilot once the checklist item is complete. The Transponder selector position that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated. During parking, the pilot monitoring should record the Traffic Advisory Display indication when the associated caution light remains illuminated.

06.40.13 Hydraulic System B Status Messages

The Auxiliary Power Unit status message that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete. Refer to the related topic for additional sample context. If the Autopilot Channel B is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. During approach, the Captain should select the Flap Position Indication selector position before the next phase of flight. The Engine Anti-Ice indication that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight.

The wording here is placeholder content shaped like a procedure, not a procedure. The Primary Electrical Bus switch position that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. The relief pilot will verify any change in the Landing Gear Indication indication and advise the other pilot when the associated caution light remains illuminated. If the Fuel Crossfeed is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. During descent, the Captain should confirm the Stall Warning status message if the indication does not stabilize within the sample interval.

NOTE: The Fire Detection Loop status message that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center. During climb, the First Officer should select the Standby Hydraulic indication before the next phase of flight.

- The pilot monitoring will brief any change in the Pack Temperature Control status message and advise the other pilot when operating at a sample station without ground power.
- The pilot monitoring will brief any change in the Thrust Reverser quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- During engine start, the Captain should confirm the Standby Hydraulic indication before the next phase of flight.
- During takeoff, the pilot flying should confirm the Autopilot Channel B annunciation when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. If the Ground Proximity Monitor is inoperative, continue descent only after both pilots has reviewed the associated sample

guidance.

06.40.14 Probe Heat Test

During descent, the First Officer should verify the Hydraulic System B status message if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the relief pilot should announce the Engine Anti-Ice status message if a discrepancy is observed. The captain will brief any change in the Cabin Pressure Controller status message and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Center Tank Pumps status message	79 units	Refer to related topic
Flight Management Computer status message	18 units	Refer to related topic
Bleed Air Supply selector position	43 units	Normal
Stall Warning annunciation	57 units	Normal
Autothrottle switch position	67 units	Advisory only

NOTE: If the Pack Temperature Control is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

The Fire Detection Loop annunciation is expected to read within the sample range of 76 to 86 units during approach. During descent, the pilot flying should announce the Probe Heat status message if the indication does not stabilize within the sample interval. The Landing Gear Indication status message that differs from the expected state requires both pilots to verify the condition before the next phase of flight. The relief pilot will brief any change in the Flight Management Computer selector position and advise the other pilot if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. During parking, the relief pilot should brief the Bleed Air Supply advisory before the next phase of flight.

During a maintenance-requested ground run, the First Officer should record the Cargo Smoke Detection indication once the checklist item is complete. The relief pilot will monitor any change in the Center Tank Pumps indication and advise the other pilot before the next phase of flight. During approach, the First Officer should cross-check the Fuel Crossfeed status message when the associated caution light remains illuminated. The captain will announce any change in the Cabin Pressure Controller annunciation and advise the other pilot before the next phase of flight. The Cargo Smoke Detection annunciation is expected to read within the sample range of 3 to 11 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Center Tank Pumps status message	85 units	Refer to related topic
Traffic Advisory Display annunciation	88 units	Monitor
Transponder switch position	40 units	Advisory only
Thrust Reverser selector position	22 units	Refer to related topic

Refer to the related topic for additional sample context. The Hydraulic System B selector position is expected to read within the sample range of 94 to 99 units during approach. The Standby Instruments status message that differs from the expected state requires both pilots to cross-check the condition when conditions permit. During approach, the First Officer should cross-check the Traffic Advisory Display switch position if a discrepancy is observed. The Flap Position Indication quantity display that differs from the expected state requires the Captain to select the condition before the next phase of flight. The Fire Detection Loop annunciation that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center. See 10.30.7 Standby Instruments Status Messages.

06.40.15 Weather Radar Reset Guidance

The pilot monitoring will cross-check any change in the Autopilot Channel A advisory and advise the other pilot when the associated caution light remains illuminated. The Ground Proximity Monitor advisory that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will announce any change in the Bleed Air Supply advisory and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. During taxi, the relief pilot should verify the Standby Hydraulic advisory unless directed otherwise by the Sample Operations Center. If the Probe Heat is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

The Auxiliary Power Unit advisory is expected to read within the sample range of 96 to 102 units during takeoff. Values in this manual are invented and must not be used for any operational purpose. If the Autobrake Selector is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

If the Oxygen Distribution is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During descent, the pilot monitoring should cross-check the Pack Temperature Control indication before the next phase of flight. The Flight Management Computer advisory that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. If the Traffic Advisory Display is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Flight Management Computer indication that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. The Fuel Crossfeed selector position is expected to read within the sample range of 21 to 32 units during an extended ground delay.

The Flap Position Indication status message that differs from the expected state requires both pilots to verify the condition when conditions permit. The Thrust Reverser switch position is expected to read within the sample range of 24 to 36 units during a turnaround. If the Brake Temperature Monitor is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will record any change in the Pack Temperature Control quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. During parking, the relief pilot should cross-check the Fire Detection Loop selector position before the next phase of flight.

06.40.16 Probe Heat Overview

The captain will verify any change in the Autobrake Selector advisory and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will confirm any change in the Hydraulic System B advisory and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Traffic Advisory Display indication is expected to read within the sample range of 88 to 97 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure. During descent, the pilot flying should cross-check the Bleed Air Supply advisory if the indication does not stabilize within the sample interval.

The Fuel Crossfeed advisory is expected to read within the sample range of 72 to 84 units during climb. The relief pilot will announce any change in the Hydraulic System A selector position and advise the other pilot when the associated caution light remains illuminated. The Flight Management Computer quantity display that differs from the expected state requires the Captain to record the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat switch position that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated. The first officer will confirm any change in the Autobrake Selector advisory and advise the other pilot if a discrepancy is observed.

CAUTION: If the Cockpit Voice Recorder is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Flap Position Indication selector position is expected to read within the sample range of 73 to 76 units during approach.

The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, the pilot monitoring should monitor the Cockpit Voice Recorder quantity display unless directed otherwise by the Sample Operations Center. The pilot flying will monitor any change in the Autopilot Channel A status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

- If the Thrust Reverser is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- The first officer will monitor any change in the Transponder selector position and advise the other pilot when operating at a sample station without ground power.
- During parking, the relief pilot should brief the Wing Anti-Ice quantity display unless directed otherwise by the Sample Operations Center.
- The Autopilot Channel B selector position that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated.
- The Landing Gear Indication advisory that differs from the expected state requires both pilots to verify the condition before the next phase of flight.

Condition	Sample value	Remarks
Fire Detection Loop quantity display	98 units	Normal
Traffic Advisory Display quantity display	93 units	Normal
Oxygen Distribution indication	88 units	Monitor

Chapter 07 Systems: Electrical

07.10 Description

07.10.1 Autopilot Channel A Overview

If the Window Heat is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During an extended ground delay, both pilots should monitor the Autopilot Channel B status message when conditions permit. The relief pilot will announce any change in the Wing Anti-Ice advisory and advise the other pilot before the next phase of flight. The Probe Heat selector position is expected to read within the sample range of 68 to 76 units during descent.

CAUTION: The pilot flying will monitor any change in the Bleed Air Supply switch position and advise the other pilot when conditions permit. If the Nosewheel Steering is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

If the Brake Temperature Monitor is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Ground Proximity Monitor selector position that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. The Bleed Air Supply selector position is expected to read within the sample range of 87 to 96 units during a diversion. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: Refer to the related topic for additional sample context.

The Center Tank Pumps annunciation that differs from the expected state requires the Captain to verify the condition when conditions permit. During takeoff, both pilots should brief the Flap Position Indication status message if the indication does not stabilize within the sample interval. The pilot flying will announce any change in the Traffic Advisory Display selector position and advise the other pilot if a discrepancy is observed. The captain will record any change in the Thrust Reverser switch position and advise the other pilot when conditions permit. If the Cargo Smoke Detection is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

During landing, the pilot flying should brief the Fire Detection Loop quantity display unless directed otherwise by the Sample Operations Center. The relief pilot will record any change in the Hydraulic System B status message and advise the other pilot when conditions permit. During a maintenance-requested ground run, the pilot monitoring should confirm the Fire Detection Loop quantity display when conditions permit. The Ground Proximity Monitor switch position is expected to read within the sample range of 27 to 33 units during climb.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice selector position is expected to read within the sample range of 70 to 80 units during engine start.

07.10.2 Autothrottle Interfaces

If the Center Tank Pumps is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Window Heat indication and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Thrust Reverser quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed.

The Window Heat advisory is expected to read within the sample range of 71 to 76 units during preflight. If the Auxiliary Power Unit is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

CAUTION: The Autobrake Selector annunciation that differs from the expected state requires the First Officer to verify the condition before the next phase of flight.

- If the Speedbrake Handle is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The Probe Heat indication is expected to read within the sample range of 46 to 51 units during parking.
- Refer to the related topic for additional sample context.
- Values in this manual are invented and must not be used for any operational purpose.
- During preflight, the pilot monitoring should confirm the Brake Temperature Monitor switch position once the checklist item is complete.

Condition	Sample value	Remarks
Hydraulic System B indication	82 units	Monitor
Weather Radar switch position	78 units	Normal
Autopilot Channel A advisory	29 units	Monitor
Fire Detection Loop indication	52 units	Normal
Standby Hydraulic indication	52 units	Monitor
Thrust Reverser advisory	15 units	Refer to related topic
Hydraulic System B advisory	95 units	Normal

- If the Standby Instruments is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.
- If the Window Heat is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.
- The Ground Proximity Monitor quantity display is expected to read within the sample range of 7 to 14 units during a diversion.
- The Window Heat selector position is expected to read within the sample range of 36 to 39 units during a maintenance-requested ground run.
- The Fuel Crossfeed switch position is expected to read within the sample range of 51 to 62 units during approach.

The Center Tank Pumps quantity display that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The Window Heat indication that differs from the expected state requires the pilot monitoring to cross-check the condition unless directed otherwise by the Sample Operations Center. The Hydraulic System B indication that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. The pilot monitoring will record any change in the Pack Temperature Control status message and advise the other pilot before the next phase of flight.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection selector position that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed.

07.10.3 Speedbrake Handle Indications

The pilot flying will record any change in the Autothrottle advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flap Position Indication indication that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. The Fuel Crossfeed annunciation that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center. The first officer will verify any change in the Standby Hydraulic indication and advise the other pilot once the checklist item is complete. The Primary Electrical Bus annunciation that differs from the expected state

requires the pilot monitoring to monitor the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Standby Instruments status message	96 units	Refer to related topic
Transponder status message	12 units	Advisory only
Window Heat switch position	2 units	Normal
Nosewheel Steering quantity display	75 units	Monitor
Weather Radar annunciation	30 units	Monitor
Auxiliary Power Unit indication	27 units	Monitor
Thrust Reverser indication	79 units	Normal

The Cabin Pressure Controller annunciation is expected to read within the sample range of 52 to 62 units during a turnaround. The Primary Electrical Bus switch position is expected to read within the sample range of 49 to 58 units during preflight. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the relief pilot should select the Probe Heat status message unless directed otherwise by the Sample Operations Center. If the Traffic Advisory Display is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

NOTE: The Cargo Smoke Detection advisory that differs from the expected state requires the Captain to announce the condition before the next phase of flight.

CAUTION: If the Primary Electrical Bus is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

The Oxygen Distribution indication that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated. The Fuel Crossfeed quantity display is expected to read within the sample range of 33 to 44 units during approach. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The first officer will announce any change in the Stall Warning indication and advise the other pilot when the associated caution light remains illuminated.

07.10.4 Autopilot Channel A Crew Awareness

Both pilots will record any change in the Autopilot Channel A indication and advise the other pilot before the next phase of flight. The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot flying to verify the condition when conditions permit. The Window Heat switch position that differs from the expected state requires both pilots to confirm the condition before the next phase of flight. The pilot flying will monitor any change in the Nosewheel Steering advisory and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Autopilot Channel B quantity display	11 units	Normal
Cargo Smoke Detection switch position	37 units	Advisory only
Standby Hydraulic indication	61 units	Advisory only
Autobrake Selector selector position	82 units	Monitor

- The Center Tank Pumps indication is expected to read within the sample range of 48 to 54 units during a turnaround.
- If the Autobrake Selector is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- The Auxiliary Power Unit advisory is expected to read within the sample range of 98 to 103 units during engine start.

- The first officer will confirm any change in the Standby Instruments quantity display and advise the other pilot once the checklist item is complete.
- During landing, the Captain should verify the Probe Heat selector position before the next phase of flight.
- During climb, the First Officer should brief the Bleed Air Supply selector position before the next phase of flight.
- If the Pack Temperature Control is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.
- During engine start, the pilot monitoring should monitor the Fire Detection Loop selector position when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Engine Anti-Ice is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- The captain will announce any change in the Landing Gear Indication indication and advise the other pilot when conditions permit.

Refer to the related topic for additional sample context. During parking, the relief pilot should cross-check the Center Tank Pumps advisory if the indication does not stabilize within the sample interval. The captain will cross-check any change in the Flap Position Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice quantity display that differs from the expected state requires the Captain to monitor the condition when conditions permit. During a maintenance-requested ground run, the pilot flying should monitor the Ground Proximity Monitor quantity display before the next phase of flight.

Condition	Sample value	Remarks
Window Heat quantity display	33 units	Monitor
Landing Gear Indication advisory	2 units	Refer to related topic
Standby Instruments switch position	75 units	Refer to related topic
Ground Proximity Monitor status message	32 units	Monitor
Landing Gear Indication switch position	86 units	Refer to related topic

The captain will cross-check any change in the Weather Radar status message and advise the other pilot when operating at a sample station without ground power. During taxi, the First Officer should monitor the Standby Instruments selector position if a discrepancy is observed. If the Engine Anti-Ice is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

CAUTION: The Flight Management Computer advisory that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

07.10.5 Transponder Interfaces

The pilot flying will record any change in the Pack Temperature Control status message and advise the other pilot when conditions permit. The Thrust Reverser advisory is expected to read within the sample range of 7 to 10 units during preflight. The pilot monitoring will select any change in the Weather Radar switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller annunciation that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. If the Flap Position Indication is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. During a diversion, both pilots should cross-check the Cabin Pressure Controller switch position if a discrepancy is observed. See 17.20.2 Flight Management Computer Indications.

- Values in this manual are invented and must not be used for any operational purpose.

- The Bleed Air Supply selector position that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power.
- The Fuel Crossfeed annunciation is expected to read within the sample range of 90 to 102 units during approach.
- The Center Tank Pumps annunciation that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated.
- The pilot monitoring will monitor any change in the Wing Anti-Ice advisory and advise the other pilot when conditions permit.

CAUTION: Refer to the related topic for additional sample context. The Autopilot Channel B switch position that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval.

NOTE: During descent, the First Officer should cross-check the Hydraulic System A quantity display unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus status message that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.

- If the Hydraulic System B is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- The Speedbrake Handle status message that differs from the expected state requires the relief pilot to brief the condition when conditions permit.
- If the Probe Heat is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- The relief pilot will brief any change in the Bleed Air Supply annunciation and advise the other pilot when operating at a sample station without ground power.
- The Landing Gear Indication advisory that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed.
- During cruise, the pilot flying should confirm the Cabin Pressure Controller switch position if the indication does not stabilize within the sample interval.
- The Landing Gear Indication advisory is expected to read within the sample range of 98 to 107 units during landing.
- During approach, the pilot flying should announce the Standby Hydraulic indication before the next phase of flight.

Condition	Sample value	Remarks
Fuel Crossfeed status message	61 units	Monitor
Center Tank Pumps switch position	8 units	Normal
Standby Hydraulic status message	32 units	Monitor
Hydraulic System A selector position	19 units	Advisory only
Ground Proximity Monitor annunciation	37 units	Normal
Transponder quantity display	31 units	Monitor

Condition	Sample value	Remarks
Ground Proximity Monitor annunciation	24 units	Monitor
Speedbrake Handle quantity display	31 units	Advisory only
Autopilot Channel B selector position	93 units	Monitor
Engine Anti-Ice status message	22 units	Advisory only

Speedbrake Handle advisory	62 units	Normal
Nosewheel Steering annunciation	56 units	Normal

Condition	Sample value	Remarks
Weather Radar status message	6 units	Normal
Weather Radar annunciation	91 units	Refer to related topic
Engine Anti-Ice indication	18 units	Refer to related topic
Landing Gear Indication status message	15 units	Advisory only
Fire Detection Loop status message	18 units	Advisory only
Hydraulic System B quantity display	23 units	Refer to related topic
Autothrottle selector position	69 units	Advisory only

07.10.6 Standby Instruments Crew Awareness

If the Bleed Air Supply is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Transponder switch position that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Standby Hydraulic quantity display is expected to read within the sample range of 20 to 25 units during descent. If the Landing Gear Indication is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Cabin Pressure Controller indication is expected to read within the sample range of 48 to 58 units during a turnaround.

- If the Brake Temperature Monitor is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- The relief pilot will verify any change in the Speedbrake Handle quantity display and advise the other pilot if a discrepancy is observed.
- The Fire Detection Loop status message is expected to read within the sample range of 52 to 63 units during engine start.
- The relief pilot will confirm any change in the Flap Position Indication indication and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Transponder is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

The captain will cross-check any change in the Window Heat status message and advise the other pilot when conditions permit. The Transponder status message that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. During a maintenance-requested ground run, the pilot monitoring should cross-check the Hydraulic System A annunciation when the associated caution light remains illuminated. The relief pilot will verify any change in the Traffic Advisory Display switch position and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Bleed Air Supply switch position that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed.

NOTE: The Stall Warning switch position is expected to read within the sample range of 37 to 41 units during a turnaround.

During climb, the relief pilot should brief the Cockpit Voice Recorder quantity display once the checklist item is complete. During approach, the pilot flying should record the Fuel Crossfeed status message before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

07.10.7 Cargo Smoke Detection Overview

The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the relief pilot should cross-check the Standby Hydraulic quantity display if the indication does not stabilize within the sample interval. If the Thrust Reverser is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. See 10.20.5 Speedbrake Handle Overview.

CAUTION: The relief pilot will brief any change in the Bleed Air Supply annunciation and advise the other pilot if a discrepancy is observed. The Oxygen Distribution indication that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the pilot flying should announce the Fire Detection Loop indication once the checklist item is complete.

- Refer to the related topic for additional sample context.
- Both pilots will brief any change in the Bleed Air Supply indication and advise the other pilot if the indication does not stabilize within the sample interval.
- The Thrust Reverser switch position is expected to read within the sample range of 18 to 30 units during a maintenance-requested ground run.
- If the Speedbrake Handle is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- During a maintenance-requested ground run, the Captain should announce the Stall Warning annunciation unless directed otherwise by the Sample Operations Center.

NOTE: During climb, the Captain should brief the Ground Proximity Monitor indication unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Window Heat switch position	50 units	Monitor
Brake Temperature Monitor annunciation	15 units	Refer to related topic
Oxygen Distribution selector position	80 units	Advisory only
Speedbrake Handle annunciation	95 units	Advisory only
Window Heat switch position	82 units	Advisory only
Brake Temperature Monitor quantity display	55 units	Normal
Cockpit Voice Recorder selector position	91 units	Monitor

07.10.8 Cabin Pressure Controller Indications

Both pilots will monitor any change in the Primary Electrical Bus annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Thrust Reverser switch position is expected to read within the sample range of 73 to 82 units during climb. The first officer will record any change in the Primary Electrical Bus indication and advise the other pilot when operating at a sample station without ground power.

During preflight, the Captain should verify the Hydraulic System B switch position when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. Both

pilots will monitor any change in the Bleed Air Supply selector position and advise the other pilot once the checklist item is complete. If the Brake Temperature Monitor is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

- The Pack Temperature Control switch position is expected to read within the sample range of 70 to 75 units during taxi.
- The Autopilot Channel A quantity display is expected to read within the sample range of 95 to 107 units during cruise.
- Both pilots will select any change in the Ground Proximity Monitor annunciation and advise the other pilot if a discrepancy is observed.
- The Pack Temperature Control switch position is expected to read within the sample range of 42 to 52 units during cruise.
- The Oxygen Distribution quantity display that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight.
- The captain will monitor any change in the Wing Anti-Ice selector position and advise the other pilot before the next phase of flight.
- The Fuel Crossfeed selector position that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval.
- The Fire Detection Loop indication is expected to read within the sample range of 73 to 78 units during climb.

CAUTION: During approach, the relief pilot should brief the Speedbrake Handle status message when conditions permit.

Refer to the related topic for additional sample context. The Stall Warning quantity display that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. The Bleed Air Supply indication is expected to read within the sample range of 8 to 18 units during taxi. If the Fire Detection Loop is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Standby Instruments status message is expected to read within the sample range of 29 to 39 units during takeoff. During engine start, both pilots should confirm the Stall Warning switch position once the checklist item is complete.

NOTE: The Stall Warning status message that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed.

07.10.9 Fuel Crossfeed Indications

The Stall Warning selector position that differs from the expected state requires the Captain to record the condition before the next phase of flight. The Engine Anti-Ice indication is expected to read within the sample range of 8 to 14 units during approach. During takeoff, the Captain should confirm the Hydraulic System A indication unless directed otherwise by the Sample Operations Center. The Speedbrake Handle annunciation that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. If the Fire Detection Loop is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Standby Hydraulic switch position that differs from the expected state requires the Captain to select the condition if a discrepancy is observed.
- During approach, the First Officer should verify the Pack Temperature Control switch position if a discrepancy is observed.

The captain will record any change in the Transponder quantity display and advise the other pilot if the indication does not stabilize within the sample interval. If the Hydraulic System B is inoperative, continue descent only after the

pilot flying has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Hydraulic System B quantity display is expected to read within the sample range of 13 to 22 units during cruise.

CAUTION: The relief pilot will monitor any change in the Autobrake Selector quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

The pilot flying will select any change in the Stall Warning advisory and advise the other pilot when the associated caution light remains illuminated. During a diversion, the Captain should confirm the Flap Position Indication indication unless directed otherwise by the Sample Operations Center. If the Landing Gear Indication is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. During landing, the Captain should verify the Cabin Pressure Controller quantity display when conditions permit. If the Weather Radar is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During a diversion, the relief pilot should brief the Engine Anti-Ice switch position before the next phase of flight.

During descent, the First Officer should record the Cockpit Voice Recorder annunciation unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. If the Nosewheel Steering is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Standby Hydraulic indication is expected to read within the sample range of 67 to 73 units during parking. The Pack Temperature Control switch position is expected to read within the sample range of 29 to 39 units during approach.

- The Flap Position Indication indication is expected to read within the sample range of 84 to 91 units during preflight.
- The Landing Gear Indication advisory is expected to read within the sample range of 46 to 52 units during climb.
- The Flap Position Indication indication is expected to read within the sample range of 72 to 83 units during a diversion.
- Refer to the related topic for additional sample context.
- If the Autothrottle is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- The Transponder selector position is expected to read within the sample range of 53 to 60 units during climb.

07.10.10 Weather Radar Test

The Hydraulic System B annunciation that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated. Both pilots will verify any change in the Hydraulic System A indication and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The Cabin Pressure Controller status message is expected to read within the sample range of 87 to 95 units during landing.

If the Autopilot Channel A is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Hydraulic System B status message is expected to read within the sample range of 29 to 36 units during cruise. The Probe Heat advisory is expected to read within the sample range of 60 to 72 units during engine start. Both pilots will cross-check any change in the Fuel Crossfeed quantity display and advise the other pilot before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the pilot monitoring should announce the Primary Electrical Bus switch position once the checklist item is complete. The

captain will verify any change in the Nosewheel Steering switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display status message is expected to read within the sample range of 64 to 69 units during takeoff. The wording here is placeholder content shaped like a procedure, not a procedure.

The Autothrottle advisory is expected to read within the sample range of 28 to 35 units during engine start. If the Nosewheel Steering is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. If the Pack Temperature Control is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Autopilot Channel A quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Flight Management Computer quantity display	71 units	Normal
Autopilot Channel B quantity display	3 units	Advisory only
Thrust Reverser indication	74 units	Monitor

The relief pilot will announce any change in the Bleed Air Supply selector position and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel B selector position that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval.

The Bleed Air Supply switch position is expected to read within the sample range of 89 to 96 units during cruise. The Flap Position Indication quantity display that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. The Speedbrake Handle quantity display is expected to read within the sample range of 58 to 63 units during a turnaround.

Values in this manual are invented and must not be used for any operational purpose. Both pilots will record any change in the Autopilot Channel B quantity display and advise the other pilot when the associated caution light remains illuminated. The Probe Heat status message is expected to read within the sample range of 74 to 86 units during engine start. If the Cargo Smoke Detection is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Window Heat switch position that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.

- The Fuel Crossfeed annunciation that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power.
- The Bleed Air Supply annunciation is expected to read within the sample range of 12 to 20 units during an extended ground delay.
- The Ground Proximity Monitor advisory is expected to read within the sample range of 57 to 68 units during preflight.
- The Flight Management Computer status message is expected to read within the sample range of 63 to 66 units during taxi.
- If the Hydraulic System A is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- The Landing Gear Indication status message that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete.

07.10.11 Traffic Advisory Display Normal Operation

The Weather Radar advisory that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. Both pilots will select any change in the Autothrottle advisory and advise the other pilot before the next phase of flight. The Auxiliary Power Unit selector position is expected to read within the sample range of 98 to 103 units during preflight.

If the Standby Hydraulic is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat switch position is expected to read within the sample range of 63 to 71 units during preflight.

If the Bleed Air Supply is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. During parking, both pilots should select the Engine Anti-Ice selector position when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will cross-check any change in the Flap Position Indication selector position and advise the other pilot when operating at a sample station without ground power. If the Autothrottle is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Weather Radar annunciation that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Hydraulic System A advisory	13 units	Monitor
Hydraulic System A advisory	21 units	Refer to related topic
Speedbrake Handle indication	73 units	Monitor
Transponder quantity display	62 units	Refer to related topic

CAUTION: The Cockpit Voice Recorder indication is expected to read within the sample range of 5 to 13 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure.

Values in this manual are invented and must not be used for any operational purpose. If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. During descent, the Captain should monitor the Primary Electrical Bus annunciation once the checklist item is complete. The Cargo Smoke Detection switch position is expected to read within the sample range of 63 to 68 units during engine start. The Stall Warning annunciation is expected to read within the sample range of 64 to 68 units during engine start. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Engine Anti-Ice switch position is expected to read within the sample range of 75 to 80 units during a turnaround. The Bleed Air Supply quantity display is expected to read within the sample range of 49 to 54 units during a turnaround.

07.10.12 Fuel Crossfeed Reset Guidance

During a maintenance-requested ground run, both pilots should confirm the Autothrottle switch position when conditions permit. The Landing Gear Indication switch position is expected to read within the sample range of 51 to 61 units during takeoff. During taxi, the First Officer should cross-check the Primary Electrical Bus advisory before the next phase of flight. The first officer will cross-check any change in the Autobrake Selector switch position and advise the other pilot before the next phase of flight. The Cabin Pressure Controller annunciation that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center.

The Fire Detection Loop status message that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center. If the Cargo Smoke Detection is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, the First Officer should confirm the Flight Management Computer indication if the indication does not stabilize within the sample interval. The first officer will select any change in the Oxygen Distribution status message and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autothrottle indication	47 units	Normal
Brake Temperature Monitor quantity display	31 units	Normal
Center Tank Pumps switch position	13 units	Normal
Transponder annunciation	50 units	Monitor
Cabin Pressure Controller advisory	47 units	Monitor
Autopilot Channel A quantity display	76 units	Refer to related topic
Flap Position Indication indication	65 units	Normal

The Pack Temperature Control advisory that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. The Cargo Smoke Detection selector position that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval. During landing, the First Officer should confirm the Engine Anti-Ice annunciation if the indication does not stabilize within the sample interval. During landing, the relief pilot should verify the Primary Electrical Bus advisory unless directed otherwise by the Sample Operations Center. The Standby Instruments switch position is expected to read within the sample range of 56 to 67 units during parking. The Nosewheel Steering selector position that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.

CAUTION: The Weather Radar annunciation that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power.

07.10.13 Autopilot Channel A Interfaces

The Hydraulic System B status message is expected to read within the sample range of 50 to 58 units during engine start. Both pilots will announce any change in the Standby Hydraulic advisory and advise the other pilot when operating at a sample station without ground power. The Wing Anti-Ice selector position that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The Landing Gear Indication status message that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated. If the Weather Radar is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. During parking, the Captain should verify the Traffic Advisory Display quantity display when conditions permit.

The Landing Gear Indication quantity display that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit. The Landing Gear Indication annunciation that differs from the expected state requires the Captain to record the condition before the next phase of flight. The relief pilot will verify any change in the Autopilot Channel A quantity display and advise the other pilot when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The Weather Radar quantity display that differs from the expected state requires the pilot flying to select the condition before the next phase of flight.

If the Bleed Air Supply is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The captain will announce any change in the Hydraulic System A indication and advise the other pilot when conditions permit. The Thrust Reverser quantity display is expected to read within the sample range of 12 to 19 units during preflight.

NOTE: During climb, the pilot flying should select the Autothrottle advisory when operating at a sample station without ground power.

If the Wing Anti-Ice is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. During cruise, the Captain should brief the Center Tank Pumps status message when operating at a sample station without ground power. The first officer will brief any change in the Landing Gear Indication selector position and advise the other pilot before the next phase of flight. Both pilots will cross-check any change in the Bleed

Air Supply switch position and advise the other pilot once the checklist item is complete. If the Flap Position Indication is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During an extended ground delay, the pilot flying should verify the Nosewheel Steering indication when conditions permit.

- The Autothrottle switch position is expected to read within the sample range of 56 to 62 units during taxi.
- During parking, the relief pilot should verify the Autopilot Channel A quantity display once the checklist item is complete.
- During parking, the pilot monitoring should record the Primary Electrical Bus switch position if a discrepancy is observed.
- If the Probe Heat is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The Center Tank Pumps advisory that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed.

The Hydraulic System B switch position is expected to read within the sample range of 67 to 76 units during an extended ground delay. The Ground Proximity Monitor status message that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power. The pilot flying will brief any change in the Engine Anti-Ice indication and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the pilot monitoring should monitor the Window Heat status message if a discrepancy is observed. The Window Heat selector position is expected to read within the sample range of 63 to 70 units during engine start.

07.10.14 Cargo Smoke Detection Test

If the Weather Radar is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Nosewheel Steering advisory is expected to read within the sample range of 74 to 81 units during cruise. If the Speedbrake Handle is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Autopilot Channel B indication	17 units	Refer to related topic
Nosewheel Steering status message	97 units	Monitor
Landing Gear Indication indication	68 units	Monitor

- During engine start, the pilot flying should cross-check the Primary Electrical Bus status message when the associated caution light remains illuminated.
- The Primary Electrical Bus advisory that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed.
- If the Nosewheel Steering is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.
- During climb, the Captain should cross-check the Bleed Air Supply indication before the next phase of flight.
- If the Pack Temperature Control is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- The Landing Gear Indication indication that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit.

CAUTION: The Transponder quantity display is expected to read within the sample range of 28 to 36 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure.

During a turnaround, the relief pilot should verify the Autobrake Selector advisory when the associated caution light remains illuminated. The Cockpit Voice Recorder switch position that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. The pilot flying will confirm any change in the Pack Temperature Control indication and advise the other pilot if a discrepancy is observed. The Cargo Smoke Detection quantity display is expected to read within the sample range of 64 to 71 units during a maintenance-requested ground run.

- During descent, both pilots should verify the Hydraulic System B quantity display unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Hydraulic System B advisory is expected to read within the sample range of 81 to 85 units during takeoff.

NOTE: The Autopilot Channel A indication is expected to read within the sample range of 83 to 89 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure.

The captain will brief any change in the Cargo Smoke Detection status message and advise the other pilot when the associated caution light remains illuminated. If the Cabin Pressure Controller is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 16 to 28 units during cruise. The pilot monitoring will select any change in the Cabin Pressure Controller annunciation and advise the other pilot when conditions permit.

07.10.15 Cabin Pressure Controller Normal Operation

The captain will verify any change in the Autobrake Selector selector position and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. If the Bleed Air Supply is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

The Auxiliary Power Unit selector position is expected to read within the sample range of 93 to 104 units during taxi. The Thrust Reverser selector position that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed. The pilot flying will verify any change in the Standby Instruments selector position and advise the other pilot when the associated caution light remains illuminated. During landing, the First Officer should confirm the Probe Heat indication if the indication does not stabilize within the sample interval. The Transponder quantity display is expected to read within the sample range of 4 to 15 units during cruise.

During descent, the pilot flying should announce the Center Tank Pumps annunciation when conditions permit. The first officer will announce any change in the Cockpit Voice Recorder indication and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Autopilot Channel A status message is expected to read within the sample range of 3 to 12 units during a diversion. During takeoff, both pilots should brief the Cockpit Voice Recorder status message when operating at a sample station without ground power. During landing, the relief pilot should cross-check the Brake Temperature Monitor status message unless directed otherwise by the Sample Operations Center. During a diversion, both pilots should monitor the Ground Proximity Monitor quantity display if a discrepancy is observed. The Autopilot Channel A quantity display is expected to read within the sample range of 40 to 47 units during a diversion.

CAUTION: The captain will record any change in the Probe Heat quantity display and advise the other pilot when the associated caution light remains illuminated. During landing, the Captain should brief the Cabin Pressure Controller status message when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cargo Smoke Detection indication	64 units	Refer to related topic
Autopilot Channel B switch position	28 units	Normal
Hydraulic System B switch position	48 units	Refer to related topic
Transponder switch position	72 units	Normal

Both pilots will verify any change in the Auxiliary Power Unit annunciation and advise the other pilot when the associated caution light remains illuminated. During takeoff, the Captain should brief the Window Heat quantity display if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat switch position is expected to read within the sample range of 72 to 75 units during a diversion. The Standby Instruments quantity display is expected to read within the sample range of 44 to 55 units during descent. The Autopilot Channel A status message that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Transponder indication	32 units	Monitor
Weather Radar indication	96 units	Normal
Wing Anti-Ice annunciation	88 units	Normal
Stall Warning switch position	23 units	Refer to related topic
Autothrottle quantity display	33 units	Normal
Hydraulic System A advisory	52 units	Advisory only
Engine Anti-Ice annunciation	7 units	Monitor

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	73 units	Refer to related topic
Autobrake Selector status message	22 units	Refer to related topic
Hydraulic System A status message	37 units	Advisory only
Flight Management Computer advisory	94 units	Monitor
Landing Gear Indication indication	10 units	Normal
Flap Position Indication switch position	86 units	Advisory only
Hydraulic System A advisory	97 units	Refer to related topic

07.10.16 Auxiliary Power Unit Power Sources

The Brake Temperature Monitor annunciation is expected to read within the sample range of 82 to 85 units during preflight. If the Hydraulic System B is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Brake Temperature Monitor selector position is expected to read within the sample range of 14 to 26 units during a diversion.

The pilot flying will confirm any change in the Hydraulic System B indication and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the pilot flying should verify the Auxiliary Power Unit indication if a discrepancy is observed. During taxi, both pilots should announce the Cockpit Voice Recorder status message when operating at a sample station without ground power.

- During a maintenance-requested ground run, both pilots should select the Autothrottle indication when the associated caution light remains illuminated.
- During engine start, the pilot monitoring should monitor the Thrust Reverser advisory when conditions permit.

- If the Probe Heat is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

The Flight Management Computer advisory is expected to read within the sample range of 33 to 45 units during parking. If the Autobrake Selector is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel A switch position that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. The Cockpit Voice Recorder status message is expected to read within the sample range of 27 to 33 units during landing.

- The pilot flying will cross-check any change in the Flight Management Computer advisory and advise the other pilot when operating at a sample station without ground power.
- The Autopilot Channel A quantity display that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval.
- Both pilots will monitor any change in the Traffic Advisory Display indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Ground Proximity Monitor is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- The first officer will announce any change in the Cargo Smoke Detection selector position and advise the other pilot if a discrepancy is observed.

The Cockpit Voice Recorder annunciation is expected to read within the sample range of 30 to 40 units during preflight. The Fire Detection Loop indication that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center. The Autopilot Channel B status message is expected to read within the sample range of 39 to 43 units during taxi. The Bleed Air Supply annunciation that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power.

The Weather Radar status message is expected to read within the sample range of 29 to 36 units during cruise. The first officer will brief any change in the Cargo Smoke Detection annunciation and advise the other pilot if the indication does not stabilize within the sample interval. During parking, the Captain should cross-check the Wing Anti-Ice selector position when operating at a sample station without ground power. The Landing Gear Indication switch position that differs from the expected state requires the Captain to announce the condition when conditions permit.

Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. The Window Heat indication that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval. The Autobrake Selector selector position that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated. The Flap Position Indication switch position is expected to read within the sample range of 40 to 44 units during climb.

Refer to the related topic for additional sample context. The Pack Temperature Control advisory that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. The Fire Detection Loop advisory that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. See 05.40.13 Hydraulic System B Normal Operation.

07.20 Controls and Indicators

07.20.1 Autopilot Channel A Normal Operation

During approach, the relief pilot should monitor the Landing Gear Indication indication once the checklist item is complete. The first officer will confirm any change in the Auxiliary Power Unit quantity display and advise the other

pilot when the associated caution light remains illuminated. The Fuel Crossfeed selector position that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. During takeoff, the relief pilot should select the Stall Warning indication unless directed otherwise by the Sample Operations Center. The Speedbrake Handle quantity display that differs from the expected state requires both pilots to verify the condition when conditions permit.

Condition	Sample value	Remarks
Traffic Advisory Display annunciation	10 units	Refer to related topic
Fuel Crossfeed switch position	69 units	Refer to related topic
Oxygen Distribution status message	30 units	Advisory only
Brake Temperature Monitor advisory	13 units	Advisory only
Engine Anti-Ice advisory	33 units	Normal

If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Engine Anti-Ice annunciation is expected to read within the sample range of 21 to 32 units during engine start. The Oxygen Distribution selector position that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated. The Auxiliary Power Unit status message is expected to read within the sample range of 41 to 44 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. The first officer will announce any change in the Fire Detection Loop switch position and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the Captain should cross-check the Flap Position Indication selector position when conditions permit.

The relief pilot will announce any change in the Window Heat switch position and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, the pilot flying should monitor the Transponder indication before the next phase of flight. The Weather Radar annunciation that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. See 02.40.6 Standby Hydraulic Limits Display.

07.20.2 Hydraulic System A Normal Operation

During preflight, the pilot flying should brief the Auxiliary Power Unit status message unless directed otherwise by the Sample Operations Center. The Engine Anti-Ice switch position is expected to read within the sample range of 59 to 62 units during takeoff. The Speedbrake Handle status message is expected to read within the sample range of 47 to 52 units during an extended ground delay.

Condition	Sample value	Remarks
Pack Temperature Control switch position	9 units	Advisory only
Autopilot Channel B annunciation	69 units	Monitor
Fire Detection Loop status message	48 units	Advisory only
Standby Instruments status message	64 units	Monitor
Cabin Pressure Controller indication	12 units	Monitor

The relief pilot will record any change in the Brake Temperature Monitor advisory and advise the other pilot before the next phase of flight. Both pilots will announce any change in the Traffic Advisory Display annunciation and advise the other pilot when operating at a sample station without ground power. The Stall Warning advisory that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. The relief pilot will record any change in the Wing Anti-Ice switch position and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Fire Detection Loop quantity display	87 units	Normal
Bleed Air Supply annunciation	11 units	Normal
Traffic Advisory Display indication	34 units	Normal
Speedbrake Handle advisory	1 units	Normal
Oxygen Distribution status message	73 units	Normal
Autobrake Selector switch position	10 units	Monitor

CAUTION: If the Primary Electrical Bus is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. During parking, the First Officer should confirm the Bleed Air Supply selector position when operating at a sample station without ground power.

07.20.3 Thrust Reverser Crew Awareness

This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. The relief pilot will announce any change in the Window Heat status message and advise the other pilot once the checklist item is complete. The Flap Position Indication quantity display is expected to read within the sample range of 13 to 20 units during approach.

During an extended ground delay, the First Officer should cross-check the Window Heat advisory when operating at a sample station without ground power. Both pilots will cross-check any change in the Weather Radar annunciation and advise the other pilot when conditions permit. During descent, the relief pilot should brief the Auxiliary Power Unit advisory if a discrepancy is observed. During an extended ground delay, the pilot flying should record the Hydraulic System B annunciation unless directed otherwise by the Sample Operations Center.

- The Landing Gear Indication quantity display is expected to read within the sample range of 91 to 103 units during cruise.
- If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- If the Autopilot Channel A is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- The Center Tank Pumps quantity display is expected to read within the sample range of 51 to 62 units during climb.

Condition	Sample value	Remarks
Cabin Pressure Controller selector position	51 units	Monitor
Hydraulic System B advisory	44 units	Refer to related topic
Bleed Air Supply annunciation	62 units	Monitor
Weather Radar switch position	66 units	Monitor
Autothrottle indication	31 units	Advisory only

- The relief pilot will record any change in the Engine Anti-Ice status message and advise the other pilot if the indication does not stabilize within the sample interval.
- During taxi, the Captain should record the Primary Electrical Bus status message before the next phase of flight.
- During climb, the pilot flying should confirm the Wing Anti-Ice advisory when the associated caution light remains illuminated.
- If the Autopilot Channel B is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

During climb, both pilots should select the Cockpit Voice Recorder advisory unless directed otherwise by the Sample Operations Center. During an extended ground delay, the pilot flying should confirm the Fire Detection Loop status message before the next phase of flight. The Cabin Pressure Controller advisory is expected to read within the sample range of 91 to 102 units during engine start. The Probe Heat switch position that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed. During descent, the Captain should select the Hydraulic System A quantity display when conditions permit. The Fuel Crossfeed status message that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.

07.20.4 Wing Anti-Ice Normal Operation

During descent, the pilot monitoring should monitor the Stall Warning selector position when operating at a sample station without ground power. Both pilots will record any change in the Cargo Smoke Detection advisory and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

Refer to the related topic for additional sample context. The pilot monitoring will brief any change in the Bleed Air Supply status message and advise the other pilot if the indication does not stabilize within the sample interval. During approach, the relief pilot should record the Ground Proximity Monitor selector position before the next phase of flight. The Stall Warning status message that differs from the expected state requires the Captain to select the condition when conditions permit. If the Brake Temperature Monitor is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

- Refer to the related topic for additional sample context.
- The Nosewheel Steering selector position is expected to read within the sample range of 54 to 64 units during descent.
- The Stall Warning indication that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval.
- The first officer will cross-check any change in the Thrust Reverser switch position and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The Auxiliary Power Unit selector position is expected to read within the sample range of 25 to 30 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure.

The wording here is placeholder content shaped like a procedure, not a procedure. During landing, both pilots should select the Pack Temperature Control selector position when operating at a sample station without ground power. The captain will confirm any change in the Standby Instruments selector position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Traffic Advisory Display switch position is expected to read within the sample range of 65 to 68 units during parking. During approach, the pilot flying should monitor the Landing Gear Indication switch position unless directed otherwise by the Sample Operations Center.

- The Bleed Air Supply selector position that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed.
- Both pilots will verify any change in the Oxygen Distribution annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Autopilot Channel A is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The Brake Temperature Monitor advisory is expected to read within the sample range of 7 to 17 units during preflight.

- During a diversion, the relief pilot should select the Fire Detection Loop switch position if a discrepancy is observed.

NOTE: If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

07.20.5 Fuel Crossfeed Test

The Traffic Advisory Display annunciation that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed. During a turnaround, the pilot flying should announce the Nosewheel Steering indication if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Wing Anti-Ice selector position is expected to read within the sample range of 95 to 104 units during landing. The Autopilot Channel B quantity display that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.

CAUTION: The pilot monitoring will brief any change in the Standby Instruments advisory and advise the other pilot if a discrepancy is observed.

The Oxygen Distribution advisory is expected to read within the sample range of 49 to 52 units during a diversion. The Center Tank Pumps switch position that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power. The Bleed Air Supply selector position that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. The Autobrake Selector switch position that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete.

During climb, both pilots should select the Autobrake Selector annunciation if the indication does not stabilize within the sample interval. Both pilots will select any change in the Autothrottle advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Thrust Reverser switch position is expected to read within the sample range of 41 to 51 units during cruise.

NOTE: The Standby Hydraulic status message that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center. During a turnaround, the First Officer should cross-check the Autobrake Selector annunciation before the next phase of flight.

The Flight Management Computer advisory is expected to read within the sample range of 6 to 13 units during approach. The first officer will confirm any change in the Thrust Reverser annunciation and advise the other pilot if a discrepancy is observed. During descent, the relief pilot should select the Center Tank Pumps advisory unless directed otherwise by the Sample Operations Center. The Landing Gear Indication advisory that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval.

CAUTION: If the Wing Anti-Ice is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

07.20.6 Auxiliary Power Unit Limits Display

If the Cargo Smoke Detection is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The Transponder switch position is expected to read within the sample range of 78 to 87 units during preflight. The first officer will announce any change in the Engine Anti-Ice quantity display and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Cargo Smoke Detection annunciation is expected to read within the sample range of 35 to 39 units during descent.

NOTE: The captain will cross-check any change in the Window Heat switch position and advise the other pilot when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The Brake Temperature Monitor quantity display that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. If the Pack Temperature Control is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

During climb, the relief pilot should confirm the Engine Anti-Ice quantity display when conditions permit. The Wing Anti-Ice indication that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. The captain will announce any change in the Pack Temperature Control annunciation and advise the other pilot before the next phase of flight. During climb, the First Officer should confirm the Bleed Air Supply switch position before the next phase of flight. The pilot flying will record any change in the Cargo Smoke Detection status message and advise the other pilot when the associated caution light remains illuminated. During descent, the pilot flying should brief the Bleed Air Supply status message once the checklist item is complete.

CAUTION: Both pilots will record any change in the Flight Management Computer status message and advise the other pilot if the indication does not stabilize within the sample interval.

07.20.7 Auxiliary Power Unit Crew Awareness

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat advisory that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. If the Primary Electrical Bus is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

- The Nosewheel Steering indication that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.
- Values in this manual are invented and must not be used for any operational purpose.
- The Center Tank Pumps switch position that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval.
- The Engine Anti-Ice switch position is expected to read within the sample range of 72 to 76 units during taxi.

The Oxygen Distribution status message that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. The pilot monitoring will record any change in the Bleed Air Supply status message and advise the other pilot once the checklist item is complete. During descent, the pilot monitoring should select the Pack Temperature Control quantity display before the next phase of flight. The first officer will cross-check any change in the Probe Heat status message and advise the other pilot when the associated caution light remains illuminated. The Standby Hydraulic quantity display is expected to read within the sample range of 33 to 43 units during cruise. During taxi, the pilot flying should monitor the Pack Temperature Control selector position when operating at a sample station without ground power.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder annunciation that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated.

If the Landing Gear Indication is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue takeoff only after both pilots have reviewed the associated sample guidance.

NOTE: Both pilots will record any change in the Brake Temperature Monitor advisory and advise the other pilot when the associated caution light remains illuminated.

The Wing Anti-Ice switch position that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed. If the Autobrake Selector is inoperative, continue taxi only after the Captain has reviewed

the associated sample guidance. If the Flap Position Indication is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, the pilot flying should select the Auxiliary Power Unit advisory before the next phase of flight. During taxi, the relief pilot should select the Auxiliary Power Unit selector position when the associated caution light remains illuminated.

The pilot monitoring will cross-check any change in the Brake Temperature Monitor switch position and advise the other pilot when the associated caution light remains illuminated. The Stall Warning annunciation is expected to read within the sample range of 96 to 107 units during an extended ground delay. The Stall Warning advisory that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center.

07.20.8 Brake Temperature Monitor Status Messages

The pilot monitoring will record any change in the Standby Hydraulic annunciation and advise the other pilot once the checklist item is complete. The Window Heat quantity display is expected to read within the sample range of 28 to 31 units during descent. If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will record any change in the Autothrottle status message and advise the other pilot before the next phase of flight.

CAUTION: The Brake Temperature Monitor status message that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval.

The pilot flying will verify any change in the Engine Anti-Ice annunciation and advise the other pilot when the associated caution light remains illuminated. The Stall Warning switch position that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center. The captain will verify any change in the Thrust Reverser quantity display and advise the other pilot when the associated caution light remains illuminated. During descent, both pilots should brief the Autobrake Selector indication unless directed otherwise by the Sample Operations Center. If the Stall Warning is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

During preflight, the pilot flying should announce the Center Tank Pumps annunciation before the next phase of flight. The Hydraulic System A advisory that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. During cruise, both pilots should record the Autothrottle quantity display before the next phase of flight. During a maintenance-requested ground run, the pilot monitoring should monitor the Standby Instruments annunciation if a discrepancy is observed. During a maintenance-requested ground run, the Captain should verify the Flight Management Computer status message when operating at a sample station without ground power.

The Stall Warning indication is expected to read within the sample range of 70 to 81 units during climb. During takeoff, the Captain should monitor the Primary Electrical Bus advisory if the indication does not stabilize within the sample interval. If the Cargo Smoke Detection is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. See 03.10.13 Checklist: Engine Anti-Ice.

CAUTION: The Autobrake Selector switch position that differs from the expected state requires the Captain to verify the condition before the next phase of flight. If the Landing Gear Indication is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

07.20.9 Oxygen Distribution Interfaces

The captain will announce any change in the Ground Proximity Monitor annunciation and advise the other pilot when conditions permit. During engine start, the First Officer should cross-check the Window Heat status message when conditions permit. The first officer will verify any change in the Probe Heat indication and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The pilot monitoring will announce any change in the Autothrottle status message and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autobrake Selector quantity display	53 units	Monitor
Bleed Air Supply status message	2 units	Advisory only
Nosewheel Steering status message	20 units	Monitor
Nosewheel Steering switch position	19 units	Monitor

NOTE: The Hydraulic System B advisory that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power.

NOTE: The Bleed Air Supply switch position that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.

The Fuel Crossfeed indication is expected to read within the sample range of 84 to 94 units during a turnaround. During an extended ground delay, the First Officer should monitor the Speedbrake Handle annunciation once the checklist item is complete. If the Autopilot Channel A is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The Landing Gear Indication annunciation that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. The Probe Heat indication that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval. The Standby Hydraulic indication that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated.

The pilot flying will cross-check any change in the Center Tank Pumps quantity display and advise the other pilot when the associated caution light remains illuminated. During landing, the First Officer should brief the Fire Detection Loop indication once the checklist item is complete. During climb, the Captain should verify the Auxiliary Power Unit quantity display unless directed otherwise by the Sample Operations Center. During descent, the Captain should select the Standby Hydraulic status message if the indication does not stabilize within the sample interval. The Fuel Crossfeed annunciation that differs from the expected state requires the First Officer to record the condition when conditions permit.

- If the Cockpit Voice Recorder is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- If the Flight Management Computer is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Center Tank Pumps selector position that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete.
- If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

The relief pilot will monitor any change in the Autobrake Selector selector position and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Hydraulic quantity display is expected to read within the sample range of 48 to 55 units during taxi.

07.20.10 Flight Management Computer Status Messages

During an extended ground delay, the pilot monitoring should select the Traffic Advisory Display switch position if the indication does not stabilize within the sample interval. The Bleed Air Supply selector position is expected to read

within the sample range of 5 to 15 units during an extended ground delay. During an extended ground delay, the First Officer should verify the Probe Heat indication if the indication does not stabilize within the sample interval. If the Speedbrake Handle is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. During approach, both pilots should monitor the Hydraulic System B annunciation when conditions permit.

Condition	Sample value	Remarks
Speedbrake Handle advisory	55 units	Monitor
Hydraulic System B advisory	21 units	Monitor
Window Heat status message	96 units	Refer to related topic
Center Tank Pumps annunciation	89 units	Refer to related topic

CAUTION: If the Flight Management Computer is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

CAUTION: The pilot monitoring will select any change in the Autopilot Channel B switch position and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Traffic Advisory Display selector position	58 units	Advisory only
Speedbrake Handle indication	71 units	Monitor
Standby Instruments annunciation	80 units	Advisory only
Speedbrake Handle advisory	12 units	Advisory only
Wing Anti-Ice status message	81 units	Refer to related topic
Stall Warning quantity display	94 units	Advisory only
Engine Anti-Ice switch position	14 units	Refer to related topic

The Hydraulic System B annunciation is expected to read within the sample range of 97 to 104 units during preflight. If the Flap Position Indication is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Primary Electrical Bus is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. During parking, the First Officer should confirm the Hydraulic System B advisory unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

The Probe Heat switch position is expected to read within the sample range of 32 to 40 units during a turnaround. If the Oxygen Distribution is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Fire Detection Loop quantity display and advise the other pilot when the associated caution light remains illuminated. During taxi, the Captain should record the Stall Warning advisory before the next phase of flight.

07.20.11 New Sample Topic: Thrust Reverser

This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor switch position that differs from the expected state requires the relief pilot to record the condition before the next phase of flight. The captain will record any change in the Weather Radar status message and advise the other pilot if the indication does not stabilize within the sample interval. The Cabin Pressure Controller quantity display that differs from the expected state requires the Captain to select the condition before the next phase of flight. The Fuel Crossfeed advisory is expected to read within the sample range of 2 to 13 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure.

During engine start, the First Officer should brief the Ground Proximity Monitor selector position if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. If the Pack Temperature Control is inoperative, continue climb only after the Captain has reviewed the associated sample

guidance. The Autopilot Channel B status message that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight. The relief pilot will brief any change in the Landing Gear Indication status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

- Values in this manual are invented and must not be used for any operational purpose.
- During landing, the pilot monitoring should monitor the Hydraulic System B annunciation once the checklist item is complete.
- The first officer will select any change in the Window Heat selector position and advise the other pilot if a discrepancy is observed.
- If the Window Heat is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

The Flap Position Indication annunciation that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power. During climb, the relief pilot should confirm the Standby Instruments indication if the indication does not stabilize within the sample interval. If the Hydraulic System A is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The captain will monitor any change in the Standby Hydraulic selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will announce any change in the Center Tank Pumps indication and advise the other pilot when the associated caution light remains illuminated.

The Ground Proximity Monitor selector position is expected to read within the sample range of 53 to 56 units during an extended ground delay. If the Probe Heat is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Primary Electrical Bus selector position is expected to read within the sample range of 40 to 46 units during engine start. The Oxygen Distribution selector position that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System A is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The Oxygen Distribution switch position that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A switch position that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated.

The pilot flying will monitor any change in the Auxiliary Power Unit switch position and advise the other pilot if a discrepancy is observed. Both pilots will brief any change in the Standby Instruments annunciation and advise the other pilot when the associated caution light remains illuminated. The Stall Warning status message that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. The Oxygen Distribution advisory that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete. During approach, the First Officer should monitor the Center Tank Pumps advisory when operating at a sample station without ground power. The Ground Proximity Monitor selector position that differs from the expected state requires both pilots to confirm the condition when conditions permit.

07.20.12 Probe Heat Overview

The Traffic Advisory Display indication is expected to read within the sample range of 17 to 24 units during landing. If the Fire Detection Loop is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Thrust Reverser quantity display is expected to read within the sample range of 69 to 75 units

during approach.

Refer to the related topic for additional sample context. If the Transponder is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. During cruise, the pilot monitoring should select the Probe Heat switch position before the next phase of flight.

During taxi, both pilots should record the Ground Proximity Monitor status message when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle advisory is expected to read within the sample range of 60 to 67 units during a turnaround.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- During a diversion, the relief pilot should verify the Nosewheel Steering advisory before the next phase of flight.
- During descent, the relief pilot should announce the Bleed Air Supply annunciation if the indication does not stabilize within the sample interval.

CAUTION: The relief pilot will select any change in the Flight Management Computer advisory and advise the other pilot before the next phase of flight.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot monitoring will record any change in the Autopilot Channel A status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Hydraulic System A selector position that differs from the expected state requires both pilots to confirm the condition when conditions permit.

07.20.13 Cabin Pressure Controller Status Messages

The Center Tank Pumps status message that differs from the expected state requires the First Officer to select the condition when conditions permit. Refer to the related topic for additional sample context. The Cabin Pressure Controller advisory is expected to read within the sample range of 39 to 50 units during preflight.

NOTE: The Hydraulic System A annunciation that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit.

If the Traffic Advisory Display is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Bleed Air Supply status message that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. If the Autothrottle is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

The Speedbrake Handle indication is expected to read within the sample range of 90 to 93 units during a diversion. If the Standby Hydraulic is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During taxi, the pilot flying should verify the Center Tank Pumps annunciation unless directed otherwise by the Sample Operations Center.

The relief pilot will record any change in the Fire Detection Loop annunciation and advise the other pilot before the next phase of flight. The captain will monitor any change in the Standby Hydraulic quantity display and advise the other pilot when conditions permit. If the Probe Heat is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Nosewheel Steering advisory is expected to read within the sample range of 88 to 100 units during descent. During preflight, the First Officer should confirm the Fuel Crossfeed status message unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	49 units	Refer to related topic
Standby Instruments quantity display	20 units	Advisory only

Speedbrake Handle status message	39 units	Monitor
Cabin Pressure Controller status message	79 units	Advisory only
Probe Heat advisory	90 units	Monitor
Autothrottle indication	83 units	Monitor
Cabin Pressure Controller switch position	87 units	Advisory only

CAUTION: During preflight, the First Officer should verify the Fuel Crossfeed annunciation once the checklist item is complete.

The Engine Anti-Ice selector position is expected to read within the sample range of 48 to 55 units during a maintenance-requested ground run. Both pilots will cross-check any change in the Traffic Advisory Display switch position and advise the other pilot once the checklist item is complete. The first officer will verify any change in the Standby Hydraulic status message and advise the other pilot if the indication does not stabilize within the sample interval. The pilot flying will brief any change in the Primary Electrical Bus annunciation and advise the other pilot before the next phase of flight. The pilot monitoring will announce any change in the Stall Warning selector position and advise the other pilot once the checklist item is complete. The Autopilot Channel B annunciation that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power. See 03.20.16 Flow: Oxygen Distribution.

CAUTION: The Probe Heat quantity display that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. If the Autopilot Channel B is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

07.20.14 Hydraulic System B Indications

The Hydraulic System A switch position is expected to read within the sample range of 87 to 91 units during landing. If the Autobrake Selector is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Cabin Pressure Controller status message is expected to read within the sample range of 8 to 11 units during a turnaround. This text is fictional and exists only to give the prototype realistic volume and structure.

Both pilots will verify any change in the Autobrake Selector annunciation and advise the other pilot before the next phase of flight. During a turnaround, the First Officer should monitor the Weather Radar switch position when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

The captain will confirm any change in the Pack Temperature Control annunciation and advise the other pilot if a discrepancy is observed. During an extended ground delay, the First Officer should verify the Weather Radar annunciation if a discrepancy is observed. If the Nosewheel Steering is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

The relief pilot will monitor any change in the Cargo Smoke Detection selector position and advise the other pilot once the checklist item is complete. The captain will verify any change in the Flap Position Indication selector position and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice switch position that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight. During taxi, the Captain should cross-check the Engine Anti-Ice indication when the associated caution light remains illuminated.

The Cargo Smoke Detection advisory is expected to read within the sample range of 55 to 59 units during preflight. The Ground Proximity Monitor selector position is expected to read within the sample range of 95 to 98 units during climb. The Auxiliary Power Unit indication is expected to read within the sample range of 39 to 49 units during descent. The Autopilot Channel A indication is expected to read within the sample range of 82 to 86 units during engine start. The Hydraulic System A selector position is expected to read within the sample range of 39 to 44 units during taxi.

- If the Primary Electrical Bus is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- The Standby Instruments annunciation is expected to read within the sample range of 81 to 91 units during engine start.
- The captain will cross-check any change in the Traffic Advisory Display advisory and advise the other pilot when conditions permit.
- The Stall Warning status message is expected to read within the sample range of 83 to 89 units during approach.
- This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: Refer to the related topic for additional sample context.

If the Flap Position Indication is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Fuel Crossfeed selector position is expected to read within the sample range of 74 to 78 units during descent.

The Stall Warning annunciation is expected to read within the sample range of 37 to 43 units during descent. During parking, the pilot flying should record the Hydraulic System B selector position when operating at a sample station without ground power. Refer to the related topic for additional sample context. The pilot flying will monitor any change in the Autothrottle switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

07.20.15 Engine Anti-Ice Test

If the Flight Management Computer is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will record any change in the Cabin Pressure Controller switch position and advise the other pilot before the next phase of flight. If the Autopilot Channel A is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Transponder switch position that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. The Engine Anti-Ice annunciation that differs from the expected state requires the pilot monitoring to select the condition when conditions permit. The relief pilot will brief any change in the Flap Position Indication indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The Standby Instruments advisory that differs from the expected state requires the Captain to brief the condition before the next phase of flight.
- During engine start, the pilot flying should select the Autothrottle selector position if a discrepancy is observed.
- The Flight Management Computer status message that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated.
- The captain will verify any change in the Engine Anti-Ice annunciation and advise the other pilot when conditions permit.
- The Fuel Crossfeed selector position is expected to read within the sample range of 98 to 110 units during climb.

CAUTION: If the Autobrake Selector is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

During a maintenance-requested ground run, the pilot flying should confirm the Cabin Pressure Controller indication when conditions permit. The pilot flying will select any change in the Thrust Reverser quantity display and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Bleed Air Supply status message is expected to read within the sample range of 55 to 60 units during landing.

If the Cockpit Voice Recorder is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The pilot flying will announce any change in the Autobrake Selector quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Stall Warning quantity display that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete.

The pilot monitoring will select any change in the Fuel Crossfeed indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The Ground Proximity Monitor annunciation is expected to read within the sample range of 58 to 68 units during a turnaround. During climb, the pilot flying should select the Hydraulic System B selector position when conditions permit. During a turnaround, the pilot monitoring should monitor the Standby Instruments selector position when operating at a sample station without ground power.

The Primary Electrical Bus annunciation that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. If the Landing Gear Indication is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cargo Smoke Detection advisory	73 units	Advisory only
Oxygen Distribution status message	6 units	Refer to related topic
Nosewheel Steering indication	46 units	Monitor
Stall Warning indication	89 units	Advisory only

07.20.16 Flight Management Computer Indications

The Engine Anti-Ice indication is expected to read within the sample range of 97 to 100 units during a maintenance-requested ground run. Both pilots will confirm any change in the Speedbrake Handle selector position and advise the other pilot when the associated caution light remains illuminated. During taxi, the First Officer should confirm the Autopilot Channel A annunciation if a discrepancy is observed. If the Primary Electrical Bus is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. During preflight, both pilots should confirm the Traffic Advisory Display indication when the associated caution light remains illuminated. If the Brake Temperature Monitor is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

The pilot flying will record any change in the Standby Instruments quantity display and advise the other pilot when operating at a sample station without ground power. The Traffic Advisory Display status message that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will verify any change in the Fire Detection Loop quantity display and advise the other pilot before the next phase of flight. The Autothrottle switch position that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will announce any change in the Thrust Reverser status message and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Wing Anti-Ice advisory that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete.

If the Oxygen Distribution is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During parking, both pilots should confirm the Autobrake Selector indication if the indication does not stabilize within the sample interval. During preflight, both pilots should monitor the Brake Temperature Monitor quantity display if a discrepancy is observed. Both pilots will select any change in the Traffic Advisory Display selector

position and advise the other pilot before the next phase of flight. During cruise, the First Officer should record the Autobrake Selector advisory before the next phase of flight.

Condition	Sample value	Remarks
Hydraulic System A advisory	54 units	Normal
Fuel Crossfeed status message	47 units	Monitor
Hydraulic System A indication	21 units	Advisory only
Engine Anti-Ice indication	44 units	Monitor
Cockpit Voice Recorder indication	93 units	Monitor
Weather Radar switch position	58 units	Monitor

Condition	Sample value	Remarks
Cabin Pressure Controller indication	93 units	Refer to related topic
Landing Gear Indication quantity display	11 units	Refer to related topic
Pack Temperature Control selector position	99 units	Monitor
Autopilot Channel B quantity display	24 units	Monitor
Autothrottle quantity display	72 units	Normal
Stall Warning selector position	68 units	Normal

If the Center Tank Pumps is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The relief pilot will confirm any change in the Auxiliary Power Unit selector position and advise the other pilot when conditions permit. During a turnaround, the relief pilot should announce the Ground Proximity Monitor indication unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Standby Instruments advisory that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power.

07.20.17 Primary Electrical Bus Interfaces

During preflight, the pilot monitoring should brief the Autobrake Selector advisory when operating at a sample station without ground power. The Center Tank Pumps annunciation is expected to read within the sample range of 10 to 16 units during a maintenance-requested ground run. During engine start, the Captain should brief the Center Tank Pumps switch position when the associated caution light remains illuminated. During a turnaround, the pilot flying should brief the Speedbrake Handle status message when the associated caution light remains illuminated. The Auxiliary Power Unit advisory is expected to read within the sample range of 26 to 32 units during an extended ground delay. The Stall Warning indication that differs from the expected state requires the relief pilot to monitor the condition when conditions permit.

CAUTION: The Hydraulic System A annunciation that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center.

During approach, the pilot monitoring should monitor the Hydraulic System B indication unless directed otherwise by the Sample Operations Center. If the Wing Anti-Ice is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. During landing, the First Officer should announce the Autopilot Channel B status message when operating at a sample station without ground power. The Brake Temperature Monitor quantity display that differs from the expected state requires both pilots to select the condition once the checklist item is complete. During cruise, the Captain should monitor the Brake Temperature Monitor quantity display when operating at a sample station without ground power.

- The Stall Warning switch position that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete.
- During landing, the pilot monitoring should monitor the Engine Anti-Ice status message when conditions permit.

- If the Pack Temperature Control is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- During a maintenance-requested ground run, the First Officer should verify the Autothrottle annunciation if the indication does not stabilize within the sample interval.
- The Brake Temperature Monitor quantity display is expected to read within the sample range of 73 to 81 units during preflight.
- During climb, the First Officer should select the Autobrake Selector advisory unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop selector position that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the relief pilot should announce the Pack Temperature Control advisory before the next phase of flight. The Transponder selector position is expected to read within the sample range of 10 to 15 units during taxi.

07.30 Operation

07.30.1 Hydraulic System B Interfaces

The Fuel Crossfeed annunciation that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. If the Engine Anti-Ice is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Pack Temperature Control annunciation is expected to read within the sample range of 43 to 49 units during engine start. If the Ground Proximity Monitor is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During descent, the relief pilot should cross-check the Landing Gear Indication selector position when operating at a sample station without ground power.

Condition	Sample value	Remarks
Engine Anti-Ice annunciation	7 units	Refer to related topic
Fire Detection Loop annunciation	12 units	Refer to related topic
Engine Anti-Ice status message	27 units	Monitor
Weather Radar quantity display	79 units	Normal
Window Heat quantity display	71 units	Normal
Nosewheel Steering selector position	56 units	Monitor
Ground Proximity Monitor switch position	59 units	Monitor

If the Pack Temperature Control is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Weather Radar status message is expected to read within the sample range of 27 to 32 units during cruise.

Condition	Sample value	Remarks
Pack Temperature Control indication	66 units	Advisory only
Autobrake Selector selector position	63 units	Advisory only
Stall Warning selector position	58 units	Normal
Standby Instruments indication	43 units	Normal
Cargo Smoke Detection selector position	13 units	Advisory only
Weather Radar switch position	33 units	Advisory only

During a diversion, the pilot monitoring should cross-check the Ground Proximity Monitor indication when the associated caution light remains illuminated. The Traffic Advisory Display advisory that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed. The pilot flying will verify any change in the Landing Gear Indication advisory and advise the other pilot if the indication does not stabilize within the sample interval. During taxi, the Captain should record the Fire Detection Loop quantity display if the indication does not stabilize within the sample interval. See 05.60.15 Center Tank Pumps Interfaces.

07.30.2 Flight Management Computer Interfaces

If the Auxiliary Power Unit is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Hydraulic annunciation that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete.

Condition	Sample value	Remarks
Auxiliary Power Unit advisory	46 units	Monitor
Auxiliary Power Unit selector position	45 units	Normal
Cockpit Voice Recorder indication	49 units	Normal

- During preflight, both pilots should confirm the Wing Anti-Ice annunciation when operating at a sample station without ground power.
- The Speedbrake Handle indication that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated.
- The Flight Management Computer annunciation that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight.
- During a maintenance-requested ground run, the relief pilot should cross-check the Hydraulic System A selector position if a discrepancy is observed.

If the Fire Detection Loop is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B quantity display is expected to read within the sample range of 8 to 16 units during approach. The pilot monitoring will verify any change in the Fire Detection Loop selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Transponder is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

If the Stall Warning is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Oxygen Distribution advisory that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power. The Hydraulic System A selector position that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval. During takeoff, the pilot flying should record the Autopilot Channel B switch position when conditions permit. The Oxygen Distribution quantity display is expected to read within the sample range of 80 to 86 units during preflight. The Standby Instruments selector position that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power.

The relief pilot will announce any change in the Speedbrake Handle advisory and advise the other pilot once the checklist item is complete. The Wing Anti-Ice advisory is expected to read within the sample range of 27 to 36 units during preflight. If the Thrust Reverser is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. During approach, the Captain should cross-check the Center Tank Pumps annunciation when operating at a sample station without ground power. The Nosewheel Steering annunciation is expected to read within the sample range of 24 to 30 units during preflight.

The Thrust Reverser annunciation is expected to read within the sample range of 92 to 101 units during landing. The Autopilot Channel A annunciation is expected to read within the sample range of 38 to 48 units during a diversion. If the Cabin Pressure Controller is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Bleed Air Supply quantity display that differs from the expected state requires both pilots to cross-check the condition when conditions permit. The Hydraulic System B status message that differs from the expected state requires the Captain to brief the condition once the checklist item is complete.

CAUTION: Refer to the related topic for additional sample context. The Probe Heat selector position that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated.

The Speedbrake Handle switch position that differs from the expected state requires the Captain to record the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will monitor any change in the Oxygen Distribution switch position and advise the other pilot when operating at a sample station without ground power. The Landing Gear Indication indication that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval.

07.30.3 Cargo Smoke Detection Normal Operation

The pilot monitoring will record any change in the Autopilot Channel A quantity display and advise the other pilot if a discrepancy is observed. The Weather Radar switch position that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Fire Detection Loop advisory is expected to read within the sample range of 22 to 32 units during engine start.

The pilot monitoring will cross-check any change in the Window Heat selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Engine Anti-Ice switch position that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. The pilot monitoring will brief any change in the Wing Anti-Ice switch position and advise the other pilot if a discrepancy is observed. The Flap Position Indication annunciation is expected to read within the sample range of 9 to 21 units during cruise.

NOTE: The Pack Temperature Control annunciation that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete.

NOTE: Values in this manual are invented and must not be used for any operational purpose. During a diversion, the Captain should verify the Center Tank Pumps switch position when conditions permit.

Condition	Sample value	Remarks
Standby Hydraulic advisory	42 units	Monitor
Pack Temperature Control switch position	40 units	Advisory only
Center Tank Pumps advisory	98 units	Monitor
Speedbrake Handle quantity display	41 units	Refer to related topic
Weather Radar quantity display	97 units	Refer to related topic
Standby Instruments annunciation	64 units	Advisory only
Ground Proximity Monitor indication	94 units	Refer to related topic

The Oxygen Distribution status message that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete. The Speedbrake Handle status message that differs from the expected state requires both pilots to confirm the condition when conditions permit. The Flight Management Computer selector position is expected to read within the sample range of 8 to 14 units during takeoff. Both pilots will select any change in the Hydraulic System B advisory and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

NOTE: Refer to the related topic for additional sample context.

07.30.4 *Hydraulic System A Indications*

Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic quantity display that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. The Wing Anti-Ice quantity display is expected to read within the sample range of 63 to 66 units during an extended ground delay. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will monitor any change in the Standby Instruments status message and advise the other pilot when operating at a sample station without ground power.

The Cabin Pressure Controller indication that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. During cruise, the pilot flying should confirm the Nosewheel Steering selector position before the next phase of flight. During taxi, the pilot flying should confirm the Weather Radar quantity display once the checklist item is complete. The Primary Electrical Bus indication is expected to read within the sample range of 78 to 88 units during takeoff.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

If the Center Tank Pumps is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The pilot flying will announce any change in the Center Tank Pumps quantity display and advise the other pilot when the associated caution light remains illuminated. The Cockpit Voice Recorder status message is expected to read within the sample range of 8 to 11 units during cruise.

CAUTION: During parking, both pilots should record the Standby Instruments quantity display unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit status message that differs from the expected state requires the First Officer to record the condition before the next phase of flight.

CAUTION: The Standby Hydraulic switch position that differs from the expected state requires the relief pilot to record the condition when conditions permit. The Auxiliary Power Unit selector position that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.

If the Hydraulic System B is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel B indication is expected to read within the sample range of 88 to 93 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will select any change in the Primary Electrical Bus switch position and advise the other pilot when the associated caution light remains illuminated.

07.30.5 *Fuel Crossfeed Limits Display*

The Autopilot Channel B advisory that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Weather Radar advisory that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval.

CAUTION: The Hydraulic System A indication that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Autopilot Channel B selector position that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated.
- The pilot flying will cross-check any change in the Traffic Advisory Display selector position and advise the other pilot if the indication does not stabilize within the sample interval.

If the Hydraulic System A is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. During a diversion, the pilot monitoring should monitor the Primary Electrical Bus annunciation if a discrepancy is observed. The Wing Anti-Ice quantity display is expected to read within the sample range of 82 to 93 units during preflight. See 08.30.1 Window Heat Power Sources.

CAUTION: During a diversion, the First Officer should verify the Fire Detection Loop switch position when conditions permit.

Condition	Sample value	Remarks
Thrust Reverser status message	16 units	Refer to related topic
Fire Detection Loop selector position	8 units	Refer to related topic
Autobrake Selector quantity display	71 units	Normal
Probe Heat advisory	6 units	Normal
Engine Anti-Ice quantity display	47 units	Advisory only
Probe Heat indication	54 units	Refer to related topic
Engine Anti-Ice status message	5 units	Advisory only

07.30.6 Auxiliary Power Unit Limits Display

The pilot monitoring will announce any change in the Thrust Reverser quantity display and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. If the Transponder is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The pilot flying will confirm any change in the Flap Position Indication advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. During taxi, the First Officer should announce the Center Tank Pumps indication once the checklist item is complete.

NOTE: The Flight Management Computer switch position is expected to read within the sample range of 30 to 38 units during approach. The Oxygen Distribution annunciation is expected to read within the sample range of 10 to 15 units during engine start.

If the Wing Anti-Ice is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Cabin Pressure Controller quantity display that differs from the expected state requires the Captain to record the condition when conditions permit. During a diversion, the pilot monitoring should confirm the Pack Temperature Control annunciation once the checklist item is complete.

The captain will brief any change in the Cargo Smoke Detection switch position and advise the other pilot if a discrepancy is observed. If the Auxiliary Power Unit is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Traffic Advisory Display advisory is expected to read within the sample range of 26 to 30 units during a maintenance-requested ground run. The Autopilot Channel B annunciation is expected to read within the sample range of 84 to 91 units during taxi.

During taxi, the First Officer should monitor the Landing Gear Indication status message before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will confirm any change in the Wing Anti-Ice status message and advise the other pilot before the next phase of flight. If the Fuel Crossfeed is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Stall Warning switch position that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. The Oxygen Distribution indication is expected to read within the sample range of 73 to 77 units during parking.

During cruise, both pilots should monitor the Transponder indication once the checklist item is complete. If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Cabin Pressure Controller is inoperative, continue landing only after the pilot flying has reviewed

the associated sample guidance.

Both pilots will monitor any change in the Cockpit Voice Recorder quantity display and advise the other pilot once the checklist item is complete. If the Bleed Air Supply is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Fire Detection Loop advisory is expected to read within the sample range of 72 to 77 units during preflight. The Fire Detection Loop indication that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. If the Window Heat is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

07.30.7 Probe Heat Crew Awareness

The captain will confirm any change in the Pack Temperature Control annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Autopilot Channel B is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Cockpit Voice Recorder selector position that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval.

NOTE: If the Thrust Reverser is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

The Pack Temperature Control selector position that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. If the Cargo Smoke Detection is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. During engine start, both pilots should select the Stall Warning annunciation when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	5 units	Monitor
Oxygen Distribution indication	12 units	Advisory only
Landing Gear Indication status message	97 units	Advisory only
Landing Gear Indication indication	78 units	Normal
Standby Instruments advisory	25 units	Advisory only
Hydraulic System B advisory	54 units	Normal
Autopilot Channel A advisory	91 units	Normal

This text is fictional and exists only to give the prototype realistic volume and structure. If the Cabin Pressure Controller is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Pack Temperature Control advisory is expected to read within the sample range of 57 to 63 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. If the Fire Detection Loop is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

During climb, both pilots should monitor the Ground Proximity Monitor status message unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller status message that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. If the Standby Instruments is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle annunciation that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center.

07.30.8 Pack Temperature Control Indications

The first officer will monitor any change in the Probe Heat annunciation and advise the other pilot if a discrepancy is observed. During a turnaround, the pilot flying should verify the Flight Management Computer indication unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller status message is expected to read within the sample range of 96 to 107 units during approach. The pilot flying will verify any change in the Transponder status message and advise the other pilot before the next phase of flight.

- If the Weather Radar is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.
- The Pack Temperature Control quantity display is expected to read within the sample range of 71 to 75 units during preflight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Cargo Smoke Detection is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.
- The Stall Warning annunciation is expected to read within the sample range of 90 to 101 units during a turnaround.
- Both pilots will brief any change in the Flight Management Computer indication and advise the other pilot when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Autobrake Selector is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Primary Electrical Bus status message	50 units	Monitor
Cockpit Voice Recorder advisory	33 units	Normal
Stall Warning annunciation	90 units	Monitor

- If the Brake Temperature Monitor is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.
- During an extended ground delay, the pilot flying should confirm the Center Tank Pumps annunciation once the checklist item is complete.
- If the Cabin Pressure Controller is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Center Tank Pumps quantity display that differs from the expected state requires both pilots to record the condition before the next phase of flight.
- Values in this manual are invented and must not be used for any operational purpose.

The Pack Temperature Control selector position that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated. If the Bleed Air Supply is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Cabin Pressure Controller status message is expected to read within the sample range of 50 to 62 units during approach. The Fire Detection Loop selector position is expected to read within the sample range of 3 to 10 units during climb. The Pack Temperature Control selector position that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power.

The Landing Gear Indication status message is expected to read within the sample range of 80 to 89 units during descent. Values in this manual are invented and must not be used for any operational purpose. The wording here is

placeholder content shaped like a procedure, not a procedure.

Values in this manual are invented and must not be used for any operational purpose. The Weather Radar advisory that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete. Both pilots will record any change in the Cargo Smoke Detection advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. See 02.10.5 General Limitation 5.

07.30.9 Autobrake Selector Status Messages

The Pack Temperature Control indication that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. During climb, the pilot flying should brief the Probe Heat selector position unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

During landing, the First Officer should cross-check the Ground Proximity Monitor indication unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus indication that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power. The Ground Proximity Monitor selector position that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed.

During parking, the pilot monitoring should brief the Wing Anti-Ice status message once the checklist item is complete. The pilot monitoring will monitor any change in the Autopilot Channel A status message and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. See 05.80.8 Standby Instruments Status Messages.

CAUTION: The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. If the Autopilot Channel A is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The captain will select any change in the Cabin Pressure Controller indication and advise the other pilot when conditions permit.

07.30.10 Brake Temperature Monitor Limits Display

The Fire Detection Loop quantity display that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System B is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The relief pilot will select any change in the Hydraulic System A annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

- The first officer will select any change in the Landing Gear Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- The first officer will select any change in the Weather Radar advisory and advise the other pilot when operating at a sample station without ground power.
- The Center Tank Pumps status message is expected to read within the sample range of 40 to 47 units during a turnaround.
- If the Engine Anti-Ice is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- During taxi, the First Officer should confirm the Fire Detection Loop advisory before the next phase of flight.

- If the Traffic Advisory Display is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Transponder annunciation	47 units	Monitor
Weather Radar switch position	80 units	Normal
Standby Hydraulic annunciation	50 units	Advisory only
Pack Temperature Control switch position	8 units	Monitor

CAUTION: The pilot flying will announce any change in the Hydraulic System A indication and advise the other pilot when the associated caution light remains illuminated. The Wing Anti-Ice quantity display is expected to read within the sample range of 57 to 62 units during a maintenance-requested ground run.

- The captain will verify any change in the Hydraulic System B annunciation and advise the other pilot when the associated caution light remains illuminated.
- The Nosewheel Steering switch position that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed.
- During a maintenance-requested ground run, the Captain should monitor the Standby Instruments advisory when the associated caution light remains illuminated.
- The pilot flying will select any change in the Autopilot Channel B selector position and advise the other pilot if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.

07.30.11 Oxygen Distribution Limits Display

The pilot monitoring will record any change in the Stall Warning selector position and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. The relief pilot will announce any change in the Center Tank Pumps status message and advise the other pilot once the checklist item is complete. The pilot flying will confirm any change in the Standby Hydraulic annunciation and advise the other pilot before the next phase of flight. The Flight Management Computer quantity display is expected to read within the sample range of 53 to 57 units during climb. During taxi, both pilots should announce the Cargo Smoke Detection advisory unless directed otherwise by the Sample Operations Center.

- During landing, the relief pilot should monitor the Autothrottle indication before the next phase of flight.
- The Bleed Air Supply advisory is expected to read within the sample range of 59 to 70 units during cruise.
- If the Pack Temperature Control is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- The Speedbrake Handle switch position is expected to read within the sample range of 79 to 89 units during takeoff.
- The Standby Instruments advisory that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Autopilot Channel A selector position is expected to read within the sample range of 57 to 67 units during climb.
- The Transponder switch position that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete.

- During engine start, the pilot flying should confirm the Transponder quantity display unless directed otherwise by the Sample Operations Center.
- If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.
- The Stall Warning indication is expected to read within the sample range of 96 to 106 units during engine start.
- Values in this manual are invented and must not be used for any operational purpose.
- The pilot monitoring will verify any change in the Standby Instruments selector position and advise the other pilot if a discrepancy is observed.
- If the Flap Position Indication is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- The Transponder quantity display is expected to read within the sample range of 88 to 96 units during climb.
- The Cargo Smoke Detection quantity display is expected to read within the sample range of 31 to 37 units during cruise.

Refer to the related topic for additional sample context. During preflight, the First Officer should monitor the Fire Detection Loop selector position if a discrepancy is observed. During parking, the pilot monitoring should confirm the Fire Detection Loop indication if the indication does not stabilize within the sample interval. The Probe Heat status message that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The pilot monitoring will record any change in the Ground Proximity Monitor advisory and advise the other pilot if the indication does not stabilize within the sample interval.

07.30.12 Cabin Pressure Controller Indications

Refer to the related topic for additional sample context. The Engine Anti-Ice indication that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. The Nosewheel Steering advisory is expected to read within the sample range of 36 to 39 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure. During parking, the First Officer should announce the Nosewheel Steering quantity display if the indication does not stabilize within the sample interval.

The pilot flying will monitor any change in the Flap Position Indication switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Stall Warning switch position that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. The Flap Position Indication annunciation that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. The Probe Heat quantity display that differs from the expected state requires both pilots to monitor the condition when conditions permit.

NOTE: Both pilots will record any change in the Autobrake Selector quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the First Officer should announce the Transponder advisory when the associated caution light remains illuminated. The Flap Position Indication status message is expected to read within the sample range of 31 to 41 units during a maintenance-requested ground run. The Hydraulic System B advisory that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. The Auxiliary Power Unit quantity display that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed.

If the Pack Temperature Control is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will monitor any change in the Speedbrake Handle indication and advise the other pilot when operating at a sample station without ground power. The Brake Temperature Monitor selector position that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. During a diversion, the relief pilot should cross-check the Standby Instruments selector position before the next phase of flight. If the Traffic Advisory Display is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

The pilot monitoring will confirm any change in the Cockpit Voice Recorder status message and advise the other pilot when operating at a sample station without ground power. The Transponder advisory that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. The pilot flying will cross-check any change in the Autopilot Channel B selector position and advise the other pilot if the indication does not stabilize within the sample interval. See 12.20.10 Speedbrake Handle Status Messages.

Condition	Sample value	Remarks
Ground Proximity Monitor indication	31 units	Advisory only
Thrust Reverser quantity display	80 units	Refer to related topic
Autopilot Channel A status message	59 units	Advisory only
Landing Gear Indication advisory	18 units	Monitor
Cabin Pressure Controller advisory	27 units	Refer to related topic
Pack Temperature Control switch position	21 units	Monitor

CAUTION: The Nosewheel Steering quantity display is expected to read within the sample range of 31 to 37 units during takeoff.

Condition	Sample value	Remarks
Landing Gear Indication quantity display	75 units	Refer to related topic
Primary Electrical Bus quantity display	34 units	Refer to related topic
Engine Anti-Ice switch position	46 units	Monitor
Brake Temperature Monitor annunciation	93 units	Advisory only

07.30.13 Pack Temperature Control Power Sources

The Primary Electrical Bus status message that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. If the Speedbrake Handle is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The relief pilot will announce any change in the Autopilot Channel B advisory and advise the other pilot when conditions permit. Both pilots will record any change in the Standby Instruments annunciation and advise the other pilot when operating at a sample station without ground power. If the Wing Anti-Ice is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Cabin Pressure Controller indication is expected to read within the sample range of 32 to 44 units during takeoff.

NOTE: The Engine Anti-Ice indication is expected to read within the sample range of 43 to 54 units during parking.

- The first officer will confirm any change in the Fire Detection Loop selector position and advise the other pilot once the checklist item is complete.
- If the Hydraulic System B is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

- The captain will cross-check any change in the Hydraulic System A advisory and advise the other pilot when conditions permit.

During parking, both pilots should record the Autopilot Channel A status message if the indication does not stabilize within the sample interval. The pilot flying will announce any change in the Cargo Smoke Detection switch position and advise the other pilot when the associated caution light remains illuminated. If the Hydraulic System A is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The Cockpit Voice Recorder selector position is expected to read within the sample range of 60 to 65 units during taxi. Values in this manual are invented and must not be used for any operational purpose. The Brake Temperature Monitor advisory that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. If the Cabin Pressure Controller is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

- During landing, both pilots should record the Hydraulic System B selector position when operating at a sample station without ground power.
- If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- Both pilots will announce any change in the Brake Temperature Monitor switch position and advise the other pilot if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.

The Autopilot Channel B selector position is expected to read within the sample range of 95 to 99 units during landing. The Traffic Advisory Display quantity display that differs from the expected state requires the relief pilot to record the condition before the next phase of flight. The captain will select any change in the Primary Electrical Bus status message and advise the other pilot once the checklist item is complete. The pilot monitoring will confirm any change in the Window Heat switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

During a turnaround, the First Officer should announce the Cargo Smoke Detection quantity display when the associated caution light remains illuminated. During cruise, both pilots should announce the Brake Temperature Monitor annunciation when conditions permit. The relief pilot will cross-check any change in the Cargo Smoke Detection status message and advise the other pilot when operating at a sample station without ground power.

- The Hydraulic System A indication that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight.
- The Transponder indication that differs from the expected state requires the Captain to brief the condition when conditions permit.
- The first officer will verify any change in the Standby Hydraulic switch position and advise the other pilot when conditions permit.

07.30.14 Cockpit Voice Recorder Interfaces

The first officer will select any change in the Nosewheel Steering status message and advise the other pilot before the next phase of flight. Both pilots will brief any change in the Flap Position Indication annunciation and advise the other pilot when conditions permit. If the Stall Warning is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will monitor any change in the Stall Warning annunciation and advise the other pilot if a discrepancy is observed. During landing, the First Officer should brief the Brake Temperature Monitor annunciation unless directed otherwise by the Sample Operations Center. If the Fire Detection Loop is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

The Speedbrake Handle quantity display that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. The Landing Gear Indication status

message that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power. The pilot monitoring will record any change in the Weather Radar status message and advise the other pilot when operating at a sample station without ground power. If the Pack Temperature Control is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. During a diversion, both pilots should monitor the Autobrake Selector status message when operating at a sample station without ground power.

If the Cargo Smoke Detection is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Brake Temperature Monitor quantity display that differs from the expected state requires both pilots to monitor the condition before the next phase of flight. If the Fuel Crossfeed is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

NOTE: If the Engine Anti-Ice is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Auxiliary Power Unit indication that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center.

CAUTION: The pilot monitoring will record any change in the Flap Position Indication advisory and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context.

The Flight Management Computer status message that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete. The Speedbrake Handle switch position that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. During takeoff, both pilots should record the Wing Anti-Ice annunciation once the checklist item is complete.

The Standby Hydraulic quantity display that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. During a turnaround, the First Officer should verify the Brake Temperature Monitor indication unless directed otherwise by the Sample Operations Center. If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will select any change in the Autopilot Channel A status message and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Auxiliary Power Unit quantity display	35 units	Refer to related topic
Autobrake Selector switch position	31 units	Refer to related topic
Autobrake Selector quantity display	27 units	Normal
Nosewheel Steering annunciation	97 units	Normal

07.30.15 *Flight Management Computer Crew Awareness*

The Hydraulic System A quantity display that differs from the expected state requires the relief pilot to verify the condition if a discrepancy is observed. The Oxygen Distribution selector position that differs from the expected state requires both pilots to brief the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Nosewheel Steering annunciation that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center. The Flight Management Computer annunciation is expected to read within the sample range of 54 to 60 units during landing.

NOTE: The Auxiliary Power Unit status message is expected to read within the sample range of 25 to 31 units during landing. During climb, the pilot flying should cross-check the Wing Anti-Ice annunciation when the associated caution light remains illuminated.

CAUTION: The Engine Anti-Ice quantity display is expected to read within the sample range of 65 to 70 units during takeoff.

Condition	Sample value	Remarks
Hydraulic System A indication	42 units	Monitor
Hydraulic System B quantity display	54 units	Advisory only
Probe Heat status message	44 units	Refer to related topic
Flap Position Indication switch position	15 units	Advisory only
Pack Temperature Control indication	77 units	Refer to related topic

This text is fictional and exists only to give the prototype realistic volume and structure. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Center Tank Pumps indication that differs from the expected state requires the pilot monitoring to record the condition when the associated caution light remains illuminated. If the Autobrake Selector is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Window Heat quantity display is expected to read within the sample range of 41 to 48 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The pilot flying will cross-check any change in the Window Heat advisory and advise the other pilot before the next phase of flight.

If the Autothrottle is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The pilot flying will select any change in the Hydraulic System A status message and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

Values in this manual are invented and must not be used for any operational purpose. The Nosewheel Steering selector position is expected to read within the sample range of 15 to 19 units during descent. The Autobrake Selector quantity display that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. See 12.10.2 Autopilot Channel A Interfaces.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

Chapter 08 Systems: Fuel

08.10 Description

08.10.1 Auxiliary Power Unit Power Sources

Values in this manual are invented and must not be used for any operational purpose. During parking, the relief pilot should select the Window Heat status message when the associated caution light remains illuminated. The Cabin Pressure Controller indication is expected to read within the sample range of 43 to 49 units during descent.

CAUTION: The Traffic Advisory Display advisory is expected to read within the sample range of 88 to 92 units during cruise.

During taxi, the Captain should announce the Auxiliary Power Unit annunciation once the checklist item is complete. During preflight, the relief pilot should select the Oxygen Distribution status message when the associated caution light remains illuminated. The first officer will brief any change in the Oxygen Distribution annunciation and advise the other pilot when operating at a sample station without ground power.

During parking, the pilot flying should select the Bleed Air Supply switch position unless directed otherwise by the Sample Operations Center. During descent, the pilot flying should monitor the Autobrake Selector selector position unless directed otherwise by the Sample Operations Center. During preflight, the pilot monitoring should announce the Cabin Pressure Controller annunciation when conditions permit.

The Fire Detection Loop status message that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. If the Fuel Crossfeed is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During descent, the First Officer should confirm the Hydraulic System A switch position before the next phase of flight.

- During approach, the pilot monitoring should confirm the Standby Instruments status message unless directed otherwise by the Sample Operations Center.
- Both pilots will cross-check any change in the Brake Temperature Monitor status message and advise the other pilot when operating at a sample station without ground power.
- Both pilots will verify any change in the Traffic Advisory Display indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.
- The Hydraulic System A quantity display that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.

If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. During descent, the First Officer should record the Nosewheel Steering switch position if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. During parking, the Captain should verify the Weather Radar annunciation once the checklist item is complete. See 03.70.3 Verification: Center Tank Pumps.

08.10.2 Landing Gear Indication Limits Display

During cruise, the relief pilot should select the Oxygen Distribution quantity display if a discrepancy is observed. During descent, both pilots should announce the Flight Management Computer advisory unless directed otherwise by the Sample Operations Center. The Standby Instruments advisory is expected to read within the sample range of 91 to 101 units during engine start. If the Autopilot Channel B is inoperative, continue descent only after the pilot flying

has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Flap Position Indication advisory is expected to read within the sample range of 63 to 73 units during landing.

Condition	Sample value	Remarks
Weather Radar indication	79 units	Refer to related topic
Hydraulic System B indication	81 units	Refer to related topic
Fire Detection Loop advisory	33 units	Normal
Center Tank Pumps selector position	33 units	Normal
Stall Warning annunciation	24 units	Monitor
Cabin Pressure Controller status message	66 units	Advisory only

The Auxiliary Power Unit selector position is expected to read within the sample range of 16 to 27 units during a maintenance-requested ground run. The Nosewheel Steering selector position that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, both pilots should monitor the Transponder indication if a discrepancy is observed.

During cruise, both pilots should select the Engine Anti-Ice indication before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

If the Primary Electrical Bus is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The pilot flying will announce any change in the Center Tank Pumps switch position and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Autothrottle indication is expected to read within the sample range of 97 to 104 units during taxi. During a diversion, the Captain should brief the Autopilot Channel B quantity display when operating at a sample station without ground power. The Fuel Crossfeed switch position is expected to read within the sample range of 50 to 57 units during parking.

NOTE: During a maintenance-requested ground run, both pilots should announce the Primary Electrical Bus indication when operating at a sample station without ground power. The first officer will cross-check any change in the Hydraulic System B annunciation and advise the other pilot before the next phase of flight.

- The Standby Hydraulic status message that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval.
- During climb, the Captain should select the Hydraulic System B quantity display if a discrepancy is observed.
- The Flight Management Computer switch position that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power.
- The first officer will confirm any change in the Hydraulic System B switch position and advise the other pilot when conditions permit.
- Refer to the related topic for additional sample context.
- If the Oxygen Distribution is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

08.10.3 Engine Anti-Ice Status Messages

The Bleed Air Supply quantity display is expected to read within the sample range of 70 to 77 units during cruise. The Standby Instruments switch position that differs from the expected state requires the pilot monitoring to select the

condition unless directed otherwise by the Sample Operations Center. During a maintenance-requested ground run, the First Officer should cross-check the Nosewheel Steering annunciation before the next phase of flight.

NOTE: The Fire Detection Loop selector position that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed. The Standby Instruments status message is expected to read within the sample range of 81 to 88 units during approach.

- The first officer will verify any change in the Auxiliary Power Unit annunciation and advise the other pilot before the next phase of flight.
- The Hydraulic System A selector position is expected to read within the sample range of 23 to 35 units during a diversion.
- If the Autopilot Channel B is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

NOTE: During takeoff, the pilot flying should brief the Thrust Reverser indication when the associated caution light remains illuminated. During parking, the relief pilot should monitor the Window Heat advisory if a discrepancy is observed.

If the Primary Electrical Bus is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Stall Warning switch position that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will monitor any change in the Auxiliary Power Unit status message and advise the other pilot when conditions permit. The Nosewheel Steering indication that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: During a turnaround, the pilot flying should verify the Bleed Air Supply indication unless directed otherwise by the Sample Operations Center. The Stall Warning switch position is expected to read within the sample range of 7 to 17 units during an extended ground delay.

The captain will monitor any change in the Landing Gear Indication status message and advise the other pilot when the associated caution light remains illuminated. The Center Tank Pumps indication that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power. The Traffic Advisory Display switch position that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. The Flap Position Indication annunciation that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. During a turnaround, both pilots should select the Cabin Pressure Controller quantity display if a discrepancy is observed.

Condition	Sample value	Remarks
Nosewheel Steering annunciation	95 units	Advisory only
Brake Temperature Monitor quantity display	18 units	Advisory only
Hydraulic System A selector position	3 units	Monitor
Hydraulic System A indication	89 units	Advisory only
Bleed Air Supply selector position	88 units	Refer to related topic

08.10.4 Landing Gear Indication Limits Display

The pilot flying will select any change in the Flight Management Computer switch position and advise the other pilot before the next phase of flight. If the Autothrottle is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should record the Fire Detection Loop indication when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

The captain will verify any change in the Primary Electrical Bus advisory and advise the other pilot once the checklist item is complete. The captain will verify any change in the Stall Warning advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. Both pilots will brief any change in the Autobrake Selector advisory and advise the other pilot if a discrepancy is observed. If the Autopilot Channel B is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Fuel Crossfeed selector position that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit.

The pilot flying will brief any change in the Primary Electrical Bus status message and advise the other pilot before the next phase of flight. If the Ground Proximity Monitor is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Wing Anti-Ice selector position that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed.

CAUTION: The first officer will cross-check any change in the Engine Anti-Ice switch position and advise the other pilot when conditions permit.

- The Oxygen Distribution annunciation that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power.
- During climb, the Captain should brief the Hydraulic System A quantity display if the indication does not stabilize within the sample interval.
- The Nosewheel Steering indication is expected to read within the sample range of 89 to 95 units during descent.
- The Stall Warning selector position is expected to read within the sample range of 72 to 82 units during descent.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Flight Management Computer is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.
- During takeoff, the pilot monitoring should announce the Landing Gear Indication advisory if a discrepancy is observed.
- Both pilots will cross-check any change in the Standby Instruments advisory and advise the other pilot when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: Both pilots will brief any change in the Standby Instruments annunciation and advise the other pilot before the next phase of flight. The Thrust Reverser indication is expected to read within the sample range of 78 to 82 units during takeoff.

During approach, the relief pilot should confirm the Thrust Reverser annunciation if the indication does not stabilize within the sample interval. Both pilots will brief any change in the Flap Position Indication selector position and advise the other pilot once the checklist item is complete. During cruise, the pilot monitoring should record the Auxiliary Power Unit advisory when conditions permit. The Fire Detection Loop selector position is expected to read within the sample range of 86 to 90 units during climb. During parking, the Captain should brief the Traffic Advisory Display status message if a discrepancy is observed. The Flight Management Computer status message is expected to read within the sample range of 27 to 39 units during taxi.

- If the Flight Management Computer is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The Autobrake Selector annunciation that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center.
- The Fire Detection Loop selector position that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed.
- The Center Tank Pumps indication is expected to read within the sample range of 33 to 40 units during approach.

- During preflight, the First Officer should announce the Autopilot Channel B quantity display when operating at a sample station without ground power.

08.10.5 Speedbrake Handle Test

The pilot flying will cross-check any change in the Autopilot Channel A quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. If the Traffic Advisory Display is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. During preflight, the pilot flying should select the Flight Management Computer switch position if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Fuel Crossfeed status message	36 units	Refer to related topic
Thrust Reverser advisory	25 units	Normal
Flight Management Computer advisory	4 units	Refer to related topic
Landing Gear Indication annunciation	19 units	Advisory only
Bleed Air Supply advisory	24 units	Advisory only

The pilot flying will cross-check any change in the Autopilot Channel A advisory and advise the other pilot when operating at a sample station without ground power. During an extended ground delay, the pilot monitoring should verify the Autobrake Selector indication once the checklist item is complete. The Ground Proximity Monitor quantity display that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle annunciation is expected to read within the sample range of 32 to 41 units during cruise. The Nosewheel Steering switch position is expected to read within the sample range of 46 to 55 units during landing.

- The Transponder indication is expected to read within the sample range of 79 to 85 units during engine start.
- During takeoff, the pilot flying should verify the Primary Electrical Bus advisory when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a turnaround, the First Officer should confirm the Cargo Smoke Detection status message once the checklist item is complete.
- The Ground Proximity Monitor selector position is expected to read within the sample range of 3 to 9 units during engine start.

During engine start, both pilots should verify the Cargo Smoke Detection indication when conditions permit. If the Pack Temperature Control is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The Standby Instruments quantity display that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete. The Hydraulic System A quantity display that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. During preflight, both pilots should announce the Fire Detection Loop quantity display when the associated caution light remains illuminated. During a diversion, the pilot flying should announce the Transponder advisory when operating at a sample station without ground power.

08.10.6 Cargo Smoke Detection Indications

During preflight, the pilot flying should confirm the Wing Anti-Ice advisory when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Weather Radar advisory is expected to read within the sample range of 66 to 72 units during landing.

During cruise, the First Officer should monitor the Autopilot Channel A quantity display when conditions permit. The first officer will cross-check any change in the Engine Anti-Ice annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will record any change in the Autopilot Channel B indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The Landing Gear Indication status message is expected to read within the sample range of 62 to 68 units during landing. During takeoff, the pilot monitoring should verify the Hydraulic System B indication when conditions permit.

Refer to the related topic for additional sample context. During parking, the pilot monitoring should cross-check the Primary Electrical Bus annunciation unless directed otherwise by the Sample Operations Center. During landing, the relief pilot should confirm the Thrust Reverser switch position once the checklist item is complete. During parking, the First Officer should cross-check the Cargo Smoke Detection switch position when conditions permit. During cruise, both pilots should cross-check the Autopilot Channel B quantity display once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

The captain will monitor any change in the Flight Management Computer status message and advise the other pilot if a discrepancy is observed. The Bleed Air Supply advisory is expected to read within the sample range of 86 to 93 units during takeoff. During a diversion, the Captain should monitor the Fuel Crossfeed switch position once the checklist item is complete.

If the Hydraulic System B is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The relief pilot will monitor any change in the Flap Position Indication quantity display and advise the other pilot if the indication does not stabilize within the sample interval. If the Oxygen Distribution is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The relief pilot will select any change in the Primary Electrical Bus switch position and advise the other pilot if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

NOTE: The pilot monitoring will announce any change in the Wing Anti-Ice selector position and advise the other pilot when operating at a sample station without ground power.

If the Traffic Advisory Display is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During preflight, the Captain should monitor the Standby Hydraulic selector position if the indication does not stabilize within the sample interval. During takeoff, the pilot flying should brief the Transponder selector position if a discrepancy is observed.

08.10.7 Fuel Crossfeed Status Messages

If the Bleed Air Supply is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Ground Proximity Monitor indication is expected to read within the sample range of 75 to 82 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

NOTE: Refer to the related topic for additional sample context.

The Standby Hydraulic annunciation that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed. If the Autopilot Channel B is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The first officer will confirm any change in the Bleed Air Supply status message and advise the other pilot if the indication does not stabilize within the sample interval. If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During parking, the pilot flying should announce the Hydraulic System B quantity display once the checklist item is complete.

The Landing Gear Indication advisory is expected to read within the sample range of 55 to 63 units during takeoff. If the Fuel Crossfeed is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Center Tank Pumps annunciation is expected to read within the sample range of 57 to 63 units during

a turnaround. The relief pilot will select any change in the Oxygen Distribution switch position and advise the other pilot if the indication does not stabilize within the sample interval. During an extended ground delay, the Captain should monitor the Autopilot Channel B advisory if the indication does not stabilize within the sample interval. During an extended ground delay, the First Officer should brief the Fuel Crossfeed switch position once the checklist item is complete.

The relief pilot will confirm any change in the Flap Position Indication quantity display and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will announce any change in the Bleed Air Supply annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Thrust Reverser selector position that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight. During engine start, the Captain should announce the Pack Temperature Control advisory if a discrepancy is observed. During landing, the Captain should confirm the Center Tank Pumps advisory if the indication does not stabilize within the sample interval.

08.10.8 Cabin Pressure Controller Normal Operation

The Hydraulic System A selector position that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center. During parking, the pilot monitoring should verify the Cargo Smoke Detection switch position when conditions permit. The Standby Instruments selector position is expected to read within the sample range of 3 to 13 units during cruise. Both pilots will verify any change in the Stall Warning annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Flight Management Computer quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

The pilot monitoring will record any change in the Standby Hydraulic advisory and advise the other pilot if a discrepancy is observed. During taxi, both pilots should cross-check the Center Tank Pumps indication unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice switch position that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. The first officer will select any change in the Ground Proximity Monitor indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autopilot Channel A selector position that differs from the expected state requires the Captain to monitor the condition when conditions permit. The pilot monitoring will confirm any change in the Transponder quantity display and advise the other pilot when conditions permit.

CAUTION: If the Autopilot Channel A is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

CAUTION: Both pilots will brief any change in the Cabin Pressure Controller advisory and advise the other pilot when the associated caution light remains illuminated.

- The Ground Proximity Monitor quantity display is expected to read within the sample range of 89 to 98 units during descent.
- During approach, the pilot monitoring should confirm the Flap Position Indication switch position if the indication does not stabilize within the sample interval.
- During taxi, the pilot monitoring should monitor the Landing Gear Indication annunciation when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.

08.10.9 Fire Detection Loop Indications

Refer to the related topic for additional sample context. The Oxygen Distribution status message that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. During takeoff, the First Officer should verify the Nosewheel Steering status message when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any

operational purpose.

Condition	Sample value	Remarks
Fire Detection Loop selector position	63 units	Advisory only
Pack Temperature Control annunciation	36 units	Refer to related topic
Landing Gear Indication selector position	87 units	Monitor

- The Transponder indication that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center.
- The Landing Gear Indication quantity display that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval.
- The pilot monitoring will record any change in the Thrust Reverser status message and advise the other pilot before the next phase of flight.
- The Speedbrake Handle indication that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center.
- The first officer will announce any change in the Window Heat status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Thrust Reverser is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

During a diversion, the pilot flying should verify the Center Tank Pumps selector position once the checklist item is complete. The captain will monitor any change in the Fuel Crossfeed selector position and advise the other pilot if a discrepancy is observed. During a turnaround, the relief pilot should brief the Hydraulic System B advisory once the checklist item is complete. The first officer will record any change in the Autothrottle switch position and advise the other pilot once the checklist item is complete. The Wing Anti-Ice selector position is expected to read within the sample range of 55 to 61 units during descent. During climb, the relief pilot should monitor the Weather Radar advisory when operating at a sample station without ground power.

NOTE: If the Flap Position Indication is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Oxygen Distribution is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Flap Position Indication advisory and advise the other pilot once the checklist item is complete. The pilot flying will record any change in the Pack Temperature Control annunciation and advise the other pilot if a discrepancy is observed. The Wing Anti-Ice quantity display is expected to read within the sample range of 21 to 29 units during a maintenance-requested ground run. The Autothrottle indication is expected to read within the sample range of 90 to 101 units during a turnaround. See 10.30.11 Standby Instruments Interfaces.

- The Speedbrake Handle status message is expected to read within the sample range of 23 to 29 units during landing.
- If the Nosewheel Steering is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.
- During approach, the relief pilot should monitor the Transponder selector position when conditions permit.
- During an extended ground delay, the pilot flying should monitor the Standby Instruments quantity display if a discrepancy is observed.
- The pilot flying will verify any change in the Transponder indication and advise the other pilot when conditions permit.

- The Pack Temperature Control advisory is expected to read within the sample range of 24 to 32 units during a maintenance-requested ground run.

08.10.10 Landing Gear Indication Crew Awareness

The relief pilot will verify any change in the Landing Gear Indication status message and advise the other pilot when the associated caution light remains illuminated. The Wing Anti-Ice quantity display that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. During a diversion, both pilots should announce the Brake Temperature Monitor annunciation when conditions permit. The captain will verify any change in the Cabin Pressure Controller switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Stall Warning status message	36 units	Advisory only
Cockpit Voice Recorder advisory	62 units	Refer to related topic
Autothrottle selector position	75 units	Advisory only
Ground Proximity Monitor quantity display	19 units	Refer to related topic
Wing Anti-Ice switch position	76 units	Normal
Thrust Reverser selector position	84 units	Refer to related topic
Brake Temperature Monitor annunciation	30 units	Monitor

The pilot monitoring will select any change in the Ground Proximity Monitor advisory and advise the other pilot when operating at a sample station without ground power. The Probe Heat status message that differs from the expected state requires the First Officer to record the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

Both pilots will verify any change in the Hydraulic System A annunciation and advise the other pilot when operating at a sample station without ground power. During climb, the Captain should cross-check the Cabin Pressure Controller selector position when conditions permit. If the Window Heat is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

The pilot monitoring will select any change in the Thrust Reverser quantity display and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Autothrottle advisory is expected to read within the sample range of 8 to 19 units during approach.

If the Autopilot Channel B is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control advisory is expected to read within the sample range of 97 to 103 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Wing Anti-Ice indication that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete.
- The pilot flying will confirm any change in the Autobrake Selector status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Cabin Pressure Controller is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- The captain will announce any change in the Speedbrake Handle selector position and advise the other pilot when the associated caution light remains illuminated.
- Both pilots will announce any change in the Cargo Smoke Detection indication and advise the other pilot if the indication does not stabilize within the sample interval.

- The Probe Heat selector position is expected to read within the sample range of 86 to 94 units during landing.

The pilot monitoring will brief any change in the Hydraulic System B selector position and advise the other pilot when conditions permit. The Autopilot Channel A selector position is expected to read within the sample range of 30 to 38 units during climb. Both pilots will record any change in the Brake Temperature Monitor quantity display and advise the other pilot once the checklist item is complete. The Speedbrake Handle selector position that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. The Flight Management Computer indication that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center.

The relief pilot will cross-check any change in the Cockpit Voice Recorder quantity display and advise the other pilot once the checklist item is complete. The Traffic Advisory Display indication that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

08.10.11 Standby Hydraulic Indications

The Stall Warning annunciation that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. The Nosewheel Steering annunciation that differs from the expected state requires the Captain to cross-check the condition when conditions permit. If the Landing Gear Indication is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Ground Proximity Monitor annunciation that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. The pilot flying will record any change in the Ground Proximity Monitor indication and advise the other pilot when operating at a sample station without ground power. During takeoff, the Captain should select the Speedbrake Handle status message unless directed otherwise by the Sample Operations Center.

During parking, the relief pilot should record the Ground Proximity Monitor status message when operating at a sample station without ground power. The Brake Temperature Monitor indication that differs from the expected state requires the Captain to record the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. During climb, the Captain should select the Fuel Crossfeed annunciation when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will cross-check any change in the Standby Hydraulic switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

The relief pilot will brief any change in the Flap Position Indication switch position and advise the other pilot once the checklist item is complete. During preflight, the First Officer should select the Weather Radar advisory when operating at a sample station without ground power. During takeoff, the pilot monitoring should record the Bleed Air Supply status message unless directed otherwise by the Sample Operations Center. The Landing Gear Indication switch position is expected to read within the sample range of 2 to 8 units during approach. The Speedbrake Handle status message that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center.

During cruise, the relief pilot should cross-check the Pack Temperature Control indication when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will confirm any change in the Landing Gear Indication indication and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

The pilot flying will confirm any change in the Hydraulic System A status message and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle indication is expected to read within the sample range of 88 to 97

units during parking.

CAUTION: If the Standby Hydraulic is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Probe Heat is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- The Traffic Advisory Display selector position that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.
- The first officer will select any change in the Fuel Crossfeed switch position and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Standby Hydraulic switch position	65 units	Normal
Autothrottle selector position	75 units	Refer to related topic
Engine Anti-Ice switch position	31 units	Refer to related topic
Autopilot Channel B status message	1 units	Monitor
Probe Heat switch position	40 units	Normal
Fuel Crossfeed selector position	26 units	Refer to related topic

08.10.12 Autopilot Channel A Crew Awareness

The captain will brief any change in the Traffic Advisory Display advisory and advise the other pilot when operating at a sample station without ground power. The Landing Gear Indication status message is expected to read within the sample range of 80 to 90 units during a maintenance-requested ground run. During taxi, the First Officer should select the Transponder quantity display if the indication does not stabilize within the sample interval. The Speedbrake Handle quantity display that differs from the expected state requires the relief pilot to announce the condition when conditions permit.

During cruise, the pilot flying should confirm the Hydraulic System B annunciation once the checklist item is complete. If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Pack Temperature Control is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Nosewheel Steering advisory is expected to read within the sample range of 68 to 78 units during engine start. Both pilots will monitor any change in the Flap Position Indication annunciation and advise the other pilot when the associated caution light remains illuminated.

Values in this manual are invented and must not be used for any operational purpose. If the Autopilot Channel A is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The first officer will announce any change in the Weather Radar selector position and advise the other pilot before the next phase of flight. The pilot monitoring will record any change in the Ground Proximity Monitor quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. If the Wing Anti-Ice is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: If the Oxygen Distribution is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Weather Radar switch position is expected to read within the sample range of 66 to 73 units during a turnaround.

Condition	Sample value	Remarks
-----------	--------------	---------

Thrust Reverser indication	95 units	Normal
Speedbrake Handle status message	10 units	Normal
Speedbrake Handle quantity display	87 units	Normal
Fire Detection Loop quantity display	25 units	Monitor

08.10.13 Ground Proximity Monitor Indications

The Autopilot Channel B annunciation that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight. During landing, the pilot flying should record the Transponder annunciation if a discrepancy is observed. The Hydraulic System B status message that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. The Auxiliary Power Unit selector position is expected to read within the sample range of 79 to 84 units during approach.

The Engine Anti-Ice switch position is expected to read within the sample range of 89 to 93 units during preflight. The Auxiliary Power Unit quantity display that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. The Stall Warning status message that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated. The Weather Radar status message is expected to read within the sample range of 69 to 81 units during a diversion. The Stall Warning status message that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center.

- The Cabin Pressure Controller quantity display is expected to read within the sample range of 70 to 79 units during an extended ground delay.
- The Traffic Advisory Display switch position that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.
- The Stall Warning advisory is expected to read within the sample range of 33 to 36 units during a maintenance-requested ground run.

NOTE: During cruise, both pilots should announce the Probe Heat indication once the checklist item is complete.

If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Nosewheel Steering indication that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. If the Fuel Crossfeed is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The captain will confirm any change in the Hydraulic System A selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

During a maintenance-requested ground run, the relief pilot should cross-check the Flight Management Computer advisory if the indication does not stabilize within the sample interval. During cruise, the First Officer should confirm the Bleed Air Supply selector position if the indication does not stabilize within the sample interval. The Autobrake Selector indication that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete.

If the Standby Instruments is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Cargo Smoke Detection is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. See 08.10.10 Landing Gear Indication Crew Awareness.

08.10.14 Autopilot Channel B Status Messages

During preflight, both pilots should brief the Standby Instruments advisory if the indication does not stabilize within the sample interval. If the Autopilot Channel B is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Thrust Reverser selector position that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed. The relief pilot will verify any change in the Brake

Temperature Monitor indication and advise the other pilot when conditions permit. The Bleed Air Supply switch position is expected to read within the sample range of 3 to 13 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure.

The pilot monitoring will confirm any change in the Landing Gear Indication status message and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. If the Center Tank Pumps is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The Cargo Smoke Detection annunciation that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

During approach, both pilots should cross-check the Ground Proximity Monitor switch position if a discrepancy is observed. Both pilots will select any change in the Autopilot Channel B quantity display and advise the other pilot once the checklist item is complete. The pilot flying will record any change in the Flap Position Indication quantity display and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Fire Detection Loop advisory	97 units	Refer to related topic
Probe Heat advisory	28 units	Normal
Cockpit Voice Recorder switch position	13 units	Monitor

- During cruise, the Captain should cross-check the Weather Radar selector position when conditions permit.
- The pilot flying will announce any change in the Auxiliary Power Unit advisory and advise the other pilot if a discrepancy is observed.
- The Flap Position Indication advisory is expected to read within the sample range of 33 to 40 units during a maintenance-requested ground run.
- The pilot flying will brief any change in the Thrust Reverser selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During a turnaround, the pilot flying should select the Hydraulic System A status message before the next phase of flight.
- The Fire Detection Loop switch position that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Flight Management Computer is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- The relief pilot will select any change in the Thrust Reverser advisory and advise the other pilot when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Autopilot Channel A is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Speedbrake Handle annunciation and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection selector position that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. During landing, the pilot flying should verify the Primary Electrical Bus indication when the associated caution light remains illuminated.

08.10.15 Wing Anti-Ice Reset Guidance

The Thrust Reverser switch position that differs from the expected state requires the pilot flying to select the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will record any change in the Cabin Pressure Controller advisory and advise the other pilot before the next phase of flight. If the Window Heat is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Autopilot Channel B selector position is expected to read within the sample range of 15 to 26 units during a maintenance-requested ground run. The first officer will verify any change in the Hydraulic System B indication and advise the other pilot when conditions permit.

NOTE: The Cockpit Voice Recorder indication is expected to read within the sample range of 6 to 12 units during a diversion.

Condition	Sample value	Remarks
Auxiliary Power Unit switch position	80 units	Normal
Hydraulic System A selector position	55 units	Advisory only
Ground Proximity Monitor indication	20 units	Normal
Ground Proximity Monitor annunciation	60 units	Normal
Bleed Air Supply advisory	55 units	Advisory only
Autobrake Selector advisory	8 units	Normal

During a maintenance-requested ground run, the First Officer should cross-check the Flap Position Indication indication when conditions permit. The pilot flying will select any change in the Fuel Crossfeed selector position and advise the other pilot when conditions permit. If the Probe Heat is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

Both pilots will cross-check any change in the Auxiliary Power Unit status message and advise the other pilot before the next phase of flight. During approach, the First Officer should monitor the Window Heat indication before the next phase of flight. The Window Heat indication that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval.

The first officer will select any change in the Primary Electrical Bus selector position and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will record any change in the Brake Temperature Monitor annunciation and advise the other pilot before the next phase of flight.

NOTE: The Cockpit Voice Recorder advisory is expected to read within the sample range of 77 to 87 units during descent.

Refer to the related topic for additional sample context. The captain will select any change in the Standby Hydraulic annunciation and advise the other pilot when the associated caution light remains illuminated. The Cockpit Voice Recorder status message that differs from the expected state requires both pilots to brief the condition unless directed otherwise by the Sample Operations Center.

08.10.16 Autobrake Selector Status Messages

During approach, the First Officer should record the Pack Temperature Control quantity display when conditions permit. If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Flap Position Indication switch position that differs from the expected state requires the Captain to verify the condition before the next phase of flight. The Hydraulic System B annunciation that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. The captain will announce any change in the Oxygen Distribution selector position

and advise the other pilot when the associated caution light remains illuminated. If the Standby Hydraulic is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Auxiliary Power Unit switch position	16 units	Normal
Fuel Crossfeed switch position	63 units	Normal
Cockpit Voice Recorder quantity display	10 units	Monitor
Bleed Air Supply indication	57 units	Advisory only
Fuel Crossfeed selector position	35 units	Advisory only

The relief pilot will select any change in the Ground Proximity Monitor indication and advise the other pilot when conditions permit. The Standby Instruments annunciation that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. The Oxygen Distribution annunciation that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight. The Hydraulic System B status message that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

The Ground Proximity Monitor selector position is expected to read within the sample range of 67 to 72 units during takeoff. The Bleed Air Supply selector position that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight. The Engine Anti-Ice indication that differs from the expected state requires the Captain to brief the condition before the next phase of flight.

Both pilots will confirm any change in the Bleed Air Supply advisory and advise the other pilot when conditions permit. The Auxiliary Power Unit advisory is expected to read within the sample range of 82 to 87 units during descent. The relief pilot will cross-check any change in the Wing Anti-Ice switch position and advise the other pilot when conditions permit. During taxi, the relief pilot should select the Wing Anti-Ice advisory unless directed otherwise by the Sample Operations Center.

Both pilots will verify any change in the Probe Heat annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, the Captain should cross-check the Pack Temperature Control indication when the associated caution light remains illuminated. See 05.70.1 Brake Temperature Monitor Limits Display.

08.20 Controls and Indicators

08.20.1 Engine Anti-Ice Overview

Refer to the related topic for additional sample context. The Autopilot Channel B annunciation is expected to read within the sample range of 93 to 103 units during parking. During a turnaround, both pilots should verify the Weather Radar status message if a discrepancy is observed. The pilot monitoring will verify any change in the Flight Management Computer annunciation and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Flight Management Computer advisory	54 units	Advisory only
Window Heat quantity display	73 units	Refer to related topic
Wing Anti-Ice status message	6 units	Advisory only
Speedbrake Handle indication	53 units	Refer to related topic

Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor quantity display that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and

structure. During landing, the pilot flying should brief the Flap Position Indication status message once the checklist item is complete. The Speedbrake Handle quantity display that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval.

- The Center Tank Pumps annunciation that differs from the expected state requires the Captain to verify the condition when conditions permit.
- If the Stall Warning is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.
- Both pilots will monitor any change in the Fuel Crossfeed selector position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Fuel Crossfeed selector position	47 units	Normal
Probe Heat annunciation	16 units	Advisory only
Flight Management Computer switch position	54 units	Refer to related topic

NOTE: If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

NOTE: The Autothrottle indication that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit. During preflight, the Captain should verify the Cargo Smoke Detection quantity display once the checklist item is complete.

Condition	Sample value	Remarks
Transponder advisory	40 units	Advisory only
Auxiliary Power Unit quantity display	85 units	Refer to related topic
Brake Temperature Monitor advisory	87 units	Monitor
Probe Heat quantity display	42 units	Normal
Traffic Advisory Display indication	84 units	Advisory only
Speedbrake Handle switch position	86 units	Normal

08.20.2 Hydraulic System B Limits Display

The Transponder status message is expected to read within the sample range of 30 to 33 units during an extended ground delay. The pilot flying will verify any change in the Autopilot Channel A selector position and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The pilot flying will monitor any change in the Speedbrake Handle quantity display and advise the other pilot once the checklist item is complete.

CAUTION: If the Weather Radar is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Wing Anti-Ice advisory that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power.

CAUTION: The Autopilot Channel A switch position that differs from the expected state requires the Captain to confirm the condition before the next phase of flight.

During descent, the relief pilot should record the Autobrake Selector indication if a discrepancy is observed. During a diversion, the pilot flying should record the Primary Electrical Bus switch position before the next phase of flight. The Cabin Pressure Controller switch position is expected to read within the sample range of 57 to 67 units during taxi. The Standby Hydraulic advisory that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice selector position is expected to read within the sample range of 54 to 60 units during taxi.

CAUTION: The Traffic Advisory Display selector position that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Fire Detection Loop quantity display	51 units	Advisory only
Engine Anti-Ice quantity display	35 units	Advisory only
Fuel Crossfeed advisory	53 units	Refer to related topic
Weather Radar selector position	22 units	Monitor
Probe Heat status message	50 units	Refer to related topic
Transponder advisory	72 units	Advisory only

08.20.3 Thrust Reverser Crew Awareness

During a diversion, the First Officer should select the Auxiliary Power Unit advisory when operating at a sample station without ground power. The relief pilot will confirm any change in the Weather Radar selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection quantity display is expected to read within the sample range of 74 to 80 units during engine start. If the Transponder is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. The Thrust Reverser status message that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

The Hydraulic System A selector position that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. Both pilots will cross-check any change in the Standby Hydraulic selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. If the Pack Temperature Control is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

The Cargo Smoke Detection indication that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power. If the Probe Heat is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

During landing, the pilot monitoring should select the Nosewheel Steering annunciation once the checklist item is complete. The Autopilot Channel A quantity display that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. The Speedbrake Handle indication that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. During climb, the pilot flying should select the Thrust Reverser status message once the checklist item is complete.

Condition	Sample value	Remarks
Wing Anti-Ice switch position	48 units	Normal
Fire Detection Loop status message	59 units	Refer to related topic
Ground Proximity Monitor annunciation	91 units	Refer to related topic
Hydraulic System B status message	89 units	Refer to related topic

CAUTION: The Hydraulic System A annunciation is expected to read within the sample range of 18 to 26 units during takeoff.

08.20.4 Cabin Pressure Controller Interfaces

The pilot flying will announce any change in the Cabin Pressure Controller advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Window Heat quantity display that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight. The pilot flying will confirm any change in the Nosewheel Steering indication and advise the other pilot when conditions permit. The relief pilot will brief any change in the Bleed Air Supply selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. If the Weather Radar is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Engine Anti-Ice status message	8 units	Monitor
Fire Detection Loop indication	14 units	Normal
Transponder quantity display	21 units	Refer to related topic
Auxiliary Power Unit advisory	15 units	Refer to related topic

CAUTION: The captain will select any change in the Flight Management Computer status message and advise the other pilot when operating at a sample station without ground power. The relief pilot will select any change in the Hydraulic System B switch position and advise the other pilot when operating at a sample station without ground power. The Autobrake Selector selector position that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. During preflight, the pilot monitoring should brief the Pack Temperature Control switch position once the checklist item is complete.

During parking, the relief pilot should brief the Pack Temperature Control selector position when conditions permit. The Standby Hydraulic quantity display is expected to read within the sample range of 94 to 101 units during an extended ground delay. During a turnaround, the pilot monitoring should cross-check the Primary Electrical Bus status message if the indication does not stabilize within the sample interval. The Weather Radar annunciation that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. During descent, the pilot flying should verify the Speedbrake Handle annunciation when operating at a sample station without ground power.

- If the Transponder is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- The Engine Anti-Ice status message is expected to read within the sample range of 22 to 33 units during climb.
- During takeoff, the pilot flying should cross-check the Landing Gear Indication quantity display once the checklist item is complete.
- The Autobrake Selector annunciation is expected to read within the sample range of 37 to 44 units during approach.
- If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- The first officer will announce any change in the Traffic Advisory Display quantity display and advise the other pilot when the associated caution light remains illuminated.

08.20.5 Nosewheel Steering Overview

The Window Heat switch position that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete. The relief pilot will brief any change in the Wing Anti-Ice selector position and

advise the other pilot if the indication does not stabilize within the sample interval. If the Ground Proximity Monitor is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. During parking, both pilots should monitor the Wing Anti-Ice annunciation when the associated caution light remains illuminated.

- If the Landing Gear Indication is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Standby Instruments annunciation is expected to read within the sample range of 95 to 107 units during parking.

NOTE: Both pilots will record any change in the Wing Anti-Ice advisory and advise the other pilot once the checklist item is complete.

The Hydraulic System B switch position is expected to read within the sample range of 2 to 5 units during a diversion. If the Autothrottle is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The Traffic Advisory Display status message that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight. The Fire Detection Loop status message is expected to read within the sample range of 54 to 61 units during a diversion. The pilot flying will announce any change in the Cockpit Voice Recorder selector position and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Nosewheel Steering quantity display is expected to read within the sample range of 62 to 70 units during descent. The relief pilot will confirm any change in the Center Tank Pumps selector position and advise the other pilot when the associated caution light remains illuminated.

- If the Window Heat is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.
- The first officer will record any change in the Hydraulic System A quantity display and advise the other pilot when the associated caution light remains illuminated.
- The pilot monitoring will verify any change in the Auxiliary Power Unit quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- The Probe Heat switch position that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated.
- During an extended ground delay, the pilot flying should record the Autobrake Selector annunciation before the next phase of flight.

Refer to the related topic for additional sample context. The Wing Anti-Ice annunciation that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Cockpit Voice Recorder advisory	30 units	Normal
Flap Position Indication annunciation	37 units	Advisory only
Auxiliary Power Unit advisory	44 units	Advisory only

The relief pilot will record any change in the Bleed Air Supply selector position and advise the other pilot before the next phase of flight. The Bleed Air Supply switch position that differs from the expected state requires both pilots to brief the condition once the checklist item is complete. The Cargo Smoke Detection quantity display is expected to read within the sample range of 85 to 92 units during taxi. During an extended ground delay, the First Officer should confirm the Wing Anti-Ice quantity display if a discrepancy is observed. See 10.20.12 Window Heat Reset Guidance.

08.20.6 Auxiliary Power Unit Power Sources

This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the relief pilot should select the Landing Gear Indication status message if the indication does not stabilize within the sample interval. The pilot flying will monitor any change in the Hydraulic System B quantity display and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Autothrottle status message	32 units	Advisory only
Autopilot Channel A switch position	84 units	Normal
Probe Heat selector position	37 units	Monitor
Flight Management Computer annunciation	88 units	Refer to related topic
Autobrake Selector advisory	61 units	Monitor
Autobrake Selector status message	61 units	Advisory only
Transponder status message	14 units	Monitor

Refer to the related topic for additional sample context. The pilot monitoring will record any change in the Hydraulic System A switch position and advise the other pilot when conditions permit. The Flight Management Computer selector position is expected to read within the sample range of 95 to 107 units during taxi. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

- During parking, the pilot monitoring should cross-check the Autopilot Channel B selector position when the associated caution light remains illuminated.
- The Flap Position Indication indication is expected to read within the sample range of 57 to 66 units during takeoff.
- The Center Tank Pumps status message that differs from the expected state requires the First Officer to announce the condition when conditions permit.
- The Autopilot Channel B status message is expected to read within the sample range of 44 to 56 units during cruise.
- The Pack Temperature Control annunciation is expected to read within the sample range of 91 to 102 units during engine start.
- The Standby Instruments advisory is expected to read within the sample range of 5 to 9 units during an extended ground delay.

This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, both pilots should monitor the Stall Warning selector position unless directed otherwise by the Sample Operations Center. If the Autobrake Selector is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Hydraulic System B switch position is expected to read within the sample range of 85 to 97 units during parking. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

The first officer will verify any change in the Fire Detection Loop indication and advise the other pilot when conditions permit. If the Bleed Air Supply is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Hydraulic System B indication is expected to read within the sample range of 63 to 72 units during climb. During taxi, the pilot flying should verify the Pack Temperature Control annunciation when operating at a sample station without ground power. The Standby Hydraulic switch position that differs from the expected state requires the Captain to confirm the condition before the next phase of flight. The relief pilot will confirm any change in the Flap Position Indication advisory and advise the other pilot if a discrepancy is observed.

CAUTION: The Oxygen Distribution quantity display that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. During parking, the First Officer should announce the Cargo

Smoke Detection selector position unless directed otherwise by the Sample Operations Center.

08.20.7 Probe Heat Status Messages

The Nosewheel Steering switch position is expected to read within the sample range of 42 to 46 units during approach. If the Standby Instruments is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

During preflight, both pilots should announce the Speedbrake Handle switch position when operating at a sample station without ground power. During parking, the pilot flying should record the Autopilot Channel A selector position unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

During approach, the Captain should cross-check the Standby Hydraulic selector position once the checklist item is complete. The Engine Anti-Ice annunciation that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. During descent, the First Officer should select the Cockpit Voice Recorder annunciation if the indication does not stabilize within the sample interval.

NOTE: The Cockpit Voice Recorder status message that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will cross-check any change in the Thrust Reverser switch position and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: The pilot flying will select any change in the Speedbrake Handle switch position and advise the other pilot when conditions permit. During an extended ground delay, both pilots should record the Standby Instruments switch position once the checklist item is complete.

CAUTION: During taxi, the First Officer should select the Thrust Reverser quantity display if a discrepancy is observed.

08.20.8 Autopilot Channel A Power Sources

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will brief any change in the Probe Heat advisory and advise the other pilot when the associated caution light remains illuminated. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

CAUTION: Both pilots will monitor any change in the Bleed Air Supply status message and advise the other pilot if the indication does not stabilize within the sample interval.

- Refer to the related topic for additional sample context.
- During preflight, the pilot monitoring should cross-check the Cargo Smoke Detection quantity display once the checklist item is complete.
- During cruise, both pilots should cross-check the Ground Proximity Monitor advisory if a discrepancy is observed.
- If the Center Tank Pumps is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- The Flight Management Computer switch position that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power.

The pilot flying will cross-check any change in the Cabin Pressure Controller switch position and advise the other pilot when conditions permit. During a turnaround, the relief pilot should cross-check the Engine Anti-Ice status message when operating at a sample station without ground power. The Landing Gear Indication annunciation is expected to read within the sample range of 29 to 35 units during cruise. The Oxygen Distribution selector position that differs

from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated.

- The pilot flying will cross-check any change in the Pack Temperature Control selector position and advise the other pilot once the checklist item is complete.
- Refer to the related topic for additional sample context.
- The Bleed Air Supply status message is expected to read within the sample range of 31 to 41 units during a maintenance-requested ground run.
- The Landing Gear Indication status message is expected to read within the sample range of 14 to 26 units during taxi.
- The pilot monitoring will monitor any change in the Pack Temperature Control annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- The first officer will select any change in the Hydraulic System A annunciation and advise the other pilot once the checklist item is complete.

NOTE: The Hydraulic System A selector position is expected to read within the sample range of 89 to 95 units during approach.

During parking, both pilots should verify the Window Heat selector position before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Bleed Air Supply is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The Autothrottle annunciation is expected to read within the sample range of 76 to 79 units during landing. The captain will record any change in the Primary Electrical Bus status message and advise the other pilot once the checklist item is complete. See 18.20.6 Autopilot Channel A Test.

CAUTION: If the Oxygen Distribution is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Primary Electrical Bus advisory	51 units	Refer to related topic
Hydraulic System A selector position	37 units	Refer to related topic
Probe Heat indication	62 units	Refer to related topic
Autobrake Selector status message	93 units	Advisory only

08.20.9 Center Tank Pumps Normal Operation

The Nosewheel Steering quantity display is expected to read within the sample range of 12 to 24 units during takeoff. The Fuel Crossfeed quantity display that differs from the expected state requires the Captain to select the condition if a discrepancy is observed. During climb, the relief pilot should announce the Cockpit Voice Recorder status message if a discrepancy is observed. Refer to the related topic for additional sample context. If the Engine Anti-Ice is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

CAUTION: If the Brake Temperature Monitor is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

The Cabin Pressure Controller selector position that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. The Ground Proximity Monitor indication is expected to read within the sample range of 93 to 97 units during approach. During landing, the pilot monitoring should brief the Standby Instruments switch position if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

- The Cockpit Voice Recorder indication that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated.

- During descent, the pilot monitoring should cross-check the Transponder annunciation when operating at a sample station without ground power.
- During parking, both pilots should select the Hydraulic System B annunciation when conditions permit.

The Brake Temperature Monitor selector position that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated. The relief pilot will record any change in the Nosewheel Steering status message and advise the other pilot when conditions permit. The Flap Position Indication status message that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. The Center Tank Pumps switch position is expected to read within the sample range of 80 to 84 units during approach.

Condition	Sample value	Remarks
Flight Management Computer advisory	91 units	Normal
Wing Anti-Ice advisory	23 units	Advisory only
Flap Position Indication annunciation	51 units	Normal
Thrust Reverser switch position	93 units	Normal

08.20.10 Stall Warning Power Sources

During an extended ground delay, both pilots should announce the Speedbrake Handle annunciation if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Cargo Smoke Detection advisory is expected to read within the sample range of 44 to 49 units during cruise. The Nosewheel Steering switch position is expected to read within the sample range of 87 to 92 units during engine start. The captain will brief any change in the Standby Hydraulic selector position and advise the other pilot once the checklist item is complete.

CAUTION: During taxi, the pilot flying should record the Landing Gear Indication quantity display before the next phase of flight.

CAUTION: The Speedbrake Handle status message is expected to read within the sample range of 15 to 23 units during a turnaround. The Cargo Smoke Detection indication is expected to read within the sample range of 38 to 46 units during climb.

NOTE: During landing, the relief pilot should monitor the Primary Electrical Bus annunciation once the checklist item is complete. During a diversion, both pilots should verify the Brake Temperature Monitor quantity display when conditions permit.

Condition	Sample value	Remarks
Autothrottle status message	81 units	Normal
Thrust Reverser selector position	54 units	Advisory only
Standby Hydraulic advisory	5 units	Monitor

The captain will verify any change in the Hydraulic System A quantity display and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will monitor any change in the Weather Radar annunciation and advise the other pilot when operating at a sample station without ground power. The Cabin Pressure Controller selector position is expected to read within the sample range of 43 to 48 units during preflight.

NOTE: The Traffic Advisory Display quantity display is expected to read within the sample range of 62 to 70 units during parking. The relief pilot will cross-check any change in the Fire Detection Loop advisory and advise the other pilot when operating at a sample station without ground power.

During parking, the relief pilot should brief the Oxygen Distribution annunciation if a discrepancy is observed. The Landing Gear Indication annunciation that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. During a maintenance-requested ground run, the Captain should

cross-check the Standby Instruments quantity display if the indication does not stabilize within the sample interval. The Speedbrake Handle advisory that differs from the expected state requires the pilot flying to record the condition when conditions permit. Both pilots will record any change in the Autopilot Channel B advisory and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context.

08.20.11 Speedbrake Handle Reset Guidance

The first officer will record any change in the Standby Instruments quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The captain will brief any change in the Landing Gear Indication quantity display and advise the other pilot before the next phase of flight. If the Ground Proximity Monitor is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Fire Detection Loop annunciation that differs from the expected state requires the First Officer to monitor the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Nosewheel Steering is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Stall Warning selector position that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 31 to 42 units during descent. The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. The Landing Gear Indication switch position that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. If the Autobrake Selector is inoperative, continue an extended ground delay only after both pilots have reviewed the associated sample guidance.

- During a turnaround, the pilot monitoring should brief the Speedbrake Handle quantity display if a discrepancy is observed.
- The captain will monitor any change in the Hydraulic System A status message and advise the other pilot once the checklist item is complete.
- During landing, the First Officer should monitor the Oxygen Distribution advisory unless directed otherwise by the Sample Operations Center.

CAUTION: The first officer will announce any change in the Auxiliary Power Unit status message and advise the other pilot once the checklist item is complete. The Cargo Smoke Detection switch position that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power.

The Stall Warning advisory that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose.

- The Bleed Air Supply switch position is expected to read within the sample range of 76 to 80 units during descent.
- Values in this manual are invented and must not be used for any operational purpose.
- During a diversion, the pilot monitoring should cross-check the Fuel Crossfeed status message once the checklist item is complete.
- The relief pilot will announce any change in the Cockpit Voice Recorder indication and advise the other pilot before the next phase of flight.
- The Autothrottle quantity display is expected to read within the sample range of 92 to 102 units during taxi.

The Engine Anti-Ice selector position that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power. The Primary Electrical Bus advisory is expected to read within the sample range of 25 to 32 units during descent. The Ground Proximity Monitor quantity display is expected to read within the sample range of 24 to 30 units during a turnaround. During a turnaround, both pilots

should monitor the Autopilot Channel B annunciation when operating at a sample station without ground power.

During a diversion, the Captain should cross-check the Brake Temperature Monitor quantity display if the indication does not stabilize within the sample interval. The Transponder switch position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. The Speedbrake Handle quantity display that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated. During engine start, the Captain should record the Autothrottle quantity display when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

08.20.12 Landing Gear Indication Crew Awareness

The Ground Proximity Monitor switch position that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. The Probe Heat advisory that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. The Hydraulic System A advisory is expected to read within the sample range of 80 to 83 units during parking. During descent, the Captain should brief the Standby Instruments switch position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Hydraulic System B advisory	70 units	Refer to related topic
Speedbrake Handle annunciation	71 units	Monitor
Center Tank Pumps switch position	7 units	Normal
Standby Hydraulic status message	6 units	Monitor

The Auxiliary Power Unit switch position that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed. The Fire Detection Loop status message is expected to read within the sample range of 47 to 53 units during parking. Values in this manual are invented and must not be used for any operational purpose.

The Autopilot Channel A selector position that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete. The Wing Anti-Ice switch position that differs from the expected state requires the pilot monitoring to select the condition when conditions permit. If the Auxiliary Power Unit is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

CAUTION: If the Window Heat is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

- The Cargo Smoke Detection selector position that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.
- During a maintenance-requested ground run, the pilot flying should select the Pack Temperature Control quantity display if a discrepancy is observed.
- The relief pilot will monitor any change in the Primary Electrical Bus status message and advise the other pilot when conditions permit.
- Both pilots will brief any change in the Window Heat selector position and advise the other pilot once the checklist item is complete.
- If the Stall Warning is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

The captain will select any change in the Bleed Air Supply switch position and advise the other pilot when the associated caution light remains illuminated. The Pack Temperature Control quantity display is expected to read within the sample range of 91 to 103 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Fuel Crossfeed selector position that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight.
- The pilot flying will select any change in the Ground Proximity Monitor annunciation and advise the other pilot before the next phase of flight.
- Refer to the related topic for additional sample context.
- The first officer will brief any change in the Autopilot Channel A status message and advise the other pilot when operating at a sample station without ground power.
- The Thrust Reverser quantity display that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated.
- During takeoff, the First Officer should monitor the Oxygen Distribution indication once the checklist item is complete.

08.20.13 Hydraulic System B Interfaces

Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will select any change in the Weather Radar switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System A advisory that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Landing Gear Indication annunciation	39 units	Normal
Hydraulic System A selector position	95 units	Normal
Oxygen Distribution quantity display	55 units	Refer to related topic
Ground Proximity Monitor switch position	67 units	Refer to related topic
Flight Management Computer indication	15 units	Normal

During a maintenance-requested ground run, the Captain should record the Engine Anti-Ice advisory unless directed otherwise by the Sample Operations Center. During a turnaround, the pilot flying should record the Cockpit Voice Recorder advisory once the checklist item is complete. The first officer will monitor any change in the Hydraulic System A status message and advise the other pilot if the indication does not stabilize within the sample interval. The Auxiliary Power Unit annunciation is expected to read within the sample range of 23 to 26 units during cruise.

NOTE: The Thrust Reverser advisory is expected to read within the sample range of 41 to 48 units during cruise.

- Values in this manual are invented and must not be used for any operational purpose.
- During taxi, the First Officer should select the Flight Management Computer annunciation before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Flight Management Computer quantity display is expected to read within the sample range of 20 to 31 units during a maintenance-requested ground run.
- The Cockpit Voice Recorder quantity display is expected to read within the sample range of 52 to 57 units during taxi.

The relief pilot will select any change in the Probe Heat annunciation and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. If the Probe Heat is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Wing Anti-Ice status message that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval.

08.20.14 Ground Proximity Monitor Overview

The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution switch position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. The Window Heat selector position that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. The first officer will monitor any change in the Brake Temperature Monitor indication and advise the other pilot once the checklist item is complete. If the Speedbrake Handle is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The Thrust Reverser annunciation that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated.

During takeoff, the relief pilot should record the Stall Warning indication before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Fire Detection Loop status message that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. The Transponder switch position that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated. The Wing Anti-Ice advisory that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. The captain will confirm any change in the Landing Gear Indication switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The Cargo Smoke Detection advisory that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. The Nosewheel Steering switch position that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Oxygen Distribution indication	46 units	Advisory only
Probe Heat status message	18 units	Refer to related topic
Window Heat switch position	17 units	Normal

CAUTION: If the Window Heat is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The first officer will cross-check any change in the Autobrake Selector advisory and advise the other pilot when conditions permit.

08.20.15 Hydraulic System B Crew Awareness

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Brake Temperature Monitor switch position that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. The Weather Radar status message that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete. The Cargo Smoke Detection switch position that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval. The Primary Electrical Bus indication is expected to read within the sample range of 57 to 68 units during a turnaround.

- Values in this manual are invented and must not be used for any operational purpose.

- During descent, the pilot flying should monitor the Autopilot Channel B switch position if a discrepancy is observed.
- If the Ground Proximity Monitor is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.
- The Oxygen Distribution quantity display that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power.
- The Stall Warning quantity display that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.
- If the Auxiliary Power Unit is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

During approach, the pilot flying should confirm the Thrust Reverser advisory when conditions permit. If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight.

NOTE: Both pilots will record any change in the Nosewheel Steering advisory and advise the other pilot when operating at a sample station without ground power.

CAUTION: If the Hydraulic System A is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will monitor any change in the Transponder switch position and advise the other pilot when conditions permit. If the Flap Position Indication is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. During descent, the pilot flying should confirm the Nosewheel Steering switch position if the indication does not stabilize within the sample interval.

08.20.16 Autopilot Channel B Indications

The pilot flying will record any change in the Weather Radar status message and advise the other pilot if a discrepancy is observed. The Autothrottle annunciation is expected to read within the sample range of 74 to 84 units during a maintenance-requested ground run. If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

- The pilot flying will record any change in the Oxygen Distribution indication and advise the other pilot before the next phase of flight.
- The captain will brief any change in the Auxiliary Power Unit annunciation and advise the other pilot when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Standby Instruments quantity display that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.
- The Primary Electrical Bus status message is expected to read within the sample range of 6 to 12 units during preflight.
- This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The Bleed Air Supply quantity display is expected to read within the sample range of 88 to 93 units during engine start.

The pilot monitoring will brief any change in the Stall Warning status message and advise the other pilot when operating at a sample station without ground power. The Primary Electrical Bus indication is expected to read within the sample range of 29 to 40 units during a maintenance-requested ground run. The pilot monitoring will monitor any change in the Engine Anti-Ice status message and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will monitor any change in the Autopilot Channel A status message and advise the other pilot when conditions permit. The pilot flying will monitor any change in the Standby Instruments advisory and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. During parking, the pilot monitoring should verify the Weather Radar indication before the next phase of flight.

08.30 Operation

08.30.1 Window Heat Power Sources

During an extended ground delay, both pilots should brief the Cabin Pressure Controller advisory before the next phase of flight. During preflight, the First Officer should cross-check the Speedbrake Handle advisory if a discrepancy is observed. If the Oxygen Distribution is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. Both pilots will confirm any change in the Cabin Pressure Controller indication and advise the other pilot when operating at a sample station without ground power. The Autopilot Channel B indication is expected to read within the sample range of 23 to 30 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure.

The Bleed Air Supply indication is expected to read within the sample range of 45 to 53 units during an extended ground delay. During taxi, the First Officer should brief the Ground Proximity Monitor selector position when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. During landing, the pilot monitoring should brief the Transponder status message unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: During landing, the Captain should cross-check the Brake Temperature Monitor annunciation when operating at a sample station without ground power. The Speedbrake Handle switch position that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval.

The Flap Position Indication switch position is expected to read within the sample range of 4 to 10 units during taxi. The Hydraulic System A selector position is expected to read within the sample range of 13 to 24 units during cruise. Both pilots will select any change in the Auxiliary Power Unit annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Pack Temperature Control selector position that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated.

The Ground Proximity Monitor indication that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power. The Standby Instruments status message is expected to read within the sample range of 98 to 104 units during takeoff. The Window Heat annunciation that differs from the expected state requires both pilots to verify the condition when conditions permit. During cruise, the pilot monitoring should record the Pack Temperature Control selector position unless directed otherwise by the Sample Operations Center. If the Primary Electrical Bus is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

08.30.2 Hydraulic System B Interfaces

Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic annunciation is expected to read within the sample range of 11 to 14 units during a diversion. Refer to the related topic for additional sample context. The Center Tank Pumps switch position is expected to read within the sample range of 62 to 70 units during engine start.

CAUTION: The Hydraulic System A advisory that differs from the expected state requires the pilot monitoring to record the condition when the associated caution light remains illuminated. The Center Tank Pumps annunciation that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete.

Condition	Sample value	Remarks
Flight Management Computer status message	33 units	Monitor
Center Tank Pumps switch position	11 units	Normal
Engine Anti-Ice annunciation	41 units	Advisory only
Standby Hydraulic status message	44 units	Monitor
Landing Gear Indication selector position	30 units	Advisory only

CAUTION: The captain will cross-check any change in the Flap Position Indication switch position and advise the other pilot when operating at a sample station without ground power. The Engine Anti-Ice quantity display that differs from the expected state requires the Captain to verify the condition before the next phase of flight.

During parking, the pilot monitoring should announce the Window Heat annunciation once the checklist item is complete. The Fuel Crossfeed indication is expected to read within the sample range of 53 to 58 units during taxi. Both pilots will monitor any change in the Flap Position Indication quantity display and advise the other pilot if a discrepancy is observed. The Speedbrake Handle status message is expected to read within the sample range of 34 to 42 units during an extended ground delay. The Cargo Smoke Detection annunciation is expected to read within the sample range of 7 to 15 units during a diversion. The Fire Detection Loop status message that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated.

- The Cargo Smoke Detection annunciation that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed.
- Refer to the related topic for additional sample context.
- The Fuel Crossfeed status message is expected to read within the sample range of 38 to 41 units during a diversion.
- If the Probe Heat is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- The Autopilot Channel B advisory that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power.
- The Brake Temperature Monitor status message is expected to read within the sample range of 70 to 75 units during approach.

Refer to the related topic for additional sample context. The Cockpit Voice Recorder indication that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Oxygen Distribution selector position that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. During approach, the First Officer should monitor the Center Tank Pumps status message if a discrepancy is observed. If the Engine Anti-Ice is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

08.30.3 Ground Proximity Monitor Interfaces

The Bleed Air Supply status message that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval. The pilot monitoring will record any change in the Cargo Smoke Detection quantity display and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Standby Instruments quantity display is expected to read within the sample range of 57 to 66 units during landing.

- The Hydraulic System A advisory that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval.
- During engine start, the pilot flying should select the Hydraulic System A quantity display when conditions permit.
- During an extended ground delay, the relief pilot should verify the Autothrottle advisory if the indication does not stabilize within the sample interval.
- The first officer will confirm any change in the Window Heat switch position and advise the other pilot if a discrepancy is observed.
- During descent, the Captain should brief the Cabin Pressure Controller status message when conditions permit.
- During takeoff, the pilot monitoring should monitor the Center Tank Pumps status message if the indication does not stabilize within the sample interval.

During taxi, the pilot monitoring should record the Nosewheel Steering indication if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle quantity display that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center. The Bleed Air Supply selector position that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete.

The pilot flying will record any change in the Wing Anti-Ice annunciation and advise the other pilot when the associated caution light remains illuminated. The relief pilot will confirm any change in the Autopilot Channel A selector position and advise the other pilot when conditions permit. The Standby Hydraulic status message that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

The Stall Warning quantity display is expected to read within the sample range of 3 to 10 units during a maintenance-requested ground run. During landing, the pilot flying should record the Engine Anti-Ice status message before the next phase of flight. During climb, the pilot flying should monitor the Stall Warning selector position if the indication does not stabilize within the sample interval. The relief pilot will record any change in the Landing Gear Indication status message and advise the other pilot when conditions permit. If the Primary Electrical Bus is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Traffic Advisory Display switch position that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power.

CAUTION: If the Flight Management Computer is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

08.30.4 Standby Instruments Overview

During descent, the First Officer should announce the Fuel Crossfeed indication when conditions permit. If the Wing Anti-Ice is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Cargo Smoke Detection selector position that differs from the expected state requires the First Officer to brief the condition when conditions permit. The Bleed Air Supply advisory is expected to read within the sample range of 37 to 46 units during climb. The captain will record any change in the Primary Electrical Bus switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System B is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Wing Anti-Ice indication and advise the other pilot once the checklist item is complete. The pilot monitoring will record any change in the Center Tank Pumps selector position and advise the other pilot before the next phase of flight. If the Thrust Reverser is inoperative, continue parking only after the pilot flying has reviewed the

associated sample guidance.

The Cargo Smoke Detection selector position that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed. The Autopilot Channel A selector position that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel B annunciation is expected to read within the sample range of 73 to 76 units during climb. During descent, the First Officer should select the Ground Proximity Monitor indication unless directed otherwise by the Sample Operations Center. The Center Tank Pumps advisory is expected to read within the sample range of 57 to 63 units during engine start.

NOTE: During landing, the pilot monitoring should verify the Thrust Reverser status message when conditions permit.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During an extended ground delay, the pilot monitoring should confirm the Auxiliary Power Unit annunciation before the next phase of flight.
- The Oxygen Distribution switch position that differs from the expected state requires both pilots to announce the condition before the next phase of flight.
- The Nosewheel Steering indication is expected to read within the sample range of 90 to 94 units during a diversion.
- The Speedbrake Handle quantity display that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit.
- If the Cabin Pressure Controller is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- The Autobrake Selector selector position is expected to read within the sample range of 61 to 68 units during landing.
- The pilot monitoring will monitor any change in the Transponder status message and advise the other pilot before the next phase of flight.
- The Engine Anti-Ice indication is expected to read within the sample range of 89 to 99 units during taxi.
- During descent, both pilots should brief the Probe Heat quantity display when conditions permit.

CAUTION: During parking, the Captain should select the Thrust Reverser status message before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

08.30.5 Pack Temperature Control Indications

The Hydraulic System B indication that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. If the Transponder is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

The Nosewheel Steering quantity display that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. If the Primary Electrical Bus is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Flap Position Indication annunciation that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power. During climb, the First Officer should brief the Flight Management Computer annunciation when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle advisory that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center.

The Thrust Reverser switch position that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder switch position is expected to read within the sample range of 34 to 46 units during approach. During climb, the relief pilot should monitor the Speedbrake Handle selector position once the checklist item is complete. The relief pilot will announce any change in the Center Tank Pumps switch position and advise the other pilot if a discrepancy is observed. The Flap Position Indication selector position is expected to read within the sample range of 68 to 80 units during engine start. The Oxygen Distribution status message that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power.

NOTE: Both pilots will cross-check any change in the Standby Instruments switch position and advise the other pilot when conditions permit. During taxi, the pilot flying should select the Speedbrake Handle advisory before the next phase of flight.

Condition	Sample value	Remarks
Auxiliary Power Unit status message	27 units	Advisory only
Probe Heat indication	58 units	Monitor
Auxiliary Power Unit annunciation	99 units	Monitor
Landing Gear Indication quantity display	79 units	Advisory only
Primary Electrical Bus advisory	23 units	Refer to related topic

If the Auxiliary Power Unit is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Wing Anti-Ice annunciation that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power. The relief pilot will cross-check any change in the Nosewheel Steering switch position and advise the other pilot when conditions permit. During descent, both pilots should select the Autobrake Selector selector position when the associated caution light remains illuminated.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. If the Autopilot Channel B is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

08.30.6 Pack Temperature Control Status Messages

During approach, the relief pilot should record the Pack Temperature Control selector position if a discrepancy is observed. If the Center Tank Pumps is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Wing Anti-Ice selector position is expected to read within the sample range of 50 to 58 units during parking. The first officer will select any change in the Autopilot Channel A advisory and advise the other pilot once the checklist item is complete. During cruise, the Captain should brief the Hydraulic System A advisory before the next phase of flight.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The first officer will record any change in the Cabin Pressure Controller selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Bleed Air Supply indication that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

The relief pilot will monitor any change in the Wing Anti-Ice quantity display and advise the other pilot once the checklist item is complete. During parking, the pilot flying should announce the Ground Proximity Monitor quantity display when conditions permit. If the Weather Radar is inoperative, continue parking only after both pilots has

reviewed the associated sample guidance.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The captain will cross-check any change in the Cabin Pressure Controller status message and advise the other pilot if a discrepancy is observed. If the Transponder is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

08.30.7 Window Heat Interfaces

The Cargo Smoke Detection switch position that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated. The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. The Autopilot Channel B selector position is expected to read within the sample range of 11 to 21 units during parking. The Cabin Pressure Controller quantity display that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center.

CAUTION: The Oxygen Distribution indication is expected to read within the sample range of 75 to 84 units during landing. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Nosewheel Steering status message that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed. During taxi, the relief pilot should announce the Engine Anti-Ice switch position if a discrepancy is observed.

During descent, the relief pilot should cross-check the Standby Instruments annunciation before the next phase of flight. During a maintenance-requested ground run, the pilot monitoring should announce the Wing Anti-Ice selector position once the checklist item is complete. The relief pilot will select any change in the Center Tank Pumps indication and advise the other pilot when conditions permit. The pilot flying will cross-check any change in the Brake Temperature Monitor selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Fire Detection Loop quantity display is expected to read within the sample range of 9 to 19 units during parking. During a diversion, the pilot flying should confirm the Speedbrake Handle selector position before the next phase of flight. See 02.40.15 Center Tank Pumps Test.

Condition	Sample value	Remarks
Autobrake Selector status message	89 units	Advisory only
Wing Anti-Ice indication	99 units	Refer to related topic
Standby Instruments indication	21 units	Advisory only
Fire Detection Loop status message	17 units	Refer to related topic
Thrust Reverser switch position	67 units	Refer to related topic

08.30.8 Bleed Air Supply Crew Awareness

Values in this manual are invented and must not be used for any operational purpose. During landing, the relief pilot should select the Cabin Pressure Controller annunciation before the next phase of flight. Refer to the related topic for additional sample context. The Autobrake Selector status message that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

- The Standby Hydraulic status message that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Flight Management Computer is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

- During an extended ground delay, the pilot flying should announce the Autothrottle status message if a discrepancy is observed.
- If the Weather Radar is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Flap Position Indication switch position is expected to read within the sample range of 7 to 16 units during taxi.

- If the Center Tank Pumps is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- The relief pilot will announce any change in the Autothrottle status message and advise the other pilot once the checklist item is complete.
- During an extended ground delay, the pilot flying should select the Oxygen Distribution annunciation when operating at a sample station without ground power.
- During cruise, both pilots should monitor the Ground Proximity Monitor advisory if the indication does not stabilize within the sample interval.
- The Ground Proximity Monitor status message that differs from the expected state requires the First Officer to brief the condition before the next phase of flight.

Condition	Sample value	Remarks
Brake Temperature Monitor selector position	45 units	Refer to related topic
Flight Management Computer advisory	61 units	Monitor
Fuel Crossfeed selector position	6 units	Advisory only
Traffic Advisory Display status message	87 units	Monitor
Pack Temperature Control status message	18 units	Monitor

08.30.9 Transponder Crew Awareness

The Hydraulic System A status message is expected to read within the sample range of 7 to 17 units during cruise. If the Stall Warning is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Nosewheel Steering indication and advise the other pilot when operating at a sample station without ground power.

If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. During preflight, the Captain should verify the Autopilot Channel B advisory when conditions permit.

During a diversion, the relief pilot should brief the Fuel Crossfeed quantity display unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Engine Anti-Ice advisory is expected to read within the sample range of 81 to 89 units during engine start. The first officer will select any change in the Fuel Crossfeed indication and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

If the Standby Instruments is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Cabin Pressure Controller advisory that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. During parking, the Captain should verify the Standby Hydraulic quantity display unless directed otherwise by the Sample Operations Center. Both pilots will confirm any change in the Thrust Reverser status message and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Flap Position Indication advisory	87 units	Normal
Stall Warning switch position	2 units	Normal
Cabin Pressure Controller advisory	41 units	Monitor

08.30.10 Thrust Reverser Overview

The Auxiliary Power Unit selector position that differs from the expected state requires both pilots to select the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the First Officer should announce the Flight Management Computer status message when conditions permit.

CAUTION: During a maintenance-requested ground run, the pilot monitoring should select the Standby Hydraulic quantity display if a discrepancy is observed. The Stall Warning status message that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated.

The Brake Temperature Monitor annunciation is expected to read within the sample range of 33 to 43 units during approach. The Weather Radar switch position is expected to read within the sample range of 41 to 50 units during a diversion. If the Brake Temperature Monitor is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Flight Management Computer is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The Ground Proximity Monitor quantity display that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated.
- During engine start, the relief pilot should announce the Auxiliary Power Unit status message if a discrepancy is observed.

Condition	Sample value	Remarks
Cockpit Voice Recorder advisory	76 units	Refer to related topic
Brake Temperature Monitor selector position	11 units	Monitor
Autobrake Selector status message	89 units	Advisory only

CAUTION: If the Probe Heat is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Flap Position Indication status message	38 units	Refer to related topic
Weather Radar annunciation	14 units	Refer to related topic
Primary Electrical Bus indication	99 units	Refer to related topic
Flight Management Computer status message	69 units	Advisory only
Pack Temperature Control quantity display	92 units	Monitor
Oxygen Distribution status message	48 units	Advisory only
Ground Proximity Monitor switch position	50 units	Normal

NOTE: The Hydraulic System B switch position that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval. If the Center Tank Pumps is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

CAUTION: During cruise, the Captain should announce the Fire Detection Loop annunciation unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

08.30.11 *New Sample Topic: Center Tank Pumps*

Refer to the related topic for additional sample context. The first officer will record any change in the Weather Radar quantity display and advise the other pilot when operating at a sample station without ground power. The Flight Management Computer annunciation is expected to read within the sample range of 46 to 52 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, the relief pilot should record the Autopilot Channel B selector position once the checklist item is complete. If the Brake Temperature Monitor is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will brief any change in the Window Heat advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. During approach, the pilot flying should monitor the Autobrake Selector indication if a discrepancy is observed.

The Transponder switch position that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval. During preflight, the relief pilot should record the Stall Warning annunciation once the checklist item is complete. During a maintenance-requested ground run, the pilot flying should verify the Autothrottle advisory when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. If the Probe Heat is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During climb, the Captain should confirm the Flap Position Indication switch position when conditions permit. The captain will verify any change in the Thrust Reverser selector position and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will confirm any change in the Probe Heat advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Engine Anti-Ice annunciation that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight.

Refer to the related topic for additional sample context. If the Pack Temperature Control is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Autothrottle quantity display that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. During a diversion, both pilots should confirm the Hydraulic System B quantity display unless directed otherwise by the Sample Operations Center.

- The pilot flying will announce any change in the Center Tank Pumps selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Autothrottle switch position that differs from the expected state requires the Captain to record the condition when the associated caution light remains illuminated.
- If the Autopilot Channel B is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

During landing, the Captain should announce the Fire Detection Loop switch position if a discrepancy is observed. The captain will record any change in the Window Heat quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Landing Gear Indication quantity display that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. The Weather Radar indication is expected to read within the sample range of 98 to 107 units during cruise. During taxi, the Captain should monitor

the Standby Hydraulic indication when the associated caution light remains illuminated. The captain will cross-check any change in the Flap Position Indication annunciation and advise the other pilot when the associated caution light remains illuminated.

08.30.12 *Bleed Air Supply Test*

The pilot monitoring will select any change in the Standby Hydraulic advisory and advise the other pilot when operating at a sample station without ground power. During parking, both pilots should announce the Auxiliary Power Unit status message when operating at a sample station without ground power. The Wing Anti-Ice annunciation is expected to read within the sample range of 80 to 87 units during descent. The Standby Hydraulic status message that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. The Autothrottle indication is expected to read within the sample range of 94 to 105 units during a diversion.

Condition	Sample value	Remarks
Ground Proximity Monitor selector position	17 units	Advisory only
Center Tank Pumps annunciation	45 units	Normal
Ground Proximity Monitor indication	10 units	Monitor
Ground Proximity Monitor advisory	10 units	Monitor

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

Both pilots will cross-check any change in the Traffic Advisory Display indication and advise the other pilot if a discrepancy is observed. The Thrust Reverser indication that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. The Standby Hydraulic quantity display is expected to read within the sample range of 3 to 11 units during a diversion. The Stall Warning advisory is expected to read within the sample range of 53 to 63 units during approach. The Engine Anti-Ice advisory is expected to read within the sample range of 92 to 101 units during cruise.

The first officer will brief any change in the Autothrottle indication and advise the other pilot once the checklist item is complete. The Engine Anti-Ice advisory is expected to read within the sample range of 84 to 90 units during approach. During cruise, the First Officer should cross-check the Pack Temperature Control status message once the checklist item is complete. During descent, both pilots should announce the Traffic Advisory Display annunciation when the associated caution light remains illuminated. The Wing Anti-Ice switch position that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power. The Flap Position Indication switch position is expected to read within the sample range of 42 to 51 units during a turnaround.

NOTE: During approach, the pilot flying should brief the Cargo Smoke Detection annunciation if a discrepancy is observed. The relief pilot will confirm any change in the Flight Management Computer quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

Values in this manual are invented and must not be used for any operational purpose. The Brake Temperature Monitor status message is expected to read within the sample range of 21 to 27 units during takeoff. If the Primary Electrical Bus is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Stall Warning quantity display	30 units	Monitor
Hydraulic System A indication	34 units	Monitor
Hydraulic System A indication	77 units	Normal
Hydraulic System A status message	28 units	Advisory only

Fire Detection Loop indication	55 units	Advisory only
Transponder selector position	38 units	Advisory only
Flap Position Indication switch position	46 units	Normal

If the Wing Anti-Ice is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Speedbrake Handle selector position is expected to read within the sample range of 56 to 61 units during taxi. If the Brake Temperature Monitor is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The pilot flying will confirm any change in the Weather Radar advisory and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

08.30.13 Wing Anti-Ice Status Messages

The captain will verify any change in the Autothrottle advisory and advise the other pilot when operating at a sample station without ground power. The Flap Position Indication indication that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. During preflight, the relief pilot should verify the Wing Anti-Ice advisory before the next phase of flight. The pilot flying will confirm any change in the Transponder selector position and advise the other pilot when operating at a sample station without ground power. The first officer will confirm any change in the Ground Proximity Monitor indication and advise the other pilot once the checklist item is complete.

During cruise, the pilot flying should record the Oxygen Distribution quantity display when the associated caution light remains illuminated. If the Traffic Advisory Display is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Standby Hydraulic selector position that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. The pilot flying will brief any change in the Fuel Crossfeed selector position and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

During cruise, the relief pilot should verify the Stall Warning selector position before the next phase of flight. The Hydraulic System B indication is expected to read within the sample range of 17 to 28 units during descent. The pilot flying will brief any change in the Flight Management Computer annunciation and advise the other pilot when operating at a sample station without ground power. The Standby Instruments advisory is expected to read within the sample range of 89 to 100 units during an extended ground delay.

This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will confirm any change in the Pack Temperature Control advisory and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. If the Pack Temperature Control is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Weather Radar quantity display	40 units	Normal
Fire Detection Loop status message	19 units	Monitor
Primary Electrical Bus annunciation	80 units	Monitor
Wing Anti-Ice advisory	10 units	Normal

Refer to the related topic for additional sample context. The Engine Anti-Ice switch position is expected to read within the sample range of 19 to 22 units during a turnaround. If the Wing Anti-Ice is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Autopilot Channel A selector position is expected to read within the sample range of 18 to 28 units during descent. During taxi, the pilot monitoring should select the Pack Temperature Control advisory when operating at a sample station without ground power.

The Fuel Crossfeed quantity display that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. If the Engine Anti-Ice is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. If the Ground Proximity Monitor is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

08.30.14 Transponder Test

If the Speedbrake Handle is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The relief pilot will select any change in the Primary Electrical Bus selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Landing Gear Indication selector position is expected to read within the sample range of 52 to 60 units during takeoff. During climb, the pilot monitoring should monitor the Landing Gear Indication annunciation when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will confirm any change in the Oxygen Distribution annunciation and advise the other pilot when operating at a sample station without ground power.

The Autothrottle switch position is expected to read within the sample range of 63 to 69 units during approach. If the Hydraulic System B is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot flying should record the Window Heat switch position when conditions permit. During descent, the First Officer should verify the Cockpit Voice Recorder status message before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

NOTE: During a maintenance-requested ground run, the pilot flying should select the Cargo Smoke Detection indication when conditions permit.

- Refer to the related topic for additional sample context.
- The pilot monitoring will record any change in the Engine Anti-Ice quantity display and advise the other pilot before the next phase of flight.
- If the Cargo Smoke Detection is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- During a diversion, the pilot flying should brief the Fire Detection Loop selector position when operating at a sample station without ground power.
- During climb, the Captain should monitor the Hydraulic System A indication before the next phase of flight.
- During approach, the relief pilot should brief the Landing Gear Indication switch position if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Values in this manual are invented and must not be used for any operational purpose.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Stall Warning annunciation that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed.
- If the Cockpit Voice Recorder is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

The Brake Temperature Monitor advisory is expected to read within the sample range of 47 to 56 units during a turnaround. During taxi, the Captain should select the Oxygen Distribution quantity display if a discrepancy is

observed. The pilot monitoring will record any change in the Window Heat advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will confirm any change in the Fuel Crossfeed annunciation and advise the other pilot if the indication does not stabilize within the sample interval. See 16.30.17 Standby Hydraulic Indications.

Condition	Sample value	Remarks
Nosewheel Steering switch position	94 units	Monitor
Wing Anti-Ice annunciation	27 units	Normal
Autopilot Channel B indication	7 units	Monitor
Auxiliary Power Unit switch position	90 units	Advisory only
Fuel Crossfeed status message	91 units	Refer to related topic

CAUTION: The Autothrottle advisory that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight. During a maintenance-requested ground run, the Captain should select the Speedbrake Handle quantity display when conditions permit.

08.30.15 Cockpit Voice Recorder Indications

If the Autobrake Selector is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The captain will confirm any change in the Window Heat selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: Refer to the related topic for additional sample context. During cruise, the pilot monitoring should announce the Wing Anti-Ice quantity display before the next phase of flight.

CAUTION: If the Speedbrake Handle is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

NOTE: During approach, the Captain should select the Engine Anti-Ice advisory before the next phase of flight.

- Refer to the related topic for additional sample context.
- The Standby Hydraulic status message that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed.
- The Autothrottle switch position that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete.
- The Wing Anti-Ice advisory is expected to read within the sample range of 17 to 25 units during a diversion.

NOTE: During an extended ground delay, the pilot monitoring should verify the Wing Anti-Ice quantity display when operating at a sample station without ground power. If the Speedbrake Handle is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

During a diversion, the relief pilot should confirm the Flap Position Indication quantity display when conditions permit. During climb, the relief pilot should monitor the Stall Warning annunciation if a discrepancy is observed. If the Hydraulic System B is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

08.30.16 Autopilot Channel A Overview

During takeoff, the Captain should announce the Standby Hydraulic indication once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Weather Radar status message that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power.

- If the Auxiliary Power Unit is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- During cruise, the pilot monitoring should confirm the Engine Anti-Ice switch position unless directed otherwise by the Sample Operations Center.
- The pilot monitoring will confirm any change in the Traffic Advisory Display status message and advise the other pilot when the associated caution light remains illuminated.
- The Bleed Air Supply status message is expected to read within the sample range of 57 to 67 units during cruise.

NOTE: The relief pilot will announce any change in the Cargo Smoke Detection advisory and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Autopilot Channel B annunciation	74 units	Advisory only
Transponder advisory	29 units	Monitor
Engine Anti-Ice switch position	96 units	Advisory only

NOTE: The captain will monitor any change in the Autothrottle indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: If the Fire Detection Loop is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

NOTE: The relief pilot will brief any change in the Stall Warning quantity display and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Cabin Pressure Controller indication	13 units	Monitor
Traffic Advisory Display quantity display	11 units	Advisory only
Brake Temperature Monitor quantity display	92 units	Normal

08.30.17 Engine Anti-Ice Reset Guidance

The pilot flying will monitor any change in the Autopilot Channel B annunciation and advise the other pilot when conditions permit. The Pack Temperature Control quantity display that differs from the expected state requires the Captain to select the condition when conditions permit. The Center Tank Pumps switch position that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval.

- If the Autothrottle is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- The Nosewheel Steering switch position that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated.
- If the Wing Anti-Ice is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- The first officer will monitor any change in the Standby Instruments switch position and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Primary Electrical Bus annunciation	78 units	Normal

Bleed Air Supply status message	58 units	Normal
Standby Hydraulic quantity display	84 units	Normal
Bleed Air Supply annunciation	80 units	Advisory only
Brake Temperature Monitor indication	37 units	Normal

The wording here is placeholder content shaped like a procedure, not a procedure. If the Pack Temperature Control is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. During descent, both pilots should record the Traffic Advisory Display selector position before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the pilot flying should cross-check the Weather Radar quantity display if the indication does not stabilize within the sample interval. If the Brake Temperature Monitor is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

CAUTION: The pilot flying will confirm any change in the Weather Radar indication and advise the other pilot before the next phase of flight.

CAUTION: The Cockpit Voice Recorder annunciation that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During engine start, the pilot flying should record the Hydraulic System B selector position when the associated caution light remains illuminated. During preflight, the relief pilot should select the Speedbrake Handle indication before the next phase of flight.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot monitoring will brief any change in the Fuel Crossfeed indication and advise the other pilot before the next phase of flight.
- The first officer will select any change in the Auxiliary Power Unit advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- The Cockpit Voice Recorder status message that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center.
- The Flight Management Computer advisory that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed.
- The Autopilot Channel A switch position that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete.

During cruise, the pilot flying should announce the Stall Warning status message before the next phase of flight. The Fuel Crossfeed annunciation is expected to read within the sample range of 81 to 88 units during a diversion. The Autopilot Channel B selector position that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The Primary Electrical Bus indication that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated.

Chapter 09 Systems: Hydraulics

09.10 Description

09.10.1 Standby Instruments Power Sources

Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle indication is expected to read within the sample range of 25 to 31 units during climb. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. Both pilots will confirm any change in the Pack Temperature Control quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Ground Proximity Monitor selector position	3 units	Monitor
Oxygen Distribution selector position	17 units	Refer to related topic
Stall Warning status message	43 units	Monitor
Flight Management Computer annunciation	11 units	Normal
Standby Hydraulic switch position	24 units	Normal

During a turnaround, the Captain should select the Cabin Pressure Controller switch position when the associated caution light remains illuminated. The Transponder switch position that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center. The Center Tank Pumps annunciation is expected to read within the sample range of 28 to 31 units during climb.

NOTE: During approach, the relief pilot should brief the Cargo Smoke Detection status message when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Speedbrake Handle annunciation	31 units	Monitor
Primary Electrical Bus indication	68 units	Refer to related topic
Bleed Air Supply status message	60 units	Refer to related topic

CAUTION: If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

09.10.2 Cabin Pressure Controller Interfaces

The Transponder switch position is expected to read within the sample range of 11 to 15 units during landing. If the Ground Proximity Monitor is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The first officer will brief any change in the Standby Instruments selector position and advise the other pilot when operating at a sample station without ground power.

The Fire Detection Loop selector position that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. During engine start, the First Officer should verify the Flap Position Indication quantity display unless directed otherwise by the Sample Operations Center. The Center Tank Pumps annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. The Autothrottle advisory that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete. The pilot monitoring will select any change in the Autopilot Channel B status message and advise the other pilot if a discrepancy is observed. During a diversion, the pilot flying should brief the Hydraulic System A selector position once the checklist item is complete.

The pilot monitoring will verify any change in the Cargo Smoke Detection switch position and advise the other pilot once the checklist item is complete. The pilot flying will verify any change in the Flight Management Computer advisory and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the relief pilot should confirm the Wing Anti-Ice indication when the associated caution light remains illuminated. During taxi, both pilots should cross-check the Transponder switch position when operating at a sample station without ground power. During a turnaround, the First Officer should verify the Hydraulic System A selector position once the checklist item is complete.

- The Bleed Air Supply status message is expected to read within the sample range of 95 to 103 units during landing.
- The captain will verify any change in the Oxygen Distribution quantity display and advise the other pilot when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The relief pilot will select any change in the Oxygen Distribution selector position and advise the other pilot when the associated caution light remains illuminated. The Brake Temperature Monitor selector position is expected to read within the sample range of 29 to 40 units during parking.

Condition	Sample value	Remarks
Hydraulic System B switch position	67 units	Advisory only
Autothrottle quantity display	26 units	Monitor
Pack Temperature Control selector position	93 units	Refer to related topic

09.10.3 *Nosewheel Steering Normal Operation*

The Bleed Air Supply selector position is expected to read within the sample range of 26 to 29 units during a diversion. Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection status message is expected to read within the sample range of 85 to 90 units during approach. During descent, the relief pilot should announce the Thrust Reverser annunciation unless directed otherwise by the Sample Operations Center.

- The Thrust Reverser annunciation that differs from the expected state requires the First Officer to select the condition when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Refer to the related topic for additional sample context.
- During climb, both pilots should verify the Standby Instruments switch position before the next phase of flight.
- If the Engine Anti-Ice is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autothrottle switch position	71 units	Refer to related topic
Stall Warning annunciation	9 units	Advisory only
Thrust Reverser annunciation	4 units	Advisory only

Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel B quantity display that differs from the expected state requires the pilot flying to announce the condition before the next

phase of flight. The Autothrottle indication is expected to read within the sample range of 65 to 77 units during climb. The Center Tank Pumps annunciation that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autopilot Channel B switch position	56 units	Normal
Cargo Smoke Detection status message	14 units	Normal
Fire Detection Loop indication	38 units	Monitor
Bleed Air Supply switch position	82 units	Advisory only
Standby Instruments annunciation	95 units	Refer to related topic

09.10.4 Transponder Status Messages

If the Cabin Pressure Controller is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The Brake Temperature Monitor status message is expected to read within the sample range of 42 to 49 units during takeoff. During cruise, the pilot monitoring should cross-check the Center Tank Pumps advisory before the next phase of flight. During climb, the pilot flying should cross-check the Stall Warning indication when the associated caution light remains illuminated. The Pack Temperature Control advisory is expected to read within the sample range of 74 to 81 units during landing.

CAUTION: The Thrust Reverser indication that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete.

- During a maintenance-requested ground run, the relief pilot should monitor the Autopilot Channel A annunciation if the indication does not stabilize within the sample interval.
- If the Fuel Crossfeed is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.
- The Fire Detection Loop switch position that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval.
- During engine start, the relief pilot should brief the Oxygen Distribution switch position if a discrepancy is observed.
- The Flight Management Computer switch position is expected to read within the sample range of 72 to 83 units during approach.

During takeoff, the pilot flying should verify the Oxygen Distribution annunciation when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, both pilots should verify the Standby Instruments advisory unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Landing Gear Indication switch position	41 units	Normal
Oxygen Distribution status message	97 units	Monitor
Thrust Reverser indication	23 units	Refer to related topic
Standby Instruments status message	74 units	Normal
Flight Management Computer quantity display	26 units	Monitor
Autopilot Channel B advisory	11 units	Monitor
Stall Warning selector position	75 units	Normal

- The pilot monitoring will record any change in the Fuel Crossfeed selector position and advise the other pilot when the associated caution light remains illuminated.
- During taxi, the Captain should monitor the Cargo Smoke Detection quantity display unless directed otherwise by the Sample Operations Center.
- The Window Heat selector position that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed.
- The Pack Temperature Control status message that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval.
- The Center Tank Pumps annunciation that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center.
- The Weather Radar advisory that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power.

The Bleed Air Supply status message is expected to read within the sample range of 44 to 48 units during taxi. The pilot flying will confirm any change in the Transponder advisory and advise the other pilot once the checklist item is complete. The relief pilot will confirm any change in the Landing Gear Indication switch position and advise the other pilot before the next phase of flight. The Bleed Air Supply annunciation that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power.

09.10.5 Primary Electrical Bus Normal Operation

Values in this manual are invented and must not be used for any operational purpose. During preflight, both pilots should verify the Hydraulic System B quantity display when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. If the Standby Instruments is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During approach, both pilots should cross-check the Speedbrake Handle advisory when the associated caution light remains illuminated.

CAUTION: The Ground Proximity Monitor quantity display that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval.

CAUTION: The pilot monitoring will monitor any change in the Flap Position Indication annunciation and advise the other pilot when conditions permit. The relief pilot will cross-check any change in the Primary Electrical Bus status message and advise the other pilot when operating at a sample station without ground power.

The Standby Hydraulic switch position that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will brief any change in the Hydraulic System A status message and advise the other pilot if a discrepancy is observed.

CAUTION: If the Autopilot Channel A is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Hydraulic System A indication is expected to read within the sample range of 29 to 39 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Bleed Air Supply switch position	92 units	Normal
Cabin Pressure Controller selector position	69 units	Normal
Hydraulic System A quantity display	63 units	Monitor
Auxiliary Power Unit status message	8 units	Monitor
Fuel Crossfeed status message	50 units	Normal

Traffic Advisory Display switch position	53 units	Normal
Cockpit Voice Recorder advisory	30 units	Refer to related topic

The Autothrottle annunciation is expected to read within the sample range of 15 to 27 units during parking. If the Standby Instruments is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Auxiliary Power Unit status message is expected to read within the sample range of 97 to 105 units during a diversion.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Oxygen Distribution is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Standby Hydraulic status message that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. The Bleed Air Supply indication is expected to read within the sample range of 48 to 60 units during an extended ground delay. During engine start, the First Officer should select the Nosewheel Steering selector position if the indication does not stabilize within the sample interval.

NOTE: The Ground Proximity Monitor selector position that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. The Bleed Air Supply annunciation is expected to read within the sample range of 56 to 64 units during approach. If the Speedbrake Handle is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

09.10.6 Flap Position Indication Overview

If the Bleed Air Supply is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The captain will announce any change in the Speedbrake Handle quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder advisory is expected to read within the sample range of 7 to 15 units during engine start.

- The Traffic Advisory Display selector position is expected to read within the sample range of 59 to 63 units during a turnaround.
- The Landing Gear Indication selector position that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed.
- During takeoff, the pilot flying should monitor the Oxygen Distribution selector position when operating at a sample station without ground power.
- The Window Heat status message that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete.
- The Engine Anti-Ice switch position that differs from the expected state requires the First Officer to verify the condition before the next phase of flight.
- During cruise, both pilots should record the Standby Instruments quantity display if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Weather Radar advisory that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center.
- The pilot monitoring will brief any change in the Center Tank Pumps quantity display and advise the other pilot when the associated caution light remains illuminated.
- If the Oxygen Distribution is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

- The captain will brief any change in the Hydraulic System B selector position and advise the other pilot when the associated caution light remains illuminated.
- The pilot monitoring will monitor any change in the Cabin Pressure Controller annunciation and advise the other pilot when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The captain will brief any change in the Stall Warning status message and advise the other pilot before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Both pilots will brief any change in the Bleed Air Supply switch position and advise the other pilot before the next phase of flight.
- The Speedbrake Handle quantity display that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center.
- During a diversion, the First Officer should verify the Oxygen Distribution switch position when operating at a sample station without ground power.
- The Transponder switch position that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight.
- The Nosewheel Steering quantity display that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power.

NOTE: The Traffic Advisory Display advisory that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. The pilot flying will cross-check any change in the Autobrake Selector quantity display and advise the other pilot once the checklist item is complete.

During landing, the Captain should select the Probe Heat quantity display when operating at a sample station without ground power. During taxi, the First Officer should confirm the Autobrake Selector switch position if a discrepancy is observed. The Bleed Air Supply selector position is expected to read within the sample range of 72 to 81 units during descent.

09.10.7 Cargo Smoke Detection Reset Guidance

If the Traffic Advisory Display is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Flap Position Indication indication is expected to read within the sample range of 93 to 100 units during landing. During a maintenance-requested ground run, the pilot monitoring should cross-check the Fire Detection Loop switch position unless directed otherwise by the Sample Operations Center. The relief pilot will select any change in the Wing Anti-Ice advisory and advise the other pilot when operating at a sample station without ground power.

- The Bleed Air Supply advisory is expected to read within the sample range of 17 to 21 units during preflight.
- The Landing Gear Indication switch position that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.
- The Thrust Reverser status message is expected to read within the sample range of 8 to 20 units during an extended ground delay.

The pilot monitoring will cross-check any change in the Hydraulic System B advisory and advise the other pilot if a discrepancy is observed. The Hydraulic System A switch position is expected to read within the sample range of 68 to 74 units during preflight. During climb, the pilot flying should monitor the Window Heat advisory unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus status message that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample

interval. The pilot monitoring will record any change in the Ground Proximity Monitor status message and advise the other pilot when conditions permit. The pilot flying will verify any change in the Standby Instruments selector position and advise the other pilot if the indication does not stabilize within the sample interval.

- The Weather Radar indication is expected to read within the sample range of 84 to 87 units during a maintenance-requested ground run.
- If the Primary Electrical Bus is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.
- If the Autothrottle is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.
- The Autopilot Channel B annunciation is expected to read within the sample range of 76 to 84 units during engine start.
- The Nosewheel Steering indication that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.
- If the Thrust Reverser is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- During an extended ground delay, both pilots should confirm the Standby Instruments switch position once the checklist item is complete.
- If the Bleed Air Supply is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.
- The Speedbrake Handle quantity display is expected to read within the sample range of 76 to 86 units during taxi.
- During climb, the pilot flying should verify the Transponder selector position unless directed otherwise by the Sample Operations Center.
- During a turnaround, the First Officer should verify the Speedbrake Handle indication if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.
- If the Autopilot Channel B is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Window Heat status message	27 units	Monitor
Cabin Pressure Controller switch position	63 units	Monitor
Autothrottle indication	26 units	Monitor
Stall Warning selector position	24 units	Advisory only
Wing Anti-Ice advisory	30 units	Refer to related topic
Transponder switch position	55 units	Monitor

09.10.8 Speedbrake Handle Interfaces

The Flap Position Indication quantity display that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. During preflight, the Captain should cross-check the Probe Heat status message if a discrepancy is observed. The Hydraulic System A advisory that differs from the expected state requires the Captain to record the condition if a discrepancy is observed. If the Hydraulic System A is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control annunciation that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated. The Cabin Pressure Controller

status message is expected to read within the sample range of 65 to 76 units during a maintenance-requested ground run.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the pilot flying should verify the Fire Detection Loop switch position if the indication does not stabilize within the sample interval.

CAUTION: If the Engine Anti-Ice is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Cockpit Voice Recorder annunciation that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight.

The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Hydraulic annunciation is expected to read within the sample range of 65 to 69 units during landing. If the Standby Instruments is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Weather Radar indication that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. See 05.50.2 Nosewheel Steering Overview.

- During takeoff, the relief pilot should brief the Engine Anti-Ice indication before the next phase of flight.
- The Auxiliary Power Unit indication is expected to read within the sample range of 79 to 89 units during taxi.
- Both pilots will announce any change in the Nosewheel Steering selector position and advise the other pilot when operating at a sample station without ground power.
- If the Bleed Air Supply is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- The Brake Temperature Monitor indication is expected to read within the sample range of 38 to 46 units during takeoff.

09.10.9 Primary Electrical Bus Limits Display

During an extended ground delay, the First Officer should cross-check the Auxiliary Power Unit annunciation unless directed otherwise by the Sample Operations Center. The Standby Hydraulic advisory is expected to read within the sample range of 23 to 30 units during a maintenance-requested ground run. If the Probe Heat is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

- Both pilots will brief any change in the Wing Anti-Ice status message and advise the other pilot if the indication does not stabilize within the sample interval.
- During engine start, both pilots should cross-check the Traffic Advisory Display quantity display unless directed otherwise by the Sample Operations Center.
- If the Bleed Air Supply is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- The Flap Position Indication advisory that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power.
- The Hydraulic System B quantity display is expected to read within the sample range of 73 to 77 units during an extended ground delay.

During engine start, the Captain should confirm the Wing Anti-Ice quantity display when the associated caution light remains illuminated. The Cabin Pressure Controller selector position is expected to read within the sample range of 47 to 59 units during parking. The Oxygen Distribution status message is expected to read within the sample range of 15 to 26 units during a maintenance-requested ground run.

NOTE: The pilot flying will verify any change in the Traffic Advisory Display switch position and advise the other pilot when operating at a sample station without ground power. During taxi, the pilot monitoring should cross-check the Engine Anti-Ice quantity display once the checklist item is complete.

The Hydraulic System B switch position is expected to read within the sample range of 39 to 45 units during descent. If the Standby Hydraulic is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. During a diversion, the relief pilot should record the Autopilot Channel A switch position unless directed otherwise by the Sample Operations Center. The Center Tank Pumps advisory is expected to read within the sample range of 7 to 16 units during a turnaround. The Fuel Crossfeed selector position that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. Refer to the related topic for additional sample context.

The pilot monitoring will announce any change in the Standby Hydraulic selector position and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, the pilot flying should announce the Bleed Air Supply switch position before the next phase of flight.

09.10.10 Brake Temperature Monitor Indications

If the Flap Position Indication is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Probe Heat indication and advise the other pilot when conditions permit. During engine start, the pilot monitoring should announce the Autopilot Channel B selector position unless directed otherwise by the Sample Operations Center.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Nosewheel Steering is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.
- If the Stall Warning is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.
- If the Probe Heat is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.
- If the Transponder is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.
- The Flight Management Computer advisory is expected to read within the sample range of 49 to 54 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Ground Proximity Monitor indication	75 units	Refer to related topic
Hydraulic System B advisory	27 units	Refer to related topic
Nosewheel Steering switch position	83 units	Monitor
Primary Electrical Bus advisory	82 units	Monitor
Auxiliary Power Unit switch position	44 units	Normal
Probe Heat advisory	17 units	Refer to related topic

NOTE: The Auxiliary Power Unit status message that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Hydraulic System B indication that differs from the expected state requires the pilot flying to record the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

09.10.11 Landing Gear Indication Overview

The wording here is placeholder content shaped like a procedure, not a procedure. The captain will confirm any change in the Thrust Reverser annunciation and advise the other pilot when the associated caution light remains

illuminated. The relief pilot will record any change in the Hydraulic System B advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Engine Anti-Ice annunciation that differs from the expected state requires both pilots to announce the condition before the next phase of flight.

The Autopilot Channel A indication that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight. If the Probe Heat is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During a maintenance-requested ground run, both pilots should announce the Ground Proximity Monitor status message if a discrepancy is observed.

Condition	Sample value	Remarks
Cargo Smoke Detection annunciation	44 units	Advisory only
Standby Hydraulic quantity display	16 units	Refer to related topic
Brake Temperature Monitor indication	16 units	Monitor
Engine Anti-Ice annunciation	40 units	Normal
Autopilot Channel A selector position	74 units	Normal
Ground Proximity Monitor quantity display	63 units	Monitor
Probe Heat status message	33 units	Advisory only

- The first officer will brief any change in the Weather Radar indication and advise the other pilot once the checklist item is complete.
- The captain will select any change in the Traffic Advisory Display quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Transponder is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. If the Weather Radar is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will confirm any change in the Autopilot Channel A selector position and advise the other pilot if a discrepancy is observed. The Window Heat switch position is expected to read within the sample range of 53 to 64 units during taxi.

CAUTION: If the Center Tank Pumps is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

- The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated.
- The Engine Anti-Ice selector position is expected to read within the sample range of 19 to 29 units during landing.
- The Hydraulic System A quantity display is expected to read within the sample range of 91 to 95 units during preflight.
- If the Standby Hydraulic is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The Window Heat selector position is expected to read within the sample range of 65 to 74 units during takeoff. The Standby Instruments annunciation is expected to read within the sample range of 4 to 14 units during climb. The Autothrottle indication is expected to read within the sample range of 22 to 33 units during preflight. The Brake Temperature Monitor annunciation is expected to read within the sample range of 14 to 26 units during engine start.

09.10.12 Thrust Reverser Test

The Landing Gear Indication switch position that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval. The Nosewheel Steering quantity display is expected to read within the sample range of 27 to 39 units during approach. During climb, the pilot monitoring should confirm the Hydraulic System B selector position when operating at a sample station without ground power. The Standby Instruments indication that differs from the expected state requires the relief pilot to select the condition when conditions permit.

- If the Thrust Reverser is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- During takeoff, both pilots should monitor the Flap Position Indication indication if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: Both pilots will cross-check any change in the Transponder selector position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Autopilot Channel B switch position	14 units	Advisory only
Bleed Air Supply indication	11 units	Monitor
Weather Radar switch position	91 units	Advisory only
Brake Temperature Monitor indication	54 units	Monitor
Cabin Pressure Controller annunciation	33 units	Refer to related topic
Fuel Crossfeed selector position	98 units	Monitor
Brake Temperature Monitor selector position	53 units	Monitor

NOTE: The Nosewheel Steering annunciation is expected to read within the sample range of 4 to 14 units during an extended ground delay.

Condition	Sample value	Remarks
Brake Temperature Monitor status message	63 units	Monitor
Autothrottle annunciation	57 units	Monitor
Cabin Pressure Controller selector position	83 units	Refer to related topic
Autobrake Selector annunciation	41 units	Advisory only
Wing Anti-Ice selector position	2 units	Advisory only
Primary Electrical Bus selector position	76 units	Normal
Autobrake Selector annunciation	95 units	Normal

- Refer to the related topic for additional sample context.
- The Autopilot Channel A indication is expected to read within the sample range of 82 to 85 units during descent.
- If the Pack Temperature Control is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.
- During climb, the Captain should brief the Landing Gear Indication quantity display when the associated caution light remains illuminated.

CAUTION: The pilot monitoring will announce any change in the Flight Management Computer annunciation and advise the other pilot if a discrepancy is observed. During a turnaround, the relief pilot should cross-check the Cabin Pressure Controller selector position once the checklist item is complete.

09.10.13 Stall Warning Power Sources

The Center Tank Pumps quantity display that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication selector position that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete.

Both pilots will monitor any change in the Landing Gear Indication selector position and advise the other pilot when the associated caution light remains illuminated. If the Nosewheel Steering is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. During a diversion, the Captain should cross-check the Autothrottle status message when conditions permit.

During climb, the First Officer should record the Fuel Crossfeed annunciation when conditions permit. The first officer will select any change in the Thrust Reverser status message and advise the other pilot unless directed otherwise by the Sample Operations Center. During parking, both pilots should verify the Autothrottle switch position once the checklist item is complete. The Window Heat quantity display is expected to read within the sample range of 83 to 92 units during descent. The captain will announce any change in the Autothrottle advisory and advise the other pilot before the next phase of flight. The captain will select any change in the Flap Position Indication status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the pilot flying should monitor the Ground Proximity Monitor quantity display when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Thrust Reverser quantity display is expected to read within the sample range of 94 to 102 units during a turnaround. The Cabin Pressure Controller switch position that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

- If the Landing Gear Indication is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- The Flight Management Computer quantity display that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete.
- The Window Heat advisory that differs from the expected state requires the Captain to announce the condition once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During engine start, the pilot monitoring should announce the Cabin Pressure Controller indication when the associated caution light remains illuminated.

During takeoff, the pilot flying should verify the Ground Proximity Monitor status message when the associated caution light remains illuminated. The Nosewheel Steering indication is expected to read within the sample range of 46 to 54 units during a diversion. If the Pack Temperature Control is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The Landing Gear Indication quantity display that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. If the Cargo Smoke Detection is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The pilot flying will select any change in the Landing Gear Indication switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will record any change in the Landing Gear Indication annunciation and advise the other pilot if a discrepancy is observed. The Cockpit Voice Recorder advisory that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. If the Autobrake Selector is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Speedbrake Handle advisory is expected to read within the sample range of 86 to 89 units during climb. If the Stall Warning is inoperative, continue an extended ground delay only after

the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Wing Anti-Ice is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

09.10.14 Cabin Pressure Controller Test

The Wing Anti-Ice advisory is expected to read within the sample range of 12 to 17 units during engine start. The first officer will record any change in the Autopilot Channel B switch position and advise the other pilot before the next phase of flight. If the Pack Temperature Control is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Brake Temperature Monitor indication is expected to read within the sample range of 70 to 82 units during a diversion. During taxi, the First Officer should record the Autothrottle annunciation once the checklist item is complete.

The pilot monitoring will record any change in the Flight Management Computer quantity display and advise the other pilot when conditions permit. The relief pilot will cross-check any change in the Stall Warning status message and advise the other pilot once the checklist item is complete. The Fuel Crossfeed status message is expected to read within the sample range of 36 to 41 units during descent.

The Window Heat quantity display that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. The captain will cross-check any change in the Weather Radar annunciation and advise the other pilot when conditions permit. The Standby Hydraulic selector position is expected to read within the sample range of 92 to 97 units during a diversion. Both pilots will select any change in the Ground Proximity Monitor switch position and advise the other pilot when operating at a sample station without ground power. Both pilots will cross-check any change in the Nosewheel Steering annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: If the Fire Detection Loop is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The first officer will verify any change in the Cabin Pressure Controller advisory and advise the other pilot once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Wing Anti-Ice is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Cargo Smoke Detection quantity display	41 units	Refer to related topic
Engine Anti-Ice annunciation	97 units	Normal
Traffic Advisory Display status message	95 units	Advisory only
Transponder indication	70 units	Advisory only

The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder status message is expected to read within the sample range of 80 to 85 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will cross-check any change in the Stall Warning indication and advise the other pilot before the next phase of flight. The Center Tank Pumps status message is expected to read within the sample range of 73 to 83 units during parking.

09.10.15 Traffic Advisory Display Normal Operation

The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Flap Position Indication status message is expected to read within the sample range of 78 to 81 units during parking.

Both pilots will monitor any change in the Standby Hydraulic selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The first officer will announce any change in the Probe Heat advisory and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will record any change in the Fuel Crossfeed indication and advise the other pilot when the associated caution light remains illuminated. The Pack Temperature Control status message that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed.

Values in this manual are invented and must not be used for any operational purpose. The first officer will monitor any change in the Standby Hydraulic selector position and advise the other pilot when the associated caution light remains illuminated. The first officer will cross-check any change in the Weather Radar selector position and advise the other pilot when operating at a sample station without ground power.

NOTE: During cruise, the relief pilot should monitor the Stall Warning status message when conditions permit.

The relief pilot will cross-check any change in the Autopilot Channel A advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autobrake Selector quantity display that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center. During landing, the Captain should monitor the Pack Temperature Control indication when operating at a sample station without ground power.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Autopilot Channel A is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.
- If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.
- The Cockpit Voice Recorder switch position is expected to read within the sample range of 24 to 31 units during preflight.
- The pilot monitoring will cross-check any change in the Autopilot Channel B quantity display and advise the other pilot when operating at a sample station without ground power.
- The first officer will verify any change in the Auxiliary Power Unit selector position and advise the other pilot once the checklist item is complete.

NOTE: During preflight, the relief pilot should record the Cargo Smoke Detection status message unless directed otherwise by the Sample Operations Center.

The Fuel Crossfeed annunciation is expected to read within the sample range of 24 to 27 units during engine start. The Cabin Pressure Controller status message that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. If the Nosewheel Steering is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The Probe Heat quantity display is expected to read within the sample range of 54 to 64 units during parking. The first officer will confirm any change in the Autopilot Channel B annunciation and advise the other pilot once the checklist item is complete. The Autothrottle annunciation that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center.

- The Oxygen Distribution status message is expected to read within the sample range of 49 to 56 units during taxi.
- If the Pack Temperature Control is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.
- If the Primary Electrical Bus is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

- If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- The Oxygen Distribution switch position that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated.
- During takeoff, the pilot monitoring should cross-check the Center Tank Pumps quantity display once the checklist item is complete.

09.10.16 Autothrottle Crew Awareness

If the Traffic Advisory Display is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Transponder indication that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed. The Brake Temperature Monitor status message is expected to read within the sample range of 54 to 65 units during a diversion. The Thrust Reverser status message that differs from the expected state requires the Captain to confirm the condition before the next phase of flight. The pilot monitoring will verify any change in the Nosewheel Steering quantity display and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

NOTE: Both pilots will announce any change in the Ground Proximity Monitor indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Standby Instruments annunciation that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated.

The Stall Warning switch position that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. The relief pilot will record any change in the Weather Radar advisory and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Stall Warning status message is expected to read within the sample range of 39 to 42 units during an extended ground delay.

- The Traffic Advisory Display status message is expected to read within the sample range of 4 to 14 units during preflight.
- Values in this manual are invented and must not be used for any operational purpose.
- The Standby Hydraulic status message that differs from the expected state requires the Captain to confirm the condition when conditions permit.
- The first officer will verify any change in the Fuel Crossfeed annunciation and advise the other pilot when conditions permit.

If the Brake Temperature Monitor is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Engine Anti-Ice selector position is expected to read within the sample range of 25 to 30 units during takeoff. During cruise, the First Officer should verify the Landing Gear Indication annunciation when the associated caution light remains illuminated. During engine start, the Captain should announce the Weather Radar advisory if the indication does not stabilize within the sample interval. The Flap Position Indication advisory is expected to read within the sample range of 54 to 66 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure.

During preflight, the Captain should select the Ground Proximity Monitor indication unless directed otherwise by the Sample Operations Center. The Flight Management Computer advisory that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. If the Oxygen Distribution is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

09.20 Controls and Indicators

09.20.1 Fire Detection Loop Normal Operation

During a diversion, the relief pilot should select the Autopilot Channel A indication when the associated caution light remains illuminated. The Bleed Air Supply annunciation is expected to read within the sample range of 56 to 59 units during takeoff. The Brake Temperature Monitor quantity display that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. If the Hydraulic System A is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During a diversion, the First Officer should select the Probe Heat annunciation when operating at a sample station without ground power. The Cargo Smoke Detection quantity display is expected to read within the sample range of 37 to 40 units during a turnaround.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The captain will brief any change in the Traffic Advisory Display quantity display and advise the other pilot before the next phase of flight. During landing, the pilot flying should confirm the Transponder annunciation when operating at a sample station without ground power. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

- The first officer will record any change in the Autothrottle selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Bleed Air Supply is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.
- The Cabin Pressure Controller switch position is expected to read within the sample range of 39 to 47 units during preflight.
- The pilot flying will confirm any change in the Wing Anti-Ice quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During descent, the pilot flying should cross-check the Traffic Advisory Display indication when conditions permit.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

The Engine Anti-Ice annunciation that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. During descent, both pilots should confirm the Nosewheel Steering status message when the associated caution light remains illuminated. If the Probe Heat is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Weather Radar status message and advise the other pilot once the checklist item is complete. The Traffic Advisory Display selector position that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated.

CAUTION: The Autothrottle switch position is expected to read within the sample range of 9 to 17 units during climb. The first officer will record any change in the Flap Position Indication annunciation and advise the other pilot when the associated caution light remains illuminated.

- Refer to the related topic for additional sample context.
- The Hydraulic System B indication is expected to read within the sample range of 37 to 42 units during descent.
- The first officer will brief any change in the Bleed Air Supply selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Hydraulic System A status message that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval.

09.20.2 Autopilot Channel A Indications

The Hydraulic System A quantity display that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated. Both pilots will record any change in the Fuel Crossfeed switch position and advise the other pilot if a discrepancy is observed. The pilot flying will monitor any change in the Transponder indication and advise the other pilot when operating at a sample station without ground power. If the Transponder is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Auxiliary Power Unit indication is expected to read within the sample range of 23 to 35 units during landing. The pilot flying will record any change in the Pack Temperature Control selector position and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Center Tank Pumps quantity display	33 units	Monitor
Cargo Smoke Detection selector position	75 units	Advisory only
Cargo Smoke Detection annunciation	63 units	Monitor
Autothrottle annunciation	39 units	Advisory only
Center Tank Pumps status message	59 units	Advisory only
Hydraulic System A status message	61 units	Monitor

CAUTION: The captain will confirm any change in the Probe Heat annunciation and advise the other pilot when the associated caution light remains illuminated.

If the Standby Hydraulic is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The captain will verify any change in the Auxiliary Power Unit indication and advise the other pilot if the indication does not stabilize within the sample interval. During descent, the Captain should monitor the Auxiliary Power Unit status message if a discrepancy is observed. The Ground Proximity Monitor indication is expected to read within the sample range of 36 to 42 units during engine start. During a diversion, the pilot flying should select the Cargo Smoke Detection indication when the associated caution light remains illuminated. See 14.20.13 Probe Heat Indications.

CAUTION: The pilot flying will monitor any change in the Autopilot Channel B advisory and advise the other pilot if a discrepancy is observed. Both pilots will brief any change in the Auxiliary Power Unit quantity display and advise the other pilot when the associated caution light remains illuminated.

09.20.3 Standby Instruments Normal Operation

Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. During cruise, the relief pilot should monitor the Probe Heat indication when conditions permit. The first officer will brief any change in the Hydraulic System A status message and advise the other pilot if a discrepancy is observed.

The pilot flying will announce any change in the Autobrake Selector switch position and advise the other pilot before the next phase of flight. During parking, the relief pilot should record the Fire Detection Loop annunciation when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Cockpit Voice Recorder switch position that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight. During taxi, both pilots should announce the Hydraulic System B switch position once the checklist item is complete.

Condition	Sample value	Remarks
Autopilot Channel A status message	38 units	Normal
Pack Temperature Control switch position	7 units	Refer to related topic
Standby Hydraulic advisory	35 units	Refer to related topic

Cabin Pressure Controller selector position	3 units	Advisory only
Cargo Smoke Detection indication	94 units	Refer to related topic

The Center Tank Pumps selector position is expected to read within the sample range of 22 to 27 units during preflight. During preflight, the First Officer should confirm the Pack Temperature Control advisory once the checklist item is complete. The pilot monitoring will brief any change in the Transponder quantity display and advise the other pilot when conditions permit. If the Autobrake Selector is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

During engine start, both pilots should confirm the Ground Proximity Monitor advisory when the associated caution light remains illuminated. If the Nosewheel Steering is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. During descent, the pilot monitoring should brief the Fire Detection Loop switch position if a discrepancy is observed.

09.20.4 Flap Position Indication Crew Awareness

If the Speedbrake Handle is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Cabin Pressure Controller status message	17 units	Normal
Transponder advisory	20 units	Monitor
Weather Radar annunciation	11 units	Normal
Autobrake Selector advisory	55 units	Monitor
Bleed Air Supply selector position	89 units	Advisory only
Cockpit Voice Recorder switch position	8 units	Normal

NOTE: During approach, the pilot flying should select the Window Heat annunciation unless directed otherwise by the Sample Operations Center. If the Brake Temperature Monitor is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

CAUTION: The Ground Proximity Monitor status message that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated. The Brake Temperature Monitor switch position that differs from the expected state requires the Captain to announce the condition before the next phase of flight.

The Speedbrake Handle selector position that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. During a maintenance-requested ground run, both pilots should cross-check the Cockpit Voice Recorder status message when conditions permit.

09.20.5 Center Tank Pumps Test

Refer to the related topic for additional sample context. During preflight, the relief pilot should announce the Primary Electrical Bus selector position when conditions permit. The Cargo Smoke Detection status message that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. If the Cabin Pressure Controller is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

During climb, the relief pilot should brief the Autothrottle advisory if a discrepancy is observed. The Fuel Crossfeed annunciation is expected to read within the sample range of 41 to 50 units during engine start. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The Primary Electrical Bus advisory is expected to read within the sample range of 5 to 8 units during a maintenance-requested ground run. During takeoff, the pilot flying should select the Transponder switch position if the indication does not stabilize within the sample interval.

- CAUTION:** Values in this manual are invented and must not be used for any operational purpose.
- NOTE:** The pilot monitoring will confirm any change in the Cockpit Voice Recorder selector position and advise the other pilot if a discrepancy is observed.
- CAUTION:** If the Autobrake Selector is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- NOTE:** The Window Heat annunciation is expected to read within the sample range of 64 to 67 units during engine start.
- CAUTION:** The captain will select any change in the Stall Warning advisory and advise the other pilot when conditions permit.

The Bleed Air Supply advisory that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. During taxi, both pilots should confirm the Bleed Air Supply selector position when conditions permit. The Autothrottle selector position that differs from the expected state requires the First Officer to record the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication status message is expected to read within the sample range of 66 to 71 units during parking.

09.20.6 Engine Anti-Ice Status Messages

The Speedbrake Handle selector position is expected to read within the sample range of 95 to 98 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Cargo Smoke Detection advisory is expected to read within the sample range of 69 to 76 units during preflight. The pilot monitoring will record any change in the Bleed Air Supply annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

- NOTE:** The captain will announce any change in the Hydraulic System A quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

The pilot monitoring will monitor any change in the Flap Position Indication advisory and advise the other pilot before the next phase of flight. During a diversion, the Captain should select the Landing Gear Indication switch position if the indication does not stabilize within the sample interval. During an extended ground delay, the pilot flying should cross-check the Brake Temperature Monitor selector position before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will verify any change in the Ground Proximity Monitor annunciation and advise the other pilot when conditions permit. The captain will confirm any change in the Autothrottle quantity display and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Probe Heat selector position	13 units	Monitor
Nosewheel Steering advisory	40 units	Normal
Traffic Advisory Display advisory	98 units	Monitor
Nosewheel Steering quantity display	83 units	Monitor
Ground Proximity Monitor switch position	51 units	Advisory only
Transponder indication	36 units	Refer to related topic

During engine start, the pilot monitoring should monitor the Standby Hydraulic switch position when operating at a sample station without ground power. During a turnaround, the pilot monitoring should announce the Weather Radar annunciation once the checklist item is complete. If the Engine Anti-Ice is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

- If the Hydraulic System A is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.
- The Traffic Advisory Display switch position that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed.
- The Thrust Reverser advisory that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval.
- The Engine Anti-Ice switch position that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated.
- Both pilots will verify any change in the Cockpit Voice Recorder quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- During an extended ground delay, the First Officer should brief the Traffic Advisory Display quantity display when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Stall Warning status message	47 units	Advisory only
Ground Proximity Monitor annunciation	67 units	Refer to related topic
Hydraulic System A annunciation	27 units	Normal

Refer to the related topic for additional sample context. During climb, the pilot flying should confirm the Bleed Air Supply quantity display when the associated caution light remains illuminated. If the Autothrottle is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will record any change in the Probe Heat advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

This text is fictional and exists only to give the prototype realistic volume and structure. During parking, the Captain should select the Pack Temperature Control status message unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus switch position is expected to read within the sample range of 22 to 26 units during landing. The Hydraulic System A advisory is expected to read within the sample range of 85 to 94 units during engine start. The Autothrottle switch position that differs from the expected state requires the First Officer to announce the condition when conditions permit. The captain will cross-check any change in the Wing Anti-Ice indication and advise the other pilot when the associated caution light remains illuminated.

09.20.7 *Flight Management Computer Interfaces*

The Standby Instruments advisory that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Flight Management Computer advisory that differs from the expected state requires the relief pilot to monitor the condition before the next phase of flight.

CAUTION: The captain will cross-check any change in the Wing Anti-Ice status message and advise the other pilot once the checklist item is complete. During climb, both pilots should confirm the Flight Management Computer advisory before the next phase of flight.

NOTE: The captain will announce any change in the Weather Radar indication and advise the other pilot when operating at a sample station without ground power.

During engine start, both pilots should select the Primary Electrical Bus quantity display if the indication does not stabilize within the sample interval. If the Stall Warning is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The first officer will select any change in the Fire Detection Loop switch position and advise the other pilot when conditions permit.

The Standby Instruments quantity display is expected to read within the sample range of 31 to 41 units during preflight. During climb, the relief pilot should record the Engine Anti-Ice indication when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will confirm any change in the Flap Position Indication status message and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: Refer to the related topic for additional sample context.

NOTE: If the Fuel Crossfeed is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

09.20.8 Bleed Air Supply Normal Operation

The Bleed Air Supply selector position is expected to read within the sample range of 58 to 62 units during descent. The Thrust Reverser annunciation is expected to read within the sample range of 56 to 64 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. If the Autothrottle is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The Wing Anti-Ice selector position that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed.

The relief pilot will brief any change in the Window Heat indication and advise the other pilot if a discrepancy is observed. During a turnaround, the pilot flying should cross-check the Weather Radar quantity display when conditions permit. The first officer will confirm any change in the Cockpit Voice Recorder selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will confirm any change in the Hydraulic System B switch position and advise the other pilot when operating at a sample station without ground power. The Fuel Crossfeed switch position that differs from the expected state requires the First Officer to select the condition before the next phase of flight. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Traffic Advisory Display selector position	7 units	Monitor
Speedbrake Handle advisory	54 units	Advisory only
Thrust Reverser indication	64 units	Advisory only
Cargo Smoke Detection annunciation	45 units	Advisory only
Nosewheel Steering annunciation	24 units	Normal
Cockpit Voice Recorder switch position	45 units	Refer to related topic
Autopilot Channel A advisory	92 units	Refer to related topic

The wording here is placeholder content shaped like a procedure, not a procedure. During a maintenance-requested ground run, the relief pilot should verify the Traffic Advisory Display annunciation once the checklist item is complete. The Probe Heat status message that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated.

The Window Heat status message is expected to read within the sample range of 86 to 93 units during approach. During engine start, the pilot flying should brief the Autopilot Channel B selector position when the associated caution light remains illuminated. The Autopilot Channel A annunciation is expected to read within the sample range of 52 to 61 units during landing.

The captain will select any change in the Cockpit Voice Recorder status message and advise the other pilot if the indication does not stabilize within the sample interval. The Cargo Smoke Detection annunciation is expected to read

within the sample range of 62 to 71 units during engine start. The pilot monitoring will select any change in the Flap Position Indication indication and advise the other pilot if a discrepancy is observed. The Engine Anti-Ice selector position that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. See 01.30.5 Abbreviation Group 5.

- During cruise, the pilot flying should brief the Hydraulic System B annunciation when conditions permit.
- The Standby Instruments annunciation is expected to read within the sample range of 73 to 82 units during cruise.
- The Auxiliary Power Unit advisory that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete.
- If the Probe Heat is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- The Autopilot Channel B status message that differs from the expected state requires both pilots to verify the condition before the next phase of flight.
- The Flap Position Indication selector position that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Fuel Crossfeed quantity display	75 units	Monitor
Standby Hydraulic advisory	1 units	Normal
Autothrottle indication	76 units	Refer to related topic
Center Tank Pumps quantity display	22 units	Refer to related topic
Flight Management Computer advisory	73 units	Refer to related topic
Cockpit Voice Recorder selector position	2 units	Monitor
Nosewheel Steering switch position	34 units	Normal

Condition	Sample value	Remarks
Probe Heat switch position	50 units	Monitor
Fuel Crossfeed status message	34 units	Advisory only
Window Heat selector position	69 units	Monitor
Landing Gear Indication indication	15 units	Refer to related topic
Wing Anti-Ice annunciation	22 units	Monitor

09.20.9 Wing Anti-Ice Normal Operation

The Traffic Advisory Display selector position that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete. The Nosewheel Steering annunciation that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated. During landing, the pilot monitoring should select the Autopilot Channel A indication unless directed otherwise by the Sample Operations Center. The pilot flying will record any change in the Speedbrake Handle switch position and advise the other pilot when the associated caution light remains illuminated.

- Values in this manual are invented and must not be used for any operational purpose.
- Both pilots will cross-check any change in the Fuel Crossfeed indication and advise the other pilot when operating at a sample station without ground power.
- The first officer will monitor any change in the Engine Anti-Ice status message and advise the other pilot when operating at a sample station without ground power.

- The pilot flying will select any change in the Nosewheel Steering selector position and advise the other pilot if a discrepancy is observed.
- The Ground Proximity Monitor annunciation that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed.
- The Probe Heat switch position that differs from the expected state requires the Captain to verify the condition once the checklist item is complete.

If the Oxygen Distribution is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Window Heat switch position that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Center Tank Pumps status message that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. The Hydraulic System A advisory is expected to read within the sample range of 63 to 72 units during a diversion.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Fire Detection Loop annunciation that differs from the expected state requires both pilots to verify the condition before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Brake Temperature Monitor advisory that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center.
- Both pilots will verify any change in the Traffic Advisory Display indication and advise the other pilot when conditions permit.
- The captain will brief any change in the Cargo Smoke Detection quantity display and advise the other pilot when the associated caution light remains illuminated.
- The Pack Temperature Control quantity display that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.

NOTE: Refer to the related topic for additional sample context.

During an extended ground delay, the relief pilot should monitor the Engine Anti-Ice status message when the associated caution light remains illuminated. During takeoff, the First Officer should select the Landing Gear Indication switch position if a discrepancy is observed. The Bleed Air Supply quantity display is expected to read within the sample range of 77 to 80 units during a turnaround. If the Bleed Air Supply is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. See 05.70.3 Stall Warning Interfaces.

NOTE: The Brake Temperature Monitor switch position that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. If the Autobrake Selector is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

09.20.10 Cargo Smoke Detection Crew Awareness

This text is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop advisory that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The Center Tank Pumps status message is expected to read within the sample range of 17 to 23 units during landing. The pilot monitoring will cross-check any change in the Fuel Crossfeed selector position and advise

the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Auxiliary Power Unit indication	73 units	Normal
Oxygen Distribution annunciation	81 units	Normal
Landing Gear Indication annunciation	71 units	Advisory only
Auxiliary Power Unit selector position	91 units	Advisory only
Autothrottle selector position	93 units	Normal
Autobrake Selector indication	29 units	Normal

The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the pilot monitoring should announce the Hydraulic System B indication when operating at a sample station without ground power. The Autothrottle status message that differs from the expected state requires the First Officer to monitor the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Traffic Advisory Display switch position that differs from the expected state requires the Captain to select the condition before the next phase of flight.

The Weather Radar indication is expected to read within the sample range of 96 to 107 units during an extended ground delay. The captain will cross-check any change in the Fuel Crossfeed advisory and advise the other pilot once the checklist item is complete. If the Cargo Smoke Detection is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. During climb, the Captain should brief the Weather Radar advisory when the associated caution light remains illuminated.

The Autothrottle quantity display that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed. If the Landing Gear Indication is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Flap Position Indication switch position is expected to read within the sample range of 94 to 99 units during taxi. The Ground Proximity Monitor switch position is expected to read within the sample range of 87 to 95 units during cruise. The pilot monitoring will announce any change in the Thrust Reverser annunciation and advise the other pilot when conditions permit. The Nosewheel Steering indication is expected to read within the sample range of 18 to 22 units during climb. See 05.50.13 Standby Instruments Normal Operation.

09.20.11 Speedbrake Handle Status Messages

The Wing Anti-Ice selector position that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete. During taxi, the pilot flying should confirm the Probe Heat indication if the indication does not stabilize within the sample interval. The Standby Hydraulic advisory is expected to read within the sample range of 11 to 14 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: Both pilots will brief any change in the Pack Temperature Control annunciation and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context.

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will record any change in the Fuel Crossfeed selector position and advise the other pilot when the associated caution light remains illuminated. During approach, the First Officer should monitor the Weather Radar status message once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, both pilots should brief the Pack Temperature Control quantity display when conditions permit. The Stall Warning indication is expected to read within the sample range of 84 to 90 units during a maintenance-requested ground run. The Fire Detection Loop status message is expected to read within the sample range of 56 to 59 units during takeoff.

CAUTION: The Fuel Crossfeed advisory is expected to read within the sample range of 3 to 8 units during engine start.

The Standby Instruments selector position is expected to read within the sample range of 77 to 84 units during engine start. The Autopilot Channel A quantity display that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, the pilot flying should confirm the Cargo Smoke Detection advisory when operating at a sample station without ground power.

09.20.12 Traffic Advisory Display Overview

The Weather Radar advisory is expected to read within the sample range of 73 to 79 units during takeoff. If the Transponder is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The Auxiliary Power Unit indication is expected to read within the sample range of 16 to 26 units during taxi. The Autothrottle status message is expected to read within the sample range of 79 to 85 units during engine start. The pilot monitoring will monitor any change in the Bleed Air Supply quantity display and advise the other pilot once the checklist item is complete.

The relief pilot will confirm any change in the Autothrottle indication and advise the other pilot once the checklist item is complete. If the Oxygen Distribution is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Window Heat annunciation that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Cargo Smoke Detection status message	8 units	Refer to related topic
Flap Position Indication selector position	78 units	Normal
Pack Temperature Control indication	53 units	Advisory only

During climb, the relief pilot should select the Engine Anti-Ice status message when operating at a sample station without ground power. The Standby Instruments switch position that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. If the Cabin Pressure Controller is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. Both pilots will cross-check any change in the Thrust Reverser annunciation and advise the other pilot before the next phase of flight.

During a maintenance-requested ground run, both pilots should confirm the Hydraulic System A selector position if the indication does not stabilize within the sample interval. The Standby Hydraulic indication that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. The Cabin Pressure Controller status message that differs from the expected state requires the Captain to record the condition when conditions permit. The first officer will select any change in the Probe Heat selector position and advise the other pilot when conditions permit.

CAUTION: The Cargo Smoke Detection annunciation is expected to read within the sample range of 76 to 83 units during climb. Both pilots will monitor any change in the Oxygen Distribution status message and advise the other pilot when operating at a sample station without ground power.

09.20.13 Autopilot Channel A Normal Operation

Both pilots will select any change in the Hydraulic System B selector position and advise the other pilot before the next phase of flight. The Autopilot Channel B quantity display that differs from the expected state requires the Captain to record the condition when conditions permit. The Center Tank Pumps quantity display that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. The Hydraulic System A indication that differs from the expected state requires both pilots to record the condition before the next phase of flight.

Condition	Sample value	Remarks
Cabin Pressure Controller advisory	74 units	Advisory only
Cabin Pressure Controller switch position	81 units	Refer to related topic
Autopilot Channel B indication	76 units	Monitor
Cockpit Voice Recorder advisory	79 units	Refer to related topic
Pack Temperature Control quantity display	41 units	Monitor
Landing Gear Indication selector position	41 units	Normal

- The Engine Anti-Ice switch position that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center.
- The Primary Electrical Bus advisory is expected to read within the sample range of 8 to 12 units during a diversion.
- Both pilots will select any change in the Autopilot Channel A indication and advise the other pilot when operating at a sample station without ground power.

If the Stall Warning is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During an extended ground delay, the Captain should confirm the Bleed Air Supply status message unless directed otherwise by the Sample Operations Center. The Center Tank Pumps advisory that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center. During a diversion, the relief pilot should verify the Speedbrake Handle indication when conditions permit. The pilot monitoring will select any change in the Autopilot Channel B indication and advise the other pilot before the next phase of flight.

The Wing Anti-Ice indication that differs from the expected state requires the pilot flying to brief the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, the First Officer should monitor the Ground Proximity Monitor indication before the next phase of flight. The Oxygen Distribution selector position that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps status message is expected to read within the sample range of 67 to 79 units during descent. The captain will announce any change in the Probe Heat quantity display and advise the other pilot when the associated caution light remains illuminated. See 07.20.3 Thrust Reverser Crew Awareness.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot monitoring will select any change in the Traffic Advisory Display indication and advise the other pilot if a discrepancy is observed.
- The first officer will brief any change in the Cockpit Voice Recorder selector position and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The first officer will cross-check any change in the Center Tank Pumps switch position and advise the other pilot if the indication does not stabilize within the sample interval.

09.20.14 Window Heat Normal Operation

If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will select any change in the Auxiliary Power Unit quantity display and advise the other pilot if a discrepancy is observed. The Ground Proximity Monitor annunciation is expected to read within the sample range of 49 to 61 units during an extended ground delay. The Cockpit Voice Recorder switch position that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete.

The Autopilot Channel A selector position is expected to read within the sample range of 25 to 33 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. If the Hydraulic System B is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

- The pilot monitoring will cross-check any change in the Autopilot Channel A indication and advise the other pilot when the associated caution light remains illuminated.
- The Fire Detection Loop annunciation is expected to read within the sample range of 76 to 85 units during takeoff.
- The Primary Electrical Bus selector position that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Standby Instruments is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.
- The Fire Detection Loop annunciation that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete.
- The Thrust Reverser status message that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed.
- The Brake Temperature Monitor switch position that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete.

Condition	Sample value	Remarks
Autobrake Selector switch position	82 units	Refer to related topic
Landing Gear Indication switch position	70 units	Normal
Center Tank Pumps status message	77 units	Advisory only
Weather Radar quantity display	94 units	Normal
Standby Instruments status message	17 units	Advisory only
Flap Position Indication status message	17 units	Normal
Stall Warning quantity display	11 units	Refer to related topic

09.20.15 Cockpit Voice Recorder Limits Display

The Wing Anti-Ice advisory is expected to read within the sample range of 34 to 38 units during a maintenance-requested ground run. During taxi, the pilot monitoring should brief the Brake Temperature Monitor quantity display once the checklist item is complete. The Cabin Pressure Controller status message that differs from the expected state requires the Captain to announce the condition when conditions permit.

If the Cockpit Voice Recorder is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Probe Heat indication is expected to read within the sample range of 81 to 87 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

If the Oxygen Distribution is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Fire Detection Loop is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. During preflight, the relief pilot should record the Auxiliary Power Unit quantity display once the checklist item is complete.

Both pilots will record any change in the Primary Electrical Bus annunciation and advise the other pilot when conditions permit. The Cockpit Voice Recorder quantity display that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center. The relief pilot will record any change in the Stall Warning annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Wing Anti-Ice switch position is expected to read within the sample range of 42 to 50 units during engine start. Both pilots will select any change in the Standby Instruments advisory and advise the other pilot if the indication does not stabilize within the sample interval.

09.20.16 Oxygen Distribution Power Sources

Both pilots will cross-check any change in the Landing Gear Indication switch position and advise the other pilot when operating at a sample station without ground power. The Thrust Reverser selector position is expected to read within the sample range of 41 to 50 units during cruise. The Flap Position Indication status message is expected to read within the sample range of 63 to 75 units during preflight.

- The Autothrottle indication that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center.
- The pilot monitoring will cross-check any change in the Nosewheel Steering annunciation and advise the other pilot when conditions permit.
- The Traffic Advisory Display selector position is expected to read within the sample range of 85 to 97 units during an extended ground delay.
- During engine start, the First Officer should brief the Autobrake Selector quantity display if a discrepancy is observed.

NOTE: During descent, the First Officer should confirm the Transponder annunciation before the next phase of flight. If the Pack Temperature Control is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The Standby Instruments quantity display is expected to read within the sample range of 15 to 20 units during parking. During engine start, the First Officer should cross-check the Flap Position Indication switch position if a discrepancy is observed.

NOTE: The Probe Heat selector position is expected to read within the sample range of 64 to 75 units during engine start.

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will verify any change in the Traffic Advisory Display quantity display and advise the other pilot if a discrepancy is observed.

If the Flight Management Computer is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Transponder annunciation that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will cross-check any change in the Fire Detection Loop advisory and advise the other pilot when operating at a sample station without ground power.

The captain will announce any change in the Fire Detection Loop selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Landing Gear Indication advisory that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel A quantity display that differs from the expected state requires the relief pilot to brief

the condition before the next phase of flight.

- During descent, both pilots should cross-check the Speedbrake Handle selector position when the associated caution light remains illuminated.
- The Ground Proximity Monitor indication is expected to read within the sample range of 54 to 66 units during parking.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Bleed Air Supply switch position that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit.
- If the Stall Warning is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

09.30 Operation

09.30.1 Weather Radar Overview

The Thrust Reverser advisory that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete. If the Stall Warning is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

The relief pilot will verify any change in the Ground Proximity Monitor indication and advise the other pilot once the checklist item is complete. If the Brake Temperature Monitor is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The first officer will select any change in the Pack Temperature Control switch position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Bleed Air Supply quantity display	68 units	Refer to related topic
Engine Anti-Ice annunciation	77 units	Monitor
Standby Instruments advisory	16 units	Refer to related topic
Hydraulic System A advisory	16 units	Advisory only
Ground Proximity Monitor status message	29 units	Monitor
Primary Electrical Bus indication	81 units	Monitor
Ground Proximity Monitor status message	22 units	Refer to related topic

If the Center Tank Pumps is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Flap Position Indication is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

If the Autopilot Channel A is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Engine Anti-Ice advisory that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center. The Transponder selector position that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. If the Autothrottle is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

09.30.2 Flight Management Computer Overview

The Cockpit Voice Recorder annunciation that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. The Pack Temperature Control annunciation that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated. The Autobrake Selector selector position that differs from the expected state requires both pilots to verify the condition when conditions permit. Both pilots will record any change in the Transponder annunciation and advise the other pilot before the next phase of flight.

The Landing Gear Indication selector position that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. During a diversion, the pilot flying should monitor the Autopilot Channel B indication when conditions permit. The Probe Heat indication that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. The Engine Anti-Ice annunciation is expected to read within the sample range of 45 to 56 units during descent. During landing, the pilot monitoring should verify the Ground Proximity Monitor status message once the checklist item is complete.

Refer to the related topic for additional sample context. The Hydraulic System A indication is expected to read within the sample range of 10 to 15 units during takeoff. The Oxygen Distribution selector position is expected to read within the sample range of 31 to 39 units during approach. If the Traffic Advisory Display is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Hydraulic System B status message	50 units	Monitor
Hydraulic System A quantity display	98 units	Normal
Window Heat advisory	52 units	Advisory only
Engine Anti-Ice switch position	89 units	Normal
Fire Detection Loop indication	5 units	Refer to related topic

Condition	Sample value	Remarks
Cargo Smoke Detection status message	23 units	Refer to related topic
Autothrottle switch position	84 units	Refer to related topic
Fuel Crossfeed status message	61 units	Advisory only
Weather Radar selector position	22 units	Monitor

09.30.3 Brake Temperature Monitor Normal Operation

Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor switch position that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. During cruise, the pilot monitoring should monitor the Speedbrake Handle quantity display unless directed otherwise by the Sample Operations Center. During a turnaround, the pilot monitoring should cross-check the Traffic Advisory Display status message when conditions permit.

The Transponder selector position that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated. During descent, the relief pilot should verify the Weather Radar status message when the associated caution light remains illuminated. The Auxiliary Power Unit switch position is expected to read within the sample range of 8 to 12 units during a turnaround. The first officer will cross-check any change in the Primary Electrical Bus status message and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The first officer will monitor any change in the Pack Temperature Control indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will brief any change in the Fire Detection Loop advisory and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: The first officer will record any change in the Stall Warning selector position and advise the other pilot if a discrepancy is observed. The Nosewheel Steering advisory that differs from the expected state requires the

relief pilot to confirm the condition before the next phase of flight.

Condition	Sample value	Remarks
Standby Instruments quantity display	43 units	Refer to related topic
Autopilot Channel B indication	54 units	Normal
Standby Instruments switch position	65 units	Normal
Fire Detection Loop annunciation	95 units	Advisory only

- The Auxiliary Power Unit advisory that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Wing Anti-Ice is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.
- If the Cargo Smoke Detection is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- The Autopilot Channel A quantity display is expected to read within the sample range of 39 to 45 units during a diversion.
- During preflight, the Captain should select the Window Heat indication if the indication does not stabilize within the sample interval.
- The Flight Management Computer advisory is expected to read within the sample range of 86 to 90 units during parking.
- If the Autopilot Channel B is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The Primary Electrical Bus quantity display that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed. The Hydraulic System B advisory that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval.

09.30.4 Auxiliary Power Unit Test

The pilot monitoring will verify any change in the Auxiliary Power Unit annunciation and advise the other pilot when conditions permit. The Oxygen Distribution selector position is expected to read within the sample range of 51 to 54 units during a maintenance-requested ground run. If the Ground Proximity Monitor is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Hydraulic System A indication	71 units	Refer to related topic
Transponder annunciation	37 units	Refer to related topic
Fuel Crossfeed quantity display	18 units	Refer to related topic
Primary Electrical Bus annunciation	70 units	Normal

CAUTION: During descent, the pilot flying should confirm the Ground Proximity Monitor selector position when conditions permit.

The Primary Electrical Bus advisory that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed. The Landing Gear Indication annunciation is expected to read within the sample range of 4 to 13 units during preflight. If the Cargo Smoke Detection is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Fire Detection Loop advisory is expected to read within the sample range of 36 to 45 units during takeoff. The Flap Position Indication advisory that differs from the expected state requires the Captain to brief the condition once the checklist item is complete.

The Wing Anti-Ice indication is expected to read within the sample range of 91 to 99 units during a diversion. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

During approach, the pilot flying should announce the Landing Gear Indication quantity display when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will monitor any change in the Probe Heat annunciation and advise the other pilot before the next phase of flight. During a turnaround, the First Officer should select the Window Heat status message once the checklist item is complete. If the Autobrake Selector is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The captain will select any change in the Window Heat selector position and advise the other pilot when operating at a sample station without ground power.

The Flight Management Computer status message is expected to read within the sample range of 81 to 92 units during preflight. The Traffic Advisory Display quantity display is expected to read within the sample range of 78 to 83 units during an extended ground delay. The Hydraulic System B switch position is expected to read within the sample range of 9 to 21 units during descent. If the Primary Electrical Bus is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. During cruise, both pilots should monitor the Auxiliary Power Unit switch position once the checklist item is complete. If the Standby Instruments is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

09.30.5 Bleed Air Supply Status Messages

The Autobrake Selector indication is expected to read within the sample range of 14 to 24 units during cruise. The Autobrake Selector annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed. The pilot flying will verify any change in the Oxygen Distribution annunciation and advise the other pilot when operating at a sample station without ground power.

- Refer to the related topic for additional sample context.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- The first officer will cross-check any change in the Thrust Reverser selector position and advise the other pilot if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During taxi, the Captain should record the Traffic Advisory Display quantity display unless directed otherwise by the Sample Operations Center.

The first officer will monitor any change in the Standby Instruments annunciation and advise the other pilot if a discrepancy is observed. The captain will record any change in the Primary Electrical Bus selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will monitor any change in the Cargo Smoke Detection switch position and advise the other pilot when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. If the Window Heat is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During cruise, the relief pilot should verify the Nosewheel Steering advisory if a discrepancy is observed.

The Bleed Air Supply selector position that differs from the expected state requires the Captain to record the condition before the next phase of flight. During climb, the Captain should confirm the Window Heat status message once the checklist item is complete. The pilot flying will monitor any change in the Primary Electrical Bus switch position and advise the other pilot when conditions permit.

During an extended ground delay, the pilot flying should announce the Center Tank Pumps quantity display unless directed otherwise by the Sample Operations Center. The pilot flying will select any change in the Pack Temperature Control indication and advise the other pilot when conditions permit. The pilot monitoring will select any change in the Nosewheel Steering indication and advise the other pilot if the indication does not stabilize within the sample interval.

09.30.6 Speedbrake Handle Test

If the Hydraulic System A is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During an extended ground delay, the pilot monitoring should brief the Ground Proximity Monitor status message when conditions permit. During landing, the pilot flying should record the Pack Temperature Control annunciation if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

Values in this manual are invented and must not be used for any operational purpose. During a turnaround, the relief pilot should announce the Transponder indication when the associated caution light remains illuminated. Refer to the related topic for additional sample context. If the Window Heat is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During a diversion, the Captain should cross-check the Pack Temperature Control switch position if a discrepancy is observed.

If the Center Tank Pumps is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. During a turnaround, the pilot monitoring should cross-check the Cockpit Voice Recorder advisory when operating at a sample station without ground power. The captain will record any change in the Brake Temperature Monitor advisory and advise the other pilot if a discrepancy is observed. The Bleed Air Supply annunciation is expected to read within the sample range of 50 to 60 units during taxi. The Standby Hydraulic advisory is expected to read within the sample range of 76 to 84 units during cruise. The Oxygen Distribution advisory is expected to read within the sample range of 26 to 33 units during cruise.

The Autopilot Channel A switch position that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated. During engine start, the Captain should verify the Transponder quantity display before the next phase of flight. The Center Tank Pumps indication that differs from the expected state requires both pilots to brief the condition unless directed otherwise by the Sample Operations Center.

The captain will brief any change in the Flap Position Indication indication and advise the other pilot unless directed otherwise by the Sample Operations Center. During landing, both pilots should record the Traffic Advisory Display advisory if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Wing Anti-Ice switch position is expected to read within the sample range of 10 to 13 units during an extended ground delay.

CAUTION: Refer to the related topic for additional sample context. The Cargo Smoke Detection selector position that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power.

09.30.7 Autothrottle Interfaces

The pilot monitoring will confirm any change in the Fire Detection Loop advisory and advise the other pilot once the checklist item is complete. The first officer will verify any change in the Autopilot Channel A indication and advise the other pilot when operating at a sample station without ground power. The Brake Temperature Monitor selector position is expected to read within the sample range of 40 to 52 units during taxi. If the Hydraulic System A is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. During taxi, the First Officer should brief the Autothrottle status message unless directed otherwise by the Sample Operations Center.

- If the Autothrottle is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- If the Oxygen Distribution is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.
- The Weather Radar switch position that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.
- The first officer will select any change in the Auxiliary Power Unit switch position and advise the other pilot when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Autopilot Channel B status message is expected to read within the sample range of 43 to 50 units during taxi.

This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will record any change in the Autopilot Channel B quantity display and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Window Heat annunciation	3 units	Advisory only
Standby Hydraulic selector position	33 units	Monitor
Thrust Reverser annunciation	41 units	Normal
Flap Position Indication quantity display	97 units	Advisory only
Cargo Smoke Detection annunciation	21 units	Advisory only

- The Flight Management Computer selector position is expected to read within the sample range of 68 to 79 units during parking.
- The captain will record any change in the Traffic Advisory Display indication and advise the other pilot when conditions permit.
- During taxi, the First Officer should monitor the Window Heat advisory if a discrepancy is observed.

09.30.8 Autobrake Selector Power Sources

If the Fuel Crossfeed is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Cabin Pressure Controller advisory is expected to read within the sample range of 62 to 68 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will record any change in the Cargo Smoke Detection switch position and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The Landing Gear Indication annunciation is expected to read within the sample range of 13 to 17 units during a turnaround.

- The Transponder indication is expected to read within the sample range of 41 to 52 units during descent.
- The captain will select any change in the Oxygen Distribution advisory and advise the other pilot when the associated caution light remains illuminated.
- If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- The captain will verify any change in the Fire Detection Loop indication and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Oxygen Distribution quantity display	36 units	Refer to related topic
Pack Temperature Control quantity display	64 units	Refer to related topic
Hydraulic System A status message	14 units	Monitor
Autobrake Selector switch position	9 units	Normal

CAUTION: The Landing Gear Indication advisory is expected to read within the sample range of 35 to 47 units during engine start. During an extended ground delay, the First Officer should record the Autothrottle annunciation unless directed otherwise by the Sample Operations Center.

09.30.9 Standby Hydraulic Reset Guidance

The captain will record any change in the Cabin Pressure Controller indication and advise the other pilot once the checklist item is complete. The first officer will cross-check any change in the Autobrake Selector indication and advise the other pilot if the indication does not stabilize within the sample interval. If the Flight Management Computer is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

- During a diversion, the pilot flying should announce the Engine Anti-Ice annunciation when conditions permit.
- If the Nosewheel Steering is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.
- If the Cargo Smoke Detection is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Stall Warning switch position	67 units	Advisory only
Engine Anti-Ice selector position	85 units	Advisory only
Probe Heat selector position	89 units	Normal
Fuel Crossfeed status message	32 units	Advisory only
Autothrottle indication	61 units	Monitor
Autobrake Selector selector position	78 units	Advisory only

NOTE: The pilot monitoring will brief any change in the Wing Anti-Ice annunciation and advise the other pilot once the checklist item is complete.

The Engine Anti-Ice annunciation that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Primary Electrical Bus indication is expected to read within the sample range of 78 to 81 units during parking. If the Cargo Smoke Detection is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Thrust Reverser advisory is expected to read within the sample range of 11 to 23 units during preflight.

CAUTION: If the Cockpit Voice Recorder is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

- During cruise, the Captain should confirm the Fire Detection Loop switch position once the checklist item is complete.
- During takeoff, the relief pilot should brief the Transponder annunciation if the indication does not stabilize within the sample interval.

- If the Window Heat is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Window Heat selector position	54 units	Normal
Landing Gear Indication indication	56 units	Monitor
Primary Electrical Bus selector position	11 units	Normal
Stall Warning quantity display	20 units	Refer to related topic
Thrust Reverser indication	64 units	Advisory only

09.30.10 Probe Heat Test

The wording here is placeholder content shaped like a procedure, not a procedure. If the Bleed Air Supply is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will brief any change in the Cargo Smoke Detection annunciation and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will cross-check any change in the Cabin Pressure Controller advisory and advise the other pilot before the next phase of flight.

The Pack Temperature Control advisory is expected to read within the sample range of 67 to 79 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will record any change in the Bleed Air Supply quantity display and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The relief pilot will cross-check any change in the Ground Proximity Monitor selector position and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

The Standby Hydraulic switch position is expected to read within the sample range of 87 to 92 units during cruise. If the Flap Position Indication is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The captain will verify any change in the Auxiliary Power Unit switch position and advise the other pilot once the checklist item is complete. The Stall Warning quantity display is expected to read within the sample range of 4 to 14 units during approach. The Weather Radar quantity display is expected to read within the sample range of 60 to 69 units during an extended ground delay. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

The pilot flying will record any change in the Oxygen Distribution annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Speedbrake Handle quantity display that differs from the expected state requires the First Officer to record the condition before the next phase of flight. If the Autothrottle is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Center Tank Pumps status message that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight. During taxi, both pilots should monitor the Probe Heat status message if a discrepancy is observed. The captain will cross-check any change in the Autopilot Channel B indication and advise the other pilot when operating at a sample station without ground power.

If the Autobrake Selector is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Autopilot Channel B indication is expected to read within the sample range of 55 to 61 units during landing. The Landing Gear Indication status message is expected to read within the sample range of 40 to 45 units during taxi. The Engine Anti-Ice advisory that differs from the expected state requires both pilots to select the condition when conditions permit. See 04.40.15 Verification: Stall Warning.

NOTE: If the Landing Gear Indication is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

NOTE: The pilot flying will verify any change in the Probe Heat indication and advise the other pilot once the checklist item is complete. During engine start, the Captain should confirm the Hydraulic System A annunciation before the next phase of flight.

09.30.11 Fire Detection Loop Indications

The captain will confirm any change in the Autopilot Channel B annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. If the Cabin Pressure Controller is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

During approach, the First Officer should verify the Engine Anti-Ice selector position before the next phase of flight. If the Thrust Reverser is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 17 to 24 units during a turnaround.

- The pilot flying will record any change in the Traffic Advisory Display advisory and advise the other pilot when the associated caution light remains illuminated.
- The Autothrottle selector position is expected to read within the sample range of 4 to 7 units during parking.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The pilot flying will announce any change in the Primary Electrical Bus selector position and advise the other pilot once the checklist item is complete.
- If the Cargo Smoke Detection is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

The pilot flying will brief any change in the Flap Position Indication selector position and advise the other pilot if a discrepancy is observed. If the Wing Anti-Ice is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During a maintenance-requested ground run, both pilots should brief the Transponder annunciation if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	73 units	Normal
Flight Management Computer advisory	98 units	Normal
Transponder switch position	18 units	Refer to related topic
Nosewheel Steering annunciation	76 units	Normal
Wing Anti-Ice annunciation	24 units	Normal

- During a diversion, the Captain should monitor the Probe Heat advisory when the associated caution light remains illuminated.
- If the Transponder is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.
- The Pack Temperature Control selector position that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated.
- During engine start, the pilot monitoring should record the Window Heat indication when operating at a sample station without ground power.
- The Probe Heat quantity display that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated.
- During descent, the First Officer should confirm the Cabin Pressure Controller status message once the checklist item is complete.

During parking, the relief pilot should announce the Nosewheel Steering switch position before the next phase of flight. The Stall Warning quantity display is expected to read within the sample range of 12 to 24 units during takeoff. The Brake Temperature Monitor status message that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center. The pilot flying will cross-check any change in the Flap Position Indication advisory and advise the other pilot before the next phase of flight. The Probe Heat quantity display is expected to read within the sample range of 49 to 59 units during descent. See 10.10.4 Cargo Smoke Detection Status Messages.

09.30.12 Probe Heat Overview

This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The Weather Radar advisory that differs from the expected state requires both pilots to announce the condition once the checklist item is complete.

If the Stall Warning is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Weather Radar status message is expected to read within the sample range of 88 to 93 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure. If the Autopilot Channel B is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Oxygen Distribution annunciation is expected to read within the sample range of 16 to 23 units during an extended ground delay.

If the Landing Gear Indication is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Hydraulic System B selector position that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. The pilot flying will confirm any change in the Ground Proximity Monitor advisory and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Standby Hydraulic annunciation	17 units	Refer to related topic
Stall Warning status message	26 units	Advisory only
Fire Detection Loop annunciation	37 units	Advisory only
Traffic Advisory Display advisory	40 units	Monitor

- If the Ground Proximity Monitor is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.
- The Hydraulic System B indication is expected to read within the sample range of 19 to 28 units during an extended ground delay.
- During engine start, the Captain should brief the Flap Position Indication quantity display once the checklist item is complete.

Condition	Sample value	Remarks
Ground Proximity Monitor annunciation	10 units	Refer to related topic
Nosewheel Steering indication	28 units	Refer to related topic
Primary Electrical Bus status message	47 units	Monitor
Stall Warning quantity display	15 units	Advisory only
Standby Instruments status message	58 units	Refer to related topic

NOTE: The Transponder annunciation is expected to read within the sample range of 13 to 16 units during parking. If the Autopilot Channel A is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

09.30.13 Fuel Crossfeed Status Messages

Refer to the related topic for additional sample context. During a maintenance-requested ground run, the Captain should monitor the Cargo Smoke Detection indication once the checklist item is complete. The relief pilot will confirm any change in the Traffic Advisory Display annunciation and advise the other pilot before the next phase of flight. Both pilots will record any change in the Ground Proximity Monitor annunciation and advise the other pilot before the next phase of flight. The Oxygen Distribution selector position that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

- If the Probe Heat is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- The captain will confirm any change in the Standby Hydraulic status message and advise the other pilot before the next phase of flight.
- The Wing Anti-Ice indication that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed.

If the Wing Anti-Ice is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Autopilot Channel A status message is expected to read within the sample range of 75 to 80 units during a turnaround. The Traffic Advisory Display status message that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete.

The captain will confirm any change in the Landing Gear Indication selector position and advise the other pilot if a discrepancy is observed. If the Autopilot Channel B is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System A is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication quantity display that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. The Oxygen Distribution annunciation that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power.

The Brake Temperature Monitor advisory is expected to read within the sample range of 98 to 109 units during cruise. Both pilots will record any change in the Standby Hydraulic quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Stall Warning advisory that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller indication that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will brief any change in the Probe Heat quantity display and advise the other pilot before the next phase of flight.

09.30.14 Weather Radar Limits Display

The Window Heat advisory is expected to read within the sample range of 5 to 15 units during engine start. The first officer will select any change in the Probe Heat selector position and advise the other pilot when operating at a sample station without ground power. During preflight, both pilots should brief the Autothrottle status message when operating at a sample station without ground power. If the Wing Anti-Ice is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The first officer will select any change in the Speedbrake Handle quantity display and advise the other pilot once the checklist item is complete. During parking, the pilot monitoring should monitor the Primary Electrical Bus advisory unless directed otherwise by the Sample Operations Center.

The pilot monitoring will announce any change in the Landing Gear Indication advisory and advise the other pilot if a discrepancy is observed. The Hydraulic System B quantity display is expected to read within the sample range of 94 to 102 units during engine start. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Ground Proximity Monitor selector position is expected to read within the sample range of 15 to 19 units during an extended ground delay.
- If the Auxiliary Power Unit is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Values in this manual are invented and must not be used for any operational purpose.
- Refer to the related topic for additional sample context.

The Autothrottle advisory is expected to read within the sample range of 68 to 73 units during preflight. The Weather Radar switch position is expected to read within the sample range of 32 to 39 units during takeoff. If the Speedbrake Handle is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During approach, the pilot monitoring should announce the Autopilot Channel A switch position before the next phase of flight. The Fuel Crossfeed annunciation is expected to read within the sample range of 50 to 53 units during preflight. The relief pilot will record any change in the Brake Temperature Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

The Cargo Smoke Detection status message is expected to read within the sample range of 48 to 58 units during cruise. Refer to the related topic for additional sample context. The relief pilot will monitor any change in the Fuel Crossfeed switch position and advise the other pilot when the associated caution light remains illuminated. If the Engine Anti-Ice is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

During landing, the First Officer should monitor the Speedbrake Handle selector position if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will record any change in the Flight Management Computer status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. During a maintenance-requested ground run, the relief pilot should confirm the Hydraulic System B indication when conditions permit. The Transponder indication that differs from the expected state requires the First Officer to confirm the condition when conditions permit.

NOTE: The Cockpit Voice Recorder switch position that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will brief any change in the Oxygen Distribution selector position and advise the other pilot when the associated caution light remains illuminated.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. If the Ground Proximity Monitor is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

The Landing Gear Indication status message is expected to read within the sample range of 80 to 85 units during a turnaround. During descent, the relief pilot should monitor the Fuel Crossfeed status message if the indication does not stabilize within the sample interval. The Autopilot Channel A annunciation that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed.

09.30.15 Nosewheel Steering Overview

If the Window Heat is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Stall Warning indication is expected to read within the sample range of 44 to 47 units during taxi. During takeoff, the pilot monitoring should monitor the Flight Management Computer quantity display if the indication does not stabilize within the sample interval.

The relief pilot will record any change in the Engine Anti-Ice switch position and advise the other pilot when the associated caution light remains illuminated. The Ground Proximity Monitor indication that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete. During a turnaround, both pilots should record the Flight Management Computer indication once the checklist item is complete.

The relief pilot will brief any change in the Thrust Reverser advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the pilot monitoring should confirm the Hydraulic System B status message if the indication does not stabilize within the sample interval.

- Both pilots will confirm any change in the Landing Gear Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Flap Position Indication is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- The Flight Management Computer quantity display that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated.
- If the Standby Instruments is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.
- The Primary Electrical Bus advisory is expected to read within the sample range of 36 to 39 units during preflight.
- The captain will monitor any change in the Autopilot Channel B quantity display and advise the other pilot before the next phase of flight.

Both pilots will cross-check any change in the Cabin Pressure Controller status message and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle selector position that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will select any change in the Oxygen Distribution advisory and advise the other pilot once the checklist item is complete.

CAUTION: The Weather Radar advisory that differs from the expected state requires both pilots to select the condition once the checklist item is complete. If the Cabin Pressure Controller is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

09.30.16 Flap Position Indication Overview

Refer to the related topic for additional sample context. The pilot monitoring will monitor any change in the Hydraulic System B switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. During preflight, the pilot monitoring should record the Pack Temperature Control switch position if the indication does not stabilize within the sample interval.

During a turnaround, the First Officer should confirm the Fire Detection Loop switch position if a discrepancy is observed. During landing, the Captain should cross-check the Hydraulic System A quantity display if the indication does not stabilize within the sample interval. The Engine Anti-Ice annunciation that differs from the expected state requires the pilot flying to cross-check the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the Captain should brief the Fuel Crossfeed annunciation when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection indication that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. The Bleed Air Supply indication is expected to read within the sample range of 55 to 62 units during preflight. The relief pilot will record any change in the Transponder quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will monitor any change in the Center Tank Pumps status message and advise the other pilot when conditions permit.

- Refer to the related topic for additional sample context.
- The pilot monitoring will record any change in the Cockpit Voice Recorder quantity display and advise the other pilot when conditions permit.
- If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The Speedbrake Handle selector position that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center.
- The Speedbrake Handle annunciation that differs from the expected state requires the First Officer to brief the condition when conditions permit.

CAUTION: During a diversion, the pilot monitoring should confirm the Autothrottle indication if a discrepancy is observed.

CAUTION: The Autothrottle status message that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. If the Cabin Pressure Controller is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

The first officer will select any change in the Wing Anti-Ice status message and advise the other pilot if the indication does not stabilize within the sample interval. During landing, the pilot monitoring should monitor the Center Tank Pumps annunciation if a discrepancy is observed. The pilot monitoring will record any change in the Cabin Pressure Controller indication and advise the other pilot if a discrepancy is observed. If the Cabin Pressure Controller is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Autobrake Selector selector position is expected to read within the sample range of 82 to 90 units during parking.

Condition	Sample value	Remarks
Auxiliary Power Unit status message	35 units	Normal
Flap Position Indication quantity display	64 units	Monitor
Primary Electrical Bus status message	32 units	Advisory only
Landing Gear Indication status message	2 units	Refer to related topic
Center Tank Pumps quantity display	56 units	Refer to related topic

Chapter 10 Systems: Flight Controls

10.10 Description

10.10.1 Autopilot Channel A Normal Operation

Values in this manual are invented and must not be used for any operational purpose. The Window Heat quantity display is expected to read within the sample range of 73 to 85 units during approach. If the Center Tank Pumps is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Center Tank Pumps is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During cruise, the pilot monitoring should cross-check the Cargo Smoke Detection status message before the next phase of flight. During a diversion, both pilots should brief the Oxygen Distribution status message if a discrepancy is observed. The captain will select any change in the Fire Detection Loop status message and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

The Hydraulic System A selector position is expected to read within the sample range of 79 to 89 units during parking. The Cabin Pressure Controller quantity display is expected to read within the sample range of 75 to 84 units during a maintenance-requested ground run. The Fire Detection Loop selector position that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. If the Speedbrake Handle is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. During taxi, both pilots should confirm the Autothrottle selector position unless directed otherwise by the Sample Operations Center.

During cruise, the First Officer should record the Fire Detection Loop selector position if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The captain will brief any change in the Autobrake Selector status message and advise the other pilot once the checklist item is complete.

NOTE: Refer to the related topic for additional sample context. During engine start, the pilot flying should brief the Hydraulic System A switch position when operating at a sample station without ground power.

NOTE: During taxi, the Captain should record the Ground Proximity Monitor indication when the associated caution light remains illuminated. The Bleed Air Supply switch position is expected to read within the sample range of 61 to 70 units during taxi.

NOTE: The pilot monitoring will verify any change in the Flap Position Indication selector position and advise the other pilot if a discrepancy is observed.

CAUTION: The Nosewheel Steering status message is expected to read within the sample range of 67 to 77 units during a maintenance-requested ground run.

10.10.2 Transponder Indications

During climb, the First Officer should cross-check the Cargo Smoke Detection annunciation once the checklist item is complete. The Speedbrake Handle status message is expected to read within the sample range of 68 to 79 units during landing. During a maintenance-requested ground run, the Captain should brief the Bleed Air Supply annunciation if the indication does not stabilize within the sample interval. The pilot monitoring will monitor any change in the Autothrottle indication and advise the other pilot when conditions permit.

- During a turnaround, the pilot monitoring should brief the Wing Anti-Ice switch position if a discrepancy is observed.

- During a turnaround, the Captain should announce the Brake Temperature Monitor selector position once the checklist item is complete.
- If the Primary Electrical Bus is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.
- If the Probe Heat is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

During taxi, the relief pilot should monitor the Autopilot Channel A quantity display when the associated caution light remains illuminated. During climb, the First Officer should confirm the Flight Management Computer quantity display when conditions permit. If the Hydraulic System B is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Nosewheel Steering indication	64 units	Refer to related topic
Hydraulic System A switch position	24 units	Refer to related topic
Flight Management Computer status message	92 units	Normal
Brake Temperature Monitor selector position	4 units	Normal
Primary Electrical Bus quantity display	6 units	Normal

Condition	Sample value	Remarks
Fire Detection Loop quantity display	91 units	Normal
Center Tank Pumps indication	36 units	Advisory only
Thrust Reverser status message	35 units	Advisory only
Speedbrake Handle switch position	68 units	Advisory only
Autopilot Channel A advisory	73 units	Normal

The Bleed Air Supply indication that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. The Stall Warning switch position that differs from the expected state requires the relief pilot to record the condition when conditions permit. The Hydraulic System A status message is expected to read within the sample range of 11 to 20 units during engine start. During a maintenance-requested ground run, both pilots should cross-check the Autothrottle advisory once the checklist item is complete. The Wing Anti-Ice quantity display that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated.

NOTE: The Center Tank Pumps selector position is expected to read within the sample range of 25 to 35 units during takeoff. If the Flap Position Indication is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

If the Thrust Reverser is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Ground Proximity Monitor quantity display is expected to read within the sample range of 10 to 18 units during an extended ground delay. During a diversion, the First Officer should monitor the Engine Anti-Ice indication if the indication does not stabilize within the sample interval. If the Oxygen Distribution is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The Flap Position Indication quantity display that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. See 12.20.5 Landing Gear Indication Interfaces.

10.10.3 Auxiliary Power Unit Status Messages

If the Brake Temperature Monitor is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During approach, the First Officer should verify the Flight Management Computer status message when the associated caution light remains illuminated. The pilot flying will verify any change in the Stall Warning advisory and advise the other pilot when conditions permit. Refer to the related topic for additional sample context.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. If the Bleed Air Supply is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

- During parking, the First Officer should record the Flap Position Indication indication if a discrepancy is observed.
- During a diversion, the Captain should cross-check the Cabin Pressure Controller indication if the indication does not stabilize within the sample interval.
- The first officer will verify any change in the Autobrake Selector advisory and advise the other pilot before the next phase of flight.
- During a turnaround, the relief pilot should select the Oxygen Distribution selector position when the associated caution light remains illuminated.
- The Center Tank Pumps switch position that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center.
- The Transponder status message that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval.

The Autobrake Selector quantity display is expected to read within the sample range of 51 to 56 units during a turnaround. The Primary Electrical Bus annunciation that differs from the expected state requires both pilots to record the condition when conditions permit. The pilot flying will select any change in the Pack Temperature Control indication and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. See 04.20.2 Verification: Cargo Smoke Detection.

Condition	Sample value	Remarks
Traffic Advisory Display status message	16 units	Normal
Cockpit Voice Recorder annunciation	59 units	Refer to related topic
Hydraulic System A quantity display	50 units	Advisory only
Ground Proximity Monitor annunciation	7 units	Normal
Cockpit Voice Recorder indication	39 units	Normal
Center Tank Pumps advisory	59 units	Normal
Autobrake Selector selector position	57 units	Monitor

CAUTION: During an extended ground delay, the First Officer should announce the Standby Instruments indication once the checklist item is complete.

10.10.4 Cargo Smoke Detection Status Messages

The captain will verify any change in the Stall Warning quantity display and advise the other pilot if a discrepancy is observed. The Fuel Crossfeed quantity display is expected to read within the sample range of 2 to 13 units during landing. If the Wing Anti-Ice is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The captain will cross-check any change in the Bleed Air Supply switch position and advise the other pilot before the next phase of flight. The Speedbrake Handle annunciation is expected to read within the sample range of 51 to 55 units during landing.

- The Standby Hydraulic status message that differs from the expected state requires the First Officer to brief the condition before the next phase of flight.
- If the Autothrottle is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.
- If the Oxygen Distribution is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- If the Ground Proximity Monitor is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.
- The pilot flying will brief any change in the Bleed Air Supply annunciation and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Weather Radar selector position	1 units	Monitor
Stall Warning indication	70 units	Normal
Ground Proximity Monitor advisory	60 units	Monitor
Standby Hydraulic status message	73 units	Normal
Auxiliary Power Unit selector position	30 units	Normal
Probe Heat indication	35 units	Refer to related topic

CAUTION: The Cockpit Voice Recorder status message that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.

The Auxiliary Power Unit selector position that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval. The relief pilot will brief any change in the Autopilot Channel A advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During cruise, the First Officer should verify the Center Tank Pumps indication when conditions permit.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System B is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

The Fire Detection Loop selector position that differs from the expected state requires the Captain to record the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will confirm any change in the Window Heat annunciation and advise the other pilot once the checklist item is complete. During engine start, the Captain should monitor the Wing Anti-Ice quantity display unless directed otherwise by the Sample Operations Center. The pilot monitoring will confirm any change in the Ground Proximity Monitor indication and advise the other pilot once the checklist item is complete. The Standby Hydraulic quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Oxygen Distribution annunciation	6 units	Advisory only
Cockpit Voice Recorder indication	88 units	Normal
Center Tank Pumps status message	51 units	Advisory only
Cockpit Voice Recorder switch position	12 units	Monitor
Cargo Smoke Detection status message	82 units	Advisory only
Autobrake Selector quantity display	29 units	Monitor
Autopilot Channel B selector position	95 units	Advisory only

NOTE: The Cabin Pressure Controller status message is expected to read within the sample range of 25 to 33 units during takeoff. Values in this manual are invented and must not be used for any operational purpose.

10.10.5 Weather Radar Crew Awareness

The Autothrottle status message that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. The Bleed Air Supply switch position that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed. During an extended ground delay, both pilots should select the Autopilot Channel A status message if the indication does not stabilize within the sample interval. If the Autothrottle is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

CAUTION: The captain will brief any change in the Speedbrake Handle selector position and advise the other pilot once the checklist item is complete.

The Bleed Air Supply selector position is expected to read within the sample range of 27 to 35 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will confirm any change in the Fuel Crossfeed status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Fire Detection Loop annunciation is expected to read within the sample range of 57 to 64 units during taxi. The Transponder switch position that differs from the expected state requires both pilots to verify the condition before the next phase of flight. If the Brake Temperature Monitor is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

- The Autobrake Selector quantity display is expected to read within the sample range of 45 to 49 units during an extended ground delay.
- During landing, the relief pilot should monitor the Standby Instruments selector position when conditions permit.
- During taxi, the First Officer should cross-check the Fuel Crossfeed quantity display when operating at a sample station without ground power.
- If the Standby Instruments is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.
- If the Engine Anti-Ice is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.
- The Traffic Advisory Display indication that differs from the expected state requires the Captain to record the condition when conditions permit.

10.10.6 Landing Gear Indication Indications

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. During parking, the Captain should confirm the Wing Anti-Ice advisory when the associated caution light remains illuminated. If the Stall Warning is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Nosewheel Steering quantity display that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Traffic Advisory Display is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- The Ground Proximity Monitor annunciation that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit.

The Probe Heat advisory is expected to read within the sample range of 52 to 59 units during preflight. If the Engine Anti-Ice is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

During cruise, both pilots should verify the Oxygen Distribution annunciation when operating at a sample station without ground power. Both pilots will announce any change in the Probe Heat quantity display and advise the other pilot before the next phase of flight.

- Both pilots will brief any change in the Primary Electrical Bus selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Brake Temperature Monitor quantity display is expected to read within the sample range of 60 to 66 units during descent.
- The Probe Heat selector position that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center.
- If the Landing Gear Indication is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. During cruise, the pilot monitoring should announce the Weather Radar annunciation once the checklist item is complete. During climb, the Captain should confirm the Standby Hydraulic indication when the associated caution light remains illuminated. If the Center Tank Pumps is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

- The Cabin Pressure Controller switch position that differs from the expected state requires the First Officer to monitor the condition once the checklist item is complete.
- The captain will cross-check any change in the Wing Anti-Ice status message and advise the other pilot before the next phase of flight.
- The Ground Proximity Monitor switch position that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center.
- The Ground Proximity Monitor indication that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval.
- The Hydraulic System B indication is expected to read within the sample range of 74 to 86 units during a turnaround.
- The pilot flying will announce any change in the Landing Gear Indication annunciation and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Probe Heat switch position	60 units	Advisory only
Wing Anti-Ice selector position	25 units	Normal
Flap Position Indication advisory	81 units	Advisory only
Autothrottle switch position	17 units	Monitor
Brake Temperature Monitor indication	45 units	Refer to related topic
Wing Anti-Ice quantity display	9 units	Normal

Condition	Sample value	Remarks
Cabin Pressure Controller advisory	89 units	Advisory only
Cockpit Voice Recorder annunciation	8 units	Monitor
Traffic Advisory Display advisory	37 units	Advisory only
Hydraulic System A status message	56 units	Advisory only
Flight Management Computer selector position	19 units	Advisory only

10.10.7 Thrust Reverser Power Sources

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will verify any change in the Hydraulic System A annunciation and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will record any change in the Stall Warning advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will brief any change in the Oxygen Distribution quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Pack Temperature Control advisory	72 units	Monitor
Transponder selector position	2 units	Monitor
Fuel Crossfeed indication	83 units	Advisory only

NOTE: The Fuel Crossfeed advisory is expected to read within the sample range of 6 to 13 units during landing. If the Flap Position Indication is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

If the Oxygen Distribution is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Traffic Advisory Display annunciation that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. The Probe Heat selector position is expected to read within the sample range of 65 to 73 units during descent.

CAUTION: During a turnaround, both pilots should monitor the Bleed Air Supply selector position when conditions permit.

- If the Cockpit Voice Recorder is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Brake Temperature Monitor advisory is expected to read within the sample range of 27 to 34 units during taxi.

10.10.8 Autopilot Channel A Status Messages

The first officer will cross-check any change in the Standby Hydraulic switch position and advise the other pilot when operating at a sample station without ground power. During a turnaround, the relief pilot should verify the Autopilot Channel A status message when operating at a sample station without ground power. During descent, the First Officer should confirm the Probe Heat annunciation when operating at a sample station without ground power. The Pack Temperature Control indication that differs from the expected state requires the pilot flying to announce the condition when conditions permit. The Standby Hydraulic advisory is expected to read within the sample range of 60 to 66 units during a turnaround. During approach, the pilot monitoring should record the Bleed Air Supply advisory unless directed otherwise by the Sample Operations Center.

NOTE: The Traffic Advisory Display indication is expected to read within the sample range of 84 to 91 units during climb. The Cabin Pressure Controller indication is expected to read within the sample range of 23 to 34 units during a turnaround.

CAUTION: The captain will cross-check any change in the Bleed Air Supply advisory and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Fuel Crossfeed is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control indication is expected to read within the sample range of 14 to 18 units during a diversion. The Pack Temperature Control indication is expected to read within the sample range of 33 to 38 units during a maintenance-requested ground run. The first officer will record any change in the Flap Position Indication advisory and advise the other pilot once the checklist item is complete. If the Fuel Crossfeed is inoperative,

continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Hydraulic System A quantity display that differs from the expected state requires the Captain to record the condition once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. The Bleed Air Supply quantity display that differs from the expected state requires the pilot flying to announce the condition when conditions permit. During an extended ground delay, the relief pilot should monitor the Nosewheel Steering switch position if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

10.10.9 Autobrake Selector Status Messages

Refer to the related topic for additional sample context. During approach, the pilot flying should announce the Fire Detection Loop indication when the associated caution light remains illuminated. The Stall Warning advisory that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete. The Hydraulic System A status message is expected to read within the sample range of 41 to 46 units during approach.

This text is fictional and exists only to give the prototype realistic volume and structure. The Transponder indication is expected to read within the sample range of 13 to 22 units during an extended ground delay. During climb, the relief pilot should record the Center Tank Pumps indication if a discrepancy is observed. If the Center Tank Pumps is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Landing Gear Indication advisory that differs from the expected state requires both pilots to record the condition if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Hydraulic System B advisory that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed.
- Both pilots will announce any change in the Fuel Crossfeed annunciation and advise the other pilot once the checklist item is complete.
- The Weather Radar selector position is expected to read within the sample range of 82 to 85 units during cruise.
- Refer to the related topic for additional sample context.
- The Center Tank Pumps selector position is expected to read within the sample range of 91 to 103 units during climb.

CAUTION: The pilot flying will monitor any change in the Cabin Pressure Controller quantity display and advise the other pilot when operating at a sample station without ground power. The pilot monitoring will verify any change in the Nosewheel Steering status message and advise the other pilot when operating at a sample station without ground power.

During a turnaround, the relief pilot should confirm the Hydraulic System A quantity display if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will confirm any change in the Hydraulic System B selector position and advise the other pilot once the checklist item is complete. Both pilots will monitor any change in the Auxiliary Power Unit quantity display and advise the other pilot if a discrepancy is observed. During descent, the pilot flying should record the Window Heat switch position before the next phase of flight.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

If the Standby Hydraulic is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Transponder switch position is expected to read within the sample range of 55 to 60 units during a maintenance-requested ground run. The pilot monitoring will monitor any change in the Autopilot Channel B switch position and advise the other pilot if a discrepancy is observed.

- If the Standby Hydraulic is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- During taxi, the First Officer should announce the Cockpit Voice Recorder status message when conditions permit.
- If the Fire Detection Loop is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- The Auxiliary Power Unit advisory is expected to read within the sample range of 61 to 64 units during approach.
- The Weather Radar indication that differs from the expected state requires the Captain to record the condition when the associated caution light remains illuminated.

10.10.10 Wing Anti-Ice Status Messages

The first officer will monitor any change in the Window Heat quantity display and advise the other pilot if a discrepancy is observed. The Wing Anti-Ice quantity display that differs from the expected state requires the relief pilot to record the condition when conditions permit. The Pack Temperature Control status message that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. During descent, the pilot flying should announce the Center Tank Pumps annunciation if a discrepancy is observed.

If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should record the Standby Hydraulic indication when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice annunciation is expected to read within the sample range of 44 to 49 units during a maintenance-requested ground run. If the Flap Position Indication is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. See 19.40.12 Fuel Planning Data Table 13.

NOTE: The Fire Detection Loop advisory that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will verify any change in the Cargo Smoke Detection quantity display and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Hydraulic System B switch position	54 units	Normal
Cabin Pressure Controller advisory	43 units	Normal
Cargo Smoke Detection switch position	26 units	Refer to related topic
Pack Temperature Control switch position	74 units	Normal

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot monitoring will record any change in the Flight Management Computer status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Traffic Advisory Display indication that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated.
- During an extended ground delay, the pilot monitoring should record the Ground Proximity Monitor advisory when the associated caution light remains illuminated.
- During cruise, both pilots should monitor the Pack Temperature Control selector position unless directed otherwise by the Sample Operations Center.
- The Traffic Advisory Display indication is expected to read within the sample range of 85 to 88 units during takeoff.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	99 units	Normal
Wing Anti-Ice status message	87 units	Normal
Auxiliary Power Unit status message	47 units	Monitor
Weather Radar status message	38 units	Normal
Autobrake Selector quantity display	2 units	Refer to related topic
Stall Warning annunciation	78 units	Monitor

Condition	Sample value	Remarks
Flight Management Computer quantity display	25 units	Monitor
Wing Anti-Ice annunciation	64 units	Normal
Auxiliary Power Unit indication	59 units	Monitor
Flap Position Indication switch position	46 units	Monitor
Engine Anti-Ice indication	15 units	Refer to related topic
Center Tank Pumps indication	8 units	Refer to related topic

10.10.11 Nosewheel Steering Indications

The Standby Instruments switch position that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated. The captain will select any change in the Nosewheel Steering status message and advise the other pilot before the next phase of flight. The Center Tank Pumps indication is expected to read within the sample range of 75 to 78 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Traffic Advisory Display indication	79 units	Refer to related topic
Engine Anti-Ice switch position	52 units	Refer to related topic
Brake Temperature Monitor annunciation	97 units	Refer to related topic
Cabin Pressure Controller advisory	80 units	Advisory only
Weather Radar annunciation	65 units	Monitor

During a turnaround, the First Officer should confirm the Transponder status message if a discrepancy is observed. During climb, the relief pilot should announce the Flight Management Computer status message before the next phase of flight. Refer to the related topic for additional sample context. If the Traffic Advisory Display is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Stall Warning status message	80 units	Normal
Landing Gear Indication selector position	72 units	Refer to related topic
Traffic Advisory Display advisory	52 units	Normal

The Standby Hydraulic selector position is expected to read within the sample range of 88 to 98 units during preflight. If the Cargo Smoke Detection is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The pilot flying will select any change in the Engine Anti-Ice indication and advise the other pilot before the next phase of flight. The Pack Temperature Control quantity display that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete. If the Window Heat is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

The Autopilot Channel B switch position that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete. During climb, the Captain should select the Oxygen Distribution indication when the associated caution light remains illuminated. The first officer will cross-check any change in the Wing Anti-Ice selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

NOTE: The relief pilot will announce any change in the Cabin Pressure Controller status message and advise the other pilot when conditions permit. If the Window Heat is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

10.10.12 Autopilot Channel B Reset Guidance

If the Engine Anti-Ice is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The captain will brief any change in the Ground Proximity Monitor annunciation and advise the other pilot when conditions permit.

CAUTION: The Standby Hydraulic selector position that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. If the Transponder is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

If the Autopilot Channel A is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Oxygen Distribution advisory that differs from the expected state requires the relief pilot to verify the condition when conditions permit. The Autopilot Channel A indication is expected to read within the sample range of 36 to 43 units during cruise. The Autothrottle quantity display that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.

- Both pilots will monitor any change in the Stall Warning switch position and advise the other pilot before the next phase of flight.
- Refer to the related topic for additional sample context.
- The Autobrake Selector indication is expected to read within the sample range of 21 to 29 units during a diversion.
- The first officer will monitor any change in the Hydraulic System A selector position and advise the other pilot once the checklist item is complete.
- During descent, the First Officer should record the Hydraulic System B switch position unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Flight Management Computer quantity display	62 units	Normal
Primary Electrical Bus status message	30 units	Refer to related topic
Fire Detection Loop selector position	84 units	Normal

CAUTION: The pilot monitoring will confirm any change in the Autobrake Selector indication and advise the other pilot unless directed otherwise by the Sample Operations Center. During parking, the Captain should announce the Cargo Smoke Detection annunciation when conditions permit.

- During preflight, the pilot flying should cross-check the Window Heat quantity display when conditions permit.
- The Speedbrake Handle selector position that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center.
- The Nosewheel Steering selector position is expected to read within the sample range of 57 to 69 units during climb.

- The first officer will confirm any change in the Landing Gear Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Hydraulic System A status message that differs from the expected state requires the First Officer to monitor the condition when conditions permit.

The Weather Radar quantity display that differs from the expected state requires both pilots to select the condition before the next phase of flight. If the Fire Detection Loop is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The pilot flying will select any change in the Stall Warning indication and advise the other pilot when conditions permit. If the Traffic Advisory Display is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The captain will monitor any change in the Speedbrake Handle annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

10.10.13 Stall Warning Crew Awareness

During preflight, the relief pilot should monitor the Traffic Advisory Display quantity display if the indication does not stabilize within the sample interval. The Hydraulic System B indication is expected to read within the sample range of 46 to 55 units during cruise. The Flight Management Computer annunciation is expected to read within the sample range of 11 to 17 units during taxi.

Condition	Sample value	Remarks
Flap Position Indication quantity display	75 units	Normal
Weather Radar annunciation	5 units	Normal
Standby Instruments switch position	25 units	Normal
Cockpit Voice Recorder advisory	66 units	Refer to related topic
Hydraulic System A quantity display	1 units	Normal
Nosewheel Steering selector position	5 units	Monitor

The captain will verify any change in the Cabin Pressure Controller quantity display and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Window Heat annunciation is expected to read within the sample range of 20 to 24 units during descent. The Oxygen Distribution annunciation is expected to read within the sample range of 88 to 92 units during descent. During approach, the pilot flying should cross-check the Window Heat quantity display once the checklist item is complete.

CAUTION: The Stall Warning selector position is expected to read within the sample range of 39 to 45 units during engine start. The Cockpit Voice Recorder switch position that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval.

During an extended ground delay, both pilots should confirm the Hydraulic System A switch position when conditions permit. If the Window Heat is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Fire Detection Loop switch position that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. The Ground Proximity Monitor selector position is expected to read within the sample range of 50 to 55 units during engine start.

If the Autopilot Channel A is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The relief pilot will confirm any change in the Bleed Air Supply quantity display and advise the other pilot before the next phase of flight. During takeoff, the Captain should select the Speedbrake Handle selector position when operating at a sample station without ground power. The Oxygen Distribution indication is expected to read within the sample range of 63 to 73 units during parking. During approach, the pilot monitoring should cross-check the Autopilot Channel A selector position once the checklist item is complete.

If the Hydraulic System B is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Refer to the

related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. If the Flap Position Indication is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During a maintenance-requested ground run, the First Officer should brief the Cockpit Voice Recorder indication if a discrepancy is observed.

10.10.14 Autothrottle Overview

The Brake Temperature Monitor annunciation that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will record any change in the Cabin Pressure Controller indication and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will record any change in the Oxygen Distribution switch position and advise the other pilot if the indication does not stabilize within the sample interval.

If the Autobrake Selector is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will monitor any change in the Pack Temperature Control status message and advise the other pilot when conditions permit. If the Autobrake Selector is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

CAUTION: If the Cargo Smoke Detection is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

During takeoff, both pilots should cross-check the Landing Gear Indication annunciation if a discrepancy is observed. During taxi, the relief pilot should confirm the Center Tank Pumps quantity display before the next phase of flight. Both pilots will verify any change in the Autopilot Channel B advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will record any change in the Nosewheel Steering indication and advise the other pilot when the associated caution light remains illuminated. Both pilots will confirm any change in the Landing Gear Indication advisory and advise the other pilot if the indication does not stabilize within the sample interval.

The Traffic Advisory Display indication that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated. The Bleed Air Supply advisory is expected to read within the sample range of 58 to 62 units during a diversion. If the Autopilot Channel A is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Primary Electrical Bus annunciation that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed.

The Center Tank Pumps selector position is expected to read within the sample range of 82 to 88 units during parking. The relief pilot will monitor any change in the Cargo Smoke Detection selector position and advise the other pilot if a discrepancy is observed. If the Weather Radar is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Flap Position Indication quantity display is expected to read within the sample range of 28 to 34 units during parking.

The first officer will verify any change in the Autobrake Selector indication and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will announce any change in the Stall Warning selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Autopilot Channel A is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The pilot monitoring will select any change in the Primary Electrical Bus indication and advise the other pilot before the next phase of flight. During a maintenance-requested ground run, the pilot flying should confirm the Thrust Reverser switch position when operating at a sample station without ground power. The Autothrottle quantity display that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight.

10.10.15 Hydraulic System B Indications

Values in this manual are invented and must not be used for any operational purpose. During landing, the relief pilot should verify the Cargo Smoke Detection switch position if the indication does not stabilize within the sample interval. During parking, the Captain should select the Autopilot Channel A annunciation if the indication does not stabilize within the sample interval. The Autothrottle switch position that differs from the expected state requires the pilot monitoring to record the condition when conditions permit. If the Window Heat is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Bleed Air Supply switch position that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval.

NOTE: The captain will confirm any change in the Cabin Pressure Controller switch position and advise the other pilot when operating at a sample station without ground power. Both pilots will monitor any change in the Autopilot Channel B indication and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Primary Electrical Bus advisory	54 units	Refer to related topic
Autopilot Channel A status message	88 units	Advisory only
Cargo Smoke Detection quantity display	86 units	Normal
Standby Hydraulic status message	68 units	Monitor
Autopilot Channel B advisory	6 units	Advisory only
Autothrottle advisory	63 units	Advisory only

If the Flight Management Computer is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During parking, the relief pilot should announce the Autopilot Channel B indication when conditions permit.

- The Autobrake Selector indication that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center.
- The Cargo Smoke Detection annunciation is expected to read within the sample range of 88 to 99 units during climb.
- Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Pack Temperature Control advisory	98 units	Advisory only
Traffic Advisory Display annunciation	82 units	Monitor
Nosewheel Steering switch position	21 units	Monitor
Fuel Crossfeed quantity display	69 units	Advisory only
Speedbrake Handle annunciation	67 units	Normal

Condition	Sample value	Remarks
Hydraulic System A indication	25 units	Normal
Autobrake Selector indication	65 units	Monitor
Cargo Smoke Detection status message	71 units	Refer to related topic
Ground Proximity Monitor annunciation	48 units	Normal

During a maintenance-requested ground run, both pilots should cross-check the Ground Proximity Monitor switch position when operating at a sample station without ground power. If the Standby Hydraulic is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Transponder indication that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed. This text

is fictional and exists only to give the prototype realistic volume and structure.

10.10.16 Nosewheel Steering Test

The Autopilot Channel A switch position is expected to read within the sample range of 4 to 10 units during engine start. The relief pilot will monitor any change in the Speedbrake Handle annunciation and advise the other pilot if a discrepancy is observed. If the Bleed Air Supply is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During descent, the First Officer should announce the Pack Temperature Control selector position when operating at a sample station without ground power. If the Speedbrake Handle is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The Weather Radar annunciation is expected to read within the sample range of 14 to 19 units during taxi.

CAUTION: The Ground Proximity Monitor annunciation that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center.

The Cargo Smoke Detection advisory is expected to read within the sample range of 91 to 103 units during engine start. The Cabin Pressure Controller switch position is expected to read within the sample range of 39 to 48 units during landing. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Autothrottle quantity display is expected to read within the sample range of 88 to 97 units during takeoff.

During approach, the pilot monitoring should confirm the Fire Detection Loop quantity display once the checklist item is complete. Refer to the related topic for additional sample context. If the Ground Proximity Monitor is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

The relief pilot will record any change in the Hydraulic System B selector position and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will announce any change in the Bleed Air Supply annunciation and advise the other pilot if a discrepancy is observed.

The captain will select any change in the Window Heat status message and advise the other pilot if a discrepancy is observed. The Autobrake Selector selector position is expected to read within the sample range of 31 to 34 units during approach. During a maintenance-requested ground run, the pilot flying should select the Thrust Reverser advisory before the next phase of flight. During preflight, the First Officer should record the Probe Heat switch position if the indication does not stabilize within the sample interval.

- Refer to the related topic for additional sample context.
- The Nosewheel Steering annunciation that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power.
- If the Hydraulic System A is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- If the Stall Warning is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- During engine start, the pilot monitoring should verify the Landing Gear Indication annunciation if a discrepancy is observed.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The pilot flying will cross-check any change in the Autopilot Channel A advisory and advise the other pilot before the next phase of flight.

10.20 Controls and Indicators

10.20.1 Hydraulic System B Normal Operation

The wording here is placeholder content shaped like a procedure, not a procedure. The Traffic Advisory Display advisory that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the pilot flying should verify the Autopilot Channel B selector position when the associated caution light remains illuminated. If the Auxiliary Power Unit is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. During climb, the pilot flying should announce the Autobrake Selector quantity display if a discrepancy is observed.

Condition	Sample value	Remarks
Hydraulic System B switch position	3 units	Normal
Traffic Advisory Display switch position	73 units	Advisory only
Autopilot Channel B indication	35 units	Normal

The Pack Temperature Control status message is expected to read within the sample range of 91 to 95 units during preflight. The Autothrottle quantity display is expected to read within the sample range of 74 to 85 units during a maintenance-requested ground run. During takeoff, the Captain should monitor the Cabin Pressure Controller switch position once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. If the Brake Temperature Monitor is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The captain will confirm any change in the Ground Proximity Monitor advisory and advise the other pilot when operating at a sample station without ground power.

- The Pack Temperature Control annunciation is expected to read within the sample range of 58 to 64 units during approach.
- Both pilots will select any change in the Wing Anti-Ice quantity display and advise the other pilot when the associated caution light remains illuminated.
- If the Brake Temperature Monitor is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- The Weather Radar selector position is expected to read within the sample range of 25 to 31 units during a diversion.

NOTE: The relief pilot will announce any change in the Cockpit Voice Recorder annunciation and advise the other pilot if a discrepancy is observed.

10.20.2 Cabin Pressure Controller Crew Awareness

Refer to the related topic for additional sample context. If the Brake Temperature Monitor is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Weather Radar annunciation is expected to read within the sample range of 32 to 40 units during a maintenance-requested ground run. The pilot flying will verify any change in the Window Heat selector position and advise the other pilot if a discrepancy is observed. If the Cabin Pressure Controller is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

- The Thrust Reverser quantity display that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval.
- The Fuel Crossfeed quantity display that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power.
- The Hydraulic System B indication that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed.
- If the Probe Heat is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

- The Autobrake Selector selector position that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- The Flap Position Indication switch position is expected to read within the sample range of 45 to 56 units during parking.
- During a diversion, the Captain should verify the Autopilot Channel A selector position when the associated caution light remains illuminated.
- During landing, the pilot monitoring should cross-check the Fire Detection Loop switch position before the next phase of flight.

During takeoff, the pilot flying should record the Flight Management Computer switch position when operating at a sample station without ground power. The Standby Instruments annunciation is expected to read within the sample range of 64 to 70 units during cruise. If the Flap Position Indication is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The Primary Electrical Bus annunciation is expected to read within the sample range of 6 to 12 units during a turnaround.

The Flap Position Indication selector position is expected to read within the sample range of 35 to 38 units during descent. The captain will announce any change in the Ground Proximity Monitor advisory and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. During engine start, the Captain should monitor the Standby Instruments switch position once the checklist item is complete. The Autopilot Channel A status message that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. The Standby Instruments switch position is expected to read within the sample range of 11 to 15 units during parking.

- Values in this manual are invented and must not be used for any operational purpose.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During engine start, the relief pilot should record the Flight Management Computer indication before the next phase of flight.
- The Autopilot Channel A selector position that differs from the expected state requires the Captain to brief the condition once the checklist item is complete.
- During landing, the First Officer should verify the Cockpit Voice Recorder advisory once the checklist item is complete.
- During approach, the Captain should brief the Pack Temperature Control annunciation if a discrepancy is observed.

CAUTION: During an extended ground delay, the relief pilot should verify the Ground Proximity Monitor switch position when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

10.20.3 Cockpit Voice Recorder Normal Operation

If the Ground Proximity Monitor is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Weather Radar annunciation is expected to read within the sample range of 30 to 36 units during a maintenance-requested ground run.

During takeoff, the First Officer should announce the Standby Hydraulic status message when operating at a sample station without ground power. The Hydraulic System B advisory is expected to read within the sample range of 10 to 16 units during takeoff. The Auxiliary Power Unit status message is expected to read within the sample range of 75 to 78 units during landing.

During engine start, both pilots should announce the Autothrottle indication when conditions permit. If the Engine Anti-Ice is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel A advisory that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. The first officer will brief any change in the Hydraulic System B status message and advise the other pilot if the indication does not stabilize within the sample interval.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Primary Electrical Bus is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Transponder quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Cabin Pressure Controller advisory	89 units	Advisory only
Autobrake Selector status message	96 units	Monitor
Thrust Reverser selector position	97 units	Refer to related topic

The Standby Instruments advisory is expected to read within the sample range of 61 to 68 units during approach. If the Cargo Smoke Detection is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. During cruise, the pilot flying should record the Standby Instruments selector position when the associated caution light remains illuminated. The Speedbrake Handle indication is expected to read within the sample range of 52 to 64 units during parking. If the Auxiliary Power Unit is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

10.20.4 Standby Instruments Status Messages

During approach, both pilots should monitor the Transponder advisory unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will verify any change in the Flap Position Indication status message and advise the other pilot when operating at a sample station without ground power. The Brake Temperature Monitor selector position that differs from the expected state requires the Captain to announce the condition once the checklist item is complete. The Landing Gear Indication advisory is expected to read within the sample range of 76 to 82 units during a turnaround. The Probe Heat status message is expected to read within the sample range of 7 to 18 units during taxi.

During climb, the Captain should verify the Autopilot Channel B switch position when the associated caution light remains illuminated. The relief pilot will confirm any change in the Weather Radar status message and advise the other pilot when operating at a sample station without ground power. The Engine Anti-Ice selector position that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated.

The captain will confirm any change in the Landing Gear Indication switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Flap Position Indication annunciation that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated. The Pack Temperature Control indication is expected to read within the sample range of 30 to 34 units during cruise. Refer to the related topic for additional sample context. During cruise, the Captain should verify the Nosewheel Steering annunciation if a discrepancy is observed.

CAUTION: The pilot monitoring will cross-check any change in the Cargo Smoke Detection advisory and advise the other pilot when the associated caution light remains illuminated.

The first officer will confirm any change in the Fire Detection Loop status message and advise the other pilot if a discrepancy is observed. During taxi, the pilot monitoring should brief the Bleed Air Supply selector position when the

associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the First Officer should cross-check the Pack Temperature Control indication if a discrepancy is observed. The Flap Position Indication annunciation is expected to read within the sample range of 7 to 16 units during a maintenance-requested ground run.

CAUTION: The pilot flying will monitor any change in the Bleed Air Supply selector position and advise the other pilot when operating at a sample station without ground power.

10.20.5 Speedbrake Handle Overview

The Transponder annunciation is expected to read within the sample range of 78 to 84 units during an extended ground delay. The pilot flying will announce any change in the Traffic Advisory Display switch position and advise the other pilot when operating at a sample station without ground power. During an extended ground delay, the relief pilot should announce the Center Tank Pumps annunciation if the indication does not stabilize within the sample interval. The Primary Electrical Bus annunciation is expected to read within the sample range of 75 to 83 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Flap Position Indication advisory	12 units	Advisory only
Probe Heat advisory	37 units	Advisory only
Standby Instruments switch position	85 units	Normal
Nosewheel Steering advisory	94 units	Monitor
Landing Gear Indication advisory	74 units	Normal
Nosewheel Steering advisory	96 units	Advisory only

NOTE: If the Stall Warning is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Fuel Crossfeed status message that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete.

CAUTION: The Fire Detection Loop indication that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed. During a turnaround, the pilot flying should verify the Standby Hydraulic selector position if a discrepancy is observed.

Condition	Sample value	Remarks
Standby Hydraulic switch position	24 units	Monitor
Hydraulic System A selector position	78 units	Advisory only
Cabin Pressure Controller selector position	94 units	Refer to related topic
Autopilot Channel B selector position	37 units	Advisory only

Condition	Sample value	Remarks
Hydraulic System A switch position	55 units	Monitor
Ground Proximity Monitor status message	60 units	Normal
Autothrottle annunciation	70 units	Advisory only

The Autothrottle switch position is expected to read within the sample range of 34 to 46 units during a maintenance-requested ground run. During approach, the pilot flying should brief the Window Heat advisory when conditions permit. The Pack Temperature Control annunciation that differs from the expected state requires both pilots to confirm the condition before the next phase of flight. The Autothrottle switch position is expected to read within the sample range of 61 to 73 units during takeoff. During a diversion, the Captain should confirm the Hydraulic System A indication before the next phase of flight.

10.20.6 Thrust Reverser Interfaces

Refer to the related topic for additional sample context. The Fire Detection Loop selector position that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. The Weather Radar annunciation is expected to read within the sample range of 60 to 66 units during landing.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The relief pilot will record any change in the Nosewheel Steering annunciation and advise the other pilot once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- The Primary Electrical Bus advisory that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated.
- If the Fire Detection Loop is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- The Wing Anti-Ice quantity display is expected to read within the sample range of 58 to 70 units during a diversion.
- The pilot monitoring will announce any change in the Cockpit Voice Recorder quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- The Stall Warning selector position that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed.
- The pilot flying will verify any change in the Brake Temperature Monitor selector position and advise the other pilot if the indication does not stabilize within the sample interval.

The Traffic Advisory Display advisory that differs from the expected state requires both pilots to announce the condition when conditions permit. The Brake Temperature Monitor advisory that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete. The Landing Gear Indication annunciation is expected to read within the sample range of 3 to 10 units during a turnaround.

During a maintenance-requested ground run, the pilot monitoring should verify the Autothrottle selector position before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will announce any change in the Autopilot Channel B selector position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Cockpit Voice Recorder switch position	64 units	Advisory only
Nosewheel Steering selector position	72 units	Monitor
Autothrottle selector position	46 units	Normal
Flap Position Indication selector position	53 units	Refer to related topic
Speedbrake Handle advisory	15 units	Monitor
Stall Warning annunciation	43 units	Advisory only
Autopilot Channel B switch position	54 units	Refer to related topic

10.20.7 Wing Anti-Ice Overview

The Center Tank Pumps quantity display is expected to read within the sample range of 3 to 13 units during an extended ground delay. The Flight Management Computer status message is expected to read within the sample range of 36 to 40 units during takeoff. The Pack Temperature Control quantity display is expected to read within the sample range of 98 to 108 units during landing. The Pack Temperature Control quantity display is expected to read within the sample range of 10 to 14 units during preflight. If the Hydraulic System A is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative,

continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The Brake Temperature Monitor quantity display is expected to read within the sample range of 86 to 96 units during a maintenance-requested ground run.

NOTE: The Wing Anti-Ice status message is expected to read within the sample range of 52 to 56 units during a turnaround.

NOTE: The Nosewheel Steering advisory that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The first officer will monitor any change in the Fire Detection Loop status message and advise the other pilot when the associated caution light remains illuminated.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

If the Weather Radar is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During approach, the pilot monitoring should brief the Landing Gear Indication quantity display before the next phase of flight. The Center Tank Pumps advisory that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power.

- If the Hydraulic System B is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- The captain will record any change in the Cabin Pressure Controller annunciation and advise the other pilot once the checklist item is complete.
- During cruise, the First Officer should cross-check the Traffic Advisory Display switch position when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.

10.20.8 Traffic Advisory Display Indications

The Primary Electrical Bus advisory that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will select any change in the Pack Temperature Control selector position and advise the other pilot once the checklist item is complete. The Cargo Smoke Detection indication is expected to read within the sample range of 44 to 47 units during preflight. Refer to the related topic for additional sample context.

The pilot flying will verify any change in the Standby Instruments status message and advise the other pilot when conditions permit. If the Ground Proximity Monitor is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Brake Temperature Monitor indication is expected to read within the sample range of 35 to 46 units during climb.

Condition	Sample value	Remarks
Autopilot Channel A selector position	36 units	Refer to related topic
Autopilot Channel A indication	29 units	Normal
Wing Anti-Ice switch position	36 units	Refer to related topic
Landing Gear Indication indication	20 units	Refer to related topic
Stall Warning selector position	98 units	Advisory only

If the Primary Electrical Bus is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Weather Radar annunciation that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. See 06.30.11 Standby Instruments Test.

CAUTION: During an extended ground delay, the pilot flying should select the Probe Heat status message once the checklist item is complete. The Flap Position Indication quantity display that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center.

- During engine start, the relief pilot should select the Transponder advisory when operating at a sample station without ground power.
- During a maintenance-requested ground run, the pilot flying should brief the Probe Heat switch position when operating at a sample station without ground power.
- The Autopilot Channel A selector position is expected to read within the sample range of 51 to 56 units during a diversion.
- During a diversion, the Captain should cross-check the Autopilot Channel A advisory if a discrepancy is observed.

CAUTION: The Probe Heat status message that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. The Thrust Reverser advisory is expected to read within the sample range of 24 to 33 units during parking.

CAUTION: The Engine Anti-Ice quantity display that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The pilot flying will verify any change in the Brake Temperature Monitor switch position and advise the other pilot if the indication does not stabilize within the sample interval. The pilot flying will cross-check any change in the Pack Temperature Control advisory and advise the other pilot when conditions permit.

10.20.9 Flight Management Computer Indications

During descent, the pilot flying should record the Standby Hydraulic switch position before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will confirm any change in the Probe Heat quantity display and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Cargo Smoke Detection indication	59 units	Normal
Standby Instruments annunciation	50 units	Monitor
Cockpit Voice Recorder advisory	96 units	Advisory only
Hydraulic System A status message	2 units	Refer to related topic
Landing Gear Indication status message	70 units	Refer to related topic

- If the Flight Management Computer is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.
- The Weather Radar selector position is expected to read within the sample range of 63 to 73 units during climb.
- The Hydraulic System B indication that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power.
- The Stall Warning indication is expected to read within the sample range of 60 to 72 units during a maintenance-requested ground run.
- During a diversion, the First Officer should brief the Wing Anti-Ice switch position if the indication does not stabilize within the sample interval.

- During approach, the First Officer should brief the Pack Temperature Control selector position if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Standby Hydraulic indication	87 units	Advisory only
Autothrottle status message	83 units	Advisory only
Landing Gear Indication quantity display	23 units	Refer to related topic
Fire Detection Loop advisory	57 units	Normal
Cargo Smoke Detection annunciation	92 units	Normal

NOTE: The Nosewheel Steering selector position that differs from the expected state requires the First Officer to cross-check the condition when conditions permit.

- Values in this manual are invented and must not be used for any operational purpose.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Oxygen Distribution is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- If the Standby Instruments is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- The Wing Anti-Ice switch position that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center.
- The Cockpit Voice Recorder quantity display is expected to read within the sample range of 94 to 105 units during climb.

Condition	Sample value	Remarks
Primary Electrical Bus indication	4 units	Advisory only
Hydraulic System B selector position	65 units	Advisory only
Wing Anti-Ice advisory	84 units	Monitor

10.20.10 Auxiliary Power Unit Indications

During an extended ground delay, the Captain should confirm the Autothrottle annunciation if a discrepancy is observed. The Thrust Reverser annunciation that differs from the expected state requires the Captain to select the condition if a discrepancy is observed. Refer to the related topic for additional sample context. The relief pilot will select any change in the Speedbrake Handle quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System A indication is expected to read within the sample range of 96 to 106 units during parking. Refer to the related topic for additional sample context.

- If the Wing Anti-Ice is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.
- The relief pilot will confirm any change in the Autobrake Selector annunciation and advise the other pilot when the associated caution light remains illuminated.
- The captain will record any change in the Weather Radar quantity display and advise the other pilot when operating at a sample station without ground power.

The pilot flying will brief any change in the Flight Management Computer switch position and advise the other pilot before the next phase of flight. If the Standby Instruments is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Primary Electrical Bus annunciation is expected to read within the sample range of 2 to 6 units during cruise.

- The Cabin Pressure Controller status message is expected to read within the sample range of 17 to 21 units during taxi.
- The Standby Hydraulic advisory that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated.
- The Nosewheel Steering quantity display that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated.

CAUTION: If the Center Tank Pumps is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Standby Instruments annunciation that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. During parking, both pilots should monitor the Autopilot Channel B advisory if a discrepancy is observed.

The first officer will verify any change in the Fire Detection Loop switch position and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will cross-check any change in the Primary Electrical Bus selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Standby Instruments status message is expected to read within the sample range of 37 to 49 units during a turnaround.

CAUTION: The Center Tank Pumps selector position that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power.

If the Autothrottle is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Hydraulic System B advisory is expected to read within the sample range of 68 to 80 units during a maintenance-requested ground run. If the Nosewheel Steering is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Cockpit Voice Recorder annunciation that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center.

10.20.11 Cockpit Voice Recorder Limits Display

The wording here is placeholder content shaped like a procedure, not a procedure. During cruise, the First Officer should brief the Flight Management Computer quantity display when conditions permit. The Nosewheel Steering advisory that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. During preflight, the Captain should brief the Standby Instruments selector position when the associated caution light remains illuminated. The pilot flying will record any change in the Autobrake Selector selector position and advise the other pilot before the next phase of flight. During a maintenance-requested ground run, the Captain should record the Speedbrake Handle status message before the next phase of flight.

Condition	Sample value	Remarks
Flap Position Indication quantity display	33 units	Normal
Nosewheel Steering advisory	77 units	Normal
Cabin Pressure Controller switch position	17 units	Monitor
Flap Position Indication advisory	83 units	Refer to related topic
Fuel Crossfeed switch position	49 units	Refer to related topic
Engine Anti-Ice indication	52 units	Normal

The Standby Instruments status message is expected to read within the sample range of 11 to 17 units during a diversion. The Standby Instruments annunciation is expected to read within the sample range of 29 to 32 units during engine start. If the Autopilot Channel B is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. During climb, the relief pilot should confirm the Nosewheel Steering indication if a discrepancy is observed. The Hydraulic System B advisory is expected to read within the sample range of 17 to 26

units during an extended ground delay.

CAUTION: The Ground Proximity Monitor selector position is expected to read within the sample range of 30 to 38 units during a diversion. During approach, both pilots should record the Fuel Crossfeed annunciation before the next phase of flight.

NOTE: The Fuel Crossfeed advisory is expected to read within the sample range of 87 to 95 units during landing.

The Oxygen Distribution selector position is expected to read within the sample range of 54 to 64 units during approach. Refer to the related topic for additional sample context. The relief pilot will verify any change in the Transponder indication and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

The relief pilot will confirm any change in the Speedbrake Handle advisory and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Stall Warning quantity display is expected to read within the sample range of 65 to 68 units during parking. See 10.30.5 Cabin Pressure Controller Limits Display.

- During a maintenance-requested ground run, the pilot monitoring should select the Auxiliary Power Unit advisory if the indication does not stabilize within the sample interval.
- The captain will confirm any change in the Cabin Pressure Controller status message and advise the other pilot when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During preflight, the Captain should confirm the Autopilot Channel B quantity display when conditions permit.
- During an extended ground delay, the relief pilot should monitor the Cockpit Voice Recorder quantity display if a discrepancy is observed.

CAUTION: If the Primary Electrical Bus is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

10.20.12 Window Heat Reset Guidance

During a turnaround, the relief pilot should verify the Hydraulic System B switch position before the next phase of flight. The Ground Proximity Monitor selector position is expected to read within the sample range of 9 to 13 units during approach. The pilot flying will monitor any change in the Window Heat annunciation and advise the other pilot when operating at a sample station without ground power. The Cargo Smoke Detection switch position is expected to read within the sample range of 83 to 86 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure. The Weather Radar indication that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit.

NOTE: The Landing Gear Indication indication that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Weather Radar selector position	84 units	Advisory only
Weather Radar quantity display	29 units	Normal
Speedbrake Handle switch position	73 units	Monitor
Autobrake Selector advisory	68 units	Advisory only

NOTE: If the Speedbrake Handle is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

- During approach, the pilot monitoring should select the Engine Anti-Ice switch position when the associated caution light remains illuminated.

- Refer to the related topic for additional sample context.
- Refer to the related topic for additional sample context.

10.20.13 Window Heat Test

The Hydraulic System B annunciation is expected to read within the sample range of 51 to 57 units during climb. If the Speedbrake Handle is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

CAUTION: The captain will monitor any change in the Nosewheel Steering indication and advise the other pilot if the indication does not stabilize within the sample interval.

During landing, both pilots should announce the Primary Electrical Bus status message when the associated caution light remains illuminated. The Autopilot Channel A switch position is expected to read within the sample range of 24 to 35 units during a diversion. If the Engine Anti-Ice is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

CAUTION: The Autothrottle indication that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. If the Cabin Pressure Controller is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

The Primary Electrical Bus quantity display is expected to read within the sample range of 61 to 65 units during engine start. The pilot flying will announce any change in the Probe Heat quantity display and advise the other pilot before the next phase of flight. If the Pack Temperature Control is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Wing Anti-Ice selector position is expected to read within the sample range of 8 to 18 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure. The Brake Temperature Monitor selector position is expected to read within the sample range of 68 to 76 units during climb.

NOTE: During an extended ground delay, the relief pilot should verify the Flight Management Computer advisory when conditions permit. The relief pilot will brief any change in the Hydraulic System B advisory and advise the other pilot when the associated caution light remains illuminated.

- The Autopilot Channel B advisory that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.
- The first officer will confirm any change in the Primary Electrical Bus status message and advise the other pilot if the indication does not stabilize within the sample interval.
- During landing, the pilot flying should confirm the Ground Proximity Monitor selector position when conditions permit.

CAUTION: The Weather Radar indication that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

10.20.14 Hydraulic System B Power Sources

The Hydraulic System A advisory is expected to read within the sample range of 55 to 60 units during cruise. During climb, both pilots should verify the Bleed Air Supply quantity display when the associated caution light remains illuminated. During landing, the pilot flying should verify the Cockpit Voice Recorder selector position unless directed otherwise by the Sample Operations Center.

The Oxygen Distribution advisory is expected to read within the sample range of 91 to 99 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. The Autothrottle indication that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power. If the Nosewheel Steering is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Ground Proximity Monitor is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- During parking, the relief pilot should cross-check the Transponder quantity display before the next phase of flight.
- During preflight, the relief pilot should cross-check the Standby Instruments selector position before the next phase of flight.

CAUTION: The Speedbrake Handle indication that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.

NOTE: The Ground Proximity Monitor annunciation is expected to read within the sample range of 64 to 72 units during a turnaround. The Flight Management Computer status message that differs from the expected state requires the relief pilot to record the condition before the next phase of flight.

- The Cockpit Voice Recorder indication is expected to read within the sample range of 80 to 91 units during a maintenance-requested ground run.
- The Autothrottle indication that differs from the expected state requires the First Officer to record the condition before the next phase of flight.
- The Ground Proximity Monitor selector position is expected to read within the sample range of 86 to 98 units during takeoff.

10.20.15 *Oxygen Distribution Crew Awareness*

During landing, the pilot flying should record the Nosewheel Steering indication if the indication does not stabilize within the sample interval. During a turnaround, the pilot flying should brief the Cabin Pressure Controller quantity display when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

- The Traffic Advisory Display quantity display is expected to read within the sample range of 87 to 94 units during climb.
- The Autopilot Channel B status message that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.
- The Landing Gear Indication annunciation is expected to read within the sample range of 7 to 15 units during landing.
- If the Window Heat is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

The Hydraulic System B annunciation is expected to read within the sample range of 47 to 59 units during a turnaround. The captain will record any change in the Fire Detection Loop annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Landing Gear Indication indication is expected to read within the sample range of 13 to 21 units during engine start. The captain will monitor any change in the Auxiliary Power Unit indication and advise the other pilot if the indication does not stabilize within the sample interval. The Flap Position Indication advisory is expected to read within the sample range of 55 to 62 units during descent.

If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The pilot monitoring will verify any change in the Wing Anti-Ice indication and advise the other pilot once the checklist item is complete.

The Bleed Air Supply quantity display that differs from the expected state requires the First Officer to brief the condition when conditions permit. The Thrust Reverser switch position that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. If the Traffic Advisory

Display is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Flight Management Computer switch position that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. The pilot flying will confirm any change in the Ground Proximity Monitor selector position and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Probe Heat advisory	47 units	Monitor
Nosewheel Steering quantity display	77 units	Refer to related topic
Standby Hydraulic quantity display	82 units	Refer to related topic
Oxygen Distribution status message	26 units	Advisory only
Auxiliary Power Unit status message	21 units	Normal
Cabin Pressure Controller advisory	56 units	Normal
Flight Management Computer status message	67 units	Normal

The first officer will announce any change in the Hydraulic System B indication and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will select any change in the Speedbrake Handle indication and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

During engine start, the Captain should verify the Traffic Advisory Display advisory unless directed otherwise by the Sample Operations Center. During parking, the relief pilot should select the Auxiliary Power Unit indication unless directed otherwise by the Sample Operations Center. The Oxygen Distribution indication that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. See 04.10.20 Checklist: Oxygen Distribution.

10.20.16 Brake Temperature Monitor Test

The Fire Detection Loop switch position that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will record any change in the Brake Temperature Monitor status message and advise the other pilot if a discrepancy is observed. The Oxygen Distribution quantity display that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. During engine start, the First Officer should confirm the Fuel Crossfeed selector position when conditions permit.

NOTE: The Thrust Reverser status message that differs from the expected state requires the Captain to monitor the condition before the next phase of flight.

CAUTION: The Cabin Pressure Controller advisory that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated.

If the Primary Electrical Bus is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

The relief pilot will announce any change in the Weather Radar switch position and advise the other pilot if a discrepancy is observed. The Fuel Crossfeed switch position that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight. If the Cargo Smoke Detection is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Stall Warning advisory is expected to read within the sample range of 32 to 42 units during cruise. The Fuel Crossfeed advisory is expected to read within

the sample range of 80 to 90 units during a turnaround.

- The Flap Position Indication advisory is expected to read within the sample range of 65 to 68 units during cruise.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Values in this manual are invented and must not be used for any operational purpose.
- The Cockpit Voice Recorder quantity display is expected to read within the sample range of 6 to 12 units during landing.
- If the Cargo Smoke Detection is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The first officer will select any change in the Traffic Advisory Display status message and advise the other pilot when the associated caution light remains illuminated.

The Hydraulic System A switch position that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice annunciation is expected to read within the sample range of 31 to 36 units during an extended ground delay. If the Nosewheel Steering is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

NOTE: Both pilots will verify any change in the Thrust Reverser indication and advise the other pilot when conditions permit. During an extended ground delay, the pilot flying should select the Hydraulic System B annunciation when operating at a sample station without ground power.

The relief pilot will brief any change in the Standby Instruments status message and advise the other pilot if a discrepancy is observed. The Engine Anti-Ice indication that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight. The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. The Wing Anti-Ice switch position that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated. Both pilots will record any change in the Probe Heat switch position and advise the other pilot before the next phase of flight.

10.20.17 Fuel Planning Data Table 10

The first officer will monitor any change in the Thrust Reverser status message and advise the other pilot when the associated caution light remains illuminated. During landing, the pilot monitoring should verify the Speedbrake Handle status message if a discrepancy is observed. Refer to the related topic for additional sample context. During landing, both pilots should brief the Hydraulic System B annunciation when conditions permit.

The Auxiliary Power Unit switch position that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center. If the Center Tank Pumps is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the relief pilot should verify the Fire Detection Loop selector position if the indication does not stabilize within the sample interval. If the Window Heat is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Hydraulic System B selector position is expected to read within the sample range of 77 to 86 units during engine start. Both pilots will cross-check any change in the Window Heat quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The Window Heat quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. The pilot monitoring will select any change in the Ground Proximity Monitor quantity display and advise the other pilot when operating at a sample station without ground power.

The Hydraulic System B status message that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. The Center Tank Pumps indication is expected to read within the sample range of 72 to 78 units during an extended ground delay. The captain will select any change in the Ground Proximity Monitor advisory and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots

will select any change in the Thrust Reverser annunciation and advise the other pilot once the checklist item is complete. See 09.30.6 Speedbrake Handle Test.

Condition	Sample value	Remarks
Cockpit Voice Recorder annunciation	99 units	Refer to related topic
Standby Hydraulic selector position	35 units	Refer to related topic
Autopilot Channel A switch position	91 units	Normal
Ground Proximity Monitor selector position	72 units	Monitor
Primary Electrical Bus quantity display	37 units	Normal
Probe Heat selector position	71 units	Monitor

10.30 Operation

10.30.1 Ground Proximity Monitor Limits Display

If the Flight Management Computer is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. If the Transponder is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Weather Radar selector position is expected to read within the sample range of 71 to 83 units during a turnaround. Refer to the related topic for additional sample context. If the Cargo Smoke Detection is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

The Speedbrake Handle switch position is expected to read within the sample range of 40 to 50 units during engine start. The Pack Temperature Control annunciation is expected to read within the sample range of 80 to 87 units during a maintenance-requested ground run. Refer to the related topic for additional sample context. The relief pilot will cross-check any change in the Flight Management Computer indication and advise the other pilot when conditions permit. If the Autopilot Channel A is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

- The Thrust Reverser status message that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight.
- The Speedbrake Handle selector position is expected to read within the sample range of 34 to 38 units during cruise.
- If the Window Heat is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autothrottle selector position	80 units	Monitor
Fuel Crossfeed quantity display	58 units	Advisory only
Cabin Pressure Controller advisory	56 units	Refer to related topic
Pack Temperature Control status message	33 units	Advisory only
Standby Instruments switch position	12 units	Advisory only
Cargo Smoke Detection switch position	35 units	Advisory only
Pack Temperature Control status message	1 units	Monitor

The Center Tank Pumps quantity display that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The Traffic Advisory Display selector position is expected to read within the sample range of 16 to 23 units during preflight. The Traffic Advisory Display indication that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power. The

Fuel Crossfeed quantity display is expected to read within the sample range of 28 to 34 units during approach.

If the Window Heat is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During climb, the relief pilot should select the Autothrottle indication if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will announce any change in the Stall Warning selector position and advise the other pilot when the associated caution light remains illuminated.

NOTE: If the Bleed Air Supply is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

If the Autopilot Channel A is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The relief pilot will confirm any change in the Autothrottle indication and advise the other pilot once the checklist item is complete. The Stall Warning quantity display is expected to read within the sample range of 54 to 61 units during preflight. If the Landing Gear Indication is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. During parking, the pilot monitoring should monitor the Autothrottle quantity display if a discrepancy is observed. During climb, the relief pilot should verify the Cabin Pressure Controller annunciation if the indication does not stabilize within the sample interval.

The Traffic Advisory Display indication is expected to read within the sample range of 64 to 74 units during a diversion. During landing, the Captain should brief the Standby Instruments annunciation before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Engine Anti-Ice annunciation is expected to read within the sample range of 7 to 15 units during a diversion.

10.30.2 Wing Anti-Ice Reset Guidance

During climb, the pilot monitoring should confirm the Stall Warning status message unless directed otherwise by the Sample Operations Center. During taxi, the pilot monitoring should verify the Autopilot Channel A quantity display before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will select any change in the Cabin Pressure Controller selector position and advise the other pilot once the checklist item is complete. The Fire Detection Loop annunciation is expected to read within the sample range of 6 to 10 units during cruise.

CAUTION: If the Stall Warning is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

NOTE: The Autobrake Selector status message that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.

The Cockpit Voice Recorder switch position is expected to read within the sample range of 47 to 59 units during takeoff. The first officer will verify any change in the Autopilot Channel A switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Center Tank Pumps quantity display is expected to read within the sample range of 58 to 68 units during preflight. Both pilots will announce any change in the Fire Detection Loop status message and advise the other pilot when the associated caution light remains illuminated.

CAUTION: Refer to the related topic for additional sample context.

The captain will brief any change in the Autopilot Channel B advisory and advise the other pilot when conditions permit. The Ground Proximity Monitor indication that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. During engine start, both pilots should record the Window Heat selector position if a discrepancy is observed.

- Refer to the related topic for additional sample context.
- The Auxiliary Power Unit selector position is expected to read within the sample range of 66 to 72 units during landing.
- The Fuel Crossfeed quantity display that differs from the expected state requires the relief pilot to verify the condition when conditions permit.

10.30.3 Autothrottle Power Sources

During an extended ground delay, both pilots should select the Stall Warning quantity display before the next phase of flight. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Brake Temperature Monitor annunciation	83 units	Refer to related topic
Fuel Crossfeed status message	70 units	Refer to related topic
Ground Proximity Monitor selector position	61 units	Normal
Autopilot Channel B advisory	86 units	Refer to related topic

CAUTION: During preflight, the pilot monitoring should verify the Flap Position Indication status message if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat status message that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Nosewheel Steering indication	54 units	Refer to related topic
Auxiliary Power Unit annunciation	21 units	Refer to related topic
Standby Instruments status message	44 units	Monitor

The Landing Gear Indication selector position that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. The pilot flying will select any change in the Nosewheel Steering annunciation and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. The Standby Hydraulic advisory is expected to read within the sample range of 39 to 46 units during an extended ground delay. During takeoff, the pilot flying should select the Window Heat advisory if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

10.30.4 Hydraulic System B Status Messages

If the Cargo Smoke Detection is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The relief pilot will brief any change in the Hydraulic System B selector position and advise the other pilot when conditions permit. The captain will confirm any change in the Nosewheel Steering switch position and advise the other pilot when operating at a sample station without ground power. The Bleed Air Supply indication that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed. The first officer will brief any change in the Flight Management Computer indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Fire Detection Loop status message	8 units	Monitor
Oxygen Distribution selector position	58 units	Refer to related topic
Pack Temperature Control indication	78 units	Monitor
Autobrake Selector advisory	65 units	Refer to related topic
Standby Instruments switch position	92 units	Advisory only
Ground Proximity Monitor selector position	24 units	Advisory only
Speedbrake Handle indication	46 units	Refer to related topic

NOTE: The first officer will record any change in the Transponder quantity display and advise the other pilot if a discrepancy is observed. The Cargo Smoke Detection status message is expected to read within the sample range of 64 to 75 units during a diversion.

CAUTION: If the Cabin Pressure Controller is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

CAUTION: During a turnaround, the First Officer should verify the Auxiliary Power Unit advisory before the next phase of flight. During a turnaround, the pilot monitoring should confirm the Thrust Reverser status message unless directed otherwise by the Sample Operations Center.

If the Autopilot Channel B is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will record any change in the Center Tank Pumps advisory and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Cabin Pressure Controller indication that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. The Fire Detection Loop selector position is expected to read within the sample range of 16 to 24 units during cruise.

Refer to the related topic for additional sample context. The captain will announce any change in the Hydraulic System B indication and advise the other pilot when the associated caution light remains illuminated. During descent, the Captain should monitor the Oxygen Distribution indication before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

10.30.5 Cabin Pressure Controller Limits Display

The Autopilot Channel B selector position is expected to read within the sample range of 63 to 70 units during descent. The relief pilot will announce any change in the Fire Detection Loop status message and advise the other pilot before the next phase of flight. The relief pilot will confirm any change in the Speedbrake Handle switch position and advise the other pilot if the indication does not stabilize within the sample interval. During engine start, the Captain should record the Probe Heat annunciation when conditions permit.

CAUTION: If the Window Heat is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Probe Heat annunciation	43 units	Refer to related topic
Traffic Advisory Display quantity display	23 units	Normal
Stall Warning quantity display	74 units	Normal
Autothrottle selector position	10 units	Advisory only
Fire Detection Loop annunciation	61 units	Refer to related topic

- If the Brake Temperature Monitor is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- If the Weather Radar is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- The pilot flying will confirm any change in the Flight Management Computer advisory and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The Flap Position Indication status message is expected to read within the sample range of 40 to 50 units during cruise.

- The Brake Temperature Monitor switch position is expected to read within the sample range of 41 to 53 units during a turnaround.
- The Ground Proximity Monitor indication that differs from the expected state requires the First Officer to monitor the condition if the indication does not stabilize within the sample interval.
- During descent, both pilots should select the Weather Radar selector position when conditions permit.

The Autobrake Selector selector position is expected to read within the sample range of 34 to 42 units during approach. Refer to the related topic for additional sample context. Both pilots will verify any change in the Brake Temperature Monitor selector position and advise the other pilot once the checklist item is complete. The pilot monitoring will confirm any change in the Window Heat advisory and advise the other pilot when conditions permit. If the Wing Anti-Ice is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Oxygen Distribution quantity display that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center. See 05.40.19 Stall Warning Indications.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. If the Oxygen Distribution is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

10.30.6 Fire Detection Loop Overview

The Transponder switch position is expected to read within the sample range of 89 to 95 units during a diversion. The pilot flying will cross-check any change in the Window Heat indication and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. The Standby Hydraulic advisory that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. The Standby Instruments selector position that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat selector position that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

- The Cargo Smoke Detection advisory that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power.
- During approach, the First Officer should select the Brake Temperature Monitor status message if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Cockpit Voice Recorder is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.
- If the Primary Electrical Bus is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

The Standby Hydraulic advisory is expected to read within the sample range of 14 to 21 units during an extended ground delay. The Hydraulic System A advisory that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. The Autobrake Selector quantity display is expected to read within the sample range of 43 to 55 units during parking. This text is fictional and exists only to give the prototype realistic volume and structure.

During climb, the relief pilot should announce the Stall Warning switch position if a discrepancy is observed. The Flight Management Computer annunciation is expected to read within the sample range of 53 to 58 units during engine start. During cruise, the pilot monitoring should monitor the Standby Instruments advisory if the indication does not stabilize within the sample interval. The Speedbrake Handle switch position is expected to read within the sample range of 19 to 26 units during a maintenance-requested ground run. Values in this manual are invented and

must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose.

Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The Weather Radar annunciation is expected to read within the sample range of 66 to 72 units during preflight. If the Cargo Smoke Detection is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Flight Management Computer selector position	75 units	Advisory only
Auxiliary Power Unit quantity display	80 units	Advisory only
Brake Temperature Monitor annunciation	44 units	Advisory only
Autobrake Selector indication	28 units	Normal

The Nosewheel Steering status message is expected to read within the sample range of 79 to 83 units during takeoff. The Speedbrake Handle switch position that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The Weather Radar advisory is expected to read within the sample range of 31 to 42 units during climb.

10.30.7 Standby Instruments Status Messages

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will monitor any change in the Fuel Crossfeed indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the pilot flying should monitor the Flap Position Indication advisory unless directed otherwise by the Sample Operations Center. If the Pack Temperature Control is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

- The Ground Proximity Monitor indication that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center.
- The Wing Anti-Ice status message that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated.
- The Standby Instruments annunciation is expected to read within the sample range of 88 to 91 units during descent.
- During approach, the pilot monitoring should announce the Cockpit Voice Recorder quantity display once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- The Ground Proximity Monitor status message that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center.

NOTE: During preflight, both pilots should brief the Standby Instruments status message when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

The Weather Radar status message that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. The captain will select any change in the Flight Management Computer annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Oxygen Distribution is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Center Tank Pumps indication is expected to read within the sample range of 97 to 109 units during parking. The Hydraulic System A advisory is expected to read within the sample range of 40 to 51 units during an extended ground delay. If the Traffic Advisory Display is inoperative, continue engine start only after the pilot

monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Pack Temperature Control quantity display	79 units	Monitor
Fire Detection Loop status message	18 units	Normal
Primary Electrical Bus annunciation	80 units	Monitor
Window Heat indication	11 units	Advisory only
Flight Management Computer selector position	91 units	Refer to related topic

If the Window Heat is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Standby Hydraulic annunciation is expected to read within the sample range of 64 to 76 units during a turnaround. The Weather Radar annunciation that differs from the expected state requires both pilots to record the condition when conditions permit. During landing, the First Officer should record the Ground Proximity Monitor quantity display when conditions permit.

- The Window Heat annunciation is expected to read within the sample range of 71 to 75 units during preflight.
- The Transponder switch position is expected to read within the sample range of 41 to 44 units during engine start.
- The pilot monitoring will record any change in the Thrust Reverser quantity display and advise the other pilot when the associated caution light remains illuminated.
- The Flight Management Computer annunciation is expected to read within the sample range of 53 to 64 units during preflight.
- The pilot flying will cross-check any change in the Brake Temperature Monitor selector position and advise the other pilot when conditions permit.
- If the Autobrake Selector is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector annunciation that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. The Probe Heat annunciation is expected to read within the sample range of 60 to 68 units during takeoff. Values in this manual are invented and must not be used for any operational purpose.

The Standby Instruments annunciation is expected to read within the sample range of 71 to 74 units during an extended ground delay. The Probe Heat advisory is expected to read within the sample range of 84 to 95 units during an extended ground delay. The Nosewheel Steering annunciation that differs from the expected state requires the Captain to record the condition when conditions permit. If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

10.30.8 Center Tank Pumps Interfaces

The Speedbrake Handle selector position is expected to read within the sample range of 31 to 43 units during parking. The Standby Hydraulic advisory that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power. The relief pilot will cross-check any change in the Autopilot Channel B selector position and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will cross-check any change in the Brake Temperature Monitor annunciation and advise the other pilot when conditions permit. The Standby Instruments quantity display that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.

If the Transponder is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Transponder selector position that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. If the Oxygen Distribution is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

The Oxygen Distribution selector position is expected to read within the sample range of 88 to 92 units during takeoff. The Weather Radar status message that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. During taxi, the First Officer should confirm the Hydraulic System B advisory once the checklist item is complete.

The Engine Anti-Ice annunciation that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed. During cruise, both pilots should cross-check the Standby Instruments advisory if a discrepancy is observed. The Standby Hydraulic quantity display is expected to read within the sample range of 52 to 58 units during an extended ground delay. The Fuel Crossfeed selector position that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. The first officer will verify any change in the Flap Position Indication advisory and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will confirm any change in the Autopilot Channel A indication and advise the other pilot before the next phase of flight.

Values in this manual are invented and must not be used for any operational purpose. Both pilots will verify any change in the Thrust Reverser selector position and advise the other pilot when the associated caution light remains illuminated. During takeoff, the pilot flying should monitor the Flight Management Computer selector position if a discrepancy is observed. During a maintenance-requested ground run, the Captain should monitor the Primary Electrical Bus advisory when the associated caution light remains illuminated. The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autobrake Selector selector position	21 units	Normal
Traffic Advisory Display indication	25 units	Advisory only
Cabin Pressure Controller switch position	39 units	Monitor
Pack Temperature Control indication	88 units	Advisory only
Flap Position Indication advisory	29 units	Monitor
Nosewheel Steering quantity display	10 units	Normal
Brake Temperature Monitor advisory	77 units	Monitor

The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will confirm any change in the Engine Anti-Ice advisory and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The Auxiliary Power Unit switch position that differs from the expected state requires the relief pilot to record the condition when conditions permit. The Cargo Smoke Detection advisory is expected to read within the sample range of 80 to 85 units during descent.

10.30.9 Landing Gear Indication Crew Awareness

The Ground Proximity Monitor indication is expected to read within the sample range of 9 to 12 units during taxi. The pilot flying will cross-check any change in the Thrust Reverser selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Fuel Crossfeed quantity display that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated.

The Autopilot Channel A annunciation that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated. The Center Tank Pumps annunciation that differs

from the expected state requires the Captain to monitor the condition before the next phase of flight. The Thrust Reverser status message is expected to read within the sample range of 94 to 98 units during engine start. The Autothrottle status message that differs from the expected state requires the relief pilot to record the condition when conditions permit.

If the Center Tank Pumps is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Speedbrake Handle selector position is expected to read within the sample range of 47 to 57 units during taxi. If the Primary Electrical Bus is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

During cruise, the pilot flying should monitor the Speedbrake Handle selector position before the next phase of flight. The Autothrottle indication is expected to read within the sample range of 33 to 41 units during takeoff. The Landing Gear Indication selector position is expected to read within the sample range of 42 to 54 units during climb. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure.

Values in this manual are invented and must not be used for any operational purpose. The pilot flying will verify any change in the Traffic Advisory Display advisory and advise the other pilot once the checklist item is complete. The Oxygen Distribution selector position is expected to read within the sample range of 76 to 86 units during engine start. The Engine Anti-Ice switch position is expected to read within the sample range of 42 to 47 units during taxi. The Window Heat status message is expected to read within the sample range of 72 to 84 units during cruise.

NOTE: Refer to the related topic for additional sample context.

The Nosewheel Steering annunciation is expected to read within the sample range of 76 to 88 units during engine start. The pilot monitoring will cross-check any change in the Ground Proximity Monitor status message and advise the other pilot once the checklist item is complete. During taxi, the pilot flying should brief the Flap Position Indication switch position when operating at a sample station without ground power. The Window Heat quantity display that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Autobrake Selector selector position	26 units	Monitor
Transponder switch position	87 units	Advisory only
Ground Proximity Monitor selector position	86 units	Advisory only
Autobrake Selector selector position	10 units	Refer to related topic
Transponder selector position	43 units	Normal
Fire Detection Loop switch position	69 units	Advisory only

- If the Standby Hydraulic is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- During cruise, the First Officer should cross-check the Ground Proximity Monitor indication unless directed otherwise by the Sample Operations Center.
- During parking, both pilots should brief the Nosewheel Steering quantity display if the indication does not stabilize within the sample interval.

10.30.10 Nosewheel Steering Power Sources

The Hydraulic System A status message is expected to read within the sample range of 82 to 85 units during a maintenance-requested ground run. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autobrake Selector is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Weather Radar switch position is expected to read within the sample range of 16 to

25 units during a maintenance-requested ground run. If the Landing Gear Indication is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Hydraulic System B annunciation	49 units	Normal
Speedbrake Handle annunciation	67 units	Advisory only
Probe Heat indication	64 units	Monitor
Pack Temperature Control annunciation	39 units	Advisory only

If the Transponder is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Thrust Reverser selector position that differs from the expected state requires both pilots to select the condition once the checklist item is complete. The Window Heat quantity display is expected to read within the sample range of 5 to 11 units during climb. The Fuel Crossfeed quantity display that differs from the expected state requires both pilots to brief the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

If the Speedbrake Handle is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. During approach, both pilots should brief the Fire Detection Loop status message before the next phase of flight. The Pack Temperature Control advisory that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. The captain will record any change in the Cargo Smoke Detection quantity display and advise the other pilot when the associated caution light remains illuminated. If the Cargo Smoke Detection is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Speedbrake Handle switch position that differs from the expected state requires the pilot monitoring to record the condition when the associated caution light remains illuminated.

If the Traffic Advisory Display is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Stall Warning annunciation is expected to read within the sample range of 63 to 74 units during an extended ground delay. Both pilots will select any change in the Flight Management Computer selector position and advise the other pilot if a discrepancy is observed.

The Probe Heat indication is expected to read within the sample range of 6 to 11 units during an extended ground delay. If the Window Heat is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Center Tank Pumps indication is expected to read within the sample range of 35 to 40 units during taxi. If the Autobrake Selector is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will brief any change in the Auxiliary Power Unit selector position and advise the other pilot when operating at a sample station without ground power. If the Probe Heat is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

- During descent, both pilots should monitor the Cabin Pressure Controller indication unless directed otherwise by the Sample Operations Center.
- The Hydraulic System B indication is expected to read within the sample range of 45 to 51 units during a maintenance-requested ground run.
- During a maintenance-requested ground run, the pilot monitoring should cross-check the Thrust Reverser switch position if the indication does not stabilize within the sample interval.
- The Autothrottle indication is expected to read within the sample range of 56 to 63 units during a maintenance-requested ground run.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

10.30.11 Standby Instruments Interfaces

The Center Tank Pumps status message that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete. The Fire Detection Loop selector position that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. During a maintenance-requested ground run, the pilot flying should cross-check the Auxiliary Power Unit annunciation if a discrepancy is observed. The Primary Electrical Bus indication that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed.

NOTE: The captain will record any change in the Pack Temperature Control status message and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Cabin Pressure Controller quantity display	38 units	Monitor
Brake Temperature Monitor advisory	55 units	Monitor
Ground Proximity Monitor quantity display	69 units	Advisory only

The relief pilot will brief any change in the Fuel Crossfeed selector position and advise the other pilot when conditions permit. If the Transponder is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Brake Temperature Monitor switch position that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval.

NOTE: During descent, the pilot flying should select the Standby Instruments indication when conditions permit.

- If the Autobrake Selector is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- If the Transponder is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- The Autopilot Channel B indication that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. If the Transponder is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During takeoff, the First Officer should monitor the Hydraulic System B advisory when the associated caution light remains illuminated. If the Speedbrake Handle is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Probe Heat annunciation	44 units	Advisory only
Ground Proximity Monitor quantity display	40 units	Refer to related topic
Ground Proximity Monitor quantity display	2 units	Normal
Probe Heat indication	36 units	Monitor
Primary Electrical Bus switch position	75 units	Monitor

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Primary Electrical Bus is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- The Autobrake Selector advisory that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power.

10.30.12 Fuel Crossfeed Limits Display

During approach, the Captain should brief the Weather Radar advisory before the next phase of flight. During preflight, the First Officer should confirm the Traffic Advisory Display annunciation if a discrepancy is observed. If the Hydraulic System B is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The Standby Hydraulic annunciation is expected to read within the sample range of 73 to 80 units during parking.

The Landing Gear Indication switch position that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval. During taxi, the First Officer should record the Autopilot Channel A switch position when conditions permit. During descent, the Captain should monitor the Flap Position Indication selector position once the checklist item is complete. The Thrust Reverser quantity display that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

- The Fuel Crossfeed advisory is expected to read within the sample range of 11 to 15 units during a diversion.
- If the Transponder is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- The pilot flying will verify any change in the Hydraulic System B status message and advise the other pilot when the associated caution light remains illuminated.
- If the Autopilot Channel A is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Bleed Air Supply switch position	72 units	Refer to related topic
Standby Hydraulic selector position	68 units	Monitor
Cabin Pressure Controller advisory	64 units	Monitor
Hydraulic System B indication	14 units	Normal

NOTE: If the Thrust Reverser is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. If the Window Heat is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

The pilot monitoring will select any change in the Speedbrake Handle status message and advise the other pilot when the associated caution light remains illuminated. The Landing Gear Indication annunciation is expected to read within the sample range of 35 to 41 units during descent. If the Pack Temperature Control is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

The Autopilot Channel A switch position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. During takeoff, the relief pilot should announce the Fuel Crossfeed annunciation unless directed otherwise by the Sample Operations Center. If the Weather Radar is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. During an extended ground delay, the Captain should confirm the Cabin Pressure Controller status message if a discrepancy is observed.

The captain will cross-check any change in the Flight Management Computer indication and advise the other pilot when operating at a sample station without ground power. The relief pilot will announce any change in the Oxygen Distribution quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, the Captain should brief the Cargo Smoke Detection quantity display once the checklist item is complete.

10.30.13 Wing Anti-Ice Interfaces

If the Autobrake Selector is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The relief pilot will confirm any change in the Bleed Air Supply selector position and advise the other pilot if a discrepancy is observed. The pilot monitoring will cross-check any change in the Standby Instruments status message and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: The Bleed Air Supply selector position is expected to read within the sample range of 81 to 87 units during parking. The Flight Management Computer annunciation is expected to read within the sample range of 67 to 74 units during descent.

Condition	Sample value	Remarks
Landing Gear Indication status message	82 units	Monitor
Wing Anti-Ice switch position	59 units	Advisory only
Pack Temperature Control annunciation	27 units	Refer to related topic
Window Heat advisory	69 units	Advisory only
Autopilot Channel B switch position	52 units	Monitor
Hydraulic System A quantity display	49 units	Advisory only

If the Flight Management Computer is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The relief pilot will select any change in the Wing Anti-Ice quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During a turnaround, the pilot flying should record the Autopilot Channel B advisory before the next phase of flight.

NOTE: The captain will announce any change in the Fuel Crossfeed annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

10.30.14 Oxygen Distribution Interfaces

During preflight, the First Officer should record the Hydraulic System B indication when conditions permit. The Autobrake Selector annunciation is expected to read within the sample range of 79 to 85 units during a maintenance-requested ground run. The Transponder status message that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. The relief pilot will record any change in the Standby Hydraulic annunciation and advise the other pilot before the next phase of flight.

- Refer to the related topic for additional sample context.
- Values in this manual are invented and must not be used for any operational purpose.
- During landing, the pilot monitoring should brief the Hydraulic System A selector position when the associated caution light remains illuminated.

NOTE: The Pack Temperature Control status message is expected to read within the sample range of 62 to 66 units during engine start.

- The pilot flying will announce any change in the Auxiliary Power Unit switch position and advise the other pilot before the next phase of flight.
- Both pilots will select any change in the Traffic Advisory Display advisory and advise the other pilot before the next phase of flight.
- The relief pilot will brief any change in the Fire Detection Loop selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The Autopilot Channel A annunciation is expected to read within the sample range of 12 to 16 units during a diversion.

The first officer will cross-check any change in the Pack Temperature Control quantity display and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a

procedure, not a procedure. During a turnaround, the relief pilot should verify the Hydraulic System A status message if the indication does not stabilize within the sample interval.

10.30.15 Standby Hydraulic Power Sources

The first officer will select any change in the Engine Anti-Ice selector position and advise the other pilot when the associated caution light remains illuminated. If the Autopilot Channel A is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will record any change in the Autopilot Channel A switch position and advise the other pilot before the next phase of flight. Both pilots will verify any change in the Thrust Reverser indication and advise the other pilot before the next phase of flight. The first officer will record any change in the Speedbrake Handle annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. During engine start, the First Officer should monitor the Window Heat selector position unless directed otherwise by the Sample Operations Center.

If the Center Tank Pumps is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Cockpit Voice Recorder selector position is expected to read within the sample range of 28 to 33 units during takeoff. If the Standby Instruments is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

The Flap Position Indication status message is expected to read within the sample range of 63 to 69 units during landing. The Center Tank Pumps selector position is expected to read within the sample range of 3 to 11 units during a diversion. During an extended ground delay, both pilots should select the Nosewheel Steering quantity display when the associated caution light remains illuminated. During a diversion, the pilot flying should cross-check the Window Heat annunciation when the associated caution light remains illuminated. The Cockpit Voice Recorder quantity display that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

If the Cockpit Voice Recorder is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

During preflight, the First Officer should confirm the Cockpit Voice Recorder status message when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The pilot flying will record any change in the Stall Warning annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

- If the Auxiliary Power Unit is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- The Oxygen Distribution annunciation that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed.
- During preflight, both pilots should confirm the Fuel Crossfeed status message when conditions permit.

During parking, the First Officer should confirm the Autopilot Channel A switch position once the checklist item is complete. The Probe Heat annunciation that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete. During descent, the pilot monitoring should brief the Traffic Advisory Display advisory when operating at a sample station without ground power. During preflight, both pilots should announce the Hydraulic System B indication once the checklist item is complete. During descent, both pilots should record the Fire Detection Loop annunciation when operating at a sample station without ground power. The Center Tank Pumps advisory that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete.

The first officer will verify any change in the Stall Warning selector position and advise the other pilot when operating at a sample station without ground power. During landing, the pilot monitoring should select the Autobrake Selector quantity display when the associated caution light remains illuminated. The Oxygen Distribution indication that differs

from the expected state requires the pilot flying to select the condition if a discrepancy is observed. The Hydraulic System B switch position is expected to read within the sample range of 95 to 106 units during an extended ground delay. If the Brake Temperature Monitor is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. During a diversion, the First Officer should cross-check the Cockpit Voice Recorder indication when the associated caution light remains illuminated.

10.30.16 Transponder Indications

The Speedbrake Handle selector position is expected to read within the sample range of 45 to 56 units during landing. If the Autopilot Channel A is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Fuel Crossfeed status message is expected to read within the sample range of 40 to 46 units during preflight.

NOTE: If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Oxygen Distribution quantity display	89 units	Normal
Flight Management Computer switch position	39 units	Refer to related topic
Transponder quantity display	36 units	Monitor
Cockpit Voice Recorder indication	77 units	Normal
Bleed Air Supply quantity display	16 units	Normal
Ground Proximity Monitor selector position	86 units	Monitor

Condition	Sample value	Remarks
Autobrake Selector advisory	2 units	Monitor
Brake Temperature Monitor indication	98 units	Advisory only
Center Tank Pumps annunciation	13 units	Monitor

- If the Primary Electrical Bus is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- The captain will cross-check any change in the Cockpit Voice Recorder selector position and advise the other pilot once the checklist item is complete.
- Both pilots will announce any change in the Brake Temperature Monitor indication and advise the other pilot once the checklist item is complete.
- The pilot flying will select any change in the Speedbrake Handle quantity display and advise the other pilot before the next phase of flight.
- The pilot flying will brief any change in the Landing Gear Indication quantity display and advise the other pilot when operating at a sample station without ground power.

During engine start, the pilot flying should cross-check the Wing Anti-Ice status message before the next phase of flight. The Nosewheel Steering advisory is expected to read within the sample range of 60 to 66 units during parking. The captain will cross-check any change in the Transponder annunciation and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Traffic Advisory Display advisory is expected to read within the sample range of 18 to 24 units during a turnaround.

- If the Autopilot Channel A is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

- The Cockpit Voice Recorder advisory is expected to read within the sample range of 98 to 108 units during takeoff.
- During engine start, the pilot monitoring should record the Ground Proximity Monitor quantity display when the associated caution light remains illuminated.

Chapter 11 Systems: Landing Gear and Brakes

11.10 Description

11.10.1 Autopilot Channel A Crew Awareness

Refer to the related topic for additional sample context. The Hydraulic System B switch position is expected to read within the sample range of 2 to 11 units during a turnaround. If the Traffic Advisory Display is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

The Fire Detection Loop switch position is expected to read within the sample range of 16 to 19 units during taxi. The Traffic Advisory Display annunciation that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. The Standby Hydraulic advisory is expected to read within the sample range of 61 to 73 units during descent. The captain will monitor any change in the Stall Warning status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat selector position is expected to read within the sample range of 42 to 47 units during a turnaround.

Condition	Sample value	Remarks
Auxiliary Power Unit status message	37 units	Refer to related topic
Hydraulic System B advisory	26 units	Advisory only
Cargo Smoke Detection selector position	97 units	Normal
Autopilot Channel B quantity display	62 units	Monitor
Bleed Air Supply annunciation	87 units	Normal

The Hydraulic System B indication that differs from the expected state requires both pilots to confirm the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. If the Stall Warning is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. During an extended ground delay, the Captain should cross-check the Window Heat switch position unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. The Wing Anti-Ice indication is expected to read within the sample range of 62 to 73 units during parking. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

- The relief pilot will record any change in the Speedbrake Handle indication and advise the other pilot when the associated caution light remains illuminated.
- During parking, the First Officer should announce the Weather Radar advisory when conditions permit.
- The captain will verify any change in the Nosewheel Steering quantity display and advise the other pilot when conditions permit.
- If the Cabin Pressure Controller is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.
- During takeoff, the Captain should select the Autopilot Channel A advisory once the checklist item is complete.
- If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

11.10.2 Window Heat Status Messages

The Autopilot Channel B switch position that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. The Probe Heat status message is expected to read within the

sample range of 4 to 16 units during landing. The Speedbrake Handle switch position is expected to read within the sample range of 87 to 97 units during landing. If the Fire Detection Loop is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. During a maintenance-requested ground run, the First Officer should brief the Nosewheel Steering status message when conditions permit. During a maintenance-requested ground run, the pilot flying should confirm the Oxygen Distribution switch position when conditions permit.

The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection advisory that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated. The Autobrake Selector indication is expected to read within the sample range of 2 to 7 units during takeoff. The Standby Instruments status message is expected to read within the sample range of 87 to 92 units during approach.

CAUTION: Refer to the related topic for additional sample context. The Standby Hydraulic switch position that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. The Auxiliary Power Unit status message is expected to read within the sample range of 83 to 95 units during a turnaround. The Ground Proximity Monitor indication is expected to read within the sample range of 69 to 79 units during cruise. The captain will verify any change in the Window Heat indication and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Hydraulic System A annunciation is expected to read within the sample range of 80 to 91 units during climb. If the Autothrottle is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. Both pilots will select any change in the Flap Position Indication selector position and advise the other pilot when conditions permit.

The Brake Temperature Monitor status message is expected to read within the sample range of 86 to 93 units during taxi. The Nosewheel Steering indication that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. Both pilots will record any change in the Hydraulic System B selector position and advise the other pilot if a discrepancy is observed. The Bleed Air Supply selector position is expected to read within the sample range of 80 to 89 units during climb. The Ground Proximity Monitor indication is expected to read within the sample range of 46 to 57 units during descent.

If the Weather Radar is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. During a diversion, the pilot flying should select the Autothrottle selector position when the associated caution light remains illuminated. The pilot monitoring will verify any change in the Flap Position Indication status message and advise the other pilot if a discrepancy is observed. The pilot monitoring will verify any change in the Pack Temperature Control indication and advise the other pilot when conditions permit. The first officer will cross-check any change in the Traffic Advisory Display advisory and advise the other pilot when the associated caution light remains illuminated.

11.10.3 Cargo Smoke Detection Reset Guidance

If the Speedbrake Handle is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During climb, the pilot flying should confirm the Autobrake Selector switch position if a discrepancy is observed. The Cockpit Voice Recorder indication is expected to read within the sample range of 75 to 84 units during descent.

If the Thrust Reverser is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Cabin Pressure Controller indication that differs from the expected state requires the pilot flying to select the condition before the next phase of flight. During preflight, the relief pilot should brief the Weather Radar selector position when operating at a sample station without ground power.

CAUTION: If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

During taxi, the pilot monitoring should confirm the Oxygen Distribution selector position when operating at a sample station without ground power. During engine start, the pilot flying should brief the Flight Management Computer status message once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. The Brake Temperature Monitor indication that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power.

CAUTION: The Probe Heat indication is expected to read within the sample range of 71 to 74 units during climb.

If the Flight Management Computer is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Brake Temperature Monitor status message is expected to read within the sample range of 6 to 9 units during parking. The wording here is placeholder content shaped like a procedure, not a procedure.

11.10.4 Autobrake Selector Interfaces

The Brake Temperature Monitor status message that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. The Hydraulic System A selector position is expected to read within the sample range of 88 to 96 units during parking. The Flap Position Indication indication that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed. During cruise, the pilot flying should record the Bleed Air Supply indication when the associated caution light remains illuminated. If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Window Heat annunciation and advise the other pilot when conditions permit.

- The first officer will record any change in the Autopilot Channel A switch position and advise the other pilot when conditions permit.
- The Landing Gear Indication annunciation that differs from the expected state requires both pilots to select the condition when conditions permit.
- During approach, the pilot monitoring should cross-check the Flap Position Indication annunciation if a discrepancy is observed.
- The Auxiliary Power Unit status message is expected to read within the sample range of 98 to 101 units during takeoff.
- During a diversion, the Captain should announce the Standby Hydraulic selector position unless directed otherwise by the Sample Operations Center.

If the Pack Temperature Control is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Transponder is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Standby Hydraulic quantity display is expected to read within the sample range of 49 to 60 units during taxi. If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Oxygen Distribution selector position is expected to read within the sample range of 58 to 62 units during preflight.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: During engine start, the Captain should announce the Nosewheel Steering quantity display if the indication does not stabilize within the sample interval.

The pilot flying will brief any change in the Center Tank Pumps indication and advise the other pilot once the checklist item is complete. The first officer will announce any change in the Pack Temperature Control annunciation and advise

the other pilot if a discrepancy is observed. The Wing Anti-Ice switch position that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center. The pilot flying will record any change in the Primary Electrical Bus selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will select any change in the Autobrake Selector quantity display and advise the other pilot when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

During cruise, the pilot flying should select the Auxiliary Power Unit quantity display when conditions permit. The Center Tank Pumps advisory is expected to read within the sample range of 4 to 16 units during landing. If the Landing Gear Indication is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During cruise, the relief pilot should monitor the Cabin Pressure Controller indication once the checklist item is complete.

Refer to the related topic for additional sample context. The Speedbrake Handle status message is expected to read within the sample range of 68 to 75 units during descent. If the Window Heat is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

During taxi, the pilot flying should cross-check the Nosewheel Steering selector position when conditions permit. The pilot monitoring will select any change in the Flap Position Indication status message and advise the other pilot when operating at a sample station without ground power. During taxi, both pilots should record the Bleed Air Supply quantity display before the next phase of flight. During descent, the pilot monitoring should verify the Primary Electrical Bus indication if a discrepancy is observed. During a turnaround, the relief pilot should confirm the Hydraulic System A annunciation before the next phase of flight.

11.10.5 Cargo Smoke Detection Crew Awareness

During a turnaround, the relief pilot should select the Ground Proximity Monitor annunciation once the checklist item is complete. The pilot monitoring will select any change in the Ground Proximity Monitor indication and advise the other pilot before the next phase of flight. The Probe Heat status message that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. The Fire Detection Loop switch position is expected to read within the sample range of 6 to 17 units during parking.

If the Thrust Reverser is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Flap Position Indication selector position is expected to read within the sample range of 19 to 25 units during landing. Both pilots will brief any change in the Standby Instruments quantity display and advise the other pilot when operating at a sample station without ground power. The Stall Warning selector position that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed. The Center Tank Pumps quantity display is expected to read within the sample range of 6 to 14 units during an extended ground delay.

- The Flap Position Indication advisory is expected to read within the sample range of 50 to 55 units during taxi.
- The Brake Temperature Monitor indication is expected to read within the sample range of 66 to 73 units during preflight.
- The Standby Instruments selector position is expected to read within the sample range of 93 to 102 units during a diversion.
- The Pack Temperature Control switch position that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.

Refer to the related topic for additional sample context. If the Landing Gear Indication is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Wing Anti-Ice advisory is expected to read within the sample range of 29 to 39 units during a diversion. This text is fictional and exists only to give the prototype realistic volume and structure. See 01.10.5 Organization Topic 4.

NOTE: The Brake Temperature Monitor switch position is expected to read within the sample range of 9 to 21 units during climb. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Speedbrake Handle annunciation	74 units	Refer to related topic
Cabin Pressure Controller advisory	61 units	Monitor
Cargo Smoke Detection annunciation	46 units	Monitor

11.10.6 Transponder Interfaces

Values in this manual are invented and must not be used for any operational purpose. During preflight, both pilots should monitor the Thrust Reverser selector position once the checklist item is complete. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. The Cockpit Voice Recorder selector position that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete. The Standby Instruments switch position is expected to read within the sample range of 58 to 64 units during a maintenance-requested ground run.

- If the Oxygen Distribution is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a diversion, the Captain should verify the Landing Gear Indication advisory when the associated caution light remains illuminated.
- If the Cockpit Voice Recorder is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.
- The Weather Radar annunciation is expected to read within the sample range of 39 to 48 units during descent.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The Bleed Air Supply status message is expected to read within the sample range of 25 to 34 units during engine start.

Condition	Sample value	Remarks
Ground Proximity Monitor switch position	68 units	Refer to related topic
Probe Heat annunciation	95 units	Normal
Pack Temperature Control switch position	22 units	Refer to related topic
Flight Management Computer advisory	95 units	Advisory only

NOTE: During takeoff, the pilot flying should record the Speedbrake Handle switch position when the associated caution light remains illuminated. The Fire Detection Loop status message is expected to read within the sample range of 19 to 30 units during parking.

- If the Fire Detection Loop is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- The Stall Warning selector position that differs from the expected state requires both pilots to select the condition once the checklist item is complete.
- If the Probe Heat is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

- The relief pilot will confirm any change in the Cockpit Voice Recorder switch position and advise the other pilot once the checklist item is complete.

The Standby Instruments advisory that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. The Brake Temperature Monitor indication is expected to read within the sample range of 68 to 76 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. If the Autobrake Selector is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

11.10.7 Probe Heat Test

The first officer will announce any change in the Brake Temperature Monitor advisory and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The captain will announce any change in the Fuel Crossfeed annunciation and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context.

During a turnaround, both pilots should cross-check the Autopilot Channel B annunciation before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System B status message that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit. The Ground Proximity Monitor advisory that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval.

NOTE: Refer to the related topic for additional sample context.

The Autopilot Channel B selector position that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. Both pilots will select any change in the Traffic Advisory Display advisory and advise the other pilot before the next phase of flight. The Autothrottle annunciation is expected to read within the sample range of 38 to 48 units during takeoff.

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will announce any change in the Center Tank Pumps switch position and advise the other pilot when conditions permit.

NOTE: During taxi, the Captain should record the Landing Gear Indication status message when the associated caution light remains illuminated.

11.10.8 Landing Gear Indication Crew Awareness

If the Auxiliary Power Unit is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Cockpit Voice Recorder annunciation that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated. The pilot monitoring will record any change in the Hydraulic System B status message and advise the other pilot when operating at a sample station without ground power. The Ground Proximity Monitor status message that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete.

The captain will select any change in the Flight Management Computer annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: Refer to the related topic for additional sample context. During taxi, the pilot flying should record the Oxygen Distribution indication when conditions permit. During a turnaround, both pilots should verify the Flight Management Computer selector position if a discrepancy is observed.

If the Brake Temperature Monitor is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. If the Transponder is inoperative, continue climb only after the pilot flying has reviewed

the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Stall Warning indication that differs from the expected state requires both pilots to record the condition once the checklist item is complete. The Autothrottle status message that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight.

- The Cabin Pressure Controller selector position that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center.
- If the Center Tank Pumps is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.
- The Flap Position Indication switch position is expected to read within the sample range of 20 to 30 units during a diversion.
- The Ground Proximity Monitor switch position that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval.
- If the Standby Hydraulic is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- During descent, both pilots should brief the Autothrottle annunciation if the indication does not stabilize within the sample interval.
- During an extended ground delay, the pilot monitoring should brief the Cargo Smoke Detection indication if a discrepancy is observed.
- The Window Heat advisory that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight.

CAUTION: Refer to the related topic for additional sample context.

11.10.9 Stall Warning Power Sources

During cruise, the Captain should select the Primary Electrical Bus quantity display unless directed otherwise by the Sample Operations Center. If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The captain will verify any change in the Hydraulic System B indication and advise the other pilot when operating at a sample station without ground power. If the Standby Instruments is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

If the Autobrake Selector is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the relief pilot should confirm the Cockpit Voice Recorder switch position when operating at a sample station without ground power. The Standby Hydraulic advisory is expected to read within the sample range of 91 to 96 units during taxi.

CAUTION: During a turnaround, the Captain should cross-check the Autobrake Selector switch position when conditions permit. The relief pilot will record any change in the Cargo Smoke Detection selector position and advise the other pilot when the associated caution light remains illuminated.

The Pack Temperature Control status message that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. If the Ground Proximity Monitor is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Cockpit Voice Recorder indication that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated. The pilot flying will monitor any change in the Standby Hydraulic advisory and advise the other pilot before the next phase of flight. The Landing Gear Indication indication that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Hydraulic System B advisory	55 units	Refer to related topic
Autothrottle switch position	65 units	Refer to related topic
Cockpit Voice Recorder quantity display	17 units	Refer to related topic

11.10.10 Autothrottle Status Messages

The Center Tank Pumps status message that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

During parking, the First Officer should confirm the Standby Instruments quantity display when operating at a sample station without ground power. Refer to the related topic for additional sample context. If the Stall Warning is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During taxi, the pilot monitoring should select the Brake Temperature Monitor advisory once the checklist item is complete. The captain will announce any change in the Flight Management Computer switch position and advise the other pilot when the associated caution light remains illuminated.

The Pack Temperature Control status message is expected to read within the sample range of 60 to 69 units during descent. The relief pilot will brief any change in the Speedbrake Handle switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Fuel Crossfeed is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

If the Flap Position Indication is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During approach, the Captain should confirm the Oxygen Distribution quantity display once the checklist item is complete. The relief pilot will verify any change in the Probe Heat indication and advise the other pilot before the next phase of flight.

- The Thrust Reverser status message that differs from the expected state requires the First Officer to announce the condition before the next phase of flight.
- The Cabin Pressure Controller annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Values in this manual are invented and must not be used for any operational purpose.
- The Traffic Advisory Display switch position is expected to read within the sample range of 36 to 47 units during takeoff.
- The first officer will verify any change in the Bleed Air Supply selector position and advise the other pilot when the associated caution light remains illuminated.
- If the Standby Hydraulic is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- The Speedbrake Handle status message that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Traffic Advisory Display quantity display that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval. The first officer will select any change in the Weather Radar status message and advise the other pilot once the checklist item is complete.

NOTE: Both pilots will record any change in the Cargo Smoke Detection switch position and advise the other pilot if a discrepancy is observed.

11.10.11 Cabin Pressure Controller Interfaces

The Engine Anti-Ice status message that differs from the expected state requires the First Officer to record the condition when conditions permit. During takeoff, the First Officer should monitor the Primary Electrical Bus quantity display before the next phase of flight. If the Thrust Reverser is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. During takeoff, the Captain should monitor the Fuel Crossfeed quantity display if the indication does not stabilize within the sample interval. During a diversion, the relief pilot should verify the Ground Proximity Monitor advisory when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

Refer to the related topic for additional sample context. The Fire Detection Loop status message is expected to read within the sample range of 46 to 56 units during climb. This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System A is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Autothrottle selector position is expected to read within the sample range of 2 to 11 units during taxi. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Cabin Pressure Controller quantity display	63 units	Normal
Standby Hydraulic indication	82 units	Monitor
Bleed Air Supply switch position	35 units	Advisory only
Cabin Pressure Controller annunciation	78 units	Refer to related topic
Cabin Pressure Controller switch position	64 units	Monitor
Cabin Pressure Controller quantity display	11 units	Normal

Condition	Sample value	Remarks
Hydraulic System A quantity display	40 units	Advisory only
Pack Temperature Control status message	38 units	Advisory only
Nosewheel Steering advisory	25 units	Refer to related topic

NOTE: The first officer will cross-check any change in the Cabin Pressure Controller annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will verify any change in the Flap Position Indication indication and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Autopilot Channel A advisory	75 units	Normal
Weather Radar indication	35 units	Normal
Wing Anti-Ice indication	47 units	Normal
Cockpit Voice Recorder annunciation	67 units	Normal
Fuel Crossfeed annunciation	12 units	Monitor
Bleed Air Supply status message	98 units	Refer to related topic

During approach, the Captain should cross-check the Auxiliary Power Unit annunciation when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Transponder quantity display that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval.

11.10.12 Hydraulic System B Indications

During climb, the Captain should cross-check the Flight Management Computer status message unless directed otherwise by the Sample Operations Center. During parking, the pilot flying should select the Probe Heat advisory when conditions permit. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

CAUTION: The relief pilot will cross-check any change in the Brake Temperature Monitor indication and advise the other pilot when conditions permit.

The Fire Detection Loop quantity display is expected to read within the sample range of 65 to 69 units during a diversion. During a turnaround, the relief pilot should select the Ground Proximity Monitor advisory when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. If the Window Heat is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Wing Anti-Ice advisory that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. See 05.60.15 Center Tank Pumps Interfaces.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

11.10.13 Cockpit Voice Recorder Status Messages

During parking, the Captain should verify the Engine Anti-Ice selector position when operating at a sample station without ground power. The Stall Warning selector position that differs from the expected state requires the First Officer to cross-check the condition when operating at a sample station without ground power. The Autobrake Selector selector position is expected to read within the sample range of 7 to 19 units during an extended ground delay. The Cabin Pressure Controller selector position is expected to read within the sample range of 32 to 40 units during cruise.

During approach, the pilot monitoring should announce the Fire Detection Loop selector position when the associated caution light remains illuminated. The Primary Electrical Bus status message is expected to read within the sample range of 49 to 56 units during takeoff. The pilot monitoring will monitor any change in the Window Heat advisory and advise the other pilot when conditions permit. During approach, the pilot flying should monitor the Weather Radar annunciation if the indication does not stabilize within the sample interval.

- Values in this manual are invented and must not be used for any operational purpose.
- The Bleed Air Supply indication is expected to read within the sample range of 86 to 90 units during climb.
- During a turnaround, the First Officer should brief the Standby Hydraulic switch position when operating at a sample station without ground power.

CAUTION: If the Auxiliary Power Unit is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

The Hydraulic System B selector position that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. The relief pilot will monitor any change in the Fire Detection Loop selector position and advise the other pilot before the next phase of flight. The Standby Instruments advisory that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated. If the Transponder is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Window Heat annunciation is expected to read within the sample range of 89 to 98 units during a turnaround. If the Standby Instruments is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
-----------	--------------	---------

Landing Gear Indication switch position	13 units	Normal
Oxygen Distribution advisory	72 units	Monitor
Landing Gear Indication indication	41 units	Refer to related topic
Wing Anti-Ice selector position	78 units	Normal
Autopilot Channel A annunciation	47 units	Monitor
Flight Management Computer indication	33 units	Refer to related topic
Flap Position Indication annunciation	13 units	Normal

11.10.14 Stall Warning Test

The Wing Anti-Ice selector position is expected to read within the sample range of 32 to 35 units during climb. The Flap Position Indication status message that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. The captain will monitor any change in the Ground Proximity Monitor advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Cabin Pressure Controller selector position is expected to read within the sample range of 78 to 83 units during approach. The captain will confirm any change in the Weather Radar status message and advise the other pilot when conditions permit. During a diversion, the Captain should record the Hydraulic System A switch position once the checklist item is complete. The Thrust Reverser advisory is expected to read within the sample range of 86 to 91 units during descent.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Standby Instruments is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will record any change in the Center Tank Pumps status message and advise the other pilot before the next phase of flight.

NOTE: The Cockpit Voice Recorder annunciation that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power.

NOTE: The first officer will confirm any change in the Engine Anti-Ice annunciation and advise the other pilot when the associated caution light remains illuminated.

The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel B indication that differs from the expected state requires the Captain to cross-check the condition when conditions permit. The captain will brief any change in the Stall Warning status message and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. During descent, the relief pilot should announce the Nosewheel Steering advisory when operating at a sample station without ground power.

11.10.15 Cockpit Voice Recorder Power Sources

If the Autothrottle is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The Traffic Advisory Display quantity display is expected to read within the sample range of 81 to 87 units during a diversion.

If the Oxygen Distribution is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Fuel Crossfeed advisory that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight. If the Weather Radar is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

- If the Engine Anti-Ice is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

- Both pilots will brief any change in the Cockpit Voice Recorder switch position and advise the other pilot when operating at a sample station without ground power.
- The pilot monitoring will verify any change in the Bleed Air Supply indication and advise the other pilot once the checklist item is complete.
- The Standby Instruments switch position is expected to read within the sample range of 3 to 6 units during a diversion.
- The Brake Temperature Monitor switch position that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.
- The Bleed Air Supply annunciation that differs from the expected state requires both pilots to select the condition when conditions permit.

CAUTION: If the Primary Electrical Bus is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Standby Hydraulic switch position that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. Refer to the related topic for additional sample context.

The Autothrottle selector position is expected to read within the sample range of 80 to 87 units during landing. The Standby Hydraulic annunciation that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. The captain will record any change in the Standby Instruments annunciation and advise the other pilot before the next phase of flight.

- The Autopilot Channel A indication is expected to read within the sample range of 74 to 84 units during engine start.
- Refer to the related topic for additional sample context.
- If the Thrust Reverser is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.
- The Flight Management Computer quantity display is expected to read within the sample range of 24 to 36 units during taxi.
- If the Standby Instruments is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.
- The relief pilot will verify any change in the Autopilot Channel B annunciation and advise the other pilot when conditions permit.

This text is fictional and exists only to give the prototype realistic volume and structure. The Center Tank Pumps indication is expected to read within the sample range of 52 to 63 units during a turnaround. The Window Heat status message that differs from the expected state requires the First Officer to announce the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

NOTE: During a diversion, the First Officer should announce the Brake Temperature Monitor quantity display when conditions permit. The Brake Temperature Monitor advisory that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval.

11.10.16 Oxygen Distribution Status Messages

If the Nosewheel Steering is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Standby Instruments advisory is expected to read within the sample range of 19 to 29 units during parking. If the Window Heat is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. During a maintenance-requested ground run, the Captain should confirm the Landing Gear Indication quantity display before the next phase of flight. The wording here is placeholder content shaped like a

procedure, not a procedure.

The first officer will cross-check any change in the Autothrottle indication and advise the other pilot if a discrepancy is observed. If the Transponder is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. During climb, the First Officer should brief the Wing Anti-Ice selector position before the next phase of flight. The pilot flying will confirm any change in the Autopilot Channel B selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Wing Anti-Ice is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The relief pilot will brief any change in the Flight Management Computer selector position and advise the other pilot if the indication does not stabilize within the sample interval.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a diversion, the Captain should confirm the Probe Heat status message if a discrepancy is observed.
- The Flight Management Computer advisory is expected to read within the sample range of 70 to 80 units during cruise.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The relief pilot will announce any change in the Brake Temperature Monitor status message and advise the other pilot once the checklist item is complete.

NOTE: The Flap Position Indication quantity display that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval.

The Speedbrake Handle quantity display that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed. If the Flight Management Computer is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Auxiliary Power Unit indication that differs from the expected state requires the relief pilot to verify the condition if a discrepancy is observed. The Stall Warning quantity display that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated.

The Autopilot Channel A indication that differs from the expected state requires the Captain to brief the condition before the next phase of flight. If the Thrust Reverser is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. During a maintenance-requested ground run, the Captain should brief the Probe Heat selector position if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Bleed Air Supply annunciation	69 units	Advisory only
Pack Temperature Control status message	50 units	Advisory only
Hydraulic System A switch position	90 units	Normal
Center Tank Pumps annunciation	80 units	Normal
Thrust Reverser quantity display	96 units	Monitor
Hydraulic System B indication	32 units	Monitor
Window Heat status message	36 units	Advisory only

11.20 Controls and Indicators

11.20.1 Oxygen Distribution Crew Awareness

If the Flight Management Computer is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue a turnaround only after both

pilots has reviewed the associated sample guidance. During cruise, the relief pilot should brief the Window Heat annunciation when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Fire Detection Loop quantity display	86 units	Monitor
Hydraulic System B status message	68 units	Refer to related topic
Autopilot Channel A selector position	42 units	Advisory only
Hydraulic System B status message	55 units	Monitor

The Standby Hydraulic selector position is expected to read within the sample range of 8 to 19 units during descent. This text is fictional and exists only to give the prototype realistic volume and structure. During landing, the pilot flying should cross-check the Engine Anti-Ice annunciation when conditions permit.

NOTE: The Pack Temperature Control annunciation is expected to read within the sample range of 82 to 91 units during descent.

Condition	Sample value	Remarks
Primary Electrical Bus status message	49 units	Normal
Speedbrake Handle advisory	32 units	Advisory only
Engine Anti-Ice advisory	37 units	Monitor
Fire Detection Loop advisory	28 units	Monitor
Window Heat annunciation	29 units	Refer to related topic

Condition	Sample value	Remarks
Standby Hydraulic selector position	11 units	Refer to related topic
Cabin Pressure Controller switch position	85 units	Refer to related topic
Standby Instruments switch position	57 units	Refer to related topic
Flap Position Indication selector position	5 units	Refer to related topic

NOTE: The relief pilot will cross-check any change in the Speedbrake Handle indication and advise the other pilot before the next phase of flight. The Probe Heat switch position that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit.

Values in this manual are invented and must not be used for any operational purpose. The Center Tank Pumps switch position is expected to read within the sample range of 46 to 51 units during a maintenance-requested ground run. The Autopilot Channel A annunciation that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. The Flight Management Computer quantity display is expected to read within the sample range of 95 to 98 units during an extended ground delay. During taxi, both pilots should confirm the Autobrake Selector status message once the checklist item is complete. During a maintenance-requested ground run, the pilot flying should brief the Cabin Pressure Controller advisory when the associated caution light remains illuminated.

11.20.2 Ground Proximity Monitor Normal Operation

The Stall Warning indication is expected to read within the sample range of 45 to 55 units during taxi. The first officer will monitor any change in the Nosewheel Steering annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The captain will brief any change in the Standby Hydraulic quantity display and advise the other pilot when the associated caution light remains illuminated. The Flap Position Indication indication is expected to read within the sample range of 44 to 53 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Window Heat annunciation	46 units	Refer to related topic
Ground Proximity Monitor annunciation	33 units	Monitor
Transponder status message	9 units	Monitor
Autobrake Selector switch position	29 units	Advisory only
Cabin Pressure Controller quantity display	71 units	Monitor
Cargo Smoke Detection status message	33 units	Refer to related topic

CAUTION: The pilot monitoring will record any change in the Flight Management Computer advisory and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Wing Anti-Ice advisory	39 units	Advisory only
Oxygen Distribution status message	5 units	Normal
Cabin Pressure Controller quantity display	65 units	Refer to related topic
Standby Hydraulic quantity display	79 units	Normal

CAUTION: The Flap Position Indication indication is expected to read within the sample range of 22 to 26 units during descent. The Center Tank Pumps quantity display that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center.

During a maintenance-requested ground run, the First Officer should verify the Landing Gear Indication switch position when operating at a sample station without ground power. The captain will record any change in the Flap Position Indication indication and advise the other pilot when conditions permit. During preflight, the First Officer should select the Center Tank Pumps advisory if the indication does not stabilize within the sample interval. If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

The Brake Temperature Monitor annunciation that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. During a diversion, the relief pilot should monitor the Bleed Air Supply status message before the next phase of flight. The Flight Management Computer quantity display that differs from the expected state requires the Captain to announce the condition once the checklist item is complete. The Autobrake Selector selector position that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval. The Traffic Advisory Display advisory that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Ground Proximity Monitor selector position	30 units	Normal
Autobrake Selector quantity display	91 units	Normal
Window Heat annunciation	64 units	Refer to related topic
Traffic Advisory Display quantity display	17 units	Refer to related topic

11.20.3 Speedbrake Handle Crew Awareness

The captain will monitor any change in the Wing Anti-Ice status message and advise the other pilot if the indication does not stabilize within the sample interval. During parking, the First Officer should cross-check the Pack Temperature Control indication when conditions permit. The captain will verify any change in the Autothrottle quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

Values in this manual are invented and must not be used for any operational purpose. During a turnaround, the First Officer should verify the Speedbrake Handle annunciation if a discrepancy is observed. The Fire Detection Loop advisory is expected to read within the sample range of 88 to 97 units during climb. The Hydraulic System A indication that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Weather Radar quantity display	23 units	Normal
Brake Temperature Monitor switch position	79 units	Advisory only
Ground Proximity Monitor annunciation	40 units	Advisory only
Primary Electrical Bus selector position	44 units	Monitor

The Auxiliary Power Unit annunciation is expected to read within the sample range of 5 to 13 units during a diversion. The Autopilot Channel A selector position is expected to read within the sample range of 3 to 6 units during engine start. The first officer will verify any change in the Window Heat status message and advise the other pilot when conditions permit. The pilot monitoring will verify any change in the Flight Management Computer indication and advise the other pilot when the associated caution light remains illuminated. During descent, the First Officer should record the Transponder selector position when conditions permit.

The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. The Cockpit Voice Recorder advisory is expected to read within the sample range of 86 to 90 units during taxi. The Flight Management Computer annunciation that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval.

NOTE: Values in this manual are invented and must not be used for any operational purpose. During engine start, the relief pilot should record the Stall Warning advisory when the associated caution light remains illuminated.

11.20.4 Nosewheel Steering Indications

The Nosewheel Steering annunciation is expected to read within the sample range of 67 to 76 units during engine start. During cruise, the relief pilot should cross-check the Bleed Air Supply status message if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Speedbrake Handle indication is expected to read within the sample range of 52 to 63 units during engine start. During a turnaround, both pilots should announce the Window Heat selector position if the indication does not stabilize within the sample interval. The Wing Anti-Ice advisory is expected to read within the sample range of 82 to 91 units during parking.

Condition	Sample value	Remarks
Hydraulic System B advisory	89 units	Advisory only
Standby Instruments quantity display	58 units	Refer to related topic
Stall Warning indication	31 units	Refer to related topic
Primary Electrical Bus switch position	1 units	Refer to related topic
Center Tank Pumps advisory	27 units	Normal

CAUTION: The pilot flying will record any change in the Autopilot Channel A switch position and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: During a turnaround, the relief pilot should announce the Hydraulic System B switch position if a discrepancy is observed.

CAUTION: The Cargo Smoke Detection selector position that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete. Refer to the related topic for additional sample context.

- If the Flap Position Indication is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.
- The Cockpit Voice Recorder quantity display is expected to read within the sample range of 50 to 55 units during a diversion.
- The Speedbrake Handle switch position that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During preflight, the pilot monitoring should select the Standby Instruments annunciation once the checklist item is complete.

During a maintenance-requested ground run, the Captain should announce the Flight Management Computer status message when operating at a sample station without ground power. The Speedbrake Handle annunciation is expected to read within the sample range of 75 to 84 units during a turnaround. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. See 14.30.9 Primary Electrical Bus Limits Display.

11.20.5 Landing Gear Indication Status Messages

If the Traffic Advisory Display is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The captain will cross-check any change in the Window Heat advisory and advise the other pilot when conditions permit.

- During preflight, the pilot monitoring should record the Hydraulic System B advisory when operating at a sample station without ground power.
- During preflight, the pilot monitoring should cross-check the Window Heat annunciation unless directed otherwise by the Sample Operations Center.
- The Wing Anti-Ice status message that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power.
- The first officer will brief any change in the Brake Temperature Monitor status message and advise the other pilot before the next phase of flight.
- If the Hydraulic System B is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- If the Autobrake Selector is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. During preflight, the Captain should monitor the Primary Electrical Bus status message when operating at a sample station without ground power. The Fire Detection Loop annunciation that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. The relief pilot will confirm any change in the Thrust Reverser advisory and advise the other pilot when conditions permit. The Autopilot Channel B quantity display that differs from the expected state requires the First Officer to select the condition once the checklist item is complete.

NOTE: The Weather Radar quantity display that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center.

- The Flight Management Computer status message is expected to read within the sample range of 55 to 64 units during cruise.

- If the Cargo Smoke Detection is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.
- The Brake Temperature Monitor selector position that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power.
- Refer to the related topic for additional sample context.

11.20.6 Flap Position Indication Limits Display

The Cargo Smoke Detection selector position that differs from the expected state requires the Captain to verify the condition before the next phase of flight. If the Wing Anti-Ice is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Fire Detection Loop selector position that differs from the expected state requires both pilots to record the condition when conditions permit.

The relief pilot will record any change in the Brake Temperature Monitor annunciation and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The Flap Position Indication indication is expected to read within the sample range of 18 to 26 units during takeoff.

The Cockpit Voice Recorder quantity display that differs from the expected state requires the Captain to confirm the condition when conditions permit. The Pack Temperature Control quantity display that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. If the Hydraulic System A is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Primary Electrical Bus quantity display that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. The Brake Temperature Monitor indication is expected to read within the sample range of 93 to 102 units during approach. The Ground Proximity Monitor status message is expected to read within the sample range of 38 to 47 units during climb.

Condition	Sample value	Remarks
Autopilot Channel A annunciation	85 units	Advisory only
Oxygen Distribution advisory	64 units	Refer to related topic
Autothrottle status message	1 units	Normal
Cockpit Voice Recorder advisory	45 units	Normal
Speedbrake Handle selector position	56 units	Advisory only

During climb, the pilot monitoring should cross-check the Wing Anti-Ice annunciation when the associated caution light remains illuminated. The Nosewheel Steering switch position is expected to read within the sample range of 32 to 41 units during cruise. The relief pilot will verify any change in the Speedbrake Handle annunciation and advise the other pilot when operating at a sample station without ground power.

CAUTION: The pilot monitoring will cross-check any change in the Traffic Advisory Display switch position and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

The pilot flying will cross-check any change in the Center Tank Pumps advisory and advise the other pilot when conditions permit. The Pack Temperature Control advisory is expected to read within the sample range of 80 to 86 units during an extended ground delay. If the Bleed Air Supply is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

11.20.7 Flap Position Indication Normal Operation

If the Nosewheel Steering is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, the pilot flying should brief the Center Tank Pumps indication before the next phase of flight.

The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the First Officer should cross-check the Wing Anti-Ice indication when conditions permit. The first officer will cross-check any change in the Traffic Advisory Display quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Ground Proximity Monitor status message is expected to read within the sample range of 79 to 87 units during landing.

- The captain will brief any change in the Cargo Smoke Detection status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The pilot flying will confirm any change in the Window Heat status message and advise the other pilot before the next phase of flight.
- The first officer will announce any change in the Cargo Smoke Detection selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Cockpit Voice Recorder is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.
- If the Autobrake Selector is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

The pilot monitoring will verify any change in the Autopilot Channel B indication and advise the other pilot before the next phase of flight. Both pilots will brief any change in the Autobrake Selector quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will record any change in the Auxiliary Power Unit advisory and advise the other pilot when conditions permit. The Primary Electrical Bus status message that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. During takeoff, both pilots should cross-check the Transponder indication unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will cross-check any change in the Hydraulic System B advisory and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Probe Heat selector position	89 units	Normal
Stall Warning selector position	36 units	Advisory only
Probe Heat indication	40 units	Monitor
Standby Hydraulic status message	92 units	Normal
Weather Radar switch position	62 units	Advisory only

The Bleed Air Supply selector position that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. If the Landing Gear Indication is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Brake Temperature Monitor switch position that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. The Cabin Pressure Controller advisory that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete.

- During takeoff, the Captain should monitor the Nosewheel Steering annunciation if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot monitoring will select any change in the Fuel Crossfeed quantity display and advise the other pilot if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.
- During preflight, the pilot flying should verify the Probe Heat annunciation if a discrepancy is observed.

- The Primary Electrical Bus annunciation that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.

11.20.8 Pack Temperature Control Indications

If the Oxygen Distribution is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Thrust Reverser advisory that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated. The captain will brief any change in the Traffic Advisory Display switch position and advise the other pilot before the next phase of flight.

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. During cruise, the First Officer should monitor the Standby Hydraulic indication before the next phase of flight.

The Wing Anti-Ice advisory that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. If the Autobrake Selector is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The Standby Hydraulic status message that differs from the expected state requires both pilots to confirm the condition when conditions permit. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will record any change in the Flap Position Indication quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Primary Electrical Bus indication is expected to read within the sample range of 41 to 48 units during parking. The Stall Warning annunciation is expected to read within the sample range of 5 to 8 units during a maintenance-requested ground run.

The Auxiliary Power Unit switch position that differs from the expected state requires the Captain to verify the condition when conditions permit. The first officer will announce any change in the Hydraulic System B selector position and advise the other pilot when conditions permit. During taxi, the First Officer should confirm the Speedbrake Handle advisory if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. See 05.10.8 Standby Hydraulic Reset Guidance.

NOTE: The captain will confirm any change in the Fuel Crossfeed quantity display and advise the other pilot if a discrepancy is observed. The relief pilot will announce any change in the Center Tank Pumps switch position and advise the other pilot before the next phase of flight.

11.20.9 Ground Proximity Monitor Limits Display

The Thrust Reverser switch position is expected to read within the sample range of 40 to 46 units during a maintenance-requested ground run. The Nosewheel Steering annunciation that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete. The Flight Management Computer status message is expected to read within the sample range of 66 to 69 units during landing.

NOTE: The Primary Electrical Bus selector position that differs from the expected state requires both pilots to select the condition once the checklist item is complete. The Standby Instruments selector position is expected to read within the sample range of 51 to 61 units during cruise.

The Oxygen Distribution advisory that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed. Refer to the related topic for additional sample context. During an extended ground delay, both pilots should brief the Brake Temperature Monitor status message before the next phase of flight. The relief pilot will select any change in the Hydraulic System A indication and advise the other pilot if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

- The Hydraulic System B switch position is expected to read within the sample range of 46 to 53 units during landing.
- The Standby Instruments advisory is expected to read within the sample range of 17 to 28 units during a diversion.
- During parking, both pilots should confirm the Speedbrake Handle quantity display if the indication does not stabilize within the sample interval.
- During parking, the pilot monitoring should verify the Autopilot Channel B annunciation when the associated caution light remains illuminated.
- If the Autothrottle is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- The Standby Instruments advisory that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete.

During a diversion, the First Officer should announce the Autopilot Channel A advisory when the associated caution light remains illuminated. The captain will confirm any change in the Standby Instruments annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. During approach, the pilot flying should cross-check the Autopilot Channel A status message if the indication does not stabilize within the sample interval. The Flight Management Computer switch position is expected to read within the sample range of 14 to 20 units during cruise. The Cockpit Voice Recorder status message is expected to read within the sample range of 81 to 87 units during a turnaround.

- During taxi, the Captain should monitor the Autobrake Selector quantity display once the checklist item is complete.
- If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Flight Management Computer status message	26 units	Advisory only
Wing Anti-Ice switch position	49 units	Normal
Autothrottle selector position	16 units	Advisory only
Probe Heat status message	75 units	Advisory only
Oxygen Distribution quantity display	4 units	Monitor
Hydraulic System B annunciation	58 units	Monitor
Cargo Smoke Detection selector position	23 units	Normal

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. If the Thrust Reverser is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. During landing, both pilots should verify the Center Tank Pumps switch position when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

11.20.10 Traffic Advisory Display Test

During preflight, the relief pilot should verify the Speedbrake Handle selector position once the checklist item is complete. The Oxygen Distribution switch position that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. The Hydraulic System B annunciation is expected to read within the sample range of 67 to 77 units during an extended ground delay. Refer to the related topic for additional sample context. The Speedbrake Handle quantity display is expected to read within the sample range of 31 to 34 units during

parking.

Condition	Sample value	Remarks
Primary Electrical Bus switch position	93 units	Refer to related topic
Probe Heat indication	89 units	Monitor
Autobrake Selector quantity display	78 units	Advisory only
Bleed Air Supply selector position	16 units	Normal
Nosewheel Steering advisory	64 units	Refer to related topic
Window Heat annunciation	54 units	Normal
Probe Heat switch position	64 units	Normal

NOTE: If the Weather Radar is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

If the Weather Radar is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Engine Anti-Ice quantity display is expected to read within the sample range of 62 to 71 units during parking. The relief pilot will cross-check any change in the Cabin Pressure Controller advisory and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Weather Radar switch position	56 units	Normal
Standby Instruments quantity display	31 units	Normal
Landing Gear Indication selector position	75 units	Monitor
Speedbrake Handle quantity display	7 units	Advisory only

CAUTION: If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

11.20.11 Transponder Status Messages

The Ground Proximity Monitor annunciation that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed. During an extended ground delay, the pilot monitoring should select the Auxiliary Power Unit annunciation before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Autobrake Selector is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Fire Detection Loop selector position that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight.

Condition	Sample value	Remarks
Standby Hydraulic advisory	96 units	Monitor
Cabin Pressure Controller selector position	9 units	Refer to related topic
Fire Detection Loop quantity display	7 units	Refer to related topic
Flap Position Indication switch position	85 units	Advisory only
Cargo Smoke Detection advisory	57 units	Monitor
Thrust Reverser indication	61 units	Monitor
Probe Heat advisory	85 units	Advisory only

Condition	Sample value	Remarks
-----------	--------------	---------

Window Heat quantity display	43 units	Monitor
Center Tank Pumps advisory	85 units	Normal
Auxiliary Power Unit advisory	38 units	Advisory only
Autobrake Selector status message	95 units	Monitor
Standby Instruments indication	53 units	Normal
Cockpit Voice Recorder selector position	98 units	Normal

NOTE: The Weather Radar advisory that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: During an extended ground delay, the Captain should announce the Standby Hydraulic status message if the indication does not stabilize within the sample interval. The Wing Anti-Ice advisory is expected to read within the sample range of 5 to 14 units during climb.

The Fire Detection Loop annunciation is expected to read within the sample range of 75 to 85 units during a maintenance-requested ground run. If the Hydraulic System B is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Autothrottle is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Standby Hydraulic quantity display is expected to read within the sample range of 10 to 19 units during cruise. The Nosewheel Steering selector position is expected to read within the sample range of 53 to 57 units during cruise.

NOTE: Both pilots will verify any change in the Center Tank Pumps quantity display and advise the other pilot before the next phase of flight.

11.20.12 Ground Proximity Monitor Crew Awareness

This text is fictional and exists only to give the prototype realistic volume and structure. If the Thrust Reverser is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Transponder status message is expected to read within the sample range of 37 to 45 units during preflight. If the Fire Detection Loop is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The Weather Radar advisory is expected to read within the sample range of 36 to 48 units during taxi. The Bleed Air Supply selector position that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power.

- Refer to the related topic for additional sample context.
- The Hydraulic System A status message that differs from the expected state requires the First Officer to brief the condition when conditions permit.
- During a turnaround, the Captain should verify the Fuel Crossfeed selector position before the next phase of flight.

Condition	Sample value	Remarks
Landing Gear Indication annunciation	89 units	Monitor
Auxiliary Power Unit switch position	92 units	Advisory only
Pack Temperature Control selector position	29 units	Refer to related topic
Fuel Crossfeed advisory	62 units	Monitor
Auxiliary Power Unit advisory	70 units	Normal
Autopilot Channel A status message	1 units	Monitor
Cargo Smoke Detection switch position	94 units	Monitor

- The first officer will record any change in the Primary Electrical Bus quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- During a turnaround, the pilot flying should cross-check the Center Tank Pumps selector position if a discrepancy is observed.
- Refer to the related topic for additional sample context.

The first officer will monitor any change in the Primary Electrical Bus advisory and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System A is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Speedbrake Handle quantity display and advise the other pilot before the next phase of flight. During a maintenance-requested ground run, the relief pilot should monitor the Window Heat quantity display unless directed otherwise by the Sample Operations Center.

- The Brake Temperature Monitor selector position that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.
- The Nosewheel Steering annunciation is expected to read within the sample range of 45 to 57 units during an extended ground delay.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Hydraulic System B switch position is expected to read within the sample range of 33 to 36 units during a turnaround.
- The Fire Detection Loop selector position is expected to read within the sample range of 42 to 53 units during engine start.
- The Fuel Crossfeed status message that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Standby Instruments quantity display	19 units	Refer to related topic
Window Heat advisory	2 units	Advisory only
Autothrottle selector position	20 units	Advisory only
Landing Gear Indication quantity display	87 units	Normal
Oxygen Distribution indication	86 units	Refer to related topic
Landing Gear Indication advisory	43 units	Refer to related topic
Engine Anti-Ice annunciation	70 units	Refer to related topic

During climb, the relief pilot should verify the Hydraulic System A annunciation if a discrepancy is observed. Both pilots will announce any change in the Traffic Advisory Display indication and advise the other pilot when the associated caution light remains illuminated. If the Engine Anti-Ice is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The pilot flying will select any change in the Window Heat quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. See 05.40.3 Thrust Reverser Reset Guidance.

11.20.13 Landing Gear Indication Crew Awareness

Refer to the related topic for additional sample context. If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Transponder switch position that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and

structure. The Weather Radar switch position that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete.

- During parking, the relief pilot should record the Speedbrake Handle advisory once the checklist item is complete.
- The Cargo Smoke Detection annunciation that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete.
- The captain will monitor any change in the Autopilot Channel B switch position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Probe Heat annunciation	19 units	Monitor
Transponder quantity display	14 units	Refer to related topic
Cabin Pressure Controller status message	70 units	Normal
Pack Temperature Control quantity display	33 units	Refer to related topic
Auxiliary Power Unit quantity display	83 units	Advisory only
Speedbrake Handle selector position	69 units	Advisory only
Oxygen Distribution advisory	16 units	Advisory only

CAUTION: The Autopilot Channel A annunciation that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated. If the Ground Proximity Monitor is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

The Auxiliary Power Unit quantity display that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will verify any change in the Landing Gear Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

11.20.14 Fire Detection Loop Indications

During engine start, both pilots should select the Flight Management Computer annunciation before the next phase of flight. During a maintenance-requested ground run, both pilots should select the Autopilot Channel B indication if a discrepancy is observed. During approach, the pilot flying should brief the Standby Hydraulic quantity display once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. See 11.30.11 Brake Temperature Monitor Crew Awareness.

NOTE: If the Auxiliary Power Unit is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control quantity display is expected to read within the sample range of 79 to 84 units during approach.

CAUTION: The pilot flying will monitor any change in the Cargo Smoke Detection selector position and advise the other pilot once the checklist item is complete. The Autothrottle indication that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center.

NOTE: The Autobrake Selector indication that differs from the expected state requires both pilots to cross-check the condition when conditions permit.

Condition	Sample value	Remarks
Transponder selector position	71 units	Advisory only
Hydraulic System A annunciation	89 units	Advisory only
Thrust Reverser switch position	8 units	Refer to related topic
Cargo Smoke Detection annunciation	75 units	Normal
Engine Anti-Ice indication	31 units	Normal

Engine Anti-Ice annunciation	18 units	Normal
Standby Instruments selector position	2 units	Normal

11.20.15 Ground Proximity Monitor Limits Display

The pilot monitoring will brief any change in the Hydraulic System A switch position and advise the other pilot when the associated caution light remains illuminated. If the Hydraulic System B is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Pack Temperature Control advisory that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval. The Autopilot Channel B indication that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Autopilot Channel B switch position that differs from the expected state requires the First Officer to brief the condition when conditions permit.

During taxi, the First Officer should confirm the Wing Anti-Ice status message when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System B is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will brief any change in the Wing Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will monitor any change in the Speedbrake Handle status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will record any change in the Flap Position Indication switch position and advise the other pilot when the associated caution light remains illuminated. The Center Tank Pumps annunciation that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

If the Hydraulic System A is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During cruise, the relief pilot should announce the Brake Temperature Monitor annunciation if the indication does not stabilize within the sample interval.

The Flight Management Computer advisory that differs from the expected state requires both pilots to brief the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the pilot flying should verify the Hydraulic System A status message if the indication does not stabilize within the sample interval. The Fuel Crossfeed status message is expected to read within the sample range of 15 to 18 units during climb.

During cruise, both pilots should monitor the Stall Warning status message when conditions permit. The Cockpit Voice Recorder advisory that differs from the expected state requires the pilot monitoring to select the condition when conditions permit. During an extended ground delay, the relief pilot should verify the Oxygen Distribution annunciation unless directed otherwise by the Sample Operations Center. During a diversion, the relief pilot should record the Flight Management Computer status message when operating at a sample station without ground power.

11.20.16 Flap Position Indication Limits Display

The Nosewheel Steering annunciation that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated. The Center Tank Pumps status message is expected to read within the sample range of 76 to 80 units during a diversion. Both pilots will record any change in the Autopilot Channel A indication and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

- The Transponder selector position that differs from the expected state requires the relief pilot to monitor the condition before the next phase of flight.

- The relief pilot will verify any change in the Weather Radar switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Cargo Smoke Detection annunciation that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Landing Gear Indication indication	42 units	Refer to related topic
Thrust Reverser selector position	87 units	Refer to related topic
Ground Proximity Monitor annunciation	37 units	Advisory only
Bleed Air Supply indication	87 units	Normal
Engine Anti-Ice advisory	74 units	Advisory only

- The Probe Heat switch position is expected to read within the sample range of 14 to 22 units during taxi.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The pilot flying will select any change in the Autothrottle selector position and advise the other pilot when the associated caution light remains illuminated.
- If the Cabin Pressure Controller is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- If the Autothrottle is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.
- The pilot flying will confirm any change in the Cargo Smoke Detection switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Autothrottle status message that differs from the expected state requires both pilots to monitor the condition before the next phase of flight.
- If the Autobrake Selector is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.
- During a turnaround, the First Officer should monitor the Wing Anti-Ice selector position if a discrepancy is observed.
- The pilot monitoring will verify any change in the Autopilot Channel B advisory and advise the other pilot if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot monitoring will select any change in the Standby Hydraulic status message and advise the other pilot when the associated caution light remains illuminated.
- During climb, the First Officer should announce the Fuel Crossfeed status message when conditions permit.
- The first officer will verify any change in the Cargo Smoke Detection status message and advise the other pilot when conditions permit.

11.30 Operation

11.30.1 Pack Temperature Control Indications

The first officer will select any change in the Pack Temperature Control quantity display and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Wing Anti-Ice status message that differs from the expected state requires the pilot

flying to announce the condition once the checklist item is complete. During engine start, the pilot monitoring should cross-check the Standby Instruments switch position when operating at a sample station without ground power.

The relief pilot will verify any change in the Autopilot Channel B status message and advise the other pilot when conditions permit. If the Primary Electrical Bus is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. During descent, the pilot monitoring should cross-check the Cargo Smoke Detection selector position unless directed otherwise by the Sample Operations Center.

NOTE: The pilot flying will verify any change in the Cabin Pressure Controller switch position and advise the other pilot when the associated caution light remains illuminated.

The first officer will brief any change in the Speedbrake Handle indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection indication that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. The Center Tank Pumps switch position that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. The Speedbrake Handle annunciation is expected to read within the sample range of 15 to 20 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: If the Oxygen Distribution is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

NOTE: The Auxiliary Power Unit indication that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Traffic Advisory Display is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Ground Proximity Monitor status message that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. During preflight, the First Officer should brief the Oxygen Distribution quantity display if the indication does not stabilize within the sample interval. The relief pilot will select any change in the Landing Gear Indication status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will confirm any change in the Flap Position Indication indication and advise the other pilot before the next phase of flight. The Flap Position Indication selector position is expected to read within the sample range of 23 to 29 units during descent.

11.30.2 *Standby Hydraulic Limits Display*

The Center Tank Pumps switch position that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. During descent, the pilot flying should verify the Standby Instruments indication when operating at a sample station without ground power.

NOTE: If the Flight Management Computer is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will cross-check any change in the Pack Temperature Control annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. The Transponder advisory is expected to read within the sample range of 36 to 46 units during an extended ground delay. The Cockpit Voice Recorder selector position that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context.

NOTE: The pilot flying will select any change in the Weather Radar selector position and advise the other pilot when conditions permit.

- During takeoff, the Captain should monitor the Hydraulic System A selector position unless directed otherwise by the Sample Operations Center.
- The Engine Anti-Ice selector position is expected to read within the sample range of 16 to 22 units during a maintenance-requested ground run.
- The Autothrottle indication is expected to read within the sample range of 33 to 38 units during an extended ground delay.

11.30.3 Cargo Smoke Detection Overview

During preflight, both pilots should confirm the Cockpit Voice Recorder quantity display once the checklist item is complete. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: Refer to the related topic for additional sample context. During cruise, the pilot flying should cross-check the Flap Position Indication advisory if a discrepancy is observed.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the First Officer should confirm the Pack Temperature Control annunciation if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Hydraulic System B status message	92 units	Normal
Standby Hydraulic selector position	11 units	Advisory only
Flight Management Computer selector position	12 units	Advisory only
Cabin Pressure Controller indication	22 units	Normal
Wing Anti-Ice switch position	23 units	Advisory only
Autopilot Channel B status message	88 units	Normal
Thrust Reverser selector position	28 units	Advisory only

The Brake Temperature Monitor indication that differs from the expected state requires the First Officer to announce the condition when conditions permit. The pilot monitoring will verify any change in the Landing Gear Indication selector position and advise the other pilot when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. If the Flight Management Computer is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During approach, the Captain should monitor the Engine Anti-Ice annunciation when conditions permit.

If the Autobrake Selector is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Speedbrake Handle quantity display that differs from the expected state requires both pilots to monitor the condition when conditions permit. The Brake Temperature Monitor status message is expected to read within the sample range of 61 to 70 units during an extended ground delay.

CAUTION: The Flight Management Computer switch position is expected to read within the sample range of 65 to 70 units during parking. Refer to the related topic for additional sample context.

11.30.4 Speedbrake Handle Indications

The Flap Position Indication advisory that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. The Landing Gear Indication indication that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. During a diversion, both pilots should confirm the Cargo Smoke Detection indication when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will verify any change in the Thrust Reverser status message and advise the other pilot before the next phase of flight. During descent, the relief pilot should announce the Hydraulic System A selector position when operating at a sample station without ground power. The first officer will brief any change in the Window Heat quantity display and advise the other pilot when the associated caution light remains illuminated. If the Autopilot Channel B is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

- The Flap Position Indication advisory that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval.
- If the Window Heat is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.
- The Pack Temperature Control selector position that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight.
- Both pilots will verify any change in the Flap Position Indication selector position and advise the other pilot before the next phase of flight.
- The pilot flying will confirm any change in the Auxiliary Power Unit selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- Both pilots will brief any change in the Bleed Air Supply status message and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Oxygen Distribution is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Engine Anti-Ice annunciation that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The Wing Anti-Ice status message that differs from the expected state requires the pilot monitoring to select the condition when conditions permit. The Window Heat advisory is expected to read within the sample range of 79 to 87 units during taxi. During descent, the Captain should verify the Transponder status message when operating at a sample station without ground power.

Refer to the related topic for additional sample context. The Transponder selector position that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated. During parking, the pilot monitoring should announce the Ground Proximity Monitor status message once the checklist item is complete. The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center.

11.30.5 Primary Electrical Bus Overview

The Brake Temperature Monitor selector position is expected to read within the sample range of 37 to 43 units during a maintenance-requested ground run. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autopilot Channel B is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. Both pilots will verify any change in the Engine Anti-Ice status message and advise the other pilot once the checklist item is complete.

The Hydraulic System B quantity display is expected to read within the sample range of 76 to 82 units during preflight. During climb, the relief pilot should monitor the Window Heat selector position if the indication does not stabilize within the sample interval. If the Fuel Crossfeed is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

The Cockpit Voice Recorder annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight. If the Cockpit Voice Recorder is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication annunciation that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed. During descent, both pilots should monitor the Fire Detection Loop annunciation before the next phase of flight.

The captain will brief any change in the Hydraulic System B indication and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will monitor any change in the Probe Heat status message and advise the other pilot when conditions permit. The captain will select any change in the Flap Position Indication annunciation and advise the other pilot when operating at a sample station without ground power. The Wing Anti-Ice advisory that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval. The Fire Detection Loop advisory that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval.

If the Probe Heat is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. During an extended ground delay, the First Officer should confirm the Autopilot Channel A annunciation when the associated caution light remains illuminated. During an extended ground delay, both pilots should cross-check the Standby Instruments status message when conditions permit.

CAUTION: The Traffic Advisory Display status message that differs from the expected state requires the Captain to brief the condition when conditions permit.

NOTE: The Primary Electrical Bus annunciation is expected to read within the sample range of 54 to 63 units during engine start.

The Hydraulic System A status message is expected to read within the sample range of 25 to 31 units during taxi. The Landing Gear Indication advisory is expected to read within the sample range of 35 to 43 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure. If the Speedbrake Handle is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

11.30.6 Transponder Indications

Values in this manual are invented and must not be used for any operational purpose. The Nosewheel Steering selector position that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed. The Bleed Air Supply switch position is expected to read within the sample range of 29 to 33 units during descent. The captain will record any change in the Oxygen Distribution selector position and advise the other pilot if a discrepancy is observed.

During approach, the relief pilot should record the Ground Proximity Monitor advisory when operating at a sample station without ground power. The pilot flying will verify any change in the Nosewheel Steering annunciation and advise the other pilot when the associated caution light remains illuminated. The Flight Management Computer advisory is expected to read within the sample range of 8 to 17 units during climb. If the Hydraulic System B is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The first officer will confirm any change in the Transponder switch position and advise the other pilot when the associated caution light remains illuminated. The Ground Proximity Monitor status message is expected to read within the sample range of 18 to 22 units during cruise.

NOTE: The Weather Radar indication that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center.

NOTE: The Pack Temperature Control indication that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit.

CAUTION: During an extended ground delay, the pilot monitoring should confirm the Standby Instruments switch position when the associated caution light remains illuminated. The Wing Anti-Ice advisory is expected to read

within the sample range of 47 to 51 units during engine start.

NOTE: If the Ground Proximity Monitor is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

The pilot flying will monitor any change in the Autopilot Channel B switch position and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The Auxiliary Power Unit switch position is expected to read within the sample range of 93 to 105 units during engine start. During a maintenance-requested ground run, the Captain should cross-check the Primary Electrical Bus selector position before the next phase of flight. Both pilots will confirm any change in the Auxiliary Power Unit annunciation and advise the other pilot when the associated caution light remains illuminated.

During parking, the relief pilot should record the Autobrake Selector advisory when the associated caution light remains illuminated. If the Autopilot Channel B is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Auxiliary Power Unit quantity display is expected to read within the sample range of 36 to 47 units during climb. The Center Tank Pumps indication is expected to read within the sample range of 53 to 62 units during cruise. The Fire Detection Loop indication is expected to read within the sample range of 32 to 44 units during descent.

Condition	Sample value	Remarks
Nosewheel Steering status message	61 units	Monitor
Primary Electrical Bus status message	91 units	Normal
Autopilot Channel B switch position	24 units	Monitor
Speedbrake Handle status message	51 units	Monitor
Cargo Smoke Detection selector position	73 units	Monitor
Cabin Pressure Controller advisory	19 units	Monitor
Fuel Crossfeed annunciation	68 units	Advisory only

11.30.7 Fuel Crossfeed Reset Guidance

If the Stall Warning is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. During landing, the First Officer should select the Speedbrake Handle annunciation before the next phase of flight. The Primary Electrical Bus status message that differs from the expected state requires the pilot monitoring to brief the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The Standby Instruments status message is expected to read within the sample range of 87 to 96 units during an extended ground delay.

If the Engine Anti-Ice is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. During approach, the First Officer should verify the Cabin Pressure Controller switch position when operating at a sample station without ground power. Both pilots will confirm any change in the Flight Management Computer annunciation and advise the other pilot when conditions permit.

If the Transponder is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 82 to 86 units during engine start. If the Ground Proximity Monitor is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Autothrottle indication that differs from the expected state requires the Captain to monitor the condition when conditions permit.

The first officer will announce any change in the Pack Temperature Control switch position and advise the other pilot when conditions permit. The Probe Heat quantity display is expected to read within the sample range of 46 to 55 units during climb. If the Bleed Air Supply is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Autothrottle quantity display that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval. During a diversion, the pilot monitoring should record the Probe Heat selector position when operating at a sample station without ground

power.

The Pack Temperature Control switch position is expected to read within the sample range of 33 to 40 units during a turnaround. The Nosewheel Steering switch position that differs from the expected state requires both pilots to verify the condition when conditions permit. If the Hydraulic System A is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Cabin Pressure Controller is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. Both pilots will confirm any change in the Bleed Air Supply advisory and advise the other pilot when the associated caution light remains illuminated. If the Autopilot Channel A is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

11.30.8 Thrust Reverser Overview

If the Ground Proximity Monitor is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Window Heat annunciation that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power. The Autopilot Channel B quantity display is expected to read within the sample range of 37 to 44 units during parking. The Speedbrake Handle indication that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power. During takeoff, the pilot flying should brief the Fuel Crossfeed annunciation if a discrepancy is observed.

Condition	Sample value	Remarks
Wing Anti-Ice switch position	13 units	Refer to related topic
Thrust Reverser switch position	31 units	Refer to related topic
Flight Management Computer status message	67 units	Monitor
Autopilot Channel B switch position	13 units	Monitor
Nosewheel Steering indication	34 units	Refer to related topic
Bleed Air Supply indication	63 units	Normal
Brake Temperature Monitor indication	68 units	Refer to related topic

The relief pilot will brief any change in the Pack Temperature Control advisory and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The first officer will record any change in the Nosewheel Steering selector position and advise the other pilot if the indication does not stabilize within the sample interval. See 09.20.6 Engine Anti-Ice Status Messages.

Condition	Sample value	Remarks
Standby Hydraulic annunciation	19 units	Monitor
Pack Temperature Control switch position	80 units	Advisory only
Cargo Smoke Detection status message	34 units	Monitor

NOTE: During parking, the pilot monitoring should announce the Cabin Pressure Controller annunciation unless directed otherwise by the Sample Operations Center. The Oxygen Distribution quantity display is expected to read within the sample range of 56 to 64 units during a diversion.

Condition	Sample value	Remarks
Stall Warning status message	66 units	Refer to related topic
Oxygen Distribution annunciation	99 units	Monitor
Cargo Smoke Detection annunciation	79 units	Normal

Autopilot Channel B indication	30 units	Advisory only
Standby Instruments advisory	57 units	Advisory only
Probe Heat quantity display	29 units	Monitor
Center Tank Pumps switch position	23 units	Monitor

NOTE: The Cockpit Voice Recorder advisory is expected to read within the sample range of 66 to 77 units during a diversion. The pilot monitoring will select any change in the Primary Electrical Bus selector position and advise the other pilot when the associated caution light remains illuminated.

11.30.9 Autothrottle Limits Display

The Cargo Smoke Detection status message is expected to read within the sample range of 14 to 18 units during parking. The Wing Anti-Ice indication is expected to read within the sample range of 22 to 34 units during descent. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Pack Temperature Control status message	77 units	Monitor
Wing Anti-Ice status message	84 units	Normal
Pack Temperature Control quantity display	57 units	Advisory only
Autobrake Selector quantity display	89 units	Advisory only
Standby Hydraulic switch position	98 units	Advisory only

The Primary Electrical Bus status message that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. During climb, the pilot flying should cross-check the Fuel Crossfeed switch position if the indication does not stabilize within the sample interval. Both pilots will cross-check any change in the Fire Detection Loop status message and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Wing Anti-Ice is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Cargo Smoke Detection switch position that differs from the expected state requires the First Officer to select the condition once the checklist item is complete.

The Autothrottle annunciation is expected to read within the sample range of 85 to 90 units during engine start. The pilot flying will announce any change in the Weather Radar annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Fuel Crossfeed is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Fuel Crossfeed selector position that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center.

NOTE: If the Ground Proximity Monitor is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The pilot flying will monitor any change in the Standby Instruments indication and advise the other pilot if the indication does not stabilize within the sample interval.

11.30.10 Pack Temperature Control Status Messages

During preflight, the pilot flying should verify the Standby Hydraulic selector position when the associated caution light remains illuminated. If the Stall Warning is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Auxiliary Power Unit is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

The Flight Management Computer selector position is expected to read within the sample range of 67 to 72 units during landing. During climb, both pilots should announce the Engine Anti-Ice status message before the next phase of flight. The Nosewheel Steering status message that differs from the expected state requires the First Officer to

select the condition when the associated caution light remains illuminated.

- The Flap Position Indication indication that differs from the expected state requires the relief pilot to brief the condition when conditions permit.
- During a turnaround, the pilot monitoring should announce the Wing Anti-Ice status message if a discrepancy is observed.
- The captain will cross-check any change in the Nosewheel Steering selector position and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Hydraulic System B switch position	94 units	Normal
Flap Position Indication advisory	66 units	Refer to related topic
Window Heat switch position	56 units	Normal
Ground Proximity Monitor switch position	33 units	Refer to related topic
Fire Detection Loop advisory	82 units	Refer to related topic

- The Landing Gear Indication status message that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center.
- The Probe Heat status message is expected to read within the sample range of 21 to 25 units during parking.
- The Cabin Pressure Controller switch position is expected to read within the sample range of 97 to 102 units during taxi.
- The Autopilot Channel A advisory that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power.
- During parking, the relief pilot should record the Engine Anti-Ice quantity display once the checklist item is complete.
- During descent, the pilot flying should record the Fuel Crossfeed quantity display before the next phase of flight.

The pilot flying will brief any change in the Primary Electrical Bus quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During climb, the pilot flying should cross-check the Nosewheel Steering annunciation before the next phase of flight. If the Hydraulic System A is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

The Wing Anti-Ice switch position that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. During parking, both pilots should brief the Probe Heat indication when operating at a sample station without ground power. The first officer will confirm any change in the Fire Detection Loop switch position and advise the other pilot once the checklist item is complete. During parking, both pilots should confirm the Pack Temperature Control switch position unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus quantity display is expected to read within the sample range of 46 to 53 units during a maintenance-requested ground run. The Bleed Air Supply status message is expected to read within the sample range of 25 to 36 units during climb.

11.30.11 Brake Temperature Monitor Crew Awareness

The first officer will announce any change in the Window Heat status message and advise the other pilot when operating at a sample station without ground power. The Cargo Smoke Detection indication that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
-----------	--------------	---------

Brake Temperature Monitor annunciation	5 units	Advisory only
Autopilot Channel A selector position	16 units	Refer to related topic
Window Heat quantity display	93 units	Advisory only

The Speedbrake Handle status message that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will brief any change in the Traffic Advisory Display advisory and advise the other pilot once the checklist item is complete. During climb, both pilots should record the Thrust Reverser quantity display when operating at a sample station without ground power.

- The Flight Management Computer switch position that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed.
- During cruise, both pilots should monitor the Primary Electrical Bus indication unless directed otherwise by the Sample Operations Center.
- The captain will record any change in the Transponder quantity display and advise the other pilot if a discrepancy is observed.
- The pilot flying will verify any change in the Landing Gear Indication switch position and advise the other pilot when conditions permit.
- The Oxygen Distribution switch position is expected to read within the sample range of 77 to 89 units during engine start.

NOTE: The Primary Electrical Bus indication that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

11.30.12 Engine Anti-Ice Test

If the Cockpit Voice Recorder is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During descent, the First Officer should record the Fire Detection Loop quantity display when the associated caution light remains illuminated. The Stall Warning status message is expected to read within the sample range of 57 to 64 units during engine start. The Window Heat switch position that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval.

NOTE: The Fire Detection Loop status message is expected to read within the sample range of 18 to 23 units during a maintenance-requested ground run.

During climb, the pilot flying should cross-check the Center Tank Pumps switch position unless directed otherwise by the Sample Operations Center. During landing, the First Officer should announce the Cockpit Voice Recorder switch position if a discrepancy is observed. The first officer will confirm any change in the Primary Electrical Bus status message and advise the other pilot when conditions permit.

If the Flight Management Computer is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The first officer will record any change in the Autothrottle status message and advise the other pilot if the indication does not stabilize within the sample interval. The Auxiliary Power Unit switch position that differs from the expected state requires the pilot monitoring to record the condition when conditions permit. The captain will verify any change in the Center Tank Pumps indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Autothrottle is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Nosewheel Steering advisory is expected to read within the sample range of 24 to 33 units during an extended ground delay.

During climb, the First Officer should cross-check the Hydraulic System A switch position before the next phase of flight. The pilot monitoring will brief any change in the Primary Electrical Bus selector position and advise the other pilot when conditions permit. During preflight, the pilot flying should cross-check the Probe Heat indication when

conditions permit. The Center Tank Pumps annunciation that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. The captain will select any change in the Fire Detection Loop quantity display and advise the other pilot before the next phase of flight.

The Flight Management Computer quantity display that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The captain will brief any change in the Autopilot Channel A indication and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. If the Autothrottle is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

CAUTION: During preflight, the relief pilot should brief the Standby Hydraulic switch position when operating at a sample station without ground power. The Autothrottle selector position is expected to read within the sample range of 82 to 92 units during taxi.

11.30.13 Probe Heat Status Messages

The Flight Management Computer selector position is expected to read within the sample range of 70 to 82 units during landing. The relief pilot will brief any change in the Weather Radar indication and advise the other pilot when operating at a sample station without ground power. The Oxygen Distribution annunciation that differs from the expected state requires the First Officer to verify the condition before the next phase of flight. The relief pilot will select any change in the Fuel Crossfeed status message and advise the other pilot if a discrepancy is observed.

If the Autobrake Selector is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Autothrottle selector position that differs from the expected state requires the pilot flying to verify the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection annunciation is expected to read within the sample range of 58 to 64 units during descent. The pilot flying will record any change in the Cabin Pressure Controller annunciation and advise the other pilot when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. The captain will cross-check any change in the Thrust Reverser status message and advise the other pilot when conditions permit. The Autobrake Selector annunciation is expected to read within the sample range of 53 to 61 units during preflight. During climb, the pilot flying should announce the Autopilot Channel A indication unless directed otherwise by the Sample Operations Center. The first officer will brief any change in the Stall Warning status message and advise the other pilot if a discrepancy is observed. The pilot flying will cross-check any change in the Cabin Pressure Controller quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

The captain will confirm any change in the Weather Radar indication and advise the other pilot when conditions permit. During takeoff, the First Officer should cross-check the Traffic Advisory Display selector position unless directed otherwise by the Sample Operations Center. During taxi, the Captain should select the Hydraulic System A switch position if the indication does not stabilize within the sample interval.

The Wing Anti-Ice status message that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. If the Flight Management Computer is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Wing Anti-Ice advisory that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center. The Nosewheel Steering switch position is expected to read within the sample range of 42 to 54 units during approach. The Auxiliary Power Unit indication that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

The Autothrottle indication that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. Both pilots will announce any change in the Autothrottle status message and

advise the other pilot if a discrepancy is observed. If the Transponder is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Weather Radar selector position that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated. If the Hydraulic System B is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. See 05.30.8 Autopilot Channel A Crew Awareness.

11.30.14 Nosewheel Steering Normal Operation

The Standby Hydraulic quantity display is expected to read within the sample range of 86 to 94 units during parking. The Pack Temperature Control switch position that differs from the expected state requires both pilots to brief the condition once the checklist item is complete. If the Auxiliary Power Unit is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Traffic Advisory Display switch position is expected to read within the sample range of 31 to 35 units during preflight. During an extended ground delay, the pilot flying should verify the Pack Temperature Control indication before the next phase of flight.

The Landing Gear Indication advisory is expected to read within the sample range of 47 to 53 units during a turnaround. During a turnaround, the First Officer should confirm the Landing Gear Indication annunciation if the indication does not stabilize within the sample interval. During cruise, both pilots should cross-check the Hydraulic System A quantity display once the checklist item is complete. The Autopilot Channel B status message that differs from the expected state requires the relief pilot to select the condition when conditions permit. The Hydraulic System A status message that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete.

Refer to the related topic for additional sample context. During parking, the relief pilot should cross-check the Autopilot Channel B advisory before the next phase of flight. The Cargo Smoke Detection selector position that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power.

NOTE: The Flight Management Computer annunciation that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete. If the Flight Management Computer is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Flap Position Indication advisory	72 units	Normal
Oxygen Distribution status message	98 units	Advisory only
Fuel Crossfeed status message	61 units	Advisory only
Traffic Advisory Display switch position	57 units	Monitor
Traffic Advisory Display switch position	51 units	Refer to related topic
Autopilot Channel A annunciation	92 units	Advisory only
Speedbrake Handle selector position	21 units	Refer to related topic

During descent, the Captain should select the Standby Instruments status message when operating at a sample station without ground power. During descent, the pilot monitoring should cross-check the Bleed Air Supply status message if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The Thrust Reverser indication that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. During a turnaround, the pilot flying should confirm the Autobrake Selector annunciation when operating at a sample station without ground power. During approach, both pilots should brief the Engine Anti-Ice indication before the next phase of flight.

CAUTION: The Transponder selector position that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated. The Primary Electrical Bus annunciation is expected to read within the sample range of 71 to 83 units during approach.

11.30.15 Probe Heat Power Sources

Refer to the related topic for additional sample context. During a diversion, both pilots should brief the Autopilot Channel A annunciation if a discrepancy is observed. During a maintenance-requested ground run, the Captain should monitor the Oxygen Distribution advisory when operating at a sample station without ground power. The Engine Anti-Ice advisory that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Cockpit Voice Recorder indication	15 units	Advisory only
Fuel Crossfeed quantity display	95 units	Normal
Brake Temperature Monitor status message	51 units	Advisory only
Flap Position Indication annunciation	94 units	Advisory only
Standby Hydraulic indication	27 units	Advisory only
Flap Position Indication quantity display	84 units	Monitor
Autobrake Selector quantity display	42 units	Monitor

If the Cargo Smoke Detection is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Probe Heat switch position that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

The Cabin Pressure Controller advisory is expected to read within the sample range of 83 to 89 units during climb. The Speedbrake Handle status message that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete. Refer to the related topic for additional sample context. During a maintenance-requested ground run, the Captain should brief the Hydraulic System A advisory unless directed otherwise by the Sample Operations Center. If the Standby Hydraulic is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Autothrottle switch position is expected to read within the sample range of 47 to 55 units during preflight.

Both pilots will verify any change in the Traffic Advisory Display selector position and advise the other pilot when the associated caution light remains illuminated. If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Transponder selector position is expected to read within the sample range of 45 to 50 units during cruise. During taxi, the pilot flying should verify the Flap Position Indication indication when the associated caution light remains illuminated.

CAUTION: The Thrust Reverser status message that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. The pilot monitoring will cross-check any change in the Probe Heat selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will cross-check any change in the Ground Proximity Monitor quantity display and advise the other pilot if a

discrepancy is observed. The Center Tank Pumps status message is expected to read within the sample range of 48 to 51 units during a diversion.

11.30.16 Probe Heat Power Sources

The Oxygen Distribution quantity display is expected to read within the sample range of 36 to 44 units during landing. During cruise, both pilots should brief the Cargo Smoke Detection annunciation when operating at a sample station without ground power. During a maintenance-requested ground run, the Captain should verify the Autopilot Channel B quantity display unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat advisory is expected to read within the sample range of 89 to 96 units during climb.

Condition	Sample value	Remarks
Window Heat advisory	76 units	Normal
Hydraulic System B advisory	52 units	Normal
Primary Electrical Bus status message	49 units	Normal

- During taxi, the pilot flying should select the Fuel Crossfeed switch position when operating at a sample station without ground power.
- The Weather Radar indication is expected to read within the sample range of 97 to 100 units during parking.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Nosewheel Steering annunciation that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. If the Autobrake Selector is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

During climb, the pilot flying should brief the Pack Temperature Control indication before the next phase of flight. The Ground Proximity Monitor indication that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight. The Flap Position Indication quantity display is expected to read within the sample range of 95 to 105 units during a turnaround. During cruise, the First Officer should monitor the Probe Heat advisory when the associated caution light remains illuminated. The Flap Position Indication annunciation is expected to read within the sample range of 10 to 17 units during a diversion. The Brake Temperature Monitor advisory that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval.

The Weather Radar status message is expected to read within the sample range of 9 to 19 units during an extended ground delay. The Wing Anti-Ice quantity display is expected to read within the sample range of 73 to 78 units during takeoff. The Wing Anti-Ice switch position is expected to read within the sample range of 2 to 13 units during approach. The Hydraulic System B indication is expected to read within the sample range of 88 to 92 units during parking. The Flight Management Computer advisory that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. The Hydraulic System B advisory that differs from the expected state requires the pilot flying to record the condition when conditions permit.

Chapter 12 Systems: Automatic Flight

12.10 Description

12.10.1 Pack Temperature Control Crew Awareness

If the Flight Management Computer is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The relief pilot will monitor any change in the Traffic Advisory Display indication and advise the other pilot when conditions permit. The Oxygen Distribution switch position that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated.

The wording here is placeholder content shaped like a procedure, not a procedure. The Thrust Reverser annunciation is expected to read within the sample range of 19 to 25 units during a turnaround. If the Nosewheel Steering is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Cargo Smoke Detection is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

- During cruise, both pilots should confirm the Bleed Air Supply quantity display once the checklist item is complete.
- During parking, the pilot flying should confirm the Engine Anti-Ice selector position when the associated caution light remains illuminated.
- During landing, the relief pilot should cross-check the Nosewheel Steering selector position if the indication does not stabilize within the sample interval.
- The Stall Warning quantity display is expected to read within the sample range of 11 to 17 units during a diversion.

The captain will brief any change in the Traffic Advisory Display selector position and advise the other pilot if a discrepancy is observed. During engine start, both pilots should select the Bleed Air Supply annunciation when conditions permit. The pilot monitoring will verify any change in the Landing Gear Indication selector position and advise the other pilot if a discrepancy is observed. If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The first officer will monitor any change in the Hydraulic System B indication and advise the other pilot once the checklist item is complete.

CAUTION: The Engine Anti-Ice annunciation is expected to read within the sample range of 67 to 75 units during cruise. The pilot flying will select any change in the Thrust Reverser advisory and advise the other pilot when the associated caution light remains illuminated.

CAUTION: If the Flight Management Computer is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. During preflight, the relief pilot should select the Landing Gear Indication switch position when conditions permit. The Center Tank Pumps quantity display that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete.

12.10.2 Autopilot Channel A Interfaces

Both pilots will verify any change in the Fire Detection Loop selector position and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Transponder status message is expected to read within the sample range of 85 to 91 units during descent. The Oxygen Distribution selector position that differs from the expected state requires the Captain to brief the condition before the next phase of flight. During climb, the pilot flying should announce the Hydraulic System B status message once the checklist item is complete. The Autopilot Channel A switch position that differs from the expected state requires the relief pilot to brief the condition when conditions permit.

During a maintenance-requested ground run, the pilot monitoring should brief the Engine Anti-Ice status message if the indication does not stabilize within the sample interval. The pilot flying will announce any change in the Center

Tank Pumps indication and advise the other pilot if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Standby Instruments annunciation that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autothrottle status message	60 units	Normal
Standby Hydraulic annunciation	12 units	Normal
Bleed Air Supply annunciation	73 units	Monitor
Thrust Reverser status message	35 units	Refer to related topic
Landing Gear Indication selector position	4 units	Monitor

The Autopilot Channel A switch position that differs from the expected state requires the relief pilot to monitor the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will monitor any change in the Engine Anti-Ice selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During engine start, the First Officer should record the Wing Anti-Ice quantity display once the checklist item is complete.

During parking, the pilot monitoring should select the Hydraulic System B annunciation when conditions permit. The Cargo Smoke Detection status message that differs from the expected state requires the First Officer to monitor the condition when conditions permit. If the Window Heat is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. During cruise, the First Officer should cross-check the Pack Temperature Control status message when the associated caution light remains illuminated. The Autopilot Channel A status message that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. See 02.20.9 Weight Limitation 9.

- During descent, both pilots should monitor the Probe Heat advisory unless directed otherwise by the Sample Operations Center.
- The relief pilot will verify any change in the Autobrake Selector annunciation and advise the other pilot before the next phase of flight.
- During climb, the pilot monitoring should record the Autopilot Channel B indication if a discrepancy is observed.
- The Ground Proximity Monitor quantity display is expected to read within the sample range of 14 to 23 units during an extended ground delay.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

12.10.3 Autopilot Channel A Power Sources

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will brief any change in the Landing Gear Indication quantity display and advise the other pilot when operating at a sample station without ground power. The Hydraulic System A quantity display is expected to read within the sample range of 79 to 91 units during a turnaround. If the Pack Temperature Control is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The first officer will record any change in the Ground Proximity Monitor status message and advise the other pilot when conditions permit.

The Brake Temperature Monitor annunciation that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed indication is expected to read within the sample range of 22 to 27 units during climb. During descent, the Captain should announce the Pack Temperature Control advisory if a discrepancy is observed. The pilot flying will brief any change in the Landing Gear Indication quantity display and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
-----------	--------------	---------

Traffic Advisory Display status message	95 units	Normal
Stall Warning indication	11 units	Normal
Speedbrake Handle advisory	9 units	Normal
Thrust Reverser switch position	35 units	Normal
Engine Anti-Ice advisory	61 units	Normal

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. During cruise, the Captain should announce the Hydraulic System B switch position if a discrepancy is observed.

- If the Center Tank Pumps is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Stall Warning selector position is expected to read within the sample range of 56 to 61 units during an extended ground delay.
- The Hydraulic System B status message is expected to read within the sample range of 57 to 62 units during a diversion.
- During climb, both pilots should brief the Landing Gear Indication annunciation when operating at a sample station without ground power.
- During engine start, the First Officer should monitor the Hydraulic System B quantity display before the next phase of flight.

The relief pilot will monitor any change in the Landing Gear Indication advisory and advise the other pilot if a discrepancy is observed. The pilot flying will monitor any change in the Bleed Air Supply selector position and advise the other pilot when the associated caution light remains illuminated. During landing, the pilot monitoring should confirm the Nosewheel Steering selector position when operating at a sample station without ground power. The Wing Anti-Ice indication is expected to read within the sample range of 49 to 56 units during landing. During a turnaround, the pilot flying should announce the Hydraulic System A advisory if a discrepancy is observed. The pilot flying will brief any change in the Weather Radar status message and advise the other pilot before the next phase of flight.

12.10.4 Landing Gear Indication Reset Guidance

If the Wing Anti-Ice is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Cabin Pressure Controller selector position is expected to read within the sample range of 47 to 55 units during landing. The Window Heat indication is expected to read within the sample range of 56 to 59 units during takeoff. If the Nosewheel Steering is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

CAUTION: If the Cargo Smoke Detection is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

If the Weather Radar is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Hydraulic System B status message and advise the other pilot when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Hydraulic quantity display	91 units	Normal

Auxiliary Power Unit quantity display	92 units	Refer to related topic
Wing Anti-Ice status message	79 units	Refer to related topic
Fire Detection Loop advisory	9 units	Monitor
Autobrake Selector quantity display	42 units	Advisory only
Probe Heat switch position	9 units	Advisory only
Hydraulic System A selector position	73 units	Normal

CAUTION: The Autopilot Channel A switch position that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center. If the Fuel Crossfeed is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

12.10.5 Primary Electrical Bus Interfaces

During parking, both pilots should verify the Engine Anti-Ice quantity display unless directed otherwise by the Sample Operations Center. If the Traffic Advisory Display is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The captain will cross-check any change in the Fuel Crossfeed advisory and advise the other pilot once the checklist item is complete.

- During a maintenance-requested ground run, the relief pilot should verify the Standby Hydraulic quantity display if the indication does not stabilize within the sample interval.
- If the Traffic Advisory Display is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- The Bleed Air Supply indication that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

The Landing Gear Indication status message that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power. Both pilots will announce any change in the Standby Instruments selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Window Heat indication that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete.

Refer to the related topic for additional sample context. The relief pilot will select any change in the Pack Temperature Control annunciation and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. If the Probe Heat is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Hydraulic System B annunciation and advise the other pilot if a discrepancy is observed. During preflight, the relief pilot should brief the Transponder quantity display if a discrepancy is observed.

The Landing Gear Indication indication that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. If the Fire Detection Loop is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Oxygen Distribution is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The pilot flying will record any change in the Flap Position Indication selector position and advise the other pilot before the next phase of flight. During taxi, both pilots should select the Transponder annunciation once the checklist item is complete. See 13.10.9 Fire Detection Loop Power Sources.

12.10.6 Hydraulic System B Reset Guidance

During approach, the First Officer should announce the Center Tank Pumps indication once the checklist item is complete. If the Cargo Smoke Detection is inoperative, continue a diversion only after the pilot monitoring has

reviewed the associated sample guidance. The Primary Electrical Bus status message that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight.

- If the Wing Anti-Ice is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- The Autobrake Selector status message is expected to read within the sample range of 58 to 62 units during taxi.
- The Landing Gear Indication indication that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power.
- If the Transponder is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- The Fire Detection Loop status message that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval.
- During climb, the pilot flying should confirm the Traffic Advisory Display advisory when the associated caution light remains illuminated.

During an extended ground delay, the First Officer should monitor the Hydraulic System B selector position unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. Both pilots will verify any change in the Bleed Air Supply switch position and advise the other pilot once the checklist item is complete.

CAUTION: The Hydraulic System B status message is expected to read within the sample range of 86 to 97 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose.

- If the Center Tank Pumps is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- If the Autopilot Channel A is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- The Traffic Advisory Display quantity display is expected to read within the sample range of 39 to 45 units during descent.
- Values in this manual are invented and must not be used for any operational purpose.
- During a turnaround, the pilot monitoring should verify the Autobrake Selector status message before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The captain will brief any change in the Hydraulic System A annunciation and advise the other pilot when operating at a sample station without ground power.
- The first officer will record any change in the Standby Hydraulic switch position and advise the other pilot if a discrepancy is observed.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The Autobrake Selector advisory is expected to read within the sample range of 66 to 78 units during a maintenance-requested ground run.

The pilot monitoring will confirm any change in the Primary Electrical Bus indication and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the pilot flying should record the Standby Instruments indication when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will confirm any change in the Cockpit Voice Recorder switch position and advise the other pilot if a discrepancy is observed.

12.10.7 Fire Detection Loop Indications

The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the pilot monitoring should announce the Fire Detection Loop selector position unless directed otherwise by the Sample Operations Center. The Autopilot Channel B switch position that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated. If the Center Tank Pumps is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Bleed Air Supply status message that differs from the expected state requires the First Officer to record the condition before the next phase of flight. The Center Tank Pumps status message that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Center Tank Pumps selector position	7 units	Advisory only
Weather Radar switch position	3 units	Normal
Autobrake Selector indication	70 units	Monitor
Autobrake Selector status message	33 units	Refer to related topic

CAUTION: During a turnaround, both pilots should announce the Standby Instruments selector position when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. The Auxiliary Power Unit selector position that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval. During an extended ground delay, the pilot flying should confirm the Wing Anti-Ice status message when the associated caution light remains illuminated.

NOTE: The Window Heat indication is expected to read within the sample range of 20 to 23 units during an extended ground delay.

Condition	Sample value	Remarks
Center Tank Pumps advisory	19 units	Advisory only
Autobrake Selector annunciation	18 units	Refer to related topic
Weather Radar advisory	93 units	Advisory only
Nosewheel Steering annunciation	2 units	Advisory only
Window Heat annunciation	22 units	Refer to related topic
Ground Proximity Monitor status message	30 units	Normal

12.10.8 Transponder Interfaces

The first officer will monitor any change in the Flight Management Computer selector position and advise the other pilot when conditions permit. If the Transponder is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Traffic Advisory Display quantity display that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed. The Nosewheel Steering status message is expected to read within the sample range of 90 to 94 units during a turnaround. The Fire Detection Loop quantity display is expected to read within the sample range of 68 to 78 units during cruise.

- The first officer will verify any change in the Weather Radar quantity display and advise the other pilot once the checklist item is complete.
- The Cabin Pressure Controller selector position is expected to read within the sample range of 35 to 45 units during taxi.
- The pilot monitoring will announce any change in the Probe Heat annunciation and advise the other pilot when the associated caution light remains illuminated.
- During landing, the Captain should record the Pack Temperature Control quantity display when conditions permit.

The Ground Proximity Monitor status message that differs from the expected state requires both pilots to brief the condition once the checklist item is complete. Both pilots will announce any change in the Transponder advisory and advise the other pilot when operating at a sample station without ground power. If the Cargo Smoke Detection is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System A selector position is expected to read within the sample range of 21 to 33 units during climb. The Ground Proximity Monitor switch position is expected to read within the sample range of 36 to 41 units during landing.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Weather Radar advisory	75 units	Normal
Standby Hydraulic quantity display	14 units	Refer to related topic
Window Heat selector position	67 units	Monitor
Auxiliary Power Unit selector position	90 units	Normal
Standby Instruments indication	82 units	Monitor

NOTE: During a maintenance-requested ground run, the relief pilot should announce the Pack Temperature Control status message when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

NOTE: If the Standby Hydraulic is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

12.10.9 Center Tank Pumps Test

The pilot flying will brief any change in the Fuel Crossfeed selector position and advise the other pilot if a discrepancy is observed. The first officer will record any change in the Speedbrake Handle status message and advise the other pilot once the checklist item is complete. The captain will select any change in the Thrust Reverser advisory and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat advisory is expected to read within the sample range of 50 to 56 units during climb.

The Bleed Air Supply annunciation that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. The Thrust Reverser annunciation is expected to read within the sample range of 21 to 32 units during approach. The Landing Gear Indication quantity display is expected to read within the sample range of 40 to 44 units during parking. This text is fictional and exists only to give the prototype realistic volume and structure. If the Fuel Crossfeed is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

The Transponder status message is expected to read within the sample range of 43 to 52 units during a maintenance-requested ground run. If the Fuel Crossfeed is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Flap Position Indication indication is expected to read within the sample range of 45 to 51 units during approach. During engine start, the pilot flying should cross-check the Cargo Smoke Detection status message when the associated caution light remains illuminated.

The Hydraulic System A selector position that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat advisory that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete. Both pilots will monitor any change in the Fuel Crossfeed advisory and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
-----------	--------------	---------

Oxygen Distribution status message	41 units	Normal
Autothrottle quantity display	35 units	Advisory only
Stall Warning selector position	94 units	Advisory only

12.10.10 Autobrake Selector Indications

If the Standby Instruments is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

- If the Cockpit Voice Recorder is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- The Oxygen Distribution selector position is expected to read within the sample range of 68 to 76 units during climb.
- During descent, the relief pilot should select the Standby Instruments switch position if the indication does not stabilize within the sample interval.
- If the Primary Electrical Bus is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- If the Window Heat is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- During a diversion, the First Officer should announce the Traffic Advisory Display status message before the next phase of flight.

The relief pilot will cross-check any change in the Cockpit Voice Recorder advisory and advise the other pilot if a discrepancy is observed. During approach, the First Officer should cross-check the Speedbrake Handle selector position if the indication does not stabilize within the sample interval. If the Hydraulic System A is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. During landing, the pilot monitoring should record the Fire Detection Loop quantity display when operating at a sample station without ground power. During descent, the Captain should cross-check the Nosewheel Steering status message if a discrepancy is observed.

Condition	Sample value	Remarks
Hydraulic System A quantity display	90 units	Refer to related topic
Primary Electrical Bus quantity display	76 units	Refer to related topic
Autobrake Selector quantity display	67 units	Advisory only

- The Flight Management Computer status message that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.
- The Weather Radar indication is expected to read within the sample range of 7 to 14 units during a turnaround.
- Refer to the related topic for additional sample context.
- The Autothrottle quantity display is expected to read within the sample range of 88 to 100 units during engine start.
- The Hydraulic System B status message that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated.
- Both pilots will confirm any change in the Weather Radar quantity display and advise the other pilot when operating at a sample station without ground power.

If the Landing Gear Indication is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During climb, the relief pilot should brief the Probe Heat advisory when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- The Hydraulic System B status message is expected to read within the sample range of 44 to 56 units during approach.

12.10.11 Pack Temperature Control Crew Awareness

The Landing Gear Indication switch position that differs from the expected state requires the relief pilot to verify the condition once the checklist item is complete. During a diversion, both pilots should brief the Stall Warning status message once the checklist item is complete. The Landing Gear Indication status message is expected to read within the sample range of 70 to 73 units during preflight.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. During a maintenance-requested ground run, the pilot monitoring should confirm the Center Tank Pumps quantity display when operating at a sample station without ground power.

CAUTION: If the Transponder is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. During climb, the pilot monitoring should monitor the Speedbrake Handle quantity display unless directed otherwise by the Sample Operations Center.

CAUTION: If the Probe Heat is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Oxygen Distribution quantity display and advise the other pilot if a discrepancy is observed.

The Standby Hydraulic switch position that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. During a diversion, both pilots should announce the Autopilot Channel A status message if the indication does not stabilize within the sample interval. The relief pilot will brief any change in the Engine Anti-Ice advisory and advise the other pilot if a discrepancy is observed. The Auxiliary Power Unit annunciation is expected to read within the sample range of 79 to 90 units during a turnaround. If the Autopilot Channel B is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

NOTE: If the Ground Proximity Monitor is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During preflight, the pilot flying should announce the Oxygen Distribution status message unless directed otherwise by the Sample Operations Center.

12.10.12 Fuel Crossfeed Test

If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Probe Heat switch position is expected to read within the sample range of 5 to 11 units during approach. During taxi, the Captain should confirm the Ground Proximity Monitor quantity display when conditions permit. If the Weather Radar is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Bleed Air Supply is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

During takeoff, the pilot flying should monitor the Nosewheel Steering indication once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, the pilot monitoring should monitor the Window Heat status message if a discrepancy is observed. During parking, the relief pilot should brief the Thrust Reverser annunciation if the indication does not stabilize within the sample interval. The Auxiliary Power Unit switch position is expected to read within the sample range of 90 to 94 units during approach. Both pilots will confirm any change in the Flight Management Computer switch position and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Oxygen Distribution quantity display	31 units	Refer to related topic
Cockpit Voice Recorder switch position	46 units	Refer to related topic
Oxygen Distribution quantity display	25 units	Monitor
Autopilot Channel B switch position	34 units	Refer to related topic
Oxygen Distribution advisory	82 units	Refer to related topic
Landing Gear Indication switch position	87 units	Normal

Condition	Sample value	Remarks
Traffic Advisory Display switch position	9 units	Normal
Traffic Advisory Display advisory	88 units	Refer to related topic
Engine Anti-Ice indication	69 units	Refer to related topic
Hydraulic System B status message	62 units	Refer to related topic
Center Tank Pumps indication	72 units	Advisory only

The Cockpit Voice Recorder selector position that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. The Hydraulic System B indication that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. The Primary Electrical Bus quantity display that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete. During descent, the First Officer should monitor the Autopilot Channel A indication when the associated caution light remains illuminated. If the Cabin Pressure Controller is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During takeoff, the relief pilot should record the Speedbrake Handle selector position when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. If the Hydraulic System A is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. During landing, both pilots should verify the Standby Hydraulic switch position if a discrepancy is observed. The Window Heat switch position is expected to read within the sample range of 25 to 28 units during taxi.

If the Window Heat is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Autopilot Channel B is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Landing Gear Indication status message is expected to read within the sample range of 38 to 50 units during an extended ground delay. If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

NOTE: Refer to the related topic for additional sample context. Both pilots will cross-check any change in the Thrust Reverser selector position and advise the other pilot when operating at a sample station without ground power.

NOTE: The Engine Anti-Ice indication that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. During climb, both pilots should select the Engine Anti-Ice selector position when conditions permit.

12.10.13 Flight Management Computer Test

If the Cockpit Voice Recorder is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the Captain should monitor the Pack Temperature Control annunciation when conditions permit. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will brief any change in the Pack Temperature Control status message and advise the other pilot when conditions permit.

The first officer will cross-check any change in the Ground Proximity Monitor indication and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The Probe Heat advisory that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated. The Traffic Advisory Display status message that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. The Fire Detection Loop quantity display is expected to read within the sample range of 84 to 93 units during landing. The Ground Proximity Monitor switch position is expected to read within the sample range of 85 to 91 units during approach.

The Pack Temperature Control switch position is expected to read within the sample range of 22 to 31 units during an extended ground delay. The Standby Instruments quantity display is expected to read within the sample range of 66 to 72 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. During a maintenance-requested ground run, the pilot flying should record the Autopilot Channel A status message unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Nosewheel Steering annunciation	16 units	Normal
Fire Detection Loop annunciation	92 units	Monitor
Cockpit Voice Recorder status message	73 units	Normal
Hydraulic System B switch position	78 units	Normal

The Autopilot Channel B annunciation is expected to read within the sample range of 53 to 57 units during a maintenance-requested ground run. The Traffic Advisory Display annunciation that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center. During parking, the relief pilot should brief the Fuel Crossfeed indication when the associated caution light remains illuminated.

Values in this manual are invented and must not be used for any operational purpose. The Auxiliary Power Unit annunciation that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. The Oxygen Distribution switch position is expected to read within the sample range of 71 to 82 units during engine start. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will monitor any change in the Standby Hydraulic switch position and advise the other pilot if the indication does not stabilize within the sample interval.

- The Standby Instruments selector position that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval.
- If the Probe Heat is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- If the Autobrake Selector is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- If the Thrust Reverser is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Fire Detection Loop indication that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval.

Refer to the related topic for additional sample context. If the Autopilot Channel B is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The pilot flying will confirm any change in the Standby Hydraulic quantity display and advise the other pilot if a discrepancy is observed. The Brake Temperature Monitor status message is expected to read within the sample range of 37 to 40 units during landing. If the Cockpit Voice Recorder is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

If the Thrust Reverser is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Cabin Pressure Controller advisory that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval. The Primary Electrical Bus indication that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. The Transponder advisory is expected to read within the sample range of 21 to 26 units during climb. The Traffic Advisory Display quantity display that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated. The Flight Management Computer indication is expected to read within the sample range of 7 to 11 units during a maintenance-requested ground run.

12.10.14 Cockpit Voice Recorder Reset Guidance

During cruise, both pilots should select the Nosewheel Steering advisory when conditions permit. The Engine Anti-Ice quantity display that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight. The Traffic Advisory Display quantity display is expected to read within the sample range of 13 to 24 units during a turnaround.

During engine start, the Captain should announce the Speedbrake Handle status message unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice indication is expected to read within the sample range of 44 to 56 units during engine start. Refer to the related topic for additional sample context.

If the Auxiliary Power Unit is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Flap Position Indication indication that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed. During an extended ground delay, the First Officer should verify the Pack Temperature Control quantity display if a discrepancy is observed.

The first officer will verify any change in the Autobrake Selector annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Hydraulic System A indication	61 units	Normal
Flight Management Computer selector position	62 units	Normal
Ground Proximity Monitor selector position	63 units	Monitor

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Oxygen Distribution selector position is expected to read within the sample range of 8 to 16 units during cruise.
- The pilot flying will select any change in the Fuel Crossfeed selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Wing Anti-Ice is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- During a diversion, the pilot flying should record the Nosewheel Steering status message when conditions permit.

If the Center Tank Pumps is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector quantity display is expected to read within the sample range of 83 to 93 units during approach. During preflight, the pilot flying should verify the Primary Electrical Bus switch position when operating at a sample station without ground power.

Condition	Sample value	Remarks
Fuel Crossfeed switch position	42 units	Normal
Standby Hydraulic switch position	52 units	Monitor
Hydraulic System B quantity display	41 units	Advisory only
Auxiliary Power Unit indication	74 units	Refer to related topic

During takeoff, the pilot flying should cross-check the Bleed Air Supply indication when conditions permit. The Primary Electrical Bus switch position that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. During a turnaround, the First Officer should select the Pack Temperature Control switch position when operating at a sample station without ground power.

12.10.15 New Sample Topic: Pack Temperature Control

The Traffic Advisory Display advisory that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit advisory that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. During descent, the Captain should confirm the Pack Temperature Control status message if a discrepancy is observed. The first officer will brief any change in the Oxygen Distribution status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. If the Center Tank Pumps is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. The Primary Electrical Bus indication that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 49 to 57 units during climb. The Fuel Crossfeed advisory that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete.

If the Probe Heat is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Flap Position Indication selector position is expected to read within the sample range of 25 to 30 units during a maintenance-requested ground run.

The Cockpit Voice Recorder annunciation that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. The relief pilot will monitor any change in the Bleed Air Supply status message and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Auxiliary Power Unit status message that differs from the expected state requires the relief pilot to record the condition when conditions permit. The Nosewheel Steering quantity display that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated.

The pilot flying will cross-check any change in the Hydraulic System B advisory and advise the other pilot before the next phase of flight. During parking, both pilots should confirm the Nosewheel Steering annunciation if the indication does not stabilize within the sample interval. The Fuel Crossfeed quantity display that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

Values in this manual are invented and must not be used for any operational purpose. The Autothrottle indication that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within

the sample interval. If the Speedbrake Handle is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

The Pack Temperature Control quantity display is expected to read within the sample range of 50 to 56 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. The Bleed Air Supply switch position is expected to read within the sample range of 20 to 28 units during approach.

The captain will announce any change in the Standby Instruments advisory and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will cross-check any change in the Traffic Advisory Display indication and advise the other pilot when the associated caution light remains illuminated. The Cargo Smoke Detection indication that differs from the expected state requires the Captain to record the condition if a discrepancy is observed.

The Oxygen Distribution quantity display that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. If the Hydraulic System A is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. During a turnaround, the First Officer should brief the Traffic Advisory Display annunciation if a discrepancy is observed. Both pilots will select any change in the Primary Electrical Bus selector position and advise the other pilot when conditions permit. The first officer will announce any change in the Auxiliary Power Unit annunciation and advise the other pilot when conditions permit. The Cockpit Voice Recorder status message that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center.

12.10.16 Flap Position Indication Crew Awareness

The Autopilot Channel A status message that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight. The Engine Anti-Ice switch position is expected to read within the sample range of 71 to 74 units during engine start. The Hydraulic System B quantity display that differs from the expected state requires the pilot monitoring to select the condition when conditions permit.

If the Wing Anti-Ice is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The captain will cross-check any change in the Window Heat quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Thrust Reverser is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Standby Instruments indication is expected to read within the sample range of 41 to 51 units during landing. During approach, the pilot monitoring should select the Pack Temperature Control status message unless directed otherwise by the Sample Operations Center. During a maintenance-requested ground run, the relief pilot should brief the Brake Temperature Monitor selector position unless directed otherwise by the Sample Operations Center.

If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Oxygen Distribution indication and advise the other pilot once the checklist item is complete. During climb, the Captain should announce the Fire Detection Loop switch position before the next phase of flight. If the Autopilot Channel A is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. During engine start, the First Officer should announce the Nosewheel Steering selector position unless directed otherwise by the Sample Operations Center.

- During landing, the pilot flying should announce the Probe Heat quantity display when the associated caution light remains illuminated.
- The Cargo Smoke Detection indication is expected to read within the sample range of 94 to 101 units during parking.
- The captain will brief any change in the Cockpit Voice Recorder status message and advise the other pilot when conditions permit.
- The Stall Warning annunciation that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autobrake Selector annunciation	49 units	Refer to related topic
Auxiliary Power Unit selector position	66 units	Advisory only
Auxiliary Power Unit status message	75 units	Refer to related topic
Autopilot Channel B indication	43 units	Normal

NOTE: The Brake Temperature Monitor advisory is expected to read within the sample range of 93 to 105 units during a maintenance-requested ground run. Refer to the related topic for additional sample context.

NOTE: Refer to the related topic for additional sample context. If the Speedbrake Handle is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

During taxi, the First Officer should record the Probe Heat quantity display when the associated caution light remains illuminated. The relief pilot will cross-check any change in the Ground Proximity Monitor switch position and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the relief pilot should record the Fire Detection Loop status message if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

- If the Fire Detection Loop is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.
- The Landing Gear Indication status message is expected to read within the sample range of 41 to 46 units during cruise.
- If the Traffic Advisory Display is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.
- If the Bleed Air Supply is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.
- The Engine Anti-Ice annunciation that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center.

12.20 Controls and Indicators

12.20.1 Fuel Crossfeed Normal Operation

This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat advisory is expected to read within the sample range of 36 to 41 units during takeoff. Refer to the related topic for additional sample context. The first officer will verify any change in the Standby Hydraulic switch position and advise the other pilot if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. The Flap Position Indication quantity display that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center. During a turnaround, the relief pilot should brief the Center Tank Pumps switch position when the associated caution light remains illuminated. During a maintenance-requested ground run, both pilots should announce the Hydraulic System B annunciation before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. During a diversion, the pilot flying should cross-check the Autopilot Channel B annunciation when the associated caution light remains illuminated.

The pilot flying will record any change in the Center Tank Pumps annunciation and advise the other pilot once the checklist item is complete. The Window Heat advisory is expected to read within the sample range of 38 to 50 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will select any change in the Standby Instruments indication and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: During engine start, the Captain should confirm the Oxygen Distribution switch position when operating at a sample station without ground power.

The Fire Detection Loop status message is expected to read within the sample range of 47 to 57 units during a turnaround. The relief pilot will announce any change in the Brake Temperature Monitor quantity display and advise the other pilot when the associated caution light remains illuminated. The captain will announce any change in the Autopilot Channel B indication and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

During approach, the relief pilot should verify the Flight Management Computer status message when operating at a sample station without ground power. The first officer will announce any change in the Probe Heat switch position and advise the other pilot when the associated caution light remains illuminated. The relief pilot will cross-check any change in the Ground Proximity Monitor advisory and advise the other pilot when conditions permit. The Fuel Crossfeed quantity display that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. The captain will verify any change in the Traffic Advisory Display quantity display and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

12.20.2 Autopilot Channel A Interfaces

The Nosewheel Steering quantity display that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. During parking, the Captain should cross-check the Bleed Air Supply status message when conditions permit. If the Cabin Pressure Controller is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The Primary Electrical Bus annunciation that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.

The Standby Instruments status message is expected to read within the sample range of 57 to 63 units during approach. During a diversion, the First Officer should brief the Weather Radar quantity display if a discrepancy is observed. During approach, the pilot flying should announce the Bleed Air Supply annunciation if a discrepancy is observed. The captain will record any change in the Stall Warning indication and advise the other pilot when operating at a sample station without ground power. The Brake Temperature Monitor advisory is expected to read within the sample range of 89 to 95 units during approach.

If the Primary Electrical Bus is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. During taxi, the Captain should select the Cabin Pressure Controller quantity display before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Instruments status message is expected to read within the sample range of 12 to 23 units during engine start. The Cargo Smoke Detection indication is expected to read within the sample range of 10 to 14 units during descent. The Wing Anti-Ice quantity display that differs from the expected state requires the relief pilot to record the condition before the next phase of flight.

- If the Transponder is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.
- The Flight Management Computer selector position is expected to read within the sample range of 44 to 53 units during preflight.
- The Bleed Air Supply annunciation that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated.
- The Wing Anti-Ice advisory that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power.

NOTE: The first officer will select any change in the Transponder switch position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
-----------	--------------	---------

Transponder switch position	53 units	Normal
Flap Position Indication quantity display	71 units	Advisory only
Brake Temperature Monitor advisory	87 units	Monitor
Wing Anti-Ice advisory	95 units	Normal

- The Fire Detection Loop selector position is expected to read within the sample range of 92 to 99 units during cruise.
- The Hydraulic System B status message is expected to read within the sample range of 75 to 87 units during landing.
- The Hydraulic System A switch position that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval.

12.20.3 Speedbrake Handle Test

This text is fictional and exists only to give the prototype realistic volume and structure. The captain will announce any change in the Ground Proximity Monitor indication and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Stall Warning selector position that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. See 04.20.8 Crew Coordination: Nosewheel Steering.

NOTE: If the Engine Anti-Ice is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

- If the Autobrake Selector is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- The Autobrake Selector advisory is expected to read within the sample range of 49 to 61 units during climb.
- The Autobrake Selector annunciation that differs from the expected state requires both pilots to brief the condition once the checklist item is complete.
- The Pack Temperature Control status message is expected to read within the sample range of 98 to 110 units during cruise.

Condition	Sample value	Remarks
Thrust Reverser switch position	31 units	Normal
Center Tank Pumps advisory	26 units	Normal
Bleed Air Supply switch position	36 units	Refer to related topic

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure.

12.20.4 Autopilot Channel B Limits Display

The relief pilot will confirm any change in the Fuel Crossfeed annunciation and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. During descent, the relief pilot should select the Bleed Air Supply annunciation once the checklist item is complete. The relief pilot will brief any change in the Wing Anti-Ice advisory and advise the other pilot before the next phase of flight. The pilot flying will select any change in the Hydraulic System B annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. See 05.10.17 Fire Detection Loop Overview.

Condition	Sample value	Remarks
Autopilot Channel B selector position	53 units	Monitor

Ground Proximity Monitor annunciation	34 units	Normal
Nosewheel Steering switch position	14 units	Normal
Stall Warning indication	21 units	Monitor
Hydraulic System A indication	47 units	Refer to related topic
Window Heat advisory	48 units	Normal

- The Cockpit Voice Recorder selector position is expected to read within the sample range of 66 to 76 units during cruise.
- If the Flight Management Computer is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.
- During a turnaround, the relief pilot should announce the Ground Proximity Monitor switch position when conditions permit.
- Both pilots will cross-check any change in the Autobrake Selector indication and advise the other pilot when operating at a sample station without ground power.
- During an extended ground delay, both pilots should verify the Standby Instruments indication when operating at a sample station without ground power.
- If the Probe Heat is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	7 units	Monitor
Autopilot Channel B quantity display	69 units	Refer to related topic
Oxygen Distribution advisory	31 units	Normal
Oxygen Distribution quantity display	58 units	Normal
Primary Electrical Bus indication	10 units	Monitor

Condition	Sample value	Remarks
Stall Warning status message	19 units	Normal
Speedbrake Handle quantity display	17 units	Advisory only
Transponder annunciation	89 units	Refer to related topic

CAUTION: The Stall Warning status message that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. The pilot monitoring will brief any change in the Landing Gear Indication selector position and advise the other pilot before the next phase of flight.

- The Cargo Smoke Detection advisory that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- The Autothrottle indication that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated.
- If the Cargo Smoke Detection is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: If the Engine Anti-Ice is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

12.20.5 Landing Gear Indication Interfaces

The Transponder switch position is expected to read within the sample range of 16 to 27 units during parking. Values in this manual are invented and must not be used for any operational purpose. The Primary Electrical Bus annunciation is expected to read within the sample range of 83 to 87 units during descent.

NOTE: If the Window Heat is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The first officer will monitor any change in the Hydraulic System A status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Oxygen Distribution status message that differs from the expected state requires the Captain to announce the condition once the checklist item is complete. Both pilots will confirm any change in the Autopilot Channel A annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The captain will confirm any change in the Traffic Advisory Display advisory and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Flap Position Indication switch position is expected to read within the sample range of 45 to 57 units during cruise. During a turnaround, the Captain should cross-check the Center Tank Pumps quantity display once the checklist item is complete.

If the Autothrottle is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. During landing, the Captain should announce the Center Tank Pumps indication when the associated caution light remains illuminated. The Primary Electrical Bus indication is expected to read within the sample range of 44 to 53 units during climb.

Condition	Sample value	Remarks
Brake Temperature Monitor annunciation	85 units	Advisory only
Speedbrake Handle advisory	13 units	Monitor
Wing Anti-Ice switch position	32 units	Monitor
Center Tank Pumps quantity display	29 units	Refer to related topic

CAUTION: If the Autobrake Selector is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

- The Brake Temperature Monitor annunciation is expected to read within the sample range of 98 to 103 units during parking.
- The Autobrake Selector status message is expected to read within the sample range of 14 to 18 units during climb.
- The Center Tank Pumps annunciation that differs from the expected state requires the relief pilot to monitor the condition before the next phase of flight.
- Refer to the related topic for additional sample context.
- If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.
- The Fire Detection Loop indication that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated.

During climb, both pilots should verify the Nosewheel Steering annunciation when operating at a sample station without ground power. The pilot monitoring will brief any change in the Wing Anti-Ice switch position and advise the other pilot once the checklist item is complete. The Primary Electrical Bus advisory is expected to read within the sample range of 15 to 23 units during engine start. The Ground Proximity Monitor switch position that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated. The pilot monitoring will record any change in the Stall Warning switch position and advise the other pilot once the checklist item is complete. See 03.50.7 Crew Coordination: Center Tank Pumps.

12.20.6 Traffic Advisory Display Status Messages

If the Primary Electrical Bus is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector selector position is expected to read within the sample range of 92 to 96 units during engine start. During parking, the relief pilot should verify the Thrust Reverser advisory if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Thrust Reverser status message is expected to read within the sample range of 3 to 9 units during preflight. If the Autothrottle is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

Both pilots will select any change in the Nosewheel Steering annunciation and advise the other pilot if a discrepancy is observed. The Landing Gear Indication switch position is expected to read within the sample range of 67 to 70 units during engine start. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will verify any change in the Nosewheel Steering annunciation and advise the other pilot when conditions permit. The Center Tank Pumps indication is expected to read within the sample range of 82 to 88 units during landing.

If the Oxygen Distribution is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The captain will cross-check any change in the Fuel Crossfeed indication and advise the other pilot when the associated caution light remains illuminated. If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System A switch position that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

12.20.7 Standby Instruments Test

The Transponder indication is expected to read within the sample range of 26 to 33 units during taxi. The Probe Heat selector position is expected to read within the sample range of 85 to 92 units during takeoff. The Primary Electrical Bus annunciation is expected to read within the sample range of 81 to 93 units during an extended ground delay.

Condition	Sample value	Remarks
Thrust Reverser switch position	78 units	Monitor
Autopilot Channel A annunciation	32 units	Refer to related topic
Standby Instruments selector position	6 units	Refer to related topic
Cargo Smoke Detection status message	47 units	Monitor
Pack Temperature Control annunciation	36 units	Normal

CAUTION: If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

If the Speedbrake Handle is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. Both pilots will brief any change in the Weather Radar advisory and advise the other pilot if a discrepancy is observed. The pilot monitoring will select any change in the Flight Management Computer annunciation and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

The Flight Management Computer annunciation that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. The Hydraulic System B advisory is expected to read within the sample range of 90 to 99 units during a diversion. The Cargo Smoke Detection annunciation is expected to read within the sample range of 3 to 13 units during landing. The Speedbrake Handle status message is expected to read within the sample range of 46 to 55 units during takeoff. The Speedbrake Handle status message that differs from the expected

state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. The Landing Gear Indication switch position that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed.

12.20.8 Bleed Air Supply Power Sources

During cruise, the relief pilot should monitor the Flap Position Indication switch position when the associated caution light remains illuminated. The captain will verify any change in the Autopilot Channel A indication and advise the other pilot when conditions permit. During preflight, the Captain should announce the Auxiliary Power Unit quantity display if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, the pilot monitoring should select the Autopilot Channel B selector position when conditions permit. The pilot monitoring will monitor any change in the Autothrottle advisory and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Autothrottle quantity display	20 units	Normal
Thrust Reverser status message	45 units	Normal
Flap Position Indication advisory	48 units	Monitor
Transponder switch position	80 units	Normal
Fire Detection Loop annunciation	39 units	Refer to related topic

During descent, the Captain should brief the Weather Radar switch position unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The captain will cross-check any change in the Stall Warning indication and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Fire Detection Loop is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Wing Anti-Ice selector position is expected to read within the sample range of 7 to 10 units during a turnaround. If the Hydraulic System B is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During takeoff, the pilot flying should monitor the Nosewheel Steering quantity display if the indication does not stabilize within the sample interval.

This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, both pilots should cross-check the Primary Electrical Bus selector position if a discrepancy is observed. The Center Tank Pumps indication is expected to read within the sample range of 86 to 90 units during taxi. The Standby Hydraulic selector position that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, both pilots should announce the Landing Gear Indication quantity display when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autopilot Channel A advisory	17 units	Normal
Speedbrake Handle selector position	41 units	Normal
Speedbrake Handle advisory	49 units	Advisory only
Fire Detection Loop selector position	31 units	Normal

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The captain will announce any change in the Flight Management Computer annunciation and advise the other pilot if a discrepancy is observed.

12.20.9 Center Tank Pumps Limits Display

If the Standby Instruments is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During takeoff, the pilot monitoring should brief the Flight Management Computer quantity display when conditions permit. The Flap Position Indication advisory that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. If the Speedbrake Handle is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Stall Warning indication is expected to read within the sample range of 12 to 20 units during an extended ground delay.

Condition	Sample value	Remarks
Weather Radar selector position	90 units	Advisory only
Bleed Air Supply advisory	48 units	Refer to related topic
Window Heat switch position	13 units	Refer to related topic
Oxygen Distribution selector position	34 units	Refer to related topic
Autobrake Selector indication	11 units	Normal
Nosewheel Steering switch position	88 units	Monitor

NOTE: During climb, both pilots should verify the Flight Management Computer quantity display unless directed otherwise by the Sample Operations Center.

The pilot flying will record any change in the Fire Detection Loop advisory and advise the other pilot when operating at a sample station without ground power. The Probe Heat quantity display that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval. If the Oxygen Distribution is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The pilot flying will monitor any change in the Landing Gear Indication switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will verify any change in the Center Tank Pumps selector position and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. If the Brake Temperature Monitor is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

During descent, the Captain should monitor the Hydraulic System B quantity display if a discrepancy is observed. The Autopilot Channel A status message that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete. Refer to the related topic for additional sample context. If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will confirm any change in the Thrust Reverser switch position and advise the other pilot if the indication does not stabilize within the sample interval.

The Fire Detection Loop advisory that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power. During descent, the First Officer should record the Thrust Reverser selector position when the associated caution light remains illuminated. The Thrust Reverser selector position is expected to read within the sample range of 12 to 15 units during takeoff. During taxi, the relief pilot should cross-check the Cockpit Voice Recorder selector position if a discrepancy is observed.

CAUTION: The Engine Anti-Ice status message that differs from the expected state requires both pilots to confirm the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

12.20.10 Speedbrake Handle Status Messages

The Weather Radar advisory that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. The Fire Detection Loop switch position that differs from the expected state

requires the pilot flying to select the condition when the associated caution light remains illuminated. During landing, the pilot flying should verify the Standby Hydraulic switch position when conditions permit. The Primary Electrical Bus status message is expected to read within the sample range of 39 to 51 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During an extended ground delay, the pilot monitoring should announce the Fire Detection Loop advisory when operating at a sample station without ground power.

The Transponder quantity display that differs from the expected state requires the First Officer to record the condition when conditions permit. The Wing Anti-Ice status message is expected to read within the sample range of 17 to 26 units during climb. During landing, the pilot flying should brief the Nosewheel Steering indication if a discrepancy is observed. The Auxiliary Power Unit switch position that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated.

CAUTION: The Center Tank Pumps advisory that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center. If the Hydraulic System B is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Cabin Pressure Controller switch position that differs from the expected state requires the First Officer to select the condition when conditions permit.

- If the Oxygen Distribution is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.
- If the Standby Hydraulic is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- During climb, both pilots should monitor the Autopilot Channel B quantity display before the next phase of flight.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

12.20.11 Thrust Reverser Status Messages

During cruise, the Captain should cross-check the Brake Temperature Monitor quantity display when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the pilot flying should verify the Ground Proximity Monitor indication once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. The Bleed Air Supply selector position is expected to read within the sample range of 97 to 106 units during takeoff. Refer to the related topic for additional sample context.

NOTE: During climb, the Captain should select the Ground Proximity Monitor annunciation if the indication does not stabilize within the sample interval.

If the Wing Anti-Ice is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During cruise, the Captain should monitor the Cockpit Voice Recorder selector position unless directed otherwise by the Sample Operations Center.

The Hydraulic System A quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed. The first officer will record any change in the Center Tank Pumps status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Engine Anti-Ice selector position that differs from the expected state requires the pilot flying to cross-check the condition if a discrepancy is observed. Both pilots will verify any change in the Standby Instruments selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Fire Detection Loop is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

If the Fuel Crossfeed is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

The pilot monitoring will brief any change in the Window Heat indication and advise the other pilot when operating at a sample station without ground power. The captain will announce any change in the Autopilot Channel A advisory and advise the other pilot before the next phase of flight. During approach, the relief pilot should cross-check the Brake Temperature Monitor indication unless directed otherwise by the Sample Operations Center. The relief pilot will select any change in the Center Tank Pumps selector position and advise the other pilot when conditions permit. The pilot monitoring will announce any change in the Flight Management Computer selector position and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Cargo Smoke Detection switch position	29 units	Advisory only
Flight Management Computer advisory	50 units	Normal
Standby Hydraulic status message	28 units	Normal
Autopilot Channel B status message	46 units	Advisory only

NOTE: The first officer will record any change in the Autopilot Channel B selector position and advise the other pilot if a discrepancy is observed.

12.20.12 Landing Gear Indication Normal Operation

During descent, the First Officer should select the Autobrake Selector advisory unless directed otherwise by the Sample Operations Center. During taxi, the First Officer should select the Ground Proximity Monitor advisory before the next phase of flight. If the Cargo Smoke Detection is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Standby Instruments annunciation is expected to read within the sample range of 18 to 21 units during preflight. The first officer will select any change in the Thrust Reverser indication and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The Flap Position Indication annunciation that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. During a maintenance-requested ground run, the Captain should cross-check the Speedbrake Handle status message once the checklist item is complete. The Flight Management Computer quantity display that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 71 to 77 units during taxi. The Flap Position Indication switch position is expected to read within the sample range of 94 to 99 units during an extended ground delay.

If the Speedbrake Handle is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The Thrust Reverser indication is expected to read within the sample range of 71 to 82 units during a diversion. The Wing Anti-Ice annunciation that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed. If the Traffic Advisory Display is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

The first officer will select any change in the Primary Electrical Bus selector position and advise the other pilot if the indication does not stabilize within the sample interval. During descent, the First Officer should monitor the Thrust Reverser quantity display unless directed otherwise by the Sample Operations Center. The pilot flying will select any change in the Transponder status message and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Hydraulic System B is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The captain will cross-check any change in the Wing Anti-Ice switch position and

advise the other pilot once the checklist item is complete.

12.20.13 Fuel Crossfeed Indications

The captain will confirm any change in the Weather Radar advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Nosewheel Steering status message that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

CAUTION: The Weather Radar quantity display is expected to read within the sample range of 8 to 16 units during taxi.

- The first officer will cross-check any change in the Nosewheel Steering indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Fuel Crossfeed selector position that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval.
- If the Auxiliary Power Unit is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.
- During climb, both pilots should monitor the Autothrottle selector position when operating at a sample station without ground power.
- The Autothrottle indication is expected to read within the sample range of 15 to 26 units during engine start.

If the Ground Proximity Monitor is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Fire Detection Loop switch position that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed. During a diversion, both pilots should monitor the Auxiliary Power Unit advisory if the indication does not stabilize within the sample interval.

NOTE: The pilot monitoring will verify any change in the Ground Proximity Monitor annunciation and advise the other pilot when operating at a sample station without ground power.

NOTE: Values in this manual are invented and must not be used for any operational purpose. If the Primary Electrical Bus is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

The relief pilot will confirm any change in the Thrust Reverser quantity display and advise the other pilot before the next phase of flight. The Window Heat selector position that differs from the expected state requires the pilot flying to verify the condition when conditions permit. The Autopilot Channel B switch position is expected to read within the sample range of 65 to 70 units during preflight. This text is fictional and exists only to give the prototype realistic volume and structure. During a maintenance-requested ground run, the pilot flying should monitor the Cargo Smoke Detection switch position when conditions permit. During preflight, the pilot flying should cross-check the Cabin Pressure Controller indication before the next phase of flight.

The Nosewheel Steering indication is expected to read within the sample range of 68 to 77 units during a diversion. The Cockpit Voice Recorder status message is expected to read within the sample range of 29 to 33 units during approach. The first officer will brief any change in the Engine Anti-Ice status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

12.20.14 Autothrottle Power Sources

The Landing Gear Indication switch position that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed. The Autopilot Channel B quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated. If the Standby Instruments is inoperative, continue climb only after the pilot flying has reviewed the associated sample

guidance. The pilot flying will confirm any change in the Nosewheel Steering status message and advise the other pilot when conditions permit.

NOTE: If the Primary Electrical Bus is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Autothrottle quantity display that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Engine Anti-Ice status message	12 units	Advisory only
Pack Temperature Control advisory	61 units	Normal
Fuel Crossfeed indication	82 units	Monitor
Standby Instruments quantity display	51 units	Normal
Landing Gear Indication status message	58 units	Normal
Nosewheel Steering advisory	39 units	Normal

During cruise, the First Officer should select the Hydraulic System B advisory when operating at a sample station without ground power. If the Wing Anti-Ice is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Traffic Advisory Display indication is expected to read within the sample range of 37 to 42 units during preflight.

Condition	Sample value	Remarks
Hydraulic System A annunciation	37 units	Normal
Standby Hydraulic indication	97 units	Advisory only
Standby Instruments status message	93 units	Advisory only
Fuel Crossfeed status message	17 units	Monitor

12.20.15 Auxiliary Power Unit Interfaces

During takeoff, the relief pilot should verify the Standby Instruments indication when operating at a sample station without ground power. During taxi, the pilot monitoring should announce the Bleed Air Supply advisory once the checklist item is complete. The relief pilot will record any change in the Speedbrake Handle switch position and advise the other pilot once the checklist item is complete. During engine start, the pilot monitoring should announce the Flight Management Computer quantity display when the associated caution light remains illuminated. The Brake Temperature Monitor status message that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.

NOTE: If the Standby Instruments is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Flap Position Indication selector position that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete.

CAUTION: The Cabin Pressure Controller indication that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit.

CAUTION: The first officer will confirm any change in the Probe Heat status message and advise the other pilot when operating at a sample station without ground power.

During taxi, the Captain should verify the Flight Management Computer switch position before the next phase of flight. The pilot flying will record any change in the Transponder status message and advise the other pilot once the checklist item is complete. During takeoff, the First Officer should monitor the Hydraulic System A status message once the checklist item is complete. The first officer will select any change in the Ground Proximity Monitor indication and advise the other pilot before the next phase of flight. If the Nosewheel Steering is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will select any change in the Standby Instruments quantity display and advise the other pilot when conditions permit.

Both pilots will record any change in the Standby Hydraulic switch position and advise the other pilot if a discrepancy is observed. The captain will record any change in the Center Tank Pumps annunciation and advise the other pilot once the checklist item is complete. The first officer will confirm any change in the Stall Warning indication and advise the other pilot when operating at a sample station without ground power. During landing, the pilot monitoring should brief the Ground Proximity Monitor advisory when the associated caution light remains illuminated.

12.20.16 Cargo Smoke Detection Power Sources

The Brake Temperature Monitor advisory is expected to read within the sample range of 31 to 35 units during a maintenance-requested ground run. The pilot flying will confirm any change in the Transponder selector position and advise the other pilot before the next phase of flight. If the Auxiliary Power Unit is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

Both pilots will record any change in the Autothrottle selector position and advise the other pilot once the checklist item is complete. The relief pilot will cross-check any change in the Autopilot Channel B selector position and advise the other pilot if the indication does not stabilize within the sample interval. The captain will confirm any change in the Hydraulic System A indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Nosewheel Steering status message that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. The Autobrake Selector annunciation is expected to read within the sample range of 18 to 23 units during an extended ground delay. The first officer will cross-check any change in the Transponder advisory and advise the other pilot when the associated caution light remains illuminated.

CAUTION: During preflight, the pilot flying should confirm the Landing Gear Indication annunciation when conditions permit.

- During an extended ground delay, the pilot monitoring should cross-check the Pack Temperature Control annunciation when conditions permit.
- The Thrust Reverser quantity display is expected to read within the sample range of 45 to 55 units during preflight.
- Refer to the related topic for additional sample context.

The Weather Radar quantity display that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. The Standby Instruments indication that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete. The relief pilot will cross-check any change in the Probe Heat advisory and advise the other pilot before the next phase of flight. The pilot monitoring will cross-check any change in the Cockpit Voice Recorder quantity display and advise the other pilot once the checklist item is complete.

The Flap Position Indication switch position is expected to read within the sample range of 3 to 15 units during approach. The pilot flying will verify any change in the Traffic Advisory Display selector position and advise the other pilot when operating at a sample station without ground power. The first officer will record any change in the Flight Management Computer switch position and advise the other pilot when operating at a sample station without ground power. During engine start, the First Officer should confirm the Pack Temperature Control switch position when the associated caution light remains illuminated. During parking, the pilot flying should cross-check the Pack Temperature Control indication when the associated caution light remains illuminated.

12.30 Operation

12.30.1 Stall Warning Interfaces

Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The Nosewheel Steering switch position is expected to read within the sample range of 15 to 20 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure.

The Thrust Reverser switch position that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center. If the Wing Anti-Ice is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Flap Position Indication switch position is expected to read within the sample range of 18 to 23 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Oxygen Distribution quantity display that differs from the expected state requires both pilots to record the condition if a discrepancy is observed.

The Window Heat quantity display is expected to read within the sample range of 38 to 49 units during descent. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will monitor any change in the Fuel Crossfeed switch position and advise the other pilot if a discrepancy is observed. If the Probe Heat is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. During takeoff, the pilot flying should select the Autopilot Channel A status message when operating at a sample station without ground power.

- The Thrust Reverser annunciation is expected to read within the sample range of 29 to 41 units during descent.
- The Speedbrake Handle switch position is expected to read within the sample range of 83 to 87 units during landing.
- The Autothrottle selector position that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight.

CAUTION: If the Autopilot Channel B is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. During climb, the First Officer should verify the Weather Radar status message if the indication does not stabilize within the sample interval.

CAUTION: The Autopilot Channel A indication that differs from the expected state requires the First Officer to verify the condition before the next phase of flight. If the Nosewheel Steering is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

If the Pack Temperature Control is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Traffic Advisory Display quantity display is expected to read within the sample range of 53 to 59 units during descent. During preflight, the relief pilot should confirm the Window Heat advisory when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Brake Temperature Monitor selector position that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

12.30.2 Stall Warning Power Sources

During engine start, both pilots should record the Transponder advisory before the next phase of flight. During engine start, both pilots should announce the Brake Temperature Monitor quantity display if a discrepancy is observed. The pilot monitoring will monitor any change in the Autopilot Channel B selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Oxygen Distribution switch position	62 units	Refer to related topic
Autobrake Selector quantity display	17 units	Advisory only
Cockpit Voice Recorder quantity display	80 units	Normal

- If the Cockpit Voice Recorder is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The first officer will brief any change in the Bleed Air Supply switch position and advise the other pilot if a discrepancy is observed.
- The pilot monitoring will verify any change in the Autothrottle selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Flight Management Computer is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

The Autobrake Selector selector position is expected to read within the sample range of 36 to 45 units during preflight. The Stall Warning indication is expected to read within the sample range of 65 to 76 units during preflight. During a turnaround, both pilots should announce the Cockpit Voice Recorder annunciation when conditions permit. Refer to the related topic for additional sample context. During engine start, both pilots should record the Primary Electrical Bus selector position when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. During landing, the First Officer should select the Thrust Reverser indication when operating at a sample station without ground power. The pilot flying will announce any change in the Stall Warning indication and advise the other pilot when conditions permit. Both pilots will brief any change in the Brake Temperature Monitor switch position and advise the other pilot when the associated caution light remains illuminated. During descent, the First Officer should monitor the Window Heat quantity display if a discrepancy is observed. During preflight, the pilot monitoring should announce the Autobrake Selector annunciation when the associated caution light remains illuminated.

The Cargo Smoke Detection status message is expected to read within the sample range of 85 to 90 units during approach. The Probe Heat quantity display is expected to read within the sample range of 86 to 89 units during takeoff. The Cockpit Voice Recorder indication that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight.

12.30.3 Center Tank Pumps Status Messages

The Flight Management Computer annunciation is expected to read within the sample range of 35 to 45 units during climb. If the Flap Position Indication is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Pack Temperature Control switch position that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

The Cargo Smoke Detection status message is expected to read within the sample range of 92 to 100 units during takeoff. If the Autobrake Selector is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

CAUTION: If the Standby Instruments is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

NOTE: If the Flap Position Indication is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The first officer will verify any change in the Nosewheel Steering selector position and advise the other pilot before the next phase of flight.

If the Cabin Pressure Controller is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The relief pilot will monitor any change in the Window Heat indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Standby Instruments annunciation that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed. The Autopilot Channel B

annunciation is expected to read within the sample range of 12 to 15 units during a turnaround. The captain will monitor any change in the Fuel Crossfeed indication and advise the other pilot when the associated caution light remains illuminated. The Autopilot Channel A quantity display that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power.

During a diversion, the pilot monitoring should confirm the Pack Temperature Control status message when conditions permit. The pilot flying will verify any change in the Standby Instruments quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During cruise, the pilot monitoring should verify the Autothrottle status message when operating at a sample station without ground power. The Brake Temperature Monitor annunciation is expected to read within the sample range of 93 to 104 units during a diversion.

Condition	Sample value	Remarks
Nosewheel Steering quantity display	18 units	Refer to related topic
Thrust Reverser quantity display	81 units	Advisory only
Center Tank Pumps selector position	4 units	Monitor
Cockpit Voice Recorder indication	35 units	Refer to related topic
Speedbrake Handle advisory	12 units	Normal
Cargo Smoke Detection indication	20 units	Refer to related topic
Transponder quantity display	77 units	Advisory only

The wording here is placeholder content shaped like a procedure, not a procedure. The captain will announce any change in the Flap Position Indication selector position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. If the Weather Radar is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will announce any change in the Hydraulic System A indication and advise the other pilot unless directed otherwise by the Sample Operations Center. See 06.40.2 Stall Warning Overview.

NOTE: During preflight, the pilot monitoring should monitor the Autopilot Channel B status message when operating at a sample station without ground power. During a turnaround, the Captain should verify the Auxiliary Power Unit status message if the indication does not stabilize within the sample interval.

12.30.4 Standby Instruments Indications

The wording here is placeholder content shaped like a procedure, not a procedure. If the Engine Anti-Ice is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The captain will monitor any change in the Oxygen Distribution quantity display and advise the other pilot before the next phase of flight.

During a maintenance-requested ground run, the pilot flying should cross-check the Speedbrake Handle indication unless directed otherwise by the Sample Operations Center. The Nosewheel Steering selector position that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. If the Weather Radar is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Speedbrake Handle advisory that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated.

The Flight Management Computer indication is expected to read within the sample range of 52 to 63 units during cruise. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. During cruise, the pilot flying should record the Autobrake Selector advisory if a discrepancy is observed. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 95 to 103 units during parking.

Refer to the related topic for additional sample context. During landing, the First Officer should verify the Brake Temperature Monitor advisory when the associated caution light remains illuminated. If the Bleed Air Supply is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The Autobrake

Selector advisory is expected to read within the sample range of 38 to 47 units during landing.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Pack Temperature Control is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Engine Anti-Ice advisory that differs from the expected state requires the Captain to record the condition before the next phase of flight. Both pilots will brief any change in the Weather Radar selector position and advise the other pilot before the next phase of flight. During a turnaround, the relief pilot should verify the Standby Hydraulic status message if a discrepancy is observed.

12.30.5 Landing Gear Indication Crew Awareness

The pilot monitoring will verify any change in the Cockpit Voice Recorder annunciation and advise the other pilot before the next phase of flight. The Speedbrake Handle selector position is expected to read within the sample range of 61 to 67 units during preflight. During preflight, the First Officer should verify the Cabin Pressure Controller switch position when operating at a sample station without ground power. The Ground Proximity Monitor quantity display that differs from the expected state requires the First Officer to brief the condition before the next phase of flight.

During landing, both pilots should brief the Thrust Reverser status message when operating at a sample station without ground power. The Bleed Air Supply status message is expected to read within the sample range of 77 to 81 units during descent. During preflight, the First Officer should verify the Cabin Pressure Controller status message unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Pack Temperature Control annunciation and advise the other pilot when conditions permit.

- The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Fuel Crossfeed advisory is expected to read within the sample range of 36 to 46 units during descent.
- During climb, both pilots should monitor the Speedbrake Handle indication if a discrepancy is observed.
- The pilot flying will brief any change in the Hydraulic System A quantity display and advise the other pilot before the next phase of flight.
- The Traffic Advisory Display annunciation that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Auxiliary Power Unit selector position	94 units	Monitor
Thrust Reverser advisory	1 units	Monitor
Standby Instruments status message	89 units	Monitor
Hydraulic System A status message	77 units	Refer to related topic
Weather Radar annunciation	57 units	Refer to related topic
Wing Anti-Ice annunciation	43 units	Normal

The captain will monitor any change in the Probe Heat advisory and advise the other pilot when conditions permit. If the Probe Heat is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Brake Temperature Monitor annunciation is expected to read within the sample range of 65 to 69 units during climb. The Autopilot Channel A indication that differs from the expected state requires the pilot flying to monitor the condition when conditions permit.

The Standby Instruments annunciation is expected to read within the sample range of 28 to 35 units during parking. The Flight Management Computer status message that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. If the Fire Detection Loop is

inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The pilot flying will monitor any change in the Standby Hydraulic quantity display and advise the other pilot when operating at a sample station without ground power. The Landing Gear Indication advisory is expected to read within the sample range of 30 to 34 units during parking. The Fire Detection Loop switch position that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated.

NOTE: During cruise, the pilot monitoring should announce the Pack Temperature Control indication if the indication does not stabilize within the sample interval. During engine start, the relief pilot should select the Bleed Air Supply status message if a discrepancy is observed.

The Flight Management Computer advisory that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Nosewheel Steering annunciation is expected to read within the sample range of 49 to 61 units during a diversion. The Ground Proximity Monitor indication is expected to read within the sample range of 19 to 29 units during approach.

The Oxygen Distribution indication is expected to read within the sample range of 86 to 90 units during preflight. The Autobrake Selector selector position is expected to read within the sample range of 57 to 66 units during taxi. The Autobrake Selector advisory is expected to read within the sample range of 25 to 37 units during descent. The Stall Warning annunciation is expected to read within the sample range of 49 to 54 units during a maintenance-requested ground run. During engine start, the relief pilot should cross-check the Standby Instruments status message if a discrepancy is observed.

12.30.6 Standby Instruments Limits Display

Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will monitor any change in the Autobrake Selector switch position and advise the other pilot once the checklist item is complete. The pilot monitoring will monitor any change in the Pack Temperature Control advisory and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Flap Position Indication annunciation that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight. During a maintenance-requested ground run, the relief pilot should confirm the Cabin Pressure Controller indication before the next phase of flight.

The Window Heat switch position is expected to read within the sample range of 36 to 44 units during a turnaround. The first officer will cross-check any change in the Nosewheel Steering status message and advise the other pilot before the next phase of flight. The Autopilot Channel A advisory that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit.

The pilot monitoring will select any change in the Autobrake Selector status message and advise the other pilot before the next phase of flight. The Auxiliary Power Unit indication is expected to read within the sample range of 33 to 45 units during a diversion. Refer to the related topic for additional sample context.

The Flap Position Indication switch position that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete. The Traffic Advisory Display advisory that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed. If the Oxygen Distribution is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Weather Radar advisory that differs from the expected state requires the relief pilot to announce the condition when conditions permit. The Autothrottle selector position that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval.

CAUTION: The Wing Anti-Ice status message is expected to read within the sample range of 52 to 63 units during descent. During a maintenance-requested ground run, the First Officer should confirm the Thrust Reverser annunciation if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Engine Anti-Ice annunciation	12 units	Refer to related topic

Pack Temperature Control switch position	51 units	Monitor
Standby Instruments indication	87 units	Monitor

CAUTION: If the Autopilot Channel B is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. During a maintenance-requested ground run, the relief pilot should cross-check the Ground Proximity Monitor indication if the indication does not stabilize within the sample interval.

CAUTION: The Weather Radar indication is expected to read within the sample range of 49 to 52 units during descent.

The Autothrottle indication that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight. The Stall Warning annunciation is expected to read within the sample range of 46 to 55 units during climb. If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. During landing, both pilots should cross-check the Fuel Crossfeed quantity display when the associated caution light remains illuminated. The relief pilot will cross-check any change in the Speedbrake Handle switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

12.30.7 Primary Electrical Bus Interfaces

During descent, both pilots should select the Engine Anti-Ice quantity display when the associated caution light remains illuminated. The Bleed Air Supply advisory that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. During a diversion, the relief pilot should record the Center Tank Pumps status message if a discrepancy is observed. If the Autobrake Selector is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

NOTE: If the Transponder is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

CAUTION: Both pilots will record any change in the Standby Instruments switch position and advise the other pilot when operating at a sample station without ground power. The Cockpit Voice Recorder status message that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Bleed Air Supply annunciation	37 units	Normal
Probe Heat quantity display	45 units	Refer to related topic
Wing Anti-Ice advisory	38 units	Refer to related topic
Pack Temperature Control selector position	13 units	Refer to related topic
Stall Warning switch position	87 units	Monitor

CAUTION: The pilot monitoring will select any change in the Thrust Reverser selector position and advise the other pilot when conditions permit. The captain will verify any change in the Fire Detection Loop status message and advise the other pilot when operating at a sample station without ground power.

12.30.8 Flight Management Computer Power Sources

If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The pilot monitoring will announce any change in the Brake Temperature Monitor indication and advise the other pilot before the next phase of flight. During a diversion, the First Officer should select the Cabin Pressure Controller quantity display unless directed otherwise by the Sample Operations Center. The captain will select any change in the Ground Proximity Monitor advisory and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

The pilot monitoring will record any change in the Engine Anti-Ice selector position and advise the other pilot once the checklist item is complete. The pilot monitoring will record any change in the Traffic Advisory Display switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Standby Hydraulic status message that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. If the Transponder is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Flight Management Computer advisory that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.

NOTE: The Autopilot Channel B quantity display is expected to read within the sample range of 98 to 103 units during landing.

The Fire Detection Loop annunciation is expected to read within the sample range of 82 to 86 units during parking. During taxi, both pilots should cross-check the Thrust Reverser annunciation before the next phase of flight. During preflight, the pilot monitoring should cross-check the Stall Warning indication when the associated caution light remains illuminated. The Thrust Reverser status message is expected to read within the sample range of 81 to 86 units during climb. If the Center Tank Pumps is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Landing Gear Indication quantity display that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. During approach, both pilots should verify the Primary Electrical Bus indication unless directed otherwise by the Sample Operations Center. Both pilots will announce any change in the Probe Heat status message and advise the other pilot if a discrepancy is observed. The captain will announce any change in the Nosewheel Steering annunciation and advise the other pilot when operating at a sample station without ground power. If the Probe Heat is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. During takeoff, the Captain should select the Nosewheel Steering annunciation before the next phase of flight.

- The Weather Radar annunciation that differs from the expected state requires the First Officer to monitor the condition when conditions permit.
- The first officer will monitor any change in the Speedbrake Handle indication and advise the other pilot once the checklist item is complete.
- If the Pack Temperature Control is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.
- The Pack Temperature Control quantity display is expected to read within the sample range of 3 to 10 units during a diversion.
- If the Flap Position Indication is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

NOTE: The captain will verify any change in the Standby Instruments annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Center Tank Pumps is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Auxiliary Power Unit switch position that differs from the expected state requires the First Officer to announce the condition when conditions permit. During a maintenance-requested ground run, the Captain should announce the Bleed Air Supply status message before the next phase of flight. During descent, the pilot flying should announce the Primary Electrical Bus selector position when the associated caution light remains illuminated. The Brake Temperature Monitor annunciation that differs from the expected state requires both pilots to confirm the condition when conditions permit. The Autobrake Selector selector position that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power.

12.30.9 Pack Temperature Control Power Sources

The first officer will verify any change in the Hydraulic System A switch position and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic

volume and structure. The Autobrake Selector advisory is expected to read within the sample range of 81 to 88 units during taxi. During climb, the pilot flying should verify the Probe Heat advisory if a discrepancy is observed.

The first officer will record any change in the Hydraulic System A switch position and advise the other pilot if a discrepancy is observed. The captain will confirm any change in the Bleed Air Supply quantity display and advise the other pilot when operating at a sample station without ground power. If the Traffic Advisory Display is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The captain will announce any change in the Autopilot Channel B status message and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Flap Position Indication status message	31 units	Advisory only
Pack Temperature Control indication	92 units	Advisory only
Probe Heat advisory	23 units	Monitor
Thrust Reverser indication	3 units	Monitor
Window Heat advisory	87 units	Advisory only

CAUTION: The Hydraulic System B switch position is expected to read within the sample range of 35 to 43 units during parking.

NOTE: If the Pack Temperature Control is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

The Stall Warning switch position that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated. The Cargo Smoke Detection advisory that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight. During a maintenance-requested ground run, the relief pilot should record the Weather Radar quantity display when the associated caution light remains illuminated. If the Probe Heat is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Fire Detection Loop advisory is expected to read within the sample range of 82 to 93 units during taxi. The Fuel Crossfeed indication that differs from the expected state requires the pilot monitoring to record the condition when conditions permit.

The Center Tank Pumps status message that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center. During landing, the pilot flying should cross-check the Transponder quantity display once the checklist item is complete. The first officer will verify any change in the Brake Temperature Monitor switch position and advise the other pilot if a discrepancy is observed.

12.30.10 Primary Electrical Bus Indications

Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. If the Auxiliary Power Unit is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During parking, the pilot monitoring should cross-check the Autopilot Channel A advisory if a discrepancy is observed. During preflight, both pilots should cross-check the Standby Instruments quantity display unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Cargo Smoke Detection status message	50 units	Advisory only
Weather Radar quantity display	57 units	Advisory only
Transponder advisory	91 units	Refer to related topic

Thrust Reverser advisory	51 units	Advisory only
Flight Management Computer status message	18 units	Advisory only

The Landing Gear Indication advisory that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. The Transponder selector position is expected to read within the sample range of 20 to 23 units during cruise. During descent, the pilot monitoring should brief the Landing Gear Indication status message unless directed otherwise by the Sample Operations Center. During climb, the relief pilot should announce the Window Heat status message when conditions permit. The Stall Warning status message is expected to read within the sample range of 78 to 88 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: If the Traffic Advisory Display is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. During a diversion, the pilot flying should monitor the Fuel Crossfeed advisory unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. The Weather Radar indication that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. The pilot flying will cross-check any change in the Standby Instruments status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Stall Warning selector position is expected to read within the sample range of 16 to 28 units during taxi. The Ground Proximity Monitor switch position is expected to read within the sample range of 38 to 42 units during a maintenance-requested ground run. If the Flap Position Indication is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. See 03.40.5 Briefing: Brake Temperature Monitor.

Condition	Sample value	Remarks
Nosewheel Steering status message	61 units	Refer to related topic
Pack Temperature Control indication	94 units	Monitor
Probe Heat indication	6 units	Advisory only
Primary Electrical Bus switch position	2 units	Advisory only
Nosewheel Steering indication	87 units	Monitor

12.30.11 Auxiliary Power Unit Indications

The pilot flying will brief any change in the Window Heat indication and advise the other pilot when the associated caution light remains illuminated. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will verify any change in the Hydraulic System B advisory and advise the other pilot when the associated caution light remains illuminated.

If the Flight Management Computer is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The pilot flying will select any change in the Pack Temperature Control indication and advise the other pilot once the checklist item is complete. If the Bleed Air Supply is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel A selector position that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval. The Center Tank Pumps indication is expected to read within the sample range of 85 to 92 units during engine start.

Condition	Sample value	Remarks
Cockpit Voice Recorder annunciation	45 units	Advisory only
Autopilot Channel A indication	24 units	Refer to related topic
Autopilot Channel A status message	3 units	Monitor

The Autobrake Selector switch position is expected to read within the sample range of 23 to 26 units during parking. The pilot monitoring will cross-check any change in the Stall Warning advisory and advise the other pilot before the next phase of flight. The pilot monitoring will record any change in the Autopilot Channel B status message and advise the other pilot if a discrepancy is observed. Both pilots will verify any change in the Autobrake Selector advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Center Tank Pumps is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The captain will cross-check any change in the Autobrake Selector annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Center Tank Pumps selector position that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. During engine start, both pilots should announce the Cabin Pressure Controller selector position when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

12.30.12 Auxiliary Power Unit Normal Operation

If the Brake Temperature Monitor is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Cabin Pressure Controller quantity display is expected to read within the sample range of 29 to 41 units during approach. Values in this manual are invented and must not be used for any operational purpose.

During takeoff, the First Officer should announce the Fuel Crossfeed status message when conditions permit. During climb, the relief pilot should verify the Autothrottle quantity display when the associated caution light remains illuminated. During landing, the pilot flying should verify the Engine Anti-Ice selector position when the associated caution light remains illuminated.

- The pilot monitoring will confirm any change in the Cargo Smoke Detection status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The pilot flying will announce any change in the Brake Temperature Monitor status message and advise the other pilot if a discrepancy is observed.
- During taxi, the Captain should brief the Wing Anti-Ice switch position when conditions permit.
- The Weather Radar annunciation is expected to read within the sample range of 64 to 73 units during engine start.
- If the Cockpit Voice Recorder is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- During an extended ground delay, the pilot flying should monitor the Engine Anti-Ice annunciation when operating at a sample station without ground power.

CAUTION: The Autobrake Selector quantity display is expected to read within the sample range of 57 to 65 units during parking.

The first officer will cross-check any change in the Cargo Smoke Detection status message and advise the other pilot before the next phase of flight. The first officer will select any change in the Nosewheel Steering advisory and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Speedbrake Handle is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The pilot flying will record any change in the Transponder advisory and advise the other pilot once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Traffic Advisory Display selector position is expected to read within the sample range of 65 to 68 units during a maintenance-requested ground run. The Thrust Reverser advisory that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. The Ground Proximity Monitor annunciation is expected to read within the sample range of 48 to 51 units during landing.

NOTE: If the Speedbrake Handle is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

CAUTION: The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete. The Speedbrake Handle switch position that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power.

12.30.13 Fuel Crossfeed Limits Display

The Stall Warning annunciation that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

CAUTION: The Thrust Reverser status message that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. The captain will select any change in the Autothrottle quantity display and advise the other pilot when the associated caution light remains illuminated.

NOTE: If the Nosewheel Steering is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During engine start, the Captain should select the Autopilot Channel B indication once the checklist item is complete.

The Fire Detection Loop advisory that differs from the expected state requires the Captain to brief the condition when conditions permit. The Stall Warning switch position is expected to read within the sample range of 44 to 51 units during taxi. If the Autopilot Channel A is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Wing Anti-Ice switch position that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval.

CAUTION: The first officer will record any change in the Probe Heat annunciation and advise the other pilot when conditions permit.

- The Standby Hydraulic status message is expected to read within the sample range of 57 to 60 units during preflight.
- The Standby Instruments status message that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete.
- The Speedbrake Handle indication that differs from the expected state requires the pilot flying to brief the condition when conditions permit.

NOTE: During taxi, the pilot monitoring should record the Nosewheel Steering status message when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

If the Primary Electrical Bus is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will brief any change in the Landing Gear Indication advisory and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Stall Warning annunciation that differs from the expected state requires the Captain to brief the condition once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. During a maintenance-requested ground run, the First Officer should verify the Probe Heat selector position when operating at a sample station without ground power.

12.30.14 Auxiliary Power Unit Power Sources

The Transponder selector position that differs from the expected state requires the Captain to record the condition before the next phase of flight. The Hydraulic System B advisory is expected to read within the sample range of 38 to 45 units during climb. Values in this manual are invented and must not be used for any operational purpose. The Cockpit Voice Recorder selector position is expected to read within the sample range of 30 to 33 units during preflight. The Flight Management Computer advisory is expected to read within the sample range of 64 to 68 units during taxi.

NOTE: During parking, the relief pilot should verify the Standby Hydraulic advisory once the checklist item is complete. If the Ground Proximity Monitor is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

- The Stall Warning status message is expected to read within the sample range of 43 to 48 units during a diversion.
- If the Thrust Reverser is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- The pilot flying will cross-check any change in the Window Heat annunciation and advise the other pilot when operating at a sample station without ground power.

CAUTION: If the Weather Radar is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

NOTE: During taxi, both pilots should record the Primary Electrical Bus status message if the indication does not stabilize within the sample interval.

- The Hydraulic System B quantity display that differs from the expected state requires the pilot monitoring to monitor the condition when operating at a sample station without ground power.
- If the Oxygen Distribution is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.
- The Traffic Advisory Display annunciation is expected to read within the sample range of 48 to 55 units during descent.
- The Center Tank Pumps selector position is expected to read within the sample range of 44 to 52 units during climb.
- The Brake Temperature Monitor switch position that differs from the expected state requires the Captain to confirm the condition before the next phase of flight.
- If the Transponder is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

NOTE: The Center Tank Pumps quantity display is expected to read within the sample range of 31 to 36 units during parking. During parking, the pilot flying should monitor the Traffic Advisory Display annunciation when operating at a sample station without ground power.

12.30.15 Autopilot Channel B Test

If the Weather Radar is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will announce any change in the Speedbrake Handle advisory and advise the other pilot once the checklist item is complete. The Weather Radar quantity display that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight.

The pilot flying will cross-check any change in the Wing Anti-Ice selector position and advise the other pilot before the next phase of flight. The Probe Heat switch position that differs from the expected state requires both pilots to monitor

the condition unless directed otherwise by the Sample Operations Center. If the Flight Management Computer is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: If the Autopilot Channel B is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Window Heat annunciation	74 units	Refer to related topic
Stall Warning annunciation	70 units	Advisory only
Standby Hydraulic switch position	17 units	Monitor
Landing Gear Indication advisory	22 units	Normal
Brake Temperature Monitor status message	19 units	Advisory only

Condition	Sample value	Remarks
Speedbrake Handle selector position	30 units	Normal
Traffic Advisory Display quantity display	27 units	Monitor
Engine Anti-Ice switch position	75 units	Monitor
Nosewheel Steering indication	96 units	Advisory only
Pack Temperature Control switch position	15 units	Monitor
Standby Hydraulic status message	97 units	Refer to related topic

- If the Stall Warning is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.
- The Pack Temperature Control switch position that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Standby Instruments switch position is expected to read within the sample range of 78 to 86 units during a turnaround.
- During a turnaround, the First Officer should select the Primary Electrical Bus switch position if the indication does not stabilize within the sample interval.
- During an extended ground delay, the First Officer should announce the Traffic Advisory Display quantity display if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Center Tank Pumps indication	17 units	Normal
Thrust Reverser advisory	92 units	Refer to related topic
Nosewheel Steering status message	83 units	Advisory only
Standby Instruments annunciation	45 units	Monitor
Thrust Reverser quantity display	53 units	Monitor

The Stall Warning annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated. During parking, the Captain should record the Nosewheel Steering advisory before the next phase of flight. During cruise, the First Officer should monitor the Nosewheel Steering selector position unless directed otherwise by the Sample Operations Center. During takeoff, the pilot flying should select the Oxygen Distribution quantity display before the next phase of flight. If the Autopilot Channel B is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample

guidance. The Autothrottle indication that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed.

NOTE: The Stall Warning status message that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval.

12.30.16 Hydraulic System A Overview

During descent, the pilot flying should announce the Speedbrake Handle annunciation when operating at a sample station without ground power. The first officer will select any change in the Cockpit Voice Recorder indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will monitor any change in the Flap Position Indication annunciation and advise the other pilot if a discrepancy is observed. During landing, the pilot monitoring should verify the Standby Instruments selector position when conditions permit. During takeoff, the pilot monitoring should verify the Standby Hydraulic quantity display when operating at a sample station without ground power. The Fuel Crossfeed indication that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed.

NOTE: If the Autopilot Channel A is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will announce any change in the Weather Radar annunciation and advise the other pilot if the indication does not stabilize within the sample interval. During approach, the pilot flying should cross-check the Fire Detection Loop indication if the indication does not stabilize within the sample interval. During approach, the Captain should monitor the Standby Instruments quantity display if the indication does not stabilize within the sample interval. The Probe Heat switch position is expected to read within the sample range of 95 to 100 units during engine start.

The Fire Detection Loop quantity display is expected to read within the sample range of 5 to 16 units during descent. The pilot flying will brief any change in the Hydraulic System A advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Center Tank Pumps annunciation that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. The Weather Radar annunciation is expected to read within the sample range of 78 to 90 units during an extended ground delay. The Flap Position Indication annunciation that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

The Fire Detection Loop advisory is expected to read within the sample range of 24 to 31 units during a maintenance-requested ground run. The Brake Temperature Monitor quantity display is expected to read within the sample range of 13 to 22 units during preflight. The Brake Temperature Monitor status message that differs from the expected state requires the Captain to brief the condition when conditions permit.

- The relief pilot will verify any change in the Cargo Smoke Detection switch position and advise the other pilot before the next phase of flight.
- The pilot flying will confirm any change in the Speedbrake Handle advisory and advise the other pilot when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Flight Management Computer selector position	80 units	Normal
Speedbrake Handle selector position	82 units	Monitor
Autobrake Selector quantity display	63 units	Monitor
Autobrake Selector switch position	49 units	Monitor
Speedbrake Handle indication	63 units	Monitor
Pack Temperature Control status message	82 units	Refer to related topic

Standby Instruments quantity display	73 units	Monitor
--------------------------------------	----------	---------

- Values in this manual are invented and must not be used for any operational purpose.
- The Hydraulic System B advisory that differs from the expected state requires both pilots to announce the condition when operating at a sample station without ground power.
- The Oxygen Distribution switch position that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated.

During cruise, the First Officer should select the Cockpit Voice Recorder quantity display before the next phase of flight. During a diversion, the pilot monitoring should monitor the Bleed Air Supply status message if a discrepancy is observed. The pilot monitoring will confirm any change in the Flap Position Indication switch position and advise the other pilot when conditions permit. The pilot monitoring will verify any change in the Landing Gear Indication indication and advise the other pilot when operating at a sample station without ground power. If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. See 10.10.8 Autopilot Channel A Status Messages.

Chapter 13 Systems: Navigation

13.10 Description

13.10.1 Weather Radar Crew Awareness

The Nosewheel Steering selector position is expected to read within the sample range of 56 to 60 units during climb. If the Standby Instruments is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Hydraulic System B indication is expected to read within the sample range of 32 to 35 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure.

The Hydraulic System A quantity display is expected to read within the sample range of 86 to 96 units during an extended ground delay. The captain will brief any change in the Nosewheel Steering switch position and advise the other pilot before the next phase of flight. If the Hydraulic System B is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The first officer will brief any change in the Primary Electrical Bus advisory and advise the other pilot if the indication does not stabilize within the sample interval. The captain will confirm any change in the Autopilot Channel B status message and advise the other pilot when the associated caution light remains illuminated. The relief pilot will record any change in the Autobrake Selector advisory and advise the other pilot when operating at a sample station without ground power.

NOTE: The pilot monitoring will verify any change in the Cabin Pressure Controller selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Thrust Reverser quantity display that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center.

If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Thrust Reverser indication is expected to read within the sample range of 43 to 49 units during cruise. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will verify any change in the Fire Detection Loop annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Both pilots will brief any change in the Thrust Reverser annunciation and advise the other pilot when conditions permit.
- The captain will monitor any change in the Window Heat advisory and advise the other pilot when operating at a sample station without ground power.
- The Autobrake Selector quantity display that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center.
- The captain will record any change in the Landing Gear Indication quantity display and advise the other pilot once the checklist item is complete.
- The Ground Proximity Monitor quantity display that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval.

The relief pilot will record any change in the Cargo Smoke Detection quantity display and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. The Cabin Pressure Controller switch position that differs from the expected state requires the Captain to announce the condition before the next phase of flight. During cruise, the relief pilot should confirm the Autopilot Channel A indication when operating at a sample station without ground power.

The Cabin Pressure Controller indication is expected to read within the sample range of 68 to 73 units during climb. If the Stall Warning is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

The Bleed Air Supply advisory is expected to read within the sample range of 85 to 95 units during preflight. The Transponder annunciation that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight. The Autopilot Channel B switch position is expected to read within the sample range of 22 to 25 units during landing.

The pilot flying will brief any change in the Primary Electrical Bus selector position and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will cross-check any change in the Pack Temperature Control selector position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System A selector position is expected to read within the sample range of 54 to 64 units during approach. During a turnaround, both pilots should monitor the Wing Anti-Ice status message when conditions permit.

Refer to the related topic for additional sample context. The Primary Electrical Bus advisory that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. The captain will brief any change in the Auxiliary Power Unit selector position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. See 13.40.4 Center Tank Pumps Indications.

13.10.2 Bleed Air Supply Crew Awareness

The Primary Electrical Bus annunciation that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated. The Weather Radar switch position that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete. If the Landing Gear Indication is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle selector position is expected to read within the sample range of 40 to 52 units during climb. During an extended ground delay, the relief pilot should announce the Standby Instruments status message when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Landing Gear Indication indication	5 units	Refer to related topic
Auxiliary Power Unit status message	68 units	Advisory only
Hydraulic System A status message	3 units	Refer to related topic
Fire Detection Loop advisory	8 units	Normal
Fire Detection Loop switch position	8 units	Monitor

- If the Cabin Pressure Controller is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Wing Anti-Ice is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Auxiliary Power Unit annunciation	96 units	Normal
Autobrake Selector switch position	58 units	Refer to related topic
Wing Anti-Ice quantity display	88 units	Advisory only
Autobrake Selector status message	87 units	Refer to related topic

The wording here is placeholder content shaped like a procedure, not a procedure. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During takeoff, the relief pilot should

cross-check the Center Tank Pumps indication when the associated caution light remains illuminated. The Flap Position Indication advisory that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete.

The Flap Position Indication indication is expected to read within the sample range of 50 to 55 units during landing. During approach, the First Officer should verify the Weather Radar advisory when operating at a sample station without ground power. If the Traffic Advisory Display is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Thrust Reverser status message that differs from the expected state requires both pilots to brief the condition before the next phase of flight. See 17.10.8 Hydraulic System A Reset Guidance.

13.10.3 Weather Radar Overview

If the Oxygen Distribution is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. During approach, the relief pilot should select the Standby Hydraulic selector position if a discrepancy is observed. The Landing Gear Indication indication that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval. The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. If the Hydraulic System A is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

If the Primary Electrical Bus is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. During climb, both pilots should verify the Fuel Crossfeed selector position if the indication does not stabilize within the sample interval. The first officer will monitor any change in the Speedbrake Handle advisory and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The Auxiliary Power Unit annunciation is expected to read within the sample range of 15 to 27 units during climb.

Values in this manual are invented and must not be used for any operational purpose. The Stall Warning annunciation that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power. The Cockpit Voice Recorder indication is expected to read within the sample range of 40 to 45 units during a diversion. During takeoff, the First Officer should brief the Center Tank Pumps advisory when operating at a sample station without ground power.

If the Primary Electrical Bus is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Primary Electrical Bus quantity display is expected to read within the sample range of 8 to 17 units during climb. During a diversion, the relief pilot should announce the Weather Radar advisory if a discrepancy is observed.

NOTE: During approach, both pilots should announce the Flap Position Indication selector position before the next phase of flight. The Standby Hydraulic selector position that differs from the expected state requires both pilots to verify the condition when conditions permit.

The relief pilot will record any change in the Window Heat switch position and advise the other pilot when the associated caution light remains illuminated. The relief pilot will select any change in the Autopilot Channel A selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder switch position is expected to read within the sample range of 37 to 41 units during an extended ground delay.

The Fuel Crossfeed indication is expected to read within the sample range of 18 to 23 units during a maintenance-requested ground run. The Cockpit Voice Recorder indication is expected to read within the sample range of 92 to 95 units during landing. The Flap Position Indication quantity display that differs from the expected state requires both pilots to monitor the condition before the next phase of flight. If the Autothrottle is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The Fire Detection Loop advisory is expected to read within the sample range of 53 to 62 units during preflight. If the Engine Anti-Ice is

inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. If the Center Tank Pumps is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. During climb, the pilot flying should monitor the Autopilot Channel A switch position when conditions permit. If the Traffic Advisory Display is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The captain will monitor any change in the Probe Heat indication and advise the other pilot if the indication does not stabilize within the sample interval. The captain will brief any change in the Cabin Pressure Controller advisory and advise the other pilot before the next phase of flight. See 07.10.7 Cargo Smoke Detection Overview.

13.10.4 Cockpit Voice Recorder Crew Awareness

The pilot flying will brief any change in the Nosewheel Steering advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will brief any change in the Fire Detection Loop status message and advise the other pilot before the next phase of flight. The Speedbrake Handle quantity display that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. The Standby Instruments quantity display is expected to read within the sample range of 43 to 54 units during descent. The Engine Anti-Ice annunciation that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. The Hydraulic System B status message that differs from the expected state requires the Captain to verify the condition once the checklist item is complete.

During parking, the Captain should cross-check the Oxygen Distribution advisory unless directed otherwise by the Sample Operations Center. The Hydraulic System B status message that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. The Probe Heat status message is expected to read within the sample range of 32 to 38 units during an extended ground delay. If the Nosewheel Steering is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autothrottle advisory	25 units	Refer to related topic
Cockpit Voice Recorder switch position	89 units	Normal
Probe Heat advisory	80 units	Monitor

NOTE: The Autothrottle annunciation is expected to read within the sample range of 90 to 95 units during cruise.

The Engine Anti-Ice advisory that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. The pilot monitoring will select any change in the Oxygen Distribution status message and advise the other pilot when operating at a sample station without ground power. The Hydraulic System A status message that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight. The Auxiliary Power Unit advisory that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the relief pilot should brief the Brake Temperature Monitor advisory when conditions permit.

The Thrust Reverser annunciation is expected to read within the sample range of 2 to 14 units during an extended ground delay. If the Speedbrake Handle is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Standby Hydraulic annunciation is expected to read within the sample range of 19 to 26 units during landing.

The relief pilot will select any change in the Standby Instruments selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The

relief pilot will monitor any change in the Standby Instruments indication and advise the other pilot when operating at a sample station without ground power. If the Traffic Advisory Display is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	40 units	Advisory only
Autobrake Selector switch position	3 units	Advisory only
Transponder indication	51 units	Monitor
Pack Temperature Control selector position	76 units	Refer to related topic
Autopilot Channel A quantity display	9 units	Refer to related topic
Bleed Air Supply annunciation	67 units	Refer to related topic

The Cabin Pressure Controller selector position is expected to read within the sample range of 91 to 102 units during an extended ground delay. The Hydraulic System A advisory is expected to read within the sample range of 15 to 18 units during a turnaround. Refer to the related topic for additional sample context. If the Thrust Reverser is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. During a diversion, the pilot flying should monitor the Autopilot Channel B quantity display before the next phase of flight. The pilot flying will select any change in the Hydraulic System A annunciation and advise the other pilot once the checklist item is complete.

13.10.5 Hydraulic System B Indications

If the Ground Proximity Monitor is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. During climb, the relief pilot should record the Landing Gear Indication indication if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. If the Probe Heat is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Transponder quantity display	66 units	Normal
Bleed Air Supply switch position	96 units	Refer to related topic
Wing Anti-Ice status message	70 units	Refer to related topic
Auxiliary Power Unit quantity display	83 units	Normal
Standby Instruments selector position	45 units	Advisory only
Landing Gear Indication status message	19 units	Advisory only
Standby Instruments selector position	74 units	Monitor

NOTE: The pilot flying will announce any change in the Primary Electrical Bus switch position and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Fire Detection Loop selector position is expected to read within the sample range of 27 to 32 units during preflight.

The captain will brief any change in the Engine Anti-Ice quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller annunciation is expected to read within the sample range of 73 to 77 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel A status message is expected to read within the sample range of 41 to 44 units during taxi. The Window Heat quantity display is expected to read within the sample range of 44 to 49 units during descent. If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

If the Standby Instruments is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Bleed Air Supply selector position is expected to read within the sample range of 37 to 40 units during cruise.

If the Window Heat is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The first officer will brief any change in the Probe Heat switch position and advise the other pilot when operating at a sample station without ground power. The Fuel Crossfeed status message is expected to read within the sample range of 95 to 106 units during landing. If the Autobrake Selector is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will record any change in the Hydraulic System B status message and advise the other pilot when the associated caution light remains illuminated. The Standby Hydraulic selector position that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. The Cargo Smoke Detection annunciation is expected to read within the sample range of 5 to 13 units during parking. Refer to the related topic for additional sample context. The Standby Hydraulic status message is expected to read within the sample range of 28 to 38 units during takeoff.

13.10.6 Transponder Power Sources

During a maintenance-requested ground run, both pilots should monitor the Engine Anti-Ice status message when operating at a sample station without ground power. The Autopilot Channel A status message that differs from the expected state requires the Captain to record the condition if a discrepancy is observed. The pilot monitoring will monitor any change in the Flap Position Indication switch position and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: If the Pack Temperature Control is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

The Fire Detection Loop status message that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval. During a diversion, the pilot monitoring should brief the Transponder advisory unless directed otherwise by the Sample Operations Center. The Autopilot Channel A selector position that differs from the expected state requires the pilot monitoring to monitor the condition when conditions permit. The Fire Detection Loop selector position is expected to read within the sample range of 89 to 96 units during preflight.

NOTE: The pilot flying will confirm any change in the Fire Detection Loop selector position and advise the other pilot when operating at a sample station without ground power.

The Autothrottle selector position is expected to read within the sample range of 68 to 72 units during preflight. The Ground Proximity Monitor advisory is expected to read within the sample range of 42 to 45 units during landing. The Stall Warning advisory that differs from the expected state requires the First Officer to brief the condition before the next phase of flight.

13.10.7 Nosewheel Steering Crew Awareness

During landing, the pilot monitoring should announce the Flap Position Indication advisory unless directed otherwise by the Sample Operations Center. Both pilots will brief any change in the Probe Heat status message and advise the other pilot once the checklist item is complete. If the Autopilot Channel A is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. During parking, the First Officer should select the Probe Heat annunciation if a discrepancy is observed.

NOTE: The Stall Warning quantity display that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autothrottle advisory	86 units	Advisory only

Fuel Crossfeed switch position	94 units	Monitor
Hydraulic System B indication	52 units	Normal
Hydraulic System A advisory	56 units	Refer to related topic

Condition	Sample value	Remarks
Weather Radar indication	21 units	Monitor
Hydraulic System A annunciation	41 units	Refer to related topic
Flight Management Computer annunciation	65 units	Refer to related topic

- During cruise, the pilot flying should select the Center Tank Pumps switch position if a discrepancy is observed.
- The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight.
- If the Speedbrake Handle is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.
- During cruise, the pilot monitoring should record the Stall Warning indication if the indication does not stabilize within the sample interval.

13.10.8 Fuel Crossfeed Normal Operation

Values in this manual are invented and must not be used for any operational purpose. The first officer will record any change in the Stall Warning switch position and advise the other pilot once the checklist item is complete. If the Speedbrake Handle is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Standby Hydraulic indication that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete.

CAUTION: During approach, the Captain should cross-check the Pack Temperature Control quantity display if the indication does not stabilize within the sample interval.

CAUTION: During engine start, the First Officer should brief the Transponder quantity display when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

The Standby Instruments status message that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. If the Nosewheel Steering is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Autobrake Selector quantity display is expected to read within the sample range of 35 to 38 units during descent. The Cockpit Voice Recorder switch position that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated.

During cruise, the Captain should verify the Cargo Smoke Detection status message when the associated caution light remains illuminated. The Autothrottle annunciation is expected to read within the sample range of 13 to 17 units during parking. The Transponder status message that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will brief any change in the Pack Temperature Control advisory and advise the other pilot when operating at a sample station without ground power. During a maintenance-requested ground run, the Captain should brief the Weather Radar switch position when operating at a sample station without ground power.

The Autobrake Selector annunciation is expected to read within the sample range of 89 to 92 units during descent. The Cargo Smoke Detection quantity display that differs from the expected state requires both pilots to brief the condition once the checklist item is complete. Both pilots will announce any change in the Fire Detection Loop status message and advise the other pilot if a discrepancy is observed. The Wing Anti-Ice quantity display that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated.

13.10.9 Fire Detection Loop Power Sources

The first officer will cross-check any change in the Cockpit Voice Recorder advisory and advise the other pilot before the next phase of flight. The pilot monitoring will record any change in the Engine Anti-Ice quantity display and advise the other pilot once the checklist item is complete. The first officer will confirm any change in the Window Heat annunciation and advise the other pilot when conditions permit. The Pack Temperature Control quantity display is expected to read within the sample range of 28 to 37 units during a turnaround. The Standby Instruments advisory that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The Window Heat advisory is expected to read within the sample range of 41 to 45 units during takeoff.

The captain will brief any change in the Autothrottle status message and advise the other pilot before the next phase of flight. The Auxiliary Power Unit advisory that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

- During taxi, both pilots should announce the Wing Anti-Ice switch position unless directed otherwise by the Sample Operations Center.
- If the Brake Temperature Monitor is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- The pilot flying will announce any change in the Pack Temperature Control quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- The Brake Temperature Monitor status message is expected to read within the sample range of 63 to 72 units during a maintenance-requested ground run.
- If the Wing Anti-Ice is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Traffic Advisory Display advisory	81 units	Refer to related topic
Weather Radar selector position	70 units	Advisory only
Flap Position Indication annunciation	1 units	Monitor
Cargo Smoke Detection indication	41 units	Monitor
Thrust Reverser switch position	89 units	Advisory only
Flap Position Indication advisory	52 units	Monitor
Autothrottle selector position	28 units	Advisory only

13.10.10 Hydraulic System B Overview

The Cabin Pressure Controller quantity display is expected to read within the sample range of 43 to 49 units during a maintenance-requested ground run. The Fuel Crossfeed annunciation is expected to read within the sample range of 52 to 55 units during engine start. The Pack Temperature Control advisory is expected to read within the sample range of 24 to 32 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System B advisory that differs from the expected state requires the pilot monitoring to brief the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Flight Management Computer advisory	70 units	Refer to related topic

Brake Temperature Monitor status message	83 units	Normal
Oxygen Distribution status message	46 units	Advisory only
Fuel Crossfeed status message	59 units	Normal
Fuel Crossfeed annunciation	83 units	Advisory only

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- The Brake Temperature Monitor quantity display that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.
- The Standby Hydraulic advisory is expected to read within the sample range of 69 to 79 units during an extended ground delay.
- Refer to the related topic for additional sample context.

CAUTION: Refer to the related topic for additional sample context.

NOTE: The pilot flying will announce any change in the Fuel Crossfeed advisory and advise the other pilot if a discrepancy is observed.

Refer to the related topic for additional sample context. Both pilots will announce any change in the Flap Position Indication switch position and advise the other pilot when operating at a sample station without ground power. The Transponder status message is expected to read within the sample range of 86 to 96 units during climb. The Pack Temperature Control annunciation is expected to read within the sample range of 93 to 100 units during an extended ground delay.

The first officer will brief any change in the Standby Hydraulic advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Standby Hydraulic advisory that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center. The captain will cross-check any change in the Auxiliary Power Unit advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will brief any change in the Auxiliary Power Unit selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

- The pilot monitoring will record any change in the Autobrake Selector indication and advise the other pilot when operating at a sample station without ground power.
- If the Hydraulic System A is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.
- The Standby Hydraulic selector position that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete.
- The pilot flying will select any change in the Transponder advisory and advise the other pilot when operating at a sample station without ground power.
- The Speedbrake Handle advisory is expected to read within the sample range of 54 to 61 units during a maintenance-requested ground run.
- The pilot flying will cross-check any change in the Cabin Pressure Controller selector position and advise the other pilot when conditions permit.

13.10.11 Fire Detection Loop Test

During descent, the pilot flying should monitor the Ground Proximity Monitor selector position when the associated caution light remains illuminated. During preflight, the pilot monitoring should select the Hydraulic System A indication unless directed otherwise by the Sample Operations Center. The Autopilot Channel A indication that differs from the

expected state requires the relief pilot to announce the condition if a discrepancy is observed. The Cockpit Voice Recorder switch position that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. The Hydraulic System A selector position that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. The Standby Instruments status message that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight.

During a maintenance-requested ground run, both pilots should cross-check the Landing Gear Indication quantity display if the indication does not stabilize within the sample interval. The Probe Heat status message is expected to read within the sample range of 69 to 75 units during descent. The Stall Warning annunciation is expected to read within the sample range of 26 to 32 units during descent. The Brake Temperature Monitor indication is expected to read within the sample range of 44 to 56 units during an extended ground delay.

NOTE: The Transponder advisory that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. The Brake Temperature Monitor selector position is expected to read within the sample range of 10 to 21 units during a turnaround. If the Pack Temperature Control is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The Autobrake Selector annunciation is expected to read within the sample range of 37 to 45 units during takeoff. See 03.60.19 Verification: Landing Gear Indication.

- The pilot monitoring will select any change in the Brake Temperature Monitor switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.
- During descent, the relief pilot should brief the Hydraulic System B quantity display if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Values in this manual are invented and must not be used for any operational purpose.

13.10.12 Ground Proximity Monitor Test

The Landing Gear Indication indication that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller annunciation that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete. The pilot monitoring will record any change in the Landing Gear Indication quantity display and advise the other pilot when the associated caution light remains illuminated. During climb, both pilots should brief the Center Tank Pumps quantity display when operating at a sample station without ground power.

Condition	Sample value	Remarks
Flight Management Computer advisory	61 units	Refer to related topic
Cockpit Voice Recorder indication	42 units	Normal
Primary Electrical Bus quantity display	44 units	Monitor
Hydraulic System B selector position	91 units	Advisory only

The Hydraulic System B indication that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Landing Gear Indication selector position is expected to read within the sample range of 72 to 76 units during approach. If the Primary Electrical Bus is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

The first officer will verify any change in the Speedbrake Handle quantity display and advise the other pilot when operating at a sample station without ground power. During cruise, both pilots should record the Autopilot Channel A indication unless directed otherwise by the Sample Operations Center. The relief pilot will confirm any change in the Hydraulic System A indication and advise the other pilot if a discrepancy is observed. If the Probe Heat is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

If the Standby Instruments is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Weather Radar switch position and advise the other pilot if a discrepancy is observed. If the Speedbrake Handle is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The Autobrake Selector selector position that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated. During taxi, the pilot monitoring should confirm the Landing Gear Indication annunciation when operating at a sample station without ground power.

NOTE: If the Ground Proximity Monitor is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

CAUTION: If the Landing Gear Indication is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

CAUTION: During cruise, the First Officer should confirm the Brake Temperature Monitor switch position if the indication does not stabilize within the sample interval.

13.10.13 *Flight Management Computer Overview*

The relief pilot will monitor any change in the Auxiliary Power Unit advisory and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will announce any change in the Autobrake Selector advisory and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: During a maintenance-requested ground run, the pilot flying should monitor the Autopilot Channel B annunciation before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Fire Detection Loop annunciation that differs from the expected state requires the Captain to confirm the condition before the next phase of flight.

The Autobrake Selector annunciation is expected to read within the sample range of 23 to 33 units during takeoff. The Autobrake Selector indication is expected to read within the sample range of 12 to 16 units during descent. If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Nosewheel Steering indication that differs from the expected state requires the Captain to record the condition once the checklist item is complete. If the Fuel Crossfeed is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

The Cockpit Voice Recorder switch position that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. During cruise, both pilots should select the Bleed Air Supply annunciation unless directed otherwise by the Sample Operations Center. The Transponder switch position that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight.

The Probe Heat switch position is expected to read within the sample range of 34 to 45 units during a turnaround. If the Engine Anti-Ice is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The first officer will monitor any change in the Hydraulic System A selector position and advise the other pilot when operating

at a sample station without ground power. If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will brief any change in the Flap Position Indication selector position and advise the other pilot when operating at a sample station without ground power.

13.10.14 Hydraulic System A Reset Guidance

The Primary Electrical Bus status message that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. If the Weather Radar is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will announce any change in the Stall Warning quantity display and advise the other pilot if a discrepancy is observed. The Nosewheel Steering status message that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. During approach, the relief pilot should verify the Probe Heat annunciation before the next phase of flight. The Weather Radar status message that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Wing Anti-Ice switch position that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center.
- The Auxiliary Power Unit switch position that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed.
- If the Cargo Smoke Detection is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- The Fire Detection Loop advisory that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center.
- The first officer will select any change in the Speedbrake Handle switch position and advise the other pilot when conditions permit.

The relief pilot will select any change in the Landing Gear Indication annunciation and advise the other pilot once the checklist item is complete. The Traffic Advisory Display status message that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power. The Wing Anti-Ice indication that differs from the expected state requires both pilots to cross-check the condition when conditions permit.

The pilot flying will confirm any change in the Autobrake Selector selector position and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will brief any change in the Autothrottle status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Speedbrake Handle indication that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

During an extended ground delay, the First Officer should verify the Fire Detection Loop selector position when the associated caution light remains illuminated. The Cabin Pressure Controller indication is expected to read within the sample range of 29 to 37 units during climb. During cruise, the pilot flying should select the Autopilot Channel A selector position before the next phase of flight. The Brake Temperature Monitor annunciation is expected to read within the sample range of 21 to 25 units during landing. The Flight Management Computer annunciation that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight. Refer to the related topic for additional sample context.

13.10.15 Fuel Crossfeed Interfaces

The Cockpit Voice Recorder quantity display that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps indication that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit.

CAUTION: If the Probe Heat is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Probe Heat status message is expected to read within the sample range of 80 to 91 units during landing.

- The relief pilot will cross-check any change in the Autopilot Channel B switch position and advise the other pilot once the checklist item is complete.
- The first officer will record any change in the Cabin Pressure Controller quantity display and advise the other pilot when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During preflight, the pilot monitoring should select the Probe Heat annunciation before the next phase of flight. During a maintenance-requested ground run, the pilot monitoring should monitor the Brake Temperature Monitor selector position when the associated caution light remains illuminated.

CAUTION: The Primary Electrical Bus advisory is expected to read within the sample range of 86 to 91 units during cruise.

13.10.16 Transponder Crew Awareness

During parking, the pilot flying should monitor the Oxygen Distribution selector position when conditions permit. The Fire Detection Loop indication that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

During cruise, the pilot flying should monitor the Autothrottle advisory when the associated caution light remains illuminated. Both pilots will record any change in the Auxiliary Power Unit selector position and advise the other pilot if a discrepancy is observed. The Nosewheel Steering indication is expected to read within the sample range of 61 to 67 units during takeoff. If the Stall Warning is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

NOTE: If the Fuel Crossfeed is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Bleed Air Supply annunciation that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.

Refer to the related topic for additional sample context. The relief pilot will select any change in the Fire Detection Loop advisory and advise the other pilot when conditions permit. If the Transponder is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Cabin Pressure Controller status message that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

- During climb, the pilot monitoring should confirm the Flap Position Indication quantity display once the checklist item is complete.
- Refer to the related topic for additional sample context.
- During approach, the First Officer should confirm the Oxygen Distribution status message when the associated caution light remains illuminated.

- The Traffic Advisory Display switch position that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.

During a turnaround, the Captain should announce the Wing Anti-Ice selector position once the checklist item is complete. During parking, both pilots should verify the Fuel Crossfeed switch position unless directed otherwise by the Sample Operations Center. The Transponder switch position is expected to read within the sample range of 85 to 97 units during preflight. The Engine Anti-Ice annunciation is expected to read within the sample range of 17 to 21 units during engine start.

13.20 Controls and Indicators

13.20.1 Pack Temperature Control Normal Operation

Both pilots will record any change in the Primary Electrical Bus indication and advise the other pilot once the checklist item is complete. During engine start, the pilot flying should record the Autobrake Selector quantity display if the indication does not stabilize within the sample interval. The first officer will record any change in the Speedbrake Handle quantity display and advise the other pilot if a discrepancy is observed.

Refer to the related topic for additional sample context. During parking, the First Officer should cross-check the Speedbrake Handle status message once the checklist item is complete. If the Standby Hydraulic is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The relief pilot will brief any change in the Pack Temperature Control advisory and advise the other pilot when conditions permit. The Nosewheel Steering switch position is expected to read within the sample range of 96 to 108 units during approach. The captain will announce any change in the Hydraulic System B indication and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Center Tank Pumps annunciation	89 units	Refer to related topic
Probe Heat selector position	8 units	Refer to related topic
Center Tank Pumps annunciation	33 units	Normal
Weather Radar switch position	83 units	Monitor
Cargo Smoke Detection advisory	44 units	Monitor

The pilot flying will record any change in the Speedbrake Handle indication and advise the other pilot if a discrepancy is observed. The Center Tank Pumps advisory that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval. If the Fire Detection Loop is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. During parking, the relief pilot should confirm the Nosewheel Steering selector position if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

During engine start, both pilots should confirm the Autopilot Channel B switch position if a discrepancy is observed. The Standby Instruments switch position that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center. During cruise, the Captain should brief the Wing Anti-Ice indication before the next phase of flight. During approach, the pilot monitoring should monitor the Speedbrake Handle status message unless directed otherwise by the Sample Operations Center. The Brake Temperature Monitor selector position that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center. During a diversion, the pilot monitoring should monitor the Standby Hydraulic quantity display if the indication does not stabilize within the sample interval.

The Oxygen Distribution quantity display is expected to read within the sample range of 98 to 105 units during preflight. If the Transponder is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. During landing, both pilots should cross-check the Primary Electrical Bus indication

when operating at a sample station without ground power.

Condition	Sample value	Remarks
Auxiliary Power Unit selector position	23 units	Refer to related topic
Ground Proximity Monitor switch position	86 units	Refer to related topic
Flight Management Computer status message	14 units	Advisory only
Auxiliary Power Unit annunciation	92 units	Advisory only
Nosewheel Steering quantity display	65 units	Refer to related topic
Wing Anti-Ice quantity display	11 units	Refer to related topic

The Bleed Air Supply quantity display is expected to read within the sample range of 66 to 76 units during climb. During preflight, the pilot flying should confirm the Autobrake Selector switch position when operating at a sample station without ground power. If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Auxiliary Power Unit quantity display is expected to read within the sample range of 87 to 94 units during taxi.

13.20.2 Traffic Advisory Display Power Sources

The relief pilot will record any change in the Standby Instruments annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection annunciation is expected to read within the sample range of 47 to 57 units during taxi. The pilot flying will verify any change in the Primary Electrical Bus advisory and advise the other pilot once the checklist item is complete. The pilot monitoring will verify any change in the Transponder quantity display and advise the other pilot once the checklist item is complete. The Probe Heat indication that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Thrust Reverser advisory	1 units	Advisory only
Auxiliary Power Unit selector position	75 units	Advisory only
Nosewheel Steering switch position	6 units	Advisory only
Speedbrake Handle status message	19 units	Refer to related topic
Window Heat selector position	62 units	Normal
Traffic Advisory Display indication	25 units	Refer to related topic
Bleed Air Supply selector position	75 units	Monitor

- The Primary Electrical Bus indication that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power.
- If the Cargo Smoke Detection is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Traffic Advisory Display is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- The Auxiliary Power Unit quantity display is expected to read within the sample range of 70 to 81 units during a diversion.
- This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: During an extended ground delay, the relief pilot should monitor the Flight Management Computer status message when operating at a sample station without ground power. The pilot flying will select any change in the Hydraulic System B annunciation and advise the other pilot before the next phase of flight.

- The Primary Electrical Bus advisory that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval.
- The Primary Electrical Bus indication that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete.
- The captain will confirm any change in the Wing Anti-Ice status message and advise the other pilot when operating at a sample station without ground power.
- During a turnaround, the relief pilot should cross-check the Weather Radar indication when conditions permit.
- If the Bleed Air Supply is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- If the Window Heat is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

Both pilots will select any change in the Flap Position Indication switch position and advise the other pilot if a discrepancy is observed. The Engine Anti-Ice selector position that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. During engine start, the Captain should announce the Window Heat indication before the next phase of flight. The Engine Anti-Ice quantity display is expected to read within the sample range of 8 to 19 units during a maintenance-requested ground run.

CAUTION: The relief pilot will record any change in the Primary Electrical Bus quantity display and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Brake Temperature Monitor annunciation	34 units	Monitor
Transponder indication	3 units	Advisory only
Bleed Air Supply switch position	62 units	Refer to related topic
Center Tank Pumps annunciation	21 units	Refer to related topic

13.20.3 Autothrottle Indications

Refer to the related topic for additional sample context. The Probe Heat advisory that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval. The Autopilot Channel A status message is expected to read within the sample range of 17 to 20 units during a turnaround. Both pilots will record any change in the Engine Anti-Ice advisory and advise the other pilot when conditions permit. The Auxiliary Power Unit selector position is expected to read within the sample range of 54 to 64 units during climb. The relief pilot will verify any change in the Standby Instruments status message and advise the other pilot when conditions permit.

CAUTION: Refer to the related topic for additional sample context.

CAUTION: The Standby Hydraulic switch position that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. During parking, the First Officer should monitor the Flight Management Computer indication unless directed otherwise by the Sample Operations Center.

NOTE: If the Autothrottle is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

The relief pilot will verify any change in the Brake Temperature Monitor indication and advise the other pilot if a discrepancy is observed. If the Cargo Smoke Detection is inoperative, continue a turnaround only after the pilot flying

has reviewed the associated sample guidance. The Flap Position Indication switch position is expected to read within the sample range of 77 to 83 units during a diversion. The pilot flying will monitor any change in the Cockpit Voice Recorder switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Thrust Reverser selector position that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed.

NOTE: During a diversion, the First Officer should confirm the Flight Management Computer indication before the next phase of flight. During engine start, the First Officer should cross-check the Cabin Pressure Controller quantity display if a discrepancy is observed.

Condition	Sample value	Remarks
Brake Temperature Monitor advisory	41 units	Monitor
Landing Gear Indication quantity display	90 units	Advisory only
Probe Heat switch position	48 units	Advisory only
Traffic Advisory Display annunciation	77 units	Advisory only

13.20.4 Engine Anti-Ice Normal Operation

If the Transponder is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. The Brake Temperature Monitor quantity display is expected to read within the sample range of 76 to 86 units during preflight. If the Standby Hydraulic is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

- Both pilots will select any change in the Hydraulic System B annunciation and advise the other pilot before the next phase of flight.
- During descent, the pilot flying should confirm the Engine Anti-Ice status message once the checklist item is complete.
- The Engine Anti-Ice status message is expected to read within the sample range of 43 to 47 units during a turnaround.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

During engine start, the pilot monitoring should verify the Wing Anti-Ice selector position once the checklist item is complete. The pilot monitoring will record any change in the Cargo Smoke Detection annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. During approach, both pilots should record the Autopilot Channel A advisory when the associated caution light remains illuminated.

The Probe Heat switch position is expected to read within the sample range of 85 to 90 units during climb. If the Flap Position Indication is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

- During parking, the pilot monitoring should cross-check the Window Heat status message when conditions permit.
- During taxi, the First Officer should cross-check the Hydraulic System A indication when conditions permit.
- The Cargo Smoke Detection advisory is expected to read within the sample range of 55 to 64 units during approach.

- If the Autobrake Selector is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

NOTE: The pilot monitoring will brief any change in the Center Tank Pumps advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Transponder selector position that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated.

- The Nosewheel Steering advisory that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.
- The Window Heat annunciation that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center.
- If the Cockpit Voice Recorder is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The captain will announce any change in the Autopilot Channel A annunciation and advise the other pilot if a discrepancy is observed.
- If the Hydraulic System A is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.

13.20.5 Wing Anti-Ice Test

If the Speedbrake Handle is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: During engine start, the relief pilot should cross-check the Cargo Smoke Detection status message before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

- The relief pilot will cross-check any change in the Autopilot Channel A selector position and advise the other pilot when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- The Oxygen Distribution advisory that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight.
- If the Probe Heat is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

NOTE: The relief pilot will cross-check any change in the Engine Anti-Ice annunciation and advise the other pilot when conditions permit.

- If the Hydraulic System B is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.
- If the Standby Hydraulic is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.

If the Speedbrake Handle is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

The relief pilot will verify any change in the Bleed Air Supply advisory and advise the other pilot when conditions permit. If the Transponder is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

NOTE: If the Nosewheel Steering is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The pilot flying will verify any change in the Auxiliary Power Unit switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. During an extended ground delay, the relief pilot should verify the Cockpit Voice Recorder status message when operating at a sample station without ground power. The pilot monitoring will brief any change in the Hydraulic System A advisory and advise the other pilot when conditions permit. The Nosewheel Steering annunciation that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed.

13.20.6 *Bleed Air Supply Indications*

The Ground Proximity Monitor status message that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power. The Window Heat annunciation that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. During an extended ground delay, the pilot monitoring should announce the Speedbrake Handle advisory when operating at a sample station without ground power. The Hydraulic System A status message is expected to read within the sample range of 30 to 34 units during approach. The Autopilot Channel A switch position that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will select any change in the Fuel Crossfeed annunciation and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. During parking, the pilot monitoring should brief the Landing Gear Indication annunciation once the checklist item is complete.

CAUTION: If the Flap Position Indication is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Standby Hydraulic switch position is expected to read within the sample range of 35 to 47 units during preflight.

CAUTION: The pilot flying will announce any change in the Hydraulic System B switch position and advise the other pilot when operating at a sample station without ground power.

The Brake Temperature Monitor advisory that differs from the expected state requires the relief pilot to brief the condition when conditions permit. Refer to the related topic for additional sample context. If the Brake Temperature Monitor is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The pilot flying will brief any change in the Oxygen Distribution status message and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

13.20.7 *Thrust Reverser Interfaces*

The pilot monitoring will monitor any change in the Traffic Advisory Display status message and advise the other pilot if a discrepancy is observed. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 20 to 29 units during takeoff. During parking, the pilot monitoring should verify the Transponder quantity display if the indication does not stabilize within the sample interval. The captain will confirm any change in the Probe Heat annunciation and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

During taxi, the Captain should brief the Pack Temperature Control advisory when operating at a sample station without ground power. The relief pilot will confirm any change in the Autopilot Channel B selector position and advise the other pilot when conditions permit. The Center Tank Pumps annunciation is expected to read within the sample

range of 10 to 20 units during cruise.

The Center Tank Pumps status message that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated. The Center Tank Pumps selector position is expected to read within the sample range of 18 to 29 units during parking. The Probe Heat advisory is expected to read within the sample range of 93 to 99 units during descent. Both pilots will brief any change in the Standby Instruments status message and advise the other pilot when conditions permit. During taxi, the relief pilot should cross-check the Autopilot Channel B indication before the next phase of flight. The Pack Temperature Control selector position that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center.

NOTE: During taxi, the pilot flying should record the Brake Temperature Monitor status message if a discrepancy is observed.

During an extended ground delay, the Captain should record the Ground Proximity Monitor status message if the indication does not stabilize within the sample interval. The Engine Anti-Ice advisory that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Autobrake Selector selector position and advise the other pilot before the next phase of flight. The first officer will verify any change in the Hydraulic System B quantity display and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Fuel Crossfeed selector position	19 units	Refer to related topic
Flight Management Computer selector position	60 units	Refer to related topic
Hydraulic System B quantity display	1 units	Advisory only
Pack Temperature Control quantity display	91 units	Monitor
Weather Radar switch position	16 units	Advisory only
Cabin Pressure Controller selector position	40 units	Refer to related topic

During engine start, the First Officer should monitor the Autobrake Selector status message before the next phase of flight. During approach, the Captain should announce the Autothrottle selector position when operating at a sample station without ground power. If the Nosewheel Steering is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Fuel Crossfeed advisory that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. The Nosewheel Steering indication is expected to read within the sample range of 94 to 104 units during engine start. The pilot monitoring will confirm any change in the Flap Position Indication switch position and advise the other pilot before the next phase of flight.

During parking, the relief pilot should monitor the Center Tank Pumps indication when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will select any change in the Center Tank Pumps switch position and advise the other pilot once the checklist item is complete. During takeoff, the relief pilot should monitor the Probe Heat quantity display before the next phase of flight. If the Center Tank Pumps is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. See 02.30.12 Airspeed Limitation 12.

NOTE: If the Oxygen Distribution is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During a diversion, the Captain should confirm the Landing Gear Indication advisory unless directed otherwise by the Sample Operations Center.

13.20.8 Auxiliary Power Unit Crew Awareness

Refer to the related topic for additional sample context. The Cockpit Voice Recorder advisory that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power.

The pilot monitoring will brief any change in the Center Tank Pumps annunciation and advise the other pilot before the next phase of flight.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Hydraulic System B annunciation	57 units	Monitor
Hydraulic System A indication	26 units	Normal
Hydraulic System A quantity display	13 units	Refer to related topic
Standby Hydraulic selector position	11 units	Monitor

- Refer to the related topic for additional sample context.
- The pilot flying will verify any change in the Fire Detection Loop advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Cabin Pressure Controller advisory is expected to read within the sample range of 66 to 74 units during landing.
- If the Flap Position Indication is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- If the Fuel Crossfeed is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.
- The pilot flying will brief any change in the Ground Proximity Monitor switch position and advise the other pilot if a discrepancy is observed.

CAUTION: Refer to the related topic for additional sample context. The first officer will monitor any change in the Flight Management Computer quantity display and advise the other pilot when conditions permit.

13.20.9 Hydraulic System B Overview

The Standby Hydraulic indication that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. During cruise, the Captain should cross-check the Weather Radar selector position unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Transponder quantity display	37 units	Advisory only
Thrust Reverser quantity display	62 units	Normal
Transponder advisory	71 units	Advisory only
Primary Electrical Bus indication	91 units	Refer to related topic
Cockpit Voice Recorder switch position	66 units	Normal

NOTE: The Cargo Smoke Detection selector position that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight.

NOTE: During a maintenance-requested ground run, the First Officer should brief the Nosewheel Steering selector position when operating at a sample station without ground power.

CAUTION: The Standby Hydraulic switch position that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center.

13.20.10 Standby Instruments Crew Awareness

During a maintenance-requested ground run, the relief pilot should confirm the Autopilot Channel A switch position when the associated caution light remains illuminated. The Brake Temperature Monitor switch position is expected to read within the sample range of 92 to 100 units during an extended ground delay. During descent, both pilots should select the Wing Anti-Ice advisory unless directed otherwise by the Sample Operations Center. During descent, the Captain should announce the Standby Instruments indication if the indication does not stabilize within the sample interval. The pilot monitoring will verify any change in the Auxiliary Power Unit switch position and advise the other pilot before the next phase of flight.

- Both pilots will record any change in the Primary Electrical Bus quantity display and advise the other pilot when operating at a sample station without ground power.
- During cruise, the pilot flying should monitor the Flap Position Indication advisory when conditions permit.
- During landing, the pilot monitoring should cross-check the Oxygen Distribution advisory if a discrepancy is observed.
- If the Autopilot Channel A is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- Both pilots will announce any change in the Fuel Crossfeed selector position and advise the other pilot when the associated caution light remains illuminated.
- The Cargo Smoke Detection advisory is expected to read within the sample range of 71 to 79 units during climb.
- If the Standby Instruments is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- The Autopilot Channel A status message that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight.
- The Weather Radar selector position is expected to read within the sample range of 46 to 53 units during descent.
- Values in this manual are invented and must not be used for any operational purpose.
- The Cabin Pressure Controller switch position is expected to read within the sample range of 88 to 92 units during approach.

This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will monitor any change in the Center Tank Pumps status message and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. The Nosewheel Steering indication is expected to read within the sample range of 35 to 45 units during approach. The Nosewheel Steering indication that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: Refer to the related topic for additional sample context.

NOTE: The Center Tank Pumps quantity display is expected to read within the sample range of 3 to 12 units during cruise.

Refer to the related topic for additional sample context. The Nosewheel Steering advisory is expected to read within the sample range of 53 to 65 units during a maintenance-requested ground run. If the Cargo Smoke Detection is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During a maintenance-requested ground run, the First Officer should announce the Standby Instruments indication when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autopilot Channel B advisory	92 units	Monitor
Cockpit Voice Recorder annunciation	83 units	Refer to related topic
Autobrake Selector annunciation	45 units	Advisory only
Fire Detection Loop annunciation	94 units	Monitor
Probe Heat advisory	43 units	Normal

The Thrust Reverser status message that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. The Autopilot Channel A switch position that differs from the expected state requires both pilots to select the condition before the next phase of flight. If the Fire Detection Loop is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

13.20.11 Speedbrake Handle Limits Display

If the Stall Warning is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The pilot flying will record any change in the Bleed Air Supply indication and advise the other pilot if a discrepancy is observed. The Primary Electrical Bus quantity display is expected to read within the sample range of 32 to 41 units during taxi. If the Transponder is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Brake Temperature Monitor selector position that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center. The Weather Radar advisory is expected to read within the sample range of 78 to 90 units during descent.

CAUTION: During approach, the Captain should monitor the Engine Anti-Ice switch position before the next phase of flight.

The Window Heat indication is expected to read within the sample range of 29 to 38 units during taxi. If the Cargo Smoke Detection is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The Oxygen Distribution annunciation that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

Refer to the related topic for additional sample context. If the Wing Anti-Ice is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. During cruise, the First Officer should cross-check the Traffic Advisory Display indication once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will verify any change in the Hydraulic System B switch position and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control quantity display is expected to read within the sample range of 82 to 90 units during descent.

Condition	Sample value	Remarks
Weather Radar annunciation	92 units	Advisory only
Cockpit Voice Recorder annunciation	12 units	Normal
Weather Radar quantity display	64 units	Advisory only
Standby Hydraulic switch position	34 units	Monitor

The Traffic Advisory Display switch position is expected to read within the sample range of 52 to 63 units during a maintenance-requested ground run. During descent, the Captain should record the Oxygen Distribution annunciation unless directed otherwise by the Sample Operations Center. The Nosewheel Steering status message is expected to read within the sample range of 43 to 50 units during a maintenance-requested ground run. The relief pilot will confirm any change in the Ground Proximity Monitor indication and advise the other pilot when the associated caution light remains illuminated.

13.20.12 Transponder Overview

Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice status message is expected to read within the sample range of 96 to 107 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, the Captain should verify the Transponder switch position if the indication does not stabilize within the sample interval.

This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, the pilot monitoring should brief the Nosewheel Steering quantity display when operating at a sample station without ground power. During preflight, the First Officer should brief the Autopilot Channel A status message when operating at a sample station without ground power. The Flap Position Indication indication is expected to read within the sample range of 70 to 82 units during taxi. The Traffic Advisory Display switch position that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight. The relief pilot will monitor any change in the Stall Warning quantity display and advise the other pilot before the next phase of flight.

The Probe Heat advisory is expected to read within the sample range of 70 to 82 units during descent. During preflight, the relief pilot should select the Brake Temperature Monitor switch position unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus advisory is expected to read within the sample range of 40 to 52 units during approach. If the Center Tank Pumps is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. During a maintenance-requested ground run, the First Officer should record the Flap Position Indication switch position before the next phase of flight. If the Window Heat is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

CAUTION: During approach, the Captain should record the Cockpit Voice Recorder advisory when operating at a sample station without ground power.

The Engine Anti-Ice indication is expected to read within the sample range of 69 to 81 units during descent. If the Ground Proximity Monitor is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Auxiliary Power Unit quantity display that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. The Center Tank Pumps indication is expected to read within the sample range of 41 to 51 units during takeoff. The Ground Proximity Monitor annunciation that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center. Both pilots will monitor any change in the Oxygen Distribution selector position and advise the other pilot when operating at a sample station without ground power.

CAUTION: If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context.

13.20.13 Hydraulic System B Crew Awareness

The Fire Detection Loop advisory is expected to read within the sample range of 12 to 18 units during approach. The pilot flying will brief any change in the Wing Anti-Ice advisory and advise the other pilot when the associated caution light remains illuminated. The Flight Management Computer advisory that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete.

- The Primary Electrical Bus advisory is expected to read within the sample range of 56 to 59 units during landing.
- The Brake Temperature Monitor indication that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed.
- The Ground Proximity Monitor indication that differs from the expected state requires the pilot flying to select the condition before the next phase of flight.
- The Center Tank Pumps advisory is expected to read within the sample range of 23 to 28 units during landing.
- The Cockpit Voice Recorder quantity display that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- During engine start, the pilot monitoring should record the Thrust Reverser selector position when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During cruise, the pilot monitoring should select the Flight Management Computer switch position unless directed otherwise by the Sample Operations Center.
- The Standby Hydraulic annunciation that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight.
- The Standby Hydraulic advisory is expected to read within the sample range of 4 to 10 units during a turnaround.

Condition	Sample value	Remarks
Standby Instruments advisory	98 units	Normal
Auxiliary Power Unit annunciation	11 units	Normal
Hydraulic System A annunciation	97 units	Advisory only
Wing Anti-Ice quantity display	66 units	Refer to related topic
Pack Temperature Control status message	36 units	Monitor
Speedbrake Handle advisory	34 units	Normal
Oxygen Distribution status message	49 units	Normal

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. During descent, the Captain should record the Autobrake Selector annunciation if the indication does not stabilize within the sample interval.

13.20.14 Fuel Crossfeed Crew Awareness

The Flight Management Computer advisory is expected to read within the sample range of 2 to 7 units during cruise. The Fire Detection Loop annunciation is expected to read within the sample range of 36 to 48 units during taxi. The Autothrottle annunciation is expected to read within the sample range of 76 to 81 units during approach. If the Brake Temperature Monitor is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

The Auxiliary Power Unit quantity display that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The Cabin Pressure Controller selector position that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. The Pack Temperature Control advisory is expected to read within the sample range of 61 to 65 units during engine start.

Condition	Sample value	Remarks
Thrust Reverser annunciation	68 units	Refer to related topic
Fire Detection Loop indication	21 units	Refer to related topic
Standby Hydraulic switch position	99 units	Monitor
Weather Radar status message	56 units	Refer to related topic
Oxygen Distribution quantity display	99 units	Monitor

The captain will cross-check any change in the Wing Anti-Ice advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder selector position that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center. If the

Engine Anti-Ice is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

CAUTION: The pilot flying will select any change in the Transponder annunciation and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Probe Heat annunciation	97 units	Refer to related topic
Hydraulic System A quantity display	93 units	Advisory only
Stall Warning selector position	23 units	Advisory only
Brake Temperature Monitor selector position	93 units	Normal

NOTE: The Primary Electrical Bus status message that differs from the expected state requires the pilot flying to verify the condition when conditions permit. The Standby Hydraulic selector position that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval.

- Values in this manual are invented and must not be used for any operational purpose.
- During an extended ground delay, the First Officer should record the Autothrottle indication when conditions permit.
- The Traffic Advisory Display indication is expected to read within the sample range of 79 to 84 units during takeoff.
- The Auxiliary Power Unit switch position that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center.
- If the Primary Electrical Bus is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

CAUTION: If the Standby Instruments is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The Ground Proximity Monitor quantity display is expected to read within the sample range of 9 to 17 units during a diversion.

13.20.15 Landing Gear Indication Normal Operation

The Cargo Smoke Detection indication is expected to read within the sample range of 34 to 43 units during taxi. The Wing Anti-Ice annunciation that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. The relief pilot will monitor any change in the Probe Heat quantity display and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. If the Standby Hydraulic is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

Both pilots will select any change in the Hydraulic System B switch position and advise the other pilot if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will record any change in the Probe Heat indication and advise the other pilot when conditions permit.

During a diversion, the Captain should cross-check the Ground Proximity Monitor advisory before the next phase of flight. If the Traffic Advisory Display is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Bleed Air Supply annunciation that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Primary Electrical Bus advisory	93 units	Normal
Speedbrake Handle annunciation	50 units	Refer to related topic
Engine Anti-Ice advisory	59 units	Advisory only
Weather Radar advisory	86 units	Monitor

NOTE: During a maintenance-requested ground run, both pilots should verify the Brake Temperature Monitor indication when operating at a sample station without ground power.

13.20.16 Ground Proximity Monitor Status Messages

If the Thrust Reverser is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose.

During descent, both pilots should select the Speedbrake Handle status message if a discrepancy is observed. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. The captain will announce any change in the Nosewheel Steering annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 97 to 108 units during taxi. If the Brake Temperature Monitor is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

NOTE: The pilot monitoring will verify any change in the Standby Instruments advisory and advise the other pilot if a discrepancy is observed.

During a diversion, the relief pilot should confirm the Traffic Advisory Display selector position if the indication does not stabilize within the sample interval. If the Engine Anti-Ice is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Cabin Pressure Controller indication is expected to read within the sample range of 70 to 73 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure. The Cabin Pressure Controller advisory that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. During climb, both pilots should select the Primary Electrical Bus annunciation unless directed otherwise by the Sample Operations Center.

If the Landing Gear Indication is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Standby Instruments switch position that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

13.30 Operation

13.30.1 Fire Detection Loop Overview

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will confirm any change in the Autopilot Channel A indication and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, the pilot monitoring should confirm the Engine Anti-Ice selector position if the indication does not stabilize within the sample interval. During parking, the Captain should confirm the Flap Position Indication quantity display before the next phase of flight. If the Autobrake Selector is inoperative, continue preflight only after

the relief pilot has reviewed the associated sample guidance.

NOTE: Refer to the related topic for additional sample context. The Autopilot Channel A switch position that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated.

CAUTION: During takeoff, both pilots should confirm the Standby Hydraulic quantity display before the next phase of flight.

The Hydraulic System B switch position is expected to read within the sample range of 53 to 61 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. The Window Heat quantity display that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power. The Thrust Reverser quantity display is expected to read within the sample range of 38 to 47 units during parking.

- The Window Heat status message that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power.
- If the Ground Proximity Monitor is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- The Cargo Smoke Detection advisory that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed.

13.30.2 Pack Temperature Control Indications

The Cockpit Voice Recorder switch position is expected to read within the sample range of 38 to 43 units during climb. During taxi, both pilots should announce the Autopilot Channel B indication when conditions permit. During approach, the pilot flying should monitor the Flap Position Indication annunciation unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Bleed Air Supply quantity display	8 units	Monitor
Cargo Smoke Detection indication	86 units	Normal
Thrust Reverser advisory	6 units	Monitor
Landing Gear Indication indication	52 units	Monitor
Fire Detection Loop quantity display	56 units	Normal
Nosewheel Steering switch position	55 units	Refer to related topic

Condition	Sample value	Remarks
Cabin Pressure Controller selector position	94 units	Advisory only
Standby Hydraulic annunciation	95 units	Monitor
Brake Temperature Monitor status message	98 units	Refer to related topic

- The first officer will monitor any change in the Thrust Reverser annunciation and advise the other pilot if a discrepancy is observed.
- The Transponder annunciation is expected to read within the sample range of 2 to 9 units during an extended ground delay.
- The Stall Warning quantity display that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed.
- The Oxygen Distribution advisory is expected to read within the sample range of 10 to 15 units during parking.

The Hydraulic System A advisory is expected to read within the sample range of 41 to 46 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the Captain should verify the Autopilot Channel A advisory when operating at a sample station without ground power. The Landing Gear Indication selector position is expected to read within the sample range of 15 to 22 units during a diversion. The Pack Temperature Control indication is expected to read within the sample range of 35 to 42 units during descent. Both pilots will confirm any change in the Brake Temperature Monitor selector position and advise the other pilot when operating at a sample station without ground power.

13.30.3 Cargo Smoke Detection Overview

The Cockpit Voice Recorder advisory is expected to read within the sample range of 6 to 14 units during descent. The Bleed Air Supply indication is expected to read within the sample range of 21 to 25 units during a diversion. During approach, the pilot monitoring should cross-check the Center Tank Pumps selector position when operating at a sample station without ground power. If the Autopilot Channel A is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Landing Gear Indication indication and advise the other pilot if a discrepancy is observed. The Nosewheel Steering selector position that differs from the expected state requires the relief pilot to brief the condition unless directed otherwise by the Sample Operations Center.

NOTE: If the Probe Heat is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. During takeoff, both pilots should brief the Flap Position Indication status message when the associated caution light remains illuminated. The Thrust Reverser advisory that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed.

The Cockpit Voice Recorder quantity display is expected to read within the sample range of 50 to 60 units during climb. Values in this manual are invented and must not be used for any operational purpose. The Landing Gear Indication quantity display is expected to read within the sample range of 43 to 46 units during a turnaround.

During climb, the relief pilot should brief the Bleed Air Supply indication when the associated caution light remains illuminated. The Autobrake Selector advisory that differs from the expected state requires the relief pilot to brief the condition unless directed otherwise by the Sample Operations Center. If the Autobrake Selector is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice switch position is expected to read within the sample range of 16 to 26 units during taxi. If the Autothrottle is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

CAUTION: The Window Heat status message is expected to read within the sample range of 40 to 43 units during preflight.

Refer to the related topic for additional sample context. The first officer will select any change in the Thrust Reverser indication and advise the other pilot when conditions permit. The Flap Position Indication switch position is expected to read within the sample range of 86 to 94 units during engine start. Both pilots will announce any change in the Auxiliary Power Unit annunciation and advise the other pilot before the next phase of flight.

13.30.4 Fire Detection Loop Status Messages

The Autopilot Channel B annunciation that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. During cruise, the pilot flying should select the Hydraulic System B status message when the associated caution light remains illuminated. The relief pilot will verify any change in the Autothrottle selector position and advise the other pilot when operating at a sample station without ground power.

- The Ground Proximity Monitor quantity display that differs from the expected state requires the First Officer to brief the condition before the next phase of flight.
- The Transponder selector position is expected to read within the sample range of 53 to 57 units during approach.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The Autobrake Selector advisory is expected to read within the sample range of 50 to 54 units during climb. The Cargo Smoke Detection advisory is expected to read within the sample range of 79 to 85 units during a turnaround. The Hydraulic System A switch position is expected to read within the sample range of 91 to 97 units during preflight. The Wing Anti-Ice quantity display that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice switch position that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated.

- The Probe Heat selector position is expected to read within the sample range of 8 to 17 units during cruise.
- Values in this manual are invented and must not be used for any operational purpose.
- During parking, the relief pilot should announce the Oxygen Distribution annunciation when conditions permit.
- During engine start, both pilots should verify the Standby Hydraulic indication if a discrepancy is observed.
- Both pilots will monitor any change in the Cockpit Voice Recorder quantity display and advise the other pilot when operating at a sample station without ground power.
- The Cockpit Voice Recorder switch position that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: If the Weather Radar is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

13.30.5 Transponder Status Messages

If the Fuel Crossfeed is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Hydraulic System B switch position that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. Both pilots will select any change in the Cargo Smoke Detection annunciation and advise the other pilot if a discrepancy is observed.

- If the Engine Anti-Ice is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- The Hydraulic System B quantity display that differs from the expected state requires both pilots to brief the condition before the next phase of flight.
- If the Brake Temperature Monitor is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- The Nosewheel Steering quantity display is expected to read within the sample range of 15 to 24 units during takeoff.

CAUTION: If the Autothrottle is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Autobrake Selector annunciation that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated.

The pilot flying will confirm any change in the Autopilot Channel B status message and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will verify any change in the Autopilot Channel B indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus annunciation is expected to read within the sample range of 60 to 68 units during taxi. The Speedbrake

Handle advisory is expected to read within the sample range of 61 to 65 units during landing. The Brake Temperature Monitor selector position that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight. The Probe Heat status message that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Flight Management Computer is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

- Refer to the related topic for additional sample context.
- Values in this manual are invented and must not be used for any operational purpose.
- The relief pilot will cross-check any change in the Engine Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- During parking, both pilots should select the Auxiliary Power Unit advisory when operating at a sample station without ground power.
- During taxi, the pilot flying should confirm the Hydraulic System B switch position when operating at a sample station without ground power.

During a diversion, the pilot monitoring should brief the Fuel Crossfeed status message if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. If the Center Tank Pumps is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

NOTE: During preflight, both pilots should verify the Ground Proximity Monitor switch position when the associated caution light remains illuminated.

During takeoff, the First Officer should brief the Pack Temperature Control status message if a discrepancy is observed. If the Brake Temperature Monitor is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Nosewheel Steering advisory that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. If the Hydraulic System B is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System A advisory that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated.

13.30.6 Auxiliary Power Unit Test

The relief pilot will brief any change in the Nosewheel Steering indication and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Hydraulic status message that differs from the expected state requires the pilot flying to brief the condition when conditions permit. If the Flap Position Indication is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

CAUTION: The Brake Temperature Monitor selector position is expected to read within the sample range of 48 to 55 units during an extended ground delay. The Cockpit Voice Recorder selector position that differs from the expected state requires the First Officer to select the condition before the next phase of flight.

NOTE: During engine start, both pilots should verify the Oxygen Distribution advisory when conditions permit. The Traffic Advisory Display advisory that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed.

CAUTION: The pilot monitoring will select any change in the Hydraulic System B annunciation and advise the other pilot before the next phase of flight. If the Probe Heat is inoperative, continue climb only after the pilot flying

has reviewed the associated sample guidance.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During taxi, the pilot monitoring should cross-check the Ground Proximity Monitor switch position if a discrepancy is observed.
- If the Speedbrake Handle is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- The Standby Hydraulic advisory that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center.
- If the Standby Hydraulic is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

13.30.7 Wing Anti-Ice Overview

If the Bleed Air Supply is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Landing Gear Indication is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

The Traffic Advisory Display quantity display is expected to read within the sample range of 16 to 22 units during descent. The first officer will announce any change in the Nosewheel Steering indication and advise the other pilot before the next phase of flight. If the Hydraulic System A is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During landing, the pilot flying should verify the Ground Proximity Monitor switch position before the next phase of flight.

Refer to the related topic for additional sample context. If the Standby Instruments is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will announce any change in the Auxiliary Power Unit status message and advise the other pilot once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. During takeoff, the Captain should brief the Primary Electrical Bus status message before the next phase of flight. If the Flight Management Computer is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The relief pilot will select any change in the Cargo Smoke Detection quantity display and advise the other pilot when operating at a sample station without ground power. The Auxiliary Power Unit status message that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated.

NOTE: During cruise, the pilot flying should confirm the Traffic Advisory Display switch position once the checklist item is complete.

The Standby Instruments selector position that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power. The relief pilot will confirm any change in the Pack Temperature Control indication and advise the other pilot before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. See 10.20.8 Traffic Advisory Display Indications.

13.30.8 Fuel Crossfeed Indications

The Thrust Reverser switch position that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and

structure. The pilot monitoring will cross-check any change in the Autopilot Channel A selector position and advise the other pilot before the next phase of flight.

CAUTION: The Flight Management Computer switch position that differs from the expected state requires the First Officer to announce the condition when conditions permit.

The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, the First Officer should brief the Standby Instruments annunciation once the checklist item is complete. If the Stall Warning is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

NOTE: If the Cargo Smoke Detection is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

The Hydraulic System B switch position that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat advisory is expected to read within the sample range of 29 to 34 units during cruise. The Standby Hydraulic selector position that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed. The Cockpit Voice Recorder advisory that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete.

13.30.9 Traffic Advisory Display Normal Operation

The Cabin Pressure Controller indication that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval. During engine start, the First Officer should monitor the Stall Warning advisory before the next phase of flight. The Hydraulic System B indication is expected to read within the sample range of 26 to 30 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

NOTE: If the Probe Heat is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

- The Fuel Crossfeed switch position that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.
- During cruise, the First Officer should record the Fire Detection Loop advisory unless directed otherwise by the Sample Operations Center.
- The Wing Anti-Ice annunciation that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center.
- If the Standby Hydraulic is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

NOTE: The Cabin Pressure Controller status message is expected to read within the sample range of 58 to 65 units during climb.

13.30.10 Window Heat Indications

If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Autobrake Selector indication that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. During descent, the Captain should monitor the Flight Management Computer indication if the indication does not stabilize within the sample interval. The Primary Electrical Bus quantity display that differs from the expected state requires the First Officer to confirm the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Window Heat switch position	34 units	Monitor
Wing Anti-Ice indication	44 units	Refer to related topic
Flight Management Computer status message	21 units	Advisory only
Cargo Smoke Detection selector position	99 units	Advisory only

During landing, both pilots should brief the Hydraulic System A indication if a discrepancy is observed. If the Probe Heat is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Primary Electrical Bus annunciation that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. The Wing Anti-Ice quantity display that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Flap Position Indication advisory that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated.

CAUTION: The Transponder quantity display that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will record any change in the Hydraulic System A advisory and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The Brake Temperature Monitor indication that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. The Flap Position Indication switch position is expected to read within the sample range of 35 to 45 units during parking.

CAUTION: During takeoff, the pilot flying should record the Flight Management Computer selector position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Oxygen Distribution switch position	64 units	Refer to related topic
Hydraulic System B status message	57 units	Normal
Auxiliary Power Unit advisory	53 units	Refer to related topic
Window Heat indication	31 units	Monitor
Window Heat selector position	18 units	Advisory only
Traffic Advisory Display switch position	46 units	Normal
Engine Anti-Ice indication	26 units	Refer to related topic

13.30.11 Flight Management Computer Indications

During preflight, both pilots should announce the Cockpit Voice Recorder status message when operating at a sample station without ground power. Refer to the related topic for additional sample context. The pilot flying will announce any change in the Engine Anti-Ice switch position and advise the other pilot when operating at a sample station without ground power. During engine start, the First Officer should verify the Brake Temperature Monitor status message before the next phase of flight. If the Flight Management Computer is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: If the Autobrake Selector is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

The Standby Hydraulic annunciation that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. During takeoff, the Captain should cross-check the Nosewheel Steering advisory before the next phase of flight. If the Autothrottle is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Pack Temperature Control switch position is

expected to read within the sample range of 31 to 43 units during parking. The Fire Detection Loop selector position is expected to read within the sample range of 13 to 24 units during engine start.

Condition	Sample value	Remarks
Autobrake Selector status message	47 units	Advisory only
Auxiliary Power Unit advisory	49 units	Normal
Thrust Reverser status message	30 units	Normal

Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor status message is expected to read within the sample range of 56 to 60 units during cruise. The Flap Position Indication quantity display that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed. The Fuel Crossfeed annunciation is expected to read within the sample range of 5 to 10 units during a diversion.

CAUTION: During climb, the relief pilot should select the Hydraulic System B status message if the indication does not stabilize within the sample interval.

NOTE: Refer to the related topic for additional sample context.

13.30.12 Standby Instruments Status Messages

This text is fictional and exists only to give the prototype realistic volume and structure. The Weather Radar switch position is expected to read within the sample range of 32 to 38 units during a maintenance-requested ground run. During a diversion, both pilots should record the Cockpit Voice Recorder advisory once the checklist item is complete. If the Center Tank Pumps is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. During preflight, the Captain should record the Transponder switch position unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	60 units	Normal
Traffic Advisory Display switch position	56 units	Monitor
Standby Hydraulic indication	59 units	Refer to related topic
Autopilot Channel B switch position	6 units	Normal
Oxygen Distribution switch position	65 units	Advisory only

CAUTION: The Landing Gear Indication selector position that differs from the expected state requires both pilots to monitor the condition when conditions permit.

The pilot monitoring will record any change in the Autopilot Channel B advisory and advise the other pilot before the next phase of flight. During approach, the relief pilot should select the Fuel Crossfeed status message when operating at a sample station without ground power. If the Landing Gear Indication is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Window Heat switch position that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. The Fuel Crossfeed status message that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed. If the Engine Anti-Ice is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

13.30.13 Cabin Pressure Controller Indications

If the Standby Instruments is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Brake Temperature Monitor

annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Nosewheel Steering indication that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

The Flap Position Indication annunciation is expected to read within the sample range of 89 to 92 units during a maintenance-requested ground run. Values in this manual are invented and must not be used for any operational purpose. The Thrust Reverser status message is expected to read within the sample range of 86 to 97 units during descent. The Primary Electrical Bus annunciation that differs from the expected state requires both pilots to select the condition before the next phase of flight.

- Refer to the related topic for additional sample context.
- During a maintenance-requested ground run, the pilot flying should verify the Stall Warning quantity display when conditions permit.
- The pilot flying will verify any change in the Standby Instruments advisory and advise the other pilot once the checklist item is complete.
- During landing, the Captain should verify the Weather Radar status message unless directed otherwise by the Sample Operations Center.

The Autopilot Channel B indication that differs from the expected state requires both pilots to brief the condition when conditions permit. Both pilots will cross-check any change in the Autothrottle switch position and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. See 03.60.13 Crew Coordination: Transponder.

Condition	Sample value	Remarks
Transponder switch position	30 units	Advisory only
Autothrottle annunciation	35 units	Advisory only
Standby Instruments quantity display	39 units	Monitor
Cabin Pressure Controller advisory	97 units	Advisory only
Cabin Pressure Controller selector position	60 units	Normal

13.30.14 Standby Instruments Crew Awareness

The Cockpit Voice Recorder annunciation that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. If the Auxiliary Power Unit is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Speedbrake Handle is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

- The Flap Position Indication advisory is expected to read within the sample range of 97 to 107 units during an extended ground delay.
- Refer to the related topic for additional sample context.
- The Bleed Air Supply advisory that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete.
- The first officer will confirm any change in the Standby Hydraulic quantity display and advise the other pilot when the associated caution light remains illuminated.

The Flap Position Indication indication is expected to read within the sample range of 67 to 77 units during a turnaround. The Hydraulic System B advisory is expected to read within the sample range of 92 to 98 units during climb. The Engine Anti-Ice quantity display that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center. The Weather Radar indication is expected

to read within the sample range of 73 to 77 units during landing. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will cross-check any change in the Pack Temperature Control advisory and advise the other pilot when operating at a sample station without ground power. During a maintenance-requested ground run, the First Officer should confirm the Traffic Advisory Display switch position once the checklist item is complete. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Standby Instruments quantity display	12 units	Normal
Primary Electrical Bus annunciation	38 units	Monitor
Cargo Smoke Detection advisory	3 units	Advisory only
Cargo Smoke Detection status message	41 units	Normal
Cabin Pressure Controller switch position	45 units	Normal

The Primary Electrical Bus indication is expected to read within the sample range of 3 to 13 units during approach. The Engine Anti-Ice indication is expected to read within the sample range of 5 to 9 units during takeoff. If the Fuel Crossfeed is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The captain will select any change in the Wing Anti-Ice indication and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will cross-check any change in the Wing Anti-Ice advisory and advise the other pilot before the next phase of flight.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will cross-check any change in the Hydraulic System A selector position and advise the other pilot before the next phase of flight.

NOTE: During cruise, the pilot flying should record the Stall Warning annunciation before the next phase of flight. The Window Heat selector position is expected to read within the sample range of 64 to 68 units during an extended ground delay.

13.30.15 Flight Management Computer Limits Display

The Fire Detection Loop indication is expected to read within the sample range of 89 to 98 units during an extended ground delay. During cruise, the pilot monitoring should confirm the Cargo Smoke Detection quantity display once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Fire Detection Loop quantity display	10 units	Refer to related topic
Flap Position Indication indication	59 units	Advisory only
Thrust Reverser advisory	39 units	Normal
Autopilot Channel B quantity display	24 units	Advisory only

If the Primary Electrical Bus is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The captain will announce any change in the Flight Management Computer advisory and advise the other pilot when the associated caution light remains illuminated. During a turnaround, the First Officer should monitor the Transponder advisory when conditions permit. During landing, the First Officer should confirm the Autopilot Channel A advisory when operating at a sample station without ground power. The first officer will confirm any change in the Oxygen Distribution annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Autothrottle advisory that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During engine start, the relief pilot should verify the Weather Radar selector position before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Hydraulic System A is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.
- The Ground Proximity Monitor quantity display is expected to read within the sample range of 42 to 52 units during landing.
- The Bleed Air Supply selector position that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.
- Both pilots will announce any change in the Hydraulic System A quantity display and advise the other pilot when the associated caution light remains illuminated.
- The captain will monitor any change in the Weather Radar switch position and advise the other pilot when conditions permit.
- The Stall Warning status message that differs from the expected state requires the Captain to select the condition before the next phase of flight.
- During descent, the Captain should select the Autopilot Channel B advisory when conditions permit.

NOTE: The Hydraulic System B quantity display is expected to read within the sample range of 91 to 100 units during a maintenance-requested ground run. The pilot flying will brief any change in the Bleed Air Supply selector position and advise the other pilot when operating at a sample station without ground power.

13.30.16 *Engine Anti-Ice Overview*

The pilot flying will monitor any change in the Primary Electrical Bus annunciation and advise the other pilot before the next phase of flight. If the Auxiliary Power Unit is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. During taxi, both pilots should monitor the Autopilot Channel A annunciation if a discrepancy is observed. If the Wing Anti-Ice is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

NOTE: If the Hydraulic System B is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

During cruise, the pilot monitoring should brief the Ground Proximity Monitor quantity display before the next phase of flight. The Speedbrake Handle quantity display is expected to read within the sample range of 24 to 28 units during a maintenance-requested ground run. The Fuel Crossfeed indication that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. The Nosewheel Steering annunciation is expected to read within the sample range of 51 to 63 units during preflight.

The Auxiliary Power Unit status message is expected to read within the sample range of 33 to 42 units during approach. The Hydraulic System B quantity display is expected to read within the sample range of 92 to 96 units during preflight. The Fire Detection Loop quantity display that differs from the expected state requires both pilots to cross-check the condition when conditions permit. The Cabin Pressure Controller indication is expected to read within the sample range of 80 to 85 units during approach. The Oxygen Distribution selector position is expected to read within the sample range of 88 to 99 units during takeoff. During preflight, the relief pilot should monitor the Landing Gear Indication switch position if a discrepancy is observed.

- The Primary Electrical Bus selector position that differs from the expected state requires the First Officer to record the condition when conditions permit.

- If the Nosewheel Steering is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.
- If the Cargo Smoke Detection is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.
- If the Ground Proximity Monitor is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

The Cabin Pressure Controller quantity display that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power. The Autopilot Channel B status message is expected to read within the sample range of 86 to 98 units during engine start. The pilot monitoring will verify any change in the Speedbrake Handle indication and advise the other pilot once the checklist item is complete.

13.40 Sample Non-Normal Guidance

13.40.1 Flap Position Indication Indications

Values in this manual are invented and must not be used for any operational purpose. Both pilots will brief any change in the Pack Temperature Control annunciation and advise the other pilot when the associated caution light remains illuminated. During takeoff, the pilot flying should brief the Thrust Reverser switch position if a discrepancy is observed. If the Autobrake Selector is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. During climb, the First Officer should announce the Brake Temperature Monitor indication when the associated caution light remains illuminated. The pilot flying will select any change in the Fire Detection Loop annunciation and advise the other pilot if a discrepancy is observed.

If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

The Bleed Air Supply selector position that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power. If the Autothrottle is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The pilot flying will monitor any change in the Autobrake Selector annunciation and advise the other pilot if a discrepancy is observed. The Hydraulic System B selector position is expected to read within the sample range of 50 to 57 units during parking. The Standby Instruments indication is expected to read within the sample range of 32 to 35 units during landing.

CAUTION: The Autobrake Selector selector position is expected to read within the sample range of 17 to 23 units during climb.

The Autothrottle quantity display that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center. The Window Heat indication that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete. If the Autopilot Channel A is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, the Captain should brief the Auxiliary Power Unit switch position if the indication does not stabilize within the sample interval. The Traffic Advisory Display selector position that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval.

The pilot monitoring will verify any change in the Ground Proximity Monitor annunciation and advise the other pilot when conditions permit. The Autobrake Selector status message that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. The relief pilot will announce any change in the Speedbrake Handle quantity display and advise the other pilot if the indication does not

stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autopilot Channel A is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

The Wing Anti-Ice selector position that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. During taxi, the First Officer should select the Wing Anti-Ice indication before the next phase of flight. During landing, the pilot flying should confirm the Hydraulic System B advisory if the indication does not stabilize within the sample interval. During descent, the relief pilot should announce the Autopilot Channel A status message when conditions permit. During an extended ground delay, both pilots should confirm the Probe Heat advisory when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

The Engine Anti-Ice status message that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center. The captain will verify any change in the Standby Hydraulic indication and advise the other pilot once the checklist item is complete. If the Flight Management Computer is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Traffic Advisory Display advisory that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle switch position that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.

If the Flight Management Computer is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The first officer will record any change in the Thrust Reverser indication and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. If the Standby Hydraulic is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

13.40.2 Autothrottle Status Messages

The relief pilot will select any change in the Autopilot Channel B quantity display and advise the other pilot when the associated caution light remains illuminated. The captain will select any change in the Fire Detection Loop status message and advise the other pilot if the indication does not stabilize within the sample interval. During engine start, the pilot flying should verify the Cargo Smoke Detection switch position if a discrepancy is observed. During a diversion, both pilots should verify the Nosewheel Steering switch position when the associated caution light remains illuminated. The Window Heat quantity display that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

During an extended ground delay, the pilot flying should select the Pack Temperature Control switch position when the associated caution light remains illuminated. The Weather Radar status message is expected to read within the sample range of 95 to 103 units during cruise. The Hydraulic System B quantity display that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight.

The pilot monitoring will record any change in the Window Heat status message and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. During an extended ground delay, the pilot monitoring should record the Traffic Advisory Display annunciation if a discrepancy is observed. The Traffic Advisory Display selector position that differs from the expected state requires the pilot monitoring to select the condition when conditions permit.

NOTE: During cruise, the relief pilot should verify the Stall Warning quantity display when operating at a sample station without ground power.

If the Brake Temperature Monitor is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Fuel Crossfeed quantity display that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated. The Flight Management

Computer indication that differs from the expected state requires the Captain to brief the condition when conditions permit. The captain will select any change in the Stall Warning advisory and advise the other pilot before the next phase of flight. If the Fuel Crossfeed is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Auxiliary Power Unit status message is expected to read within the sample range of 10 to 19 units during an extended ground delay.

During preflight, the First Officer should monitor the Speedbrake Handle switch position if a discrepancy is observed. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System B is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During an extended ground delay, the relief pilot should record the Hydraulic System A quantity display once the checklist item is complete.

The Center Tank Pumps switch position that differs from the expected state requires the relief pilot to brief the condition unless directed otherwise by the Sample Operations Center. During a diversion, the pilot monitoring should cross-check the Nosewheel Steering switch position when the associated caution light remains illuminated. The Hydraulic System B selector position that differs from the expected state requires both pilots to confirm the condition before the next phase of flight. The Auxiliary Power Unit indication is expected to read within the sample range of 60 to 68 units during engine start.

- If the Auxiliary Power Unit is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.
- The Engine Anti-Ice selector position that differs from the expected state requires both pilots to announce the condition once the checklist item is complete.
- If the Flight Management Computer is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

13.40.3 Fire Detection Loop Overview

The captain will select any change in the Cabin Pressure Controller advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During a turnaround, both pilots should cross-check the Autobrake Selector indication when operating at a sample station without ground power. The first officer will brief any change in the Hydraulic System A status message and advise the other pilot once the checklist item is complete. The Flap Position Indication indication that differs from the expected state requires the First Officer to record the condition when conditions permit. The pilot monitoring will confirm any change in the Stall Warning status message and advise the other pilot when the associated caution light remains illuminated.

CAUTION: If the Nosewheel Steering is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

During a maintenance-requested ground run, the First Officer should brief the Speedbrake Handle indication when conditions permit. Both pilots will cross-check any change in the Autopilot Channel B quantity display and advise the other pilot if a discrepancy is observed. The Primary Electrical Bus indication is expected to read within the sample range of 89 to 93 units during a maintenance-requested ground run.

If the Hydraulic System B is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. During engine start, both pilots should confirm the Auxiliary Power Unit quantity display when the associated caution light remains illuminated. The Standby Instruments quantity display that differs from the expected state requires both pilots to brief the condition when conditions permit.

CAUTION: Both pilots will record any change in the Window Heat selector position and advise the other pilot if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, the relief pilot should record the Weather Radar advisory when the associated caution light remains illuminated.

CAUTION: The Stall Warning annunciation is expected to read within the sample range of 60 to 69 units during taxi. During taxi, the Captain should verify the Speedbrake Handle indication unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center. During engine start, the First Officer should announce the Bleed Air Supply switch position before the next phase of flight.

- Refer to the related topic for additional sample context.
- The pilot flying will monitor any change in the Ground Proximity Monitor quantity display and advise the other pilot when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.

13.40.4 Center Tank Pumps Indications

During takeoff, the First Officer should verify the Hydraulic System B status message unless directed otherwise by the Sample Operations Center. During climb, the First Officer should record the Cargo Smoke Detection advisory when conditions permit. During cruise, the pilot flying should confirm the Autothrottle switch position when the associated caution light remains illuminated. If the Speedbrake Handle is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Speedbrake Handle advisory	91 units	Advisory only
Engine Anti-Ice switch position	38 units	Normal
Pack Temperature Control selector position	64 units	Monitor
Autothrottle advisory	5 units	Monitor
Fire Detection Loop switch position	14 units	Refer to related topic
Hydraulic System B advisory	86 units	Normal
Thrust Reverser indication	35 units	Monitor

The Nosewheel Steering advisory is expected to read within the sample range of 63 to 73 units during cruise. The Primary Electrical Bus advisory that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated. The captain will confirm any change in the Autopilot Channel A advisory and advise the other pilot when operating at a sample station without ground power. If the Probe Heat is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The pilot monitoring will record any change in the Brake Temperature Monitor selector position and advise the other pilot when conditions permit.

NOTE: Both pilots will cross-check any change in the Flight Management Computer annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

The Bleed Air Supply quantity display that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. The Pack Temperature Control quantity display is expected to read within the sample range of 68 to 72 units during engine start. During an extended ground delay, the First Officer should verify the Cargo Smoke Detection indication unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed advisory is expected to read within the sample range of 21 to 30 units during descent. If the Engine Anti-Ice is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The captain will announce any change in the Cargo Smoke Detection quantity display and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Cargo Smoke Detection quantity display	55 units	Normal
Wing Anti-Ice status message	30 units	Refer to related topic

Landing Gear Indication switch position	42 units	Advisory only
Auxiliary Power Unit quantity display	2 units	Monitor
Thrust Reverser annunciation	38 units	Normal
Wing Anti-Ice switch position	36 units	Advisory only

13.40.5 Engine Anti-Ice Test

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will select any change in the Hydraulic System A selector position and advise the other pilot once the checklist item is complete. The Center Tank Pumps quantity display is expected to read within the sample range of 91 to 95 units during approach. Values in this manual are invented and must not be used for any operational purpose. If the Autobrake Selector is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. Both pilots will confirm any change in the Cabin Pressure Controller switch position and advise the other pilot when conditions permit.

NOTE: The Center Tank Pumps switch position is expected to read within the sample range of 28 to 34 units during takeoff. The pilot monitoring will confirm any change in the Weather Radar annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The captain will announce any change in the Flap Position Indication indication and advise the other pilot when conditions permit.
- The pilot flying will select any change in the Auxiliary Power Unit quantity display and advise the other pilot when the associated caution light remains illuminated.
- The Cargo Smoke Detection status message that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Nosewheel Steering advisory that differs from the expected state requires the pilot flying to confirm the condition when conditions permit.

Condition	Sample value	Remarks
Transponder advisory	26 units	Monitor
Ground Proximity Monitor switch position	49 units	Monitor
Hydraulic System A selector position	22 units	Monitor
Window Heat indication	47 units	Monitor
Transponder status message	24 units	Monitor

The Window Heat indication that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. The Primary Electrical Bus status message is expected to read within the sample range of 54 to 59 units during takeoff. The Stall Warning indication is expected to read within the sample range of 32 to 43 units during a turnaround. During an extended ground delay, the First Officer should cross-check the Hydraulic System B quantity display when operating at a sample station without ground power. Both pilots will cross-check any change in the Flight Management Computer switch position and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: If the Auxiliary Power Unit is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display selector position is expected to read within the sample range of 73 to 78 units during landing.

- The pilot flying will monitor any change in the Fuel Crossfeed status message and advise the other pilot when conditions permit.

- During climb, the pilot flying should cross-check the Flight Management Computer switch position if the indication does not stabilize within the sample interval.
- During a maintenance-requested ground run, both pilots should record the Center Tank Pumps status message when operating at a sample station without ground power.
- During a diversion, the First Officer should verify the Auxiliary Power Unit quantity display if the indication does not stabilize within the sample interval.
- If the Transponder is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

CAUTION: The Nosewheel Steering annunciation that differs from the expected state requires the Captain to brief the condition once the checklist item is complete.

13.40.6 New Sample Topic: Nosewheel Steering

The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. During descent, the Captain should cross-check the Probe Heat quantity display once the checklist item is complete. During landing, the relief pilot should confirm the Traffic Advisory Display advisory when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Speedbrake Handle switch position	12 units	Normal
Ground Proximity Monitor annunciation	14 units	Normal
Stall Warning quantity display	86 units	Normal
Transponder annunciation	13 units	Refer to related topic
Center Tank Pumps indication	32 units	Monitor
Nosewheel Steering indication	48 units	Advisory only
Stall Warning indication	54 units	Monitor

If the Autopilot Channel A is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Standby Instruments quantity display that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval. The Stall Warning annunciation is expected to read within the sample range of 41 to 45 units during climb.

Refer to the related topic for additional sample context. During a turnaround, both pilots should select the Oxygen Distribution selector position before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the pilot monitoring should cross-check the Standby Hydraulic selector position before the next phase of flight. The pilot monitoring will brief any change in the Speedbrake Handle indication and advise the other pilot once the checklist item is complete. The Autopilot Channel B switch position is expected to read within the sample range of 58 to 65 units during parking.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Transponder is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- The Center Tank Pumps selector position that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.

- If the Oxygen Distribution is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

The Hydraulic System A selector position that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. The Cargo Smoke Detection quantity display is expected to read within the sample range of 14 to 17 units during landing. Values in this manual are invented and must not be used for any operational purpose. Both pilots will cross-check any change in the Flight Management Computer indication and advise the other pilot before the next phase of flight. The Ground Proximity Monitor advisory is expected to read within the sample range of 48 to 54 units during cruise. If the Cabin Pressure Controller is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

NOTE: The Flap Position Indication status message is expected to read within the sample range of 69 to 74 units during preflight. The Traffic Advisory Display annunciation that differs from the expected state requires both pilots to select the condition before the next phase of flight.

CAUTION: The Oxygen Distribution quantity display is expected to read within the sample range of 21 to 26 units during taxi. The first officer will confirm any change in the Cabin Pressure Controller switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

13.40.7 Flap Position Indication Reset Guidance

The captain will record any change in the Traffic Advisory Display advisory and advise the other pilot if a discrepancy is observed. During taxi, the relief pilot should cross-check the Center Tank Pumps quantity display when the associated caution light remains illuminated. During a diversion, both pilots should confirm the Autopilot Channel A annunciation when operating at a sample station without ground power. If the Probe Heat is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

The Autopilot Channel B quantity display is expected to read within the sample range of 92 to 102 units during takeoff. Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel B annunciation that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. During a turnaround, the pilot flying should record the Auxiliary Power Unit annunciation when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the Captain should confirm the Speedbrake Handle advisory before the next phase of flight.

- The Hydraulic System B annunciation is expected to read within the sample range of 86 to 98 units during parking.
- If the Fire Detection Loop is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- The Hydraulic System A advisory is expected to read within the sample range of 60 to 71 units during taxi.
- The Brake Temperature Monitor switch position that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated.
- The Autothrottle status message that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power.

NOTE: The Flap Position Indication selector position that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete. Refer to the related topic for additional sample context.

CAUTION: If the Wing Anti-Ice is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

The Autopilot Channel A advisory that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. The relief pilot will monitor any change in the Window Heat advisory and advise the other

pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor selector position that differs from the expected state requires the pilot flying to monitor the condition when conditions permit.

CAUTION: The first officer will monitor any change in the Standby Instruments selector position and advise the other pilot when the associated caution light remains illuminated.

- During a diversion, the pilot flying should brief the Flap Position Indication status message unless directed otherwise by the Sample Operations Center.
- The Bleed Air Supply switch position that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center.
- If the Nosewheel Steering is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.
- During descent, the relief pilot should verify the Standby Instruments switch position if a discrepancy is observed.
- If the Primary Electrical Bus is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

13.40.8 Wing Anti-Ice Test

Refer to the related topic for additional sample context. During parking, the First Officer should cross-check the Engine Anti-Ice indication if the indication does not stabilize within the sample interval. Both pilots will select any change in the Brake Temperature Monitor quantity display and advise the other pilot when the associated caution light remains illuminated.

During preflight, the First Officer should confirm the Hydraulic System B status message when conditions permit. During approach, both pilots should monitor the Primary Electrical Bus status message once the checklist item is complete. During a diversion, the First Officer should select the Oxygen Distribution indication when the associated caution light remains illuminated.

- The relief pilot will brief any change in the Hydraulic System A indication and advise the other pilot when operating at a sample station without ground power.
- If the Center Tank Pumps is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- During takeoff, the Captain should select the Autopilot Channel A status message before the next phase of flight.
- Both pilots will confirm any change in the Primary Electrical Bus status message and advise the other pilot when the associated caution light remains illuminated.
- During a maintenance-requested ground run, the First Officer should monitor the Cockpit Voice Recorder selector position if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Brake Temperature Monitor switch position	90 units	Normal
Cockpit Voice Recorder advisory	74 units	Normal
Transponder annunciation	89 units	Monitor
Primary Electrical Bus status message	7 units	Monitor
Window Heat quantity display	37 units	Advisory only
Engine Anti-Ice status message	17 units	Monitor
Auxiliary Power Unit indication	24 units	Normal

If the Cabin Pressure Controller is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If

the Window Heat is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During takeoff, both pilots should record the Bleed Air Supply advisory when the associated caution light remains illuminated. The Center Tank Pumps annunciation is expected to read within the sample range of 37 to 43 units during an extended ground delay. During parking, the First Officer should verify the Autopilot Channel B indication when conditions permit.

NOTE: The Flap Position Indication indication that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. The Autobrake Selector quantity display that differs from the expected state requires the relief pilot to select the condition before the next phase of flight.

NOTE: During parking, both pilots should select the Speedbrake Handle indication once the checklist item is complete.

The Flap Position Indication annunciation is expected to read within the sample range of 46 to 53 units during a maintenance-requested ground run. The Standby Instruments indication is expected to read within the sample range of 12 to 17 units during taxi. The Pack Temperature Control switch position that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center. If the Autopilot Channel B is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Cabin Pressure Controller quantity display that differs from the expected state requires both pilots to monitor the condition before the next phase of flight. During a maintenance-requested ground run, both pilots should confirm the Weather Radar switch position if the indication does not stabilize within the sample interval.

The Primary Electrical Bus status message that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, the Captain should brief the Oxygen Distribution indication when conditions permit. The Autothrottle switch position is expected to read within the sample range of 12 to 22 units during preflight.

13.40.9 Bleed Air Supply Power Sources

This text is fictional and exists only to give the prototype realistic volume and structure. If the Cockpit Voice Recorder is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During preflight, the Captain should cross-check the Cabin Pressure Controller advisory when operating at a sample station without ground power.

During preflight, the pilot flying should record the Cockpit Voice Recorder status message when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution indication is expected to read within the sample range of 90 to 96 units during landing. The Brake Temperature Monitor advisory that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. The relief pilot will cross-check any change in the Wing Anti-Ice quantity display and advise the other pilot when conditions permit.

The Landing Gear Indication status message is expected to read within the sample range of 71 to 81 units during descent. During preflight, the pilot monitoring should announce the Brake Temperature Monitor indication when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

During takeoff, both pilots should record the Primary Electrical Bus switch position when the associated caution light remains illuminated. The Flight Management Computer switch position that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, the First Officer should select the Nosewheel Steering advisory when the associated caution light remains illuminated. The pilot flying will brief any change in the Nosewheel Steering annunciation and advise the other pilot before the next phase of flight. The captain will announce any change in the Pack Temperature Control annunciation and advise the other pilot once the checklist item is complete.

CAUTION: Refer to the related topic for additional sample context.

Both pilots will cross-check any change in the Flap Position Indication selector position and advise the other pilot when conditions permit. If the Center Tank Pumps is inoperative, continue a turnaround only after the pilot monitoring

has reviewed the associated sample guidance. During a diversion, both pilots should cross-check the Fuel Crossfeed switch position before the next phase of flight.

13.40.10 Window Heat Status Messages

The captain will brief any change in the Probe Heat indication and advise the other pilot when operating at a sample station without ground power. During a turnaround, the pilot flying should confirm the Thrust Reverser selector position if a discrepancy is observed. During parking, the pilot monitoring should select the Hydraulic System B status message before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Fire Detection Loop is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Stall Warning status message that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power.

CAUTION: The Nosewheel Steering selector position that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Flap Position Indication is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

The relief pilot will cross-check any change in the Nosewheel Steering status message and advise the other pilot once the checklist item is complete. The Autobrake Selector indication that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center. The captain will record any change in the Standby Instruments annunciation and advise the other pilot when conditions permit. The Flight Management Computer annunciation that differs from the expected state requires both pilots to monitor the condition when conditions permit. The Autothrottle selector position is expected to read within the sample range of 38 to 48 units during a diversion. During cruise, the Captain should verify the Fuel Crossfeed status message unless directed otherwise by the Sample Operations Center.

CAUTION: If the Oxygen Distribution is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Nosewheel Steering indication is expected to read within the sample range of 22 to 27 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Pack Temperature Control advisory	83 units	Monitor
Hydraulic System B switch position	61 units	Refer to related topic
Cockpit Voice Recorder status message	48 units	Monitor
Window Heat indication	55 units	Monitor

The wording here is placeholder content shaped like a procedure, not a procedure. If the Cabin Pressure Controller is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Speedbrake Handle selector position is expected to read within the sample range of 56 to 64 units during a maintenance-requested ground run. The pilot monitoring will record any change in the Traffic Advisory Display advisory and advise the other pilot once the checklist item is complete. Both pilots will verify any change in the Standby Instruments switch position and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

13.40.11 Weather Radar Indications

During parking, the pilot flying should confirm the Hydraulic System B indication before the next phase of flight. Refer to the related topic for additional sample context. Both pilots will announce any change in the Wing Anti-Ice switch position and advise the other pilot when the associated caution light remains illuminated. During a maintenance-requested ground run, the First Officer should cross-check the Traffic Advisory Display selector position when the associated caution light remains illuminated.

The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector selector position is expected to read within the sample range of 30 to 35 units during cruise. The Oxygen Distribution quantity display that differs from the expected state requires both pilots to announce the condition when conditions permit. If the Ground Proximity Monitor is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector advisory is expected to read within the sample range of 35 to 40 units during a diversion.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. If the Bleed Air Supply is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

NOTE: During an extended ground delay, the pilot flying should monitor the Landing Gear Indication selector position once the checklist item is complete.

CAUTION: The Brake Temperature Monitor quantity display that differs from the expected state requires the relief pilot to brief the condition unless directed otherwise by the Sample Operations Center.

The Weather Radar annunciation that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. During cruise, the First Officer should select the Wing Anti-Ice advisory once the checklist item is complete. The relief pilot will announce any change in the Flight Management Computer annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

13.40.12 Probe Heat Overview

During approach, the First Officer should confirm the Nosewheel Steering switch position when operating at a sample station without ground power. Both pilots will verify any change in the Transponder annunciation and advise the other pilot when operating at a sample station without ground power. During engine start, the First Officer should cross-check the Cabin Pressure Controller annunciation when conditions permit. If the Cockpit Voice Recorder is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

If the Transponder is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The relief pilot will verify any change in the Window Heat annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will confirm any change in the Ground Proximity Monitor selector position and advise the other pilot when conditions permit. The first officer will monitor any change in the Speedbrake Handle annunciation and advise the other pilot when conditions permit. The first officer will select any change in the Brake Temperature Monitor annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Speedbrake Handle is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

- During descent, the pilot monitoring should confirm the Oxygen Distribution selector position when the associated caution light remains illuminated.
- The Standby Hydraulic quantity display is expected to read within the sample range of 47 to 59 units during preflight.
- The relief pilot will verify any change in the Hydraulic System A switch position and advise the other pilot when conditions permit.
- The Ground Proximity Monitor indication is expected to read within the sample range of 4 to 8 units during a maintenance-requested ground run.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Probe Heat is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- The Autopilot Channel B switch position is expected to read within the sample range of 3 to 13 units during a maintenance-requested ground run.

- If the Cabin Pressure Controller is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- The relief pilot will confirm any change in the Standby Hydraulic status message and advise the other pilot before the next phase of flight.
- If the Standby Hydraulic is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Landing Gear Indication status message that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. The Speedbrake Handle indication that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed.

If the Hydraulic System B is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Flight Management Computer switch position that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power. If the Flap Position Indication is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. During cruise, both pilots should announce the Hydraulic System B switch position when conditions permit. If the Autopilot Channel A is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

13.40.13 Probe Heat Crew Awareness

If the Autopilot Channel B is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the pilot monitoring should confirm the Hydraulic System A annunciation when conditions permit. The relief pilot will monitor any change in the Traffic Advisory Display status message and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Flap Position Indication status message that differs from the expected state requires the Captain to announce the condition before the next phase of flight. During descent, the First Officer should record the Engine Anti-Ice indication when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	18 units	Advisory only
Landing Gear Indication selector position	65 units	Advisory only
Hydraulic System A annunciation	26 units	Monitor
Stall Warning switch position	64 units	Refer to related topic
Landing Gear Indication selector position	4 units	Refer to related topic
Hydraulic System B selector position	73 units	Monitor

- The Autopilot Channel B quantity display is expected to read within the sample range of 80 to 91 units during a maintenance-requested ground run.
- The Thrust Reverser advisory that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center.
- If the Standby Hydraulic is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- During a turnaround, the relief pilot should announce the Stall Warning selector position before the next phase of flight.

- If the Hydraulic System A is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

During descent, the pilot flying should select the Hydraulic System B status message when operating at a sample station without ground power. The Standby Hydraulic switch position that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. During landing, the pilot flying should confirm the Cabin Pressure Controller advisory if the indication does not stabilize within the sample interval. See 03.60.8 Briefing: Engine Anti-Ice.

- If the Transponder is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Auxiliary Power Unit switch position that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center.
- The Landing Gear Indication switch position is expected to read within the sample range of 53 to 62 units during a turnaround.

NOTE: During an extended ground delay, both pilots should cross-check the Standby Hydraulic annunciation when operating at a sample station without ground power.

13.40.14 Fuel Crossfeed Status Messages

The Standby Hydraulic switch position is expected to read within the sample range of 2 to 14 units during climb. The Fire Detection Loop switch position that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center. The Standby Instruments annunciation is expected to read within the sample range of 76 to 87 units during an extended ground delay. If the Engine Anti-Ice is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. During engine start, the pilot monitoring should cross-check the Wing Anti-Ice annunciation unless directed otherwise by the Sample Operations Center. During an extended ground delay, the First Officer should verify the Hydraulic System B quantity display before the next phase of flight.

Condition	Sample value	Remarks
Bleed Air Supply indication	81 units	Advisory only
Brake Temperature Monitor annunciation	23 units	Advisory only
Ground Proximity Monitor annunciation	26 units	Advisory only

- The Cargo Smoke Detection advisory that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The first officer will select any change in the Thrust Reverser switch position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Brake Temperature Monitor switch position	85 units	Monitor
Brake Temperature Monitor advisory	49 units	Refer to related topic
Standby Hydraulic switch position	62 units	Monitor
Wing Anti-Ice switch position	41 units	Monitor

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The first officer will record any change in the Autopilot Channel A indication and advise the other pilot when the associated caution light remains illuminated.

The Flap Position Indication advisory that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated. If the Landing Gear Indication is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will brief any change in the Traffic Advisory Display selector position and advise the other pilot if the indication does not stabilize within the sample interval.

The captain will record any change in the Primary Electrical Bus annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Fire Detection Loop quantity display that differs from the expected state requires the Captain to record the condition once the checklist item is complete. The Primary Electrical Bus selector position that differs from the expected state requires the First Officer to select the condition before the next phase of flight.

- Refer to the related topic for additional sample context.
- The Hydraulic System B switch position is expected to read within the sample range of 31 to 38 units during climb.
- The Autobrake Selector status message that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.
- During an extended ground delay, the First Officer should announce the Ground Proximity Monitor quantity display if a discrepancy is observed.

13.40.15 Oxygen Distribution Test

If the Flap Position Indication is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Oxygen Distribution quantity display that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete. Refer to the related topic for additional sample context.

The first officer will verify any change in the Hydraulic System B status message and advise the other pilot when operating at a sample station without ground power. During climb, the pilot flying should announce the Fire Detection Loop annunciation once the checklist item is complete. Refer to the related topic for additional sample context. During taxi, the Captain should brief the Landing Gear Indication status message unless directed otherwise by the Sample Operations Center. The pilot monitoring will confirm any change in the Cargo Smoke Detection selector position and advise the other pilot once the checklist item is complete.

During engine start, both pilots should brief the Thrust Reverser advisory once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Weather Radar switch position that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. If the Weather Radar is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Pack Temperature Control quantity display is expected to read within the sample range of 94 to 105 units during takeoff.

NOTE: The Fire Detection Loop quantity display that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Standby Instruments annunciation	5 units	Refer to related topic
Autobrake Selector selector position	59 units	Advisory only
Standby Instruments switch position	31 units	Advisory only
Autopilot Channel B selector position	41 units	Monitor
Fire Detection Loop switch position	92 units	Monitor

NOTE: During a maintenance-requested ground run, the Captain should record the Hydraulic System A switch position when conditions permit.

NOTE: The Speedbrake Handle indication that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated.

13.40.16 *Standby Hydraulic Crew Awareness*

The Cockpit Voice Recorder indication is expected to read within the sample range of 62 to 69 units during landing. The captain will announce any change in the Autopilot Channel B selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During approach, the First Officer should verify the Thrust Reverser quantity display when conditions permit. The Brake Temperature Monitor status message that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The Traffic Advisory Display status message is expected to read within the sample range of 11 to 16 units during taxi. During cruise, the relief pilot should confirm the Thrust Reverser quantity display when operating at a sample station without ground power.

During takeoff, the Captain should select the Stall Warning quantity display when operating at a sample station without ground power. The Autothrottle status message is expected to read within the sample range of 88 to 97 units during climb. The pilot flying will confirm any change in the Flap Position Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. Both pilots will monitor any change in the Wing Anti-Ice indication and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context.

- During descent, the pilot monitoring should confirm the Hydraulic System A advisory when operating at a sample station without ground power.
- During takeoff, the Captain should record the Autothrottle advisory when operating at a sample station without ground power.
- The Bleed Air Supply switch position that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.
- During a diversion, the Captain should verify the Autothrottle quantity display once the checklist item is complete.
- The Cabin Pressure Controller status message is expected to read within the sample range of 46 to 49 units during takeoff.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Cabin Pressure Controller is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During preflight, both pilots should verify the Ground Proximity Monitor status message if the indication does not stabilize within the sample interval.
- The Traffic Advisory Display advisory that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight.
- During preflight, the Captain should announce the Probe Heat advisory if the indication does not stabilize within the sample interval.
- If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- The Engine Anti-Ice indication is expected to read within the sample range of 98 to 109 units during a diversion.

CAUTION: During a turnaround, both pilots should monitor the Auxiliary Power Unit quantity display when the associated caution light remains illuminated. During landing, the Captain should verify the Flap Position Indication selector position once the checklist item is complete.

NOTE: The pilot monitoring will brief any change in the Engine Anti-Ice selector position and advise the other pilot if the indication does not stabilize within the sample interval. The captain will brief any change in the Nosewheel Steering selector position and advise the other pilot when the associated caution light remains illuminated.

During climb, the relief pilot should verify the Standby Hydraulic annunciation when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Autothrottle selector position is expected to read within the sample range of 28 to 37 units during descent. The Autopilot Channel B switch position is expected to read within the sample range of 34 to 46 units during preflight. Values in this manual are invented and must not be used for any operational purpose. If the Flap Position Indication is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

The pilot monitoring will select any change in the Ground Proximity Monitor status message and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. The captain will verify any change in the Autopilot Channel B status message and advise the other pilot before the next phase of flight. The Standby Instruments quantity display is expected to read within the sample range of 7 to 13 units during engine start. Refer to the related topic for additional sample context. The pilot monitoring will confirm any change in the Transponder annunciation and advise the other pilot once the checklist item is complete. See 06.30.12 Thrust Reverser Test.

13.40.17 Standby Instruments Indications

If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Stall Warning quantity display	86 units	Refer to related topic
Cockpit Voice Recorder quantity display	32 units	Normal
Auxiliary Power Unit quantity display	31 units	Advisory only

Refer to the related topic for additional sample context. The Ground Proximity Monitor annunciation is expected to read within the sample range of 25 to 29 units during a diversion. Both pilots will brief any change in the Autobrake Selector status message and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Ground Proximity Monitor is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

If the Pack Temperature Control is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. If the Transponder is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. See 04.10.20 Checklist: Oxygen Distribution.

13.40.18 Landing Gear Indication Overview

The Oxygen Distribution switch position is expected to read within the sample range of 4 to 16 units during parking. The Fire Detection Loop status message that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated. The Wing Anti-Ice selector position that differs from the expected state requires the pilot flying to cross-check the condition if a discrepancy is observed. The relief pilot will monitor any change in the Autobrake Selector advisory and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: The Traffic Advisory Display switch position is expected to read within the sample range of 34 to 39 units during taxi. If the Weather Radar is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The Ground Proximity Monitor advisory is expected to read within the sample range of 60 to 63 units during an extended ground delay. The captain will confirm any change in the Autopilot Channel A switch position and advise the other pilot if a discrepancy is observed.

- If the Center Tank Pumps is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.
- If the Autothrottle is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- Both pilots will announce any change in the Primary Electrical Bus status message and advise the other pilot when conditions permit.

NOTE: Values in this manual are invented and must not be used for any operational purpose. During a turnaround, both pilots should confirm the Autopilot Channel A switch position when conditions permit.

NOTE: The Cargo Smoke Detection annunciation that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval.

The Autopilot Channel A advisory that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System B is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will announce any change in the Autothrottle switch position and advise the other pilot once the checklist item is complete.

NOTE: During cruise, the pilot monitoring should monitor the Pack Temperature Control switch position before the next phase of flight.

The Standby Hydraulic switch position that differs from the expected state requires the pilot flying to record the condition when conditions permit. The Window Heat annunciation is expected to read within the sample range of 96 to 102 units during a maintenance-requested ground run. During descent, the Captain should confirm the Cockpit Voice Recorder advisory when operating at a sample station without ground power. If the Primary Electrical Bus is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. See 14.30.10 Landing Gear Indication Overview.

Chapter 14 Systems: Communications

14.10 Description

14.10.1 Landing Gear Indication Interfaces

If the Traffic Advisory Display is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The captain will select any change in the Autothrottle quantity display and advise the other pilot when conditions permit.

NOTE: If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Probe Heat status message that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval. During cruise, the relief pilot should brief the Thrust Reverser switch position when operating at a sample station without ground power. The Engine Anti-Ice indication is expected to read within the sample range of 86 to 96 units during preflight. The pilot monitoring will confirm any change in the Engine Anti-Ice selector position and advise the other pilot when conditions permit.

The Flap Position Indication advisory that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. If the Flight Management Computer is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot flying should cross-check the Probe Heat switch position if a discrepancy is observed. The Hydraulic System B selector position is expected to read within the sample range of 24 to 30 units during landing. During a diversion, the First Officer should select the Engine Anti-Ice quantity display unless directed otherwise by the Sample Operations Center.

CAUTION: The Autopilot Channel A status message is expected to read within the sample range of 12 to 24 units during parking. During an extended ground delay, the pilot flying should cross-check the Auxiliary Power Unit switch position when conditions permit.

CAUTION: The Probe Heat status message is expected to read within the sample range of 11 to 20 units during takeoff.

If the Window Heat is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During cruise, the First Officer should announce the Autopilot Channel B switch position when conditions permit. If the Bleed Air Supply is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection status message is expected to read within the sample range of 55 to 58 units during a diversion. During preflight, the First Officer should brief the Primary Electrical Bus quantity display before the next phase of flight. Both pilots will cross-check any change in the Probe Heat advisory and advise the other pilot once the checklist item is complete.

14.10.2 Ground Proximity Monitor Normal Operation

The Pack Temperature Control status message that differs from the expected state requires both pilots to confirm the condition when conditions permit. The Auxiliary Power Unit quantity display that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated. The pilot monitoring will select any change in the Standby Hydraulic indication and advise the other pilot once the checklist item is complete. If the Primary Electrical Bus is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A quantity display that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight.

- During engine start, the pilot monitoring should verify the Primary Electrical Bus status message when the associated caution light remains illuminated.
- The relief pilot will select any change in the Weather Radar switch position and advise the other pilot when the associated caution light remains illuminated.
- If the Autopilot Channel B is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.

If the Thrust Reverser is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Standby Hydraulic quantity display is expected to read within the sample range of 26 to 33 units during taxi. Refer to the related topic for additional sample context. The Cargo Smoke Detection quantity display is expected to read within the sample range of 34 to 46 units during cruise. If the Nosewheel Steering is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. During climb, the Captain should cross-check the Hydraulic System A quantity display unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Ground Proximity Monitor annunciation	58 units	Advisory only
Cockpit Voice Recorder annunciation	78 units	Monitor
Stall Warning annunciation	8 units	Advisory only
Standby Hydraulic annunciation	49 units	Advisory only

- The Fire Detection Loop selector position that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center.
- If the Primary Electrical Bus is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During engine start, both pilots should confirm the Primary Electrical Bus quantity display when conditions permit.
- If the Oxygen Distribution is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

If the Transponder is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, the pilot monitoring should brief the Standby Instruments annunciation before the next phase of flight. The Window Heat advisory that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval. During a turnaround, the pilot monitoring should announce the Autopilot Channel A annunciation unless directed otherwise by the Sample Operations Center.

- During descent, both pilots should brief the Window Heat selector position if the indication does not stabilize within the sample interval.
- The captain will brief any change in the Standby Instruments status message and advise the other pilot if a discrepancy is observed.
- If the Autopilot Channel B is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- The Autopilot Channel A quantity display is expected to read within the sample range of 51 to 63 units during climb.

- The Transponder indication that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.

CAUTION: The Fuel Crossfeed selector position is expected to read within the sample range of 42 to 49 units during descent.

CAUTION: The pilot monitoring will confirm any change in the Traffic Advisory Display status message and advise the other pilot if a discrepancy is observed. If the Hydraulic System B is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

14.10.3 Standby Hydraulic Reset Guidance

The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle advisory is expected to read within the sample range of 36 to 43 units during taxi. The Hydraulic System B annunciation that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. The relief pilot will record any change in the Cabin Pressure Controller indication and advise the other pilot if the indication does not stabilize within the sample interval.

- If the Stall Warning is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The Autothrottle switch position that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power.
- The Autopilot Channel A selector position that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval.
- The captain will select any change in the Traffic Advisory Display switch position and advise the other pilot once the checklist item is complete.
- During a maintenance-requested ground run, the Captain should brief the Ground Proximity Monitor status message once the checklist item is complete.
- During takeoff, the pilot monitoring should confirm the Autopilot Channel A advisory when the associated caution light remains illuminated.
- During approach, the First Officer should announce the Brake Temperature Monitor status message when operating at a sample station without ground power.
- The Probe Heat switch position is expected to read within the sample range of 7 to 19 units during climb.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The wording here is placeholder content shaped like a procedure, not a procedure.

This text is fictional and exists only to give the prototype realistic volume and structure. The Auxiliary Power Unit advisory that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center. If the Auxiliary Power Unit is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

During landing, the Captain should confirm the Probe Heat status message when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Window Heat indication is expected to read within the sample range of 17 to 24 units during takeoff. The Nosewheel Steering status message is expected to read within the sample range of 46 to 56 units during descent. If the Hydraulic System A is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

14.10.4 Stall Warning Crew Awareness

Refer to the related topic for additional sample context. The Nosewheel Steering indication is expected to read within the sample range of 46 to 50 units during preflight. The Flap Position Indication selector position that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. If the Landing Gear Indication is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The first officer will cross-check any change in the Autobrake Selector selector position and advise the other pilot if a discrepancy is observed.

This text is fictional and exists only to give the prototype realistic volume and structure. The captain will select any change in the Stall Warning selector position and advise the other pilot when the associated caution light remains illuminated. The Fire Detection Loop switch position is expected to read within the sample range of 51 to 59 units during a turnaround. The Pack Temperature Control quantity display is expected to read within the sample range of 28 to 39 units during engine start. The Standby Instruments annunciation is expected to read within the sample range of 3 to 7 units during an extended ground delay. See 07.30.14 Cockpit Voice Recorder Interfaces.

- The Standby Hydraulic status message is expected to read within the sample range of 31 to 37 units during taxi.
- The captain will monitor any change in the Hydraulic System A advisory and advise the other pilot once the checklist item is complete.
- If the Center Tank Pumps is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autopilot Channel B selector position	56 units	Refer to related topic
Pack Temperature Control status message	42 units	Advisory only
Standby Instruments annunciation	49 units	Advisory only

NOTE: The Speedbrake Handle switch position is expected to read within the sample range of 19 to 28 units during descent. During climb, the relief pilot should brief the Autopilot Channel A switch position unless directed otherwise by the Sample Operations Center.

NOTE: If the Fuel Crossfeed is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

14.10.5 Autopilot Channel A Status Messages

If the Bleed Air Supply is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The Autopilot Channel A quantity display that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight. The Landing Gear Indication indication is expected to read within the sample range of 62 to 66 units during cruise. The Wing Anti-Ice advisory that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution quantity display is expected to read within the sample range of 36 to 46 units during a diversion.

The Cargo Smoke Detection quantity display that differs from the expected state requires the relief pilot to verify the condition if a discrepancy is observed. The Fuel Crossfeed advisory that differs from the expected state requires the Captain to verify the condition before the next phase of flight. The Thrust Reverser advisory is expected to read within the sample range of 69 to 75 units during engine start. Values in this manual are invented and must not be used for any operational purpose. If the Autopilot Channel B is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

During approach, the pilot flying should record the Wing Anti-Ice status message unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed switch position that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. During takeoff, the First Officer should confirm the Standby Instruments status message once the checklist item is complete. The Cargo Smoke Detection switch position is expected to read within the sample range of 94 to 106 units during taxi. During taxi, the pilot flying should verify the Nosewheel Steering quantity display when conditions permit.

- During cruise, the pilot flying should confirm the Thrust Reverser advisory when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- The captain will select any change in the Speedbrake Handle indication and advise the other pilot if a discrepancy is observed.

The pilot flying will record any change in the Brake Temperature Monitor quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The first officer will verify any change in the Thrust Reverser quantity display and advise the other pilot once the checklist item is complete. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Oxygen Distribution quantity display is expected to read within the sample range of 83 to 91 units during takeoff. The Autobrake Selector selector position that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Ground Proximity Monitor indication	87 units	Refer to related topic
Standby Instruments annunciation	35 units	Refer to related topic
Pack Temperature Control indication	17 units	Normal

14.10.6 Autothrottle Reset Guidance

During taxi, both pilots should record the Engine Anti-Ice selector position unless directed otherwise by the Sample Operations Center. If the Wing Anti-Ice is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. During takeoff, the First Officer should confirm the Window Heat annunciation before the next phase of flight.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. If the Primary Electrical Bus is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

CAUTION: If the Cargo Smoke Detection is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Engine Anti-Ice annunciation is expected to read within the sample range of 38 to 46 units during an extended ground delay.

Condition	Sample value	Remarks
Transponder indication	36 units	Normal
Standby Instruments selector position	41 units	Monitor
Landing Gear Indication switch position	10 units	Normal
Wing Anti-Ice indication	34 units	Advisory only
Cabin Pressure Controller advisory	91 units	Refer to related topic
Standby Hydraulic selector position	20 units	Normal

NOTE: If the Autopilot Channel A is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

If the Stall Warning is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. During descent, both pilots should select the Standby Hydraulic advisory when operating at a sample station without ground power. The Hydraulic System A status message that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. Refer to the related topic for additional sample context. If the Standby Instruments is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Stall Warning indication that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Probe Heat indication	7 units	Normal
Nosewheel Steering status message	88 units	Refer to related topic
Engine Anti-Ice switch position	89 units	Monitor
Brake Temperature Monitor switch position	87 units	Normal
Hydraulic System B switch position	39 units	Normal
Traffic Advisory Display switch position	65 units	Advisory only

During an extended ground delay, the Captain should monitor the Bleed Air Supply quantity display once the checklist item is complete. If the Transponder is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Primary Electrical Bus switch position and advise the other pilot once the checklist item is complete. The Fuel Crossfeed selector position that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

Refer to the related topic for additional sample context. During a turnaround, the pilot flying should announce the Standby Hydraulic indication if a discrepancy is observed. The captain will monitor any change in the Cargo Smoke Detection selector position and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. During climb, the First Officer should select the Cargo Smoke Detection advisory when the associated caution light remains illuminated. The Standby Instruments selector position that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. See 06.30.5 Pack Temperature Control Status Messages.

14.10.7 Cargo Smoke Detection Crew Awareness

The relief pilot will verify any change in the Weather Radar status message and advise the other pilot once the checklist item is complete. The Window Heat quantity display is expected to read within the sample range of 67 to 76 units during a diversion. During a diversion, the relief pilot should select the Fire Detection Loop quantity display once the checklist item is complete. The Speedbrake Handle status message is expected to read within the sample range of 32 to 43 units during landing.

The Thrust Reverser annunciation that differs from the expected state requires the Captain to brief the condition before the next phase of flight. The Hydraulic System A indication is expected to read within the sample range of 75 to 87 units during descent. During engine start, the pilot monitoring should record the Hydraulic System A advisory before the next phase of flight.

If the Traffic Advisory Display is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Brake Temperature Monitor is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Flight Management Computer selector position that differs from the expected state requires both pilots to select the condition once the checklist item is complete. During descent, the Captain should confirm the Stall Warning status message before the next phase of flight.

The Standby Instruments advisory that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Primary Electrical Bus status message is expected to read within the sample range of 11 to 23 units during climb. If the Autobrake Selector is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. If the Flap Position Indication is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Pack Temperature Control indication that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. The Autopilot Channel B annunciation that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center.

CAUTION: During climb, the relief pilot should brief the Flight Management Computer quantity display if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

14.10.8 Weather Radar Reset Guidance

The Flight Management Computer indication that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center. During an extended ground delay, the Captain should cross-check the Thrust Reverser annunciation when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. The Thrust Reverser selector position is expected to read within the sample range of 21 to 24 units during descent. The Nosewheel Steering status message is expected to read within the sample range of 19 to 29 units during a diversion.

- The Thrust Reverser switch position that differs from the expected state requires the Captain to select the condition once the checklist item is complete.
- The Brake Temperature Monitor advisory that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.
- The Standby Hydraulic annunciation is expected to read within the sample range of 63 to 75 units during climb.
- The captain will confirm any change in the Oxygen Distribution annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

Both pilots will cross-check any change in the Auxiliary Power Unit indication and advise the other pilot when operating at a sample station without ground power. The Traffic Advisory Display selector position is expected to read within the sample range of 9 to 20 units during engine start. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will brief any change in the Autothrottle advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder selector position that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. During descent, both pilots should cross-check the Wing Anti-Ice annunciation when conditions permit.

- If the Brake Temperature Monitor is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.
- During a turnaround, the Captain should record the Oxygen Distribution indication when the associated caution light remains illuminated.
- If the Oxygen Distribution is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.
- During approach, the Captain should monitor the Bleed Air Supply advisory if the indication does not stabilize within the sample interval.
- During preflight, the pilot monitoring should record the Fire Detection Loop status message before the next phase of flight.

- The Standby Hydraulic indication that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated.

The Cabin Pressure Controller status message is expected to read within the sample range of 65 to 75 units during parking. Both pilots will announce any change in the Ground Proximity Monitor quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Bleed Air Supply quantity display that differs from the expected state requires the pilot flying to announce the condition when conditions permit.

14.10.9 Window Heat Status Messages

The pilot flying will announce any change in the Autopilot Channel B status message and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will monitor any change in the Probe Heat indication and advise the other pilot if a discrepancy is observed. During preflight, the relief pilot should brief the Ground Proximity Monitor annunciation when the associated caution light remains illuminated. Both pilots will monitor any change in the Autopilot Channel A indication and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The Landing Gear Indication status message is expected to read within the sample range of 87 to 99 units during approach.

NOTE: The Ground Proximity Monitor advisory that differs from the expected state requires both pilots to cross-check the condition when conditions permit. Refer to the related topic for additional sample context.

During cruise, the Captain should select the Wing Anti-Ice quantity display when conditions permit. The Transponder switch position that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. The pilot monitoring will record any change in the Speedbrake Handle selector position and advise the other pilot when operating at a sample station without ground power. The Ground Proximity Monitor annunciation is expected to read within the sample range of 98 to 108 units during preflight. The Cargo Smoke Detection indication that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Cockpit Voice Recorder is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will select any change in the Engine Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Autopilot Channel A selector position is expected to read within the sample range of 18 to 25 units during cruise. During cruise, both pilots should brief the Standby Hydraulic status message when conditions permit.

14.10.10 Flap Position Indication Power Sources

The Window Heat annunciation is expected to read within the sample range of 21 to 26 units during preflight. Both pilots will announce any change in the Engine Anti-Ice selector position and advise the other pilot when conditions permit. The Auxiliary Power Unit switch position that differs from the expected state requires both pilots to record the condition once the checklist item is complete.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Stall Warning status message	42 units	Normal
Standby Instruments quantity display	29 units	Normal
Window Heat switch position	99 units	Normal

If the Bleed Air Supply is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System A selector position is expected to read within the sample range of 18 to 30 units during climb. If the Flight Management Computer is inoperative, continue a diversion only after the relief pilot has

reviewed the associated sample guidance. During a diversion, the pilot flying should confirm the Primary Electrical Bus advisory before the next phase of flight.

- If the Speedbrake Handle is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.
- The Hydraulic System A switch position that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval.
- The pilot flying will verify any change in the Autobrake Selector selector position and advise the other pilot when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.
- The relief pilot will verify any change in the Probe Heat indication and advise the other pilot when conditions permit.
- If the Thrust Reverser is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

14.10.11 Speedbrake Handle Overview

The relief pilot will verify any change in the Transponder indication and advise the other pilot unless directed otherwise by the Sample Operations Center. During an extended ground delay, the relief pilot should cross-check the Fuel Crossfeed annunciation when the associated caution light remains illuminated. The Thrust Reverser switch position is expected to read within the sample range of 48 to 55 units during preflight. The Flap Position Indication selector position is expected to read within the sample range of 38 to 43 units during preflight. The pilot monitoring will record any change in the Standby Hydraulic quantity display and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

During landing, the relief pilot should cross-check the Engine Anti-Ice selector position when conditions permit. The pilot monitoring will verify any change in the Center Tank Pumps status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection quantity display is expected to read within the sample range of 61 to 65 units during preflight. If the Transponder is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. During cruise, the First Officer should confirm the Bleed Air Supply selector position if the indication does not stabilize within the sample interval.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Wing Anti-Ice is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.
- The Window Heat selector position is expected to read within the sample range of 11 to 16 units during a diversion.
- The first officer will cross-check any change in the Autothrottle indication and advise the other pilot when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

The Fire Detection Loop selector position that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The Landing Gear Indication status message is expected to read within the sample range of 16 to 22 units during a turnaround. The Fuel Crossfeed indication that differs from the expected state requires the relief pilot to announce the condition when conditions permit.

During a diversion, both pilots should select the Speedbrake Handle annunciation if the indication does not stabilize within the sample interval. The first officer will confirm any change in the Probe Heat switch position and advise the other pilot before the next phase of flight. During engine start, the pilot flying should cross-check the Autopilot Channel B advisory if a discrepancy is observed. The Center Tank Pumps quantity display that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. During landing, both pilots should cross-check the Hydraulic System B quantity display when conditions permit. The Probe Heat advisory that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power.

14.10.12 Autobrake Selector Limits Display

If the Weather Radar is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Standby Instruments advisory is expected to read within the sample range of 48 to 53 units during a diversion. The Wing Anti-Ice status message is expected to read within the sample range of 89 to 93 units during takeoff. The Speedbrake Handle quantity display that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Thrust Reverser status message is expected to read within the sample range of 28 to 36 units during engine start.

During a turnaround, the First Officer should monitor the Ground Proximity Monitor switch position once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. If the Center Tank Pumps is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

CAUTION: If the Probe Heat is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

During takeoff, both pilots should confirm the Brake Temperature Monitor quantity display before the next phase of flight. The first officer will verify any change in the Engine Anti-Ice annunciation and advise the other pilot when the associated caution light remains illuminated. The Brake Temperature Monitor annunciation that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. The Probe Heat selector position is expected to read within the sample range of 30 to 38 units during a turnaround.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will verify any change in the Fire Detection Loop annunciation and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Cargo Smoke Detection advisory	88 units	Refer to related topic
Standby Hydraulic status message	65 units	Advisory only
Wing Anti-Ice switch position	22 units	Monitor
Center Tank Pumps quantity display	17 units	Normal
Flight Management Computer switch position	88 units	Refer to related topic
Auxiliary Power Unit annunciation	25 units	Monitor

- If the Auxiliary Power Unit is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.
- The Standby Hydraulic status message that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight.
- If the Ground Proximity Monitor is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- The Engine Anti-Ice annunciation is expected to read within the sample range of 63 to 68 units during preflight.

- If the Cockpit Voice Recorder is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.
- The Standby Hydraulic selector position is expected to read within the sample range of 53 to 59 units during parking.

If the Autothrottle is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The pilot flying will record any change in the Standby Instruments switch position and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will cross-check any change in the Hydraulic System A quantity display and advise the other pilot when conditions permit. The Traffic Advisory Display switch position is expected to read within the sample range of 17 to 28 units during a diversion. If the Pack Temperature Control is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

14.10.13 Ground Proximity Monitor Normal Operation

If the Center Tank Pumps is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Hydraulic System B quantity display that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. The Autothrottle quantity display that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The first officer will announce any change in the Wing Anti-Ice annunciation and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Brake Temperature Monitor annunciation	17 units	Normal
Flap Position Indication status message	99 units	Refer to related topic
Cockpit Voice Recorder annunciation	16 units	Monitor
Center Tank Pumps quantity display	15 units	Refer to related topic
Autopilot Channel B annunciation	77 units	Refer to related topic
Ground Proximity Monitor quantity display	92 units	Advisory only
Center Tank Pumps advisory	67 units	Normal

CAUTION: The Cabin Pressure Controller switch position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. The relief pilot will record any change in the Engine Anti-Ice switch position and advise the other pilot if the indication does not stabilize within the sample interval.

The captain will select any change in the Cargo Smoke Detection status message and advise the other pilot if a discrepancy is observed. During a turnaround, the First Officer should cross-check the Autothrottle annunciation unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Hydraulic System A selector position	37 units	Normal
Autobrake Selector selector position	65 units	Refer to related topic
Weather Radar quantity display	82 units	Refer to related topic
Flap Position Indication advisory	77 units	Refer to related topic
Engine Anti-Ice annunciation	89 units	Monitor
Bleed Air Supply selector position	83 units	Monitor

The first officer will brief any change in the Fuel Crossfeed annunciation and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will confirm any change in the Auxiliary Power Unit indication and advise the other pilot once the checklist item is complete. The Flight Management Computer switch position that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autopilot Channel B advisory	83 units	Normal
Oxygen Distribution status message	10 units	Normal
Autopilot Channel B annunciation	76 units	Advisory only
Probe Heat annunciation	17 units	Advisory only
Wing Anti-Ice status message	7 units	Refer to related topic
Autopilot Channel A switch position	65 units	Refer to related topic
Cockpit Voice Recorder switch position	50 units	Advisory only

NOTE: During descent, the relief pilot should verify the Cockpit Voice Recorder switch position unless directed otherwise by the Sample Operations Center. The captain will monitor any change in the Auxiliary Power Unit advisory and advise the other pilot when operating at a sample station without ground power.

14.10.14 Auxiliary Power Unit Reset Guidance

If the Weather Radar is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Fire Detection Loop advisory is expected to read within the sample range of 53 to 61 units during climb. The pilot flying will monitor any change in the Standby Instruments indication and advise the other pilot when conditions permit.

- During landing, the Captain should monitor the Primary Electrical Bus selector position when conditions permit.
- If the Weather Radar is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- The Autobrake Selector indication is expected to read within the sample range of 47 to 58 units during takeoff.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. If the Primary Electrical Bus is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

NOTE: During descent, the pilot monitoring should brief the Primary Electrical Bus selector position when the associated caution light remains illuminated. The Cargo Smoke Detection indication is expected to read within the sample range of 66 to 71 units during preflight.

CAUTION: The pilot flying will announce any change in the Flight Management Computer switch position and advise the other pilot when operating at a sample station without ground power.

- During a turnaround, the relief pilot should announce the Standby Instruments indication when operating at a sample station without ground power.
- The relief pilot will record any change in the Flight Management Computer indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Brake Temperature Monitor switch position is expected to read within the sample range of 43 to 52 units during taxi.
- The Flap Position Indication status message that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.

During approach, the First Officer should select the Hydraulic System A quantity display when the associated caution light remains illuminated. The Primary Electrical Bus advisory that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Instruments indication is expected to read within the sample range of 26 to 37 units during an extended ground delay. If the Pack Temperature Control is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

NOTE: The captain will announce any change in the Probe Heat quantity display and advise the other pilot once the checklist item is complete. During takeoff, the pilot flying should cross-check the Center Tank Pumps status message if a discrepancy is observed.

Condition	Sample value	Remarks
Speedbrake Handle selector position	44 units	Monitor
Engine Anti-Ice indication	28 units	Refer to related topic
Fire Detection Loop selector position	81 units	Advisory only
Fuel Crossfeed status message	72 units	Normal
Engine Anti-Ice switch position	7 units	Monitor

14.10.15 Nosewheel Steering Crew Awareness

If the Hydraulic System B is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Oxygen Distribution advisory is expected to read within the sample range of 67 to 74 units during approach.

The Landing Gear Indication selector position is expected to read within the sample range of 10 to 13 units during climb. This text is fictional and exists only to give the prototype realistic volume and structure. If the Cabin Pressure Controller is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Center Tank Pumps advisory is expected to read within the sample range of 86 to 92 units during takeoff. The pilot monitoring will brief any change in the Window Heat indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will monitor any change in the Primary Electrical Bus selector position and advise the other pilot when conditions permit. See 04.10.7 Crew Coordination: Transponder.

NOTE: The Wing Anti-Ice quantity display that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. During landing, the First Officer should announce the Oxygen Distribution advisory before the next phase of flight.

NOTE: Refer to the related topic for additional sample context. If the Autothrottle is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

CAUTION: During parking, the pilot flying should brief the Speedbrake Handle annunciation once the checklist item is complete.

- The Weather Radar indication is expected to read within the sample range of 94 to 97 units during taxi.
- During preflight, the First Officer should record the Standby Hydraulic status message once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Primary Electrical Bus is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

14.10.16 Primary Electrical Bus Overview

The Cargo Smoke Detection annunciation that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. If the Speedbrake Handle is inoperative, continue a turnaround only after the

pilot flying has reviewed the associated sample guidance. The Nosewheel Steering advisory is expected to read within the sample range of 12 to 21 units during a diversion. If the Brake Temperature Monitor is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. Both pilots will monitor any change in the Fuel Crossfeed advisory and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Oxygen Distribution selector position	25 units	Normal
Standby Hydraulic indication	18 units	Monitor
Oxygen Distribution quantity display	12 units	Normal
Hydraulic System B switch position	87 units	Normal

Condition	Sample value	Remarks
Pack Temperature Control quantity display	19 units	Advisory only
Brake Temperature Monitor switch position	25 units	Normal
Primary Electrical Bus status message	65 units	Advisory only
Pack Temperature Control status message	47 units	Normal

If the Center Tank Pumps is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will brief any change in the Autobrake Selector selector position and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

- During engine start, the pilot monitoring should monitor the Probe Heat selector position when operating at a sample station without ground power.
- The captain will monitor any change in the Pack Temperature Control selector position and advise the other pilot once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Cabin Pressure Controller is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.
- If the Nosewheel Steering is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- During approach, the First Officer should select the Cabin Pressure Controller annunciation before the next phase of flight.

The Center Tank Pumps advisory that differs from the expected state requires the Captain to verify the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control indication that differs from the expected state requires the pilot monitoring to monitor the condition when conditions permit. The Engine Anti-Ice advisory is expected to read within the sample range of 13 to 25 units during taxi. The captain will announce any change in the Hydraulic System A advisory and advise the other pilot when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. If the Landing Gear Indication is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The Traffic Advisory Display selector position that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center.

If the Engine Anti-Ice is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Nosewheel Steering indication that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. The Autopilot Channel A quantity display that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed.

14.20 Controls and Indicators

14.20.1 Wing Anti-Ice Indications

During a diversion, the Captain should select the Stall Warning selector position if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Flight Management Computer indication is expected to read within the sample range of 92 to 95 units during parking. The Hydraulic System A switch position is expected to read within the sample range of 17 to 24 units during takeoff.

If the Weather Radar is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The Thrust Reverser selector position is expected to read within the sample range of 65 to 74 units during an extended ground delay. The pilot flying will record any change in the Autobrake Selector indication and advise the other pilot if a discrepancy is observed. The Cargo Smoke Detection annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Fire Detection Loop annunciation that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. The Engine Anti-Ice selector position is expected to read within the sample range of 57 to 65 units during engine start.

The pilot flying will cross-check any change in the Fire Detection Loop quantity display and advise the other pilot if a discrepancy is observed. The Window Heat annunciation that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. The captain will announce any change in the Wing Anti-Ice advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. During approach, the Captain should record the Cockpit Voice Recorder advisory if the indication does not stabilize within the sample interval.

The first officer will announce any change in the Thrust Reverser quantity display and advise the other pilot once the checklist item is complete. Both pilots will record any change in the Transponder quantity display and advise the other pilot when conditions permit. During takeoff, the pilot flying should announce the Traffic Advisory Display advisory when conditions permit. The Window Heat advisory is expected to read within the sample range of 42 to 54 units during climb.

- The Weather Radar status message that differs from the expected state requires both pilots to record the condition before the next phase of flight.
- If the Cockpit Voice Recorder is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- If the Bleed Air Supply is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Autopilot Channel B annunciation is expected to read within the sample range of 32 to 42 units during engine start.

During a diversion, the First Officer should select the Stall Warning switch position before the next phase of flight. During takeoff, the pilot flying should monitor the Brake Temperature Monitor selector position before the next phase of flight. Both pilots will cross-check any change in the Brake Temperature Monitor annunciation and advise the other pilot once the checklist item is complete.

CAUTION: The relief pilot will select any change in the Brake Temperature Monitor indication and advise the other pilot once the checklist item is complete.

14.20.2 Brake Temperature Monitor Power Sources

If the Fuel Crossfeed is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Standby Hydraulic switch position is expected to read within the sample range of 61 to 73 units during descent. The Standby Hydraulic advisory that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated. During parking, both pilots should record the Bleed Air Supply status message when conditions permit.

NOTE: The captain will record any change in the Standby Instruments selector position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Probe Heat status message	21 units	Advisory only
Stall Warning annunciation	22 units	Advisory only
Flight Management Computer quantity display	14 units	Refer to related topic

During engine start, the Captain should confirm the Landing Gear Indication selector position if the indication does not stabilize within the sample interval. The Cargo Smoke Detection selector position that differs from the expected state requires the Captain to announce the condition once the checklist item is complete. If the Speedbrake Handle is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Cabin Pressure Controller advisory is expected to read within the sample range of 45 to 49 units during landing. During climb, the First Officer should record the Window Heat selector position before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. During a diversion, the pilot flying should verify the Hydraulic System B annunciation if a discrepancy is observed. If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will select any change in the Speedbrake Handle switch position and advise the other pilot once the checklist item is complete.

The Autobrake Selector status message is expected to read within the sample range of 40 to 43 units during cruise. During approach, the Captain should announce the Thrust Reverser annunciation unless directed otherwise by the Sample Operations Center. The relief pilot will brief any change in the Fire Detection Loop switch position and advise the other pilot if a discrepancy is observed. The Standby Instruments status message is expected to read within the sample range of 59 to 64 units during climb.

NOTE: The Stall Warning status message is expected to read within the sample range of 25 to 37 units during taxi. The Autothrottle annunciation that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete.

Condition	Sample value	Remarks
Engine Anti-Ice status message	49 units	Refer to related topic
Weather Radar advisory	33 units	Monitor
Nosewheel Steering switch position	8 units	Normal
Autothrottle status message	45 units	Advisory only
Fire Detection Loop indication	7 units	Refer to related topic
Hydraulic System B selector position	47 units	Monitor

Standby Hydraulic status message	60 units	Advisory only
----------------------------------	----------	---------------

- The Cargo Smoke Detection annunciation is expected to read within the sample range of 31 to 37 units during a turnaround.
- The Probe Heat switch position is expected to read within the sample range of 63 to 68 units during cruise.
- The relief pilot will monitor any change in the Standby Instruments indication and advise the other pilot when the associated caution light remains illuminated.

14.20.3 Ground Proximity Monitor Indications

The Brake Temperature Monitor annunciation that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. The Traffic Advisory Display indication that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller annunciation that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed.

If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Center Tank Pumps status message is expected to read within the sample range of 11 to 15 units during takeoff. During a maintenance-requested ground run, the pilot monitoring should verify the Autothrottle switch position when the associated caution light remains illuminated. The Flight Management Computer advisory is expected to read within the sample range of 27 to 34 units during engine start. The wording here is placeholder content shaped like a procedure, not a procedure. If the Primary Electrical Bus is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

The Landing Gear Indication status message that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete. During descent, the relief pilot should verify the Autopilot Channel A quantity display when operating at a sample station without ground power. The Bleed Air Supply selector position is expected to read within the sample range of 25 to 35 units during climb. If the Speedbrake Handle is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

If the Center Tank Pumps is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A indication that differs from the expected state requires both pilots to record the condition before the next phase of flight.

The pilot flying will record any change in the Nosewheel Steering advisory and advise the other pilot when operating at a sample station without ground power. The Nosewheel Steering quantity display that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. The Autothrottle status message is expected to read within the sample range of 12 to 15 units during taxi. The captain will confirm any change in the Bleed Air Supply advisory and advise the other pilot once the checklist item is complete. The Landing Gear Indication selector position that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete.

CAUTION: If the Landing Gear Indication is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. During cruise, the relief pilot should select the Oxygen Distribution quantity display when operating at a sample station without ground power.

14.20.4 Ground Proximity Monitor Indications

The first officer will announce any change in the Landing Gear Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The captain will confirm any change in the Wing Anti-Ice status message and advise the other pilot if the indication does not stabilize within the sample

interval. If the Fire Detection Loop is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. During descent, the First Officer should cross-check the Cargo Smoke Detection advisory when the associated caution light remains illuminated.

CAUTION: During takeoff, the relief pilot should brief the Hydraulic System B status message if the indication does not stabilize within the sample interval.

The Stall Warning indication that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. The captain will monitor any change in the Window Heat quantity display and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated.

The Window Heat quantity display is expected to read within the sample range of 28 to 34 units during a maintenance-requested ground run. If the Standby Instruments is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Bleed Air Supply annunciation that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. The first officer will brief any change in the Hydraulic System B annunciation and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

The Ground Proximity Monitor annunciation is expected to read within the sample range of 97 to 102 units during climb. The Window Heat advisory is expected to read within the sample range of 29 to 33 units during a maintenance-requested ground run. The Center Tank Pumps selector position that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. During descent, the relief pilot should select the Cabin Pressure Controller indication when conditions permit. If the Auxiliary Power Unit is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

14.20.5 Cockpit Voice Recorder Limits Display

The relief pilot will select any change in the Fire Detection Loop selector position and advise the other pilot if a discrepancy is observed. If the Cargo Smoke Detection is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During preflight, the Captain should verify the Traffic Advisory Display annunciation if a discrepancy is observed. The Stall Warning quantity display that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Thrust Reverser advisory	22 units	Normal
Pack Temperature Control annunciation	71 units	Refer to related topic
Cargo Smoke Detection quantity display	67 units	Refer to related topic
Standby Hydraulic selector position	11 units	Advisory only
Autothrottle selector position	56 units	Refer to related topic
Autobrake Selector indication	93 units	Refer to related topic
Fuel Crossfeed status message	45 units	Normal

NOTE: If the Standby Hydraulic is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. During climb, the pilot flying should record the Traffic Advisory Display status message before the next phase of flight.

- If the Standby Hydraulic is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

- The Autopilot Channel A annunciation that differs from the expected state requires the relief pilot to brief the condition when conditions permit.
- During climb, the relief pilot should announce the Engine Anti-Ice status message before the next phase of flight.
- The Fire Detection Loop indication that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Pack Temperature Control advisory	95 units	Normal
Weather Radar selector position	72 units	Advisory only
Cabin Pressure Controller advisory	58 units	Monitor
Oxygen Distribution advisory	63 units	Refer to related topic

The Nosewheel Steering switch position is expected to read within the sample range of 87 to 99 units during a diversion. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

The Auxiliary Power Unit quantity display is expected to read within the sample range of 69 to 80 units during taxi. The Window Heat switch position that differs from the expected state requires both pilots to monitor the condition when conditions permit. During a turnaround, the pilot flying should record the Landing Gear Indication quantity display if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete. See 15.30.8 Cabin Pressure Controller Reset Guidance.

14.20.6 Cockpit Voice Recorder Normal Operation

The Nosewheel Steering selector position is expected to read within the sample range of 34 to 46 units during cruise. The Transponder advisory is expected to read within the sample range of 74 to 77 units during approach. The first officer will select any change in the Transponder selector position and advise the other pilot once the checklist item is complete. The Thrust Reverser status message is expected to read within the sample range of 45 to 52 units during a turnaround. Refer to the related topic for additional sample context.

The pilot monitoring will announce any change in the Window Heat annunciation and advise the other pilot before the next phase of flight. The Autopilot Channel A selector position that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. If the Center Tank Pumps is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. During engine start, the Captain should cross-check the Hydraulic System A advisory unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Auxiliary Power Unit indication	33 units	Normal
Traffic Advisory Display annunciation	26 units	Advisory only
Thrust Reverser switch position	50 units	Advisory only
Thrust Reverser quantity display	74 units	Monitor
Hydraulic System B switch position	20 units	Monitor

The Speedbrake Handle advisory that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed. If the Cargo Smoke Detection is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Auxiliary Power Unit status message is expected to read within the sample range of 20 to 27 units during takeoff.

The Transponder selector position that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval. During climb, both pilots should cross-check the Autobrake Selector advisory before the next phase of flight. The Probe Heat annunciation that differs from the expected state requires the First Officer to monitor the condition when conditions permit. The first officer will verify any change in the Weather Radar annunciation and advise the other pilot once the checklist item is complete. The relief pilot will verify any change in the Pack Temperature Control advisory and advise the other pilot once the checklist item is complete.

NOTE: The first officer will record any change in the Thrust Reverser status message and advise the other pilot when the associated caution light remains illuminated. The Flap Position Indication indication is expected to read within the sample range of 58 to 62 units during takeoff.

CAUTION: The relief pilot will announce any change in the Window Heat switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Engine Anti-Ice selector position	74 units	Advisory only
Window Heat quantity display	46 units	Normal
Auxiliary Power Unit annunciation	38 units	Advisory only
Cargo Smoke Detection status message	68 units	Advisory only
Autobrake Selector quantity display	24 units	Advisory only
Autopilot Channel B advisory	4 units	Normal
Cabin Pressure Controller quantity display	80 units	Refer to related topic

14.20.7 Fire Detection Loop Interfaces

During engine start, the First Officer should record the Standby Instruments annunciation when conditions permit. The Fuel Crossfeed advisory is expected to read within the sample range of 19 to 28 units during preflight. If the Standby Hydraulic is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

Values in this manual are invented and must not be used for any operational purpose. The Primary Electrical Bus switch position is expected to read within the sample range of 36 to 40 units during an extended ground delay. The relief pilot will select any change in the Autothrottle status message and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System B selector position that differs from the expected state requires both pilots to confirm the condition before the next phase of flight.

CAUTION: The Autothrottle quantity display that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power. The Wing Anti-Ice annunciation is expected to read within the sample range of 78 to 83 units during descent.

NOTE: During engine start, both pilots should select the Fire Detection Loop switch position if the indication does not stabilize within the sample interval. If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

During descent, the Captain should brief the Primary Electrical Bus selector position if a discrepancy is observed. The captain will confirm any change in the Oxygen Distribution selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Autothrottle selector position that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. During descent, the pilot monitoring should select the Hydraulic System A annunciation once the checklist item is complete.

CAUTION: The Ground Proximity Monitor advisory is expected to read within the sample range of 29 to 40 units during a diversion. The Speedbrake Handle annunciation that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.

14.20.8 Traffic Advisory Display Status Messages

If the Stall Warning is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. During a diversion, both pilots should monitor the Cockpit Voice Recorder annunciation when conditions permit. If the Nosewheel Steering is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Cabin Pressure Controller selector position that differs from the expected state requires the First Officer to monitor the condition if the indication does not stabilize within the sample interval. The Traffic Advisory Display switch position that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power.

CAUTION: During preflight, the pilot flying should brief the Autopilot Channel A status message once the checklist item is complete.

CAUTION: The first officer will record any change in the Bleed Air Supply advisory and advise the other pilot when conditions permit.

NOTE: The Traffic Advisory Display annunciation is expected to read within the sample range of 78 to 89 units during taxi.

- During an extended ground delay, the Captain should monitor the Primary Electrical Bus switch position unless directed otherwise by the Sample Operations Center.
- The pilot flying will confirm any change in the Landing Gear Indication selector position and advise the other pilot once the checklist item is complete.
- During cruise, the Captain should verify the Brake Temperature Monitor status message if a discrepancy is observed.
- The pilot monitoring will announce any change in the Pack Temperature Control indication and advise the other pilot if a discrepancy is observed.

14.20.9 Cabin Pressure Controller Status Messages

If the Autobrake Selector is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Window Heat status message that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed. The Hydraulic System A selector position that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated. The Thrust Reverser status message that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed. During parking, the Captain should select the Window Heat status message if a discrepancy is observed.

Values in this manual are invented and must not be used for any operational purpose. The Fire Detection Loop advisory that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval. The Fuel Crossfeed quantity display is expected to read within the sample range of 61 to 72 units during a turnaround. During a turnaround, the Captain should brief the Autopilot Channel A indication when the associated caution light remains illuminated. During a turnaround, the First Officer should select the Flap Position Indication advisory if the indication does not stabilize within the sample interval.

NOTE: The Cabin Pressure Controller indication is expected to read within the sample range of 3 to 6 units during a turnaround.

- The Autobrake Selector status message that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval.
- During climb, the Captain should cross-check the Landing Gear Indication quantity display once the checklist item is complete.
- The Auxiliary Power Unit advisory that differs from the expected state requires the pilot monitoring to cross-check the condition unless directed otherwise by the Sample Operations Center.

- If the Traffic Advisory Display is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder selector position that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. The Ground Proximity Monitor selector position is expected to read within the sample range of 20 to 23 units during a turnaround.

If the Engine Anti-Ice is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, the relief pilot should select the Thrust Reverser selector position unless directed otherwise by the Sample Operations Center. If the Stall Warning is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

- The captain will record any change in the Wing Anti-Ice quantity display and advise the other pilot when the associated caution light remains illuminated.
- The Window Heat annunciation is expected to read within the sample range of 79 to 84 units during approach.
- The Weather Radar status message is expected to read within the sample range of 91 to 102 units during a turnaround.
- During engine start, the Captain should record the Stall Warning annunciation when the associated caution light remains illuminated.
- If the Autopilot Channel B is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.
- The captain will announce any change in the Landing Gear Indication status message and advise the other pilot when the associated caution light remains illuminated.
- The Engine Anti-Ice quantity display that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated.
- The Ground Proximity Monitor advisory that differs from the expected state requires the First Officer to select the condition once the checklist item is complete.
- The Nosewheel Steering annunciation that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval.
- The Engine Anti-Ice status message that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power.
- If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- The Auxiliary Power Unit selector position that differs from the expected state requires the Captain to verify the condition once the checklist item is complete.

14.20.10 Weather Radar Crew Awareness

The Speedbrake Handle status message that differs from the expected state requires the First Officer to verify the condition before the next phase of flight. Refer to the related topic for additional sample context. During climb, the First Officer should cross-check the Fuel Crossfeed advisory if the indication does not stabilize within the sample interval.

The Fuel Crossfeed annunciation that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed. If the Brake Temperature Monitor is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Flight Management Computer quantity display that differs from the expected state requires the First Officer to record the

condition before the next phase of flight. The Wing Anti-Ice annunciation is expected to read within the sample range of 32 to 40 units during approach.

NOTE: The Autothrottle quantity display that differs from the expected state requires the First Officer to cross-check the condition when operating at a sample station without ground power.

If the Flap Position Indication is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Cabin Pressure Controller advisory is expected to read within the sample range of 2 to 14 units during climb. If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Oxygen Distribution status message that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight.

CAUTION: During parking, the pilot monitoring should verify the Cockpit Voice Recorder annunciation when operating at a sample station without ground power. The Standby Hydraulic annunciation that differs from the expected state requires the Captain to monitor the condition before the next phase of flight.

NOTE: The Bleed Air Supply annunciation that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval. If the Transponder is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

14.20.11 Transponder Interfaces

If the Primary Electrical Bus is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. During a turnaround, both pilots should monitor the Fire Detection Loop indication unless directed otherwise by the Sample Operations Center. Both pilots will cross-check any change in the Oxygen Distribution annunciation and advise the other pilot before the next phase of flight. Both pilots will select any change in the Autopilot Channel B advisory and advise the other pilot if a discrepancy is observed. The Pack Temperature Control selector position is expected to read within the sample range of 5 to 11 units during climb. The captain will record any change in the Thrust Reverser annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat indication is expected to read within the sample range of 16 to 27 units during engine start. The Bleed Air Supply quantity display that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed. The Stall Warning selector position that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight. The Center Tank Pumps advisory that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center.

- The Cabin Pressure Controller status message is expected to read within the sample range of 18 to 29 units during an extended ground delay.
- Refer to the related topic for additional sample context.
- The Nosewheel Steering quantity display is expected to read within the sample range of 88 to 93 units during landing.
- During approach, the relief pilot should monitor the Fire Detection Loop indication if a discrepancy is observed.

During parking, the relief pilot should brief the Autopilot Channel B quantity display when conditions permit. If the Flight Management Computer is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Flap Position Indication quantity display that differs from the expected state requires the pilot flying to verify the condition when conditions permit. If the Cabin Pressure Controller is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Traffic Advisory Display quantity display is expected to read within the sample range of 20 to 31 units during engine start. This text is fictional and exists only to give the prototype realistic volume and structure.

The Autothrottle annunciation is expected to read within the sample range of 57 to 69 units during landing. The pilot monitoring will monitor any change in the Weather Radar selector position and advise the other pilot if a discrepancy is observed. During parking, the relief pilot should verify the Autopilot Channel B quantity display when conditions permit. If the Nosewheel Steering is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

- The relief pilot will brief any change in the Standby Instruments advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The relief pilot will brief any change in the Thrust Reverser quantity display and advise the other pilot when operating at a sample station without ground power.
- Values in this manual are invented and must not be used for any operational purpose.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Flight Management Computer is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control selector position that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. The Wing Anti-Ice quantity display that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

14.20.12 Cabin Pressure Controller Limits Display

If the Thrust Reverser is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Engine Anti-Ice status message that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. The Probe Heat selector position is expected to read within the sample range of 19 to 28 units during an extended ground delay. During approach, the relief pilot should monitor the Landing Gear Indication advisory when the associated caution light remains illuminated. The Window Heat annunciation is expected to read within the sample range of 75 to 85 units during approach.

The Ground Proximity Monitor advisory that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed. The Fire Detection Loop annunciation is expected to read within the sample range of 35 to 42 units during climb. The Wing Anti-Ice quantity display that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context.

Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will announce any change in the Standby Hydraulic quantity display and advise the other pilot when the associated caution light remains illuminated. During climb, the Captain should cross-check the Stall Warning selector position if the indication does not stabilize within the sample interval. See 12.20.4 Autopilot Channel B Limits Display.

NOTE: If the Probe Heat is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

CAUTION: The pilot monitoring will record any change in the Standby Instruments indication and advise the other pilot once the checklist item is complete.

14.20.13 Probe Heat Indications

Values in this manual are invented and must not be used for any operational purpose. During a maintenance-requested ground run, the relief pilot should verify the Hydraulic System A advisory unless directed otherwise by the Sample Operations Center. If the Hydraulic System B is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During preflight, the First Officer should verify the Oxygen Distribution status message when operating at a sample station without ground power.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

The Transponder indication that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center. The Fire Detection Loop selector position is expected to read within the sample range of 15 to 21 units during climb. If the Fire Detection Loop is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. During taxi, both pilots should brief the Thrust Reverser quantity display once the checklist item is complete.

Condition	Sample value	Remarks
Standby Hydraulic status message	82 units	Monitor
Cockpit Voice Recorder switch position	38 units	Monitor
Cabin Pressure Controller selector position	3 units	Advisory only
Hydraulic System A status message	44 units	Normal

The Primary Electrical Bus indication that differs from the expected state requires both pilots to monitor the condition before the next phase of flight. The Flight Management Computer status message is expected to read within the sample range of 86 to 89 units during preflight. If the Fuel Crossfeed is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Autopilot Channel B switch position is expected to read within the sample range of 30 to 36 units during a turnaround. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Engine Anti-Ice annunciation is expected to read within the sample range of 59 to 67 units during parking. The Transponder indication is expected to read within the sample range of 18 to 27 units during preflight.

14.20.14 Standby Hydraulic Normal Operation

Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. The first officer will cross-check any change in the Speedbrake Handle status message and advise the other pilot when conditions permit. The Primary Electrical Bus switch position that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated. The Autopilot Channel B selector position is expected to read within the sample range of 27 to 31 units during an extended ground delay.

Values in this manual are invented and must not be used for any operational purpose. During engine start, the pilot monitoring should select the Engine Anti-Ice switch position before the next phase of flight. The Auxiliary Power Unit quantity display is expected to read within the sample range of 45 to 48 units during engine start. The Autobrake Selector selector position is expected to read within the sample range of 27 to 30 units during a maintenance-requested ground run. The Standby Hydraulic selector position is expected to read within the sample range of 11 to 14 units during parking. During a turnaround, the First Officer should monitor the Primary Electrical Bus switch position before the next phase of flight.

Condition	Sample value	Remarks
Landing Gear Indication annunciation	65 units	Advisory only
Flight Management Computer indication	24 units	Normal
Probe Heat switch position	63 units	Advisory only
Fuel Crossfeed advisory	86 units	Advisory only

Nosewheel Steering selector position	80 units	Normal
Weather Radar status message	79 units	Advisory only
Center Tank Pumps status message	58 units	Refer to related topic

NOTE: The Flap Position Indication indication that differs from the expected state requires the Captain to record the condition before the next phase of flight. The Standby Instruments status message that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power.

The Nosewheel Steering selector position that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power. During parking, both pilots should cross-check the Traffic Advisory Display selector position once the checklist item is complete. The Thrust Reverser status message is expected to read within the sample range of 5 to 11 units during takeoff.

NOTE: The Wing Anti-Ice advisory is expected to read within the sample range of 37 to 48 units during a diversion. Values in this manual are invented and must not be used for any operational purpose.

14.20.15 Primary Electrical Bus Status Messages

During climb, the First Officer should record the Flap Position Indication indication when operating at a sample station without ground power. The pilot flying will monitor any change in the Window Heat selector position and advise the other pilot before the next phase of flight. The relief pilot will announce any change in the Autopilot Channel B quantity display and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice status message is expected to read within the sample range of 45 to 49 units during preflight. The first officer will select any change in the Stall Warning status message and advise the other pilot before the next phase of flight.

If the Oxygen Distribution is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Bleed Air Supply advisory is expected to read within the sample range of 23 to 26 units during a turnaround. The Wing Anti-Ice switch position is expected to read within the sample range of 31 to 39 units during cruise. During preflight, the pilot flying should record the Hydraulic System B indication when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The pilot flying will monitor any change in the Autopilot Channel B selector position and advise the other pilot when the associated caution light remains illuminated.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During climb, both pilots should cross-check the Flight Management Computer selector position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Brake Temperature Monitor quantity display	56 units	Refer to related topic
Autopilot Channel B annunciation	90 units	Refer to related topic
Center Tank Pumps advisory	99 units	Monitor
Brake Temperature Monitor indication	45 units	Refer to related topic
Cargo Smoke Detection status message	49 units	Normal
Stall Warning selector position	66 units	Monitor
Engine Anti-Ice switch position	96 units	Normal

Values in this manual are invented and must not be used for any operational purpose. The Center Tank Pumps switch position is expected to read within the sample range of 14 to 22 units during takeoff. The Fire Detection Loop switch position that differs from the expected state requires the pilot flying to monitor the condition unless directed

otherwise by the Sample Operations Center. The Cargo Smoke Detection advisory is expected to read within the sample range of 48 to 51 units during parking. Both pilots will brief any change in the Landing Gear Indication annunciation and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Pack Temperature Control selector position	89 units	Monitor
Auxiliary Power Unit annunciation	88 units	Normal
Transponder advisory	18 units	Normal
Landing Gear Indication indication	86 units	Monitor
Weather Radar selector position	47 units	Advisory only
Hydraulic System A indication	59 units	Monitor

The Ground Proximity Monitor indication is expected to read within the sample range of 22 to 34 units during landing. During engine start, the pilot monitoring should brief the Oxygen Distribution indication before the next phase of flight. If the Nosewheel Steering is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. During takeoff, the pilot monitoring should cross-check the Flight Management Computer advisory unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Flap Position Indication annunciation	9 units	Advisory only
Fire Detection Loop advisory	32 units	Advisory only
Autobrake Selector annunciation	4 units	Refer to related topic
Weather Radar status message	70 units	Advisory only
Primary Electrical Bus switch position	83 units	Monitor

14.20.16 Engine Anti-Ice Status Messages

If the Flap Position Indication is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot flying should verify the Ground Proximity Monitor annunciation when conditions permit. The Window Heat quantity display is expected to read within the sample range of 73 to 81 units during takeoff. The Hydraulic System B selector position that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Window Heat quantity display	44 units	Advisory only
Traffic Advisory Display selector position	79 units	Monitor
Autopilot Channel B advisory	12 units	Refer to related topic
Cargo Smoke Detection switch position	16 units	Normal
Fire Detection Loop quantity display	63 units	Refer to related topic

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel B advisory is expected to read within the sample range of 51 to 56 units during engine start.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps advisory is expected to read within the sample range of 9 to 15 units during climb.

The pilot flying will verify any change in the Center Tank Pumps status message and advise the other pilot if a discrepancy is observed. During parking, the Captain should record the Pack Temperature Control indication when operating at a sample station without ground power. During takeoff, the Captain should verify the Oxygen Distribution status message unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional

sample context. The relief pilot will record any change in the Probe Heat switch position and advise the other pilot if a discrepancy is observed. The Cockpit Voice Recorder status message is expected to read within the sample range of 72 to 78 units during parking. See 16.30.13 Primary Electrical Bus Indications.

CAUTION: The Oxygen Distribution switch position that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. The Auxiliary Power Unit quantity display is expected to read within the sample range of 23 to 33 units during parking.

14.30 Operation

14.30.1 Standby Instruments Status Messages

The Autopilot Channel B advisory that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. The captain will record any change in the Fire Detection Loop indication and advise the other pilot once the checklist item is complete. The Transponder switch position is expected to read within the sample range of 87 to 92 units during climb. The Auxiliary Power Unit status message is expected to read within the sample range of 14 to 23 units during descent. If the Stall Warning is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the relief pilot should select the Flap Position Indication quantity display before the next phase of flight. The Engine Anti-Ice switch position that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. The captain will record any change in the Window Heat indication and advise the other pilot once the checklist item is complete. The Fuel Crossfeed quantity display is expected to read within the sample range of 20 to 28 units during approach.

CAUTION: The captain will record any change in the Wing Anti-Ice advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

The captain will confirm any change in the Standby Instruments status message and advise the other pilot if the indication does not stabilize within the sample interval. The Cargo Smoke Detection switch position that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. Both pilots will brief any change in the Hydraulic System B switch position and advise the other pilot when the associated caution light remains illuminated. The pilot flying will record any change in the Bleed Air Supply status message and advise the other pilot before the next phase of flight. The captain will announce any change in the Landing Gear Indication indication and advise the other pilot when operating at a sample station without ground power.

The first officer will announce any change in the Fire Detection Loop annunciation and advise the other pilot when the associated caution light remains illuminated. The Cargo Smoke Detection advisory is expected to read within the sample range of 95 to 98 units during a maintenance-requested ground run. If the Hydraulic System A is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. During takeoff, the Captain should verify the Brake Temperature Monitor switch position when operating at a sample station without ground power. The relief pilot will record any change in the Oxygen Distribution switch position and advise the other pilot when conditions permit. The Transponder quantity display that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval.

- If the Hydraulic System A is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- If the Standby Hydraulic is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	75 units	Advisory only
Standby Instruments status message	72 units	Refer to related topic

Traffic Advisory Display switch position	35 units	Monitor
Flap Position Indication status message	36 units	Monitor

The Autothrottle indication that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power. The Standby Instruments status message is expected to read within the sample range of 36 to 42 units during cruise. The Flight Management Computer selector position that differs from the expected state requires the First Officer to record the condition before the next phase of flight. During engine start, the First Officer should confirm the Nosewheel Steering switch position before the next phase of flight. During approach, the Captain should cross-check the Ground Proximity Monitor status message if the indication does not stabilize within the sample interval. If the Weather Radar is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. See 16.30.6 Standby Instruments Normal Operation.

Condition	Sample value	Remarks
Cockpit Voice Recorder selector position	45 units	Normal
Hydraulic System B indication	10 units	Advisory only
Stall Warning quantity display	14 units	Refer to related topic
Ground Proximity Monitor advisory	47 units	Refer to related topic

14.30.2 Pack Temperature Control Normal Operation

The Nosewheel Steering annunciation is expected to read within the sample range of 76 to 79 units during takeoff. Refer to the related topic for additional sample context. If the Thrust Reverser is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Bleed Air Supply indication	80 units	Advisory only
Transponder indication	40 units	Monitor
Window Heat advisory	45 units	Refer to related topic
Flap Position Indication switch position	4 units	Advisory only
Primary Electrical Bus status message	50 units	Refer to related topic
Pack Temperature Control quantity display	98 units	Advisory only
Probe Heat switch position	97 units	Normal

Condition	Sample value	Remarks
Autobrake Selector indication	54 units	Normal
Thrust Reverser selector position	83 units	Monitor
Primary Electrical Bus status message	71 units	Normal
Oxygen Distribution status message	90 units	Normal
Bleed Air Supply status message	61 units	Normal
Flight Management Computer indication	5 units	Normal

NOTE: During taxi, the pilot flying should confirm the Autopilot Channel A selector position when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Cabin Pressure Controller is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will cross-check any change in the Traffic Advisory Display advisory and advise the other pilot once the checklist item is complete. If the Autopilot Channel B is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The wording here is

placeholder content shaped like a procedure, not a procedure. The Hydraulic System A annunciation that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. If the Weather Radar is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

- The Flap Position Indication status message is expected to read within the sample range of 80 to 87 units during landing.
- The Thrust Reverser switch position is expected to read within the sample range of 87 to 99 units during a turnaround.
- The Primary Electrical Bus annunciation is expected to read within the sample range of 81 to 88 units during engine start.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During parking, the relief pilot should brief the Window Heat quantity display unless directed otherwise by the Sample Operations Center.
- If the Brake Temperature Monitor is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Bleed Air Supply is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Ground Proximity Monitor indication that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated.

Both pilots will announce any change in the Stall Warning status message and advise the other pilot if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. During preflight, the Captain should verify the Cabin Pressure Controller quantity display if the indication does not stabilize within the sample interval. The Autothrottle indication that differs from the expected state requires the Captain to verify the condition before the next phase of flight. The Landing Gear Indication indication is expected to read within the sample range of 81 to 87 units during a diversion. The first officer will brief any change in the Pack Temperature Control quantity display and advise the other pilot if a discrepancy is observed.

- The Oxygen Distribution quantity display is expected to read within the sample range of 97 to 104 units during cruise.
- During engine start, the relief pilot should monitor the Autopilot Channel A switch position when conditions permit.
- The pilot flying will brief any change in the Stall Warning status message and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

14.30.3 Primary Electrical Bus Indications

The Cabin Pressure Controller selector position that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. The Standby Hydraulic indication is expected to read within the sample range of 26 to 31 units during approach. If the Pack Temperature Control is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Window Heat indication that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete. If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

The Probe Heat quantity display is expected to read within the sample range of 18 to 23 units during takeoff. The Cockpit Voice Recorder quantity display that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval. During parking, the Captain should cross-check the Thrust Reverser status message unless directed otherwise by the Sample Operations Center. The Fire Detection Loop switch position that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed.

The Nosewheel Steering switch position that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. During a diversion, the pilot flying should brief the Traffic Advisory Display annunciation when the associated caution light remains illuminated. The Hydraulic System A status message that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete.

During cruise, the relief pilot should verify the Hydraulic System A indication when operating at a sample station without ground power. During an extended ground delay, the relief pilot should select the Nosewheel Steering switch position before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: Refer to the related topic for additional sample context.

NOTE: If the Speedbrake Handle is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Autothrottle annunciation is expected to read within the sample range of 22 to 27 units during preflight.

14.30.4 Pack Temperature Control Status Messages

The captain will select any change in the Cargo Smoke Detection advisory and advise the other pilot if a discrepancy is observed. The Stall Warning annunciation that differs from the expected state requires the Captain to record the condition before the next phase of flight. The Autopilot Channel B quantity display is expected to read within the sample range of 21 to 28 units during climb. If the Autopilot Channel A is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The captain will select any change in the Cabin Pressure Controller advisory and advise the other pilot once the checklist item is complete.

If the Autopilot Channel B is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The Auxiliary Power Unit indication that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. The relief pilot will verify any change in the Cargo Smoke Detection status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Landing Gear Indication advisory that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. The Fire Detection Loop switch position is expected to read within the sample range of 55 to 59 units during engine start.

The pilot flying will brief any change in the Pack Temperature Control quantity display and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel A selector position is expected to read within the sample range of 33 to 38 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the Captain should verify the Engine Anti-Ice status message when conditions permit. The Primary Electrical Bus switch position is expected to read within the sample range of 61 to 67 units during a maintenance-requested ground run.

The pilot monitoring will brief any change in the Auxiliary Power Unit annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will record any change in the Autothrottle status message and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will record any change in the Landing Gear Indication status message and advise the other pilot before the next phase of flight. Both pilots will cross-check any change in the Autopilot Channel B indication and advise the other pilot when

the associated caution light remains illuminated. The pilot flying will announce any change in the Standby Hydraulic advisory and advise the other pilot if a discrepancy is observed. The Hydraulic System A annunciation that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autobrake Selector quantity display	51 units	Advisory only
Primary Electrical Bus selector position	18 units	Advisory only
Pack Temperature Control indication	92 units	Advisory only
Autobrake Selector selector position	80 units	Advisory only
Landing Gear Indication annunciation	65 units	Advisory only
Cargo Smoke Detection selector position	7 units	Normal

CAUTION: The relief pilot will record any change in the Wing Anti-Ice quantity display and advise the other pilot when conditions permit. If the Pack Temperature Control is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

- During takeoff, the relief pilot should brief the Autothrottle annunciation when the associated caution light remains illuminated.
- During a diversion, the First Officer should record the Speedbrake Handle indication before the next phase of flight.
- The pilot monitoring will select any change in the Wing Anti-Ice quantity display and advise the other pilot once the checklist item is complete.

During landing, both pilots should verify the Pack Temperature Control quantity display when the associated caution light remains illuminated. During taxi, the Captain should verify the Auxiliary Power Unit annunciation if the indication does not stabilize within the sample interval. During preflight, the First Officer should record the Transponder advisory when the associated caution light remains illuminated. The pilot monitoring will verify any change in the Autopilot Channel A status message and advise the other pilot if the indication does not stabilize within the sample interval.

14.30.5 Probe Heat Overview

The Fuel Crossfeed status message that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B switch position is expected to read within the sample range of 98 to 105 units during approach. The Cockpit Voice Recorder advisory that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval. During parking, the First Officer should monitor the Engine Anti-Ice indication when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. If the Brake Temperature Monitor is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During an extended ground delay, the Captain should select the Autothrottle selector position once the checklist item is complete.

CAUTION: The pilot flying will verify any change in the Flight Management Computer advisory and advise the other pilot once the checklist item is complete.

- Both pilots will monitor any change in the Auxiliary Power Unit quantity display and advise the other pilot before the next phase of flight.
- The Hydraulic System A status message that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed.

- The Wing Anti-Ice annunciation is expected to read within the sample range of 70 to 80 units during a diversion.
- During an extended ground delay, the pilot flying should record the Hydraulic System A status message if the indication does not stabilize within the sample interval.
- If the Fuel Crossfeed is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.
- The Hydraulic System A quantity display is expected to read within the sample range of 22 to 33 units during parking.

During a diversion, the Captain should monitor the Landing Gear Indication annunciation when conditions permit. During approach, the pilot flying should select the Cabin Pressure Controller status message if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

The Flight Management Computer switch position that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. If the Primary Electrical Bus is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Autothrottle switch position that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. If the Bleed Air Supply is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

During takeoff, the pilot monitoring should select the Window Heat indication before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Center Tank Pumps advisory is expected to read within the sample range of 64 to 71 units during preflight. Values in this manual are invented and must not be used for any operational purpose. The Oxygen Distribution status message is expected to read within the sample range of 38 to 48 units during preflight.

14.30.6 Landing Gear Indication Crew Awareness

The Oxygen Distribution indication that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight. During taxi, both pilots should record the Autothrottle selector position if the indication does not stabilize within the sample interval. If the Standby Instruments is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During a turnaround, the pilot monitoring should confirm the Cockpit Voice Recorder quantity display unless directed otherwise by the Sample Operations Center. During climb, the First Officer should select the Primary Electrical Bus selector position unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Wing Anti-Ice quantity display	12 units	Refer to related topic
Pack Temperature Control status message	73 units	Normal
Ground Proximity Monitor switch position	80 units	Normal
Ground Proximity Monitor quantity display	52 units	Monitor
Pack Temperature Control advisory	98 units	Monitor

CAUTION: The first officer will cross-check any change in the Traffic Advisory Display indication and advise the other pilot once the checklist item is complete.

The pilot monitoring will verify any change in the Hydraulic System A advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will verify any change in the Probe Heat indication and advise the other pilot when operating at a sample station without ground power. The Flap Position Indication status message that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Window Heat annunciation	17 units	Refer to related topic
Landing Gear Indication quantity display	40 units	Advisory only
Standby Hydraulic annunciation	15 units	Monitor

The Probe Heat switch position is expected to read within the sample range of 87 to 97 units during an extended ground delay. The Pack Temperature Control quantity display that differs from the expected state requires the Captain to record the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control quantity display is expected to read within the sample range of 60 to 72 units during descent. See 02.40.27 Oxygen Distribution Interfaces.

NOTE: The pilot monitoring will record any change in the Nosewheel Steering status message and advise the other pilot if the indication does not stabilize within the sample interval.

14.30.7 Thrust Reverser Limits Display

The Autopilot Channel B advisory that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. The Cargo Smoke Detection annunciation that differs from the expected state requires the Captain to announce the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector indication that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated.

The first officer will select any change in the Autopilot Channel B quantity display and advise the other pilot when the associated caution light remains illuminated. The Weather Radar switch position is expected to read within the sample range of 36 to 39 units during a turnaround. The Autopilot Channel B switch position is expected to read within the sample range of 26 to 34 units during preflight. The Pack Temperature Control status message is expected to read within the sample range of 41 to 49 units during taxi.

If the Brake Temperature Monitor is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Fuel Crossfeed indication is expected to read within the sample range of 70 to 73 units during an extended ground delay. The Oxygen Distribution switch position is expected to read within the sample range of 18 to 30 units during landing. The Flight Management Computer annunciation is expected to read within the sample range of 6 to 16 units during approach. During preflight, the First Officer should cross-check the Cargo Smoke Detection indication once the checklist item is complete.

NOTE: If the Hydraulic System B is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The relief pilot will confirm any change in the Hydraulic System A switch position and advise the other pilot when the associated caution light remains illuminated.

The captain will cross-check any change in the Probe Heat annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Brake Temperature Monitor is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Autobrake Selector is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

Both pilots will announce any change in the Autopilot Channel A annunciation and advise the other pilot before the next phase of flight. The Thrust Reverser indication is expected to read within the sample range of 19 to 23 units during takeoff. If the Primary Electrical Bus is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

The Cargo Smoke Detection status message is expected to read within the sample range of 27 to 34 units during cruise. If the Center Tank Pumps is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Ground Proximity Monitor is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

During a diversion, both pilots should cross-check the Speedbrake Handle switch position unless directed otherwise by the Sample Operations Center. The Flap Position Indication annunciation that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. If the Probe Heat is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

The Autobrake Selector switch position is expected to read within the sample range of 88 to 100 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder quantity display that differs from the expected state requires the First Officer to monitor the condition if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder switch position is expected to read within the sample range of 61 to 70 units during a diversion. The Flight Management Computer annunciation is expected to read within the sample range of 38 to 50 units during descent.

14.30.8 Center Tank Pumps Overview

During a maintenance-requested ground run, the relief pilot should cross-check the Autothrottle quantity display when operating at a sample station without ground power. If the Cargo Smoke Detection is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The captain will record any change in the Hydraulic System A status message and advise the other pilot when operating at a sample station without ground power. The Stall Warning switch position is expected to read within the sample range of 48 to 60 units during taxi.

The relief pilot will brief any change in the Autobrake Selector switch position and advise the other pilot before the next phase of flight. During takeoff, the relief pilot should verify the Brake Temperature Monitor quantity display when operating at a sample station without ground power. The captain will verify any change in the Weather Radar indication and advise the other pilot when the associated caution light remains illuminated. The Oxygen Distribution selector position is expected to read within the sample range of 39 to 45 units during cruise.

NOTE: The Cabin Pressure Controller annunciation is expected to read within the sample range of 16 to 28 units during landing. The captain will announce any change in the Transponder selector position and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Window Heat switch position	13 units	Monitor
Wing Anti-Ice advisory	97 units	Monitor
Flap Position Indication quantity display	93 units	Normal
Autopilot Channel A status message	12 units	Advisory only

The Standby Instruments indication is expected to read within the sample range of 65 to 77 units during a maintenance-requested ground run. The Standby Hydraulic quantity display is expected to read within the sample range of 36 to 48 units during parking. The pilot flying will record any change in the Standby Instruments quantity display and advise the other pilot once the checklist item is complete.

14.30.9 Primary Electrical Bus Limits Display

If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The relief pilot will record any change in the Bleed Air Supply annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

- The captain will confirm any change in the Center Tank Pumps indication and advise the other pilot if the indication does not stabilize within the sample interval.

- If the Standby Hydraulic is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.
- The Weather Radar advisory is expected to read within the sample range of 41 to 53 units during landing.
- During preflight, the First Officer should announce the Transponder annunciation if the indication does not stabilize within the sample interval.
- The Auxiliary Power Unit status message is expected to read within the sample range of 62 to 68 units during an extended ground delay.
- The Engine Anti-Ice status message that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval.

The first officer will confirm any change in the Cockpit Voice Recorder selector position and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will cross-check any change in the Window Heat indication and advise the other pilot if a discrepancy is observed. During preflight, the First Officer should monitor the Standby Hydraulic quantity display when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Speedbrake Handle quantity display	53 units	Normal
Wing Anti-Ice selector position	54 units	Monitor
Cargo Smoke Detection indication	33 units	Refer to related topic
Cabin Pressure Controller advisory	7 units	Monitor

If the Pack Temperature Control is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During preflight, the pilot monitoring should select the Traffic Advisory Display selector position when conditions permit. The relief pilot will record any change in the Cockpit Voice Recorder indication and advise the other pilot if the indication does not stabilize within the sample interval. The Cabin Pressure Controller status message that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. During a diversion, the First Officer should brief the Probe Heat status message when conditions permit.

14.30.10 Landing Gear Indication Overview

During landing, both pilots should monitor the Autobrake Selector switch position when conditions permit. The Speedbrake Handle annunciation that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. The Weather Radar status message is expected to read within the sample range of 98 to 101 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice quantity display is expected to read within the sample range of 21 to 26 units during approach.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: Refer to the related topic for additional sample context.

- Values in this manual are invented and must not be used for any operational purpose.
- The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Wing Anti-Ice advisory is expected to read within the sample range of 72 to 84 units during a diversion. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Hydraulic System A advisory	68 units	Monitor
Cabin Pressure Controller advisory	91 units	Monitor
Brake Temperature Monitor annunciation	93 units	Advisory only
Standby Instruments indication	76 units	Advisory only

CAUTION: The Standby Instruments advisory is expected to read within the sample range of 11 to 21 units during preflight. The Fuel Crossfeed quantity display is expected to read within the sample range of 15 to 18 units during takeoff.

The Thrust Reverser quantity display is expected to read within the sample range of 16 to 19 units during takeoff. The Auxiliary Power Unit annunciation that differs from the expected state requires the Captain to cross-check the condition when conditions permit. During a maintenance-requested ground run, the First Officer should monitor the Transponder advisory when operating at a sample station without ground power.

The relief pilot will record any change in the Landing Gear Indication status message and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Cargo Smoke Detection indication is expected to read within the sample range of 20 to 28 units during climb.

14.30.11 Engine Anti-Ice Interfaces

Refer to the related topic for additional sample context. The Pack Temperature Control advisory that differs from the expected state requires the Captain to brief the condition when conditions permit. If the Nosewheel Steering is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

The Primary Electrical Bus indication is expected to read within the sample range of 58 to 68 units during parking. If the Hydraulic System A is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Pack Temperature Control advisory that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. During descent, the pilot flying should announce the Pack Temperature Control advisory when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Fuel Crossfeed indication that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

The Landing Gear Indication status message that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete. The Hydraulic System A status message is expected to read within the sample range of 91 to 102 units during a diversion. Values in this manual are invented and must not be used for any operational purpose.

During cruise, the First Officer should confirm the Cockpit Voice Recorder switch position when conditions permit. The Hydraulic System A annunciation that differs from the expected state requires the pilot monitoring to record the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. During landing, the Captain should verify the Standby Hydraulic selector position before the next phase of flight. The Traffic Advisory Display status message is expected to read within the sample range of 8 to 15 units during a diversion. The Autobrake Selector quantity display is expected to read within the sample range of 93 to 105 units during approach.

NOTE: If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Primary Electrical Bus indication	25 units	Advisory only

Cockpit Voice Recorder switch position	25 units	Monitor
Nosewheel Steering switch position	77 units	Normal
Cabin Pressure Controller status message	96 units	Monitor
Ground Proximity Monitor annunciation	8 units	Advisory only
Thrust Reverser advisory	10 units	Normal
Weather Radar annunciation	28 units	Normal

The Pack Temperature Control switch position that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete. During cruise, the First Officer should record the Wing Anti-Ice advisory when operating at a sample station without ground power. The first officer will monitor any change in the Bleed Air Supply selector position and advise the other pilot when conditions permit.

14.30.12 Center Tank Pumps Status Messages

Values in this manual are invented and must not be used for any operational purpose. During takeoff, both pilots should confirm the Engine Anti-Ice advisory when the associated caution light remains illuminated. If the Cabin Pressure Controller is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Cockpit Voice Recorder selector position is expected to read within the sample range of 74 to 83 units during landing. If the Hydraulic System A is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. During parking, both pilots should record the Primary Electrical Bus advisory if the indication does not stabilize within the sample interval.

The Wing Anti-Ice selector position that differs from the expected state requires both pilots to brief the condition before the next phase of flight. The Autobrake Selector status message is expected to read within the sample range of 17 to 22 units during a diversion. The Nosewheel Steering selector position is expected to read within the sample range of 41 to 51 units during landing.

The Fire Detection Loop indication that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. The Cockpit Voice Recorder selector position that differs from the expected state requires the First Officer to confirm the condition when conditions permit. During a maintenance-requested ground run, the relief pilot should confirm the Pack Temperature Control advisory when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. If the Flap Position Indication is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Wing Anti-Ice selector position is expected to read within the sample range of 55 to 63 units during engine start.

The Oxygen Distribution status message is expected to read within the sample range of 33 to 44 units during a diversion. The Landing Gear Indication quantity display that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed. If the Cargo Smoke Detection is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. During approach, both pilots should brief the Oxygen Distribution indication if a discrepancy is observed. If the Fire Detection Loop is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Hydraulic System B status message that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

The Weather Radar selector position that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed. If the Primary Electrical Bus is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Autothrottle status message that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

14.30.13 Weather Radar Power Sources

The Landing Gear Indication quantity display that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power. If the Probe Heat is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. During takeoff, both pilots should select the Transponder advisory when the associated caution light remains illuminated.

The relief pilot will confirm any change in the Nosewheel Steering quantity display and advise the other pilot if the indication does not stabilize within the sample interval. If the Fire Detection Loop is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The captain will record any change in the Autopilot Channel A switch position and advise the other pilot when conditions permit. The relief pilot will cross-check any change in the Fire Detection Loop annunciation and advise the other pilot when the associated caution light remains illuminated. During engine start, the pilot monitoring should verify the Hydraulic System A advisory if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

- During a maintenance-requested ground run, the pilot monitoring should monitor the Center Tank Pumps annunciation unless directed otherwise by the Sample Operations Center.
- The Autopilot Channel B quantity display is expected to read within the sample range of 79 to 83 units during landing.
- If the Hydraulic System B is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.
- The Fuel Crossfeed selector position that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval.
- The Center Tank Pumps annunciation is expected to read within the sample range of 20 to 23 units during taxi.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

The first officer will select any change in the Traffic Advisory Display switch position and advise the other pilot when conditions permit. During climb, the relief pilot should confirm the Fuel Crossfeed selector position when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel A switch position is expected to read within the sample range of 12 to 17 units during approach. The Landing Gear Indication indication that differs from the expected state requires the Captain to verify the condition when conditions permit.

The captain will monitor any change in the Primary Electrical Bus annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. During approach, the First Officer should monitor the Bleed Air Supply annunciation once the checklist item is complete. If the Bleed Air Supply is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The captain will brief any change in the Ground Proximity Monitor annunciation and advise the other pilot once the checklist item is complete. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The Engine Anti-Ice quantity display is expected to read within the sample range of 74 to 84 units during an extended ground delay. Both pilots will announce any change in the Autobrake Selector status message and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Wing Anti-Ice indication	57 units	Refer to related topic
Nosewheel Steering annunciation	66 units	Monitor
Stall Warning annunciation	75 units	Refer to related topic

14.30.14 Probe Heat Normal Operation

The Standby Hydraulic annunciation is expected to read within the sample range of 7 to 19 units during taxi. The Center Tank Pumps annunciation is expected to read within the sample range of 93 to 99 units during approach. During climb, the pilot monitoring should cross-check the Autopilot Channel A advisory when operating at a sample station without ground power. The pilot flying will verify any change in the Flight Management Computer quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Autopilot Channel B advisory	8 units	Refer to related topic
Landing Gear Indication selector position	43 units	Refer to related topic
Center Tank Pumps selector position	63 units	Refer to related topic

- During landing, both pilots should record the Window Heat advisory when operating at a sample station without ground power.
- During cruise, the relief pilot should select the Ground Proximity Monitor annunciation when conditions permit.
- The Weather Radar annunciation is expected to read within the sample range of 76 to 83 units during an extended ground delay.
- If the Auxiliary Power Unit is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- The pilot monitoring will monitor any change in the Nosewheel Steering indication and advise the other pilot when conditions permit.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

- The Pack Temperature Control status message that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed.
- The Bleed Air Supply annunciation is expected to read within the sample range of 57 to 62 units during approach.
- The pilot monitoring will brief any change in the Thrust Reverser quantity display and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Engine Anti-Ice selector position	39 units	Normal
Fuel Crossfeed switch position	53 units	Monitor
Ground Proximity Monitor status message	89 units	Normal
Fuel Crossfeed switch position	10 units	Normal

14.30.15 Autopilot Channel B Power Sources

The Hydraulic System A selector position is expected to read within the sample range of 5 to 12 units during a maintenance-requested ground run. If the Landing Gear Indication is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

The Center Tank Pumps status message is expected to read within the sample range of 97 to 101 units during a turnaround. The first officer will monitor any change in the Standby Instruments advisory and advise the other pilot if a discrepancy is observed. The Hydraulic System A status message that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated. The Weather Radar status message is expected to read within the sample range of 11 to 15 units during landing. If the Hydraulic System B is

inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The first officer will confirm any change in the Standby Hydraulic switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The Hydraulic System A annunciation is expected to read within the sample range of 34 to 45 units during engine start.
- The Landing Gear Indication indication that differs from the expected state requires the First Officer to announce the condition before the next phase of flight.
- The first officer will record any change in the Landing Gear Indication status message and advise the other pilot when conditions permit.
- If the Standby Instruments is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.
- The pilot monitoring will select any change in the Primary Electrical Bus switch position and advise the other pilot when conditions permit.
- During parking, the Captain should monitor the Wing Anti-Ice selector position when conditions permit.

During engine start, both pilots should announce the Wing Anti-Ice selector position once the checklist item is complete. If the Autothrottle is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. Both pilots will brief any change in the Bleed Air Supply quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Cabin Pressure Controller quantity display that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed.

The Wing Anti-Ice indication is expected to read within the sample range of 88 to 95 units during an extended ground delay. The relief pilot will monitor any change in the Probe Heat quantity display and advise the other pilot when operating at a sample station without ground power. The Cabin Pressure Controller quantity display that differs from the expected state requires both pilots to record the condition when conditions permit. If the Thrust Reverser is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The pilot flying will monitor any change in the Standby Hydraulic switch position and advise the other pilot once the checklist item is complete. The Flight Management Computer indication is expected to read within the sample range of 47 to 53 units during descent.

14.30.16 Thrust Reverser Status Messages

During a turnaround, both pilots should announce the Standby Instruments quantity display unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The relief pilot will cross-check any change in the Transponder annunciation and advise the other pilot when conditions permit. The Window Heat switch position is expected to read within the sample range of 86 to 91 units during engine start. The first officer will brief any change in the Pack Temperature Control status message and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Window Heat annunciation is expected to read within the sample range of 81 to 91 units during a turnaround. During a maintenance-requested ground run, both pilots should verify the Cargo Smoke Detection advisory when operating at a sample station without ground power.

Both pilots will brief any change in the Fire Detection Loop switch position and advise the other pilot before the next phase of flight. If the Flap Position Indication is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The captain will monitor any change in the Autopilot Channel A switch position and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the

prototype realistic volume and structure.

Condition	Sample value	Remarks
Primary Electrical Bus status message	31 units	Normal
Cockpit Voice Recorder status message	7 units	Refer to related topic
Standby Instruments status message	95 units	Advisory only
Center Tank Pumps annunciation	20 units	Monitor
Autothrottle annunciation	61 units	Refer to related topic

The Wing Anti-Ice selector position that differs from the expected state requires the Captain to record the condition when conditions permit. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure.

- During a maintenance-requested ground run, the pilot monitoring should verify the Cabin Pressure Controller advisory when conditions permit.
- The Center Tank Pumps quantity display that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated.
- The pilot flying will cross-check any change in the Center Tank Pumps switch position and advise the other pilot before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Transponder is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- The pilot flying will brief any change in the Transponder annunciation and advise the other pilot once the checklist item is complete.
- If the Flap Position Indication is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.
- During cruise, the First Officer should monitor the Transponder advisory if a discrepancy is observed.
- The pilot monitoring will verify any change in the Cabin Pressure Controller switch position and advise the other pilot when operating at a sample station without ground power.
- During climb, the pilot flying should record the Fuel Crossfeed quantity display if a discrepancy is observed.
- During takeoff, the pilot monitoring should announce the Window Heat annunciation when conditions permit.

Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Fire Detection Loop status message that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete. During cruise, the relief pilot should verify the Brake Temperature Monitor selector position when conditions permit.

Chapter 15 Systems: Fire Protection

15.10 Description

15.10.1 Engine Anti-Ice Crew Awareness

During descent, the pilot flying should verify the Cabin Pressure Controller selector position if the indication does not stabilize within the sample interval. During approach, the First Officer should announce the Thrust Reverser indication when the associated caution light remains illuminated. If the Center Tank Pumps is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Cockpit Voice Recorder is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Cabin Pressure Controller switch position that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated. If the Cockpit Voice Recorder is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. Both pilots will verify any change in the Window Heat quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. During climb, both pilots should monitor the Cabin Pressure Controller selector position if a discrepancy is observed.

The Standby Hydraulic indication is expected to read within the sample range of 19 to 24 units during descent. If the Cockpit Voice Recorder is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Standby Hydraulic selector position that differs from the expected state requires the pilot flying to select the condition when conditions permit. The Auxiliary Power Unit indication is expected to read within the sample range of 80 to 85 units during climb.

The pilot monitoring will cross-check any change in the Flap Position Indication selector position and advise the other pilot when the associated caution light remains illuminated. During descent, the pilot monitoring should announce the Traffic Advisory Display advisory before the next phase of flight. Refer to the related topic for additional sample context. The pilot flying will announce any change in the Stall Warning indication and advise the other pilot if a discrepancy is observed.

This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the First Officer should select the Flight Management Computer status message before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. During a diversion, both pilots should record the Fuel Crossfeed quantity display when operating at a sample station without ground power. During preflight, the pilot monitoring should select the Landing Gear Indication selector position when conditions permit. Values in this manual are invented and must not be used for any operational purpose. If the Transponder is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

15.10.2 Primary Electrical Bus Normal Operation

The relief pilot will verify any change in the Hydraulic System A switch position and advise the other pilot if the indication does not stabilize within the sample interval. If the Cargo Smoke Detection is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Thrust Reverser annunciation is expected to read within the sample range of 76 to 86 units during climb.

- If the Center Tank Pumps is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

- The pilot monitoring will confirm any change in the Autopilot Channel A quantity display and advise the other pilot before the next phase of flight.
- The Ground Proximity Monitor selector position that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power.
- The Pack Temperature Control indication is expected to read within the sample range of 47 to 59 units during a maintenance-requested ground run.
- During approach, the pilot monitoring should select the Ground Proximity Monitor switch position if the indication does not stabilize within the sample interval.

If the Cabin Pressure Controller is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The first officer will brief any change in the Standby Instruments indication and advise the other pilot before the next phase of flight. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 80 to 86 units during takeoff. During landing, the pilot monitoring should verify the Standby Instruments annunciation before the next phase of flight.

CAUTION: If the Fire Detection Loop is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

During landing, the pilot monitoring should verify the Weather Radar switch position once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. During climb, both pilots should cross-check the Transponder indication if the indication does not stabilize within the sample interval. During landing, the relief pilot should cross-check the Cockpit Voice Recorder annunciation before the next phase of flight.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During preflight, the pilot flying should brief the Center Tank Pumps indication if the indication does not stabilize within the sample interval.
- The captain will monitor any change in the Window Heat advisory and advise the other pilot when operating at a sample station without ground power.
- The Autothrottle annunciation that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Primary Electrical Bus quantity display is expected to read within the sample range of 13 to 24 units during taxi. If the Primary Electrical Bus is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

15.10.3 Brake Temperature Monitor Test

Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the First Officer should verify the Oxygen Distribution annunciation if the indication does not stabilize within the sample interval. The Flight Management Computer advisory is expected to read within the sample range of 92 to 101 units during descent. The Autothrottle quantity display that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center.

During descent, the pilot monitoring should monitor the Auxiliary Power Unit annunciation when operating at a sample station without ground power. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The relief pilot will verify any change in the Transponder quantity display and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection indication is expected to

read within the sample range of 24 to 33 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure.

The Wing Anti-Ice status message is expected to read within the sample range of 89 to 95 units during landing. The Primary Electrical Bus indication that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit. If the Window Heat is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Window Heat selector position that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete.

The Thrust Reverser annunciation that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete. The Probe Heat selector position that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. During climb, the pilot monitoring should record the Weather Radar indication if the indication does not stabilize within the sample interval.

NOTE: The Speedbrake Handle selector position is expected to read within the sample range of 51 to 63 units during parking.

15.10.4 Brake Temperature Monitor Power Sources

The Landing Gear Indication annunciation is expected to read within the sample range of 21 to 27 units during an extended ground delay. The captain will brief any change in the Window Heat status message and advise the other pilot if a discrepancy is observed. The Cargo Smoke Detection status message is expected to read within the sample range of 29 to 36 units during approach.

If the Stall Warning is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Wing Anti-Ice advisory is expected to read within the sample range of 22 to 33 units during a turnaround. During a maintenance-requested ground run, the First Officer should cross-check the Standby Instruments advisory unless directed otherwise by the Sample Operations Center. The Stall Warning selector position that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval. The captain will record any change in the Engine Anti-Ice switch position and advise the other pilot once the checklist item is complete. Both pilots will select any change in the Cabin Pressure Controller indication and advise the other pilot once the checklist item is complete. See 16.30.6 Standby Instruments Normal Operation.

CAUTION: The Standby Hydraulic indication that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Hydraulic System B indication	84 units	Monitor
Primary Electrical Bus indication	93 units	Refer to related topic
Hydraulic System A selector position	26 units	Normal
Engine Anti-Ice annunciation	53 units	Monitor
Autopilot Channel B quantity display	27 units	Refer to related topic

- The Autopilot Channel B selector position that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed.
- The pilot flying will cross-check any change in the Nosewheel Steering selector position and advise the other pilot once the checklist item is complete.
- The Ground Proximity Monitor indication is expected to read within the sample range of 2 to 7 units during cruise.
- During engine start, both pilots should verify the Standby Hydraulic status message once the checklist item is complete.

- If the Brake Temperature Monitor is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.
- If the Autobrake Selector is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.
- Both pilots will confirm any change in the Probe Heat annunciation and advise the other pilot when conditions permit.
- The Pack Temperature Control status message is expected to read within the sample range of 39 to 44 units during landing.
- The Stall Warning indication that differs from the expected state requires the pilot flying to record the condition when conditions permit.
- The Speedbrake Handle switch position is expected to read within the sample range of 10 to 13 units during a turnaround.
- The Landing Gear Indication advisory is expected to read within the sample range of 42 to 51 units during parking.
- If the Autothrottle is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.
- The Standby Hydraulic annunciation that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete.

Condition	Sample value	Remarks
Autopilot Channel B indication	86 units	Advisory only
Engine Anti-Ice switch position	34 units	Advisory only
Cockpit Voice Recorder quantity display	72 units	Refer to related topic

15.10.5 Speedbrake Handle Limits Display

During a diversion, the First Officer should cross-check the Autobrake Selector indication when operating at a sample station without ground power. The Brake Temperature Monitor switch position is expected to read within the sample range of 53 to 62 units during approach. The Weather Radar advisory that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed.

Values in this manual are invented and must not be used for any operational purpose. The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. During a diversion, the relief pilot should confirm the Hydraulic System B selector position if the indication does not stabilize within the sample interval. During a diversion, the Captain should select the Traffic Advisory Display quantity display when the associated caution light remains illuminated. The Autopilot Channel A annunciation that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. The captain will cross-check any change in the Standby Hydraulic quantity display and advise the other pilot when conditions permit. See 06.10.6 Hydraulic System B Indications.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will record any change in the Bleed Air Supply switch position and advise the other pilot when conditions permit.

- The pilot monitoring will brief any change in the Weather Radar indication and advise the other pilot if a discrepancy is observed.
- If the Nosewheel Steering is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.
- If the Engine Anti-Ice is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

CAUTION: During preflight, the pilot monitoring should verify the Autothrottle switch position when operating at a sample station without ground power.

15.10.6 Hydraulic System B Indications

The Fire Detection Loop quantity display is expected to read within the sample range of 91 to 102 units during climb. The Ground Proximity Monitor selector position that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. The pilot monitoring will confirm any change in the Transponder annunciation and advise the other pilot once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle indication is expected to read within the sample range of 29 to 35 units during climb. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Hydraulic System B is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Primary Electrical Bus status message	33 units	Advisory only
Center Tank Pumps switch position	34 units	Refer to related topic
Autothrottle annunciation	95 units	Normal
Fuel Crossfeed switch position	31 units	Refer to related topic

CAUTION: The relief pilot will announce any change in the Hydraulic System B quantity display and advise the other pilot when operating at a sample station without ground power.

- Values in this manual are invented and must not be used for any operational purpose.
- The pilot monitoring will confirm any change in the Bleed Air Supply quantity display and advise the other pilot when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The relief pilot will select any change in the Stall Warning annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.

The Traffic Advisory Display annunciation that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight. The relief pilot will confirm any change in the Traffic Advisory Display annunciation and advise the other pilot when conditions permit. The Stall Warning advisory is expected to read within the sample range of 31 to 37 units during engine start.

This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. If the Traffic Advisory Display is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

15.10.7 Bleed Air Supply Power Sources

The pilot flying will announce any change in the Center Tank Pumps advisory and advise the other pilot when operating at a sample station without ground power. The Primary Electrical Bus indication that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. The Autopilot Channel B status message that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete. During parking, both pilots should confirm the Thrust Reverser annunciation if the indication does not stabilize within the sample interval.

The Ground Proximity Monitor indication that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. The Hydraulic System B advisory is expected to read within the sample range of 84 to 91 units during descent. Refer to the related topic for additional sample context. The Oxygen Distribution switch position is expected to read within the sample range of 37 to 44 units during descent. Values in this manual are invented and must not be used for any operational purpose.

If the Thrust Reverser is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. During parking, both pilots should monitor the Autobrake Selector switch position when the associated caution light remains illuminated. The Hydraulic System A quantity display that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Window Heat status message that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight.

The Standby Hydraulic annunciation that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power. The pilot monitoring will brief any change in the Brake Temperature Monitor quantity display and advise the other pilot when operating at a sample station without ground power. If the Center Tank Pumps is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

If the Fuel Crossfeed is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The pilot flying will announce any change in the Fuel Crossfeed annunciation and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Fuel Crossfeed advisory is expected to read within the sample range of 26 to 38 units during a turnaround. The Cockpit Voice Recorder switch position that differs from the expected state requires the Captain to select the condition when conditions permit. The first officer will announce any change in the Weather Radar annunciation and advise the other pilot when conditions permit.

CAUTION: The Flight Management Computer status message that differs from the expected state requires the First Officer to record the condition before the next phase of flight. The Cargo Smoke Detection annunciation that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight.

- Both pilots will verify any change in the Autobrake Selector quantity display and advise the other pilot when conditions permit.
- The Weather Radar switch position is expected to read within the sample range of 53 to 61 units during a maintenance-requested ground run.
- During approach, the First Officer should brief the Brake Temperature Monitor annunciation unless directed otherwise by the Sample Operations Center.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will record any change in the Hydraulic System B advisory and advise the other pilot before the next phase of flight.

CAUTION: If the Hydraulic System B is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Pack Temperature Control status message is expected to read within the sample range of 67 to 75 units during landing.

15.10.8 Weather Radar Reset Guidance

During descent, the relief pilot should announce the Speedbrake Handle selector position if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder switch position that differs from the expected state requires the pilot monitoring to monitor the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

- If the Bleed Air Supply is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

- The Ground Proximity Monitor indication that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight.
- Both pilots will cross-check any change in the Probe Heat annunciation and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Oxygen Distribution annunciation	32 units	Normal
Hydraulic System B advisory	17 units	Refer to related topic
Autothrottle switch position	65 units	Normal
Autopilot Channel B selector position	83 units	Refer to related topic

- The Traffic Advisory Display advisory that differs from the expected state requires both pilots to confirm the condition when conditions permit.
- The pilot monitoring will verify any change in the Transponder status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The relief pilot will verify any change in the Cargo Smoke Detection status message and advise the other pilot if a discrepancy is observed.
- The Probe Heat annunciation that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed.
- The Pack Temperature Control switch position that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.

During preflight, the Captain should announce the Autobrake Selector indication when the associated caution light remains illuminated. The Standby Hydraulic quantity display is expected to read within the sample range of 83 to 94 units during approach. The Hydraulic System B selector position is expected to read within the sample range of 43 to 52 units during takeoff. During a maintenance-requested ground run, the relief pilot should verify the Cabin Pressure Controller annunciation once the checklist item is complete.

The Autopilot Channel B status message that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete. The Stall Warning switch position is expected to read within the sample range of 8 to 18 units during preflight. If the Weather Radar is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

15.10.9 Oxygen Distribution Indications

During engine start, the Captain should record the Brake Temperature Monitor switch position if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. If the Stall Warning is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During engine start, the Captain should record the Bleed Air Supply status message once the checklist item is complete. See 15.30.2 Hydraulic System A Limits Display.

Condition	Sample value	Remarks
Standby Instruments indication	50 units	Normal
Traffic Advisory Display annunciation	15 units	Refer to related topic
Pack Temperature Control switch position	61 units	Monitor

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice switch position that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed.

CAUTION: The Oxygen Distribution status message is expected to read within the sample range of 20 to 31 units during takeoff. During parking, the pilot flying should brief the Bleed Air Supply quantity display before the next phase of flight.

CAUTION: The Engine Anti-Ice annunciation that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated.

15.10.10 Weather Radar Overview

The Cabin Pressure Controller selector position is expected to read within the sample range of 93 to 102 units during a maintenance-requested ground run. The Standby Hydraulic indication that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller switch position is expected to read within the sample range of 23 to 27 units during engine start. The Landing Gear Indication status message that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed. During taxi, the pilot monitoring should monitor the Standby Instruments advisory before the next phase of flight. If the Ground Proximity Monitor is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Fire Detection Loop selector position that differs from the expected state requires the pilot monitoring to monitor the condition when conditions permit.

The pilot monitoring will cross-check any change in the Landing Gear Indication switch position and advise the other pilot when operating at a sample station without ground power. The relief pilot will announce any change in the Flight Management Computer switch position and advise the other pilot when the associated caution light remains illuminated. If the Stall Warning is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Transponder advisory is expected to read within the sample range of 28 to 34 units during descent.

If the Hydraulic System A is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The first officer will confirm any change in the Standby Hydraulic indication and advise the other pilot once the checklist item is complete. The Autopilot Channel A advisory is expected to read within the sample range of 71 to 75 units during landing. The Standby Hydraulic indication that differs from the expected state requires the relief pilot to record the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will cross-check any change in the Weather Radar annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the pilot monitoring should confirm the Autopilot Channel B status message when the associated caution light remains illuminated. Both pilots will verify any change in the Window Heat quantity display and advise the other pilot when the associated caution light remains illuminated.

CAUTION: During engine start, the relief pilot should verify the Nosewheel Steering switch position before the next phase of flight.

15.10.11 Bleed Air Supply Overview

The Brake Temperature Monitor selector position is expected to read within the sample range of 14 to 19 units during a turnaround. The Autopilot Channel B indication is expected to read within the sample range of 23 to 34 units during parking. Refer to the related topic for additional sample context. The captain will cross-check any change in the Flight Management Computer indication and advise the other pilot once the checklist item is complete. The Center Tank Pumps indication that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. The Auxiliary Power Unit switch position is expected to read within the sample range of 64 to 67 units during landing.

- The Weather Radar switch position is expected to read within the sample range of 44 to 50 units during a maintenance-requested ground run.

- During engine start, both pilots should record the Flight Management Computer advisory when operating at a sample station without ground power.
- The Oxygen Distribution selector position that differs from the expected state requires the Captain to record the condition once the checklist item is complete.
- The Primary Electrical Bus status message that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power.
- If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the pilot flying should announce the Probe Heat quantity display when operating at a sample station without ground power. The Brake Temperature Monitor status message that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated. Both pilots will confirm any change in the Nosewheel Steering annunciation and advise the other pilot when conditions permit. If the Window Heat is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context. During descent, both pilots should brief the Cockpit Voice Recorder annunciation when the associated caution light remains illuminated.

The Engine Anti-Ice selector position is expected to read within the sample range of 9 to 14 units during cruise. Both pilots will select any change in the Center Tank Pumps switch position and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection status message that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center.

During descent, the First Officer should monitor the Hydraulic System A selector position once the checklist item is complete. The Autopilot Channel B status message that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will verify any change in the Ground Proximity Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will monitor any change in the Flap Position Indication switch position and advise the other pilot if a discrepancy is observed.

15.10.12 Wing Anti-Ice Normal Operation

The relief pilot will confirm any change in the Hydraulic System B annunciation and advise the other pilot when conditions permit. The Stall Warning status message that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center. The Transponder selector position is expected to read within the sample range of 89 to 95 units during a diversion. During an extended ground delay, the First Officer should record the Thrust Reverser quantity display once the checklist item is complete. The first officer will announce any change in the Autobrake Selector advisory and advise the other pilot before the next phase of flight.

CAUTION: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Traffic Advisory Display quantity display	32 units	Normal
Wing Anti-Ice selector position	22 units	Monitor
Probe Heat status message	27 units	Monitor
Autopilot Channel A status message	88 units	Monitor
Fuel Crossfeed status message	68 units	Advisory only

The Nosewheel Steering annunciation is expected to read within the sample range of 78 to 82 units during engine start. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Speedbrake Handle switch position that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight.

The Auxiliary Power Unit indication that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will cross-check any change in the Engine Anti-Ice selector position and advise the other pilot when the associated caution light remains illuminated.

The Autopilot Channel A annunciation that differs from the expected state requires both pilots to select the condition when conditions permit. If the Transponder is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Cargo Smoke Detection selector position is expected to read within the sample range of 72 to 80 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose.

This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the relief pilot should cross-check the Oxygen Distribution selector position before the next phase of flight. The captain will verify any change in the Traffic Advisory Display status message and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Weather Radar is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

If the Standby Hydraulic is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The Speedbrake Handle selector position that differs from the expected state requires the Captain to monitor the condition when conditions permit. During an extended ground delay, the First Officer should cross-check the Thrust Reverser selector position before the next phase of flight. The Cabin Pressure Controller indication that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight. During preflight, the Captain should select the Autopilot Channel B status message unless directed otherwise by the Sample Operations Center. The pilot flying will record any change in the Engine Anti-Ice advisory and advise the other pilot before the next phase of flight.

15.10.13 Brake Temperature Monitor Limits Display

The pilot monitoring will record any change in the Autobrake Selector quantity display and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. The Ground Proximity Monitor advisory that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval.

CAUTION: If the Thrust Reverser is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

CAUTION: If the Thrust Reverser is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

During an extended ground delay, both pilots should confirm the Thrust Reverser selector position once the checklist item is complete. The Wing Anti-Ice advisory that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. The captain will confirm any change in the Cockpit Voice Recorder status message and advise the other pilot once the checklist item is complete.

CAUTION: Refer to the related topic for additional sample context. The Flap Position Indication indication is expected to read within the sample range of 7 to 17 units during climb.

The Oxygen Distribution advisory is expected to read within the sample range of 91 to 103 units during cruise. Both pilots will brief any change in the Cargo Smoke Detection switch position and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel B status message is expected to read within the sample range of 61 to 69 units during a diversion.

- Both pilots will select any change in the Bleed Air Supply annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Traffic Advisory Display quantity display that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed.
- Both pilots will announce any change in the Flap Position Indication status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Engine Anti-Ice advisory is expected to read within the sample range of 16 to 26 units during approach.
- If the Engine Anti-Ice is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. During landing, the pilot flying should monitor the Hydraulic System A selector position unless directed otherwise by the Sample Operations Center.

15.10.14 *Speedbrake Handle Power Sources*

This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will verify any change in the Speedbrake Handle selector position and advise the other pilot once the checklist item is complete. The pilot monitoring will monitor any change in the Transponder indication and advise the other pilot before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control selector position is expected to read within the sample range of 61 to 64 units during a maintenance-requested ground run. The captain will announce any change in the Probe Heat switch position and advise the other pilot when operating at a sample station without ground power. During taxi, the pilot monitoring should confirm the Hydraulic System A indication before the next phase of flight.

The Auxiliary Power Unit advisory is expected to read within the sample range of 86 to 94 units during approach. During preflight, both pilots should cross-check the Brake Temperature Monitor switch position when conditions permit. During takeoff, the relief pilot should record the Ground Proximity Monitor selector position if a discrepancy is observed. The Transponder switch position that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. During engine start, the pilot flying should brief the Window Heat indication before the next phase of flight.

The Oxygen Distribution selector position that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated. The Landing Gear Indication switch position is expected to read within the sample range of 52 to 64 units during parking. The first officer will monitor any change in the Speedbrake Handle selector position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. If the Flap Position Indication is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Landing Gear Indication selector position is expected to read within the sample range of 75 to 83 units during cruise.

CAUTION: The Probe Heat selector position is expected to read within the sample range of 88 to 100 units during takeoff. The Standby Hydraulic annunciation is expected to read within the sample range of 62 to 73 units during descent.

- The Fuel Crossfeed quantity display that differs from the expected state requires the pilot flying to cross-check the condition if a discrepancy is observed.
- The Brake Temperature Monitor indication is expected to read within the sample range of 69 to 77 units during an extended ground delay.
- The Cargo Smoke Detection advisory that differs from the expected state requires both pilots to record the condition when conditions permit.

- If the Fire Detection Loop is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- The Traffic Advisory Display selector position that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center.
- During a diversion, the pilot flying should announce the Probe Heat annunciation when operating at a sample station without ground power.

During cruise, the pilot flying should record the Window Heat switch position once the checklist item is complete. The Autothrottle status message is expected to read within the sample range of 13 to 17 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Traffic Advisory Display status message	1 units	Refer to related topic
Cockpit Voice Recorder annunciation	58 units	Monitor
Standby Instruments selector position	92 units	Refer to related topic
Autobrake Selector indication	66 units	Advisory only
Cargo Smoke Detection indication	11 units	Advisory only

15.10.15 Thrust Reverser Limits Display

The first officer will select any change in the Autopilot Channel B switch position and advise the other pilot when conditions permit. The Autopilot Channel B switch position is expected to read within the sample range of 23 to 29 units during engine start. The Thrust Reverser selector position that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated.

CAUTION: The Cargo Smoke Detection status message that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. The pilot monitoring will brief any change in the Autobrake Selector advisory and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Standby Instruments advisory	24 units	Normal
Window Heat annunciation	43 units	Monitor
Autopilot Channel B annunciation	1 units	Refer to related topic
Brake Temperature Monitor switch position	71 units	Advisory only
Autopilot Channel A status message	21 units	Monitor
Stall Warning indication	64 units	Normal

Condition	Sample value	Remarks
Transponder switch position	5 units	Normal
Flap Position Indication quantity display	19 units	Refer to related topic
Stall Warning status message	1 units	Monitor
Weather Radar status message	74 units	Refer to related topic
Standby Instruments annunciation	21 units	Advisory only

NOTE: The Traffic Advisory Display switch position is expected to read within the sample range of 62 to 68 units during landing.

During taxi, the pilot monitoring should brief the Hydraulic System A status message before the next phase of flight. During climb, the pilot flying should announce the Landing Gear Indication quantity display when operating at a

sample station without ground power. The Primary Electrical Bus annunciation is expected to read within the sample range of 47 to 57 units during a diversion. During takeoff, both pilots should confirm the Window Heat status message unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

15.20 Controls and Indicators

15.20.1 Cockpit Voice Recorder Interfaces

The pilot monitoring will confirm any change in the Standby Hydraulic quantity display and advise the other pilot when conditions permit. During landing, the pilot flying should cross-check the Fuel Crossfeed quantity display unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display status message is expected to read within the sample range of 64 to 71 units during climb.

During preflight, the relief pilot should verify the Cabin Pressure Controller quantity display when operating at a sample station without ground power. The Bleed Air Supply quantity display is expected to read within the sample range of 71 to 82 units during a maintenance-requested ground run. Refer to the related topic for additional sample context. The Stall Warning annunciation is expected to read within the sample range of 6 to 12 units during a turnaround.

CAUTION: During landing, the relief pilot should cross-check the Autopilot Channel A advisory before the next phase of flight.

The Speedbrake Handle indication that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated. If the Center Tank Pumps is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display quantity display that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Fire Detection Loop switch position	15 units	Advisory only
Fire Detection Loop indication	8 units	Refer to related topic
Cockpit Voice Recorder status message	10 units	Normal
Flap Position Indication status message	96 units	Advisory only
Hydraulic System B advisory	94 units	Normal
Center Tank Pumps advisory	19 units	Advisory only

- The Engine Anti-Ice advisory is expected to read within the sample range of 27 to 36 units during an extended ground delay.
- If the Engine Anti-Ice is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Fuel Crossfeed indication	24 units	Monitor
Hydraulic System B annunciation	90 units	Refer to related topic
Probe Heat advisory	11 units	Normal

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection switch position is expected to read within the sample range of 84 to 94 units during engine start.

15.20.2 Hydraulic System A Interfaces

The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle status message is expected to read within the sample range of 6 to 13 units during parking. During landing, the pilot monitoring should brief the Nosewheel Steering switch position if a discrepancy is observed. The Autopilot Channel B selector position is expected to read within the sample range of 2 to 5 units during takeoff. The Flight Management Computer advisory is expected to read within the sample range of 63 to 72 units during preflight.

CAUTION: During engine start, both pilots should announce the Autobrake Selector switch position if the indication does not stabilize within the sample interval. The first officer will select any change in the Standby Hydraulic selector position and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The Weather Radar advisory that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval. During preflight, both pilots should monitor the Probe Heat indication once the checklist item is complete.

NOTE: The Stall Warning annunciation is expected to read within the sample range of 67 to 75 units during approach.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic annunciation is expected to read within the sample range of 35 to 38 units during a maintenance-requested ground run. During a turnaround, the First Officer should cross-check the Autobrake Selector status message once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

15.20.3 Pack Temperature Control Interfaces

The Flap Position Indication switch position is expected to read within the sample range of 74 to 83 units during a turnaround. If the Cargo Smoke Detection is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Center Tank Pumps status message and advise the other pilot once the checklist item is complete. During a turnaround, both pilots should cross-check the Center Tank Pumps quantity display before the next phase of flight. The Cargo Smoke Detection advisory that differs from the expected state requires the First Officer to record the condition before the next phase of flight.

If the Primary Electrical Bus is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The first officer will record any change in the Engine Anti-Ice advisory and advise the other pilot when operating at a sample station without ground power. During approach, the Captain should cross-check the Primary Electrical Bus switch position if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure.

The pilot flying will monitor any change in the Fuel Crossfeed selector position and advise the other pilot when the associated caution light remains illuminated. The Autobrake Selector advisory that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power. If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Stall Warning status message that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will monitor any change in the Flap Position Indication indication and advise the other pilot if a discrepancy is observed.

The Cargo Smoke Detection quantity display that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. During descent, the pilot monitoring should confirm the Wing Anti-Ice annunciation before the next phase of flight. During climb, both pilots should record the Auxiliary Power Unit switch position if the indication does not stabilize within the sample interval. During takeoff, both pilots should monitor the Wing Anti-Ice status message before the next phase of flight. The Transponder annunciation is expected to read within the sample range of 40 to 50 units during takeoff.

NOTE: During parking, the pilot monitoring should verify the Standby Hydraulic advisory before the next phase of flight.

Condition	Sample value	Remarks
Auxiliary Power Unit status message	84 units	Refer to related topic
Autopilot Channel B annunciation	75 units	Advisory only
Autopilot Channel B switch position	39 units	Monitor
Brake Temperature Monitor switch position	43 units	Refer to related topic
Oxygen Distribution indication	72 units	Advisory only

CAUTION: The relief pilot will confirm any change in the Stall Warning selector position and advise the other pilot before the next phase of flight. During engine start, the relief pilot should confirm the Flap Position Indication quantity display when conditions permit.

During engine start, the relief pilot should verify the Wing Anti-Ice selector position when the associated caution light remains illuminated. Refer to the related topic for additional sample context. During taxi, the pilot flying should verify the Flap Position Indication selector position if the indication does not stabilize within the sample interval.

If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Window Heat is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

15.20.4 Autothrottle Test

If the Oxygen Distribution is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During approach, the pilot flying should select the Cargo Smoke Detection selector position when operating at a sample station without ground power. Both pilots will select any change in the Transponder advisory and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. See 18.10.12 Transponder Reset Guidance.

- During landing, the First Officer should cross-check the Probe Heat quantity display before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Transponder is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.
- During cruise, the pilot monitoring should announce the Flap Position Indication annunciation unless directed otherwise by the Sample Operations Center.

NOTE: The first officer will announce any change in the Probe Heat advisory and advise the other pilot when conditions permit.

CAUTION: The pilot flying will record any change in the Weather Radar indication and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The relief pilot will brief any change in the Cockpit Voice Recorder quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The Brake Temperature Monitor indication that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. During parking, the relief pilot should record the Standby Hydraulic annunciation when operating at a sample station without ground power.

15.20.5 Window Heat Overview

The Auxiliary Power Unit switch position is expected to read within the sample range of 79 to 88 units during a diversion. The captain will select any change in the Standby Hydraulic quantity display and advise the other pilot before the next phase of flight. If the Cockpit Voice Recorder is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The Auxiliary Power Unit switch position is expected to read within the sample range of 59 to 64 units during preflight. The Center Tank Pumps switch position that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed. The Speedbrake Handle status message that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit.

CAUTION: During cruise, both pilots should record the Fuel Crossfeed selector position if a discrepancy is observed.

Refer to the related topic for additional sample context. The Traffic Advisory Display status message is expected to read within the sample range of 83 to 88 units during a maintenance-requested ground run. The captain will cross-check any change in the Probe Heat status message and advise the other pilot once the checklist item is complete. If the Cargo Smoke Detection is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Cargo Smoke Detection switch position that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. If the Engine Anti-Ice is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

- The Pack Temperature Control quantity display that differs from the expected state requires the pilot flying to announce the condition when conditions permit.
- If the Fuel Crossfeed is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- During landing, the First Officer should verify the Autobrake Selector switch position once the checklist item is complete.
- If the Oxygen Distribution is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- The Autobrake Selector status message is expected to read within the sample range of 65 to 70 units during preflight.
- If the Center Tank Pumps is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

CAUTION: If the Hydraulic System B is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Flap Position Indication switch position	90 units	Monitor
Wing Anti-Ice quantity display	86 units	Advisory only
Hydraulic System A quantity display	75 units	Monitor

15.20.6 Wing Anti-Ice Power Sources

The Autothrottle quantity display is expected to read within the sample range of 32 to 44 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

Values in this manual are invented and must not be used for any operational purpose. The relief pilot will confirm any change in the Primary Electrical Bus advisory and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. During a diversion, the pilot monitoring should record the Fire Detection Loop advisory once the checklist item is complete. The pilot monitoring will confirm any change in the Cabin Pressure

Controller annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 53 to 59 units during parking.

- The Window Heat status message that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power.
- During a turnaround, the pilot monitoring should announce the Cockpit Voice Recorder indication if the indication does not stabilize within the sample interval.
- The Probe Heat selector position that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight.
- The Oxygen Distribution indication that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During cruise, the Captain should cross-check the Auxiliary Power Unit annunciation once the checklist item is complete.
- If the Landing Gear Indication is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.
- The Speedbrake Handle selector position is expected to read within the sample range of 47 to 51 units during approach.
- During climb, the Captain should brief the Autopilot Channel B switch position when conditions permit.
- The Cabin Pressure Controller selector position is expected to read within the sample range of 62 to 70 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Thrust Reverser switch position	92 units	Monitor
Hydraulic System B indication	12 units	Refer to related topic
Flap Position Indication switch position	56 units	Advisory only
Fuel Crossfeed advisory	22 units	Advisory only

Condition	Sample value	Remarks
Hydraulic System A indication	96 units	Normal
Cabin Pressure Controller quantity display	78 units	Advisory only
Flight Management Computer indication	2 units	Normal
Autobrake Selector switch position	77 units	Monitor
Traffic Advisory Display advisory	8 units	Refer to related topic
Speedbrake Handle selector position	84 units	Normal

Condition	Sample value	Remarks
Cabin Pressure Controller status message	71 units	Normal
Thrust Reverser switch position	73 units	Advisory only
Autobrake Selector status message	50 units	Monitor
Flap Position Indication annunciation	40 units	Monitor
Ground Proximity Monitor status message	47 units	Normal
Transponder indication	36 units	Monitor

CAUTION: If the Auxiliary Power Unit is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Nosewheel Steering switch position that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center.

The pilot monitoring will confirm any change in the Hydraulic System A quantity display and advise the other pilot when operating at a sample station without ground power. The captain will announce any change in the Landing Gear Indication advisory and advise the other pilot when the associated caution light remains illuminated. The Stall Warning annunciation that differs from the expected state requires the Captain to select the condition when conditions permit. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

15.20.7 Hydraulic System B Indications

Refer to the related topic for additional sample context. The pilot flying will verify any change in the Thrust Reverser selector position and advise the other pilot when the associated caution light remains illuminated. If the Speedbrake Handle is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel B indication that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Primary Electrical Bus annunciation	15 units	Normal
Speedbrake Handle status message	54 units	Advisory only
Primary Electrical Bus selector position	86 units	Refer to related topic
Bleed Air Supply advisory	44 units	Advisory only
Landing Gear Indication annunciation	73 units	Refer to related topic
Standby Instruments quantity display	75 units	Advisory only

The pilot monitoring will verify any change in the Probe Heat switch position and advise the other pilot once the checklist item is complete. The Weather Radar quantity display is expected to read within the sample range of 93 to 101 units during a turnaround. During preflight, the First Officer should brief the Hydraulic System A indication before the next phase of flight.

CAUTION: The pilot monitoring will monitor any change in the Hydraulic System A status message and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

The Traffic Advisory Display status message is expected to read within the sample range of 74 to 79 units during landing. Values in this manual are invented and must not be used for any operational purpose. If the Hydraulic System B is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Weather Radar switch position	57 units	Normal
Probe Heat quantity display	80 units	Refer to related topic
Standby Instruments indication	38 units	Normal

During taxi, the Captain should verify the Probe Heat quantity display when conditions permit. The pilot monitoring will select any change in the Flight Management Computer switch position and advise the other pilot if a discrepancy is observed. The pilot monitoring will announce any change in the Primary Electrical Bus status message and advise the other pilot when the associated caution light remains illuminated. If the Probe Heat is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, the relief pilot should select the Probe Heat status

message unless directed otherwise by the Sample Operations Center.

The pilot monitoring will monitor any change in the Ground Proximity Monitor selector position and advise the other pilot once the checklist item is complete. During landing, the pilot flying should brief the Thrust Reverser selector position if the indication does not stabilize within the sample interval. The Weather Radar switch position that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. The pilot monitoring will verify any change in the Pack Temperature Control annunciation and advise the other pilot when operating at a sample station without ground power. During takeoff, the pilot monitoring should monitor the Oxygen Distribution selector position if a discrepancy is observed.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

15.20.8 Thrust Reverser Power Sources

The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder quantity display that differs from the expected state requires the First Officer to record the condition once the checklist item is complete. If the Landing Gear Indication is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Stall Warning quantity display is expected to read within the sample range of 36 to 40 units during taxi.

The Hydraulic System A quantity display that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. During cruise, both pilots should cross-check the Weather Radar annunciation when the associated caution light remains illuminated. If the Cockpit Voice Recorder is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Stall Warning status message that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, the pilot flying should record the Pack Temperature Control switch position when conditions permit. The Autobrake Selector quantity display that differs from the expected state requires the pilot monitoring to brief the condition if the indication does not stabilize within the sample interval. Both pilots will select any change in the Cabin Pressure Controller quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder switch position that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center.

NOTE: The relief pilot will record any change in the Hydraulic System B indication and advise the other pilot once the checklist item is complete. The Traffic Advisory Display switch position that differs from the expected state requires both pilots to monitor the condition before the next phase of flight.

Condition	Sample value	Remarks
Flight Management Computer indication	83 units	Advisory only
Nosewheel Steering advisory	90 units	Monitor
Landing Gear Indication indication	39 units	Advisory only
Flight Management Computer indication	81 units	Normal
Hydraulic System A selector position	56 units	Normal
Autopilot Channel A switch position	40 units	Refer to related topic
Pack Temperature Control indication	74 units	Monitor

- The captain will cross-check any change in the Landing Gear Indication selector position and advise the other pilot before the next phase of flight.
- If the Ground Proximity Monitor is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

- The captain will record any change in the Window Heat advisory and advise the other pilot when operating at a sample station without ground power.
- If the Flap Position Indication is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.
- The pilot flying will brief any change in the Engine Anti-Ice indication and advise the other pilot when conditions permit.
- The relief pilot will announce any change in the Cargo Smoke Detection annunciation and advise the other pilot if a discrepancy is observed.
- The Cockpit Voice Recorder selector position is expected to read within the sample range of 40 to 47 units during cruise.
- Refer to the related topic for additional sample context.
- If the Hydraulic System B is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- During engine start, the relief pilot should verify the Autopilot Channel B advisory when the associated caution light remains illuminated.
- The Stall Warning switch position that differs from the expected state requires both pilots to announce the condition when operating at a sample station without ground power.
- The Cabin Pressure Controller status message is expected to read within the sample range of 62 to 74 units during a diversion.
- During takeoff, the relief pilot should monitor the Wing Anti-Ice selector position when conditions permit.
- The captain will verify any change in the Wing Anti-Ice status message and advise the other pilot when conditions permit.
- The captain will monitor any change in the Engine Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- During descent, the pilot flying should announce the Ground Proximity Monitor quantity display when conditions permit.

Condition	Sample value	Remarks
Center Tank Pumps status message	97 units	Normal
Speedbrake Handle selector position	50 units	Monitor
Thrust Reverser annunciation	15 units	Advisory only

15.20.9 Standby Instruments Crew Awareness

The Nosewheel Steering status message that differs from the expected state requires the First Officer to monitor the condition once the checklist item is complete. The relief pilot will brief any change in the Landing Gear Indication indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Center Tank Pumps quantity display that differs from the expected state requires the relief pilot to brief the condition when conditions permit.

The Window Heat annunciation is expected to read within the sample range of 3 to 14 units during a turnaround. The captain will confirm any change in the Ground Proximity Monitor status message and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. If the Window Heat is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

During cruise, both pilots should cross-check the Pack Temperature Control status message when operating at a sample station without ground power. If the Flight Management Computer is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The first officer will announce any change in the Traffic Advisory Display quantity display and advise the other pilot when the associated caution light remains illuminated. During engine start, both pilots should verify the Fire Detection Loop advisory when operating at a sample station without ground power.

CAUTION: If the Autothrottle is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. During takeoff, the relief pilot should record the Flap Position Indication status message before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. If the Ground Proximity Monitor is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. Both pilots will brief any change in the Autobrake Selector annunciation and advise the other pilot once the checklist item is complete.

If the Cabin Pressure Controller is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During descent, the pilot monitoring should record the Cockpit Voice Recorder quantity display when conditions permit. The Fuel Crossfeed status message is expected to read within the sample range of 23 to 29 units during an extended ground delay. The pilot monitoring will cross-check any change in the Autobrake Selector selector position and advise the other pilot before the next phase of flight.

The Thrust Reverser status message that differs from the expected state requires the First Officer to verify the condition when conditions permit. The Standby Hydraulic indication is expected to read within the sample range of 96 to 106 units during a maintenance-requested ground run. The Transponder indication is expected to read within the sample range of 84 to 89 units during preflight.

15.20.10 Speedbrake Handle Crew Awareness

The relief pilot will select any change in the Thrust Reverser selector position and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. During takeoff, both pilots should select the Cargo Smoke Detection selector position when operating at a sample station without ground power. Both pilots will cross-check any change in the Ground Proximity Monitor switch position and advise the other pilot once the checklist item is complete.

The Probe Heat annunciation that differs from the expected state requires the Captain to select the condition before the next phase of flight. The pilot flying will verify any change in the Weather Radar annunciation and advise the other pilot when conditions permit. During parking, the relief pilot should brief the Hydraulic System B advisory when operating at a sample station without ground power. The Stall Warning advisory is expected to read within the sample range of 37 to 49 units during landing.

- During an extended ground delay, the relief pilot should monitor the Cabin Pressure Controller indication unless directed otherwise by the Sample Operations Center.
- The pilot monitoring will confirm any change in the Standby Instruments selector position and advise the other pilot when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- The Nosewheel Steering status message that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed.

The Weather Radar advisory that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. Refer to the related topic for additional sample context. The Flap Position Indication advisory is expected to read within the sample range of 3 to 12 units during an extended ground delay. During approach, the pilot flying should record the Weather Radar indication before the next phase of flight. If the

Autopilot Channel B is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

CAUTION: Both pilots will verify any change in the Autobrake Selector selector position and advise the other pilot once the checklist item is complete.

During engine start, the pilot monitoring should confirm the Probe Heat annunciation if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. During approach, the relief pilot should confirm the Fuel Crossfeed status message when operating at a sample station without ground power. If the Window Heat is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The relief pilot will select any change in the Standby Hydraulic annunciation and advise the other pilot once the checklist item is complete.

During an extended ground delay, the First Officer should brief the Center Tank Pumps annunciation once the checklist item is complete. The Nosewheel Steering indication that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power. The Primary Electrical Bus indication that differs from the expected state requires both pilots to announce the condition before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

15.20.11 Hydraulic System B Overview

If the Landing Gear Indication is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Stall Warning is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

If the Ground Proximity Monitor is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Nosewheel Steering selector position and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Engine Anti-Ice selector position that differs from the expected state requires the Captain to select the condition when conditions permit.
- The captain will brief any change in the Hydraulic System B annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The pilot flying will select any change in the Traffic Advisory Display quantity display and advise the other pilot once the checklist item is complete.
- The Hydraulic System B switch position is expected to read within the sample range of 2 to 14 units during an extended ground delay.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Speedbrake Handle status message is expected to read within the sample range of 16 to 24 units during preflight.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

- Values in this manual are invented and must not be used for any operational purpose.
- The captain will select any change in the Standby Hydraulic advisory and advise the other pilot once the checklist item is complete.
- The Probe Heat quantity display that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated.

- The Thrust Reverser selector position is expected to read within the sample range of 3 to 13 units during engine start.
- During cruise, the First Officer should cross-check the Wing Anti-Ice advisory when conditions permit.
- The Autopilot Channel A quantity display is expected to read within the sample range of 93 to 104 units during a turnaround.

CAUTION: The Stall Warning advisory is expected to read within the sample range of 96 to 102 units during a turnaround. The relief pilot will cross-check any change in the Transponder switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Center Tank Pumps is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The first officer will announce any change in the Flap Position Indication selector position and advise the other pilot when the associated caution light remains illuminated. The Engine Anti-Ice quantity display is expected to read within the sample range of 64 to 76 units during takeoff. The Primary Electrical Bus indication that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated. The Cabin Pressure Controller annunciation that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete.

CAUTION: The Standby Hydraulic advisory that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

15.20.12 Autopilot Channel A Overview

The Auxiliary Power Unit switch position is expected to read within the sample range of 19 to 27 units during preflight. The Oxygen Distribution indication is expected to read within the sample range of 92 to 98 units during a turnaround. The Window Heat selector position is expected to read within the sample range of 32 to 37 units during approach.

The Speedbrake Handle quantity display is expected to read within the sample range of 44 to 56 units during takeoff. If the Hydraulic System B is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. Both pilots will monitor any change in the Nosewheel Steering advisory and advise the other pilot when the associated caution light remains illuminated. If the Probe Heat is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

NOTE: During engine start, both pilots should cross-check the Window Heat indication when the associated caution light remains illuminated. The Autobrake Selector switch position is expected to read within the sample range of 12 to 24 units during parking.

NOTE: The Bleed Air Supply advisory that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. The Autobrake Selector selector position that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated.

During cruise, the Captain should announce the Hydraulic System A advisory if the indication does not stabilize within the sample interval. If the Flight Management Computer is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display advisory is expected to read within the sample range of 83 to 87 units during landing. During climb, the pilot monitoring should monitor the Cargo Smoke Detection indication when conditions permit. The relief pilot will select any change in the Autobrake Selector status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: During cruise, the pilot monitoring should announce the Thrust Reverser selector position once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control switch position is expected to read within the sample range of 74 to 82 units during a maintenance-requested

ground run. If the Autopilot Channel B is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The pilot monitoring will monitor any change in the Weather Radar quantity display and advise the other pilot before the next phase of flight. The Bleed Air Supply indication is expected to read within the sample range of 8 to 20 units during climb.

15.20.13 Flap Position Indication Power Sources

The Flight Management Computer advisory is expected to read within the sample range of 42 to 46 units during an extended ground delay. The Autopilot Channel A status message that differs from the expected state requires the Captain to monitor the condition when conditions permit. The Thrust Reverser switch position that differs from the expected state requires both pilots to record the condition before the next phase of flight. The Standby Hydraulic switch position is expected to read within the sample range of 98 to 103 units during landing. The pilot monitoring will announce any change in the Thrust Reverser selector position and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

NOTE: During parking, the pilot flying should select the Autobrake Selector annunciation if the indication does not stabilize within the sample interval. Both pilots will select any change in the Cargo Smoke Detection selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Oxygen Distribution selector position is expected to read within the sample range of 28 to 38 units during landing. The relief pilot will confirm any change in the Flight Management Computer selector position and advise the other pilot once the checklist item is complete. If the Brake Temperature Monitor is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

If the Weather Radar is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Cockpit Voice Recorder indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Probe Heat is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

The captain will monitor any change in the Flap Position Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will cross-check any change in the Speedbrake Handle advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During a maintenance-requested ground run, both pilots should verify the Thrust Reverser advisory when conditions permit.

15.20.14 Ground Proximity Monitor Crew Awareness

The Flap Position Indication advisory that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. The Oxygen Distribution status message that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. If the Nosewheel Steering is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Wing Anti-Ice indication is expected to read within the sample range of 6 to 15 units during cruise.

The Oxygen Distribution quantity display that differs from the expected state requires the First Officer to record the condition before the next phase of flight. Refer to the related topic for additional sample context. During a turnaround, the Captain should verify the Pack Temperature Control quantity display when the associated caution light remains illuminated. The Bleed Air Supply advisory is expected to read within the sample range of 62 to 72 units during a diversion. The Wing Anti-Ice quantity display that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed.

NOTE: During a turnaround, the pilot monitoring should verify the Center Tank Pumps advisory before the next phase of flight.

During landing, the pilot flying should monitor the Brake Temperature Monitor status message before the next phase of flight. The Cockpit Voice Recorder status message that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated. The Stall Warning selector position is

expected to read within the sample range of 67 to 77 units during takeoff. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 46 to 49 units during preflight.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

- The Standby Hydraulic switch position is expected to read within the sample range of 53 to 65 units during engine start.
- During climb, the Captain should record the Wing Anti-Ice indication once the checklist item is complete.
- The Oxygen Distribution annunciation that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center.
- If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- During climb, the pilot flying should cross-check the Thrust Reverser indication when conditions permit.

The Traffic Advisory Display annunciation is expected to read within the sample range of 61 to 68 units during descent. The Engine Anti-Ice switch position is expected to read within the sample range of 38 to 43 units during landing. If the Hydraulic System A is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

- The Bleed Air Supply selector position is expected to read within the sample range of 33 to 38 units during climb.
- The Bleed Air Supply selector position is expected to read within the sample range of 21 to 28 units during takeoff.
- The pilot flying will cross-check any change in the Hydraulic System B switch position and advise the other pilot when conditions permit.
- If the Flap Position Indication is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- The relief pilot will announce any change in the Ground Proximity Monitor annunciation and advise the other pilot when conditions permit.
- The Ground Proximity Monitor indication that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center.

NOTE: The Stall Warning selector position that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

15.20.15 Standby Instruments Power Sources

The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle indication that differs from the expected state requires the First Officer to verify the condition when conditions permit. If the Ground Proximity Monitor is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

During a turnaround, the Captain should announce the Speedbrake Handle selector position when conditions permit. During descent, both pilots should monitor the Primary Electrical Bus indication before the next phase of flight. If the Auxiliary Power Unit is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

During takeoff, the relief pilot should record the Standby Instruments switch position when conditions permit. The Probe Heat selector position that differs from the expected state requires both pilots to monitor the condition if a

discrepancy is observed. During descent, both pilots should confirm the Oxygen Distribution switch position unless directed otherwise by the Sample Operations Center. The Fire Detection Loop indication is expected to read within the sample range of 42 to 46 units during descent. The Fuel Crossfeed indication that differs from the expected state requires both pilots to monitor the condition before the next phase of flight. During engine start, the First Officer should select the Autopilot Channel B status message when the associated caution light remains illuminated.

CAUTION: The pilot flying will record any change in the Autobrake Selector advisory and advise the other pilot when the associated caution light remains illuminated.

The Landing Gear Indication advisory that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. The Cockpit Voice Recorder switch position that differs from the expected state requires the relief pilot to brief the condition unless directed otherwise by the Sample Operations Center. During descent, the First Officer should confirm the Hydraulic System B status message when operating at a sample station without ground power. The Nosewheel Steering indication that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Thrust Reverser quantity display and advise the other pilot when the associated caution light remains illuminated.

If the Autobrake Selector is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During engine start, the relief pilot should confirm the Probe Heat quantity display when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. If the Primary Electrical Bus is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Window Heat selector position is expected to read within the sample range of 12 to 19 units during takeoff.

NOTE: The Flap Position Indication selector position is expected to read within the sample range of 49 to 52 units during a turnaround.

CAUTION: The Transponder status message that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete.

NOTE: Both pilots will brief any change in the Cockpit Voice Recorder annunciation and advise the other pilot before the next phase of flight. If the Bleed Air Supply is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

15.20.16 Wing Anti-Ice Limits Display

Both pilots will cross-check any change in the Nosewheel Steering advisory and advise the other pilot if a discrepancy is observed. During descent, the Captain should verify the Oxygen Distribution quantity display when the associated caution light remains illuminated. The Fire Detection Loop advisory that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight. The pilot flying will record any change in the Pack Temperature Control status message and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Engine Anti-Ice indication	63 units	Advisory only
Oxygen Distribution annunciation	71 units	Monitor
Probe Heat status message	78 units	Normal
Hydraulic System A status message	54 units	Monitor

- Both pilots will record any change in the Engine Anti-Ice switch position and advise the other pilot before the next phase of flight.
- Values in this manual are invented and must not be used for any operational purpose.
- This text is fictional and exists only to give the prototype realistic volume and structure.

- The Primary Electrical Bus switch position that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During an extended ground delay, the First Officer should select the Autothrottle selector position once the checklist item is complete.

Condition	Sample value	Remarks
Nosewheel Steering indication	83 units	Monitor
Auxiliary Power Unit indication	24 units	Advisory only
Autopilot Channel B quantity display	34 units	Advisory only

If the Pack Temperature Control is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will select any change in the Autobrake Selector selector position and advise the other pilot when operating at a sample station without ground power. The first officer will record any change in the Speedbrake Handle status message and advise the other pilot unless directed otherwise by the Sample Operations Center. During landing, the pilot flying should cross-check the Oxygen Distribution switch position if a discrepancy is observed.

The Primary Electrical Bus quantity display that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. The Fire Detection Loop indication that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated. The Cargo Smoke Detection switch position is expected to read within the sample range of 53 to 59 units during an extended ground delay. During takeoff, both pilots should announce the Landing Gear Indication annunciation unless directed otherwise by the Sample Operations Center. The Center Tank Pumps advisory that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated.

The Speedbrake Handle selector position is expected to read within the sample range of 80 to 83 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel A switch position is expected to read within the sample range of 25 to 30 units during takeoff. The Center Tank Pumps switch position is expected to read within the sample range of 55 to 61 units during climb.

Condition	Sample value	Remarks
Hydraulic System B advisory	43 units	Monitor
Pack Temperature Control indication	42 units	Monitor
Window Heat switch position	76 units	Monitor
Hydraulic System A quantity display	15 units	Advisory only
Pack Temperature Control indication	92 units	Refer to related topic

15.30 Operation

15.30.1 Autobrake Selector Interfaces

During an extended ground delay, both pilots should announce the Bleed Air Supply switch position when the associated caution light remains illuminated. The Window Heat selector position is expected to read within the sample range of 40 to 50 units during descent. If the Transponder is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Weather Radar switch position is expected to read within the sample range of 55 to 62 units during takeoff.

NOTE: The Wing Anti-Ice status message is expected to read within the sample range of 25 to 37 units during engine start.

The relief pilot will record any change in the Fire Detection Loop switch position and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will monitor any change in the Probe Heat quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Autobrake Selector is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

The pilot monitoring will verify any change in the Auxiliary Power Unit status message and advise the other pilot before the next phase of flight. If the Fuel Crossfeed is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will record any change in the Pack Temperature Control annunciation and advise the other pilot when conditions permit. If the Primary Electrical Bus is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: If the Engine Anti-Ice is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

NOTE: The Flap Position Indication selector position that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Hydraulic System B switch position	5 units	Monitor
Auxiliary Power Unit advisory	3 units	Normal
Window Heat annunciation	29 units	Normal
Probe Heat annunciation	11 units	Normal

The relief pilot will announce any change in the Standby Hydraulic switch position and advise the other pilot before the next phase of flight. If the Window Heat is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Speedbrake Handle annunciation that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed.

15.30.2 Hydraulic System A Limits Display

The Center Tank Pumps annunciation is expected to read within the sample range of 54 to 60 units during descent. During a turnaround, the Captain should confirm the Weather Radar switch position unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus status message that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will monitor any change in the Stall Warning selector position and advise the other pilot if a discrepancy is observed. During descent, the Captain should announce the Primary Electrical Bus indication when conditions permit.

NOTE: The captain will confirm any change in the Cockpit Voice Recorder quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The first officer will announce any change in the Engine Anti-Ice switch position and advise the other pilot when conditions permit. The relief pilot will confirm any change in the Landing Gear Indication annunciation and advise the other pilot when operating at a sample station without ground power.

CAUTION: Both pilots will announce any change in the Cargo Smoke Detection status message and advise the other pilot if the indication does not stabilize within the sample interval. During a turnaround, the Captain should verify the Autopilot Channel A annunciation once the checklist item is complete.

The Brake Temperature Monitor annunciation is expected to read within the sample range of 24 to 36 units during engine start. During an extended ground delay, the Captain should select the Ground Proximity Monitor status message if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. The Transponder switch position that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. The Landing Gear Indication quantity display that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center.

The Bleed Air Supply selector position is expected to read within the sample range of 22 to 26 units during a maintenance-requested ground run. During landing, both pilots should select the Auxiliary Power Unit advisory if the indication does not stabilize within the sample interval. If the Cabin Pressure Controller is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During a diversion, the pilot monitoring should confirm the Pack Temperature Control indication when operating at a sample station without ground power. The Thrust Reverser indication that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Autopilot Channel B selector position	48 units	Monitor
Autothrottle switch position	45 units	Normal
Standby Instruments status message	98 units	Normal
Brake Temperature Monitor indication	87 units	Advisory only

15.30.3 Ground Proximity Monitor Test

The Thrust Reverser indication is expected to read within the sample range of 72 to 75 units during an extended ground delay. During preflight, the pilot monitoring should brief the Landing Gear Indication advisory if the indication does not stabilize within the sample interval. During a turnaround, the pilot monitoring should select the Auxiliary Power Unit status message when operating at a sample station without ground power.

NOTE: The Window Heat status message that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. If the Landing Gear Indication is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Hydraulic System A advisory	35 units	Advisory only
Cargo Smoke Detection selector position	82 units	Advisory only
Pack Temperature Control switch position	4 units	Refer to related topic
Ground Proximity Monitor indication	94 units	Normal

NOTE: If the Auxiliary Power Unit is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During taxi, the pilot monitoring should verify the Window Heat switch position if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. The Bleed Air Supply indication is expected to read within the sample range of 55 to 63 units during an extended ground delay. During a maintenance-requested ground run, the pilot flying should record the Landing Gear Indication status message if a discrepancy is observed. During climb, the relief pilot should verify the Transponder selector position once the checklist item is complete.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

15.30.4 Fuel Crossfeed Test

The Auxiliary Power Unit status message is expected to read within the sample range of 71 to 76 units during takeoff. The Fire Detection Loop annunciation is expected to read within the sample range of 67 to 77 units during engine start. The Autopilot Channel A advisory is expected to read within the sample range of 12 to 21 units during an extended ground delay.

NOTE: If the Wing Anti-Ice is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

The pilot monitoring will announce any change in the Center Tank Pumps indication and advise the other pilot when the associated caution light remains illuminated. The Center Tank Pumps quantity display is expected to read within the sample range of 60 to 64 units during landing. Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection selector position that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. The Pack Temperature Control quantity display that differs from the expected state requires the Captain to select the condition once the checklist item is complete. The captain will select any change in the Probe Heat quantity display and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Fire Detection Loop advisory	2 units	Advisory only
Bleed Air Supply switch position	69 units	Refer to related topic
Standby Instruments quantity display	3 units	Refer to related topic
Weather Radar selector position	95 units	Advisory only
Bleed Air Supply indication	14 units	Advisory only

- The Standby Hydraulic quantity display is expected to read within the sample range of 36 to 39 units during a diversion.
- If the Weather Radar is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.
- During engine start, the relief pilot should verify the Fire Detection Loop advisory once the checklist item is complete.
- The captain will announce any change in the Stall Warning indication and advise the other pilot if a discrepancy is observed.
- The first officer will brief any change in the Wing Anti-Ice status message and advise the other pilot before the next phase of flight.
- During a diversion, the pilot flying should announce the Window Heat annunciation before the next phase of flight.

15.30.5 Stall Warning Power Sources

The Stall Warning switch position that differs from the expected state requires the Captain to select the condition when conditions permit. The Brake Temperature Monitor annunciation that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. The Auxiliary Power Unit selector position that differs from the expected state requires the pilot flying to verify the condition when conditions permit.

Condition	Sample value	Remarks
Window Heat status message	93 units	Refer to related topic
Stall Warning quantity display	97 units	Advisory only
Center Tank Pumps selector position	60 units	Monitor

Autothrottle status message	59 units	Normal
Transponder advisory	38 units	Refer to related topic
Oxygen Distribution switch position	3 units	Normal
Autobrake Selector quantity display	83 units	Monitor

During parking, the pilot flying should cross-check the Transponder annunciation when operating at a sample station without ground power. The first officer will record any change in the Standby Instruments switch position and advise the other pilot before the next phase of flight. During engine start, the relief pilot should record the Autopilot Channel A switch position once the checklist item is complete. The Center Tank Pumps switch position that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated. The Brake Temperature Monitor switch position that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete.

- Refer to the related topic for additional sample context.
- The Probe Heat advisory that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.
- Both pilots will record any change in the Autothrottle switch position and advise the other pilot when operating at a sample station without ground power.
- The pilot monitoring will verify any change in the Thrust Reverser selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Nosewheel Steering quantity display is expected to read within the sample range of 7 to 12 units during climb.
- The relief pilot will verify any change in the Autopilot Channel A status message and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Nosewheel Steering selector position	20 units	Normal
Autopilot Channel A status message	56 units	Refer to related topic
Autobrake Selector quantity display	80 units	Advisory only

Condition	Sample value	Remarks
Oxygen Distribution annunciation	71 units	Monitor
Transponder quantity display	35 units	Advisory only
Traffic Advisory Display switch position	26 units	Normal
Nosewheel Steering advisory	34 units	Refer to related topic
Engine Anti-Ice status message	84 units	Monitor
Center Tank Pumps annunciation	30 units	Refer to related topic

The Center Tank Pumps annunciation that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. If the Standby Instruments is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

15.30.6 Cargo Smoke Detection Normal Operation

Both pilots will record any change in the Autobrake Selector advisory and advise the other pilot when the associated caution light remains illuminated. The Bleed Air Supply quantity display that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. During parking, the Captain should brief the Landing Gear Indication switch position if a discrepancy is observed. The Wing Anti-Ice

annunciation is expected to read within the sample range of 49 to 59 units during landing. The Hydraulic System A advisory is expected to read within the sample range of 91 to 96 units during descent.

- The first officer will confirm any change in the Fuel Crossfeed status message and advise the other pilot when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Stall Warning annunciation that differs from the expected state requires the relief pilot to select the condition when conditions permit.
- The Fire Detection Loop selector position is expected to read within the sample range of 54 to 66 units during landing.

The relief pilot will announce any change in the Ground Proximity Monitor advisory and advise the other pilot when the associated caution light remains illuminated. The Cabin Pressure Controller quantity display that differs from the expected state requires the Captain to select the condition if a discrepancy is observed. If the Window Heat is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

The Hydraulic System A switch position that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated. The Engine Anti-Ice selector position is expected to read within the sample range of 16 to 28 units during an extended ground delay. During takeoff, the pilot monitoring should confirm the Fire Detection Loop selector position if the indication does not stabilize within the sample interval. During engine start, the Captain should confirm the Probe Heat quantity display when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the pilot monitoring should select the Fuel Crossfeed advisory unless directed otherwise by the Sample Operations Center.

If the Engine Anti-Ice is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Landing Gear Indication advisory that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. Refer to the related topic for additional sample context. During takeoff, the Captain should brief the Autopilot Channel A annunciation when operating at a sample station without ground power.

Condition	Sample value	Remarks
Primary Electrical Bus quantity display	8 units	Advisory only
Nosewheel Steering switch position	40 units	Monitor
Autothrottle quantity display	77 units	Advisory only
Pack Temperature Control annunciation	55 units	Normal
Probe Heat status message	61 units	Advisory only

Values in this manual are invented and must not be used for any operational purpose. If the Hydraulic System B is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

15.30.7 Standby Hydraulic Overview

During engine start, the relief pilot should confirm the Ground Proximity Monitor indication before the next phase of flight. The pilot monitoring will monitor any change in the Cabin Pressure Controller indication and advise the other pilot when the associated caution light remains illuminated. The Wing Anti-Ice advisory is expected to read within the sample range of 58 to 67 units during climb.

Condition	Sample value	Remarks
Cargo Smoke Detection status message	47 units	Advisory only

Hydraulic System B annunciation	24 units	Normal
Standby Hydraulic indication	41 units	Monitor
Transponder selector position	37 units	Advisory only

The Thrust Reverser selector position that differs from the expected state requires the pilot flying to brief the condition when conditions permit. Both pilots will record any change in the Autopilot Channel B switch position and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

The Cargo Smoke Detection indication is expected to read within the sample range of 77 to 89 units during a diversion. Refer to the related topic for additional sample context. The relief pilot will monitor any change in the Thrust Reverser selector position and advise the other pilot if a discrepancy is observed. The relief pilot will monitor any change in the Speedbrake Handle annunciation and advise the other pilot when conditions permit. The Speedbrake Handle indication that differs from the expected state requires both pilots to record the condition when conditions permit. During a diversion, the First Officer should monitor the Weather Radar quantity display when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autobrake Selector status message	81 units	Refer to related topic
Hydraulic System B quantity display	89 units	Advisory only
Center Tank Pumps annunciation	39 units	Normal
Flap Position Indication selector position	6 units	Advisory only

- The pilot monitoring will confirm any change in the Primary Electrical Bus selector position and advise the other pilot if a discrepancy is observed.
- During landing, both pilots should announce the Transponder status message when operating at a sample station without ground power.
- The Stall Warning switch position is expected to read within the sample range of 15 to 27 units during descent.

During takeoff, the Captain should announce the Autothrottle status message if the indication does not stabilize within the sample interval. The Fire Detection Loop annunciation is expected to read within the sample range of 32 to 43 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System A is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Autothrottle status message is expected to read within the sample range of 5 to 17 units during a turnaround. The Primary Electrical Bus indication that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated.

- The Cargo Smoke Detection switch position that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center.
- Refer to the related topic for additional sample context.
- The wording here is placeholder content shaped like a procedure, not a procedure.

15.30.8 Cabin Pressure Controller Reset Guidance

The Auxiliary Power Unit switch position that differs from the expected state requires both pilots to select the condition before the next phase of flight. The captain will confirm any change in the Hydraulic System A indication and advise the other pilot when conditions permit. The pilot flying will confirm any change in the Autopilot Channel A selector position and advise the other pilot when the associated caution light remains illuminated. The captain will announce any change in the Autobrake Selector switch position and advise the other pilot once the checklist item is complete. During climb, the pilot flying should brief the Brake Temperature Monitor advisory before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

NOTE: If the Pack Temperature Control is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Engine Anti-Ice advisory	49 units	Monitor
Weather Radar advisory	28 units	Advisory only
Flight Management Computer annunciation	59 units	Refer to related topic
Autobrake Selector switch position	41 units	Advisory only

- During taxi, both pilots should record the Speedbrake Handle selector position if the indication does not stabilize within the sample interval.
- The Wing Anti-Ice advisory that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center.
- During a turnaround, the relief pilot should brief the Wing Anti-Ice indication once the checklist item is complete.
- If the Hydraulic System B is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.
- The Transponder advisory that differs from the expected state requires the relief pilot to verify the condition if a discrepancy is observed.

During approach, both pilots should select the Bleed Air Supply selector position when conditions permit. The Wing Anti-Ice quantity display that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. If the Nosewheel Steering is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Bleed Air Supply switch position	65 units	Normal
Cockpit Voice Recorder selector position	69 units	Refer to related topic
Stall Warning switch position	47 units	Advisory only
Hydraulic System A annunciation	18 units	Advisory only
Landing Gear Indication status message	49 units	Monitor
Nosewheel Steering advisory	49 units	Normal
Landing Gear Indication quantity display	50 units	Monitor

Condition	Sample value	Remarks
Autothrottle annunciation	9 units	Refer to related topic
Landing Gear Indication indication	83 units	Monitor
Autobrake Selector status message	24 units	Monitor
Ground Proximity Monitor annunciation	56 units	Refer to related topic

Condition	Sample value	Remarks
Cabin Pressure Controller indication	87 units	Monitor
Speedbrake Handle switch position	23 units	Monitor
Auxiliary Power Unit selector position	33 units	Advisory only

Thrust Reverser status message	34 units	Refer to related topic
Cargo Smoke Detection advisory	97 units	Monitor
Window Heat selector position	98 units	Monitor
Oxygen Distribution selector position	79 units	Advisory only

The Hydraulic System A status message that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. The pilot flying will brief any change in the Traffic Advisory Display switch position and advise the other pilot before the next phase of flight. During a turnaround, both pilots should monitor the Autobrake Selector annunciation if a discrepancy is observed. The pilot monitoring will brief any change in the Transponder advisory and advise the other pilot when the associated caution light remains illuminated. During descent, the relief pilot should cross-check the Stall Warning status message once the checklist item is complete.

15.30.9 Hydraulic System B Indications

The Pack Temperature Control indication that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Ground Proximity Monitor indication that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated. Both pilots will verify any change in the Landing Gear Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Window Heat selector position that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Pack Temperature Control indication is expected to read within the sample range of 47 to 52 units during approach.
- During cruise, the pilot monitoring should select the Flight Management Computer quantity display if a discrepancy is observed.
- The Center Tank Pumps selector position that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight.

NOTE: The pilot monitoring will record any change in the Pack Temperature Control selector position and advise the other pilot when operating at a sample station without ground power.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

- Values in this manual are invented and must not be used for any operational purpose.
- If the Oxygen Distribution is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.
- If the Pack Temperature Control is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- The pilot flying will monitor any change in the Cockpit Voice Recorder status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Standby Hydraulic is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

During landing, the Captain should announce the Window Heat indication if a discrepancy is observed. During preflight, the pilot flying should monitor the Transponder indication if a discrepancy is observed. The Hydraulic System B status message is expected to read within the sample range of 16 to 26 units during an extended ground delay.

NOTE: The Wing Anti-Ice selector position that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power. If the Pack Temperature Control is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

15.30.10 Auxiliary Power Unit Interfaces

The first officer will cross-check any change in the Weather Radar selector position and advise the other pilot before the next phase of flight. The captain will record any change in the Weather Radar quantity display and advise the other pilot if a discrepancy is observed. The Bleed Air Supply indication that differs from the expected state requires the Captain to record the condition when the associated caution light remains illuminated.

CAUTION: The Hydraulic System B selector position is expected to read within the sample range of 70 to 78 units during a maintenance-requested ground run.

The Cabin Pressure Controller switch position is expected to read within the sample range of 85 to 97 units during a diversion. The Autobrake Selector quantity display that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. During an extended ground delay, the First Officer should monitor the Ground Proximity Monitor indication before the next phase of flight. The relief pilot will announce any change in the Speedbrake Handle indication and advise the other pilot once the checklist item is complete. The Engine Anti-Ice quantity display is expected to read within the sample range of 98 to 109 units during engine start.

NOTE: The captain will brief any change in the Flap Position Indication indication and advise the other pilot before the next phase of flight. If the Autothrottle is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

The Stall Warning selector position that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete. If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector status message that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Hydraulic System A advisory	96 units	Monitor
Probe Heat switch position	96 units	Normal
Stall Warning quantity display	25 units	Monitor
Fire Detection Loop selector position	40 units	Refer to related topic
Fuel Crossfeed annunciation	30 units	Monitor
Traffic Advisory Display quantity display	60 units	Refer to related topic

15.30.11 Hydraulic System A Indications

The Weather Radar switch position is expected to read within the sample range of 19 to 22 units during landing. The Autobrake Selector switch position is expected to read within the sample range of 35 to 46 units during a diversion. During cruise, the First Officer should confirm the Flap Position Indication selector position when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

The Bleed Air Supply indication that differs from the expected state requires both pilots to record the condition if a discrepancy is observed. The Landing Gear Indication quantity display is expected to read within the sample range of 83 to 87 units during a turnaround. If the Standby Instruments is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A status message that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center.

The Landing Gear Indication quantity display is expected to read within the sample range of 83 to 93 units during engine start. During an extended ground delay, the Captain should brief the Probe Heat selector position when operating at a sample station without ground power. During taxi, the relief pilot should select the Engine Anti-Ice status message when conditions permit. The Oxygen Distribution status message that differs from the expected state requires the First Officer to announce the condition before the next phase of flight. The Flap Position Indication status message that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System B is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

The first officer will record any change in the Landing Gear Indication annunciation and advise the other pilot if a discrepancy is observed. The Autopilot Channel A advisory is expected to read within the sample range of 48 to 53 units during climb. The Autopilot Channel B quantity display is expected to read within the sample range of 8 to 17 units during cruise.

During takeoff, the pilot monitoring should confirm the Engine Anti-Ice advisory once the checklist item is complete. Refer to the related topic for additional sample context. The pilot flying will monitor any change in the Autopilot Channel A advisory and advise the other pilot when the associated caution light remains illuminated. During approach, the First Officer should record the Probe Heat annunciation before the next phase of flight.

NOTE: The Transponder indication is expected to read within the sample range of 31 to 40 units during approach.

During a turnaround, the relief pilot should verify the Flap Position Indication quantity display when conditions permit. If the Cabin Pressure Controller is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Bleed Air Supply quantity display that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. If the Cabin Pressure Controller is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. If the Transponder is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

15.30.12 Primary Electrical Bus Normal Operation

The Cockpit Voice Recorder switch position is expected to read within the sample range of 70 to 74 units during cruise. The Cockpit Voice Recorder advisory is expected to read within the sample range of 34 to 45 units during takeoff. If the Center Tank Pumps is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will verify any change in the Bleed Air Supply switch position and advise the other pilot when conditions permit. The Engine Anti-Ice indication that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. If the Hydraulic System A is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

The Window Heat advisory that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. During cruise, the pilot flying should announce the Cargo Smoke Detection annunciation before the next phase of flight. During cruise, the relief pilot should monitor the Center Tank Pumps indication unless directed otherwise by the Sample Operations Center.

The Landing Gear Indication indication that differs from the expected state requires the Captain to select the condition when conditions permit. During cruise, the First Officer should brief the Autobrake Selector selector position if a discrepancy is observed. The captain will brief any change in the Hydraulic System B annunciation and advise the other pilot once the checklist item is complete. The Brake Temperature Monitor advisory that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. The Flap Position Indication switch position is expected to read within the sample range of 22 to 26 units during taxi.

If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Ground Proximity Monitor quantity display that differs from the expected state requires the relief pilot to record the condition when conditions permit. The Center Tank Pumps status message that differs from the expected state requires both pilots to confirm the condition before the next phase of

flight. The Flap Position Indication switch position that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

The Autobrake Selector switch position is expected to read within the sample range of 52 to 55 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Landing Gear Indication annunciation is expected to read within the sample range of 81 to 89 units during engine start. The first officer will monitor any change in the Cargo Smoke Detection indication and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Nosewheel Steering selector position	67 units	Refer to related topic
Wing Anti-Ice advisory	2 units	Refer to related topic
Flight Management Computer status message	70 units	Monitor
Transponder quantity display	48 units	Monitor
Flap Position Indication quantity display	70 units	Monitor
Cockpit Voice Recorder advisory	8 units	Refer to related topic

Condition	Sample value	Remarks
Traffic Advisory Display advisory	2 units	Advisory only
Ground Proximity Monitor advisory	89 units	Normal
Auxiliary Power Unit selector position	83 units	Normal

Condition	Sample value	Remarks
Auxiliary Power Unit selector position	80 units	Refer to related topic
Fuel Crossfeed annunciation	49 units	Monitor
Ground Proximity Monitor indication	21 units	Refer to related topic
Thrust Reverser switch position	14 units	Advisory only

15.30.13 Probe Heat Crew Awareness

During parking, the pilot flying should select the Hydraulic System B status message unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Speedbrake Handle annunciation is expected to read within the sample range of 77 to 80 units during takeoff.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System A status message is expected to read within the sample range of 50 to 54 units during taxi. Values in this manual are invented and must not be used for any operational purpose. During a maintenance-requested ground run, the First Officer should announce the Autopilot Channel B quantity display if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

Values in this manual are invented and must not be used for any operational purpose. During approach, the pilot monitoring should confirm the Window Heat quantity display when operating at a sample station without ground power. The first officer will monitor any change in the Traffic Advisory Display indication and advise the other pilot

when the associated caution light remains illuminated. The relief pilot will record any change in the Wing Anti-Ice advisory and advise the other pilot once the checklist item is complete.

- The Thrust Reverser status message is expected to read within the sample range of 17 to 24 units during a turnaround.
- The pilot flying will announce any change in the Autobrake Selector status message and advise the other pilot before the next phase of flight.
- The captain will confirm any change in the Window Heat status message and advise the other pilot once the checklist item is complete.
- During approach, both pilots should brief the Center Tank Pumps advisory when the associated caution light remains illuminated.
- If the Probe Heat is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Hydraulic System A advisory	97 units	Advisory only
Hydraulic System B switch position	50 units	Normal
Pack Temperature Control advisory	51 units	Advisory only
Autobrake Selector switch position	21 units	Normal
Traffic Advisory Display annunciation	58 units	Monitor

15.30.14 Wing Anti-Ice Test

The wording here is placeholder content shaped like a procedure, not a procedure. The Flight Management Computer quantity display that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. The Center Tank Pumps selector position that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.

If the Cargo Smoke Detection is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Oxygen Distribution annunciation that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. If the Autobrake Selector is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The captain will announce any change in the Brake Temperature Monitor annunciation and advise the other pilot before the next phase of flight.

During landing, the Captain should record the Landing Gear Indication status message when conditions permit. If the Cabin Pressure Controller is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Autopilot Channel A selector position that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight.

The Autopilot Channel A quantity display is expected to read within the sample range of 2 to 13 units during preflight. The Center Tank Pumps quantity display is expected to read within the sample range of 63 to 66 units during engine start. The captain will record any change in the Ground Proximity Monitor switch position and advise the other pilot when conditions permit. During a diversion, the relief pilot should verify the Fuel Crossfeed switch position when the associated caution light remains illuminated.

If the Fire Detection Loop is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The Stall Warning advisory is expected to read within the sample range of 58 to 69 units during cruise. During landing, the pilot flying should record the Cargo Smoke Detection selector position once the checklist item is complete. During takeoff, the relief pilot should cross-check the Traffic Advisory Display advisory before the next phase of flight. Both pilots will confirm any change in the Auxiliary Power Unit advisory and advise the other pilot if the indication does not stabilize within the sample interval. See 09.10.8 Speedbrake Handle Interfaces.

Condition	Sample value	Remarks
Standby Hydraulic status message	11 units	Refer to related topic
Speedbrake Handle advisory	55 units	Normal
Weather Radar switch position	87 units	Advisory only

15.30.15 Cargo Smoke Detection Reset Guidance

Refer to the related topic for additional sample context. The Cargo Smoke Detection advisory that differs from the expected state requires the Captain to announce the condition when conditions permit. During a turnaround, the First Officer should record the Autopilot Channel A switch position when the associated caution light remains illuminated. During descent, the pilot flying should monitor the Probe Heat status message when the associated caution light remains illuminated. The Stall Warning annunciation is expected to read within the sample range of 76 to 83 units during landing. If the Primary Electrical Bus is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

The Standby Hydraulic switch position is expected to read within the sample range of 33 to 37 units during approach. During landing, the pilot flying should brief the Flap Position Indication advisory once the checklist item is complete. The first officer will brief any change in the Cockpit Voice Recorder annunciation and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Fuel Crossfeed switch position	85 units	Refer to related topic
Autopilot Channel A status message	40 units	Advisory only
Autopilot Channel A quantity display	95 units	Normal
Standby Hydraulic quantity display	90 units	Monitor
Fuel Crossfeed advisory	52 units	Advisory only
Stall Warning advisory	89 units	Monitor
Oxygen Distribution advisory	52 units	Normal

CAUTION: Both pilots will brief any change in the Bleed Air Supply indication and advise the other pilot if the indication does not stabilize within the sample interval.

If the Hydraulic System A is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The pilot flying will monitor any change in the Pack Temperature Control switch position and advise the other pilot when operating at a sample station without ground power. Both pilots will brief any change in the Weather Radar quantity display and advise the other pilot when conditions permit. The Thrust Reverser quantity display is expected to read within the sample range of 56 to 59 units during a turnaround. The Weather Radar annunciation that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

15.30.16 Window Heat Power Sources

The Center Tank Pumps indication that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will cross-check any change in the Standby Hydraulic indication and advise the other pilot if a discrepancy is observed. The Flight Management Computer switch position that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Landing Gear Indication indication	91 units	Normal
Weather Radar selector position	82 units	Refer to related topic

Probe Heat switch position	78 units	Refer to related topic
Probe Heat status message	77 units	Normal
Oxygen Distribution advisory	10 units	Refer to related topic

CAUTION: Refer to the related topic for additional sample context. The Primary Electrical Bus switch position that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval.

If the Brake Temperature Monitor is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The captain will select any change in the Stall Warning selector position and advise the other pilot if a discrepancy is observed. During preflight, the First Officer should brief the Landing Gear Indication selector position once the checklist item is complete. The Probe Heat selector position is expected to read within the sample range of 53 to 60 units during climb. The captain will confirm any change in the Probe Heat quantity display and advise the other pilot before the next phase of flight. During landing, the Captain should brief the Ground Proximity Monitor indication once the checklist item is complete.

The Bleed Air Supply indication is expected to read within the sample range of 37 to 42 units during an extended ground delay. If the Probe Heat is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will record any change in the Auxiliary Power Unit status message and advise the other pilot before the next phase of flight. If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

15.30.17 New Sample Topic: Primary Electrical Bus

The Fuel Crossfeed quantity display is expected to read within the sample range of 62 to 74 units during landing. Refer to the related topic for additional sample context. The first officer will cross-check any change in the Hydraulic System A advisory and advise the other pilot if the indication does not stabilize within the sample interval.

The Bleed Air Supply advisory that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. Both pilots will monitor any change in the Wing Anti-Ice switch position and advise the other pilot when the associated caution light remains illuminated. During a turnaround, the pilot flying should announce the Oxygen Distribution switch position when conditions permit.

The Speedbrake Handle selector position that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center. During engine start, the relief pilot should monitor the Transponder selector position unless directed otherwise by the Sample Operations Center. Both pilots will record any change in the Primary Electrical Bus advisory and advise the other pilot before the next phase of flight. The Autopilot Channel B switch position is expected to read within the sample range of 12 to 24 units during descent.

The Hydraulic System A selector position that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. During takeoff, the pilot flying should verify the Traffic Advisory Display indication if a discrepancy is observed. The Weather Radar advisory is expected to read within the sample range of 14 to 19 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will select any change in the Traffic Advisory Display quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will brief any change in the Hydraulic System B indication and advise the other pilot when conditions permit.

- During a maintenance-requested ground run, both pilots should confirm the Autobrake Selector annunciation once the checklist item is complete.
- The Nosewheel Steering indication that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete.
- The Stall Warning indication that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight.

- The Cargo Smoke Detection advisory is expected to read within the sample range of 23 to 26 units during landing.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The relief pilot will select any change in the Probe Heat indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The Stall Warning quantity display is expected to read within the sample range of 8 to 16 units during landing.

The Autobrake Selector quantity display that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. During climb, the Captain should brief the Autopilot Channel B advisory unless directed otherwise by the Sample Operations Center. If the Stall Warning is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot flying should select the Hydraulic System B status message when the associated caution light remains illuminated.

CAUTION: The Hydraulic System B advisory is expected to read within the sample range of 71 to 79 units during a diversion.

Chapter 16 Systems: Ice and Rain Protection

16.10 Description

16.10.1 Nosewheel Steering Interfaces

During climb, the relief pilot should record the Landing Gear Indication indication when conditions permit. The Speedbrake Handle selector position that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. The Standby Instruments advisory is expected to read within the sample range of 67 to 74 units during engine start. During takeoff, both pilots should cross-check the Cargo Smoke Detection quantity display when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure.

The Fire Detection Loop quantity display that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. During landing, both pilots should announce the Primary Electrical Bus status message if the indication does not stabilize within the sample interval. During preflight, the First Officer should cross-check the Transponder quantity display when operating at a sample station without ground power. The pilot flying will cross-check any change in the Ground Proximity Monitor status message and advise the other pilot when the associated caution light remains illuminated. The Auxiliary Power Unit selector position is expected to read within the sample range of 90 to 100 units during takeoff.

Condition	Sample value	Remarks
Landing Gear Indication switch position	92 units	Advisory only
Traffic Advisory Display switch position	15 units	Monitor
Autopilot Channel A switch position	94 units	Normal

The Flap Position Indication quantity display is expected to read within the sample range of 10 to 14 units during a turnaround. During landing, the Captain should record the Brake Temperature Monitor quantity display once the checklist item is complete. The Flap Position Indication advisory that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight. The Hydraulic System B selector position that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. The Transponder quantity display that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

- Refer to the related topic for additional sample context.
- The Landing Gear Indication annunciation is expected to read within the sample range of 70 to 82 units during a diversion.
- The Fire Detection Loop selector position is expected to read within the sample range of 20 to 25 units during taxi.
- The Window Heat annunciation that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.
- During parking, both pilots should select the Center Tank Pumps status message if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autopilot Channel B indication	36 units	Normal
Autopilot Channel B status message	73 units	Normal
Center Tank Pumps indication	43 units	Monitor

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

The pilot monitoring will monitor any change in the Autothrottle status message and advise the other pilot if a discrepancy is observed. The Standby Instruments indication is expected to read within the sample range of 85 to 94 units during descent. During taxi, the relief pilot should select the Autopilot Channel B quantity display if a discrepancy is observed.

Condition	Sample value	Remarks
Wing Anti-Ice quantity display	2 units	Monitor
Wing Anti-Ice advisory	62 units	Advisory only
Center Tank Pumps switch position	38 units	Normal
Hydraulic System A selector position	23 units	Refer to related topic
Traffic Advisory Display status message	73 units	Advisory only
Hydraulic System B advisory	50 units	Monitor

16.10.2 Autopilot Channel B Status Messages

The Fire Detection Loop status message that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated. During landing, the relief pilot should verify the Oxygen Distribution advisory when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure.

Refer to the related topic for additional sample context. The relief pilot will monitor any change in the Flap Position Indication advisory and advise the other pilot before the next phase of flight. If the Brake Temperature Monitor is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

The Autopilot Channel A selector position that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit. The Autopilot Channel A annunciation is expected to read within the sample range of 77 to 83 units during parking. The Stall Warning annunciation is expected to read within the sample range of 42 to 52 units during cruise. The Thrust Reverser quantity display that differs from the expected state requires the First Officer to cross-check the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. If the Primary Electrical Bus is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

The Cargo Smoke Detection status message is expected to read within the sample range of 88 to 94 units during parking. During parking, the pilot flying should record the Cabin Pressure Controller annunciation once the checklist item is complete. During engine start, both pilots should cross-check the Auxiliary Power Unit annunciation when operating at a sample station without ground power. The Flight Management Computer selector position is expected to read within the sample range of 47 to 52 units during a turnaround. The Oxygen Distribution indication is expected to read within the sample range of 44 to 56 units during climb.

If the Hydraulic System B is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will cross-check any change in the Weather Radar advisory and advise the other pilot when operating at a sample station without ground power. The Autobrake Selector indication that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight.

16.10.3 Fuel Crossfeed Limits Display

Both pilots will cross-check any change in the Cargo Smoke Detection quantity display and advise the other pilot when the associated caution light remains illuminated. The Thrust Reverser switch position is expected to read within the sample range of 32 to 41 units during a turnaround. The Auxiliary Power Unit selector position is expected to read within the sample range of 94 to 98 units during engine start. The relief pilot will record any change in the Flap Position Indication selector position and advise the other pilot when operating at a sample station without ground power. The first officer will announce any change in the Bleed Air Supply annunciation and advise the other pilot when conditions permit.

The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments status message that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will monitor any change in the Standby Instruments advisory and advise the other pilot when the associated caution light remains illuminated. The captain will cross-check any change in the Autopilot Channel A switch position and advise the other pilot when the associated caution light remains illuminated.

- The Center Tank Pumps annunciation is expected to read within the sample range of 49 to 60 units during landing.
- If the Standby Instruments is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- The Standby Hydraulic indication is expected to read within the sample range of 83 to 88 units during takeoff.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During takeoff, both pilots should select the Brake Temperature Monitor indication unless directed otherwise by the Sample Operations Center.
- Refer to the related topic for additional sample context.

NOTE: During a maintenance-requested ground run, both pilots should monitor the Transponder selector position if a discrepancy is observed.

Condition	Sample value	Remarks
Auxiliary Power Unit indication	52 units	Advisory only
Standby Hydraulic indication	93 units	Monitor
Autopilot Channel A status message	65 units	Advisory only
Autopilot Channel B indication	66 units	Normal
Standby Instruments status message	53 units	Normal
Autobrake Selector selector position	73 units	Monitor
Auxiliary Power Unit selector position	65 units	Advisory only

NOTE: The Thrust Reverser indication that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. The Thrust Reverser quantity display that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval.

- The captain will record any change in the Standby Instruments advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- During climb, the pilot flying should brief the Autopilot Channel B advisory when the associated caution light remains illuminated.
- The Engine Anti-Ice selector position that differs from the expected state requires the First Officer to verify the condition before the next phase of flight.
- Refer to the related topic for additional sample context.

- This text is fictional and exists only to give the prototype realistic volume and structure.

The Autothrottle annunciation that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated. If the Hydraulic System A is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Transponder selector position and advise the other pilot before the next phase of flight. See 05.10.12 Wing Anti-Ice Crew Awareness.

16.10.4 Thrust Reverser Indications

If the Flap Position Indication is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Landing Gear Indication is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

NOTE: The Pack Temperature Control status message that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power.

The Landing Gear Indication annunciation that differs from the expected state requires both pilots to confirm the condition before the next phase of flight. The Flight Management Computer status message that differs from the expected state requires the Captain to record the condition before the next phase of flight. During an extended ground delay, the pilot flying should verify the Standby Hydraulic selector position when the associated caution light remains illuminated. The Standby Instruments quantity display is expected to read within the sample range of 24 to 29 units during climb. The pilot flying will verify any change in the Flap Position Indication quantity display and advise the other pilot once the checklist item is complete. The Fire Detection Loop annunciation is expected to read within the sample range of 35 to 42 units during a maintenance-requested ground run.

If the Thrust Reverser is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Transponder indication that differs from the expected state requires the First Officer to cross-check the condition when conditions permit. The captain will monitor any change in the Hydraulic System B switch position and advise the other pilot if a discrepancy is observed.

The Transponder indication that differs from the expected state requires both pilots to announce the condition when conditions permit. The Standby Hydraulic status message that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power. If the Transponder is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The captain will cross-check any change in the Fire Detection Loop quantity display and advise the other pilot once the checklist item is complete. The Standby Hydraulic status message is expected to read within the sample range of 79 to 90 units during landing. See 05.10.3 Autopilot Channel B Test.

CAUTION: The Oxygen Distribution annunciation is expected to read within the sample range of 24 to 36 units during a turnaround.

16.10.5 Bleed Air Supply Overview

If the Nosewheel Steering is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. During approach, the First Officer should announce the Fuel Crossfeed selector position if a discrepancy is observed. If the Oxygen Distribution is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Window Heat selector position is expected to read within the sample range of 71 to 78 units during engine start.

- Values in this manual are invented and must not be used for any operational purpose.
- During preflight, both pilots should verify the Standby Instruments advisory when operating at a sample station without ground power.

- If the Standby Hydraulic is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autopilot Channel B status message	16 units	Refer to related topic
Pack Temperature Control advisory	91 units	Refer to related topic
Engine Anti-Ice annunciation	18 units	Normal

Condition	Sample value	Remarks
Fuel Crossfeed quantity display	53 units	Normal
Brake Temperature Monitor status message	52 units	Advisory only
Autopilot Channel B indication	59 units	Normal

The Traffic Advisory Display quantity display is expected to read within the sample range of 95 to 98 units during landing. The first officer will record any change in the Hydraulic System B quantity display and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

- During takeoff, the pilot flying should announce the Autothrottle selector position when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- During an extended ground delay, the pilot flying should confirm the Cabin Pressure Controller switch position when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The Brake Temperature Monitor switch position is expected to read within the sample range of 35 to 43 units during a turnaround. The Fuel Crossfeed quantity display that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic indication that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

16.10.6 Primary Electrical Bus Test

The pilot flying will monitor any change in the Window Heat selector position and advise the other pilot when the associated caution light remains illuminated. The first officer will confirm any change in the Wing Anti-Ice status message and advise the other pilot when conditions permit. The Transponder advisory is expected to read within the sample range of 4 to 16 units during a turnaround. The Wing Anti-Ice annunciation is expected to read within the sample range of 96 to 107 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

The pilot monitoring will announce any change in the Nosewheel Steering advisory and advise the other pilot when operating at a sample station without ground power. The Probe Heat indication is expected to read within the sample range of 32 to 37 units during approach. During a maintenance-requested ground run, the Captain should announce the Landing Gear Indication status message unless directed otherwise by the Sample Operations Center. The pilot monitoring will select any change in the Oxygen Distribution annunciation and advise the other pilot when the associated caution light remains illuminated. The Transponder selector position is expected to read within the sample range of 98 to 105 units during a maintenance-requested ground run. The pilot flying will brief any change in the Auxiliary Power Unit indication and advise the other pilot when operating at a sample station without ground power.

The Nosewheel Steering switch position that differs from the expected state requires the Captain to verify the condition before the next phase of flight. The first officer will record any change in the Weather Radar quantity display

and advise the other pilot before the next phase of flight. During descent, both pilots should select the Cargo Smoke Detection quantity display if the indication does not stabilize within the sample interval.

NOTE: During a maintenance-requested ground run, the pilot flying should brief the Traffic Advisory Display switch position when the associated caution light remains illuminated.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Cockpit Voice Recorder quantity display that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight.

If the Oxygen Distribution is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The captain will confirm any change in the Hydraulic System B status message and advise the other pilot once the checklist item is complete. If the Probe Heat is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. See 05.50.12 Autothrottle Power Sources.

NOTE: The relief pilot will announce any change in the Flight Management Computer quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

- During preflight, the pilot monitoring should monitor the Primary Electrical Bus indication before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Transponder advisory that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval.
- If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- The first officer will brief any change in the Hydraulic System A advisory and advise the other pilot before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.

16.10.7 Window Heat Status Messages

The Cargo Smoke Detection quantity display is expected to read within the sample range of 50 to 58 units during cruise. If the Primary Electrical Bus is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Autopilot Channel A advisory that differs from the expected state requires both pilots to confirm the condition when conditions permit. During approach, the pilot flying should monitor the Probe Heat status message once the checklist item is complete. The Autopilot Channel A status message that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power. The relief pilot will monitor any change in the Landing Gear Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The captain will brief any change in the Speedbrake Handle annunciation and advise the other pilot when conditions permit.
- The Center Tank Pumps selector position that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval.
- The Standby Hydraulic annunciation that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed.
- The captain will record any change in the Speedbrake Handle advisory and advise the other pilot when operating at a sample station without ground power.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, the pilot monitoring should confirm the Wing Anti-Ice status message if a discrepancy is observed.

CAUTION: The Flap Position Indication switch position that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Transponder selector position	97 units	Refer to related topic
Pack Temperature Control switch position	19 units	Monitor
Speedbrake Handle quantity display	36 units	Refer to related topic
Cockpit Voice Recorder status message	15 units	Refer to related topic
Weather Radar status message	27 units	Monitor
Bleed Air Supply switch position	22 units	Normal

CAUTION: If the Hydraulic System B is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: If the Cockpit Voice Recorder is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

If the Autothrottle is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

- Refer to the related topic for additional sample context.
- The Primary Electrical Bus selector position that differs from the expected state requires both pilots to select the condition if a discrepancy is observed.
- If the Ground Proximity Monitor is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.
- During a diversion, both pilots should cross-check the Landing Gear Indication switch position if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.
- The Standby Hydraulic status message that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval.

16.10.8 Transponder Status Messages

Values in this manual are invented and must not be used for any operational purpose. Both pilots will monitor any change in the Engine Anti-Ice selector position and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Oxygen Distribution quantity display that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. During takeoff, the First Officer should verify the Cabin Pressure Controller status message when the associated caution light remains illuminated.

The Bleed Air Supply quantity display is expected to read within the sample range of 79 to 89 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. If the Standby Hydraulic is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Stall Warning status message that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. Refer to the related topic for additional sample context.

The Autobrake Selector quantity display that differs from the expected state requires the First Officer to select the condition when conditions permit. The Auxiliary Power Unit status message is expected to read within the sample

range of 55 to 61 units during taxi. The pilot monitoring will record any change in the Cockpit Voice Recorder status message and advise the other pilot when conditions permit. The Autopilot Channel A annunciation that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated. During takeoff, the pilot flying should monitor the Cabin Pressure Controller indication when conditions permit. The captain will announce any change in the Nosewheel Steering switch position and advise the other pilot when conditions permit.

CAUTION: During landing, the First Officer should monitor the Nosewheel Steering indication once the checklist item is complete.

- The Transponder quantity display is expected to read within the sample range of 12 to 17 units during takeoff.
- The pilot flying will confirm any change in the Cabin Pressure Controller annunciation and advise the other pilot when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Autothrottle quantity display that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight.
- Values in this manual are invented and must not be used for any operational purpose.
- The relief pilot will monitor any change in the Bleed Air Supply status message and advise the other pilot when the associated caution light remains illuminated.

The captain will select any change in the Wing Anti-Ice selector position and advise the other pilot once the checklist item is complete. The Bleed Air Supply indication is expected to read within the sample range of 93 to 105 units during landing. The Center Tank Pumps indication is expected to read within the sample range of 46 to 52 units during parking. If the Primary Electrical Bus is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

The Cabin Pressure Controller advisory is expected to read within the sample range of 32 to 42 units during climb. If the Probe Heat is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Probe Heat annunciation is expected to read within the sample range of 20 to 32 units during a diversion. The Weather Radar switch position is expected to read within the sample range of 16 to 20 units during descent. During preflight, both pilots should cross-check the Flap Position Indication switch position when operating at a sample station without ground power. If the Probe Heat is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

- The Primary Electrical Bus switch position that differs from the expected state requires the pilot flying to select the condition when conditions permit.
- The Nosewheel Steering advisory that differs from the expected state requires the First Officer to verify the condition when conditions permit.
- If the Cockpit Voice Recorder is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The Autopilot Channel A annunciation is expected to read within the sample range of 37 to 47 units during descent.
- Refer to the related topic for additional sample context.

16.10.9 Autobrake Selector Interfaces

The Traffic Advisory Display selector position is expected to read within the sample range of 4 to 7 units during landing. If the Bleed Air Supply is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed switch position that differs from the expected state requires the Captain to monitor the condition when

operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Speedbrake Handle status message	30 units	Monitor
Standby Instruments annunciation	9 units	Monitor
Probe Heat switch position	91 units	Monitor
Autobrake Selector selector position	5 units	Normal
Nosewheel Steering quantity display	89 units	Normal

If the Hydraulic System B is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Speedbrake Handle selector position is expected to read within the sample range of 22 to 25 units during approach. Refer to the related topic for additional sample context.

The pilot monitoring will select any change in the Standby Instruments indication and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will select any change in the Speedbrake Handle quantity display and advise the other pilot when conditions permit. Both pilots will announce any change in the Flap Position Indication quantity display and advise the other pilot when operating at a sample station without ground power.

If the Autobrake Selector is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The captain will verify any change in the Center Tank Pumps advisory and advise the other pilot when the associated caution light remains illuminated. The captain will brief any change in the Hydraulic System B advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

16.10.10 Pack Temperature Control Status Messages

The first officer will monitor any change in the Primary Electrical Bus indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Brake Temperature Monitor advisory that differs from the expected state requires the Captain to select the condition before the next phase of flight. The pilot monitoring will verify any change in the Probe Heat advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will select any change in the Auxiliary Power Unit quantity display and advise the other pilot once the checklist item is complete.

If the Traffic Advisory Display is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During approach, the pilot flying should monitor the Standby Instruments quantity display when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The Cockpit Voice Recorder advisory is expected to read within the sample range of 29 to 41 units during cruise. If the Brake Temperature Monitor is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The Autobrake Selector status message is expected to read within the sample range of 76 to 85 units during preflight. During climb, the relief pilot should verify the Brake Temperature Monitor switch position unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Flap Position Indication advisory is expected to read within the sample range of 94 to 104 units during engine start. If the Stall Warning is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

The Engine Anti-Ice status message that differs from the expected state requires both pilots to select the condition when conditions permit. If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after

the First Officer has reviewed the associated sample guidance. During a maintenance-requested ground run, the Captain should confirm the Oxygen Distribution status message if a discrepancy is observed. The pilot monitoring will verify any change in the Window Heat switch position and advise the other pilot before the next phase of flight.

NOTE: Both pilots will record any change in the Cargo Smoke Detection indication and advise the other pilot if a discrepancy is observed. Both pilots will verify any change in the Standby Hydraulic advisory and advise the other pilot when the associated caution light remains illuminated.

16.10.11 Autothrottle Limits Display

The captain will announce any change in the Autopilot Channel B selector position and advise the other pilot when the associated caution light remains illuminated. During a turnaround, the relief pilot should brief the Autopilot Channel A quantity display when conditions permit. During taxi, the relief pilot should verify the Autothrottle advisory when conditions permit. Refer to the related topic for additional sample context.

During a turnaround, the relief pilot should announce the Thrust Reverser annunciation when conditions permit. During a turnaround, the relief pilot should confirm the Flight Management Computer indication unless directed otherwise by the Sample Operations Center. During approach, the Captain should cross-check the Autopilot Channel B advisory if a discrepancy is observed. During parking, the First Officer should brief the Auxiliary Power Unit selector position when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autobrake Selector advisory	60 units	Monitor
Primary Electrical Bus annunciation	30 units	Advisory only
Cargo Smoke Detection annunciation	27 units	Refer to related topic
Oxygen Distribution advisory	2 units	Normal
Standby Instruments quantity display	26 units	Monitor

NOTE: The Nosewheel Steering quantity display is expected to read within the sample range of 82 to 93 units during a diversion. If the Landing Gear Indication is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

During climb, the pilot monitoring should record the Transponder quantity display if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the pilot flying should verify the Fire Detection Loop selector position when the associated caution light remains illuminated. The relief pilot will monitor any change in the Center Tank Pumps indication and advise the other pilot if a discrepancy is observed.

16.10.12 Autothrottle Crew Awareness

The Engine Anti-Ice indication that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. The Flap Position Indication selector position is expected to read within the sample range of 81 to 85 units during takeoff. During takeoff, both pilots should brief the Cabin Pressure Controller status message before the next phase of flight.

Condition	Sample value	Remarks
Center Tank Pumps status message	78 units	Monitor
Autothrottle status message	91 units	Monitor
Fuel Crossfeed quantity display	72 units	Monitor
Weather Radar annunciation	36 units	Normal
Auxiliary Power Unit annunciation	72 units	Refer to related topic
Engine Anti-Ice indication	70 units	Monitor

Standby Instruments selector position	53 units	Refer to related topic
---------------------------------------	----------	------------------------

- If the Cargo Smoke Detection is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- The Weather Radar status message that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval.
- If the Cabin Pressure Controller is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- The first officer will cross-check any change in the Wing Anti-Ice selector position and advise the other pilot before the next phase of flight.
- The Autothrottle quantity display is expected to read within the sample range of 74 to 82 units during approach.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The pilot flying will select any change in the Hydraulic System B status message and advise the other pilot unless directed otherwise by the Sample Operations Center. During a diversion, the Captain should record the Speedbrake Handle selector position unless directed otherwise by the Sample Operations Center. If the Landing Gear Indication is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The Center Tank Pumps indication that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval. During approach, the Captain should confirm the Fuel Crossfeed quantity display once the checklist item is complete.

Condition	Sample value	Remarks
Autobrake Selector switch position	19 units	Monitor
Autobrake Selector advisory	61 units	Normal
Bleed Air Supply status message	73 units	Advisory only
Cargo Smoke Detection quantity display	93 units	Monitor
Cargo Smoke Detection annunciation	13 units	Advisory only
Speedbrake Handle status message	2 units	Monitor
Primary Electrical Bus selector position	89 units	Normal

16.10.13 Ground Proximity Monitor Test

The Hydraulic System A switch position that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. Both pilots will cross-check any change in the Fire Detection Loop status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Landing Gear Indication quantity display that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete. The Center Tank Pumps indication that differs from the expected state requires the pilot monitoring to monitor the condition when conditions permit.

- The relief pilot will monitor any change in the Window Heat indication and advise the other pilot before the next phase of flight.
- The Engine Anti-Ice annunciation that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.
- During cruise, the relief pilot should select the Center Tank Pumps selector position before the next phase of flight.
- The pilot monitoring will brief any change in the Primary Electrical Bus indication and advise the other pilot if a discrepancy is observed.

CAUTION: If the Autopilot Channel B is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

If the Engine Anti-Ice is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Bleed Air Supply selector position is expected to read within the sample range of 56 to 59 units during cruise. If the Autobrake Selector is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. Both pilots will announce any change in the Speedbrake Handle quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Hydraulic System B advisory	82 units	Advisory only
Hydraulic System A annunciation	37 units	Refer to related topic
Stall Warning advisory	53 units	Advisory only
Fire Detection Loop selector position	41 units	Refer to related topic
Fire Detection Loop switch position	69 units	Normal

NOTE: The captain will brief any change in the Standby Hydraulic annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Engine Anti-Ice is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

- Refer to the related topic for additional sample context.
- The first officer will announce any change in the Transponder selector position and advise the other pilot before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Values in this manual are invented and must not be used for any operational purpose.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During landing, the pilot monitoring should select the Center Tank Pumps indication when operating at a sample station without ground power.
- The Standby Hydraulic status message is expected to read within the sample range of 64 to 76 units during a turnaround.
- The Speedbrake Handle selector position that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- During preflight, the pilot flying should brief the Transponder annunciation unless directed otherwise by the Sample Operations Center.

16.10.14 Fuel Crossfeed Overview

During taxi, both pilots should confirm the Landing Gear Indication selector position if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. If the Flight Management Computer is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The pilot monitoring will cross-check any change in the Standby Hydraulic switch position and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: The Wing Anti-Ice annunciation is expected to read within the sample range of 76 to 81 units during taxi. During engine start, the pilot flying should brief the Pack Temperature Control advisory when operating at a sample station without ground power.

If the Transponder is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The pilot flying will brief any change in the Autothrottle indication and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. If the Flight Management Computer is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Standby Hydraulic indication and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: If the Brake Temperature Monitor is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

The pilot monitoring will monitor any change in the Engine Anti-Ice quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. During descent, the Captain should brief the Standby Hydraulic indication if a discrepancy is observed. Refer to the related topic for additional sample context. If the Autopilot Channel B is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Hydraulic System A switch position	4 units	Advisory only
Flight Management Computer switch position	92 units	Normal
Wing Anti-Ice selector position	98 units	Refer to related topic

The Brake Temperature Monitor quantity display is expected to read within the sample range of 40 to 47 units during climb. If the Thrust Reverser is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Fuel Crossfeed quantity display is expected to read within the sample range of 95 to 102 units during a maintenance-requested ground run.

16.10.15 Autothrottle Overview

If the Probe Heat is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Traffic Advisory Display selector position that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Autopilot Channel A switch position	55 units	Monitor
Cockpit Voice Recorder switch position	15 units	Normal
Pack Temperature Control advisory	25 units	Refer to related topic
Probe Heat indication	83 units	Advisory only
Speedbrake Handle indication	7 units	Advisory only
Nosewheel Steering advisory	65 units	Refer to related topic
Autopilot Channel A advisory	15 units	Normal

The captain will brief any change in the Probe Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The Oxygen Distribution quantity display that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power.

During parking, the pilot monitoring should cross-check the Fuel Crossfeed status message when conditions permit. If the Fire Detection Loop is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector status message is expected to read within the sample range of 48 to 55 units during approach. During taxi, the First Officer should announce the Stall Warning indication when the associated caution light remains illuminated. The Fuel Crossfeed annunciation is expected to read within the sample range of 11 to 20 units during a maintenance-requested ground run. The Cabin Pressure Controller advisory is expected to read within the sample range of 5 to 17 units during an extended ground delay.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- During a maintenance-requested ground run, the First Officer should verify the Standby Instruments annunciation once the checklist item is complete.
- The Hydraulic System A quantity display is expected to read within the sample range of 41 to 53 units during an extended ground delay.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Thrust Reverser is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

The Cargo Smoke Detection status message that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. If the Engine Anti-Ice is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Bleed Air Supply quantity display that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. If the Stall Warning is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

16.20 Controls and Indicators

16.20.1 Standby Hydraulic Reset Guidance

This text is fictional and exists only to give the prototype realistic volume and structure. The Thrust Reverser switch position that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval. The Stall Warning switch position is expected to read within the sample range of 12 to 15 units during climb. If the Autothrottle is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

NOTE: The Cargo Smoke Detection switch position that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. The first officer will select any change in the Bleed Air Supply indication and advise the other pilot when the associated caution light remains illuminated.

During cruise, the pilot flying should record the Brake Temperature Monitor annunciation once the checklist item is complete. The Bleed Air Supply status message is expected to read within the sample range of 75 to 84 units during parking. The pilot monitoring will cross-check any change in the Cabin Pressure Controller status message and advise the other pilot before the next phase of flight. The Engine Anti-Ice selector position is expected to read within the sample range of 63 to 71 units during an extended ground delay.

During preflight, the First Officer should confirm the Probe Heat quantity display if the indication does not stabilize within the sample interval. During landing, the pilot monitoring should select the Window Heat quantity display if a discrepancy is observed. The pilot flying will announce any change in the Wing Anti-Ice quantity display and advise the other pilot when conditions permit. The Pack Temperature Control annunciation is expected to read within the sample range of 73 to 84 units during landing. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. During preflight, both pilots should verify the Cargo Smoke Detection advisory before the next phase of flight. If the Speedbrake Handle is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

If the Probe Heat is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. During taxi, both pilots should brief the Window Heat switch position if the indication does not stabilize within the sample interval. The pilot flying will select any change in the Cargo Smoke Detection advisory and advise the other pilot if a discrepancy is observed. If the Autothrottle is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Auxiliary Power Unit indication that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power.

The Wing Anti-Ice advisory that differs from the expected state requires the pilot monitoring to select the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. See 07.10.4 Autopilot Channel A Crew Awareness.

Condition	Sample value	Remarks
Bleed Air Supply advisory	86 units	Refer to related topic
Cabin Pressure Controller advisory	29 units	Refer to related topic
Speedbrake Handle status message	6 units	Refer to related topic
Window Heat annunciation	44 units	Monitor
Brake Temperature Monitor advisory	95 units	Monitor
Fire Detection Loop advisory	67 units	Monitor
Stall Warning indication	24 units	Normal

16.20.2 Cockpit Voice Recorder Indications

During descent, the Captain should announce the Engine Anti-Ice annunciation when the associated caution light remains illuminated. Refer to the related topic for additional sample context. During an extended ground delay, the First Officer should record the Autobrake Selector annunciation when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

The captain will monitor any change in the Brake Temperature Monitor indication and advise the other pilot if a discrepancy is observed. The captain will select any change in the Pack Temperature Control switch position and advise the other pilot before the next phase of flight. The Probe Heat advisory that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval. The Brake Temperature Monitor selector position is expected to read within the sample range of 78 to 82 units during approach. The captain will brief any change in the Weather Radar advisory and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Primary Electrical Bus status message	87 units	Refer to related topic
Cargo Smoke Detection advisory	84 units	Normal
Window Heat quantity display	60 units	Normal
Engine Anti-Ice status message	69 units	Monitor
Fire Detection Loop indication	80 units	Normal
Auxiliary Power Unit annunciation	61 units	Normal
Standby Hydraulic quantity display	67 units	Advisory only

The Standby Hydraulic indication is expected to read within the sample range of 82 to 87 units during preflight. Values in this manual are invented and must not be used for any operational purpose. During a diversion, the First Officer should record the Bleed Air Supply indication if a discrepancy is observed.

NOTE: The Ground Proximity Monitor annunciation that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.

- The Wing Anti-Ice quantity display is expected to read within the sample range of 66 to 70 units during takeoff.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Flight Management Computer selector position is expected to read within the sample range of 89 to 99 units during engine start.
- The Bleed Air Supply quantity display is expected to read within the sample range of 8 to 20 units during landing.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

16.20.3 Probe Heat Crew Awareness

The Stall Warning quantity display is expected to read within the sample range of 2 to 13 units during a maintenance-requested ground run. The first officer will select any change in the Pack Temperature Control indication and advise the other pilot when conditions permit. The Center Tank Pumps status message that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight. The pilot monitoring will select any change in the Window Heat annunciation and advise the other pilot if a discrepancy is observed.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will brief any change in the Primary Electrical Bus advisory and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Weather Radar annunciation	52 units	Monitor
Transponder indication	49 units	Normal
Standby Hydraulic advisory	7 units	Monitor
Pack Temperature Control status message	19 units	Advisory only
Brake Temperature Monitor switch position	47 units	Advisory only
Fire Detection Loop status message	14 units	Monitor
Autobrake Selector selector position	51 units	Advisory only

If the Thrust Reverser is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The captain will brief any change in the Ground Proximity Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The pilot flying will confirm any change in the Thrust Reverser annunciation and advise the other pilot once the checklist item is complete. The Autopilot Channel A quantity display that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit. During takeoff, the pilot monitoring should cross-check the Autopilot Channel B quantity display when the associated caution light remains illuminated. See 15.10.2 Primary Electrical Bus Normal Operation.

- During descent, the pilot monitoring should verify the Pack Temperature Control quantity display when conditions permit.
- Both pilots will record any change in the Probe Heat quantity display and advise the other pilot when operating at a sample station without ground power.

- The Primary Electrical Bus status message that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed.

CAUTION: The pilot monitoring will announce any change in the Probe Heat switch position and advise the other pilot when operating at a sample station without ground power. Both pilots will verify any change in the Fire Detection Loop advisory and advise the other pilot when operating at a sample station without ground power.

16.20.4 Weather Radar Reset Guidance

The Bleed Air Supply selector position is expected to read within the sample range of 89 to 98 units during preflight. The Thrust Reverser status message is expected to read within the sample range of 30 to 34 units during a diversion. The relief pilot will monitor any change in the Probe Heat annunciation and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The Fire Detection Loop selector position that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power.

If the Cargo Smoke Detection is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The pilot monitoring will cross-check any change in the Speedbrake Handle indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The pilot monitoring will monitor any change in the Pack Temperature Control annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. During an extended ground delay, both pilots should announce the Standby Hydraulic advisory when the associated caution light remains illuminated. If the Bleed Air Supply is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

If the Flap Position Indication is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The first officer will monitor any change in the Window Heat switch position and advise the other pilot when the associated caution light remains illuminated. The Center Tank Pumps switch position is expected to read within the sample range of 13 to 25 units during taxi.

The captain will brief any change in the Window Heat switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. If the Landing Gear Indication is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Wing Anti-Ice status message is expected to read within the sample range of 84 to 96 units during engine start. The Center Tank Pumps advisory that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Fuel Crossfeed indication is expected to read within the sample range of 34 to 41 units during a maintenance-requested ground run.
- The Auxiliary Power Unit selector position that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated.
- The Autobrake Selector indication that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit.
- If the Transponder is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.

The Autopilot Channel A switch position is expected to read within the sample range of 84 to 95 units during takeoff. The pilot flying will brief any change in the Cabin Pressure Controller advisory and advise the other pilot once the checklist item is complete. During descent, the relief pilot should monitor the Center Tank Pumps advisory once the checklist item is complete. During taxi, both pilots should monitor the Standby Hydraulic annunciation before the next

phase of flight. The Autopilot Channel A advisory is expected to read within the sample range of 34 to 38 units during parking.

16.20.5 Speedbrake Handle Power Sources

The Cabin Pressure Controller indication is expected to read within the sample range of 62 to 67 units during takeoff. The Wing Anti-Ice selector position is expected to read within the sample range of 73 to 85 units during a maintenance-requested ground run. The Auxiliary Power Unit switch position that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit.

- If the Cargo Smoke Detection is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- During an extended ground delay, both pilots should monitor the Autopilot Channel A quantity display if a discrepancy is observed.
- Refer to the related topic for additional sample context.
- Values in this manual are invented and must not be used for any operational purpose.
- During approach, the First Officer should record the Weather Radar indication when operating at a sample station without ground power.

CAUTION: During descent, the First Officer should monitor the Standby Hydraulic switch position before the next phase of flight.

- If the Oxygen Distribution is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.
- During a turnaround, the Captain should monitor the Probe Heat indication unless directed otherwise by the Sample Operations Center.
- If the Wing Anti-Ice is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- During parking, both pilots should select the Wing Anti-Ice selector position when operating at a sample station without ground power.

The Transponder selector position that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. The Fuel Crossfeed advisory that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. The pilot flying will confirm any change in the Traffic Advisory Display selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Standby Hydraulic is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication annunciation that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete. During a diversion, the First Officer should monitor the Cabin Pressure Controller advisory if a discrepancy is observed. See 06.30.13 Standby Instruments Test.

CAUTION: The Oxygen Distribution switch position is expected to read within the sample range of 87 to 99 units during climb. The Window Heat selector position is expected to read within the sample range of 64 to 70 units during climb.

Condition	Sample value	Remarks
Autopilot Channel B annunciation	64 units	Refer to related topic
Bleed Air Supply quantity display	10 units	Normal
Center Tank Pumps indication	47 units	Advisory only
Standby Hydraulic selector position	25 units	Monitor

Fire Detection Loop selector position	64 units	Refer to related topic
Engine Anti-Ice quantity display	91 units	Refer to related topic

NOTE: Refer to the related topic for additional sample context.

16.20.6 Stall Warning Normal Operation

If the Standby Instruments is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The captain will confirm any change in the Weather Radar status message and advise the other pilot if a discrepancy is observed. If the Probe Heat is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

- The Brake Temperature Monitor annunciation is expected to read within the sample range of 78 to 85 units during a maintenance-requested ground run.
- Both pilots will monitor any change in the Flap Position Indication selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- The relief pilot will brief any change in the Brake Temperature Monitor indication and advise the other pilot when the associated caution light remains illuminated.
- The captain will announce any change in the Autobrake Selector selector position and advise the other pilot when operating at a sample station without ground power.
- The captain will confirm any change in the Center Tank Pumps switch position and advise the other pilot once the checklist item is complete.
- If the Transponder is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

The Flight Management Computer annunciation is expected to read within the sample range of 59 to 69 units during descent. If the Autopilot Channel B is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. During approach, the Captain should monitor the Cargo Smoke Detection advisory when the associated caution light remains illuminated. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

During preflight, the relief pilot should cross-check the Ground Proximity Monitor indication unless directed otherwise by the Sample Operations Center. The Standby Instruments annunciation that differs from the expected state requires both pilots to confirm the condition when conditions permit. The Pack Temperature Control switch position is expected to read within the sample range of 95 to 102 units during a maintenance-requested ground run.

The Weather Radar annunciation is expected to read within the sample range of 53 to 63 units during preflight. During engine start, the pilot monitoring should announce the Autopilot Channel A switch position before the next phase of flight. The Probe Heat switch position is expected to read within the sample range of 67 to 78 units during engine start. Refer to the related topic for additional sample context. The Bleed Air Supply switch position that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval.

The Flight Management Computer selector position that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. The Hydraulic System B indication is expected to read within the sample range of 15 to 20 units during a turnaround. Refer to the related topic for additional sample context. If the Transponder is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Cockpit Voice Recorder annunciation that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center. See 13.40.13 Probe Heat Crew Awareness.

16.20.7 Landing Gear Indication Indications

The Autothrottle selector position is expected to read within the sample range of 52 to 55 units during cruise. Values in this manual are invented and must not be used for any operational purpose. If the Hydraulic System A is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The captain will confirm any change in the Primary Electrical Bus status message and advise the other pilot when conditions permit. Refer to the related topic for additional sample context.

The Ground Proximity Monitor switch position that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. If the Weather Radar is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

- The first officer will monitor any change in the Wing Anti-Ice indication and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Fuel Crossfeed is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- The Speedbrake Handle quantity display is expected to read within the sample range of 71 to 83 units during climb.
- The Nosewheel Steering status message is expected to read within the sample range of 79 to 88 units during taxi.
- If the Autopilot Channel B is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Cargo Smoke Detection indication	31 units	Refer to related topic
Wing Anti-Ice quantity display	89 units	Monitor
Transponder quantity display	42 units	Normal
Cabin Pressure Controller switch position	13 units	Monitor
Auxiliary Power Unit status message	92 units	Normal

- During taxi, both pilots should brief the Bleed Air Supply advisory if a discrepancy is observed.
- If the Transponder is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

16.20.8 Center Tank Pumps Status Messages

If the Stall Warning is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Autobrake Selector indication is expected to read within the sample range of 45 to 48 units during parking. The pilot flying will monitor any change in the Auxiliary Power Unit switch position and advise the other pilot if a discrepancy is observed. The Oxygen Distribution advisory that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

During a diversion, the First Officer should cross-check the Stall Warning status message when the associated caution light remains illuminated. The Autopilot Channel A advisory that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power. The Window Heat

indication is expected to read within the sample range of 80 to 92 units during a turnaround. During landing, the Captain should announce the Primary Electrical Bus annunciation when the associated caution light remains illuminated. If the Nosewheel Steering is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Instruments status message	55 units	Advisory only
Auxiliary Power Unit switch position	7 units	Refer to related topic
Nosewheel Steering indication	71 units	Normal
Stall Warning advisory	36 units	Advisory only
Center Tank Pumps advisory	30 units	Normal
Landing Gear Indication quantity display	21 units	Refer to related topic

NOTE: During a diversion, both pilots should cross-check the Engine Anti-Ice annunciation if the indication does not stabilize within the sample interval. The Cargo Smoke Detection advisory that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight.

The Hydraulic System A advisory that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete. The Center Tank Pumps quantity display is expected to read within the sample range of 22 to 29 units during an extended ground delay. The Hydraulic System A switch position that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. See 07.10.4 Autopilot Channel A Crew Awareness.

NOTE: Refer to the related topic for additional sample context. During a diversion, the pilot monitoring should record the Pack Temperature Control status message before the next phase of flight.

NOTE: The Autothrottle switch position that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete.

- During descent, the relief pilot should monitor the Probe Heat indication when operating at a sample station without ground power.
- The Center Tank Pumps selector position that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Standby Hydraulic advisory that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power.
- During takeoff, the Captain should brief the Window Heat indication unless directed otherwise by the Sample Operations Center.

16.20.9 Autopilot Channel B Normal Operation

If the Bleed Air Supply is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Hydraulic System B status message that differs from the expected state requires the pilot flying to record the condition before the next phase of flight. If the Hydraulic System B is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. Both pilots will select any change in the Hydraulic System B advisory and advise the other pilot if a discrepancy is observed. The Oxygen Distribution quantity display that differs from the expected state requires the First Officer to confirm the condition when conditions permit. The Speedbrake Handle switch position is expected to read within the sample range of 58 to 68 units during parking.

CAUTION: The Autopilot Channel B status message is expected to read within the sample range of 22 to 27 units during taxi.

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. During takeoff, the First Officer should record the Engine Anti-Ice switch position if the indication does not stabilize within the sample interval. If the Autopilot Channel A is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. If the Transponder is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

- The Autothrottle status message is expected to read within the sample range of 23 to 28 units during a turnaround.
- During preflight, the relief pilot should announce the Center Tank Pumps indication when conditions permit.
- During approach, the pilot monitoring should record the Nosewheel Steering indication if the indication does not stabilize within the sample interval.
- If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- During a turnaround, the Captain should monitor the Autobrake Selector selector position if a discrepancy is observed.
- The Transponder quantity display that differs from the expected state requires the relief pilot to record the condition before the next phase of flight.

The Cockpit Voice Recorder selector position is expected to read within the sample range of 24 to 35 units during takeoff. The Transponder selector position is expected to read within the sample range of 71 to 78 units during a turnaround. This text is fictional and exists only to give the prototype realistic volume and structure. If the Window Heat is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. If the Pack Temperature Control is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Autopilot Channel A indication that differs from the expected state requires the Captain to announce the condition when conditions permit.

16.20.10 Brake Temperature Monitor Indications

This text is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop quantity display is expected to read within the sample range of 45 to 52 units during a turnaround. The Standby Instruments indication that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The Bleed Air Supply quantity display is expected to read within the sample range of 85 to 94 units during a maintenance-requested ground run. During engine start, the relief pilot should confirm the Fuel Crossfeed indication when the associated caution light remains illuminated.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will monitor any change in the Primary Electrical Bus quantity display and advise the other pilot when the associated caution light remains illuminated. If the Autothrottle is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The pilot flying will confirm any change in the Auxiliary Power Unit switch position and advise the other pilot if a discrepancy is observed.

- During engine start, the pilot flying should confirm the Fire Detection Loop status message if a discrepancy is observed.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Probe Heat is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.
- During preflight, the First Officer should monitor the Cabin Pressure Controller advisory unless directed otherwise by the Sample Operations Center.
- The Hydraulic System B switch position that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power.

16.20.11 Nosewheel Steering Limits Display

If the Landing Gear Indication is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Standby Hydraulic switch position that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. If the Center Tank Pumps is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The captain will brief any change in the Weather Radar quantity display and advise the other pilot when conditions permit. The Stall Warning annunciation that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed.

- The Autothrottle advisory that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power.
- The Fuel Crossfeed status message is expected to read within the sample range of 63 to 69 units during preflight.
- The wording here is placeholder content shaped like a procedure, not a procedure.

During cruise, the relief pilot should monitor the Cockpit Voice Recorder annunciation when conditions permit. If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. During preflight, the pilot monitoring should brief the Bleed Air Supply indication if the indication does not stabilize within the sample interval. The Hydraulic System A advisory is expected to read within the sample range of 32 to 38 units during preflight. The Fire Detection Loop switch position is expected to read within the sample range of 62 to 72 units during a turnaround.

CAUTION: The Auxiliary Power Unit selector position is expected to read within the sample range of 2 to 8 units during parking.

The pilot flying will brief any change in the Probe Heat advisory and advise the other pilot if a discrepancy is observed. During landing, both pilots should verify the Hydraulic System B advisory before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

16.20.12 Stall Warning Overview

The Transponder switch position that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. During an extended ground delay, the pilot flying should monitor the Brake Temperature Monitor annunciation when operating at a sample station without ground power. During climb, the pilot flying should brief the Hydraulic System A status message if a discrepancy is observed. During descent, both pilots should cross-check the Fuel Crossfeed quantity display when operating at a sample station without ground power.

CAUTION: The Autobrake Selector switch position that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center.

- The relief pilot will record any change in the Window Heat selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During climb, the relief pilot should announce the Stall Warning annunciation when the associated caution light remains illuminated.

- The Flap Position Indication advisory is expected to read within the sample range of 39 to 46 units during a diversion.

NOTE: During an extended ground delay, the Captain should monitor the Weather Radar selector position when operating at a sample station without ground power. The Landing Gear Indication quantity display that differs from the expected state requires the First Officer to cross-check the condition when conditions permit.

The Stall Warning annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. During a turnaround, the pilot monitoring should cross-check the Hydraulic System A quantity display if the indication does not stabilize within the sample interval. During cruise, the Captain should cross-check the Weather Radar indication once the checklist item is complete. If the Nosewheel Steering is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

The Stall Warning quantity display is expected to read within the sample range of 6 to 18 units during a maintenance-requested ground run. The Pack Temperature Control indication that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete. The Primary Electrical Bus annunciation that differs from the expected state requires the relief pilot to verify the condition once the checklist item is complete. The Autopilot Channel A annunciation is expected to read within the sample range of 95 to 102 units during landing. During a maintenance-requested ground run, the pilot monitoring should brief the Primary Electrical Bus annunciation when conditions permit.

The Weather Radar status message is expected to read within the sample range of 18 to 25 units during cruise. The Fuel Crossfeed quantity display that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval. The Oxygen Distribution advisory is expected to read within the sample range of 78 to 89 units during climb.

- If the Primary Electrical Bus is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- During an extended ground delay, the Captain should announce the Thrust Reverser quantity display when the associated caution light remains illuminated.
- During cruise, the Captain should verify the Landing Gear Indication status message when operating at a sample station without ground power.
- If the Engine Anti-Ice is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- The Autopilot Channel A switch position that differs from the expected state requires the First Officer to monitor the condition when conditions permit.
- The relief pilot will verify any change in the Cargo Smoke Detection advisory and advise the other pilot before the next phase of flight.
- If the Probe Heat is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The wording here is placeholder content shaped like a procedure, not a procedure.

16.20.13 Stall Warning Normal Operation

During takeoff, the First Officer should verify the Weather Radar advisory when the associated caution light remains illuminated. If the Engine Anti-Ice is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

- The first officer will record any change in the Brake Temperature Monitor quantity display and advise the other pilot if a discrepancy is observed.
- The Standby Hydraulic annunciation that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight.
- During an extended ground delay, the pilot monitoring should cross-check the Flap Position Indication switch position unless directed otherwise by the Sample Operations Center.

The pilot flying will verify any change in the Hydraulic System B indication and advise the other pilot when conditions permit. If the Fire Detection Loop is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The pilot flying will verify any change in the Flap Position Indication status message and advise the other pilot when operating at a sample station without ground power. The Ground Proximity Monitor quantity display that differs from the expected state requires the First Officer to select the condition when conditions permit. The captain will announce any change in the Autopilot Channel A status message and advise the other pilot once the checklist item is complete.

The Ground Proximity Monitor selector position is expected to read within the sample range of 38 to 44 units during a turnaround. The pilot flying will record any change in the Fire Detection Loop status message and advise the other pilot when operating at a sample station without ground power. The Standby Hydraulic annunciation that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power. During takeoff, the pilot flying should brief the Autobrake Selector selector position before the next phase of flight.

Condition	Sample value	Remarks
Center Tank Pumps quantity display	47 units	Monitor
Bleed Air Supply status message	27 units	Advisory only
Cargo Smoke Detection quantity display	4 units	Normal
Ground Proximity Monitor selector position	17 units	Normal
Stall Warning status message	41 units	Monitor
Fire Detection Loop quantity display	73 units	Advisory only
Cargo Smoke Detection status message	91 units	Refer to related topic

CAUTION: The Traffic Advisory Display status message is expected to read within the sample range of 45 to 53 units during taxi. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Stall Warning annunciation	63 units	Normal
Nosewheel Steering switch position	25 units	Refer to related topic
Autothrottle quantity display	24 units	Normal
Nosewheel Steering switch position	14 units	Advisory only

Condition	Sample value	Remarks
Flight Management Computer selector position	18 units	Advisory only
Thrust Reverser advisory	39 units	Monitor
Autopilot Channel B quantity display	32 units	Advisory only
Standby Instruments selector position	44 units	Normal

16.20.14 Autobrake Selector Normal Operation

The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder advisory that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed. The pilot monitoring will verify any change in the Flap Position Indication indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The Center Tank Pumps status message is expected to read within the sample range of 8 to 13 units during a maintenance-requested ground run.

The pilot monitoring will select any change in the Traffic Advisory Display quantity display and advise the other pilot when conditions permit. The Oxygen Distribution quantity display that differs from the expected state requires the Captain to select the condition before the next phase of flight. If the Brake Temperature Monitor is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. During preflight, the pilot flying should verify the Autopilot Channel A switch position once the checklist item is complete. The first officer will verify any change in the Cargo Smoke Detection status message and advise the other pilot when conditions permit.

The Fuel Crossfeed status message is expected to read within the sample range of 93 to 99 units during takeoff. During a turnaround, the pilot flying should monitor the Cabin Pressure Controller annunciation when operating at a sample station without ground power. If the Weather Radar is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Standby Hydraulic switch position that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. If the Autobrake Selector is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

During approach, the First Officer should confirm the Flap Position Indication switch position when operating at a sample station without ground power. During cruise, the First Officer should select the Standby Hydraulic advisory if a discrepancy is observed. The first officer will confirm any change in the Primary Electrical Bus selector position and advise the other pilot before the next phase of flight. The pilot flying will brief any change in the Center Tank Pumps quantity display and advise the other pilot when the associated caution light remains illuminated.

NOTE: If the Hydraulic System A is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

The Window Heat indication that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. Both pilots will cross-check any change in the Cockpit Voice Recorder annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit advisory is expected to read within the sample range of 59 to 64 units during preflight. During a turnaround, the Captain should cross-check the Cockpit Voice Recorder status message if a discrepancy is observed.

16.20.15 Autopilot Channel A Reset Guidance

During a maintenance-requested ground run, the relief pilot should verify the Autopilot Channel B selector position when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will monitor any change in the Ground Proximity Monitor switch position and advise the other pilot before the next phase of flight.

NOTE: The Auxiliary Power Unit advisory is expected to read within the sample range of 94 to 103 units during taxi. The pilot monitoring will select any change in the Hydraulic System A annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The first officer will select any change in the Standby Hydraulic status message and advise the other pilot before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Weather Radar is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

- If the Flight Management Computer is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.
- If the Window Heat is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

If the Landing Gear Indication is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During a diversion, the relief pilot should verify the Auxiliary Power Unit advisory when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the relief pilot should verify the Standby Hydraulic selector position before the next phase of flight. The Center Tank Pumps advisory that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power.

The Hydraulic System B indication is expected to read within the sample range of 25 to 34 units during taxi. Values in this manual are invented and must not be used for any operational purpose. The Flap Position Indication status message is expected to read within the sample range of 47 to 54 units during an extended ground delay. Refer to the related topic for additional sample context.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

16.30 Operation

16.30.1 Standby Hydraulic Test

The relief pilot will verify any change in the Autopilot Channel A switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the relief pilot should select the Standby Hydraulic quantity display if a discrepancy is observed.

The Engine Anti-Ice annunciation is expected to read within the sample range of 2 to 10 units during a diversion. Refer to the related topic for additional sample context. The Traffic Advisory Display advisory is expected to read within the sample range of 7 to 16 units during takeoff.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The pilot monitoring will select any change in the Fuel Crossfeed selector position and advise the other pilot once the checklist item is complete.
- During an extended ground delay, the pilot flying should record the Standby Instruments annunciation when operating at a sample station without ground power.

During climb, the pilot monitoring should cross-check the Traffic Advisory Display selector position when the associated caution light remains illuminated. During taxi, the pilot monitoring should confirm the Ground Proximity Monitor switch position when the associated caution light remains illuminated. Both pilots will verify any change in the Wing Anti-Ice indication and advise the other pilot when conditions permit.

The pilot monitoring will confirm any change in the Flight Management Computer advisory and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor annunciation is expected to read within the sample range of 24 to 33 units during a maintenance-requested ground run.

If the Stall Warning is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Cockpit Voice Recorder status message is expected to read within the sample range of 86 to 89 units during an extended ground delay. The Stall Warning switch position that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. The Ground Proximity Monitor status message that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated. During takeoff, the Captain should verify the Transponder advisory if a discrepancy is observed.

The pilot flying will announce any change in the Cargo Smoke Detection indication and advise the other pilot if a discrepancy is observed. If the Auxiliary Power Unit is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Landing Gear Indication quantity display is expected to read within the sample range of 22 to 28 units during takeoff. Refer to the related topic for additional sample context.

16.30.2 Autopilot Channel A Crew Awareness

During a diversion, both pilots should verify the Auxiliary Power Unit quantity display when operating at a sample station without ground power. The first officer will select any change in the Bleed Air Supply indication and advise the other pilot if the indication does not stabilize within the sample interval. If the Landing Gear Indication is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During a maintenance-requested ground run, the First Officer should confirm the Speedbrake Handle selector position unless directed otherwise by the Sample Operations Center.

The Standby Instruments switch position that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center. The Oxygen Distribution quantity display is expected to read within the sample range of 46 to 54 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Speedbrake Handle advisory that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Standby Hydraulic annunciation that differs from the expected state requires the Captain to monitor the condition before the next phase of flight.
- The Transponder selector position is expected to read within the sample range of 81 to 90 units during a turnaround.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Flap Position Indication annunciation that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed.
- If the Engine Anti-Ice is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Stall Warning is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

- The Flap Position Indication quantity display that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated.
- During descent, the Captain should confirm the Cabin Pressure Controller quantity display once the checklist item is complete.
- During cruise, the First Officer should select the Autopilot Channel A switch position if the indication does not stabilize within the sample interval.
- During parking, both pilots should monitor the Pack Temperature Control indication unless directed otherwise by the Sample Operations Center.
- If the Cockpit Voice Recorder is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

- The Nosewheel Steering annunciation that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.
- Both pilots will announce any change in the Wing Anti-Ice selector position and advise the other pilot if a discrepancy is observed.
- During climb, the relief pilot should cross-check the Speedbrake Handle advisory if the indication does not stabilize within the sample interval.

NOTE: The Fuel Crossfeed switch position is expected to read within the sample range of 30 to 40 units during taxi.

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will brief any change in the Cargo Smoke Detection quantity display and advise the other pilot once the checklist item is complete. During an extended ground delay, both pilots should brief the Fire Detection Loop selector position if a discrepancy is observed.

16.30.3 Standby Instruments Indications

The captain will confirm any change in the Traffic Advisory Display selector position and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose.

- The Oxygen Distribution indication is expected to read within the sample range of 64 to 69 units during takeoff.
- The Traffic Advisory Display indication is expected to read within the sample range of 29 to 36 units during a maintenance-requested ground run.
- Both pilots will monitor any change in the Nosewheel Steering switch position and advise the other pilot when conditions permit.
- The Autobrake Selector indication that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center.
- During landing, the relief pilot should record the Standby Instruments annunciation when conditions permit.
- The Center Tank Pumps annunciation that differs from the expected state requires the Captain to select the condition when conditions permit.

NOTE: If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The pilot monitoring will brief any change in the Window Heat advisory and advise the other pilot when conditions permit.

NOTE: The Hydraulic System B advisory that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. The relief pilot will verify any change in the Center Tank Pumps advisory and advise the other pilot when the associated caution light remains illuminated.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. During descent, the Captain should monitor the Nosewheel Steering indication before the next phase of flight.

- The Speedbrake Handle switch position that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete.
- If the Cabin Pressure Controller is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.
- During parking, the pilot monitoring should announce the Weather Radar status message once the checklist item is complete.
- The Autobrake Selector indication is expected to read within the sample range of 21 to 26 units during a diversion.

- During taxi, the relief pilot should brief the Nosewheel Steering advisory if the indication does not stabilize within the sample interval.
- The Auxiliary Power Unit indication that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.

16.30.4 Autopilot Channel A Indications

The Transponder advisory is expected to read within the sample range of 69 to 78 units during approach. Values in this manual are invented and must not be used for any operational purpose. The Weather Radar selector position is expected to read within the sample range of 96 to 104 units during cruise. The Probe Heat switch position is expected to read within the sample range of 47 to 56 units during an extended ground delay. During climb, the pilot monitoring should verify the Probe Heat switch position unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Landing Gear Indication quantity display	67 units	Normal
Fuel Crossfeed status message	27 units	Advisory only
Weather Radar indication	8 units	Refer to related topic
Window Heat annunciation	22 units	Refer to related topic
Landing Gear Indication selector position	45 units	Monitor
Oxygen Distribution switch position	21 units	Normal

Condition	Sample value	Remarks
Autopilot Channel A advisory	71 units	Normal
Wing Anti-Ice annunciation	80 units	Monitor
Hydraulic System A indication	16 units	Advisory only

CAUTION: The Cargo Smoke Detection switch position is expected to read within the sample range of 24 to 30 units during an extended ground delay.

During approach, the pilot monitoring should confirm the Flight Management Computer selector position when the associated caution light remains illuminated. During taxi, the pilot flying should cross-check the Pack Temperature Control annunciation if the indication does not stabilize within the sample interval. The Cargo Smoke Detection switch position is expected to read within the sample range of 68 to 78 units during landing. The Cabin Pressure Controller switch position that differs from the expected state requires the Captain to monitor the condition before the next phase of flight.

During takeoff, the relief pilot should announce the Fire Detection Loop quantity display when operating at a sample station without ground power. Both pilots will select any change in the Flap Position Indication selector position and advise the other pilot when conditions permit. The Auxiliary Power Unit indication is expected to read within the sample range of 13 to 18 units during a diversion. The Primary Electrical Bus status message is expected to read within the sample range of 53 to 60 units during engine start.

16.30.5 Oxygen Distribution Test

The Pack Temperature Control annunciation is expected to read within the sample range of 22 to 28 units during descent. This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the pilot flying should monitor the Pack Temperature Control indication when the associated caution light remains illuminated. During a maintenance-requested ground run, the pilot flying should brief the Bleed Air Supply status message once the checklist item is complete.

- If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

- During preflight, the relief pilot should record the Standby Hydraulic selector position when operating at a sample station without ground power.
- The Thrust Reverser selector position that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center.
- Refer to the related topic for additional sample context.
- The Autopilot Channel B status message that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center.

The first officer will brief any change in the Cockpit Voice Recorder status message and advise the other pilot once the checklist item is complete. Both pilots will confirm any change in the Cabin Pressure Controller annunciation and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The pilot flying will record any change in the Ground Proximity Monitor quantity display and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Nosewheel Steering switch position	48 units	Normal
Fuel Crossfeed status message	1 units	Refer to related topic
Window Heat switch position	15 units	Normal

The Ground Proximity Monitor annunciation that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection status message that differs from the expected state requires the Captain to confirm the condition when conditions permit. The relief pilot will cross-check any change in the Autopilot Channel B indication and advise the other pilot if a discrepancy is observed. The captain will brief any change in the Center Tank Pumps selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display quantity display that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Autobrake Selector switch position	29 units	Advisory only
Landing Gear Indication selector position	64 units	Normal
Cabin Pressure Controller annunciation	70 units	Advisory only

CAUTION: During an extended ground delay, the Captain should cross-check the Hydraulic System B selector position when operating at a sample station without ground power.

The Bleed Air Supply switch position is expected to read within the sample range of 40 to 43 units during descent. During a turnaround, the pilot monitoring should record the Fuel Crossfeed annunciation once the checklist item is complete. The Hydraulic System B quantity display is expected to read within the sample range of 28 to 31 units during climb.

16.30.6 Standby Instruments Normal Operation

Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

Refer to the related topic for additional sample context. During a turnaround, the pilot monitoring should brief the Cockpit Voice Recorder switch position if the indication does not stabilize within the sample interval. The pilot flying will cross-check any change in the Standby Instruments indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, the pilot monitoring should brief the Speedbrake Handle indication when the associated

caution light remains illuminated.

The pilot monitoring will announce any change in the Window Heat annunciation and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel A annunciation that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. The Hydraulic System B selector position that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. If the Ground Proximity Monitor is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Bleed Air Supply status message is expected to read within the sample range of 81 to 90 units during descent.

NOTE: If the Hydraulic System B is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Brake Temperature Monitor annunciation that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval.
- The first officer will verify any change in the Traffic Advisory Display selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Both pilots will announce any change in the Fuel Crossfeed selector position and advise the other pilot before the next phase of flight.
- If the Autopilot Channel B is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- The Ground Proximity Monitor switch position that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed.
- During a turnaround, the pilot flying should monitor the Stall Warning selector position unless directed otherwise by the Sample Operations Center.
- If the Center Tank Pumps is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- The Center Tank Pumps indication is expected to read within the sample range of 22 to 25 units during an extended ground delay.

16.30.7 Oxygen Distribution Interfaces

The Landing Gear Indication selector position that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power. If the Autopilot Channel A is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should confirm the Standby Hydraulic quantity display if the indication does not stabilize within the sample interval. The Primary Electrical Bus advisory that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete.

Condition	Sample value	Remarks
Weather Radar status message	54 units	Advisory only
Ground Proximity Monitor status message	94 units	Normal
Probe Heat status message	28 units	Refer to related topic

CAUTION: The pilot flying will select any change in the Traffic Advisory Display advisory and advise the other pilot when the associated caution light remains illuminated.

NOTE: If the Primary Electrical Bus is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cargo Smoke Detection selector position	72 units	Normal
Thrust Reverser switch position	35 units	Monitor
Flap Position Indication status message	12 units	Advisory only
Cabin Pressure Controller advisory	56 units	Refer to related topic
Autobrake Selector advisory	45 units	Monitor
Standby Hydraulic switch position	34 units	Monitor
Thrust Reverser annunciation	80 units	Advisory only

Condition	Sample value	Remarks
Primary Electrical Bus selector position	45 units	Advisory only
Nosewheel Steering advisory	16 units	Monitor
Autothrottle annunciation	84 units	Monitor

NOTE: The Wing Anti-Ice selector position is expected to read within the sample range of 59 to 65 units during cruise. The Flight Management Computer selector position is expected to read within the sample range of 89 to 95 units during climb.

NOTE: The Autopilot Channel A switch position that differs from the expected state requires the First Officer to record the condition once the checklist item is complete. Both pilots will brief any change in the Flight Management Computer switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The pilot flying will confirm any change in the Nosewheel Steering status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The pilot monitoring will monitor any change in the Cargo Smoke Detection status message and advise the other pilot when conditions permit. The pilot monitoring will brief any change in the Primary Electrical Bus switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will announce any change in the Cargo Smoke Detection status message and advise the other pilot when the associated caution light remains illuminated.

16.30.8 Transponder Reset Guidance

Values in this manual are invented and must not be used for any operational purpose. If the Landing Gear Indication is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Hydraulic System B is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

The first officer will cross-check any change in the Cabin Pressure Controller selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System B quantity display is expected to read within the sample range of 57 to 66 units during landing. During preflight, the pilot monitoring should monitor the Autobrake Selector status message when operating at a sample station without ground power.

If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Fuel Crossfeed quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Auxiliary Power Unit is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Window Heat status message is expected to read within the sample range of 27 to 35 units during preflight.

- The Stall Warning status message that differs from the expected state requires the pilot flying to select the condition when conditions permit.
- During preflight, the Captain should verify the Cargo Smoke Detection status message once the checklist item is complete.
- The Ground Proximity Monitor annunciation is expected to read within the sample range of 89 to 95 units during engine start.
- The Hydraulic System B indication is expected to read within the sample range of 21 to 32 units during a maintenance-requested ground run.

If the Autopilot Channel A is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will monitor any change in the Standby Instruments indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

The Autopilot Channel A switch position is expected to read within the sample range of 44 to 52 units during preflight. The Speedbrake Handle switch position is expected to read within the sample range of 42 to 54 units during preflight. The Ground Proximity Monitor status message that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval. Both pilots will monitor any change in the Auxiliary Power Unit status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus selector position that differs from the expected state requires both pilots to cross-check the condition when conditions permit.

If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Stall Warning quantity display and advise the other pilot when the associated caution light remains illuminated. The Autothrottle status message is expected to read within the sample range of 76 to 88 units during a maintenance-requested ground run.

16.30.9 Thrust Reverser Normal Operation

The Wing Anti-Ice quantity display that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. If the Standby Instruments is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Landing Gear Indication switch position is expected to read within the sample range of 85 to 97 units during preflight. The Pack Temperature Control indication that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Oxygen Distribution indication	80 units	Refer to related topic
Autobrake Selector annunciation	67 units	Monitor
Fuel Crossfeed quantity display	27 units	Normal
Hydraulic System A indication	41 units	Advisory only
Nosewheel Steering selector position	14 units	Normal

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. If the Flight Management Computer is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. During parking, the pilot flying should brief the Stall Warning advisory if the indication does not stabilize within the sample interval. The relief pilot will

monitor any change in the Engine Anti-Ice annunciation and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

If the Oxygen Distribution is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Flap Position Indication status message that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. The pilot flying will verify any change in the Thrust Reverser annunciation and advise the other pilot when the associated caution light remains illuminated. The Traffic Advisory Display advisory is expected to read within the sample range of 93 to 99 units during a diversion. During cruise, both pilots should announce the Window Heat switch position before the next phase of flight.

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. During takeoff, the relief pilot should brief the Thrust Reverser advisory when conditions permit.

NOTE: The Traffic Advisory Display status message is expected to read within the sample range of 47 to 55 units during parking.

16.30.10 Traffic Advisory Display Indications

The Cockpit Voice Recorder annunciation is expected to read within the sample range of 28 to 37 units during an extended ground delay. The Autopilot Channel A switch position is expected to read within the sample range of 21 to 24 units during engine start. If the Primary Electrical Bus is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. During a turnaround, the Captain should cross-check the Fire Detection Loop annunciation when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, the relief pilot should select the Thrust Reverser annunciation when conditions permit.

CAUTION: During engine start, the pilot flying should select the Fire Detection Loop indication when operating at a sample station without ground power.

The captain will select any change in the Cockpit Voice Recorder annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. During descent, the relief pilot should announce the Flap Position Indication switch position when the associated caution light remains illuminated. During a turnaround, the First Officer should select the Thrust Reverser switch position before the next phase of flight. During descent, the relief pilot should announce the Hydraulic System A switch position when operating at a sample station without ground power.

During preflight, the First Officer should confirm the Ground Proximity Monitor selector position once the checklist item is complete. During a turnaround, the relief pilot should cross-check the Fuel Crossfeed annunciation unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. If the Thrust Reverser is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight.

Refer to the related topic for additional sample context. The Flight Management Computer advisory that differs from the expected state requires the First Officer to select the condition when conditions permit. The captain will announce any change in the Window Heat advisory and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. During cruise, the pilot monitoring should record the Center Tank Pumps quantity display if the indication does not stabilize within the sample interval.

The Cockpit Voice Recorder switch position that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power. If the Standby Instruments is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During cruise, the pilot flying should record the Autothrottle selector position before the next phase of flight.

NOTE: Refer to the related topic for additional sample context.

Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor selector position is expected to read within the sample range of 94 to 103 units during a diversion. During climb, the pilot monitoring should record the Traffic Advisory Display advisory when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

The Center Tank Pumps indication that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. During preflight, the relief pilot should announce the Cockpit Voice Recorder status message before the next phase of flight. If the Pack Temperature Control is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Transponder switch position that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated. During landing, the First Officer should brief the Traffic Advisory Display switch position when the associated caution light remains illuminated. Both pilots will monitor any change in the Flap Position Indication switch position and advise the other pilot when the associated caution light remains illuminated.

16.30.11 Landing Gear Indication Crew Awareness

If the Window Heat is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Pack Temperature Control advisory is expected to read within the sample range of 65 to 68 units during takeoff. During parking, both pilots should monitor the Standby Hydraulic status message if the indication does not stabilize within the sample interval. The relief pilot will announce any change in the Fuel Crossfeed selector position and advise the other pilot before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Thrust Reverser quantity display	18 units	Normal
Oxygen Distribution status message	25 units	Monitor
Stall Warning status message	45 units	Refer to related topic
Bleed Air Supply advisory	20 units	Normal
Flight Management Computer status message	59 units	Refer to related topic
Autothrottle quantity display	16 units	Advisory only
Center Tank Pumps selector position	4 units	Normal

NOTE: Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

The Center Tank Pumps advisory that differs from the expected state requires both pilots to record the condition when conditions permit. During engine start, the First Officer should confirm the Engine Anti-Ice switch position once the checklist item is complete. If the Center Tank Pumps is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Nosewheel Steering selector position is expected to read within the sample range of 54 to 59 units during descent. If the Autopilot Channel B is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

The pilot flying will select any change in the Landing Gear Indication annunciation and advise the other pilot when conditions permit. The pilot flying will confirm any change in the Stall Warning selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During an extended ground delay, the pilot monitoring should confirm the Transponder status message when the associated caution light remains illuminated. If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Speedbrake Handle status message is expected to read within the sample range of 36 to 42 units during climb.

- The Auxiliary Power Unit status message that differs from the expected state requires the Captain to record the condition if a discrepancy is observed.

- The Thrust Reverser status message is expected to read within the sample range of 15 to 18 units during descent.
- During engine start, both pilots should record the Fire Detection Loop indication before the next phase of flight.
- If the Pack Temperature Control is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- During a maintenance-requested ground run, the pilot flying should confirm the Cargo Smoke Detection selector position when conditions permit.

16.30.12 Thrust Reverser Overview

During taxi, the pilot flying should select the Traffic Advisory Display switch position unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice annunciation is expected to read within the sample range of 41 to 44 units during taxi. The Standby Hydraulic selector position that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated. During a maintenance-requested ground run, the pilot flying should monitor the Transponder advisory once the checklist item is complete. The Oxygen Distribution selector position is expected to read within the sample range of 62 to 65 units during takeoff. The Bleed Air Supply annunciation that differs from the expected state requires the pilot monitoring to select the condition when conditions permit.

NOTE: The Fuel Crossfeed advisory that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

NOTE: Both pilots will brief any change in the Probe Heat advisory and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Hydraulic System B annunciation is expected to read within the sample range of 52 to 63 units during climb.
- The Stall Warning advisory that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed.
- If the Auxiliary Power Unit is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.
- The Engine Anti-Ice switch position that differs from the expected state requires both pilots to select the condition when conditions permit.
- Both pilots will monitor any change in the Nosewheel Steering advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- The Cargo Smoke Detection quantity display that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight.
- The Brake Temperature Monitor selector position is expected to read within the sample range of 83 to 95 units during preflight.
- During a maintenance-requested ground run, the First Officer should monitor the Transponder indication when the associated caution light remains illuminated.
- If the Flap Position Indication is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

During an extended ground delay, the Captain should record the Brake Temperature Monitor indication if a discrepancy is observed. If the Flight Management Computer is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Speedbrake Handle advisory is expected to read within the sample range of 38 to 42 units during takeoff. See 03.50.11 Verification: Autopilot Channel B.

Condition	Sample value	Remarks
-----------	--------------	---------

Engine Anti-Ice quantity display	40 units	Refer to related topic
Pack Temperature Control indication	41 units	Normal
Standby Hydraulic annunciation	58 units	Advisory only
Oxygen Distribution switch position	89 units	Refer to related topic
Primary Electrical Bus status message	62 units	Monitor

Condition	Sample value	Remarks
Standby Instruments status message	63 units	Advisory only
Standby Hydraulic advisory	89 units	Monitor
Cargo Smoke Detection status message	9 units	Normal
Window Heat status message	66 units	Monitor
Standby Instruments annunciation	39 units	Normal

- The Hydraulic System A advisory that differs from the expected state requires the Captain to confirm the condition when conditions permit.
- During taxi, the pilot monitoring should select the Standby Instruments status message when operating at a sample station without ground power.
- During taxi, both pilots should verify the Wing Anti-Ice advisory when conditions permit.
- If the Fire Detection Loop is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.
- The Hydraulic System A switch position is expected to read within the sample range of 38 to 45 units during a turnaround.
- The Ground Proximity Monitor annunciation that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.

16.30.13 Primary Electrical Bus Indications

If the Autobrake Selector is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Cabin Pressure Controller quantity display is expected to read within the sample range of 25 to 32 units during taxi. The first officer will verify any change in the Landing Gear Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval. See 05.50.4 Flight Management Computer Power Sources.

CAUTION: If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Nosewheel Steering status message	19 units	Advisory only
Cargo Smoke Detection annunciation	16 units	Monitor
Cargo Smoke Detection advisory	71 units	Refer to related topic
Ground Proximity Monitor switch position	95 units	Refer to related topic
Auxiliary Power Unit advisory	18 units	Refer to related topic

CAUTION: The Traffic Advisory Display quantity display is expected to read within the sample range of 61 to 73 units during engine start. The Standby Instruments selector position is expected to read within the sample range of 68 to 73 units during taxi.

Condition	Sample value	Remarks
-----------	--------------	---------

Engine Anti-Ice advisory	87 units	Monitor
Auxiliary Power Unit status message	87 units	Refer to related topic
Cabin Pressure Controller advisory	60 units	Refer to related topic

CAUTION: The Flight Management Computer annunciation that differs from the expected state requires the relief pilot to announce the condition when conditions permit.

16.30.14 Flap Position Indication Power Sources

During preflight, both pilots should brief the Standby Instruments quantity display if the indication does not stabilize within the sample interval. The relief pilot will confirm any change in the Speedbrake Handle annunciation and advise the other pilot when operating at a sample station without ground power. The Autopilot Channel B advisory that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed. The Flap Position Indication switch position that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. The relief pilot will record any change in the Hydraulic System B advisory and advise the other pilot when operating at a sample station without ground power. The Pack Temperature Control indication is expected to read within the sample range of 53 to 61 units during descent.

CAUTION: During descent, both pilots should record the Autothrottle quantity display before the next phase of flight. During preflight, both pilots should cross-check the Ground Proximity Monitor quantity display when the associated caution light remains illuminated.

The Transponder annunciation that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. If the Probe Heat is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The first officer will announce any change in the Bleed Air Supply status message and advise the other pilot when operating at a sample station without ground power. The relief pilot will verify any change in the Auxiliary Power Unit selector position and advise the other pilot once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. During a diversion, the First Officer should brief the Pack Temperature Control status message when conditions permit. The Autopilot Channel A annunciation that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. The Probe Heat annunciation that differs from the expected state requires the relief pilot to select the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Hydraulic System B is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Hydraulic System B quantity display is expected to read within the sample range of 80 to 89 units during takeoff. The Fuel Crossfeed selector position that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated. The pilot flying will record any change in the Landing Gear Indication status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

- During an extended ground delay, the relief pilot should record the Transponder switch position when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Fire Detection Loop is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- The Standby Instruments switch position is expected to read within the sample range of 96 to 101 units during approach.
- The Window Heat indication that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.

- The pilot flying will cross-check any change in the Autothrottle quantity display and advise the other pilot before the next phase of flight.

The captain will confirm any change in the Standby Instruments selector position and advise the other pilot before the next phase of flight. The Cabin Pressure Controller annunciation is expected to read within the sample range of 21 to 24 units during descent. The captain will monitor any change in the Pack Temperature Control quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector switch position is expected to read within the sample range of 88 to 97 units during preflight. This text is fictional and exists only to give the prototype realistic volume and structure.

16.30.15 Engine Anti-Ice Interfaces

The Cargo Smoke Detection quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. The Autothrottle advisory that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed. If the Transponder is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. During climb, both pilots should record the Brake Temperature Monitor status message once the checklist item is complete. The Landing Gear Indication annunciation that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus selector position is expected to read within the sample range of 65 to 75 units during a maintenance-requested ground run.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The relief pilot will brief any change in the Standby Instruments switch position and advise the other pilot when the associated caution light remains illuminated.
- During a maintenance-requested ground run, the Captain should brief the Thrust Reverser switch position when operating at a sample station without ground power.

Condition	Sample value	Remarks
Stall Warning status message	43 units	Advisory only
Brake Temperature Monitor switch position	2 units	Advisory only
Cabin Pressure Controller switch position	59 units	Monitor
Auxiliary Power Unit selector position	74 units	Advisory only
Pack Temperature Control advisory	88 units	Advisory only

If the Hydraulic System B is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. Both pilots will brief any change in the Cargo Smoke Detection indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed indication is expected to read within the sample range of 65 to 71 units during preflight. The Center Tank Pumps advisory that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center. If the Cargo Smoke Detection is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The relief pilot will confirm any change in the Center Tank Pumps switch position and advise the other pilot when operating at a sample station without ground power.

The pilot monitoring will monitor any change in the Cabin Pressure Controller quantity display and advise the other pilot before the next phase of flight. The first officer will select any change in the Window Heat annunciation and advise the other pilot when conditions permit. If the Engine Anti-Ice is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. Both pilots will cross-check any change in the Standby Hydraulic annunciation and advise the other pilot when conditions permit. If the Fuel Crossfeed is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

NOTE: The Thrust Reverser status message is expected to read within the sample range of 65 to 68 units during parking.

- If the Center Tank Pumps is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- During preflight, the First Officer should confirm the Standby Instruments quantity display when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Auxiliary Power Unit advisory	16 units	Monitor
Engine Anti-Ice quantity display	7 units	Refer to related topic
Ground Proximity Monitor quantity display	75 units	Advisory only
Cockpit Voice Recorder indication	27 units	Monitor
Hydraulic System B selector position	63 units	Monitor
Cabin Pressure Controller advisory	44 units	Monitor

During a diversion, the First Officer should select the Brake Temperature Monitor switch position if a discrepancy is observed. The first officer will verify any change in the Primary Electrical Bus annunciation and advise the other pilot when operating at a sample station without ground power. The relief pilot will select any change in the Window Heat quantity display and advise the other pilot when conditions permit. During landing, the Captain should confirm the Landing Gear Indication annunciation once the checklist item is complete.

16.30.16 New Sample Topic: Auxiliary Power Unit

During takeoff, the pilot flying should verify the Flap Position Indication switch position if a discrepancy is observed. If the Standby Hydraulic is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: During landing, the Captain should brief the Fire Detection Loop switch position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Fire Detection Loop quantity display	98 units	Monitor
Nosewheel Steering switch position	22 units	Monitor
Hydraulic System B quantity display	59 units	Refer to related topic
Hydraulic System A indication	2 units	Advisory only
Weather Radar selector position	27 units	Advisory only
Cockpit Voice Recorder status message	62 units	Refer to related topic

NOTE: During taxi, both pilots should monitor the Pack Temperature Control selector position when conditions permit. The Standby Instruments advisory that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated.

CAUTION: During takeoff, the relief pilot should announce the Traffic Advisory Display status message when the associated caution light remains illuminated.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Oxygen Distribution is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Thrust Reverser indication and advise the other pilot when operating at a sample station without ground power. The Standby Instruments switch position is expected to read within the sample range of 12 to 20 units during taxi. The Wing Anti-Ice switch position is expected to read within the sample range of 65 to 71 units during taxi. The relief pilot will confirm any change in the Traffic Advisory Display selector position and advise the other pilot once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, the pilot monitoring should announce the Pack Temperature Control switch position when the associated caution light remains illuminated. The Pack Temperature Control quantity display is expected to read within the sample range of 40 to 48 units during landing. The Flight Management Computer selector position is expected to read within the sample range of 45 to 57 units during landing. The first officer will monitor any change in the Autopilot Channel A advisory and advise the other pilot if a discrepancy is observed.

This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the Captain should verify the Traffic Advisory Display selector position once the checklist item is complete. The Oxygen Distribution quantity display is expected to read within the sample range of 3 to 9 units during preflight. If the Weather Radar is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During parking, the First Officer should cross-check the Autopilot Channel B advisory if a discrepancy is observed.

CAUTION: If the Autopilot Channel B is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

16.30.17 *Standby Hydraulic Indications*

Values in this manual are invented and must not be used for any operational purpose. Both pilots will monitor any change in the Window Heat advisory and advise the other pilot when conditions permit. If the Engine Anti-Ice is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

During preflight, the relief pilot should cross-check the Autopilot Channel A quantity display when operating at a sample station without ground power. During a maintenance-requested ground run, the First Officer should record the Hydraulic System B indication if a discrepancy is observed. The Speedbrake Handle status message that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: During cruise, the pilot monitoring should confirm the Thrust Reverser annunciation once the checklist item is complete.

CAUTION: The captain will record any change in the Cargo Smoke Detection switch position and advise the other pilot when the associated caution light remains illuminated.

- The Nosewheel Steering annunciation that differs from the expected state requires both pilots to announce the condition when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Wing Anti-Ice status message that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated.
- Both pilots will announce any change in the Probe Heat annunciation and advise the other pilot when conditions permit.

NOTE: If the Window Heat is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Landing Gear Indication status message that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Primary Electrical Bus selector position is expected to read within the sample range of 91 to 98 units during an extended ground delay.

- The relief pilot will cross-check any change in the Fire Detection Loop advisory and advise the other pilot before the next phase of flight.
- Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Window Heat advisory	42 units	Normal
Standby Hydraulic advisory	18 units	Refer to related topic
Cargo Smoke Detection selector position	69 units	Refer to related topic

NOTE: The Speedbrake Handle quantity display is expected to read within the sample range of 26 to 37 units during landing.

Chapter 17 Systems: Oxygen

17.10 Description

17.10.1 Weather Radar Test

Values in this manual are invented and must not be used for any operational purpose. If the Cargo Smoke Detection is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The Traffic Advisory Display indication that differs from the expected state requires both pilots to select the condition when conditions permit. The Primary Electrical Bus switch position is expected to read within the sample range of 68 to 74 units during climb. Values in this manual are invented and must not be used for any operational purpose.

- Refer to the related topic for additional sample context.
- Both pilots will announce any change in the Traffic Advisory Display switch position and advise the other pilot if a discrepancy is observed.
- The first officer will confirm any change in the Bleed Air Supply annunciation and advise the other pilot before the next phase of flight.
- The pilot flying will cross-check any change in the Transponder status message and advise the other pilot if a discrepancy is observed.
- Refer to the related topic for additional sample context.

CAUTION: The Cockpit Voice Recorder status message is expected to read within the sample range of 43 to 46 units during climb.

NOTE: If the Cabin Pressure Controller is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Pack Temperature Control advisory that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Speedbrake Handle quantity display	97 units	Monitor
Fuel Crossfeed indication	30 units	Normal
Transponder indication	45 units	Advisory only
Standby Hydraulic advisory	18 units	Normal

Both pilots will select any change in the Ground Proximity Monitor status message and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, the First Officer should confirm the Landing Gear Indication switch position once the checklist item is complete. The relief pilot will brief any change in the Cargo Smoke Detection annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will record any change in the Standby Instruments annunciation and advise the other pilot once the checklist item is complete. See 05.60.6 Stall Warning Power Sources.

- Refer to the related topic for additional sample context.
- During a maintenance-requested ground run, the First Officer should cross-check the Wing Anti-Ice indication when conditions permit.
- The pilot monitoring will brief any change in the Fire Detection Loop advisory and advise the other pilot when conditions permit.

- During parking, the pilot flying should verify the Autopilot Channel A indication when the associated caution light remains illuminated.
- The first officer will select any change in the Speedbrake Handle advisory and advise the other pilot when the associated caution light remains illuminated.
- The Brake Temperature Monitor quantity display that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center.

NOTE: The Nosewheel Steering switch position that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. During a maintenance-requested ground run, both pilots should select the Autopilot Channel A status message if a discrepancy is observed.

17.10.2 Engine Anti-Ice Indications

The pilot flying will monitor any change in the Autothrottle advisory and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. The pilot monitoring will select any change in the Hydraulic System B quantity display and advise the other pilot when operating at a sample station without ground power.

If the Brake Temperature Monitor is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. During landing, the pilot flying should brief the Stall Warning advisory if a discrepancy is observed. The Probe Heat selector position that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Flight Management Computer annunciation is expected to read within the sample range of 93 to 97 units during approach.

Condition	Sample value	Remarks
Hydraulic System B annunciation	64 units	Advisory only
Ground Proximity Monitor indication	92 units	Normal
Hydraulic System B quantity display	55 units	Monitor
Flight Management Computer advisory	54 units	Refer to related topic

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	94 units	Refer to related topic
Brake Temperature Monitor switch position	59 units	Normal
Brake Temperature Monitor status message	18 units	Refer to related topic
Standby Hydraulic selector position	64 units	Normal
Nosewheel Steering advisory	29 units	Refer to related topic

CAUTION: If the Oxygen Distribution is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The captain will confirm any change in the Hydraulic System A indication and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autopilot Channel B annunciation	33 units	Refer to related topic
Cargo Smoke Detection status message	22 units	Refer to related topic
Window Heat switch position	24 units	Refer to related topic
Nosewheel Steering quantity display	97 units	Refer to related topic

During an extended ground delay, the First Officer should monitor the Transponder status message unless directed otherwise by the Sample Operations Center. The Standby Instruments status message that differs from the expected state requires the First Officer to cross-check the condition when operating at a sample station without ground power.

If the Autopilot Channel B is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

17.10.3 Weather Radar Normal Operation

If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will monitor any change in the Window Heat advisory and advise the other pilot before the next phase of flight. During a diversion, the pilot flying should brief the Wing Anti-Ice advisory if the indication does not stabilize within the sample interval.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Probe Heat is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.
- The Oxygen Distribution quantity display is expected to read within the sample range of 35 to 38 units during climb.
- The Standby Instruments status message that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.
- The Autothrottle quantity display is expected to read within the sample range of 81 to 85 units during a turnaround.

NOTE: The Center Tank Pumps annunciation that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder indication that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power.

CAUTION: Refer to the related topic for additional sample context. During climb, the First Officer should record the Engine Anti-Ice quantity display when conditions permit.

- If the Autopilot Channel B is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.
- If the Cockpit Voice Recorder is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.
- During climb, both pilots should cross-check the Cargo Smoke Detection indication before the next phase of flight.
- During a diversion, the relief pilot should confirm the Autothrottle quantity display when conditions permit.
- The Stall Warning quantity display that differs from the expected state requires the First Officer to announce the condition before the next phase of flight.
- The Cabin Pressure Controller advisory is expected to read within the sample range of 91 to 96 units during engine start.

The Thrust Reverser selector position that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center. The Flight Management Computer selector position that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. If the Thrust Reverser is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Probe Heat status message	19 units	Advisory only
Transponder quantity display	75 units	Normal
Auxiliary Power Unit advisory	20 units	Refer to related topic
Weather Radar switch position	32 units	Refer to related topic

17.10.4 Window Heat Power Sources

If the Pack Temperature Control is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. During a diversion, the pilot monitoring should cross-check the Stall Warning switch position when the associated caution light remains illuminated. The Stall Warning annunciation is expected to read within the sample range of 34 to 44 units during approach. The Traffic Advisory Display advisory that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete.

The first officer will cross-check any change in the Fuel Crossfeed status message and advise the other pilot if a discrepancy is observed. The Cockpit Voice Recorder switch position is expected to read within the sample range of 80 to 85 units during taxi. The Fuel Crossfeed annunciation that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete. During parking, the First Officer should verify the Autobrake Selector quantity display when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

- If the Engine Anti-Ice is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- Values in this manual are invented and must not be used for any operational purpose.
- The Weather Radar status message is expected to read within the sample range of 32 to 39 units during climb.
- The Oxygen Distribution indication is expected to read within the sample range of 96 to 106 units during a maintenance-requested ground run.
- The pilot flying will record any change in the Landing Gear Indication annunciation and advise the other pilot once the checklist item is complete.
- The Autothrottle status message is expected to read within the sample range of 54 to 64 units during preflight.
- The Speedbrake Handle quantity display that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.
- The pilot flying will brief any change in the Wing Anti-Ice status message and advise the other pilot when conditions permit.

CAUTION: The Brake Temperature Monitor annunciation that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval. The pilot flying will record any change in the Traffic Advisory Display status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

During cruise, the pilot monitoring should brief the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center. The Pack Temperature Control selector position is expected to read within the sample range of 19 to 31 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will verify any change in the Nosewheel Steering quantity display and advise the other pilot when operating at a sample station without ground power. The Landing Gear Indication status message that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. The Wing Anti-Ice advisory is expected to read within the sample range of 32 to 41 units during landing.

The Primary Electrical Bus status message is expected to read within the sample range of 91 to 100 units during climb. The Fire Detection Loop indication is expected to read within the sample range of 49 to 58 units during a diversion. The Landing Gear Indication advisory that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. During an extended ground delay, the relief pilot should confirm the Window Heat annunciation when the associated caution light remains illuminated.

The Stall Warning quantity display is expected to read within the sample range of 19 to 29 units during parking. The Autopilot Channel B quantity display that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. See 03.30.8 Checklist: Oxygen Distribution.

CAUTION: The Hydraulic System B status message is expected to read within the sample range of 95 to 105 units during landing.

17.10.5 Oxygen Distribution Crew Awareness

The Primary Electrical Bus selector position that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center. The relief pilot will brief any change in the Cargo Smoke Detection annunciation and advise the other pilot before the next phase of flight. The captain will announce any change in the Hydraulic System B selector position and advise the other pilot when the associated caution light remains illuminated.

If the Auxiliary Power Unit is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will cross-check any change in the Autopilot Channel B advisory and advise the other pilot when conditions permit. The Autothrottle status message that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed annunciation is expected to read within the sample range of 34 to 41 units during taxi. The Probe Heat selector position is expected to read within the sample range of 85 to 91 units during a turnaround. The Cabin Pressure Controller indication is expected to read within the sample range of 8 to 11 units during descent.

NOTE: The Pack Temperature Control advisory is expected to read within the sample range of 23 to 35 units during takeoff.

Condition	Sample value	Remarks
Brake Temperature Monitor switch position	81 units	Refer to related topic
Transponder advisory	58 units	Advisory only
Cargo Smoke Detection indication	54 units	Monitor
Cargo Smoke Detection switch position	87 units	Refer to related topic
Autobrake Selector advisory	19 units	Refer to related topic

Values in this manual are invented and must not be used for any operational purpose. If the Fuel Crossfeed is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Traffic Advisory Display switch position that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated. Both pilots will verify any change in the Thrust Reverser switch position and advise the other pilot if a discrepancy is observed.

The Primary Electrical Bus switch position that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. During a diversion, both pilots should select the Transponder switch position if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will record any change in the Hydraulic System B status message and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will monitor any change in the Fire Detection Loop annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

17.10.6 Traffic Advisory Display Test

The relief pilot will cross-check any change in the Transponder indication and advise the other pilot when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the Captain should monitor the

Thrust Reverser status message once the checklist item is complete. The Pack Temperature Control status message that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. The pilot monitoring will cross-check any change in the Oxygen Distribution status message and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Thrust Reverser indication	47 units	Monitor
Flap Position Indication switch position	47 units	Advisory only
Brake Temperature Monitor advisory	66 units	Monitor
Oxygen Distribution indication	62 units	Refer to related topic

Condition	Sample value	Remarks
Pack Temperature Control annunciation	71 units	Advisory only
Autopilot Channel B indication	49 units	Advisory only
Cockpit Voice Recorder quantity display	94 units	Normal
Nosewheel Steering quantity display	75 units	Normal
Flap Position Indication status message	30 units	Advisory only

If the Center Tank Pumps is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During takeoff, the pilot flying should cross-check the Flap Position Indication selector position before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will cross-check any change in the Probe Heat selector position and advise the other pilot when the associated caution light remains illuminated.

The Brake Temperature Monitor switch position that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. The Brake Temperature Monitor indication that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. If the Probe Heat is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. During descent, both pilots should brief the Standby Hydraulic selector position if a discrepancy is observed. During preflight, the pilot flying should cross-check the Fire Detection Loop quantity display before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

The Probe Heat switch position is expected to read within the sample range of 35 to 47 units during taxi. The Landing Gear Indication annunciation is expected to read within the sample range of 75 to 81 units during landing. The Landing Gear Indication indication that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval.

- If the Ground Proximity Monitor is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- The Engine Anti-Ice quantity display that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight.
- The Flap Position Indication status message that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power.

17.10.7 Flight Management Computer Reset Guidance

If the Autobrake Selector is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Fire Detection Loop quantity display is expected to read within the sample range of 11 to 19 units during a diversion. During landing, the relief pilot should announce the Hydraulic System B indication when the associated caution light remains illuminated. If the Fire Detection Loop is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a

procedure, not a procedure.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. If the Weather Radar is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle quantity display is expected to read within the sample range of 88 to 92 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure. The Fuel Crossfeed status message that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Stall Warning switch position is expected to read within the sample range of 26 to 34 units during cruise.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	28 units	Advisory only
Transponder advisory	43 units	Normal
Speedbrake Handle indication	32 units	Normal
Center Tank Pumps quantity display	68 units	Normal
Standby Instruments switch position	9 units	Monitor

- The Autopilot Channel A selector position is expected to read within the sample range of 32 to 35 units during a maintenance-requested ground run.
- Refer to the related topic for additional sample context.
- The pilot flying will verify any change in the Fire Detection Loop indication and advise the other pilot before the next phase of flight.
- The pilot monitoring will verify any change in the Weather Radar selector position and advise the other pilot when the associated caution light remains illuminated.
- The Autothrottle status message that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power.

The first officer will monitor any change in the Brake Temperature Monitor selector position and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Bleed Air Supply annunciation is expected to read within the sample range of 23 to 35 units during approach. If the Landing Gear Indication is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

17.10.8 Hydraulic System A Reset Guidance

If the Autopilot Channel B is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. During taxi, both pilots should announce the Pack Temperature Control indication when operating at a sample station without ground power. During an extended ground delay, the Captain should confirm the Thrust Reverser selector position when the associated caution light remains illuminated.

NOTE: The pilot flying will confirm any change in the Cockpit Voice Recorder selector position and advise the other pilot if the indication does not stabilize within the sample interval.

The Brake Temperature Monitor indication that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power. The Nosewheel Steering quantity display is expected to read within the sample range of 89 to 97 units during a diversion. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will monitor any change in the Traffic Advisory Display annunciation and advise the other pilot when operating at a sample station without ground power. Values in

this manual are invented and must not be used for any operational purpose. The Standby Hydraulic switch position that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center.

Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will select any change in the Thrust Reverser status message and advise the other pilot when the associated caution light remains illuminated. Both pilots will verify any change in the Cargo Smoke Detection indication and advise the other pilot if the indication does not stabilize within the sample interval. The Bleed Air Supply indication that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

NOTE: The pilot flying will brief any change in the Weather Radar status message and advise the other pilot if the indication does not stabilize within the sample interval. The Autobrake Selector annunciation that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center.

CAUTION: The Flight Management Computer annunciation that differs from the expected state requires the relief pilot to monitor the condition before the next phase of flight. If the Landing Gear Indication is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

NOTE: If the Autobrake Selector is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

17.10.9 Thrust Reverser Status Messages

The Oxygen Distribution quantity display is expected to read within the sample range of 98 to 103 units during climb. If the Oxygen Distribution is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During takeoff, the First Officer should announce the Cargo Smoke Detection advisory unless directed otherwise by the Sample Operations Center.

During a maintenance-requested ground run, the pilot flying should record the Autopilot Channel A selector position before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder selector position is expected to read within the sample range of 43 to 52 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Hydraulic System B switch position	67 units	Refer to related topic
Autothrottle switch position	22 units	Normal
Autobrake Selector indication	89 units	Advisory only
Primary Electrical Bus selector position	4 units	Refer to related topic
Transponder indication	20 units	Refer to related topic
Autobrake Selector indication	84 units	Refer to related topic
Autopilot Channel B indication	82 units	Normal

Condition	Sample value	Remarks
Transponder quantity display	95 units	Refer to related topic
Pack Temperature Control status message	79 units	Monitor

Autopilot Channel A switch position	32 units	Refer to related topic
Hydraulic System B status message	54 units	Normal

The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the pilot monitoring should announce the Hydraulic System A selector position if a discrepancy is observed.

CAUTION: The Fuel Crossfeed annunciation that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. If the Speedbrake Handle is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

17.10.10 Fuel Crossfeed Normal Operation

The relief pilot will select any change in the Fire Detection Loop status message and advise the other pilot once the checklist item is complete. The pilot monitoring will verify any change in the Ground Proximity Monitor annunciation and advise the other pilot once the checklist item is complete. The Brake Temperature Monitor indication that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center. The captain will select any change in the Fire Detection Loop selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During a turnaround, the relief pilot should announce the Weather Radar quantity display if the indication does not stabilize within the sample interval.

During climb, the Captain should record the Autobrake Selector quantity display unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. If the Cockpit Voice Recorder is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Engine Anti-Ice selector position is expected to read within the sample range of 68 to 76 units during takeoff.

The pilot monitoring will record any change in the Autopilot Channel A annunciation and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. During a turnaround, the pilot monitoring should select the Standby Instruments advisory unless directed otherwise by the Sample Operations Center. During parking, the relief pilot should verify the Wing Anti-Ice indication when operating at a sample station without ground power. During landing, the pilot monitoring should record the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center. The relief pilot will cross-check any change in the Fuel Crossfeed advisory and advise the other pilot once the checklist item is complete.

The Nosewheel Steering status message is expected to read within the sample range of 67 to 79 units during landing. The Autothrottle switch position that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed. If the Fuel Crossfeed is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During a turnaround, the pilot monitoring should cross-check the Transponder selector position when operating at a sample station without ground power. The Wing Anti-Ice indication that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. The Speedbrake Handle annunciation that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center.

17.10.11 Autopilot Channel B Power Sources

The Oxygen Distribution quantity display is expected to read within the sample range of 30 to 35 units during an extended ground delay. The Auxiliary Power Unit selector position that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. During an extended ground delay, the pilot flying

should brief the Standby Hydraulic selector position when operating at a sample station without ground power. The Ground Proximity Monitor advisory that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. The Traffic Advisory Display selector position is expected to read within the sample range of 45 to 55 units during descent.

If the Hydraulic System A is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Hydraulic System B annunciation and advise the other pilot before the next phase of flight. If the Center Tank Pumps is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. During descent, the relief pilot should record the Standby Hydraulic advisory when conditions permit.

- During taxi, the Captain should cross-check the Bleed Air Supply switch position unless directed otherwise by the Sample Operations Center.
- The Traffic Advisory Display annunciation is expected to read within the sample range of 22 to 26 units during parking.
- If the Fire Detection Loop is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- The first officer will cross-check any change in the Speedbrake Handle quantity display and advise the other pilot when the associated caution light remains illuminated.
- During preflight, the relief pilot should record the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center.

During preflight, the Captain should brief the Cockpit Voice Recorder annunciation when conditions permit. During an extended ground delay, the pilot monitoring should verify the Standby Instruments status message once the checklist item is complete. If the Transponder is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

The captain will record any change in the Autothrottle status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will brief any change in the Fuel Crossfeed quantity display and advise the other pilot once the checklist item is complete. The first officer will select any change in the Fuel Crossfeed selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will record any change in the Cockpit Voice Recorder status message and advise the other pilot when operating at a sample station without ground power.

The Engine Anti-Ice annunciation is expected to read within the sample range of 54 to 61 units during landing. If the Engine Anti-Ice is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The pilot flying will record any change in the Oxygen Distribution advisory and advise the other pilot once the checklist item is complete. The pilot flying will monitor any change in the Flight Management Computer switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Auxiliary Power Unit is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Autobrake Selector quantity display is expected to read within the sample range of 56 to 61 units during descent.
- During preflight, both pilots should select the Standby Hydraulic status message unless directed otherwise by the Sample Operations Center.

- Both pilots will cross-check any change in the Stall Warning advisory and advise the other pilot if a discrepancy is observed.

17.10.12 Fuel Crossfeed Overview

The Hydraulic System B indication is expected to read within the sample range of 72 to 84 units during a turnaround. The pilot flying will record any change in the Autobrake Selector status message and advise the other pilot when the associated caution light remains illuminated. The Probe Heat annunciation is expected to read within the sample range of 24 to 30 units during takeoff. If the Ground Proximity Monitor is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will record any change in the Bleed Air Supply selector position and advise the other pilot if a discrepancy is observed.

The Pack Temperature Control quantity display that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval. During approach, both pilots should verify the Fuel Crossfeed annunciation if the indication does not stabilize within the sample interval. Both pilots will select any change in the Fire Detection Loop selector position and advise the other pilot when the associated caution light remains illuminated. During climb, the relief pilot should confirm the Traffic Advisory Display status message unless directed otherwise by the Sample Operations Center. During a maintenance-requested ground run, the pilot monitoring should verify the Autobrake Selector advisory before the next phase of flight.

During descent, the First Officer should verify the Nosewheel Steering status message if the indication does not stabilize within the sample interval. The Fuel Crossfeed advisory that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval. During climb, both pilots should verify the Autopilot Channel A advisory when the associated caution light remains illuminated. During a maintenance-requested ground run, the pilot monitoring should cross-check the Transponder annunciation unless directed otherwise by the Sample Operations Center.

If the Stall Warning is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. Both pilots will monitor any change in the Autopilot Channel A advisory and advise the other pilot when the associated caution light remains illuminated. During a maintenance-requested ground run, both pilots should select the Transponder quantity display before the next phase of flight. The relief pilot will cross-check any change in the Cargo Smoke Detection switch position and advise the other pilot when operating at a sample station without ground power.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

If the Thrust Reverser is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Standby Hydraulic status message that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. The pilot monitoring will brief any change in the Ground Proximity Monitor indication and advise the other pilot when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure.

17.10.13 Transponder Test

The Bleed Air Supply advisory that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder advisory is expected to read within the sample range of 73 to 82 units during climb. If the Ground Proximity Monitor is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps switch position is expected to read within the sample range of 46 to 54 units during a diversion.

During preflight, the pilot monitoring should select the Traffic Advisory Display selector position if a discrepancy is observed. During a maintenance-requested ground run, the First Officer should select the Stall Warning indication

when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Autopilot Channel B status message that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated.

The relief pilot will monitor any change in the Transponder selector position and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. The first officer will confirm any change in the Autopilot Channel A annunciation and advise the other pilot before the next phase of flight. During engine start, the Captain should record the Speedbrake Handle quantity display before the next phase of flight.

During taxi, the pilot flying should cross-check the Pack Temperature Control annunciation when conditions permit. During an extended ground delay, the First Officer should monitor the Autothrottle indication if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. Both pilots will record any change in the Flap Position Indication indication and advise the other pilot when the associated caution light remains illuminated.

The Primary Electrical Bus quantity display is expected to read within the sample range of 15 to 26 units during parking. During a turnaround, the pilot flying should announce the Hydraulic System B switch position if a discrepancy is observed. The first officer will monitor any change in the Autobrake Selector switch position and advise the other pilot if a discrepancy is observed. The Nosewheel Steering status message is expected to read within the sample range of 81 to 90 units during takeoff.

17.10.14 Standby Hydraulic Indications

If the Autobrake Selector is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The Traffic Advisory Display switch position that differs from the expected state requires both pilots to record the condition before the next phase of flight.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot flying will brief any change in the Cockpit Voice Recorder advisory and advise the other pilot when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.

The pilot flying will announce any change in the Cockpit Voice Recorder switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. During a turnaround, the Captain should record the Autopilot Channel B selector position if a discrepancy is observed. The Cabin Pressure Controller status message is expected to read within the sample range of 69 to 80 units during preflight. See 05.70.12 Wing Anti-Ice Power Sources.

Condition	Sample value	Remarks
Flap Position Indication advisory	82 units	Monitor
Brake Temperature Monitor advisory	95 units	Advisory only
Flap Position Indication indication	12 units	Monitor
Window Heat indication	55 units	Normal
Center Tank Pumps annunciation	68 units	Refer to related topic

CAUTION: During parking, the pilot flying should select the Engine Anti-Ice indication once the checklist item is complete.

17.10.15 Engine Anti-Ice Status Messages

The Speedbrake Handle indication that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight. The Cockpit Voice Recorder switch position that differs from the expected

state requires both pilots to confirm the condition when the associated caution light remains illuminated. If the Hydraulic System B is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. During a maintenance-requested ground run, the First Officer should verify the Weather Radar annunciation when operating at a sample station without ground power. During an extended ground delay, the pilot flying should brief the Landing Gear Indication switch position when conditions permit.

Condition	Sample value	Remarks
Thrust Reverser annunciation	17 units	Advisory only
Stall Warning status message	60 units	Monitor
Hydraulic System A indication	18 units	Monitor
Flight Management Computer annunciation	33 units	Normal
Engine Anti-Ice quantity display	7 units	Advisory only

If the Bleed Air Supply is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The pilot flying will record any change in the Stall Warning selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

The pilot flying will announce any change in the Wing Anti-Ice selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Center Tank Pumps is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Oxygen Distribution indication and advise the other pilot when conditions permit. The Engine Anti-Ice status message that differs from the expected state requires the Captain to announce the condition when conditions permit.

If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, both pilots should brief the Standby Hydraulic switch position when the associated caution light remains illuminated. During climb, the pilot monitoring should monitor the Stall Warning status message before the next phase of flight.

Condition	Sample value	Remarks
Transponder switch position	61 units	Refer to related topic
Autopilot Channel B status message	51 units	Monitor
Oxygen Distribution quantity display	39 units	Refer to related topic
Autobrake Selector advisory	67 units	Advisory only
Traffic Advisory Display annunciation	66 units	Advisory only
Primary Electrical Bus status message	34 units	Advisory only
Wing Anti-Ice advisory	80 units	Refer to related topic

Values in this manual are invented and must not be used for any operational purpose. During descent, the pilot flying should verify the Standby Instruments indication once the checklist item is complete. The relief pilot will brief any change in the Autopilot Channel B quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Fuel Crossfeed selector position that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center.

17.10.16 Bleed Air Supply Crew Awareness

The Ground Proximity Monitor annunciation is expected to read within the sample range of 11 to 22 units during a turnaround. If the Window Heat is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Standby Instruments switch position is expected to read within the sample range of 21 to 24 units during a turnaround. This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat advisory that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete. Both pilots will announce any change in the Center Tank Pumps quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. The Nosewheel Steering quantity display that differs from the expected state requires the pilot flying to cross-check the condition if a discrepancy is observed. The Standby Instruments advisory is expected to read within the sample range of 3 to 7 units during parking. The Fire Detection Loop status message that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. The Autopilot Channel A quantity display is expected to read within the sample range of 48 to 53 units during descent.

NOTE: Refer to the related topic for additional sample context.

CAUTION: During climb, the Captain should announce the Auxiliary Power Unit switch position before the next phase of flight.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- During taxi, the pilot monitoring should monitor the Cargo Smoke Detection quantity display before the next phase of flight.
- Both pilots will select any change in the Wing Anti-Ice selector position and advise the other pilot when the associated caution light remains illuminated.
- The Speedbrake Handle advisory that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval.
- The Landing Gear Indication switch position that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed indication is expected to read within the sample range of 53 to 62 units during approach. If the Cockpit Voice Recorder is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. Both pilots will select any change in the Brake Temperature Monitor advisory and advise the other pilot when conditions permit. The Flight Management Computer indication that differs from the expected state requires the pilot monitoring to monitor the condition when operating at a sample station without ground power. The Flight Management Computer status message that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Cabin Pressure Controller annunciation	21 units	Monitor
Window Heat advisory	47 units	Refer to related topic
Brake Temperature Monitor switch position	2 units	Advisory only
Cockpit Voice Recorder status message	70 units	Refer to related topic
Autothrottle quantity display	17 units	Normal
Speedbrake Handle quantity display	44 units	Advisory only
Ground Proximity Monitor switch position	65 units	Monitor

CAUTION: The pilot flying will record any change in the Hydraulic System A switch position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context.

17.20 Controls and Indicators

17.20.1 Fire Detection Loop Overview

If the Ground Proximity Monitor is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Stall Warning switch position that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. Both pilots will cross-check any change in the Center Tank Pumps indication and advise the other pilot unless directed otherwise by the Sample Operations Center. During landing, both pilots should record the Brake Temperature Monitor indication once the checklist item is complete. During climb, the pilot monitoring should select the Bleed Air Supply advisory when operating at a sample station without ground power.

NOTE: The Oxygen Distribution advisory is expected to read within the sample range of 53 to 60 units during takeoff.

The Oxygen Distribution quantity display that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power. If the Transponder is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. During a diversion, the pilot monitoring should announce the Center Tank Pumps quantity display if the indication does not stabilize within the sample interval. If the Stall Warning is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

NOTE: The Stall Warning switch position that differs from the expected state requires the First Officer to cross-check the condition when conditions permit.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

Values in this manual are invented and must not be used for any operational purpose. If the Autothrottle is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Cockpit Voice Recorder quantity display that differs from the expected state requires both pilots to monitor the condition before the next phase of flight. The Center Tank Pumps selector position is expected to read within the sample range of 38 to 49 units during takeoff.

- The first officer will brief any change in the Flap Position Indication status message and advise the other pilot before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Values in this manual are invented and must not be used for any operational purpose.
- The pilot flying will select any change in the Autopilot Channel B annunciation and advise the other pilot when operating at a sample station without ground power.
- Refer to the related topic for additional sample context.
- The relief pilot will verify any change in the Transponder indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Traffic Advisory Display is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The pilot flying will announce any change in the Transponder switch position and advise the other pilot when operating at a sample station without ground power.

17.20.2 Flight Management Computer Indications

During landing, both pilots should verify the Stall Warning indication when operating at a sample station without ground power. The relief pilot will confirm any change in the Flap Position Indication indication and advise the other pilot when conditions permit. The Engine Anti-Ice selector position that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. The Probe Heat indication is expected to read

within the sample range of 52 to 62 units during taxi. The relief pilot will brief any change in the Nosewheel Steering indication and advise the other pilot once the checklist item is complete. The first officer will select any change in the Flap Position Indication selector position and advise the other pilot before the next phase of flight.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will confirm any change in the Autopilot Channel A indication and advise the other pilot if the indication does not stabilize within the sample interval.

The Bleed Air Supply annunciation that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. If the Fire Detection Loop is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control selector position is expected to read within the sample range of 60 to 69 units during a diversion. The Brake Temperature Monitor status message that differs from the expected state requires the First Officer to announce the condition when conditions permit. During climb, the First Officer should cross-check the Autothrottle selector position when operating at a sample station without ground power.

The Fire Detection Loop status message that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete. The Stall Warning annunciation is expected to read within the sample range of 92 to 97 units during cruise. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat quantity display is expected to read within the sample range of 41 to 52 units during descent. The Landing Gear Indication indication is expected to read within the sample range of 63 to 67 units during a diversion.

The Fire Detection Loop indication is expected to read within the sample range of 6 to 17 units during climb. If the Autopilot Channel B is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During an extended ground delay, the pilot monitoring should monitor the Bleed Air Supply indication if the indication does not stabilize within the sample interval.

If the Transponder is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Hydraulic System B annunciation that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, the pilot flying should select the Cargo Smoke Detection indication unless directed otherwise by the Sample Operations Center. If the Thrust Reverser is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

The Autobrake Selector annunciation is expected to read within the sample range of 23 to 29 units during parking. The pilot flying will confirm any change in the Cabin Pressure Controller indication and advise the other pilot before the next phase of flight. The pilot flying will cross-check any change in the Standby Hydraulic advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

- The pilot flying will monitor any change in the Speedbrake Handle indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During preflight, the Captain should verify the Autothrottle switch position before the next phase of flight.
- The captain will verify any change in the Auxiliary Power Unit annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- Refer to the related topic for additional sample context.

NOTE: The Standby Hydraulic switch position is expected to read within the sample range of 84 to 93 units during an extended ground delay. This text is fictional and exists only to give the prototype realistic volume and structure.

17.20.3 Nosewheel Steering Reset Guidance

The Primary Electrical Bus switch position that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. During takeoff, the pilot monitoring should cross-check the Flap Position Indication selector position if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. If the Cabin Pressure Controller is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

The first officer will record any change in the Auxiliary Power Unit advisory and advise the other pilot if a discrepancy is observed. The Hydraulic System B status message that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. The Auxiliary Power Unit indication is expected to read within the sample range of 14 to 26 units during landing. During taxi, the First Officer should select the Landing Gear Indication advisory unless directed otherwise by the Sample Operations Center.

NOTE: The Probe Heat indication that differs from the expected state requires the relief pilot to announce the condition when conditions permit. If the Speedbrake Handle is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

The Window Heat status message is expected to read within the sample range of 90 to 99 units during landing. This text is fictional and exists only to give the prototype realistic volume and structure. The Window Heat advisory that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center. Both pilots will cross-check any change in the Flap Position Indication advisory and advise the other pilot if a discrepancy is observed. If the Autothrottle is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

The Cargo Smoke Detection annunciation that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit. During landing, the pilot monitoring should confirm the Pack Temperature Control status message when the associated caution light remains illuminated. The relief pilot will confirm any change in the Auxiliary Power Unit indication and advise the other pilot when conditions permit. If the Standby Instruments is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Landing Gear Indication selector position	59 units	Normal
Transponder quantity display	93 units	Normal
Bleed Air Supply quantity display	4 units	Refer to related topic
Center Tank Pumps selector position	88 units	Monitor
Cabin Pressure Controller annunciation	88 units	Advisory only
Transponder selector position	70 units	Advisory only
Standby Hydraulic indication	61 units	Normal

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the relief pilot should monitor the Weather Radar indication before the next phase of flight. The Primary Electrical Bus annunciation that differs from the expected state requires the Captain to monitor the condition before the next phase of flight.

CAUTION: Both pilots will select any change in the Autothrottle quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

17.20.4 Cockpit Voice Recorder Indications

The Weather Radar switch position is expected to read within the sample range of 6 to 18 units during parking. The Engine Anti-Ice switch position is expected to read within the sample range of 24 to 31 units during a maintenance-requested ground run. If the Autopilot Channel A is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

If the Standby Instruments is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Window Heat indication is expected to read within the sample range of 61 to 73 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose. If the Cargo Smoke Detection is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

CAUTION: During approach, the Captain should monitor the Auxiliary Power Unit status message unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

CAUTION: If the Thrust Reverser is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

The pilot flying will confirm any change in the Primary Electrical Bus annunciation and advise the other pilot once the checklist item is complete. If the Weather Radar is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control indication is expected to read within the sample range of 84 to 92 units during takeoff. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Fuel Crossfeed quantity display is expected to read within the sample range of 41 to 44 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: During parking, the pilot monitoring should monitor the Stall Warning quantity display once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Autobrake Selector is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

17.20.5 Auxiliary Power Unit Status Messages

During a diversion, both pilots should cross-check the Engine Anti-Ice advisory once the checklist item is complete. During cruise, the First Officer should verify the Autopilot Channel A advisory if the indication does not stabilize within the sample interval. The Weather Radar status message that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval.

- During cruise, both pilots should announce the Standby Hydraulic selector position if a discrepancy is observed.
- The Nosewheel Steering quantity display that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Pack Temperature Control advisory is expected to read within the sample range of 29 to 35 units during parking.
- If the Oxygen Distribution is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.
- The Autopilot Channel B advisory that differs from the expected state requires the pilot flying to record the condition when conditions permit.

The Ground Proximity Monitor annunciation is expected to read within the sample range of 36 to 46 units during preflight. The Oxygen Distribution indication is expected to read within the sample range of 95 to 106 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. If the Autobrake Selector is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Pack Temperature Control switch position	43 units	Normal
Pack Temperature Control advisory	28 units	Refer to related topic

Bleed Air Supply switch position	46 units	Monitor
Transponder selector position	51 units	Normal
Cabin Pressure Controller selector position	73 units	Refer to related topic
Landing Gear Indication annunciation	33 units	Advisory only

The Brake Temperature Monitor advisory is expected to read within the sample range of 33 to 38 units during landing. The Landing Gear Indication status message that differs from the expected state requires the pilot flying to cross-check the condition if a discrepancy is observed. If the Cockpit Voice Recorder is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

The captain will monitor any change in the Autothrottle indication and advise the other pilot if a discrepancy is observed. During a diversion, the relief pilot should monitor the Fuel Crossfeed indication unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The pilot monitoring will record any change in the Hydraulic System A selector position and advise the other pilot once the checklist item is complete. If the Stall Warning is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fire Detection Loop advisory	47 units	Monitor
Nosewheel Steering selector position	3 units	Monitor
Fuel Crossfeed selector position	52 units	Normal
Ground Proximity Monitor selector position	97 units	Monitor
Primary Electrical Bus annunciation	40 units	Refer to related topic

The Cargo Smoke Detection quantity display is expected to read within the sample range of 64 to 72 units during takeoff. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

17.20.6 Autobrake Selector Overview

If the Weather Radar is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will verify any change in the Probe Heat annunciation and advise the other pilot once the checklist item is complete.

CAUTION: During an extended ground delay, the relief pilot should select the Transponder annunciation unless directed otherwise by the Sample Operations Center.

Both pilots will select any change in the Ground Proximity Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During approach, the pilot flying should announce the Cargo Smoke Detection selector position when conditions permit. The Fire Detection Loop indication that differs from the expected state requires the pilot flying to record the condition when conditions permit. The captain will brief any change in the Fire Detection Loop advisory and advise the other pilot when conditions permit.

- Values in this manual are invented and must not be used for any operational purpose.
- The pilot flying will verify any change in the Autobrake Selector indication and advise the other pilot when operating at a sample station without ground power.
- The Standby Instruments quantity display that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Speedbrake Handle is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

- The Probe Heat indication is expected to read within the sample range of 15 to 21 units during cruise.

The relief pilot will record any change in the Cargo Smoke Detection status message and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Fire Detection Loop switch position that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power.

- Values in this manual are invented and must not be used for any operational purpose.
- The first officer will monitor any change in the Standby Hydraulic advisory and advise the other pilot before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Thrust Reverser is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- The Standby Instruments switch position that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated.

17.20.7 Traffic Advisory Display Interfaces

Both pilots will record any change in the Fuel Crossfeed annunciation and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Weather Radar status message is expected to read within the sample range of 28 to 34 units during engine start. The Pack Temperature Control selector position is expected to read within the sample range of 6 to 17 units during climb. The Ground Proximity Monitor switch position that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. The Fuel Crossfeed advisory that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight.

The Center Tank Pumps indication is expected to read within the sample range of 6 to 12 units during approach. Values in this manual are invented and must not be used for any operational purpose. During cruise, the pilot monitoring should record the Auxiliary Power Unit indication if a discrepancy is observed. If the Stall Warning is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The relief pilot will monitor any change in the Wing Anti-Ice switch position and advise the other pilot when the associated caution light remains illuminated.

CAUTION: Refer to the related topic for additional sample context. If the Auxiliary Power Unit is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

- During approach, the First Officer should brief the Cabin Pressure Controller quantity display when operating at a sample station without ground power.
- The first officer will confirm any change in the Wing Anti-Ice quantity display and advise the other pilot before the next phase of flight.
- The Flight Management Computer advisory that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated.
- During approach, both pilots should confirm the Fire Detection Loop selector position if the indication does not stabilize within the sample interval.
- The Fire Detection Loop selector position is expected to read within the sample range of 46 to 49 units during approach.
- The first officer will monitor any change in the Probe Heat advisory and advise the other pilot before the next phase of flight.
- The Cargo Smoke Detection annunciation that differs from the expected state requires the Captain to announce the condition when conditions permit.

- During taxi, the pilot flying should brief the Transponder selector position when conditions permit.
- The Autobrake Selector quantity display is expected to read within the sample range of 91 to 98 units during climb.

17.20.8 Standby Instruments Status Messages

The Speedbrake Handle status message that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight. The Standby Instruments selector position that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated. If the Landing Gear Indication is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the relief pilot should verify the Probe Heat advisory if a discrepancy is observed. The pilot flying will select any change in the Thrust Reverser indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. The Window Heat annunciation is expected to read within the sample range of 69 to 74 units during an extended ground delay. If the Autopilot Channel B is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Center Tank Pumps advisory that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit.

NOTE: During cruise, the pilot flying should record the Oxygen Distribution advisory once the checklist item is complete. During engine start, the pilot monitoring should record the Thrust Reverser indication once the checklist item is complete.

NOTE: If the Landing Gear Indication is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The captain will confirm any change in the Pack Temperature Control indication and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cockpit Voice Recorder status message	34 units	Advisory only
Autopilot Channel A advisory	80 units	Refer to related topic
Hydraulic System A selector position	8 units	Advisory only
Flap Position Indication annunciation	98 units	Advisory only
Transponder annunciation	64 units	Refer to related topic
Weather Radar selector position	2 units	Advisory only

CAUTION: During landing, the relief pilot should announce the Landing Gear Indication selector position when conditions permit.

If the Standby Hydraulic is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. During descent, the pilot monitoring should record the Primary Electrical Bus indication if a discrepancy is observed. The captain will monitor any change in the Cargo Smoke Detection quantity display and advise the other pilot when operating at a sample station without ground power. The Fire Detection Loop status message that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power. The Oxygen Distribution annunciation is expected to read within the sample range of 4 to 10 units during a maintenance-requested ground run.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Cargo Smoke Detection status message that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed.
- The Fuel Crossfeed selector position that differs from the expected state requires the relief pilot to monitor the condition when conditions permit.

- The Weather Radar selector position that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center.

17.20.9 Flight Management Computer Reset Guidance

The first officer will cross-check any change in the Speedbrake Handle advisory and advise the other pilot when operating at a sample station without ground power. The Speedbrake Handle selector position is expected to read within the sample range of 10 to 20 units during landing. The Fire Detection Loop selector position that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight.

CAUTION: The Oxygen Distribution advisory is expected to read within the sample range of 5 to 13 units during an extended ground delay. Both pilots will verify any change in the Autopilot Channel A status message and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Stall Warning indication	6 units	Advisory only
Cargo Smoke Detection indication	83 units	Normal
Center Tank Pumps indication	8 units	Monitor
Fuel Crossfeed quantity display	91 units	Refer to related topic
Ground Proximity Monitor selector position	47 units	Refer to related topic

Values in this manual are invented and must not be used for any operational purpose. During cruise, both pilots should record the Fire Detection Loop annunciation before the next phase of flight. If the Flight Management Computer is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should announce the Traffic Advisory Display annunciation if a discrepancy is observed.

- The Stall Warning status message is expected to read within the sample range of 85 to 91 units during climb.
- During preflight, the pilot flying should monitor the Autobrake Selector status message if a discrepancy is observed.
- The relief pilot will monitor any change in the Window Heat selector position and advise the other pilot before the next phase of flight.
- If the Cockpit Voice Recorder is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The captain will announce any change in the Autobrake Selector status message and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle quantity display that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center. The Weather Radar quantity display that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Nosewheel Steering indication	89 units	Advisory only
Engine Anti-Ice selector position	27 units	Normal
Thrust Reverser selector position	13 units	Monitor
Oxygen Distribution advisory	10 units	Normal
Flight Management Computer quantity display	16 units	Normal
Autopilot Channel A advisory	14 units	Monitor

NOTE: Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Auxiliary Power Unit advisory is expected to read within the sample range of 93 to 96 units during approach.

17.20.10 Window Heat Crew Awareness

Refer to the related topic for additional sample context. During a diversion, the pilot monitoring should announce the Hydraulic System B annunciation when conditions permit. The Fuel Crossfeed quantity display that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. The Window Heat status message is expected to read within the sample range of 69 to 72 units during parking. The pilot monitoring will record any change in the Autothrottle selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The captain will select any change in the Brake Temperature Monitor indication and advise the other pilot when operating at a sample station without ground power.

- During climb, the pilot monitoring should record the Thrust Reverser indication when operating at a sample station without ground power.
- Both pilots will select any change in the Hydraulic System A quantity display and advise the other pilot before the next phase of flight.
- If the Cockpit Voice Recorder is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Brake Temperature Monitor quantity display that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Autopilot Channel B indication that differs from the expected state requires the pilot monitoring to record the condition when the associated caution light remains illuminated.

CAUTION: The captain will confirm any change in the Cockpit Voice Recorder selector position and advise the other pilot before the next phase of flight.

CAUTION: The Brake Temperature Monitor status message is expected to read within the sample range of 72 to 83 units during cruise. If the Landing Gear Indication is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

The Primary Electrical Bus quantity display is expected to read within the sample range of 9 to 14 units during climb. The Cargo Smoke Detection advisory is expected to read within the sample range of 41 to 48 units during a turnaround. If the Weather Radar is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

17.20.11 Primary Electrical Bus Overview

If the Nosewheel Steering is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Cabin Pressure Controller annunciation is expected to read within the sample range of 73 to 76 units during an extended ground delay. The Brake Temperature Monitor advisory that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. The pilot flying will confirm any change in the Pack Temperature Control switch position and advise the other pilot when conditions permit. The captain will brief any change in the Hydraulic System B selector position and advise the other pilot before the next phase of flight.

CAUTION: During parking, the relief pilot should verify the Standby Hydraulic status message if a discrepancy is observed. The captain will select any change in the Autobrake Selector quantity display and advise the other pilot when the associated caution light remains illuminated.

If the Autopilot Channel B is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The relief pilot will verify any change in the Cabin Pressure Controller quantity display and advise the other pilot once the checklist item is complete. During cruise, the pilot flying should verify the Cockpit Voice Recorder quantity display when conditions permit. During climb, the Captain should brief the Auxiliary Power Unit annunciation if a discrepancy is observed.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Probe Heat indication	99 units	Normal
Primary Electrical Bus selector position	48 units	Refer to related topic
Window Heat indication	76 units	Advisory only
Landing Gear Indication indication	14 units	Refer to related topic

CAUTION: If the Window Heat is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

17.20.12 Cockpit Voice Recorder Overview

If the Stall Warning is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. During approach, the relief pilot should brief the Ground Proximity Monitor status message if the indication does not stabilize within the sample interval. The Traffic Advisory Display annunciation is expected to read within the sample range of 75 to 83 units during approach. The captain will cross-check any change in the Bleed Air Supply indication and advise the other pilot once the checklist item is complete.

The Pack Temperature Control quantity display is expected to read within the sample range of 83 to 90 units during engine start. The Center Tank Pumps advisory that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval. The first officer will monitor any change in the Pack Temperature Control indication and advise the other pilot once the checklist item is complete. The Bleed Air Supply selector position is expected to read within the sample range of 45 to 51 units during preflight. The first officer will verify any change in the Landing Gear Indication indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Landing Gear Indication annunciation that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete. The Flight Management Computer switch position is expected to read within the sample range of 86 to 92 units during approach. The Stall Warning advisory that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power.

The relief pilot will record any change in the Cockpit Voice Recorder switch position and advise the other pilot when the associated caution light remains illuminated. During preflight, the pilot monitoring should confirm the Probe Heat switch position once the checklist item is complete. The Autothrottle advisory is expected to read within the sample range of 33 to 42 units during engine start. Both pilots will announce any change in the Transponder switch position and advise the other pilot when the associated caution light remains illuminated. During climb, the pilot monitoring should brief the Weather Radar status message unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display quantity display is expected to read within the sample range of 76 to 88 units during a maintenance-requested ground run.

Both pilots will record any change in the Oxygen Distribution annunciation and advise the other pilot before the next phase of flight. During an extended ground delay, the pilot flying should confirm the Standby Hydraulic quantity display when operating at a sample station without ground power. Both pilots will cross-check any change in the

Autopilot Channel B advisory and advise the other pilot if the indication does not stabilize within the sample interval.

17.20.13 *Nosewheel Steering Test*

If the Standby Instruments is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection switch position is expected to read within the sample range of 26 to 38 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure. The Nosewheel Steering quantity display is expected to read within the sample range of 28 to 37 units during landing. The Engine Anti-Ice advisory is expected to read within the sample range of 34 to 46 units during a maintenance-requested ground run.

CAUTION: The captain will confirm any change in the Standby Instruments annunciation and advise the other pilot when conditions permit.

- The Stall Warning quantity display is expected to read within the sample range of 21 to 32 units during preflight.
- The Hydraulic System A status message is expected to read within the sample range of 80 to 85 units during a turnaround.
- The Nosewheel Steering status message is expected to read within the sample range of 90 to 94 units during takeoff.
- If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- The Center Tank Pumps switch position that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power.

The captain will brief any change in the Bleed Air Supply annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Primary Electrical Bus advisory is expected to read within the sample range of 98 to 108 units during engine start. This text is fictional and exists only to give the prototype realistic volume and structure. The Cabin Pressure Controller indication that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. During cruise, the pilot flying should confirm the Standby Instruments indication unless directed otherwise by the Sample Operations Center.

17.20.14 *Wing Anti-Ice Interfaces*

Refer to the related topic for additional sample context. During cruise, the relief pilot should cross-check the Autopilot Channel A indication once the checklist item is complete. The Window Heat selector position is expected to read within the sample range of 44 to 47 units during preflight. During takeoff, the Captain should brief the Cockpit Voice Recorder status message before the next phase of flight.

CAUTION: The Autopilot Channel B status message that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight.

Condition	Sample value	Remarks
Center Tank Pumps advisory	50 units	Normal
Hydraulic System A status message	10 units	Refer to related topic
Ground Proximity Monitor status message	23 units	Normal

CAUTION: The pilot monitoring will cross-check any change in the Cargo Smoke Detection annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

Refer to the related topic for additional sample context. During a maintenance-requested ground run, both pilots should select the Weather Radar annunciation unless directed otherwise by the Sample Operations Center. If the Thrust Reverser is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Brake Temperature Monitor annunciation	70 units	Monitor
Autothrottle selector position	77 units	Normal
Cockpit Voice Recorder indication	75 units	Refer to related topic
Cockpit Voice Recorder quantity display	78 units	Normal
Oxygen Distribution switch position	49 units	Advisory only
Engine Anti-Ice switch position	2 units	Normal
Thrust Reverser status message	67 units	Refer to related topic

17.20.15 Bleed Air Supply Limits Display

This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, both pilots should monitor the Stall Warning status message if a discrepancy is observed. The Standby Hydraulic indication is expected to read within the sample range of 28 to 35 units during approach.

- The Autopilot Channel B switch position is expected to read within the sample range of 71 to 81 units during climb.
- The pilot flying will brief any change in the Cockpit Voice Recorder status message and advise the other pilot when operating at a sample station without ground power.
- The Primary Electrical Bus annunciation that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval.
- The Autopilot Channel B quantity display that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed.
- Both pilots will select any change in the Autopilot Channel A selector position and advise the other pilot before the next phase of flight.

The pilot flying will verify any change in the Ground Proximity Monitor quantity display and advise the other pilot if a discrepancy is observed. During parking, the pilot flying should record the Window Heat selector position when conditions permit. If the Brake Temperature Monitor is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Center Tank Pumps quantity display	56 units	Normal
Auxiliary Power Unit switch position	60 units	Normal
Standby Instruments status message	69 units	Refer to related topic
Autopilot Channel B advisory	8 units	Normal
Weather Radar selector position	83 units	Monitor
Fire Detection Loop indication	36 units	Monitor

The Hydraulic System A annunciation is expected to read within the sample range of 6 to 15 units during an extended ground delay. The first officer will cross-check any change in the Bleed Air Supply switch position and advise the other pilot when the associated caution light remains illuminated. During a maintenance-requested ground run, the pilot monitoring should brief the Window Heat advisory if the indication does not stabilize within the sample interval.

The Cargo Smoke Detection quantity display is expected to read within the sample range of 61 to 68 units during taxi. If the Transponder is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Nosewheel Steering advisory that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. The Pack Temperature Control annunciation that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power.

- If the Center Tank Pumps is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- The Stall Warning selector position that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power.
- During parking, the First Officer should confirm the Flap Position Indication status message if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Window Heat switch position	63 units	Advisory only
Autothrottle status message	14 units	Monitor
Autopilot Channel A advisory	81 units	Advisory only
Flap Position Indication status message	23 units	Monitor
Speedbrake Handle switch position	99 units	Advisory only
Ground Proximity Monitor switch position	32 units	Refer to related topic

Condition	Sample value	Remarks
Oxygen Distribution quantity display	77 units	Advisory only
Hydraulic System B indication	43 units	Refer to related topic
Traffic Advisory Display annunciation	31 units	Refer to related topic

17.20.16 Window Heat Power Sources

The Engine Anti-Ice indication that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center. The first officer will record any change in the Traffic Advisory Display quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will confirm any change in the Fire Detection Loop selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The relief pilot will select any change in the Transponder switch position and advise the other pilot when operating at a sample station without ground power. During a turnaround, the First Officer should verify the Standby Instruments switch position when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

The Thrust Reverser status message is expected to read within the sample range of 51 to 56 units during a diversion. The relief pilot will cross-check any change in the Ground Proximity Monitor status message and advise the other pilot when the associated caution light remains illuminated. The captain will brief any change in the Hydraulic System B switch position and advise the other pilot if the indication does not stabilize within the sample interval. If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. During a diversion, the Captain should monitor the Standby Hydraulic quantity display before the next phase of flight.

NOTE: During landing, the First Officer should verify the Speedbrake Handle annunciation before the next phase of flight.

The Pack Temperature Control selector position is expected to read within the sample range of 73 to 77 units during a diversion. During parking, the pilot flying should announce the Stall Warning advisory if the indication does not

stabilize within the sample interval. During parking, the pilot flying should select the Standby Instruments quantity display before the next phase of flight. The pilot monitoring will record any change in the Traffic Advisory Display indication and advise the other pilot if a discrepancy is observed.

The pilot monitoring will select any change in the Autopilot Channel B indication and advise the other pilot when conditions permit. The Speedbrake Handle status message is expected to read within the sample range of 80 to 85 units during descent. During a turnaround, the pilot flying should verify the Auxiliary Power Unit advisory if the indication does not stabilize within the sample interval. The Autobrake Selector switch position that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center.

CAUTION: During takeoff, the Captain should verify the Thrust Reverser quantity display unless directed otherwise by the Sample Operations Center. During an extended ground delay, both pilots should announce the Standby Instruments quantity display when operating at a sample station without ground power.

Chapter 18 Systems: Warning Systems

18.10 Description

18.10.1 Autothrottle Power Sources

During climb, the pilot flying should monitor the Nosewheel Steering quantity display unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. If the Stall Warning is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: If the Probe Heat is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. During cruise, the Captain should brief the Cargo Smoke Detection quantity display once the checklist item is complete.

CAUTION: The Traffic Advisory Display switch position is expected to read within the sample range of 28 to 36 units during a diversion.

NOTE: The Ground Proximity Monitor indication is expected to read within the sample range of 59 to 63 units during an extended ground delay.

The Standby Hydraulic quantity display that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

CAUTION: During climb, the pilot monitoring should brief the Weather Radar quantity display when the associated caution light remains illuminated.

18.10.2 Probe Heat Indications

The Standby Instruments indication that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. If the Autopilot Channel A is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Speedbrake Handle indication	46 units	Advisory only
Hydraulic System B selector position	35 units	Refer to related topic
Flap Position Indication selector position	65 units	Normal
Center Tank Pumps switch position	72 units	Refer to related topic
Autopilot Channel B quantity display	69 units	Monitor

The Cabin Pressure Controller advisory is expected to read within the sample range of 96 to 101 units during engine start. During engine start, the Captain should select the Pack Temperature Control quantity display unless directed otherwise by the Sample Operations Center. The Bleed Air Supply selector position that differs from the expected state requires the pilot flying to select the condition before the next phase of flight.

NOTE: If the Traffic Advisory Display is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The first officer will brief any change in the Cabin Pressure

Controller status message and advise the other pilot if the indication does not stabilize within the sample interval.

During takeoff, the First Officer should monitor the Transponder quantity display unless directed otherwise by the Sample Operations Center. If the Engine Anti-Ice is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control status message is expected to read within the sample range of 89 to 94 units during a maintenance-requested ground run. If the Wing Anti-Ice is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The first officer will brief any change in the Window Heat quantity display and advise the other pilot once the checklist item is complete. The Autopilot Channel B quantity display is expected to read within the sample range of 6 to 10 units during takeoff.

Condition	Sample value	Remarks
Probe Heat switch position	64 units	Advisory only
Window Heat quantity display	10 units	Monitor
Cockpit Voice Recorder quantity display	28 units	Monitor
Hydraulic System A annunciation	94 units	Monitor
Cargo Smoke Detection annunciation	27 units	Advisory only
Nosewheel Steering quantity display	85 units	Normal

18.10.3 Traffic Advisory Display Normal Operation

If the Cabin Pressure Controller is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will select any change in the Nosewheel Steering quantity display and advise the other pilot when the associated caution light remains illuminated.

NOTE: Refer to the related topic for additional sample context. The pilot monitoring will monitor any change in the Landing Gear Indication annunciation and advise the other pilot before the next phase of flight.

NOTE: The Center Tank Pumps switch position is expected to read within the sample range of 88 to 92 units during an extended ground delay.

- The pilot flying will announce any change in the Bleed Air Supply switch position and advise the other pilot before the next phase of flight.
- The Transponder annunciation that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight.
- The Hydraulic System A switch position is expected to read within the sample range of 23 to 35 units during taxi.
- If the Window Heat is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

The Engine Anti-Ice status message is expected to read within the sample range of 27 to 35 units during parking. If the Thrust Reverser is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During taxi, the relief pilot should select the Hydraulic System B quantity display when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic annunciation is expected to read within the sample range of 20 to 30 units during descent. The wording here is placeholder content shaped like a procedure, not a procedure.

- Refer to the related topic for additional sample context.
- If the Autothrottle is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- During taxi, the pilot monitoring should monitor the Flap Position Indication selector position if the indication does not stabilize within the sample interval.
- The relief pilot will verify any change in the Transponder annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The Probe Heat quantity display is expected to read within the sample range of 40 to 43 units during taxi.

Condition	Sample value	Remarks
Bleed Air Supply advisory	12 units	Normal
Autothrottle indication	23 units	Refer to related topic
Brake Temperature Monitor status message	20 units	Monitor

18.10.4 Wing Anti-Ice Status Messages

The Traffic Advisory Display quantity display is expected to read within the sample range of 37 to 40 units during a turnaround. The Autopilot Channel B switch position is expected to read within the sample range of 9 to 18 units during a maintenance-requested ground run. During approach, the pilot flying should select the Cabin Pressure Controller annunciation when the associated caution light remains illuminated. The relief pilot will select any change in the Transponder advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Bleed Air Supply is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The pilot monitoring will cross-check any change in the Cabin Pressure Controller quantity display and advise the other pilot when conditions permit. During parking, the pilot flying should cross-check the Flap Position Indication indication when conditions permit. The captain will select any change in the Speedbrake Handle selector position and advise the other pilot when the associated caution light remains illuminated.

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will verify any change in the Autopilot Channel B quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Stall Warning is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. See 08.30.7 Window Heat Interfaces.

CAUTION: The Weather Radar indication that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. During a diversion, the Captain should verify the Fire Detection Loop quantity display when operating at a sample station without ground power.

- Refer to the related topic for additional sample context.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Pack Temperature Control indication that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated.
- Both pilots will verify any change in the Cargo Smoke Detection advisory and advise the other pilot when conditions permit.
- Both pilots will monitor any change in the Autopilot Channel B annunciation and advise the other pilot when conditions permit.
- If the Flight Management Computer is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

18.10.5 New Sample Topic: Probe Heat

This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the pilot flying should select the Transponder indication once the checklist item is complete. If the Thrust Reverser is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. If the Hydraulic System A is

inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

NOTE: The Thrust Reverser switch position is expected to read within the sample range of 14 to 20 units during taxi.

Condition	Sample value	Remarks
Bleed Air Supply advisory	33 units	Advisory only
Standby Instruments indication	95 units	Normal
Pack Temperature Control annunciation	2 units	Advisory only
Cockpit Voice Recorder switch position	18 units	Normal
Primary Electrical Bus annunciation	93 units	Refer to related topic
Cabin Pressure Controller selector position	38 units	Monitor

This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the pilot flying should verify the Traffic Advisory Display switch position when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Primary Electrical Bus switch position that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power.

- The Cabin Pressure Controller annunciation is expected to read within the sample range of 51 to 61 units during taxi.
- If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Standby Hydraulic is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.
- During descent, the pilot monitoring should monitor the Bleed Air Supply indication unless directed otherwise by the Sample Operations Center.

18.10.6 Brake Temperature Monitor Overview

The wording here is placeholder content shaped like a procedure, not a procedure. The Flap Position Indication indication is expected to read within the sample range of 22 to 31 units during parking. The Ground Proximity Monitor indication that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. The first officer will brief any change in the Thrust Reverser annunciation and advise the other pilot if a discrepancy is observed.

CAUTION: If the Stall Warning is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. During a diversion, the First Officer should cross-check the Nosewheel Steering indication when conditions permit.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

Refer to the related topic for additional sample context. The Center Tank Pumps advisory that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. The Traffic Advisory Display status message that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power. Both pilots will cross-check any change in the Hydraulic System B advisory and advise the other pilot once the checklist item is complete.

The Thrust Reverser indication that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. During cruise, the pilot monitoring should monitor the Fuel Crossfeed switch position when conditions permit. The Pack Temperature Control indication is expected to read within the sample range of 81 to 84 units during landing. The relief pilot will cross-check any change in the Standby

Hydraulic indication and advise the other pilot if the indication does not stabilize within the sample interval. During cruise, both pilots should record the Thrust Reverser annunciation when conditions permit. The captain will brief any change in the Flap Position Indication selector position and advise the other pilot if the indication does not stabilize within the sample interval.

18.10.7 Bleed Air Supply Reset Guidance

The Flap Position Indication annunciation that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. If the Nosewheel Steering is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The pilot flying will brief any change in the Autothrottle advisory and advise the other pilot when conditions permit.

During a diversion, the pilot monitoring should confirm the Pack Temperature Control indication if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will verify any change in the Flight Management Computer switch position and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Landing Gear Indication indication that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power.

- If the Ground Proximity Monitor is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- Both pilots will select any change in the Standby Instruments quantity display and advise the other pilot once the checklist item is complete.
- The Window Heat selector position that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power.
- During cruise, both pilots should select the Wing Anti-Ice quantity display when operating at a sample station without ground power.
- If the Autobrake Selector is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Flight Management Computer annunciation that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center.
- The Standby Hydraulic status message is expected to read within the sample range of 70 to 74 units during taxi.
- If the Transponder is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- During cruise, the pilot monitoring should record the Fire Detection Loop annunciation if the indication does not stabilize within the sample interval.
- The Standby Hydraulic quantity display is expected to read within the sample range of 37 to 42 units during cruise.
- This text is fictional and exists only to give the prototype realistic volume and structure.

If the Center Tank Pumps is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Brake Temperature Monitor selector position that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. The Fuel Crossfeed advisory is expected to read within the sample range of 89 to 99 units during a maintenance-requested ground run. The Autopilot Channel A selector position is expected to read within the sample range of 15 to 20 units during descent. The Brake Temperature Monitor advisory that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight. The first officer will monitor any change in the Traffic Advisory Display indication and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The Ground Proximity Monitor selector position is expected to read within the sample range of 62 to 71 units during descent. The Cockpit Voice Recorder quantity display that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed.

18.10.8 Flap Position Indication Reset Guidance

During an extended ground delay, the relief pilot should cross-check the Nosewheel Steering selector position when conditions permit. The Autobrake Selector selector position is expected to read within the sample range of 54 to 60 units during descent. If the Engine Anti-Ice is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System B is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

- The Thrust Reverser quantity display is expected to read within the sample range of 28 to 31 units during engine start.
- During landing, the Captain should confirm the Center Tank Pumps quantity display when operating at a sample station without ground power.
- The Fuel Crossfeed selector position that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval.

CAUTION: The Autopilot Channel A advisory that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. The Speedbrake Handle status message is expected to read within the sample range of 84 to 94 units during landing.

The Cockpit Voice Recorder indication is expected to read within the sample range of 59 to 71 units during cruise. The first officer will confirm any change in the Nosewheel Steering selector position and advise the other pilot once the checklist item is complete. Both pilots will brief any change in the Standby Instruments annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

The first officer will select any change in the Fuel Crossfeed switch position and advise the other pilot when the associated caution light remains illuminated. The Center Tank Pumps annunciation is expected to read within the sample range of 70 to 82 units during climb. The first officer will record any change in the Window Heat annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder advisory is expected to read within the sample range of 21 to 33 units during an extended ground delay.

The Bleed Air Supply advisory is expected to read within the sample range of 26 to 30 units during a diversion. The captain will verify any change in the Fuel Crossfeed selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Weather Radar is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

18.10.9 Standby Instruments Limits Display

If the Oxygen Distribution is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control annunciation that differs from the expected state requires the Captain to select the condition before the next phase of flight. The pilot monitoring will confirm any change in the Window Heat indication and advise the other pilot if the indication does not stabilize within the sample interval. The pilot flying will record any change in the Primary Electrical Bus advisory and advise the other pilot once the checklist item is complete. The Primary Electrical Bus quantity display is expected to read within the sample range of 87 to 97 units during landing. The Brake Temperature Monitor switch position is expected to read within the sample range of 23 to 31 units during a diversion.

During a diversion, the relief pilot should select the Autopilot Channel A indication if a discrepancy is observed. The first officer will cross-check any change in the Window Heat annunciation and advise the other pilot when conditions

permit. During a diversion, the Captain should record the Hydraulic System A status message once the checklist item is complete. The Probe Heat indication is expected to read within the sample range of 93 to 100 units during a diversion.

NOTE: If the Standby Hydraulic is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Pack Temperature Control quantity display and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Fuel Crossfeed switch position that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight.

During an extended ground delay, the relief pilot should confirm the Ground Proximity Monitor quantity display before the next phase of flight. The relief pilot will confirm any change in the Center Tank Pumps advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Engine Anti-Ice selector position that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete. During preflight, the pilot monitoring should cross-check the Hydraulic System B indication when operating at a sample station without ground power. The Autopilot Channel A indication that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center.

During a diversion, the pilot monitoring should brief the Cockpit Voice Recorder selector position before the next phase of flight. During a diversion, both pilots should record the Hydraulic System A quantity display when the associated caution light remains illuminated. The Oxygen Distribution status message is expected to read within the sample range of 49 to 61 units during taxi.

If the Fire Detection Loop is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. During descent, the pilot monitoring should announce the Cockpit Voice Recorder status message when the associated caution light remains illuminated. During takeoff, the Captain should brief the Transponder selector position when the associated caution light remains illuminated. Refer to the related topic for additional sample context. During approach, the relief pilot should announce the Hydraulic System B status message if the indication does not stabilize within the sample interval.

CAUTION: The Bleed Air Supply switch position is expected to read within the sample range of 31 to 42 units during engine start. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Oxygen Distribution is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Transponder quantity display is expected to read within the sample range of 89 to 98 units during descent. If the Standby Hydraulic is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. See 14.10.13 Ground Proximity Monitor Normal Operation.

18.10.10 Autopilot Channel A Power Sources

The Standby Hydraulic advisory that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power. The pilot monitoring will announce any change in the Cargo Smoke Detection advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Fire Detection Loop indication is expected to read within the sample range of 84 to 92 units during engine start. The Ground Proximity Monitor annunciation is expected to read within the sample range of 58 to 65 units during approach. If the Weather Radar is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The relief pilot will confirm any change in the Ground Proximity Monitor advisory and advise the other pilot if the indication does not stabilize within the sample interval.

If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Flight Management Computer switch position is expected to read within the sample range of 64 to 68 units during preflight.
- The Stall Warning switch position that differs from the expected state requires the relief pilot to select the condition when conditions permit.
- The pilot flying will select any change in the Wing Anti-Ice quantity display and advise the other pilot before the next phase of flight.
- If the Traffic Advisory Display is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- The Hydraulic System B advisory is expected to read within the sample range of 84 to 96 units during cruise.

If the Standby Instruments is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Standby Hydraulic selector position is expected to read within the sample range of 58 to 64 units during descent. During a diversion, the First Officer should monitor the Hydraulic System B advisory before the next phase of flight. The Pack Temperature Control status message is expected to read within the sample range of 74 to 80 units during preflight. The Autopilot Channel A selector position is expected to read within the sample range of 48 to 56 units during takeoff.

The pilot flying will announce any change in the Cargo Smoke Detection selector position and advise the other pilot when operating at a sample station without ground power. The Cargo Smoke Detection annunciation that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. The Hydraulic System B selector position is expected to read within the sample range of 79 to 91 units during a turnaround.

NOTE: If the Transponder is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

NOTE: The Primary Electrical Bus advisory that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center. The first officer will confirm any change in the Oxygen Distribution quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

If the Window Heat is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. If the Window Heat is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

18.10.11 Thrust Reverser Limits Display

During a diversion, both pilots should announce the Ground Proximity Monitor indication unless directed otherwise by the Sample Operations Center. The Hydraulic System B annunciation is expected to read within the sample range of 83 to 89 units during landing. Refer to the related topic for additional sample context.

The Autothrottle indication that differs from the expected state requires the Captain to monitor the condition when conditions permit. If the Ground Proximity Monitor is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Hydraulic System A quantity display that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. The Oxygen Distribution switch position is expected to read within the sample range of 80 to 87 units during parking.

Condition	Sample value	Remarks
Thrust Reverser indication	45 units	Normal
Auxiliary Power Unit annunciation	46 units	Refer to related topic
Primary Electrical Bus status message	72 units	Monitor
Transponder indication	43 units	Monitor
Oxygen Distribution status message	97 units	Normal

Oxygen Distribution quantity display	8 units	Refer to related topic
--------------------------------------	---------	------------------------

Condition	Sample value	Remarks
Pack Temperature Control selector position	31 units	Advisory only
Oxygen Distribution indication	75 units	Refer to related topic
Autopilot Channel B annunciation	43 units	Refer to related topic
Cabin Pressure Controller indication	61 units	Normal
Traffic Advisory Display advisory	90 units	Monitor
Ground Proximity Monitor annunciation	11 units	Refer to related topic

During approach, the pilot flying should confirm the Standby Hydraulic selector position if a discrepancy is observed. The relief pilot will cross-check any change in the Cockpit Voice Recorder indication and advise the other pilot once the checklist item is complete. The Ground Proximity Monitor quantity display that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. The Hydraulic System A switch position that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. The captain will monitor any change in the Wing Anti-Ice annunciation and advise the other pilot when conditions permit.

CAUTION: Both pilots will announce any change in the Transponder indication and advise the other pilot if a discrepancy is observed.

CAUTION: The first officer will announce any change in the Traffic Advisory Display quantity display and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Standby Hydraulic advisory	12 units	Normal
Cabin Pressure Controller switch position	74 units	Monitor
Autopilot Channel A status message	3 units	Advisory only
Flight Management Computer switch position	23 units	Advisory only

18.10.12 Transponder Reset Guidance

During a turnaround, the First Officer should select the Window Heat selector position when operating at a sample station without ground power. The Fire Detection Loop indication that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. The Fire Detection Loop advisory is expected to read within the sample range of 60 to 72 units during engine start.

The pilot flying will announce any change in the Flight Management Computer annunciation and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. During a diversion, the First Officer should verify the Autobrake Selector switch position once the checklist item is complete.

CAUTION: The pilot monitoring will brief any change in the Hydraulic System B switch position and advise the other pilot before the next phase of flight. During preflight, the Captain should verify the Nosewheel Steering selector position when operating at a sample station without ground power.

CAUTION: The Standby Instruments indication is expected to read within the sample range of 97 to 104 units during cruise.

Condition	Sample value	Remarks
Fire Detection Loop selector position	15 units	Normal
Nosewheel Steering annunciation	44 units	Normal

Probe Heat annunciation	69 units	Advisory only
-------------------------	----------	---------------

18.10.13 Ground Proximity Monitor Limits Display

During takeoff, the First Officer should brief the Landing Gear Indication quantity display once the checklist item is complete. The pilot monitoring will cross-check any change in the Fuel Crossfeed advisory and advise the other pilot when the associated caution light remains illuminated. Both pilots will announce any change in the Autopilot Channel A advisory and advise the other pilot before the next phase of flight. If the Traffic Advisory Display is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During a turnaround, the Captain should announce the Brake Temperature Monitor selector position if a discrepancy is observed.

NOTE: The Weather Radar selector position that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed.

The Autopilot Channel B annunciation is expected to read within the sample range of 15 to 25 units during approach. The Standby Instruments selector position is expected to read within the sample range of 3 to 12 units during climb. If the Probe Heat is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Cockpit Voice Recorder selector position is expected to read within the sample range of 41 to 49 units during parking. During an extended ground delay, the Captain should verify the Flap Position Indication indication if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

CAUTION: The Fuel Crossfeed advisory is expected to read within the sample range of 29 to 32 units during engine start.

Condition	Sample value	Remarks
Oxygen Distribution advisory	30 units	Refer to related topic
Stall Warning advisory	10 units	Advisory only
Hydraulic System A quantity display	77 units	Monitor
Probe Heat status message	33 units	Normal

18.10.14 Stall Warning Crew Awareness

If the Probe Heat is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. During descent, the Captain should monitor the Transponder quantity display if the indication does not stabilize within the sample interval.

The Fire Detection Loop indication is expected to read within the sample range of 14 to 24 units during parking. This text is fictional and exists only to give the prototype realistic volume and structure. If the Center Tank Pumps is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Fuel Crossfeed annunciation is expected to read within the sample range of 75 to 83 units during an extended ground delay. During engine start, both pilots should monitor the Cabin Pressure Controller annunciation when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

The Cabin Pressure Controller status message that differs from the expected state requires the First Officer to announce the condition when conditions permit. If the Flight Management Computer is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Standby Hydraulic indication that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Cockpit Voice Recorder advisory	42 units	Refer to related topic

Bleed Air Supply quantity display	79 units	Advisory only
Hydraulic System B annunciation	25 units	Refer to related topic

- Refer to the related topic for additional sample context.
- The Flap Position Indication status message is expected to read within the sample range of 46 to 52 units during engine start.
- The Flight Management Computer indication is expected to read within the sample range of 95 to 103 units during approach.
- The captain will monitor any change in the Flap Position Indication selector position and advise the other pilot when operating at a sample station without ground power.
- The pilot monitoring will confirm any change in the Pack Temperature Control switch position and advise the other pilot if a discrepancy is observed.

Values in this manual are invented and must not be used for any operational purpose. Both pilots will monitor any change in the Autopilot Channel B indication and advise the other pilot once the checklist item is complete. The relief pilot will verify any change in the Standby Hydraulic status message and advise the other pilot when the associated caution light remains illuminated.

18.10.15 Cockpit Voice Recorder Overview

The wording here is placeholder content shaped like a procedure, not a procedure. The captain will verify any change in the Weather Radar switch position and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The first officer will verify any change in the Traffic Advisory Display switch position and advise the other pilot if the indication does not stabilize within the sample interval. If the Cabin Pressure Controller is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

The pilot flying will select any change in the Transponder switch position and advise the other pilot once the checklist item is complete. If the Primary Electrical Bus is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

- The Ground Proximity Monitor status message that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated.
- During climb, both pilots should monitor the Auxiliary Power Unit annunciation once the checklist item is complete.
- The pilot monitoring will announce any change in the Primary Electrical Bus switch position and advise the other pilot when the associated caution light remains illuminated.
- If the Autopilot Channel A is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Primary Electrical Bus indication	9 units	Refer to related topic
Bleed Air Supply annunciation	44 units	Monitor
Cargo Smoke Detection advisory	78 units	Normal
Flap Position Indication selector position	61 units	Monitor
Bleed Air Supply indication	75 units	Refer to related topic
Autothrottle switch position	89 units	Advisory only

Both pilots will monitor any change in the Probe Heat switch position and advise the other pilot once the checklist item is complete. During a diversion, the pilot monitoring should monitor the Auxiliary Power Unit selector position unless directed otherwise by the Sample Operations Center. The Autobrake Selector indication that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power. If the Fire Detection Loop is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will cross-check any change in the Thrust Reverser quantity display and advise the other pilot once the checklist item is complete. During landing, both pilots should confirm the Traffic Advisory Display quantity display when the associated caution light remains illuminated.

18.10.16 Wing Anti-Ice Reset Guidance

During takeoff, the Captain should select the Oxygen Distribution advisory when the associated caution light remains illuminated. During cruise, both pilots should announce the Speedbrake Handle selector position if a discrepancy is observed. During a diversion, the relief pilot should select the Oxygen Distribution annunciation unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Nosewheel Steering status message that differs from the expected state requires the pilot flying to verify the condition when conditions permit. The Auxiliary Power Unit advisory that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power.

NOTE: The captain will confirm any change in the Flap Position Indication advisory and advise the other pilot if a discrepancy is observed.

The Autobrake Selector annunciation is expected to read within the sample range of 26 to 34 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure. If the Center Tank Pumps is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Cargo Smoke Detection selector position that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete.

If the Probe Heat is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Traffic Advisory Display quantity display that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Auxiliary Power Unit switch position	62 units	Refer to related topic
Hydraulic System A annunciation	4 units	Monitor
Thrust Reverser advisory	11 units	Refer to related topic

Condition	Sample value	Remarks
Speedbrake Handle advisory	28 units	Normal
Thrust Reverser indication	85 units	Normal
Brake Temperature Monitor selector position	88 units	Normal
Center Tank Pumps status message	20 units	Refer to related topic
Stall Warning annunciation	11 units	Advisory only
Wing Anti-Ice selector position	91 units	Refer to related topic
Landing Gear Indication quantity display	20 units	Monitor

During descent, the pilot flying should monitor the Stall Warning quantity display once the checklist item is complete. The Cargo Smoke Detection selector position is expected to read within the sample range of 14 to 23 units during a maintenance-requested ground run. The Primary Electrical Bus annunciation is expected to read within the sample range of 65 to 69 units during taxi.

This text is fictional and exists only to give the prototype realistic volume and structure. The Brake Temperature Monitor advisory that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. The first officer will select any change in the Cockpit Voice Recorder switch position and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

18.10.17 Speedbrake Handle Normal Operation

If the Cockpit Voice Recorder is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The captain will confirm any change in the Ground Proximity Monitor quantity display and advise the other pilot when conditions permit. During parking, both pilots should select the Stall Warning selector position before the next phase of flight.

NOTE: During climb, the pilot flying should confirm the Autobrake Selector status message when conditions permit. During a maintenance-requested ground run, both pilots should announce the Autopilot Channel B advisory unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Autobrake Selector selector position	16 units	Refer to related topic
Fuel Crossfeed indication	61 units	Normal
Cockpit Voice Recorder switch position	19 units	Refer to related topic
Brake Temperature Monitor selector position	6 units	Advisory only
Autobrake Selector quantity display	6 units	Refer to related topic
Brake Temperature Monitor status message	53 units	Monitor
Brake Temperature Monitor status message	65 units	Refer to related topic

The Stall Warning indication that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. If the Primary Electrical Bus is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic status message that differs from the expected state requires the First Officer to confirm the condition when conditions permit. The first officer will record any change in the Hydraulic System B quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

If the Window Heat is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Autothrottle advisory is expected to read within the sample range of 58 to 68 units during a maintenance-requested ground run. During a turnaround, the First Officer should verify the Thrust Reverser switch position if the indication does not stabilize within the sample interval. The Autopilot Channel A status message is expected to read within the sample range of 86 to 90 units during a maintenance-requested ground run. Values in this manual are invented and must not be used for any operational purpose. During cruise, both pilots should verify the Cargo Smoke Detection advisory before the next phase of flight.

The Primary Electrical Bus annunciation that differs from the expected state requires both pilots to announce the condition unless directed otherwise by the Sample Operations Center. During cruise, both pilots should select the Thrust Reverser selector position if a discrepancy is observed. The Window Heat annunciation that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. During takeoff, the Captain should brief the Nosewheel Steering status message when the associated caution light remains illuminated.

CAUTION: The pilot monitoring will confirm any change in the Traffic Advisory Display status message and advise the other pilot if a discrepancy is observed.

- During a maintenance-requested ground run, the First Officer should announce the Transponder status message when operating at a sample station without ground power.
- During taxi, the Captain should cross-check the Flap Position Indication selector position if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.

18.20 Controls and Indicators

18.20.1 Landing Gear Indication Limits Display

The pilot monitoring will announce any change in the Landing Gear Indication advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Speedbrake Handle indication that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight. The Thrust Reverser indication that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power.

NOTE: The Autothrottle status message that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. If the Traffic Advisory Display is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: During preflight, the pilot flying should select the Traffic Advisory Display selector position unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Oxygen Distribution selector position	96 units	Monitor
Wing Anti-Ice advisory	42 units	Refer to related topic
Autopilot Channel B advisory	40 units	Monitor
Cockpit Voice Recorder indication	71 units	Refer to related topic
Flight Management Computer advisory	77 units	Advisory only

- The first officer will record any change in the Nosewheel Steering annunciation and advise the other pilot when the associated caution light remains illuminated.
- If the Cabin Pressure Controller is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.
- If the Flight Management Computer is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.
- During taxi, the First Officer should verify the Brake Temperature Monitor advisory unless directed otherwise by the Sample Operations Center.
- The Cockpit Voice Recorder indication that differs from the expected state requires the pilot monitoring to monitor the condition when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.

18.20.2 Ground Proximity Monitor Crew Awareness

During preflight, the pilot monitoring should brief the Autobrake Selector indication when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Fuel Crossfeed advisory that differs from the expected state requires the First Officer to verify the condition once the checklist item is complete. The Cargo Smoke Detection advisory that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

During preflight, the First Officer should monitor the Probe Heat annunciation before the next phase of flight. The relief pilot will confirm any change in the Flap Position Indication switch position and advise the other pilot when conditions permit. The pilot monitoring will announce any change in the Standby Hydraulic quantity display and advise the other pilot when conditions permit. During climb, the pilot flying should monitor the Fuel Crossfeed indication when conditions permit.

If the Traffic Advisory Display is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Standby Hydraulic annunciation that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Hydraulic System A advisory	12 units	Normal
Primary Electrical Bus annunciation	19 units	Advisory only
Bleed Air Supply indication	6 units	Monitor
Primary Electrical Bus quantity display	2 units	Refer to related topic

During takeoff, the pilot flying should select the Center Tank Pumps indication if the indication does not stabilize within the sample interval. The Cabin Pressure Controller quantity display that differs from the expected state requires the Captain to announce the condition once the checklist item is complete. During a maintenance-requested ground run, the pilot monitoring should verify the Traffic Advisory Display selector position unless directed otherwise by the Sample Operations Center. If the Nosewheel Steering is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

The captain will monitor any change in the Speedbrake Handle indication and advise the other pilot when operating at a sample station without ground power. If the Autopilot Channel B is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. During climb, the First Officer should confirm the Probe Heat switch position unless directed otherwise by the Sample Operations Center. If the Fire Detection Loop is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. During engine start, both pilots should verify the Brake Temperature Monitor status message if the indication does not stabilize within the sample interval. If the Standby Hydraulic is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

If the Flight Management Computer is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Fire Detection Loop selector position is expected to read within the sample range of 19 to 26 units during a maintenance-requested ground run. During engine start, the Captain should select the Standby Instruments selector position once the checklist item is complete. During approach, both pilots should verify the Flight Management Computer indication if a discrepancy is observed. The Cockpit Voice Recorder selector position is expected to read within the sample range of 82 to 87 units during engine start. Values in this manual are invented and must not be used for any operational purpose.

18.20.3 Transponder Crew Awareness

If the Flap Position Indication is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. During engine start, both pilots should announce the Autopilot Channel A status message when operating at a sample station without ground power. If the Cargo Smoke Detection is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

The pilot monitoring will monitor any change in the Hydraulic System B advisory and advise the other pilot when operating at a sample station without ground power. The Autopilot Channel A switch position is expected to read within the sample range of 98 to 108 units during parking. During landing, the relief pilot should confirm the Ground Proximity Monitor quantity display if the indication does not stabilize within the sample interval. If the Cabin Pressure Controller is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Instruments advisory	3 units	Monitor
Nosewheel Steering annunciation	65 units	Normal
Oxygen Distribution annunciation	90 units	Normal
Flight Management Computer status message	12 units	Refer to related topic

This text is fictional and exists only to give the prototype realistic volume and structure. The Window Heat indication is expected to read within the sample range of 48 to 52 units during climb. If the Speedbrake Handle is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

The first officer will confirm any change in the Autopilot Channel A switch position and advise the other pilot when conditions permit. If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Landing Gear Indication switch position is expected to read within the sample range of 27 to 33 units during takeoff. The Standby Instruments switch position that differs from the expected state requires the relief pilot to brief the condition unless directed otherwise by the Sample Operations Center.

NOTE: The Nosewheel Steering switch position is expected to read within the sample range of 30 to 42 units during approach. The Brake Temperature Monitor annunciation is expected to read within the sample range of 97 to 100 units during preflight.

- If the Speedbrake Handle is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- During preflight, the pilot flying should cross-check the Brake Temperature Monitor switch position when operating at a sample station without ground power.
- The captain will confirm any change in the Standby Instruments advisory and advise the other pilot before the next phase of flight.
- The Standby Instruments indication that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

The Cargo Smoke Detection switch position is expected to read within the sample range of 5 to 11 units during a diversion. During descent, the pilot flying should select the Window Heat selector position once the checklist item is complete. During landing, both pilots should record the Transponder selector position when conditions permit. The captain will record any change in the Autobrake Selector status message and advise the other pilot once the checklist item is complete. If the Oxygen Distribution is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System B selector position that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated.

18.20.4 Center Tank Pumps Status Messages

The Primary Electrical Bus indication that differs from the expected state requires the relief pilot to announce the condition when conditions permit. The pilot monitoring will record any change in the Flight Management Computer advisory and advise the other pilot when conditions permit. If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Bleed Air Supply annunciation is expected to read within the sample range of 14 to 18 units during approach. The Brake Temperature Monitor indication is expected to read within the sample range of 40 to 48 units during parking.

Condition	Sample value	Remarks
Speedbrake Handle advisory	90 units	Monitor
Pack Temperature Control switch position	57 units	Refer to related topic

Autopilot Channel B switch position	83 units	Normal
Autothrottle switch position	87 units	Monitor
Engine Anti-Ice quantity display	99 units	Normal
Flight Management Computer selector position	76 units	Advisory only

The Standby Instruments switch position that differs from the expected state requires the pilot monitoring to select the condition when conditions permit. The Traffic Advisory Display annunciation is expected to read within the sample range of 57 to 67 units during approach. The first officer will monitor any change in the Fuel Crossfeed switch position and advise the other pilot when the associated caution light remains illuminated.

The first officer will select any change in the Fire Detection Loop advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The captain will select any change in the Ground Proximity Monitor quantity display and advise the other pilot when operating at a sample station without ground power. The relief pilot will monitor any change in the Standby Instruments selector position and advise the other pilot when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

During takeoff, the relief pilot should monitor the Flight Management Computer quantity display when conditions permit. The relief pilot will announce any change in the Pack Temperature Control annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Hydraulic System B is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Speedbrake Handle indication is expected to read within the sample range of 72 to 76 units during taxi. The pilot flying will announce any change in the Hydraulic System A indication and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

The Traffic Advisory Display switch position that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. The Autopilot Channel B switch position is expected to read within the sample range of 93 to 103 units during a maintenance-requested ground run. During preflight, the First Officer should verify the Fire Detection Loop indication unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Primary Electrical Bus quantity display is expected to read within the sample range of 9 to 12 units during engine start. If the Flap Position Indication is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

CAUTION: If the Speedbrake Handle is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Transponder status message	94 units	Normal
Wing Anti-Ice advisory	53 units	Monitor
Landing Gear Indication indication	82 units	Refer to related topic
Weather Radar switch position	85 units	Refer to related topic
Fuel Crossfeed annunciation	73 units	Refer to related topic
Flight Management Computer advisory	38 units	Refer to related topic

- During parking, the pilot monitoring should confirm the Hydraulic System B quantity display if the indication does not stabilize within the sample interval.
- The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center.
- The Autopilot Channel A annunciation that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval.

- If the Probe Heat is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

18.20.5 Ground Proximity Monitor Overview

During a turnaround, the pilot flying should verify the Cabin Pressure Controller indication before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel A advisory is expected to read within the sample range of 24 to 33 units during climb. Refer to the related topic for additional sample context. The Stall Warning indication is expected to read within the sample range of 90 to 94 units during takeoff. If the Hydraulic System B is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Flight Management Computer status message	44 units	Normal
Hydraulic System A quantity display	86 units	Normal
Traffic Advisory Display status message	67 units	Normal
Transponder quantity display	36 units	Advisory only
Bleed Air Supply selector position	99 units	Refer to related topic
Autopilot Channel B switch position	6 units	Normal

- During a diversion, the First Officer should announce the Standby Instruments selector position if a discrepancy is observed.
- Refer to the related topic for additional sample context.
- During landing, the pilot monitoring should monitor the Window Heat switch position if the indication does not stabilize within the sample interval.
- The Autopilot Channel A quantity display that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated.

NOTE: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Transponder status message	99 units	Advisory only
Fuel Crossfeed status message	57 units	Normal
Flight Management Computer indication	94 units	Normal
Cockpit Voice Recorder quantity display	42 units	Advisory only
Standby Instruments advisory	5 units	Advisory only
Autopilot Channel A selector position	90 units	Refer to related topic
Cockpit Voice Recorder advisory	22 units	Advisory only

- The relief pilot will select any change in the Primary Electrical Bus quantity display and advise the other pilot when conditions permit.
- The Autothrottle indication is expected to read within the sample range of 69 to 79 units during engine start.
- If the Center Tank Pumps is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- The Flap Position Indication annunciation that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed.

- If the Brake Temperature Monitor is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

NOTE: The first officer will monitor any change in the Engine Anti-Ice switch position and advise the other pilot before the next phase of flight. During a diversion, both pilots should confirm the Oxygen Distribution indication unless directed otherwise by the Sample Operations Center.

The Wing Anti-Ice quantity display is expected to read within the sample range of 91 to 100 units during parking. The Oxygen Distribution status message that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. The Standby Hydraulic quantity display that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated.

18.20.6 Autopilot Channel A Test

The Primary Electrical Bus annunciation that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice indication that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. The pilot flying will announce any change in the Traffic Advisory Display switch position and advise the other pilot before the next phase of flight. If the Standby Hydraulic is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

The Thrust Reverser quantity display is expected to read within the sample range of 60 to 66 units during landing. The captain will select any change in the Primary Electrical Bus switch position and advise the other pilot when the associated caution light remains illuminated. The Autobrake Selector advisory that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval. The pilot monitoring will record any change in the Engine Anti-Ice annunciation and advise the other pilot if a discrepancy is observed. During a turnaround, the relief pilot should record the Cabin Pressure Controller selector position when operating at a sample station without ground power.

Condition	Sample value	Remarks
Auxiliary Power Unit status message	67 units	Monitor
Brake Temperature Monitor quantity display	6 units	Normal
Window Heat selector position	79 units	Advisory only

NOTE: The Flight Management Computer advisory that differs from the expected state requires the pilot flying to select the condition before the next phase of flight. During a maintenance-requested ground run, the pilot flying should verify the Landing Gear Indication quantity display if the indication does not stabilize within the sample interval.

- The Thrust Reverser advisory is expected to read within the sample range of 9 to 21 units during approach.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The captain will cross-check any change in the Hydraulic System A selector position and advise the other pilot once the checklist item is complete.
- During engine start, the pilot flying should announce the Auxiliary Power Unit annunciation once the checklist item is complete.
- The Auxiliary Power Unit indication that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Flap Position Indication advisory	10 units	Advisory only

Oxygen Distribution indication	94 units	Refer to related topic
Brake Temperature Monitor indication	77 units	Refer to related topic
Wing Anti-Ice indication	10 units	Normal

The Autobrake Selector selector position that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center. The first officer will announce any change in the Hydraulic System A status message and advise the other pilot when conditions permit. The Fuel Crossfeed advisory is expected to read within the sample range of 12 to 22 units during parking. If the Autobrake Selector is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Pack Temperature Control switch position is expected to read within the sample range of 48 to 51 units during approach. If the Autopilot Channel B is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Window Heat switch position	9 units	Normal
Ground Proximity Monitor annunciation	74 units	Refer to related topic
Hydraulic System A indication	50 units	Monitor
Brake Temperature Monitor selector position	1 units	Refer to related topic
Hydraulic System A indication	71 units	Normal
Flap Position Indication advisory	76 units	Monitor
Oxygen Distribution selector position	30 units	Refer to related topic

During an extended ground delay, the Captain should announce the Primary Electrical Bus indication before the next phase of flight. The Transponder annunciation is expected to read within the sample range of 47 to 50 units during a maintenance-requested ground run. During an extended ground delay, both pilots should brief the Autobrake Selector status message unless directed otherwise by the Sample Operations Center. The relief pilot will brief any change in the Autopilot Channel A annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

18.20.7 Transponder Indications

The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder switch position is expected to read within the sample range of 50 to 54 units during taxi. If the Window Heat is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During parking, the First Officer should announce the Autothrottle advisory when the associated caution light remains illuminated. During a diversion, the pilot monitoring should verify the Standby Hydraulic annunciation when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Hydraulic System B status message	17 units	Refer to related topic
Nosewheel Steering advisory	1 units	Refer to related topic
Autopilot Channel A status message	19 units	Advisory only

If the Speedbrake Handle is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Speedbrake Handle quantity display that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete. If the Nosewheel Steering is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During descent, the pilot monitoring should record the Standby

Instruments annunciation if a discrepancy is observed.

The pilot monitoring will cross-check any change in the Brake Temperature Monitor advisory and advise the other pilot when conditions permit. The pilot monitoring will monitor any change in the Hydraulic System B status message and advise the other pilot when operating at a sample station without ground power. The Cockpit Voice Recorder quantity display that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. The Thrust Reverser advisory is expected to read within the sample range of 79 to 83 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the pilot monitoring should monitor the Standby Instruments indication when operating at a sample station without ground power.

The captain will monitor any change in the Landing Gear Indication selector position and advise the other pilot when operating at a sample station without ground power. If the Traffic Advisory Display is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display indication is expected to read within the sample range of 98 to 103 units during landing.

18.20.8 Oxygen Distribution Crew Awareness

If the Autothrottle is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. If the Landing Gear Indication is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Cabin Pressure Controller indication that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit.

NOTE: If the Stall Warning is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

- During descent, the First Officer should confirm the Autopilot Channel B selector position unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Wing Anti-Ice indication that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power.
- During climb, the relief pilot should record the Primary Electrical Bus switch position if the indication does not stabilize within the sample interval.
- The pilot monitoring will select any change in the Pack Temperature Control advisory and advise the other pilot if a discrepancy is observed.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the First Officer should confirm the Probe Heat selector position if the indication does not stabilize within the sample interval.

The Autopilot Channel B indication that differs from the expected state requires the Captain to verify the condition once the checklist item is complete. During cruise, the relief pilot should brief the Weather Radar status message when the associated caution light remains illuminated. The Hydraulic System B switch position is expected to read within the sample range of 69 to 73 units during taxi. During an extended ground delay, the pilot monitoring should confirm the Autopilot Channel B indication if a discrepancy is observed. If the Center Tank Pumps is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Weather Radar annunciation that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval.

- During takeoff, the Captain should record the Standby Hydraulic indication when the associated caution light remains illuminated.

- If the Autopilot Channel A is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- During engine start, the First Officer should select the Speedbrake Handle selector position unless directed otherwise by the Sample Operations Center.

The Stall Warning switch position is expected to read within the sample range of 67 to 70 units during taxi. The Ground Proximity Monitor advisory is expected to read within the sample range of 73 to 80 units during descent. The Fire Detection Loop selector position is expected to read within the sample range of 95 to 99 units during engine start. The Fuel Crossfeed status message that differs from the expected state requires both pilots to announce the condition when conditions permit. The Primary Electrical Bus quantity display is expected to read within the sample range of 40 to 48 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure.

- Refer to the related topic for additional sample context.
- The Window Heat quantity display is expected to read within the sample range of 16 to 19 units during engine start.
- The Fire Detection Loop status message that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power.

18.20.9 Autothrottle Limits Display

The first officer will monitor any change in the Hydraulic System B advisory and advise the other pilot before the next phase of flight. The Autopilot Channel B advisory is expected to read within the sample range of 89 to 98 units during takeoff. The Wing Anti-Ice switch position is expected to read within the sample range of 79 to 88 units during a turnaround.

NOTE: During cruise, the relief pilot should verify the Flight Management Computer advisory when conditions permit. The first officer will select any change in the Fire Detection Loop status message and advise the other pilot when conditions permit.

CAUTION: The Fuel Crossfeed annunciation is expected to read within the sample range of 60 to 66 units during preflight.

The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector annunciation is expected to read within the sample range of 65 to 69 units during climb. Both pilots will record any change in the Primary Electrical Bus indication and advise the other pilot when operating at a sample station without ground power.

If the Fuel Crossfeed is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Speedbrake Handle annunciation is expected to read within the sample range of 24 to 28 units during parking. The Traffic Advisory Display advisory that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. The Wing Anti-Ice switch position that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated. See 11.20.6 Flap Position Indication Limits Display.

NOTE: The Transponder status message is expected to read within the sample range of 34 to 37 units during engine start. The captain will select any change in the Stall Warning advisory and advise the other pilot when the associated caution light remains illuminated.

18.20.10 Traffic Advisory Display Reset Guidance

The Engine Anti-Ice switch position is expected to read within the sample range of 55 to 58 units during a turnaround. If the Oxygen Distribution is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue a maintenance-requested

ground run only after the pilot flying has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Cabin Pressure Controller selector position that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval. The Fire Detection Loop annunciation is expected to read within the sample range of 75 to 82 units during approach. If the Ground Proximity Monitor is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, the pilot monitoring should cross-check the Stall Warning switch position before the next phase of flight. Refer to the related topic for additional sample context.

- During climb, the Captain should confirm the Stall Warning quantity display when operating at a sample station without ground power.
- During a diversion, both pilots should verify the Flap Position Indication indication unless directed otherwise by the Sample Operations Center.
- The Hydraulic System A status message that differs from the expected state requires both pilots to cross-check the condition when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.
- The Hydraulic System A quantity display that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Oxygen Distribution quantity display	61 units	Refer to related topic
Pack Temperature Control quantity display	58 units	Refer to related topic
Autobrake Selector status message	67 units	Advisory only
Ground Proximity Monitor indication	4 units	Normal
Bleed Air Supply annunciation	54 units	Advisory only
Flap Position Indication status message	93 units	Normal
Autobrake Selector annunciation	16 units	Monitor

18.20.11 *Autobrake Selector Limits Display*

The Window Heat quantity display that differs from the expected state requires the Captain to brief the condition when conditions permit. If the Hydraulic System B is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. During an extended ground delay, the Captain should cross-check the Probe Heat switch position when the associated caution light remains illuminated. The Autothrottle indication is expected to read within the sample range of 23 to 33 units during climb. The Autopilot Channel B switch position that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center. During cruise, the relief pilot should brief the Flight Management Computer indication before the next phase of flight.

NOTE: If the Hydraulic System B is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Autopilot Channel B is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Primary Electrical Bus annunciation is expected to read within the sample range of 29 to 39 units during a diversion.

NOTE: Both pilots will cross-check any change in the Autopilot Channel B status message and advise the other pilot unless directed otherwise by the Sample Operations Center. During parking, the Captain should verify the

Speedbrake Handle annunciation unless directed otherwise by the Sample Operations Center.

The captain will confirm any change in the Flap Position Indication switch position and advise the other pilot when conditions permit. The Autothrottle annunciation that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

NOTE: During landing, the pilot flying should record the Flight Management Computer selector position before the next phase of flight.

The Flight Management Computer quantity display that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. During engine start, both pilots should monitor the Traffic Advisory Display switch position if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

18.20.12 Flap Position Indication Overview

The Primary Electrical Bus status message that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center. If the Probe Heat is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will confirm any change in the Speedbrake Handle advisory and advise the other pilot once the checklist item is complete.

CAUTION: The Standby Instruments selector position is expected to read within the sample range of 73 to 78 units during a maintenance-requested ground run. Both pilots will verify any change in the Cabin Pressure Controller quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Auxiliary Power Unit status message that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. During approach, the First Officer should cross-check the Standby Hydraulic indication unless directed otherwise by the Sample Operations Center. During taxi, the First Officer should confirm the Flap Position Indication status message when the associated caution light remains illuminated. If the Nosewheel Steering is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. During preflight, both pilots should brief the Auxiliary Power Unit indication before the next phase of flight. The pilot flying will monitor any change in the Hydraulic System B quantity display and advise the other pilot if a discrepancy is observed.

During preflight, the Captain should monitor the Fuel Crossfeed switch position when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Flap Position Indication advisory is expected to read within the sample range of 65 to 74 units during a turnaround. If the Flight Management Computer is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cargo Smoke Detection annunciation	45 units	Refer to related topic
Brake Temperature Monitor annunciation	67 units	Advisory only
Weather Radar indication	4 units	Advisory only
Brake Temperature Monitor advisory	14 units	Normal
Pack Temperature Control status message	82 units	Normal
Window Heat status message	97 units	Monitor
Fuel Crossfeed annunciation	50 units	Refer to related topic

If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During taxi, the pilot flying should monitor the Flight Management Computer switch position once the checklist item is

complete. The captain will brief any change in the Hydraulic System B selector position and advise the other pilot if a discrepancy is observed. During taxi, both pilots should brief the Cabin Pressure Controller switch position when the associated caution light remains illuminated.

During descent, both pilots should cross-check the Autothrottle status message if the indication does not stabilize within the sample interval. The Hydraulic System A annunciation is expected to read within the sample range of 58 to 64 units during a maintenance-requested ground run. The Standby Hydraulic quantity display is expected to read within the sample range of 49 to 54 units during climb.

18.20.13 Hydraulic System A Normal Operation

If the Pack Temperature Control is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will brief any change in the Landing Gear Indication switch position and advise the other pilot if a discrepancy is observed. The Probe Heat indication that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete. During preflight, both pilots should select the Landing Gear Indication quantity display unless directed otherwise by the Sample Operations Center. The captain will record any change in the Engine Anti-Ice status message and advise the other pilot when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. The Primary Electrical Bus status message that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. The Stall Warning annunciation that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval. If the Autobrake Selector is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Autothrottle selector position that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. The Brake Temperature Monitor annunciation is expected to read within the sample range of 17 to 21 units during parking.

- Refer to the related topic for additional sample context.
- Refer to the related topic for additional sample context.
- The pilot flying will record any change in the Ground Proximity Monitor selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Hydraulic System A is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- The relief pilot will brief any change in the Pack Temperature Control status message and advise the other pilot before the next phase of flight.
- If the Oxygen Distribution is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fire Detection Loop selector position	23 units	Normal
Engine Anti-Ice indication	86 units	Advisory only
Flap Position Indication status message	55 units	Advisory only
Ground Proximity Monitor annunciation	61 units	Normal
Oxygen Distribution indication	76 units	Monitor
Pack Temperature Control selector position	50 units	Normal
Brake Temperature Monitor status message	85 units	Normal

Both pilots will record any change in the Cockpit Voice Recorder selector position and advise the other pilot if a discrepancy is observed. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fuel Crossfeed annunciation	20 units	Refer to related topic
Bleed Air Supply switch position	65 units	Normal
Autopilot Channel B advisory	78 units	Refer to related topic
Pack Temperature Control quantity display	96 units	Advisory only

Refer to the related topic for additional sample context. The Flap Position Indication indication is expected to read within the sample range of 49 to 61 units during a maintenance-requested ground run. The Landing Gear Indication selector position is expected to read within the sample range of 3 to 15 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. The Auxiliary Power Unit status message that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated. The first officer will verify any change in the Traffic Advisory Display switch position and advise the other pilot if a discrepancy is observed.

During cruise, the pilot monitoring should monitor the Wing Anti-Ice indication when operating at a sample station without ground power. The pilot flying will record any change in the Cargo Smoke Detection status message and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the pilot monitoring should monitor the Stall Warning advisory if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autobrake Selector is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will record any change in the Autopilot Channel A switch position and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

18.20.14 Cockpit Voice Recorder Test

If the Hydraulic System A is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Auxiliary Power Unit switch position that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center. The first officer will announce any change in the Cockpit Voice Recorder status message and advise the other pilot when the associated caution light remains illuminated. The Primary Electrical Bus advisory that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed. Both pilots will brief any change in the Window Heat annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Hydraulic System A is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

- The Engine Anti-Ice switch position is expected to read within the sample range of 4 to 8 units during cruise.
- During a turnaround, the First Officer should brief the Bleed Air Supply annunciation when conditions permit.
- During parking, the pilot flying should brief the Autobrake Selector switch position once the checklist item is complete.
- If the Traffic Advisory Display is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

During landing, the pilot monitoring should verify the Nosewheel Steering annunciation unless directed otherwise by the Sample Operations Center. The Flap Position Indication annunciation is expected to read within the sample range of 36 to 42 units during descent. The wording here is placeholder content shaped like a procedure, not a procedure. The Stall Warning annunciation that differs from the expected state requires the pilot flying to confirm the condition when conditions permit. If the Oxygen Distribution is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. During parking, the First Officer should confirm the Fire Detection Loop annunciation when the associated caution light remains illuminated.

NOTE: If the Traffic Advisory Display is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

NOTE: The relief pilot will monitor any change in the Window Heat selector position and advise the other pilot when operating at a sample station without ground power.

CAUTION: If the Brake Temperature Monitor is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

The pilot monitoring will announce any change in the Cockpit Voice Recorder quantity display and advise the other pilot when conditions permit. During engine start, the pilot flying should brief the Ground Proximity Monitor advisory when operating at a sample station without ground power. If the Auxiliary Power Unit is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. See 05.40.10 Brake Temperature Monitor Normal Operation.

CAUTION: During parking, the pilot monitoring should confirm the Fuel Crossfeed switch position when operating at a sample station without ground power. If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

- Both pilots will announce any change in the Flap Position Indication indication and advise the other pilot before the next phase of flight.
- If the Ground Proximity Monitor is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- If the Weather Radar is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

18.20.15 Flow: Autopilot Channel B

This text is fictional and exists only to give the prototype realistic volume and structure. The Engine Anti-Ice quantity display is expected to read within the sample range of 82 to 90 units during a diversion. Refer to the related topic for additional sample context.

During takeoff, the First Officer should verify the Standby Instruments annunciation when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Flap Position Indication selector position that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete. During takeoff, the First Officer should announce the Flap Position Indication selector position when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. If the Cargo Smoke Detection is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The captain will record any change in the Stall Warning annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

- If the Standby Instruments is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- Both pilots will announce any change in the Window Heat selector position and advise the other pilot once the checklist item is complete.
- If the Flap Position Indication is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.
- If the Standby Hydraulic is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- During cruise, the First Officer should cross-check the Landing Gear Indication advisory when conditions permit.

CAUTION: The pilot flying will confirm any change in the Cargo Smoke Detection switch position and advise the other pilot when the associated caution light remains illuminated.

If the Flap Position Indication is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Fire Detection Loop indication is expected to read within the sample range of 75 to 81 units during climb. The first officer will verify any change in the Stall Warning advisory and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. The Transponder annunciation that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.

The pilot monitoring will brief any change in the Speedbrake Handle indication and advise the other pilot when operating at a sample station without ground power. The relief pilot will brief any change in the Center Tank Pumps status message and advise the other pilot when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

- Values in this manual are invented and must not be used for any operational purpose.
- The Standby Hydraulic switch position that differs from the expected state requires both pilots to select the condition once the checklist item is complete.
- During a diversion, the relief pilot should monitor the Traffic Advisory Display selector position when conditions permit.
- Refer to the related topic for additional sample context.
- If the Brake Temperature Monitor is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- During landing, both pilots should brief the Autopilot Channel B advisory if the indication does not stabilize within the sample interval.

CAUTION: During cruise, the First Officer should monitor the Hydraulic System B selector position when conditions permit.

18.20.16 Ground Proximity Monitor Status Messages

The Landing Gear Indication indication that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated. The Flap Position Indication annunciation is expected to read within the sample range of 51 to 60 units during a turnaround. During takeoff, the pilot flying should cross-check the Landing Gear Indication quantity display when conditions permit. Values in this manual are invented and must not be used for any operational purpose. During descent, the Captain should record the Stall Warning indication if the indication does not stabilize within the sample interval.

The captain will announce any change in the Engine Anti-Ice advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Autothrottle indication is expected to read within the sample range of 90 to 96 units during an extended ground delay. The pilot monitoring will brief any change in the Autopilot Channel B switch position and advise the other pilot when operating at a sample station without ground power. The Flap Position Indication selector position that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. During taxi, the Captain should cross-check the Cockpit Voice Recorder status message if the indication does not stabilize within the sample interval.

- During taxi, the pilot flying should confirm the Thrust Reverser quantity display once the checklist item is complete.
- During cruise, the pilot flying should brief the Speedbrake Handle status message if a discrepancy is observed.
- Refer to the related topic for additional sample context.
- During climb, the pilot flying should record the Speedbrake Handle indication unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Wing Anti-Ice advisory	99 units	Monitor
Fuel Crossfeed status message	44 units	Normal
Weather Radar indication	45 units	Advisory only
Wing Anti-Ice switch position	49 units	Refer to related topic
Ground Proximity Monitor indication	58 units	Monitor

The Fire Detection Loop annunciation is expected to read within the sample range of 21 to 33 units during approach. The captain will confirm any change in the Fire Detection Loop advisory and advise the other pilot when the associated caution light remains illuminated. The first officer will select any change in the Bleed Air Supply selector position and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

NOTE: If the Weather Radar is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. Both pilots will record any change in the Flap Position Indication indication and advise the other pilot once the checklist item is complete.

During parking, the relief pilot should announce the Traffic Advisory Display indication if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Pack Temperature Control indication is expected to read within the sample range of 86 to 95 units during takeoff. The Autopilot Channel A quantity display that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. The pilot flying will announce any change in the Standby Hydraulic advisory and advise the other pilot when the associated caution light remains illuminated.

During preflight, the First Officer should select the Window Heat selector position when operating at a sample station without ground power. During takeoff, the First Officer should brief the Standby Instruments advisory if a discrepancy is observed. The Flap Position Indication indication is expected to read within the sample range of 29 to 41 units during landing. The Cockpit Voice Recorder indication that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. See 08.10.8 Cabin Pressure Controller Normal Operation.

18.20.17 Hydraulic System A Status Messages

The first officer will announce any change in the Landing Gear Indication status message and advise the other pilot when operating at a sample station without ground power. Both pilots will monitor any change in the Autothrottle advisory and advise the other pilot before the next phase of flight. The Autobrake Selector indication is expected to read within the sample range of 16 to 28 units during landing. The Ground Proximity Monitor annunciation is expected to read within the sample range of 62 to 72 units during an extended ground delay. Refer to the related topic for additional sample context. The Autothrottle annunciation is expected to read within the sample range of 20 to 31 units during an extended ground delay.

If the Autopilot Channel B is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The Flight Management Computer quantity display that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Autothrottle status message is expected to read within the sample range of 58 to 61 units during a diversion. If the Nosewheel Steering is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

CAUTION: During cruise, the pilot flying should cross-check the Speedbrake Handle indication if the indication does not stabilize within the sample interval. The Hydraulic System B indication that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. The Fire Detection Loop quantity display is expected to read within the sample range of 37 to 48 units during landing. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will monitor any change in the Autopilot Channel A annunciation and advise the other pilot once the checklist item is complete. During engine start, the First Officer should monitor the Speedbrake Handle advisory when operating at a sample station without ground power. The Engine Anti-Ice switch position is expected to read within the sample range of 80 to 85 units during a diversion.

CAUTION: During taxi, the First Officer should brief the Hydraulic System A status message before the next phase of flight.

If the Cargo Smoke Detection is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Autopilot Channel B quantity display that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated. The Primary Electrical Bus quantity display that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. The Ground Proximity Monitor selector position is expected to read within the sample range of 44 to 50 units during engine start. If the Window Heat is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

During landing, the First Officer should verify the Brake Temperature Monitor status message when the associated caution light remains illuminated. The Traffic Advisory Display quantity display is expected to read within the sample range of 28 to 37 units during descent. During takeoff, the pilot flying should brief the Auxiliary Power Unit indication when the associated caution light remains illuminated.

If the Landing Gear Indication is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Auxiliary Power Unit selector position is expected to read within the sample range of 93 to 101 units during a diversion. The wording here is placeholder content shaped like a procedure, not a procedure. If the Center Tank Pumps is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Standby Instruments status message that differs from the expected state requires the relief pilot to monitor the condition when conditions permit.

Condition	Sample value	Remarks
Weather Radar selector position	33 units	Advisory only
Traffic Advisory Display quantity display	34 units	Normal
Flight Management Computer advisory	10 units	Monitor
Cockpit Voice Recorder advisory	52 units	Monitor
Standby Instruments annunciation	91 units	Normal
Standby Hydraulic quantity display	41 units	Normal

18.30 Operation

18.30.1 Brake Temperature Monitor Crew Awareness

The Hydraulic System B annunciation is expected to read within the sample range of 82 to 87 units during landing. The Engine Anti-Ice indication that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Traffic Advisory Display quantity display	78 units	Normal
Thrust Reverser quantity display	38 units	Refer to related topic
Nosewheel Steering selector position	5 units	Refer to related topic
Cockpit Voice Recorder advisory	60 units	Monitor

Brake Temperature Monitor indication	45 units	Normal
--------------------------------------	----------	--------

This text is fictional and exists only to give the prototype realistic volume and structure. During engine start, the pilot monitoring should select the Bleed Air Supply annunciation if a discrepancy is observed. During landing, the First Officer should record the Auxiliary Power Unit advisory when the associated caution light remains illuminated.

Both pilots will announce any change in the Flight Management Computer annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Engine Anti-Ice status message that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. The first officer will confirm any change in the Nosewheel Steering annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Thrust Reverser is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The Cargo Smoke Detection selector position that differs from the expected state requires both pilots to verify the condition once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. The Wing Anti-Ice quantity display that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autopilot Channel B selector position	18 units	Normal
Primary Electrical Bus status message	36 units	Refer to related topic
Landing Gear Indication status message	50 units	Advisory only

The Fire Detection Loop indication that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. If the Window Heat is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice quantity display is expected to read within the sample range of 24 to 33 units during a diversion.

18.30.2 Transponder Overview

If the Autopilot Channel B is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The Engine Anti-Ice indication is expected to read within the sample range of 44 to 47 units during takeoff. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will verify any change in the Pack Temperature Control selector position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context.

If the Ground Proximity Monitor is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

NOTE: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Cockpit Voice Recorder indication	4 units	Advisory only
Nosewheel Steering status message	67 units	Refer to related topic
Hydraulic System A annunciation	44 units	Advisory only

NOTE: The Hydraulic System B quantity display that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. During parking, the Captain

should confirm the Fuel Crossfeed quantity display unless directed otherwise by the Sample Operations Center.

- During engine start, the pilot flying should announce the Cargo Smoke Detection indication when the associated caution light remains illuminated.
- The pilot flying will select any change in the Window Heat indication and advise the other pilot if the indication does not stabilize within the sample interval.
- The first officer will announce any change in the Auxiliary Power Unit selector position and advise the other pilot when operating at a sample station without ground power.
- The relief pilot will cross-check any change in the Autopilot Channel A advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During landing, both pilots should select the Center Tank Pumps annunciation when the associated caution light remains illuminated.
- If the Autothrottle is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- The pilot flying will select any change in the Stall Warning annunciation and advise the other pilot once the checklist item is complete.

18.30.3 Brake Temperature Monitor Interfaces

During a maintenance-requested ground run, the pilot monitoring should brief the Brake Temperature Monitor quantity display when conditions permit. The Landing Gear Indication quantity display that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. During taxi, the pilot flying should select the Hydraulic System B quantity display if the indication does not stabilize within the sample interval.

During cruise, the relief pilot should record the Cabin Pressure Controller annunciation before the next phase of flight. During parking, both pilots should select the Speedbrake Handle selector position before the next phase of flight. The Center Tank Pumps quantity display that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. The Cockpit Voice Recorder selector position that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. The pilot monitoring will cross-check any change in the Auxiliary Power Unit quantity display and advise the other pilot before the next phase of flight. During a turnaround, the relief pilot should record the Ground Proximity Monitor status message if the indication does not stabilize within the sample interval. If the Autobrake Selector is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

- Refer to the related topic for additional sample context.
- If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- If the Cabin Pressure Controller is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- This text is fictional and exists only to give the prototype realistic volume and structure.

Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the First Officer should monitor the Cargo Smoke Detection status message when the associated caution light remains illuminated. The Oxygen Distribution switch position that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed.

18.30.4 Probe Heat Normal Operation

The Thrust Reverser selector position that differs from the expected state requires the First Officer to cross-check the condition when conditions permit. The pilot monitoring will brief any change in the Fuel Crossfeed quantity display and advise the other pilot if a discrepancy is observed. The first officer will record any change in the Center Tank Pumps selector position and advise the other pilot when conditions permit. During climb, the pilot flying should announce the Auxiliary Power Unit annunciation if a discrepancy is observed. The Cabin Pressure Controller switch position is expected to read within the sample range of 65 to 75 units during preflight. The Stall Warning advisory is expected to read within the sample range of 17 to 29 units during a turnaround.

Condition	Sample value	Remarks
Auxiliary Power Unit indication	54 units	Refer to related topic
Standby Instruments indication	33 units	Advisory only
Fire Detection Loop selector position	95 units	Normal
Window Heat advisory	83 units	Refer to related topic
Engine Anti-Ice selector position	52 units	Advisory only
Nosewheel Steering switch position	1 units	Monitor

- The Autopilot Channel A indication that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit.
- The pilot flying will select any change in the Flap Position Indication switch position and advise the other pilot if a discrepancy is observed.
- Refer to the related topic for additional sample context.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The first officer will select any change in the Hydraulic System B selector position and advise the other pilot once the checklist item is complete. If the Cabin Pressure Controller is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During approach, the Captain should select the Standby Instruments indication before the next phase of flight.

CAUTION: The captain will select any change in the Cockpit Voice Recorder selector position and advise the other pilot when the associated caution light remains illuminated.

Values in this manual are invented and must not be used for any operational purpose. The Pack Temperature Control indication is expected to read within the sample range of 67 to 74 units during takeoff. The Center Tank Pumps status message is expected to read within the sample range of 85 to 95 units during taxi. The Stall Warning status message that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight. See 05.30.3 Autopilot Channel B Overview.

Condition	Sample value	Remarks
Wing Anti-Ice indication	39 units	Advisory only
Autopilot Channel B status message	62 units	Monitor
Weather Radar indication	60 units	Refer to related topic
Autopilot Channel A annunciation	71 units	Refer to related topic
Primary Electrical Bus advisory	6 units	Normal
Cockpit Voice Recorder quantity display	89 units	Refer to related topic
Standby Hydraulic advisory	22 units	Advisory only

- The wording here is placeholder content shaped like a procedure, not a procedure.

- During landing, the First Officer should announce the Transponder status message if a discrepancy is observed.
- During taxi, the relief pilot should cross-check the Auxiliary Power Unit advisory unless directed otherwise by the Sample Operations Center.
- If the Standby Instruments is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.
- If the Engine Anti-Ice is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Auxiliary Power Unit switch position	29 units	Monitor
Engine Anti-Ice switch position	57 units	Normal
Speedbrake Handle annunciation	33 units	Monitor
Speedbrake Handle annunciation	67 units	Refer to related topic

18.30.5 *Nosewheel Steering Test*

If the Center Tank Pumps is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. During a turnaround, the pilot flying should cross-check the Cabin Pressure Controller quantity display if the indication does not stabilize within the sample interval. During engine start, the First Officer should announce the Standby Instruments quantity display if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

Both pilots will verify any change in the Flap Position Indication advisory and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. If the Standby Hydraulic is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. During a diversion, the relief pilot should monitor the Fuel Crossfeed annunciation if a discrepancy is observed.

NOTE: During descent, both pilots should announce the Pack Temperature Control status message if a discrepancy is observed. Refer to the related topic for additional sample context.

If the Speedbrake Handle is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Fire Detection Loop selector position that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. If the Probe Heat is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Flap Position Indication annunciation that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval. If the Transponder is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. See 16.10.13 Ground Proximity Monitor Test.

NOTE: During descent, the pilot flying should brief the Thrust Reverser indication if a discrepancy is observed. The Autopilot Channel B quantity display is expected to read within the sample range of 67 to 74 units during approach.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

18.30.6 *Stall Warning Normal Operation*

Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The Autobrake Selector advisory that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. During engine start, the First Officer should confirm the Fire Detection Loop advisory unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display annunciation that differs from the expected state requires both pilots to select the condition when conditions permit.

NOTE: Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The captain will monitor any change in the Engine Anti-Ice switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The first officer will confirm any change in the Ground Proximity Monitor status message and advise the other pilot once the checklist item is complete.
- The Wing Anti-Ice selector position that differs from the expected state requires the pilot flying to select the condition when conditions permit.

The Auxiliary Power Unit switch position is expected to read within the sample range of 58 to 62 units during an extended ground delay. If the Autopilot Channel B is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Flap Position Indication quantity display is expected to read within the sample range of 35 to 41 units during climb.

Condition	Sample value	Remarks
Window Heat advisory	77 units	Refer to related topic
Cargo Smoke Detection indication	16 units	Normal
Flight Management Computer indication	12 units	Monitor
Brake Temperature Monitor status message	63 units	Advisory only
Probe Heat status message	49 units	Advisory only
Window Heat switch position	11 units	Normal
Stall Warning switch position	47 units	Advisory only

The Standby Hydraulic status message is expected to read within the sample range of 21 to 33 units during approach. The Fuel Crossfeed status message that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. During an extended ground delay, the First Officer should confirm the Autopilot Channel A indication once the checklist item is complete. The Thrust Reverser status message is expected to read within the sample range of 70 to 82 units during parking. The captain will verify any change in the Auxiliary Power Unit annunciation and advise the other pilot if a discrepancy is observed. See 12.10.7 Fire Detection Loop Indications.

- During descent, the First Officer should select the Engine Anti-Ice annunciation when operating at a sample station without ground power.
- During taxi, the pilot flying should verify the Brake Temperature Monitor quantity display when operating at a sample station without ground power.
- Both pilots will monitor any change in the Stall Warning switch position and advise the other pilot before the next phase of flight.
- During engine start, the pilot monitoring should select the Weather Radar status message when conditions permit.

18.30.7 Speedbrake Handle Interfaces

The Speedbrake Handle indication that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed. If the Hydraulic System B is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. During approach, both pilots should confirm the Brake Temperature Monitor advisory when the associated caution light remains illuminated. The Standby Instruments status message is expected to read within the sample range of 79 to 82 units during approach. The pilot monitoring will brief any change in the Cabin Pressure Controller advisory and advise the other pilot if the indication does not stabilize within the

sample interval. The Hydraulic System A switch position that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed.

NOTE: Both pilots will verify any change in the Landing Gear Indication annunciation and advise the other pilot when conditions permit.

The Probe Heat switch position that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated. If the Transponder is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During a turnaround, both pilots should record the Thrust Reverser advisory before the next phase of flight. During parking, the Captain should monitor the Stall Warning quantity display when the associated caution light remains illuminated. During engine start, the Captain should monitor the Wing Anti-Ice status message when operating at a sample station without ground power. If the Center Tank Pumps is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

During a diversion, the Captain should cross-check the Autothrottle quantity display when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The Primary Electrical Bus annunciation that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center. The Engine Anti-Ice status message is expected to read within the sample range of 3 to 11 units during approach.

- The Ground Proximity Monitor indication is expected to read within the sample range of 37 to 41 units during descent.
- The Nosewheel Steering annunciation is expected to read within the sample range of 75 to 83 units during a diversion.
- Refer to the related topic for additional sample context.
- During a diversion, the pilot flying should select the Thrust Reverser quantity display once the checklist item is complete.
- If the Flight Management Computer is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

NOTE: The pilot flying will record any change in the Fire Detection Loop indication and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

18.30.8 Speedbrake Handle Reset Guidance

The Brake Temperature Monitor advisory is expected to read within the sample range of 69 to 76 units during approach. During climb, both pilots should cross-check the Flight Management Computer annunciation when operating at a sample station without ground power. If the Autopilot Channel A is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The relief pilot will monitor any change in the Weather Radar annunciation and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will record any change in the Standby Hydraulic status message and advise the other pilot before the next phase of flight.

The relief pilot will brief any change in the Autobrake Selector indication and advise the other pilot if a discrepancy is observed. If the Brake Temperature Monitor is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Ground Proximity Monitor status message is expected to read within the sample range of 94 to 98 units during preflight. The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete.

The Hydraulic System A advisory is expected to read within the sample range of 24 to 28 units during takeoff. The pilot flying will announce any change in the Nosewheel Steering selector position and advise the other pilot once the checklist item is complete. If the Wing Anti-Ice is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During a diversion, the Captain should verify the Engine Anti-Ice advisory when conditions permit. The Bleed Air Supply status message that differs from the expected state requires both pilots to announce the condition unless directed otherwise by the Sample Operations Center. See 05.30.3 Autopilot Channel B Overview.

NOTE: The Primary Electrical Bus indication that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power.

18.30.9 New Sample Topic: Thrust Reverser

This text is fictional and exists only to give the prototype realistic volume and structure. The Flight Management Computer advisory is expected to read within the sample range of 94 to 99 units during parking. If the Weather Radar is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

- The Autothrottle indication is expected to read within the sample range of 32 to 35 units during parking.
- The Engine Anti-Ice quantity display that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval.
- If the Standby Hydraulic is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The Oxygen Distribution selector position is expected to read within the sample range of 65 to 77 units during engine start.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During parking, the pilot monitoring should brief the Cabin Pressure Controller advisory if a discrepancy is observed.
- The pilot flying will announce any change in the Landing Gear Indication advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Bleed Air Supply is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Bleed Air Supply advisory	62 units	Advisory only
Traffic Advisory Display quantity display	45 units	Monitor
Autobrake Selector status message	67 units	Advisory only
Autothrottle switch position	59 units	Advisory only
Autopilot Channel B advisory	28 units	Advisory only
Pack Temperature Control advisory	68 units	Normal

The Fire Detection Loop indication is expected to read within the sample range of 49 to 57 units during parking. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. During parking, both pilots should announce the Autopilot Channel A status message if the indication does not stabilize within the sample interval. The pilot flying will confirm any change in the Weather Radar selector position and advise the other pilot if a discrepancy is observed.

18.30.10 Hydraulic System B Reset Guidance

The Standby Hydraulic annunciation is expected to read within the sample range of 30 to 38 units during engine start. During parking, the First Officer should brief the Bleed Air Supply annunciation unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor advisory that differs from the expected state requires the Captain to confirm the condition when conditions permit. See 09.30.15 Nosewheel Steering Overview.

Condition	Sample value	Remarks
Hydraulic System B indication	28 units	Refer to related topic
Wing Anti-Ice selector position	88 units	Refer to related topic
Center Tank Pumps status message	46 units	Monitor
Hydraulic System A annunciation	89 units	Refer to related topic
Window Heat annunciation	12 units	Advisory only
Primary Electrical Bus status message	52 units	Advisory only

Condition	Sample value	Remarks
Nosewheel Steering switch position	56 units	Monitor
Fire Detection Loop status message	47 units	Monitor
Primary Electrical Bus quantity display	80 units	Monitor
Autopilot Channel B quantity display	79 units	Normal
Window Heat status message	31 units	Monitor
Window Heat annunciation	82 units	Monitor
Autobrake Selector quantity display	89 units	Normal

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Flap Position Indication indication	88 units	Monitor
Weather Radar quantity display	93 units	Advisory only
Thrust Reverser annunciation	78 units	Refer to related topic
Ground Proximity Monitor advisory	90 units	Monitor

CAUTION: If the Speedbrake Handle is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

- During a diversion, both pilots should record the Engine Anti-Ice quantity display once the checklist item is complete.
- The Cargo Smoke Detection advisory that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval.
- The captain will monitor any change in the Transponder switch position and advise the other pilot if a discrepancy is observed.
- During climb, the pilot monitoring should brief the Thrust Reverser advisory if a discrepancy is observed.

CAUTION: The Autobrake Selector annunciation is expected to read within the sample range of 6 to 14 units during climb. During taxi, the Captain should record the Standby Instruments quantity display if the indication does not stabilize within the sample interval.

18.30.11 Primary Electrical Bus Limits Display

The Stall Warning status message is expected to read within the sample range of 67 to 75 units during approach. Both pilots will monitor any change in the Transponder annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Autothrottle is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The relief pilot will monitor any change in the Auxiliary Power Unit selector position and advise the other pilot when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

The Cargo Smoke Detection indication is expected to read within the sample range of 25 to 34 units during climb. The Transponder quantity display that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. The Transponder indication that differs from the expected state requires both pilots to select the condition if a discrepancy is observed.

The Autopilot Channel B switch position is expected to read within the sample range of 28 to 37 units during a diversion. The captain will monitor any change in the Standby Instruments quantity display and advise the other pilot if a discrepancy is observed. The captain will verify any change in the Autothrottle status message and advise the other pilot once the checklist item is complete.

During a diversion, the relief pilot should verify the Cargo Smoke Detection annunciation once the checklist item is complete. The Autobrake Selector status message is expected to read within the sample range of 96 to 104 units during an extended ground delay. If the Autobrake Selector is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The pilot flying will select any change in the Wing Anti-Ice selector position and advise the other pilot when conditions permit. During approach, the pilot monitoring should cross-check the Window Heat quantity display when conditions permit. Refer to the related topic for additional sample context.

The Flight Management Computer annunciation is expected to read within the sample range of 60 to 71 units during parking. The Hydraulic System B quantity display is expected to read within the sample range of 60 to 69 units during cruise. If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Brake Temperature Monitor indication	6 units	Refer to related topic
Auxiliary Power Unit selector position	73 units	Refer to related topic
Nosewheel Steering switch position	92 units	Normal
Autopilot Channel B switch position	73 units	Refer to related topic
Weather Radar annunciation	12 units	Normal
Wing Anti-Ice status message	70 units	Normal

NOTE: The Autobrake Selector selector position is expected to read within the sample range of 95 to 98 units during an extended ground delay. If the Primary Electrical Bus is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The Transponder indication is expected to read within the sample range of 98 to 110 units during approach. The Fire Detection Loop indication that differs from the expected state requires the relief pilot to select the condition when conditions permit. The captain will announce any change in the Probe Heat switch position and advise the other pilot when the associated caution light remains illuminated. The Probe Heat switch position is expected to read within the sample range of 58 to 68 units during a turnaround.

18.30.12 Auxiliary Power Unit Status Messages

The Cabin Pressure Controller indication is expected to read within the sample range of 16 to 28 units during climb. The Standby Instruments annunciation is expected to read within the sample range of 20 to 25 units during climb. The relief pilot will verify any change in the Bleed Air Supply switch position and advise the other pilot before the next

phase of flight.

CAUTION: The captain will confirm any change in the Hydraulic System A switch position and advise the other pilot when conditions permit.

The first officer will record any change in the Engine Anti-Ice selector position and advise the other pilot when conditions permit. If the Autopilot Channel A is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The Flight Management Computer annunciation is expected to read within the sample range of 41 to 49 units during a turnaround. The pilot monitoring will announce any change in the Ground Proximity Monitor switch position and advise the other pilot when operating at a sample station without ground power.

NOTE: If the Standby Instruments is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

CAUTION: The pilot monitoring will brief any change in the Fire Detection Loop advisory and advise the other pilot if a discrepancy is observed. If the Weather Radar is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the First Officer should brief the Thrust Reverser advisory if the indication does not stabilize within the sample interval.

NOTE: Both pilots will select any change in the Cabin Pressure Controller quantity display and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Weather Radar indication	97 units	Advisory only
Probe Heat indication	23 units	Normal
Hydraulic System A switch position	81 units	Normal
Cargo Smoke Detection switch position	51 units	Advisory only

The Speedbrake Handle advisory is expected to read within the sample range of 81 to 90 units during cruise. During a maintenance-requested ground run, the pilot monitoring should record the Autothrottle indication when operating at a sample station without ground power. The pilot flying will verify any change in the Standby Hydraulic status message and advise the other pilot before the next phase of flight. The Probe Heat annunciation that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. During approach, the pilot monitoring should cross-check the Flight Management Computer annunciation when conditions permit.

18.30.13 Nosewheel Steering Overview

During a turnaround, the pilot monitoring should select the Bleed Air Supply indication before the next phase of flight. If the Weather Radar is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Thrust Reverser selector position is expected to read within the sample range of 84 to 90 units during landing. The Landing Gear Indication quantity display that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.

NOTE: During engine start, the relief pilot should record the Primary Electrical Bus switch position unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller quantity display is expected to read within the sample range of 45 to 57 units during a turnaround.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will announce any change in the Pack Temperature Control switch position and advise the other pilot when the associated caution light remains illuminated.

CAUTION: If the Flap Position Indication is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the

sample interval.

- The Autopilot Channel B quantity display is expected to read within the sample range of 31 to 38 units during a maintenance-requested ground run.
- Values in this manual are invented and must not be used for any operational purpose.
- Both pilots will select any change in the Flight Management Computer advisory and advise the other pilot once the checklist item is complete.

The first officer will verify any change in the Traffic Advisory Display selector position and advise the other pilot when operating at a sample station without ground power. The Autopilot Channel B indication that differs from the expected state requires the Captain to monitor the condition when conditions permit. The Cargo Smoke Detection selector position is expected to read within the sample range of 56 to 59 units during cruise. If the Cockpit Voice Recorder is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Nosewheel Steering quantity display that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated.

The Flight Management Computer selector position that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed. The Wing Anti-Ice status message is expected to read within the sample range of 28 to 34 units during climb. The Cockpit Voice Recorder advisory that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval. The Standby Hydraulic annunciation is expected to read within the sample range of 42 to 51 units during approach. The Flight Management Computer advisory is expected to read within the sample range of 75 to 81 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Autothrottle annunciation	54 units	Normal
Standby Hydraulic indication	57 units	Normal
Auxiliary Power Unit selector position	42 units	Refer to related topic
Flight Management Computer indication	18 units	Monitor
Fire Detection Loop quantity display	53 units	Advisory only

NOTE: If the Standby Instruments is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Autopilot Channel B quantity display that differs from the expected state requires the Captain to record the condition once the checklist item is complete.

18.30.14 Center Tank Pumps Overview

During landing, the First Officer should record the Cabin Pressure Controller indication when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution quantity display is expected to read within the sample range of 73 to 82 units during cruise.

NOTE: The Brake Temperature Monitor indication that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Auxiliary Power Unit quantity display	90 units	Normal
Pack Temperature Control indication	42 units	Monitor
Autobrake Selector quantity display	65 units	Monitor

- During climb, the relief pilot should verify the Wing Anti-Ice indication when conditions permit.
- The Auxiliary Power Unit selector position is expected to read within the sample range of 43 to 53 units during engine start.

- During descent, the pilot monitoring should select the Cockpit Voice Recorder advisory when operating at a sample station without ground power.

The Transponder selector position that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated. The Traffic Advisory Display indication is expected to read within the sample range of 51 to 59 units during parking. This text is fictional and exists only to give the prototype realistic volume and structure. During landing, both pilots should record the Thrust Reverser switch position unless directed otherwise by the Sample Operations Center. See 11.10.1 Autopilot Channel A Crew Awareness.

- If the Engine Anti-Ice is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- The Ground Proximity Monitor quantity display that differs from the expected state requires both pilots to brief the condition before the next phase of flight.
- During descent, the pilot monitoring should record the Stall Warning quantity display if a discrepancy is observed.

18.30.15 Stall Warning Normal Operation

Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle status message that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed. The first officer will brief any change in the Traffic Advisory Display status message and advise the other pilot before the next phase of flight. During engine start, the First Officer should record the Flap Position Indication indication if the indication does not stabilize within the sample interval. The Auxiliary Power Unit selector position that differs from the expected state requires the relief pilot to record the condition before the next phase of flight.

CAUTION: If the Thrust Reverser is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. During an extended ground delay, the First Officer should brief the Wing Anti-Ice advisory before the next phase of flight.

The captain will confirm any change in the Transponder status message and advise the other pilot when conditions permit. The Primary Electrical Bus quantity display is expected to read within the sample range of 52 to 55 units during climb. The Speedbrake Handle switch position that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power. If the Pack Temperature Control is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

- If the Nosewheel Steering is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Weather Radar advisory is expected to read within the sample range of 62 to 65 units during cruise.
- Values in this manual are invented and must not be used for any operational purpose.

CAUTION: During a maintenance-requested ground run, the pilot flying should announce the Traffic Advisory Display advisory before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

The first officer will announce any change in the Flight Management Computer indication and advise the other pilot before the next phase of flight. If the Engine Anti-Ice is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Center Tank Pumps advisory is expected to read within the sample range of 23 to 32 units during descent.

The Window Heat advisory is expected to read within the sample range of 66 to 77 units during takeoff. The first officer will select any change in the Nosewheel Steering status message and advise the other pilot unless directed

otherwise by the Sample Operations Center. The Transponder annunciation that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. During landing, the First Officer should select the Ground Proximity Monitor annunciation if the indication does not stabilize within the sample interval. If the Engine Anti-Ice is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

CAUTION: During cruise, the relief pilot should select the Pack Temperature Control quantity display unless directed otherwise by the Sample Operations Center.

18.30.16 Cabin Pressure Controller Crew Awareness

Refer to the related topic for additional sample context. During engine start, the pilot flying should cross-check the Brake Temperature Monitor status message if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. During preflight, the pilot flying should record the Landing Gear Indication quantity display when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The Landing Gear Indication switch position that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed.

If the Wing Anti-Ice is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will monitor any change in the Wing Anti-Ice quantity display and advise the other pilot when conditions permit.

CAUTION: If the Brake Temperature Monitor is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

- The relief pilot will confirm any change in the Cargo Smoke Detection indication and advise the other pilot once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- Refer to the related topic for additional sample context.

CAUTION: The Bleed Air Supply advisory is expected to read within the sample range of 57 to 67 units during engine start.

The Traffic Advisory Display switch position is expected to read within the sample range of 42 to 48 units during preflight. During a turnaround, both pilots should select the Center Tank Pumps status message unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. During cruise, the Captain should verify the Ground Proximity Monitor switch position when the associated caution light remains illuminated.

During taxi, the pilot flying should monitor the Hydraulic System A switch position if a discrepancy is observed. The Speedbrake Handle advisory is expected to read within the sample range of 84 to 94 units during engine start. The wording here is placeholder content shaped like a procedure, not a procedure. During descent, both pilots should verify the Hydraulic System B annunciation before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments selector position that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center.

18.30.17 Autopilot Channel B Overview

Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. The Center Tank Pumps advisory is expected to read within the sample range of 44 to 53 units during engine start. The captain will record any change in the Primary Electrical

Bus quantity display and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During climb, the First Officer should monitor the Speedbrake Handle advisory when conditions permit.

Refer to the related topic for additional sample context. The Stall Warning switch position that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector switch position that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed. During cruise, the First Officer should record the Bleed Air Supply status message before the next phase of flight.

Condition	Sample value	Remarks
Engine Anti-Ice selector position	84 units	Monitor
Landing Gear Indication status message	40 units	Advisory only
Primary Electrical Bus switch position	14 units	Normal
Autobrake Selector switch position	40 units	Advisory only
Flap Position Indication indication	31 units	Normal

If the Hydraulic System B is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control selector position that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. If the Traffic Advisory Display is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Autopilot Channel B quantity display and advise the other pilot when the associated caution light remains illuminated. During landing, the Captain should verify the Oxygen Distribution annunciation before the next phase of flight.

The Hydraulic System B selector position that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. The Autopilot Channel A annunciation is expected to read within the sample range of 43 to 50 units during cruise. Values in this manual are invented and must not be used for any operational purpose. During descent, the pilot flying should brief the Autopilot Channel A advisory when conditions permit.

During takeoff, the pilot flying should cross-check the Flight Management Computer annunciation when the associated caution light remains illuminated. The Nosewheel Steering annunciation that differs from the expected state requires both pilots to select the condition when conditions permit. During takeoff, the Captain should select the Hydraulic System A annunciation when the associated caution light remains illuminated. The Stall Warning selector position is expected to read within the sample range of 7 to 13 units during descent.

The pilot flying will confirm any change in the Autobrake Selector indication and advise the other pilot once the checklist item is complete. If the Thrust Reverser is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Engine Anti-Ice switch position that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. The pilot flying will announce any change in the Ground Proximity Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will cross-check any change in the Traffic Advisory Display switch position and advise the other pilot before the next phase of flight. The captain will announce any change in the Fuel Crossfeed indication and advise the other pilot once the checklist item is complete.

Chapter 19 Performance

19.10 Takeoff Performance

19.10.1 Takeoff Performance Table 1

If the Landing Gear Indication is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The captain will confirm any change in the Autobrake Selector indication and advise the other pilot if a discrepancy is observed. The Flap Position Indication quantity display is expected to read within the sample range of 6 to 13 units during descent. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During takeoff, the pilot flying should cross-check the Fire Detection Loop annunciation when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

CAUTION: The first officer will confirm any change in the Oxygen Distribution advisory and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Center Tank Pumps is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

NOTE: If the Cargo Smoke Detection is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Center Tank Pumps indication that differs from the expected state requires the pilot monitoring to select the condition when conditions permit.

Condition	Sample value	Remarks
Autobrake Selector switch position	5 units	Refer to related topic
Primary Electrical Bus quantity display	86 units	Advisory only
Hydraulic System A annunciation	30 units	Monitor
Bleed Air Supply selector position	61 units	Refer to related topic
Autobrake Selector switch position	31 units	Refer to related topic
Thrust Reverser advisory	22 units	Refer to related topic

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will announce any change in the Engine Anti-Ice selector position and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. Both pilots will select any change in the Window Heat status message and advise the other pilot if the indication does not stabilize within the sample interval. If the Cabin Pressure Controller is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel B quantity display that differs from the expected state requires the Captain to brief the condition once the checklist item is complete.

- The Autopilot Channel B status message that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated.
- The pilot flying will cross-check any change in the Nosewheel Steering advisory and advise the other pilot when the associated caution light remains illuminated.
- The Transponder annunciation that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval.

- During approach, the Captain should cross-check the Bleed Air Supply quantity display unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The first officer will verify any change in the Traffic Advisory Display status message and advise the other pilot before the next phase of flight.
- The Fuel Crossfeed switch position that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.

19.10.2 Takeoff Performance Table 2

During landing, the relief pilot should select the Cargo Smoke Detection indication once the checklist item is complete. If the Brake Temperature Monitor is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Auxiliary Power Unit annunciation is expected to read within the sample range of 29 to 38 units during climb.

CAUTION: The Fuel Crossfeed selector position that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.

During a maintenance-requested ground run, the Captain should cross-check the Fuel Crossfeed advisory if the indication does not stabilize within the sample interval. The Thrust Reverser quantity display that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. If the Autopilot Channel A is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

NOTE: During an extended ground delay, the relief pilot should announce the Fire Detection Loop annunciation when conditions permit. The relief pilot will select any change in the Window Heat annunciation and advise the other pilot once the checklist item is complete.

CAUTION: During climb, both pilots should cross-check the Wing Anti-Ice status message if a discrepancy is observed. During a maintenance-requested ground run, the pilot monitoring should select the Speedbrake Handle selector position when conditions permit.

During an extended ground delay, the pilot flying should announce the Weather Radar quantity display if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Auxiliary Power Unit advisory that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. If the Stall Warning is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

- The Cockpit Voice Recorder status message that differs from the expected state requires both pilots to verify the condition when conditions permit.
- The first officer will verify any change in the Weather Radar indication and advise the other pilot once the checklist item is complete.
- The Stall Warning selector position that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval.
- The pilot monitoring will confirm any change in the Hydraulic System B status message and advise the other pilot when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.

The relief pilot will select any change in the Autobrake Selector quantity display and advise the other pilot once the checklist item is complete. If the Autopilot Channel A is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. During landing, the Captain should brief the Thrust Reverser status message before the next phase of flight. During parking, the Captain should brief the Fire Detection Loop indication if the indication does not stabilize within the sample interval. The pilot monitoring will monitor any change in the Autopilot Channel A annunciation and advise the other pilot when conditions permit. If the Flight Management Computer is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

19.10.3 Center Tank Pumps Normal Operation

The Hydraulic System A advisory that differs from the expected state requires both pilots to select the condition once the checklist item is complete. The Autothrottle status message is expected to read within the sample range of 34 to 37 units during an extended ground delay. The pilot flying will cross-check any change in the Autopilot Channel B switch position and advise the other pilot if a discrepancy is observed. During approach, both pilots should confirm the Probe Heat status message before the next phase of flight.

Condition	Sample value	Remarks
Auxiliary Power Unit annunciation	84 units	Normal
Landing Gear Indication selector position	36 units	Monitor
Wing Anti-Ice annunciation	17 units	Monitor

Condition	Sample value	Remarks
Fire Detection Loop selector position	19 units	Monitor
Oxygen Distribution annunciation	65 units	Refer to related topic
Autopilot Channel B indication	68 units	Advisory only
Fire Detection Loop annunciation	79 units	Advisory only
Center Tank Pumps annunciation	32 units	Monitor
Window Heat indication	40 units	Monitor
Auxiliary Power Unit selector position	61 units	Refer to related topic

- Refer to the related topic for additional sample context.
- During descent, the pilot monitoring should announce the Nosewheel Steering indication if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.

During approach, the pilot monitoring should cross-check the Brake Temperature Monitor indication before the next phase of flight. The Thrust Reverser switch position that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. The pilot flying will brief any change in the Autobrake Selector advisory and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the pilot flying should record the Ground Proximity Monitor quantity display when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Landing Gear Indication indication	66 units	Advisory only
Brake Temperature Monitor quantity display	32 units	Normal
Cabin Pressure Controller status message	65 units	Advisory only
Transponder quantity display	25 units	Normal
Ground Proximity Monitor status message	52 units	Refer to related topic

Condition	Sample value	Remarks
Engine Anti-Ice switch position	1 units	Refer to related topic
Engine Anti-Ice indication	26 units	Advisory only
Transponder status message	7 units	Normal
Fuel Crossfeed quantity display	59 units	Refer to related topic
Bleed Air Supply annunciation	97 units	Monitor
Hydraulic System B indication	72 units	Monitor
Flight Management Computer quantity display	89 units	Monitor

- The Autopilot Channel A indication that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power.
- The Fire Detection Loop indication that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete.
- The Nosewheel Steering advisory that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power.
- During landing, the Captain should monitor the Flap Position Indication switch position if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Hydraulic System A switch position	29 units	Normal
Center Tank Pumps status message	20 units	Advisory only
Probe Heat status message	6 units	Normal
Autopilot Channel A selector position	97 units	Refer to related topic
Standby Hydraulic annunciation	30 units	Normal
Center Tank Pumps quantity display	10 units	Advisory only

Challenge	Response
Center Tank Pumps	Closed
Bleed Air Supply	Off
Pack Temperature Control	Armed
Standby Instruments	As required
Auxiliary Power Unit	On
Flight Management Computer	Checked
Cargo Smoke Detection	Verified
Hydraulic System A	Checked
Traffic Advisory Display	Set

19.10.4 Takeoff Performance Table 3

The Autopilot Channel B indication that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated. The pilot flying will brief any change in the Pack Temperature Control indication and advise the other pilot when operating at a sample station without ground power. During a diversion, the Captain should brief the Landing Gear Indication quantity display before the next phase of flight. The Autopilot Channel B advisory that differs from the expected state requires the relief pilot to record the condition when

conditions permit. Refer to the related topic for additional sample context.

During preflight, the pilot flying should monitor the Thrust Reverser indication unless directed otherwise by the Sample Operations Center. During takeoff, the First Officer should select the Autobrake Selector switch position if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Brake Temperature Monitor switch position that differs from the expected state requires both pilots to announce the condition before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

- During climb, the First Officer should announce the Speedbrake Handle indication once the checklist item is complete.
- If the Primary Electrical Bus is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- During preflight, the Captain should confirm the Autobrake Selector indication when conditions permit.
- The Traffic Advisory Display status message is expected to read within the sample range of 3 to 13 units during landing.
- During a maintenance-requested ground run, the pilot monitoring should select the Cockpit Voice Recorder indication once the checklist item is complete.

The Flight Management Computer switch position is expected to read within the sample range of 81 to 86 units during takeoff. Refer to the related topic for additional sample context. During cruise, the Captain should cross-check the Flap Position Indication selector position if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. If the Nosewheel Steering is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

The Fire Detection Loop advisory is expected to read within the sample range of 43 to 49 units during approach. The pilot flying will monitor any change in the Oxygen Distribution quantity display and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the relief pilot should monitor the Primary Electrical Bus quantity display when operating at a sample station without ground power. During descent, the pilot monitoring should announce the Wing Anti-Ice indication unless directed otherwise by the Sample Operations Center. If the Ground Proximity Monitor is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

The relief pilot will verify any change in the Fire Detection Loop advisory and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder switch position is expected to read within the sample range of 80 to 88 units during engine start. The Hydraulic System B switch position that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center. During parking, the relief pilot should cross-check the Cargo Smoke Detection selector position when conditions permit. See 05.60.12 Standby Hydraulic Status Messages.

CAUTION: If the Wing Anti-Ice is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cabin Pressure Controller selector position	6 units	Monitor
Nosewheel Steering quantity display	72 units	Monitor
Standby Hydraulic annunciation	6 units	Monitor
Fuel Crossfeed advisory	39 units	Advisory only
Flap Position Indication status message	95 units	Refer to related topic
Cargo Smoke Detection annunciation	51 units	Normal

Condition	Sample value	Remarks
-----------	--------------	---------

Flap Position Indication indication	29 units	Refer to related topic
Speedbrake Handle indication	88 units	Refer to related topic
Weather Radar indication	66 units	Advisory only
Probe Heat indication	58 units	Monitor

19.10.5 Takeoff Performance Table 4

During a turnaround, the First Officer should verify the Flap Position Indication indication once the checklist item is complete. During preflight, the pilot monitoring should select the Fuel Crossfeed quantity display before the next phase of flight. If the Fuel Crossfeed is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector switch position is expected to read within the sample range of 11 to 19 units during cruise. The Nosewheel Steering selector position that differs from the expected state requires the Captain to record the condition when the associated caution light remains illuminated.

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. If the Center Tank Pumps is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. If the Pack Temperature Control is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

- Refer to the related topic for additional sample context.
- The Landing Gear Indication advisory is expected to read within the sample range of 6 to 12 units during approach.
- The Probe Heat indication that differs from the expected state requires both pilots to announce the condition once the checklist item is complete.
- During a diversion, both pilots should cross-check the Ground Proximity Monitor indication before the next phase of flight.

CAUTION: The captain will record any change in the Primary Electrical Bus advisory and advise the other pilot once the checklist item is complete.

- The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight.
- Values in this manual are invented and must not be used for any operational purpose.
- The Brake Temperature Monitor annunciation is expected to read within the sample range of 63 to 69 units during a turnaround.
- The pilot monitoring will cross-check any change in the Auxiliary Power Unit selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Standby Instruments is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The captain will cross-check any change in the Ground Proximity Monitor annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The pilot flying will brief any change in the Flight Management Computer status message and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Pack Temperature Control selector position	5 units	Advisory only
Speedbrake Handle indication	77 units	Monitor

Primary Electrical Bus annunciation	57 units	Refer to related topic
-------------------------------------	----------	------------------------

During a maintenance-requested ground run, both pilots should confirm the Cargo Smoke Detection status message before the next phase of flight. The Ground Proximity Monitor indication that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display status message that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. If the Hydraulic System B is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The first officer will monitor any change in the Standby Hydraulic selector position and advise the other pilot if a discrepancy is observed. During a maintenance-requested ground run, the Captain should cross-check the Auxiliary Power Unit advisory if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will verify any change in the Fire Detection Loop switch position and advise the other pilot once the checklist item is complete. The Hydraulic System B selector position is expected to read within the sample range of 61 to 71 units during engine start. If the Thrust Reverser is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. During taxi, the First Officer should verify the Fire Detection Loop status message once the checklist item is complete.

19.10.6 Takeoff Performance Table 5

During approach, the Captain should select the Cockpit Voice Recorder status message if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, the relief pilot should monitor the Cargo Smoke Detection switch position unless directed otherwise by the Sample Operations Center. If the Brake Temperature Monitor is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Nosewheel Steering selector position	35 units	Monitor
Pack Temperature Control annunciation	90 units	Monitor
Wing Anti-Ice advisory	43 units	Monitor
Landing Gear Indication status message	63 units	Advisory only

NOTE: During climb, the pilot flying should monitor the Cabin Pressure Controller advisory unless directed otherwise by the Sample Operations Center.

CAUTION: The Fuel Crossfeed advisory is expected to read within the sample range of 58 to 70 units during a turnaround.

During engine start, the First Officer should select the Oxygen Distribution selector position once the checklist item is complete. If the Flight Management Computer is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

19.10.7 Takeoff Performance Table 6

This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control switch position is expected to read within the sample range of 60 to 65 units during descent. Both pilots will select any change in the Stall Warning quantity display and advise the other pilot when conditions permit. The Center Tank Pumps switch position that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. The Auxiliary Power Unit annunciation that differs from the expected state requires the First Officer to brief the condition when conditions permit.

Condition	Sample value	Remarks
Center Tank Pumps status message	52 units	Monitor

Hydraulic System B status message	48 units	Monitor
Standby Instruments annunciation	93 units	Monitor

The Fuel Crossfeed quantity display is expected to read within the sample range of 18 to 30 units during climb. The Ground Proximity Monitor status message that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete. The Standby Instruments status message that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power. The Ground Proximity Monitor status message is expected to read within the sample range of 45 to 53 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During a maintenance-requested ground run, the relief pilot should brief the Primary Electrical Bus switch position when conditions permit.

The relief pilot will select any change in the Autothrottle indication and advise the other pilot when the associated caution light remains illuminated. The Bleed Air Supply quantity display that differs from the expected state requires the First Officer to select the condition when conditions permit. During climb, the Captain should select the Autobrake Selector annunciation unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The captain will record any change in the Ground Proximity Monitor annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. During takeoff, the pilot monitoring should brief the Weather Radar annunciation when the associated caution light remains illuminated.

19.10.8 Takeoff Performance Table 7

During cruise, the Captain should confirm the Fire Detection Loop selector position before the next phase of flight. If the Standby Instruments is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The captain will confirm any change in the Cargo Smoke Detection indication and advise the other pilot when conditions permit.

The pilot flying will select any change in the Speedbrake Handle annunciation and advise the other pilot when the associated caution light remains illuminated. The Standby Hydraulic status message that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight. If the Traffic Advisory Display is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Bleed Air Supply is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. During a turnaround, the pilot monitoring should cross-check the Wing Anti-Ice quantity display unless directed otherwise by the Sample Operations Center.

The Standby Instruments quantity display is expected to read within the sample range of 52 to 63 units during cruise. During descent, the Captain should select the Flight Management Computer selector position before the next phase of flight. The relief pilot will verify any change in the Nosewheel Steering indication and advise the other pilot when conditions permit. The Weather Radar status message that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center.

If the Engine Anti-Ice is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Autopilot Channel B is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Autothrottle switch position is expected to read within the sample range of 39 to 51 units during preflight.

Condition	Sample value	Remarks
Landing Gear Indication annunciation	99 units	Monitor
Nosewheel Steering annunciation	89 units	Normal

Wing Anti-Ice selector position	43 units	Monitor
Hydraulic System B switch position	92 units	Normal
Stall Warning advisory	67 units	Normal
Thrust Reverser annunciation	54 units	Advisory only
Autopilot Channel B selector position	53 units	Monitor

NOTE: During cruise, the Captain should confirm the Wing Anti-Ice indication when the associated caution light remains illuminated.

During a turnaround, the First Officer should verify the Speedbrake Handle selector position when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Auxiliary Power Unit status message that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. During preflight, the First Officer should record the Center Tank Pumps indication when operating at a sample station without ground power.

- During climb, the First Officer should select the Pack Temperature Control annunciation if a discrepancy is observed.
- The Stall Warning selector position that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Oxygen Distribution annunciation is expected to read within the sample range of 82 to 86 units during descent.
- During taxi, both pilots should verify the Flap Position Indication switch position if a discrepancy is observed.
- During takeoff, the First Officer should cross-check the Pack Temperature Control switch position when operating at a sample station without ground power.

NOTE: The Weather Radar quantity display is expected to read within the sample range of 86 to 98 units during landing. This text is fictional and exists only to give the prototype realistic volume and structure.

19.10.9 Takeoff Performance Table 8

The Probe Heat switch position is expected to read within the sample range of 35 to 38 units during an extended ground delay. The Autobrake Selector advisory that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval. The Weather Radar selector position is expected to read within the sample range of 84 to 96 units during an extended ground delay. The Standby Instruments switch position is expected to read within the sample range of 10 to 18 units during cruise. The Cargo Smoke Detection advisory that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated. The Auxiliary Power Unit indication is expected to read within the sample range of 29 to 40 units during a turnaround.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The Probe Heat quantity display that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context.

The wording here is placeholder content shaped like a procedure, not a procedure. The Wing Anti-Ice status message is expected to read within the sample range of 12 to 17 units during cruise. If the Traffic Advisory Display is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The Hydraulic System B selector position is expected to read within the sample range of 6 to 15 units during approach.

Condition	Sample value	Remarks
-----------	--------------	---------

Standby Instruments switch position	57 units	Normal
Probe Heat indication	10 units	Normal
Cabin Pressure Controller quantity display	86 units	Monitor
Thrust Reverser annunciation	33 units	Refer to related topic
Probe Heat switch position	25 units	Monitor
Bleed Air Supply selector position	61 units	Refer to related topic

CAUTION: The Brake Temperature Monitor selector position is expected to read within the sample range of 37 to 47 units during landing. If the Speedbrake Handle is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Oxygen Distribution annunciation that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated. During approach, the First Officer should brief the Ground Proximity Monitor advisory when operating at a sample station without ground power.

- The first officer will verify any change in the Probe Heat status message and advise the other pilot when operating at a sample station without ground power.
- During engine start, both pilots should verify the Cabin Pressure Controller selector position if a discrepancy is observed.
- During preflight, the Captain should announce the Autopilot Channel B quantity display when conditions permit.
- If the Cockpit Voice Recorder is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

19.10.10 Takeoff Performance Table 9

If the Standby Instruments is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The Standby Hydraulic annunciation that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power. The Transponder indication is expected to read within the sample range of 60 to 68 units during approach.

- Values in this manual are invented and must not be used for any operational purpose.
- Values in this manual are invented and must not be used for any operational purpose.
- During landing, both pilots should verify the Brake Temperature Monitor annunciation when operating at a sample station without ground power.

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	74 units	Normal
Probe Heat advisory	81 units	Refer to related topic
Transponder status message	61 units	Advisory only
Autopilot Channel A annunciation	63 units	Normal
Flight Management Computer switch position	28 units	Advisory only

CAUTION: Both pilots will verify any change in the Thrust Reverser annunciation and advise the other pilot if a discrepancy is observed. If the Traffic Advisory Display is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Weather Radar status message that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval. During approach, the Captain should record the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center. The pilot monitoring will brief any change in the Standby

Hydraulic indication and advise the other pilot when operating at a sample station without ground power.

- The Flight Management Computer advisory is expected to read within the sample range of 69 to 81 units during taxi.
- If the Auxiliary Power Unit is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- If the Fire Detection Loop is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- The Cabin Pressure Controller annunciation that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center.

NOTE: The pilot flying will monitor any change in the Flap Position Indication status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will verify any change in the Cockpit Voice Recorder indication and advise the other pilot once the checklist item is complete.

- The Flight Management Computer annunciation that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval.
- The Standby Instruments quantity display that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete.
- The Weather Radar selector position that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight.
- If the Autobrake Selector is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.
- The first officer will record any change in the Auxiliary Power Unit annunciation and advise the other pilot before the next phase of flight.

19.10.11 Takeoff Performance Table 10

If the Autopilot Channel B is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The pilot monitoring will cross-check any change in the Autothrottle advisory and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Autobrake Selector annunciation that differs from the expected state requires the Captain to record the condition when conditions permit. The Wing Anti-Ice advisory that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. The Fire Detection Loop switch position that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The captain will verify any change in the Autobrake Selector quantity display and advise the other pilot before the next phase of flight.

During a maintenance-requested ground run, both pilots should monitor the Brake Temperature Monitor status message when the associated caution light remains illuminated. If the Thrust Reverser is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Autothrottle indication that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. The first officer will announce any change in the Speedbrake Handle quantity display and advise the other pilot before the next phase of flight. The Flap Position Indication selector position that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval. The Bleed Air Supply advisory that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. During takeoff, the First Officer should cross-check the Cockpit Voice Recorder status message when conditions permit.

NOTE: The captain will verify any change in the Cabin Pressure Controller indication and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: Refer to the related topic for additional sample context.

This text is fictional and exists only to give the prototype realistic volume and structure. The Auxiliary Power Unit indication is expected to read within the sample range of 75 to 86 units during approach. During a turnaround, both pilots should brief the Autothrottle status message when conditions permit. The Thrust Reverser status message is expected to read within the sample range of 45 to 48 units during landing. Both pilots will cross-check any change in the Pack Temperature Control status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will select any change in the Cargo Smoke Detection quantity display and advise the other pilot if a discrepancy is observed.

19.10.12 Takeoff Performance Table 11

During a maintenance-requested ground run, the Captain should announce the Fire Detection Loop annunciation once the checklist item is complete. The Fuel Crossfeed annunciation is expected to read within the sample range of 79 to 83 units during climb. The relief pilot will confirm any change in the Window Heat annunciation and advise the other pilot when conditions permit. During parking, both pilots should confirm the Autothrottle quantity display when conditions permit.

The Weather Radar annunciation is expected to read within the sample range of 90 to 100 units during takeoff. If the Flight Management Computer is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Pack Temperature Control selector position is expected to read within the sample range of 41 to 49 units during climb. The Window Heat advisory is expected to read within the sample range of 79 to 82 units during landing. The Thrust Reverser selector position is expected to read within the sample range of 10 to 14 units during climb.

If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Primary Electrical Bus status message that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder status message is expected to read within the sample range of 10 to 16 units during taxi. During climb, the pilot monitoring should monitor the Cargo Smoke Detection indication if the indication does not stabilize within the sample interval.

If the Oxygen Distribution is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. During a maintenance-requested ground run, the First Officer should confirm the Center Tank Pumps selector position if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Probe Heat indication that differs from the expected state requires the Captain to verify the condition when conditions permit.

The Weather Radar status message that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control switch position is expected to read within the sample range of 68 to 71 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure.

The pilot monitoring will select any change in the Hydraulic System B advisory and advise the other pilot if a discrepancy is observed. The Autopilot Channel A quantity display is expected to read within the sample range of 38 to 41 units during cruise. The Wing Anti-Ice status message is expected to read within the sample range of 96 to 102 units during an extended ground delay. If the Wing Anti-Ice is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. See 16.20.1 Standby Hydraulic Reset Guidance.

19.10.13 Takeoff Performance Table 12

If the Engine Anti-Ice is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The pilot flying will verify any change in the Pack Temperature Control status message and advise the other pilot once the checklist item is complete. If the Stall Warning is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Weather Radar advisory	83 units	Normal
Autobrake Selector switch position	11 units	Advisory only
Bleed Air Supply advisory	14 units	Refer to related topic
Autobrake Selector indication	60 units	Normal
Nosewheel Steering selector position	80 units	Refer to related topic

The Autobrake Selector quantity display that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed. If the Wing Anti-Ice is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Brake Temperature Monitor indication is expected to read within the sample range of 96 to 100 units during cruise.

- The Oxygen Distribution annunciation is expected to read within the sample range of 67 to 76 units during a maintenance-requested ground run.
- The Standby Hydraulic selector position that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed.
- The first officer will verify any change in the Weather Radar indication and advise the other pilot when the associated caution light remains illuminated.
- The Center Tank Pumps annunciation that differs from the expected state requires the Captain to cross-check the condition when conditions permit.
- During taxi, both pilots should cross-check the Wing Anti-Ice status message once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Transponder is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. During engine start, both pilots should cross-check the Primary Electrical Bus indication when conditions permit.

19.10.14 Takeoff Performance Table 13

If the Fire Detection Loop is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The first officer will brief any change in the Transponder advisory and advise the other pilot if a discrepancy is observed. The Window Heat annunciation that differs from the expected state requires the relief pilot to verify the condition once the checklist item is complete.

- The pilot monitoring will select any change in the Cabin Pressure Controller annunciation and advise the other pilot once the checklist item is complete.
- If the Engine Anti-Ice is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- The pilot flying will cross-check any change in the Weather Radar advisory and advise the other pilot when operating at a sample station without ground power.
- During a diversion, both pilots should confirm the Ground Proximity Monitor indication once the checklist item is complete.

If the Cargo Smoke Detection is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The first officer will record any change in the Engine Anti-Ice annunciation and advise the other pilot before the next phase of flight. During approach, the pilot flying should verify the Pack Temperature Control switch position if a discrepancy is observed. The Primary Electrical Bus indication is expected to read within the sample range of 55 to 59 units during approach. The Stall Warning advisory is expected to read within the sample range of 14 to 21 units during descent. The Nosewheel Steering indication that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete.

Condition	Sample value	Remarks
Engine Anti-Ice quantity display	79 units	Refer to related topic
Hydraulic System A selector position	29 units	Normal
Auxiliary Power Unit quantity display	88 units	Refer to related topic
Landing Gear Indication quantity display	62 units	Advisory only

The Primary Electrical Bus annunciation that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. The Engine Anti-Ice annunciation that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval. The captain will announce any change in the Speedbrake Handle status message and advise the other pilot if the indication does not stabilize within the sample interval.

- The relief pilot will monitor any change in the Engine Anti-Ice indication and advise the other pilot before the next phase of flight.
- The Standby Hydraulic indication is expected to read within the sample range of 16 to 26 units during descent.
- During preflight, the First Officer should brief the Autothrottle status message if a discrepancy is observed.

Condition	Sample value	Remarks
Probe Heat status message	6 units	Monitor
Cabin Pressure Controller switch position	44 units	Normal
Flap Position Indication indication	96 units	Monitor
Ground Proximity Monitor advisory	70 units	Advisory only
Nosewheel Steering quantity display	46 units	Monitor
Nosewheel Steering indication	14 units	Advisory only
Transponder annunciation	34 units	Advisory only

If the Transponder is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Traffic Advisory Display annunciation is expected to read within the sample range of 12 to 16 units during a maintenance-requested ground run. During descent, the pilot monitoring should record the Standby Hydraulic selector position when operating at a sample station without ground power. The Cargo Smoke Detection annunciation is expected to read within the sample range of 4 to 11 units during approach. The Traffic Advisory Display indication is expected to read within the sample range of 67 to 75 units during takeoff. During takeoff, the Captain should verify the Center Tank Pumps indication when the associated caution light remains illuminated.

The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, the First Officer should cross-check the Wing Anti-Ice indication if the indication does not stabilize within the sample interval. Both pilots will record any change in the Fuel Crossfeed annunciation and advise the other pilot when conditions permit. See 08.10.3 Engine Anti-Ice Status Messages.

19.20 Enroute Performance

19.20.1 Enroute Performance Table 1

During a turnaround, the relief pilot should cross-check the Flap Position Indication annunciation unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. If the Autobrake Selector is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The pilot monitoring will brief any change in the Standby Hydraulic advisory and advise the other pilot when operating at a sample station without ground power. The Stall Warning selector position is expected to read within the sample range of 21 to 25 units during engine start.

- During a diversion, the relief pilot should cross-check the Speedbrake Handle annunciation if a discrepancy is observed.
- The Bleed Air Supply switch position is expected to read within the sample range of 12 to 23 units during a diversion.
- During an extended ground delay, both pilots should verify the Transponder switch position once the checklist item is complete.
- The Hydraulic System A switch position that differs from the expected state requires the First Officer to announce the condition before the next phase of flight.
- During parking, the pilot flying should announce the Hydraulic System A selector position before the next phase of flight.
- The pilot flying will cross-check any change in the Speedbrake Handle advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Stall Warning is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.
- Both pilots will select any change in the Autopilot Channel A selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Probe Heat advisory that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Brake Temperature Monitor is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The relief pilot will record any change in the Fuel Crossfeed annunciation and advise the other pilot if a discrepancy is observed.
- Refer to the related topic for additional sample context.
- If the Oxygen Distribution is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

The Auxiliary Power Unit switch position is expected to read within the sample range of 55 to 59 units during taxi. The relief pilot will cross-check any change in the Transponder status message and advise the other pilot when operating at a sample station without ground power. The Flight Management Computer quantity display is expected to read within the sample range of 93 to 97 units during engine start. During engine start, the pilot flying should announce the Ground Proximity Monitor indication when operating at a sample station without ground power. If the Traffic Advisory Display is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Brake Temperature Monitor is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The Cockpit Voice Recorder advisory is expected to read within the sample range of 82 to 91 units during preflight.

19.20.2 Enroute Performance Table 2

The Landing Gear Indication status message that differs from the expected state requires the pilot flying to announce the condition when conditions permit. During approach, the pilot monitoring should cross-check the Traffic Advisory Display selector position if a discrepancy is observed. Refer to the related topic for additional sample context.

The Autopilot Channel B advisory is expected to read within the sample range of 50 to 62 units during parking. The Autopilot Channel A annunciation is expected to read within the sample range of 63 to 70 units during a diversion. The Wing Anti-Ice status message is expected to read within the sample range of 10 to 13 units during a diversion. Both pilots will monitor any change in the Autobrake Selector status message and advise the other pilot when operating at a sample station without ground power. The relief pilot will monitor any change in the Standby Hydraulic quantity display and advise the other pilot when operating at a sample station without ground power. The pilot monitoring will confirm any change in the Brake Temperature Monitor annunciation and advise the other pilot when conditions permit.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- During landing, the relief pilot should select the Hydraulic System A selector position once the checklist item is complete.
- Refer to the related topic for additional sample context.
- The Stall Warning annunciation that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power.
- If the Cabin Pressure Controller is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.
- During climb, the Captain should monitor the Transponder status message before the next phase of flight.

The Traffic Advisory Display status message is expected to read within the sample range of 43 to 53 units during a turnaround. If the Standby Instruments is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Flight Management Computer advisory that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete.

During taxi, the pilot monitoring should brief the Brake Temperature Monitor quantity display when operating at a sample station without ground power. The relief pilot will cross-check any change in the Ground Proximity Monitor annunciation and advise the other pilot if the indication does not stabilize within the sample interval. During takeoff, the Captain should announce the Cargo Smoke Detection advisory when operating at a sample station without ground power. See 09.10.5 Primary Electrical Bus Normal Operation.

- The Nosewheel Steering quantity display that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated.
- The Primary Electrical Bus selector position that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During a maintenance-requested ground run, the First Officer should cross-check the Wing Anti-Ice quantity display if the indication does not stabilize within the sample interval.
- If the Fuel Crossfeed is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

- During preflight, both pilots should monitor the Pack Temperature Control indication if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Probe Heat selector position	80 units	Normal
Flap Position Indication advisory	57 units	Advisory only
Fuel Crossfeed quantity display	97 units	Advisory only
Window Heat selector position	31 units	Refer to related topic

19.20.3 Enroute Performance Table 3

If the Window Heat is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Stall Warning advisory that differs from the expected state requires the pilot flying to confirm the condition when conditions permit. Both pilots will verify any change in the Standby Hydraulic quantity display and advise the other pilot when the associated caution light remains illuminated. During an extended ground delay, both pilots should verify the Standby Hydraulic quantity display when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

- The Window Heat switch position is expected to read within the sample range of 57 to 62 units during a maintenance-requested ground run.
- The pilot monitoring will brief any change in the Weather Radar status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Hydraulic System B status message is expected to read within the sample range of 60 to 65 units during preflight.
- The Autothrottle annunciation is expected to read within the sample range of 20 to 24 units during preflight.
- The Brake Temperature Monitor annunciation is expected to read within the sample range of 89 to 92 units during preflight.

During descent, the Captain should verify the Weather Radar advisory unless directed otherwise by the Sample Operations Center. The Pack Temperature Control indication is expected to read within the sample range of 73 to 79 units during a diversion. If the Autopilot Channel B is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Probe Heat indication	27 units	Normal
Cargo Smoke Detection advisory	34 units	Advisory only
Thrust Reverser switch position	79 units	Monitor

The relief pilot will select any change in the Primary Electrical Bus advisory and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. If the Traffic Advisory Display is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. Both pilots will cross-check any change in the Hydraulic System A indication and advise the other pilot once the checklist item is complete. The Oxygen Distribution indication that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete. During a maintenance-requested ground run, the relief pilot should brief the Stall Warning annunciation when the associated caution light remains illuminated.

- The Cockpit Voice Recorder status message is expected to read within the sample range of 50 to 54 units during a diversion.

- The Stall Warning selector position that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed.
- The Cockpit Voice Recorder annunciation is expected to read within the sample range of 48 to 56 units during cruise.
- If the Fire Detection Loop is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- Both pilots will brief any change in the Autopilot Channel A advisory and advise the other pilot before the next phase of flight.

The Autopilot Channel B annunciation that differs from the expected state requires the pilot monitoring to select the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The Autothrottle switch position is expected to read within the sample range of 55 to 66 units during approach. The pilot monitoring will brief any change in the Speedbrake Handle annunciation and advise the other pilot when the associated caution light remains illuminated.

19.20.4 Enroute Performance Table 4

The Fuel Crossfeed quantity display is expected to read within the sample range of 16 to 22 units during parking. During preflight, the pilot flying should monitor the Fire Detection Loop switch position when the associated caution light remains illuminated. If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Weather Radar status message is expected to read within the sample range of 29 to 36 units during an extended ground delay. If the Auxiliary Power Unit is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Autobrake Selector advisory that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power.

- If the Window Heat is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- Both pilots will verify any change in the Stall Warning annunciation and advise the other pilot when operating at a sample station without ground power.
- The first officer will select any change in the Oxygen Distribution selector position and advise the other pilot once the checklist item is complete.
- During approach, the pilot flying should announce the Window Heat advisory when conditions permit.
- The Oxygen Distribution status message is expected to read within the sample range of 62 to 71 units during a maintenance-requested ground run.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The pilot flying will monitor any change in the Probe Heat status message and advise the other pilot if a discrepancy is observed.
- The Brake Temperature Monitor status message is expected to read within the sample range of 96 to 102 units during approach.
- The pilot monitoring will announce any change in the Nosewheel Steering switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- During parking, the pilot flying should record the Window Heat selector position when the associated caution light remains illuminated.

NOTE: If the Cabin Pressure Controller is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Landing Gear Indication switch position is expected to read within the sample range of 21 to 31 units during preflight.

CAUTION: The pilot flying will record any change in the Thrust Reverser switch position and advise the other pilot if a discrepancy is observed.

The Ground Proximity Monitor quantity display that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the pilot flying should verify the Bleed Air Supply indication once the checklist item is complete. During taxi, both pilots should monitor the Transponder indication if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

The wording here is placeholder content shaped like a procedure, not a procedure. The Flight Management Computer indication that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

19.20.5 Enroute Performance Table 5

The Cabin Pressure Controller quantity display that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. The Flap Position Indication indication is expected to read within the sample range of 66 to 74 units during taxi. If the Fire Detection Loop is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Hydraulic System B switch position that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. The pilot monitoring will brief any change in the Hydraulic System B advisory and advise the other pilot when conditions permit. The Pack Temperature Control indication is expected to read within the sample range of 45 to 51 units during a diversion.

The relief pilot will record any change in the Standby Instruments selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

The first officer will record any change in the Bleed Air Supply switch position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. The pilot monitoring will record any change in the Brake Temperature Monitor selector position and advise the other pilot if a discrepancy is observed. The Hydraulic System B quantity display is expected to read within the sample range of 21 to 27 units during takeoff. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

The Stall Warning status message is expected to read within the sample range of 24 to 35 units during landing. The Window Heat quantity display that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. The Primary Electrical Bus status message is expected to read within the sample range of 80 to 83 units during a maintenance-requested ground run. The pilot flying will brief any change in the Wing Anti-Ice indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Pack Temperature Control status message is expected to read within the sample range of 33 to 39 units during preflight. The pilot monitoring will select any change in the Cabin Pressure Controller advisory and advise the other pilot once the checklist item is complete.

During approach, the Captain should cross-check the Primary Electrical Bus annunciation when the associated caution light remains illuminated. If the Hydraulic System B is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. Both pilots will verify any change in the Traffic Advisory Display selector position and advise the other pilot if the indication does not stabilize within the sample interval.

The first officer will confirm any change in the Fire Detection Loop advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus advisory that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. The relief pilot will select any change in the Stall Warning status message and advise the other pilot once the checklist item is complete. If the Fire Detection Loop is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

- Both pilots will record any change in the Probe Heat selector position and advise the other pilot before the next phase of flight.
- If the Brake Temperature Monitor is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.
- The Stall Warning advisory that differs from the expected state requires the Captain to record the condition if a discrepancy is observed.
- During preflight, the pilot monitoring should record the Center Tank Pumps status message if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. Both pilots will select any change in the Weather Radar advisory and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. The pilot monitoring will cross-check any change in the Traffic Advisory Display status message and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. During descent, the pilot flying should announce the Weather Radar selector position before the next phase of flight.

Condition	Sample value	Remarks
Weather Radar advisory	35 units	Advisory only
Weather Radar quantity display	51 units	Normal
Hydraulic System B advisory	21 units	Advisory only
Auxiliary Power Unit selector position	74 units	Advisory only
Speedbrake Handle annunciation	97 units	Monitor

19.20.6 Enroute Performance Table 6

During an extended ground delay, the relief pilot should confirm the Wing Anti-Ice quantity display if the indication does not stabilize within the sample interval. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The first officer will select any change in the Engine Anti-Ice status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The relief pilot will monitor any change in the Autothrottle advisory and advise the other pilot when conditions permit. The Bleed Air Supply advisory that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

- The Brake Temperature Monitor advisory that differs from the expected state requires the First Officer to select the condition before the next phase of flight.
- During a diversion, the relief pilot should announce the Weather Radar quantity display if a discrepancy is observed.
- If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- During a turnaround, the Captain should announce the Cargo Smoke Detection status message if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.
- Values in this manual are invented and must not be used for any operational purpose.

- The pilot monitoring will announce any change in the Cabin Pressure Controller switch position and advise the other pilot when the associated caution light remains illuminated.
- The Nosewheel Steering advisory is expected to read within the sample range of 52 to 57 units during an extended ground delay.
- The Hydraulic System A quantity display that differs from the expected state requires the First Officer to brief the condition when conditions permit.
- During preflight, the First Officer should brief the Ground Proximity Monitor status message if a discrepancy is observed.

The pilot monitoring will announce any change in the Oxygen Distribution quantity display and advise the other pilot when operating at a sample station without ground power. The Autobrake Selector selector position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. The Ground Proximity Monitor indication that differs from the expected state requires both pilots to select the condition if a discrepancy is observed. The Auxiliary Power Unit switch position is expected to read within the sample range of 14 to 23 units during climb.

- During landing, both pilots should verify the Hydraulic System A selector position when the associated caution light remains illuminated.
- The Fire Detection Loop selector position is expected to read within the sample range of 97 to 107 units during preflight.
- The pilot flying will confirm any change in the Standby Hydraulic switch position and advise the other pilot if a discrepancy is observed.
- The Autopilot Channel B switch position that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power.
- If the Bleed Air Supply is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- During a maintenance-requested ground run, both pilots should brief the Autobrake Selector annunciation before the next phase of flight.

During engine start, the pilot monitoring should brief the Primary Electrical Bus indication once the checklist item is complete. The Fuel Crossfeed status message that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center. The captain will confirm any change in the Standby Instruments advisory and advise the other pilot when conditions permit. The Flight Management Computer indication is expected to read within the sample range of 21 to 24 units during climb. The Autopilot Channel B selector position is expected to read within the sample range of 56 to 62 units during takeoff. The Speedbrake Handle selector position is expected to read within the sample range of 9 to 12 units during taxi. See 02.10.4 General Limitation 4.

19.20.7 Enroute Performance Table 7

The Fire Detection Loop switch position is expected to read within the sample range of 46 to 50 units during taxi. If the Thrust Reverser is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The relief pilot will select any change in the Wing Anti-Ice status message and advise the other pilot when operating at a sample station without ground power. During takeoff, the relief pilot should verify the Hydraulic System A switch position before the next phase of flight. During engine start, the relief pilot should select the Oxygen Distribution indication before the next phase of flight.

The Primary Electrical Bus indication that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. The Standby Instruments indication that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval. The Engine Anti-Ice status message is expected to read within the sample range of 14 to 23 units

during landing. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control annunciation that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.

NOTE: The Fire Detection Loop quantity display that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete.

Condition	Sample value	Remarks
Flap Position Indication indication	26 units	Monitor
Weather Radar quantity display	43 units	Refer to related topic
Traffic Advisory Display status message	11 units	Normal

Condition	Sample value	Remarks
Engine Anti-Ice indication	38 units	Normal
Bleed Air Supply switch position	23 units	Monitor
Weather Radar annunciation	56 units	Advisory only

CAUTION: During climb, the pilot flying should announce the Thrust Reverser selector position when operating at a sample station without ground power.

The pilot monitoring will confirm any change in the Flap Position Indication advisory and advise the other pilot once the checklist item is complete. The Transponder advisory is expected to read within the sample range of 97 to 102 units during a diversion. The Fire Detection Loop advisory that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center. The first officer will brief any change in the Center Tank Pumps annunciation and advise the other pilot when conditions permit. The Probe Heat status message is expected to read within the sample range of 66 to 78 units during engine start. See 05.30.15 Ground Proximity Monitor Interfaces.

19.20.8 Enroute Performance Table 8

The pilot flying will brief any change in the Oxygen Distribution status message and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. Both pilots will brief any change in the Brake Temperature Monitor status message and advise the other pilot once the checklist item is complete. The Bleed Air Supply selector position is expected to read within the sample range of 63 to 70 units during engine start.

If the Standby Hydraulic is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Oxygen Distribution advisory	97 units	Advisory only
Standby Hydraulic status message	22 units	Normal
Brake Temperature Monitor indication	16 units	Refer to related topic

If the Nosewheel Steering is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Bleed Air Supply advisory is expected to read within the sample range of 39 to 43 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Hydraulic System B selector position	18 units	Advisory only

Bleed Air Supply advisory	19 units	Monitor
Stall Warning status message	84 units	Monitor
Autobrake Selector selector position	3 units	Refer to related topic
Engine Anti-Ice quantity display	54 units	Advisory only

19.20.9 Enroute Performance Table 9

The Autothrottle advisory is expected to read within the sample range of 86 to 94 units during engine start. The Fuel Crossfeed selector position that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. During cruise, both pilots should select the Cargo Smoke Detection indication once the checklist item is complete. The first officer will record any change in the Hydraulic System A status message and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Hydraulic System B selector position	74 units	Advisory only
Pack Temperature Control indication	59 units	Normal
Autobrake Selector quantity display	67 units	Advisory only
Hydraulic System B switch position	38 units	Refer to related topic

The Thrust Reverser advisory is expected to read within the sample range of 82 to 85 units during landing. Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle annunciation that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed. The Cabin Pressure Controller annunciation that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Flap Position Indication annunciation is expected to read within the sample range of 56 to 60 units during preflight.

Condition	Sample value	Remarks
Hydraulic System B annunciation	50 units	Refer to related topic
Engine Anti-Ice annunciation	64 units	Normal
Flap Position Indication status message	84 units	Refer to related topic

Condition	Sample value	Remarks
Standby Instruments status message	80 units	Advisory only
Wing Anti-Ice switch position	84 units	Advisory only
Fire Detection Loop switch position	60 units	Normal
Wing Anti-Ice switch position	56 units	Normal

The Hydraulic System B advisory is expected to read within the sample range of 13 to 17 units during descent. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. During climb, the Captain should confirm the Bleed Air Supply status message if the indication does not stabilize within the sample interval. The Autobrake Selector annunciation is expected to read within the sample range of 41 to 53 units during engine start.

Condition	Sample value	Remarks
Cabin Pressure Controller quantity display	41 units	Normal
Hydraulic System B selector position	10 units	Normal

Center Tank Pumps annunciation	92 units	Monitor
Brake Temperature Monitor advisory	39 units	Normal
Autopilot Channel A advisory	5 units	Refer to related topic

Condition	Sample value	Remarks
Autobrake Selector selector position	70 units	Advisory only
Fire Detection Loop advisory	7 units	Refer to related topic
Window Heat indication	64 units	Normal
Flap Position Indication status message	73 units	Monitor

19.20.10 Enroute Performance Table 10

The Ground Proximity Monitor advisory is expected to read within the sample range of 84 to 92 units during takeoff. If the Flap Position Indication is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. During cruise, the pilot flying should announce the Standby Hydraulic quantity display before the next phase of flight. The captain will select any change in the Weather Radar annunciation and advise the other pilot before the next phase of flight. If the Stall Warning is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Engine Anti-Ice selector position	25 units	Advisory only
Wing Anti-Ice advisory	62 units	Monitor
Autothrottle annunciation	63 units	Monitor
Standby Hydraulic selector position	42 units	Monitor

NOTE: The Autothrottle status message is expected to read within the sample range of 66 to 75 units during a maintenance-requested ground run. The pilot flying will select any change in the Cargo Smoke Detection quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Autobrake Selector indication that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete.

The Fuel Crossfeed switch position is expected to read within the sample range of 65 to 72 units during landing. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: If the Cargo Smoke Detection is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

The Landing Gear Indication indication that differs from the expected state requires the Captain to brief the condition when conditions permit. The relief pilot will confirm any change in the Bleed Air Supply annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Oxygen Distribution quantity display that differs from the expected state requires the First Officer to cross-check the condition when conditions permit. During preflight, both pilots should brief the Speedbrake Handle status message once the checklist item is complete.

19.20.11 Enroute Performance Table 11

The Landing Gear Indication selector position is expected to read within the sample range of 43 to 51 units during a diversion. The Cabin Pressure Controller indication is expected to read within the sample range of 26 to 34 units during parking. If the Autopilot Channel A is inoperative, continue a diversion only after both pilots has reviewed the

associated sample guidance. The pilot monitoring will confirm any change in the Wing Anti-Ice selector position and advise the other pilot if the indication does not stabilize within the sample interval. During engine start, both pilots should brief the Auxiliary Power Unit advisory before the next phase of flight. During taxi, the First Officer should cross-check the Fire Detection Loop status message before the next phase of flight.

- The Flap Position Indication switch position is expected to read within the sample range of 25 to 33 units during engine start.
- The relief pilot will announce any change in the Thrust Reverser advisory and advise the other pilot when conditions permit.
- During parking, the pilot monitoring should cross-check the Stall Warning switch position unless directed otherwise by the Sample Operations Center.

CAUTION: If the Auxiliary Power Unit is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The pilot flying will announce any change in the Flight Management Computer advisory and advise the other pilot once the checklist item is complete.

The Traffic Advisory Display quantity display is expected to read within the sample range of 69 to 80 units during an extended ground delay. The pilot monitoring will monitor any change in the Auxiliary Power Unit advisory and advise the other pilot if the indication does not stabilize within the sample interval. During parking, the First Officer should select the Autopilot Channel B annunciation if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, the Captain should select the Probe Heat annunciation unless directed otherwise by the Sample Operations Center. See 11.30.9 Autothrottle Limits Display.

NOTE: The Autobrake Selector annunciation that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed. During landing, the pilot flying should verify the Autobrake Selector advisory if the indication does not stabilize within the sample interval.

- The first officer will brief any change in the Thrust Reverser status message and advise the other pilot once the checklist item is complete.
- If the Engine Anti-Ice is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- During preflight, the pilot monitoring should brief the Speedbrake Handle status message before the next phase of flight.
- If the Nosewheel Steering is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- The Thrust Reverser advisory is expected to read within the sample range of 58 to 69 units during taxi.
- During takeoff, both pilots should verify the Speedbrake Handle annunciation once the checklist item is complete.

NOTE: The Autothrottle quantity display that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed.

19.20.12 Enroute Performance Table 12

The Ground Proximity Monitor switch position is expected to read within the sample range of 46 to 51 units during an extended ground delay. The Transponder annunciation that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Pack Temperature Control selector position that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.

- The Ground Proximity Monitor advisory that differs from the expected state requires the First Officer to monitor the condition if the indication does not stabilize within the sample interval.

The Nosewheel Steering advisory is expected to read within the sample range of 8 to 19 units during climb. The Weather Radar quantity display is expected to read within the sample range of 86 to 95 units during a diversion. The Autothrottle annunciation is expected to read within the sample range of 94 to 103 units during a turnaround.

Condition	Sample value	Remarks
Autothrottle switch position	53 units	Normal
Speedbrake Handle quantity display	42 units	Normal
Window Heat selector position	53 units	Advisory only
Probe Heat status message	93 units	Refer to related topic
Traffic Advisory Display annunciation	45 units	Advisory only

Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

19.20.13 Enroute Performance Table 13

The relief pilot will monitor any change in the Engine Anti-Ice indication and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will verify any change in the Speedbrake Handle quantity display and advise the other pilot if a discrepancy is observed. The Autobrake Selector selector position is expected to read within the sample range of 49 to 54 units during descent. The Standby Instruments indication is expected to read within the sample range of 47 to 50 units during climb. If the Landing Gear Indication is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Cockpit Voice Recorder indication that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. The Thrust Reverser quantity display that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval. If the Brake Temperature Monitor is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. During landing, the pilot flying should confirm the Thrust Reverser advisory when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor advisory is expected to read within the sample range of 22 to 25 units during descent. The Brake Temperature Monitor switch position that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight.

NOTE: The Autopilot Channel A quantity display is expected to read within the sample range of 35 to 46 units during takeoff.

The Autopilot Channel A status message that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. If the Autopilot Channel B is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The first officer will select any change in the Flap Position Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

19.30 Landing Performance

19.30.1 Landing Performance Table 1

The Cockpit Voice Recorder advisory is expected to read within the sample range of 12 to 17 units during an extended ground delay. The Bleed Air Supply quantity display is expected to read within the sample range of 8 to 14 units during approach. The relief pilot will announce any change in the Cabin Pressure Controller switch position and advise the other pilot before the next phase of flight. Both pilots will monitor any change in the Landing Gear Indication indication and advise the other pilot once the checklist item is complete. During a diversion, both pilots should announce the Ground Proximity Monitor selector position when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

The Flight Management Computer status message is expected to read within the sample range of 90 to 94 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure. The Ground Proximity Monitor annunciation that differs from the expected state requires the Captain to confirm the condition when conditions permit. The Wing Anti-Ice quantity display that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Stall Warning is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps quantity display that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit. If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Flight Management Computer indication that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power. The Autopilot Channel A status message is expected to read within the sample range of 47 to 53 units during approach. The Autothrottle status message that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Weather Radar indication	38 units	Normal
Autothrottle selector position	73 units	Monitor
Hydraulic System A selector position	8 units	Advisory only
Brake Temperature Monitor indication	67 units	Advisory only
Pack Temperature Control selector position	40 units	Advisory only
Hydraulic System B annunciation	24 units	Advisory only

19.30.2 Landing Performance Table 2

The Speedbrake Handle quantity display is expected to read within the sample range of 3 to 14 units during landing. Values in this manual are invented and must not be used for any operational purpose. The Fuel Crossfeed switch position is expected to read within the sample range of 4 to 8 units during takeoff. The Autopilot Channel A advisory is expected to read within the sample range of 33 to 40 units during engine start.

The Cabin Pressure Controller quantity display that differs from the expected state requires the Captain to announce the condition once the checklist item is complete. The Autobrake Selector advisory that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. If the Window Heat is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

NOTE: Both pilots will select any change in the Wing Anti-Ice switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

During taxi, both pilots should announce the Probe Heat annunciation if a discrepancy is observed. During a diversion, the Captain should announce the Flap Position Indication indication unless directed otherwise by the Sample Operations Center. The first officer will select any change in the Pack Temperature Control status message and advise the other pilot when conditions permit. The Fire Detection Loop switch position is expected to read within the sample range of 62 to 65 units during parking.

During parking, the First Officer should confirm the Primary Electrical Bus indication when conditions permit. The Cargo Smoke Detection quantity display that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed. The Thrust Reverser advisory is expected to read within the sample range of 24 to 28 units during parking.

During a turnaround, the pilot flying should cross-check the Cabin Pressure Controller selector position when the associated caution light remains illuminated. The Autopilot Channel B switch position is expected to read within the sample range of 55 to 63 units during an extended ground delay. The Center Tank Pumps status message that differs from the expected state requires both pilots to cross-check the condition when conditions permit. If the Bleed Air Supply is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Oxygen Distribution advisory is expected to read within the sample range of 92 to 97 units during descent. During an extended ground delay, the Captain should confirm the Fire Detection Loop selector position unless directed otherwise by the Sample Operations Center.

The relief pilot will verify any change in the Autopilot Channel B indication and advise the other pilot when operating at a sample station without ground power. During landing, both pilots should announce the Bleed Air Supply selector position before the next phase of flight. The first officer will confirm any change in the Autothrottle switch position and advise the other pilot if a discrepancy is observed. See 10.20.12 Window Heat Reset Guidance.

- Values in this manual are invented and must not be used for any operational purpose.
- The pilot monitoring will brief any change in the Pack Temperature Control advisory and advise the other pilot when operating at a sample station without ground power.
- The Cabin Pressure Controller annunciation that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated.
- During a diversion, the pilot monitoring should cross-check the Autothrottle quantity display when the associated caution light remains illuminated.
- The first officer will cross-check any change in the Center Tank Pumps quantity display and advise the other pilot when the associated caution light remains illuminated.

NOTE: During engine start, the First Officer should brief the Hydraulic System A advisory unless directed otherwise by the Sample Operations Center. During cruise, the Captain should monitor the Flight Management Computer annunciation when conditions permit.

19.30.3 Landing Performance Table 3

The captain will monitor any change in the Flap Position Indication annunciation and advise the other pilot when the associated caution light remains illuminated. The first officer will select any change in the Standby Instruments status message and advise the other pilot when conditions permit. Refer to the related topic for additional sample context.

The Weather Radar selector position that differs from the expected state requires the pilot monitoring to cross-check the condition unless directed otherwise by the Sample Operations Center. During climb, the First Officer should monitor the Wing Anti-Ice annunciation once the checklist item is complete. During climb, the Captain should confirm the Autopilot Channel B annunciation if the indication does not stabilize within the sample interval. During cruise, the Captain should verify the Cargo Smoke Detection status message when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will cross-check any change in the Autothrottle indication and advise the other pilot if a discrepancy is observed. If the

Engine Anti-Ice is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer annunciation is expected to read within the sample range of 68 to 80 units during an extended ground delay.

Condition	Sample value	Remarks
Cargo Smoke Detection indication	19 units	Monitor
Wing Anti-Ice selector position	16 units	Monitor
Ground Proximity Monitor selector position	93 units	Monitor

NOTE: During preflight, the Captain should record the Nosewheel Steering annunciation when operating at a sample station without ground power. The Autopilot Channel B status message is expected to read within the sample range of 38 to 46 units during parking.

- During a maintenance-requested ground run, both pilots should select the Nosewheel Steering selector position if a discrepancy is observed.
- During parking, the pilot flying should brief the Center Tank Pumps status message if the indication does not stabilize within the sample interval.
- During descent, the relief pilot should announce the Standby Hydraulic annunciation before the next phase of flight.
- During a maintenance-requested ground run, the First Officer should brief the Engine Anti-Ice advisory before the next phase of flight.
- The captain will select any change in the Cargo Smoke Detection quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

During landing, the pilot monitoring should monitor the Auxiliary Power Unit quantity display if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Center Tank Pumps switch position	11 units	Monitor
Primary Electrical Bus selector position	13 units	Advisory only
Thrust Reverser switch position	68 units	Normal
Flap Position Indication quantity display	2 units	Advisory only
Cabin Pressure Controller indication	52 units	Advisory only

CAUTION: The Brake Temperature Monitor indication is expected to read within the sample range of 42 to 51 units during cruise. The Cabin Pressure Controller indication is expected to read within the sample range of 96 to 103 units during a turnaround.

19.30.4 Landing Performance Table 4

The captain will announce any change in the Autothrottle switch position and advise the other pilot when the associated caution light remains illuminated. During approach, the relief pilot should cross-check the Brake Temperature Monitor quantity display when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Center Tank Pumps status message	30 units	Refer to related topic

Traffic Advisory Display annunciation	12 units	Monitor
Primary Electrical Bus switch position	40 units	Monitor
Primary Electrical Bus selector position	77 units	Advisory only
Center Tank Pumps indication	58 units	Refer to related topic

CAUTION: The Weather Radar quantity display is expected to read within the sample range of 38 to 44 units during taxi.

- During parking, both pilots should monitor the Primary Electrical Bus indication when operating at a sample station without ground power.
- During a diversion, the First Officer should record the Fire Detection Loop selector position if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Stall Warning selector position is expected to read within the sample range of 29 to 34 units during parking.
- The Fire Detection Loop status message that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.
- If the Standby Instruments is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

NOTE: The Transponder status message that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval. The Ground Proximity Monitor selector position is expected to read within the sample range of 75 to 87 units during a turnaround. If the Autopilot Channel B is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Standby Instruments status message that differs from the expected state requires both pilots to announce the condition before the next phase of flight. During climb, both pilots should record the Standby Hydraulic annunciation if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

The Ground Proximity Monitor switch position that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, the relief pilot should monitor the Transponder advisory when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. See 19.10.14 Takeoff Performance Table 13.

19.30.5 Landing Performance Table 5

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Traffic Advisory Display switch position that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. During cruise, the pilot monitoring should cross-check the Probe Heat annunciation when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Window Heat selector position is expected to read within the sample range of 86 to 92 units during landing. The pilot monitoring will confirm any change in the Pack Temperature Control indication and advise the other pilot before the next phase of flight.

During an extended ground delay, the relief pilot should select the Nosewheel Steering selector position before the next phase of flight. If the Brake Temperature Monitor is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During preflight, the First Officer should verify the Standby Instruments selector position when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The relief pilot will announce any change in the Flap Position Indication indication and advise the

other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

The Engine Anti-Ice switch position that differs from the expected state requires the relief pilot to announce the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector annunciation is expected to read within the sample range of 58 to 69 units during preflight. The Standby Instruments quantity display is expected to read within the sample range of 67 to 71 units during a turnaround. During a turnaround, the pilot monitoring should monitor the Wing Anti-Ice annunciation when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Flap Position Indication selector position is expected to read within the sample range of 98 to 109 units during landing.
- The Fire Detection Loop advisory that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power.
- Values in this manual are invented and must not be used for any operational purpose.

The Flap Position Indication annunciation is expected to read within the sample range of 46 to 50 units during cruise. The Bleed Air Supply status message is expected to read within the sample range of 87 to 93 units during a diversion. During parking, the Captain should announce the Autopilot Channel A indication once the checklist item is complete. The relief pilot will record any change in the Window Heat quantity display and advise the other pilot when the associated caution light remains illuminated. See 05.30.3 Autopilot Channel B Overview.

Condition	Sample value	Remarks
Probe Heat indication	61 units	Advisory only
Pack Temperature Control advisory	95 units	Normal
Probe Heat selector position	97 units	Refer to related topic
Auxiliary Power Unit indication	29 units	Refer to related topic
Traffic Advisory Display switch position	37 units	Advisory only
Autobrake Selector status message	2 units	Monitor

19.30.6 Landing Performance Table 6

Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will cross-check any change in the Primary Electrical Bus quantity display and advise the other pilot when the associated caution light remains illuminated. The Probe Heat status message that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit annunciation that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated. The Auxiliary Power Unit quantity display is expected to read within the sample range of 41 to 46 units during takeoff.

The pilot flying will confirm any change in the Pack Temperature Control switch position and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, the pilot monitoring should verify the Stall Warning switch position unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display selector position is expected to read within the sample range of 56 to 63 units during an extended ground delay. The Autopilot Channel B status message that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval.

During taxi, the Captain should confirm the Auxiliary Power Unit indication when conditions permit. If the Autopilot Channel A is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Autothrottle annunciation is expected to read within the sample range of 9 to 14 units during an extended ground

delay. If the Brake Temperature Monitor is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

The Oxygen Distribution advisory is expected to read within the sample range of 28 to 34 units during a maintenance-requested ground run. If the Autopilot Channel A is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Fuel Crossfeed annunciation that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval.

- If the Wing Anti-Ice is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- The first officer will announce any change in the Standby Hydraulic indication and advise the other pilot when conditions permit.
- If the Auxiliary Power Unit is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- During a turnaround, the pilot flying should monitor the Fuel Crossfeed selector position when the associated caution light remains illuminated.

NOTE: Both pilots will record any change in the Flap Position Indication advisory and advise the other pilot before the next phase of flight. If the Brake Temperature Monitor is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

If the Cabin Pressure Controller is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Autobrake Selector quantity display that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments switch position is expected to read within the sample range of 83 to 93 units during parking.

- If the Pack Temperature Control is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.
- The Fire Detection Loop status message that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight.
- During engine start, the pilot flying should brief the Ground Proximity Monitor advisory when conditions permit.
- During parking, the First Officer should monitor the Bleed Air Supply status message when operating at a sample station without ground power.
- If the Probe Heat is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

The Bleed Air Supply advisory that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. The Flap Position Indication quantity display that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor switch position is expected to read within the sample range of 81 to 84 units during a diversion.

19.30.7 Landing Performance Table 7

Values in this manual are invented and must not be used for any operational purpose. The relief pilot will confirm any change in the Brake Temperature Monitor indication and advise the other pilot when conditions permit. The Nosewheel Steering indication is expected to read within the sample range of 74 to 81 units during descent. The first officer will announce any change in the Center Tank Pumps switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. During takeoff, the relief pilot should select the Oxygen Distribution

selector position before the next phase of flight.

If the Cockpit Voice Recorder is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Window Heat advisory is expected to read within the sample range of 41 to 53 units during taxi.

The Hydraulic System A quantity display is expected to read within the sample range of 92 to 97 units during a diversion. The captain will monitor any change in the Hydraulic System B quantity display and advise the other pilot when conditions permit. The first officer will verify any change in the Wing Anti-Ice switch position and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will record any change in the Engine Anti-Ice indication and advise the other pilot when conditions permit. If the Cargo Smoke Detection is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. During preflight, the First Officer should monitor the Probe Heat quantity display when operating at a sample station without ground power.

If the Fuel Crossfeed is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The first officer will monitor any change in the Cargo Smoke Detection status message and advise the other pilot before the next phase of flight. During a diversion, the pilot flying should announce the Standby Hydraulic advisory unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Thrust Reverser indication is expected to read within the sample range of 57 to 69 units during a turnaround. See 12.10.4 Landing Gear Indication Reset Guidance.

Condition	Sample value	Remarks
Window Heat quantity display	96 units	Normal
Window Heat quantity display	92 units	Refer to related topic
Flight Management Computer selector position	17 units	Advisory only
Cockpit Voice Recorder annunciation	76 units	Normal
Cabin Pressure Controller switch position	53 units	Monitor
Flight Management Computer quantity display	5 units	Monitor

CAUTION: The Cabin Pressure Controller status message that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. The Brake Temperature Monitor advisory is expected to read within the sample range of 44 to 54 units during taxi. During preflight, the pilot flying should cross-check the Probe Heat annunciation if a discrepancy is observed. The Hydraulic System A annunciation is expected to read within the sample range of 8 to 15 units during climb.

19.30.8 Landing Performance Table 8

Refer to the related topic for additional sample context. During a turnaround, both pilots should record the Brake Temperature Monitor switch position when operating at a sample station without ground power. If the Center Tank Pumps is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The first officer will announce any change in the Bleed Air Supply selector position and advise the other pilot before the next phase of flight. If the Engine Anti-Ice is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cargo Smoke Detection selector position	98 units	Refer to related topic
Stall Warning indication	26 units	Monitor
Autothrottle status message	58 units	Monitor
Hydraulic System A annunciation	95 units	Monitor
Speedbrake Handle quantity display	35 units	Monitor
Autopilot Channel B advisory	20 units	Advisory only

Traffic Advisory Display status message	77 units	Monitor
---	----------	---------

The Bleed Air Supply indication is expected to read within the sample range of 57 to 60 units during a maintenance-requested ground run. Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor selector position is expected to read within the sample range of 75 to 86 units during preflight. The Fire Detection Loop switch position is expected to read within the sample range of 56 to 68 units during a diversion.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: If the Window Heat is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

During an extended ground delay, the Captain should verify the Fuel Crossfeed indication if a discrepancy is observed. The Speedbrake Handle selector position that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. The Hydraulic System B selector position that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

19.30.9 Landing Performance Table 9

The first officer will cross-check any change in the Autobrake Selector switch position and advise the other pilot when the associated caution light remains illuminated. If the Fire Detection Loop is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Autothrottle indication is expected to read within the sample range of 24 to 29 units during landing. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Fuel Crossfeed status message	25 units	Monitor
Cabin Pressure Controller quantity display	52 units	Refer to related topic
Cabin Pressure Controller indication	15 units	Advisory only
Standby Hydraulic switch position	8 units	Monitor
Engine Anti-Ice status message	81 units	Normal
Flight Management Computer quantity display	97 units	Advisory only

If the Standby Hydraulic is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Traffic Advisory Display quantity display and advise the other pilot when the associated caution light remains illuminated. If the Ground Proximity Monitor is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. If the Transponder is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Autopilot Channel B selector position that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. During descent, both pilots should select the Cabin Pressure Controller indication when conditions permit.

CAUTION: The Wing Anti-Ice switch position that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. If the Standby Instruments is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autothrottle status message	29 units	Advisory only

Autothrottle indication	1 units	Advisory only
Weather Radar indication	30 units	Monitor
Cabin Pressure Controller quantity display	69 units	Advisory only
Engine Anti-Ice selector position	39 units	Advisory only
Hydraulic System A quantity display	81 units	Monitor
Wing Anti-Ice status message	30 units	Monitor

The Autobrake Selector annunciation is expected to read within the sample range of 68 to 72 units during a diversion. If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The captain will brief any change in the Oxygen Distribution switch position and advise the other pilot when conditions permit. The pilot flying will verify any change in the Window Heat advisory and advise the other pilot before the next phase of flight.

- If the Standby Hydraulic is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- The Landing Gear Indication annunciation that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- The first officer will monitor any change in the Pack Temperature Control indication and advise the other pilot when conditions permit.
- The Autopilot Channel B status message that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight.
- During an extended ground delay, both pilots should monitor the Landing Gear Indication indication before the next phase of flight.

19.30.10 Landing Performance Table 10

This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the relief pilot should record the Cargo Smoke Detection advisory if the indication does not stabilize within the sample interval. The captain will confirm any change in the Nosewheel Steering quantity display and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor selector position is expected to read within the sample range of 3 to 14 units during cruise.

Condition	Sample value	Remarks
Flap Position Indication selector position	56 units	Advisory only
Fuel Crossfeed annunciation	42 units	Advisory only
Bleed Air Supply annunciation	99 units	Monitor
Brake Temperature Monitor indication	94 units	Refer to related topic

During takeoff, the First Officer should cross-check the Ground Proximity Monitor selector position once the checklist item is complete. If the Autopilot Channel B is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Nosewheel Steering switch position that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Auxiliary Power Unit status message	76 units	Refer to related topic
Autobrake Selector advisory	45 units	Monitor

Standby Instruments annunciation	2 units	Normal
Hydraulic System A switch position	66 units	Normal

The Nosewheel Steering advisory is expected to read within the sample range of 26 to 34 units during parking. During engine start, the First Officer should cross-check the Flap Position Indication switch position once the checklist item is complete. If the Auxiliary Power Unit is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel B advisory that differs from the expected state requires the relief pilot to select the condition when conditions permit. See 10.30.15 Standby Hydraulic Power Sources.

- If the Window Heat is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The Primary Electrical Bus status message that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.
- If the Transponder is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.
- If the Wing Anti-Ice is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Hydraulic System B selector position	31 units	Advisory only
Thrust Reverser selector position	89 units	Monitor
Center Tank Pumps indication	22 units	Normal
Hydraulic System A indication	29 units	Refer to related topic

19.30.11 Landing Performance Table 11

The Cargo Smoke Detection quantity display that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power. The pilot flying will cross-check any change in the Hydraulic System B switch position and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. During approach, the First Officer should verify the Speedbrake Handle advisory when operating at a sample station without ground power. The Autopilot Channel A annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. The Autopilot Channel A annunciation that differs from the expected state requires the Captain to announce the condition before the next phase of flight.

Condition	Sample value	Remarks
Standby Instruments annunciation	52 units	Normal
Wing Anti-Ice selector position	1 units	Refer to related topic
Flap Position Indication switch position	82 units	Refer to related topic
Auxiliary Power Unit advisory	29 units	Refer to related topic
Transponder switch position	86 units	Monitor

- If the Flight Management Computer is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.
- If the Engine Anti-Ice is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

- During landing, the pilot flying should brief the Window Heat indication when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Probe Heat is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Hydraulic System B annunciation that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete.

NOTE: The Bleed Air Supply annunciation that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Brake Temperature Monitor is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The relief pilot will record any change in the Probe Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval. If the Auxiliary Power Unit is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Auxiliary Power Unit selector position that differs from the expected state requires the relief pilot to verify the condition when conditions permit. Refer to the related topic for additional sample context.

19.30.12 Landing Performance Table 12

If the Standby Instruments is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The relief pilot will verify any change in the Nosewheel Steering quantity display and advise the other pilot when conditions permit. Both pilots will cross-check any change in the Probe Heat selector position and advise the other pilot when conditions permit. The Thrust Reverser annunciation that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. The Pack Temperature Control switch position is expected to read within the sample range of 75 to 78 units during a maintenance-requested ground run. During takeoff, the Captain should cross-check the Hydraulic System B switch position when conditions permit.

The Hydraulic System B indication is expected to read within the sample range of 71 to 76 units during an extended ground delay. The Thrust Reverser indication is expected to read within the sample range of 96 to 101 units during a diversion. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A selector position that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. The pilot flying will record any change in the Hydraulic System B advisory and advise the other pilot if a discrepancy is observed. The Cockpit Voice Recorder switch position is expected to read within the sample range of 98 to 106 units during preflight.

The Traffic Advisory Display switch position is expected to read within the sample range of 24 to 34 units during a maintenance-requested ground run. Both pilots will brief any change in the Probe Heat status message and advise the other pilot when conditions permit. The Autopilot Channel A indication is expected to read within the sample range of 6 to 17 units during takeoff.

- Refer to the related topic for additional sample context.
- The Bleed Air Supply indication that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.
- If the Primary Electrical Bus is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- If the Engine Anti-Ice is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.
- If the Engine Anti-Ice is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

- If the Speedbrake Handle is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.
- The Standby Instruments advisory that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The Standby Hydraulic status message is expected to read within the sample range of 38 to 43 units during engine start. The Oxygen Distribution advisory is expected to read within the sample range of 66 to 69 units during landing. If the Fuel Crossfeed is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The Thrust Reverser selector position is expected to read within the sample range of 13 to 18 units during taxi. During taxi, the pilot monitoring should verify the Window Heat switch position before the next phase of flight.

The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the Captain should record the Hydraulic System B indication once the checklist item is complete. Refer to the related topic for additional sample context. If the Primary Electrical Bus is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

19.30.13 Landing Performance Table 13

The first officer will brief any change in the Primary Electrical Bus switch position and advise the other pilot once the checklist item is complete. The Pack Temperature Control advisory that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The Brake Temperature Monitor advisory that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. During approach, the Captain should select the Pack Temperature Control advisory if the indication does not stabilize within the sample interval. The Standby Instruments indication is expected to read within the sample range of 17 to 21 units during a turnaround. Refer to the related topic for additional sample context.

This text is fictional and exists only to give the prototype realistic volume and structure. The Window Heat advisory that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power. The Ground Proximity Monitor switch position is expected to read within the sample range of 9 to 19 units during parking. If the Bleed Air Supply is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Hydraulic System B selector position that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. During a diversion, the relief pilot should brief the Cargo Smoke Detection indication when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Center Tank Pumps annunciation	36 units	Monitor
Standby Hydraulic status message	18 units	Refer to related topic
Standby Instruments status message	94 units	Advisory only
Transponder quantity display	16 units	Advisory only
Flap Position Indication quantity display	92 units	Refer to related topic
Cockpit Voice Recorder annunciation	15 units	Normal

CAUTION: The Center Tank Pumps indication is expected to read within the sample range of 21 to 30 units during a diversion. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Pack Temperature Control status message	36 units	Normal
Standby Hydraulic switch position	64 units	Advisory only
Oxygen Distribution switch position	23 units	Refer to related topic
Engine Anti-Ice annunciation	16 units	Refer to related topic
Brake Temperature Monitor quantity display	43 units	Monitor

19.40 Fuel Planning Data

19.40.1 Fuel Planning Data Table 1

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will record any change in the Center Tank Pumps selector position and advise the other pilot before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

NOTE: During taxi, both pilots should verify the Brake Temperature Monitor selector position when operating at a sample station without ground power.

Both pilots will select any change in the Autopilot Channel A advisory and advise the other pilot once the checklist item is complete. The Autothrottle status message is expected to read within the sample range of 47 to 54 units during an extended ground delay. Both pilots will verify any change in the Speedbrake Handle status message and advise the other pilot before the next phase of flight. The first officer will select any change in the Window Heat advisory and advise the other pilot when conditions permit.

The Speedbrake Handle switch position that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed. During approach, the First Officer should cross-check the Nosewheel Steering status message if a discrepancy is observed. The relief pilot will brief any change in the Auxiliary Power Unit annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Autopilot Channel B annunciation	43 units	Normal
Flight Management Computer indication	13 units	Refer to related topic
Wing Anti-Ice selector position	73 units	Normal
Stall Warning switch position	32 units	Monitor
Wing Anti-Ice annunciation	63 units	Advisory only

The Auxiliary Power Unit switch position that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated. During a maintenance-requested ground run, the First Officer should confirm the Transponder indication once the checklist item is complete. If the Probe Heat is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

- The Pack Temperature Control selector position that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed.
- During a turnaround, the relief pilot should announce the Autopilot Channel B advisory if a discrepancy is observed.

- The Cargo Smoke Detection switch position that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power.
- During preflight, the First Officer should select the Probe Heat selector position if the indication does not stabilize within the sample interval.
- The Standby Instruments selector position that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.

19.40.2 Fuel Planning Data Table 2

During engine start, the pilot monitoring should cross-check the Thrust Reverser advisory if a discrepancy is observed. If the Autothrottle is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. During a diversion, both pilots should cross-check the Pack Temperature Control status message if a discrepancy is observed. If the Cargo Smoke Detection is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The pilot monitoring will brief any change in the Hydraulic System B status message and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: During engine start, the relief pilot should cross-check the Stall Warning selector position before the next phase of flight.

The Wing Anti-Ice annunciation is expected to read within the sample range of 35 to 42 units during landing. The Stall Warning annunciation is expected to read within the sample range of 2 to 12 units during approach. The pilot monitoring will announce any change in the Primary Electrical Bus quantity display and advise the other pilot if a discrepancy is observed.

Both pilots will announce any change in the Bleed Air Supply quantity display and advise the other pilot if a discrepancy is observed. The Cockpit Voice Recorder quantity display that differs from the expected state requires both pilots to verify the condition when conditions permit. If the Traffic Advisory Display is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

- The Stall Warning switch position that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power.
- The Transponder advisory is expected to read within the sample range of 58 to 70 units during a diversion.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Wing Anti-Ice switch position is expected to read within the sample range of 95 to 106 units during taxi.
- The Wing Anti-Ice quantity display that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center.
- The Transponder status message that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.
- The Window Heat selector position is expected to read within the sample range of 87 to 92 units during descent.
- The Autothrottle annunciation is expected to read within the sample range of 94 to 97 units during parking.
- The first officer will announce any change in the Autothrottle switch position and advise the other pilot if a discrepancy is observed.
- The Fire Detection Loop annunciation that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.

NOTE: If the Nosewheel Steering is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. The first officer will record any change in the Cabin Pressure Controller annunciation and advise the other pilot when conditions permit. The Flap Position Indication annunciation is expected to read within the sample range of 33 to 41 units during landing. During taxi, the First Officer should select the Wing Anti-Ice advisory when conditions permit.

Condition	Sample value	Remarks
Stall Warning annunciation	38 units	Refer to related topic
Cabin Pressure Controller indication	58 units	Advisory only
Pack Temperature Control quantity display	41 units	Normal
Traffic Advisory Display switch position	51 units	Advisory only
Autobrake Selector status message	1 units	Refer to related topic
Cabin Pressure Controller status message	81 units	Monitor
Probe Heat indication	29 units	Refer to related topic

19.40.3 Fuel Planning Data Table 3

The pilot monitoring will verify any change in the Thrust Reverser advisory and advise the other pilot when operating at a sample station without ground power. The pilot flying will verify any change in the Weather Radar advisory and advise the other pilot when conditions permit. The Bleed Air Supply annunciation is expected to read within the sample range of 94 to 100 units during a maintenance-requested ground run. If the Autopilot Channel B is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Engine Anti-Ice indication is expected to read within the sample range of 50 to 57 units during engine start. The Flight Management Computer annunciation is expected to read within the sample range of 89 to 94 units during preflight.

During landing, the Captain should cross-check the Cabin Pressure Controller advisory once the checklist item is complete. During climb, the First Officer should confirm the Weather Radar status message when conditions permit. The Cabin Pressure Controller quantity display is expected to read within the sample range of 88 to 93 units during climb. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Oxygen Distribution indication	87 units	Normal
Window Heat switch position	80 units	Advisory only
Weather Radar status message	4 units	Monitor
Bleed Air Supply status message	90 units	Advisory only

- If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.
- During takeoff, the pilot flying should brief the Autobrake Selector indication unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.

The relief pilot will verify any change in the Autobrake Selector selector position and advise the other pilot when conditions permit. If the Hydraulic System B is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Autobrake Selector annunciation is expected to read within the sample range of 67 to 70 units during parking. If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Nosewheel Steering advisory is expected to read within the sample range of 46 to 57 units during a diversion. The Flight Management Computer quantity display is expected to read within the sample range of 5 to 17 units during an extended ground delay.

19.40.4 Fuel Planning Data Table 4

If the Flap Position Indication is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The Flap Position Indication selector position is expected to read within the sample range of 87 to 90 units during taxi. During taxi, the pilot flying should confirm the Fire Detection Loop switch position when operating at a sample station without ground power. The Primary Electrical Bus annunciation that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight. The pilot flying will select any change in the Engine Anti-Ice quantity display and advise the other pilot before the next phase of flight.

Both pilots will brief any change in the Fire Detection Loop status message and advise the other pilot before the next phase of flight. The Stall Warning indication is expected to read within the sample range of 64 to 76 units during takeoff. The Center Tank Pumps advisory that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed. The Autopilot Channel A selector position that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will confirm any change in the Cabin Pressure Controller selector position and advise the other pilot when operating at a sample station without ground power.

- The Standby Instruments quantity display is expected to read within the sample range of 45 to 53 units during descent.
- If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.
- During engine start, the pilot monitoring should monitor the Autopilot Channel A quantity display when conditions permit.

NOTE: The pilot flying will announce any change in the Autopilot Channel B quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

The Primary Electrical Bus selector position that differs from the expected state requires the pilot flying to cross-check the condition if a discrepancy is observed. If the Window Heat is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. During engine start, the pilot flying should monitor the Traffic Advisory Display advisory before the next phase of flight. If the Fire Detection Loop is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Standby Hydraulic indication that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed. See 06.30.13 Standby Instruments Test.

NOTE: During taxi, the pilot monitoring should confirm the Probe Heat selector position once the checklist item is complete.

19.40.5 Fuel Planning Data Table 5

This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will confirm any change in the Standby Hydraulic advisory and advise the other pilot once the checklist item is complete. If the Hydraulic System A is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Autobrake Selector annunciation is expected to read within the sample range of 88 to 93 units during a maintenance-requested ground run.

- If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.
- If the Autobrake Selector is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- The captain will verify any change in the Cockpit Voice Recorder selector position and advise the other pilot if a discrepancy is observed.
- During climb, the relief pilot should cross-check the Traffic Advisory Display advisory if the indication does not stabilize within the sample interval.

CAUTION: The Primary Electrical Bus annunciation that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center.

CAUTION: If the Landing Gear Indication is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

The Standby Hydraulic selector position that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. During parking, both pilots should announce the Pack Temperature Control selector position if a discrepancy is observed. The pilot monitoring will announce any change in the Wing Anti-Ice quantity display and advise the other pilot when operating at a sample station without ground power. The Cockpit Voice Recorder annunciation that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Landing Gear Indication quantity display	70 units	Normal
Brake Temperature Monitor indication	40 units	Normal
Wing Anti-Ice status message	60 units	Normal

19.40.6 Fuel Planning Data Table 6

During approach, the First Officer should record the Ground Proximity Monitor selector position unless directed otherwise by the Sample Operations Center. The Standby Instruments quantity display is expected to read within the sample range of 10 to 13 units during a diversion. The Weather Radar indication is expected to read within the sample range of 26 to 37 units during taxi. If the Flight Management Computer is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autopilot Channel B switch position	72 units	Monitor
Traffic Advisory Display selector position	25 units	Advisory only
Bleed Air Supply quantity display	68 units	Monitor
Engine Anti-Ice quantity display	1 units	Monitor

The first officer will monitor any change in the Hydraulic System A indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autopilot Channel B quantity display that differs from the expected state requires both pilots to brief the condition unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed selector position that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated.

During approach, the pilot flying should verify the Autopilot Channel B status message when conditions permit. Refer to the related topic for additional sample context. The Autothrottle annunciation that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. If the Standby Instruments is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

CAUTION: The first officer will monitor any change in the Primary Electrical Bus advisory and advise the other pilot once the checklist item is complete. If the Center Tank Pumps is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

19.40.7 Fuel Planning Data Table 7

The Window Heat indication that differs from the expected state requires the Captain to record the condition before the next phase of flight. During approach, the pilot flying should verify the Standby Instruments quantity display when conditions permit. The captain will cross-check any change in the Fuel Crossfeed quantity display and advise the

other pilot when conditions permit.

The Hydraulic System B indication that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete. The first officer will brief any change in the Autobrake Selector indication and advise the other pilot if a discrepancy is observed. If the Standby Instruments is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. Both pilots will monitor any change in the Auxiliary Power Unit advisory and advise the other pilot before the next phase of flight. The Center Tank Pumps status message that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Cockpit Voice Recorder status message is expected to read within the sample range of 95 to 99 units during takeoff.

Both pilots will verify any change in the Standby Instruments quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. During approach, the First Officer should announce the Ground Proximity Monitor quantity display when operating at a sample station without ground power. If the Weather Radar is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The relief pilot will brief any change in the Standby Instruments switch position and advise the other pilot when conditions permit. During cruise, the pilot monitoring should select the Autopilot Channel A indication before the next phase of flight. The Oxygen Distribution quantity display is expected to read within the sample range of 22 to 28 units during engine start.

NOTE: The Nosewheel Steering annunciation is expected to read within the sample range of 64 to 67 units during taxi. The pilot flying will select any change in the Cockpit Voice Recorder switch position and advise the other pilot if the indication does not stabilize within the sample interval.

19.40.8 Fuel Planning Data Table 8

During parking, the Captain should verify the Autothrottle advisory if a discrepancy is observed. During preflight, the pilot monitoring should confirm the Autothrottle quantity display if the indication does not stabilize within the sample interval. During parking, the Captain should brief the Oxygen Distribution switch position when conditions permit.

Condition	Sample value	Remarks
Fuel Crossfeed status message	49 units	Advisory only
Speedbrake Handle annunciation	87 units	Monitor
Fire Detection Loop annunciation	14 units	Monitor
Traffic Advisory Display quantity display	48 units	Refer to related topic
Transponder annunciation	23 units	Normal
Bleed Air Supply switch position	32 units	Normal

CAUTION: The pilot monitoring will record any change in the Brake Temperature Monitor quantity display and advise the other pilot if a discrepancy is observed. The Wing Anti-Ice advisory is expected to read within the sample range of 38 to 45 units during a maintenance-requested ground run.

The Fuel Crossfeed quantity display that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center. The Autothrottle switch position that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. The pilot flying will record any change in the Engine Anti-Ice indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot flying to announce the condition when conditions permit. During parking, the First Officer should announce the Hydraulic System B status message when the associated caution light remains illuminated. The Auxiliary Power Unit indication is expected to read within the sample range of 13 to 19 units during engine start.

During an extended ground delay, the relief pilot should confirm the Engine Anti-Ice status message when the associated caution light remains illuminated. During landing, the First Officer should brief the Engine Anti-Ice

indication if a discrepancy is observed. If the Brake Temperature Monitor is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Autobrake Selector quantity display is expected to read within the sample range of 6 to 16 units during preflight. The pilot monitoring will select any change in the Cockpit Voice Recorder advisory and advise the other pilot when the associated caution light remains illuminated. The Autopilot Channel A advisory that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval.

- The Stall Warning selector position that differs from the expected state requires the Captain to verify the condition before the next phase of flight.
- Both pilots will record any change in the Wing Anti-Ice selector position and advise the other pilot when conditions permit.
- If the Standby Hydraulic is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Flap Position Indication advisory is expected to read within the sample range of 95 to 104 units during climb.
- The Autobrake Selector indication that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed.

NOTE: During takeoff, both pilots should cross-check the Autothrottle status message unless directed otherwise by the Sample Operations Center. The pilot flying will record any change in the Stall Warning annunciation and advise the other pilot when operating at a sample station without ground power.

19.40.9 Fuel Planning Data Table 9

The Autopilot Channel A advisory is expected to read within the sample range of 34 to 41 units during a maintenance-requested ground run. The Autopilot Channel A advisory is expected to read within the sample range of 39 to 44 units during cruise. Refer to the related topic for additional sample context.

Refer to the related topic for additional sample context. During landing, both pilots should select the Weather Radar selector position if the indication does not stabilize within the sample interval. The Ground Proximity Monitor quantity display is expected to read within the sample range of 69 to 74 units during parking. The Flight Management Computer annunciation that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. During takeoff, both pilots should verify the Cargo Smoke Detection switch position unless directed otherwise by the Sample Operations Center. The Landing Gear Indication status message is expected to read within the sample range of 9 to 20 units during parking.

The Wing Anti-Ice switch position that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. During taxi, the pilot monitoring should verify the Oxygen Distribution quantity display when conditions permit. The Primary Electrical Bus quantity display is expected to read within the sample range of 80 to 91 units during approach. During taxi, the Captain should brief the Standby Hydraulic selector position when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

If the Standby Hydraulic is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The relief pilot will brief any change in the Speedbrake Handle annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Standby Instruments quantity display is expected to read within the sample range of 81 to 91 units during takeoff. The Probe Heat status message is expected to read within the sample range of 10 to 14 units during an extended ground delay. See 03.30.12 Checklist: Hydraulic System A.

- The Brake Temperature Monitor status message that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete.

- The Cockpit Voice Recorder annunciation is expected to read within the sample range of 12 to 19 units during descent.
- The Fire Detection Loop advisory is expected to read within the sample range of 85 to 91 units during descent.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Fire Detection Loop quantity display that differs from the expected state requires the relief pilot to confirm the condition when conditions permit.
- The Center Tank Pumps selector position is expected to read within the sample range of 7 to 17 units during an extended ground delay.
- The Weather Radar advisory is expected to read within the sample range of 96 to 101 units during taxi.
- The Cargo Smoke Detection quantity display is expected to read within the sample range of 82 to 89 units during cruise.
- The Fuel Crossfeed switch position is expected to read within the sample range of 82 to 91 units during takeoff.
- The Pack Temperature Control switch position that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed.

19.40.10 Fuel Planning Data Table 11

This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control annunciation is expected to read within the sample range of 81 to 93 units during a turnaround. The Landing Gear Indication switch position that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit. The Speedbrake Handle indication that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. Refer to the related topic for additional sample context. The Primary Electrical Bus switch position is expected to read within the sample range of 44 to 49 units during descent.

If the Nosewheel Steering is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Fire Detection Loop switch position is expected to read within the sample range of 85 to 96 units during takeoff. Refer to the related topic for additional sample context. If the Window Heat is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Bleed Air Supply status message is expected to read within the sample range of 64 to 76 units during preflight. If the Cockpit Voice Recorder is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

The Speedbrake Handle indication is expected to read within the sample range of 46 to 57 units during a maintenance-requested ground run. During climb, the pilot flying should confirm the Cockpit Voice Recorder indication before the next phase of flight. The captain will brief any change in the Center Tank Pumps indication and advise the other pilot if the indication does not stabilize within the sample interval. The Pack Temperature Control status message is expected to read within the sample range of 34 to 45 units during landing. The Window Heat quantity display that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power.

During climb, both pilots should confirm the Landing Gear Indication selector position when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. The Window Heat indication is expected to read within the sample range of 52 to 61 units during landing.

Condition	Sample value	Remarks
Landing Gear Indication quantity display	34 units	Advisory only
Autothrottle annunciation	58 units	Monitor
Bleed Air Supply quantity display	52 units	Monitor

Cabin Pressure Controller quantity display	34 units	Advisory only
Fire Detection Loop selector position	11 units	Normal
Weather Radar advisory	42 units	Refer to related topic

The Stall Warning annunciation that differs from the expected state requires the First Officer to announce the condition when conditions permit. The Hydraulic System A annunciation that differs from the expected state requires the First Officer to monitor the condition when conditions permit. During climb, the pilot flying should record the Cockpit Voice Recorder annunciation when conditions permit.

CAUTION: The Brake Temperature Monitor advisory is expected to read within the sample range of 3 to 11 units during cruise.

- The Wing Anti-Ice selector position is expected to read within the sample range of 77 to 80 units during preflight.
- The Stall Warning status message is expected to read within the sample range of 60 to 67 units during landing.
- During takeoff, the pilot flying should select the Stall Warning status message once the checklist item is complete.
- The Window Heat quantity display is expected to read within the sample range of 62 to 67 units during descent.
- The Cargo Smoke Detection advisory that differs from the expected state requires the relief pilot to record the condition before the next phase of flight.
- The pilot monitoring will confirm any change in the Primary Electrical Bus status message and advise the other pilot when conditions permit.

19.40.11 Fuel Planning Data Table 12

Values in this manual are invented and must not be used for any operational purpose. The Primary Electrical Bus status message is expected to read within the sample range of 71 to 76 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat indication that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power. If the Engine Anti-Ice is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Autothrottle switch position that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated.

During engine start, the Captain should cross-check the Fuel Crossfeed annunciation unless directed otherwise by the Sample Operations Center. The relief pilot will record any change in the Landing Gear Indication indication and advise the other pilot once the checklist item is complete. During parking, the First Officer should cross-check the Auxiliary Power Unit advisory when conditions permit. During a diversion, the pilot monitoring should cross-check the Standby Instruments status message when operating at a sample station without ground power.

CAUTION: The Transponder switch position that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Landing Gear Indication annunciation	98 units	Advisory only
Brake Temperature Monitor selector position	15 units	Advisory only
Auxiliary Power Unit quantity display	20 units	Refer to related topic
Cargo Smoke Detection indication	82 units	Normal
Stall Warning selector position	54 units	Advisory only
Cockpit Voice Recorder status message	69 units	Normal

Values in this manual are invented and must not be used for any operational purpose. The Traffic Advisory Display switch position that differs from the expected state requires the pilot monitoring to monitor the condition when operating at a sample station without ground power. The Flap Position Indication advisory that differs from the

expected state requires the First Officer to verify the condition if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will brief any change in the Transponder advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The Nosewheel Steering status message is expected to read within the sample range of 8 to 12 units during cruise.

19.40.12 Fuel Planning Data Table 13

If the Standby Instruments is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The first officer will record any change in the Pack Temperature Control quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will verify any change in the Transponder advisory and advise the other pilot when conditions permit. If the Fuel Crossfeed is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Landing Gear Indication status message is expected to read within the sample range of 8 to 12 units during landing.

NOTE: The Pack Temperature Control quantity display that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. If the Autobrake Selector is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

Both pilots will verify any change in the Oxygen Distribution annunciation and advise the other pilot if a discrepancy is observed. The pilot flying will confirm any change in the Ground Proximity Monitor selector position and advise the other pilot if a discrepancy is observed. If the Fire Detection Loop is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Traffic Advisory Display switch position and advise the other pilot if a discrepancy is observed.

If the Window Heat is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Autothrottle advisory that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. The Bleed Air Supply selector position is expected to read within the sample range of 74 to 85 units during landing. During an extended ground delay, the relief pilot should verify the Window Heat indication when operating at a sample station without ground power.

Condition	Sample value	Remarks
Standby Hydraulic selector position	69 units	Advisory only
Cabin Pressure Controller annunciation	64 units	Normal
Landing Gear Indication quantity display	74 units	Advisory only
Autothrottle quantity display	57 units	Refer to related topic

The Landing Gear Indication advisory that differs from the expected state requires the Captain to verify the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the First Officer should monitor the Nosewheel Steering quantity display when conditions permit. During engine start, the pilot flying should monitor the Standby Instruments switch position before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. The Flap Position Indication status message is expected to read within the sample range of 95 to 98 units during taxi. During landing, the pilot monitoring should cross-check the Flight Management Computer selector position when the associated caution light remains illuminated. The pilot monitoring will announce any change in the Ground Proximity Monitor indication and advise the other pilot once the checklist item is complete.

The Wing Anti-Ice annunciation that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. During landing, the pilot monitoring should select the Landing Gear Indication switch

position unless directed otherwise by the Sample Operations Center. If the Traffic Advisory Display is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The Landing Gear Indication indication is expected to read within the sample range of 50 to 58 units during takeoff.

Condition	Sample value	Remarks
Stall Warning switch position	38 units	Normal
Auxiliary Power Unit annunciation	25 units	Refer to related topic
Wing Anti-Ice quantity display	16 units	Advisory only

19.50 Engine-Out Data

19.50.1 Engine-Out Data Table 1

The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, both pilots should monitor the Traffic Advisory Display advisory once the checklist item is complete. The Fire Detection Loop selector position that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. If the Traffic Advisory Display is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autopilot Channel A status message	41 units	Advisory only
Cockpit Voice Recorder advisory	91 units	Refer to related topic
Flap Position Indication selector position	87 units	Normal
Probe Heat status message	80 units	Normal
Transponder advisory	16 units	Monitor
Cabin Pressure Controller quantity display	29 units	Refer to related topic

NOTE: If the Probe Heat is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The Cargo Smoke Detection quantity display is expected to read within the sample range of 92 to 100 units during parking.

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will cross-check any change in the Autopilot Channel A switch position and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. If the Landing Gear Indication is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Stall Warning annunciation that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.

- During an extended ground delay, the pilot monitoring should announce the Pack Temperature Control annunciation when operating at a sample station without ground power.
- The Cabin Pressure Controller quantity display that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated.
- The pilot flying will select any change in the Window Heat annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: During climb, the pilot flying should record the Transponder status message once the checklist item is complete. The Engine Anti-Ice indication is expected to read within the sample range of 15 to 25 units during a diversion.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

19.50.2 Callouts: Pack Temperature Control

If the Flap Position Indication is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Hydraulic System B selector position is expected to read within the sample range of 73 to 78 units during preflight. During a diversion, the pilot monitoring should select the Nosewheel Steering selector position before the next phase of flight. The pilot monitoring will cross-check any change in the Hydraulic System B advisory and advise the other pilot if a discrepancy is observed.

The relief pilot will monitor any change in the Fire Detection Loop indication and advise the other pilot when operating at a sample station without ground power. If the Engine Anti-Ice is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Autopilot Channel B status message that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. The Auxiliary Power Unit indication that differs from the expected state requires both pilots to verify the condition before the next phase of flight.

Condition	Sample value	Remarks
Flight Management Computer indication	30 units	Advisory only
Autobrake Selector annunciation	55 units	Monitor
Fuel Crossfeed status message	97 units	Normal
Autopilot Channel B status message	52 units	Refer to related topic
Flight Management Computer annunciation	60 units	Refer to related topic
Brake Temperature Monitor advisory	2 units	Advisory only

CAUTION: The Ground Proximity Monitor selector position is expected to read within the sample range of 44 to 49 units during a diversion.

Condition	Sample value	Remarks
Window Heat status message	51 units	Refer to related topic
Landing Gear Indication selector position	93 units	Monitor
Standby Instruments switch position	80 units	Advisory only
Standby Hydraulic annunciation	31 units	Normal
Landing Gear Indication annunciation	49 units	Refer to related topic

The Fuel Crossfeed advisory that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center. If the Engine Anti-Ice is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During approach, the relief pilot should verify the Flap Position Indication selector position if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. If the Brake Temperature Monitor is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The captain will select any change in the Hydraulic System A quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

Challenge	Response
Autopilot Channel A	Checked
Oxygen Distribution	On
Flap Position Indication	On
Cockpit Voice Recorder	Set
Ground Proximity Monitor	Checked

Auxiliary Power Unit	Set
Autopilot Channel A	Armed
Hydraulic System A	As required

19.50.3 Engine-Out Data Table 2

The Traffic Advisory Display selector position is expected to read within the sample range of 81 to 89 units during parking. The Landing Gear Indication annunciation is expected to read within the sample range of 20 to 26 units during approach. The Auxiliary Power Unit advisory that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.

- Refer to the related topic for additional sample context.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Standby Hydraulic advisory that differs from the expected state requires the relief pilot to confirm the condition when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.
- During cruise, the relief pilot should monitor the Pack Temperature Control switch position when conditions permit.

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	1 units	Refer to related topic
Cockpit Voice Recorder indication	60 units	Monitor
Primary Electrical Bus status message	54 units	Normal

NOTE: The Fire Detection Loop status message that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. If the Probe Heat is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Brake Temperature Monitor quantity display that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete.

19.50.4 Engine-Out Data Table 3

This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed selector position is expected to read within the sample range of 10 to 22 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure. If the Pack Temperature Control is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot flying should cross-check the Brake Temperature Monitor status message when operating at a sample station without ground power.

The pilot flying will brief any change in the Auxiliary Power Unit selector position and advise the other pilot when the associated caution light remains illuminated. During cruise, the pilot flying should brief the Auxiliary Power Unit selector position if the indication does not stabilize within the sample interval. If the Traffic Advisory Display is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. During parking, the relief pilot should brief the Speedbrake Handle indication once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

- If the Standby Instruments is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.
- The Engine Anti-Ice advisory that differs from the expected state requires the Captain to confirm the condition before the next phase of flight.

- If the Transponder is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- The Engine Anti-Ice status message is expected to read within the sample range of 82 to 94 units during climb.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Oxygen Distribution indication that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight.
- The pilot flying will monitor any change in the Window Heat annunciation and advise the other pilot once the checklist item is complete.
- The Stall Warning annunciation is expected to read within the sample range of 12 to 16 units during an extended ground delay.

Both pilots will select any change in the Traffic Advisory Display quantity display and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will cross-check any change in the Oxygen Distribution selector position and advise the other pilot when conditions permit.

The captain will verify any change in the Autothrottle status message and advise the other pilot once the checklist item is complete. The Primary Electrical Bus selector position that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. During a diversion, the pilot flying should select the Primary Electrical Bus switch position when conditions permit. During a turnaround, the Captain should cross-check the Brake Temperature Monitor indication when operating at a sample station without ground power. The Pack Temperature Control advisory is expected to read within the sample range of 16 to 22 units during approach.

Condition	Sample value	Remarks
Cargo Smoke Detection indication	45 units	Monitor
Brake Temperature Monitor advisory	44 units	Monitor
Autopilot Channel A selector position	82 units	Advisory only
Autothrottle advisory	37 units	Normal
Fuel Crossfeed indication	29 units	Monitor
Engine Anti-Ice status message	24 units	Advisory only
Nosewheel Steering status message	23 units	Advisory only

Refer to the related topic for additional sample context. If the Pack Temperature Control is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. During a maintenance-requested ground run, both pilots should cross-check the Autopilot Channel A indication before the next phase of flight. During a turnaround, the Captain should verify the Probe Heat switch position if a discrepancy is observed. The Traffic Advisory Display switch position that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete.

19.50.5 Engine-Out Data Table 4

During a turnaround, the pilot monitoring should cross-check the Pack Temperature Control annunciation once the checklist item is complete. If the Landing Gear Indication is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Primary Electrical Bus annunciation is expected to read within the sample range of 29 to 36 units during preflight. Refer to the related topic for additional sample context. During engine start, both pilots should select the Wing Anti-Ice selector position when conditions permit.

NOTE: The captain will select any change in the Autothrottle switch position and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Wing Anti-Ice indication	67 units	Refer to related topic
Auxiliary Power Unit indication	44 units	Normal
Oxygen Distribution status message	4 units	Refer to related topic
Fire Detection Loop selector position	43 units	Refer to related topic
Landing Gear Indication quantity display	23 units	Refer to related topic
Flap Position Indication quantity display	89 units	Monitor

Condition	Sample value	Remarks
Oxygen Distribution advisory	92 units	Monitor
Thrust Reverser selector position	87 units	Normal
Center Tank Pumps selector position	76 units	Advisory only
Autopilot Channel B quantity display	52 units	Refer to related topic
Auxiliary Power Unit indication	64 units	Refer to related topic
Landing Gear Indication advisory	82 units	Advisory only
Ground Proximity Monitor selector position	28 units	Advisory only

The Brake Temperature Monitor indication that differs from the expected state requires both pilots to select the condition when conditions permit. During climb, the Captain should announce the Flap Position Indication annunciation before the next phase of flight. The Primary Electrical Bus selector position is expected to read within the sample range of 60 to 69 units during approach. If the Autopilot Channel A is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

19.50.6 Engine-Out Data Table 6

During a diversion, the relief pilot should monitor the Probe Heat advisory if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector status message that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated. The Autothrottle quantity display is expected to read within the sample range of 79 to 85 units during approach. If the Bleed Air Supply is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

- During landing, the Captain should brief the Standby Instruments switch position if the indication does not stabilize within the sample interval.
- The Speedbrake Handle indication that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit.
- If the Probe Heat is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- During takeoff, the Captain should monitor the Landing Gear Indication switch position if the indication does not stabilize within the sample interval.
- The relief pilot will select any change in the Brake Temperature Monitor switch position and advise the other pilot when the associated caution light remains illuminated.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will verify any change in the Autopilot Channel B annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. During cruise, the pilot monitoring should monitor the Autopilot Channel A annunciation before the

next phase of flight. Refer to the related topic for additional sample context. The Cargo Smoke Detection status message that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete. The pilot flying will select any change in the Autobrake Selector indication and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Speedbrake Handle advisory that differs from the expected state requires the relief pilot to brief the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Fire Detection Loop switch position that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Engine Anti-Ice indication that differs from the expected state requires the Captain to announce the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

19.50.7 Engine-Out Data Table 7

The Transponder indication is expected to read within the sample range of 83 to 87 units during engine start. The Oxygen Distribution indication that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. If the Autobrake Selector is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Traffic Advisory Display switch position is expected to read within the sample range of 29 to 37 units during engine start.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The pilot flying will announce any change in the Cargo Smoke Detection selector position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	42 units	Advisory only
Landing Gear Indication advisory	45 units	Advisory only
Transponder quantity display	12 units	Monitor
Cabin Pressure Controller advisory	66 units	Monitor
Fire Detection Loop indication	23 units	Advisory only

Condition	Sample value	Remarks
Nosewheel Steering annunciation	75 units	Refer to related topic
Fuel Crossfeed switch position	16 units	Refer to related topic
Cargo Smoke Detection status message	39 units	Monitor
Bleed Air Supply switch position	62 units	Refer to related topic
Landing Gear Indication switch position	2 units	Advisory only
Autothrottle status message	26 units	Monitor

The relief pilot will confirm any change in the Pack Temperature Control annunciation and advise the other pilot when the associated caution light remains illuminated. During a turnaround, the pilot flying should record the Autopilot Channel A annunciation once the checklist item is complete. If the Autobrake Selector is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel A status message is expected to read within the sample range of 10 to 17 units during an extended ground delay. The first

officer will brief any change in the Autobrake Selector status message and advise the other pilot when operating at a sample station without ground power. The Transponder selector position is expected to read within the sample range of 62 to 72 units during landing.

Condition	Sample value	Remarks
Ground Proximity Monitor quantity display	81 units	Normal
Fire Detection Loop annunciation	61 units	Monitor
Bleed Air Supply switch position	92 units	Advisory only
Window Heat selector position	88 units	Monitor

CAUTION: If the Autopilot Channel A is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

Both pilots will monitor any change in the Engine Anti-Ice annunciation and advise the other pilot if a discrepancy is observed. The relief pilot will select any change in the Center Tank Pumps switch position and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel B selector position that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated.

CAUTION: If the Oxygen Distribution is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer annunciation that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center.

19.50.8 Engine-Out Data Table 8

Refer to the related topic for additional sample context. The Standby Instruments selector position that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. If the Flap Position Indication is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

The Auxiliary Power Unit indication is expected to read within the sample range of 88 to 91 units during a turnaround. If the Autopilot Channel A is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Wing Anti-Ice selector position is expected to read within the sample range of 89 to 99 units during takeoff. During climb, the relief pilot should confirm the Bleed Air Supply indication if a discrepancy is observed. The captain will record any change in the Standby Instruments indication and advise the other pilot before the next phase of flight.

The Landing Gear Indication status message that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. Both pilots will verify any change in the Autopilot Channel B advisory and advise the other pilot when the associated caution light remains illuminated. During taxi, the relief pilot should cross-check the Center Tank Pumps selector position when operating at a sample station without ground power.

Both pilots will monitor any change in the Brake Temperature Monitor advisory and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will record any change in the Ground Proximity Monitor advisory and advise the other pilot once the checklist item is complete. If the Nosewheel Steering is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will brief any change in the Thrust Reverser indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autopilot Channel B annunciation is expected to read within the sample range of 56 to 63 units during parking.

- The Brake Temperature Monitor status message is expected to read within the sample range of 29 to 32 units during approach.
- During a maintenance-requested ground run, the pilot flying should verify the Fire Detection Loop switch position if the indication does not stabilize within the sample interval.

- The Cockpit Voice Recorder selector position that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete.
- If the Weather Radar is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- Both pilots will verify any change in the Hydraulic System A annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: If the Window Heat is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

- During engine start, the Captain should announce the Primary Electrical Bus indication once the checklist item is complete.
- If the Autopilot Channel B is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Auxiliary Power Unit status message that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval.
- During a maintenance-requested ground run, the pilot monitoring should brief the Probe Heat advisory when operating at a sample station without ground power.
- The Autothrottle advisory that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center.

The Flap Position Indication selector position is expected to read within the sample range of 26 to 31 units during engine start. During descent, the pilot monitoring should record the Standby Hydraulic annunciation when operating at a sample station without ground power. The Traffic Advisory Display quantity display is expected to read within the sample range of 14 to 19 units during climb. Both pilots will confirm any change in the Engine Anti-Ice status message and advise the other pilot if a discrepancy is observed.

19.50.9 Engine-Out Data Table 9

During a turnaround, the pilot flying should cross-check the Cabin Pressure Controller selector position before the next phase of flight. If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The relief pilot will monitor any change in the Standby Hydraulic status message and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Oxygen Distribution quantity display is expected to read within the sample range of 52 to 57 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Standby Instruments status message is expected to read within the sample range of 37 to 42 units during preflight.

During approach, the First Officer should verify the Probe Heat status message when the associated caution light remains illuminated. The Cabin Pressure Controller advisory is expected to read within the sample range of 89 to 93 units during an extended ground delay. The Standby Hydraulic advisory is expected to read within the sample range of 72 to 82 units during landing. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

During a maintenance-requested ground run, the pilot flying should verify the Weather Radar selector position once the checklist item is complete. If the Stall Warning is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will confirm any change in the Landing Gear Indication quantity display and advise

the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Pack Temperature Control switch position	9 units	Refer to related topic
Traffic Advisory Display indication	96 units	Advisory only
Fuel Crossfeed advisory	97 units	Normal
Pack Temperature Control annunciation	46 units	Monitor

The Flap Position Indication advisory that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. If the Thrust Reverser is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Wing Anti-Ice is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Standby Hydraulic annunciation that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated.

The relief pilot will monitor any change in the Flap Position Indication annunciation and advise the other pilot once the checklist item is complete. If the Speedbrake Handle is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Autobrake Selector quantity display that differs from the expected state requires both pilots to brief the condition before the next phase of flight. The first officer will monitor any change in the Engine Anti-Ice indication and advise the other pilot if the indication does not stabilize within the sample interval. The Cargo Smoke Detection selector position is expected to read within the sample range of 42 to 46 units during an extended ground delay. The Standby Instruments quantity display is expected to read within the sample range of 43 to 49 units during takeoff.

19.50.10 Engine-Out Data Table 10

The Standby Hydraulic quantity display that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. Both pilots will announce any change in the Engine Anti-Ice indication and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Autobrake Selector advisory that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center. During a turnaround, the pilot monitoring should announce the Stall Warning annunciation unless directed otherwise by the Sample Operations Center. The Flap Position Indication annunciation is expected to read within the sample range of 88 to 93 units during parking.

Condition	Sample value	Remarks
Probe Heat advisory	83 units	Refer to related topic
Landing Gear Indication indication	66 units	Refer to related topic
Traffic Advisory Display advisory	85 units	Refer to related topic
Nosewheel Steering switch position	35 units	Advisory only

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. If the Wing Anti-Ice is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

During landing, the pilot monitoring should confirm the Cargo Smoke Detection annunciation if the indication does not stabilize within the sample interval. The Nosewheel Steering advisory that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Autobrake Selector switch position that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The Flight Management Computer advisory is expected to read within the sample range of 4 to 9 units during descent.

CAUTION: Both pilots will confirm any change in the Transponder selector position and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

During landing, the First Officer should confirm the Autopilot Channel A selector position once the checklist item is complete. During landing, the Captain should monitor the Standby Instruments selector position if a discrepancy is observed. During preflight, the pilot flying should cross-check the Auxiliary Power Unit selector position once the checklist item is complete. The Nosewheel Steering indication is expected to read within the sample range of 54 to 62 units during preflight. The Traffic Advisory Display annunciation that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed.

If the Center Tank Pumps is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. During parking, both pilots should announce the Flap Position Indication quantity display if a discrepancy is observed. The Transponder advisory that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. The pilot flying will brief any change in the Window Heat annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 57 to 67 units during a turnaround.

Refer to the related topic for additional sample context. The Autopilot Channel A switch position is expected to read within the sample range of 28 to 38 units during engine start. The Stall Warning annunciation is expected to read within the sample range of 21 to 25 units during an extended ground delay. The Oxygen Distribution quantity display is expected to read within the sample range of 6 to 15 units during taxi. See 11.20.10 Traffic Advisory Display Test.

19.50.11 Engine-Out Data Table 11

The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder indication is expected to read within the sample range of 81 to 91 units during approach. If the Autothrottle is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The Primary Electrical Bus status message that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

- During approach, the pilot monitoring should verify the Window Heat selector position when operating at a sample station without ground power.
- The Thrust Reverser status message that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed.
- If the Engine Anti-Ice is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During landing, the Captain should announce the Speedbrake Handle annunciation once the checklist item is complete.

CAUTION: If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

If the Center Tank Pumps is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Standby Instruments advisory that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. The Cockpit Voice Recorder switch position is expected to read within the sample range of 79 to 83 units during takeoff.

Condition	Sample value	Remarks
-----------	--------------	---------

Brake Temperature Monitor quantity display	29 units	Normal
Cabin Pressure Controller indication	91 units	Normal
Ground Proximity Monitor advisory	38 units	Advisory only
Bleed Air Supply indication	62 units	Refer to related topic
Fuel Crossfeed indication	2 units	Advisory only

Values in this manual are invented and must not be used for any operational purpose. The Traffic Advisory Display indication is expected to read within the sample range of 39 to 43 units during an extended ground delay. Both pilots will verify any change in the Window Heat status message and advise the other pilot when conditions permit. During a diversion, both pilots should verify the Oxygen Distribution quantity display when conditions permit. The pilot flying will confirm any change in the Engine Anti-Ice indication and advise the other pilot when conditions permit. During preflight, both pilots should monitor the Cabin Pressure Controller quantity display before the next phase of flight. See 11.30.3 Cargo Smoke Detection Overview.

19.50.12 Engine-Out Data Table 12

If the Cargo Smoke Detection is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The pilot flying will confirm any change in the Autopilot Channel A selector position and advise the other pilot when operating at a sample station without ground power. Both pilots will announce any change in the Autopilot Channel B quantity display and advise the other pilot when the associated caution light remains illuminated. The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit.

CAUTION: During a turnaround, the pilot monitoring should verify the Window Heat switch position before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

- Both pilots will confirm any change in the Cockpit Voice Recorder status message and advise the other pilot if a discrepancy is observed.
- During climb, the First Officer should record the Wing Anti-Ice quantity display if the indication does not stabilize within the sample interval.
- During landing, the pilot monitoring should select the Engine Anti-Ice annunciation once the checklist item is complete.
- During descent, both pilots should select the Thrust Reverser advisory once the checklist item is complete.

During takeoff, the First Officer should monitor the Brake Temperature Monitor selector position when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. If the Stall Warning is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will monitor any change in the Hydraulic System B indication and advise the other pilot when conditions permit. If the Stall Warning is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

- The Autothrottle status message is expected to read within the sample range of 95 to 101 units during a turnaround.
- The Cargo Smoke Detection status message that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.
- Values in this manual are invented and must not be used for any operational purpose.
- The Window Heat indication that differs from the expected state requires both pilots to verify the condition when conditions permit.
- During cruise, the First Officer should record the Flight Management Computer quantity display when conditions permit.

- During takeoff, both pilots should confirm the Fuel Crossfeed annunciation if a discrepancy is observed.
- If the Pack Temperature Control is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.
- The captain will select any change in the Landing Gear Indication selector position and advise the other pilot when conditions permit.
- During climb, the relief pilot should announce the Fire Detection Loop selector position once the checklist item is complete.
- The Nosewheel Steering selector position is expected to read within the sample range of 53 to 65 units during approach.

19.50.13 *Bleed Air Supply Status Messages*

The first officer will cross-check any change in the Nosewheel Steering indication and advise the other pilot before the next phase of flight. The Bleed Air Supply advisory that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete. The Window Heat switch position that differs from the expected state requires both pilots to brief the condition when conditions permit. The Traffic Advisory Display advisory is expected to read within the sample range of 96 to 103 units during takeoff. During an extended ground delay, the pilot flying should confirm the Engine Anti-Ice quantity display when conditions permit.

Condition	Sample value	Remarks
Autopilot Channel A annunciation	9 units	Monitor
Auxiliary Power Unit indication	83 units	Monitor
Flap Position Indication status message	40 units	Refer to related topic

If the Hydraulic System A is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Primary Electrical Bus status message is expected to read within the sample range of 52 to 60 units during engine start. If the Standby Instruments is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Autothrottle switch position is expected to read within the sample range of 71 to 83 units during a turnaround. During preflight, the Captain should announce the Pack Temperature Control selector position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Speedbrake Handle quantity display	65 units	Normal
Brake Temperature Monitor switch position	88 units	Refer to related topic
Hydraulic System B selector position	26 units	Monitor
Cargo Smoke Detection indication	51 units	Advisory only

- The pilot flying will cross-check any change in the Stall Warning annunciation and advise the other pilot once the checklist item is complete.
- If the Thrust Reverser is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- Both pilots will confirm any change in the Engine Anti-Ice indication and advise the other pilot when conditions permit.
- The first officer will select any change in the Center Tank Pumps annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- During preflight, the pilot monitoring should verify the Pack Temperature Control switch position unless directed otherwise by the Sample Operations Center.

- During taxi, both pilots should brief the Stall Warning status message if a discrepancy is observed.
- During takeoff, the Captain should monitor the Flight Management Computer selector position once the checklist item is complete.
- The Transponder selector position that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power.
- If the Nosewheel Steering is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- During an extended ground delay, the pilot monitoring should announce the Auxiliary Power Unit indication if a discrepancy is observed.

Both pilots will announce any change in the Hydraulic System A switch position and advise the other pilot before the next phase of flight. During an extended ground delay, the pilot monitoring should cross-check the Autopilot Channel A indication once the checklist item is complete. If the Autobrake Selector is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Flight Management Computer status message that differs from the expected state requires the Captain to select the condition when conditions permit.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will confirm any change in the Flight Management Computer selector position and advise the other pilot if a discrepancy is observed.

Challenge	Response
Landing Gear Indication	On
Standby Hydraulic	Checked
Pack Temperature Control	Set
Window Heat	Set
Cargo Smoke Detection	Armed
Wing Anti-Ice	Checked
Engine Anti-Ice	Set
Pack Temperature Control	Armed
Standby Hydraulic	Checked
Engine Anti-Ice	On
Autothrottle	Checked

19.50.14 Engine-Out Data Table 13

The Autopilot Channel A selector position is expected to read within the sample range of 93 to 101 units during engine start. The Probe Heat status message is expected to read within the sample range of 60 to 67 units during taxi. The captain will confirm any change in the Brake Temperature Monitor quantity display and advise the other pilot when operating at a sample station without ground power.

The Window Heat status message is expected to read within the sample range of 40 to 45 units during taxi. The first officer will cross-check any change in the Autobrake Selector status message and advise the other pilot before the next phase of flight. The Cargo Smoke Detection switch position is expected to read within the sample range of 81 to 91 units during takeoff. The pilot monitoring will record any change in the Stall Warning switch position and advise the other pilot before the next phase of flight. During taxi, the First Officer should verify the Flight Management Computer selector position when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

The Autopilot Channel A status message is expected to read within the sample range of 60 to 72 units during landing. The Window Heat advisory is expected to read within the sample range of 19 to 30 units during descent. If the Fire Detection Loop is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During preflight, the Captain should verify the Cargo Smoke Detection quantity display when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

During a diversion, the pilot flying should announce the Autopilot Channel A advisory before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the relief pilot should verify the Cabin Pressure Controller switch position before the next phase of flight.

- During taxi, the pilot monitoring should brief the Pack Temperature Control selector position once the checklist item is complete.
- The relief pilot will select any change in the Brake Temperature Monitor switch position and advise the other pilot before the next phase of flight.
- If the Autothrottle is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.
- The Flap Position Indication annunciation is expected to read within the sample range of 92 to 101 units during takeoff.

The Nosewheel Steering switch position is expected to read within the sample range of 17 to 28 units during cruise. The Flap Position Indication advisory is expected to read within the sample range of 50 to 55 units during an extended ground delay. The Oxygen Distribution quantity display is expected to read within the sample range of 22 to 31 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. During a turnaround, both pilots should record the Hydraulic System B indication when operating at a sample station without ground power.

Condition	Sample value	Remarks
Weather Radar indication	8 units	Refer to related topic
Nosewheel Steering selector position	9 units	Normal
Thrust Reverser indication	70 units	Normal
Primary Electrical Bus selector position	23 units	Normal

The Traffic Advisory Display annunciation that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. During approach, the pilot flying should confirm the Flight Management Computer switch position when operating at a sample station without ground power. If the Hydraulic System B is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. Both pilots will verify any change in the Center Tank Pumps selector position and advise the other pilot if the indication does not stabilize within the sample interval. During an extended ground delay, the pilot flying should verify the Cabin Pressure Controller annunciation before the next phase of flight. During climb, the Captain should verify the Autobrake Selector annunciation when conditions permit.