

Sample Flight Manual - SAMPLE-200

Revision 4 Revision date 2026-06-01 Effective 2026-06-15

Applicability: SAMPLE-200 Owner: Sample Flight Standards

Routine revision.

This document is entirely fictional. It was written to give a prototype realistic structure and volume. It is not derived from any operator manual and must not be used for any operational purpose.

Chapter 01 Introduction

01.10 Manual Organization

01.10.1 Organization Topic 1

If the Weather Radar is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. During takeoff, the pilot monitoring should announce the Thrust Reverser status message when operating at a sample station without ground power. The Wing Anti-Ice quantity display that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power.

The Nosewheel Steering indication is expected to read within the sample range of 33 to 42 units during preflight. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will announce any change in the Brake Temperature Monitor indication and advise the other pilot once the checklist item is complete. The Standby Instruments selector position is expected to read within the sample range of 47 to 58 units during an extended ground delay. During climb, both pilots should brief the Auxiliary Power Unit advisory if a discrepancy is observed. If the Fuel Crossfeed is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Engine Anti-Ice quantity display	74 units	Advisory only
Stall Warning switch position	23 units	Refer to related topic
Autopilot Channel B status message	33 units	Refer to related topic
Oxygen Distribution selector position	74 units	Advisory only
Autothrottle quantity display	94 units	Monitor
Autopilot Channel B annunciation	79 units	Normal
Center Tank Pumps status message	40 units	Monitor

The Landing Gear Indication switch position is expected to read within the sample range of 92 to 97 units during a turnaround. The Standby Hydraulic status message that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. During parking, both pilots should monitor the Center Tank Pumps advisory when the associated caution light remains illuminated.

During descent, the Captain should brief the Autopilot Channel B advisory unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice indication is expected to read within the sample range of 64 to 72 units during cruise. The relief pilot will announce any change in the Fuel Crossfeed status message and advise the other pilot when operating at a sample station without ground power. The Probe Heat status message that differs from the expected state requires the Captain to verify the condition once the checklist item is complete. The relief pilot will monitor any change in the Auxiliary Power Unit status message and advise the other pilot once the checklist item is complete.

CAUTION: If the Transponder is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The Center Tank Pumps annunciation that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center. If the Speedbrake Handle is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

CAUTION: During takeoff, the First Officer should brief the Autothrottle switch position if the indication does not stabilize within the sample interval. During a turnaround, the Captain should cross-check the Hydraulic System A quantity display when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Hydraulic System A indication	36 units	Advisory only
Hydraulic System A switch position	97 units	Advisory only
Cargo Smoke Detection status message	43 units	Normal
Autopilot Channel A quantity display	30 units	Advisory only

01.10.2 Organization Topic 2

The Nosewheel Steering status message is expected to read within the sample range of 64 to 72 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure. The Wing Anti-Ice selector position that differs from the expected state requires the Captain to verify the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector selector position that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed.

CAUTION: During a maintenance-requested ground run, both pilots should cross-check the Autothrottle annunciation if the indication does not stabilize within the sample interval.

CAUTION: The Weather Radar annunciation that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power. The Weather Radar quantity display that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center.

The Primary Electrical Bus annunciation is expected to read within the sample range of 63 to 75 units during approach. The Fire Detection Loop status message that differs from the expected state requires the First Officer to confirm the condition when conditions permit. Both pilots will record any change in the Cockpit Voice Recorder switch position and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. The Thrust Reverser annunciation is expected to read within the sample range of 54 to 58 units during landing. The pilot monitoring will record any change in the Traffic Advisory Display switch position and advise the other pilot when the associated caution light remains illuminated.

- The Autothrottle advisory is expected to read within the sample range of 39 to 47 units during climb.
- Values in this manual are invented and must not be used for any operational purpose.
- The pilot flying will brief any change in the Auxiliary Power Unit quantity display and advise the other pilot once the checklist item is complete.
- The pilot flying will confirm any change in the Wing Anti-Ice advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During taxi, the pilot monitoring should brief the Flight Management Computer quantity display when operating at a sample station without ground power.
- The pilot flying will confirm any change in the Cockpit Voice Recorder indication and advise the other pilot when conditions permit.
- If the Brake Temperature Monitor is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.
- During a turnaround, both pilots should verify the Pack Temperature Control indication unless directed otherwise by the Sample Operations Center.

NOTE: The Fuel Crossfeed annunciation that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

01.20 Revision Service

01.20.1 Revision Service Topic 1

The Flap Position Indication indication that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. The Autothrottle annunciation that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. The Thrust Reverser quantity display that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power.

- The Fire Detection Loop quantity display that differs from the expected state requires both pilots to select the condition before the next phase of flight.
- The Hydraulic System A quantity display that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center.
- The relief pilot will cross-check any change in the Thrust Reverser quantity display and advise the other pilot when operating at a sample station without ground power.
- Refer to the related topic for additional sample context.
- The Auxiliary Power Unit advisory is expected to read within the sample range of 89 to 101 units during parking.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Wing Anti-Ice is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Nosewheel Steering annunciation that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed. The first officer will select any change in the Weather Radar annunciation and advise the other pilot once the checklist item is complete. The Engine Anti-Ice quantity display is expected to read within the sample range of 88 to 92 units during landing.

- The Standby Hydraulic switch position is expected to read within the sample range of 97 to 107 units during landing.
- Both pilots will brief any change in the Auxiliary Power Unit annunciation and advise the other pilot when conditions permit.
- During preflight, the Captain should announce the Pack Temperature Control annunciation if the indication does not stabilize within the sample interval.
- The Fuel Crossfeed quantity display that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated.
- During approach, the pilot flying should monitor the Autopilot Channel A advisory before the next phase of flight.

NOTE: The first officer will announce any change in the Hydraulic System A selector position and advise the other pilot once the checklist item is complete. The Fire Detection Loop quantity display that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight.

If the Engine Anti-Ice is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, both pilots should verify the Hydraulic System B quantity display when conditions permit. During preflight, the pilot monitoring should verify the Thrust Reverser advisory before the next phase of flight. See 10.20.3 Auxiliary Power Unit Status Messages.

- The Cargo Smoke Detection quantity display that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center.
- During climb, the First Officer should record the Autothrottle status message once the checklist item is complete.

- During approach, the Captain should brief the Window Heat indication when operating at a sample station without ground power.
- The Fire Detection Loop selector position that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power.

01.20.2 Revision Service Topic 2

The Fire Detection Loop quantity display is expected to read within the sample range of 59 to 63 units during descent. If the Cabin Pressure Controller is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Fire Detection Loop quantity display that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Fuel Crossfeed switch position is expected to read within the sample range of 16 to 26 units during takeoff.

The Hydraulic System A status message that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. Both pilots will verify any change in the Cargo Smoke Detection switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. During takeoff, both pilots should verify the Cargo Smoke Detection selector position once the checklist item is complete. The Wing Anti-Ice status message is expected to read within the sample range of 77 to 83 units during approach. The Primary Electrical Bus indication is expected to read within the sample range of 48 to 56 units during climb. Refer to the related topic for additional sample context.

Refer to the related topic for additional sample context. During a maintenance-requested ground run, the First Officer should brief the Wing Anti-Ice switch position unless directed otherwise by the Sample Operations Center. The first officer will cross-check any change in the Autopilot Channel B quantity display and advise the other pilot before the next phase of flight. During preflight, the pilot flying should confirm the Speedbrake Handle switch position if a discrepancy is observed. If the Probe Heat is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

NOTE: The pilot flying will verify any change in the Primary Electrical Bus selector position and advise the other pilot before the next phase of flight. The Autopilot Channel A annunciation that differs from the expected state requires the First Officer to confirm the condition when conditions permit.

If the Autopilot Channel B is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. During landing, the relief pilot should select the Traffic Advisory Display selector position once the checklist item is complete. Both pilots will record any change in the Standby Instruments indication and advise the other pilot when conditions permit. During taxi, the pilot monitoring should monitor the Fire Detection Loop indication unless directed otherwise by the Sample Operations Center. The Pack Temperature Control annunciation is expected to read within the sample range of 53 to 58 units during preflight. The Primary Electrical Bus indication is expected to read within the sample range of 70 to 78 units during an extended ground delay.

CAUTION: The relief pilot will brief any change in the Thrust Reverser selector position and advise the other pilot before the next phase of flight.

01.30 Abbreviations

01.30.1 Abbreviation Group 1

Both pilots will select any change in the Fuel Crossfeed annunciation and advise the other pilot once the checklist item is complete. The pilot flying will brief any change in the Weather Radar switch position and advise the other pilot when conditions permit. The Center Tank Pumps quantity display is expected to read within the sample range of 65 to 76 units during a maintenance-requested ground run. The relief pilot will brief any change in the Stall Warning annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
-----------	--------------	---------

Standby Instruments quantity display	58 units	Normal
Traffic Advisory Display selector position	24 units	Advisory only
Cockpit Voice Recorder advisory	76 units	Monitor

NOTE: If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Ground Proximity Monitor status message	9 units	Advisory only
Fuel Crossfeed annunciation	94 units	Normal
Hydraulic System B selector position	96 units	Refer to related topic
Autopilot Channel A quantity display	21 units	Monitor
Pack Temperature Control status message	25 units	Advisory only
Landing Gear Indication indication	25 units	Normal
Pack Temperature Control status message	24 units	Advisory only

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will record any change in the Landing Gear Indication status message and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The Speedbrake Handle indication that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center.

If the Cargo Smoke Detection is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The Brake Temperature Monitor annunciation is expected to read within the sample range of 36 to 43 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure.

The Thrust Reverser switch position is expected to read within the sample range of 53 to 63 units during approach. During cruise, the pilot monitoring should brief the Autobrake Selector status message once the checklist item is complete. The first officer will brief any change in the Oxygen Distribution indication and advise the other pilot when the associated caution light remains illuminated. During parking, both pilots should brief the Stall Warning quantity display when operating at a sample station without ground power. During a turnaround, both pilots should record the Wing Anti-Ice indication when the associated caution light remains illuminated.

01.30.2 Abbreviation Group 2

The Ground Proximity Monitor switch position that differs from the expected state requires the pilot flying to announce the condition when conditions permit. During an extended ground delay, the Captain should confirm the Autopilot Channel A status message when conditions permit. The relief pilot will verify any change in the Flight Management Computer selector position and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. Both pilots will confirm any change in the Weather Radar advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: If the Engine Anti-Ice is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

CAUTION: During landing, the relief pilot should cross-check the Transponder switch position when the associated caution light remains illuminated. The Standby Hydraulic indication is expected to read within the sample range of 58 to 70 units during a turnaround.

CAUTION: The pilot monitoring will select any change in the Thrust Reverser annunciation and advise the other pilot before the next phase of flight.

CAUTION: The Nosewheel Steering advisory is expected to read within the sample range of 57 to 60 units during landing. If the Center Tank Pumps is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

- The Nosewheel Steering switch position that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.
- During descent, the Captain should verify the Wing Anti-Ice selector position when operating at a sample station without ground power.
- During descent, the pilot flying should brief the Window Heat annunciation when operating at a sample station without ground power.
- The Cabin Pressure Controller selector position is expected to read within the sample range of 81 to 90 units during takeoff.
- The Autothrottle quantity display is expected to read within the sample range of 68 to 78 units during parking.

Condition	Sample value	Remarks
Flight Management Computer indication	80 units	Refer to related topic
Cargo Smoke Detection quantity display	99 units	Monitor
Cabin Pressure Controller annunciation	41 units	Advisory only
Brake Temperature Monitor switch position	32 units	Advisory only
Autothrottle switch position	77 units	Normal
Primary Electrical Bus indication	1 units	Normal
Brake Temperature Monitor status message	76 units	Advisory only

If the Transponder is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Nosewheel Steering annunciation is expected to read within the sample range of 43 to 54 units during parking. The relief pilot will verify any change in the Wing Anti-Ice status message and advise the other pilot when the associated caution light remains illuminated.

Chapter 02 Limitations

02.10 General Limitations

02.10.1 General Limitation 1

The relief pilot will cross-check any change in the Bleed Air Supply indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Center Tank Pumps quantity display that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. The Standby Instruments quantity display is expected to read within the sample range of 48 to 56 units during approach. The Probe Heat quantity display that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated.

The first officer will brief any change in the Cabin Pressure Controller selector position and advise the other pilot when conditions permit. During an extended ground delay, the Captain should verify the Probe Heat quantity display when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: Refer to the related topic for additional sample context. During a diversion, the relief pilot should select the Landing Gear Indication quantity display once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic selector position that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. The Oxygen Distribution advisory that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed.

The Standby Instruments switch position is expected to read within the sample range of 76 to 85 units during takeoff. During landing, both pilots should announce the Autopilot Channel A indication before the next phase of flight. The Standby Instruments advisory is expected to read within the sample range of 54 to 62 units during takeoff.

The Wing Anti-Ice switch position is expected to read within the sample range of 59 to 70 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. The Bleed Air Supply annunciation is expected to read within the sample range of 3 to 13 units during a maintenance-requested ground run. During a maintenance-requested ground run, the First Officer should verify the Engine Anti-Ice selector position once the checklist item is complete. Refer to the related topic for additional sample context.

- Refer to the related topic for additional sample context.
- During climb, the relief pilot should brief the Wing Anti-Ice selector position if a discrepancy is observed.
- During descent, the Captain should record the Fire Detection Loop annunciation unless directed otherwise by the Sample Operations Center.
- During a turnaround, both pilots should confirm the Autothrottle advisory before the next phase of flight.
- During descent, the Captain should record the Brake Temperature Monitor switch position if a discrepancy is observed.
- During a turnaround, the pilot flying should brief the Wing Anti-Ice quantity display when operating at a sample station without ground power.

If the Weather Radar is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Wing Anti-Ice status message that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. The Engine Anti-Ice quantity display is expected to read within the sample range of 71 to 78 units during a maintenance-requested ground run. During taxi, the Captain should cross-check the Speedbrake Handle annunciation unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Window Heat status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

02.10.2 General Limitation 2

If the Stall Warning is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. During parking, the pilot flying should cross-check the Center Tank Pumps advisory when operating at a sample station without ground power. The Hydraulic System B indication that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed. If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

NOTE: The Landing Gear Indication advisory is expected to read within the sample range of 47 to 56 units during a diversion. Refer to the related topic for additional sample context.

NOTE: The Fuel Crossfeed switch position that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. The Wing Anti-Ice indication is expected to read within the sample range of 45 to 49 units during taxi.

NOTE: The Standby Hydraulic selector position is expected to read within the sample range of 40 to 50 units during climb. The relief pilot will brief any change in the Nosewheel Steering selector position and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autopilot Channel A annunciation	55 units	Monitor
Wing Anti-Ice quantity display	56 units	Refer to related topic
Standby Hydraulic advisory	41 units	Normal

If the Autopilot Channel B is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The Standby Hydraulic quantity display is expected to read within the sample range of 32 to 40 units during taxi. The Cargo Smoke Detection advisory is expected to read within the sample range of 12 to 24 units during taxi. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Bleed Air Supply indication	63 units	Refer to related topic
Cargo Smoke Detection advisory	55 units	Normal
Flight Management Computer advisory	62 units	Monitor
Oxygen Distribution status message	46 units	Advisory only

02.10.3 General Limitation 3

The Cockpit Voice Recorder annunciation is expected to read within the sample range of 39 to 44 units during taxi. Both pilots will cross-check any change in the Center Tank Pumps advisory and advise the other pilot when conditions permit. If the Autobrake Selector is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Nosewheel Steering switch position	34 units	Refer to related topic
Primary Electrical Bus selector position	70 units	Monitor
Primary Electrical Bus status message	97 units	Normal
Ground Proximity Monitor status message	24 units	Normal
Nosewheel Steering indication	40 units	Advisory only
Transponder status message	7 units	Refer to related topic

During preflight, the relief pilot should select the Bleed Air Supply indication before the next phase of flight. Refer to the related topic for additional sample context. If the Probe Heat is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Wing Anti-Ice quantity display is expected to read within the sample range of 18 to 23 units during an extended ground delay.

NOTE: During cruise, the First Officer should confirm the Autopilot Channel B annunciation before the next phase of flight. If the Standby Hydraulic is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

The Flight Management Computer switch position that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed. The Cabin Pressure Controller quantity display that differs from the expected state requires both pilots to monitor the condition when conditions permit. The Speedbrake Handle selector position is expected to read within the sample range of 56 to 65 units during preflight. Refer to the related topic for additional sample context.

If the Traffic Advisory Display is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. During preflight, the relief pilot should verify the Autobrake Selector selector position once the checklist item is complete. The Weather Radar switch position that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.

The Stall Warning advisory is expected to read within the sample range of 74 to 85 units during descent. The Nosewheel Steering annunciation that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center. If the Engine Anti-Ice is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Flap Position Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

The first officer will brief any change in the Engine Anti-Ice status message and advise the other pilot if a discrepancy is observed. The Standby Instruments status message that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. During parking, the pilot monitoring should verify the Flight Management Computer advisory once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will announce any change in the Engine Anti-Ice indication and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	67 units	Refer to related topic
Ground Proximity Monitor advisory	65 units	Normal
Standby Instruments annunciation	23 units	Monitor

02.20 Weight Limitations

02.20.1 Weight Limitation 1

The pilot monitoring will verify any change in the Engine Anti-Ice indication and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Auxiliary Power Unit advisory is expected to read within the sample range of 82 to 90 units during taxi. If the Ground Proximity Monitor is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

During cruise, the pilot monitoring should brief the Fuel Crossfeed indication when the associated caution light remains illuminated. The captain will verify any change in the Hydraulic System B advisory and advise the other pilot once the checklist item is complete. If the Autopilot Channel B is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

If the Hydraulic System A is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During takeoff, the relief pilot should announce the Flap Position Indication annunciation before the next phase of flight. During taxi, the Captain should verify the Ground Proximity Monitor status message unless directed otherwise by the Sample Operations Center.

If the Standby Hydraulic is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Window Heat switch position that differs from the expected state requires the Captain to monitor the condition when conditions permit. During a diversion, the pilot monitoring should cross-check the Speedbrake Handle advisory before the next phase of flight. The Flight Management Computer status message is expected to read within the sample range of 84 to 88 units during preflight.

- If the Autopilot Channel A is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- The pilot flying will select any change in the Standby Instruments indication and advise the other pilot when the associated caution light remains illuminated.
- During an extended ground delay, the First Officer should verify the Auxiliary Power Unit selector position before the next phase of flight.
- If the Primary Electrical Bus is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.
- The Flap Position Indication indication that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit.
- Refer to the related topic for additional sample context.

The Cockpit Voice Recorder indication is expected to read within the sample range of 81 to 91 units during a turnaround. If the Standby Hydraulic is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During a maintenance-requested ground run, both pilots should select the Pack Temperature Control switch position if a discrepancy is observed. The Autopilot Channel A indication that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. See 19.30.2 Landing Performance Table 2.

NOTE: During landing, both pilots should brief the Autopilot Channel A quantity display when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: If the Autobrake Selector is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

02.20.2 Weight Limitation 2

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The Cockpit Voice Recorder indication that differs from the expected state requires the pilot flying to confirm the condition when conditions permit. Refer to the related topic for additional sample context. The Center Tank Pumps selector position that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	11 units	Refer to related topic
Stall Warning selector position	71 units	Refer to related topic
Hydraulic System B quantity display	65 units	Refer to related topic
Cargo Smoke Detection annunciation	31 units	Monitor
Thrust Reverser indication	70 units	Advisory only

Standby Instruments advisory	55 units	Monitor
------------------------------	----------	---------

- The wording here is placeholder content shaped like a procedure, not a procedure.
- Values in this manual are invented and must not be used for any operational purpose.
- The Center Tank Pumps advisory is expected to read within the sample range of 61 to 69 units during taxi.
- If the Stall Warning is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- The first officer will select any change in the Probe Heat annunciation and advise the other pilot when operating at a sample station without ground power.
- The Autopilot Channel A annunciation is expected to read within the sample range of 84 to 91 units during a turnaround.
- Both pilots will announce any change in the Nosewheel Steering indication and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Nosewheel Steering status message	23 units	Normal
Ground Proximity Monitor indication	10 units	Normal
Transponder selector position	99 units	Normal

NOTE: The captain will brief any change in the Thrust Reverser indication and advise the other pilot when operating at a sample station without ground power. If the Auxiliary Power Unit is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

02.30 Airspeed Limitations

02.30.1 Airspeed Limitation 1

If the Cargo Smoke Detection is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The relief pilot will announce any change in the Cabin Pressure Controller advisory and advise the other pilot if the indication does not stabilize within the sample interval. If the Transponder is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The first officer will announce any change in the Flap Position Indication switch position and advise the other pilot when the associated caution light remains illuminated. If the Primary Electrical Bus is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The first officer will brief any change in the Probe Heat advisory and advise the other pilot when operating at a sample station without ground power.

If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Center Tank Pumps status message is expected to read within the sample range of 60 to 72 units during approach. The Autopilot Channel B switch position is expected to read within the sample range of 61 to 64 units during climb. During parking, the Captain should record the Auxiliary Power Unit indication before the next phase of flight.

Condition	Sample value	Remarks
Fuel Crossfeed switch position	96 units	Advisory only
Stall Warning quantity display	28 units	Monitor
Standby Instruments selector position	12 units	Refer to related topic
Traffic Advisory Display indication	53 units	Advisory only
Landing Gear Indication selector position	94 units	Advisory only

The Brake Temperature Monitor selector position that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power. During taxi, both pilots should select the Oxygen Distribution indication if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. During preflight, the pilot monitoring should monitor the Cabin Pressure Controller advisory if the indication does not stabilize within the sample interval.

During preflight, the relief pilot should monitor the Window Heat annunciation if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. Both pilots will verify any change in the Autobrake Selector quantity display and advise the other pilot before the next phase of flight. If the Pack Temperature Control is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Transponder quantity display	23 units	Advisory only
Hydraulic System B advisory	96 units	Advisory only
Weather Radar quantity display	19 units	Refer to related topic
Weather Radar indication	75 units	Monitor
Autopilot Channel A annunciation	91 units	Normal
Wing Anti-Ice selector position	63 units	Monitor

02.30.2 *Airspeed Limitation 2*

The Thrust Reverser advisory that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed. The Auxiliary Power Unit status message that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

- CAUTION:** The first officer will monitor any change in the Flight Management Computer annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- CAUTION:** If the Stall Warning is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Thrust Reverser switch position is expected to read within the sample range of 15 to 21 units during landing.
- CAUTION:** During cruise, both pilots should record the Cargo Smoke Detection selector position when the associated caution light remains illuminated.

If the Oxygen Distribution is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. During engine start, both pilots should announce the Speedbrake Handle indication if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Landing Gear Indication quantity display	2 units	Refer to related topic
Hydraulic System A advisory	87 units	Advisory only
Auxiliary Power Unit status message	84 units	Advisory only
Bleed Air Supply indication	18 units	Refer to related topic
Autothrottle switch position	3 units	Refer to related topic

02.30.3 *Airspeed Limitation 3*

If the Autopilot Channel B is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Cockpit Voice Recorder switch position is

expected to read within the sample range of 27 to 35 units during cruise.

The Stall Warning selector position that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed. Both pilots will verify any change in the Autopilot Channel A switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Autothrottle quantity display that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed. During approach, the First Officer should verify the Fuel Crossfeed annunciation unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Window Heat status message	65 units	Monitor
Engine Anti-Ice advisory	77 units	Refer to related topic
Window Heat indication	76 units	Refer to related topic
Oxygen Distribution advisory	44 units	Advisory only
Stall Warning annunciation	3 units	Normal
Window Heat indication	70 units	Monitor

- Both pilots will verify any change in the Thrust Reverser selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During landing, the pilot monitoring should monitor the Speedbrake Handle switch position before the next phase of flight.

During landing, the pilot monitoring should brief the Auxiliary Power Unit indication unless directed otherwise by the Sample Operations Center. During engine start, the pilot monitoring should brief the Speedbrake Handle quantity display unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Stall Warning status message is expected to read within the sample range of 92 to 95 units during parking. During cruise, the Captain should cross-check the Speedbrake Handle advisory when the associated caution light remains illuminated.

02.40 Systems Limitations

02.40.1 Stall Warning Crew Awareness

The Stall Warning status message is expected to read within the sample range of 69 to 81 units during engine start. If the Window Heat is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The captain will record any change in the Hydraulic System B quantity display and advise the other pilot before the next phase of flight. During climb, the pilot flying should brief the Hydraulic System B switch position if the indication does not stabilize within the sample interval. The Fuel Crossfeed selector position is expected to read within the sample range of 45 to 57 units during engine start.

The pilot flying will brief any change in the Hydraulic System B advisory and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Auxiliary Power Unit quantity display that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed. The Brake Temperature Monitor annunciation is expected to read within the sample range of 77 to 83 units during a diversion.

During approach, the pilot monitoring should verify the Autothrottle indication when conditions permit. During cruise, the pilot monitoring should brief the Hydraulic System B advisory if the indication does not stabilize within the sample interval. During parking, the relief pilot should verify the Cargo Smoke Detection advisory before the next phase of

flight. The Autopilot Channel A quantity display is expected to read within the sample range of 31 to 41 units during climb. The Auxiliary Power Unit switch position that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Nosewheel Steering selector position	92 units	Normal
Standby Hydraulic switch position	92 units	Normal
Ground Proximity Monitor switch position	66 units	Advisory only

Refer to the related topic for additional sample context. The Landing Gear Indication switch position is expected to read within the sample range of 86 to 95 units during preflight. During takeoff, the First Officer should announce the Autothrottle switch position when conditions permit.

CAUTION: The pilot flying will select any change in the Autothrottle quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

02.40.2 Wing Anti-Ice Limits Display

If the Speedbrake Handle is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. Both pilots will select any change in the Oxygen Distribution switch position and advise the other pilot when the associated caution light remains illuminated. During preflight, the pilot flying should confirm the Autopilot Channel A annunciation if a discrepancy is observed. During approach, the pilot flying should record the Autopilot Channel A selector position when the associated caution light remains illuminated. The Flight Management Computer status message that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power.

- The Engine Anti-Ice annunciation is expected to read within the sample range of 10 to 14 units during climb.
- The relief pilot will announce any change in the Probe Heat status message and advise the other pilot when conditions permit.
- The Brake Temperature Monitor indication is expected to read within the sample range of 74 to 78 units during preflight.
- The Fuel Crossfeed quantity display that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval.
- The Autobrake Selector quantity display that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval.
- If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

NOTE: The Cabin Pressure Controller switch position that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed.

The Ground Proximity Monitor switch position is expected to read within the sample range of 60 to 67 units during preflight. The Hydraulic System B annunciation is expected to read within the sample range of 54 to 63 units during cruise. During takeoff, the pilot flying should confirm the Autopilot Channel A selector position if a discrepancy is observed. The Cabin Pressure Controller advisory is expected to read within the sample range of 48 to 57 units during an extended ground delay. During landing, both pilots should confirm the Hydraulic System A indication once the checklist item is complete. The Weather Radar status message that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center.

During a diversion, the pilot flying should verify the Transponder advisory when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A quantity display that differs from the expected state requires the First Officer to select the condition once

the checklist item is complete.

The Nosewheel Steering quantity display that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. During cruise, the First Officer should verify the Brake Temperature Monitor status message once the checklist item is complete. The pilot monitoring will confirm any change in the Hydraulic System B annunciation and advise the other pilot if a discrepancy is observed.

NOTE: The Auxiliary Power Unit selector position that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power.

02.40.3 Fire Detection Loop Reset Guidance

The Cabin Pressure Controller selector position that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval. During landing, the Captain should confirm the Cargo Smoke Detection indication once the checklist item is complete. The Pack Temperature Control quantity display that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. The Probe Heat annunciation is expected to read within the sample range of 36 to 40 units during descent. The Nosewheel Steering quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated.

The pilot monitoring will select any change in the Window Heat quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Ground Proximity Monitor indication is expected to read within the sample range of 30 to 35 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Oxygen Distribution is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Weather Radar status message is expected to read within the sample range of 71 to 74 units during preflight.

NOTE: If the Primary Electrical Bus is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

During landing, the pilot monitoring should cross-check the Primary Electrical Bus switch position unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Nosewheel Steering advisory is expected to read within the sample range of 67 to 70 units during landing. The Center Tank Pumps indication is expected to read within the sample range of 31 to 34 units during engine start. The Transponder status message is expected to read within the sample range of 29 to 41 units during landing.

CAUTION: The Autothrottle selector position is expected to read within the sample range of 4 to 12 units during approach. The Primary Electrical Bus status message is expected to read within the sample range of 31 to 36 units during landing.

02.40.4 Landing Gear Indication Normal Operation

During a maintenance-requested ground run, the relief pilot should record the Standby Instruments switch position if the indication does not stabilize within the sample interval. The Window Heat quantity display that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. The Hydraulic System A advisory that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. The Probe Heat selector position that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cockpit Voice Recorder advisory	60 units	Monitor
Cabin Pressure Controller selector position	60 units	Advisory only
Center Tank Pumps annunciation	67 units	Normal

Autobrake Selector selector position	46 units	Monitor
Standby Instruments annunciation	10 units	Monitor
Transponder indication	87 units	Refer to related topic
Landing Gear Indication status message	74 units	Monitor

During an extended ground delay, the First Officer should announce the Cockpit Voice Recorder quantity display unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Primary Electrical Bus selector position that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. If the Autopilot Channel A is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Nosewheel Steering quantity display is expected to read within the sample range of 72 to 79 units during preflight.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Transponder is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.

NOTE: If the Stall Warning is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

If the Hydraulic System A is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Flap Position Indication selector position that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. Both pilots will cross-check any change in the Pack Temperature Control selector position and advise the other pilot when operating at a sample station without ground power. The Traffic Advisory Display selector position is expected to read within the sample range of 4 to 9 units during climb.

- Values in this manual are invented and must not be used for any operational purpose.
- The Hydraulic System A selector position that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- The Landing Gear Indication indication is expected to read within the sample range of 16 to 23 units during descent.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Autopilot Channel B advisory	37 units	Advisory only
Wing Anti-Ice advisory	45 units	Monitor
Bleed Air Supply annunciation	43 units	Normal
Traffic Advisory Display switch position	8 units	Advisory only
Standby Hydraulic advisory	28 units	Advisory only
Cockpit Voice Recorder advisory	30 units	Refer to related topic

02.40.5 Speedbrake Handle Status Messages

The Weather Radar selector position that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. The Hydraulic System B selector position is expected to read within the sample range of 82 to 94 units during descent. The wording here is placeholder content

shaped like a procedure, not a procedure. The Autopilot Channel A status message is expected to read within the sample range of 6 to 9 units during preflight.

- The Flap Position Indication selector position is expected to read within the sample range of 12 to 21 units during a diversion.
- During cruise, the Captain should select the Auxiliary Power Unit indication when conditions permit.
- Refer to the related topic for additional sample context.

During descent, both pilots should monitor the Center Tank Pumps quantity display once the checklist item is complete. The Cargo Smoke Detection quantity display is expected to read within the sample range of 56 to 67 units during taxi. Refer to the related topic for additional sample context.

During landing, the First Officer should cross-check the Nosewheel Steering status message before the next phase of flight. The relief pilot will select any change in the Traffic Advisory Display selector position and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Wing Anti-Ice selector position is expected to read within the sample range of 41 to 49 units during an extended ground delay. The captain will confirm any change in the Cockpit Voice Recorder advisory and advise the other pilot before the next phase of flight. The Brake Temperature Monitor status message is expected to read within the sample range of 13 to 23 units during a diversion.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The captain will cross-check any change in the Standby Hydraulic switch position and advise the other pilot when conditions permit.
- The relief pilot will record any change in the Pack Temperature Control switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The first officer will brief any change in the Autopilot Channel B advisory and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, both pilots should announce the Auxiliary Power Unit advisory when conditions permit.

During approach, both pilots should monitor the Nosewheel Steering status message when the associated caution light remains illuminated. If the Landing Gear Indication is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Autothrottle annunciation is expected to read within the sample range of 75 to 78 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. If the Weather Radar is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Hydraulic System B status message is expected to read within the sample range of 37 to 47 units during a turnaround.

Condition	Sample value	Remarks
Standby Hydraulic switch position	55 units	Monitor
Auxiliary Power Unit indication	96 units	Monitor
Window Heat indication	62 units	Refer to related topic
Autopilot Channel A indication	65 units	Normal

02.40.6 Cockpit Voice Recorder Interfaces

If the Cockpit Voice Recorder is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Hydraulic System A selector

position and advise the other pilot once the checklist item is complete. If the Standby Instruments is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Flight Management Computer selector position is expected to read within the sample range of 40 to 45 units during a turnaround.

NOTE: Refer to the related topic for additional sample context. The Stall Warning advisory is expected to read within the sample range of 44 to 54 units during preflight.

NOTE: The Bleed Air Supply selector position that differs from the expected state requires the Captain to record the condition if a discrepancy is observed. The Wing Anti-Ice quantity display is expected to read within the sample range of 63 to 69 units during landing.

CAUTION: The captain will announce any change in the Brake Temperature Monitor quantity display and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Cargo Smoke Detection switch position	67 units	Monitor
Speedbrake Handle status message	9 units	Advisory only
Standby Instruments switch position	6 units	Advisory only
Brake Temperature Monitor advisory	84 units	Refer to related topic
Engine Anti-Ice indication	31 units	Monitor

- The Autopilot Channel A status message is expected to read within the sample range of 88 to 95 units during takeoff.
- If the Traffic Advisory Display is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.
- The relief pilot will select any change in the Brake Temperature Monitor selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During descent, the pilot monitoring should brief the Engine Anti-Ice selector position if a discrepancy is observed.
- The first officer will brief any change in the Speedbrake Handle indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic annunciation is expected to read within the sample range of 71 to 83 units during landing. The Flap Position Indication advisory is expected to read within the sample range of 40 to 49 units during parking. The Standby Hydraulic switch position is expected to read within the sample range of 51 to 55 units during approach.

02.40.7 Cockpit Voice Recorder Status Messages

Refer to the related topic for additional sample context. The Landing Gear Indication selector position is expected to read within the sample range of 8 to 12 units during a turnaround. If the Hydraulic System B is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The first officer will monitor any change in the Hydraulic System A switch position and advise the other pilot once the checklist item is complete. The Primary Electrical Bus status message is expected to read within the sample range of 68 to 74 units during climb.

The Probe Heat quantity display is expected to read within the sample range of 30 to 38 units during parking. The Transponder annunciation that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. The Transponder quantity display is expected to read within the sample range of 56 to 59 units during preflight.

The first officer will record any change in the Autopilot Channel A annunciation and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume

and structure. The wording here is placeholder content shaped like a procedure, not a procedure.

During parking, the Captain should verify the Stall Warning annunciation once the checklist item is complete. The Probe Heat annunciation is expected to read within the sample range of 82 to 93 units during cruise. Both pilots will announce any change in the Ground Proximity Monitor quantity display and advise the other pilot when conditions permit.

The Auxiliary Power Unit switch position is expected to read within the sample range of 74 to 80 units during an extended ground delay. If the Nosewheel Steering is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

CAUTION: During a diversion, the Captain should confirm the Transponder indication unless directed otherwise by the Sample Operations Center. The relief pilot will select any change in the Brake Temperature Monitor annunciation and advise the other pilot if a discrepancy is observed.

The pilot monitoring will brief any change in the Landing Gear Indication quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will record any change in the Standby Hydraulic switch position and advise the other pilot before the next phase of flight. The Window Heat status message that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. The Nosewheel Steering switch position is expected to read within the sample range of 97 to 100 units during descent. This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor annunciation is expected to read within the sample range of 31 to 42 units during a diversion. See 12.30.3 Autopilot Channel B Indications.

02.40.8 Hydraulic System A Power Sources

The Fire Detection Loop quantity display is expected to read within the sample range of 94 to 102 units during parking. This text is fictional and exists only to give the prototype realistic volume and structure. If the Cabin Pressure Controller is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During climb, the Captain should select the Auxiliary Power Unit indication when the associated caution light remains illuminated. During parking, the Captain should announce the Cargo Smoke Detection status message if a discrepancy is observed. If the Standby Hydraulic is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. During climb, both pilots should announce the Primary Electrical Bus indication unless directed otherwise by the Sample Operations Center. During climb, the pilot flying should record the Autopilot Channel A switch position before the next phase of flight.

CAUTION: Both pilots will verify any change in the Brake Temperature Monitor quantity display and advise the other pilot once the checklist item is complete.

The Pack Temperature Control selector position is expected to read within the sample range of 35 to 39 units during landing. If the Traffic Advisory Display is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. During takeoff, the relief pilot should verify the Flight Management Computer switch position unless directed otherwise by the Sample Operations Center.

The Fuel Crossfeed indication that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. If the Autopilot Channel B is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Standby Instruments indication that differs from the expected state requires the First Officer to brief the condition when conditions permit. The Probe Heat indication that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. The Hydraulic System A switch position is expected to read within the sample range of 24 to 35 units during preflight. The first officer will brief any change in the Standby Instruments advisory and advise the other pilot once the checklist item is complete.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

The Engine Anti-Ice selector position that differs from the expected state requires both pilots to record the condition when conditions permit. The Autobrake Selector quantity display is expected to read within the sample range of 95 to 105 units during engine start. During descent, the pilot flying should cross-check the Bleed Air Supply annunciation when operating at a sample station without ground power. During descent, the Captain should monitor the Engine Anti-Ice indication once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. Both pilots will record any change in the Pack Temperature Control advisory and advise the other pilot when conditions permit.

Chapter 03 Normal Procedures

03.10 Preflight

03.10.1 Crew Coordination: Autopilot Channel A

During takeoff, the Captain should announce the Window Heat selector position when operating at a sample station without ground power. During a maintenance-requested ground run, the pilot flying should confirm the Cabin Pressure Controller indication when operating at a sample station without ground power. The Probe Heat quantity display is expected to read within the sample range of 91 to 103 units during landing. During an extended ground delay, the relief pilot should announce the Flap Position Indication selector position if a discrepancy is observed. The Cabin Pressure Controller selector position that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Flap Position Indication annunciation	37 units	Monitor
Stall Warning indication	32 units	Monitor
Engine Anti-Ice quantity display	90 units	Monitor

During parking, the Captain should verify the Engine Anti-Ice indication once the checklist item is complete. The Engine Anti-Ice status message is expected to read within the sample range of 63 to 68 units during preflight. The Window Heat status message is expected to read within the sample range of 93 to 105 units during preflight.

- The Wing Anti-Ice switch position that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.
- If the Autopilot Channel B is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- The pilot monitoring will select any change in the Hydraulic System A annunciation and advise the other pilot once the checklist item is complete.
- Both pilots will monitor any change in the Bleed Air Supply status message and advise the other pilot when operating at a sample station without ground power.
- The Oxygen Distribution annunciation that differs from the expected state requires the pilot monitoring to record the condition when conditions permit.

CAUTION: If the Stall Warning is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

03.10.2 Checklist: Window Heat

During taxi, the Captain should cross-check the Oxygen Distribution switch position when operating at a sample station without ground power. If the Autopilot Channel B is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The first officer will monitor any change in the Wing Anti-Ice selector position and advise the other pilot when operating at a sample station without ground power. During climb, the Captain should announce the Autothrottle indication unless directed otherwise by the Sample Operations Center. The first officer will monitor any change in the Pack Temperature Control indication and advise the other pilot if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Autobrake Selector is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. During cruise, the First Officer should verify the Nosewheel Steering status message before the next phase of flight. The Probe Heat status message that differs from the expected state requires the Captain to brief the condition when conditions permit.

The relief pilot will select any change in the Nosewheel Steering status message and advise the other pilot when the associated caution light remains illuminated.

NOTE: If the Window Heat is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

The first officer will record any change in the Stall Warning indication and advise the other pilot before the next phase of flight. The Traffic Advisory Display switch position is expected to read within the sample range of 65 to 69 units during cruise. The Transponder switch position is expected to read within the sample range of 65 to 71 units during takeoff.

The Autopilot Channel A indication that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval. During preflight, both pilots should cross-check the Autobrake Selector selector position once the checklist item is complete. Both pilots will cross-check any change in the Oxygen Distribution advisory and advise the other pilot once the checklist item is complete.

The Standby Hydraulic annunciation that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated. During takeoff, both pilots should cross-check the Bleed Air Supply selector position if the indication does not stabilize within the sample interval. Both pilots will cross-check any change in the Speedbrake Handle annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Landing Gear Indication is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

- The Wing Anti-Ice quantity display is expected to read within the sample range of 14 to 26 units during parking.
- If the Center Tank Pumps is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.
- If the Transponder is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- If the Hydraulic System A is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.
- The captain will confirm any change in the Nosewheel Steering quantity display and advise the other pilot before the next phase of flight.

The pilot flying will confirm any change in the Transponder annunciation and advise the other pilot once the checklist item is complete. Both pilots will brief any change in the Standby Hydraulic advisory and advise the other pilot when conditions permit. The Hydraulic System B indication is expected to read within the sample range of 63 to 67 units during preflight. The Bleed Air Supply indication is expected to read within the sample range of 19 to 24 units during a turnaround. The Standby Hydraulic switch position that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. The Weather Radar switch position that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated.

03.10.3 Crew Coordination: Standby Hydraulic

The Cockpit Voice Recorder quantity display is expected to read within the sample range of 31 to 42 units during landing. The Window Heat switch position is expected to read within the sample range of 48 to 53 units during engine start. If the Probe Heat is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
-----------	--------------	---------

Weather Radar selector position	41 units	Refer to related topic
Primary Electrical Bus quantity display	2 units	Normal
Cargo Smoke Detection advisory	38 units	Normal

CAUTION: Both pilots will verify any change in the Autothrottle status message and advise the other pilot when the associated caution light remains illuminated.

NOTE: Refer to the related topic for additional sample context.

The Flap Position Indication selector position is expected to read within the sample range of 41 to 44 units during descent. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. During cruise, the pilot flying should brief the Speedbrake Handle advisory if the indication does not stabilize within the sample interval.

NOTE: During a diversion, the First Officer should cross-check the Speedbrake Handle selector position if a discrepancy is observed.

Challenge	Response
Auxiliary Power Unit	Off
Wing Anti-Ice	As required
Stall Warning	Verified
Autopilot Channel A	Armed
Center Tank Pumps	Armed
Fuel Crossfeed	As required
Speedbrake Handle	Armed

03.10.4 Callouts: Flap Position Indication

If the Center Tank Pumps is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. If the Transponder is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

The Primary Electrical Bus switch position that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power. The Cargo Smoke Detection switch position that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power. The Traffic Advisory Display selector position that differs from the expected state requires the First Officer to brief the condition when conditions permit. If the Primary Electrical Bus is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. During a maintenance-requested ground run, the First Officer should monitor the Engine Anti-Ice annunciation before the next phase of flight.

If the Hydraulic System A is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Flight Management Computer quantity display that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. If the Autobrake Selector is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

NOTE: The first officer will confirm any change in the Auxiliary Power Unit selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Transponder annunciation is expected to read within the sample range of 60 to 63 units during preflight.

- If the Engine Anti-Ice is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- The Oxygen Distribution quantity display is expected to read within the sample range of 55 to 62 units during taxi.

- The Autopilot Channel A status message is expected to read within the sample range of 52 to 64 units during an extended ground delay.
- If the Speedbrake Handle is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- The captain will record any change in the Weather Radar advisory and advise the other pilot if a discrepancy is observed.
- The pilot monitoring will confirm any change in the Autopilot Channel A annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During parking, the relief pilot should select the Cabin Pressure Controller switch position if the indication does not stabilize within the sample interval.
- The Engine Anti-Ice switch position that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated.
- The Primary Electrical Bus quantity display that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed.
- If the Flap Position Indication is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- The pilot flying will cross-check any change in the Standby Instruments selector position and advise the other pilot when the associated caution light remains illuminated.
- The Fuel Crossfeed status message is expected to read within the sample range of 45 to 50 units during climb.
- During an extended ground delay, the pilot monitoring should monitor the Weather Radar selector position if a discrepancy is observed.
- Refer to the related topic for additional sample context.
- The pilot flying will verify any change in the Stall Warning status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: If the Center Tank Pumps is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

Challenge	Response
Engine Anti-Ice	As required
Cabin Pressure Controller	Closed
Pack Temperature Control	Checked
Cargo Smoke Detection	Verified
Standby Instruments	As required
Autothrottle	Armed
Flight Management Computer	Set
Landing Gear Indication	Closed
Cargo Smoke Detection	Checked
Standby Instruments	Closed

03.10.5 Callouts: Thrust Reverser

The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection selector position that differs from the expected state requires the pilot monitoring to verify the condition unless

directed otherwise by the Sample Operations Center. The pilot flying will record any change in the Speedbrake Handle quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Hydraulic System A advisory	96 units	Normal
Brake Temperature Monitor annunciation	52 units	Refer to related topic
Traffic Advisory Display switch position	1 units	Monitor
Cockpit Voice Recorder indication	41 units	Normal
Cargo Smoke Detection switch position	34 units	Normal
Flight Management Computer annunciation	1 units	Refer to related topic
Autothrottle quantity display	76 units	Advisory only

NOTE: If the Oxygen Distribution is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

During climb, the relief pilot should announce the Flight Management Computer quantity display if the indication does not stabilize within the sample interval. The Transponder switch position is expected to read within the sample range of 97 to 102 units during an extended ground delay. This text is fictional and exists only to give the prototype realistic volume and structure. If the Autopilot Channel B is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

The Nosewheel Steering selector position is expected to read within the sample range of 91 to 98 units during engine start. The Engine Anti-Ice status message that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight. If the Landing Gear Indication is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The pilot flying will select any change in the Auxiliary Power Unit advisory and advise the other pilot when operating at a sample station without ground power.

03.10.6 Callouts: Standby Hydraulic

The relief pilot will announce any change in the Hydraulic System B annunciation and advise the other pilot when operating at a sample station without ground power. The Hydraulic System A status message is expected to read within the sample range of 71 to 74 units during landing. The Auxiliary Power Unit quantity display is expected to read within the sample range of 70 to 80 units during a maintenance-requested ground run. The Pack Temperature Control indication that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. If the Brake Temperature Monitor is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

- If the Nosewheel Steering is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.
- During taxi, the Captain should verify the Bleed Air Supply annunciation if a discrepancy is observed.
- If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.
- The Auxiliary Power Unit switch position is expected to read within the sample range of 35 to 43 units during cruise.
- During a maintenance-requested ground run, the pilot flying should confirm the Engine Anti-Ice indication unless directed otherwise by the Sample Operations Center.
- Both pilots will announce any change in the Fire Detection Loop switch position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
-----------	--------------	---------

Cockpit Voice Recorder switch position	21 units	Monitor
Hydraulic System A selector position	53 units	Advisory only
Bleed Air Supply annunciation	89 units	Advisory only
Fire Detection Loop status message	54 units	Advisory only
Hydraulic System A status message	30 units	Normal
Fire Detection Loop annunciation	9 units	Refer to related topic
Transponder indication	21 units	Refer to related topic

The wording here is placeholder content shaped like a procedure, not a procedure. During cruise, the First Officer should brief the Thrust Reverser status message before the next phase of flight. The Cargo Smoke Detection status message that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. The pilot flying will announce any change in the Oxygen Distribution quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

- The first officer will record any change in the Autobrake Selector quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Fire Detection Loop is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.
- The Standby Instruments selector position is expected to read within the sample range of 29 to 32 units during a maintenance-requested ground run.

NOTE: Both pilots will verify any change in the Speedbrake Handle status message and advise the other pilot if a discrepancy is observed.

During preflight, the pilot monitoring should record the Brake Temperature Monitor quantity display if the indication does not stabilize within the sample interval. The Probe Heat indication that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. The captain will brief any change in the Window Heat quantity display and advise the other pilot when conditions permit. The Standby Instruments status message is expected to read within the sample range of 62 to 65 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection indication that differs from the expected state requires both pilots to monitor the condition when conditions permit.

NOTE: During engine start, the First Officer should record the Landing Gear Indication advisory unless directed otherwise by the Sample Operations Center.

During descent, the First Officer should record the Traffic Advisory Display indication before the next phase of flight. Both pilots will cross-check any change in the Probe Heat status message and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Transponder is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. Both pilots will select any change in the Autothrottle annunciation and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice quantity display is expected to read within the sample range of 91 to 101 units during parking.

Challenge	Response
Center Tank Pumps	On
Window Heat	Closed
Landing Gear Indication	Off
Autothrottle	Checked
Traffic Advisory Display	Closed
Oxygen Distribution	Closed

Wing Anti-Ice	On
Nosewheel Steering	Off
Cabin Pressure Controller	On
Transponder	As required
Autopilot Channel A	Closed
Standby Hydraulic	Checked

03.10.7 Briefing: Autothrottle

During descent, the pilot flying should brief the Primary Electrical Bus switch position when conditions permit. The pilot flying will verify any change in the Traffic Advisory Display switch position and advise the other pilot when operating at a sample station without ground power. During approach, both pilots should announce the Standby Hydraulic status message when operating at a sample station without ground power. The Engine Anti-Ice status message is expected to read within the sample range of 85 to 96 units during climb. Refer to the related topic for additional sample context.

The Pack Temperature Control indication is expected to read within the sample range of 55 to 65 units during a maintenance-requested ground run. The Hydraulic System B annunciation is expected to read within the sample range of 18 to 26 units during descent. The Autopilot Channel B switch position is expected to read within the sample range of 44 to 50 units during parking.

- Values in this manual are invented and must not be used for any operational purpose.
- The Cargo Smoke Detection quantity display is expected to read within the sample range of 40 to 46 units during taxi.
- The first officer will select any change in the Thrust Reverser indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Bleed Air Supply advisory is expected to read within the sample range of 25 to 32 units during descent.
- The Traffic Advisory Display selector position is expected to read within the sample range of 48 to 60 units during a maintenance-requested ground run.
- During a maintenance-requested ground run, the pilot flying should brief the Wing Anti-Ice advisory once the checklist item is complete.

The pilot monitoring will monitor any change in the Window Heat selector position and advise the other pilot before the next phase of flight. If the Center Tank Pumps is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During preflight, the pilot flying should brief the Speedbrake Handle quantity display when conditions permit. If the Stall Warning is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

The relief pilot will announce any change in the Window Heat annunciation and advise the other pilot before the next phase of flight. The captain will select any change in the Autothrottle advisory and advise the other pilot when operating at a sample station without ground power. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. Both pilots will cross-check any change in the Cargo Smoke Detection indication and advise the other pilot when the associated caution light remains illuminated. During climb, the First Officer should record the Nosewheel Steering annunciation when conditions permit.

Condition	Sample value	Remarks
Cockpit Voice Recorder switch position	23 units	Normal
Primary Electrical Bus quantity display	43 units	Advisory only

Standby Hydraulic selector position	80 units	Normal
-------------------------------------	----------	--------

Challenge	Response
Probe Heat	Verified
Autopilot Channel B	Armed
Oxygen Distribution	As required
Cockpit Voice Recorder	Armed
Traffic Advisory Display	Off
Wing Anti-Ice	Checked
Oxygen Distribution	Checked
Cabin Pressure Controller	Off
Flap Position Indication	Armed
Speedbrake Handle	Closed

03.10.8 Crew Coordination: Stall Warning

The Nosewheel Steering annunciation is expected to read within the sample range of 70 to 82 units during parking. The Autopilot Channel A indication that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. The Standby Instruments switch position is expected to read within the sample range of 33 to 42 units during engine start. The first officer will record any change in the Wing Anti-Ice selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Pack Temperature Control is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. During taxi, the First Officer should cross-check the Engine Anti-Ice advisory if a discrepancy is observed.

This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will confirm any change in the Auxiliary Power Unit indication and advise the other pilot when the associated caution light remains illuminated. The Landing Gear Indication quantity display is expected to read within the sample range of 73 to 76 units during approach. The Standby Instruments indication is expected to read within the sample range of 23 to 30 units during landing. The Primary Electrical Bus advisory is expected to read within the sample range of 69 to 80 units during cruise. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During a turnaround, both pilots should cross-check the Standby Instruments selector position unless directed otherwise by the Sample Operations Center.

CAUTION: If the Fire Detection Loop is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

The Traffic Advisory Display advisory is expected to read within the sample range of 45 to 52 units during approach. Both pilots will monitor any change in the Thrust Reverser quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During approach, the relief pilot should record the Bleed Air Supply quantity display when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

03.20 Before Start and Engine Start

03.20.1 Verification: Hydraulic System B

Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection indication is expected to read within the sample range of 80 to 89 units during taxi. The Weather Radar quantity display that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is

complete. The pilot monitoring will monitor any change in the Flight Management Computer annunciation and advise the other pilot once the checklist item is complete.

- If the Wing Anti-Ice is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- The captain will select any change in the Standby Hydraulic quantity display and advise the other pilot once the checklist item is complete.
- During landing, the pilot monitoring should monitor the Probe Heat annunciation unless directed otherwise by the Sample Operations Center.
- The pilot monitoring will cross-check any change in the Traffic Advisory Display indication and advise the other pilot when operating at a sample station without ground power.

During taxi, the First Officer should confirm the Hydraulic System B quantity display if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. The Cockpit Voice Recorder annunciation that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. The first officer will cross-check any change in the Transponder switch position and advise the other pilot once the checklist item is complete. During descent, the pilot monitoring should verify the Center Tank Pumps selector position when the associated caution light remains illuminated.

The Autobrake Selector status message is expected to read within the sample range of 20 to 31 units during a diversion. The Nosewheel Steering advisory is expected to read within the sample range of 61 to 68 units during preflight. During landing, the First Officer should brief the Wing Anti-Ice status message when the associated caution light remains illuminated. If the Autopilot Channel B is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The Pack Temperature Control annunciation is expected to read within the sample range of 23 to 34 units during descent. If the Center Tank Pumps is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

If the Ground Proximity Monitor is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Pack Temperature Control switch position is expected to read within the sample range of 67 to 75 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure. See 05.30.5 Wing Anti-Ice Crew Awareness.

Challenge	Response
Bleed Air Supply	Set
Pack Temperature Control	Checked
Brake Temperature Monitor	Set
Autopilot Channel B	Verified
Autopilot Channel A	As required
Fire Detection Loop	Set
Hydraulic System B	On
Bleed Air Supply	As required

03.20.2 Flow: Landing Gear Indication

Refer to the related topic for additional sample context. During takeoff, the Captain should monitor the Autopilot Channel A selector position unless directed otherwise by the Sample Operations Center. The Landing Gear Indication indication is expected to read within the sample range of 30 to 38 units during parking. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Cockpit Voice Recorder advisory	45 units	Normal
Cabin Pressure Controller annunciation	71 units	Advisory only
Nosewheel Steering switch position	41 units	Normal
Cargo Smoke Detection quantity display	81 units	Refer to related topic
Hydraulic System A annunciation	6 units	Monitor
Speedbrake Handle status message	8 units	Normal
Stall Warning selector position	13 units	Normal

The Oxygen Distribution advisory that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. Both pilots will verify any change in the Flap Position Indication advisory and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will announce any change in the Standby Instruments selector position and advise the other pilot before the next phase of flight. The pilot flying will select any change in the Flap Position Indication annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: If the Primary Electrical Bus is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should record the Hydraulic System A status message once the checklist item is complete.

CAUTION: Both pilots will select any change in the Landing Gear Indication indication and advise the other pilot when the associated caution light remains illuminated. During descent, the First Officer should monitor the Autobrake Selector status message unless directed otherwise by the Sample Operations Center.

During climb, both pilots should select the Fire Detection Loop annunciation when the associated caution light remains illuminated. Refer to the related topic for additional sample context. If the Thrust Reverser is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Fuel Crossfeed quantity display that differs from the expected state requires the pilot flying to record the condition before the next phase of flight. The Thrust Reverser quantity display is expected to read within the sample range of 85 to 91 units during descent.

The Stall Warning advisory is expected to read within the sample range of 40 to 50 units during a turnaround. The Autobrake Selector advisory that differs from the expected state requires the First Officer to cross-check the condition when operating at a sample station without ground power. Both pilots will announce any change in the Primary Electrical Bus indication and advise the other pilot when the associated caution light remains illuminated. The Cabin Pressure Controller status message is expected to read within the sample range of 80 to 91 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Standby Hydraulic	On
Speedbrake Handle	Closed
Window Heat	Checked
Stall Warning	Off
Hydraulic System A	Set
Cabin Pressure Controller	Verified

03.20.3 Crew Coordination: Flight Management Computer

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Flight Management Computer quantity display that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will record any change in the Autopilot Channel A indication and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

Values in this manual are invented and must not be used for any operational purpose. If the Flight Management Computer is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The Hydraulic System B quantity display is expected to read within the sample range of 80 to 86 units during preflight. The Weather Radar indication that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. The Brake Temperature Monitor status message that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center.

The Flap Position Indication quantity display is expected to read within the sample range of 28 to 37 units during a diversion. The first officer will confirm any change in the Brake Temperature Monitor advisory and advise the other pilot once the checklist item is complete. During an extended ground delay, both pilots should monitor the Standby Hydraulic advisory if a discrepancy is observed.

- The captain will announce any change in the Flap Position Indication status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The Flight Management Computer status message is expected to read within the sample range of 85 to 89 units during cruise.
- The Hydraulic System B status message that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight.
- If the Cargo Smoke Detection is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

NOTE: During preflight, the pilot monitoring should cross-check the Transponder selector position if a discrepancy is observed. If the Stall Warning is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

During a turnaround, the Captain should record the Speedbrake Handle advisory if the indication does not stabilize within the sample interval. The relief pilot will select any change in the Flap Position Indication quantity display and advise the other pilot before the next phase of flight. The Standby Instruments switch position is expected to read within the sample range of 91 to 101 units during engine start.

The Cargo Smoke Detection advisory is expected to read within the sample range of 64 to 76 units during landing. During cruise, the relief pilot should announce the Cargo Smoke Detection advisory when the associated caution light remains illuminated. The pilot flying will record any change in the Flap Position Indication indication and advise the other pilot before the next phase of flight. Both pilots will cross-check any change in the Traffic Advisory Display indication and advise the other pilot once the checklist item is complete.

Challenge	Response
Wing Anti-Ice	Verified
Primary Electrical Bus	Armed
Cabin Pressure Controller	Checked
Wing Anti-Ice	As required
Bleed Air Supply	Off
Primary Electrical Bus	Armed

Window Heat	Off
Center Tank Pumps	Checked

03.20.4 Callouts: Cockpit Voice Recorder

Both pilots will announce any change in the Auxiliary Power Unit switch position and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps annunciation that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight.

- If the Landing Gear Indication is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- The Autothrottle advisory is expected to read within the sample range of 86 to 97 units during approach.
- During engine start, the First Officer should verify the Weather Radar indication if a discrepancy is observed.
- If the Weather Radar is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- During engine start, the First Officer should confirm the Transponder quantity display before the next phase of flight.

CAUTION: If the Transponder is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

CAUTION: The Standby Instruments status message that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval.

During a maintenance-requested ground run, the relief pilot should confirm the Pack Temperature Control indication when the associated caution light remains illuminated. The pilot flying will confirm any change in the Autopilot Channel B selector position and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Cabin Pressure Controller selector position that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete.

The Traffic Advisory Display advisory is expected to read within the sample range of 48 to 57 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication quantity display that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. During engine start, the First Officer should brief the Bleed Air Supply switch position if the indication does not stabilize within the sample interval. If the Fire Detection Loop is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. During a turnaround, the pilot flying should announce the Pack Temperature Control quantity display once the checklist item is complete.

Condition	Sample value	Remarks
Standby Instruments selector position	6 units	Monitor
Nosewheel Steering switch position	66 units	Normal
Speedbrake Handle status message	77 units	Monitor

03.20.5 Briefing: Probe Heat

The relief pilot will cross-check any change in the Hydraulic System A status message and advise the other pilot if the indication does not stabilize within the sample interval. During approach, the Captain should verify the Landing Gear Indication annunciation if a discrepancy is observed. The first officer will brief any change in the Landing Gear Indication selector position and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will verify any change in the Flight Management Computer quantity display and advise the other pilot before the next phase of flight. The relief pilot will monitor any change in the Standby Instruments switch position and

advise the other pilot if a discrepancy is observed.

NOTE: The Flight Management Computer advisory is expected to read within the sample range of 63 to 66 units during engine start. If the Standby Instruments is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

NOTE: If the Autopilot Channel B is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Stall Warning selector position	60 units	Normal
Cabin Pressure Controller selector position	10 units	Refer to related topic
Standby Hydraulic quantity display	15 units	Refer to related topic
Fire Detection Loop quantity display	61 units	Monitor

- Refer to the related topic for additional sample context.
- The first officer will cross-check any change in the Fuel Crossfeed switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- The relief pilot will select any change in the Cargo Smoke Detection status message and advise the other pilot when conditions permit.
- If the Oxygen Distribution is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- During taxi, the Captain should brief the Flap Position Indication advisory when the associated caution light remains illuminated.
- The relief pilot will cross-check any change in the Window Heat annunciation and advise the other pilot when the associated caution light remains illuminated.

Challenge	Response
Cockpit Voice Recorder	Off
Auxiliary Power Unit	Verified
Standby Instruments	On
Bleed Air Supply	As required
Thrust Reverser	Armed
Speedbrake Handle	On
Ground Proximity Monitor	Verified
Wing Anti-Ice	Verified

03.20.6 Verification: Standby Instruments

The Autobrake Selector selector position is expected to read within the sample range of 95 to 100 units during parking. The Fire Detection Loop advisory that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete. During climb, both pilots should monitor the Fire Detection Loop advisory once the checklist item is complete. If the Fire Detection Loop is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

CAUTION: If the Wing Anti-Ice is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
-----------	--------------	---------

Transponder switch position	54 units	Refer to related topic
Bleed Air Supply selector position	92 units	Refer to related topic
Brake Temperature Monitor advisory	13 units	Refer to related topic
Pack Temperature Control selector position	67 units	Refer to related topic
Fuel Crossfeed status message	75 units	Normal
Cockpit Voice Recorder advisory	88 units	Normal

NOTE: The Window Heat selector position that differs from the expected state requires the Captain to select the condition if a discrepancy is observed.

CAUTION: If the Autobrake Selector is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Hydraulic indication	20 units	Normal
Auxiliary Power Unit status message	40 units	Advisory only
Cockpit Voice Recorder selector position	88 units	Monitor
Stall Warning advisory	1 units	Advisory only
Fuel Crossfeed indication	49 units	Normal
Thrust Reverser quantity display	4 units	Advisory only
Flap Position Indication indication	38 units	Advisory only

The Pack Temperature Control selector position is expected to read within the sample range of 11 to 22 units during a turnaround. The first officer will select any change in the Standby Instruments advisory and advise the other pilot if a discrepancy is observed. If the Autobrake Selector is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During engine start, the First Officer should select the Stall Warning quantity display when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. See 07.20.2 Transponder Limits Display.

Challenge	Response
Center Tank Pumps	Set
Flap Position Indication	As required
Flight Management Computer	Armed
Hydraulic System A	As required
Standby Instruments	As required
Nosewheel Steering	Verified
Ground Proximity Monitor	Verified
Hydraulic System A	Closed
Cockpit Voice Recorder	Off
Cockpit Voice Recorder	Set
Landing Gear Indication	Verified
Primary Electrical Bus	Armed

03.30 Taxi

03.30.1 Callouts: Primary Electrical Bus

The first officer will select any change in the Probe Heat switch position and advise the other pilot when conditions permit. The captain will confirm any change in the Cockpit Voice Recorder switch position and advise the other pilot when the associated caution light remains illuminated. The Nosewheel Steering status message that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. The Hydraulic System A quantity display is expected to read within the sample range of 53 to 56 units during preflight. The Bleed Air Supply status message that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete.

Condition	Sample value	Remarks
Landing Gear Indication indication	50 units	Normal
Thrust Reverser switch position	14 units	Advisory only
Primary Electrical Bus status message	86 units	Normal
Cockpit Voice Recorder quantity display	4 units	Refer to related topic
Window Heat indication	86 units	Monitor
Standby Instruments indication	68 units	Advisory only
Brake Temperature Monitor indication	75 units	Advisory only

During a maintenance-requested ground run, the relief pilot should select the Ground Proximity Monitor status message unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During descent, the relief pilot should record the Autopilot Channel B selector position when operating at a sample station without ground power.

The captain will brief any change in the Hydraulic System A quantity display and advise the other pilot if a discrepancy is observed. The Thrust Reverser quantity display is expected to read within the sample range of 14 to 23 units during taxi. The Fire Detection Loop quantity display is expected to read within the sample range of 47 to 59 units during preflight. The Fire Detection Loop switch position is expected to read within the sample range of 28 to 34 units during a turnaround.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

Values in this manual are invented and must not be used for any operational purpose. If the Pack Temperature Control is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Landing Gear Indication quantity display that differs from the expected state requires the Captain to record the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Hydraulic System B status message	74 units	Advisory only
Transponder status message	1 units	Refer to related topic
Speedbrake Handle quantity display	13 units	Monitor
Autopilot Channel A selector position	88 units	Refer to related topic
Fuel Crossfeed annunciation	12 units	Monitor
Transponder advisory	90 units	Monitor

Both pilots will select any change in the Ground Proximity Monitor selector position and advise the other pilot before the next phase of flight. The Stall Warning selector position is expected to read within the sample range of 87 to 95 units during preflight. During preflight, the pilot monitoring should select the Wing Anti-Ice status message if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
-----------	--------------	---------

Stall Warning switch position	76 units	Advisory only
Autopilot Channel B status message	95 units	Advisory only
Autopilot Channel B status message	26 units	Refer to related topic
Window Heat indication	85 units	Monitor
Primary Electrical Bus selector position	37 units	Normal
Window Heat switch position	22 units	Normal
Transponder indication	31 units	Monitor

03.30.2 Checklist: Autopilot Channel B

If the Probe Heat is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Standby Hydraulic annunciation that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. If the Autopilot Channel B is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Transponder selector position is expected to read within the sample range of 71 to 78 units during taxi.

The Brake Temperature Monitor quantity display that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. If the Autopilot Channel B is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display selector position that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed. During cruise, the relief pilot should cross-check the Autopilot Channel A indication before the next phase of flight. During engine start, the relief pilot should announce the Probe Heat switch position unless directed otherwise by the Sample Operations Center. If the Wing Anti-Ice is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

NOTE: The Oxygen Distribution advisory is expected to read within the sample range of 14 to 21 units during cruise. The Engine Anti-Ice selector position that differs from the expected state requires the First Officer to select the condition once the checklist item is complete.

- During a turnaround, the pilot monitoring should cross-check the Flap Position Indication advisory when operating at a sample station without ground power.
- If the Hydraulic System B is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.
- The Autothrottle selector position is expected to read within the sample range of 87 to 93 units during cruise.

Condition	Sample value	Remarks
Hydraulic System A annunciation	63 units	Normal
Center Tank Pumps status message	11 units	Advisory only
Bleed Air Supply selector position	64 units	Advisory only
Fire Detection Loop selector position	96 units	Normal
Center Tank Pumps switch position	93 units	Monitor
Autopilot Channel A annunciation	39 units	Advisory only
Fuel Crossfeed status message	77 units	Monitor

- If the Hydraulic System A is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

- The Hydraulic System B annunciation is expected to read within the sample range of 2 to 13 units during approach.
- The Cabin Pressure Controller advisory that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center.

Challenge	Response
Ground Proximity Monitor	Off
Wing Anti-Ice	On
Autothrottle	Armed
Flight Management Computer	Off
Fire Detection Loop	Set
Bleed Air Supply	Verified
Stall Warning	On
Standby Hydraulic	On
Probe Heat	Armed
Wing Anti-Ice	Checked

03.30.3 Crew Coordination: Probe Heat

Refer to the related topic for additional sample context. During taxi, the pilot flying should brief the Fuel Crossfeed quantity display before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Cabin Pressure Controller is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will cross-check any change in the Speedbrake Handle quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

The Flap Position Indication switch position that differs from the expected state requires the pilot flying to record the condition when conditions permit. During an extended ground delay, the First Officer should verify the Nosewheel Steering quantity display when conditions permit. The pilot monitoring will announce any change in the Flight Management Computer status message and advise the other pilot before the next phase of flight. The Cabin Pressure Controller annunciation is expected to read within the sample range of 84 to 88 units during climb.

During engine start, the pilot flying should record the Stall Warning indication if the indication does not stabilize within the sample interval. The Cabin Pressure Controller advisory that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit. Both pilots will confirm any change in the Autobrake Selector switch position and advise the other pilot if a discrepancy is observed.

If the Auxiliary Power Unit is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The captain will confirm any change in the Cargo Smoke Detection advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Pack Temperature Control annunciation is expected to read within the sample range of 17 to 22 units during a turnaround.

NOTE: The Standby Hydraulic selector position is expected to read within the sample range of 32 to 41 units during a diversion. During cruise, the First Officer should select the Wing Anti-Ice status message when conditions permit.

The pilot monitoring will cross-check any change in the Fuel Crossfeed switch position and advise the other pilot when operating at a sample station without ground power. During engine start, the pilot flying should announce the Autopilot Channel A quantity display when operating at a sample station without ground power. If the Auxiliary Power Unit is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Autopilot Channel B status message is expected to read within the sample range of 5 to 16 units during parking. The Center Tank Pumps status message that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete. If the Probe Heat is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

If the Stall Warning is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. During cruise, the Captain should record the Wing Anti-Ice selector position when the associated caution light remains illuminated. The Pack Temperature Control annunciation that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder annunciation is expected to read within the sample range of 24 to 35 units during preflight. During parking, the First Officer should verify the Stall Warning indication unless directed otherwise by the Sample Operations Center.

- During climb, the pilot flying should confirm the Hydraulic System A selector position if a discrepancy is observed.
- The Autothrottle status message is expected to read within the sample range of 49 to 59 units during an extended ground delay.
- If the Speedbrake Handle is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- During a turnaround, both pilots should brief the Flight Management Computer selector position if the indication does not stabilize within the sample interval.

The pilot flying will monitor any change in the Flap Position Indication status message and advise the other pilot when the associated caution light remains illuminated. The Hydraulic System A annunciation that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. During preflight, the First Officer should brief the Standby Instruments advisory when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

03.30.4 Checklist: Standby Instruments

The pilot monitoring will brief any change in the Fuel Crossfeed status message and advise the other pilot if the indication does not stabilize within the sample interval. The Transponder switch position is expected to read within the sample range of 93 to 97 units during a turnaround. The Hydraulic System B indication is expected to read within the sample range of 83 to 94 units during landing. If the Cabin Pressure Controller is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The captain will verify any change in the Thrust Reverser indication and advise the other pilot when operating at a sample station without ground power.

The Primary Electrical Bus status message that differs from the expected state requires the First Officer to record the condition before the next phase of flight. If the Traffic Advisory Display is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder advisory is expected to read within the sample range of 78 to 81 units during a turnaround.

During climb, the relief pilot should record the Traffic Advisory Display quantity display if the indication does not stabilize within the sample interval. During taxi, the pilot monitoring should monitor the Standby Instruments advisory when the associated caution light remains illuminated. If the Autopilot Channel A is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: During takeoff, the Captain should monitor the Speedbrake Handle annunciation when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Autothrottle indication	12 units	Refer to related topic
Stall Warning switch position	25 units	Normal
Brake Temperature Monitor quantity display	50 units	Refer to related topic

CAUTION: The Cabin Pressure Controller indication that differs from the expected state requires both pilots to brief the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

Challenge	Response
Standby Hydraulic	Armed
Wing Anti-Ice	Off
Flap Position Indication	As required
Fire Detection Loop	As required
Landing Gear Indication	On
Probe Heat	Armed
Primary Electrical Bus	Off
Hydraulic System A	Verified

03.40 Takeoff and Climb

03.40.1 Verification: Primary Electrical Bus

The Standby Instruments advisory that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed. During a turnaround, the Captain should monitor the Flap Position Indication indication if the indication does not stabilize within the sample interval. If the Hydraulic System B is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

- During an extended ground delay, both pilots should record the Flight Management Computer advisory unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a diversion, the Captain should monitor the Autopilot Channel B selector position unless directed otherwise by the Sample Operations Center.
- During a maintenance-requested ground run, the relief pilot should record the Oxygen Distribution switch position if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Landing Gear Indication status message is expected to read within the sample range of 19 to 25 units during landing.

Condition	Sample value	Remarks
Thrust Reverser switch position	30 units	Advisory only
Speedbrake Handle switch position	36 units	Refer to related topic
Hydraulic System A annunciation	68 units	Refer to related topic
Standby Hydraulic indication	1 units	Advisory only
Autobrake Selector annunciation	62 units	Monitor
Hydraulic System B indication	63 units	Normal

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

The Transponder switch position is expected to read within the sample range of 35 to 44 units during a diversion. If the Standby Instruments is inoperative, continue cruise only after the pilot monitoring has reviewed the associated

sample guidance. The Flight Management Computer advisory is expected to read within the sample range of 72 to 81 units during climb. Refer to the related topic for additional sample context. The Landing Gear Indication advisory is expected to read within the sample range of 46 to 55 units during engine start.

NOTE: The relief pilot will cross-check any change in the Hydraulic System A advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Cargo Smoke Detection indication that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The captain will monitor any change in the Hydraulic System B annunciation and advise the other pilot when conditions permit. The Flight Management Computer indication is expected to read within the sample range of 5 to 11 units during approach.

- The Primary Electrical Bus indication that differs from the expected state requires the relief pilot to brief the condition unless directed otherwise by the Sample Operations Center.
- The Stall Warning quantity display is expected to read within the sample range of 33 to 39 units during a maintenance-requested ground run.
- During descent, the relief pilot should verify the Speedbrake Handle annunciation once the checklist item is complete.

03.40.2 Checklist: Weather Radar

The Fire Detection Loop selector position is expected to read within the sample range of 49 to 52 units during cruise. The Wing Anti-Ice advisory that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. The Autothrottle annunciation is expected to read within the sample range of 46 to 53 units during taxi. The pilot monitoring will record any change in the Pack Temperature Control selector position and advise the other pilot before the next phase of flight.

CAUTION: The relief pilot will monitor any change in the Bleed Air Supply quantity display and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Fuel Crossfeed indication	84 units	Normal
Brake Temperature Monitor selector position	53 units	Normal
Speedbrake Handle annunciation	46 units	Normal

The first officer will monitor any change in the Auxiliary Power Unit quantity display and advise the other pilot once the checklist item is complete. Both pilots will brief any change in the Oxygen Distribution selector position and advise the other pilot if the indication does not stabilize within the sample interval. The captain will monitor any change in the Thrust Reverser quantity display and advise the other pilot if a discrepancy is observed. During a turnaround, the relief pilot should select the Weather Radar quantity display once the checklist item is complete. The Fire Detection Loop status message that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. The Cockpit Voice Recorder status message that differs from the expected state requires both pilots to select the condition before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Flight Management Computer is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Engine Anti-Ice status message that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. Both pilots will announce any change in the Nosewheel Steering quantity display and advise the other pilot when operating at a sample station without ground power. During a diversion, the pilot flying should cross-check the Probe Heat quantity display if the indication does not stabilize within the sample interval.

NOTE: The Transponder annunciation is expected to read within the sample range of 63 to 71 units during climb. If the Flight Management Computer is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

The pilot flying will confirm any change in the Cargo Smoke Detection selector position and advise the other pilot once the checklist item is complete. If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication annunciation that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. During climb, the relief pilot should monitor the Standby Instruments advisory if the indication does not stabilize within the sample interval. The Pack Temperature Control status message that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. The Thrust Reverser status message is expected to read within the sample range of 65 to 77 units during a turnaround.

NOTE: The Weather Radar status message is expected to read within the sample range of 13 to 18 units during landing.

03.40.3 Checklist: Cargo Smoke Detection

If the Speedbrake Handle is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The relief pilot will confirm any change in the Cockpit Voice Recorder advisory and advise the other pilot if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, the First Officer should announce the Window Heat quantity display if a discrepancy is observed. The Speedbrake Handle quantity display that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight. The Wing Anti-Ice annunciation is expected to read within the sample range of 79 to 84 units during takeoff.

- During cruise, the relief pilot should monitor the Center Tank Pumps quantity display when conditions permit.
- The Hydraulic System A advisory that differs from the expected state requires both pilots to select the condition when conditions permit.
- The Ground Proximity Monitor status message that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center.
- The pilot flying will cross-check any change in the Nosewheel Steering indication and advise the other pilot when conditions permit.

If the Cabin Pressure Controller is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The first officer will monitor any change in the Fuel Crossfeed quantity display and advise the other pilot once the checklist item is complete. The Hydraulic System A status message that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. During a diversion, both pilots should brief the Fuel Crossfeed advisory when conditions permit.

CAUTION: The Flap Position Indication advisory is expected to read within the sample range of 69 to 72 units during taxi.

- If the Traffic Advisory Display is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.
- The Hydraulic System A selector position is expected to read within the sample range of 13 to 23 units during an extended ground delay.
- The Fire Detection Loop quantity display that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated.
- The relief pilot will confirm any change in the Wing Anti-Ice selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During a maintenance-requested ground run, the pilot flying should record the Autopilot Channel A selector position unless directed otherwise by the Sample Operations Center.

- The Flap Position Indication selector position that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete.
- The pilot monitoring will record any change in the Cargo Smoke Detection advisory and advise the other pilot if a discrepancy is observed.
- During an extended ground delay, the Captain should brief the Landing Gear Indication selector position unless directed otherwise by the Sample Operations Center.
- During engine start, both pilots should record the Fuel Crossfeed annunciation unless directed otherwise by the Sample Operations Center.
- If the Cockpit Voice Recorder is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, the Captain should select the Auxiliary Power Unit quantity display when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, both pilots should monitor the Wing Anti-Ice selector position when the associated caution light remains illuminated.

The Nosewheel Steering status message that differs from the expected state requires both pilots to confirm the condition when conditions permit. The Cargo Smoke Detection status message that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center. The captain will confirm any change in the Standby Hydraulic indication and advise the other pilot if a discrepancy is observed.

If the Hydraulic System B is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Speedbrake Handle indication that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. If the Autopilot Channel B is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During a turnaround, both pilots should verify the Oxygen Distribution quantity display if the indication does not stabilize within the sample interval. The Autothrottle quantity display is expected to read within the sample range of 63 to 67 units during taxi.

Challenge	Response
Pack Temperature Control	On
Auxiliary Power Unit	Closed
Hydraulic System B	Verified
Engine Anti-Ice	Checked
Weather Radar	Armed
Flight Management Computer	Checked
Engine Anti-Ice	Verified
Auxiliary Power Unit	On
Auxiliary Power Unit	Verified

03.40.4 Checklist: Flap Position Indication

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic status message that differs from the expected state requires the First Officer to confirm the condition when conditions permit. The Standby Hydraulic annunciation that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Fire Detection Loop switch position that differs from the expected state requires the First Officer to brief the condition when conditions permit.

During cruise, the relief pilot should announce the Brake Temperature Monitor indication when the associated caution light remains illuminated. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 77 to 80 units during climb. The Landing Gear Indication annunciation is expected to read within the sample range of 46 to 55 units during a diversion. If the Window Heat is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Autopilot Channel A quantity display that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete.

CAUTION: During a turnaround, the pilot monitoring should record the Oxygen Distribution advisory once the checklist item is complete. During taxi, both pilots should cross-check the Brake Temperature Monitor selector position when conditions permit.

- The first officer will select any change in the Autopilot Channel B status message and advise the other pilot when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot flying will announce any change in the Fire Detection Loop status message and advise the other pilot if the indication does not stabilize within the sample interval.

During landing, both pilots should brief the Hydraulic System A advisory when conditions permit. The pilot flying will confirm any change in the Engine Anti-Ice selector position and advise the other pilot when the associated caution light remains illuminated. The Fire Detection Loop annunciation is expected to read within the sample range of 63 to 73 units during a maintenance-requested ground run. The pilot monitoring will record any change in the Flight Management Computer switch position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Hydraulic System B selector position	27 units	Advisory only
Flight Management Computer selector position	11 units	Refer to related topic
Auxiliary Power Unit switch position	97 units	Normal

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

Challenge	Response
Standby Instruments	Off
Cabin Pressure Controller	On
Center Tank Pumps	On
Engine Anti-Ice	Checked
Hydraulic System B	Verified
Speedbrake Handle	Checked
Wing Anti-Ice	On
Brake Temperature Monitor	Off
Traffic Advisory Display	Closed

03.40.5 Checklist: Window Heat

If the Probe Heat is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During taxi, both pilots should verify the Thrust Reverser selector position when operating at a sample station without ground power. The relief pilot will announce any change in the Speedbrake Handle quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
-----------	--------------	---------

Cockpit Voice Recorder quantity display	92 units	Normal
Fuel Crossfeed quantity display	20 units	Monitor
Standby Hydraulic advisory	51 units	Advisory only
Pack Temperature Control annunciation	85 units	Normal
Autobrake Selector status message	23 units	Refer to related topic
Autothrottle indication	42 units	Refer to related topic

- During a diversion, the Captain should brief the Fuel Crossfeed switch position when the associated caution light remains illuminated.
- If the Pack Temperature Control is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.
- If the Ground Proximity Monitor is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.
- The pilot monitoring will brief any change in the Traffic Advisory Display status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The relief pilot will brief any change in the Autopilot Channel B status message and advise the other pilot when conditions permit.

The pilot flying will confirm any change in the Autopilot Channel B switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The Autopilot Channel B indication that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Standby Instruments indication is expected to read within the sample range of 22 to 27 units during a turnaround. During preflight, both pilots should cross-check the Landing Gear Indication switch position when the associated caution light remains illuminated.

NOTE: If the Speedbrake Handle is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

Challenge	Response
Thrust Reverser	Closed
Hydraulic System A	Closed
Landing Gear Indication	As required
Wing Anti-Ice	Off
Fire Detection Loop	As required
Window Heat	Off

03.50 Cruise

03.50.1 Verification: Fuel Crossfeed

If the Cockpit Voice Recorder is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Transponder status message is expected to read within the sample range of 91 to 96 units during takeoff. Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice advisory is expected to read within the sample range of 71 to 80 units during an extended ground delay. The Autopilot Channel A switch position that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. The Engine Anti-Ice switch position is expected to read within the sample range of 32 to 43 units during approach.

- The Fuel Crossfeed status message that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed.
- During approach, the pilot flying should select the Primary Electrical Bus annunciation unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During climb, the First Officer should announce the Autobrake Selector annunciation if the indication does not stabilize within the sample interval.
- During approach, the pilot flying should brief the Auxiliary Power Unit quantity display unless directed otherwise by the Sample Operations Center.

NOTE: The Autopilot Channel B indication is expected to read within the sample range of 37 to 40 units during parking. The captain will record any change in the Cabin Pressure Controller advisory and advise the other pilot before the next phase of flight.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

03.50.2 Checklist: Fire Detection Loop

Refer to the related topic for additional sample context. During engine start, the First Officer should record the Cabin Pressure Controller annunciation if the indication does not stabilize within the sample interval. The Hydraulic System A switch position that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Values in this manual are invented and must not be used for any operational purpose.
- During approach, the pilot monitoring should record the Fuel Crossfeed indication if the indication does not stabilize within the sample interval.
- During a maintenance-requested ground run, the First Officer should confirm the Transponder indication before the next phase of flight.
- The pilot flying will announce any change in the Ground Proximity Monitor switch position and advise the other pilot when operating at a sample station without ground power.
- The Cargo Smoke Detection annunciation is expected to read within the sample range of 38 to 48 units during descent.

Condition	Sample value	Remarks
Hydraulic System A indication	84 units	Normal
Hydraulic System A indication	34 units	Refer to related topic
Weather Radar selector position	72 units	Advisory only
Flap Position Indication quantity display	33 units	Normal
Autopilot Channel A switch position	93 units	Normal
Landing Gear Indication quantity display	55 units	Normal

Condition	Sample value	Remarks
Speedbrake Handle annunciation	3 units	Advisory only
Pack Temperature Control annunciation	60 units	Advisory only
Fuel Crossfeed status message	10 units	Advisory only

Probe Heat status message	32 units	Monitor
Ground Proximity Monitor status message	15 units	Normal

During cruise, the pilot flying should record the Probe Heat selector position if a discrepancy is observed. The Traffic Advisory Display annunciation that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed. If the Cargo Smoke Detection is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Wing Anti-Ice switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Transponder status message that differs from the expected state requires both pilots to brief the condition before the next phase of flight.

CAUTION: The Hydraulic System A quantity display that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power.

Challenge	Response
Autopilot Channel A	Set
Transponder	Armed
Hydraulic System B	As required
Window Heat	Checked
Flap Position Indication	Set
Standby Instruments	Set
Cabin Pressure Controller	On
Hydraulic System B	Armed
Fuel Crossfeed	Armed
Oxygen Distribution	Set
Hydraulic System B	On
Weather Radar	Closed

03.50.3 Briefing: Autopilot Channel B

This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will record any change in the Probe Heat indication and advise the other pilot before the next phase of flight. The relief pilot will monitor any change in the Thrust Reverser quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Pack Temperature Control advisory is expected to read within the sample range of 53 to 60 units during an extended ground delay. During approach, both pilots should select the Thrust Reverser status message if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder advisory that differs from the expected state requires both pilots to record the condition if a discrepancy is observed.

If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During cruise, the First Officer should cross-check the Standby Hydraulic annunciation when the associated caution light remains illuminated. If the Hydraulic System B is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

The Stall Warning switch position is expected to read within the sample range of 21 to 33 units during cruise. During parking, the Captain should record the Transponder status message when the associated caution light remains illuminated. If the Cargo Smoke Detection is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. During approach, both pilots should record the Probe Heat quantity display unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 72 to 77 units during takeoff. Refer to the related topic for additional sample context.

CAUTION: The Nosewheel Steering switch position that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. The Bleed Air Supply switch position that differs from the expected state requires the First Officer to monitor the condition when conditions permit.

Condition	Sample value	Remarks
Flight Management Computer selector position	61 units	Refer to related topic
Brake Temperature Monitor annunciation	53 units	Normal
Fire Detection Loop switch position	25 units	Normal
Brake Temperature Monitor selector position	66 units	Normal
Primary Electrical Bus selector position	69 units	Normal
Brake Temperature Monitor annunciation	82 units	Normal

Challenge	Response
Standby Hydraulic	Set
Wing Anti-Ice	On
Stall Warning	Off
Window Heat	Checked
Autopilot Channel A	Closed
Pack Temperature Control	Verified
Center Tank Pumps	Verified
Cockpit Voice Recorder	As required
Cabin Pressure Controller	Checked
Hydraulic System A	Armed
Transponder	Off
Flight Management Computer	Checked

03.50.4 Briefing: Autopilot Channel A

The Fire Detection Loop quantity display that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. The Autopilot Channel B quantity display is expected to read within the sample range of 33 to 38 units during taxi. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will announce any change in the Autothrottle quantity display and advise the other pilot once the checklist item is complete. During a maintenance-requested ground run, the relief pilot should confirm the Window Heat quantity display when conditions permit. If the Autopilot Channel A is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

- If the Speedbrake Handle is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.
- The Fire Detection Loop indication that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center.
- The pilot flying will cross-check any change in the Autopilot Channel B annunciation and advise the other pilot before the next phase of flight.
- During engine start, both pilots should cross-check the Engine Anti-Ice quantity display when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: During a maintenance-requested ground run, the relief pilot should record the Cabin Pressure Controller indication if a discrepancy is observed. The Fire Detection Loop indication is expected to read within the sample range of 11 to 18 units during a turnaround.

The Cabin Pressure Controller selector position that differs from the expected state requires both pilots to select the condition once the checklist item is complete. During a maintenance-requested ground run, both pilots should verify the Stall Warning selector position if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. During parking, the First Officer should verify the Autopilot Channel B status message when operating at a sample station without ground power. The pilot flying will announce any change in the Fire Detection Loop indication and advise the other pilot when the associated caution light remains illuminated. The first officer will confirm any change in the Primary Electrical Bus switch position and advise the other pilot once the checklist item is complete.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Flight Management Computer is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The first officer will confirm any change in the Traffic Advisory Display annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

The Cockpit Voice Recorder status message is expected to read within the sample range of 88 to 91 units during cruise. Values in this manual are invented and must not be used for any operational purpose. The Brake Temperature Monitor selector position that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. During a diversion, the pilot flying should confirm the Stall Warning annunciation unless directed otherwise by the Sample Operations Center. The captain will select any change in the Hydraulic System A status message and advise the other pilot if a discrepancy is observed.

During climb, the relief pilot should announce the Ground Proximity Monitor annunciation when operating at a sample station without ground power. The Engine Anti-Ice status message that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. The Cargo Smoke Detection advisory is expected to read within the sample range of 54 to 64 units during climb.

03.60 Descent and Approach

03.60.1 Checklist: Hydraulic System B

The Pack Temperature Control switch position that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. The Primary Electrical Bus switch position that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight. If the Landing Gear Indication is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

NOTE: The relief pilot will record any change in the Autopilot Channel A selector position and advise the other pilot when the associated caution light remains illuminated.

The Fuel Crossfeed switch position is expected to read within the sample range of 60 to 66 units during engine start. The Standby Hydraulic annunciation is expected to read within the sample range of 11 to 17 units during parking. During an extended ground delay, the Captain should monitor the Autopilot Channel A annunciation if the indication does not stabilize within the sample interval. The Stall Warning switch position is expected to read within the sample range of 31 to 34 units during climb. Values in this manual are invented and must not be used for any operational purpose. The Thrust Reverser selector position that differs from the expected state requires the Captain to brief the condition when conditions permit.

The Autobrake Selector indication is expected to read within the sample range of 4 to 14 units during parking. During taxi, the pilot flying should confirm the Hydraulic System B switch position before the next phase of flight. The

Standby Hydraulic selector position that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Brake Temperature Monitor selector position	79 units	Advisory only
Cockpit Voice Recorder indication	73 units	Refer to related topic
Bleed Air Supply indication	58 units	Normal
Stall Warning annunciation	9 units	Normal
Cabin Pressure Controller advisory	30 units	Advisory only

NOTE: During takeoff, the First Officer should cross-check the Engine Anti-Ice indication when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

The pilot flying will select any change in the Bleed Air Supply indication and advise the other pilot when operating at a sample station without ground power. The first officer will monitor any change in the Wing Anti-Ice quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Engine Anti-Ice annunciation is expected to read within the sample range of 56 to 67 units during approach. See 13.20.4 Window Heat Status Messages.

- If the Speedbrake Handle is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- The Nosewheel Steering annunciation that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated.
- If the Traffic Advisory Display is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The Standby Hydraulic selector position is expected to read within the sample range of 50 to 56 units during cruise.

Challenge	Response
Pack Temperature Control	Armed
Autopilot Channel B	As required
Landing Gear Indication	Set
Window Heat	As required
Cockpit Voice Recorder	Verified
Oxygen Distribution	On

03.60.2 Crew Coordination: Flap Position Indication

The wording here is placeholder content shaped like a procedure, not a procedure. The Traffic Advisory Display advisory is expected to read within the sample range of 21 to 32 units during a diversion. The Weather Radar switch position is expected to read within the sample range of 5 to 13 units during preflight. Refer to the related topic for additional sample context. During climb, the relief pilot should verify the Transponder status message if the indication does not stabilize within the sample interval. Both pilots will announce any change in the Landing Gear Indication indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The Center Tank Pumps indication is expected to read within the sample range of 98 to 109 units during engine start.
- During descent, the Captain should record the Center Tank Pumps status message before the next phase of flight.

- If the Stall Warning is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.

The pilot monitoring will monitor any change in the Cargo Smoke Detection switch position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor status message is expected to read within the sample range of 92 to 100 units during landing. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: If the Cockpit Voice Recorder is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power.

- Both pilots will verify any change in the Bleed Air Supply advisory and advise the other pilot before the next phase of flight.
- If the Auxiliary Power Unit is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.
- If the Cabin Pressure Controller is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.
- During a turnaround, the pilot monitoring should verify the Hydraulic System B status message when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The first officer will cross-check any change in the Probe Heat indication and advise the other pilot when the associated caution light remains illuminated.

The relief pilot will verify any change in the Hydraulic System B switch position and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. The Hydraulic System B status message that differs from the expected state requires the Captain to brief the condition before the next phase of flight. During descent, the First Officer should confirm the Autopilot Channel B switch position when the associated caution light remains illuminated.

03.60.3 Flow: Weather Radar

The Autothrottle annunciation that differs from the expected state requires both pilots to monitor the condition when conditions permit. During an extended ground delay, the pilot monitoring should record the Cockpit Voice Recorder switch position when operating at a sample station without ground power. If the Stall Warning is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The Center Tank Pumps status message that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight.

Condition	Sample value	Remarks
Center Tank Pumps quantity display	50 units	Normal
Standby Instruments advisory	69 units	Normal
Cockpit Voice Recorder advisory	81 units	Normal
Fuel Crossfeed advisory	8 units	Monitor

The pilot flying will cross-check any change in the Wing Anti-Ice indication and advise the other pilot when the associated caution light remains illuminated. If the Brake Temperature Monitor is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Center Tank Pumps annunciation that

differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. The Flap Position Indication switch position is expected to read within the sample range of 56 to 67 units during descent. The captain will select any change in the Autothrottle selector position and advise the other pilot once the checklist item is complete.

The Flap Position Indication annunciation is expected to read within the sample range of 21 to 32 units during climb. The Speedbrake Handle advisory is expected to read within the sample range of 55 to 58 units during landing. The Pack Temperature Control quantity display is expected to read within the sample range of 9 to 12 units during landing. The relief pilot will confirm any change in the Transponder switch position and advise the other pilot before the next phase of flight. Both pilots will monitor any change in the Weather Radar indication and advise the other pilot if the indication does not stabilize within the sample interval.

The Transponder switch position is expected to read within the sample range of 80 to 88 units during descent. The Traffic Advisory Display switch position is expected to read within the sample range of 87 to 96 units during takeoff. During takeoff, the relief pilot should monitor the Fuel Crossfeed annunciation if the indication does not stabilize within the sample interval. Both pilots will verify any change in the Speedbrake Handle quantity display and advise the other pilot when conditions permit. During cruise, the pilot monitoring should announce the Standby Hydraulic status message when operating at a sample station without ground power. Refer to the related topic for additional sample context.

03.60.4 Verification: Brake Temperature Monitor

The Nosewheel Steering annunciation that differs from the expected state requires the First Officer to select the condition before the next phase of flight. The Weather Radar indication is expected to read within the sample range of 50 to 61 units during preflight. The Pack Temperature Control selector position is expected to read within the sample range of 35 to 39 units during a diversion. This text is fictional and exists only to give the prototype realistic volume and structure. If the Brake Temperature Monitor is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

CAUTION: If the Thrust Reverser is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The pilot flying will monitor any change in the Hydraulic System B advisory and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Brake Temperature Monitor selector position	45 units	Advisory only
Autobrake Selector selector position	16 units	Monitor
Speedbrake Handle switch position	4 units	Advisory only
Wing Anti-Ice status message	13 units	Refer to related topic
Primary Electrical Bus switch position	21 units	Advisory only
Traffic Advisory Display switch position	66 units	Refer to related topic

- If the Oxygen Distribution is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The Thrust Reverser status message is expected to read within the sample range of 19 to 24 units during landing.
- During an extended ground delay, both pilots should announce the Primary Electrical Bus switch position once the checklist item is complete.
- During takeoff, the Captain should monitor the Cockpit Voice Recorder advisory when operating at a sample station without ground power.
- The Nosewheel Steering selector position is expected to read within the sample range of 30 to 39 units during cruise.

If the Pack Temperature Control is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The Window Heat annunciation is expected to read within the sample range of 3 to 14 units during taxi. The Hydraulic System B switch position is expected to read within the sample range of 44 to 47 units during climb. The pilot monitoring will confirm any change in the Center Tank Pumps quantity display and advise the other pilot when conditions permit. The Standby Instruments indication is expected to read within the sample range of 59 to 68 units during preflight.

CAUTION: The captain will monitor any change in the Window Heat status message and advise the other pilot when conditions permit. The Autothrottle selector position is expected to read within the sample range of 62 to 70 units during an extended ground delay.

- During engine start, the Captain should confirm the Engine Anti-Ice switch position if a discrepancy is observed.
- The Primary Electrical Bus selector position that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During descent, the Captain should brief the Wing Anti-Ice status message when the associated caution light remains illuminated.
- The first officer will verify any change in the Flight Management Computer switch position and advise the other pilot when operating at a sample station without ground power.

NOTE: During taxi, the relief pilot should brief the Stall Warning status message if the indication does not stabilize within the sample interval. The pilot monitoring will verify any change in the Auxiliary Power Unit switch position and advise the other pilot before the next phase of flight.

03.60.5 Verification: Stall Warning

The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder advisory that differs from the expected state requires the Captain to record the condition when the associated caution light remains illuminated. The Nosewheel Steering status message is expected to read within the sample range of 57 to 69 units during taxi. The relief pilot will confirm any change in the Flap Position Indication status message and advise the other pilot if a discrepancy is observed. The Weather Radar indication that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Primary Electrical Bus selector position that differs from the expected state requires the pilot flying to cross-check the condition if a discrepancy is observed. If the Nosewheel Steering is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Hydraulic System A indication that differs from the expected state requires the First Officer to monitor the condition once the checklist item is complete.

- If the Stall Warning is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- The pilot flying will announce any change in the Primary Electrical Bus switch position and advise the other pilot if a discrepancy is observed.
- If the Flight Management Computer is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The Autothrottle selector position is expected to read within the sample range of 88 to 99 units during a turnaround.

- If the Weather Radar is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Stall Warning advisory	31 units	Normal
Flap Position Indication annunciation	47 units	Monitor
Weather Radar quantity display	30 units	Advisory only
Flight Management Computer switch position	26 units	Normal

- If the Fuel Crossfeed is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.
- If the Traffic Advisory Display is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- The pilot flying will select any change in the Pack Temperature Control switch position and advise the other pilot if a discrepancy is observed.

The pilot flying will verify any change in the Center Tank Pumps annunciation and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. The pilot monitoring will confirm any change in the Standby Hydraulic indication and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

The pilot monitoring will monitor any change in the Hydraulic System A annunciation and advise the other pilot if a discrepancy is observed. The relief pilot will verify any change in the Hydraulic System A annunciation and advise the other pilot before the next phase of flight. The pilot monitoring will confirm any change in the Standby Hydraulic switch position and advise the other pilot when operating at a sample station without ground power. The Autobrake Selector indication is expected to read within the sample range of 93 to 104 units during a diversion. See 08.10.4 Wing Anti-Ice Overview.

Challenge	Response
Traffic Advisory Display	As required
Cabin Pressure Controller	Off
Nosewheel Steering	Armed
Fuel Crossfeed	Armed
Stall Warning	Off
Autothrottle	Closed
Speedbrake Handle	Checked

03.60.6 Flow: Stall Warning

Refer to the related topic for additional sample context. During preflight, the First Officer should brief the Cockpit Voice Recorder quantity display once the checklist item is complete. If the Thrust Reverser is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. Both pilots will record any change in the Speedbrake Handle annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Engine Anti-Ice advisory that differs from the expected state requires the First Officer to select the condition when conditions permit.

The Thrust Reverser indication is expected to read within the sample range of 40 to 52 units during engine start. The relief pilot will announce any change in the Cargo Smoke Detection switch position and advise the other pilot once the

checklist item is complete. The pilot monitoring will monitor any change in the Primary Electrical Bus status message and advise the other pilot when the associated caution light remains illuminated. The relief pilot will monitor any change in the Weather Radar status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will verify any change in the Hydraulic System B selector position and advise the other pilot before the next phase of flight. During a maintenance-requested ground run, the Captain should select the Standby Hydraulic advisory before the next phase of flight.

- The Flap Position Indication annunciation that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated.
- The Fire Detection Loop selector position is expected to read within the sample range of 21 to 27 units during a maintenance-requested ground run.
- Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Probe Heat switch position that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. During approach, the pilot flying should announce the Traffic Advisory Display status message when the associated caution light remains illuminated.

NOTE: During cruise, the pilot monitoring should monitor the Cockpit Voice Recorder advisory if the indication does not stabilize within the sample interval. The Ground Proximity Monitor selector position that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated.

- Values in this manual are invented and must not be used for any operational purpose.
- The Fuel Crossfeed quantity display is expected to read within the sample range of 50 to 54 units during approach.
- During a maintenance-requested ground run, the First Officer should select the Transponder status message when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Primary Electrical Bus status message	32 units	Monitor
Oxygen Distribution status message	13 units	Refer to related topic
Oxygen Distribution switch position	9 units	Advisory only
Flap Position Indication advisory	35 units	Monitor
Window Heat selector position	81 units	Monitor
Oxygen Distribution indication	38 units	Refer to related topic
Weather Radar advisory	46 units	Monitor

The Pack Temperature Control status message that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete. The Autothrottle annunciation is expected to read within the sample range of 8 to 14 units during an extended ground delay. The Weather Radar indication that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. During an extended ground delay, the Captain should record the Bleed Air Supply quantity display unless directed otherwise by the Sample Operations Center.

Challenge	Response
Brake Temperature Monitor	As required
Traffic Advisory Display	Closed

Stall Warning	Checked
Brake Temperature Monitor	Closed
Standby Hydraulic	Set
Oxygen Distribution	Checked
Cabin Pressure Controller	Checked
Autothrottle	Verified
Cockpit Voice Recorder	Closed

03.70 Landing and Shutdown

03.70.1 Callouts: Brake Temperature Monitor

The Window Heat status message that differs from the expected state requires both pilots to announce the condition before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. During a maintenance-requested ground run, the Captain should confirm the Brake Temperature Monitor annunciation if the indication does not stabilize within the sample interval.

The Primary Electrical Bus status message that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. The Weather Radar annunciation is expected to read within the sample range of 12 to 19 units during preflight. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: If the Probe Heat is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Brake Temperature Monitor annunciation is expected to read within the sample range of 82 to 87 units during takeoff.

NOTE: The Wing Anti-Ice annunciation is expected to read within the sample range of 87 to 97 units during a diversion.

NOTE: If the Flight Management Computer is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will announce any change in the Fuel Crossfeed advisory and advise the other pilot if the indication does not stabilize within the sample interval. If the Wing Anti-Ice is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

NOTE: If the Pack Temperature Control is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

03.70.2 Checklist: Hydraulic System B

During parking, both pilots should cross-check the Ground Proximity Monitor advisory before the next phase of flight. The Hydraulic System B status message that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval. The pilot monitoring will record any change in the Cockpit Voice Recorder selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Thrust Reverser is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. During engine start, the relief pilot should confirm the Landing Gear Indication annunciation once the checklist item is complete. The Oxygen Distribution annunciation is expected to read within the sample range of 31 to 42 units during engine start.

CAUTION: The relief pilot will monitor any change in the Primary Electrical Bus selector position and advise the other pilot when conditions permit.

The pilot monitoring will confirm any change in the Flap Position Indication switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Autothrottle advisory is expected to read within the sample range of 89 to 94 units during landing. If the Weather Radar is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

The Nosewheel Steering status message that differs from the expected state requires the Captain to brief the condition when conditions permit. The Wing Anti-Ice annunciation that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. The Thrust Reverser selector position that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

The Autothrottle quantity display is expected to read within the sample range of 16 to 22 units during a diversion. The Cabin Pressure Controller quantity display is expected to read within the sample range of 55 to 65 units during preflight. During an extended ground delay, both pilots should record the Oxygen Distribution status message when conditions permit. During landing, the pilot flying should verify the Landing Gear Indication annunciation if a discrepancy is observed. If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

03.70.3 Crew Coordination: Oxygen Distribution

The first officer will brief any change in the Cargo Smoke Detection selector position and advise the other pilot before the next phase of flight. The Stall Warning selector position that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. If the Auxiliary Power Unit is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Ground Proximity Monitor selector position that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval.

If the Hydraulic System A is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will cross-check any change in the Autobrake Selector selector position and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

During approach, the pilot flying should verify the Wing Anti-Ice selector position when conditions permit. The Fuel Crossfeed annunciation that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated. The Autopilot Channel A switch position is expected to read within the sample range of 97 to 104 units during landing. The captain will monitor any change in the Hydraulic System B indication and advise the other pilot once the checklist item is complete.

CAUTION: The Traffic Advisory Display indication that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center. If the Thrust Reverser is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

During cruise, the Captain should select the Probe Heat annunciation if a discrepancy is observed. The Pack Temperature Control quantity display is expected to read within the sample range of 6 to 13 units during a turnaround. If the Autopilot Channel A is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Nosewheel Steering status message is expected to read within the sample range of 9 to 12 units during taxi. The Autothrottle advisory is expected to read within the sample range of 79 to 87 units during an extended ground delay. If the Weather Radar is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

- The Weather Radar switch position that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated.

- If the Hydraulic System B is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.
- During a diversion, the pilot monitoring should brief the Probe Heat indication once the checklist item is complete.
- During takeoff, the relief pilot should record the Landing Gear Indication advisory when operating at a sample station without ground power.

The Traffic Advisory Display selector position that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. If the Engine Anti-Ice is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

During engine start, the Captain should announce the Cabin Pressure Controller advisory when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The Primary Electrical Bus quantity display is expected to read within the sample range of 56 to 62 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose.

The pilot monitoring will cross-check any change in the Pack Temperature Control indication and advise the other pilot if the indication does not stabilize within the sample interval. If the Weather Radar is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During taxi, the pilot flying should verify the Thrust Reverser selector position unless directed otherwise by the Sample Operations Center. The Flap Position Indication advisory is expected to read within the sample range of 94 to 97 units during a maintenance-requested ground run. Both pilots will verify any change in the Autopilot Channel B annunciation and advise the other pilot when conditions permit.

Challenge	Response
Bleed Air Supply	Armed
Landing Gear Indication	Armed
Oxygen Distribution	Set
Wing Anti-Ice	On
Cabin Pressure Controller	Armed
Landing Gear Indication	On
Autopilot Channel A	On
Autothrottle	Set
Fire Detection Loop	Closed
Landing Gear Indication	Set
Autothrottle	Checked

03.70.4 Checklist: Window Heat

If the Flight Management Computer is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The captain will cross-check any change in the Nosewheel Steering annunciation and advise the other pilot once the checklist item is complete. The Standby Hydraulic selector position is expected to read within the sample range of 73 to 78 units during takeoff.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	62 units	Monitor
Standby Instruments quantity display	69 units	Advisory only
Thrust Reverser switch position	75 units	Advisory only

Fire Detection Loop selector position	54 units	Advisory only
Nosewheel Steering status message	98 units	Monitor
Transponder switch position	2 units	Refer to related topic

If the Flap Position Indication is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The Standby Hydraulic annunciation is expected to read within the sample range of 69 to 73 units during a diversion.

CAUTION: The Hydraulic System B status message that differs from the expected state requires the Captain to cross-check the condition when conditions permit. The Transponder indication is expected to read within the sample range of 5 to 16 units during preflight.

If the Standby Instruments is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector status message is expected to read within the sample range of 85 to 88 units during engine start. During climb, the pilot flying should select the Thrust Reverser status message if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the pilot flying should cross-check the Standby Hydraulic advisory when conditions permit.

Condition	Sample value	Remarks
Thrust Reverser switch position	81 units	Refer to related topic
Center Tank Pumps selector position	89 units	Monitor
Cargo Smoke Detection indication	43 units	Advisory only
Fire Detection Loop quantity display	68 units	Normal
Hydraulic System A advisory	73 units	Normal
Hydraulic System B indication	96 units	Normal

Challenge	Response
Nosewheel Steering	Set
Oxygen Distribution	Checked
Standby Instruments	Checked
Thrust Reverser	Closed
Traffic Advisory Display	Armed
Auxiliary Power Unit	Closed
Hydraulic System B	On
Autopilot Channel B	On
Center Tank Pumps	As required
Autobrake Selector	Off
Cargo Smoke Detection	Verified

03.70.5 Flow: Primary Electrical Bus

The Hydraulic System B quantity display that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power. If the Flap Position Indication is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The first officer will verify any change in the Oxygen Distribution annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

During preflight, the pilot monitoring should confirm the Fire Detection Loop annunciation if a discrepancy is observed. During a maintenance-requested ground run, the relief pilot should select the Stall Warning indication when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Bleed Air Supply switch position is expected to read within the sample range of 22 to 31 units during cruise. The Thrust Reverser annunciation that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated.

If the Probe Heat is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will select any change in the Flap Position Indication switch position and advise the other pilot before the next phase of flight.

During climb, the First Officer should brief the Pack Temperature Control switch position if a discrepancy is observed. The captain will monitor any change in the Engine Anti-Ice switch position and advise the other pilot if the indication does not stabilize within the sample interval. During takeoff, the Captain should verify the Standby Instruments indication if a discrepancy is observed. The Standby Instruments advisory that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. The Flight Management Computer annunciation is expected to read within the sample range of 33 to 44 units during a diversion. See 15.30.2 Cabin Pressure Controller Reset Guidance.

- Refer to the related topic for additional sample context.
- The Brake Temperature Monitor selector position that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Pack Temperature Control is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- Both pilots will select any change in the Weather Radar switch position and advise the other pilot if a discrepancy is observed.
- The first officer will cross-check any change in the Ground Proximity Monitor annunciation and advise the other pilot if a discrepancy is observed.
- The captain will confirm any change in the Transponder selector position and advise the other pilot when the associated caution light remains illuminated.
- During parking, the relief pilot should confirm the Auxiliary Power Unit annunciation when conditions permit.
- The first officer will announce any change in the Center Tank Pumps quantity display and advise the other pilot when the associated caution light remains illuminated.

Challenge	Response
Flight Management Computer	On
Primary Electrical Bus	Verified
Fuel Crossfeed	Armed
Auxiliary Power Unit	Armed
Center Tank Pumps	Armed
Hydraulic System A	Armed
Hydraulic System A	Closed
Ground Proximity Monitor	As required
Ground Proximity Monitor	Closed
Wing Anti-Ice	Closed

Chapter 04 Supplementary Procedures

04.10 Adverse Weather

04.10.1 Verification: Cockpit Voice Recorder

The Flap Position Indication quantity display that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic indication is expected to read within the sample range of 62 to 66 units during climb. The Cabin Pressure Controller advisory is expected to read within the sample range of 72 to 78 units during takeoff. The Brake Temperature Monitor status message that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

The first officer will brief any change in the Transponder selector position and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will verify any change in the Fire Detection Loop advisory and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The Cabin Pressure Controller status message that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power.

The relief pilot will brief any change in the Autobrake Selector status message and advise the other pilot if a discrepancy is observed. During cruise, the pilot flying should confirm the Landing Gear Indication annunciation once the checklist item is complete. The Wing Anti-Ice indication is expected to read within the sample range of 75 to 86 units during a turnaround. The Primary Electrical Bus selector position is expected to read within the sample range of 42 to 46 units during engine start. If the Engine Anti-Ice is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

Both pilots will confirm any change in the Hydraulic System A switch position and advise the other pilot when operating at a sample station without ground power. The Brake Temperature Monitor selector position is expected to read within the sample range of 61 to 64 units during parking. During a turnaround, the pilot monitoring should record the Cockpit Voice Recorder advisory if a discrepancy is observed.

Condition	Sample value	Remarks
Hydraulic System B selector position	71 units	Refer to related topic
Center Tank Pumps status message	8 units	Advisory only
Landing Gear Indication switch position	1 units	Advisory only

Condition	Sample value	Remarks
Traffic Advisory Display advisory	8 units	Refer to related topic
Cabin Pressure Controller switch position	32 units	Refer to related topic
Pack Temperature Control switch position	96 units	Advisory only

04.10.2 Crew Coordination: Standby Instruments

The Flap Position Indication indication that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. The Traffic Advisory Display selector position is expected to read within the sample range of 88 to 93 units during taxi. The Autopilot Channel B status message that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

NOTE: If the Fire Detection Loop is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

CAUTION: The Autopilot Channel A status message is expected to read within the sample range of 56 to 64 units during an extended ground delay.

The Flight Management Computer annunciation that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. If the Flap Position Indication is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The pilot monitoring will monitor any change in the Standby Hydraulic advisory and advise the other pilot before the next phase of flight. The Autothrottle switch position that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight.

The Nosewheel Steering selector position that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. The first officer will record any change in the Traffic Advisory Display indication and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. If the Bleed Air Supply is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

04.10.3 Briefing: Bleed Air Supply

If the Hydraulic System B is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The Auxiliary Power Unit quantity display that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. If the Hydraulic System A is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the relief pilot should brief the Fire Detection Loop quantity display before the next phase of flight. The Hydraulic System A advisory is expected to read within the sample range of 26 to 37 units during cruise.

CAUTION: The Landing Gear Indication advisory is expected to read within the sample range of 43 to 48 units during landing. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

During a maintenance-requested ground run, the First Officer should verify the Auxiliary Power Unit indication before the next phase of flight. The Autopilot Channel B indication is expected to read within the sample range of 11 to 19 units during approach. The Fuel Crossfeed indication is expected to read within the sample range of 28 to 37 units during approach.

CAUTION: During cruise, the pilot monitoring should cross-check the Transponder indication when operating at a sample station without ground power.

CAUTION: During a turnaround, the relief pilot should cross-check the Speedbrake Handle status message once the checklist item is complete.

- Both pilots will cross-check any change in the Cargo Smoke Detection status message and advise the other pilot if a discrepancy is observed.
- During engine start, the pilot flying should announce the Cabin Pressure Controller indication once the checklist item is complete.
- If the Autopilot Channel A is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.
- During takeoff, the pilot monitoring should brief the Landing Gear Indication switch position when operating at a sample station without ground power.
- During taxi, the First Officer should confirm the Autobrake Selector annunciation unless directed otherwise by the Sample Operations Center.

During a turnaround, the pilot flying should confirm the Fire Detection Loop annunciation when operating at a sample station without ground power. The captain will select any change in the Pack Temperature Control advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

The relief pilot will monitor any change in the Autothrottle status message and advise the other pilot when the associated caution light remains illuminated. If the Thrust Reverser is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Wing Anti-Ice status message is expected to read within the sample range of 41 to 44 units during climb. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Cabin Pressure Controller is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

04.10.4 Briefing: Bleed Air Supply

The Standby Hydraulic selector position that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center. The Brake Temperature Monitor selector position is expected to read within the sample range of 35 to 38 units during approach. If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During cruise, the pilot monitoring should select the Standby Hydraulic indication if the indication does not stabilize within the sample interval.

Refer to the related topic for additional sample context. During approach, both pilots should monitor the Primary Electrical Bus selector position unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

- During preflight, the relief pilot should verify the Traffic Advisory Display indication once the checklist item is complete.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During taxi, the Captain should confirm the Hydraulic System B indication if the indication does not stabilize within the sample interval.
- If the Engine Anti-Ice is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Engine Anti-Ice quantity display	84 units	Advisory only
Landing Gear Indication switch position	43 units	Normal
Autopilot Channel B selector position	71 units	Monitor

The relief pilot will announce any change in the Speedbrake Handle switch position and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed status message is expected to read within the sample range of 61 to 71 units during descent. If the Autopilot Channel B is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

The first officer will confirm any change in the Weather Radar quantity display and advise the other pilot when operating at a sample station without ground power. If the Hydraulic System A is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The relief pilot will verify any change in the Cockpit Voice Recorder switch position and advise the other pilot when the associated caution light remains illuminated. The

first officer will brief any change in the Wing Anti-Ice annunciation and advise the other pilot if a discrepancy is observed.

- The Wing Anti-Ice annunciation is expected to read within the sample range of 60 to 71 units during climb.
- Refer to the related topic for additional sample context.
- The Wing Anti-Ice annunciation is expected to read within the sample range of 21 to 28 units during parking.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During descent, the pilot flying should brief the Fire Detection Loop status message when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Oxygen Distribution advisory	85 units	Monitor
Landing Gear Indication quantity display	87 units	Advisory only
Hydraulic System A annunciation	92 units	Refer to related topic

During approach, the pilot monitoring should verify the Bleed Air Supply selector position when the associated caution light remains illuminated. During taxi, the pilot flying should confirm the Wing Anti-Ice quantity display if the indication does not stabilize within the sample interval. If the Autopilot Channel B is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. During takeoff, the pilot monitoring should monitor the Hydraulic System A status message before the next phase of flight. The Brake Temperature Monitor quantity display is expected to read within the sample range of 8 to 14 units during a maintenance-requested ground run. The relief pilot will verify any change in the Flight Management Computer annunciation and advise the other pilot when conditions permit. See 17.20.2 Autobrake Selector Normal Operation.

04.10.5 Callouts: Wing Anti-Ice

Both pilots will record any change in the Oxygen Distribution annunciation and advise the other pilot before the next phase of flight. The Fuel Crossfeed annunciation that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. During parking, the relief pilot should cross-check the Cargo Smoke Detection annunciation if a discrepancy is observed.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Weather Radar is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The first officer will announce any change in the Standby Hydraulic quantity display and advise the other pilot when conditions permit.

This text is fictional and exists only to give the prototype realistic volume and structure. During climb, the relief pilot should confirm the Standby Instruments indication when conditions permit. The captain will record any change in the Landing Gear Indication quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will select any change in the Center Tank Pumps selector position and advise the other pilot when operating at a sample station without ground power. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 63 to 75 units during a turnaround.

CAUTION: During a maintenance-requested ground run, both pilots should confirm the Autothrottle advisory unless directed otherwise by the Sample Operations Center.

CAUTION: The Speedbrake Handle quantity display is expected to read within the sample range of 73 to 82 units during preflight.

This text is fictional and exists only to give the prototype realistic volume and structure. The Weather Radar indication is expected to read within the sample range of 46 to 52 units during a turnaround. The Flap Position Indication quantity display is expected to read within the sample range of 28 to 36 units during takeoff. The Traffic Advisory Display switch position that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. The Window Heat switch position is expected to read within the sample range of 54 to 62 units during a maintenance-requested ground run. If the Cockpit Voice Recorder is

inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

The pilot monitoring will record any change in the Wing Anti-Ice quantity display and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, the relief pilot should brief the Autobrake Selector status message when operating at a sample station without ground power. The Autopilot Channel B indication is expected to read within the sample range of 29 to 40 units during taxi. During descent, the First Officer should verify the Flap Position Indication annunciation once the checklist item is complete.

If the Speedbrake Handle is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During a diversion, the relief pilot should cross-check the Bleed Air Supply switch position when operating at a sample station without ground power. The Stall Warning indication that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Hydraulic System A quantity display	10 units	Advisory only
Thrust Reverser annunciation	22 units	Advisory only
Window Heat selector position	32 units	Refer to related topic
Probe Heat selector position	79 units	Normal
Speedbrake Handle status message	51 units	Advisory only
Center Tank Pumps quantity display	89 units	Normal

04.10.6 Verification: Cockpit Voice Recorder

The Standby Hydraulic status message that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. The Window Heat annunciation that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. If the Cockpit Voice Recorder is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Weather Radar indication that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated.

If the Primary Electrical Bus is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. During approach, the Captain should brief the Fire Detection Loop switch position when the associated caution light remains illuminated. If the Ground Proximity Monitor is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Wing Anti-Ice quantity display that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. The Auxiliary Power Unit selector position is expected to read within the sample range of 35 to 39 units during descent.

During engine start, the pilot flying should select the Engine Anti-Ice status message when operating at a sample station without ground power. During cruise, the Captain should brief the Nosewheel Steering indication before the next phase of flight. During parking, the relief pilot should select the Ground Proximity Monitor quantity display before the next phase of flight. The Transponder advisory is expected to read within the sample range of 44 to 56 units during takeoff. During a maintenance-requested ground run, the First Officer should select the Auxiliary Power Unit selector position before the next phase of flight. The relief pilot will verify any change in the Standby Instruments quantity display and advise the other pilot when conditions permit.

- If the Autopilot Channel A is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.
- During preflight, the First Officer should cross-check the Cargo Smoke Detection indication when conditions permit.

- If the Flight Management Computer is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.
- If the Flight Management Computer is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- The Autopilot Channel B advisory that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.

NOTE: The first officer will brief any change in the Speedbrake Handle switch position and advise the other pilot before the next phase of flight. The Hydraulic System A advisory is expected to read within the sample range of 3 to 10 units during preflight.

The Transponder annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. The Center Tank Pumps selector position that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. The first officer will announce any change in the Pack Temperature Control annunciation and advise the other pilot when conditions permit. Both pilots will record any change in the Speedbrake Handle advisory and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

The pilot flying will confirm any change in the Fire Detection Loop advisory and advise the other pilot when operating at a sample station without ground power. If the Thrust Reverser is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display switch position is expected to read within the sample range of 84 to 92 units during a maintenance-requested ground run. The Hydraulic System B selector position that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. See 13.30.4 Fire Detection Loop Normal Operation.

04.20 Cold Weather Operations

04.20.1 Flow: Standby Instruments

During taxi, the pilot monitoring should verify the Transponder quantity display before the next phase of flight. The Pack Temperature Control selector position is expected to read within the sample range of 33 to 37 units during takeoff. The captain will monitor any change in the Stall Warning status message and advise the other pilot if a discrepancy is observed.

During descent, the Captain should monitor the Standby Hydraulic switch position when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control status message that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated. The Cargo Smoke Detection switch position that differs from the expected state requires both pilots to select the condition before the next phase of flight. The Center Tank Pumps quantity display is expected to read within the sample range of 87 to 91 units during engine start. Refer to the related topic for additional sample context.

- If the Engine Anti-Ice is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- The Hydraulic System B indication that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power.
- The Auxiliary Power Unit annunciation that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center.

If the Transponder is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Primary Electrical Bus quantity display that differs from the expected state

requires the pilot flying to monitor the condition before the next phase of flight. The Bleed Air Supply selector position is expected to read within the sample range of 44 to 51 units during cruise. Both pilots will record any change in the Autobrake Selector indication and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will monitor any change in the Transponder selector position and advise the other pilot before the next phase of flight.

CAUTION: Both pilots will record any change in the Cargo Smoke Detection advisory and advise the other pilot if a discrepancy is observed. The Landing Gear Indication annunciation that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.

- The Autopilot Channel B status message that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power.
- The captain will cross-check any change in the Pack Temperature Control switch position and advise the other pilot before the next phase of flight.
- During a turnaround, the Captain should record the Engine Anti-Ice quantity display when operating at a sample station without ground power.
- The pilot monitoring will select any change in the Hydraulic System B annunciation and advise the other pilot once the checklist item is complete.
- The Nosewheel Steering quantity display that differs from the expected state requires the pilot monitoring to record the condition when conditions permit.

Both pilots will record any change in the Auxiliary Power Unit switch position and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice selector position is expected to read within the sample range of 10 to 17 units during engine start. The Stall Warning selector position that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power.

- The pilot monitoring will monitor any change in the Transponder quantity display and advise the other pilot when conditions permit.
- During taxi, the Captain should brief the Engine Anti-Ice switch position when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.

04.20.2 Briefing: Probe Heat

The relief pilot will announce any change in the Cockpit Voice Recorder annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will brief any change in the Cabin Pressure Controller advisory and advise the other pilot when operating at a sample station without ground power. The Landing Gear Indication selector position is expected to read within the sample range of 45 to 51 units during climb. The Hydraulic System B quantity display is expected to read within the sample range of 77 to 83 units during preflight. Values in this manual are invented and must not be used for any operational purpose. If the Auxiliary Power Unit is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

CAUTION: If the Autobrake Selector is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

During a turnaround, the pilot monitoring should select the Weather Radar advisory if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. During climb, the relief pilot should select the Autobrake Selector selector position before the next phase of flight.

CAUTION: During a maintenance-requested ground run, the pilot flying should announce the Speedbrake Handle switch position when the associated caution light remains illuminated.

- The pilot flying will monitor any change in the Nosewheel Steering quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During takeoff, the First Officer should verify the Cargo Smoke Detection annunciation unless directed otherwise by the Sample Operations Center.
- The Flight Management Computer status message that differs from the expected state requires the Captain to brief the condition once the checklist item is complete.
- The Traffic Advisory Display indication is expected to read within the sample range of 24 to 31 units during takeoff.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Hydraulic System A is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- The Flight Management Computer quantity display is expected to read within the sample range of 3 to 14 units during a maintenance-requested ground run.
- Values in this manual are invented and must not be used for any operational purpose.
- During a diversion, the relief pilot should monitor the Fire Detection Loop status message before the next phase of flight.
- The Primary Electrical Bus quantity display is expected to read within the sample range of 5 to 12 units during takeoff.

Both pilots will monitor any change in the Cockpit Voice Recorder indication and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The captain will confirm any change in the Ground Proximity Monitor annunciation and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. If the Brake Temperature Monitor is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

04.20.3 Flow: Traffic Advisory Display

During a turnaround, the relief pilot should confirm the Autothrottle indication when operating at a sample station without ground power. The Landing Gear Indication advisory is expected to read within the sample range of 65 to 68 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure.

The Primary Electrical Bus switch position is expected to read within the sample range of 83 to 91 units during preflight. The Center Tank Pumps quantity display is expected to read within the sample range of 59 to 63 units during preflight. During a turnaround, the Captain should confirm the Oxygen Distribution quantity display once the checklist item is complete. The Hydraulic System B annunciation is expected to read within the sample range of 85 to 95 units during parking.

The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice quantity display that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. During landing, the Captain should select the Autobrake Selector status message if the indication does not stabilize within the sample interval. During taxi, the First Officer should cross-check the Hydraulic System B selector position unless directed otherwise by the Sample Operations Center. During cruise, the First Officer should record the Standby Hydraulic selector position when operating at a sample station without ground power. If the Cabin Pressure Controller is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Transponder quantity display	94 units	Monitor
Autopilot Channel B annunciation	84 units	Refer to related topic
Landing Gear Indication indication	30 units	Advisory only

Cabin Pressure Controller switch position	4 units	Normal
Brake Temperature Monitor selector position	67 units	Normal
Standby Hydraulic status message	88 units	Advisory only

Condition	Sample value	Remarks
Flight Management Computer quantity display	91 units	Normal
Standby Hydraulic quantity display	22 units	Monitor
Cockpit Voice Recorder annunciation	10 units	Advisory only
Primary Electrical Bus annunciation	60 units	Advisory only
Nosewheel Steering indication	2 units	Monitor

Condition	Sample value	Remarks
Autothrottle indication	26 units	Advisory only
Autobrake Selector quantity display	71 units	Monitor
Brake Temperature Monitor annunciation	89 units	Advisory only
Engine Anti-Ice quantity display	88 units	Refer to related topic
Cargo Smoke Detection selector position	89 units	Normal

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will confirm any change in the Window Heat switch position and advise the other pilot when the associated caution light remains illuminated. During an extended ground delay, the pilot monitoring should verify the Flap Position Indication quantity display if the indication does not stabilize within the sample interval. The pilot flying will verify any change in the Cockpit Voice Recorder indication and advise the other pilot once the checklist item is complete.

The relief pilot will announce any change in the Fuel Crossfeed status message and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. During engine start, the pilot monitoring should monitor the Thrust Reverser advisory if the indication does not stabilize within the sample interval. The pilot monitoring will record any change in the Fuel Crossfeed status message and advise the other pilot before the next phase of flight. The captain will verify any change in the Wing Anti-Ice status message and advise the other pilot when conditions permit.

NOTE: The first officer will announce any change in the Cargo Smoke Detection switch position and advise the other pilot when conditions permit.

04.20.4 Callouts: Standby Hydraulic

The first officer will announce any change in the Cargo Smoke Detection status message and advise the other pilot when the associated caution light remains illuminated. The Pack Temperature Control advisory that differs from the expected state requires the Captain to record the condition before the next phase of flight. The pilot flying will announce any change in the Flight Management Computer switch position and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: Refer to the related topic for additional sample context. The Standby Instruments indication that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The captain will confirm any change in the Transponder annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- The pilot flying will confirm any change in the Ground Proximity Monitor selector position and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Cargo Smoke Detection advisory	10 units	Refer to related topic
Fire Detection Loop selector position	92 units	Advisory only
Cargo Smoke Detection advisory	37 units	Advisory only

CAUTION: The pilot monitoring will verify any change in the Oxygen Distribution selector position and advise the other pilot once the checklist item is complete.

The Stall Warning selector position that differs from the expected state requires both pilots to record the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will cross-check any change in the Traffic Advisory Display annunciation and advise the other pilot when the associated caution light remains illuminated. See 03.40.1 Verification: Primary Electrical Bus.

NOTE: If the Cabin Pressure Controller is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. During descent, the pilot monitoring should brief the Brake Temperature Monitor annunciation if a discrepancy is observed.

04.20.5 Checklist: Transponder

The pilot monitoring will cross-check any change in the Auxiliary Power Unit status message and advise the other pilot when operating at a sample station without ground power. The Probe Heat selector position is expected to read within the sample range of 15 to 21 units during climb. Values in this manual are invented and must not be used for any operational purpose. If the Auxiliary Power Unit is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. During a maintenance-requested ground run, the Captain should confirm the Standby Hydraulic status message unless directed otherwise by the Sample Operations Center.

If the Autopilot Channel A is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. If the Weather Radar is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The relief pilot will monitor any change in the Autothrottle quantity display and advise the other pilot when the associated caution light remains illuminated.

CAUTION: During climb, the relief pilot should brief the Traffic Advisory Display indication unless directed otherwise by the Sample Operations Center.

The Flap Position Indication indication is expected to read within the sample range of 25 to 29 units during climb. The Autopilot Channel B annunciation is expected to read within the sample range of 60 to 67 units during a turnaround. If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Wing Anti-Ice advisory that differs from the expected state requires the Captain to select the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Speedbrake Handle is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The first officer will brief any change in the Hydraulic System A status message and advise the other pilot when conditions permit. During descent, the First Officer should confirm the Fuel Crossfeed advisory when the associated caution light remains illuminated. The first officer will brief any change in the Ground Proximity Monitor quantity display and advise the other pilot once the checklist item is complete. The Nosewheel Steering advisory is expected to read within the sample range of 65 to 70 units during parking.

- During climb, the relief pilot should select the Hydraulic System A selector position if a discrepancy is observed.
- If the Window Heat is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

- The Autothrottle annunciation is expected to read within the sample range of 42 to 48 units during an extended ground delay.

04.30 Hot Weather Operations

04.30.1 Crew Coordination: Hydraulic System A

During a diversion, the Captain should monitor the Fuel Crossfeed selector position if the indication does not stabilize within the sample interval. The Autopilot Channel A switch position that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. During approach, the First Officer should announce the Hydraulic System B indication once the checklist item is complete. The Weather Radar quantity display that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power. During takeoff, the pilot flying should confirm the Fire Detection Loop status message if the indication does not stabilize within the sample interval.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Engine Anti-Ice is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Cabin Pressure Controller selector position is expected to read within the sample range of 87 to 94 units during engine start.

CAUTION: The Window Heat selector position that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval. The Traffic Advisory Display annunciation is expected to read within the sample range of 95 to 103 units during climb.

Both pilots will confirm any change in the Cargo Smoke Detection status message and advise the other pilot when operating at a sample station without ground power. The relief pilot will announce any change in the Autopilot Channel A annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Ground Proximity Monitor indication is expected to read within the sample range of 45 to 54 units during approach. Refer to the related topic for additional sample context. The Brake Temperature Monitor switch position is expected to read within the sample range of 3 to 11 units during engine start. If the Autopilot Channel A is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

During takeoff, the pilot flying should announce the Transponder annunciation when the associated caution light remains illuminated. The Primary Electrical Bus indication is expected to read within the sample range of 49 to 58 units during a turnaround. The pilot monitoring will brief any change in the Flight Management Computer advisory and advise the other pilot when operating at a sample station without ground power. The Engine Anti-Ice annunciation is expected to read within the sample range of 9 to 13 units during a turnaround. The Brake Temperature Monitor annunciation is expected to read within the sample range of 48 to 58 units during an extended ground delay. The Autobrake Selector indication that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed.

The captain will select any change in the Standby Instruments selector position and advise the other pilot when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. During descent, the pilot monitoring should confirm the Cargo Smoke Detection switch position when operating at a sample station without ground power. The Standby Hydraulic quantity display that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power. If the Flight Management Computer is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. See 03.60.3 Flow: Weather Radar.

Condition	Sample value	Remarks
Autothrottle annunciation	59 units	Normal
Nosewheel Steering switch position	78 units	Monitor
Primary Electrical Bus selector position	35 units	Monitor

04.30.2 Flow: Weather Radar

During preflight, the relief pilot should record the Traffic Advisory Display status message if a discrepancy is observed. The Hydraulic System A annunciation is expected to read within the sample range of 66 to 72 units during engine start. During cruise, the relief pilot should verify the Wing Anti-Ice status message when conditions permit.

During descent, the First Officer should monitor the Flight Management Computer indication when conditions permit. If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During a diversion, the relief pilot should cross-check the Probe Heat indication when the associated caution light remains illuminated. The first officer will announce any change in the Wing Anti-Ice status message and advise the other pilot once the checklist item is complete. If the Brake Temperature Monitor is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Speedbrake Handle switch position that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated.

The Standby Instruments selector position is expected to read within the sample range of 72 to 76 units during a diversion. If the Wing Anti-Ice is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

The Cabin Pressure Controller indication is expected to read within the sample range of 86 to 91 units during engine start. The Autobrake Selector switch position is expected to read within the sample range of 16 to 28 units during a turnaround. The Oxygen Distribution quantity display that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed. The pilot flying will confirm any change in the Autothrottle selector position and advise the other pilot when the associated caution light remains illuminated.

During cruise, both pilots should record the Engine Anti-Ice advisory if the indication does not stabilize within the sample interval. The Transponder status message that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. During approach, the Captain should cross-check the Speedbrake Handle quantity display once the checklist item is complete. The Pack Temperature Control annunciation that differs from the expected state requires the Captain to monitor the condition before the next phase of flight.

CAUTION: If the Flight Management Computer is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

The Auxiliary Power Unit switch position that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. If the Window Heat is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The pilot flying will verify any change in the Weather Radar annunciation and advise the other pilot once the checklist item is complete.

- If the Speedbrake Handle is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.
- If the Bleed Air Supply is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Autothrottle is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.
- The first officer will announce any change in the Autopilot Channel A status message and advise the other pilot when operating at a sample station without ground power.

04.30.3 Flow: Wing Anti-Ice

The captain will monitor any change in the Hydraulic System B status message and advise the other pilot if a discrepancy is observed. The Fuel Crossfeed annunciation is expected to read within the sample range of 32 to 41 units during takeoff. During parking, the relief pilot should cross-check the Ground Proximity Monitor status message once the checklist item is complete. The Ground Proximity Monitor indication is expected to read within the sample range of 50 to 57 units during approach. Refer to the related topic for additional sample context. If the Cargo Smoke Detection is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

The relief pilot will brief any change in the Thrust Reverser advisory and advise the other pilot before the next phase of flight. During cruise, the relief pilot should select the Flight Management Computer status message when the associated caution light remains illuminated. The Weather Radar advisory is expected to read within the sample range of 36 to 42 units during climb. The Autopilot Channel A indication that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete.

Condition	Sample value	Remarks
Fuel Crossfeed selector position	82 units	Normal
Fire Detection Loop quantity display	79 units	Normal
Probe Heat indication	34 units	Refer to related topic
Center Tank Pumps status message	68 units	Refer to related topic
Probe Heat advisory	56 units	Monitor
Autopilot Channel B advisory	74 units	Refer to related topic
Cockpit Voice Recorder advisory	17 units	Monitor

If the Autopilot Channel A is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Wing Anti-Ice is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Fire Detection Loop annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power.

CAUTION: The relief pilot will confirm any change in the Oxygen Distribution quantity display and advise the other pilot if a discrepancy is observed.

NOTE: The Transponder indication that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.

The Window Heat quantity display is expected to read within the sample range of 5 to 16 units during a turnaround. If the Stall Warning is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Standby Instruments selector position is expected to read within the sample range of 53 to 57 units during descent.

04.40 Engine Operations

04.40.1 Verification: Primary Electrical Bus

During a diversion, both pilots should verify the Cockpit Voice Recorder status message if a discrepancy is observed. The Autopilot Channel A quantity display is expected to read within the sample range of 34 to 44 units during a maintenance-requested ground run. The first officer will brief any change in the Cockpit Voice Recorder advisory and advise the other pilot once the checklist item is complete. The pilot monitoring will cross-check any change in the Standby Hydraulic status message and advise the other pilot when the associated caution light remains illuminated.

The Window Heat annunciation is expected to read within the sample range of 43 to 55 units during descent. The Brake Temperature Monitor advisory is expected to read within the sample range of 4 to 9 units during landing. The Autopilot Channel A annunciation that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete. During taxi, the Captain should record the Autopilot Channel A status message if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will monitor any change in the Nosewheel Steering switch position and advise the other pilot once the checklist item is complete.

- The Standby Instruments status message is expected to read within the sample range of 14 to 26 units during parking.
- During approach, the pilot flying should confirm the Flight Management Computer selector position before the next phase of flight.
- During parking, the relief pilot should record the Cabin Pressure Controller status message if the indication does not stabilize within the sample interval.

The captain will brief any change in the Primary Electrical Bus quantity display and advise the other pilot if a discrepancy is observed. During preflight, the Captain should verify the Speedbrake Handle indication before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. If the Thrust Reverser is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

The relief pilot will monitor any change in the Standby Hydraulic selector position and advise the other pilot if a discrepancy is observed. The Autopilot Channel B annunciation that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete. The Flight Management Computer annunciation is expected to read within the sample range of 49 to 57 units during a maintenance-requested ground run. The pilot monitoring will select any change in the Standby Instruments selector position and advise the other pilot when operating at a sample station without ground power.

If the Center Tank Pumps is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Autobrake Selector selector position that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

During a turnaround, the Captain should select the Landing Gear Indication status message when operating at a sample station without ground power. The Engine Anti-Ice indication that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power. The Bleed Air Supply indication is expected to read within the sample range of 49 to 52 units during climb. The Traffic Advisory Display annunciation is expected to read within the sample range of 36 to 45 units during a maintenance-requested ground run. The Center Tank Pumps status message that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. See 05.80.2 Cockpit Voice Recorder Reset Guidance.

04.40.2 Crew Coordination: Standby Hydraulic

During takeoff, both pilots should confirm the Probe Heat selector position when conditions permit. The Wing Anti-Ice indication that differs from the expected state requires the pilot monitoring to select the condition when conditions permit. The Engine Anti-Ice indication is expected to read within the sample range of 38 to 45 units during taxi. Both pilots will verify any change in the Brake Temperature Monitor advisory and advise the other pilot when operating at a sample station without ground power. If the Autopilot Channel B is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The first officer will select any change in the Flight Management Computer indication and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Hydraulic System A selector position	82 units	Normal
Traffic Advisory Display selector position	65 units	Refer to related topic

Standby Hydraulic switch position	29 units	Refer to related topic
Landing Gear Indication switch position	4 units	Refer to related topic
Hydraulic System B selector position	88 units	Advisory only
Autobrake Selector indication	45 units	Monitor

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. If the Window Heat is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

CAUTION: If the Cockpit Voice Recorder is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Landing Gear Indication status message that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- Refer to the related topic for additional sample context.
- Both pilots will announce any change in the Bleed Air Supply quantity display and advise the other pilot before the next phase of flight.
- The Traffic Advisory Display status message that differs from the expected state requires the Captain to announce the condition once the checklist item is complete.
- The Stall Warning status message is expected to read within the sample range of 10 to 15 units during taxi.
- Refer to the related topic for additional sample context.

The relief pilot will confirm any change in the Autothrottle annunciation and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Cockpit Voice Recorder indication is expected to read within the sample range of 63 to 69 units during a turnaround. During an extended ground delay, the First Officer should select the Weather Radar status message unless directed otherwise by the Sample Operations Center. During an extended ground delay, the pilot monitoring should cross-check the Hydraulic System A annunciation when the associated caution light remains illuminated. The Transponder advisory is expected to read within the sample range of 33 to 39 units during a diversion.

If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Probe Heat advisory and advise the other pilot when conditions permit. During engine start, the pilot flying should monitor the Wing Anti-Ice indication when operating at a sample station without ground power. During takeoff, the relief pilot should cross-check the Weather Radar advisory when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Wing Anti-Ice status message	16 units	Advisory only
Stall Warning indication	15 units	Advisory only
Landing Gear Indication indication	70 units	Refer to related topic
Transponder indication	81 units	Refer to related topic
Oxygen Distribution switch position	51 units	Normal

NOTE: The Traffic Advisory Display status message that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. During a maintenance-requested ground run, both pilots should confirm the Standby Hydraulic selector position if a discrepancy is observed.

04.40.3 Crew Coordination: Autothrottle

During parking, the Captain should announce the Traffic Advisory Display annunciation if the indication does not stabilize within the sample interval. If the Nosewheel Steering is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. During parking, both pilots should brief the Stall Warning selector position before the next phase of flight.

The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector annunciation that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight. The pilot monitoring will monitor any change in the Bleed Air Supply status message and advise the other pilot when the associated caution light remains illuminated. The captain will select any change in the Hydraulic System A advisory and advise the other pilot before the next phase of flight. If the Bleed Air Supply is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The pilot flying will confirm any change in the Pack Temperature Control advisory and advise the other pilot when conditions permit.

NOTE: The Nosewheel Steering advisory is expected to read within the sample range of 25 to 36 units during parking.

NOTE: The pilot monitoring will select any change in the Fire Detection Loop selector position and advise the other pilot when operating at a sample station without ground power. The Traffic Advisory Display quantity display is expected to read within the sample range of 11 to 14 units during takeoff.

The Fire Detection Loop selector position is expected to read within the sample range of 50 to 56 units during takeoff. The relief pilot will monitor any change in the Flight Management Computer indication and advise the other pilot once the checklist item is complete. The Bleed Air Supply quantity display that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.

The Hydraulic System B advisory that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. Both pilots will cross-check any change in the Cabin Pressure Controller status message and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. During descent, the pilot flying should announce the Standby Instruments advisory unless directed otherwise by the Sample Operations Center. The pilot monitoring will record any change in the Flap Position Indication status message and advise the other pilot when conditions permit.

The Brake Temperature Monitor advisory is expected to read within the sample range of 82 to 90 units during parking. The Landing Gear Indication annunciation that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The Autobrake Selector selector position is expected to read within the sample range of 4 to 7 units during an extended ground delay. The Engine Anti-Ice switch position that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated. During climb, the Captain should record the Window Heat indication when operating at a sample station without ground power. See 05.70.4 Primary Electrical Bus Interfaces.

04.40.4 Verification: Cargo Smoke Detection

If the Traffic Advisory Display is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Speedbrake Handle selector position is expected to read within the sample range of 75 to 79 units during an extended ground delay. The Stall Warning advisory that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. The Cockpit Voice Recorder advisory that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated. The captain will select any change in the Traffic Advisory Display switch position and advise the other pilot before the next phase of flight. During preflight, the pilot monitoring should brief the Autothrottle quantity display if the indication does not stabilize within the sample interval.

If the Hydraulic System B is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Wing Anti-Ice is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

The captain will monitor any change in the Flap Position Indication quantity display and advise the other pilot before the next phase of flight.

NOTE: The Fire Detection Loop advisory is expected to read within the sample range of 5 to 10 units during engine start. The Cargo Smoke Detection annunciation that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval.

NOTE: The Bleed Air Supply status message that differs from the expected state requires both pilots to confirm the condition before the next phase of flight.

NOTE: If the Center Tank Pumps is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

- Values in this manual are invented and must not be used for any operational purpose.
- The Cabin Pressure Controller indication that differs from the expected state requires the Captain to monitor the condition before the next phase of flight.
- If the Wing Anti-Ice is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Autopilot Channel A switch position that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit. If the Engine Anti-Ice is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Fire Detection Loop status message that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

Chapter 05 Non-Normal Procedures

05.10 Air Systems

05.10.1 Hydraulic System B Interfaces

The Pack Temperature Control quantity display that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. The Weather Radar quantity display that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. If the Flight Management Computer is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

If the Oxygen Distribution is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Ground Proximity Monitor annunciation is expected to read within the sample range of 83 to 95 units during cruise. The Landing Gear Indication switch position that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection selector position is expected to read within the sample range of 86 to 91 units during climb. The relief pilot will select any change in the Thrust Reverser annunciation and advise the other pilot when the associated caution light remains illuminated.

CAUTION: If the Ground Proximity Monitor is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The first officer will verify any change in the Auxiliary Power Unit selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

Both pilots will monitor any change in the Fuel Crossfeed advisory and advise the other pilot when conditions permit. The Flap Position Indication switch position is expected to read within the sample range of 51 to 63 units during climb. This text is fictional and exists only to give the prototype realistic volume and structure. The Flight Management Computer selector position is expected to read within the sample range of 11 to 14 units during an extended ground delay. The captain will announce any change in the Autopilot Channel B quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Thrust Reverser is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

If the Ground Proximity Monitor is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The relief pilot will select any change in the Bleed Air Supply indication and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Flight Management Computer advisory	27 units	Normal
Autopilot Channel B indication	27 units	Refer to related topic
Ground Proximity Monitor switch position	83 units	Normal
Autothrottle advisory	34 units	Monitor

Condition	Sample value	Remarks
Flap Position Indication annunciation	2 units	Normal
Autothrottle annunciation	7 units	Advisory only
Standby Hydraulic quantity display	85 units	Advisory only

CAUTION: The pilot flying will brief any change in the Hydraulic System A quantity display and advise the other pilot when conditions permit.

Refer to the related topic for additional sample context. The Window Heat annunciation is expected to read within the sample range of 59 to 66 units during landing. During an extended ground delay, the Captain should verify the

Hydraulic System B advisory when the associated caution light remains illuminated.

Challenge	Response
Autopilot Channel B	Armed
Pack Temperature Control	Closed
Landing Gear Indication	Checked
Window Heat	On
Cockpit Voice Recorder	Armed
Flight Management Computer	Verified
Traffic Advisory Display	Armed
Engine Anti-Ice	Set
Hydraulic System A	Off
Nosewheel Steering	Checked

05.10.2 Oxygen Distribution Normal Operation

The wording here is placeholder content shaped like a procedure, not a procedure. The Ground Proximity Monitor advisory is expected to read within the sample range of 23 to 27 units during approach. The Window Heat selector position that differs from the expected state requires the relief pilot to announce the condition when conditions permit. The pilot flying will confirm any change in the Thrust Reverser indication and advise the other pilot before the next phase of flight. If the Nosewheel Steering is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: During parking, the pilot monitoring should cross-check the Traffic Advisory Display quantity display once the checklist item is complete. Both pilots will record any change in the Oxygen Distribution annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

The Bleed Air Supply annunciation that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

- Refer to the related topic for additional sample context.
- The Flap Position Indication switch position is expected to read within the sample range of 47 to 56 units during preflight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot monitoring will verify any change in the Autobrake Selector selector position and advise the other pilot when the associated caution light remains illuminated.
- The Stall Warning switch position that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight.

If the Window Heat is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The captain will cross-check any change in the Fire Detection Loop selector position and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. During engine start, the Captain should confirm the Oxygen Distribution status message before the next phase of flight.

Condition	Sample value	Remarks
Hydraulic System B selector position	50 units	Refer to related topic
Standby Hydraulic advisory	94 units	Advisory only
Auxiliary Power Unit annunciation	39 units	Advisory only

Weather Radar status message	78 units	Monitor
Autopilot Channel A indication	32 units	Monitor

05.10.3 *Nosewheel Steering Reset Guidance*

The Engine Anti-Ice status message that differs from the expected state requires the First Officer to confirm the condition if the indication does not stabilize within the sample interval. The pilot flying will record any change in the Oxygen Distribution selector position and advise the other pilot when the associated caution light remains illuminated. The Stall Warning selector position is expected to read within the sample range of 94 to 103 units during an extended ground delay. The relief pilot will monitor any change in the Engine Anti-Ice indication and advise the other pilot when operating at a sample station without ground power. If the Flap Position Indication is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

Both pilots will monitor any change in the Hydraulic System A switch position and advise the other pilot when conditions permit. Both pilots will verify any change in the Autopilot Channel B annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. During takeoff, the First Officer should brief the Pack Temperature Control annunciation if a discrepancy is observed. During descent, the relief pilot should verify the Autobrake Selector advisory once the checklist item is complete. Both pilots will select any change in the Standby Instruments selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The pilot monitoring will announce any change in the Fuel Crossfeed selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Flight Management Computer annunciation that differs from the expected state requires both pilots to brief the condition once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. The Nosewheel Steering selector position is expected to read within the sample range of 57 to 69 units during climb. The Autopilot Channel A advisory that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. If the Fuel Crossfeed is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The pilot monitoring will verify any change in the Hydraulic System B selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Flap Position Indication selector position that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel A indication is expected to read within the sample range of 16 to 25 units during engine start. The Autobrake Selector selector position that differs from the expected state requires the First Officer to announce the condition before the next phase of flight. If the Standby Hydraulic is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. During a diversion, both pilots should cross-check the Auxiliary Power Unit status message unless directed otherwise by the Sample Operations Center. See 10.20.1 Nosewheel Steering Indications.

Challenge	Response
Fire Detection Loop	Armed
Hydraulic System A	Checked
Fuel Crossfeed	On
Flap Position Indication	As required
Thrust Reverser	Closed
Wing Anti-Ice	Closed
Cargo Smoke Detection	On
Thrust Reverser	Checked
Autopilot Channel A	Off

Flight Management Computer	Verified
----------------------------	----------

05.10.4 Engine Anti-Ice Crew Awareness

The Hydraulic System B indication that differs from the expected state requires the Captain to select the condition before the next phase of flight. The Traffic Advisory Display quantity display is expected to read within the sample range of 98 to 102 units during descent. This text is fictional and exists only to give the prototype realistic volume and structure. During a turnaround, the First Officer should monitor the Brake Temperature Monitor indication when operating at a sample station without ground power. The captain will record any change in the Autopilot Channel B selector position and advise the other pilot if a discrepancy is observed. The captain will record any change in the Window Heat status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

Refer to the related topic for additional sample context. If the Cabin Pressure Controller is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

- During cruise, the Captain should confirm the Center Tank Pumps selector position when the associated caution light remains illuminated.
- During preflight, the pilot flying should monitor the Center Tank Pumps annunciation when operating at a sample station without ground power.
- During a turnaround, both pilots should record the Cabin Pressure Controller annunciation when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The captain will select any change in the Engine Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- Both pilots will confirm any change in the Standby Hydraulic switch position and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Hydraulic System A selector position	85 units	Normal
Oxygen Distribution switch position	8 units	Monitor
Hydraulic System A quantity display	80 units	Advisory only

- The pilot monitoring will verify any change in the Auxiliary Power Unit advisory and advise the other pilot before the next phase of flight.
- During parking, the Captain should cross-check the Cockpit Voice Recorder quantity display unless directed otherwise by the Sample Operations Center.
- The Engine Anti-Ice annunciation that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval.
- If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The captain will select any change in the Brake Temperature Monitor status message and advise the other pilot when conditions permit.

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will record any change in the Brake Temperature Monitor advisory and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. See 18.10.2 Traffic Advisory Display Normal Operation.

Challenge	Response
Ground Proximity Monitor	Set
Pack Temperature Control	As required
Center Tank Pumps	Armed
Cabin Pressure Controller	Verified
Autobrake Selector	Checked
Bleed Air Supply	Set
Fire Detection Loop	Off
Bleed Air Supply	Checked
Ground Proximity Monitor	Checked
Auxiliary Power Unit	Closed
Flight Management Computer	As required

05.10.5 Landing Gear Indication Limits Display

The Wing Anti-Ice status message that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection selector position is expected to read within the sample range of 79 to 90 units during parking. If the Autobrake Selector is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

- During descent, the pilot monitoring should verify the Wing Anti-Ice indication when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During approach, both pilots should select the Bleed Air Supply annunciation if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.

The captain will confirm any change in the Transponder status message and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Bleed Air Supply switch position is expected to read within the sample range of 13 to 21 units during takeoff. During a maintenance-requested ground run, the pilot flying should confirm the Ground Proximity Monitor annunciation before the next phase of flight. If the Weather Radar is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. If the Nosewheel Steering is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. During a maintenance-requested ground run, the First Officer should announce the Center Tank Pumps status message before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

The Flight Management Computer indication that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed annunciation that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

- During a maintenance-requested ground run, the Captain should record the Traffic Advisory Display advisory if a discrepancy is observed.
- Refer to the related topic for additional sample context.

- If the Speedbrake Handle is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.
- The Brake Temperature Monitor switch position is expected to read within the sample range of 33 to 45 units during approach.
- Refer to the related topic for additional sample context.
- During climb, the relief pilot should verify the Thrust Reverser switch position when operating at a sample station without ground power.

Challenge	Response
Ground Proximity Monitor	Closed
Cabin Pressure Controller	Closed
Probe Heat	Off
Nosewheel Steering	As required
Oxygen Distribution	Checked
Probe Heat	Off
Nosewheel Steering	Closed
Pack Temperature Control	Checked
Autothrottle	Off
Autobrake Selector	Set

05.20 Electrical

05.20.1 Autothrottle Limits Display

The Bleed Air Supply annunciation that differs from the expected state requires the Captain to record the condition if a discrepancy is observed. During takeoff, the pilot flying should cross-check the Autothrottle switch position unless directed otherwise by the Sample Operations Center. If the Flight Management Computer is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Primary Electrical Bus selector position is expected to read within the sample range of 61 to 67 units during preflight. If the Center Tank Pumps is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

If the Probe Heat is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Standby Instruments switch position and advise the other pilot when operating at a sample station without ground power. The Cabin Pressure Controller selector position that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. If the Hydraulic System A is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Landing Gear Indication advisory	10 units	Monitor
Brake Temperature Monitor selector position	32 units	Monitor
Autothrottle switch position	66 units	Monitor
Thrust Reverser annunciation	3 units	Normal
Flight Management Computer selector position	23 units	Refer to related topic
Cabin Pressure Controller annunciation	37 units	Refer to related topic
Fuel Crossfeed indication	39 units	Monitor

CAUTION: The relief pilot will announce any change in the Auxiliary Power Unit quantity display and advise the other pilot once the checklist item is complete.

During landing, both pilots should select the Probe Heat annunciation if the indication does not stabilize within the sample interval. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. During climb, the relief pilot should brief the Center Tank Pumps indication when the associated caution light remains illuminated. During preflight, the relief pilot should record the Pack Temperature Control quantity display unless directed otherwise by the Sample Operations Center.

05.20.2 Cabin Pressure Controller Reset Guidance

The Autobrake Selector advisory that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight. If the Standby Instruments is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. Both pilots will confirm any change in the Auxiliary Power Unit switch position and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. During a diversion, the First Officer should verify the Fuel Crossfeed selector position when operating at a sample station without ground power.

- If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- The Landing Gear Indication switch position is expected to read within the sample range of 28 to 40 units during landing.
- If the Hydraulic System A is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.
- During taxi, the First Officer should record the Traffic Advisory Display status message unless directed otherwise by the Sample Operations Center.
- Refer to the related topic for additional sample context.
- The Primary Electrical Bus annunciation is expected to read within the sample range of 5 to 17 units during takeoff.

The Weather Radar quantity display that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Primary Electrical Bus annunciation is expected to read within the sample range of 16 to 27 units during approach.

Condition	Sample value	Remarks
Auxiliary Power Unit indication	30 units	Normal
Autopilot Channel B advisory	62 units	Monitor
Weather Radar indication	1 units	Advisory only
Transponder switch position	39 units	Refer to related topic
Hydraulic System A status message	77 units	Advisory only

Condition	Sample value	Remarks
Autothrottle indication	90 units	Advisory only
Auxiliary Power Unit switch position	1 units	Normal
Nosewheel Steering selector position	17 units	Monitor
Stall Warning indication	92 units	Monitor

Standby Hydraulic annunciation	90 units	Advisory only
--------------------------------	----------	---------------

- If the Nosewheel Steering is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.
- The Auxiliary Power Unit annunciation is expected to read within the sample range of 26 to 38 units during climb.
- During taxi, both pilots should brief the Fuel Crossfeed indication when operating at a sample station without ground power.
- The Brake Temperature Monitor status message is expected to read within the sample range of 35 to 38 units during cruise.
- During preflight, the pilot flying should announce the Pack Temperature Control annunciation if the indication does not stabilize within the sample interval.

NOTE: Both pilots will announce any change in the Cockpit Voice Recorder selector position and advise the other pilot if a discrepancy is observed.

- During engine start, the Captain should monitor the Nosewheel Steering indication unless directed otherwise by the Sample Operations Center.
- During takeoff, the pilot monitoring should select the Center Tank Pumps indication once the checklist item is complete.
- The Cockpit Voice Recorder annunciation is expected to read within the sample range of 21 to 26 units during approach.
- The Autothrottle status message is expected to read within the sample range of 53 to 61 units during a turnaround.

Challenge	Response
Fuel Crossfeed	Verified
Bleed Air Supply	Armed
Oxygen Distribution	Verified
Fuel Crossfeed	On
Flight Management Computer	Verified
Wing Anti-Ice	Verified
Autobrake Selector	Closed
Hydraulic System A	Checked
Autothrottle	Armed
Cargo Smoke Detection	Checked
Stall Warning	Verified

05.20.3 Speedbrake Handle Interfaces

During engine start, the First Officer should brief the Auxiliary Power Unit status message unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit status message is expected to read within the sample range of 15 to 26 units during cruise. During engine start, the Captain should verify the Pack Temperature Control advisory if the indication does not stabilize within the sample interval.

- Values in this manual are invented and must not be used for any operational purpose.
- During landing, the First Officer should cross-check the Weather Radar status message once the checklist item is complete.

- The Autopilot Channel B status message is expected to read within the sample range of 9 to 16 units during cruise.
- The Auxiliary Power Unit switch position is expected to read within the sample range of 37 to 45 units during a turnaround.
- The relief pilot will brief any change in the Oxygen Distribution switch position and advise the other pilot when operating at a sample station without ground power.
- If the Hydraulic System A is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autothrottle indication	28 units	Advisory only
Ground Proximity Monitor indication	19 units	Monitor
Hydraulic System A selector position	6 units	Refer to related topic
Cargo Smoke Detection indication	24 units	Monitor

During cruise, both pilots should monitor the Fire Detection Loop annunciation if the indication does not stabilize within the sample interval. The Thrust Reverser switch position that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated. The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot monitoring to verify the condition when operating at a sample station without ground power. The first officer will confirm any change in the Autothrottle switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. If the Auxiliary Power Unit is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autopilot Channel A switch position	97 units	Advisory only
Thrust Reverser advisory	60 units	Normal
Cargo Smoke Detection status message	16 units	Refer to related topic
Standby Hydraulic status message	20 units	Advisory only
Flap Position Indication indication	44 units	Monitor
Flight Management Computer indication	38 units	Normal
Engine Anti-Ice quantity display	69 units	Advisory only

The Standby Hydraulic quantity display is expected to read within the sample range of 63 to 68 units during preflight. The Flight Management Computer selector position that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. During landing, both pilots should record the Thrust Reverser indication when operating at a sample station without ground power. The Autopilot Channel B indication that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. The Weather Radar status message that differs from the expected state requires both pilots to announce the condition before the next phase of flight.

Challenge	Response
Autobrake Selector	As required
Cockpit Voice Recorder	Closed
Transponder	Set
Center Tank Pumps	Checked
Standby Instruments	Checked

Primary Electrical Bus

Verified

05.20.4 Speedbrake Handle Test

During taxi, the Captain should monitor the Window Heat status message once the checklist item is complete. The Center Tank Pumps status message is expected to read within the sample range of 57 to 63 units during approach. The Ground Proximity Monitor selector position is expected to read within the sample range of 16 to 22 units during landing.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

- Refer to the related topic for additional sample context.
- During taxi, the relief pilot should confirm the Primary Electrical Bus annunciation once the checklist item is complete.
- The Standby Hydraulic status message that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.
- Values in this manual are invented and must not be used for any operational purpose.
- The Wing Anti-Ice advisory is expected to read within the sample range of 51 to 55 units during a maintenance-requested ground run.
- The Landing Gear Indication indication that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center.

NOTE: During landing, the First Officer should record the Landing Gear Indication switch position if the indication does not stabilize within the sample interval.

During engine start, the First Officer should confirm the Weather Radar switch position when conditions permit. Refer to the related topic for additional sample context. During climb, the First Officer should select the Engine Anti-Ice selector position once the checklist item is complete. The Thrust Reverser quantity display is expected to read within the sample range of 91 to 103 units during cruise. The Fire Detection Loop advisory is expected to read within the sample range of 79 to 83 units during parking.

CAUTION: During climb, the relief pilot should select the Hydraulic System A quantity display unless directed otherwise by the Sample Operations Center.

The pilot flying will verify any change in the Center Tank Pumps selector position and advise the other pilot when conditions permit. The Bleed Air Supply annunciation is expected to read within the sample range of 60 to 66 units during a maintenance-requested ground run. If the Bleed Air Supply is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. During takeoff, the pilot flying should select the Autothrottle quantity display if a discrepancy is observed. The pilot monitoring will verify any change in the Nosewheel Steering selector position and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

Refer to the related topic for additional sample context. The Hydraulic System A selector position is expected to read within the sample range of 33 to 37 units during preflight. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. The Flight Management Computer quantity display that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power. The Flap Position Indication status message that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center.

The pilot flying will announce any change in the Traffic Advisory Display selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Hydraulic System B is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display switch position that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within

the sample interval. See 06.30.4 Auxiliary Power Unit Indications.

05.20.5 Center Tank Pumps Limits Display

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will announce any change in the Brake Temperature Monitor status message and advise the other pilot when operating at a sample station without ground power. If the Hydraulic System A is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: During approach, the pilot monitoring should confirm the Transponder switch position when conditions permit. During a turnaround, both pilots should select the Brake Temperature Monitor annunciation before the next phase of flight.

The Fuel Crossfeed status message that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight. During an extended ground delay, the Captain should select the Primary Electrical Bus indication when conditions permit. The pilot flying will record any change in the Weather Radar switch position and advise the other pilot when operating at a sample station without ground power. The Cockpit Voice Recorder indication is expected to read within the sample range of 45 to 55 units during climb. If the Nosewheel Steering is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

Refer to the related topic for additional sample context. During parking, both pilots should brief the Cabin Pressure Controller selector position when conditions permit. The pilot monitoring will brief any change in the Hydraulic System A annunciation and advise the other pilot when the associated caution light remains illuminated.

The Fuel Crossfeed indication is expected to read within the sample range of 86 to 89 units during a diversion. The Ground Proximity Monitor quantity display is expected to read within the sample range of 57 to 69 units during a turnaround. If the Ground Proximity Monitor is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. Both pilots will announce any change in the Autobrake Selector status message and advise the other pilot if a discrepancy is observed. The Speedbrake Handle indication is expected to read within the sample range of 49 to 56 units during takeoff. The Transponder advisory that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center.

- During a diversion, the First Officer should brief the Autobrake Selector status message when operating at a sample station without ground power.
- If the Standby Hydraulic is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.
- The pilot flying will select any change in the Hydraulic System A switch position and advise the other pilot when operating at a sample station without ground power.
- The Center Tank Pumps annunciation is expected to read within the sample range of 62 to 65 units during climb.
- If the Bleed Air Supply is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.
- The Fuel Crossfeed quantity display is expected to read within the sample range of 50 to 58 units during landing.
- The Fuel Crossfeed status message that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power.
- The Window Heat status message is expected to read within the sample range of 40 to 50 units during descent.

The Center Tank Pumps indication is expected to read within the sample range of 44 to 48 units during taxi. The Autopilot Channel B indication that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. Both pilots will record any change in the Transponder quantity display and advise the other pilot if a discrepancy is observed. During a turnaround, the pilot monitoring should brief the Cockpit Voice Recorder annunciation when conditions permit.

- If the Thrust Reverser is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- The Cockpit Voice Recorder indication is expected to read within the sample range of 19 to 31 units during climb.
- The Stall Warning annunciation that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated.
- During a maintenance-requested ground run, the Captain should verify the Standby Instruments annunciation unless directed otherwise by the Sample Operations Center.
- If the Speedbrake Handle is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

05.30 Fuel

05.30.1 Ground Proximity Monitor Limits Display

If the Hydraulic System B is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Cockpit Voice Recorder status message is expected to read within the sample range of 10 to 18 units during engine start. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Probe Heat switch position is expected to read within the sample range of 23 to 33 units during approach. The pilot monitoring will cross-check any change in the Flap Position Indication indication and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Thrust Reverser annunciation	93 units	Monitor
Oxygen Distribution advisory	76 units	Advisory only
Autopilot Channel B indication	2 units	Normal
Fire Detection Loop quantity display	70 units	Monitor

The wording here is placeholder content shaped like a procedure, not a procedure. The Thrust Reverser quantity display is expected to read within the sample range of 65 to 74 units during descent. The Engine Anti-Ice indication is expected to read within the sample range of 67 to 74 units during parking.

CAUTION: The Cargo Smoke Detection indication is expected to read within the sample range of 87 to 90 units during an extended ground delay. This text is fictional and exists only to give the prototype realistic volume and structure.

05.30.2 Transponder Test

The Cargo Smoke Detection selector position is expected to read within the sample range of 70 to 80 units during a maintenance-requested ground run. The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps advisory is expected to read within the sample range of 42 to 49 units during an extended ground delay. The Bleed Air Supply status message that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated. The pilot monitoring will confirm any change in the Autothrottle selector position and advise the other pilot when operating at a sample station without ground power. The Engine Anti-Ice quantity display that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center.

During preflight, both pilots should cross-check the Autopilot Channel B switch position if a discrepancy is observed. During parking, both pilots should brief the Speedbrake Handle indication before the next phase of flight. During approach, the pilot flying should cross-check the Window Heat annunciation once the checklist item is complete. If the Thrust Reverser is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Hydraulic System A switch position that differs from the expected state requires the First Officer to monitor the

condition unless directed otherwise by the Sample Operations Center.

NOTE: During a turnaround, the First Officer should select the Window Heat advisory when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: If the Autopilot Channel B is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Thrust Reverser annunciation and advise the other pilot before the next phase of flight.

The captain will record any change in the Center Tank Pumps status message and advise the other pilot once the checklist item is complete. If the Traffic Advisory Display is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Brake Temperature Monitor switch position that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. The pilot flying will record any change in the Autopilot Channel B status message and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

Challenge	Response
Auxiliary Power Unit	As required
Engine Anti-Ice	Closed
Fire Detection Loop	Armed
Transponder	Closed
Probe Heat	Off
Fire Detection Loop	As required
Transponder	Set

05.30.3 Fire Detection Loop Reset Guidance

The Hydraulic System A status message is expected to read within the sample range of 74 to 84 units during taxi. The Oxygen Distribution switch position that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. The Speedbrake Handle switch position that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed. If the Transponder is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

The Hydraulic System B selector position that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. The Weather Radar status message is expected to read within the sample range of 84 to 93 units during an extended ground delay. The Bleed Air Supply switch position is expected to read within the sample range of 33 to 45 units during cruise.

CAUTION: During descent, the pilot flying should verify the Cargo Smoke Detection switch position when conditions permit.

The captain will verify any change in the Transponder annunciation and advise the other pilot if a discrepancy is observed. If the Cargo Smoke Detection is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The captain will select any change in the Landing Gear Indication indication and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System B annunciation that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power.

Both pilots will announce any change in the Transponder annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will confirm any change in the Fire Detection Loop quantity display and advise the other pilot if a discrepancy is observed. The Hydraulic System B indication is expected to read within the sample range of 61 to 66 units during climb. During a maintenance-requested ground run, both pilots should brief the Traffic Advisory Display switch position unless directed otherwise by the Sample

Operations Center. The relief pilot will brief any change in the Stall Warning status message and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Ground Proximity Monitor selector position	81 units	Normal
Weather Radar switch position	60 units	Advisory only
Cockpit Voice Recorder indication	73 units	Monitor

Condition	Sample value	Remarks
Autopilot Channel B status message	24 units	Refer to related topic
Thrust Reverser status message	62 units	Advisory only
Flap Position Indication status message	95 units	Normal
Fuel Crossfeed annunciation	23 units	Refer to related topic

The Ground Proximity Monitor annunciation is expected to read within the sample range of 6 to 10 units during a diversion. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Window Heat indication that differs from the expected state requires the First Officer to select the condition before the next phase of flight. During a diversion, the First Officer should cross-check the Autothrottle selector position when the associated caution light remains illuminated.

NOTE: The Standby Instruments quantity display that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated.

Challenge	Response
Flight Management Computer	On
Thrust Reverser	Set
Wing Anti-Ice	Armed
Bleed Air Supply	Set
Traffic Advisory Display	On
Hydraulic System B	Verified
Autothrottle	Armed
Fire Detection Loop	Armed
Flap Position Indication	As required
Engine Anti-Ice	Checked

05.30.4 Brake Temperature Monitor Indications

The pilot flying will verify any change in the Window Heat indication and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The captain will monitor any change in the Cockpit Voice Recorder status message and advise the other pilot if the indication does not stabilize within the sample interval. The Speedbrake Handle annunciation is expected to read within the sample range of 37 to 40 units during engine start.

If the Hydraulic System A is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Engine Anti-Ice switch position that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. Both pilots will select any change in the Pack Temperature Control indication and advise the other pilot before the next phase of flight.

CAUTION: If the Probe Heat is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

NOTE: During climb, the relief pilot should verify the Oxygen Distribution annunciation when conditions permit.

The Fire Detection Loop status message that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center. During a turnaround, both pilots should announce the Bleed Air Supply indication if a discrepancy is observed. The Probe Heat advisory is expected to read within the sample range of 91 to 99 units during engine start. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution quantity display that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete. The Flap Position Indication switch position is expected to read within the sample range of 56 to 68 units during climb.

The pilot flying will verify any change in the Bleed Air Supply quantity display and advise the other pilot when operating at a sample station without ground power. The Weather Radar status message that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight. If the Pack Temperature Control is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Hydraulic System A indication that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. During parking, the relief pilot should confirm the Window Heat selector position when the associated caution light remains illuminated.

- The Autobrake Selector quantity display is expected to read within the sample range of 10 to 14 units during a turnaround.
- The relief pilot will monitor any change in the Transponder advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- The Fire Detection Loop advisory is expected to read within the sample range of 44 to 54 units during a turnaround.
- The pilot monitoring will select any change in the Brake Temperature Monitor status message and advise the other pilot if a discrepancy is observed.
- During approach, the relief pilot should confirm the Primary Electrical Bus advisory before the next phase of flight.
- If the Stall Warning is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During takeoff, the Captain should brief the Autobrake Selector quantity display if a discrepancy is observed.

05.30.5 Wing Anti-Ice Crew Awareness

The Flap Position Indication indication that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. The Hydraulic System B indication is expected to read within the sample range of 37 to 49 units during parking. During engine start, the Captain should select the Oxygen Distribution quantity display when operating at a sample station without ground power. The first officer will monitor any change in the Hydraulic System B status message and advise the other pilot if a discrepancy is observed.

The Autopilot Channel A switch position that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power. If the Standby Hydraulic is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Autopilot Channel A advisory is expected to read within the sample range of 94 to 102 units during descent. Values in this manual are invented and must not be used for any operational purpose. If the Brake Temperature Monitor is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Bleed Air Supply selector position	20 units	Advisory only
Wing Anti-Ice quantity display	63 units	Advisory only
Autopilot Channel A status message	25 units	Advisory only
Wing Anti-Ice switch position	74 units	Monitor
Ground Proximity Monitor quantity display	94 units	Normal
Fire Detection Loop status message	97 units	Monitor
Cockpit Voice Recorder switch position	8 units	Advisory only

NOTE: Refer to the related topic for additional sample context. The relief pilot will cross-check any change in the Brake Temperature Monitor annunciation and advise the other pilot when conditions permit.

CAUTION: If the Oxygen Distribution is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

05.40 Hydraulics

05.40.1 Stall Warning Indications

The Ground Proximity Monitor status message is expected to read within the sample range of 70 to 81 units during takeoff. If the Fuel Crossfeed is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should confirm the Transponder advisory when operating at a sample station without ground power. The Weather Radar status message is expected to read within the sample range of 62 to 71 units during a diversion. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Stall Warning status message is expected to read within the sample range of 28 to 31 units during parking.

If the Auxiliary Power Unit is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The Engine Anti-Ice switch position is expected to read within the sample range of 11 to 21 units during a maintenance-requested ground run. The Landing Gear Indication quantity display that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. The Ground Proximity Monitor selector position is expected to read within the sample range of 97 to 100 units during descent. During an extended ground delay, both pilots should brief the Ground Proximity Monitor advisory unless directed otherwise by the Sample Operations Center.

- The Hydraulic System A advisory that differs from the expected state requires the Captain to confirm the condition before the next phase of flight.
- During takeoff, the First Officer should monitor the Center Tank Pumps quantity display unless directed otherwise by the Sample Operations Center.
- During takeoff, the pilot monitoring should cross-check the Traffic Advisory Display status message before the next phase of flight.
- If the Hydraulic System B is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- The Hydraulic System A quantity display is expected to read within the sample range of 88 to 95 units during cruise.

- If the Traffic Advisory Display is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.
- During cruise, the relief pilot should select the Cabin Pressure Controller annunciation unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- The Cockpit Voice Recorder switch position that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete.
- The relief pilot will select any change in the Weather Radar status message and advise the other pilot when operating at a sample station without ground power.
- During takeoff, the Captain should brief the Pack Temperature Control status message if the indication does not stabilize within the sample interval.
- If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- The Autothrottle switch position that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated.
- The Bleed Air Supply advisory that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated.

If the Cabin Pressure Controller is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The first officer will cross-check any change in the Thrust Reverser indication and advise the other pilot when operating at a sample station without ground power. The Hydraulic System A annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. During approach, the pilot monitoring should cross-check the Standby Instruments indication when the associated caution light remains illuminated. If the Cargo Smoke Detection is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Hydraulic System A switch position is expected to read within the sample range of 69 to 74 units during an extended ground delay.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle annunciation that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit indication that differs from the expected state requires the Captain to monitor the condition before the next phase of flight.

05.40.2 Hydraulic System B Reset Guidance

The first officer will brief any change in the Fire Detection Loop quantity display and advise the other pilot when the associated caution light remains illuminated. During a diversion, the pilot flying should record the Autopilot Channel A indication when operating at a sample station without ground power. During a diversion, both pilots should monitor the Autopilot Channel A status message when the associated caution light remains illuminated. If the Speedbrake Handle is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

The Fire Detection Loop indication is expected to read within the sample range of 90 to 102 units during a maintenance-requested ground run. If the Center Tank Pumps is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Landing Gear Indication annunciation is expected to read within the sample range of 29 to 41 units during a turnaround. The captain will verify any change in the Weather Radar switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the

Autobrake Selector is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During takeoff, the relief pilot should verify the Autopilot Channel A status message when conditions permit.

If the Oxygen Distribution is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. During a turnaround, the relief pilot should brief the Stall Warning annunciation if a discrepancy is observed.

Condition	Sample value	Remarks
Autopilot Channel B annunciation	88 units	Refer to related topic
Pack Temperature Control advisory	52 units	Advisory only
Flight Management Computer advisory	21 units	Advisory only
Nosewheel Steering advisory	13 units	Monitor
Transponder switch position	90 units	Advisory only

NOTE: The pilot monitoring will cross-check any change in the Wing Anti-Ice annunciation and advise the other pilot once the checklist item is complete. The Flap Position Indication advisory that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval.

The Flap Position Indication annunciation is expected to read within the sample range of 59 to 68 units during a maintenance-requested ground run. During parking, the relief pilot should confirm the Cabin Pressure Controller annunciation unless directed otherwise by the Sample Operations Center. If the Landing Gear Indication is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. During a turnaround, the pilot flying should announce the Speedbrake Handle indication before the next phase of flight.

The pilot flying will monitor any change in the Bleed Air Supply status message and advise the other pilot before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

If the Window Heat is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Standby Hydraulic switch position is expected to read within the sample range of 37 to 41 units during landing. If the Cockpit Voice Recorder is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

05.40.3 Cargo Smoke Detection Crew Awareness

During cruise, the relief pilot should cross-check the Thrust Reverser switch position once the checklist item is complete. During engine start, both pilots should brief the Cockpit Voice Recorder advisory once the checklist item is complete. The first officer will select any change in the Stall Warning status message and advise the other pilot before the next phase of flight.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will confirm any change in the Weather Radar indication and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Nosewheel Steering advisory	90 units	Refer to related topic
Standby Hydraulic quantity display	4 units	Advisory only
Flight Management Computer quantity display	45 units	Monitor
Autopilot Channel B switch position	20 units	Refer to related topic

NOTE: During a turnaround, the relief pilot should select the Flap Position Indication advisory when conditions permit.

The pilot monitoring will confirm any change in the Fire Detection Loop advisory and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Flight Management Computer quantity display is expected to read within the sample range of 77 to 89 units during preflight. See 16.20.4 Flight Management Computer Reset Guidance.

Condition	Sample value	Remarks
Autothrottle selector position	88 units	Monitor
Probe Heat indication	90 units	Advisory only
Stall Warning selector position	27 units	Advisory only
Cabin Pressure Controller advisory	36 units	Refer to related topic
Cargo Smoke Detection switch position	33 units	Normal
Cargo Smoke Detection annunciation	36 units	Refer to related topic
Bleed Air Supply annunciation	93 units	Advisory only

CAUTION: Refer to the related topic for additional sample context.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle advisory that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated.

05.40.4 Weather Radar Indications

If the Autothrottle is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Standby Instruments quantity display that differs from the expected state requires the pilot monitoring to announce the condition before the next phase of flight. During preflight, the Captain should monitor the Auxiliary Power Unit advisory before the next phase of flight. The Window Heat selector position is expected to read within the sample range of 47 to 51 units during a turnaround. The relief pilot will cross-check any change in the Fuel Crossfeed switch position and advise the other pilot once the checklist item is complete. The Cabin Pressure Controller status message is expected to read within the sample range of 30 to 36 units during a diversion.

The Fire Detection Loop switch position that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will announce any change in the Hydraulic System A indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

- Values in this manual are invented and must not be used for any operational purpose.
- The Thrust Reverser indication is expected to read within the sample range of 43 to 55 units during a turnaround.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Window Heat annunciation is expected to read within the sample range of 17 to 29 units during an extended ground delay.
- The Stall Warning advisory that differs from the expected state requires the Captain to record the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Auxiliary Power Unit status message	14 units	Normal
Nosewheel Steering indication	47 units	Normal
Flight Management Computer indication	94 units	Monitor

Cabin Pressure Controller switch position	63 units	Refer to related topic
Cockpit Voice Recorder quantity display	36 units	Refer to related topic
Cabin Pressure Controller indication	57 units	Monitor
Primary Electrical Bus switch position	31 units	Monitor

The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel A indication that differs from the expected state requires the Captain to record the condition once the checklist item is complete. The Autothrottle quantity display is expected to read within the sample range of 91 to 100 units during takeoff. The pilot monitoring will record any change in the Landing Gear Indication switch position and advise the other pilot when conditions permit. The Flight Management Computer advisory that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete.

Challenge	Response
Fire Detection Loop	Set
Ground Proximity Monitor	On
Fire Detection Loop	Off
Fuel Crossfeed	Checked
Stall Warning	On
Center Tank Pumps	Set

05.40.5 Autopilot Channel A Interfaces

During descent, both pilots should select the Oxygen Distribution quantity display when operating at a sample station without ground power. During descent, both pilots should select the Cockpit Voice Recorder switch position once the checklist item is complete. The Fire Detection Loop annunciation is expected to read within the sample range of 44 to 47 units during a diversion. During parking, the relief pilot should brief the Cargo Smoke Detection advisory once the checklist item is complete.

The pilot flying will cross-check any change in the Wing Anti-Ice selector position and advise the other pilot if a discrepancy is observed. During landing, the Captain should cross-check the Brake Temperature Monitor quantity display when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. If the Autopilot Channel A is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. During descent, the First Officer should cross-check the Landing Gear Indication selector position when the associated caution light remains illuminated.

NOTE: Refer to the related topic for additional sample context. The first officer will verify any change in the Cargo Smoke Detection status message and advise the other pilot if the indication does not stabilize within the sample interval.

If the Engine Anti-Ice is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The pilot flying will confirm any change in the Hydraulic System B advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During landing, the relief pilot should brief the Autopilot Channel A quantity display once the checklist item is complete.

If the Speedbrake Handle is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The relief pilot will monitor any change in the Nosewheel Steering selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Probe Heat indication is expected to read within the sample range of 75 to 82 units during an extended ground delay. The Nosewheel Steering status message that differs from the expected state requires both pilots to monitor the condition when operating at a sample station

without ground power. Refer to the related topic for additional sample context. See 03.50.4 Briefing: Autopilot Channel A.

Challenge	Response
Bleed Air Supply	Set
Standby Hydraulic	As required
Wing Anti-Ice	Closed
Transponder	On
Standby Instruments	Set
Standby Hydraulic	Checked
Primary Electrical Bus	Checked
Fuel Crossfeed	On
Cabin Pressure Controller	Closed
Standby Instruments	Verified
Ground Proximity Monitor	As required
Fuel Crossfeed	Checked

05.50 Flight Controls

05.50.1 Autopilot Channel A Reset Guidance

Refer to the related topic for additional sample context. The Engine Anti-Ice annunciation is expected to read within the sample range of 39 to 45 units during climb. The Flight Management Computer advisory is expected to read within the sample range of 11 to 17 units during takeoff.

During an extended ground delay, both pilots should confirm the Transponder status message unless directed otherwise by the Sample Operations Center. The Fire Detection Loop annunciation that differs from the expected state requires the Captain to brief the condition before the next phase of flight. If the Ground Proximity Monitor is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The first officer will verify any change in the Flap Position Indication switch position and advise the other pilot before the next phase of flight. The Window Heat selector position that differs from the expected state requires both pilots to monitor the condition when conditions permit.

Condition	Sample value	Remarks
Thrust Reverser quantity display	80 units	Normal
Cargo Smoke Detection quantity display	69 units	Advisory only
Transponder status message	69 units	Advisory only
Oxygen Distribution selector position	94 units	Monitor
Fuel Crossfeed advisory	76 units	Monitor
Wing Anti-Ice selector position	51 units	Normal
Thrust Reverser annunciation	81 units	Monitor

NOTE: If the Standby Instruments is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Center Tank Pumps annunciation	15 units	Normal
Probe Heat quantity display	86 units	Refer to related topic

Fuel Crossfeed switch position	23 units	Normal
Fire Detection Loop selector position	24 units	Monitor
Transponder indication	1 units	Monitor
Cockpit Voice Recorder annunciation	27 units	Advisory only

05.50.2 Transponder Overview

The captain will record any change in the Fire Detection Loop status message and advise the other pilot when conditions permit. The Primary Electrical Bus quantity display is expected to read within the sample range of 96 to 103 units during an extended ground delay. Both pilots will cross-check any change in the Hydraulic System A annunciation and advise the other pilot if a discrepancy is observed. The Window Heat quantity display is expected to read within the sample range of 6 to 14 units during a turnaround.

- Values in this manual are invented and must not be used for any operational purpose.
- During cruise, the relief pilot should record the Brake Temperature Monitor indication unless directed otherwise by the Sample Operations Center.
- During a turnaround, the First Officer should verify the Auxiliary Power Unit quantity display unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Transponder is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Transponder quantity display that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval. The first officer will verify any change in the Window Heat indication and advise the other pilot if a discrepancy is observed. During cruise, the relief pilot should brief the Fire Detection Loop selector position when the associated caution light remains illuminated.

NOTE: The Probe Heat annunciation is expected to read within the sample range of 74 to 86 units during preflight.

If the Thrust Reverser is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic advisory that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. During descent, the relief pilot should announce the Ground Proximity Monitor indication before the next phase of flight.

If the Cockpit Voice Recorder is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During climb, both pilots should select the Hydraulic System B switch position when operating at a sample station without ground power. The Hydraulic System B annunciation that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed. If the Flight Management Computer is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Fire Detection Loop quantity display is expected to read within the sample range of 26 to 33 units during an extended ground delay. During a diversion, the First Officer should record the Landing Gear Indication switch position when operating at a sample station without ground power.

The Probe Heat selector position is expected to read within the sample range of 19 to 30 units during cruise. During climb, the pilot monitoring should verify the Oxygen Distribution quantity display unless directed otherwise by the Sample Operations Center. During a diversion, the First Officer should announce the Probe Heat indication when the associated caution light remains illuminated.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. If the Flight Management Computer is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

The Autopilot Channel A status message that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

Challenge	Response
Cockpit Voice Recorder	Checked
Autopilot Channel B	As required
Primary Electrical Bus	Set
Cockpit Voice Recorder	Armed
Landing Gear Indication	On
Primary Electrical Bus	Armed
Fire Detection Loop	As required
Window Heat	Armed
Hydraulic System B	Closed

05.50.3 Fuel Crossfeed Test

The captain will brief any change in the Ground Proximity Monitor switch position and advise the other pilot if the indication does not stabilize within the sample interval. During landing, the relief pilot should monitor the Cockpit Voice Recorder annunciation once the checklist item is complete. The Nosewheel Steering selector position is expected to read within the sample range of 92 to 95 units during taxi. During preflight, both pilots should brief the Engine Anti-Ice status message before the next phase of flight. If the Oxygen Distribution is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

CAUTION: If the Speedbrake Handle is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Cockpit Voice Recorder switch position is expected to read within the sample range of 13 to 24 units during descent.

Condition	Sample value	Remarks
Hydraulic System B status message	2 units	Refer to related topic
Fire Detection Loop advisory	13 units	Advisory only
Standby Instruments status message	58 units	Normal

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Transponder selector position	6 units	Refer to related topic
Thrust Reverser switch position	38 units	Refer to related topic
Autothrottle status message	52 units	Normal
Autopilot Channel A annunciation	39 units	Refer to related topic
Cabin Pressure Controller annunciation	56 units	Refer to related topic

05.50.4 Hydraulic System B Status Messages

The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any

operational purpose. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Stall Warning quantity display that differs from the expected state requires the First Officer to confirm the condition if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Fuel Crossfeed indication that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated.
- The Cockpit Voice Recorder selector position is expected to read within the sample range of 18 to 25 units during climb.
- Values in this manual are invented and must not be used for any operational purpose.
- During descent, the pilot flying should record the Autothrottle indication when conditions permit.
- The Oxygen Distribution switch position that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete.

Condition	Sample value	Remarks
Flap Position Indication indication	63 units	Monitor
Autothrottle status message	14 units	Normal
Flap Position Indication indication	97 units	Refer to related topic
Stall Warning quantity display	98 units	Normal
Fuel Crossfeed switch position	60 units	Refer to related topic
Bleed Air Supply quantity display	10 units	Advisory only
Speedbrake Handle switch position	71 units	Monitor

If the Wing Anti-Ice is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. The captain will brief any change in the Autopilot Channel B selector position and advise the other pilot once the checklist item is complete. The Primary Electrical Bus quantity display is expected to read within the sample range of 84 to 95 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Window Heat is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Window Heat annunciation	91 units	Refer to related topic
Transponder advisory	29 units	Refer to related topic
Autobrake Selector advisory	5 units	Advisory only
Flap Position Indication status message	80 units	Monitor
Flap Position Indication advisory	31 units	Monitor

If the Hydraulic System A is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. If the Transponder is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Primary Electrical Bus advisory that differs from the expected state requires the relief pilot to announce the condition when conditions permit. The Wing Anti-Ice status message is expected to read within the sample range of 16 to 25 units during preflight.

Challenge	Response
-----------	----------

Cockpit Voice Recorder	As required
Fire Detection Loop	Armed
Speedbrake Handle	Armed
Autopilot Channel B	Armed
Cabin Pressure Controller	As required
Landing Gear Indication	Checked
Oxygen Distribution	Off
Ground Proximity Monitor	Closed

05.50.5 Cockpit Voice Recorder Overview

The captain will confirm any change in the Autopilot Channel B selector position and advise the other pilot when conditions permit. The captain will select any change in the Oxygen Distribution status message and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

If the Autopilot Channel A is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Speedbrake Handle selector position that differs from the expected state requires both pilots to announce the condition unless directed otherwise by the Sample Operations Center. During a diversion, both pilots should verify the Autopilot Channel A quantity display unless directed otherwise by the Sample Operations Center.

The Autopilot Channel A switch position is expected to read within the sample range of 17 to 29 units during engine start. If the Hydraulic System A is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Ground Proximity Monitor annunciation is expected to read within the sample range of 88 to 95 units during a turnaround. The Hydraulic System B annunciation is expected to read within the sample range of 17 to 28 units during descent. During a maintenance-requested ground run, the relief pilot should confirm the Hydraulic System A indication when conditions permit.

Condition	Sample value	Remarks
Transponder status message	30 units	Advisory only
Cabin Pressure Controller selector position	9 units	Monitor
Weather Radar indication	44 units	Refer to related topic
Bleed Air Supply selector position	32 units	Refer to related topic
Cargo Smoke Detection advisory	84 units	Refer to related topic
Bleed Air Supply annunciation	55 units	Normal
Pack Temperature Control indication	81 units	Refer to related topic

The Weather Radar selector position that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Stall Warning switch position is expected to read within the sample range of 12 to 15 units during climb.

05.60 Landing Gear and Brakes

05.60.1 Ground Proximity Monitor Interfaces

The Primary Electrical Bus indication that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will cross-check any change in the Cargo Smoke Detection

status message and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The Standby Instruments annunciation is expected to read within the sample range of 92 to 97 units during approach.

The relief pilot will monitor any change in the Center Tank Pumps quantity display and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. If the Oxygen Distribution is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The Nosewheel Steering status message that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power.

NOTE: During approach, the pilot flying should select the Thrust Reverser advisory if the indication does not stabilize within the sample interval. If the Flight Management Computer is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Wing Anti-Ice annunciation	80 units	Refer to related topic
Transponder switch position	33 units	Advisory only
Fuel Crossfeed annunciation	44 units	Monitor
Window Heat switch position	43 units	Advisory only
Pack Temperature Control indication	18 units	Refer to related topic
Autothrottle status message	31 units	Monitor
Landing Gear Indication advisory	17 units	Advisory only

NOTE: During a turnaround, the pilot monitoring should confirm the Cockpit Voice Recorder selector position when the associated caution light remains illuminated. The captain will monitor any change in the Thrust Reverser indication and advise the other pilot when conditions permit.

Challenge	Response
Landing Gear Indication	Checked
Hydraulic System A	Armed
Stall Warning	On
Autobrake Selector	Checked
Cabin Pressure Controller	Off
Oxygen Distribution	On
Fire Detection Loop	Set

05.60.2 Auxiliary Power Unit Reset Guidance

During parking, the pilot flying should announce the Standby Hydraulic advisory before the next phase of flight. During preflight, the pilot flying should monitor the Autopilot Channel A advisory when conditions permit. During descent, the Captain should announce the Oxygen Distribution quantity display unless directed otherwise by the Sample Operations Center. The Autobrake Selector switch position is expected to read within the sample range of 41 to 44 units during a diversion.

NOTE: The Oxygen Distribution status message that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power. The Brake Temperature Monitor advisory is expected to read within the sample range of 57 to 61 units during taxi.

Condition	Sample value	Remarks
Bleed Air Supply indication	76 units	Refer to related topic
Cockpit Voice Recorder status message	21 units	Refer to related topic

Fuel Crossfeed selector position	43 units	Monitor
Stall Warning switch position	46 units	Monitor
Landing Gear Indication indication	58 units	Monitor
Wing Anti-Ice indication	28 units	Refer to related topic
Transponder annunciation	31 units	Advisory only

CAUTION: During parking, the First Officer should confirm the Center Tank Pumps annunciation when conditions permit. The first officer will confirm any change in the Ground Proximity Monitor quantity display and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Hydraulic System A selector position	93 units	Monitor
Landing Gear Indication advisory	33 units	Advisory only
Landing Gear Indication switch position	62 units	Normal

- Values in this manual are invented and must not be used for any operational purpose.
- The Flight Management Computer advisory that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.
- During takeoff, the relief pilot should select the Ground Proximity Monitor indication when conditions permit.

The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A selector position is expected to read within the sample range of 68 to 78 units during descent. If the Traffic Advisory Display is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Auxiliary Power Unit status message	48 units	Refer to related topic
Engine Anti-Ice quantity display	84 units	Monitor
Stall Warning quantity display	95 units	Advisory only
Fuel Crossfeed quantity display	72 units	Monitor

05.60.3 Speedbrake Handle Crew Awareness

The Autopilot Channel B selector position is expected to read within the sample range of 79 to 91 units during parking. Refer to the related topic for additional sample context. If the Flight Management Computer is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The first officer will select any change in the Fuel Crossfeed selector position and advise the other pilot if a discrepancy is observed. The Brake Temperature Monitor switch position is expected to read within the sample range of 66 to 78 units during preflight. Refer to the related topic for additional sample context.

NOTE: The Pack Temperature Control advisory is expected to read within the sample range of 45 to 54 units during a maintenance-requested ground run.

If the Nosewheel Steering is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During a maintenance-requested ground run, the pilot flying should record the Fuel Crossfeed advisory when the associated caution light remains illuminated. The Hydraulic System A indication that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated.

NOTE: If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. During taxi, the relief pilot should verify the Hydraulic System B annunciation before the next phase of flight.

CAUTION: The Autopilot Channel B status message is expected to read within the sample range of 81 to 91 units during preflight.

Condition	Sample value	Remarks
Thrust Reverser selector position	40 units	Refer to related topic
Autopilot Channel A indication	61 units	Refer to related topic
Autobrake Selector indication	87 units	Advisory only
Wing Anti-Ice status message	77 units	Monitor

05.60.4 Autopilot Channel A Status Messages

During a diversion, both pilots should verify the Ground Proximity Monitor advisory if a discrepancy is observed. During cruise, the pilot flying should cross-check the Ground Proximity Monitor advisory when operating at a sample station without ground power. The Probe Heat indication is expected to read within the sample range of 6 to 13 units during climb. Refer to the related topic for additional sample context. The captain will cross-check any change in the Pack Temperature Control switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Brake Temperature Monitor quantity display is expected to read within the sample range of 62 to 69 units during a diversion.

CAUTION: The Engine Anti-Ice selector position is expected to read within the sample range of 31 to 37 units during an extended ground delay.

Condition	Sample value	Remarks
Standby Hydraulic annunciation	37 units	Advisory only
Bleed Air Supply switch position	40 units	Refer to related topic
Wing Anti-Ice switch position	78 units	Monitor
Center Tank Pumps quantity display	35 units	Advisory only
Bleed Air Supply switch position	3 units	Refer to related topic
Probe Heat status message	39 units	Advisory only
Nosewheel Steering quantity display	61 units	Monitor

- During preflight, the pilot flying should brief the Nosewheel Steering annunciation when the associated caution light remains illuminated.
- If the Primary Electrical Bus is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- If the Weather Radar is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.
- The Center Tank Pumps status message that differs from the expected state requires the First Officer to brief the condition before the next phase of flight.
- If the Autothrottle is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.
- If the Stall Warning is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

- The Cabin Pressure Controller selector position that differs from the expected state requires the First Officer to monitor the condition once the checklist item is complete.

NOTE: The pilot flying will announce any change in the Center Tank Pumps quantity display and advise the other pilot when the associated caution light remains illuminated. During descent, the First Officer should select the Landing Gear Indication status message before the next phase of flight.

The wording here is placeholder content shaped like a procedure, not a procedure. The Fire Detection Loop switch position is expected to read within the sample range of 91 to 94 units during parking. Both pilots will select any change in the Traffic Advisory Display status message and advise the other pilot when the associated caution light remains illuminated.

The Stall Warning advisory that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. The pilot monitoring will monitor any change in the Hydraulic System B annunciation and advise the other pilot once the checklist item is complete. If the Standby Hydraulic is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

- The Nosewheel Steering annunciation is expected to read within the sample range of 91 to 99 units during climb.
- If the Brake Temperature Monitor is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- The Fire Detection Loop status message is expected to read within the sample range of 37 to 48 units during a turnaround.
- The Hydraulic System B quantity display is expected to read within the sample range of 79 to 91 units during descent.
- The Standby Instruments selector position that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated.
- The Wing Anti-Ice switch position is expected to read within the sample range of 17 to 27 units during engine start.

Challenge	Response
Engine Anti-Ice	Verified
Window Heat	Closed
Standby Hydraulic	As required
Autothrottle	Checked
Standby Hydraulic	Verified
Hydraulic System B	Set

05.60.5 Transponder Limits Display

If the Engine Anti-Ice is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Hydraulic System A quantity display is expected to read within the sample range of 47 to 53 units during takeoff. The pilot flying will select any change in the Oxygen Distribution indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Nosewheel Steering indication	47 units	Normal
Window Heat switch position	82 units	Refer to related topic
Weather Radar status message	27 units	Monitor

The Speedbrake Handle switch position that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. During engine start, the Captain should confirm the Cabin Pressure Controller selector position once the checklist item is complete. The Oxygen Distribution advisory that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Bleed Air Supply selector position	25 units	Advisory only
Cabin Pressure Controller status message	50 units	Normal
Flight Management Computer annunciation	67 units	Advisory only

Condition	Sample value	Remarks
Fire Detection Loop status message	2 units	Normal
Speedbrake Handle selector position	99 units	Advisory only
Speedbrake Handle selector position	74 units	Advisory only
Primary Electrical Bus status message	36 units	Normal
Cargo Smoke Detection indication	41 units	Normal

- Refer to the related topic for additional sample context.
- The captain will record any change in the Window Heat selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During a turnaround, both pilots should cross-check the Pack Temperature Control selector position before the next phase of flight.

CAUTION: The Cabin Pressure Controller indication is expected to read within the sample range of 65 to 76 units during takeoff. The Autopilot Channel B selector position that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Transponder indication	20 units	Advisory only
Ground Proximity Monitor selector position	81 units	Monitor
Fuel Crossfeed quantity display	4 units	Advisory only
Probe Heat advisory	97 units	Advisory only
Fuel Crossfeed indication	22 units	Monitor
Flap Position Indication status message	9 units	Advisory only
Transponder selector position	58 units	Normal

Challenge	Response
Window Heat	Set
Standby Instruments	On
Stall Warning	On
Cockpit Voice Recorder	Off
Traffic Advisory Display	On
Cabin Pressure Controller	On
Autopilot Channel B	Verified
Thrust Reverser	Verified

Auxiliary Power Unit	Off
Weather Radar	Closed
Nosewheel Steering	As required
Primary Electrical Bus	Set

05.70 Automatic Flight

05.70.1 Traffic Advisory Display Interfaces

During cruise, the pilot flying should cross-check the Thrust Reverser selector position unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. If the Flap Position Indication is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. During approach, the Captain should announce the Center Tank Pumps status message if the indication does not stabilize within the sample interval. During preflight, the Captain should select the Hydraulic System B switch position if the indication does not stabilize within the sample interval.

CAUTION: The first officer will announce any change in the Autothrottle switch position and advise the other pilot before the next phase of flight. During a turnaround, the First Officer should monitor the Brake Temperature Monitor status message unless directed otherwise by the Sample Operations Center.

If the Standby Instruments is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Nosewheel Steering switch position is expected to read within the sample range of 85 to 89 units during engine start. During cruise, the pilot flying should cross-check the Brake Temperature Monitor selector position when conditions permit.

Condition	Sample value	Remarks
Fire Detection Loop advisory	49 units	Normal
Autopilot Channel B selector position	55 units	Normal
Autothrottle selector position	30 units	Refer to related topic
Nosewheel Steering annunciation	19 units	Monitor
Wing Anti-Ice advisory	2 units	Normal

Condition	Sample value	Remarks
Transponder indication	1 units	Monitor
Ground Proximity Monitor advisory	78 units	Refer to related topic
Engine Anti-Ice advisory	44 units	Advisory only
Fire Detection Loop advisory	13 units	Advisory only

The Cabin Pressure Controller selector position is expected to read within the sample range of 43 to 52 units during taxi. The Window Heat switch position that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. If the Transponder is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. See 10.20.2 Landing Gear Indication Interfaces.

CAUTION: The Brake Temperature Monitor annunciation is expected to read within the sample range of 43 to 48 units during preflight.

Condition	Sample value	Remarks
Standby Hydraulic switch position	62 units	Normal

Stall Warning annunciation	29 units	Refer to related topic
Pack Temperature Control selector position	72 units	Monitor
Ground Proximity Monitor annunciation	87 units	Advisory only
Oxygen Distribution indication	46 units	Normal

Challenge	Response
Autothrottle	Off
Standby Instruments	Verified
Center Tank Pumps	On
Cockpit Voice Recorder	Armed
Brake Temperature Monitor	Verified
Flight Management Computer	Off
Standby Hydraulic	Armed
Landing Gear Indication	Closed
Standby Instruments	Armed
Nosewheel Steering	As required
Autopilot Channel B	Closed
Landing Gear Indication	As required

05.70.2 Flap Position Indication Crew Awareness

The Cargo Smoke Detection selector position is expected to read within the sample range of 28 to 33 units during descent. The Primary Electrical Bus status message that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. The Thrust Reverser quantity display is expected to read within the sample range of 88 to 97 units during landing.

The captain will record any change in the Stall Warning annunciation and advise the other pilot once the checklist item is complete. The Wing Anti-Ice advisory that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed. The first officer will brief any change in the Engine Anti-Ice annunciation and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Thrust Reverser is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

The Cockpit Voice Recorder switch position that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The pilot flying will cross-check any change in the Fuel Crossfeed selector position and advise the other pilot when operating at a sample station without ground power.

During taxi, the First Officer should cross-check the Center Tank Pumps indication when the associated caution light remains illuminated. The Hydraulic System A advisory that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated. The pilot flying will confirm any change in the Probe Heat selector position and advise the other pilot if a discrepancy is observed. The Hydraulic System A selector position is expected to read within the sample range of 52 to 63 units during parking. The Cockpit Voice Recorder indication that differs from the expected state requires the Captain to announce the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. See 13.20.3 Auxiliary Power Unit Limits Display.

05.70.3 Brake Temperature Monitor Overview

The Pack Temperature Control annunciation that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight. If the Landing Gear Indication is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Hydraulic System B annunciation is expected to read within the sample range of 41 to 47 units during approach. If the Speedbrake Handle is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Primary Electrical Bus selector position that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval.

- The Standby Hydraulic indication is expected to read within the sample range of 81 to 84 units during a diversion.
- The captain will confirm any change in the Engine Anti-Ice indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Bleed Air Supply is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- If the Window Heat is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

If the Cockpit Voice Recorder is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Thrust Reverser selector position that differs from the expected state requires the Captain to announce the condition when conditions permit. During landing, the Captain should select the Autopilot Channel B quantity display when conditions permit. If the Autopilot Channel A is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

Values in this manual are invented and must not be used for any operational purpose. The Thrust Reverser annunciation is expected to read within the sample range of 24 to 29 units during a turnaround. During engine start, the Captain should verify the Hydraulic System A selector position if a discrepancy is observed. The relief pilot will monitor any change in the Thrust Reverser switch position and advise the other pilot when conditions permit. If the Standby Instruments is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

During landing, the pilot monitoring should cross-check the Hydraulic System A annunciation when operating at a sample station without ground power. The Primary Electrical Bus switch position is expected to read within the sample range of 66 to 78 units during descent. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Window Heat switch position	36 units	Refer to related topic
Standby Hydraulic selector position	13 units	Advisory only
Flap Position Indication advisory	25 units	Normal

During descent, both pilots should record the Bleed Air Supply advisory if a discrepancy is observed. The Traffic Advisory Display advisory that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. During a maintenance-requested ground run, both pilots should confirm the Hydraulic System B indication when operating at a sample station without ground power. The Fire Detection Loop advisory is expected to read within the sample range of 65 to 77 units during approach.

Condition	Sample value	Remarks
Pack Temperature Control indication	13 units	Normal
Flight Management Computer quantity display	39 units	Monitor
Transponder switch position	35 units	Advisory only
Flight Management Computer advisory	86 units	Refer to related topic

05.70.4 Primary Electrical Bus Interfaces

The Flap Position Indication status message that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. The Oxygen Distribution advisory that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. During preflight, both pilots should brief the Window Heat quantity display when conditions permit. If the Cockpit Voice Recorder is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. During parking, the pilot flying should monitor the Autopilot Channel B annunciation if the indication does not stabilize within the sample interval. The Probe Heat status message that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight.

During climb, the pilot flying should monitor the Hydraulic System A indication before the next phase of flight. If the Cockpit Voice Recorder is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display quantity display that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. The Traffic Advisory Display advisory that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. If the Autothrottle is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The first officer will cross-check any change in the Autopilot Channel A quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Speedbrake Handle status message that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated. The Cockpit Voice Recorder advisory that differs from the expected state requires the Captain to record the condition when conditions permit.

If the Primary Electrical Bus is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The Brake Temperature Monitor switch position is expected to read within the sample range of 13 to 16 units during takeoff. If the Flight Management Computer is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. During an extended ground delay, the pilot monitoring should cross-check the Nosewheel Steering selector position when operating at a sample station without ground power. During a maintenance-requested ground run, the relief pilot should record the Flight Management Computer quantity display when the associated caution light remains illuminated. The Standby Hydraulic quantity display is expected to read within the sample range of 90 to 93 units during cruise.

The pilot flying will record any change in the Standby Instruments indication and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. If the Brake Temperature Monitor is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

- The Ground Proximity Monitor annunciation that differs from the expected state requires the pilot flying to record the condition when conditions permit.
- The Hydraulic System A selector position that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit.
- During a maintenance-requested ground run, the First Officer should brief the Probe Heat status message once the checklist item is complete.
- The pilot flying will monitor any change in the Bleed Air Supply quantity display and advise the other pilot when operating at a sample station without ground power.
- The Engine Anti-Ice advisory that differs from the expected state requires the First Officer to verify the condition when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.
- During climb, both pilots should record the Window Heat advisory if a discrepancy is observed.

- The Flight Management Computer indication that differs from the expected state requires the Captain to monitor the condition when conditions permit.

Condition	Sample value	Remarks
Speedbrake Handle switch position	85 units	Normal
Engine Anti-Ice switch position	89 units	Monitor
Weather Radar selector position	59 units	Advisory only
Traffic Advisory Display indication	84 units	Advisory only

During climb, the pilot flying should cross-check the Weather Radar selector position when operating at a sample station without ground power. The Flight Management Computer selector position that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight. During descent, both pilots should cross-check the Oxygen Distribution indication if the indication does not stabilize within the sample interval.

05.70.5 Transponder Normal Operation

The Standby Hydraulic quantity display that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. The Nosewheel Steering advisory is expected to read within the sample range of 53 to 58 units during parking. The Oxygen Distribution selector position that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center. The first officer will cross-check any change in the Hydraulic System A selector position and advise the other pilot when conditions permit. If the Wing Anti-Ice is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Traffic Advisory Display is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The Pack Temperature Control status message is expected to read within the sample range of 43 to 46 units during climb. The pilot flying will verify any change in the Wing Anti-Ice switch position and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

- During an extended ground delay, the Captain should record the Cockpit Voice Recorder status message once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- The Brake Temperature Monitor quantity display is expected to read within the sample range of 13 to 17 units during a diversion.
- If the Primary Electrical Bus is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The relief pilot will announce any change in the Fuel Crossfeed switch position and advise the other pilot when conditions permit.
- If the Wing Anti-Ice is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- During taxi, both pilots should select the Pack Temperature Control switch position when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During cruise, both pilots should select the Autobrake Selector status message when operating at a sample station without ground power.

If the Stall Warning is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Window Heat indication is expected to read within the sample range of 94 to 98 units during descent. During preflight, the Captain should record the Autopilot Channel A selector position if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will record any change in the Standby Hydraulic indication and advise the other pilot before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will brief any change in the Center Tank Pumps indication and advise the other pilot once the checklist item is complete. During preflight, the First Officer should select the Flight Management Computer indication when operating at a sample station without ground power. The Hydraulic System A indication is expected to read within the sample range of 98 to 101 units during an extended ground delay.

The Cargo Smoke Detection quantity display is expected to read within the sample range of 12 to 16 units during landing. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. The Autobrake Selector status message is expected to read within the sample range of 26 to 38 units during preflight. The Standby Hydraulic annunciation that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center.

05.80 Navigation

05.80.1 Fire Detection Loop Normal Operation

During a turnaround, the pilot flying should cross-check the Auxiliary Power Unit selector position when conditions permit. The Thrust Reverser quantity display is expected to read within the sample range of 58 to 69 units during cruise. The Autothrottle indication is expected to read within the sample range of 41 to 48 units during landing. The Window Heat indication that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. The Pack Temperature Control status message is expected to read within the sample range of 35 to 40 units during takeoff.

- The Fire Detection Loop advisory is expected to read within the sample range of 41 to 46 units during descent.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During climb, both pilots should brief the Cabin Pressure Controller switch position when operating at a sample station without ground power.
- During taxi, the relief pilot should verify the Hydraulic System B indication if a discrepancy is observed.

During landing, the relief pilot should monitor the Cockpit Voice Recorder status message unless directed otherwise by the Sample Operations Center. During cruise, the relief pilot should confirm the Cockpit Voice Recorder annunciation when the associated caution light remains illuminated. During taxi, the pilot flying should cross-check the Cockpit Voice Recorder switch position if the indication does not stabilize within the sample interval. The Thrust Reverser switch position that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval.

- The Stall Warning indication is expected to read within the sample range of 10 to 20 units during landing.
- During parking, both pilots should verify the Cargo Smoke Detection indication unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Both pilots will record any change in the Flight Management Computer quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. If the Transponder is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

05.80.2 Cockpit Voice Recorder Reset Guidance

The Window Heat advisory that differs from the expected state requires the First Officer to cross-check the condition when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Hydraulic selector position is expected to read within the sample range of 87 to 91 units during approach. Refer to the related topic for additional sample context. If the Standby Hydraulic is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

If the Thrust Reverser is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. Both pilots will cross-check any change in the Wing Anti-Ice advisory and advise the other pilot when operating at a sample station without ground power. The Ground Proximity Monitor advisory that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Cargo Smoke Detection is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Fire Detection Loop quantity display that differs from the expected state requires the pilot monitoring to monitor the condition when operating at a sample station without ground power.

The Hydraulic System A advisory is expected to read within the sample range of 57 to 60 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. The Weather Radar advisory is expected to read within the sample range of 12 to 23 units during a maintenance-requested ground run. The Flap Position Indication annunciation that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. The Autobrake Selector advisory that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. During descent, the First Officer should announce the Thrust Reverser quantity display if the indication does not stabilize within the sample interval.

- The Stall Warning indication that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power.
- The captain will announce any change in the Speedbrake Handle switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- During climb, the pilot flying should confirm the Engine Anti-Ice switch position once the checklist item is complete.
- The Wing Anti-Ice indication is expected to read within the sample range of 61 to 70 units during a maintenance-requested ground run.

05.80.3 Bleed Air Supply Power Sources

During an extended ground delay, the Captain should brief the Nosewheel Steering indication when conditions permit. During a turnaround, the pilot monitoring should announce the Autopilot Channel B advisory before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will announce any change in the Primary Electrical Bus selector position and advise the other pilot if a discrepancy is observed. If the Window Heat is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The Flap Position Indication status message is expected to read within the sample range of 91 to 103 units during cruise.

- During a turnaround, the First Officer should verify the Wing Anti-Ice advisory once the checklist item is complete.
- The Landing Gear Indication selector position is expected to read within the sample range of 25 to 31 units during a turnaround.

- During takeoff, the First Officer should monitor the Speedbrake Handle switch position when operating at a sample station without ground power.

If the Hydraulic System B is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The captain will confirm any change in the Engine Anti-Ice quantity display and advise the other pilot if a discrepancy is observed. During a maintenance-requested ground run, the pilot monitoring should brief the Probe Heat advisory when the associated caution light remains illuminated. During parking, the pilot flying should confirm the Thrust Reverser quantity display unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display annunciation is expected to read within the sample range of 6 to 15 units during takeoff. Refer to the related topic for additional sample context.

NOTE: During landing, the pilot monitoring should cross-check the Primary Electrical Bus switch position when conditions permit. The relief pilot will monitor any change in the Hydraulic System B advisory and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Auxiliary Power Unit switch position	31 units	Advisory only
Standby Instruments annunciation	95 units	Advisory only
Center Tank Pumps status message	47 units	Normal
Weather Radar annunciation	90 units	Advisory only
Flight Management Computer indication	63 units	Monitor

Condition	Sample value	Remarks
Thrust Reverser switch position	56 units	Normal
Hydraulic System B switch position	70 units	Monitor
Thrust Reverser status message	50 units	Normal
Brake Temperature Monitor status message	72 units	Advisory only
Ground Proximity Monitor quantity display	17 units	Normal

The captain will announce any change in the Cargo Smoke Detection selector position and advise the other pilot when operating at a sample station without ground power. The Weather Radar indication is expected to read within the sample range of 42 to 53 units during climb. During an extended ground delay, the relief pilot should announce the Cargo Smoke Detection annunciation when the associated caution light remains illuminated. The Pack Temperature Control advisory that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. The Nosewheel Steering switch position is expected to read within the sample range of 60 to 67 units during cruise.

05.80.4 Stall Warning Overview

During cruise, both pilots should confirm the Cargo Smoke Detection indication unless directed otherwise by the Sample Operations Center. If the Standby Hydraulic is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During a turnaround, the pilot monitoring should monitor the Flap Position Indication selector position when the associated caution light remains illuminated. The Ground Proximity Monitor status message that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power. The Landing Gear Indication quantity display is expected to read within the sample range of 9 to 19 units during a maintenance-requested ground run.

CAUTION: The Flight Management Computer selector position that differs from the expected state requires both pilots to brief the condition before the next phase of flight.

CAUTION: The first officer will select any change in the Standby Instruments status message and advise the other pilot when operating at a sample station without ground power. During climb, the Captain should record the Cargo Smoke Detection quantity display unless directed otherwise by the Sample Operations Center.

CAUTION: The Wing Anti-Ice selector position is expected to read within the sample range of 28 to 32 units during a maintenance-requested ground run. If the Window Heat is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

CAUTION: During cruise, the First Officer should brief the Oxygen Distribution indication when operating at a sample station without ground power.

Challenge	Response
Center Tank Pumps	Closed
Nosewheel Steering	On
Auxiliary Power Unit	On
Oxygen Distribution	Checked
Primary Electrical Bus	On
Weather Radar	Off
Autothrottle	Off
Window Heat	As required
Primary Electrical Bus	Set
Nosewheel Steering	Off

05.80.5 Landing Gear Indication Interfaces

The Hydraulic System B annunciation is expected to read within the sample range of 30 to 35 units during descent. The Probe Heat quantity display is expected to read within the sample range of 65 to 69 units during a turnaround. The captain will confirm any change in the Thrust Reverser advisory and advise the other pilot once the checklist item is complete. During an extended ground delay, the First Officer should verify the Wing Anti-Ice annunciation when operating at a sample station without ground power.

CAUTION: The pilot flying will select any change in the Auxiliary Power Unit status message and advise the other pilot if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

If the Nosewheel Steering is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor switch position is expected to read within the sample range of 80 to 87 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure.

The first officer will record any change in the Hydraulic System A advisory and advise the other pilot when conditions permit. The Hydraulic System A selector position is expected to read within the sample range of 97 to 107 units during descent. The pilot monitoring will brief any change in the Brake Temperature Monitor quantity display and advise the other pilot before the next phase of flight. If the Standby Instruments is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Landing Gear Indication indication that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed.
- If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

Chapter 06 Systems: Air Systems

06.10 Description

06.10.1 Autobrake Selector Status Messages

If the Hydraulic System A is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Thrust Reverser quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Bleed Air Supply selector position that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. If the Flap Position Indication is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. During approach, both pilots should confirm the Brake Temperature Monitor status message when the associated caution light remains illuminated.

The Autothrottle annunciation that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center. During a turnaround, both pilots should announce the Pack Temperature Control annunciation when the associated caution light remains illuminated. The pilot monitoring will cross-check any change in the Engine Anti-Ice quantity display and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

- Both pilots will record any change in the Autopilot Channel B advisory and advise the other pilot when operating at a sample station without ground power.
- During takeoff, the pilot flying should announce the Standby Hydraulic quantity display when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Nosewheel Steering is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Traffic Advisory Display annunciation	40 units	Advisory only
Hydraulic System A status message	85 units	Normal
Oxygen Distribution advisory	31 units	Monitor
Cabin Pressure Controller switch position	93 units	Normal

The Pack Temperature Control advisory is expected to read within the sample range of 28 to 40 units during parking. The pilot monitoring will confirm any change in the Cabin Pressure Controller indication and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The first officer will cross-check any change in the Bleed Air Supply quantity display and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Cargo Smoke Detection is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

06.10.2 Autothrottle Reset Guidance

The wording here is placeholder content shaped like a procedure, not a procedure. The Nosewheel Steering switch position that differs from the expected state requires both pilots to brief the condition when conditions permit. If the Center Tank Pumps is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. During engine start, the relief pilot should brief the Cockpit Voice Recorder indication when operating at a sample

station without ground power.

- The Stall Warning annunciation that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power.
- During cruise, the relief pilot should confirm the Primary Electrical Bus indication when the associated caution light remains illuminated.
- The Brake Temperature Monitor annunciation is expected to read within the sample range of 7 to 13 units during approach.
- The pilot monitoring will select any change in the Ground Proximity Monitor annunciation and advise the other pilot if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.

Both pilots will brief any change in the Window Heat switch position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. If the Probe Heat is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. Both pilots will announce any change in the Ground Proximity Monitor indication and advise the other pilot if a discrepancy is observed. If the Standby Instruments is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

CAUTION: During cruise, the relief pilot should brief the Auxiliary Power Unit switch position when operating at a sample station without ground power.

During approach, the First Officer should brief the Autobrake Selector status message once the checklist item is complete. The pilot monitoring will cross-check any change in the Fire Detection Loop switch position and advise the other pilot before the next phase of flight. If the Flap Position Indication is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Hydraulic System B switch position is expected to read within the sample range of 43 to 47 units during approach. During an extended ground delay, both pilots should announce the Nosewheel Steering switch position before the next phase of flight. The relief pilot will brief any change in the Autothrottle annunciation and advise the other pilot before the next phase of flight.

06.10.3 Brake Temperature Monitor Reset Guidance

During cruise, the relief pilot should brief the Center Tank Pumps indication if the indication does not stabilize within the sample interval. The captain will record any change in the Brake Temperature Monitor switch position and advise the other pilot if a discrepancy is observed. The pilot monitoring will monitor any change in the Ground Proximity Monitor selector position and advise the other pilot before the next phase of flight. The relief pilot will monitor any change in the Oxygen Distribution selector position and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: Refer to the related topic for additional sample context.

The pilot monitoring will monitor any change in the Window Heat selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autothrottle indication that differs from the expected state requires the Captain to announce the condition when conditions permit. Both pilots will cross-check any change in the Nosewheel Steering selector position and advise the other pilot before the next phase of flight. The Engine Anti-Ice annunciation is expected to read within the sample range of 96 to 105 units during approach. If the Pack Temperature Control is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will cross-check any change in the Weather Radar status message and advise the other pilot once the checklist item is complete. During descent, both pilots should brief the Fuel Crossfeed indication when conditions permit. The Auxiliary

Power Unit annunciation that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. The Thrust Reverser quantity display is expected to read within the sample range of 32 to 37 units during landing. If the Pack Temperature Control is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

The captain will confirm any change in the Window Heat status message and advise the other pilot when conditions permit. If the Autopilot Channel B is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Landing Gear Indication quantity display is expected to read within the sample range of 61 to 70 units during approach. If the Speedbrake Handle is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Standby Hydraulic quantity display that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated.

06.10.4 Traffic Advisory Display Status Messages

The Engine Anti-Ice switch position that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. If the Bleed Air Supply is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

The Autothrottle quantity display is expected to read within the sample range of 88 to 93 units during preflight. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 37 to 48 units during a diversion. If the Cargo Smoke Detection is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. During takeoff, the pilot flying should select the Center Tank Pumps switch position when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. During approach, both pilots should select the Autobrake Selector advisory when conditions permit. The captain will announce any change in the Cargo Smoke Detection indication and advise the other pilot when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

If the Traffic Advisory Display is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Fuel Crossfeed quantity display that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments quantity display is expected to read within the sample range of 97 to 103 units during a diversion. If the Oxygen Distribution is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

The Standby Hydraulic switch position that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight. During a turnaround, the pilot flying should monitor the Hydraulic System A indication when operating at a sample station without ground power. The Cargo Smoke Detection quantity display that differs from the expected state requires the First Officer to record the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Wing Anti-Ice indication is expected to read within the sample range of 61 to 64 units during a turnaround. The captain will confirm any change in the Auxiliary Power Unit selector position and advise the other pilot before the next phase of flight.

The wording here is placeholder content shaped like a procedure, not a procedure. During climb, the pilot flying should select the Fire Detection Loop advisory when the associated caution light remains illuminated. The relief pilot will verify any change in the Autothrottle indication and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

- If the Pack Temperature Control is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.
- During descent, the pilot flying should record the Pack Temperature Control quantity display when conditions permit.
- During climb, the pilot flying should record the Transponder advisory if the indication does not stabilize within the sample interval.

06.20 Controls and Indicators

06.20.1 Probe Heat Status Messages

The pilot monitoring will confirm any change in the Oxygen Distribution indication and advise the other pilot when conditions permit. If the Pack Temperature Control is inoperative, continue preflight only after both pilots have reviewed the associated sample guidance. During a maintenance-requested ground run, both pilots should brief the Autobrake Selector selector position when operating at a sample station without ground power. The pilot flying will confirm any change in the Standby Hydraulic status message and advise the other pilot once the checklist item is complete. During climb, the Captain should cross-check the Brake Temperature Monitor selector position when the associated caution light remains illuminated. The first officer will monitor any change in the Pack Temperature Control status message and advise the other pilot before the next phase of flight.

CAUTION: During landing, the pilot flying should confirm the Traffic Advisory Display selector position when conditions permit.

The Standby Instruments selector position that differs from the expected state requires the First Officer to announce the condition when conditions permit. During a maintenance-requested ground run, the Captain should verify the Ground Proximity Monitor switch position before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System A switch position is expected to read within the sample range of 33 to 45 units during an extended ground delay. The pilot monitoring will confirm any change in the Stall Warning annunciation and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

The pilot monitoring will verify any change in the Thrust Reverser quantity display and advise the other pilot before the next phase of flight. The Bleed Air Supply annunciation is expected to read within the sample range of 56 to 68 units during takeoff. During a turnaround, the relief pilot should monitor the Brake Temperature Monitor selector position once the checklist item is complete.

The relief pilot will monitor any change in the Thrust Reverser status message and advise the other pilot if the indication does not stabilize within the sample interval. During landing, the relief pilot should announce the Ground Proximity Monitor annunciation if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose.

During an extended ground delay, both pilots should confirm the Brake Temperature Monitor annunciation if a discrepancy is observed. The Speedbrake Handle annunciation is expected to read within the sample range of 21 to 29 units during descent. The Flight Management Computer selector position that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated. The Window Heat annunciation that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.

CAUTION: The Transponder advisory that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. The Weather Radar status message is expected to read within the sample range of 86 to 89 units during cruise.

- Values in this manual are invented and must not be used for any operational purpose.
- The captain will select any change in the Hydraulic System B annunciation and advise the other pilot before the next phase of flight.

- During preflight, the Captain should announce the Hydraulic System A selector position when operating at a sample station without ground power.

CAUTION: Both pilots will confirm any change in the Bleed Air Supply selector position and advise the other pilot before the next phase of flight. During cruise, both pilots should brief the Cabin Pressure Controller annunciation once the checklist item is complete.

06.20.2 Transponder Power Sources

The Landing Gear Indication indication that differs from the expected state requires the Captain to select the condition when conditions permit. Both pilots will verify any change in the Standby Hydraulic status message and advise the other pilot once the checklist item is complete. If the Cargo Smoke Detection is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System B advisory is expected to read within the sample range of 45 to 57 units during cruise.

NOTE: The Pack Temperature Control selector position is expected to read within the sample range of 6 to 10 units during engine start.

The Cockpit Voice Recorder advisory is expected to read within the sample range of 73 to 79 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose. During cruise, the Captain should verify the Standby Instruments indication when the associated caution light remains illuminated. The Pack Temperature Control selector position is expected to read within the sample range of 77 to 89 units during preflight.

Both pilots will cross-check any change in the Autothrottle advisory and advise the other pilot when operating at a sample station without ground power. If the Hydraulic System A is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Transponder selector position is expected to read within the sample range of 53 to 65 units during descent. During a turnaround, both pilots should announce the Oxygen Distribution indication when conditions permit. The pilot monitoring will select any change in the Bleed Air Supply annunciation and advise the other pilot if a discrepancy is observed.

The Cargo Smoke Detection selector position is expected to read within the sample range of 35 to 40 units during takeoff. During an extended ground delay, the Captain should select the Autopilot Channel A selector position once the checklist item is complete. If the Flight Management Computer is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. During cruise, the Captain should confirm the Thrust Reverser quantity display before the next phase of flight. The Autopilot Channel B annunciation that differs from the expected state requires the Captain to select the condition when conditions permit.

NOTE: The Flight Management Computer quantity display that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed.

The Stall Warning switch position is expected to read within the sample range of 65 to 73 units during a diversion. The Bleed Air Supply selector position is expected to read within the sample range of 85 to 90 units during a turnaround. The Center Tank Pumps annunciation that differs from the expected state requires the pilot flying to verify the condition if a discrepancy is observed. The Bleed Air Supply switch position that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power.

NOTE: The first officer will brief any change in the Autopilot Channel A annunciation and advise the other pilot if a discrepancy is observed. During parking, the pilot monitoring should record the Fire Detection Loop quantity display if a discrepancy is observed.

If the Nosewheel Steering is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. During preflight, the pilot monitoring should monitor the Standby Instruments status message when operating at a sample station without ground power. The pilot monitoring will monitor any change in the Probe Heat indication and advise the other pilot before the next phase of flight. During cruise, both pilots should brief the Engine Anti-Ice advisory before the next phase of flight. The first officer will record any change in the Autobrake Selector advisory and advise the other pilot if the indication does not stabilize within the sample interval. During cruise, both

pilots should verify the Auxiliary Power Unit status message when the associated caution light remains illuminated.

06.20.3 Cargo Smoke Detection Reset Guidance

The captain will brief any change in the Wing Anti-Ice indication and advise the other pilot once the checklist item is complete. The Hydraulic System A status message is expected to read within the sample range of 98 to 102 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice status message that differs from the expected state requires the pilot flying to announce the condition unless directed otherwise by the Sample Operations Center.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Center Tank Pumps selector position that differs from the expected state requires the First Officer to record the condition before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Both pilots will monitor any change in the Ground Proximity Monitor advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Flight Management Computer selector position	45 units	Monitor
Cockpit Voice Recorder quantity display	35 units	Monitor
Standby Instruments switch position	71 units	Normal
Transponder selector position	83 units	Normal

- The Ground Proximity Monitor selector position is expected to read within the sample range of 66 to 78 units during takeoff.
- The Fire Detection Loop status message that differs from the expected state requires the Captain to record the condition once the checklist item is complete.
- During a maintenance-requested ground run, the pilot flying should brief the Weather Radar selector position when the associated caution light remains illuminated.
- If the Cabin Pressure Controller is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The relief pilot will record any change in the Transponder advisory and advise the other pilot once the checklist item is complete.

During climb, the pilot monitoring should select the Oxygen Distribution advisory when the associated caution light remains illuminated. The Traffic Advisory Display quantity display that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete. The pilot monitoring will cross-check any change in the Stall Warning status message and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. During parking, both pilots should record the Wing Anti-Ice advisory if a discrepancy is observed. If the Autopilot Channel B is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

The Speedbrake Handle switch position is expected to read within the sample range of 60 to 64 units during takeoff. The relief pilot will announce any change in the Landing Gear Indication annunciation and advise the other pilot when the associated caution light remains illuminated. During approach, both pilots should record the Hydraulic System B status message when operating at a sample station without ground power. During taxi, both pilots should cross-check the Autobrake Selector advisory when the associated caution light remains illuminated. The Autobrake Selector quantity display is expected to read within the sample range of 85 to 90 units during descent.

NOTE: The first officer will verify any change in the Center Tank Pumps selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Autopilot Channel B quantity display that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight.

Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The Landing Gear Indication advisory that differs from the expected state requires the pilot flying to select the condition before the next phase of flight. The relief pilot will record any change in the Oxygen Distribution advisory and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context.

06.20.4 Probe Heat Crew Awareness

The Engine Anti-Ice quantity display is expected to read within the sample range of 91 to 100 units during approach. During an extended ground delay, the pilot flying should brief the Landing Gear Indication selector position when conditions permit. The Nosewheel Steering quantity display is expected to read within the sample range of 90 to 101 units during parking. The wording here is placeholder content shaped like a procedure, not a procedure. The Nosewheel Steering advisory is expected to read within the sample range of 4 to 8 units during takeoff.

The Window Heat quantity display that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center. The Autobrake Selector indication is expected to read within the sample range of 53 to 59 units during climb. The pilot monitoring will monitor any change in the Hydraulic System B annunciation and advise the other pilot when the associated caution light remains illuminated. The relief pilot will brief any change in the Standby Hydraulic switch position and advise the other pilot if the indication does not stabilize within the sample interval.

The Primary Electrical Bus selector position is expected to read within the sample range of 68 to 75 units during a maintenance-requested ground run. The Bleed Air Supply advisory is expected to read within the sample range of 70 to 74 units during cruise. The Pack Temperature Control status message is expected to read within the sample range of 31 to 36 units during a diversion. The Autopilot Channel A indication that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated. The Traffic Advisory Display selector position that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

- The pilot flying will brief any change in the Auxiliary Power Unit quantity display and advise the other pilot when conditions permit.
- The first officer will verify any change in the Oxygen Distribution selector position and advise the other pilot when conditions permit.
- The pilot monitoring will announce any change in the Brake Temperature Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- The first officer will monitor any change in the Hydraulic System A quantity display and advise the other pilot when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The relief pilot will confirm any change in the Center Tank Pumps annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. During engine start, the relief pilot should record the Traffic Advisory Display advisory when conditions permit. The Autopilot Channel A quantity display is expected to read within the sample range of 88 to 94 units during climb. If the Standby Hydraulic is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

The Pack Temperature Control selector position that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. The Nosewheel Steering switch position that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Pack Temperature Control selector position	2 units	Advisory only
Fire Detection Loop annunciation	24 units	Monitor
Cargo Smoke Detection quantity display	39 units	Advisory only
Probe Heat switch position	18 units	Monitor
Autopilot Channel A quantity display	76 units	Normal
Flight Management Computer annunciation	25 units	Monitor
Probe Heat indication	35 units	Monitor

06.30 Operation

06.30.1 Transponder Limits Display

During a diversion, both pilots should cross-check the Engine Anti-Ice advisory when the associated caution light remains illuminated. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 90 to 97 units during an extended ground delay. The Autopilot Channel B annunciation that differs from the expected state requires both pilots to select the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Stall Warning advisory that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power.

- If the Flap Position Indication is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- During descent, both pilots should announce the Center Tank Pumps quantity display once the checklist item is complete.
- During preflight, the First Officer should brief the Flap Position Indication advisory when operating at a sample station without ground power.

The captain will record any change in the Engine Anti-Ice status message and advise the other pilot when the associated caution light remains illuminated. If the Stall Warning is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Brake Temperature Monitor annunciation that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval.

CAUTION: If the Window Heat is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: If the Fuel Crossfeed is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Engine Anti-Ice switch position	80 units	Normal
Autothrottle annunciation	40 units	Advisory only
Wing Anti-Ice advisory	15 units	Monitor

During climb, the Captain should record the Bleed Air Supply status message if a discrepancy is observed. If the Brake Temperature Monitor is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The pilot flying will brief any change in the Autopilot Channel B advisory and advise the other pilot when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. See 11.10.4 Primary Electrical Bus Status Messages.

06.30.2 Primary Electrical Bus Status Messages

The Wing Anti-Ice selector position that differs from the expected state requires the First Officer to select the condition before the next phase of flight. During a turnaround, the pilot flying should record the Weather Radar status message before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Flap Position Indication quantity display that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center.

- If the Wing Anti-Ice is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- The first officer will verify any change in the Ground Proximity Monitor selector position and advise the other pilot once the checklist item is complete.
- The Wing Anti-Ice annunciation is expected to read within the sample range of 49 to 58 units during cruise.
- The Weather Radar indication is expected to read within the sample range of 68 to 78 units during a diversion.
- The Brake Temperature Monitor switch position that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval.

This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat indication that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight. If the Fuel Crossfeed is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

NOTE: During descent, the pilot monitoring should monitor the Transponder switch position once the checklist item is complete.

Condition	Sample value	Remarks
Nosewheel Steering quantity display	12 units	Refer to related topic
Engine Anti-Ice indication	47 units	Normal
Cabin Pressure Controller switch position	91 units	Refer to related topic
Hydraulic System A indication	1 units	Advisory only
Thrust Reverser switch position	17 units	Normal
Landing Gear Indication annunciation	71 units	Refer to related topic
Hydraulic System A quantity display	79 units	Advisory only

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot flying will select any change in the Autobrake Selector advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- The Fuel Crossfeed switch position that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.

- The pilot monitoring will verify any change in the Speedbrake Handle selector position and advise the other pilot when conditions permit.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. If the Traffic Advisory Display is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

06.30.3 Window Heat Overview

The Brake Temperature Monitor selector position is expected to read within the sample range of 38 to 43 units during a maintenance-requested ground run. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will announce any change in the Probe Heat quantity display and advise the other pilot when conditions permit. If the Transponder is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Speedbrake Handle indication that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Autopilot Channel A indication is expected to read within the sample range of 39 to 46 units during preflight. Both pilots will cross-check any change in the Primary Electrical Bus status message and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Flap Position Indication quantity display	84 units	Normal
Probe Heat quantity display	87 units	Monitor
Flap Position Indication selector position	48 units	Normal
Wing Anti-Ice status message	99 units	Advisory only
Brake Temperature Monitor advisory	20 units	Refer to related topic
Standby Instruments quantity display	1 units	Refer to related topic

Both pilots will brief any change in the Thrust Reverser status message and advise the other pilot before the next phase of flight. The Ground Proximity Monitor annunciation that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated. If the Cockpit Voice Recorder is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Oxygen Distribution status message is expected to read within the sample range of 67 to 75 units during takeoff. The Center Tank Pumps indication that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete.

06.30.4 Auxiliary Power Unit Indications

If the Wing Anti-Ice is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel B quantity display that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.

- If the Cabin Pressure Controller is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.
- Both pilots will monitor any change in the Stall Warning selector position and advise the other pilot when the associated caution light remains illuminated.
- If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Primary Electrical Bus switch position	55 units	Advisory only
Thrust Reverser indication	87 units	Refer to related topic
Window Heat switch position	36 units	Monitor
Transponder quantity display	92 units	Normal
Window Heat quantity display	13 units	Advisory only
Cargo Smoke Detection quantity display	99 units	Advisory only

NOTE: During takeoff, both pilots should record the Transponder quantity display when conditions permit. If the Standby Instruments is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

- The Bleed Air Supply switch position is expected to read within the sample range of 70 to 80 units during climb.
- The Bleed Air Supply annunciation is expected to read within the sample range of 23 to 26 units during cruise.
- During an extended ground delay, the First Officer should record the Cockpit Voice Recorder quantity display when the associated caution light remains illuminated.
- During a diversion, both pilots should monitor the Autothrottle selector position once the checklist item is complete.

Condition	Sample value	Remarks
Landing Gear Indication indication	88 units	Normal
Traffic Advisory Display advisory	14 units	Advisory only
Standby Hydraulic quantity display	15 units	Monitor
Speedbrake Handle indication	86 units	Advisory only

CAUTION: If the Cabin Pressure Controller is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autobrake Selector switch position	42 units	Normal
Engine Anti-Ice advisory	51 units	Refer to related topic
Auxiliary Power Unit status message	84 units	Advisory only
Weather Radar advisory	71 units	Refer to related topic

06.40 Sample Non-Normal Guidance

06.40.1 Nosewheel Steering Status Messages

The Window Heat status message is expected to read within the sample range of 21 to 32 units during parking. During approach, the First Officer should monitor the Hydraulic System A selector position unless directed otherwise by the Sample Operations Center. If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During a diversion, the Captain should monitor the Pack Temperature Control selector position when operating at a sample station without ground power.

CAUTION: The Fuel Crossfeed indication is expected to read within the sample range of 92 to 99 units during landing. The Cabin Pressure Controller annunciation that differs from the expected state requires the pilot flying

to monitor the condition before the next phase of flight.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will announce any change in the Engine Anti-Ice quantity display and advise the other pilot before the next phase of flight.

Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel A indication that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power.

- Refer to the related topic for additional sample context.
- If the Weather Radar is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- During parking, the pilot flying should select the Autopilot Channel A status message once the checklist item is complete.
- During a turnaround, both pilots should record the Standby Instruments status message before the next phase of flight.

NOTE: During takeoff, the First Officer should monitor the Transponder switch position when conditions permit. The Hydraulic System A switch position that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center.

The Primary Electrical Bus annunciation that differs from the expected state requires the pilot flying to brief the condition when conditions permit. The Landing Gear Indication status message that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. The relief pilot will brief any change in the Landing Gear Indication advisory and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

06.40.2 Bleed Air Supply Status Messages

The Nosewheel Steering status message that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat selector position that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.

Condition	Sample value	Remarks
Thrust Reverser quantity display	87 units	Advisory only
Standby Hydraulic selector position	80 units	Normal
Probe Heat quantity display	32 units	Refer to related topic
Probe Heat switch position	80 units	Normal
Hydraulic System A annunciation	32 units	Refer to related topic

- During an extended ground delay, the pilot flying should record the Wing Anti-Ice status message before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- The first officer will cross-check any change in the Wing Anti-Ice indication and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The Primary Electrical Bus selector position is expected to read within the sample range of 82 to 86 units during cruise.

During taxi, the pilot monitoring should select the Autopilot Channel A switch position before the next phase of flight. During taxi, the relief pilot should confirm the Flight Management Computer advisory once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. During climb, the relief pilot should select the Engine Anti-Ice status message when operating at a sample station without ground power.

- The Brake Temperature Monitor indication that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete.
- If the Weather Radar is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.
- The relief pilot will cross-check any change in the Traffic Advisory Display status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Flap Position Indication quantity display that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power.

06.40.3 Oxygen Distribution Power Sources

During approach, the pilot monitoring should verify the Standby Instruments annunciation unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. If the Probe Heat is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

The Wing Anti-Ice selector position is expected to read within the sample range of 8 to 13 units during takeoff. Refer to the related topic for additional sample context. The pilot monitoring will announce any change in the Transponder status message and advise the other pilot once the checklist item is complete.

NOTE: If the Stall Warning is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

The relief pilot will confirm any change in the Autobrake Selector advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The captain will announce any change in the Autobrake Selector switch position and advise the other pilot when conditions permit. The Weather Radar selector position is expected to read within the sample range of 47 to 53 units during a maintenance-requested ground run.

The relief pilot will confirm any change in the Thrust Reverser switch position and advise the other pilot once the checklist item is complete. During cruise, the pilot flying should cross-check the Traffic Advisory Display advisory when conditions permit. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Transponder annunciation	8 units	Normal
Thrust Reverser switch position	75 units	Refer to related topic
Fuel Crossfeed indication	63 units	Refer to related topic
Thrust Reverser annunciation	94 units	Refer to related topic
Flight Management Computer quantity display	85 units	Refer to related topic
Cabin Pressure Controller selector position	54 units	Normal

06.40.4 Oxygen Distribution Limits Display

The pilot flying will announce any change in the Stall Warning indication and advise the other pilot if a discrepancy is observed. If the Landing Gear Indication is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Weather Radar indication and

advise the other pilot when conditions permit.

During an extended ground delay, the First Officer should select the Flap Position Indication advisory before the next phase of flight. During landing, the Captain should brief the Oxygen Distribution status message when operating at a sample station without ground power. During a turnaround, the First Officer should record the Speedbrake Handle selector position when the associated caution light remains illuminated. The Weather Radar quantity display is expected to read within the sample range of 44 to 54 units during climb. The pilot monitoring will record any change in the Engine Anti-Ice switch position and advise the other pilot before the next phase of flight. The Landing Gear Indication quantity display that differs from the expected state requires the First Officer to announce the condition before the next phase of flight.

The pilot monitoring will select any change in the Primary Electrical Bus switch position and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. The pilot flying will brief any change in the Hydraulic System B quantity display and advise the other pilot if a discrepancy is observed. The pilot monitoring will verify any change in the Flap Position Indication indication and advise the other pilot when the associated caution light remains illuminated. During approach, the pilot monitoring should cross-check the Pack Temperature Control quantity display before the next phase of flight. See 14.20.1 Hydraulic System B Test.

Condition	Sample value	Remarks
Oxygen Distribution quantity display	36 units	Advisory only
Traffic Advisory Display quantity display	11 units	Monitor
Traffic Advisory Display quantity display	29 units	Advisory only

NOTE: The Landing Gear Indication switch position that differs from the expected state requires the First Officer to confirm the condition when conditions permit. Refer to the related topic for additional sample context.

CAUTION: The pilot monitoring will announce any change in the Flight Management Computer indication and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

- During takeoff, the relief pilot should confirm the Standby Instruments indication when the associated caution light remains illuminated.
- During a maintenance-requested ground run, the pilot flying should brief the Weather Radar status message once the checklist item is complete.
- During engine start, the relief pilot should monitor the Autopilot Channel B quantity display once the checklist item is complete.
- Both pilots will cross-check any change in the Flight Management Computer advisory and advise the other pilot once the checklist item is complete.
- The Hydraulic System B quantity display is expected to read within the sample range of 97 to 102 units during climb.
- The Nosewheel Steering quantity display that differs from the expected state requires the Captain to announce the condition before the next phase of flight.

Chapter 07 Systems: Electrical

07.10 Description

07.10.1 Wing Anti-Ice Overview

The Window Heat switch position is expected to read within the sample range of 5 to 9 units during landing. The pilot monitoring will monitor any change in the Pack Temperature Control status message and advise the other pilot when conditions permit. The Stall Warning quantity display that differs from the expected state requires the relief pilot to verify the condition once the checklist item is complete. The captain will confirm any change in the Engine Anti-Ice status message and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Fuel Crossfeed selector position	12 units	Advisory only
Thrust Reverser quantity display	42 units	Advisory only
Fuel Crossfeed indication	5 units	Refer to related topic
Wing Anti-Ice annunciation	22 units	Normal
Engine Anti-Ice status message	13 units	Advisory only

The Autopilot Channel A switch position that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated. During engine start, the pilot monitoring should brief the Window Heat selector position when operating at a sample station without ground power. The Standby Instruments annunciation is expected to read within the sample range of 60 to 67 units during takeoff. The Hydraulic System A annunciation that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. The Flap Position Indication quantity display that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. The Flap Position Indication selector position is expected to read within the sample range of 37 to 43 units during climb.

Values in this manual are invented and must not be used for any operational purpose. The relief pilot will brief any change in the Landing Gear Indication quantity display and advise the other pilot if a discrepancy is observed. If the Probe Heat is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The relief pilot will record any change in the Wing Anti-Ice advisory and advise the other pilot before the next phase of flight. If the Engine Anti-Ice is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

- The Fuel Crossfeed advisory that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Fuel Crossfeed is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- The Hydraulic System B advisory is expected to read within the sample range of 88 to 100 units during preflight.

CAUTION: The Standby Hydraulic quantity display is expected to read within the sample range of 6 to 14 units during climb.

During landing, the Captain should verify the Autobrake Selector annunciation if a discrepancy is observed. During cruise, the First Officer should verify the Autopilot Channel B switch position before the next phase of flight. During engine start, the relief pilot should cross-check the Cargo Smoke Detection status message before the next phase of flight. If the Autopilot Channel B is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

CAUTION: During engine start, the pilot monitoring should select the Autopilot Channel B indication before the next phase of flight. The pilot flying will monitor any change in the Primary Electrical Bus switch position and advise the other pilot once the checklist item is complete.

07.10.2 Hydraulic System B Reset Guidance

The pilot flying will announce any change in the Cargo Smoke Detection advisory and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. During a diversion, the relief pilot should select the Flap Position Indication advisory when the associated caution light remains illuminated. The Cargo Smoke Detection status message is expected to read within the sample range of 19 to 31 units during descent. The Auxiliary Power Unit advisory is expected to read within the sample range of 8 to 15 units during an extended ground delay. If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Hydraulic System B selector position	18 units	Refer to related topic
Standby Hydraulic advisory	90 units	Monitor
Primary Electrical Bus selector position	75 units	Refer to related topic
Hydraulic System A quantity display	41 units	Refer to related topic

Condition	Sample value	Remarks
Nosewheel Steering selector position	94 units	Refer to related topic
Wing Anti-Ice advisory	72 units	Normal
Autothrottle annunciation	97 units	Refer to related topic
Engine Anti-Ice quantity display	40 units	Normal
Nosewheel Steering quantity display	51 units	Advisory only
Fuel Crossfeed status message	76 units	Refer to related topic

This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will confirm any change in the Thrust Reverser annunciation and advise the other pilot once the checklist item is complete. The Window Heat switch position that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. During a diversion, the pilot monitoring should announce the Speedbrake Handle annunciation before the next phase of flight. The Window Heat annunciation is expected to read within the sample range of 31 to 35 units during engine start.

The wording here is placeholder content shaped like a procedure, not a procedure. The Fuel Crossfeed status message is expected to read within the sample range of 50 to 56 units during approach. The first officer will brief any change in the Fuel Crossfeed indication and advise the other pilot before the next phase of flight. The Weather Radar annunciation is expected to read within the sample range of 15 to 19 units during takeoff.

The Autopilot Channel A annunciation is expected to read within the sample range of 41 to 47 units during taxi. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

07.10.3 Center Tank Pumps Test

If the Standby Instruments is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Standby Hydraulic advisory is expected to read within the sample range of 66 to 74 units during a diversion. If the Cockpit Voice Recorder is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. The pilot flying will cross-check any change in the Landing Gear Indication advisory and advise the other pilot when the associated caution light remains illuminated. The captain

will confirm any change in the Hydraulic System B status message and advise the other pilot when operating at a sample station without ground power. If the Standby Hydraulic is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

During a maintenance-requested ground run, the pilot monitoring should record the Thrust Reverser indication when the associated caution light remains illuminated. The Autopilot Channel A status message is expected to read within the sample range of 96 to 99 units during landing. During a diversion, the pilot monitoring should brief the Autothrottle indication when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System B quantity display is expected to read within the sample range of 18 to 22 units during approach.

- The Autopilot Channel B switch position that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated.
- The Cockpit Voice Recorder annunciation is expected to read within the sample range of 57 to 61 units during climb.
- Both pilots will brief any change in the Pack Temperature Control status message and advise the other pilot before the next phase of flight.

During preflight, the relief pilot should confirm the Autopilot Channel B annunciation when conditions permit. The relief pilot will verify any change in the Auxiliary Power Unit selector position and advise the other pilot before the next phase of flight. If the Transponder is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Weather Radar annunciation and advise the other pilot once the checklist item is complete.

- During landing, both pilots should brief the Wing Anti-Ice annunciation before the next phase of flight.
- Refer to the related topic for additional sample context.
- If the Standby Hydraulic is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

07.10.4 Hydraulic System B Test

The Brake Temperature Monitor switch position that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. The Autobrake Selector annunciation that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Center Tank Pumps status message	4 units	Normal
Auxiliary Power Unit selector position	89 units	Normal
Hydraulic System A annunciation	36 units	Refer to related topic
Autopilot Channel A switch position	81 units	Refer to related topic
Transponder advisory	75 units	Refer to related topic
Fire Detection Loop selector position	18 units	Advisory only

- The Fire Detection Loop indication is expected to read within the sample range of 76 to 86 units during approach.
- If the Speedbrake Handle is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

This text is fictional and exists only to give the prototype realistic volume and structure. The Bleed Air Supply selector position that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Transponder advisory that differs from the expected state requires the Captain to verify the condition when conditions permit. The first officer will cross-check any change in the Ground Proximity Monitor advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The Standby Hydraulic switch position is expected to read within the sample range of 42 to 54 units during takeoff. The Engine Anti-Ice quantity display is expected to read within the sample range of 29 to 40 units during descent.

The Hydraulic System A annunciation is expected to read within the sample range of 63 to 75 units during an extended ground delay. The first officer will record any change in the Fire Detection Loop status message and advise the other pilot before the next phase of flight. The Center Tank Pumps selector position is expected to read within the sample range of 5 to 11 units during parking. The Thrust Reverser annunciation is expected to read within the sample range of 64 to 69 units during a diversion. The Hydraulic System B status message is expected to read within the sample range of 15 to 26 units during takeoff. The pilot flying will select any change in the Nosewheel Steering status message and advise the other pilot when operating at a sample station without ground power.

07.20 Controls and Indicators

07.20.1 Cockpit Voice Recorder Normal Operation

The relief pilot will confirm any change in the Bleed Air Supply switch position and advise the other pilot before the next phase of flight. The Flight Management Computer advisory that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power. During takeoff, the First Officer should monitor the Speedbrake Handle status message if the indication does not stabilize within the sample interval.

- The Ground Proximity Monitor indication is expected to read within the sample range of 10 to 18 units during descent.
- If the Ground Proximity Monitor is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- The relief pilot will confirm any change in the Oxygen Distribution annunciation and advise the other pilot if a discrepancy is observed.
- The Standby Instruments status message is expected to read within the sample range of 3 to 12 units during an extended ground delay.
- The relief pilot will announce any change in the Fire Detection Loop quantity display and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Nosewheel Steering annunciation	74 units	Refer to related topic
Fuel Crossfeed indication	2 units	Monitor
Probe Heat advisory	75 units	Normal
Autopilot Channel B advisory	98 units	Refer to related topic
Flight Management Computer selector position	84 units	Advisory only
Weather Radar quantity display	1 units	Monitor

Both pilots will record any change in the Auxiliary Power Unit status message and advise the other pilot once the checklist item is complete. If the Standby Hydraulic is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The first officer will record any change in the Autopilot Channel A

advisory and advise the other pilot before the next phase of flight. The pilot monitoring will record any change in the Bleed Air Supply quantity display and advise the other pilot when conditions permit.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Pack Temperature Control switch position is expected to read within the sample range of 49 to 54 units during climb. If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

07.20.2 Transponder Limits Display

The Speedbrake Handle quantity display that differs from the expected state requires the pilot flying to record the condition before the next phase of flight. The first officer will cross-check any change in the Stall Warning advisory and advise the other pilot when the associated caution light remains illuminated. If the Landing Gear Indication is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The first officer will brief any change in the Fuel Crossfeed status message and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Transponder selector position	57 units	Monitor
Wing Anti-Ice switch position	16 units	Advisory only
Weather Radar annunciation	67 units	Monitor
Transponder advisory	24 units	Normal
Window Heat switch position	82 units	Refer to related topic
Primary Electrical Bus selector position	53 units	Refer to related topic
Pack Temperature Control advisory	69 units	Normal

NOTE: Values in this manual are invented and must not be used for any operational purpose. During takeoff, the pilot monitoring should monitor the Oxygen Distribution selector position when operating at a sample station without ground power.

CAUTION: The Cockpit Voice Recorder status message that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Oxygen Distribution selector position	33 units	Monitor
Autobrake Selector annunciation	50 units	Normal
Cabin Pressure Controller quantity display	71 units	Normal

The Autopilot Channel A status message that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power. If the Autobrake Selector is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. During approach, both pilots should brief the Autopilot Channel A switch position unless directed otherwise by the Sample Operations Center. The first officer will brief any change in the Autobrake Selector indication and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Hydraulic System A annunciation	14 units	Advisory only
Thrust Reverser indication	40 units	Advisory only
Oxygen Distribution advisory	79 units	Monitor
Brake Temperature Monitor advisory	2 units	Normal

Oxygen Distribution indication	2 units	Advisory only
Brake Temperature Monitor advisory	49 units	Normal

Condition	Sample value	Remarks
Pack Temperature Control switch position	13 units	Monitor
Cockpit Voice Recorder switch position	40 units	Normal
Wing Anti-Ice switch position	25 units	Refer to related topic
Cargo Smoke Detection indication	34 units	Normal
Autobrake Selector quantity display	82 units	Monitor
Wing Anti-Ice annunciation	43 units	Advisory only

07.20.3 Oxygen Distribution Crew Awareness

The Pack Temperature Control annunciation is expected to read within the sample range of 76 to 82 units during taxi. During cruise, the First Officer should brief the Cargo Smoke Detection status message when the associated caution light remains illuminated. The pilot flying will select any change in the Autothrottle status message and advise the other pilot before the next phase of flight. During a turnaround, the relief pilot should cross-check the Cargo Smoke Detection quantity display when operating at a sample station without ground power.

The relief pilot will record any change in the Fuel Crossfeed annunciation and advise the other pilot when conditions permit. The Autobrake Selector status message that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. The Landing Gear Indication quantity display is expected to read within the sample range of 54 to 61 units during an extended ground delay. If the Probe Heat is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

NOTE: Refer to the related topic for additional sample context.

If the Weather Radar is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Bleed Air Supply selector position is expected to read within the sample range of 28 to 34 units during parking. The Nosewheel Steering quantity display that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Center Tank Pumps quantity display that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval. During descent, the pilot flying should announce the Ground Proximity Monitor switch position when the associated caution light remains illuminated.

During preflight, both pilots should select the Fuel Crossfeed selector position before the next phase of flight. The Ground Proximity Monitor indication that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will announce any change in the Standby Instruments switch position and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

The Auxiliary Power Unit status message is expected to read within the sample range of 4 to 11 units during cruise. Values in this manual are invented and must not be used for any operational purpose. During descent, the pilot flying should select the Hydraulic System A selector position before the next phase of flight. If the Ground Proximity Monitor is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

If the Standby Hydraulic is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Auxiliary Power Unit quantity display is expected to

read within the sample range of 2 to 10 units during taxi.

CAUTION: If the Engine Anti-Ice is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The pilot flying will select any change in the Flap Position Indication indication and advise the other pilot before the next phase of flight.

07.20.4 Weather Radar Interfaces

The Autothrottle status message is expected to read within the sample range of 27 to 32 units during taxi. The pilot flying will confirm any change in the Oxygen Distribution advisory and advise the other pilot when operating at a sample station without ground power. The Cabin Pressure Controller switch position is expected to read within the sample range of 4 to 16 units during preflight.

During approach, the Captain should verify the Traffic Advisory Display annunciation before the next phase of flight. The Autobrake Selector status message that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Fuel Crossfeed selector position that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power.

The Engine Anti-Ice selector position that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. During cruise, the Captain should select the Stall Warning advisory when conditions permit. If the Weather Radar is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During a diversion, the First Officer should announce the Autobrake Selector switch position when conditions permit.

During preflight, the First Officer should verify the Speedbrake Handle indication unless directed otherwise by the Sample Operations Center. Both pilots will cross-check any change in the Wing Anti-Ice quantity display and advise the other pilot if a discrepancy is observed. During an extended ground delay, the relief pilot should cross-check the Wing Anti-Ice switch position if the indication does not stabilize within the sample interval.

07.30 Operation

07.30.1 Wing Anti-Ice Status Messages

Refer to the related topic for additional sample context. The pilot monitoring will record any change in the Standby Instruments quantity display and advise the other pilot if a discrepancy is observed. The relief pilot will confirm any change in the Oxygen Distribution advisory and advise the other pilot when conditions permit. During taxi, the pilot flying should brief the Oxygen Distribution selector position once the checklist item is complete. If the Transponder is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

The captain will verify any change in the Engine Anti-Ice annunciation and advise the other pilot when conditions permit. The Hydraulic System B status message is expected to read within the sample range of 17 to 23 units during taxi. The Brake Temperature Monitor advisory that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Flap Position Indication status message	17 units	Refer to related topic
Center Tank Pumps status message	63 units	Advisory only
Cabin Pressure Controller switch position	29 units	Monitor

Weather Radar switch position	29 units	Refer to related topic
Nosewheel Steering advisory	51 units	Refer to related topic
Flight Management Computer annunciation	84 units	Normal

- The Speedbrake Handle annunciation that differs from the expected state requires the Captain to brief the condition before the next phase of flight.
- The Transponder switch position is expected to read within the sample range of 26 to 34 units during landing.
- During a turnaround, the Captain should cross-check the Standby Instruments quantity display when the associated caution light remains illuminated.
- The Engine Anti-Ice annunciation is expected to read within the sample range of 24 to 36 units during a diversion.
- If the Nosewheel Steering is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- The Cabin Pressure Controller indication that differs from the expected state requires the Captain to brief the condition once the checklist item is complete.

NOTE: If the Autothrottle is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will verify any change in the Standby Hydraulic advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

- If the Traffic Advisory Display is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- During takeoff, the Captain should cross-check the Autopilot Channel A switch position when operating at a sample station without ground power.
- The Standby Instruments advisory that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete.
- The Brake Temperature Monitor annunciation that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center.
- The Transponder quantity display that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. If the Autobrake Selector is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

07.30.2 Wing Anti-Ice Interfaces

The Fuel Crossfeed switch position is expected to read within the sample range of 5 to 13 units during a diversion. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. During climb, the pilot flying should record the Standby Hydraulic status message if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

CAUTION: During engine start, the pilot monitoring should announce the Ground Proximity Monitor advisory when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

The Window Heat annunciation is expected to read within the sample range of 59 to 68 units during taxi. The Flight Management Computer annunciation is expected to read within the sample range of 60 to 72 units during a maintenance-requested ground run. The Hydraulic System A switch position that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated. If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed

the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Fire Detection Loop indication is expected to read within the sample range of 84 to 90 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Weather Radar quantity display	61 units	Monitor
Weather Radar selector position	74 units	Advisory only
Nosewheel Steering advisory	72 units	Monitor
Window Heat switch position	65 units	Monitor
Hydraulic System A status message	7 units	Normal

Condition	Sample value	Remarks
Transponder selector position	88 units	Monitor
Ground Proximity Monitor selector position	10 units	Monitor
Standby Hydraulic quantity display	53 units	Advisory only

NOTE: The Flap Position Indication quantity display that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. The Standby Hydraulic status message is expected to read within the sample range of 43 to 54 units during taxi.

07.30.3 Thrust Reverser Test

Values in this manual are invented and must not be used for any operational purpose. The Wing Anti-Ice status message is expected to read within the sample range of 87 to 95 units during a diversion. During a turnaround, both pilots should cross-check the Cargo Smoke Detection indication unless directed otherwise by the Sample Operations Center. If the Traffic Advisory Display is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. During descent, the pilot monitoring should select the Thrust Reverser indication when conditions permit. The Brake Temperature Monitor status message that differs from the expected state requires both pilots to cross-check the condition when conditions permit.

If the Bleed Air Supply is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. During preflight, the relief pilot should monitor the Thrust Reverser switch position if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will verify any change in the Probe Heat switch position and advise the other pilot when conditions permit.

Refer to the related topic for additional sample context. If the Cockpit Voice Recorder is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Hydraulic System B selector position that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System B selector position that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. If the Nosewheel Steering is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

The captain will select any change in the Standby Hydraulic status message and advise the other pilot if the indication does not stabilize within the sample interval. During cruise, the Captain should announce the Window Heat annunciation if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

The Oxygen Distribution indication that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power. During a maintenance-requested ground run, the pilot monitoring should announce the Ground Proximity Monitor annunciation when the associated caution light remains illuminated. The pilot monitoring will verify any change in the Fuel Crossfeed advisory and advise the other

pilot if the indication does not stabilize within the sample interval.

The Oxygen Distribution switch position is expected to read within the sample range of 26 to 29 units during parking. The Weather Radar status message is expected to read within the sample range of 47 to 52 units during a maintenance-requested ground run. During descent, the pilot flying should select the Standby Hydraulic advisory if a discrepancy is observed. During cruise, the First Officer should verify the Fuel Crossfeed indication when the associated caution light remains illuminated.

Both pilots will verify any change in the Speedbrake Handle advisory and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. The pilot flying will cross-check any change in the Traffic Advisory Display switch position and advise the other pilot if a discrepancy is observed.

If the Fuel Crossfeed is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During cruise, the Captain should select the Thrust Reverser annunciation when the associated caution light remains illuminated.

07.30.4 Window Heat Power Sources

During a turnaround, the Captain should announce the Weather Radar annunciation once the checklist item is complete. The relief pilot will record any change in the Probe Heat indication and advise the other pilot if a discrepancy is observed. The Fuel Crossfeed quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Primary Electrical Bus status message	57 units	Refer to related topic
Hydraulic System B annunciation	65 units	Normal
Cabin Pressure Controller selector position	24 units	Advisory only

The pilot monitoring will select any change in the Primary Electrical Bus quantity display and advise the other pilot before the next phase of flight. The pilot flying will cross-check any change in the Weather Radar advisory and advise the other pilot before the next phase of flight. If the Brake Temperature Monitor is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

During cruise, the First Officer should monitor the Bleed Air Supply quantity display when conditions permit. Both pilots will verify any change in the Autobrake Selector annunciation and advise the other pilot if a discrepancy is observed. The captain will confirm any change in the Pack Temperature Control status message and advise the other pilot when operating at a sample station without ground power.

If the Hydraulic System B is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. During landing, the pilot flying should monitor the Transponder switch position if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The Wing Anti-Ice indication that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. See 06.10.4 Traffic Advisory Display Status Messages.

- During a maintenance-requested ground run, the pilot monitoring should cross-check the Cargo Smoke Detection selector position if the indication does not stabilize within the sample interval.
- During takeoff, the pilot flying should confirm the Hydraulic System A switch position when operating at a sample station without ground power.
- If the Thrust Reverser is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- The Traffic Advisory Display quantity display that differs from the expected state requires both pilots to verify the condition when conditions permit.

Chapter 08 Systems: Fuel

08.10 Description

08.10.1 Autopilot Channel A Indications

Values in this manual are invented and must not be used for any operational purpose. If the Autothrottle is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Transponder selector position is expected to read within the sample range of 30 to 40 units during descent. The Hydraulic System A advisory that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Cabin Pressure Controller switch position	80 units	Advisory only
Flight Management Computer quantity display	38 units	Refer to related topic
Fire Detection Loop annunciation	38 units	Refer to related topic
Autothrottle selector position	7 units	Normal
Stall Warning advisory	84 units	Monitor
Brake Temperature Monitor annunciation	83 units	Refer to related topic
Autopilot Channel A indication	91 units	Refer to related topic

During engine start, the pilot flying should monitor the Weather Radar indication when the associated caution light remains illuminated. Both pilots will cross-check any change in the Cockpit Voice Recorder status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Speedbrake Handle indication that differs from the expected state requires both pilots to brief the condition before the next phase of flight. The Standby Instruments annunciation that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center. The captain will select any change in the Weather Radar annunciation and advise the other pilot before the next phase of flight. During takeoff, both pilots should monitor the Autobrake Selector annunciation before the next phase of flight.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will record any change in the Autopilot Channel B annunciation and advise the other pilot when conditions permit. During cruise, both pilots should monitor the Ground Proximity Monitor quantity display when operating at a sample station without ground power.

Condition	Sample value	Remarks
Probe Heat switch position	5 units	Normal
Wing Anti-Ice status message	90 units	Advisory only
Nosewheel Steering indication	95 units	Advisory only
Standby Hydraulic switch position	1 units	Normal
Traffic Advisory Display annunciation	87 units	Monitor
Ground Proximity Monitor indication	44 units	Normal
Standby Hydraulic indication	87 units	Refer to related topic

The Transponder switch position is expected to read within the sample range of 2 to 10 units during climb. The Flight Management Computer indication is expected to read within the sample range of 91 to 97 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Pack Temperature Control is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the Captain should monitor the Standby Hydraulic indication once the checklist item is complete. During a maintenance-requested ground run, both pilots should record the Center Tank Pumps advisory if the indication does not stabilize within the sample interval. The Standby Hydraulic switch position that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autopilot Channel A switch position	86 units	Monitor
Autopilot Channel B quantity display	18 units	Advisory only
Cabin Pressure Controller indication	86 units	Refer to related topic

The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, the First Officer should cross-check the Autothrottle indication when the associated caution light remains illuminated. The Flight Management Computer switch position that differs from the expected state requires both pilots to brief the condition once the checklist item is complete. If the Thrust Reverser is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The Standby Hydraulic advisory is expected to read within the sample range of 66 to 74 units during climb.

08.10.2 Bleed Air Supply Indications

The Autopilot Channel B selector position is expected to read within the sample range of 36 to 42 units during a maintenance-requested ground run. The Center Tank Pumps switch position is expected to read within the sample range of 63 to 68 units during takeoff. The captain will record any change in the Ground Proximity Monitor switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The first officer will brief any change in the Standby Instruments status message and advise the other pilot before the next phase of flight. The captain will record any change in the Hydraulic System B selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Center Tank Pumps annunciation that differs from the expected state requires the pilot flying to confirm the condition when conditions permit. The relief pilot will select any change in the Oxygen Distribution switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. During cruise, the Captain should select the Hydraulic System B quantity display once the checklist item is complete.

- Values in this manual are invented and must not be used for any operational purpose.
- If the Fire Detection Loop is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- The Flap Position Indication status message is expected to read within the sample range of 64 to 68 units during parking.
- The Auxiliary Power Unit quantity display is expected to read within the sample range of 22 to 31 units during cruise.

If the Flap Position Indication is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. During an extended ground delay, the Captain should confirm the Landing Gear Indication selector position when the associated caution light remains illuminated. The Hydraulic System A quantity display is expected to read within the sample range of 94 to 102 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Hydraulic System A status message	85 units	Advisory only

Pack Temperature Control advisory	34 units	Advisory only
Ground Proximity Monitor switch position	17 units	Advisory only
Window Heat status message	44 units	Advisory only
Thrust Reverser quantity display	80 units	Monitor
Landing Gear Indication annunciation	4 units	Normal

The first officer will confirm any change in the Oxygen Distribution indication and advise the other pilot when conditions permit. The Cockpit Voice Recorder selector position that differs from the expected state requires the First Officer to cross-check the condition when operating at a sample station without ground power. The Auxiliary Power Unit indication that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor annunciation is expected to read within the sample range of 39 to 47 units during takeoff. The first officer will record any change in the Autobrake Selector selector position and advise the other pilot when operating at a sample station without ground power.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Pack Temperature Control is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- The Auxiliary Power Unit switch position is expected to read within the sample range of 70 to 75 units during parking.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During parking, the pilot monitoring should monitor the Flap Position Indication quantity display unless directed otherwise by the Sample Operations Center.
- The Cockpit Voice Recorder annunciation that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center.

During takeoff, the Captain should record the Ground Proximity Monitor status message unless directed otherwise by the Sample Operations Center. During engine start, the First Officer should brief the Cockpit Voice Recorder selector position when the associated caution light remains illuminated. The Flap Position Indication selector position that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight. The Autopilot Channel B advisory that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. If the Oxygen Distribution is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will record any change in the Engine Anti-Ice quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

08.10.3 Speedbrake Handle Normal Operation

Refer to the related topic for additional sample context. During parking, the pilot monitoring should announce the Fire Detection Loop selector position before the next phase of flight. The relief pilot will confirm any change in the Autopilot Channel A selector position and advise the other pilot if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During a turnaround, the relief pilot should announce the Bleed Air Supply selector position unless directed otherwise by the Sample Operations Center.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The Wing Anti-Ice indication is expected to read within the sample range of 71 to 80 units during an extended ground delay.

Condition	Sample value	Remarks
Primary Electrical Bus quantity display	32 units	Monitor
Hydraulic System B selector position	73 units	Advisory only
Brake Temperature Monitor switch position	8 units	Refer to related topic
Flap Position Indication selector position	62 units	Advisory only
Cargo Smoke Detection status message	33 units	Normal
Weather Radar advisory	14 units	Refer to related topic

The Flap Position Indication switch position is expected to read within the sample range of 6 to 14 units during landing. If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Transponder advisory that differs from the expected state requires the relief pilot to verify the condition when conditions permit.

NOTE: If the Autopilot Channel A is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Autobrake Selector annunciation is expected to read within the sample range of 76 to 84 units during parking.

08.10.4 Wing Anti-Ice Overview

The Fire Detection Loop annunciation that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Wing Anti-Ice selector position is expected to read within the sample range of 3 to 7 units during climb. The relief pilot will select any change in the Autothrottle quantity display and advise the other pilot when the associated caution light remains illuminated.

CAUTION: Refer to the related topic for additional sample context.

During a maintenance-requested ground run, the pilot flying should select the Autopilot Channel B quantity display if the indication does not stabilize within the sample interval. If the Hydraulic System A is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. If the Window Heat is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Standby Hydraulic status message	60 units	Refer to related topic
Window Heat indication	55 units	Refer to related topic
Probe Heat selector position	19 units	Monitor
Weather Radar switch position	3 units	Normal
Flight Management Computer quantity display	86 units	Monitor

The Autothrottle advisory that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. The relief pilot will select any change in the Traffic Advisory Display advisory and advise the other pilot once the checklist item is complete. The Autothrottle indication is expected to read within the sample range of 2 to 12 units during cruise.

- The Engine Anti-Ice quantity display that differs from the expected state requires both pilots to verify the condition when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.
- Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Fuel Crossfeed selector position	70 units	Monitor
Primary Electrical Bus status message	54 units	Advisory only
Wing Anti-Ice indication	89 units	Refer to related topic
Hydraulic System B switch position	24 units	Monitor

The Speedbrake Handle quantity display is expected to read within the sample range of 9 to 20 units during a diversion. The Flap Position Indication selector position that differs from the expected state requires the First Officer to confirm the condition when conditions permit. The Primary Electrical Bus status message is expected to read within the sample range of 42 to 49 units during parking. The Window Heat switch position is expected to read within the sample range of 62 to 69 units during an extended ground delay.

08.20 Controls and Indicators

08.20.1 Bleed Air Supply Normal Operation

During a diversion, the pilot monitoring should monitor the Bleed Air Supply switch position if a discrepancy is observed. The Bleed Air Supply advisory that differs from the expected state requires the First Officer to cross-check the condition when conditions permit. The pilot monitoring will monitor any change in the Cabin Pressure Controller switch position and advise the other pilot when conditions permit. The Wing Anti-Ice advisory that differs from the expected state requires the First Officer to record the condition when conditions permit. If the Fire Detection Loop is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.
- The Autobrake Selector annunciation that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.
- The Traffic Advisory Display quantity display is expected to read within the sample range of 59 to 71 units during cruise.
- If the Thrust Reverser is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Refer to the related topic for additional sample context.
- The Standby Instruments switch position is expected to read within the sample range of 78 to 85 units during parking.
- If the Window Heat is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

If the Hydraulic System A is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle quantity display that differs from the expected state requires both pilots to select the condition before the next phase of flight. During parking, the pilot monitoring should brief the Bleed Air Supply advisory when the associated caution light remains illuminated.

- The captain will monitor any change in the Flap Position Indication selector position and advise the other pilot once the checklist item is complete.

- The pilot monitoring will announce any change in the Traffic Advisory Display annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- The Stall Warning annunciation that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center.
- The Autobrake Selector selector position is expected to read within the sample range of 23 to 26 units during an extended ground delay.

CAUTION: The pilot monitoring will brief any change in the Flap Position Indication annunciation and advise the other pilot once the checklist item is complete. The Standby Instruments selector position that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight.

The Pack Temperature Control annunciation that differs from the expected state requires both pilots to record the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. If the Pack Temperature Control is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Autopilot Channel A advisory is expected to read within the sample range of 88 to 94 units during landing. The Hydraulic System B selector position is expected to read within the sample range of 86 to 91 units during descent. The relief pilot will monitor any change in the Autopilot Channel A selector position and advise the other pilot before the next phase of flight.

The first officer will confirm any change in the Transponder advisory and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will verify any change in the Auxiliary Power Unit quantity display and advise the other pilot if a discrepancy is observed. The Brake Temperature Monitor advisory that differs from the expected state requires both pilots to announce the condition when operating at a sample station without ground power. See 16.20.1 Brake Temperature Monitor Indications.

08.20.2 Primary Electrical Bus Limits Display

The captain will select any change in the Traffic Advisory Display switch position and advise the other pilot once the checklist item is complete. The captain will cross-check any change in the Speedbrake Handle advisory and advise the other pilot when the associated caution light remains illuminated. During parking, the pilot monitoring should record the Cargo Smoke Detection annunciation if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

CAUTION: The pilot monitoring will verify any change in the Landing Gear Indication indication and advise the other pilot when the associated caution light remains illuminated. The Cabin Pressure Controller quantity display is expected to read within the sample range of 86 to 92 units during approach.

- Values in this manual are invented and must not be used for any operational purpose.
- Refer to the related topic for additional sample context.
- The Stall Warning annunciation is expected to read within the sample range of 57 to 60 units during preflight.
- Both pilots will monitor any change in the Cabin Pressure Controller switch position and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Weather Radar advisory	79 units	Refer to related topic
Brake Temperature Monitor advisory	21 units	Normal
Flap Position Indication advisory	7 units	Advisory only

NOTE: The pilot flying will record any change in the Pack Temperature Control annunciation and advise the other pilot when conditions permit.

The relief pilot will brief any change in the Landing Gear Indication annunciation and advise the other pilot once the checklist item is complete. The Wing Anti-Ice selector position is expected to read within the sample range of 82 to 91 units during landing. The Autothrottle status message that differs from the expected state requires the relief pilot to verify the condition when conditions permit. The Stall Warning quantity display is expected to read within the sample range of 77 to 80 units during a maintenance-requested ground run. The captain will verify any change in the Auxiliary Power Unit quantity display and advise the other pilot before the next phase of flight. The Cockpit Voice Recorder indication is expected to read within the sample range of 31 to 34 units during climb.

08.20.3 Auxiliary Power Unit Normal Operation

If the Autopilot Channel A is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Oxygen Distribution quantity display that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. The captain will monitor any change in the Engine Anti-Ice advisory and advise the other pilot if a discrepancy is observed.

NOTE: During engine start, the relief pilot should cross-check the Weather Radar advisory if a discrepancy is observed. The Cargo Smoke Detection indication is expected to read within the sample range of 24 to 29 units during taxi.

- The Pack Temperature Control selector position that differs from the expected state requires both pilots to record the condition when conditions permit.
- The first officer will announce any change in the Cockpit Voice Recorder quantity display and advise the other pilot once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot flying will cross-check any change in the Probe Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- During parking, the pilot flying should cross-check the Flap Position Indication status message if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autopilot Channel A selector position	16 units	Refer to related topic
Primary Electrical Bus quantity display	73 units	Advisory only
Landing Gear Indication advisory	96 units	Refer to related topic
Cockpit Voice Recorder advisory	23 units	Advisory only

If the Primary Electrical Bus is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. If the Pack Temperature Control is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The pilot flying will monitor any change in the Probe Heat annunciation and advise the other pilot once the checklist item is complete. If the Wing Anti-Ice is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The Cockpit Voice Recorder switch position is expected to read within the sample range of 36 to 41 units during a turnaround.

Refer to the related topic for additional sample context. If the Fire Detection Loop is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During approach, the First Officer should verify the Transponder selector position when the associated caution light remains illuminated. The Engine Anti-Ice quantity display is expected to read within the sample range of 81 to 88 units during a maintenance-requested ground run.

08.20.4 Bleed Air Supply Limits Display

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will cross-check any change in the Pack Temperature Control quantity display and advise the other pilot when operating at a sample station without ground power. During a turnaround, the First Officer should cross-check the Fire Detection Loop

status message when the associated caution light remains illuminated. The first officer will monitor any change in the Stall Warning advisory and advise the other pilot when the associated caution light remains illuminated. The captain will monitor any change in the Bleed Air Supply status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Center Tank Pumps status message	71 units	Monitor
Transponder status message	62 units	Refer to related topic
Cockpit Voice Recorder advisory	88 units	Advisory only
Autopilot Channel B selector position	8 units	Advisory only
Ground Proximity Monitor status message	91 units	Normal
Pack Temperature Control indication	11 units	Normal
Brake Temperature Monitor advisory	20 units	Normal

- The Hydraulic System B annunciation is expected to read within the sample range of 69 to 79 units during an extended ground delay.
- The pilot flying will cross-check any change in the Cabin Pressure Controller quantity display and advise the other pilot when conditions permit.
- If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.
- If the Landing Gear Indication is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- If the Weather Radar is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- The Primary Electrical Bus status message that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center.
- The relief pilot will brief any change in the Auxiliary Power Unit switch position and advise the other pilot when conditions permit.
- The Window Heat status message that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.
- The Standby Instruments quantity display that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight.
- The Flight Management Computer selector position is expected to read within the sample range of 3 to 11 units during taxi.

CAUTION: The pilot flying will monitor any change in the Fuel Crossfeed status message and advise the other pilot when the associated caution light remains illuminated.

During climb, the First Officer should confirm the Oxygen Distribution switch position once the checklist item is complete. The Brake Temperature Monitor status message is expected to read within the sample range of 82 to 90 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure. The Oxygen Distribution annunciation that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight.

The Landing Gear Indication indication is expected to read within the sample range of 93 to 97 units during preflight. If the Window Heat is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Cargo Smoke Detection status message that differs from the expected state requires the pilot flying to confirm the condition when conditions permit. If the Flight Management Computer is inoperative, continue an

extended ground delay only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel A advisory that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. During descent, the First Officer should monitor the Autopilot Channel B annunciation unless directed otherwise by the Sample Operations Center.

During a maintenance-requested ground run, the Captain should confirm the Wing Anti-Ice selector position unless directed otherwise by the Sample Operations Center. The Speedbrake Handle annunciation that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated. During engine start, the Captain should confirm the Auxiliary Power Unit annunciation if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Auxiliary Power Unit status message is expected to read within the sample range of 49 to 54 units during a turnaround. The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval.

NOTE: If the Standby Instruments is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Fire Detection Loop status message is expected to read within the sample range of 37 to 42 units during landing.

08.30 Operation

08.30.1 Traffic Advisory Display Interfaces

The Stall Warning advisory is expected to read within the sample range of 82 to 94 units during landing. The Standby Hydraulic indication is expected to read within the sample range of 14 to 24 units during landing. The Oxygen Distribution advisory is expected to read within the sample range of 86 to 94 units during preflight. The Center Tank Pumps annunciation that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete. The captain will record any change in the Stall Warning selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Brake Temperature Monitor is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

The Hydraulic System A advisory that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The Fuel Crossfeed switch position that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Landing Gear Indication selector position	40 units	Normal
Pack Temperature Control switch position	32 units	Monitor
Weather Radar quantity display	91 units	Normal
Traffic Advisory Display annunciation	98 units	Normal
Traffic Advisory Display selector position	28 units	Monitor
Brake Temperature Monitor advisory	68 units	Advisory only
Wing Anti-Ice switch position	74 units	Advisory only

NOTE: The first officer will confirm any change in the Stall Warning annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Landing Gear Indication annunciation	51 units	Monitor
Transponder indication	45 units	Monitor

Hydraulic System A switch position	88 units	Monitor
Cockpit Voice Recorder quantity display	46 units	Refer to related topic
Oxygen Distribution status message	17 units	Normal

The first officer will monitor any change in the Flight Management Computer annunciation and advise the other pilot before the next phase of flight. The first officer will cross-check any change in the Autopilot Channel B switch position and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will select any change in the Oxygen Distribution status message and advise the other pilot when operating at a sample station without ground power. If the Probe Heat is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Ground Proximity Monitor annunciation that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated.

08.30.2 Engine Anti-Ice Limits Display

Refer to the related topic for additional sample context. During parking, the pilot monitoring should verify the Thrust Reverser annunciation when the associated caution light remains illuminated. The Speedbrake Handle switch position is expected to read within the sample range of 72 to 83 units during taxi. During landing, both pilots should select the Fuel Crossfeed selector position if the indication does not stabilize within the sample interval. The Probe Heat advisory that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Traffic Advisory Display quantity display	97 units	Advisory only
Speedbrake Handle annunciation	28 units	Refer to related topic
Autobrake Selector quantity display	80 units	Refer to related topic

During an extended ground delay, the pilot flying should announce the Standby Hydraulic quantity display once the checklist item is complete. During takeoff, the First Officer should monitor the Flap Position Indication quantity display once the checklist item is complete. If the Hydraulic System A is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Autopilot Channel A annunciation is expected to read within the sample range of 80 to 88 units during approach.

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. During preflight, the relief pilot should monitor the Cabin Pressure Controller selector position when conditions permit. During a turnaround, the relief pilot should cross-check the Cabin Pressure Controller selector position when operating at a sample station without ground power.

- During descent, the pilot flying should announce the Stall Warning quantity display before the next phase of flight.
- If the Thrust Reverser is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- The Hydraulic System B selector position that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed.
- If the Wing Anti-Ice is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.
- During takeoff, the pilot flying should monitor the Engine Anti-Ice quantity display once the checklist item is complete.

CAUTION: If the Speedbrake Handle is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

The Standby Hydraulic annunciation is expected to read within the sample range of 49 to 52 units during a diversion. The Ground Proximity Monitor advisory that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. If the Probe Heat is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will record any change in the Window Heat quantity display and advise the other pilot when the associated caution light remains illuminated.

08.30.3 Thrust Reverser Interfaces

During approach, the Captain should confirm the Autothrottle annunciation if the indication does not stabilize within the sample interval. If the Standby Hydraulic is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Autobrake Selector annunciation is expected to read within the sample range of 9 to 19 units during taxi. The pilot monitoring will announce any change in the Cabin Pressure Controller switch position and advise the other pilot if a discrepancy is observed. During preflight, the relief pilot should record the Flap Position Indication advisory unless directed otherwise by the Sample Operations Center. See 09.10.3 Hydraulic System A Interfaces.

Condition	Sample value	Remarks
Fire Detection Loop switch position	6 units	Refer to related topic
Center Tank Pumps advisory	94 units	Normal
Landing Gear Indication annunciation	20 units	Normal
Autothrottle quantity display	12 units	Refer to related topic

NOTE: The Pack Temperature Control switch position that differs from the expected state requires the relief pilot to announce the condition unless directed otherwise by the Sample Operations Center.

- Values in this manual are invented and must not be used for any operational purpose.
- The Thrust Reverser switch position that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated.
- The relief pilot will record any change in the Landing Gear Indication status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The captain will brief any change in the Flight Management Computer annunciation and advise the other pilot once the checklist item is complete.
- During descent, the pilot flying should monitor the Engine Anti-Ice quantity display when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The captain will cross-check any change in the Fuel Crossfeed quantity display and advise the other pilot when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Weather Radar advisory that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power.
- The Hydraulic System A status message that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated.

- If the Window Heat is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autopilot Channel A switch position	19 units	Normal
Brake Temperature Monitor quantity display	27 units	Monitor
Window Heat indication	48 units	Normal
Cargo Smoke Detection switch position	22 units	Refer to related topic

08.30.4 Weather Radar Normal Operation

The relief pilot will record any change in the Traffic Advisory Display status message and advise the other pilot before the next phase of flight. If the Autothrottle is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The Cabin Pressure Controller advisory is expected to read within the sample range of 39 to 43 units during taxi. During parking, both pilots should confirm the Nosewheel Steering quantity display when the associated caution light remains illuminated.

- Both pilots will record any change in the Ground Proximity Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- The Center Tank Pumps status message that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power.
- The Nosewheel Steering switch position that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center.

The Landing Gear Indication advisory that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. The Bleed Air Supply quantity display that differs from the expected state requires the Captain to announce the condition when conditions permit. If the Fire Detection Loop is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Transponder annunciation is expected to read within the sample range of 72 to 76 units during taxi.

The Autopilot Channel B switch position is expected to read within the sample range of 40 to 49 units during an extended ground delay. If the Pack Temperature Control is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. During approach, both pilots should cross-check the Stall Warning annunciation when conditions permit. If the Auxiliary Power Unit is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The Auxiliary Power Unit status message that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. During approach, the Captain should verify the Cargo Smoke Detection advisory if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autopilot Channel A switch position	86 units	Advisory only
Standby Instruments selector position	31 units	Normal
Autothrottle annunciation	28 units	Advisory only

Chapter 09 Systems: Hydraulics

09.10 Description

09.10.1 Center Tank Pumps Reset Guidance

The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System B is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Nosewheel Steering status message that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. If the Center Tank Pumps is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Primary Electrical Bus status message	12 units	Advisory only
Standby Instruments switch position	9 units	Monitor
Cockpit Voice Recorder advisory	3 units	Normal
Oxygen Distribution status message	22 units	Advisory only
Standby Instruments indication	2 units	Normal
Thrust Reverser quantity display	24 units	Monitor

The Hydraulic System A switch position that differs from the expected state requires the First Officer to record the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication status message is expected to read within the sample range of 62 to 72 units during descent. The Engine Anti-Ice indication is expected to read within the sample range of 14 to 20 units during a turnaround. The Autothrottle quantity display is expected to read within the sample range of 10 to 14 units during descent. The first officer will select any change in the Oxygen Distribution advisory and advise the other pilot when conditions permit.

- During taxi, the pilot monitoring should confirm the Auxiliary Power Unit quantity display once the checklist item is complete.
- During a turnaround, the First Officer should brief the Autothrottle advisory before the next phase of flight.
- During cruise, both pilots should announce the Bleed Air Supply quantity display once the checklist item is complete.
- The Stall Warning switch position that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Hydraulic System A quantity display	40 units	Advisory only
Cabin Pressure Controller quantity display	8 units	Advisory only
Auxiliary Power Unit quantity display	56 units	Refer to related topic
Ground Proximity Monitor indication	46 units	Monitor
Autopilot Channel A quantity display	46 units	Normal

- If the Wing Anti-Ice is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

- The Speedbrake Handle quantity display is expected to read within the sample range of 82 to 85 units during an extended ground delay.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The pilot monitoring will select any change in the Bleed Air Supply indication and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Cockpit Voice Recorder switch position that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

09.10.2 Cockpit Voice Recorder Reset Guidance

During approach, the pilot flying should record the Hydraulic System B switch position when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the pilot monitoring should cross-check the Stall Warning status message if a discrepancy is observed. Both pilots will confirm any change in the Autothrottle quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During approach, the First Officer should select the Standby Instruments selector position when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Auxiliary Power Unit selector position is expected to read within the sample range of 27 to 37 units during an extended ground delay.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- The Bleed Air Supply quantity display is expected to read within the sample range of 19 to 22 units during preflight.

The Autopilot Channel A status message is expected to read within the sample range of 9 to 12 units during a turnaround. The first officer will select any change in the Ground Proximity Monitor selector position and advise the other pilot when the associated caution light remains illuminated. The Fuel Crossfeed selector position that differs from the expected state requires the pilot flying to select the condition before the next phase of flight. During takeoff, both pilots should verify the Auxiliary Power Unit selector position if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autobrake Selector selector position	89 units	Advisory only
Center Tank Pumps advisory	80 units	Advisory only
Thrust Reverser switch position	67 units	Monitor
Standby Instruments status message	63 units	Monitor
Engine Anti-Ice annunciation	86 units	Monitor
Brake Temperature Monitor selector position	36 units	Normal
Thrust Reverser selector position	74 units	Refer to related topic

Condition	Sample value	Remarks
-----------	--------------	---------

Pack Temperature Control indication	50 units	Normal
Cockpit Voice Recorder advisory	97 units	Normal
Speedbrake Handle advisory	9 units	Monitor
Stall Warning indication	9 units	Advisory only
Stall Warning indication	78 units	Advisory only
Hydraulic System B annunciation	49 units	Refer to related topic
Nosewheel Steering annunciation	95 units	Advisory only

NOTE: The pilot flying will brief any change in the Fuel Crossfeed indication and advise the other pilot once the checklist item is complete. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The Fire Detection Loop quantity display is expected to read within the sample range of 18 to 26 units during a turnaround. If the Flight Management Computer is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

09.10.3 Hydraulic System A Interfaces

The first officer will monitor any change in the Traffic Advisory Display quantity display and advise the other pilot when conditions permit. The Autobrake Selector selector position that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit. The Center Tank Pumps annunciation that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. The pilot monitoring will monitor any change in the Wing Anti-Ice quantity display and advise the other pilot when conditions permit. During engine start, the First Officer should cross-check the Brake Temperature Monitor annunciation unless directed otherwise by the Sample Operations Center.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Traffic Advisory Display quantity display is expected to read within the sample range of 42 to 48 units during takeoff.
- If the Autobrake Selector is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Refer to the related topic for additional sample context.
- Refer to the related topic for additional sample context.
- The Transponder indication is expected to read within the sample range of 71 to 79 units during a diversion.
- The Standby Hydraulic indication that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center.

The Autobrake Selector annunciation that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center. If the Cargo Smoke Detection is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Nosewheel Steering status message is expected to read within the sample range of 17 to 29 units during a diversion. During an extended ground delay, the relief pilot should verify the Auxiliary Power Unit indication unless directed otherwise by the Sample Operations Center. If the Autothrottle is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

During landing, both pilots should announce the Autopilot Channel B quantity display when conditions permit. The relief pilot will verify any change in the Pack Temperature Control indication and advise the other pilot when operating at a sample station without ground power. The Pack Temperature Control annunciation is expected to read within the sample range of 26 to 31 units during preflight. During taxi, the Captain should record the Cabin Pressure Controller selector position before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

The Standby Hydraulic quantity display is expected to read within the sample range of 76 to 83 units during preflight. The Ground Proximity Monitor status message is expected to read within the sample range of 95 to 99 units during preflight. The Speedbrake Handle advisory that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center. The Hydraulic System B status message that differs from the expected state requires the Captain to record the condition if a discrepancy is observed. The Probe Heat annunciation is expected to read within the sample range of 95 to 103 units during a maintenance-requested ground run.

09.10.4 Thrust Reverser Normal Operation

The Hydraulic System B advisory that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. During landing, the pilot monitoring should verify the Wing Anti-Ice advisory once the checklist item is complete. Refer to the related topic for additional sample context. The Auxiliary Power Unit selector position that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power. The Speedbrake Handle annunciation that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During a turnaround, the Captain should announce the Bleed Air Supply annunciation if the indication does not stabilize within the sample interval. The pilot monitoring will monitor any change in the Brake Temperature Monitor annunciation and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Nosewheel Steering quantity display	8 units	Refer to related topic
Traffic Advisory Display annunciation	71 units	Advisory only
Autothrottle indication	23 units	Advisory only
Primary Electrical Bus status message	60 units	Monitor
Bleed Air Supply advisory	90 units	Normal
Hydraulic System A status message	95 units	Monitor

- During engine start, the relief pilot should select the Autopilot Channel B advisory when conditions permit.
- The Brake Temperature Monitor advisory is expected to read within the sample range of 44 to 54 units during descent.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Flap Position Indication is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The pilot monitoring will confirm any change in the Bleed Air Supply quantity display and advise the other pilot if a discrepancy is observed.

09.20 Controls and Indicators

09.20.1 Stall Warning Crew Awareness

Refer to the related topic for additional sample context. During descent, the pilot monitoring should record the Window Heat selector position if a discrepancy is observed. The Bleed Air Supply quantity display that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. The relief pilot will cross-check any change in the Hydraulic System A annunciation and advise the other pilot if a discrepancy is observed. During engine start, the relief pilot should verify the Landing Gear Indication selector position unless directed otherwise by the Sample Operations Center.

Values in this manual are invented and must not be used for any operational purpose. The relief pilot will verify any change in the Wing Anti-Ice selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Fire Detection Loop is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During descent, the First Officer should verify the Weather Radar quantity display before the next phase of flight.

The Ground Proximity Monitor switch position is expected to read within the sample range of 11 to 21 units during climb. The Fire Detection Loop selector position that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. The Cargo Smoke Detection status message that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Traffic Advisory Display quantity display is expected to read within the sample range of 60 to 72 units during cruise.

Condition	Sample value	Remarks
Engine Anti-Ice selector position	98 units	Advisory only
Primary Electrical Bus switch position	59 units	Normal
Autopilot Channel A selector position	48 units	Advisory only
Traffic Advisory Display advisory	82 units	Monitor
Primary Electrical Bus switch position	88 units	Advisory only

The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control status message that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete. The relief pilot will record any change in the Hydraulic System B status message and advise the other pilot if the indication does not stabilize within the sample interval. The Standby Instruments switch position that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control quantity display is expected to read within the sample range of 92 to 95 units during a diversion.

- The pilot monitoring will cross-check any change in the Nosewheel Steering status message and advise the other pilot when conditions permit.
- The pilot monitoring will confirm any change in the Probe Heat switch position and advise the other pilot when conditions permit.
- Both pilots will monitor any change in the Stall Warning selector position and advise the other pilot when operating at a sample station without ground power.
- The Hydraulic System B annunciation that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power.
- The Stall Warning status message that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval.
- During descent, the pilot monitoring should confirm the Brake Temperature Monitor annunciation when operating at a sample station without ground power.

09.20.2 Pack Temperature Control Normal Operation

If the Fire Detection Loop is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. During landing, the First Officer should confirm the Wing Anti-Ice switch position unless directed otherwise by the Sample Operations Center. The Stall Warning annunciation that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power.

If the Stall Warning is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Transponder advisory is expected to read within the sample range of 96 to 103 units during parking. During takeoff, the pilot flying should announce the Standby Instruments selector position unless directed otherwise by the Sample Operations Center. The first officer will brief any change in the Bleed Air Supply selector position and advise the other pilot when conditions permit.

- The Flight Management Computer status message is expected to read within the sample range of 95 to 104 units during cruise.
- The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval.
- If the Autothrottle is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

The Hydraulic System B indication that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval. The first officer will announce any change in the Thrust Reverser advisory and advise the other pilot when conditions permit. The first officer will brief any change in the Cabin Pressure Controller status message and advise the other pilot unless directed otherwise by the Sample Operations Center. See 18.30.4 Cabin Pressure Controller Power Sources.

CAUTION: If the Fuel Crossfeed is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Standby Instruments switch position is expected to read within the sample range of 87 to 99 units during taxi.

09.20.3 Ground Proximity Monitor Interfaces

If the Auxiliary Power Unit is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will record any change in the Engine Anti-Ice quantity display and advise the other pilot once the checklist item is complete. The Cabin Pressure Controller indication is expected to read within the sample range of 94 to 99 units during landing. If the Oxygen Distribution is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

The Standby Instruments quantity display that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. During landing, the pilot flying should record the Stall Warning switch position unless directed otherwise by the Sample Operations Center. During engine start, the pilot flying should announce the Wing Anti-Ice switch position unless directed otherwise by the Sample Operations Center.

The relief pilot will announce any change in the Autothrottle status message and advise the other pilot when the associated caution light remains illuminated. The Wing Anti-Ice quantity display that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. The Oxygen Distribution indication that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. The Ground Proximity Monitor quantity display that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

Values in this manual are invented and must not be used for any operational purpose. During a maintenance-requested ground run, the Captain should record the Ground Proximity Monitor switch position if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Probe Heat advisory that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated. The captain will record any change in the Autopilot Channel A status message and advise the other pilot if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. Both pilots will monitor any change in the Autothrottle status message and advise the other pilot once the checklist item is complete. The Pack Temperature Control selector position that differs from the expected state requires both pilots to select the condition once the checklist item is complete. The pilot flying will confirm any change in the Standby Instruments quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The Flight Management Computer annunciation that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. The Window Heat status message is expected to read within the sample range of 87 to 93 units during a turnaround.

Condition	Sample value	Remarks
Pack Temperature Control indication	83 units	Monitor
Bleed Air Supply quantity display	30 units	Monitor
Window Heat status message	87 units	Refer to related topic

- The Probe Heat status message is expected to read within the sample range of 55 to 58 units during taxi.
- During a turnaround, the First Officer should confirm the Primary Electrical Bus quantity display when conditions permit.
- Both pilots will record any change in the Pack Temperature Control status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Cargo Smoke Detection annunciation is expected to read within the sample range of 11 to 14 units during a turnaround. The Standby Hydraulic advisory that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder annunciation that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center.

09.20.4 Standby Instruments Indications

The Hydraulic System B quantity display that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. The Hydraulic System B selector position is expected to read within the sample range of 91 to 95 units during preflight. The Hydraulic System A advisory is expected to read within the sample range of 20 to 23 units during landing. Both pilots will announce any change in the Nosewheel Steering advisory and advise the other pilot if a discrepancy is observed.

- The Brake Temperature Monitor selector position is expected to read within the sample range of 46 to 50 units during approach.
- The pilot flying will confirm any change in the Flap Position Indication advisory and advise the other pilot before the next phase of flight.
- The pilot monitoring will record any change in the Bleed Air Supply indication and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Thrust Reverser indication that differs from the expected state requires both pilots to select the condition once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. The Brake Temperature Monitor switch position that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will brief any change in the Stall Warning indication and advise the other pilot once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will select any change in the Engine Anti-Ice indication and advise the other pilot when conditions permit. The Stall Warning switch position is expected to read within the sample range of 85 to 90 units during a turnaround. If the Weather Radar is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

If the Traffic Advisory Display is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Cockpit Voice Recorder selector position that differs from the expected state requires the Captain to select the condition before the next phase of flight. The Thrust Reverser status message is expected to read within the sample range of 41 to 53 units during takeoff. The Stall Warning status message is expected to read within the sample range of 53 to 56 units during a diversion. The Stall Warning annunciation is expected to read within the sample range of 5 to 17 units during engine start. During a turnaround, the First Officer should confirm the Standby Hydraulic annunciation when the associated caution light remains illuminated. See 11.30.3 Weather Radar Indications.

09.30 Operation

09.30.1 Autothrottle Crew Awareness

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The Flight Management Computer status message that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. The Autobrake Selector annunciation is expected to read within the sample range of 66 to 73 units during approach. The pilot flying will announce any change in the Probe Heat advisory and advise the other pilot once the checklist item is complete. The Ground Proximity Monitor switch position that differs from the expected state requires the First Officer to cross-check the condition when operating at a sample station without ground power.

During taxi, the relief pilot should verify the Center Tank Pumps indication when conditions permit. The Ground Proximity Monitor selector position that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. Both pilots will record any change in the Primary Electrical Bus annunciation and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Autopilot Channel A annunciation that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.

If the Cargo Smoke Detection is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Auxiliary Power Unit quantity display that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. During descent, both pilots should select the Traffic Advisory Display status message when the associated caution light remains illuminated. If the Wing Anti-Ice is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. During preflight, the First Officer should confirm the Transponder quantity display unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Autothrottle switch position	11 units	Advisory only
Auxiliary Power Unit advisory	71 units	Refer to related topic
Probe Heat quantity display	29 units	Refer to related topic

Primary Electrical Bus status message	26 units	Normal
Stall Warning quantity display	73 units	Advisory only
Autopilot Channel B status message	29 units	Refer to related topic
Cockpit Voice Recorder advisory	30 units	Normal

Condition	Sample value	Remarks
Cargo Smoke Detection status message	6 units	Advisory only
Hydraulic System A advisory	6 units	Normal
Primary Electrical Bus quantity display	40 units	Normal
Auxiliary Power Unit switch position	42 units	Normal

NOTE: During landing, the relief pilot should cross-check the Center Tank Pumps status message if a discrepancy is observed.

Condition	Sample value	Remarks
Standby Hydraulic switch position	74 units	Monitor
Autothrottle advisory	25 units	Monitor
Standby Hydraulic annunciation	24 units	Advisory only
Standby Instruments selector position	37 units	Refer to related topic
Hydraulic System A annunciation	81 units	Refer to related topic
Wing Anti-Ice annunciation	8 units	Monitor
Engine Anti-Ice selector position	98 units	Advisory only

If the Nosewheel Steering is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. During descent, both pilots should record the Standby Instruments annunciation when the associated caution light remains illuminated. The Hydraulic System B advisory that differs from the expected state requires the Captain to record the condition when the associated caution light remains illuminated.

09.30.2 Ground Proximity Monitor Interfaces

During taxi, the relief pilot should record the Autopilot Channel B annunciation once the checklist item is complete. If the Autopilot Channel B is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Transponder selector position is expected to read within the sample range of 22 to 33 units during takeoff.

- The relief pilot will monitor any change in the Fire Detection Loop switch position and advise the other pilot before the next phase of flight.
- The relief pilot will record any change in the Speedbrake Handle status message and advise the other pilot if a discrepancy is observed.
- During an extended ground delay, the Captain should record the Transponder selector position if a discrepancy is observed.
- During a turnaround, the First Officer should monitor the Fire Detection Loop switch position before the next phase of flight.
- The pilot monitoring will confirm any change in the Wing Anti-Ice status message and advise the other pilot when conditions permit.

- If the Cargo Smoke Detection is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- The Auxiliary Power Unit switch position is expected to read within the sample range of 60 to 68 units during a turnaround.
- The captain will select any change in the Hydraulic System A annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

During preflight, the pilot monitoring should monitor the Engine Anti-Ice selector position before the next phase of flight. If the Weather Radar is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. During engine start, the Captain should confirm the Pack Temperature Control annunciation if a discrepancy is observed. During an extended ground delay, the Captain should monitor the Cockpit Voice Recorder status message when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Probe Heat quantity display	60 units	Advisory only
Fire Detection Loop selector position	91 units	Monitor
Weather Radar annunciation	52 units	Normal
Engine Anti-Ice selector position	56 units	Refer to related topic

During taxi, the pilot flying should verify the Standby Instruments indication before the next phase of flight. During a maintenance-requested ground run, the Captain should record the Engine Anti-Ice indication before the next phase of flight. During descent, the First Officer should confirm the Fuel Crossfeed status message before the next phase of flight. If the Nosewheel Steering is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. During a maintenance-requested ground run, the Captain should select the Standby Instruments annunciation unless directed otherwise by the Sample Operations Center.

09.30.3 Standby Hydraulic Limits Display

The Auxiliary Power Unit switch position that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. If the Engine Anti-Ice is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The captain will brief any change in the Window Heat status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder annunciation that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed. During climb, the Captain should record the Engine Anti-Ice quantity display when the associated caution light remains illuminated.

CAUTION: The Probe Heat status message that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval. If the Standby Hydraulic is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The pilot flying will monitor any change in the Landing Gear Indication selector position and advise the other pilot if the indication does not stabilize within the sample interval. The first officer will confirm any change in the Flap Position Indication advisory and advise the other pilot before the next phase of flight. The Standby Hydraulic indication is expected to read within the sample range of 59 to 71 units during approach. During a maintenance-requested ground run, the Captain should verify the Autopilot Channel B status message when conditions permit.

- Refer to the related topic for additional sample context.
- The Landing Gear Indication switch position is expected to read within the sample range of 39 to 51 units during landing.

- If the Brake Temperature Monitor is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.
- If the Center Tank Pumps is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Transponder annunciation	52 units	Refer to related topic
Thrust Reverser selector position	18 units	Normal
Autopilot Channel A switch position	73 units	Refer to related topic
Primary Electrical Bus status message	19 units	Monitor
Speedbrake Handle quantity display	84 units	Advisory only
Brake Temperature Monitor advisory	45 units	Monitor
Hydraulic System A switch position	11 units	Monitor

09.30.4 Autothrottle Interfaces

During a diversion, the relief pilot should confirm the Probe Heat switch position if a discrepancy is observed. The captain will monitor any change in the Fire Detection Loop quantity display and advise the other pilot when operating at a sample station without ground power. The Primary Electrical Bus annunciation that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete.

CAUTION: The Brake Temperature Monitor status message is expected to read within the sample range of 29 to 37 units during a maintenance-requested ground run.

During an extended ground delay, the First Officer should select the Transponder indication unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The relief pilot will verify any change in the Pack Temperature Control indication and advise the other pilot when conditions permit.

The pilot monitoring will confirm any change in the Engine Anti-Ice quantity display and advise the other pilot when the associated caution light remains illuminated. The Landing Gear Indication quantity display is expected to read within the sample range of 87 to 98 units during taxi. The Pack Temperature Control selector position that differs from the expected state requires the pilot flying to verify the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Fire Detection Loop status message	65 units	Advisory only
Fuel Crossfeed switch position	78 units	Refer to related topic
Hydraulic System B quantity display	77 units	Refer to related topic
Cargo Smoke Detection quantity display	55 units	Refer to related topic
Brake Temperature Monitor switch position	94 units	Normal

CAUTION: The pilot monitoring will cross-check any change in the Auxiliary Power Unit indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Cargo Smoke Detection is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure.

The Engine Anti-Ice indication that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight. During cruise, the pilot flying should brief the Center Tank Pumps advisory before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the relief pilot should announce the Cabin Pressure Controller advisory when conditions permit. The Cabin Pressure Controller annunciation that differs from the expected state requires the First Officer to monitor the condition

once the checklist item is complete.

- The Probe Heat advisory is expected to read within the sample range of 91 to 98 units during a turnaround.
- Both pilots will select any change in the Thrust Reverser status message and advise the other pilot if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Stall Warning is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The Standby Instruments advisory that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center.
- During parking, the Captain should record the Autopilot Channel B advisory before the next phase of flight.

Chapter 10 Systems: Flight Controls

10.10 Description

10.10.1 Autopilot Channel B Reset Guidance

The Autothrottle status message that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated. If the Standby Hydraulic is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the pilot flying should announce the Probe Heat status message once the checklist item is complete. The Ground Proximity Monitor indication that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. The Auxiliary Power Unit switch position that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated.

The Autobrake Selector status message is expected to read within the sample range of 9 to 17 units during a diversion. The Autopilot Channel A quantity display is expected to read within the sample range of 24 to 32 units during preflight. During approach, both pilots should verify the Oxygen Distribution quantity display before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. If the Nosewheel Steering is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. During preflight, the First Officer should brief the Transponder annunciation when conditions permit.

NOTE: During cruise, the Captain should monitor the Oxygen Distribution selector position unless directed otherwise by the Sample Operations Center. If the Autopilot Channel A is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

The first officer will record any change in the Cabin Pressure Controller selector position and advise the other pilot when conditions permit. If the Engine Anti-Ice is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Standby Hydraulic switch position is expected to read within the sample range of 44 to 49 units during parking. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Flap Position Indication quantity display	73 units	Refer to related topic
Probe Heat advisory	29 units	Monitor
Ground Proximity Monitor annunciation	44 units	Monitor

Condition	Sample value	Remarks
Pack Temperature Control annunciation	43 units	Normal
Fuel Crossfeed annunciation	56 units	Refer to related topic
Wing Anti-Ice switch position	34 units	Normal
Oxygen Distribution annunciation	25 units	Refer to related topic
Thrust Reverser status message	94 units	Advisory only

CAUTION: The Center Tank Pumps advisory that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power.

10.10.2 Flight Management Computer Interfaces

If the Hydraulic System A is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. During a turnaround, the pilot monitoring should monitor the Ground Proximity Monitor indication once the checklist item is complete. The Stall Warning quantity display that differs from the expected state requires

the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. If the Landing Gear Indication is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Autobrake Selector quantity display that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed.

NOTE: The Cargo Smoke Detection selector position that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight.

The Probe Heat selector position that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated. The Weather Radar advisory that differs from the expected state requires the Captain to announce the condition before the next phase of flight. If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. During an extended ground delay, the relief pilot should confirm the Autopilot Channel A indication before the next phase of flight.

During taxi, the relief pilot should monitor the Standby Instruments selector position before the next phase of flight. During climb, the First Officer should confirm the Nosewheel Steering quantity display when operating at a sample station without ground power. The Hydraulic System B selector position that differs from the expected state requires the Captain to brief the condition when conditions permit. Both pilots will record any change in the Stall Warning advisory and advise the other pilot if a discrepancy is observed.

If the Cabin Pressure Controller is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. During climb, the First Officer should monitor the Bleed Air Supply quantity display if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A annunciation is expected to read within the sample range of 93 to 99 units during takeoff. The Auxiliary Power Unit indication that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight.

10.10.3 Weather Radar Crew Awareness

The Autopilot Channel B status message is expected to read within the sample range of 86 to 97 units during parking. During landing, the Captain should confirm the Auxiliary Power Unit advisory when conditions permit. The Autobrake Selector quantity display that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. The Engine Anti-Ice annunciation that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. During approach, the pilot flying should confirm the Hydraulic System B status message unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

- Refer to the related topic for additional sample context.
- Values in this manual are invented and must not be used for any operational purpose.
- During cruise, the First Officer should verify the Primary Electrical Bus advisory if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will monitor any change in the Landing Gear Indication switch position and advise the other pilot before the next phase of flight.

The Autothrottle selector position that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. If the Pack Temperature Control is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Center Tank Pumps status message is expected to read within the sample range of 44 to 48 units during preflight. The Transponder quantity display is expected to read within the sample range of 34 to 44

units during descent.

Condition	Sample value	Remarks
Landing Gear Indication status message	8 units	Normal
Autothrottle advisory	81 units	Advisory only
Speedbrake Handle quantity display	50 units	Normal

10.10.4 Oxygen Distribution Reset Guidance

The Auxiliary Power Unit switch position is expected to read within the sample range of 70 to 80 units during a diversion. The pilot monitoring will monitor any change in the Wing Anti-Ice annunciation and advise the other pilot once the checklist item is complete. The Window Heat quantity display that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. The Flap Position Indication advisory is expected to read within the sample range of 73 to 81 units during taxi.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: If the Landing Gear Indication is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Fuel Crossfeed status message that differs from the expected state requires the Captain to announce the condition when conditions permit.

Refer to the related topic for additional sample context. The Cabin Pressure Controller status message that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight. The captain will confirm any change in the Autothrottle indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection quantity display that differs from the expected state requires the pilot monitoring to record the condition when conditions permit. During descent, both pilots should monitor the Cockpit Voice Recorder status message when the associated caution light remains illuminated.

CAUTION: The captain will select any change in the Bleed Air Supply status message and advise the other pilot when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. The captain will select any change in the Bleed Air Supply indication and advise the other pilot when the associated caution light remains illuminated. The Autobrake Selector quantity display is expected to read within the sample range of 35 to 41 units during landing.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Auxiliary Power Unit status message is expected to read within the sample range of 58 to 69 units during approach.

10.20 Controls and Indicators

10.20.1 Nosewheel Steering Indications

If the Landing Gear Indication is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Fuel Crossfeed status message is expected to read within the sample range of 78 to 90 units during parking. If the Brake Temperature Monitor is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication quantity display is expected to read within the sample range of 43 to 51 units during parking.

The Engine Anti-Ice quantity display is expected to read within the sample range of 63 to 74 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the First Officer

should record the Auxiliary Power Unit indication unless directed otherwise by the Sample Operations Center. The captain will confirm any change in the Center Tank Pumps indication and advise the other pilot before the next phase of flight. If the Pack Temperature Control is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Flight Management Computer selector position and advise the other pilot when the associated caution light remains illuminated.

- During a turnaround, the pilot monitoring should brief the Transponder selector position before the next phase of flight.
- The Stall Warning annunciation that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power.
- Both pilots will monitor any change in the Autobrake Selector annunciation and advise the other pilot before the next phase of flight.

CAUTION: During a diversion, the relief pilot should select the Autothrottle status message once the checklist item is complete.

- The Speedbrake Handle annunciation that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.
- The Engine Anti-Ice quantity display is expected to read within the sample range of 91 to 96 units during cruise.
- The Nosewheel Steering status message is expected to read within the sample range of 72 to 79 units during preflight.
- During engine start, both pilots should confirm the Transponder quantity display unless directed otherwise by the Sample Operations Center.

The Cabin Pressure Controller selector position is expected to read within the sample range of 47 to 55 units during descent. The Ground Proximity Monitor indication that differs from the expected state requires the Captain to record the condition when conditions permit. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

The Fuel Crossfeed switch position is expected to read within the sample range of 29 to 36 units during parking. The Fire Detection Loop annunciation is expected to read within the sample range of 33 to 43 units during an extended ground delay. During taxi, both pilots should brief the Hydraulic System A selector position unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice selector position is expected to read within the sample range of 28 to 32 units during engine start.

10.20.2 Landing Gear Indication Interfaces

The Standby Instruments indication that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. Both pilots will monitor any change in the Standby Hydraulic indication and advise the other pilot if the indication does not stabilize within the sample interval. The captain will monitor any change in the Pack Temperature Control indication and advise the other pilot when operating at a sample station without ground power. The Cockpit Voice Recorder advisory is expected to read within the sample range of 76 to 83 units during preflight.

- The pilot flying will cross-check any change in the Center Tank Pumps indication and advise the other pilot when conditions permit.
- The pilot monitoring will brief any change in the Flap Position Indication annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- Both pilots will announce any change in the Cabin Pressure Controller selector position and advise the other pilot when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.

- The Probe Heat status message is expected to read within the sample range of 42 to 47 units during landing.
- The Fire Detection Loop quantity display that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight.
- The Thrust Reverser quantity display that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center.
- If the Wing Anti-Ice is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.
- The Hydraulic System A status message that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.

The Engine Anti-Ice selector position that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. During a turnaround, the Captain should cross-check the Autobrake Selector advisory if the indication does not stabilize within the sample interval. The pilot monitoring will confirm any change in the Cabin Pressure Controller status message and advise the other pilot unless directed otherwise by the Sample Operations Center. During climb, both pilots should confirm the Brake Temperature Monitor status message if the indication does not stabilize within the sample interval. The captain will verify any change in the Bleed Air Supply switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Traffic Advisory Display quantity display is expected to read within the sample range of 16 to 24 units during landing.

CAUTION: During taxi, the pilot flying should cross-check the Autopilot Channel B annunciation unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

10.20.3 Auxiliary Power Unit Status Messages

The Fire Detection Loop advisory that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Window Heat advisory is expected to read within the sample range of 90 to 94 units during a turnaround.

- The Standby Instruments quantity display is expected to read within the sample range of 46 to 51 units during climb.
- Both pilots will brief any change in the Fuel Crossfeed annunciation and advise the other pilot when operating at a sample station without ground power.
- Both pilots will confirm any change in the Fire Detection Loop indication and advise the other pilot when the associated caution light remains illuminated.
- If the Fire Detection Loop is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.
- During landing, the First Officer should select the Hydraulic System B status message when the associated caution light remains illuminated.
- During engine start, the pilot monitoring should record the Hydraulic System B status message when conditions permit.

During climb, the relief pilot should verify the Bleed Air Supply annunciation once the checklist item is complete. The Pack Temperature Control annunciation is expected to read within the sample range of 69 to 75 units during descent. During taxi, the relief pilot should cross-check the Standby Hydraulic selector position if the indication does not stabilize within the sample interval. The Pack Temperature Control annunciation is expected to read within the sample range of 52 to 57 units during taxi.

During taxi, the pilot monitoring should select the Primary Electrical Bus switch position when operating at a sample station without ground power. During climb, the pilot flying should monitor the Flap Position Indication indication unless directed otherwise by the Sample Operations Center. The Autopilot Channel B annunciation that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. If the Autobrake Selector is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

The Cargo Smoke Detection indication that differs from the expected state requires the pilot monitoring to monitor the condition if the indication does not stabilize within the sample interval. The relief pilot will monitor any change in the Cabin Pressure Controller switch position and advise the other pilot before the next phase of flight. The Oxygen Distribution quantity display is expected to read within the sample range of 30 to 39 units during a turnaround. During a maintenance-requested ground run, the pilot flying should record the Transponder quantity display if a discrepancy is observed. The pilot flying will announce any change in the Window Heat switch position and advise the other pilot if the indication does not stabilize within the sample interval.

The pilot flying will record any change in the Cabin Pressure Controller indication and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A advisory is expected to read within the sample range of 44 to 56 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure.

Values in this manual are invented and must not be used for any operational purpose. If the Fire Detection Loop is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Autothrottle advisory that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval. During engine start, the relief pilot should cross-check the Autopilot Channel B switch position if the indication does not stabilize within the sample interval.

During climb, the pilot flying should monitor the Probe Heat annunciation when conditions permit. If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Autobrake Selector status message that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed.

The Speedbrake Handle status message that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the Captain should record the Probe Heat annunciation when operating at a sample station without ground power. During a maintenance-requested ground run, the pilot monitoring should monitor the Window Heat quantity display when operating at a sample station without ground power.

10.20.4 Hydraulic System B Indications

This text is fictional and exists only to give the prototype realistic volume and structure. The Speedbrake Handle indication is expected to read within the sample range of 97 to 102 units during parking. The Center Tank Pumps quantity display that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed. The Primary Electrical Bus quantity display that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed.

The captain will select any change in the Center Tank Pumps switch position and advise the other pilot if a discrepancy is observed. The first officer will record any change in the Autothrottle advisory and advise the other pilot once the checklist item is complete. If the Transponder is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Brake Temperature Monitor quantity display that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated. The Ground Proximity Monitor indication is expected to read within the sample range of 43 to 55 units during taxi.

Condition	Sample value	Remarks
Standby Instruments switch position	31 units	Normal
Flap Position Indication switch position	77 units	Refer to related topic
Fuel Crossfeed switch position	43 units	Monitor

CAUTION: The Brake Temperature Monitor advisory is expected to read within the sample range of 82 to 89 units during engine start.

The Speedbrake Handle switch position is expected to read within the sample range of 49 to 52 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Cargo Smoke Detection is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. See 03.60.1 Checklist: Hydraulic System B.

10.30 Operation

10.30.1 Flap Position Indication Crew Awareness

The pilot monitoring will record any change in the Brake Temperature Monitor annunciation and advise the other pilot when conditions permit. If the Ground Proximity Monitor is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Probe Heat advisory that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. During an extended ground delay, both pilots should brief the Speedbrake Handle status message unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

During a maintenance-requested ground run, the relief pilot should select the Stall Warning switch position when operating at a sample station without ground power. The Center Tank Pumps indication that differs from the expected state requires the pilot monitoring to monitor the condition when operating at a sample station without ground power. During takeoff, the relief pilot should confirm the Thrust Reverser selector position unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit switch position is expected to read within the sample range of 73 to 77 units during preflight. This text is fictional and exists only to give the prototype realistic volume and structure.

Values in this manual are invented and must not be used for any operational purpose. The Oxygen Distribution quantity display is expected to read within the sample range of 54 to 64 units during engine start. The Flap Position Indication switch position is expected to read within the sample range of 75 to 81 units during approach. Both pilots will confirm any change in the Wing Anti-Ice quantity display and advise the other pilot before the next phase of flight. During a diversion, the Captain should announce the Thrust Reverser switch position if a discrepancy is observed.

NOTE: The Autobrake Selector advisory is expected to read within the sample range of 17 to 24 units during approach.

The Speedbrake Handle annunciation that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed. The Pack Temperature Control quantity display that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. The Cargo Smoke Detection indication that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight. During a diversion, the Captain should brief the Speedbrake Handle selector position unless directed otherwise by the Sample Operations Center. The Stall Warning indication that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center.

10.30.2 Flap Position Indication Power Sources

The Traffic Advisory Display selector position that differs from the expected state requires both pilots to record the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will cross-check any change in the Wing Anti-Ice switch position and advise the other pilot when the associated caution light remains illuminated. During a diversion, both pilots should verify the Fire Detection Loop selector position once the checklist item is complete.

The first officer will verify any change in the Autothrottle quantity display and advise the other pilot before the next phase of flight. The Fuel Crossfeed quantity display that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete. If the Window Heat is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Cockpit Voice Recorder annunciation that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval. The Autopilot Channel A status message is expected to read within the sample range of 41 to 48 units during descent.

If the Landing Gear Indication is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The relief pilot will confirm any change in the Engine Anti-Ice switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Autopilot Channel A quantity display is expected to read within the sample range of 4 to 12 units during landing. During a maintenance-requested ground run, the pilot monitoring should record the Nosewheel Steering indication before the next phase of flight. The captain will record any change in the Center Tank Pumps selector position and advise the other pilot when operating at a sample station without ground power. The Speedbrake Handle status message is expected to read within the sample range of 5 to 8 units during approach.

Condition	Sample value	Remarks
Nosewheel Steering indication	24 units	Monitor
Auxiliary Power Unit indication	31 units	Normal
Autobrake Selector quantity display	19 units	Monitor
Standby Hydraulic indication	44 units	Refer to related topic
Wing Anti-Ice status message	57 units	Advisory only
Wing Anti-Ice advisory	3 units	Refer to related topic

CAUTION: The Window Heat selector position that differs from the expected state requires the Captain to record the condition once the checklist item is complete. The Nosewheel Steering annunciation that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Window Heat quantity display	22 units	Normal
Auxiliary Power Unit switch position	40 units	Refer to related topic
Autothrottle annunciation	8 units	Normal
Oxygen Distribution status message	11 units	Advisory only
Probe Heat advisory	41 units	Advisory only

The Autothrottle indication that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. The Auxiliary Power Unit advisory is expected to read within the sample range of 54 to 61 units during an extended ground delay. During preflight, the relief pilot should record the Fire Detection Loop selector position when the associated caution light remains illuminated. The Hydraulic System A advisory that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. The Traffic Advisory Display selector position that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight.

NOTE: The Autobrake Selector annunciation that differs from the expected state requires the Captain to record the condition when conditions permit.

10.30.3 Cockpit Voice Recorder Interfaces

The Flight Management Computer selector position is expected to read within the sample range of 2 to 12 units during engine start. The captain will record any change in the Cargo Smoke Detection switch position and advise the other pilot before the next phase of flight. During descent, both pilots should verify the Nosewheel Steering indication when conditions permit. The pilot monitoring will verify any change in the Nosewheel Steering advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The relief pilot will record any change in the Oxygen Distribution annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

CAUTION: Refer to the related topic for additional sample context. The pilot flying will brief any change in the Speedbrake Handle indication and advise the other pilot before the next phase of flight.

If the Nosewheel Steering is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. During climb, the relief pilot should confirm the Primary Electrical Bus annunciation once the checklist item is complete. The Autobrake Selector advisory that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center. The Landing Gear Indication status message that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight. During a diversion, both pilots should confirm the Bleed Air Supply selector position when operating at a sample station without ground power. The Window Heat annunciation that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated.

NOTE: The relief pilot will brief any change in the Cockpit Voice Recorder advisory and advise the other pilot when operating at a sample station without ground power. The Standby Instruments switch position that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed.

10.30.4 Engine Anti-Ice Status Messages

The Traffic Advisory Display switch position is expected to read within the sample range of 45 to 48 units during takeoff. During a turnaround, the pilot flying should select the Standby Instruments quantity display if the indication does not stabilize within the sample interval. If the Transponder is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The captain will cross-check any change in the Hydraulic System A status message and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System B selector position that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. The Probe Heat selector position that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. If the Engine Anti-Ice is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Center Tank Pumps annunciation that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete.

If the Landing Gear Indication is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Ground Proximity Monitor advisory is expected to read within the sample range of 24 to 30 units during engine start. During engine start, the pilot flying should monitor the Cabin Pressure Controller advisory when operating at a sample station without ground power. The Cargo Smoke Detection indication is expected to read within the sample range of 59 to 65 units during preflight. During takeoff, the relief pilot should monitor the Autopilot Channel A advisory before the next phase of flight. The Standby Instruments status message that differs from the expected state requires both pilots to confirm the condition before the next phase of flight.

- During a diversion, the Captain should announce the Brake Temperature Monitor status message once the checklist item is complete.

- The Flap Position Indication advisory that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete.
- If the Cockpit Voice Recorder is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

The Probe Heat selector position that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. If the Center Tank Pumps is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Cockpit Voice Recorder selector position that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. During engine start, both pilots should select the Hydraulic System B switch position unless directed otherwise by the Sample Operations Center. During preflight, the pilot flying should confirm the Wing Anti-Ice status message if the indication does not stabilize within the sample interval.

Chapter 11 Systems: Landing Gear and Brakes

11.10 Description

11.10.1 Hydraulic System B Overview

The Autopilot Channel B selector position is expected to read within the sample range of 94 to 104 units during taxi. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Auxiliary Power Unit advisory is expected to read within the sample range of 9 to 20 units during an extended ground delay. The Hydraulic System B advisory is expected to read within the sample range of 75 to 86 units during parking. The Oxygen Distribution switch position is expected to read within the sample range of 7 to 11 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure.

During parking, the pilot flying should monitor the Probe Heat annunciation when the associated caution light remains illuminated. If the Traffic Advisory Display is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The Standby Instruments advisory is expected to read within the sample range of 44 to 49 units during a diversion.

The Window Heat switch position is expected to read within the sample range of 26 to 38 units during preflight. If the Nosewheel Steering is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The first officer will record any change in the Probe Heat status message and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will confirm any change in the Cargo Smoke Detection annunciation and advise the other pilot when operating at a sample station without ground power. The Standby Hydraulic selector position is expected to read within the sample range of 54 to 60 units during an extended ground delay.

The Autopilot Channel B switch position is expected to read within the sample range of 70 to 75 units during approach. Values in this manual are invented and must not be used for any operational purpose. During cruise, both pilots should monitor the Autopilot Channel B advisory if a discrepancy is observed. The pilot flying will announce any change in the Brake Temperature Monitor indication and advise the other pilot when operating at a sample station without ground power. The Hydraulic System A switch position that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. The Flight Management Computer status message that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed.

The Center Tank Pumps selector position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. During engine start, the First Officer should monitor the Thrust Reverser switch position if a discrepancy is observed. If the Stall Warning is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

The Cabin Pressure Controller quantity display that differs from the expected state requires both pilots to select the condition when conditions permit. The Flight Management Computer status message that differs from the expected state requires the relief pilot to record the condition when conditions permit. During landing, the First Officer should record the Primary Electrical Bus annunciation if the indication does not stabilize within the sample interval. The Cargo Smoke Detection advisory is expected to read within the sample range of 81 to 86 units during climb. The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight.

The Auxiliary Power Unit quantity display is expected to read within the sample range of 49 to 59 units during climb. During preflight, the relief pilot should cross-check the Weather Radar advisory unless directed otherwise by the Sample Operations Center. Both pilots will confirm any change in the Stall Warning advisory and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will record any change in the Thrust Reverser advisory and advise the other pilot when operating at a sample station without ground power. The

pilot monitoring will cross-check any change in the Auxiliary Power Unit selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Fire Detection Loop status message is expected to read within the sample range of 54 to 58 units during descent.

If the Cabin Pressure Controller is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

11.10.2 Cargo Smoke Detection Power Sources

The pilot flying will cross-check any change in the Autothrottle annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Hydraulic System A switch position and advise the other pilot when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. During descent, both pilots should record the Landing Gear Indication status message when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will cross-check any change in the Speedbrake Handle switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Auxiliary Power Unit is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Oxygen Distribution selector position and advise the other pilot if a discrepancy is observed. The first officer will brief any change in the Oxygen Distribution annunciation and advise the other pilot when operating at a sample station without ground power.

NOTE: The captain will record any change in the Fire Detection Loop switch position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Landing Gear Indication selector position	37 units	Refer to related topic
Window Heat annunciation	58 units	Refer to related topic
Fire Detection Loop selector position	6 units	Refer to related topic
Hydraulic System A advisory	80 units	Refer to related topic
Hydraulic System A indication	85 units	Normal
Nosewheel Steering selector position	9 units	Normal

CAUTION: The Cabin Pressure Controller selector position is expected to read within the sample range of 63 to 67 units during takeoff. During an extended ground delay, the First Officer should select the Weather Radar advisory if a discrepancy is observed.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Cargo Smoke Detection indication is expected to read within the sample range of 93 to 97 units during an extended ground delay.
- The Hydraulic System A annunciation that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed.
- The Transponder annunciation is expected to read within the sample range of 30 to 42 units during taxi.
- The Autobrake Selector quantity display is expected to read within the sample range of 19 to 23 units during a turnaround.

If the Thrust Reverser is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

11.10.3 Bleed Air Supply Normal Operation

If the Speedbrake Handle is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Wing Anti-Ice switch position is expected to read within the sample range of 14 to 22 units during engine start. During engine start, the First Officer should announce the Brake Temperature Monitor annunciation if a discrepancy is observed.

The Autobrake Selector switch position that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated. If the Primary Electrical Bus is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The captain will verify any change in the Transponder status message and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. If the Cabin Pressure Controller is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

The pilot monitoring will monitor any change in the Nosewheel Steering annunciation and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The pilot monitoring will record any change in the Weather Radar indication and advise the other pilot unless directed otherwise by the Sample Operations Center. See 03.30.3 Crew Coordination: Probe Heat.

- NOTE:** The Weather Radar advisory that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated.

NOTE: The first officer will monitor any change in the Transponder indication and advise the other pilot before the next phase of flight.

NOTE: The pilot flying will verify any change in the Stall Warning advisory and advise the other pilot when operating at a sample station without ground power.

NOTE: If the Transponder is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

11.10.4 Primary Electrical Bus Status Messages

The Cabin Pressure Controller annunciation is expected to read within the sample range of 44 to 55 units during takeoff. The Autothrottle quantity display that differs from the expected state requires the relief pilot to cross-check the condition once the checklist item is complete. The Autopilot Channel A switch position is expected to read within the sample range of 65 to 70 units during cruise. The Engine Anti-Ice status message that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power.

The Fire Detection Loop switch position that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. The first officer will monitor any change in the Thrust Reverser selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Fire Detection Loop advisory that differs from the expected state requires the Captain to cross-check the condition when conditions permit. The Primary Electrical Bus selector position is expected to read within the sample range of 28 to 38 units during a diversion. During a diversion, both pilots should monitor the Oxygen Distribution advisory when conditions permit.

Condition	Sample value	Remarks
Thrust Reverser advisory	59 units	Normal

Primary Electrical Bus indication	58 units	Refer to related topic
Brake Temperature Monitor indication	35 units	Normal
Window Heat annunciation	93 units	Advisory only
Nosewheel Steering annunciation	32 units	Refer to related topic

- During a turnaround, the First Officer should brief the Thrust Reverser annunciation if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Nosewheel Steering is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

If the Fire Detection Loop is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Autopilot Channel A switch position is expected to read within the sample range of 14 to 17 units during takeoff. The first officer will monitor any change in the Bleed Air Supply advisory and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

The Hydraulic System B switch position that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete. If the Landing Gear Indication is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will record any change in the Cabin Pressure Controller quantity display and advise the other pilot when the associated caution light remains illuminated. Both pilots will select any change in the Hydraulic System A advisory and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Nosewheel Steering advisory	9 units	Monitor
Cabin Pressure Controller indication	80 units	Advisory only
Traffic Advisory Display selector position	11 units	Refer to related topic

The Engine Anti-Ice quantity display that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. The Primary Electrical Bus selector position is expected to read within the sample range of 80 to 92 units during a turnaround. The first officer will announce any change in the Landing Gear Indication indication and advise the other pilot when the associated caution light remains illuminated.

During engine start, the First Officer should brief the Nosewheel Steering selector position before the next phase of flight. If the Thrust Reverser is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A status message that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. If the Traffic Advisory Display is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

11.20 Controls and Indicators

11.20.1 Autopilot Channel B Power Sources

The Traffic Advisory Display indication that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. The Cabin Pressure Controller annunciation that differs from the expected state requires the relief pilot to record the condition when conditions permit. The Flap Position Indication advisory that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated. The Pack Temperature Control annunciation that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations

Center. During taxi, both pilots should monitor the Center Tank Pumps quantity display once the checklist item is complete.

During cruise, the First Officer should verify the Traffic Advisory Display quantity display once the checklist item is complete. Both pilots will confirm any change in the Probe Heat indication and advise the other pilot when the associated caution light remains illuminated. The Speedbrake Handle quantity display that differs from the expected state requires the First Officer to cross-check the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel A annunciation that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center.

- The Oxygen Distribution quantity display that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval.
- The pilot flying will verify any change in the Autopilot Channel A status message and advise the other pilot before the next phase of flight.
- During preflight, the First Officer should verify the Traffic Advisory Display quantity display when the associated caution light remains illuminated.
- During a maintenance-requested ground run, the relief pilot should monitor the Ground Proximity Monitor advisory unless directed otherwise by the Sample Operations Center.
- If the Cargo Smoke Detection is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- If the Bleed Air Supply is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cockpit Voice Recorder switch position	45 units	Normal
Fuel Crossfeed annunciation	85 units	Normal
Engine Anti-Ice advisory	28 units	Normal
Cabin Pressure Controller status message	85 units	Refer to related topic
Cabin Pressure Controller switch position	71 units	Advisory only
Engine Anti-Ice quantity display	58 units	Monitor
Autobrake Selector indication	48 units	Advisory only

- The Cabin Pressure Controller selector position is expected to read within the sample range of 62 to 66 units during parking.
- During landing, the First Officer should monitor the Oxygen Distribution status message when the associated caution light remains illuminated.
- During a turnaround, the pilot flying should cross-check the Speedbrake Handle status message before the next phase of flight.

CAUTION: The Autothrottle annunciation is expected to read within the sample range of 74 to 84 units during takeoff. The first officer will verify any change in the Flap Position Indication advisory and advise the other pilot when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Cabin Pressure Controller is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Cabin Pressure Controller switch position that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. If the Transponder is

inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

The Fuel Crossfeed selector position is expected to read within the sample range of 9 to 18 units during an extended ground delay. This text is fictional and exists only to give the prototype realistic volume and structure. The Center Tank Pumps status message is expected to read within the sample range of 17 to 25 units during parking.

11.20.2 Wing Anti-Ice Status Messages

During cruise, the pilot flying should confirm the Standby Hydraulic selector position when operating at a sample station without ground power. If the Standby Hydraulic is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. During parking, the Captain should confirm the Fire Detection Loop quantity display when conditions permit. Both pilots will verify any change in the Standby Instruments advisory and advise the other pilot before the next phase of flight. During descent, the Captain should announce the Center Tank Pumps switch position once the checklist item is complete. During approach, the relief pilot should record the Transponder quantity display when operating at a sample station without ground power.

- The Primary Electrical Bus annunciation is expected to read within the sample range of 14 to 19 units during descent.
- If the Weather Radar is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- The first officer will confirm any change in the Autobrake Selector selector position and advise the other pilot when operating at a sample station without ground power.

The pilot flying will monitor any change in the Autopilot Channel A advisory and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. During engine start, the First Officer should record the Flight Management Computer selector position when operating at a sample station without ground power. The Autobrake Selector advisory that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed. If the Flight Management Computer is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

CAUTION: The pilot flying will monitor any change in the Wing Anti-Ice selector position and advise the other pilot when conditions permit.

The Pack Temperature Control indication that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight. During landing, the pilot flying should cross-check the Cargo Smoke Detection indication when operating at a sample station without ground power. The Probe Heat advisory is expected to read within the sample range of 86 to 91 units during parking. The first officer will verify any change in the Hydraulic System A status message and advise the other pilot before the next phase of flight. The Autopilot Channel B status message that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated.

The Nosewheel Steering annunciation is expected to read within the sample range of 2 to 14 units during landing. The Standby Hydraulic switch position is expected to read within the sample range of 95 to 102 units during approach. Refer to the related topic for additional sample context. See 04.20.4 Callouts: Standby Hydraulic.

11.20.3 Cargo Smoke Detection Reset Guidance

The pilot flying will confirm any change in the Cockpit Voice Recorder status message and advise the other pilot once the checklist item is complete. The pilot flying will verify any change in the Thrust Reverser selector position and advise the other pilot when the associated caution light remains illuminated. If the Window Heat is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Standby Instruments advisory that differs from the expected state requires both pilots to brief the condition before the next phase of flight. During cruise, the pilot flying should record the Brake Temperature Monitor selector position if a discrepancy is observed.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Primary Electrical Bus is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The first officer will monitor any change in the Wing Anti-Ice annunciation and advise the other pilot if a discrepancy is observed. During approach, the relief pilot should announce the Standby Instruments annunciation unless directed otherwise by the Sample Operations Center. During descent, the relief pilot should cross-check the Cabin Pressure Controller status message when conditions permit. The Center Tank Pumps status message that differs from the expected state requires the Captain to select the condition before the next phase of flight. The Cabin Pressure Controller annunciation that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete.

Condition	Sample value	Remarks
Stall Warning quantity display	46 units	Monitor
Oxygen Distribution quantity display	45 units	Normal
Cockpit Voice Recorder status message	92 units	Advisory only
Auxiliary Power Unit quantity display	63 units	Normal
Center Tank Pumps status message	6 units	Refer to related topic

CAUTION: The pilot monitoring will confirm any change in the Stall Warning selector position and advise the other pilot when conditions permit.

NOTE: Refer to the related topic for additional sample context. During landing, both pilots should verify the Autopilot Channel A advisory unless directed otherwise by the Sample Operations Center.

- The Flap Position Indication selector position that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval.
- The Flap Position Indication annunciation that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed.
- The Fire Detection Loop switch position that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Ground Proximity Monitor is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.
- The Weather Radar selector position is expected to read within the sample range of 48 to 56 units during landing.

11.20.4 Autopilot Channel B Test

Both pilots will confirm any change in the Nosewheel Steering switch position and advise the other pilot when the associated caution light remains illuminated. The Thrust Reverser selector position is expected to read within the sample range of 79 to 89 units during approach. The first officer will cross-check any change in the Cabin Pressure Controller selector position and advise the other pilot when the associated caution light remains illuminated. The Cabin Pressure Controller indication is expected to read within the sample range of 29 to 39 units during engine start. Refer to the related topic for additional sample context.

The Brake Temperature Monitor advisory that differs from the expected state requires the pilot monitoring to record the condition when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. During approach, the pilot flying should cross-check the Thrust Reverser status message when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Autothrottle selector position that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. During preflight, the relief pilot should announce the Fire Detection Loop annunciation before the next phase of flight.

During landing, both pilots should brief the Flight Management Computer selector position if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the Captain should monitor the Standby Hydraulic annunciation before the next phase of flight. If the Oxygen Distribution is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

NOTE: The Autopilot Channel B advisory that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed.

The Flap Position Indication advisory that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel B annunciation is expected to read within the sample range of 24 to 36 units during engine start. If the Landing Gear Indication is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

The Flap Position Indication quantity display is expected to read within the sample range of 57 to 69 units during descent. The Autopilot Channel B quantity display is expected to read within the sample range of 46 to 52 units during a maintenance-requested ground run. If the Hydraulic System B is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Stall Warning quantity display that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. The first officer will cross-check any change in the Nosewheel Steering annunciation and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Fuel Crossfeed quantity display	29 units	Monitor
Auxiliary Power Unit status message	87 units	Normal
Transponder switch position	38 units	Normal
Autopilot Channel A switch position	37 units	Advisory only

11.30 Operation

11.30.1 Stall Warning Power Sources

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

The Bleed Air Supply indication that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. The Auxiliary Power Unit annunciation that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. During descent, the pilot flying should monitor the Autobrake Selector annunciation before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. During descent, the pilot flying should record the Hydraulic System B quantity display if a discrepancy is observed. Refer to the related topic for additional sample context.

CAUTION: The Nosewheel Steering indication is expected to read within the sample range of 13 to 16 units during a diversion. The Primary Electrical Bus switch position is expected to read within the sample range of 51 to 61 units during engine start.

- The Wing Anti-Ice quantity display is expected to read within the sample range of 49 to 54 units during taxi.

- The pilot flying will brief any change in the Weather Radar quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Fuel Crossfeed advisory that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed.
- The Autopilot Channel A status message that differs from the expected state requires the pilot monitoring to brief the condition when operating at a sample station without ground power.
- The Window Heat selector position that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete.

The Autobrake Selector quantity display is expected to read within the sample range of 26 to 30 units during a turnaround. If the Cabin Pressure Controller is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Nosewheel Steering selector position is expected to read within the sample range of 80 to 89 units during a diversion. The pilot flying will record any change in the Thrust Reverser indication and advise the other pilot if a discrepancy is observed.

NOTE: If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The first officer will confirm any change in the Flight Management Computer selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Flight Management Computer advisory is expected to read within the sample range of 93 to 98 units during parking. The Fire Detection Loop indication is expected to read within the sample range of 25 to 28 units during a turnaround. During engine start, the pilot flying should cross-check the Hydraulic System B selector position when conditions permit. If the Thrust Reverser is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Transponder is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

11.30.2 Fuel Crossfeed Test

If the Autothrottle is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication annunciation is expected to read within the sample range of 52 to 62 units during landing. The Ground Proximity Monitor indication that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight. The first officer will select any change in the Wing Anti-Ice selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Ground Proximity Monitor is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The relief pilot will confirm any change in the Traffic Advisory Display indication and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Nosewheel Steering switch position	61 units	Advisory only
Transponder switch position	28 units	Monitor
Autopilot Channel B selector position	3 units	Refer to related topic
Oxygen Distribution quantity display	76 units	Refer to related topic
Center Tank Pumps status message	60 units	Refer to related topic
Cabin Pressure Controller switch position	4 units	Advisory only
Cockpit Voice Recorder advisory	15 units	Advisory only

Refer to the related topic for additional sample context. The pilot flying will monitor any change in the Weather Radar annunciation and advise the other pilot once the checklist item is complete. Both pilots will confirm any change in the

Auxiliary Power Unit status message and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The captain will cross-check any change in the Ground Proximity Monitor quantity display and advise the other pilot when the associated caution light remains illuminated. The Landing Gear Indication advisory that differs from the expected state requires the Captain to confirm the condition before the next phase of flight.

- If the Autothrottle is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- If the Autopilot Channel A is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.
- During a maintenance-requested ground run, the pilot monitoring should monitor the Wing Anti-Ice switch position when conditions permit.
- If the Traffic Advisory Display is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.

The Pack Temperature Control status message is expected to read within the sample range of 53 to 62 units during landing. The Cabin Pressure Controller switch position is expected to read within the sample range of 67 to 74 units during parking. This text is fictional and exists only to give the prototype realistic volume and structure. The Transponder status message that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated. The Window Heat status message is expected to read within the sample range of 27 to 39 units during parking. The Bleed Air Supply advisory that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval.

The Transponder indication is expected to read within the sample range of 44 to 53 units during engine start. During a turnaround, the Captain should select the Autopilot Channel A annunciation if the indication does not stabilize within the sample interval. During landing, the Captain should select the Thrust Reverser quantity display when the associated caution light remains illuminated. The Flight Management Computer selector position is expected to read within the sample range of 7 to 12 units during a maintenance-requested ground run. The first officer will monitor any change in the Fire Detection Loop switch position and advise the other pilot when conditions permit. The Autobrake Selector annunciation is expected to read within the sample range of 43 to 50 units during takeoff.

11.30.3 Weather Radar Indications

During takeoff, the pilot monitoring should record the Auxiliary Power Unit quantity display when the associated caution light remains illuminated. The Stall Warning advisory is expected to read within the sample range of 71 to 75 units during climb. The relief pilot will announce any change in the Thrust Reverser switch position and advise the other pilot when operating at a sample station without ground power.

NOTE: The Standby Instruments quantity display that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated.

NOTE: The Stall Warning advisory is expected to read within the sample range of 80 to 84 units during landing.

NOTE: During cruise, the pilot monitoring should cross-check the Hydraulic System A quantity display when the associated caution light remains illuminated.

- During engine start, both pilots should cross-check the Traffic Advisory Display indication before the next phase of flight.
- If the Thrust Reverser is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

- The Bleed Air Supply quantity display is expected to read within the sample range of 93 to 99 units during engine start.

During landing, both pilots should announce the Flap Position Indication switch position when the associated caution light remains illuminated. The Hydraulic System A selector position is expected to read within the sample range of 47 to 59 units during a maintenance-requested ground run. The Fuel Crossfeed selector position is expected to read within the sample range of 58 to 68 units during engine start.

NOTE: The Standby Hydraulic indication is expected to read within the sample range of 15 to 21 units during an extended ground delay. The Hydraulic System B indication is expected to read within the sample range of 37 to 40 units during an extended ground delay.

NOTE: The captain will monitor any change in the Brake Temperature Monitor status message and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Fire Detection Loop quantity display that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed.

11.30.4 Brake Temperature Monitor Normal Operation

The Speedbrake Handle selector position that differs from the expected state requires both pilots to monitor the condition when conditions permit. The Center Tank Pumps selector position that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete. The Stall Warning annunciation that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Traffic Advisory Display is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Landing Gear Indication switch position and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. During a diversion, the pilot monitoring should monitor the Flap Position Indication advisory if a discrepancy is observed. The first officer will monitor any change in the Brake Temperature Monitor switch position and advise the other pilot if a discrepancy is observed.

- The Engine Anti-Ice quantity display is expected to read within the sample range of 88 to 91 units during parking.
- Both pilots will verify any change in the Landing Gear Indication annunciation and advise the other pilot before the next phase of flight.
- The Standby Instruments annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit.
- If the Speedbrake Handle is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.
- The Window Heat annunciation is expected to read within the sample range of 43 to 48 units during a turnaround.

If the Wing Anti-Ice is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Standby Instruments indication and advise the other pilot if a discrepancy is observed. If the Traffic Advisory Display is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Probe Heat status message	6 units	Refer to related topic
Traffic Advisory Display quantity display	75 units	Normal
Probe Heat selector position	91 units	Advisory only

Window Heat quantity display	61 units	Advisory only
Autopilot Channel A switch position	2 units	Monitor
Hydraulic System B indication	17 units	Monitor
Bleed Air Supply status message	75 units	Normal

Chapter 12 Systems: Automatic Flight

12.10 Description

12.10.1 Cockpit Voice Recorder Crew Awareness

During preflight, the Captain should brief the Auxiliary Power Unit selector position unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Landing Gear Indication is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

The pilot flying will select any change in the Traffic Advisory Display status message and advise the other pilot before the next phase of flight. The pilot monitoring will verify any change in the Fuel Crossfeed status message and advise the other pilot when conditions permit. The first officer will confirm any change in the Fuel Crossfeed quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will cross-check any change in the Stall Warning annunciation and advise the other pilot when conditions permit.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The Engine Anti-Ice quantity display is expected to read within the sample range of 84 to 92 units during parking. The captain will select any change in the Speedbrake Handle annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Standby Instruments is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Cockpit Voice Recorder indication is expected to read within the sample range of 11 to 17 units during a maintenance-requested ground run. If the Cockpit Voice Recorder is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

- The Speedbrake Handle quantity display that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power.
- During a turnaround, the pilot monitoring should announce the Landing Gear Indication annunciation when conditions permit.
- During cruise, the First Officer should confirm the Autopilot Channel B selector position when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The first officer will verify any change in the Flap Position Indication status message and advise the other pilot before the next phase of flight.
- The captain will verify any change in the Hydraulic System B selector position and advise the other pilot when the associated caution light remains illuminated.

If the Window Heat is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

12.10.2 Center Tank Pumps Indications

The pilot flying will verify any change in the Hydraulic System B indication and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Bleed Air Supply switch position that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. The Nosewheel Steering advisory that differs

from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Fire Detection Loop advisory	11 units	Refer to related topic
Cargo Smoke Detection annunciation	6 units	Monitor
Cabin Pressure Controller annunciation	64 units	Refer to related topic
Stall Warning advisory	25 units	Normal
Autothrottle indication	80 units	Advisory only

The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will verify any change in the Ground Proximity Monitor selector position and advise the other pilot when the associated caution light remains illuminated. The Speedbrake Handle selector position is expected to read within the sample range of 69 to 76 units during a diversion. During landing, the Captain should cross-check the Cargo Smoke Detection annunciation when the associated caution light remains illuminated. The Ground Proximity Monitor status message is expected to read within the sample range of 41 to 50 units during preflight.

Condition	Sample value	Remarks
Autopilot Channel B advisory	29 units	Advisory only
Speedbrake Handle status message	54 units	Normal
Traffic Advisory Display annunciation	33 units	Monitor
Pack Temperature Control advisory	85 units	Advisory only
Window Heat selector position	55 units	Normal

Condition	Sample value	Remarks
Weather Radar status message	23 units	Monitor
Ground Proximity Monitor selector position	18 units	Normal
Hydraulic System A selector position	75 units	Normal
Probe Heat quantity display	10 units	Advisory only
Ground Proximity Monitor annunciation	9 units	Normal
Speedbrake Handle status message	77 units	Advisory only

The pilot monitoring will cross-check any change in the Autopilot Channel B selector position and advise the other pilot when operating at a sample station without ground power. The Thrust Reverser selector position is expected to read within the sample range of 56 to 62 units during a diversion. During taxi, the First Officer should select the Thrust Reverser switch position once the checklist item is complete. If the Ground Proximity Monitor is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

12.10.3 Standby Hydraulic Test

This text is fictional and exists only to give the prototype realistic volume and structure. If the Landing Gear Indication is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. Both pilots will record any change in the Fuel Crossfeed selector position and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed status message that differs from the expected state requires the relief pilot to select the condition when conditions permit. The Cargo Smoke Detection advisory that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power.

NOTE: The Wing Anti-Ice switch position is expected to read within the sample range of 43 to 50 units during approach. The Autothrottle status message that differs from the expected state requires both pilots to record the

condition when operating at a sample station without ground power.

The captain will monitor any change in the Autobrake Selector selector position and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel B switch position that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. If the Auxiliary Power Unit is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

The Standby Hydraulic annunciation that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. The Engine Anti-Ice advisory that differs from the expected state requires the relief pilot to record the condition when conditions permit. The Pack Temperature Control switch position that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. The Flap Position Indication status message is expected to read within the sample range of 11 to 23 units during a turnaround. During preflight, the pilot flying should monitor the Autothrottle selector position when the associated caution light remains illuminated.

12.10.4 Fire Detection Loop Crew Awareness

The Wing Anti-Ice indication is expected to read within the sample range of 85 to 95 units during descent. The captain will brief any change in the Nosewheel Steering advisory and advise the other pilot when conditions permit. The Engine Anti-Ice advisory that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated. The Auxiliary Power Unit status message that differs from the expected state requires the pilot flying to record the condition when conditions permit. The Center Tank Pumps advisory that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power.

- The Wing Anti-Ice status message that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Stall Warning advisory that differs from the expected state requires the relief pilot to announce the condition when conditions permit.
- The Ground Proximity Monitor switch position that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete.

If the Autopilot Channel B is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should announce the Oxygen Distribution annunciation unless directed otherwise by the Sample Operations Center.

- The pilot monitoring will select any change in the Fuel Crossfeed selector position and advise the other pilot when operating at a sample station without ground power.
- The Hydraulic System A indication is expected to read within the sample range of 87 to 99 units during a turnaround.
- The pilot flying will monitor any change in the Probe Heat advisory and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Standby Hydraulic status message	66 units	Normal
Autothrottle switch position	20 units	Monitor

Transponder selector position	58 units	Refer to related topic
Engine Anti-Ice quantity display	86 units	Refer to related topic
Cargo Smoke Detection annunciation	97 units	Normal
Probe Heat annunciation	24 units	Advisory only

Values in this manual are invented and must not be used for any operational purpose. The Stall Warning quantity display is expected to read within the sample range of 97 to 108 units during engine start. If the Flap Position Indication is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Window Heat annunciation that differs from the expected state requires the First Officer to cross-check the condition when conditions permit.

CAUTION: The Fire Detection Loop status message is expected to read within the sample range of 45 to 49 units during cruise.

The Weather Radar selector position is expected to read within the sample range of 57 to 68 units during preflight. If the Traffic Advisory Display is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. During an extended ground delay, the relief pilot should verify the Autobrake Selector indication before the next phase of flight. See 03.10.4 Callouts: Flap Position Indication.

- If the Autothrottle is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.
- The Autobrake Selector annunciation is expected to read within the sample range of 7 to 14 units during climb.
- The Brake Temperature Monitor indication that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete.
- During landing, the Captain should brief the Transponder annunciation when conditions permit.
- If the Nosewheel Steering is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- The Flight Management Computer quantity display is expected to read within the sample range of 94 to 105 units during landing.

12.20 Controls and Indicators

12.20.1 Wing Anti-Ice Reset Guidance

The Flap Position Indication annunciation is expected to read within the sample range of 59 to 69 units during taxi. The Center Tank Pumps advisory that differs from the expected state requires both pilots to verify the condition before the next phase of flight. During a diversion, the pilot flying should announce the Cargo Smoke Detection switch position if the indication does not stabilize within the sample interval. The Hydraulic System A quantity display is expected to read within the sample range of 90 to 94 units during preflight. The Speedbrake Handle advisory is expected to read within the sample range of 5 to 9 units during parking.

If the Probe Heat is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. During descent, the First Officer should monitor the Autobrake Selector switch position unless directed otherwise by the Sample Operations Center. If the Landing Gear Indication is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Autothrottle advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Pack Temperature Control switch position that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit.

Condition	Sample value	Remarks
-----------	--------------	---------

Ground Proximity Monitor advisory	93 units	Normal
Engine Anti-Ice quantity display	63 units	Refer to related topic
Autobrake Selector status message	56 units	Advisory only
Window Heat status message	81 units	Advisory only
Engine Anti-Ice indication	56 units	Refer to related topic
Traffic Advisory Display switch position	93 units	Advisory only

- If the Stall Warning is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.
- The relief pilot will select any change in the Landing Gear Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Landing Gear Indication is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- This text is fictional and exists only to give the prototype realistic volume and structure.

If the Weather Radar is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During descent, the Captain should select the Window Heat selector position once the checklist item is complete.

If the Primary Electrical Bus is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Fuel Crossfeed annunciation that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. If the Oxygen Distribution is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

CAUTION: The Nosewheel Steering quantity display that differs from the expected state requires the First Officer to confirm the condition when conditions permit.

NOTE: The Auxiliary Power Unit indication is expected to read within the sample range of 56 to 61 units during approach.

12.20.2 Autopilot Channel A Indications

The Pack Temperature Control selector position that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. The Oxygen Distribution annunciation that differs from the expected state requires the First Officer to select the condition when conditions permit. The pilot monitoring will record any change in the Nosewheel Steering status message and advise the other pilot once the checklist item is complete. If the Brake Temperature Monitor is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

The relief pilot will confirm any change in the Pack Temperature Control annunciation and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. If the Autopilot Channel A is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Speedbrake Handle switch position that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center.

NOTE: The Traffic Advisory Display annunciation that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autothrottle selector position	77 units	Advisory only
Landing Gear Indication annunciation	34 units	Monitor

Fuel Crossfeed switch position	73 units	Monitor
Window Heat advisory	15 units	Refer to related topic
Flight Management Computer quantity display	63 units	Refer to related topic

CAUTION: The pilot monitoring will cross-check any change in the Bleed Air Supply status message and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Engine Anti-Ice switch position	54 units	Monitor
Speedbrake Handle status message	79 units	Normal
Window Heat status message	11 units	Refer to related topic
Flight Management Computer selector position	85 units	Monitor
Nosewheel Steering quantity display	32 units	Refer to related topic

Condition	Sample value	Remarks
Standby Instruments annunciation	84 units	Advisory only
Pack Temperature Control indication	47 units	Advisory only
Transponder advisory	48 units	Advisory only
Hydraulic System A quantity display	74 units	Monitor
Nosewheel Steering annunciation	87 units	Advisory only
Flight Management Computer quantity display	7 units	Refer to related topic

12.20.3 Autopilot Channel B Limits Display

The Weather Radar switch position is expected to read within the sample range of 6 to 16 units during climb. The captain will announce any change in the Primary Electrical Bus quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Traffic Advisory Display selector position is expected to read within the sample range of 95 to 100 units during engine start. During a turnaround, the First Officer should cross-check the Engine Anti-Ice quantity display if a discrepancy is observed.

NOTE: If the Flap Position Indication is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Flap Position Indication selector position that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval.

The Hydraulic System B indication is expected to read within the sample range of 92 to 96 units during approach. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The captain will announce any change in the Thrust Reverser switch position and advise the other pilot when conditions permit.

NOTE: Both pilots will confirm any change in the Speedbrake Handle annunciation and advise the other pilot when the associated caution light remains illuminated.

- If the Primary Electrical Bus is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.
- Both pilots will brief any change in the Autothrottle status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The Thrust Reverser advisory that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power.

Refer to the related topic for additional sample context. The first officer will cross-check any change in the Stall Warning annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The

Probe Heat indication that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete. During approach, the pilot monitoring should cross-check the Cargo Smoke Detection advisory before the next phase of flight. During cruise, the Captain should brief the Flight Management Computer annunciation if the indication does not stabilize within the sample interval. See 05.70.3 Brake Temperature Monitor Overview.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

12.20.4 Autobrake Selector Normal Operation

The Cargo Smoke Detection selector position that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated. If the Ground Proximity Monitor is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The relief pilot will select any change in the Wing Anti-Ice switch position and advise the other pilot once the checklist item is complete. The Stall Warning status message is expected to read within the sample range of 45 to 53 units during climb. The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The Flight Management Computer advisory is expected to read within the sample range of 16 to 28 units during a diversion.

The Thrust Reverser quantity display that differs from the expected state requires the First Officer to monitor the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Flap Position Indication indication that differs from the expected state requires the pilot flying to verify the condition if a discrepancy is observed. Refer to the related topic for additional sample context. During parking, the Captain should cross-check the Window Heat advisory if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Speedbrake Handle indication	83 units	Normal
Nosewheel Steering annunciation	49 units	Refer to related topic
Standby Hydraulic indication	33 units	Advisory only
Weather Radar advisory	47 units	Refer to related topic
Standby Hydraulic annunciation	40 units	Refer to related topic
Autopilot Channel B indication	44 units	Refer to related topic
Primary Electrical Bus status message	50 units	Monitor

- The Bleed Air Supply annunciation that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power.
- If the Flap Position Indication is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The Brake Temperature Monitor quantity display is expected to read within the sample range of 6 to 18 units during descent.
- The Autopilot Channel A status message is expected to read within the sample range of 13 to 20 units during landing.
- The Landing Gear Indication selector position is expected to read within the sample range of 92 to 97 units during a maintenance-requested ground run.

The Primary Electrical Bus selector position that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. The Wing Anti-Ice status message that differs from the expected state requires

the Captain to brief the condition when operating at a sample station without ground power. During approach, the pilot flying should confirm the Cargo Smoke Detection quantity display when operating at a sample station without ground power. If the Stall Warning is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control indication that differs from the expected state requires the relief pilot to select the condition before the next phase of flight.

Condition	Sample value	Remarks
Hydraulic System B status message	86 units	Monitor
Brake Temperature Monitor indication	64 units	Refer to related topic
Autopilot Channel A selector position	20 units	Advisory only
Autothrottle status message	29 units	Monitor
Cabin Pressure Controller indication	43 units	Normal

CAUTION: The Pack Temperature Control annunciation that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval.

Refer to the related topic for additional sample context. The Fire Detection Loop selector position is expected to read within the sample range of 91 to 99 units during engine start. The Weather Radar status message that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete. If the Pack Temperature Control is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

12.30 Operation

12.30.1 Fire Detection Loop Reset Guidance

The Fire Detection Loop quantity display that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete. The Probe Heat status message is expected to read within the sample range of 78 to 86 units during a diversion. If the Engine Anti-Ice is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The first officer will brief any change in the Thrust Reverser advisory and advise the other pilot once the checklist item is complete.

- The Fuel Crossfeed quantity display that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power.
- If the Hydraulic System A is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.
- If the Cockpit Voice Recorder is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.
- If the Autothrottle is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.
- During a maintenance-requested ground run, the pilot monitoring should monitor the Wing Anti-Ice switch position if the indication does not stabilize within the sample interval.
- If the Flap Position Indication is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- Both pilots will brief any change in the Traffic Advisory Display indication and advise the other pilot once the checklist item is complete.
- If the Oxygen Distribution is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

- The Transponder status message is expected to read within the sample range of 80 to 88 units during a maintenance-requested ground run.
- If the Traffic Advisory Display is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.
- The Window Heat status message is expected to read within the sample range of 52 to 55 units during parking.
- Values in this manual are invented and must not be used for any operational purpose.
- During engine start, both pilots should confirm the Thrust Reverser annunciation before the next phase of flight.
- The Flight Management Computer status message is expected to read within the sample range of 28 to 39 units during a maintenance-requested ground run.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will record any change in the Pack Temperature Control switch position and advise the other pilot when operating at a sample station without ground power.

12.30.2 Standby Instruments Status Messages

If the Center Tank Pumps is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The relief pilot will select any change in the Cabin Pressure Controller selector position and advise the other pilot if a discrepancy is observed.

NOTE: Refer to the related topic for additional sample context. The pilot flying will brief any change in the Hydraulic System B status message and advise the other pilot if the indication does not stabilize within the sample interval.

If the Weather Radar is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Bleed Air Supply status message is expected to read within the sample range of 45 to 53 units during cruise. During climb, the relief pilot should confirm the Nosewheel Steering advisory before the next phase of flight. If the Window Heat is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

If the Center Tank Pumps is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Weather Radar annunciation	12 units	Normal
Cabin Pressure Controller selector position	79 units	Normal
Autobrake Selector quantity display	48 units	Monitor
Auxiliary Power Unit quantity display	32 units	Monitor

CAUTION: During an extended ground delay, the pilot monitoring should record the Autopilot Channel A quantity display once the checklist item is complete.

CAUTION: During an extended ground delay, both pilots should brief the Ground Proximity Monitor status message before the next phase of flight.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

12.30.3 Autopilot Channel B Indications

The Pack Temperature Control annunciation that differs from the expected state requires the Captain to announce the condition when conditions permit. The Primary Electrical Bus annunciation is expected to read within the sample range of 79 to 88 units during landing. Both pilots will brief any change in the Cargo Smoke Detection switch position and advise the other pilot if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

- The Fire Detection Loop switch position is expected to read within the sample range of 51 to 62 units during cruise.
- During parking, the relief pilot should brief the Autothrottle selector position if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Probe Heat indication that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight.

CAUTION: The first officer will cross-check any change in the Window Heat advisory and advise the other pilot if a discrepancy is observed. The first officer will select any change in the Probe Heat indication and advise the other pilot when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. The pilot monitoring will brief any change in the Primary Electrical Bus selector position and advise the other pilot when the associated caution light remains illuminated. The Cockpit Voice Recorder indication that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center.

The Center Tank Pumps selector position is expected to read within the sample range of 63 to 66 units during parking. If the Autobrake Selector is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. Both pilots will announce any change in the Weather Radar annunciation and advise the other pilot if a discrepancy is observed. The Autopilot Channel A advisory is expected to read within the sample range of 7 to 15 units during cruise.

Both pilots will confirm any change in the Stall Warning selector position and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. The pilot flying will announce any change in the Standby Hydraulic annunciation and advise the other pilot before the next phase of flight. The pilot flying will brief any change in the Autopilot Channel B switch position and advise the other pilot once the checklist item is complete.

12.30.4 Autopilot Channel B Test

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will confirm any change in the Speedbrake Handle annunciation and advise the other pilot when conditions permit. If the Cabin Pressure Controller is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

NOTE: During a diversion, the pilot flying should record the Fire Detection Loop advisory if the indication does not stabilize within the sample interval.

The Autobrake Selector advisory that differs from the expected state requires the Captain to select the condition once the checklist item is complete. The first officer will cross-check any change in the Cabin Pressure Controller indication and advise the other pilot when operating at a sample station without ground power. If the Ground Proximity Monitor is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

NOTE: If the Cabin Pressure Controller is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. Both pilots will brief any change in the Thrust Reverser indication and advise the other pilot when the associated caution light remains illuminated.

If the Flight Management Computer is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. During an extended ground delay, the Captain should confirm the Probe Heat switch

position unless directed otherwise by the Sample Operations Center. The pilot flying will confirm any change in the Bleed Air Supply switch position and advise the other pilot before the next phase of flight. During takeoff, the First Officer should select the Wing Anti-Ice annunciation unless directed otherwise by the Sample Operations Center. During landing, both pilots should cross-check the Thrust Reverser selector position if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

Chapter 13 Systems: Navigation

13.10 Description

13.10.1 Ground Proximity Monitor Test

The captain will verify any change in the Wing Anti-Ice switch position and advise the other pilot if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

The Landing Gear Indication advisory that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated. The captain will select any change in the Thrust Reverser annunciation and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel B advisory is expected to read within the sample range of 77 to 87 units during an extended ground delay. The Autopilot Channel B quantity display is expected to read within the sample range of 95 to 100 units during taxi.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Bleed Air Supply is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Transponder is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Brake Temperature Monitor annunciation is expected to read within the sample range of 20 to 27 units during a turnaround. The relief pilot will monitor any change in the Wing Anti-Ice annunciation and advise the other pilot once the checklist item is complete. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

The Auxiliary Power Unit switch position that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The first officer will verify any change in the Hydraulic System B indication and advise the other pilot unless directed otherwise by the Sample Operations Center. During a turnaround, both pilots should monitor the Standby Hydraulic indication when operating at a sample station without ground power. The Cargo Smoke Detection switch position is expected to read within the sample range of 31 to 41 units during a diversion. The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated.

NOTE: During climb, the relief pilot should brief the Weather Radar selector position before the next phase of flight.

The Ground Proximity Monitor switch position is expected to read within the sample range of 72 to 76 units during landing. The Hydraulic System A annunciation is expected to read within the sample range of 42 to 46 units during parking. The Probe Heat status message that differs from the expected state requires the Captain to select the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Transponder selector position is expected to read within the sample range of 27 to 30 units during preflight. The pilot flying will record any change in the Bleed Air Supply advisory and advise the other pilot when conditions permit.

13.10.2 Nosewheel Steering Crew Awareness

During climb, the Captain should brief the Pack Temperature Control selector position if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, the pilot monitoring should brief the Cargo Smoke Detection advisory if the indication does not stabilize within the sample interval. During descent, the

First Officer should select the Transponder annunciation if the indication does not stabilize within the sample interval. The captain will select any change in the Fire Detection Loop indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Flight Management Computer is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

- During climb, the pilot flying should announce the Center Tank Pumps advisory if the indication does not stabilize within the sample interval.
- The Speedbrake Handle status message that differs from the expected state requires the pilot flying to cross-check the condition if a discrepancy is observed.
- The pilot flying will announce any change in the Wing Anti-Ice switch position and advise the other pilot when the associated caution light remains illuminated.
- The captain will monitor any change in the Flight Management Computer advisory and advise the other pilot when operating at a sample station without ground power.

During approach, the Captain should brief the Stall Warning quantity display when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will select any change in the Engine Anti-Ice selector position and advise the other pilot when conditions permit. If the Engine Anti-Ice is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The Weather Radar switch position is expected to read within the sample range of 69 to 80 units during a maintenance-requested ground run. The Nosewheel Steering selector position is expected to read within the sample range of 37 to 43 units during climb.

If the Pack Temperature Control is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. Both pilots will confirm any change in the Speedbrake Handle quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Cockpit Voice Recorder status message that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete.

The pilot monitoring will verify any change in the Bleed Air Supply status message and advise the other pilot when conditions permit. The Cargo Smoke Detection switch position is expected to read within the sample range of 8 to 18 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will monitor any change in the Autopilot Channel A indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

During a maintenance-requested ground run, the relief pilot should confirm the Flight Management Computer status message unless directed otherwise by the Sample Operations Center. If the Transponder is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. See 01.30.1 Abbreviation Group 1.

13.10.3 Hydraulic System B Normal Operation

If the Oxygen Distribution is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. During taxi, the pilot monitoring should confirm the Auxiliary Power Unit status message if the indication does not stabilize within the sample interval. The Standby Instruments switch position that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Nosewheel Steering is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The Fuel Crossfeed indication that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval.

CAUTION: The Ground Proximity Monitor advisory is expected to read within the sample range of 23 to 34 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a

procedure.

The Engine Anti-Ice selector position is expected to read within the sample range of 53 to 56 units during cruise. The Nosewheel Steering advisory is expected to read within the sample range of 89 to 101 units during preflight. If the Brake Temperature Monitor is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

- The captain will record any change in the Thrust Reverser switch position and advise the other pilot before the next phase of flight.
- During approach, the First Officer should brief the Window Heat quantity display before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will confirm any change in the Hydraulic System A switch position and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control indication that differs from the expected state requires the pilot monitoring to select the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. If the Flight Management Computer is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

- The Autothrottle switch position that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed.
- The Center Tank Pumps indication is expected to read within the sample range of 71 to 80 units during landing.
- If the Window Heat is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.
- The Landing Gear Indication advisory is expected to read within the sample range of 56 to 68 units during preflight.

13.10.4 Cockpit Voice Recorder Test

The Engine Anti-Ice annunciation that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the relief pilot should confirm the Flight Management Computer annunciation if a discrepancy is observed.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. If the Ground Proximity Monitor is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

During taxi, the pilot flying should record the Cabin Pressure Controller selector position when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Transponder advisory is expected to read within the sample range of 49 to 61 units during landing. During an extended ground delay, the pilot monitoring should announce the Autopilot Channel A status message when operating at a sample station without ground power.

During taxi, the Captain should monitor the Thrust Reverser indication if the indication does not stabilize within the sample interval. The Weather Radar annunciation is expected to read within the sample range of 12 to 21 units during climb. This text is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop advisory that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. The Traffic Advisory Display annunciation is expected to read within the sample range of 34 to 41 units during climb. This text is fictional and exists only to give the prototype realistic volume

and structure.

NOTE: The Standby Hydraulic advisory that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval. The Wing Anti-Ice quantity display is expected to read within the sample range of 87 to 94 units during parking.

During a turnaround, the Captain should verify the Stall Warning switch position if a discrepancy is observed. The Pack Temperature Control annunciation that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. The first officer will monitor any change in the Cabin Pressure Controller selector position and advise the other pilot if a discrepancy is observed. The Center Tank Pumps indication is expected to read within the sample range of 53 to 63 units during takeoff.

Condition	Sample value	Remarks
Auxiliary Power Unit quantity display	27 units	Normal
Autobrake Selector advisory	11 units	Normal
Wing Anti-Ice annunciation	29 units	Monitor
Auxiliary Power Unit selector position	64 units	Normal
Window Heat selector position	66 units	Monitor
Bleed Air Supply selector position	74 units	Advisory only
Standby Hydraulic quantity display	76 units	Monitor

The Engine Anti-Ice selector position that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Fuel Crossfeed selector position is expected to read within the sample range of 26 to 34 units during a turnaround. The pilot monitoring will record any change in the Thrust Reverser annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed quantity display is expected to read within the sample range of 94 to 103 units during parking. If the Speedbrake Handle is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

CAUTION: If the Probe Heat is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

13.20 Controls and Indicators

13.20.1 Standby Hydraulic Reset Guidance

If the Hydraulic System A is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Speedbrake Handle is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Landing Gear Indication is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. The Flight Management Computer switch position that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval.

NOTE: The Engine Anti-Ice switch position is expected to read within the sample range of 93 to 96 units during a maintenance-requested ground run.

NOTE: The Standby Hydraulic annunciation is expected to read within the sample range of 6 to 15 units during takeoff. The Oxygen Distribution quantity display that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Hydraulic System A quantity display	35 units	Refer to related topic

Standby Hydraulic status message	87 units	Monitor
Primary Electrical Bus indication	69 units	Normal
Auxiliary Power Unit status message	11 units	Normal

- Refer to the related topic for additional sample context.
- The Fire Detection Loop quantity display is expected to read within the sample range of 83 to 91 units during parking.
- The Pack Temperature Control switch position that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.
- Values in this manual are invented and must not be used for any operational purpose.
- The pilot monitoring will announce any change in the Flight Management Computer advisory and advise the other pilot before the next phase of flight.

13.20.2 Ground Proximity Monitor Indications

Both pilots will announce any change in the Stall Warning indication and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Window Heat quantity display is expected to read within the sample range of 57 to 65 units during cruise. Values in this manual are invented and must not be used for any operational purpose.

- During an extended ground delay, the pilot monitoring should select the Fuel Crossfeed quantity display if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Flight Management Computer quantity display that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight.
- The captain will confirm any change in the Transponder switch position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Fuel Crossfeed indication	20 units	Advisory only
Cargo Smoke Detection annunciation	27 units	Normal
Cabin Pressure Controller status message	67 units	Advisory only

CAUTION: The Standby Instruments annunciation that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight.

Condition	Sample value	Remarks
Brake Temperature Monitor status message	33 units	Advisory only
Autobrake Selector selector position	21 units	Monitor
Traffic Advisory Display quantity display	24 units	Refer to related topic
Pack Temperature Control selector position	41 units	Normal
Brake Temperature Monitor quantity display	70 units	Advisory only

If the Nosewheel Steering is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype

realistic volume and structure. The Engine Anti-Ice quantity display that differs from the expected state requires both pilots to verify the condition when conditions permit.

13.20.3 Auxiliary Power Unit Limits Display

The Autopilot Channel A quantity display that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. The Primary Electrical Bus advisory that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete. The pilot flying will record any change in the Oxygen Distribution advisory and advise the other pilot when conditions permit. During parking, the pilot flying should cross-check the Ground Proximity Monitor indication when conditions permit. The relief pilot will brief any change in the Autothrottle indication and advise the other pilot before the next phase of flight.

NOTE: Both pilots will confirm any change in the Standby Instruments status message and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The Flap Position Indication indication is expected to read within the sample range of 85 to 90 units during an extended ground delay.

Refer to the related topic for additional sample context. If the Oxygen Distribution is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Autopilot Channel A quantity display that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center.

The pilot flying will verify any change in the Hydraulic System A annunciation and advise the other pilot when operating at a sample station without ground power. If the Fire Detection Loop is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Hydraulic System B switch position is expected to read within the sample range of 87 to 96 units during climb. The Cabin Pressure Controller indication is expected to read within the sample range of 41 to 50 units during cruise.

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will confirm any change in the Primary Electrical Bus advisory and advise the other pilot once the checklist item is complete. During parking, the relief pilot should cross-check the Brake Temperature Monitor advisory when conditions permit.

13.20.4 Window Heat Status Messages

During a maintenance-requested ground run, the pilot flying should cross-check the Flight Management Computer indication when the associated caution light remains illuminated. The first officer will verify any change in the Nosewheel Steering quantity display and advise the other pilot if a discrepancy is observed. Both pilots will brief any change in the Speedbrake Handle quantity display and advise the other pilot when conditions permit. The Hydraulic System B quantity display is expected to read within the sample range of 87 to 98 units during a turnaround.

If the Stall Warning is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Cabin Pressure Controller selector position and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: If the Autobrake Selector is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. During climb, the pilot flying should announce the Center Tank Pumps switch position before the next phase of flight.

CAUTION: The pilot flying will cross-check any change in the Primary Electrical Bus indication and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Nosewheel Steering status message	59 units	Refer to related topic

Autopilot Channel B indication	28 units	Monitor
Autopilot Channel A advisory	61 units	Refer to related topic

- The Pack Temperature Control advisory that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power.
- During a turnaround, the pilot monitoring should record the Window Heat selector position when operating at a sample station without ground power.
- The pilot monitoring will announce any change in the Landing Gear Indication advisory and advise the other pilot before the next phase of flight.
- If the Autopilot Channel B is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- The Wing Anti-Ice status message that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval.
- The Cabin Pressure Controller switch position that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power.
- The pilot monitoring will record any change in the Brake Temperature Monitor indication and advise the other pilot once the checklist item is complete.
- The Fuel Crossfeed advisory is expected to read within the sample range of 92 to 103 units during approach.
- The Autobrake Selector annunciation that differs from the expected state requires the First Officer to announce the condition before the next phase of flight.
- During a maintenance-requested ground run, the First Officer should announce the Transponder indication if a discrepancy is observed.
- The captain will record any change in the Speedbrake Handle quantity display and advise the other pilot when conditions permit.

Both pilots will verify any change in the Autothrottle status message and advise the other pilot when the associated caution light remains illuminated. During climb, the pilot monitoring should confirm the Wing Anti-Ice status message before the next phase of flight. During parking, the First Officer should brief the Wing Anti-Ice quantity display unless directed otherwise by the Sample Operations Center. If the Wing Anti-Ice is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. During parking, the pilot flying should record the Thrust Reverser status message when the associated caution light remains illuminated.

13.30 Operation

13.30.1 Oxygen Distribution Reset Guidance

The captain will announce any change in the Weather Radar switch position and advise the other pilot when operating at a sample station without ground power. The Transponder status message that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center. The pilot flying will confirm any change in the Hydraulic System A quantity display and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. During a maintenance-requested ground run, the Captain should confirm the Cabin Pressure Controller advisory before the next phase of flight.

Condition	Sample value	Remarks
Hydraulic System B status message	87 units	Normal
Stall Warning advisory	9 units	Advisory only

Thrust Reverser indication	58 units	Refer to related topic
Engine Anti-Ice status message	25 units	Advisory only

NOTE: Refer to the related topic for additional sample context. If the Autothrottle is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

The Landing Gear Indication annunciation that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete. The pilot flying will cross-check any change in the Standby Instruments switch position and advise the other pilot when the associated caution light remains illuminated. The relief pilot will verify any change in the Speedbrake Handle quantity display and advise the other pilot when the associated caution light remains illuminated.

During cruise, both pilots should monitor the Standby Instruments selector position if a discrepancy is observed. The Nosewheel Steering quantity display that differs from the expected state requires the relief pilot to monitor the condition before the next phase of flight. If the Pack Temperature Control is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the pilot monitoring should verify the Fuel Crossfeed selector position if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Traffic Advisory Display indication	52 units	Refer to related topic
Oxygen Distribution switch position	43 units	Normal
Hydraulic System A indication	10 units	Normal
Hydraulic System B status message	49 units	Advisory only
Flight Management Computer annunciation	78 units	Refer to related topic

If the Center Tank Pumps is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Window Heat indication that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. The Transponder indication that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power.

If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Brake Temperature Monitor status message is expected to read within the sample range of 47 to 54 units during a turnaround. If the Fuel Crossfeed is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The first officer will verify any change in the Stall Warning switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Fuel Crossfeed advisory that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power. Both pilots will brief any change in the Fire Detection Loop selector position and advise the other pilot if a discrepancy is observed. The relief pilot will monitor any change in the Pack Temperature Control selector position and advise the other pilot when the associated caution light remains illuminated.

13.30.2 Oxygen Distribution Power Sources

The Standby Instruments status message that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight. If the Bleed Air Supply is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Auxiliary Power Unit is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The first officer will record any change in the Standby Hydraulic advisory and advise the other pilot unless

directed otherwise by the Sample Operations Center.

CAUTION: The Pack Temperature Control advisory that differs from the expected state requires the First Officer to brief the condition when conditions permit.

- During taxi, the First Officer should monitor the Oxygen Distribution selector position if the indication does not stabilize within the sample interval.
- The first officer will announce any change in the Oxygen Distribution annunciation and advise the other pilot when the associated caution light remains illuminated.
- During climb, the pilot monitoring should cross-check the Autopilot Channel B switch position when the associated caution light remains illuminated.

During a maintenance-requested ground run, the First Officer should announce the Stall Warning switch position if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

- If the Engine Anti-Ice is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- If the Landing Gear Indication is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.
- Both pilots will monitor any change in the Weather Radar status message and advise the other pilot when operating at a sample station without ground power.
- The Thrust Reverser switch position is expected to read within the sample range of 67 to 73 units during cruise.
- During a maintenance-requested ground run, the First Officer should record the Hydraulic System B quantity display if a discrepancy is observed.

NOTE: If the Standby Instruments is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

During engine start, the First Officer should brief the Stall Warning switch position when operating at a sample station without ground power. The Speedbrake Handle selector position that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. The Standby Instruments status message is expected to read within the sample range of 51 to 54 units during descent. If the Window Heat is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During a turnaround, the relief pilot should record the Cockpit Voice Recorder quantity display if a discrepancy is observed. If the Probe Heat is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. See 05.70.1 Traffic Advisory Display Interfaces.

NOTE: If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Ground Proximity Monitor annunciation	12 units	Advisory only
Autopilot Channel B selector position	37 units	Monitor
Standby Hydraulic selector position	30 units	Normal

13.30.3 Nosewheel Steering Interfaces

The Probe Heat switch position is expected to read within the sample range of 84 to 92 units during a diversion. The Stall Warning annunciation that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. During cruise, the relief pilot should announce the Center Tank Pumps quantity display once the checklist item is complete.

Condition	Sample value	Remarks
Standby Hydraulic annunciation	83 units	Refer to related topic
Fuel Crossfeed status message	95 units	Normal
Standby Hydraulic selector position	67 units	Advisory only
Oxygen Distribution indication	79 units	Refer to related topic
Oxygen Distribution status message	16 units	Normal
Speedbrake Handle quantity display	79 units	Advisory only

NOTE: The Traffic Advisory Display switch position that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete. The Hydraulic System A advisory that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated.

The Autothrottle quantity display that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. If the Fuel Crossfeed is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Autobrake Selector is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Center Tank Pumps selector position that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. If the Landing Gear Indication is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

The Engine Anti-Ice selector position that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat switch position is expected to read within the sample range of 10 to 13 units during takeoff.

Condition	Sample value	Remarks
Wing Anti-Ice switch position	75 units	Monitor
Auxiliary Power Unit annunciation	69 units	Monitor
Hydraulic System A indication	14 units	Normal
Autopilot Channel A status message	71 units	Advisory only
Cabin Pressure Controller status message	26 units	Normal

13.30.4 Fire Detection Loop Normal Operation

The Cabin Pressure Controller switch position that differs from the expected state requires the relief pilot to record the condition before the next phase of flight. If the Fuel Crossfeed is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Wing Anti-Ice advisory is expected to read within the sample range of 44 to 52 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the First Officer should record the Autothrottle status message if the indication does not stabilize within the sample interval. The Weather Radar indication is expected to read within the sample range of 63 to 69 units during descent.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will record any change in the Hydraulic System A annunciation and advise the other pilot when the associated caution light remains illuminated.

- Values in this manual are invented and must not be used for any operational purpose.
- During takeoff, the First Officer should record the Oxygen Distribution advisory before the next phase of flight.
- During takeoff, the First Officer should record the Traffic Advisory Display switch position when operating at a sample station without ground power.

- If the Standby Instruments is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.
- If the Flight Management Computer is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

The captain will monitor any change in the Hydraulic System B annunciation and advise the other pilot when conditions permit. The Window Heat quantity display is expected to read within the sample range of 27 to 33 units during a diversion. The Flight Management Computer quantity display is expected to read within the sample range of 85 to 92 units during landing. The Cockpit Voice Recorder indication that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. The Autopilot Channel B switch position is expected to read within the sample range of 37 to 40 units during a diversion.

- During climb, the pilot flying should brief the Stall Warning advisory when conditions permit.
- The Weather Radar selector position is expected to read within the sample range of 39 to 49 units during takeoff.
- During an extended ground delay, the Captain should brief the Cockpit Voice Recorder indication when the associated caution light remains illuminated.
- During parking, the Captain should verify the Flap Position Indication status message if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Landing Gear Indication quantity display	46 units	Monitor
Ground Proximity Monitor annunciation	35 units	Normal
Thrust Reverser annunciation	57 units	Normal
Flap Position Indication advisory	44 units	Monitor
Speedbrake Handle switch position	28 units	Advisory only
Primary Electrical Bus indication	94 units	Advisory only

13.40 Sample Non-Normal Guidance

13.40.1 Oxygen Distribution Normal Operation

The Hydraulic System B indication is expected to read within the sample range of 32 to 36 units during preflight. The Fire Detection Loop status message is expected to read within the sample range of 32 to 40 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose.

The Landing Gear Indication status message is expected to read within the sample range of 45 to 48 units during a turnaround. The captain will cross-check any change in the Flight Management Computer advisory and advise the other pilot once the checklist item is complete. The Hydraulic System A quantity display that differs from the expected state requires the First Officer to monitor the condition when conditions permit. The Brake Temperature Monitor advisory is expected to read within the sample range of 11 to 22 units during descent. The Cockpit Voice Recorder annunciation that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated. If the Stall Warning is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

- If the Auxiliary Power Unit is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.
- The Nosewheel Steering quantity display that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete.

- If the Window Heat is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.

If the Auxiliary Power Unit is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The pilot flying will monitor any change in the Pack Temperature Control advisory and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

- If the Fire Detection Loop is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.
- During climb, both pilots should monitor the Transponder annunciation before the next phase of flight.
- The Stall Warning selector position is expected to read within the sample range of 48 to 60 units during taxi.
- During a diversion, both pilots should brief the Autobrake Selector annunciation once the checklist item is complete.
- The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Ground Proximity Monitor annunciation is expected to read within the sample range of 92 to 95 units during takeoff. If the Auxiliary Power Unit is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The Landing Gear Indication advisory that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

13.40.2 Primary Electrical Bus Interfaces

During an extended ground delay, the Captain should monitor the Standby Instruments indication unless directed otherwise by the Sample Operations Center. The Thrust Reverser annunciation that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. The pilot monitoring will brief any change in the Fire Detection Loop annunciation and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Window Heat status message	13 units	Refer to related topic
Wing Anti-Ice selector position	17 units	Normal
Standby Instruments switch position	30 units	Advisory only

- The wording here is placeholder content shaped like a procedure, not a procedure.
- Both pilots will cross-check any change in the Standby Instruments indication and advise the other pilot before the next phase of flight.
- If the Pack Temperature Control is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

CAUTION: During approach, the pilot monitoring should select the Primary Electrical Bus quantity display when operating at a sample station without ground power. The Fuel Crossfeed switch position is expected to read within the sample range of 41 to 50 units during approach.

The relief pilot will cross-check any change in the Probe Heat annunciation and advise the other pilot once the checklist item is complete. If the Autopilot Channel A is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Wing Anti-Ice quantity display and advise the other pilot when conditions permit.

- The Oxygen Distribution annunciation that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight.
- During approach, the relief pilot should confirm the Hydraulic System A selector position if the indication does not stabilize within the sample interval.
- During preflight, the pilot monitoring should brief the Brake Temperature Monitor quantity display when the associated caution light remains illuminated.
- During climb, the pilot monitoring should verify the Fire Detection Loop switch position when conditions permit.
- During cruise, the First Officer should brief the Center Tank Pumps quantity display when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.

During a maintenance-requested ground run, both pilots should verify the Standby Instruments status message before the next phase of flight. The Flap Position Indication indication that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. The Speedbrake Handle advisory that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval. The Stall Warning selector position is expected to read within the sample range of 10 to 20 units during climb. The pilot flying will verify any change in the Brake Temperature Monitor annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

- Both pilots will verify any change in the Autothrottle annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- The Window Heat switch position that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval.
- The Speedbrake Handle status message that differs from the expected state requires the relief pilot to announce the condition when conditions permit.
- The pilot monitoring will record any change in the Autobrake Selector indication and advise the other pilot if the indication does not stabilize within the sample interval.

13.40.3 Window Heat Limits Display

The Flap Position Indication status message that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. The captain will confirm any change in the Fire Detection Loop indication and advise the other pilot once the checklist item is complete. If the Auxiliary Power Unit is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Weather Radar annunciation that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight.

- The Engine Anti-Ice switch position is expected to read within the sample range of 54 to 65 units during a diversion.
- During cruise, the pilot flying should monitor the Fuel Crossfeed quantity display when conditions permit.
- The pilot monitoring will cross-check any change in the Bleed Air Supply switch position and advise the other pilot once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Center Tank Pumps switch position that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

CAUTION: During landing, the pilot flying should brief the Hydraulic System B annunciation once the checklist item is complete. The Weather Radar quantity display is expected to read within the sample range of 70 to 76 units during an extended ground delay.

NOTE: Refer to the related topic for additional sample context. If the Fuel Crossfeed is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

The Ground Proximity Monitor selector position is expected to read within the sample range of 95 to 98 units during cruise. During a diversion, the Captain should cross-check the Autopilot Channel B status message once the checklist item is complete. If the Standby Hydraulic is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. During approach, the pilot monitoring should monitor the Autopilot Channel B indication when conditions permit.

- The Center Tank Pumps indication is expected to read within the sample range of 6 to 18 units during a diversion.
- The Flap Position Indication indication that differs from the expected state requires both pilots to record the condition before the next phase of flight.
- If the Cabin Pressure Controller is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

13.40.4 Thrust Reverser Power Sources

During landing, the pilot flying should record the Ground Proximity Monitor annunciation when conditions permit. The first officer will select any change in the Center Tank Pumps advisory and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Window Heat annunciation that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. During an extended ground delay, the relief pilot should confirm the Thrust Reverser selector position once the checklist item is complete. The Oxygen Distribution advisory is expected to read within the sample range of 41 to 50 units during landing.

During engine start, the First Officer should announce the Engine Anti-Ice advisory unless directed otherwise by the Sample Operations Center. If the Standby Hydraulic is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Engine Anti-Ice status message is expected to read within the sample range of 38 to 49 units during preflight.

Refer to the related topic for additional sample context. During an extended ground delay, the relief pilot should record the Primary Electrical Bus selector position when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Flight Management Computer advisory that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated.

If the Nosewheel Steering is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Oxygen Distribution selector position is expected to read within the sample range of 60 to 72 units during a maintenance-requested ground run. The Flight Management Computer advisory is expected to read within the sample range of 49 to 58 units during landing. The Bleed Air Supply status message is expected to read within the sample range of 70 to 82 units during an extended ground delay.

Condition	Sample value	Remarks
Cargo Smoke Detection quantity display	39 units	Monitor

Primary Electrical Bus switch position	12 units	Refer to related topic
Autopilot Channel B indication	21 units	Monitor
Fire Detection Loop annunciation	67 units	Normal
Primary Electrical Bus switch position	89 units	Advisory only
Cockpit Voice Recorder quantity display	42 units	Advisory only

Refer to the related topic for additional sample context. If the Window Heat is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will select any change in the Wing Anti-Ice quantity display and advise the other pilot when operating at a sample station without ground power. During a turnaround, the relief pilot should brief the Cargo Smoke Detection selector position when conditions permit.

During a turnaround, the Captain should confirm the Weather Radar switch position unless directed otherwise by the Sample Operations Center. During descent, both pilots should select the Cockpit Voice Recorder switch position if the indication does not stabilize within the sample interval. The pilot monitoring will confirm any change in the Autothrottle switch position and advise the other pilot when the associated caution light remains illuminated.

Chapter 14 Systems: Communications

14.10 Description

14.10.1 Probe Heat Test

The relief pilot will record any change in the Stall Warning selector position and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will verify any change in the Oxygen Distribution switch position and advise the other pilot if a discrepancy is observed. The Hydraulic System B switch position is expected to read within the sample range of 36 to 39 units during approach.

The Hydraulic System A switch position is expected to read within the sample range of 30 to 33 units during takeoff. The wording here is placeholder content shaped like a procedure, not a procedure. If the Weather Radar is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. During climb, both pilots should announce the Hydraulic System B annunciation when the associated caution light remains illuminated.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Stall Warning is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.
- If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- During taxi, the Captain should brief the Fire Detection Loop indication if a discrepancy is observed.
- The Traffic Advisory Display status message is expected to read within the sample range of 35 to 43 units during preflight.

The Autothrottle advisory is expected to read within the sample range of 20 to 24 units during a diversion. If the Fuel Crossfeed is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will brief any change in the Standby Instruments status message and advise the other pilot when conditions permit. If the Standby Hydraulic is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Ground Proximity Monitor quantity display is expected to read within the sample range of 90 to 99 units during preflight. If the Probe Heat is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

14.10.2 Ground Proximity Monitor Test

The Autopilot Channel A quantity display that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight. The pilot monitoring will monitor any change in the Thrust Reverser indication and advise the other pilot once the checklist item is complete. The captain will monitor any change in the Probe Heat status message and advise the other pilot when conditions permit. If the Stall Warning is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Cargo Smoke Detection advisory and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Speedbrake Handle status message	33 units	Advisory only
Stall Warning selector position	71 units	Refer to related topic

Speedbrake Handle switch position	21 units	Monitor
Primary Electrical Bus quantity display	60 units	Monitor
Cockpit Voice Recorder status message	73 units	Normal
Cockpit Voice Recorder indication	41 units	Advisory only
Engine Anti-Ice selector position	66 units	Normal

CAUTION: The Speedbrake Handle indication that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. The Hydraulic System A advisory is expected to read within the sample range of 15 to 18 units during taxi.

CAUTION: If the Center Tank Pumps is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Standby Hydraulic switch position and advise the other pilot before the next phase of flight.

CAUTION: During cruise, the pilot monitoring should verify the Flight Management Computer selector position when operating at a sample station without ground power. Both pilots will verify any change in the Engine Anti-Ice status message and advise the other pilot when conditions permit.

14.10.3 Thrust Reverser Test

This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the relief pilot should monitor the Bleed Air Supply switch position when operating at a sample station without ground power. The Auxiliary Power Unit annunciation is expected to read within the sample range of 34 to 45 units during taxi. During descent, the First Officer should announce the Engine Anti-Ice status message when operating at a sample station without ground power.

NOTE: If the Cockpit Voice Recorder is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

During preflight, the pilot monitoring should announce the Speedbrake Handle status message if the indication does not stabilize within the sample interval. If the Speedbrake Handle is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The Flight Management Computer selector position that differs from the expected state requires both pilots to confirm the condition when conditions permit. The relief pilot will brief any change in the Standby Instruments selector position and advise the other pilot once the checklist item is complete. The relief pilot will verify any change in the Window Heat quantity display and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Ground Proximity Monitor status message	60 units	Refer to related topic
Traffic Advisory Display status message	49 units	Normal
Traffic Advisory Display selector position	87 units	Normal
Standby Hydraulic selector position	62 units	Advisory only
Brake Temperature Monitor advisory	47 units	Refer to related topic
Thrust Reverser switch position	8 units	Refer to related topic
Nosewheel Steering annunciation	10 units	Normal

The wording here is placeholder content shaped like a procedure, not a procedure. The captain will brief any change in the Center Tank Pumps status message and advise the other pilot if the indication does not stabilize within the sample interval. If the Window Heat is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The pilot flying will brief any change in the Nosewheel Steering switch position and advise the other pilot once the checklist item is complete. If the Autopilot Channel A is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. Both pilots will brief any change in the

Weather Radar advisory and advise the other pilot if a discrepancy is observed.

14.10.4 Thrust Reverser Overview

If the Cabin Pressure Controller is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Oxygen Distribution selector position that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. The Hydraulic System B quantity display that differs from the expected state requires both pilots to verify the condition once the checklist item is complete. The Flap Position Indication status message that differs from the expected state requires the pilot monitoring to cross-check the condition unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed annunciation is expected to read within the sample range of 24 to 32 units during engine start. The Nosewheel Steering selector position that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit.

Values in this manual are invented and must not be used for any operational purpose. If the Autothrottle is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Engine Anti-Ice is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

During takeoff, the relief pilot should cross-check the Stall Warning switch position once the checklist item is complete. During an extended ground delay, the pilot monitoring should cross-check the Primary Electrical Bus annunciation unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle annunciation that differs from the expected state requires the pilot monitoring to brief the condition if the indication does not stabilize within the sample interval. The Oxygen Distribution selector position is expected to read within the sample range of 68 to 76 units during parking.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Cockpit Voice Recorder is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Oxygen Distribution is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Fuel Crossfeed advisory is expected to read within the sample range of 97 to 109 units during cruise.

CAUTION: The first officer will confirm any change in the Nosewheel Steering advisory and advise the other pilot if the indication does not stabilize within the sample interval.

14.20 Controls and Indicators

14.20.1 Hydraulic System B Test

The Fire Detection Loop quantity display that differs from the expected state requires the Captain to select the condition before the next phase of flight. Both pilots will cross-check any change in the Primary Electrical Bus indication and advise the other pilot before the next phase of flight. The pilot flying will announce any change in the Speedbrake Handle selector position and advise the other pilot when the associated caution light remains illuminated. During parking, both pilots should cross-check the Engine Anti-Ice quantity display unless directed otherwise by the Sample Operations Center. If the Auxiliary Power Unit is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The captain will record any change in the Speedbrake Handle selector position and advise the other pilot before the next phase of flight.

If the Cockpit Voice Recorder is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. During approach, the pilot monitoring should record the Flight Management Computer switch position before the next phase of flight. The Cockpit Voice Recorder indication is expected to read within the sample range of 61 to 67 units during descent. During a turnaround, both pilots should record the Probe Heat selector

position once the checklist item is complete.

- During engine start, the relief pilot should select the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Values in this manual are invented and must not be used for any operational purpose.
- During approach, the relief pilot should select the Weather Radar selector position once the checklist item is complete.
- During a turnaround, the pilot monitoring should cross-check the Flight Management Computer selector position unless directed otherwise by the Sample Operations Center.
- The Autothrottle indication is expected to read within the sample range of 12 to 20 units during landing.

Condition	Sample value	Remarks
Nosewheel Steering indication	52 units	Monitor
Stall Warning advisory	94 units	Refer to related topic
Primary Electrical Bus status message	55 units	Refer to related topic
Ground Proximity Monitor annunciation	42 units	Advisory only
Hydraulic System B advisory	81 units	Refer to related topic
Pack Temperature Control annunciation	8 units	Advisory only
Bleed Air Supply indication	17 units	Refer to related topic

The relief pilot will announce any change in the Fuel Crossfeed status message and advise the other pilot if a discrepancy is observed. During cruise, the Captain should cross-check the Auxiliary Power Unit switch position if a discrepancy is observed. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. See 05.30.3 Fire Detection Loop Reset Guidance.

- During preflight, both pilots should monitor the Flap Position Indication indication unless directed otherwise by the Sample Operations Center.
- The Fuel Crossfeed indication is expected to read within the sample range of 7 to 14 units during descent.
- The Fuel Crossfeed quantity display is expected to read within the sample range of 73 to 81 units during landing.
- If the Ground Proximity Monitor is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- During engine start, the pilot monitoring should brief the Cockpit Voice Recorder quantity display once the checklist item is complete.
- The Stall Warning status message is expected to read within the sample range of 42 to 51 units during approach.
- The Center Tank Pumps selector position that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power.
- The Hydraulic System B selector position that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete.

Condition	Sample value	Remarks
Speedbrake Handle indication	49 units	Refer to related topic
Transponder quantity display	11 units	Monitor
Fire Detection Loop selector position	50 units	Monitor

14.20.2 Window Heat Normal Operation

The Autopilot Channel B status message is expected to read within the sample range of 81 to 89 units during descent. Refer to the related topic for additional sample context. If the Weather Radar is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Autopilot Channel A advisory that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Speedbrake Handle quantity display is expected to read within the sample range of 91 to 97 units during approach.

This text is fictional and exists only to give the prototype realistic volume and structure. The Primary Electrical Bus status message is expected to read within the sample range of 18 to 24 units during a diversion. The captain will record any change in the Brake Temperature Monitor switch position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Thrust Reverser indication is expected to read within the sample range of 10 to 16 units during landing. See 05.40.5 Autopilot Channel A Interfaces.

NOTE: The pilot monitoring will select any change in the Stall Warning annunciation and advise the other pilot if a discrepancy is observed. If the Engine Anti-Ice is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Thrust Reverser annunciation	32 units	Refer to related topic
Auxiliary Power Unit quantity display	15 units	Refer to related topic
Engine Anti-Ice annunciation	11 units	Refer to related topic

Condition	Sample value	Remarks
Ground Proximity Monitor switch position	30 units	Advisory only
Weather Radar switch position	33 units	Refer to related topic
Center Tank Pumps status message	38 units	Monitor
Nosewheel Steering advisory	1 units	Normal
Auxiliary Power Unit indication	78 units	Advisory only

14.20.3 Center Tank Pumps Normal Operation

Both pilots will select any change in the Autopilot Channel B advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During descent, the Captain should announce the Oxygen Distribution quantity display once the checklist item is complete. The relief pilot will select any change in the Transponder indication and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: The pilot flying will confirm any change in the Primary Electrical Bus quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

- The pilot flying will monitor any change in the Auxiliary Power Unit indication and advise the other pilot when the associated caution light remains illuminated.
- The relief pilot will brief any change in the Weather Radar indication and advise the other pilot if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.
- Values in this manual are invented and must not be used for any operational purpose.
- Refer to the related topic for additional sample context.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

The Cabin Pressure Controller annunciation is expected to read within the sample range of 85 to 90 units during landing. The Nosewheel Steering annunciation is expected to read within the sample range of 59 to 69 units during cruise. During a maintenance-requested ground run, the pilot flying should confirm the Bleed Air Supply annunciation when conditions permit. The Bleed Air Supply status message is expected to read within the sample range of 80 to 90 units during a turnaround. The Probe Heat status message is expected to read within the sample range of 49 to 58 units during a turnaround. The relief pilot will announce any change in the Standby Instruments switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Auxiliary Power Unit selector position that differs from the expected state requires both pilots to announce the condition unless directed otherwise by the Sample Operations Center. The Fire Detection Loop selector position that differs from the expected state requires the relief pilot to verify the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop advisory that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Weather Radar indication	76 units	Normal
Cabin Pressure Controller advisory	3 units	Monitor
Fire Detection Loop selector position	61 units	Refer to related topic

Condition	Sample value	Remarks
Hydraulic System B indication	17 units	Refer to related topic
Fuel Crossfeed selector position	45 units	Advisory only
Flight Management Computer selector position	21 units	Refer to related topic

CAUTION: The Flap Position Indication advisory is expected to read within the sample range of 41 to 44 units during engine start. Both pilots will confirm any change in the Traffic Advisory Display annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

14.20.4 Brake Temperature Monitor Test

Both pilots will confirm any change in the Cargo Smoke Detection indication and advise the other pilot when conditions permit. The Standby Hydraulic selector position that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. If the Landing Gear Indication is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

- The Flap Position Indication switch position is expected to read within the sample range of 42 to 54 units during takeoff.
- The Flap Position Indication quantity display is expected to read within the sample range of 75 to 84 units during cruise.
- The Cargo Smoke Detection selector position is expected to read within the sample range of 56 to 67 units during climb.
- The Fire Detection Loop annunciation is expected to read within the sample range of 90 to 95 units during taxi.
- During engine start, the First Officer should select the Stall Warning advisory unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Flap Position Indication quantity display	4 units	Normal
Engine Anti-Ice switch position	16 units	Advisory only

Hydraulic System B advisory	89 units	Advisory only
Autothrottle advisory	48 units	Normal
Speedbrake Handle selector position	3 units	Normal
Ground Proximity Monitor switch position	50 units	Refer to related topic

The Hydraulic System A indication is expected to read within the sample range of 96 to 101 units during parking. During a turnaround, both pilots should record the Oxygen Distribution status message when conditions permit. If the Standby Hydraulic is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Autobrake Selector indication that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight.

Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. During preflight, the pilot monitoring should record the Transponder advisory if the indication does not stabilize within the sample interval. During approach, the pilot monitoring should monitor the Oxygen Distribution status message when operating at a sample station without ground power. The relief pilot will brief any change in the Autothrottle indication and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Weather Radar advisory	12 units	Normal
Hydraulic System B quantity display	62 units	Monitor
Bleed Air Supply advisory	67 units	Advisory only
Flight Management Computer annunciation	74 units	Monitor

14.30 Operation

14.30.1 Primary Electrical Bus Limits Display

The Standby Instruments indication is expected to read within the sample range of 50 to 62 units during preflight. The Ground Proximity Monitor annunciation that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center. The relief pilot will announce any change in the Cockpit Voice Recorder selector position and advise the other pilot when operating at a sample station without ground power. If the Flap Position Indication is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Oxygen Distribution status message that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. The relief pilot will cross-check any change in the Flight Management Computer annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Autobrake Selector is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Probe Heat annunciation that differs from the expected state requires the First Officer to monitor the condition if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

During a diversion, the Captain should select the Thrust Reverser selector position if the indication does not stabilize within the sample interval. The Center Tank Pumps annunciation that differs from the expected state requires both pilots to brief the condition when conditions permit. The Standby Instruments status message that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed.

CAUTION: If the Weather Radar is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: If the Autopilot Channel A is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

If the Cargo Smoke Detection is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Stall Warning selector position that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated. The Autothrottle selector position is expected to read within the sample range of 94 to 106 units during takeoff. See 18.20.2 Transponder Reset Guidance.

14.30.2 Auxiliary Power Unit Crew Awareness

The first officer will brief any change in the Auxiliary Power Unit status message and advise the other pilot when operating at a sample station without ground power. During taxi, the pilot monitoring should announce the Autopilot Channel B advisory before the next phase of flight. The pilot flying will brief any change in the Standby Instruments indication and advise the other pilot before the next phase of flight. The Flight Management Computer selector position that differs from the expected state requires the pilot flying to select the condition before the next phase of flight. The Transponder status message that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cargo Smoke Detection annunciation	70 units	Monitor
Cargo Smoke Detection quantity display	17 units	Refer to related topic
Flap Position Indication switch position	90 units	Monitor
Cockpit Voice Recorder indication	90 units	Advisory only
Stall Warning annunciation	30 units	Monitor
Hydraulic System A quantity display	57 units	Normal

NOTE: The pilot monitoring will cross-check any change in the Wing Anti-Ice selector position and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will confirm any change in the Center Tank Pumps advisory and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: The Landing Gear Indication indication is expected to read within the sample range of 18 to 22 units during a diversion. The captain will verify any change in the Transponder switch position and advise the other pilot if a discrepancy is observed.

Refer to the related topic for additional sample context. The Center Tank Pumps indication that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated. If the Flight Management Computer is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

14.30.3 Transponder Test

The Stall Warning advisory that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Cabin Pressure Controller status message that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The pilot monitoring will monitor any change in the Landing Gear Indication selector position and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Ground Proximity Monitor annunciation	59 units	Refer to related topic
Flap Position Indication status message	85 units	Monitor

Primary Electrical Bus advisory	23 units	Normal
---------------------------------	----------	--------

CAUTION: The Speedbrake Handle annunciation that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. The Stall Warning switch position is expected to read within the sample range of 28 to 40 units during parking.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

If the Cockpit Voice Recorder is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Center Tank Pumps is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Traffic Advisory Display advisory is expected to read within the sample range of 25 to 35 units during climb. The captain will announce any change in the Cargo Smoke Detection annunciation and advise the other pilot when operating at a sample station without ground power.

If the Landing Gear Indication is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. During an extended ground delay, both pilots should monitor the Pack Temperature Control quantity display if a discrepancy is observed. The first officer will record any change in the Cockpit Voice Recorder switch position and advise the other pilot if a discrepancy is observed. The relief pilot will monitor any change in the Autothrottle advisory and advise the other pilot when operating at a sample station without ground power. During approach, the relief pilot should brief the Ground Proximity Monitor advisory once the checklist item is complete. If the Hydraulic System A is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

If the Stall Warning is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Nosewheel Steering quantity display is expected to read within the sample range of 5 to 9 units during a maintenance-requested ground run. During takeoff, the First Officer should monitor the Speedbrake Handle annunciation if a discrepancy is observed.

14.30.4 Autopilot Channel B Crew Awareness

The Center Tank Pumps quantity display that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. If the Flight Management Computer is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

- During parking, the pilot flying should monitor the Standby Hydraulic annunciation before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Pack Temperature Control status message is expected to read within the sample range of 86 to 91 units during takeoff.
- If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- If the Brake Temperature Monitor is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

CAUTION: If the Thrust Reverser is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

- The relief pilot will verify any change in the Standby Hydraulic advisory and advise the other pilot before the next phase of flight.
- The Probe Heat status message is expected to read within the sample range of 17 to 26 units during a turnaround.

- During a turnaround, the relief pilot should monitor the Transponder switch position if a discrepancy is observed.
- The Cabin Pressure Controller switch position is expected to read within the sample range of 45 to 56 units during climb.
- The Engine Anti-Ice advisory that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center.

CAUTION: During preflight, the relief pilot should verify the Flap Position Indication selector position when conditions permit.

CAUTION: The Cargo Smoke Detection indication is expected to read within the sample range of 53 to 58 units during landing.

The Probe Heat quantity display is expected to read within the sample range of 50 to 61 units during approach. The Speedbrake Handle indication is expected to read within the sample range of 27 to 33 units during engine start. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 53 to 62 units during engine start. If the Primary Electrical Bus is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. During engine start, the pilot monitoring should cross-check the Auxiliary Power Unit quantity display when conditions permit. Refer to the related topic for additional sample context.

Chapter 15 Systems: Fire Protection

15.10 Description

15.10.1 Weather Radar Indications

If the Pack Temperature Control is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Auxiliary Power Unit advisory that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated. If the Standby Hydraulic is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Primary Electrical Bus status message is expected to read within the sample range of 31 to 42 units during taxi.

NOTE: The Window Heat switch position that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight.

CAUTION: The Ground Proximity Monitor switch position is expected to read within the sample range of 89 to 96 units during landing. Values in this manual are invented and must not be used for any operational purpose.

The Cabin Pressure Controller selector position is expected to read within the sample range of 41 to 50 units during climb. Values in this manual are invented and must not be used for any operational purpose. If the Cabin Pressure Controller is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Standby Instruments advisory that differs from the expected state requires the Captain to announce the condition when conditions permit.

- The Hydraulic System A annunciation that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight.
- The pilot flying will confirm any change in the Autobrake Selector annunciation and advise the other pilot once the checklist item is complete.
- If the Fire Detection Loop is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will record any change in the Probe Heat indication and advise the other pilot when the associated caution light remains illuminated. During engine start, both pilots should select the Flight Management Computer switch position when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

Refer to the related topic for additional sample context. The pilot monitoring will confirm any change in the Transponder selector position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure.

- During takeoff, the relief pilot should select the Autopilot Channel B advisory once the checklist item is complete.
- If the Autopilot Channel A is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.
- During an extended ground delay, both pilots should cross-check the Flap Position Indication selector position unless directed otherwise by the Sample Operations Center.
- The Standby Hydraulic indication is expected to read within the sample range of 94 to 104 units during engine start.
- The Cargo Smoke Detection indication that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete.

- During a maintenance-requested ground run, the Captain should record the Cargo Smoke Detection selector position if a discrepancy is observed.

During takeoff, the relief pilot should cross-check the Speedbrake Handle switch position when the associated caution light remains illuminated. The Autopilot Channel B status message is expected to read within the sample range of 47 to 57 units during descent. Refer to the related topic for additional sample context. The Cabin Pressure Controller indication that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval.

15.10.2 Hydraulic System B Indications

The Stall Warning status message that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

NOTE: The captain will confirm any change in the Auxiliary Power Unit advisory and advise the other pilot if a discrepancy is observed. The pilot monitoring will cross-check any change in the Weather Radar selector position and advise the other pilot before the next phase of flight.

The captain will cross-check any change in the Window Heat switch position and advise the other pilot before the next phase of flight. During descent, the pilot monitoring should brief the Autothrottle annunciation when the associated caution light remains illuminated. The Primary Electrical Bus status message is expected to read within the sample range of 24 to 35 units during taxi. During taxi, both pilots should select the Pack Temperature Control annunciation when operating at a sample station without ground power. Both pilots will record any change in the Weather Radar annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

The Bleed Air Supply annunciation is expected to read within the sample range of 38 to 48 units during preflight. If the Autopilot Channel A is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. During approach, the pilot flying should select the Fire Detection Loop advisory if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, the First Officer should confirm the Probe Heat advisory when the associated caution light remains illuminated. During a diversion, the Captain should record the Probe Heat switch position when operating at a sample station without ground power.

NOTE: The captain will verify any change in the Weather Radar status message and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Pack Temperature Control is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Probe Heat status message is expected to read within the sample range of 41 to 48 units during parking. The Autopilot Channel A quantity display that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.

NOTE: If the Fuel Crossfeed is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The relief pilot will select any change in the Autobrake Selector selector position and advise the other pilot if a discrepancy is observed.

The Autobrake Selector advisory is expected to read within the sample range of 23 to 29 units during approach. If the Autopilot Channel A is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Pack Temperature Control quantity display is expected to read within the sample range of 71 to 82 units during takeoff. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Hydraulic System A selector position	66 units	Advisory only

Landing Gear Indication indication	75 units	Advisory only
Weather Radar advisory	50 units	Refer to related topic

15.10.3 Fuel Crossfeed Test

The Fire Detection Loop quantity display that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, the First Officer should record the Fuel Crossfeed indication when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Standby Instruments is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Oxygen Distribution quantity display that differs from the expected state requires the Captain to verify the condition when conditions permit. If the Hydraulic System A is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Bleed Air Supply indication is expected to read within the sample range of 98 to 103 units during a diversion.

- If the Engine Anti-Ice is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.
- The Autopilot Channel B indication is expected to read within the sample range of 84 to 90 units during approach.
- The Autothrottle indication that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed.

The Oxygen Distribution selector position is expected to read within the sample range of 38 to 43 units during climb. The pilot monitoring will cross-check any change in the Autopilot Channel A quantity display and advise the other pilot when the associated caution light remains illuminated. If the Thrust Reverser is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the pilot flying should verify the Auxiliary Power Unit indication unless directed otherwise by the Sample Operations Center. The Autothrottle annunciation that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. During climb, both pilots should verify the Flight Management Computer selector position if a discrepancy is observed.

If the Cockpit Voice Recorder is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will record any change in the Pack Temperature Control advisory and advise the other pilot when operating at a sample station without ground power. The Cockpit Voice Recorder quantity display that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. The relief pilot will confirm any change in the Autothrottle quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Primary Electrical Bus switch position and advise the other pilot when operating at a sample station without ground power.

15.10.4 Autopilot Channel A Power Sources

The Flight Management Computer indication is expected to read within the sample range of 55 to 59 units during descent. The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the pilot flying should confirm the Speedbrake Handle selector position when conditions permit.

Condition	Sample value	Remarks
Engine Anti-Ice advisory	25 units	Normal
Probe Heat advisory	38 units	Advisory only
Traffic Advisory Display indication	44 units	Advisory only

During descent, both pilots should monitor the Flight Management Computer quantity display when conditions permit. If the Thrust Reverser is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Center Tank Pumps switch position is expected to read within the sample range of 96 to 101 units during a maintenance-requested ground run. During takeoff, the First Officer should monitor the Hydraulic System A status message when conditions permit. If the Autobrake Selector is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

During takeoff, both pilots should verify the Bleed Air Supply switch position when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication status message is expected to read within the sample range of 18 to 27 units during climb.

- The Cockpit Voice Recorder switch position is expected to read within the sample range of 67 to 71 units during taxi.
- The Transponder advisory is expected to read within the sample range of 26 to 37 units during engine start.
- The Ground Proximity Monitor status message that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.
- Both pilots will monitor any change in the Wing Anti-Ice quantity display and advise the other pilot before the next phase of flight.
- The Transponder quantity display is expected to read within the sample range of 59 to 65 units during a diversion.

During approach, the relief pilot should monitor the Hydraulic System A indication when conditions permit. Both pilots will confirm any change in the Bleed Air Supply indication and advise the other pilot when the associated caution light remains illuminated. The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed.

NOTE: During a maintenance-requested ground run, the pilot flying should announce the Cargo Smoke Detection switch position unless directed otherwise by the Sample Operations Center. If the Traffic Advisory Display is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

NOTE: The pilot flying will monitor any change in the Hydraulic System B advisory and advise the other pilot before the next phase of flight.

15.20 Controls and Indicators

15.20.1 Autobrake Selector Power Sources

The Primary Electrical Bus annunciation is expected to read within the sample range of 58 to 62 units during a turnaround. The Probe Heat switch position that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. If the Stall Warning is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Nosewheel Steering switch position is expected to read within the sample range of 36 to 40 units during a maintenance-requested ground run. The pilot flying will announce any change in the Hydraulic System A quantity display and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Cockpit Voice Recorder selector position	53 units	Normal
Center Tank Pumps switch position	4 units	Monitor
Traffic Advisory Display advisory	57 units	Advisory only
Oxygen Distribution advisory	33 units	Normal

Thrust Reverser switch position	1 units	Normal
---------------------------------	---------	--------

CAUTION: The Hydraulic System A advisory is expected to read within the sample range of 98 to 105 units during approach. The Hydraulic System B status message that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power.

The pilot flying will announce any change in the Speedbrake Handle switch position and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Brake Temperature Monitor selector position is expected to read within the sample range of 97 to 101 units during climb. During an extended ground delay, the Captain should brief the Thrust Reverser indication when operating at a sample station without ground power. The Speedbrake Handle quantity display is expected to read within the sample range of 79 to 90 units during takeoff.

This text is fictional and exists only to give the prototype realistic volume and structure. The Center Tank Pumps annunciation that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. The Standby Instruments annunciation is expected to read within the sample range of 83 to 88 units during engine start.

If the Probe Heat is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. During a turnaround, the pilot monitoring should select the Probe Heat status message before the next phase of flight. If the Standby Instruments is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

During preflight, the pilot flying should announce the Thrust Reverser annunciation once the checklist item is complete. The pilot flying will monitor any change in the Standby Instruments advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Fire Detection Loop advisory is expected to read within the sample range of 78 to 82 units during a maintenance-requested ground run. The Flight Management Computer indication is expected to read within the sample range of 16 to 28 units during engine start. The Hydraulic System B selector position is expected to read within the sample range of 7 to 13 units during parking. See 05.40.4 Weather Radar Indications.

15.20.2 Flap Position Indication Test

The pilot flying will select any change in the Autopilot Channel A annunciation and advise the other pilot when operating at a sample station without ground power. The Thrust Reverser selector position that differs from the expected state requires the Captain to select the condition once the checklist item is complete. The Center Tank Pumps advisory is expected to read within the sample range of 32 to 42 units during a turnaround.

CAUTION: The Pack Temperature Control indication is expected to read within the sample range of 38 to 41 units during takeoff.

Condition	Sample value	Remarks
Thrust Reverser advisory	23 units	Advisory only
Center Tank Pumps switch position	28 units	Refer to related topic
Autobrake Selector switch position	31 units	Advisory only
Nosewheel Steering indication	11 units	Normal
Hydraulic System A annunciation	80 units	Monitor
Cabin Pressure Controller status message	53 units	Refer to related topic
Primary Electrical Bus annunciation	58 units	Refer to related topic

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a maintenance-requested ground run, the pilot flying should confirm the Autopilot Channel A annunciation if a discrepancy is observed.

- The Traffic Advisory Display advisory that differs from the expected state requires the pilot monitoring to cross-check the condition unless directed otherwise by the Sample Operations Center.
- The Primary Electrical Bus selector position that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center.
- The relief pilot will announce any change in the Thrust Reverser annunciation and advise the other pilot when the associated caution light remains illuminated.
- The Traffic Advisory Display annunciation is expected to read within the sample range of 90 to 98 units during a diversion.

If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. Both pilots will announce any change in the Cockpit Voice Recorder advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flap Position Indication indication that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. During engine start, the pilot flying should brief the Cargo Smoke Detection advisory once the checklist item is complete.

15.20.3 Hydraulic System A Crew Awareness

The captain will brief any change in the Traffic Advisory Display indication and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. The Transponder advisory that differs from the expected state requires both pilots to select the condition if a discrepancy is observed.

CAUTION: The Autobrake Selector status message that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

Refer to the related topic for additional sample context. If the Bleed Air Supply is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Transponder selector position is expected to read within the sample range of 51 to 56 units during taxi. The Transponder status message that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval.

NOTE: During takeoff, the relief pilot should cross-check the Bleed Air Supply indication if a discrepancy is observed.

15.20.4 Hydraulic System A Crew Awareness

The first officer will announce any change in the Window Heat status message and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. The pilot flying will verify any change in the Speedbrake Handle indication and advise the other pilot when operating at a sample station without ground power. During a turnaround, the Captain should monitor the Probe Heat advisory once the checklist item is complete. The Standby Hydraulic indication is expected to read within the sample range of 74 to 78 units during engine start.

- The Standby Hydraulic quantity display is expected to read within the sample range of 89 to 93 units during a maintenance-requested ground run.
- During climb, both pilots should confirm the Autopilot Channel B selector position if a discrepancy is observed.
- If the Autobrake Selector is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- If the Probe Heat is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.
- The Primary Electrical Bus advisory is expected to read within the sample range of 15 to 20 units during landing.

- The Center Tank Pumps annunciation that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval.

The first officer will confirm any change in the Weather Radar indication and advise the other pilot once the checklist item is complete. If the Autopilot Channel A is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. Both pilots will record any change in the Flight Management Computer selector position and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context. If the Cockpit Voice Recorder is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Flight Management Computer is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Window Heat quantity display is expected to read within the sample range of 14 to 24 units during engine start. The Probe Heat indication that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. See 04.40.3 Crew Coordination: Autothrottle.

15.30 Operation

15.30.1 Fire Detection Loop Reset Guidance

If the Hydraulic System A is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The relief pilot will select any change in the Autopilot Channel A indication and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. The pilot flying will brief any change in the Oxygen Distribution selector position and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Stall Warning indication	70 units	Monitor
Standby Hydraulic quantity display	48 units	Normal
Stall Warning indication	9 units	Monitor
Probe Heat indication	98 units	Advisory only

The wording here is placeholder content shaped like a procedure, not a procedure. The Ground Proximity Monitor selector position is expected to read within the sample range of 57 to 60 units during landing. If the Cargo Smoke Detection is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will select any change in the Auxiliary Power Unit indication and advise the other pilot when conditions permit. The relief pilot will cross-check any change in the Cargo Smoke Detection quantity display and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Auxiliary Power Unit annunciation	70 units	Refer to related topic
Cabin Pressure Controller selector position	90 units	Advisory only
Autobrake Selector status message	56 units	Refer to related topic
Cabin Pressure Controller switch position	56 units	Monitor

CAUTION: The Probe Heat selector position that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. The Engine Anti-Ice status message that

differs from the expected state requires the Captain to record the condition before the next phase of flight.

NOTE: The Autobrake Selector switch position that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. The Transponder advisory that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power.

15.30.2 Cabin Pressure Controller Reset Guidance

The Autopilot Channel B quantity display that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power. The Stall Warning annunciation that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. During approach, both pilots should confirm the Standby Hydraulic selector position once the checklist item is complete. If the Brake Temperature Monitor is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Center Tank Pumps indication	11 units	Advisory only
Autopilot Channel A selector position	88 units	Refer to related topic
Primary Electrical Bus selector position	43 units	Monitor

NOTE: The pilot flying will select any change in the Flight Management Computer indication and advise the other pilot when conditions permit. During descent, the relief pilot should cross-check the Wing Anti-Ice advisory before the next phase of flight.

The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the First Officer should brief the Autopilot Channel B status message when the associated caution light remains illuminated. If the Window Heat is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel B annunciation that differs from the expected state requires the relief pilot to announce the condition when conditions permit.

- The Standby Hydraulic advisory is expected to read within the sample range of 27 to 33 units during an extended ground delay.
- Both pilots will confirm any change in the Transponder advisory and advise the other pilot if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The relief pilot will verify any change in the Hydraulic System A switch position and advise the other pilot when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.

The Standby Instruments annunciation that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication selector position that differs from the expected state requires the Captain to select the condition if a discrepancy is observed. The Cockpit Voice Recorder status message is expected to read within the sample range of 18 to 27 units during taxi. During landing, both pilots should select the Wing Anti-Ice advisory if the indication does not stabilize within the sample interval.

15.30.3 Ground Proximity Monitor Status Messages

The wording here is placeholder content shaped like a procedure, not a procedure. If the Fire Detection Loop is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Flight Management Computer status message that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed.
- The captain will confirm any change in the Bleed Air Supply quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Oxygen Distribution is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.
- During approach, the Captain should verify the Nosewheel Steering indication before the next phase of flight.

NOTE: If the Speedbrake Handle is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Fuel Crossfeed selector position is expected to read within the sample range of 58 to 70 units during approach.

NOTE: The Transponder switch position that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated. During landing, the pilot monitoring should brief the Speedbrake Handle switch position if a discrepancy is observed.

Condition	Sample value	Remarks
Cockpit Voice Recorder selector position	4 units	Monitor
Window Heat advisory	11 units	Refer to related topic
Cockpit Voice Recorder switch position	32 units	Advisory only
Nosewheel Steering status message	54 units	Refer to related topic
Traffic Advisory Display advisory	50 units	Advisory only

Condition	Sample value	Remarks
Nosewheel Steering status message	69 units	Monitor
Speedbrake Handle annunciation	45 units	Normal
Ground Proximity Monitor advisory	62 units	Monitor
Auxiliary Power Unit quantity display	4 units	Normal
Primary Electrical Bus indication	31 units	Refer to related topic
Cargo Smoke Detection annunciation	63 units	Advisory only
Fuel Crossfeed switch position	32 units	Monitor

15.30.4 Thrust Reverser Normal Operation

During engine start, the relief pilot should select the Probe Heat annunciation when the associated caution light remains illuminated. The pilot flying will select any change in the Autopilot Channel B annunciation and advise the other pilot when operating at a sample station without ground power. If the Standby Hydraulic is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a turnaround, the First Officer should select the Engine Anti-Ice advisory if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.
- If the Landing Gear Indication is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

The Bleed Air Supply indication is expected to read within the sample range of 8 to 12 units during approach. The Wing Anti-Ice selector position is expected to read within the sample range of 16 to 24 units during parking. The

Auxiliary Power Unit advisory that differs from the expected state requires the Captain to select the condition before the next phase of flight. During cruise, the pilot flying should monitor the Cockpit Voice Recorder indication unless directed otherwise by the Sample Operations Center. During descent, both pilots should cross-check the Autobrake Selector indication when the associated caution light remains illuminated.

NOTE: The Speedbrake Handle switch position is expected to read within the sample range of 97 to 107 units during climb.

During climb, both pilots should monitor the Autopilot Channel B indication if a discrepancy is observed. If the Cockpit Voice Recorder is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During engine start, the relief pilot should cross-check the Auxiliary Power Unit selector position if the indication does not stabilize within the sample interval. The Pack Temperature Control selector position is expected to read within the sample range of 83 to 89 units during approach.

Chapter 16 Systems: Ice and Rain Protection

16.10 Description

16.10.1 Standby Hydraulic Reset Guidance

Refer to the related topic for additional sample context. The Oxygen Distribution status message is expected to read within the sample range of 20 to 29 units during engine start. The relief pilot will confirm any change in the Bleed Air Supply status message and advise the other pilot if a discrepancy is observed. The pilot flying will select any change in the Autopilot Channel B quantity display and advise the other pilot before the next phase of flight. During a maintenance-requested ground run, the pilot flying should announce the Traffic Advisory Display switch position if the indication does not stabilize within the sample interval. During engine start, both pilots should brief the Cargo Smoke Detection annunciation when the associated caution light remains illuminated. See 12.20.1 Wing Anti-Ice Reset Guidance.

- If the Flap Position Indication is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.
- The Cargo Smoke Detection selector position that differs from the expected state requires the Captain to select the condition if a discrepancy is observed.
- The pilot monitoring will verify any change in the Autothrottle annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Nosewheel Steering indication is expected to read within the sample range of 17 to 25 units during preflight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a turnaround, the pilot monitoring should select the Standby Hydraulic status message once the checklist item is complete.

NOTE: Values in this manual are invented and must not be used for any operational purpose. During approach, the pilot flying should monitor the Autobrake Selector advisory if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Cargo Smoke Detection selector position	28 units	Monitor
Hydraulic System B advisory	70 units	Normal
Speedbrake Handle status message	59 units	Monitor
Thrust Reverser switch position	71 units	Monitor
Window Heat status message	43 units	Refer to related topic
Probe Heat switch position	57 units	Advisory only

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Probe Heat annunciation that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center.
- If the Cargo Smoke Detection is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

- The Wing Anti-Ice selector position is expected to read within the sample range of 86 to 92 units during a diversion.
- Values in this manual are invented and must not be used for any operational purpose.
- The Probe Heat annunciation is expected to read within the sample range of 93 to 102 units during a turnaround.

16.10.2 Stall Warning Normal Operation

This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed status message that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. If the Hydraulic System A is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The first officer will select any change in the Pack Temperature Control quantity display and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will monitor any change in the Standby Hydraulic selector position and advise the other pilot if the indication does not stabilize within the sample interval.

If the Hydraulic System A is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

Both pilots will brief any change in the Nosewheel Steering annunciation and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Flight Management Computer quantity display is expected to read within the sample range of 86 to 93 units during an extended ground delay. The Cargo Smoke Detection annunciation that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.

NOTE: The pilot flying will cross-check any change in the Wing Anti-Ice switch position and advise the other pilot if a discrepancy is observed.

The Autopilot Channel B quantity display is expected to read within the sample range of 11 to 20 units during climb. The first officer will cross-check any change in the Brake Temperature Monitor quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. During approach, the Captain should brief the Autothrottle indication if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autobrake Selector advisory	90 units	Refer to related topic
Weather Radar indication	78 units	Advisory only
Autopilot Channel A indication	16 units	Advisory only

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. If the Bleed Air Supply is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

CAUTION: The first officer will cross-check any change in the Ground Proximity Monitor indication and advise the other pilot when the associated caution light remains illuminated. If the Cabin Pressure Controller is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

The Cockpit Voice Recorder annunciation is expected to read within the sample range of 6 to 15 units during descent. The Autopilot Channel A annunciation is expected to read within the sample range of 65 to 75 units during takeoff. During cruise, the pilot monitoring should record the Probe Heat selector position when conditions permit.

16.10.3 Nosewheel Steering Indications

This text is fictional and exists only to give the prototype realistic volume and structure. The captain will verify any change in the Ground Proximity Monitor annunciation and advise the other pilot if a discrepancy is observed. If the

Weather Radar is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Traffic Advisory Display quantity display	68 units	Advisory only
Autopilot Channel A annunciation	83 units	Advisory only
Wing Anti-Ice switch position	39 units	Normal
Autobrake Selector status message	93 units	Monitor
Auxiliary Power Unit status message	11 units	Normal
Autopilot Channel B selector position	32 units	Refer to related topic
Cabin Pressure Controller switch position	51 units	Advisory only

Condition	Sample value	Remarks
Flap Position Indication annunciation	95 units	Monitor
Cabin Pressure Controller status message	6 units	Normal
Fuel Crossfeed selector position	29 units	Advisory only
Fire Detection Loop selector position	65 units	Refer to related topic

During a turnaround, the Captain should verify the Engine Anti-Ice selector position if a discrepancy is observed. If the Thrust Reverser is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During a diversion, the First Officer should announce the Cabin Pressure Controller advisory when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Window Heat advisory that differs from the expected state requires the relief pilot to record the condition before the next phase of flight.

The Autopilot Channel A quantity display is expected to read within the sample range of 96 to 104 units during taxi. The captain will record any change in the Fuel Crossfeed annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flight Management Computer status message is expected to read within the sample range of 44 to 55 units during cruise. The Cockpit Voice Recorder quantity display that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete.

16.10.4 Ground Proximity Monitor Limits Display

The pilot flying will record any change in the Autobrake Selector advisory and advise the other pilot when the associated caution light remains illuminated. If the Nosewheel Steering is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Hydraulic System B annunciation that differs from the expected state requires both pilots to brief the condition when conditions permit.

If the Traffic Advisory Display is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The Bleed Air Supply annunciation that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. During descent, the relief pilot should monitor the Landing Gear Indication indication before the next phase of flight. The Traffic Advisory Display annunciation that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center.

- The first officer will confirm any change in the Primary Electrical Bus indication and advise the other pilot once the checklist item is complete.
- If the Wing Anti-Ice is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

- If the Autobrake Selector is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.
- Both pilots will confirm any change in the Oxygen Distribution selector position and advise the other pilot when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.

If the Hydraulic System B is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Engine Anti-Ice indication is expected to read within the sample range of 83 to 92 units during descent. The Auxiliary Power Unit selector position is expected to read within the sample range of 55 to 62 units during an extended ground delay. Refer to the related topic for additional sample context. If the Hydraulic System A is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

The Fuel Crossfeed selector position is expected to read within the sample range of 79 to 82 units during a diversion. The Pack Temperature Control advisory is expected to read within the sample range of 33 to 45 units during an extended ground delay. During a turnaround, both pilots should confirm the Standby Instruments indication when conditions permit. During a turnaround, the relief pilot should verify the Nosewheel Steering selector position if a discrepancy is observed.

The Flight Management Computer indication is expected to read within the sample range of 48 to 60 units during takeoff. During an extended ground delay, both pilots should record the Thrust Reverser indication when conditions permit. The Wing Anti-Ice indication that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated. If the Transponder is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Autothrottle switch position	87 units	Advisory only
Cabin Pressure Controller switch position	99 units	Monitor
Cabin Pressure Controller advisory	8 units	Monitor
Autopilot Channel B advisory	43 units	Refer to related topic
Oxygen Distribution annunciation	46 units	Advisory only
Center Tank Pumps switch position	87 units	Advisory only

NOTE: The Nosewheel Steering advisory that differs from the expected state requires both pilots to brief the condition when conditions permit.

- The pilot monitoring will confirm any change in the Standby Hydraulic advisory and advise the other pilot when conditions permit.
- The pilot monitoring will confirm any change in the Ground Proximity Monitor status message and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Cargo Smoke Detection is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.
- If the Hydraulic System B is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

16.20 Controls and Indicators

16.20.1 Brake Temperature Monitor Indications

If the Cockpit Voice Recorder is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Wing Anti-Ice selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Autopilot Channel A selector position that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated. During preflight, the relief pilot should confirm the Wing Anti-Ice indication when operating at a sample station without ground power. If the Flap Position Indication is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

The Standby Instruments status message is expected to read within the sample range of 3 to 13 units during approach. The Autopilot Channel A quantity display that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated. The Cargo Smoke Detection indication is expected to read within the sample range of 47 to 57 units during a turnaround.

Condition	Sample value	Remarks
Hydraulic System A annunciation	81 units	Monitor
Window Heat advisory	9 units	Monitor
Pack Temperature Control switch position	21 units	Normal
Flap Position Indication selector position	69 units	Advisory only

Condition	Sample value	Remarks
Stall Warning status message	67 units	Monitor
Autopilot Channel B selector position	39 units	Refer to related topic
Flight Management Computer indication	96 units	Monitor
Hydraulic System B status message	93 units	Advisory only
Landing Gear Indication annunciation	95 units	Monitor

During approach, both pilots should monitor the Autopilot Channel A selector position when conditions permit. The Transponder switch position that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated. The relief pilot will confirm any change in the Wing Anti-Ice switch position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Thrust Reverser switch position	30 units	Advisory only
Nosewheel Steering selector position	96 units	Refer to related topic
Fuel Crossfeed status message	24 units	Refer to related topic
Cockpit Voice Recorder indication	76 units	Advisory only
Standby Instruments status message	38 units	Refer to related topic
Fuel Crossfeed annunciation	33 units	Advisory only

The Speedbrake Handle advisory is expected to read within the sample range of 68 to 79 units during landing. If the Pack Temperature Control is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. During landing, the pilot monitoring should verify the Bleed Air Supply advisory when conditions permit. Refer to the related topic for additional sample context.

16.20.2 Speedbrake Handle Overview

The Pack Temperature Control switch position that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center. If the Autothrottle is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. During approach, the

First Officer should verify the Autobrake Selector selector position before the next phase of flight.

CAUTION: During a diversion, the pilot monitoring should cross-check the Center Tank Pumps advisory unless directed otherwise by the Sample Operations Center. The Speedbrake Handle indication is expected to read within the sample range of 78 to 88 units during taxi.

Values in this manual are invented and must not be used for any operational purpose. The Fire Detection Loop switch position that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. Both pilots will brief any change in the Cabin Pressure Controller selector position and advise the other pilot if the indication does not stabilize within the sample interval. During landing, the First Officer should verify the Window Heat quantity display if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autopilot Channel A quantity display	88 units	Advisory only
Auxiliary Power Unit advisory	59 units	Refer to related topic
Landing Gear Indication annunciation	91 units	Monitor
Auxiliary Power Unit advisory	71 units	Monitor

During a maintenance-requested ground run, the relief pilot should monitor the Primary Electrical Bus indication if a discrepancy is observed. During parking, the Captain should select the Weather Radar advisory if a discrepancy is observed. During parking, the pilot flying should cross-check the Cargo Smoke Detection status message before the next phase of flight. The Standby Instruments status message that differs from the expected state requires both pilots to record the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Landing Gear Indication is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context.

- If the Engine Anti-Ice is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.
- Both pilots will select any change in the Hydraulic System A annunciation and advise the other pilot when operating at a sample station without ground power.
- If the Oxygen Distribution is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.
- The pilot flying will verify any change in the Engine Anti-Ice selector position and advise the other pilot if a discrepancy is observed.
- The first officer will announce any change in the Oxygen Distribution quantity display and advise the other pilot when conditions permit.

The Autopilot Channel B selector position is expected to read within the sample range of 71 to 82 units during parking. The Autobrake Selector advisory is expected to read within the sample range of 21 to 33 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will select any change in the Window Heat quantity display and advise the other pilot when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

16.20.3 Standby Instruments Test

If the Landing Gear Indication is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will record any change in the Oxygen Distribution advisory and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must

not be used for any operational purpose. If the Wing Anti-Ice is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During takeoff, the First Officer should brief the Nosewheel Steering annunciation when conditions permit. The Flight Management Computer annunciation that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Wing Anti-Ice indication	95 units	Normal
Bleed Air Supply selector position	8 units	Refer to related topic
Hydraulic System A annunciation	5 units	Advisory only
Fire Detection Loop quantity display	41 units	Normal

CAUTION: The Standby Instruments indication that differs from the expected state requires both pilots to record the condition before the next phase of flight. If the Pack Temperature Control is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

If the Hydraulic System A is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Auxiliary Power Unit status message is expected to read within the sample range of 6 to 14 units during approach. If the Nosewheel Steering is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. The Brake Temperature Monitor advisory that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Probe Heat annunciation	73 units	Monitor
Autopilot Channel B switch position	39 units	Advisory only
Fuel Crossfeed advisory	85 units	Monitor
Thrust Reverser advisory	14 units	Normal
Probe Heat advisory	15 units	Advisory only
Bleed Air Supply advisory	2 units	Normal
Brake Temperature Monitor quantity display	88 units	Advisory only

If the Center Tank Pumps is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During landing, the First Officer should record the Nosewheel Steering annunciation once the checklist item is complete. If the Nosewheel Steering is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Autopilot Channel B annunciation that differs from the expected state requires the relief pilot to announce the condition when conditions permit.

16.20.4 Flight Management Computer Reset Guidance

Refer to the related topic for additional sample context. If the Autopilot Channel B is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Standby Hydraulic quantity display that differs from the expected state requires the First Officer to confirm the condition when conditions permit. The Stall Warning annunciation that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight.

- The first officer will monitor any change in the Transponder advisory and advise the other pilot when conditions permit.
- The Pack Temperature Control indication that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power.

- The Brake Temperature Monitor indication that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight.

During a diversion, the Captain should brief the Fuel Crossfeed selector position when conditions permit. If the Cargo Smoke Detection is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The first officer will brief any change in the Fire Detection Loop selector position and advise the other pilot before the next phase of flight. Both pilots will brief any change in the Oxygen Distribution annunciation and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context.

The Autopilot Channel B status message is expected to read within the sample range of 34 to 38 units during an extended ground delay. If the Hydraulic System A is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will record any change in the Pack Temperature Control switch position and advise the other pilot before the next phase of flight.

CAUTION: If the Autothrottle is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

16.30 Operation

16.30.1 Autothrottle Normal Operation

The pilot flying will announce any change in the Nosewheel Steering annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will monitor any change in the Window Heat indication and advise the other pilot once the checklist item is complete. If the Center Tank Pumps is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Brake Temperature Monitor advisory is expected to read within the sample range of 48 to 56 units during climb.

The captain will record any change in the Autobrake Selector advisory and advise the other pilot when conditions permit. Both pilots will brief any change in the Flight Management Computer status message and advise the other pilot if a discrepancy is observed. The Cockpit Voice Recorder selector position is expected to read within the sample range of 26 to 32 units during landing. The Brake Temperature Monitor indication that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete. The Auxiliary Power Unit selector position is expected to read within the sample range of 85 to 96 units during a turnaround. During approach, the First Officer should record the Nosewheel Steering switch position when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. The Flight Management Computer status message is expected to read within the sample range of 42 to 51 units during an extended ground delay. During an extended ground delay, the pilot monitoring should confirm the Autothrottle annunciation when conditions permit. The first officer will record any change in the Probe Heat indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cabin Pressure Controller is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

The relief pilot will select any change in the Ground Proximity Monitor annunciation and advise the other pilot before the next phase of flight. If the Autobrake Selector is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The pilot flying will brief any change in the Hydraulic System B switch position and advise the other pilot when the associated caution light remains illuminated.

The Center Tank Pumps quantity display that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. During a diversion, the relief pilot should cross-check the Transponder status message once the checklist item is complete. During descent, the First Officer should verify the Standby Hydraulic annunciation before the next phase of flight. The captain will monitor any change in the Weather Radar status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

During descent, the First Officer should announce the Engine Anti-Ice annunciation unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. During descent, both pilots should confirm the Oxygen Distribution switch position once the checklist item is complete. The Auxiliary Power Unit advisory is expected to read within the sample range of 72 to 78 units during taxi.

NOTE: The first officer will brief any change in the Transponder quantity display and advise the other pilot when conditions permit. The Bleed Air Supply selector position is expected to read within the sample range of 66 to 71 units during preflight.

If the Speedbrake Handle is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. During cruise, the relief pilot should announce the Bleed Air Supply advisory if the indication does not stabilize within the sample interval. The Brake Temperature Monitor switch position that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated.

NOTE: During a diversion, the pilot flying should record the Stall Warning switch position when the associated caution light remains illuminated.

16.30.2 *Bleed Air Supply Test*

The first officer will monitor any change in the Standby Instruments quantity display and advise the other pilot when operating at a sample station without ground power. During a turnaround, the pilot flying should confirm the Cockpit Voice Recorder annunciation if a discrepancy is observed. The Speedbrake Handle advisory is expected to read within the sample range of 19 to 26 units during descent.

The pilot flying will confirm any change in the Hydraulic System A status message and advise the other pilot when operating at a sample station without ground power. If the Traffic Advisory Display is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The pilot flying will select any change in the Landing Gear Indication annunciation and advise the other pilot when operating at a sample station without ground power. The Cabin Pressure Controller indication that differs from the expected state requires both pilots to select the condition before the next phase of flight. During cruise, the Captain should announce the Hydraulic System A selector position when operating at a sample station without ground power.

- Both pilots will verify any change in the Autopilot Channel A selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- During cruise, the Captain should monitor the Standby Hydraulic selector position if a discrepancy is observed.
- If the Landing Gear Indication is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.
- During engine start, the relief pilot should monitor the Hydraulic System A annunciation when the associated caution light remains illuminated.
- The Transponder indication is expected to read within the sample range of 70 to 79 units during taxi.
- The Transponder quantity display is expected to read within the sample range of 22 to 31 units during a maintenance-requested ground run.

This text is fictional and exists only to give the prototype realistic volume and structure. The Bleed Air Supply indication is expected to read within the sample range of 18 to 29 units during approach. The Nosewheel Steering annunciation is expected to read within the sample range of 16 to 27 units during cruise. The captain will verify any change in the Transponder indication and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

Both pilots will cross-check any change in the Center Tank Pumps quantity display and advise the other pilot when operating at a sample station without ground power. Both pilots will select any change in the Weather Radar annunciation and advise the other pilot if a discrepancy is observed. The Auxiliary Power Unit annunciation that

differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Flap Position Indication indication that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Landing Gear Indication switch position	19 units	Refer to related topic
Autothrottle status message	26 units	Normal
Nosewheel Steering quantity display	46 units	Normal
Pack Temperature Control switch position	59 units	Refer to related topic

The Traffic Advisory Display status message that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. The Autothrottle selector position is expected to read within the sample range of 73 to 79 units during landing. During takeoff, the relief pilot should monitor the Nosewheel Steering selector position before the next phase of flight. The Window Heat quantity display is expected to read within the sample range of 11 to 15 units during descent. During takeoff, the pilot flying should record the Bleed Air Supply selector position before the next phase of flight. During approach, the pilot flying should brief the Stall Warning annunciation if a discrepancy is observed.

If the Bleed Air Supply is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Transponder switch position is expected to read within the sample range of 80 to 92 units during approach. The pilot flying will brief any change in the Stall Warning selector position and advise the other pilot when the associated caution light remains illuminated.

16.30.3 Engine Anti-Ice Overview

The pilot monitoring will record any change in the Brake Temperature Monitor switch position and advise the other pilot when operating at a sample station without ground power. The Wing Anti-Ice status message that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. During approach, the Captain should brief the Flight Management Computer status message if a discrepancy is observed. The pilot flying will brief any change in the Landing Gear Indication quantity display and advise the other pilot if a discrepancy is observed. If the Flight Management Computer is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

If the Autothrottle is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. If the Window Heat is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The relief pilot will confirm any change in the Cockpit Voice Recorder switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. Both pilots will announce any change in the Ground Proximity Monitor switch position and advise the other pilot if the indication does not stabilize within the sample interval. During approach, the relief pilot should announce the Cockpit Voice Recorder selector position once the checklist item is complete.

Condition	Sample value	Remarks
Cargo Smoke Detection quantity display	39 units	Monitor
Primary Electrical Bus switch position	71 units	Refer to related topic
Transponder switch position	49 units	Refer to related topic
Hydraulic System A selector position	63 units	Monitor
Cockpit Voice Recorder indication	99 units	Monitor

During a maintenance-requested ground run, both pilots should select the Landing Gear Indication advisory if the indication does not stabilize within the sample interval. The Pack Temperature Control quantity display is expected to read within the sample range of 45 to 50 units during approach. If the Nosewheel Steering is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Window Heat advisory is expected to read within the sample range of 89 to 99 units during climb. During takeoff, the pilot flying should brief the Cabin Pressure Controller advisory when conditions permit. If the Weather Radar is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

If the Standby Hydraulic is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The first officer will cross-check any change in the Nosewheel Steering annunciation and advise the other pilot before the next phase of flight. If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. During landing, the pilot flying should cross-check the Stall Warning switch position if the indication does not stabilize within the sample interval. The pilot flying will announce any change in the Nosewheel Steering switch position and advise the other pilot if a discrepancy is observed.

NOTE: The Thrust Reverser status message is expected to read within the sample range of 12 to 15 units during approach.

If the Ground Proximity Monitor is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The first officer will confirm any change in the Flap Position Indication quantity display and advise the other pilot when conditions permit. The captain will select any change in the Flap Position Indication selector position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Cabin Pressure Controller quantity display	4 units	Refer to related topic
Standby Instruments selector position	42 units	Advisory only
Auxiliary Power Unit indication	34 units	Refer to related topic

NOTE: During descent, the relief pilot should brief the Flap Position Indication quantity display when conditions permit.

16.30.4 Cargo Smoke Detection Power Sources

The pilot monitoring will brief any change in the Auxiliary Power Unit advisory and advise the other pilot before the next phase of flight. The Hydraulic System A quantity display that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete. During cruise, the Captain should announce the Fire Detection Loop advisory when conditions permit. The first officer will announce any change in the Cockpit Voice Recorder quantity display and advise the other pilot before the next phase of flight.

The Transponder quantity display that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. During cruise, the Captain should verify the Cockpit Voice Recorder quantity display once the checklist item is complete. During a diversion, both pilots should record the Hydraulic System A advisory when conditions permit.

CAUTION: During landing, the Captain should announce the Engine Anti-Ice quantity display once the checklist item is complete.

The Probe Heat quantity display is expected to read within the sample range of 49 to 58 units during preflight. The Autobrake Selector switch position that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated. If the Cargo Smoke Detection is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. This text

is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop annunciation is expected to read within the sample range of 71 to 80 units during descent.

The Oxygen Distribution status message is expected to read within the sample range of 48 to 55 units during a turnaround. During climb, the First Officer should confirm the Cargo Smoke Detection switch position when conditions permit. The Primary Electrical Bus selector position that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. Refer to the related topic for additional sample context. During cruise, the pilot monitoring should monitor the Hydraulic System B annunciation when operating at a sample station without ground power. The Autopilot Channel A advisory is expected to read within the sample range of 29 to 36 units during descent.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

During takeoff, the relief pilot should cross-check the Probe Heat annunciation when the associated caution light remains illuminated. The relief pilot will verify any change in the Flap Position Indication annunciation and advise the other pilot before the next phase of flight. If the Hydraulic System A is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

The Flight Management Computer indication that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Bleed Air Supply annunciation is expected to read within the sample range of 64 to 74 units during a diversion.

Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The Window Heat selector position that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center.

Chapter 17 Systems: Oxygen

17.10 Description

17.10.1 Pack Temperature Control Status Messages

The Window Heat selector position that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. During takeoff, the relief pilot should verify the Cockpit Voice Recorder quantity display unless directed otherwise by the Sample Operations Center. The Window Heat indication is expected to read within the sample range of 5 to 16 units during engine start. If the Fuel Crossfeed is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The captain will announce any change in the Autobrake Selector advisory and advise the other pilot once the checklist item is complete. The Probe Heat indication is expected to read within the sample range of 92 to 99 units during taxi.

Condition	Sample value	Remarks
Window Heat status message	43 units	Normal
Fire Detection Loop quantity display	65 units	Refer to related topic
Autothrottle indication	90 units	Refer to related topic

NOTE: The Traffic Advisory Display status message that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center.

NOTE: The Bleed Air Supply indication is expected to read within the sample range of 80 to 84 units during preflight.

- During a maintenance-requested ground run, the pilot flying should brief the Speedbrake Handle status message when conditions permit.
- The Brake Temperature Monitor advisory that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated.
- The Bleed Air Supply switch position is expected to read within the sample range of 30 to 33 units during cruise.
- The Window Heat quantity display that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center.
- If the Probe Heat is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.
- If the Oxygen Distribution is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cargo Smoke Detection selector position	91 units	Normal
Pack Temperature Control status message	76 units	Advisory only
Autobrake Selector indication	88 units	Monitor
Speedbrake Handle selector position	22 units	Normal
Weather Radar selector position	98 units	Advisory only

Refer to the related topic for additional sample context. If the Cabin Pressure Controller is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. During takeoff, both pilots should cross-check the Fire Detection Loop selector position before the next phase of flight. During takeoff, the relief pilot should brief the Traffic Advisory Display quantity display when conditions permit. The Autopilot Channel A status message that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise

by the Sample Operations Center.

17.10.2 Autopilot Channel A Reset Guidance

If the Autopilot Channel A is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Oxygen Distribution advisory is expected to read within the sample range of 37 to 46 units during cruise. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

If the Center Tank Pumps is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The relief pilot will monitor any change in the Auxiliary Power Unit status message and advise the other pilot if the indication does not stabilize within the sample interval. The Weather Radar indication is expected to read within the sample range of 84 to 88 units during parking. The relief pilot will announce any change in the Nosewheel Steering indication and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Engine Anti-Ice indication	78 units	Refer to related topic
Center Tank Pumps status message	79 units	Monitor
Autopilot Channel A switch position	99 units	Refer to related topic
Flap Position Indication advisory	50 units	Normal
Brake Temperature Monitor selector position	19 units	Advisory only

- If the Thrust Reverser is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- If the Primary Electrical Bus is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The pilot flying will monitor any change in the Probe Heat selector position and advise the other pilot when operating at a sample station without ground power. The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. The Stall Warning quantity display that differs from the expected state requires the First Officer to announce the condition when conditions permit. The pilot monitoring will select any change in the Standby Instruments annunciation and advise the other pilot once the checklist item is complete.

The relief pilot will cross-check any change in the Probe Heat indication and advise the other pilot if a discrepancy is observed. The relief pilot will brief any change in the Transponder status message and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

The Traffic Advisory Display switch position that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval. During parking, the pilot monitoring should announce the Bleed Air Supply status message if the indication does not stabilize within the sample interval. The Autopilot Channel A indication that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. The relief pilot will verify any change in the Cockpit Voice Recorder annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: If the Primary Electrical Bus is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

17.10.3 Stall Warning Test

The pilot monitoring will announce any change in the Brake Temperature Monitor annunciation and advise the other pilot when the associated caution light remains illuminated. During an extended ground delay, the First Officer should confirm the Speedbrake Handle switch position if the indication does not stabilize within the sample interval. The Stall Warning switch position that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The Pack Temperature Control advisory that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval.

During engine start, the pilot flying should select the Pack Temperature Control indication when conditions permit. If the Hydraulic System B is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The pilot flying will announce any change in the Fuel Crossfeed selector position and advise the other pilot if a discrepancy is observed. The pilot monitoring will brief any change in the Speedbrake Handle quantity display and advise the other pilot once the checklist item is complete. The Autopilot Channel A annunciation is expected to read within the sample range of 23 to 33 units during engine start. During a maintenance-requested ground run, the Captain should verify the Landing Gear Indication switch position when conditions permit.

- The Autobrake Selector selector position is expected to read within the sample range of 32 to 40 units during landing.
- Values in this manual are invented and must not be used for any operational purpose.
- The Ground Proximity Monitor selector position is expected to read within the sample range of 97 to 109 units during descent.

NOTE: The pilot monitoring will cross-check any change in the Hydraulic System B switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Cargo Smoke Detection status message	15 units	Monitor
Landing Gear Indication indication	12 units	Refer to related topic
Stall Warning selector position	86 units	Normal
Cockpit Voice Recorder switch position	51 units	Advisory only
Hydraulic System A annunciation	50 units	Normal

17.10.4 Window Heat Interfaces

During approach, the pilot monitoring should confirm the Cargo Smoke Detection advisory if the indication does not stabilize within the sample interval. The Engine Anti-Ice quantity display that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. The Oxygen Distribution status message that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. The captain will select any change in the Autothrottle selector position and advise the other pilot once the checklist item is complete. The Center Tank Pumps advisory is expected to read within the sample range of 6 to 17 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure.

- During preflight, both pilots should announce the Autopilot Channel B annunciation if a discrepancy is observed.
- During preflight, the First Officer should announce the Stall Warning annunciation if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.
- The Flight Management Computer annunciation is expected to read within the sample range of 25 to 35 units during cruise.

- The Oxygen Distribution quantity display is expected to read within the sample range of 70 to 73 units during a diversion.
- Refer to the related topic for additional sample context.

If the Autopilot Channel B is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will verify any change in the Cockpit Voice Recorder annunciation and advise the other pilot if a discrepancy is observed. The Fire Detection Loop switch position is expected to read within the sample range of 31 to 35 units during a turnaround. See 02.30.3 Airspeed Limitation 3.

- If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Fire Detection Loop selector position	93 units	Advisory only
Fire Detection Loop selector position	93 units	Refer to related topic
Fire Detection Loop switch position	52 units	Monitor

- If the Traffic Advisory Display is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.
- The Autopilot Channel A selector position that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight.
- Values in this manual are invented and must not be used for any operational purpose.
- Refer to the related topic for additional sample context.
- During a maintenance-requested ground run, the First Officer should monitor the Probe Heat selector position unless directed otherwise by the Sample Operations Center.
- The Pack Temperature Control advisory is expected to read within the sample range of 83 to 87 units during parking.

NOTE: The Brake Temperature Monitor status message that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed.

17.20 Controls and Indicators

17.20.1 Cabin Pressure Controller Overview

During a maintenance-requested ground run, the pilot flying should brief the Flap Position Indication indication if the indication does not stabilize within the sample interval. The Speedbrake Handle indication is expected to read within the sample range of 68 to 74 units during a maintenance-requested ground run. The Wing Anti-Ice advisory is expected to read within the sample range of 53 to 61 units during approach. The Fuel Crossfeed quantity display is expected to read within the sample range of 81 to 85 units during takeoff. If the Landing Gear Indication is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

If the Cockpit Voice Recorder is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During takeoff, the pilot monitoring should confirm the Standby Instruments switch position when conditions permit. During taxi, the pilot flying should record the Standby Hydraulic indication when operating at a sample station without ground power. During takeoff, both pilots should monitor the Fire Detection Loop switch position before the next phase of flight.

The pilot monitoring will verify any change in the Flight Management Computer quantity display and advise the other pilot once the checklist item is complete. If the Primary Electrical Bus is inoperative, continue takeoff only after both pilots have reviewed the associated sample guidance. The Autothrottle switch position is expected to read within the sample range of 5 to 17 units during approach. During engine start, both pilots should confirm the Oxygen Distribution switch position before the next phase of flight. The Ground Proximity Monitor switch position that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center. Both pilots will select any change in the Ground Proximity Monitor switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The pilot flying will announce any change in the Standby Hydraulic indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Nosewheel Steering quantity display	54 units	Refer to related topic
Engine Anti-Ice switch position	50 units	Advisory only
Autopilot Channel B selector position	51 units	Monitor
Flap Position Indication indication	40 units	Advisory only
Autopilot Channel A advisory	49 units	Refer to related topic
Standby Hydraulic status message	64 units	Refer to related topic
Brake Temperature Monitor quantity display	9 units	Monitor

Condition	Sample value	Remarks
Engine Anti-Ice quantity display	48 units	Advisory only
Auxiliary Power Unit status message	99 units	Advisory only
Traffic Advisory Display indication	79 units	Refer to related topic
Stall Warning status message	57 units	Monitor
Flight Management Computer switch position	81 units	Normal
Autobrake Selector advisory	67 units	Refer to related topic
Ground Proximity Monitor quantity display	4 units	Advisory only

17.20.2 Autobrake Selector Normal Operation

The Window Heat indication that differs from the expected state requires the pilot monitoring to record the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector switch position that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. The Standby Hydraulic indication that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. Both pilots will select any change in the Transponder status message and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

The Standby Hydraulic annunciation is expected to read within the sample range of 63 to 69 units during a maintenance-requested ground run. During preflight, the Captain should announce the Autopilot Channel A advisory before the next phase of flight. The Auxiliary Power Unit selector position that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated. The Probe Heat quantity display that differs from the expected state requires the Captain to cross-check the condition when conditions permit.

Condition	Sample value	Remarks
Brake Temperature Monitor indication	55 units	Monitor
Bleed Air Supply status message	29 units	Monitor

Brake Temperature Monitor quantity display	75 units	Normal
Cockpit Voice Recorder status message	70 units	Refer to related topic
Autothrottle status message	26 units	Monitor
Ground Proximity Monitor indication	16 units	Refer to related topic
Standby Instruments indication	32 units	Refer to related topic

- The pilot flying will select any change in the Cockpit Voice Recorder status message and advise the other pilot when operating at a sample station without ground power.
- Values in this manual are invented and must not be used for any operational purpose.
- The Hydraulic System A indication that differs from the expected state requires the relief pilot to record the condition when conditions permit.
- If the Fire Detection Loop is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Weather Radar is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

If the Transponder is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Autobrake Selector status message is expected to read within the sample range of 30 to 36 units during a maintenance-requested ground run. The Flight Management Computer status message that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power. If the Autopilot Channel B is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

The Autopilot Channel B advisory is expected to read within the sample range of 62 to 65 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure. If the Nosewheel Steering is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The relief pilot will verify any change in the Window Heat quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Nosewheel Steering selector position that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autopilot Channel B annunciation	16 units	Advisory only
Wing Anti-Ice status message	80 units	Monitor
Probe Heat advisory	2 units	Refer to related topic
Bleed Air Supply annunciation	22 units	Advisory only

17.20.3 Probe Heat Limits Display

The Thrust Reverser advisory is expected to read within the sample range of 10 to 21 units during descent. The Nosewheel Steering selector position that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

The Standby Hydraulic indication is expected to read within the sample range of 11 to 22 units during approach. The pilot flying will record any change in the Auxiliary Power Unit selector position and advise the other pilot when conditions permit. Both pilots will brief any change in the Fuel Crossfeed switch position and advise the other pilot

when the associated caution light remains illuminated. The Cargo Smoke Detection switch position is expected to read within the sample range of 13 to 24 units during landing. If the Cargo Smoke Detection is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Brake Temperature Monitor annunciation is expected to read within the sample range of 12 to 24 units during cruise.

Condition	Sample value	Remarks
Autobrake Selector quantity display	41 units	Refer to related topic
Thrust Reverser selector position	36 units	Normal
Oxygen Distribution switch position	4 units	Normal

If the Weather Radar is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During taxi, the pilot monitoring should monitor the Stall Warning annunciation when conditions permit. The Transponder indication that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. The Speedbrake Handle annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Stall Warning indication	70 units	Monitor
Engine Anti-Ice advisory	57 units	Normal
Flight Management Computer status message	68 units	Monitor
Weather Radar annunciation	95 units	Normal
Cargo Smoke Detection quantity display	67 units	Refer to related topic
Transponder indication	41 units	Normal

17.20.4 Speedbrake Handle Power Sources

The Standby Hydraulic annunciation is expected to read within the sample range of 28 to 33 units during takeoff. If the Auxiliary Power Unit is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Flight Management Computer status message that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete.

The pilot flying will confirm any change in the Speedbrake Handle selector position and advise the other pilot if a discrepancy is observed. The pilot monitoring will cross-check any change in the Wing Anti-Ice advisory and advise the other pilot if the indication does not stabilize within the sample interval. During taxi, the pilot flying should select the Traffic Advisory Display selector position unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

The Hydraulic System A annunciation that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight. The captain will cross-check any change in the Stall Warning quantity display and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Ground Proximity Monitor status message	92 units	Monitor
Speedbrake Handle advisory	80 units	Refer to related topic
Cargo Smoke Detection indication	74 units	Monitor
Engine Anti-Ice switch position	86 units	Normal
Pack Temperature Control selector position	54 units	Refer to related topic
Nosewheel Steering quantity display	27 units	Advisory only

Landing Gear Indication status message	39 units	Monitor
--	----------	---------

During a maintenance-requested ground run, the pilot flying should brief the Primary Electrical Bus annunciation once the checklist item is complete. The pilot monitoring will brief any change in the Stall Warning status message and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will monitor any change in the Hydraulic System B selector position and advise the other pilot before the next phase of flight. The pilot flying will brief any change in the Oxygen Distribution quantity display and advise the other pilot if the indication does not stabilize within the sample interval. If the Fire Detection Loop is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

- The Bleed Air Supply selector position that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval.
- The captain will verify any change in the Transponder quantity display and advise the other pilot when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- The Brake Temperature Monitor annunciation that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.
- The relief pilot will select any change in the Hydraulic System B indication and advise the other pilot when conditions permit.

Chapter 18 Systems: Warning Systems

18.10 Description

18.10.1 Thrust Reverser Test

The first officer will cross-check any change in the Standby Instruments advisory and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. The Primary Electrical Bus indication is expected to read within the sample range of 2 to 10 units during engine start. During climb, the pilot monitoring should select the Oxygen Distribution switch position before the next phase of flight.

CAUTION: Both pilots will record any change in the Stall Warning annunciation and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

The relief pilot will record any change in the Wing Anti-Ice switch position and advise the other pilot when the associated caution light remains illuminated. The Ground Proximity Monitor indication is expected to read within the sample range of 93 to 102 units during parking. The Flap Position Indication annunciation that differs from the expected state requires the pilot flying to verify the condition if a discrepancy is observed.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Cargo Smoke Detection annunciation is expected to read within the sample range of 25 to 35 units during landing.
- Refer to the related topic for additional sample context.
- The Pack Temperature Control selector position is expected to read within the sample range of 77 to 80 units during a maintenance-requested ground run.

The Auxiliary Power Unit indication that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. If the Traffic Advisory Display is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. During cruise, the Captain should select the Nosewheel Steering switch position when the associated caution light remains illuminated. See 13.20.1 Standby Hydraulic Reset Guidance.

Condition	Sample value	Remarks
Autothrottle annunciation	28 units	Normal
Bleed Air Supply indication	16 units	Refer to related topic
Bleed Air Supply selector position	82 units	Refer to related topic
Flight Management Computer quantity display	64 units	Advisory only
Cargo Smoke Detection indication	23 units	Normal
Pack Temperature Control quantity display	7 units	Advisory only

18.10.2 Traffic Advisory Display Normal Operation

During taxi, the pilot flying should select the Oxygen Distribution switch position unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus status message is expected to read within the sample range of 78 to 84 units during preflight. The Center Tank Pumps quantity display that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center. If the Center Tank Pumps is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.

The relief pilot will brief any change in the Ground Proximity Monitor selector position and advise the other pilot when operating at a sample station without ground power. The Fuel Crossfeed advisory is expected to read within the sample range of 96 to 105 units during taxi. The Wing Anti-Ice advisory is expected to read within the sample range of 50 to 58 units during a diversion.

Condition	Sample value	Remarks
Nosewheel Steering selector position	21 units	Monitor
Bleed Air Supply advisory	38 units	Refer to related topic
Oxygen Distribution annunciation	7 units	Normal
Fuel Crossfeed selector position	21 units	Normal
Autopilot Channel B indication	15 units	Normal
Weather Radar indication	67 units	Advisory only

CAUTION: If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice advisory is expected to read within the sample range of 16 to 25 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection indication that differs from the expected state requires both pilots to brief the condition when conditions permit. The Weather Radar switch position that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. The Pack Temperature Control quantity display is expected to read within the sample range of 19 to 24 units during an extended ground delay.

Condition	Sample value	Remarks
Stall Warning switch position	37 units	Normal
Ground Proximity Monitor status message	27 units	Advisory only
Hydraulic System B status message	98 units	Advisory only
Stall Warning switch position	57 units	Refer to related topic

If the Bleed Air Supply is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. Both pilots will cross-check any change in the Autopilot Channel A switch position and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will record any change in the Autopilot Channel A indication and advise the other pilot once the checklist item is complete. The Brake Temperature Monitor annunciation that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center. If the Autothrottle is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Oxygen Distribution annunciation	83 units	Advisory only
Oxygen Distribution status message	95 units	Advisory only
Nosewheel Steering status message	11 units	Monitor
Probe Heat indication	81 units	Normal
Bleed Air Supply switch position	84 units	Monitor

Condition	Sample value	Remarks
Weather Radar indication	70 units	Monitor
Autopilot Channel A switch position	36 units	Normal

Oxygen Distribution annunciation	4 units	Normal
Stall Warning annunciation	38 units	Refer to related topic
Autopilot Channel B annunciation	2 units	Advisory only
Autobrake Selector indication	48 units	Advisory only
Thrust Reverser selector position	46 units	Monitor

18.10.3 Cabin Pressure Controller Normal Operation

This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, the First Officer should cross-check the Primary Electrical Bus status message when operating at a sample station without ground power. The Thrust Reverser quantity display that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

During a maintenance-requested ground run, the pilot monitoring should cross-check the Weather Radar switch position unless directed otherwise by the Sample Operations Center. The Nosewheel Steering status message is expected to read within the sample range of 91 to 99 units during descent. During approach, the pilot flying should confirm the Hydraulic System B annunciation unless directed otherwise by the Sample Operations Center. If the Transponder is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

The Flight Management Computer advisory is expected to read within the sample range of 3 to 10 units during an extended ground delay. The Autothrottle advisory is expected to read within the sample range of 3 to 15 units during a maintenance-requested ground run. If the Fire Detection Loop is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

During taxi, the Captain should verify the Transponder advisory if a discrepancy is observed. If the Speedbrake Handle is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Transponder selector position is expected to read within the sample range of 32 to 44 units during engine start. The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. During engine start, the relief pilot should brief the Probe Heat indication when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the pilot flying should monitor the Brake Temperature Monitor annunciation before the next phase of flight. The pilot flying will announce any change in the Standby Hydraulic selector position and advise the other pilot when operating at a sample station without ground power. The Bleed Air Supply quantity display is expected to read within the sample range of 72 to 76 units during parking. The Pack Temperature Control annunciation that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. The Flap Position Indication selector position is expected to read within the sample range of 32 to 43 units during descent.

18.10.4 Traffic Advisory Display Power Sources

The Cabin Pressure Controller quantity display is expected to read within the sample range of 47 to 50 units during climb. During an extended ground delay, the relief pilot should record the Thrust Reverser indication once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Hydraulic System B is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The Auxiliary Power Unit switch position that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. During approach, both pilots should select the Landing Gear Indication indication if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Cockpit Voice Recorder selector position is expected to read within the sample range of 19 to 22 units during cruise.

- If the Cabin Pressure Controller is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.
- The Autothrottle status message is expected to read within the sample range of 54 to 58 units during landing.
- The Cabin Pressure Controller selector position that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.

CAUTION: During preflight, the First Officer should record the Fuel Crossfeed advisory before the next phase of flight.

Refer to the related topic for additional sample context. If the Autopilot Channel B is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Speedbrake Handle annunciation that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. The Ground Proximity Monitor annunciation is expected to read within the sample range of 26 to 31 units during taxi.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. During parking, the Captain should brief the Speedbrake Handle quantity display once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The first officer will brief any change in the Flap Position Indication advisory and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. The relief pilot will monitor any change in the Engine Anti-Ice advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

18.20 Controls and Indicators

18.20.1 Autopilot Channel A Test

This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. The Autothrottle quantity display is expected to read within the sample range of 33 to 40 units during approach. During preflight, both pilots should cross-check the Wing Anti-Ice status message if a discrepancy is observed. The Cabin Pressure Controller advisory is expected to read within the sample range of 90 to 97 units during a maintenance-requested ground run.

If the Auxiliary Power Unit is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. If the Pack Temperature Control is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will brief any change in the Cargo Smoke Detection quantity display and advise the other pilot when operating at a sample station without ground power. The Nosewheel Steering status message is expected to read within the sample range of 75 to 80 units during a turnaround. The Weather Radar switch position that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System B is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Brake Temperature Monitor quantity display that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated.

CAUTION: The Flight Management Computer status message that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. The first officer will brief any change in the Oxygen Distribution indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The Brake Temperature Monitor advisory that differs from the expected state requires the Captain to record the condition before the next phase of flight.

- The Center Tank Pumps annunciation is expected to read within the sample range of 12 to 18 units during engine start.
- The Traffic Advisory Display indication that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated.

If the Thrust Reverser is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Primary Electrical Bus advisory is expected to read within the sample range of 62 to 68 units during taxi. The Speedbrake Handle quantity display is expected to read within the sample range of 12 to 20 units during a turnaround.

The Ground Proximity Monitor quantity display that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval. The relief pilot will brief any change in the Primary Electrical Bus indication and advise the other pilot when operating at a sample station without ground power. The Weather Radar selector position that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. During cruise, the Captain should brief the Probe Heat annunciation if the indication does not stabilize within the sample interval. The relief pilot will monitor any change in the Probe Heat status message and advise the other pilot when the associated caution light remains illuminated. The Cargo Smoke Detection status message is expected to read within the sample range of 83 to 95 units during takeoff. See 06.30.4 Auxiliary Power Unit Indications.

NOTE: If the Nosewheel Steering is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

18.20.2 Transponder Reset Guidance

If the Autothrottle is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. During climb, the Captain should confirm the Speedbrake Handle selector position before the next phase of flight. The Autopilot Channel A quantity display is expected to read within the sample range of 40 to 49 units during an extended ground delay.

CAUTION: The Speedbrake Handle selector position is expected to read within the sample range of 37 to 42 units during cruise.

- If the Speedbrake Handle is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- If the Thrust Reverser is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- During descent, the pilot monitoring should brief the Weather Radar indication unless directed otherwise by the Sample Operations Center.
- The Center Tank Pumps selector position that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power.

The Bleed Air Supply selector position is expected to read within the sample range of 94 to 105 units during descent. The Cabin Pressure Controller switch position that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice quantity display is expected to read within the sample range of 74 to 80 units during a maintenance-requested ground run. The Speedbrake Handle annunciation is expected to read within the sample range of 51 to 62 units during descent.

The Nosewheel Steering annunciation is expected to read within the sample range of 6 to 10 units during parking. The Standby Hydraulic status message is expected to read within the sample range of 71 to 75 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will announce any change in the Fire Detection Loop switch position and advise the other pilot before the next phase of flight. The Cargo Smoke Detection quantity display that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. The pilot flying will record any change in the Engine

Anti-Ice switch position and advise the other pilot if a discrepancy is observed.

NOTE: The Probe Heat selector position is expected to read within the sample range of 40 to 49 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure.

- During parking, both pilots should announce the Autothrottle status message unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Cockpit Voice Recorder annunciation is expected to read within the sample range of 58 to 69 units during descent.
- The captain will announce any change in the Nosewheel Steering annunciation and advise the other pilot when operating at a sample station without ground power.

18.20.3 Hydraulic System B Interfaces

Values in this manual are invented and must not be used for any operational purpose. The Landing Gear Indication switch position is expected to read within the sample range of 81 to 91 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Cockpit Voice Recorder status message	81 units	Advisory only
Window Heat indication	46 units	Monitor
Autopilot Channel B annunciation	95 units	Advisory only
Flap Position Indication indication	85 units	Refer to related topic
Cargo Smoke Detection annunciation	9 units	Refer to related topic
Flap Position Indication selector position	16 units	Monitor
Fire Detection Loop advisory	8 units	Normal

The Stall Warning switch position is expected to read within the sample range of 65 to 71 units during takeoff. During approach, the Captain should cross-check the Standby Instruments switch position when operating at a sample station without ground power. The pilot monitoring will select any change in the Cargo Smoke Detection selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During cruise, both pilots should brief the Speedbrake Handle annunciation when operating at a sample station without ground power.

NOTE: The Autopilot Channel B advisory that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center.

During a maintenance-requested ground run, the pilot flying should verify the Primary Electrical Bus quantity display unless directed otherwise by the Sample Operations Center. The Pack Temperature Control switch position is expected to read within the sample range of 3 to 9 units during taxi. The Thrust Reverser advisory that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. During cruise, the Captain should cross-check the Oxygen Distribution status message when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the pilot monitoring should brief the Hydraulic System A selector position unless directed otherwise by the Sample Operations Center.

The Thrust Reverser indication that differs from the expected state requires both pilots to brief the condition before the next phase of flight. The pilot flying will cross-check any change in the Primary Electrical Bus selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Stall Warning is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Speedbrake Handle status message that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated. The Window Heat status message is expected to read within the sample range of 66 to 77 units during cruise.

The pilot flying will announce any change in the Autobrake Selector indication and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The pilot flying will announce any change in the Standby Instruments quantity display and advise the other pilot if a discrepancy is observed. The pilot flying will verify any change in the Flap Position Indication status message and advise the other pilot before the next phase of flight. The captain will announce any change in the Cargo Smoke Detection advisory and advise the other pilot before the next phase of flight.

- The pilot flying will brief any change in the Oxygen Distribution switch position and advise the other pilot when conditions permit.
- The first officer will confirm any change in the Nosewheel Steering status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The relief pilot will announce any change in the Center Tank Pumps status message and advise the other pilot if the indication does not stabilize within the sample interval.

18.20.4 Standby Hydraulic Test

This text is fictional and exists only to give the prototype realistic volume and structure. If the Flight Management Computer is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. During cruise, the relief pilot should monitor the Speedbrake Handle quantity display once the checklist item is complete. The Engine Anti-Ice indication that differs from the expected state requires the pilot flying to record the condition unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit quantity display is expected to read within the sample range of 88 to 100 units during parking.

Condition	Sample value	Remarks
Standby Instruments annunciation	57 units	Refer to related topic
Window Heat switch position	77 units	Monitor
Flight Management Computer quantity display	54 units	Refer to related topic
Auxiliary Power Unit advisory	10 units	Advisory only
Wing Anti-Ice advisory	50 units	Monitor

The Hydraulic System A advisory is expected to read within the sample range of 62 to 71 units during preflight. If the Ground Proximity Monitor is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

The Nosewheel Steering status message is expected to read within the sample range of 40 to 45 units during an extended ground delay. If the Fuel Crossfeed is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. During taxi, the Captain should verify the Fire Detection Loop status message before the next phase of flight.

If the Oxygen Distribution is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. Both pilots will announce any change in the Hydraulic System B quantity display and advise the other pilot when conditions permit. If the Engine Anti-Ice is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will monitor any change in the Center Tank Pumps quantity display and advise the other pilot when operating at a sample station without ground power. The Landing Gear Indication advisory is expected to read within the sample range of 57 to 61 units during a turnaround. The pilot flying will cross-check any change in the Fuel Crossfeed quantity display and advise the other pilot when the associated caution light remains illuminated.

18.30 Operation

18.30.1 Standby Instruments Power Sources

This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the relief pilot should verify the Traffic Advisory Display quantity display unless directed otherwise by the Sample Operations Center. The Standby Hydraulic indication that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor advisory that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit.

The Probe Heat status message is expected to read within the sample range of 12 to 19 units during parking. If the Engine Anti-Ice is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will announce any change in the Hydraulic System B annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Thrust Reverser is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During descent, the relief pilot should announce the Stall Warning switch position if a discrepancy is observed.

Both pilots will announce any change in the Primary Electrical Bus selector position and advise the other pilot when conditions permit. The relief pilot will verify any change in the Bleed Air Supply annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will select any change in the Bleed Air Supply indication and advise the other pilot if a discrepancy is observed. If the Pack Temperature Control is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. During cruise, the pilot monitoring should monitor the Bleed Air Supply status message when conditions permit. The Cabin Pressure Controller status message is expected to read within the sample range of 33 to 38 units during takeoff.

The Weather Radar switch position is expected to read within the sample range of 39 to 45 units during approach. The Flight Management Computer indication that differs from the expected state requires both pilots to announce the condition when conditions permit. If the Autobrake Selector is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

- Both pilots will verify any change in the Primary Electrical Bus selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- During a diversion, the pilot monitoring should announce the Brake Temperature Monitor selector position before the next phase of flight.
- The Oxygen Distribution advisory is expected to read within the sample range of 54 to 57 units during cruise.
- The Bleed Air Supply switch position is expected to read within the sample range of 43 to 53 units during parking.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Fire Detection Loop annunciation is expected to read within the sample range of 81 to 93 units during takeoff.
- This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The pilot monitoring will select any change in the Autobrake Selector indication and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

The Auxiliary Power Unit quantity display is expected to read within the sample range of 4 to 14 units during engine start. The Wing Anti-Ice annunciation is expected to read within the sample range of 50 to 62 units during an extended ground delay. The pilot flying will cross-check any change in the Wing Anti-Ice quantity display and advise the other pilot if a discrepancy is observed. During taxi, the Captain should confirm the Standby Instruments switch position if the indication does not stabilize within the sample interval. During climb, both pilots should announce the Autobrake Selector switch position when conditions permit. The wording here is placeholder content shaped like a

procedure, not a procedure.

18.30.2 Standby Instruments Test

The Speedbrake Handle annunciation that differs from the expected state requires the Captain to select the condition if a discrepancy is observed. Both pilots will cross-check any change in the Pack Temperature Control status message and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The Center Tank Pumps switch position that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval. The relief pilot will brief any change in the Brake Temperature Monitor indication and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Window Heat advisory	89 units	Normal
Autobrake Selector switch position	6 units	Advisory only
Speedbrake Handle annunciation	43 units	Advisory only
Engine Anti-Ice indication	97 units	Advisory only

During landing, the pilot monitoring should announce the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center. The pilot monitoring will verify any change in the Fire Detection Loop advisory and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will cross-check any change in the Stall Warning advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Primary Electrical Bus quantity display is expected to read within the sample range of 98 to 104 units during parking. During parking, the First Officer should record the Autothrottle switch position if a discrepancy is observed.

Condition	Sample value	Remarks
Fuel Crossfeed status message	5 units	Normal
Flight Management Computer status message	80 units	Refer to related topic
Nosewheel Steering status message	54 units	Advisory only

CAUTION: During preflight, the pilot flying should confirm the Flight Management Computer switch position when the associated caution light remains illuminated. The Traffic Advisory Display quantity display is expected to read within the sample range of 95 to 102 units during climb.

If the Pack Temperature Control is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. During an extended ground delay, the First Officer should announce the Landing Gear Indication switch position when conditions permit.

Condition	Sample value	Remarks
Thrust Reverser indication	9 units	Normal
Cargo Smoke Detection selector position	63 units	Advisory only
Traffic Advisory Display selector position	54 units	Refer to related topic
Speedbrake Handle switch position	99 units	Advisory only
Window Heat quantity display	91 units	Normal
Stall Warning switch position	12 units	Refer to related topic

18.30.3 Brake Temperature Monitor Power Sources

The pilot flying will cross-check any change in the Transponder switch position and advise the other pilot when the associated caution light remains illuminated. The Fire Detection Loop indication that differs from the expected state requires the First Officer to announce the condition before the next phase of flight. The Center Tank Pumps switch position that differs from the expected state requires the pilot monitoring to monitor the condition when conditions permit. The Stall Warning quantity display is expected to read within the sample range of 29 to 32 units during parking. Both pilots will select any change in the Fuel Crossfeed indication and advise the other pilot once the checklist item is complete. The Brake Temperature Monitor selector position is expected to read within the sample range of 55 to 63 units during a turnaround.

- During climb, the First Officer should announce the Wing Anti-Ice selector position if the indication does not stabilize within the sample interval.
- Both pilots will monitor any change in the Stall Warning quantity display and advise the other pilot when operating at a sample station without ground power.
- Both pilots will announce any change in the Cargo Smoke Detection annunciation and advise the other pilot when conditions permit.
- If the Window Heat is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- If the Autobrake Selector is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

During engine start, both pilots should confirm the Ground Proximity Monitor status message when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the First Officer should record the Standby Instruments annunciation when the associated caution light remains illuminated.

CAUTION: The Auxiliary Power Unit annunciation that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power.

The Pack Temperature Control quantity display is expected to read within the sample range of 98 to 108 units during approach. The first officer will monitor any change in the Engine Anti-Ice indication and advise the other pilot when conditions permit. The Center Tank Pumps annunciation is expected to read within the sample range of 32 to 38 units during an extended ground delay.

The Autobrake Selector status message is expected to read within the sample range of 22 to 34 units during a turnaround. If the Cabin Pressure Controller is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. During a turnaround, the pilot monitoring should confirm the Cockpit Voice Recorder status message unless directed otherwise by the Sample Operations Center. The captain will cross-check any change in the Fire Detection Loop quantity display and advise the other pilot before the next phase of flight.

- The Cockpit Voice Recorder annunciation that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During an extended ground delay, the pilot monitoring should cross-check the Autopilot Channel B quantity display when the associated caution light remains illuminated.
- If the Fire Detection Loop is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Probe Heat switch position	42 units	Advisory only
Cabin Pressure Controller advisory	31 units	Advisory only
Pack Temperature Control quantity display	28 units	Monitor

Cockpit Voice Recorder status message	25 units	Advisory only
Autopilot Channel B indication	60 units	Refer to related topic
Nosewheel Steering quantity display	81 units	Normal
Flap Position Indication advisory	21 units	Advisory only

18.30.4 Cabin Pressure Controller Power Sources

The Nosewheel Steering switch position is expected to read within the sample range of 16 to 25 units during landing. The Weather Radar switch position is expected to read within the sample range of 3 to 9 units during preflight. Both pilots will cross-check any change in the Probe Heat switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. During descent, the pilot flying should confirm the Weather Radar status message when conditions permit.

The Hydraulic System A switch position is expected to read within the sample range of 64 to 71 units during taxi. Values in this manual are invented and must not be used for any operational purpose. During taxi, the pilot flying should confirm the Stall Warning status message unless directed otherwise by the Sample Operations Center. The relief pilot will select any change in the Autopilot Channel B indication and advise the other pilot when conditions permit. During engine start, the pilot flying should record the Standby Instruments advisory unless directed otherwise by the Sample Operations Center. The Pack Temperature Control selector position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power.

NOTE: The Fuel Crossfeed indication is expected to read within the sample range of 55 to 65 units during descent. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: During preflight, both pilots should select the Window Heat indication when operating at a sample station without ground power.

CAUTION: The captain will announce any change in the Hydraulic System A indication and advise the other pilot if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the relief pilot should brief the Hydraulic System B advisory when conditions permit. The relief pilot will select any change in the Thrust Reverser status message and advise the other pilot when conditions permit. The Center Tank Pumps status message is expected to read within the sample range of 79 to 85 units during a maintenance-requested ground run.

NOTE: If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Window Heat status message is expected to read within the sample range of 28 to 32 units during engine start.

Condition	Sample value	Remarks
Autopilot Channel B selector position	86 units	Advisory only
Auxiliary Power Unit switch position	29 units	Advisory only
Traffic Advisory Display annunciation	39 units	Refer to related topic
Traffic Advisory Display status message	15 units	Refer to related topic
Flap Position Indication status message	39 units	Advisory only
Autothrottle status message	1 units	Advisory only

Chapter 19 Performance

19.10 Takeoff Performance

19.10.1 Takeoff Performance Table 1

Both pilots will cross-check any change in the Autopilot Channel A quantity display and advise the other pilot when conditions permit. During takeoff, the Captain should monitor the Autopilot Channel A indication if a discrepancy is observed. During taxi, the Captain should monitor the Landing Gear Indication quantity display unless directed otherwise by the Sample Operations Center. The Transponder quantity display is expected to read within the sample range of 15 to 18 units during parking. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The relief pilot will cross-check any change in the Cabin Pressure Controller selector position and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Pack Temperature Control annunciation	47 units	Monitor
Autothrottle advisory	52 units	Refer to related topic
Window Heat selector position	91 units	Refer to related topic
Primary Electrical Bus advisory	47 units	Refer to related topic
Oxygen Distribution status message	64 units	Monitor
Auxiliary Power Unit status message	22 units	Normal

CAUTION: The Fire Detection Loop indication that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval. The Cabin Pressure Controller switch position is expected to read within the sample range of 4 to 14 units during preflight.

The pilot flying will select any change in the Fuel Crossfeed status message and advise the other pilot when operating at a sample station without ground power. During cruise, both pilots should verify the Cargo Smoke Detection indication once the checklist item is complete. During approach, both pilots should brief the Autobrake Selector quantity display when conditions permit. The Hydraulic System B advisory is expected to read within the sample range of 50 to 54 units during engine start. The relief pilot will verify any change in the Brake Temperature Monitor selector position and advise the other pilot before the next phase of flight.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Instruments status message that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will select any change in the Autobrake Selector quantity display and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the relief pilot should brief the Autothrottle indication before the next phase of flight.

The Ground Proximity Monitor annunciation that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. The Autopilot Channel A status message is expected to read within the sample range of 12 to 20 units during approach. The Autopilot Channel B status message that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. See 11.30.1 Stall Warning Power Sources.

19.10.2 Takeoff Performance Table 2

During approach, the pilot flying should record the Auxiliary Power Unit status message when operating at a sample station without ground power. The Auxiliary Power Unit indication is expected to read within the sample range of 48 to 53 units during a turnaround. During landing, the Captain should confirm the Autothrottle quantity display unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Pack Temperature Control quantity display is expected to read within the sample range of 80 to 89 units during an extended ground delay.

- The first officer will announce any change in the Hydraulic System A indication and advise the other pilot when operating at a sample station without ground power.
- If the Cargo Smoke Detection is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.
- The relief pilot will confirm any change in the Auxiliary Power Unit indication and advise the other pilot before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Standby Instruments indication is expected to read within the sample range of 60 to 67 units during an extended ground delay.
- The pilot flying will announce any change in the Hydraulic System A switch position and advise the other pilot when conditions permit.
- If the Probe Heat is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- The Pack Temperature Control switch position is expected to read within the sample range of 75 to 79 units during takeoff.
- During a diversion, both pilots should cross-check the Center Tank Pumps advisory if a discrepancy is observed.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Traffic Advisory Display status message that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval.
- The Pack Temperature Control quantity display that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated.
- During cruise, the Captain should brief the Traffic Advisory Display annunciation unless directed otherwise by the Sample Operations Center.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a maintenance-requested ground run, the pilot monitoring should verify the Fire Detection Loop switch position when operating at a sample station without ground power.

19.10.3 Takeoff Performance Table 3

Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection annunciation that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated. The pilot flying will announce any change in the Standby Hydraulic indication and advise the other pilot unless directed otherwise by the Sample Operations Center. During a diversion, the pilot monitoring should select the Autopilot Channel B annunciation when operating at a sample station without ground power. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The pilot flying will announce any change in the Standby Instruments indication and advise the other pilot before the next phase of flight.

- The Transponder annunciation that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval.
- Both pilots will record any change in the Autopilot Channel B advisory and advise the other pilot when operating at a sample station without ground power.
- The Thrust Reverser annunciation is expected to read within the sample range of 39 to 51 units during taxi.
- The Autobrake Selector quantity display that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete.
- If the Wing Anti-Ice is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.
- If the Hydraulic System B is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- Both pilots will brief any change in the Auxiliary Power Unit advisory and advise the other pilot when operating at a sample station without ground power.
- The Probe Heat status message is expected to read within the sample range of 84 to 92 units during climb.
- Refer to the related topic for additional sample context.
- If the Weather Radar is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.
- The Standby Instruments status message that differs from the expected state requires the relief pilot to select the condition once the checklist item is complete.
- The Cargo Smoke Detection quantity display that differs from the expected state requires both pilots to verify the condition before the next phase of flight.

The Weather Radar indication is expected to read within the sample range of 40 to 43 units during a diversion. The Cargo Smoke Detection switch position is expected to read within the sample range of 7 to 18 units during taxi. The relief pilot will verify any change in the Wing Anti-Ice selector position and advise the other pilot once the checklist item is complete. If the Cabin Pressure Controller is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Flap Position Indication status message is expected to read within the sample range of 30 to 36 units during landing. The Weather Radar advisory is expected to read within the sample range of 95 to 102 units during preflight.

The Standby Hydraulic selector position that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. During a turnaround, both pilots should brief the Nosewheel Steering selector position when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat status message that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated.

19.20 Enroute Performance

19.20.1 Enroute Performance Table 1

If the Fire Detection Loop is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The pilot flying will select any change in the Cargo Smoke Detection indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Hydraulic System A switch position that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within

the sample interval. If the Flap Position Indication is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During engine start, the pilot flying should announce the Engine Anti-Ice indication once the checklist item is complete.

- If the Autopilot Channel B is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- The Wing Anti-Ice quantity display that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated.
- The relief pilot will record any change in the Pack Temperature Control selector position and advise the other pilot once the checklist item is complete.
- If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

The pilot monitoring will monitor any change in the Flap Position Indication status message and advise the other pilot before the next phase of flight. The pilot flying will record any change in the Standby Hydraulic annunciation and advise the other pilot if a discrepancy is observed. During climb, both pilots should cross-check the Engine Anti-Ice advisory when operating at a sample station without ground power.

During engine start, both pilots should select the Autothrottle status message when the associated caution light remains illuminated. During a turnaround, the relief pilot should verify the Weather Radar selector position when the associated caution light remains illuminated. The captain will select any change in the Flight Management Computer quantity display and advise the other pilot once the checklist item is complete.

The Hydraulic System A indication that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval. The Traffic Advisory Display status message that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power. The Fuel Crossfeed indication is expected to read within the sample range of 5 to 14 units during approach. See 02.40.7 Cockpit Voice Recorder Status Messages.

Condition	Sample value	Remarks
Ground Proximity Monitor quantity display	25 units	Advisory only
Probe Heat status message	68 units	Monitor
Traffic Advisory Display indication	41 units	Normal
Hydraulic System A annunciation	90 units	Advisory only
Thrust Reverser selector position	13 units	Advisory only
Landing Gear Indication quantity display	70 units	Monitor

- The pilot flying will brief any change in the Fuel Crossfeed quantity display and advise the other pilot when conditions permit.
- During parking, the First Officer should confirm the Stall Warning status message unless directed otherwise by the Sample Operations Center.
- If the Cargo Smoke Detection is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.
- The Fire Detection Loop switch position is expected to read within the sample range of 12 to 15 units during descent.
- The Window Heat status message is expected to read within the sample range of 26 to 38 units during engine start.

19.20.2 Enroute Performance Table 2

During climb, the pilot flying should record the Pack Temperature Control selector position when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. If the Fire Detection Loop is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Flap Position Indication selector position is expected to read within the sample range of 76 to 84 units during cruise. The Center Tank Pumps quantity display is expected to read within the sample range of 2 to 9 units during takeoff. During landing, the pilot monitoring should cross-check the Auxiliary Power Unit quantity display when operating at a sample station without ground power.

- If the Standby Hydraulic is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.
- If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.
- The Autothrottle switch position is expected to read within the sample range of 59 to 66 units during cruise.
- The captain will brief any change in the Ground Proximity Monitor quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- During approach, the pilot flying should record the Standby Hydraulic annunciation once the checklist item is complete.

The relief pilot will monitor any change in the Standby Instruments quantity display and advise the other pilot when operating at a sample station without ground power. During descent, the First Officer should cross-check the Primary Electrical Bus annunciation if the indication does not stabilize within the sample interval. During descent, both pilots should select the Landing Gear Indication selector position when the associated caution light remains illuminated. If the Flight Management Computer is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Fire Detection Loop selector position that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. The Hydraulic System A advisory is expected to read within the sample range of 2 to 8 units during an extended ground delay. See 13.10.1 Ground Proximity Monitor Test.

- The first officer will announce any change in the Autopilot Channel A annunciation and advise the other pilot if a discrepancy is observed.
- The Cockpit Voice Recorder advisory is expected to read within the sample range of 76 to 84 units during a diversion.
- Refer to the related topic for additional sample context.
- If the Autobrake Selector is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

CAUTION: During an extended ground delay, the relief pilot should verify the Transponder selector position when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Stall Warning quantity display	72 units	Advisory only
Pack Temperature Control status message	70 units	Monitor
Standby Hydraulic annunciation	16 units	Monitor

- The relief pilot will verify any change in the Fire Detection Loop annunciation and advise the other pilot when the associated caution light remains illuminated.
- The Cabin Pressure Controller annunciation is expected to read within the sample range of 66 to 72 units during cruise.

- During taxi, the pilot flying should announce the Engine Anti-Ice indication if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.
- Both pilots will verify any change in the Stall Warning annunciation and advise the other pilot when the associated caution light remains illuminated.
- The Autobrake Selector annunciation that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power.
- During climb, the relief pilot should verify the Autopilot Channel B switch position if the indication does not stabilize within the sample interval.
- The Fire Detection Loop selector position that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.
- If the Hydraulic System B is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- The Weather Radar status message that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed.

19.20.3 Enroute Performance Table 3

The Thrust Reverser advisory that differs from the expected state requires the Captain to record the condition once the checklist item is complete. During a turnaround, the pilot monitoring should announce the Oxygen Distribution indication when operating at a sample station without ground power. During a diversion, the pilot monitoring should select the Nosewheel Steering switch position if a discrepancy is observed. The first officer will announce any change in the Ground Proximity Monitor switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will brief any change in the Flight Management Computer quantity display and advise the other pilot when conditions permit.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Fuel Crossfeed switch position is expected to read within the sample range of 14 to 23 units during approach. During descent, the Captain should cross-check the Traffic Advisory Display status message once the checklist item is complete.

If the Hydraulic System A is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Speedbrake Handle annunciation is expected to read within the sample range of 49 to 61 units during parking. The Ground Proximity Monitor quantity display that differs from the expected state requires the First Officer to brief the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B switch position is expected to read within the sample range of 23 to 29 units during a diversion. The Autobrake Selector advisory that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power.

CAUTION: The Weather Radar advisory that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight. The Primary Electrical Bus quantity display that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval.

CAUTION: The Wing Anti-Ice status message is expected to read within the sample range of 53 to 61 units during a turnaround.

- The first officer will monitor any change in the Auxiliary Power Unit annunciation and advise the other pilot when conditions permit.
- If the Brake Temperature Monitor is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

- The Primary Electrical Bus selector position is expected to read within the sample range of 13 to 18 units during takeoff.
- The Wing Anti-Ice advisory that differs from the expected state requires the pilot flying to monitor the condition if a discrepancy is observed.
- The first officer will confirm any change in the Window Heat quantity display and advise the other pilot once the checklist item is complete.
- If the Probe Heat is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. If the Pack Temperature Control is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Stall Warning quantity display that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat status message is expected to read within the sample range of 58 to 66 units during parking.

19.30 Landing Performance

19.30.1 Landing Performance Table 1

The first officer will confirm any change in the Stall Warning indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Speedbrake Handle is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Oxygen Distribution annunciation is expected to read within the sample range of 15 to 22 units during a diversion. The Wing Anti-Ice status message is expected to read within the sample range of 5 to 8 units during parking.

CAUTION: During cruise, the pilot flying should monitor the Brake Temperature Monitor quantity display if a discrepancy is observed.

- The Engine Anti-Ice quantity display is expected to read within the sample range of 67 to 78 units during climb.
- Both pilots will confirm any change in the Cabin Pressure Controller advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- The pilot flying will verify any change in the Auxiliary Power Unit indication and advise the other pilot when the associated caution light remains illuminated.
- If the Thrust Reverser is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Cabin Pressure Controller is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

NOTE: During a maintenance-requested ground run, both pilots should confirm the Window Heat status message when the associated caution light remains illuminated. The Brake Temperature Monitor selector position is expected to read within the sample range of 40 to 47 units during landing.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

19.30.2 Landing Performance Table 2

During parking, the First Officer should record the Stall Warning indication when conditions permit. The Cockpit Voice Recorder advisory that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. The pilot monitoring will monitor any change in the Cargo Smoke

Detection advisory and advise the other pilot once the checklist item is complete. The Flap Position Indication switch position is expected to read within the sample range of 87 to 90 units during an extended ground delay.

The Cargo Smoke Detection annunciation that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The first officer will monitor any change in the Traffic Advisory Display annunciation and advise the other pilot when the associated caution light remains illuminated.

- The captain will brief any change in the Cargo Smoke Detection switch position and advise the other pilot when operating at a sample station without ground power.
- During landing, both pilots should select the Hydraulic System A status message before the next phase of flight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Values in this manual are invented and must not be used for any operational purpose.
- The Cockpit Voice Recorder indication is expected to read within the sample range of 4 to 9 units during approach.
- Refer to the related topic for additional sample context.

CAUTION: If the Flap Position Indication is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

The Standby Hydraulic switch position that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. The captain will confirm any change in the Thrust Reverser selector position and advise the other pilot before the next phase of flight. During descent, the First Officer should monitor the Speedbrake Handle quantity display before the next phase of flight. The Fuel Crossfeed status message is expected to read within the sample range of 11 to 14 units during landing. The Nosewheel Steering annunciation that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.

The pilot monitoring will verify any change in the Probe Heat annunciation and advise the other pilot when the associated caution light remains illuminated. If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The relief pilot will announce any change in the Fuel Crossfeed advisory and advise the other pilot once the checklist item is complete. The Standby Hydraulic annunciation that differs from the expected state requires both pilots to announce the condition before the next phase of flight. During engine start, the Captain should record the Brake Temperature Monitor selector position when operating at a sample station without ground power.

Condition	Sample value	Remarks
Wing Anti-Ice selector position	6 units	Refer to related topic
Flight Management Computer quantity display	59 units	Monitor
Cargo Smoke Detection switch position	9 units	Refer to related topic

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will monitor any change in the Flap Position Indication indication and advise the other pilot once the checklist item is complete. The Hydraulic System A annunciation is expected to read within the sample range of 19 to 23 units during landing. The Brake Temperature Monitor switch position is expected to read within the sample range of 5 to 17 units during a turnaround. During takeoff, the relief pilot should confirm the Weather Radar switch position when operating at a sample station without ground power.

NOTE: The Weather Radar quantity display is expected to read within the sample range of 76 to 85 units during cruise.

19.30.3 Landing Performance Table 3

The Stall Warning selector position is expected to read within the sample range of 37 to 46 units during takeoff. The first officer will record any change in the Standby Instruments indication and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the First Officer should select the Wing Anti-Ice indication if the indication does not stabilize within the sample interval. The Ground Proximity Monitor status message is expected to read within the sample range of 96 to 99 units during takeoff. The relief pilot will confirm any change in the Weather Radar selector position and advise the other pilot when conditions permit.

CAUTION: The Flap Position Indication selector position is expected to read within the sample range of 56 to 60 units during cruise.

The Window Heat selector position is expected to read within the sample range of 54 to 60 units during descent. If the Autothrottle is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. During engine start, the pilot monitoring should record the Bleed Air Supply switch position when conditions permit.

Values in this manual are invented and must not be used for any operational purpose. During a maintenance-requested ground run, the Captain should confirm the Probe Heat status message unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The Standby Instruments quantity display is expected to read within the sample range of 97 to 107 units during a turnaround.

Condition	Sample value	Remarks
Autothrottle selector position	24 units	Advisory only
Wing Anti-Ice quantity display	67 units	Monitor
Landing Gear Indication quantity display	87 units	Monitor
Probe Heat selector position	50 units	Refer to related topic
Engine Anti-Ice selector position	51 units	Refer to related topic
Cabin Pressure Controller indication	11 units	Advisory only
Thrust Reverser selector position	50 units	Monitor

19.40 Fuel Planning Data

19.40.1 Fuel Planning Data Table 1

During an extended ground delay, the relief pilot should brief the Autothrottle selector position when the associated caution light remains illuminated. The Primary Electrical Bus switch position is expected to read within the sample range of 84 to 94 units during climb. During takeoff, both pilots should announce the Engine Anti-Ice quantity display before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic quantity display is expected to read within the sample range of 26 to 34 units during a diversion.

During preflight, the pilot monitoring should verify the Cockpit Voice Recorder advisory if a discrepancy is observed. The Center Tank Pumps indication that differs from the expected state requires the pilot monitoring to record the condition if the indication does not stabilize within the sample interval. If the Flight Management Computer is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Oxygen Distribution quantity display that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight.

- The Pack Temperature Control selector position is expected to read within the sample range of 97 to 106 units during climb.

- The Stall Warning status message that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete.
- Refer to the related topic for additional sample context.
- The Center Tank Pumps switch position is expected to read within the sample range of 56 to 60 units during taxi.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The wording here is placeholder content shaped like a procedure, not a procedure.

During descent, the pilot monitoring should monitor the Autopilot Channel B annunciation if the indication does not stabilize within the sample interval. The Window Heat status message that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

If the Brake Temperature Monitor is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Cabin Pressure Controller status message is expected to read within the sample range of 41 to 46 units during engine start. Refer to the related topic for additional sample context. The Auxiliary Power Unit quantity display is expected to read within the sample range of 89 to 96 units during a maintenance-requested ground run.

19.40.2 Fuel Planning Data Table 2

This text is fictional and exists only to give the prototype realistic volume and structure. The Stall Warning switch position is expected to read within the sample range of 77 to 89 units during a turnaround. The first officer will select any change in the Speedbrake Handle annunciation and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autopilot Channel A is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Flight Management Computer selector position	14 units	Normal
Probe Heat annunciation	38 units	Monitor
Nosewheel Steering indication	47 units	Monitor
Pack Temperature Control quantity display	63 units	Normal

The Wing Anti-Ice selector position is expected to read within the sample range of 9 to 12 units during an extended ground delay. The Autopilot Channel A advisory that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. If the Pack Temperature Control is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The relief pilot will brief any change in the Fuel Crossfeed indication and advise the other pilot when operating at a sample station without ground power. The Hydraulic System B advisory is expected to read within the sample range of 86 to 89 units during engine start.

The wording here is placeholder content shaped like a procedure, not a procedure. The Cabin Pressure Controller status message that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

During an extended ground delay, the Captain should select the Wing Anti-Ice selector position once the checklist item is complete. The Stall Warning status message that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. The first officer will confirm any change in the Autobrake Selector advisory and advise the other pilot before the next phase of flight. The Standby Instruments selector position is expected to read within the sample range of 66 to 75 units during takeoff. The Fire Detection Loop indication that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated.

19.40.3 Fuel Planning Data Table 3

If the Traffic Advisory Display is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. Both pilots will confirm any change in the Stall Warning advisory and advise the other pilot before the next phase of flight. The pilot monitoring will verify any change in the Flap Position Indication advisory and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. The captain will confirm any change in the Cargo Smoke Detection annunciation and advise the other pilot when operating at a sample station without ground power.

NOTE: If the Probe Heat is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

During climb, the Captain should select the Wing Anti-Ice advisory if the indication does not stabilize within the sample interval. The Weather Radar advisory that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed. If the Autobrake Selector is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. See 13.30.2 Oxygen Distribution Power Sources.

CAUTION: During approach, the pilot flying should record the Flight Management Computer selector position unless directed otherwise by the Sample Operations Center.

19.50 Engine-Out Data

19.50.1 Engine-Out Data Table 1

During an extended ground delay, the relief pilot should monitor the Fuel Crossfeed advisory when operating at a sample station without ground power. The Autobrake Selector switch position that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center. The relief pilot will verify any change in the Hydraulic System B indication and advise the other pilot once the checklist item is complete.

During landing, the pilot flying should record the Transponder advisory when operating at a sample station without ground power. During climb, the Captain should verify the Window Heat annunciation when operating at a sample station without ground power. During landing, the pilot monitoring should cross-check the Thrust Reverser annunciation if the indication does not stabilize within the sample interval. During a diversion, the pilot flying should announce the Cargo Smoke Detection switch position before the next phase of flight. If the Autopilot Channel A is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

The pilot monitoring will select any change in the Pack Temperature Control status message and advise the other pilot before the next phase of flight. During descent, both pilots should select the Weather Radar selector position unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice switch position is expected to read within the sample range of 43 to 55 units during descent.

Condition	Sample value	Remarks
Cockpit Voice Recorder advisory	61 units	Advisory only
Ground Proximity Monitor indication	75 units	Monitor
Cockpit Voice Recorder status message	43 units	Advisory only
Window Heat quantity display	25 units	Monitor
Hydraulic System A advisory	16 units	Normal
Autobrake Selector quantity display	34 units	Normal

Speedbrake Handle status message	29 units	Advisory only
----------------------------------	----------	---------------

This text is fictional and exists only to give the prototype realistic volume and structure. If the Autobrake Selector is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Center Tank Pumps quantity display is expected to read within the sample range of 7 to 14 units during a maintenance-requested ground run. The Weather Radar status message that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete.

CAUTION: The Wing Anti-Ice switch position is expected to read within the sample range of 96 to 101 units during landing. The captain will record any change in the Pack Temperature Control advisory and advise the other pilot when operating at a sample station without ground power.

- The Cockpit Voice Recorder indication is expected to read within the sample range of 50 to 59 units during an extended ground delay.
- If the Weather Radar is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

19.50.2 Engine-Out Data Table 2

The Standby Instruments switch position that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector annunciation is expected to read within the sample range of 15 to 20 units during a diversion. The Standby Instruments status message is expected to read within the sample range of 16 to 28 units during a turnaround.

Condition	Sample value	Remarks
Cabin Pressure Controller status message	87 units	Advisory only
Primary Electrical Bus switch position	11 units	Normal
Weather Radar switch position	59 units	Refer to related topic
Cabin Pressure Controller switch position	74 units	Normal

- The Auxiliary Power Unit quantity display is expected to read within the sample range of 60 to 68 units during an extended ground delay.
- If the Wing Anti-Ice is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.
- The Fire Detection Loop status message that differs from the expected state requires the Captain to record the condition before the next phase of flight.
- If the Oxygen Distribution is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

If the Autobrake Selector is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Cabin Pressure Controller indication that differs from the expected state requires both pilots to record the condition before the next phase of flight. Refer to the related topic for additional sample context. The pilot flying will announce any change in the Stall Warning annunciation and advise the other pilot if the indication does not stabilize within the sample interval. During taxi, the pilot flying should record the Hydraulic System B indication when operating at a sample station without ground power.

If the Autothrottle is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The captain will cross-check any change in the Cabin Pressure Controller annunciation and advise

the other pilot when operating at a sample station without ground power. The captain will select any change in the Weather Radar quantity display and advise the other pilot when conditions permit. The Transponder quantity display is expected to read within the sample range of 45 to 50 units during a maintenance-requested ground run. During a turnaround, the relief pilot should verify the Bleed Air Supply annunciation when operating at a sample station without ground power.

- The Speedbrake Handle selector position is expected to read within the sample range of 91 to 98 units during descent.
- During landing, both pilots should cross-check the Transponder status message when operating at a sample station without ground power.
- If the Ground Proximity Monitor is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.
- The captain will brief any change in the Cockpit Voice Recorder status message and advise the other pilot when conditions permit.
- If the Flight Management Computer is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.
- The relief pilot will select any change in the Cargo Smoke Detection advisory and advise the other pilot when conditions permit.
- The Ground Proximity Monitor annunciation that differs from the expected state requires the pilot flying to brief the condition when conditions permit.
- During landing, the First Officer should monitor the Autopilot Channel B advisory before the next phase of flight.
- If the Oxygen Distribution is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- During a maintenance-requested ground run, the First Officer should monitor the Auxiliary Power Unit advisory when operating at a sample station without ground power.
- If the Flight Management Computer is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance.
- The Standby Hydraulic status message is expected to read within the sample range of 79 to 84 units during preflight.

During taxi, the relief pilot should select the Flap Position Indication status message if the indication does not stabilize within the sample interval. The pilot monitoring will record any change in the Engine Anti-Ice switch position and advise the other pilot before the next phase of flight. If the Auxiliary Power Unit is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

- The Pack Temperature Control status message that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval.
- The Standby Instruments quantity display is expected to read within the sample range of 97 to 108 units during cruise.
- The Landing Gear Indication indication is expected to read within the sample range of 22 to 32 units during descent.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Values in this manual are invented and must not be used for any operational purpose.

19.50.3 Engine-Out Data Table 3

The Oxygen Distribution quantity display is expected to read within the sample range of 9 to 12 units during taxi. The Hydraulic System A selector position is expected to read within the sample range of 91 to 103 units during landing. The pilot monitoring will record any change in the Thrust Reverser annunciation and advise the other pilot when operating at a sample station without ground power. The Cabin Pressure Controller indication that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated.

If the Center Tank Pumps is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Pack Temperature Control switch position that differs from the expected state requires the pilot flying to record the condition when operating at a sample station without ground power. The Autopilot Channel A indication that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. The relief pilot will brief any change in the Landing Gear Indication annunciation and advise the other pilot once the checklist item is complete. The pilot flying will brief any change in the Flight Management Computer indication and advise the other pilot when the associated caution light remains illuminated.

During a maintenance-requested ground run, both pilots should confirm the Autothrottle switch position when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will brief any change in the Center Tank Pumps indication and advise the other pilot if the indication does not stabilize within the sample interval.

If the Traffic Advisory Display is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Thrust Reverser indication that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The Flap Position Indication advisory is expected to read within the sample range of 69 to 77 units during engine start. Refer to the related topic for additional sample context.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.