

Sample Flight Operations Manual

Revision 12 Revision date 2026-05-01 Effective 2026-05-15

Applicability: ALL Owner: Sample Flight Standards

Routine revision.

This document is entirely fictional. It was written to give a prototype realistic structure and volume. It is not derived from any operator manual and must not be used for any operational purpose.

Chapter 01 General

01.10 General: Part A

01.10.1 General Policy 1

The Thrust Reverser advisory that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed. The Autopilot Channel A status message is expected to read within the sample range of 21 to 25 units during an extended ground delay. If the Autothrottle is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. Both pilots will record any change in the Hydraulic System A annunciation and advise the other pilot when the associated caution light remains illuminated.

The Center Tank Pumps selector position is expected to read within the sample range of 51 to 61 units during cruise. During approach, both pilots should monitor the Auxiliary Power Unit indication if the indication does not stabilize within the sample interval. During landing, the Captain should verify the Wing Anti-Ice indication if the indication does not stabilize within the sample interval. During landing, the pilot monitoring should verify the Engine Anti-Ice indication if a discrepancy is observed. If the Cabin Pressure Controller is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel A indication that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center.

During a turnaround, both pilots should confirm the Oxygen Distribution quantity display once the checklist item is complete. The Wing Anti-Ice selector position that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. If the Speedbrake Handle is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Speedbrake Handle is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The captain will cross-check any change in the Oxygen Distribution annunciation and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Autopilot Channel B advisory	73 units	Advisory only
Autopilot Channel A switch position	8 units	Advisory only
Thrust Reverser quantity display	51 units	Normal

The relief pilot will record any change in the Bleed Air Supply annunciation and advise the other pilot when conditions permit. If the Flap Position Indication is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Standby Instruments switch position is expected to read within the sample range of 19 to 29 units during an extended ground delay. If the Bleed Air Supply is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Traffic Advisory Display advisory is expected to read within the sample range of 82 to 90 units during engine start. The Autopilot Channel A switch position that differs from the expected state requires the First Officer to select the condition once the checklist item is complete.

Condition	Sample value	Remarks
Ground Proximity Monitor switch position	7 units	Monitor
Center Tank Pumps switch position	65 units	Advisory only
Standby Instruments indication	6 units	Monitor
Cargo Smoke Detection quantity display	72 units	Refer to related topic
Transponder selector position	17 units	Refer to related topic
Window Heat advisory	90 units	Monitor

The Wing Anti-Ice annunciation is expected to read within the sample range of 54 to 60 units during cruise. The pilot monitoring will brief any change in the Fire Detection Loop status message and advise the other pilot unless directed otherwise by the Sample Operations Center. During parking, the pilot monitoring should cross-check the Pack Temperature Control status message when conditions permit. The first officer will record any change in the Autopilot Channel A indication and advise the other pilot if a discrepancy is observed.

During cruise, the relief pilot should announce the Pack Temperature Control quantity display when conditions permit. During taxi, the pilot monitoring should verify the Wing Anti-Ice switch position when conditions permit. Refer to the related topic for additional sample context. If the Autobrake Selector is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

01.10.2 General Policy 2

The pilot monitoring will record any change in the Hydraulic System B advisory and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will select any change in the Fuel Crossfeed annunciation and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will announce any change in the Autopilot Channel A indication and advise the other pilot once the checklist item is complete.

- The Window Heat annunciation that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed.
- Both pilots will monitor any change in the Standby Hydraulic status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The relief pilot will record any change in the Oxygen Distribution advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The first officer will select any change in the Flight Management Computer annunciation and advise the other pilot before the next phase of flight.
- Refer to the related topic for additional sample context.
- During a diversion, the First Officer should confirm the Autobrake Selector switch position if a discrepancy is observed.
- During cruise, the First Officer should confirm the Standby Instruments status message before the next phase of flight.
- Values in this manual are invented and must not be used for any operational purpose.

If the Nosewheel Steering is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The pilot flying will record any change in the Cargo Smoke Detection advisory and advise the other pilot if a discrepancy is observed.

Refer to the related topic for additional sample context. The Probe Heat selector position is expected to read within the sample range of 37 to 42 units during a maintenance-requested ground run. The Autopilot Channel A status message is expected to read within the sample range of 80 to 89 units during an extended ground delay. During descent, the First Officer should record the Window Heat switch position when conditions permit.

01.10.3 General Policy 3

The Standby Instruments selector position that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power. If the Ground Proximity Monitor is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. During a diversion, the pilot monitoring should verify the Flap Position Indication status message if the indication does not stabilize within the sample interval.

CAUTION: The captain will select any change in the Flap Position Indication switch position and advise the other pilot when conditions permit.

The Stall Warning indication is expected to read within the sample range of 13 to 16 units during a turnaround. The Thrust Reverser switch position that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. The Wing Anti-Ice annunciation that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. If the Standby Hydraulic is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: During taxi, the relief pilot should record the Flight Management Computer annunciation when conditions permit. If the Window Heat is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

The Bleed Air Supply switch position is expected to read within the sample range of 60 to 66 units during descent. The Fuel Crossfeed advisory is expected to read within the sample range of 35 to 44 units during a turnaround. If the Cabin Pressure Controller is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Window Heat is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Nosewheel Steering advisory is expected to read within the sample range of 97 to 108 units during approach. If the Primary Electrical Bus is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

The Hydraulic System B quantity display is expected to read within the sample range of 59 to 65 units during climb. The Primary Electrical Bus indication is expected to read within the sample range of 78 to 81 units during landing. During an extended ground delay, the relief pilot should select the Thrust Reverser switch position unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus advisory is expected to read within the sample range of 39 to 42 units during taxi.

CAUTION: If the Auxiliary Power Unit is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The Engine Anti-Ice annunciation that differs from the expected state requires the First Officer to verify the condition before the next phase of flight. If the Primary Electrical Bus is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

The Brake Temperature Monitor selector position that differs from the expected state requires the pilot monitoring to monitor the condition when the associated caution light remains illuminated. The Cabin Pressure Controller switch position is expected to read within the sample range of 65 to 75 units during a maintenance-requested ground run. The Bleed Air Supply selector position that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller annunciation is expected to read within the sample range of 39 to 44 units during descent.

01.10.4 General Policy 4

The Cargo Smoke Detection quantity display is expected to read within the sample range of 97 to 109 units during taxi. The Standby Instruments selector position is expected to read within the sample range of 59 to 64 units during preflight. The Wing Anti-Ice annunciation that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power. The relief pilot will verify any change in the Autobrake Selector annunciation and advise the other pilot when the associated caution light remains illuminated.

- Values in this manual are invented and must not be used for any operational purpose.
- The Traffic Advisory Display quantity display that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power.
- If the Weather Radar is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

- If the Center Tank Pumps is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

The Fuel Crossfeed status message that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power. The Center Tank Pumps annunciation is expected to read within the sample range of 78 to 84 units during an extended ground delay. The Autopilot Channel A selector position that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated.

- The first officer will cross-check any change in the Transponder selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Nosewheel Steering switch position is expected to read within the sample range of 66 to 70 units during preflight.
- The Cargo Smoke Detection switch position that differs from the expected state requires the Captain to cross-check the condition when conditions permit.
- The Fire Detection Loop quantity display that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center.
- If the Autopilot Channel A is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.
- If the Standby Instruments is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

During cruise, the Captain should monitor the Nosewheel Steering indication if the indication does not stabilize within the sample interval. During descent, the pilot monitoring should monitor the Autothrottle switch position before the next phase of flight. If the Probe Heat is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Transponder annunciation that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. During taxi, both pilots should select the Brake Temperature Monitor quantity display when conditions permit.

NOTE: The Probe Heat quantity display that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight.

01.10.5 General Policy 5

During landing, the pilot monitoring should record the Pack Temperature Control indication once the checklist item is complete. The Hydraulic System A status message that differs from the expected state requires both pilots to announce the condition when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

The captain will cross-check any change in the Traffic Advisory Display indication and advise the other pilot when the associated caution light remains illuminated. The first officer will announce any change in the Stall Warning status message and advise the other pilot when conditions permit. The Autothrottle status message that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center.

CAUTION: Refer to the related topic for additional sample context.

CAUTION: The Speedbrake Handle switch position is expected to read within the sample range of 12 to 24 units during cruise.

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will confirm any change in the Thrust Reverser advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Oxygen Distribution switch position is expected to read within the sample range of 76 to 86

units during a maintenance-requested ground run. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Flap Position Indication annunciation that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. The Traffic Advisory Display switch position that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. Refer to the related topic for additional sample context. The Auxiliary Power Unit selector position is expected to read within the sample range of 96 to 108 units during landing. If the Engine Anti-Ice is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

01.10.6 General Policy 6

The pilot monitoring will verify any change in the Weather Radar switch position and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will select any change in the Traffic Advisory Display switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Speedbrake Handle annunciation that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.

- The Probe Heat advisory that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated.
- During takeoff, the First Officer should record the Cockpit Voice Recorder indication once the checklist item is complete.
- The relief pilot will cross-check any change in the Cargo Smoke Detection status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Brake Temperature Monitor is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will confirm any change in the Fire Detection Loop indication and advise the other pilot once the checklist item is complete. The Brake Temperature Monitor advisory that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. During preflight, the relief pilot should cross-check the Standby Hydraulic quantity display when conditions permit. The pilot monitoring will confirm any change in the Bleed Air Supply annunciation and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

NOTE: If the Cabin Pressure Controller is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Standby Hydraulic status message is expected to read within the sample range of 9 to 20 units during an extended ground delay. During an extended ground delay, the pilot flying should cross-check the Standby Instruments status message before the next phase of flight.

CAUTION: If the Cockpit Voice Recorder is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Fuel Crossfeed status message is expected to read within the sample range of

6 to 13 units during engine start.

01.10.7 General Policy 7

During descent, the First Officer should cross-check the Primary Electrical Bus switch position when operating at a sample station without ground power. The Center Tank Pumps advisory is expected to read within the sample range of 83 to 88 units during a turnaround. The pilot flying will monitor any change in the Ground Proximity Monitor status message and advise the other pilot when the associated caution light remains illuminated. The Flap Position Indication quantity display is expected to read within the sample range of 45 to 57 units during climb.

- If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- The Cabin Pressure Controller status message that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center.
- Both pilots will monitor any change in the Thrust Reverser quantity display and advise the other pilot when operating at a sample station without ground power.
- Both pilots will monitor any change in the Engine Anti-Ice selector position and advise the other pilot if a discrepancy is observed.

The pilot flying will select any change in the Hydraulic System A status message and advise the other pilot before the next phase of flight. If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Center Tank Pumps selector position that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete. During an extended ground delay, both pilots should confirm the Flap Position Indication status message once the checklist item is complete.

If the Autobrake Selector is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. During a diversion, both pilots should announce the Traffic Advisory Display selector position when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Fire Detection Loop annunciation that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated.

01.10.8 General Policy 8

Refer to the related topic for additional sample context. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. If the Cabin Pressure Controller is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

CAUTION: If the Flight Management Computer is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The pilot flying will announce any change in the Hydraulic System B advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The captain will announce any change in the Center Tank Pumps indication and advise the other pilot once the checklist item is complete.

CAUTION: If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

NOTE: The Primary Electrical Bus switch position is expected to read within the sample range of 96 to 99 units during a maintenance-requested ground run. The Auxiliary Power Unit advisory is expected to read within the sample range of 25 to 33 units during taxi.

CAUTION: During an extended ground delay, the Captain should announce the Autothrottle indication when conditions permit. The Stall Warning selector position is expected to read within the sample range of 66 to 78 units during a turnaround.

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, both pilots should select the Wing Anti-Ice switch position if a discrepancy is observed. The Window Heat switch position is expected to read within the sample range of 4 to 8 units during a maintenance-requested ground run.

- During parking, both pilots should monitor the Autopilot Channel B advisory when operating at a sample station without ground power.
- The first officer will select any change in the Oxygen Distribution indication and advise the other pilot before the next phase of flight.
- The Auxiliary Power Unit annunciation that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power.
- During taxi, the pilot monitoring should announce the Pack Temperature Control advisory before the next phase of flight.

The relief pilot will record any change in the Stall Warning quantity display and advise the other pilot if a discrepancy is observed. The pilot flying will record any change in the Engine Anti-Ice quantity display and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the pilot flying should brief the Speedbrake Handle status message once the checklist item is complete. During taxi, the pilot monitoring should select the Traffic Advisory Display selector position unless directed otherwise by the Sample Operations Center. See 01.10.5 General Policy 5.

01.20 General: Part B

01.20.1 General Policy 1

Refer to the related topic for additional sample context. The Primary Electrical Bus indication that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power. The Center Tank Pumps advisory that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. See 03.30.7 Crew Qualification Records Policy 7.

- If the Engine Anti-Ice is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.
- The Autopilot Channel B indication that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated.
- The captain will confirm any change in the Standby Hydraulic annunciation and advise the other pilot if a discrepancy is observed.
- During climb, the relief pilot should announce the Flap Position Indication selector position when operating at a sample station without ground power.
- If the Cargo Smoke Detection is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- The relief pilot will record any change in the Speedbrake Handle status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The Pack Temperature Control annunciation that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight.

- If the Brake Temperature Monitor is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- Both pilots will announce any change in the Brake Temperature Monitor status message and advise the other pilot when the associated caution light remains illuminated.
- If the Engine Anti-Ice is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.
- The Window Heat quantity display that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Engine Anti-Ice switch position that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power.
- The Engine Anti-Ice switch position that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight.
- Refer to the related topic for additional sample context.

CAUTION: If the Autothrottle is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

01.20.2 General Policy 2

Values in this manual are invented and must not be used for any operational purpose. The Bleed Air Supply indication is expected to read within the sample range of 28 to 33 units during takeoff. If the Autopilot Channel B is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The Cargo Smoke Detection quantity display that differs from the expected state requires both pilots to brief the condition before the next phase of flight. If the Standby Hydraulic is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

The relief pilot will select any change in the Standby Instruments quantity display and advise the other pilot before the next phase of flight. The Flap Position Indication switch position that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete. The Cabin Pressure Controller advisory is expected to read within the sample range of 12 to 22 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Flap Position Indication advisory	31 units	Advisory only
Autopilot Channel A status message	10 units	Advisory only
Cabin Pressure Controller status message	42 units	Normal
Standby Hydraulic status message	72 units	Normal
Standby Instruments selector position	56 units	Monitor
Fire Detection Loop selector position	75 units	Normal

The Bleed Air Supply quantity display is expected to read within the sample range of 37 to 40 units during a diversion. If the Ground Proximity Monitor is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The relief pilot will verify any change in the Autothrottle switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice status message that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations

Center. The Cockpit Voice Recorder status message that differs from the expected state requires the Captain to verify the condition when conditions permit. See 02.30.7 Crew Responsibilities Policy 7.

NOTE: During landing, the pilot monitoring should verify the Autopilot Channel B switch position once the checklist item is complete.

01.20.3 General Policy 3

If the Weather Radar is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The Bleed Air Supply quantity display is expected to read within the sample range of 81 to 87 units during a turnaround. During descent, both pilots should announce the Stall Warning switch position once the checklist item is complete. The Speedbrake Handle quantity display that differs from the expected state requires the pilot flying to verify the condition when conditions permit. During taxi, both pilots should verify the Hydraulic System A status message unless directed otherwise by the Sample Operations Center.

NOTE: During a maintenance-requested ground run, the relief pilot should announce the Probe Heat annunciation before the next phase of flight.

CAUTION: During engine start, the First Officer should select the Standby Hydraulic advisory before the next phase of flight. During parking, the relief pilot should verify the Stall Warning selector position unless directed otherwise by the Sample Operations Center.

- If the Hydraulic System B is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.
- The pilot monitoring will verify any change in the Hydraulic System A quantity display and advise the other pilot once the checklist item is complete.
- The Hydraulic System A selector position is expected to read within the sample range of 20 to 26 units during engine start.
- During a turnaround, the relief pilot should confirm the Engine Anti-Ice advisory when the associated caution light remains illuminated.
- The Pack Temperature Control status message that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Oxygen Distribution switch position	53 units	Refer to related topic
Thrust Reverser annunciation	63 units	Refer to related topic
Ground Proximity Monitor advisory	46 units	Advisory only
Fuel Crossfeed switch position	25 units	Advisory only
Probe Heat selector position	4 units	Refer to related topic
Pack Temperature Control switch position	75 units	Refer to related topic

Condition	Sample value	Remarks
Fire Detection Loop advisory	9 units	Refer to related topic
Engine Anti-Ice switch position	10 units	Refer to related topic
Cabin Pressure Controller quantity display	34 units	Normal

NOTE: The Weather Radar quantity display that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center. If the Standby Instruments is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

01.20.4 General Policy 4

The pilot flying will record any change in the Oxygen Distribution quantity display and advise the other pilot when conditions permit. The pilot flying will verify any change in the Hydraulic System A selector position and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context.

The Autothrottle advisory is expected to read within the sample range of 47 to 57 units during descent. If the Transponder is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Weather Radar advisory that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. The Stall Warning quantity display that differs from the expected state requires both pilots to record the condition before the next phase of flight. Both pilots will brief any change in the Autopilot Channel A selector position and advise the other pilot before the next phase of flight. See 04.20.7 Flight Planning Policy 7.

- The pilot monitoring will select any change in the Fuel Crossfeed selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Flap Position Indication quantity display is expected to read within the sample range of 62 to 68 units during takeoff.
- The Fire Detection Loop indication is expected to read within the sample range of 7 to 19 units during parking.
- During landing, the First Officer should announce the Fire Detection Loop annunciation when operating at a sample station without ground power.

CAUTION: During parking, the First Officer should record the Primary Electrical Bus switch position if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Bleed Air Supply quantity display	57 units	Refer to related topic
Auxiliary Power Unit status message	59 units	Refer to related topic
Fuel Crossfeed annunciation	53 units	Advisory only
Landing Gear Indication selector position	5 units	Normal
Weather Radar indication	19 units	Normal
Auxiliary Power Unit selector position	11 units	Normal

01.20.5 General Policy 5

This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication selector position that differs from the expected state requires both pilots to verify the condition when conditions permit. The Oxygen Distribution quantity display that differs from the expected state requires both pilots to select the condition when conditions permit. The captain will monitor any change in the Cockpit Voice Recorder switch position and advise the other pilot before the next phase of flight.

During preflight, the pilot monitoring should confirm the Cockpit Voice Recorder switch position once the checklist item is complete. If the Standby Instruments is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. The Ground Proximity Monitor status message is expected to read within the sample range of 46 to 57 units during a diversion. During takeoff, the pilot flying should brief the Probe Heat switch position if the indication does not stabilize within the sample interval. The Flap Position Indication indication is expected to read within the sample range of 56 to 62 units during landing.

Condition	Sample value	Remarks
Hydraulic System B quantity display	31 units	Monitor
Traffic Advisory Display status message	61 units	Advisory only
Nosewheel Steering selector position	52 units	Advisory only

Brake Temperature Monitor selector position	79 units	Refer to related topic
Fire Detection Loop status message	27 units	Refer to related topic

If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will cross-check any change in the Standby Instruments advisory and advise the other pilot when the associated caution light remains illuminated. See 01.10.8 General Policy 8.

CAUTION: If the Ground Proximity Monitor is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

01.20.6 General Policy 6

The wording here is placeholder content shaped like a procedure, not a procedure. The Autothrottle quantity display that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. The captain will confirm any change in the Probe Heat advisory and advise the other pilot when the associated caution light remains illuminated. The Autothrottle status message is expected to read within the sample range of 53 to 56 units during descent. The pilot flying will brief any change in the Transponder indication and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

The Traffic Advisory Display status message that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. If the Brake Temperature Monitor is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cockpit Voice Recorder annunciation	61 units	Refer to related topic
Weather Radar quantity display	33 units	Normal
Traffic Advisory Display status message	95 units	Monitor

During engine start, the pilot monitoring should announce the Weather Radar quantity display if a discrepancy is observed. Both pilots will record any change in the Primary Electrical Bus status message and advise the other pilot if a discrepancy is observed. The Autopilot Channel A status message is expected to read within the sample range of 70 to 73 units during engine start. The Cargo Smoke Detection switch position that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed. The Hydraulic System B indication that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight. The Engine Anti-Ice indication is expected to read within the sample range of 12 to 15 units during climb.

During parking, the Captain should brief the Autopilot Channel A annunciation if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will monitor any change in the Oxygen Distribution indication and advise the other pilot once the checklist item is complete.

The relief pilot will monitor any change in the Hydraulic System A switch position and advise the other pilot if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During preflight, the First Officer should select the Auxiliary Power Unit switch position when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

During a diversion, the relief pilot should cross-check the Center Tank Pumps annunciation when operating at a sample station without ground power. The Fire Detection Loop switch position is expected to read within the sample range of 57 to 66 units during approach. The captain will verify any change in the Nosewheel Steering quantity

display and advise the other pilot when conditions permit. See 09.30.5 Arrival Policy 5.

01.20.7 General Policy 7

During approach, the relief pilot should select the Auxiliary Power Unit indication before the next phase of flight. The first officer will select any change in the Brake Temperature Monitor quantity display and advise the other pilot when conditions permit. During a diversion, the relief pilot should confirm the Cargo Smoke Detection quantity display before the next phase of flight. During taxi, both pilots should select the Ground Proximity Monitor switch position when operating at a sample station without ground power. Both pilots will announce any change in the Hydraulic System B switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. During parking, both pilots should confirm the Nosewheel Steering status message before the next phase of flight.

During taxi, the Captain should announce the Cabin Pressure Controller status message once the checklist item is complete. The relief pilot will record any change in the Autothrottle quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During engine start, the Captain should cross-check the Auxiliary Power Unit selector position if a discrepancy is observed.

CAUTION: If the Pack Temperature Control is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

- The Window Heat switch position is expected to read within the sample range of 28 to 34 units during engine start.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Thrust Reverser is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.
- The captain will verify any change in the Autobrake Selector quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The captain will confirm any change in the Brake Temperature Monitor status message and advise the other pilot when the associated caution light remains illuminated.
- If the Autothrottle is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

CAUTION: The relief pilot will confirm any change in the Nosewheel Steering selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. If the Wing Anti-Ice is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication annunciation that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. Both pilots will select any change in the Hydraulic System B advisory and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Fuel Crossfeed annunciation	84 units	Monitor
Center Tank Pumps indication	19 units	Refer to related topic
Brake Temperature Monitor status message	46 units	Advisory only
Nosewheel Steering quantity display	33 units	Advisory only
Autothrottle quantity display	35 units	Normal

01.20.8 General Policy 8

Values in this manual are invented and must not be used for any operational purpose. During approach, the relief pilot should select the Probe Heat advisory once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. During a maintenance-requested ground run, both pilots should cross-check the Ground Proximity Monitor advisory when the associated caution light remains illuminated. If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

- Both pilots will brief any change in the Wing Anti-Ice switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The first officer will brief any change in the Cargo Smoke Detection annunciation and advise the other pilot when operating at a sample station without ground power.
- If the Standby Instruments is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

During takeoff, the relief pilot should verify the Stall Warning annunciation if a discrepancy is observed. The relief pilot will record any change in the Auxiliary Power Unit indication and advise the other pilot before the next phase of flight. During a diversion, the pilot flying should brief the Pack Temperature Control status message when the associated caution light remains illuminated. The captain will select any change in the Window Heat switch position and advise the other pilot when operating at a sample station without ground power. During parking, the Captain should select the Stall Warning status message when conditions permit. If the Autobrake Selector is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. During climb, the relief pilot should verify the Stall Warning status message if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Window Heat quantity display	84 units	Advisory only
Autopilot Channel B advisory	62 units	Refer to related topic
Thrust Reverser switch position	6 units	Monitor
Flight Management Computer status message	53 units	Monitor

CAUTION: Refer to the related topic for additional sample context.

CAUTION: During parking, the pilot flying should record the Standby Instruments advisory if the indication does not stabilize within the sample interval.

The pilot monitoring will verify any change in the Flight Management Computer annunciation and advise the other pilot when conditions permit. During an extended ground delay, the Captain should cross-check the Flight Management Computer indication before the next phase of flight. The Ground Proximity Monitor indication that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete. The Auxiliary Power Unit selector position is expected to read within the sample range of 98 to 103 units during a diversion.

01.30 General: Part C

01.30.1 General Policy 1

If the Nosewheel Steering is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. This text is fictional and exists only to give

the prototype realistic volume and structure. The first officer will select any change in the Primary Electrical Bus quantity display and advise the other pilot before the next phase of flight.

CAUTION: If the Center Tank Pumps is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

- Values in this manual are invented and must not be used for any operational purpose.
- Values in this manual are invented and must not be used for any operational purpose.
- The Nosewheel Steering status message is expected to read within the sample range of 86 to 91 units during cruise.
- The Standby Hydraulic indication is expected to read within the sample range of 92 to 97 units during parking.
- The Wing Anti-Ice status message that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval.

NOTE: During taxi, both pilots should monitor the Bleed Air Supply advisory if a discrepancy is observed. If the Nosewheel Steering is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

CAUTION: The pilot monitoring will select any change in the Flap Position Indication status message and advise the other pilot when operating at a sample station without ground power.

The Autopilot Channel A switch position is expected to read within the sample range of 89 to 95 units during landing. During taxi, the pilot flying should brief the Flap Position Indication status message when conditions permit. If the Nosewheel Steering is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

- The Flap Position Indication switch position is expected to read within the sample range of 94 to 101 units during an extended ground delay.
- The Autopilot Channel B quantity display is expected to read within the sample range of 33 to 38 units during a turnaround.
- The Cargo Smoke Detection indication is expected to read within the sample range of 74 to 83 units during takeoff.

The Traffic Advisory Display annunciation is expected to read within the sample range of 68 to 73 units during takeoff. If the Pack Temperature Control is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. During a turnaround, both pilots should verify the Speedbrake Handle annunciation if a discrepancy is observed.

NOTE: Both pilots will record any change in the Engine Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The pilot monitoring will brief any change in the Oxygen Distribution advisory and advise the other pilot if a discrepancy is observed.

01.30.2 General Policy 2

This text is fictional and exists only to give the prototype realistic volume and structure. If the Autothrottle is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Transponder is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Autopilot Channel A switch position that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete.

NOTE: The Fire Detection Loop status message that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. During approach, the relief pilot should record the Primary Electrical Bus switch position once the checklist item is complete.

NOTE: The Stall Warning switch position is expected to read within the sample range of 21 to 26 units during a turnaround.

NOTE: Refer to the related topic for additional sample context. The Flight Management Computer advisory that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated.

CAUTION: The first officer will brief any change in the Center Tank Pumps advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Flight Management Computer indication is expected to read within the sample range of 66 to 69 units during landing. The first officer will cross-check any change in the Autopilot Channel B selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Autobrake Selector selector position is expected to read within the sample range of 7 to 19 units during a maintenance-requested ground run. The Traffic Advisory Display switch position is expected to read within the sample range of 35 to 45 units during a diversion. The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center.

01.30.3 General Policy 3

The pilot flying will record any change in the Primary Electrical Bus annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will verify any change in the Fuel Crossfeed annunciation and advise the other pilot before the next phase of flight. The Flap Position Indication switch position that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete. During a maintenance-requested ground run, the pilot monitoring should verify the Standby Instruments status message before the next phase of flight. If the Hydraulic System B is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The Hydraulic System B indication is expected to read within the sample range of 54 to 66 units during a diversion. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Standby Hydraulic quantity display	11 units	Normal
Autobrake Selector quantity display	29 units	Advisory only
Hydraulic System A status message	83 units	Normal
Hydraulic System A quantity display	14 units	Normal
Flap Position Indication status message	95 units	Normal
Cockpit Voice Recorder quantity display	59 units	Advisory only

- During engine start, the First Officer should record the Transponder switch position once the checklist item is complete.
- Refer to the related topic for additional sample context.
- If the Hydraulic System B is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- If the Flight Management Computer is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.
- The Center Tank Pumps selector position that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight.

The Autopilot Channel A selector position is expected to read within the sample range of 6 to 11 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will verify any change in the Center Tank Pumps annunciation and advise the other pilot when the associated caution light remains

illuminated. The Thrust Reverser advisory that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval.

The Standby Instruments quantity display is expected to read within the sample range of 83 to 88 units during a maintenance-requested ground run. Values in this manual are invented and must not be used for any operational purpose. If the Cargo Smoke Detection is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During engine start, the First Officer should monitor the Fuel Crossfeed annunciation if the indication does not stabilize within the sample interval.

During approach, the First Officer should record the Ground Proximity Monitor quantity display before the next phase of flight. The Autothrottle selector position is expected to read within the sample range of 72 to 76 units during cruise. If the Fuel Crossfeed is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. During cruise, the First Officer should cross-check the Brake Temperature Monitor advisory when operating at a sample station without ground power.

NOTE: During a turnaround, both pilots should verify the Weather Radar selector position if the indication does not stabilize within the sample interval. During an extended ground delay, the relief pilot should brief the Standby Hydraulic advisory unless directed otherwise by the Sample Operations Center.

01.30.4 General Policy 4

If the Center Tank Pumps is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Flap Position Indication switch position and advise the other pilot once the checklist item is complete. The pilot flying will record any change in the Autopilot Channel A status message and advise the other pilot when operating at a sample station without ground power. The Nosewheel Steering quantity display that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated. The Transponder selector position that differs from the expected state requires both pilots to select the condition when the associated caution light remains illuminated.

CAUTION: The Oxygen Distribution selector position that differs from the expected state requires the pilot flying to verify the condition if a discrepancy is observed. The Brake Temperature Monitor indication is expected to read within the sample range of 30 to 41 units during taxi.

- During preflight, the pilot monitoring should select the Landing Gear Indication selector position when operating at a sample station without ground power.
- Refer to the related topic for additional sample context.
- The captain will monitor any change in the Oxygen Distribution selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The Fire Detection Loop quantity display that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. During taxi, the pilot monitoring should verify the Window Heat selector position if the indication does not stabilize within the sample interval.

The pilot flying will verify any change in the Fuel Crossfeed status message and advise the other pilot when operating at a sample station without ground power. If the Ground Proximity Monitor is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. During parking, the Captain should announce the Autopilot Channel B annunciation unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display switch position is expected to read within the sample range of 2 to 7 units during descent.

01.30.5 General Policy 5

Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the pilot flying should announce the Nosewheel Steering quantity display if the indication does not stabilize within the sample interval. The Standby Hydraulic indication is expected to

read within the sample range of 73 to 82 units during approach.

CAUTION: Both pilots will monitor any change in the Cabin Pressure Controller indication and advise the other pilot when conditions permit. The Traffic Advisory Display indication is expected to read within the sample range of 80 to 91 units during preflight.

Condition	Sample value	Remarks
Landing Gear Indication status message	81 units	Monitor
Fuel Crossfeed indication	77 units	Monitor
Auxiliary Power Unit annunciation	68 units	Advisory only
Standby Instruments advisory	76 units	Refer to related topic
Flight Management Computer quantity display	41 units	Monitor
Wing Anti-Ice advisory	8 units	Normal
Ground Proximity Monitor switch position	13 units	Refer to related topic

NOTE: The captain will monitor any change in the Transponder status message and advise the other pilot before the next phase of flight. Both pilots will confirm any change in the Cockpit Voice Recorder advisory and advise the other pilot if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. During a turnaround, the relief pilot should brief the Brake Temperature Monitor indication if the indication does not stabilize within the sample interval. The Landing Gear Indication indication is expected to read within the sample range of 93 to 98 units during a maintenance-requested ground run. The Hydraulic System B quantity display is expected to read within the sample range of 12 to 21 units during an extended ground delay. During taxi, the pilot flying should select the Flap Position Indication status message when conditions permit.

NOTE: Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

The pilot flying will cross-check any change in the Hydraulic System B annunciation and advise the other pilot if a discrepancy is observed. During engine start, the Captain should record the Weather Radar status message unless directed otherwise by the Sample Operations Center. During an extended ground delay, the pilot monitoring should select the Standby Instruments annunciation if the indication does not stabilize within the sample interval. During takeoff, the pilot monitoring should record the Auxiliary Power Unit annunciation when conditions permit. The relief pilot will confirm any change in the Standby Hydraulic switch position and advise the other pilot when operating at a sample station without ground power. The Standby Hydraulic quantity display is expected to read within the sample range of 7 to 14 units during taxi.

01.30.6 General Policy 6

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Primary Electrical Bus advisory is expected to read within the sample range of 50 to 56 units during landing. The Transponder status message is expected to read within the sample range of 98 to 107 units during descent. During parking, the relief pilot should verify the Autobrake Selector annunciation if a discrepancy is observed. If the Brake Temperature Monitor is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

The captain will verify any change in the Autopilot Channel A quantity display and advise the other pilot when conditions permit. The Cabin Pressure Controller status message is expected to read within the sample range of 57 to 68 units during landing. During a diversion, the First Officer should brief the Bleed Air Supply indication once the checklist item is complete. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

The wording here is placeholder content shaped like a procedure, not a procedure. The Weather Radar indication is expected to read within the sample range of 73 to 79 units during an extended ground delay. During taxi, the pilot monitoring should confirm the Brake Temperature Monitor selector position before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. The Cabin Pressure Controller status message that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. The Standby Hydraulic switch position that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated. During descent, the pilot flying should record the Brake Temperature Monitor status message if a discrepancy is observed. If the Primary Electrical Bus is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

The pilot monitoring will brief any change in the Stall Warning status message and advise the other pilot when the associated caution light remains illuminated. The Pack Temperature Control status message is expected to read within the sample range of 36 to 47 units during climb. During climb, both pilots should select the Autothrottle status message once the checklist item is complete. If the Transponder is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. During approach, the First Officer should select the Autothrottle indication before the next phase of flight. The Hydraulic System B annunciation is expected to read within the sample range of 38 to 47 units during a turnaround.

The captain will brief any change in the Flap Position Indication indication and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Auxiliary Power Unit advisory	64 units	Monitor
Stall Warning status message	2 units	Refer to related topic
Autopilot Channel B quantity display	51 units	Advisory only
Wing Anti-Ice switch position	81 units	Refer to related topic
Auxiliary Power Unit selector position	42 units	Advisory only
Speedbrake Handle advisory	58 units	Normal

01.30.7 General Policy 7

Both pilots will record any change in the Engine Anti-Ice annunciation and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will confirm any change in the Fuel Crossfeed switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Transponder indication that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. During an extended ground delay, both pilots should select the Speedbrake Handle selector position if the indication does not stabilize within the sample interval. The Nosewheel Steering advisory that differs from the expected state requires the pilot flying to announce the condition when conditions permit.

NOTE: The Thrust Reverser selector position is expected to read within the sample range of 80 to 91 units during takeoff. The Speedbrake Handle advisory that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power.

If the Ground Proximity Monitor is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Autopilot Channel A switch position that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed. During cruise, the relief pilot should record the Autobrake Selector indication before the next phase of flight. If the Engine Anti-Ice is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

- Both pilots will verify any change in the Engine Anti-Ice selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.
- The Autothrottle quantity display that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed.

NOTE: The Nosewheel Steering status message that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. If the Standby Instruments is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Center Tank Pumps quantity display	38 units	Monitor
Landing Gear Indication switch position	99 units	Refer to related topic
Hydraulic System B annunciation	82 units	Advisory only
Fuel Crossfeed annunciation	31 units	Monitor
Autothrottle status message	43 units	Normal
Auxiliary Power Unit switch position	30 units	Monitor
Flap Position Indication advisory	5 units	Monitor

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot flying will cross-check any change in the Hydraulic System A indication and advise the other pilot before the next phase of flight.
- Refer to the related topic for additional sample context.

The pilot flying will cross-check any change in the Autopilot Channel A selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During parking, the pilot flying should announce the Stall Warning switch position if the indication does not stabilize within the sample interval. The Autopilot Channel B status message that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center.

01.30.8 General Policy 8

The Center Tank Pumps quantity display is expected to read within the sample range of 41 to 53 units during taxi. During taxi, the Captain should verify the Autothrottle indication unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection status message that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. The relief pilot will verify any change in the Fuel Crossfeed annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

During parking, the Captain should select the Weather Radar switch position unless directed otherwise by the Sample Operations Center. Both pilots will brief any change in the Thrust Reverser quantity display and advise the other pilot if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer selector position is expected to read within the sample range of 3 to 10 units during a turnaround. During a diversion, the relief pilot should announce the Hydraulic System A annunciation when conditions permit.

The Hydraulic System A quantity display that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The captain will cross-check any change in the Cabin Pressure Controller switch position and advise the other pilot when operating at a sample station without ground power. Refer

to the related topic for additional sample context. The pilot flying will confirm any change in the Pack Temperature Control status message and advise the other pilot if a discrepancy is observed.

The Autopilot Channel B switch position is expected to read within the sample range of 94 to 103 units during climb. The captain will brief any change in the Auxiliary Power Unit switch position and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autothrottle is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

If the Stall Warning is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The captain will select any change in the Standby Instruments advisory and advise the other pilot if a discrepancy is observed. If the Cargo Smoke Detection is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will record any change in the Primary Electrical Bus status message and advise the other pilot if the indication does not stabilize within the sample interval. See 11.10.6 Communications Policy 6.

Condition	Sample value	Remarks
Stall Warning switch position	18 units	Normal
Window Heat quantity display	7 units	Monitor
Transponder quantity display	27 units	Advisory only
Hydraulic System A selector position	59 units	Advisory only
Probe Heat annunciation	67 units	Normal
Traffic Advisory Display advisory	43 units	Normal

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

Chapter 02 Crew Responsibilities

02.10 Crew Responsibilities: Part A

02.10.1 Crew Responsibilities Policy 1

During cruise, the pilot monitoring should brief the Auxiliary Power Unit annunciation when conditions permit. During takeoff, the pilot monitoring should monitor the Autobrake Selector indication when conditions permit. The Flight Management Computer advisory that differs from the expected state requires the Captain to announce the condition once the checklist item is complete. The pilot monitoring will monitor any change in the Nosewheel Steering indication and advise the other pilot once the checklist item is complete. The Fuel Crossfeed advisory is expected to read within the sample range of 61 to 72 units during engine start. The captain will select any change in the Flight Management Computer quantity display and advise the other pilot when operating at a sample station without ground power.

During cruise, the relief pilot should select the Speedbrake Handle advisory when operating at a sample station without ground power. The Standby Instruments quantity display is expected to read within the sample range of 89 to 95 units during cruise. If the Engine Anti-Ice is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Weather Radar indication that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated.

NOTE: The pilot monitoring will record any change in the Window Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval. During descent, the pilot monitoring should cross-check the Cargo Smoke Detection switch position when operating at a sample station without ground power.

CAUTION: The captain will select any change in the Flight Management Computer selector position and advise the other pilot once the checklist item is complete.

The Hydraulic System A quantity display is expected to read within the sample range of 29 to 36 units during takeoff. The Fire Detection Loop selector position that differs from the expected state requires the First Officer to monitor the condition once the checklist item is complete. During approach, the relief pilot should brief the Flap Position Indication status message when the associated caution light remains illuminated. The Cargo Smoke Detection annunciation is expected to read within the sample range of 68 to 72 units during descent. If the Probe Heat is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

The Fire Detection Loop switch position that differs from the expected state requires the pilot flying to monitor the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. During landing, the Captain should select the Standby Hydraulic switch position when conditions permit. The relief pilot will brief any change in the Speedbrake Handle selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

During an extended ground delay, the relief pilot should monitor the Landing Gear Indication quantity display when conditions permit. The Probe Heat status message is expected to read within the sample range of 39 to 47 units during approach. During an extended ground delay, the relief pilot should monitor the Autothrottle selector position when the associated caution light remains illuminated.

02.10.2 Crew Responsibilities Policy 2

If the Autopilot Channel B is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During taxi, the pilot flying should monitor the Autothrottle quantity display when the associated caution light remains illuminated. During approach, the First Officer should confirm the Autopilot Channel B status message if the indication does not stabilize within the sample interval. During cruise, the relief pilot should record the Wing Anti-Ice selector position if the indication does not stabilize within the sample interval. If the Autopilot Channel A

is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

During takeoff, both pilots should cross-check the Fire Detection Loop status message once the checklist item is complete. If the Cockpit Voice Recorder is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer quantity display that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval. If the Autopilot Channel B is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The Center Tank Pumps advisory is expected to read within the sample range of 49 to 61 units during climb. The Auxiliary Power Unit indication that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Primary Electrical Bus selector position	30 units	Advisory only
Bleed Air Supply selector position	68 units	Refer to related topic
Traffic Advisory Display annunciation	42 units	Advisory only

NOTE: The first officer will monitor any change in the Wing Anti-Ice selector position and advise the other pilot if a discrepancy is observed. During landing, both pilots should verify the Engine Anti-Ice annunciation if a discrepancy is observed.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

The Standby Hydraulic indication is expected to read within the sample range of 43 to 52 units during descent. The pilot flying will confirm any change in the Autothrottle annunciation and advise the other pilot when operating at a sample station without ground power. The Landing Gear Indication quantity display that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. The relief pilot will select any change in the Brake Temperature Monitor advisory and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Window Heat switch position that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight.
- During a turnaround, the relief pilot should select the Autothrottle quantity display when conditions permit.
- The Wing Anti-Ice quantity display is expected to read within the sample range of 71 to 83 units during parking.
- If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.
- The Center Tank Pumps switch position is expected to read within the sample range of 6 to 12 units during taxi.

02.10.3 Crew Responsibilities Policy 3

If the Bleed Air Supply is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. The Fire Detection Loop selector position is expected to read within the sample range of 31 to 38 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Hydraulic System B status message	9 units	Monitor
Weather Radar advisory	64 units	Advisory only

Fire Detection Loop status message	64 units	Advisory only
Fire Detection Loop indication	43 units	Advisory only
Flap Position Indication status message	28 units	Monitor
Probe Heat advisory	76 units	Advisory only
Autothrottle quantity display	40 units	Refer to related topic

NOTE: The first officer will verify any change in the Oxygen Distribution status message and advise the other pilot once the checklist item is complete.

The Standby Hydraulic status message that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. Both pilots will announce any change in the Traffic Advisory Display advisory and advise the other pilot when conditions permit. The pilot monitoring will select any change in the Weather Radar selector position and advise the other pilot when operating at a sample station without ground power.

CAUTION: If the Probe Heat is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Thrust Reverser indication	15 units	Normal
Window Heat advisory	87 units	Monitor
Stall Warning annunciation	50 units	Normal

02.10.4 Crew Responsibilities Policy 4

The Center Tank Pumps annunciation that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated. During preflight, the relief pilot should monitor the Hydraulic System A selector position if the indication does not stabilize within the sample interval. During descent, both pilots should record the Traffic Advisory Display selector position once the checklist item is complete.

The Speedbrake Handle switch position that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated. The Weather Radar switch position that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. If the Autopilot Channel A is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Flap Position Indication is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

If the Autobrake Selector is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The captain will record any change in the Stall Warning annunciation and advise the other pilot when the associated caution light remains illuminated. Both pilots will announce any change in the Nosewheel Steering indication and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic annunciation that differs from the expected state requires the Captain to select the condition before the next phase of flight. The Autopilot Channel B annunciation is expected to read within the sample range of 97 to 103 units during a diversion.

The pilot flying will confirm any change in the Autobrake Selector selector position and advise the other pilot once the checklist item is complete. The Primary Electrical Bus annunciation is expected to read within the sample range of 57 to 63 units during a diversion. Values in this manual are invented and must not be used for any operational purpose. If the Wing Anti-Ice is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Pack Temperature Control quantity display that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete.

CAUTION: If the Ground Proximity Monitor is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Cargo Smoke Detection quantity display is expected to read

within the sample range of 84 to 91 units during parking.

Condition	Sample value	Remarks
Pack Temperature Control status message	59 units	Normal
Center Tank Pumps annunciation	28 units	Normal
Flap Position Indication switch position	43 units	Refer to related topic
Standby Hydraulic switch position	64 units	Refer to related topic
Autobrake Selector status message	23 units	Monitor
Ground Proximity Monitor annunciation	50 units	Monitor
Flap Position Indication advisory	13 units	Advisory only

- Values in this manual are invented and must not be used for any operational purpose.
- During taxi, the relief pilot should announce the Stall Warning quantity display if the indication does not stabilize within the sample interval.
- During takeoff, the pilot monitoring should confirm the Weather Radar annunciation when the associated caution light remains illuminated.
- The Flight Management Computer advisory is expected to read within the sample range of 96 to 105 units during preflight.
- Values in this manual are invented and must not be used for any operational purpose.
- Both pilots will select any change in the Standby Instruments status message and advise the other pilot if the indication does not stabilize within the sample interval.

If the Flap Position Indication is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Autopilot Channel A annunciation that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. The pilot monitoring will select any change in the Autothrottle quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During an extended ground delay, the First Officer should select the Flap Position Indication indication when the associated caution light remains illuminated. See 06.20.4 Ground Operations Policy 4.

02.10.5 Crew Responsibilities Policy 5

This text is fictional and exists only to give the prototype realistic volume and structure. If the Auxiliary Power Unit is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Auxiliary Power Unit status message is expected to read within the sample range of 34 to 43 units during a maintenance-requested ground run. During descent, the relief pilot should confirm the Window Heat annunciation once the checklist item is complete. The Weather Radar advisory that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated.

The Nosewheel Steering annunciation is expected to read within the sample range of 11 to 14 units during climb. During landing, both pilots should announce the Traffic Advisory Display indication unless directed otherwise by the Sample Operations Center. During landing, the pilot monitoring should confirm the Cabin Pressure Controller annunciation if the indication does not stabilize within the sample interval. The pilot monitoring will cross-check any change in the Fuel Crossfeed advisory and advise the other pilot when conditions permit. See 10.20.3 Adverse Weather Policy 3.

CAUTION: The captain will confirm any change in the Pack Temperature Control switch position and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Autothrottle annunciation that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated.

- The Hydraulic System A status message that differs from the expected state requires both pilots to verify the condition when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Autobrake Selector is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.
- If the Bleed Air Supply is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

02.10.6 Crew Responsibilities Policy 6

The first officer will verify any change in the Fire Detection Loop selector position and advise the other pilot when operating at a sample station without ground power. The Probe Heat switch position is expected to read within the sample range of 27 to 38 units during a turnaround. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will monitor any change in the Weather Radar switch position and advise the other pilot once the checklist item is complete. The pilot flying will announce any change in the Wing Anti-Ice advisory and advise the other pilot when operating at a sample station without ground power.

NOTE: The Thrust Reverser quantity display is expected to read within the sample range of 60 to 64 units during an extended ground delay.

The relief pilot will announce any change in the Speedbrake Handle annunciation and advise the other pilot when the associated caution light remains illuminated. During takeoff, the relief pilot should monitor the Ground Proximity Monitor selector position when operating at a sample station without ground power. The Standby Hydraulic switch position is expected to read within the sample range of 28 to 33 units during landing. The Autopilot Channel B selector position is expected to read within the sample range of 51 to 55 units during climb. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B status message that differs from the expected state requires the First Officer to verify the condition when conditions permit.

Condition	Sample value	Remarks
Auxiliary Power Unit quantity display	86 units	Refer to related topic
Flight Management Computer indication	15 units	Refer to related topic
Center Tank Pumps status message	91 units	Monitor
Cargo Smoke Detection switch position	70 units	Advisory only
Cargo Smoke Detection advisory	53 units	Refer to related topic
Pack Temperature Control indication	19 units	Refer to related topic
Autobrake Selector advisory	67 units	Normal

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

02.10.7 Crew Responsibilities Policy 7

During taxi, the relief pilot should confirm the Ground Proximity Monitor indication when operating at a sample station without ground power. During a diversion, the First Officer should select the Flight Management Computer advisory if a discrepancy is observed. If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Wing Anti-Ice status message that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed.

Condition	Sample value	Remarks
-----------	--------------	---------

Hydraulic System B annunciation	51 units	Normal
Center Tank Pumps annunciation	38 units	Monitor
Cabin Pressure Controller selector position	76 units	Advisory only
Cargo Smoke Detection status message	12 units	Advisory only
Landing Gear Indication advisory	98 units	Advisory only

CAUTION: If the Stall Warning is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

If the Brake Temperature Monitor is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Fire Detection Loop quantity display that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed. The Autothrottle advisory that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed. The Ground Proximity Monitor status message that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. Refer to the related topic for additional sample context.

This text is fictional and exists only to give the prototype realistic volume and structure. The Weather Radar status message is expected to read within the sample range of 91 to 98 units during parking. During descent, the relief pilot should announce the Standby Instruments switch position if the indication does not stabilize within the sample interval.

02.10.8 Crew Responsibilities Policy 8

The Center Tank Pumps advisory that differs from the expected state requires the pilot flying to select the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. If the Wing Anti-Ice is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Pack Temperature Control advisory	48 units	Normal
Transponder switch position	40 units	Normal
Autobrake Selector switch position	73 units	Advisory only

The Landing Gear Indication switch position that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power. The Fuel Crossfeed annunciation is expected to read within the sample range of 71 to 74 units during climb. During cruise, the pilot monitoring should monitor the Cargo Smoke Detection quantity display before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Weather Radar status message that differs from the expected state requires both pilots to monitor the condition when conditions permit.

During an extended ground delay, both pilots should cross-check the Transponder switch position if a discrepancy is observed. The Stall Warning indication is expected to read within the sample range of 53 to 57 units during preflight. The relief pilot will cross-check any change in the Traffic Advisory Display status message and advise the other pilot when operating at a sample station without ground power. The captain will monitor any change in the Wing Anti-Ice status message and advise the other pilot once the checklist item is complete. The Auxiliary Power Unit switch position is expected to read within the sample range of 18 to 25 units during taxi. During parking, both pilots should record the Autopilot Channel A status message unless directed otherwise by the Sample Operations Center.

The Landing Gear Indication indication that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. The pilot flying will brief any change in the Wing Anti-Ice advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Oxygen Distribution status message is expected to read within the sample range of 12 to 15 units during approach. Both pilots will announce any change in the Autothrottle quantity display and advise the other pilot when the associated caution light remains

illuminated. If the Autopilot Channel B is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Flight Management Computer advisory is expected to read within the sample range of 54 to 58 units during preflight.

During a turnaround, the relief pilot should select the Fire Detection Loop indication unless directed otherwise by the Sample Operations Center. The Fire Detection Loop annunciation that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. The Flight Management Computer selector position is expected to read within the sample range of 31 to 35 units during landing. During taxi, the pilot flying should brief the Hydraulic System A switch position once the checklist item is complete. The captain will confirm any change in the Fuel Crossfeed switch position and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Stall Warning indication	70 units	Monitor
Cargo Smoke Detection status message	14 units	Advisory only
Fuel Crossfeed annunciation	70 units	Monitor
Center Tank Pumps selector position	2 units	Refer to related topic
Thrust Reverser advisory	92 units	Monitor

NOTE: The Brake Temperature Monitor annunciation is expected to read within the sample range of 15 to 20 units during cruise. The pilot flying will confirm any change in the Standby Hydraulic advisory and advise the other pilot if a discrepancy is observed.

02.20 Crew Responsibilities: Part B

02.20.1 Crew Responsibilities Policy 1

During taxi, the relief pilot should select the Hydraulic System B switch position once the checklist item is complete. If the Engine Anti-Ice is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. If the Window Heat is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The first officer will cross-check any change in the Weather Radar annunciation and advise the other pilot when conditions permit. If the Autopilot Channel B is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

NOTE: The relief pilot will cross-check any change in the Wing Anti-Ice advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Hydraulic System A indication that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed.

The Flap Position Indication status message is expected to read within the sample range of 86 to 93 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder status message that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated. During a turnaround, the Captain should confirm the Cockpit Voice Recorder advisory when operating at a sample station without ground power. If the Standby Hydraulic is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Wing Anti-Ice indication is expected to read within the sample range of 19 to 29 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure. The Bleed Air Supply selector position is expected to read within the sample range of 40 to 47 units during preflight.

- The Probe Heat selector position is expected to read within the sample range of 43 to 47 units during an extended ground delay.

- The Weather Radar selector position that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete.
- If the Standby Hydraulic is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- The relief pilot will verify any change in the Bleed Air Supply quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Window Heat indication that differs from the expected state requires both pilots to select the condition when conditions permit.
- The Traffic Advisory Display annunciation is expected to read within the sample range of 71 to 74 units during engine start.
- The Engine Anti-Ice selector position that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed.
- The Wing Anti-Ice selector position that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete.
- During parking, the First Officer should announce the Wing Anti-Ice status message if a discrepancy is observed.
- The Transponder indication is expected to read within the sample range of 69 to 74 units during taxi.

If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. During preflight, the Captain should confirm the Thrust Reverser annunciation when operating at a sample station without ground power. During cruise, the First Officer should confirm the Stall Warning selector position once the checklist item is complete.

02.20.2 Crew Responsibilities Policy 2

The Standby Hydraulic annunciation that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed. The Fire Detection Loop indication is expected to read within the sample range of 98 to 103 units during engine start. The Flight Management Computer indication that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated. The Weather Radar quantity display is expected to read within the sample range of 93 to 105 units during a turnaround.

If the Brake Temperature Monitor is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. During a turnaround, the pilot monitoring should confirm the Cargo Smoke Detection quantity display if the indication does not stabilize within the sample interval. During preflight, both pilots should verify the Nosewheel Steering advisory if a discrepancy is observed.

Condition	Sample value	Remarks
Autopilot Channel B annunciation	20 units	Monitor
Brake Temperature Monitor quantity display	96 units	Normal
Oxygen Distribution indication	9 units	Monitor
Cabin Pressure Controller switch position	54 units	Advisory only
Nosewheel Steering advisory	78 units	Monitor
Bleed Air Supply selector position	80 units	Refer to related topic
Thrust Reverser annunciation	53 units	Advisory only

The relief pilot will select any change in the Center Tank Pumps switch position and advise the other pilot if a discrepancy is observed. During preflight, the First Officer should verify the Speedbrake Handle switch position before the next phase of flight. The Stall Warning selector position is expected to read within the sample range of 36 to 46 units during a diversion. The Cabin Pressure Controller quantity display is expected to read within the sample

range of 21 to 28 units during a diversion. The relief pilot will record any change in the Autopilot Channel A selector position and advise the other pilot when conditions permit. The Window Heat status message is expected to read within the sample range of 40 to 52 units during cruise.

- The Transponder selector position is expected to read within the sample range of 45 to 49 units during descent.
- The Wing Anti-Ice indication that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated.
- The pilot flying will brief any change in the Fire Detection Loop status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The Hydraulic System B switch position that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated.
- During engine start, the pilot flying should brief the Window Heat advisory when operating at a sample station without ground power.

CAUTION: The captain will cross-check any change in the Weather Radar advisory and advise the other pilot when the associated caution light remains illuminated. During approach, the Captain should select the Traffic Advisory Display status message when the associated caution light remains illuminated.

The pilot monitoring will monitor any change in the Probe Heat selector position and advise the other pilot before the next phase of flight. The Hydraulic System B quantity display is expected to read within the sample range of 72 to 84 units during parking. If the Auxiliary Power Unit is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. During takeoff, both pilots should brief the Traffic Advisory Display switch position once the checklist item is complete. The Autopilot Channel A status message is expected to read within the sample range of 58 to 68 units during cruise. See 01.20.3 General Policy 3.

CAUTION: The Cabin Pressure Controller advisory that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power.

02.20.3 Crew Responsibilities Policy 3

During an extended ground delay, the pilot monitoring should cross-check the Oxygen Distribution annunciation once the checklist item is complete. The Autopilot Channel A selector position that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed. The Standby Instruments switch position that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

Both pilots will monitor any change in the Autopilot Channel A switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. If the Speedbrake Handle is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

- If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- The Wing Anti-Ice advisory is expected to read within the sample range of 84 to 90 units during takeoff.
- During engine start, the pilot flying should cross-check the Hydraulic System A switch position when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
-----------	--------------	---------

Ground Proximity Monitor advisory	98 units	Monitor
Landing Gear Indication indication	84 units	Refer to related topic
Autopilot Channel A advisory	10 units	Normal

02.20.4 Crew Responsibilities Policy 4

The Speedbrake Handle switch position that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. The first officer will brief any change in the Flight Management Computer selector position and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context.

During approach, both pilots should select the Auxiliary Power Unit selector position when conditions permit. During cruise, both pilots should verify the Flight Management Computer status message when operating at a sample station without ground power. If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Nosewheel Steering indication is expected to read within the sample range of 9 to 14 units during descent.

Condition	Sample value	Remarks
Bleed Air Supply switch position	66 units	Advisory only
Landing Gear Indication status message	20 units	Refer to related topic
Cabin Pressure Controller indication	19 units	Monitor

If the Hydraulic System B is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Nosewheel Steering status message is expected to read within the sample range of 89 to 100 units during takeoff. Refer to the related topic for additional sample context.

NOTE: The pilot monitoring will select any change in the Autopilot Channel B advisory and advise the other pilot when the associated caution light remains illuminated.

02.20.5 Crew Responsibilities Policy 5

Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat indication that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. The Hydraulic System B switch position that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval. During an extended ground delay, the First Officer should record the Autobrake Selector status message when the associated caution light remains illuminated. The pilot flying will select any change in the Auxiliary Power Unit advisory and advise the other pilot if a discrepancy is observed.

CAUTION: The Probe Heat selector position that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power. The Wing Anti-Ice indication is expected to read within the sample range of 67 to 71 units during descent.

The Auxiliary Power Unit indication is expected to read within the sample range of 33 to 36 units during a turnaround. If the Flap Position Indication is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Probe Heat is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, the First Officer should cross-check the Fire Detection Loop quantity display if the indication does not stabilize within the sample interval.

NOTE: The Brake Temperature Monitor indication is expected to read within the sample range of 36 to 42 units during climb. The Autopilot Channel A quantity display that differs from the expected state requires the Captain to

monitor the condition unless directed otherwise by the Sample Operations Center.

The Nosewheel Steering quantity display is expected to read within the sample range of 48 to 51 units during a maintenance-requested ground run. The Cabin Pressure Controller switch position is expected to read within the sample range of 42 to 50 units during preflight. If the Flap Position Indication is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Wing Anti-Ice annunciation is expected to read within the sample range of 20 to 26 units during a maintenance-requested ground run.

02.20.6 Crew Responsibilities Policy 6

The Stall Warning switch position that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. During approach, the Captain should verify the Flight Management Computer advisory unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed status message is expected to read within the sample range of 28 to 38 units during a maintenance-requested ground run. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

The Ground Proximity Monitor status message is expected to read within the sample range of 81 to 92 units during takeoff. The Ground Proximity Monitor advisory that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. The Landing Gear Indication annunciation is expected to read within the sample range of 44 to 48 units during a diversion. If the Hydraulic System B is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Speedbrake Handle indication is expected to read within the sample range of 8 to 19 units during an extended ground delay.

The pilot monitoring will select any change in the Standby Instruments quantity display and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The pilot monitoring will confirm any change in the Autopilot Channel B switch position and advise the other pilot before the next phase of flight.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor quantity display is expected to read within the sample range of 77 to 88 units during climb.

The Stall Warning switch position is expected to read within the sample range of 60 to 72 units during a diversion. The Hydraulic System A advisory that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. The Pack Temperature Control indication is expected to read within the sample range of 72 to 81 units during a maintenance-requested ground run. Refer to the related topic for additional sample context.

CAUTION: The relief pilot will confirm any change in the Cabin Pressure Controller quantity display and advise the other pilot when conditions permit. Refer to the related topic for additional sample context.

02.20.7 Crew Responsibilities Policy 7

The Bleed Air Supply quantity display that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. During a turnaround, the First Officer should monitor the Speedbrake Handle annunciation if a discrepancy is observed. The Window Heat switch position that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. The Center Tank Pumps selector position that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Auxiliary Power Unit indication	91 units	Normal
Flap Position Indication indication	22 units	Advisory only
Engine Anti-Ice quantity display	44 units	Refer to related topic
Hydraulic System B indication	59 units	Refer to related topic

Cockpit Voice Recorder switch position	4 units	Normal
--	---------	--------

The first officer will confirm any change in the Flight Management Computer quantity display and advise the other pilot before the next phase of flight. The Brake Temperature Monitor status message is expected to read within the sample range of 72 to 77 units during descent. The Autothrottle status message is expected to read within the sample range of 87 to 92 units during taxi. If the Pack Temperature Control is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. If the Flight Management Computer is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. If the Autopilot Channel B is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, the pilot flying should select the Cabin Pressure Controller annunciation unless directed otherwise by the Sample Operations Center. Both pilots will verify any change in the Brake Temperature Monitor quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. During an extended ground delay, the relief pilot should record the Fire Detection Loop selector position once the checklist item is complete. The Autopilot Channel B selector position is expected to read within the sample range of 8 to 13 units during cruise.

Condition	Sample value	Remarks
Primary Electrical Bus indication	9 units	Refer to related topic
Weather Radar selector position	45 units	Monitor
Cabin Pressure Controller switch position	2 units	Monitor
Autothrottle status message	47 units	Monitor
Hydraulic System B advisory	51 units	Refer to related topic

Condition	Sample value	Remarks
Weather Radar status message	70 units	Normal
Cargo Smoke Detection indication	27 units	Refer to related topic
Autopilot Channel A status message	39 units	Refer to related topic
Flight Management Computer advisory	82 units	Monitor
Window Heat status message	88 units	Monitor
Standby Instruments annunciation	74 units	Refer to related topic
Fuel Crossfeed indication	63 units	Advisory only

CAUTION: During descent, the pilot monitoring should cross-check the Cockpit Voice Recorder advisory when the associated caution light remains illuminated.

02.20.8 Crew Responsibilities Policy 8

Values in this manual are invented and must not be used for any operational purpose. Both pilots will record any change in the Bleed Air Supply switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. During takeoff, the Captain should brief the Standby Instruments status message when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Standby Instruments annunciation	74 units	Monitor
Flap Position Indication indication	77 units	Normal
Traffic Advisory Display switch position	78 units	Advisory only

Oxygen Distribution advisory	4 units	Refer to related topic
Window Heat status message	7 units	Monitor

CAUTION: The pilot flying will brief any change in the Weather Radar advisory and advise the other pilot once the checklist item is complete. The Speedbrake Handle advisory that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Traffic Advisory Display annunciation	13 units	Normal
Autopilot Channel A advisory	57 units	Normal
Weather Radar switch position	91 units	Advisory only

- The first officer will verify any change in the Oxygen Distribution switch position and advise the other pilot if a discrepancy is observed.
- The Bleed Air Supply advisory that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed.
- The Autopilot Channel B status message is expected to read within the sample range of 93 to 97 units during takeoff.
- During descent, the Captain should record the Cabin Pressure Controller indication before the next phase of flight.
- If the Fuel Crossfeed is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.
- The Primary Electrical Bus annunciation that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center.

02.30 Crew Responsibilities: Part C

02.30.1 Crew Responsibilities Policy 1

Both pilots will announce any change in the Landing Gear Indication quantity display and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. During taxi, the pilot flying should record the Bleed Air Supply selector position when the associated caution light remains illuminated.

NOTE: The Traffic Advisory Display annunciation that differs from the expected state requires the First Officer to announce the condition before the next phase of flight.

CAUTION: During landing, the pilot flying should select the Weather Radar selector position if a discrepancy is observed.

Condition	Sample value	Remarks
Traffic Advisory Display advisory	48 units	Normal
Window Heat status message	96 units	Monitor
Window Heat switch position	6 units	Advisory only
Hydraulic System B selector position	89 units	Advisory only

The Autopilot Channel A selector position is expected to read within the sample range of 46 to 57 units during descent. The pilot monitoring will select any change in the Brake Temperature Monitor advisory and advise the other pilot before the next phase of flight. The Autopilot Channel B advisory that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight. Values in this manual are invented and must not

be used for any operational purpose. The Wing Anti-Ice selector position that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Flight Management Computer status message	70 units	Normal
Cockpit Voice Recorder advisory	34 units	Normal
Flap Position Indication selector position	84 units	Monitor
Flight Management Computer status message	73 units	Monitor
Pack Temperature Control status message	66 units	Advisory only
Primary Electrical Bus advisory	49 units	Monitor

During taxi, the relief pilot should verify the Center Tank Pumps status message before the next phase of flight. During parking, the First Officer should announce the Brake Temperature Monitor status message unless directed otherwise by the Sample Operations Center. If the Engine Anti-Ice is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. During cruise, the relief pilot should monitor the Center Tank Pumps annunciation when the associated caution light remains illuminated. If the Bleed Air Supply is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

The Standby Hydraulic switch position is expected to read within the sample range of 90 to 95 units during preflight. If the Autothrottle is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Fire Detection Loop status message is expected to read within the sample range of 61 to 71 units during parking. During cruise, the pilot monitoring should confirm the Oxygen Distribution switch position if a discrepancy is observed. The Center Tank Pumps selector position that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit. See 05.30.7 Operations Center Coordination Policy 7.

02.30.2 Crew Responsibilities Policy 2

If the Wing Anti-Ice is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The first officer will brief any change in the Autothrottle indication and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will brief any change in the Center Tank Pumps quantity display and advise the other pilot when the associated caution light remains illuminated.

- If the Wing Anti-Ice is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- If the Autothrottle is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- The Fire Detection Loop annunciation is expected to read within the sample range of 48 to 51 units during landing.
- The Center Tank Pumps indication that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center.
- The Autopilot Channel B annunciation is expected to read within the sample range of 51 to 60 units during approach.

NOTE: The pilot flying will announce any change in the Hydraulic System A advisory and advise the other pilot once the checklist item is complete. If the Autopilot Channel B is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

The Fuel Crossfeed status message that differs from the expected state requires both pilots to announce the condition when conditions permit. If the Cabin Pressure Controller is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

The pilot monitoring will confirm any change in the Stall Warning advisory and advise the other pilot when the associated caution light remains illuminated. The Window Heat selector position that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

If the Fire Detection Loop is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Pack Temperature Control quantity display is expected to read within the sample range of 37 to 42 units during a turnaround. The Thrust Reverser quantity display is expected to read within the sample range of 58 to 63 units during approach. During taxi, the First Officer should brief the Pack Temperature Control annunciation unless directed otherwise by the Sample Operations Center. The pilot monitoring will record any change in the Autothrottle annunciation and advise the other pilot once the checklist item is complete. The first officer will record any change in the Oxygen Distribution switch position and advise the other pilot if the indication does not stabilize within the sample interval.

During preflight, the pilot flying should record the Weather Radar switch position when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A switch position is expected to read within the sample range of 59 to 67 units during an extended ground delay.

CAUTION: The captain will verify any change in the Ground Proximity Monitor status message and advise the other pilot before the next phase of flight.

The Autobrake Selector indication that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center. During parking, the pilot flying should select the Window Heat quantity display if the indication does not stabilize within the sample interval. If the Speedbrake Handle is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. During climb, the First Officer should record the Ground Proximity Monitor annunciation once the checklist item is complete. The Bleed Air Supply indication that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated. See 06.20.2 Ground Operations Policy 2.

02.30.3 Crew Responsibilities Policy 3

The Fuel Crossfeed advisory is expected to read within the sample range of 83 to 89 units during preflight. During landing, the pilot monitoring should brief the Flap Position Indication selector position when operating at a sample station without ground power. The Flight Management Computer selector position that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During a maintenance-requested ground run, the First Officer should brief the Pack Temperature Control annunciation when the associated caution light remains illuminated.

NOTE: If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

- The relief pilot will select any change in the Autothrottle indication and advise the other pilot before the next phase of flight.
- During climb, both pilots should record the Autopilot Channel A advisory once the checklist item is complete.
- During engine start, the relief pilot should verify the Probe Heat selector position if a discrepancy is observed.
- If the Center Tank Pumps is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

- During climb, the Captain should cross-check the Oxygen Distribution indication unless directed otherwise by the Sample Operations Center.
- The Hydraulic System A advisory is expected to read within the sample range of 30 to 37 units during approach.

NOTE: The first officer will monitor any change in the Landing Gear Indication quantity display and advise the other pilot when operating at a sample station without ground power. The Auxiliary Power Unit annunciation that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center.

02.30.4 Crew Responsibilities Policy 4

During climb, the relief pilot should verify the Pack Temperature Control advisory if a discrepancy is observed. Both pilots will confirm any change in the Cargo Smoke Detection status message and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Nosewheel Steering is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. During a turnaround, the Captain should select the Speedbrake Handle switch position if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will cross-check any change in the Hydraulic System B indication and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

The Autopilot Channel A selector position that differs from the expected state requires the Captain to record the condition once the checklist item is complete. During taxi, the First Officer should record the Traffic Advisory Display indication when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Bleed Air Supply selector position is expected to read within the sample range of 49 to 59 units during a turnaround.
- The Cockpit Voice Recorder annunciation that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The Wing Anti-Ice annunciation that differs from the expected state requires the First Officer to monitor the condition if the indication does not stabilize within the sample interval.

02.30.5 Crew Responsibilities Policy 5

The Probe Heat selector position that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. During a turnaround, the relief pilot should monitor the Cargo Smoke Detection annunciation if a discrepancy is observed. The pilot flying will verify any change in the Speedbrake Handle selector position and advise the other pilot when conditions permit. The captain will brief any change in the Oxygen Distribution advisory and advise the other pilot if the indication does not stabilize within the sample interval.

- During a diversion, both pilots should monitor the Autobrake Selector advisory unless directed otherwise by the Sample Operations Center.
- During a turnaround, the First Officer should confirm the Pack Temperature Control advisory when conditions permit.
- The Flight Management Computer indication that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Transponder is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

CAUTION: If the Stall Warning is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

During an extended ground delay, the First Officer should select the Flight Management Computer indication when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During climb, the First Officer should select the Bleed Air Supply status message when conditions permit. If the Traffic Advisory Display is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Flight Management Computer switch position that differs from the expected state requires the First Officer to cross-check the condition when conditions permit. The first officer will record any change in the Hydraulic System B indication and advise the other pilot before the next phase of flight.

The first officer will confirm any change in the Cabin Pressure Controller annunciation and advise the other pilot when operating at a sample station without ground power. The Bleed Air Supply switch position is expected to read within the sample range of 13 to 17 units during takeoff. If the Probe Heat is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Speedbrake Handle indication	54 units	Normal
Standby Instruments indication	24 units	Refer to related topic
Center Tank Pumps status message	97 units	Advisory only
Speedbrake Handle advisory	35 units	Monitor

- During a maintenance-requested ground run, both pilots should verify the Brake Temperature Monitor status message once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- The pilot flying will select any change in the Brake Temperature Monitor quantity display and advise the other pilot when conditions permit.

The wording here is placeholder content shaped like a procedure, not a procedure. The Oxygen Distribution advisory that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. During a diversion, the Captain should cross-check the Standby Instruments quantity display when operating at a sample station without ground power. Refer to the related topic for additional sample context. The pilot monitoring will verify any change in the Nosewheel Steering quantity display and advise the other pilot when the associated caution light remains illuminated.

02.30.6 Crew Responsibilities Policy 6

If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. During a diversion, the relief pilot should confirm the Fuel Crossfeed status message if a discrepancy is observed. The Pack Temperature Control advisory that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. The Standby Hydraulic indication that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated. The Autopilot Channel A annunciation is expected to read within the sample range of 16 to 24 units during parking.

- If the Thrust Reverser is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- The first officer will verify any change in the Standby Hydraulic selector position and advise the other pilot once the checklist item is complete.
- If the Brake Temperature Monitor is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

NOTE: If the Autopilot Channel B is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

- If the Cabin Pressure Controller is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.

If the Standby Instruments is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance. The captain will brief any change in the Probe Heat advisory and advise the other pilot when the associated caution light remains illuminated. The Autothrottle annunciation that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. The Primary Electrical Bus quantity display that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Cabin Pressure Controller annunciation	70 units	Advisory only
Center Tank Pumps quantity display	20 units	Refer to related topic
Flight Management Computer indication	56 units	Normal
Bleed Air Supply quantity display	51 units	Refer to related topic

02.30.7 Crew Responsibilities Policy 7

The Transponder quantity display that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed. During approach, the Captain should cross-check the Autopilot Channel B switch position once the checklist item is complete. During landing, both pilots should brief the Flight Management Computer quantity display when the associated caution light remains illuminated. The Autopilot Channel A annunciation that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, the relief pilot should announce the Autopilot Channel B annunciation before the next phase of flight.

- During parking, the pilot flying should cross-check the Probe Heat status message once the checklist item is complete.
- Refer to the related topic for additional sample context.
- The Oxygen Distribution status message that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Autobrake Selector status message that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed.
- If the Oxygen Distribution is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Window Heat quantity display	39 units	Normal
Brake Temperature Monitor selector position	24 units	Refer to related topic
Oxygen Distribution annunciation	49 units	Normal
Auxiliary Power Unit selector position	69 units	Advisory only
Autopilot Channel B switch position	82 units	Refer to related topic
Fuel Crossfeed indication	14 units	Normal
Flight Management Computer selector position	66 units	Normal

Condition	Sample value	Remarks
Autobrake Selector status message	57 units	Monitor
Landing Gear Indication annunciation	21 units	Advisory only
Hydraulic System B switch position	13 units	Monitor

During landing, the pilot flying should record the Weather Radar switch position before the next phase of flight. The Thrust Reverser indication that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. If the Wing Anti-Ice is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will confirm any change in the Traffic Advisory Display annunciation and advise the other pilot when the associated caution light remains illuminated. The Fuel Crossfeed status message is expected to read within the sample range of 73 to 82 units during approach. If the Cockpit Voice Recorder is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

- The Autopilot Channel B status message that differs from the expected state requires both pilots to monitor the condition before the next phase of flight.
- During preflight, the pilot flying should verify the Nosewheel Steering advisory unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Refer to the related topic for additional sample context.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Fire Detection Loop is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

02.30.8 Crew Responsibilities Policy 8

During an extended ground delay, both pilots should verify the Flight Management Computer switch position unless directed otherwise by the Sample Operations Center. The Stall Warning quantity display is expected to read within the sample range of 71 to 77 units during approach. If the Probe Heat is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The relief pilot will select any change in the Auxiliary Power Unit annunciation and advise the other pilot before the next phase of flight. If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 18 to 26 units during preflight.

CAUTION: The Brake Temperature Monitor selector position that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. Both pilots will verify any change in the Cockpit Voice Recorder switch position and advise the other pilot when operating at a sample station without ground power.

The pilot monitoring will verify any change in the Center Tank Pumps annunciation and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The Transponder advisory that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated.

The relief pilot will record any change in the Transponder indication and advise the other pilot when the associated caution light remains illuminated. During engine start, both pilots should select the Autobrake Selector status message when operating at a sample station without ground power. The pilot monitoring will announce any change in the Hydraulic System B indication and advise the other pilot if a discrepancy is observed. During landing, the pilot monitoring should announce the Landing Gear Indication annunciation if a discrepancy is observed. During taxi, the First Officer should cross-check the Stall Warning annunciation if the indication does not stabilize within the sample interval.

The Cockpit Voice Recorder switch position is expected to read within the sample range of 46 to 53 units during takeoff. During descent, the relief pilot should verify the Cockpit Voice Recorder annunciation when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. See 11.20.3 Communications Policy 3.

NOTE: The Autopilot Channel B advisory is expected to read within the sample range of 76 to 82 units during engine start. During taxi, the First Officer should announce the Autopilot Channel A selector position when operating at a sample station without ground power.

Chapter 03 Crew Qualification Records

03.10 Crew Qualification Records: Part A

03.10.1 Crew Qualification Records Policy 1

Both pilots will verify any change in the Fire Detection Loop selector position and advise the other pilot when the associated caution light remains illuminated. During engine start, both pilots should cross-check the Autobrake Selector selector position if a discrepancy is observed. The Cargo Smoke Detection selector position that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. During cruise, the pilot monitoring should verify the Weather Radar selector position unless directed otherwise by the Sample Operations Center.

The Stall Warning indication is expected to read within the sample range of 49 to 56 units during approach. The captain will monitor any change in the Center Tank Pumps indication and advise the other pilot when conditions permit. If the Nosewheel Steering is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. Both pilots will cross-check any change in the Fuel Crossfeed annunciation and advise the other pilot before the next phase of flight.

During descent, the First Officer should record the Standby Hydraulic annunciation if a discrepancy is observed. If the Probe Heat is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure.

The relief pilot will cross-check any change in the Pack Temperature Control advisory and advise the other pilot before the next phase of flight. The pilot monitoring will announce any change in the Traffic Advisory Display indication and advise the other pilot once the checklist item is complete. If the Window Heat is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. See 15.20.3 Reports and Records Policy 3.

- The Primary Electrical Bus quantity display that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed.
- The Speedbrake Handle indication is expected to read within the sample range of 83 to 87 units during a turnaround.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During climb, the First Officer should select the Cockpit Voice Recorder advisory once the checklist item is complete.
- The Center Tank Pumps selector position is expected to read within the sample range of 86 to 98 units during climb.

03.10.2 Crew Qualification Records Policy 2

The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps status message is expected to read within the sample range of 46 to 54 units during descent. The Oxygen Distribution status message that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Autopilot Channel A quantity display	36 units	Refer to related topic
Traffic Advisory Display quantity display	95 units	Refer to related topic
Oxygen Distribution indication	23 units	Refer to related topic

Engine Anti-Ice advisory	56 units	Monitor
Thrust Reverser status message	65 units	Advisory only
Window Heat switch position	24 units	Normal
Transponder quantity display	62 units	Advisory only

CAUTION: The Cockpit Voice Recorder switch position is expected to read within the sample range of 31 to 39 units during a diversion.

CAUTION: The Cabin Pressure Controller advisory that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval. The pilot flying will verify any change in the Bleed Air Supply switch position and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Traffic Advisory Display annunciation	10 units	Monitor
Center Tank Pumps advisory	6 units	Normal
Cockpit Voice Recorder selector position	92 units	Normal

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Landing Gear Indication status message	73 units	Advisory only
Oxygen Distribution quantity display	31 units	Monitor
Flight Management Computer annunciation	23 units	Refer to related topic
Autothrottle indication	2 units	Monitor
Window Heat quantity display	63 units	Refer to related topic
Traffic Advisory Display status message	99 units	Refer to related topic
Primary Electrical Bus indication	17 units	Normal

Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. If the Transponder is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

03.10.3 Crew Qualification Records Policy 3

The Cockpit Voice Recorder annunciation that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. During climb, the pilot monitoring should select the Autothrottle annunciation when conditions permit. The Transponder annunciation is expected to read within the sample range of 40 to 52 units during parking. During landing, the First Officer should verify the Hydraulic System A quantity display when operating at a sample station without ground power.

The Stall Warning selector position is expected to read within the sample range of 90 to 100 units during an extended ground delay. The Oxygen Distribution selector position is expected to read within the sample range of 63 to 68 units during parking. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Oxygen Distribution switch position	41 units	Advisory only
Cargo Smoke Detection quantity display	45 units	Refer to related topic
Fuel Crossfeed advisory	58 units	Refer to related topic

Condition	Sample value	Remarks
-----------	--------------	---------

Brake Temperature Monitor status message	47 units	Refer to related topic
Wing Anti-Ice annunciation	13 units	Advisory only
Speedbrake Handle indication	36 units	Advisory only
Window Heat switch position	14 units	Normal
Pack Temperature Control indication	21 units	Advisory only
Standby Instruments status message	11 units	Normal

Condition	Sample value	Remarks
Window Heat selector position	28 units	Normal
Fuel Crossfeed selector position	88 units	Refer to related topic
Fuel Crossfeed selector position	77 units	Monitor
Weather Radar advisory	89 units	Monitor
Transponder annunciation	41 units	Normal
Hydraulic System A annunciation	2 units	Normal

Condition	Sample value	Remarks
Fire Detection Loop selector position	18 units	Advisory only
Hydraulic System A advisory	7 units	Normal
Standby Hydraulic annunciation	84 units	Refer to related topic
Standby Instruments switch position	55 units	Advisory only
Traffic Advisory Display switch position	58 units	Normal
Pack Temperature Control switch position	44 units	Normal
Cockpit Voice Recorder status message	7 units	Monitor

During takeoff, the pilot monitoring should confirm the Transponder indication when conditions permit. The Stall Warning advisory is expected to read within the sample range of 4 to 9 units during climb. If the Thrust Reverser is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

03.10.4 Crew Qualification Records Policy 4

If the Pack Temperature Control is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Oxygen Distribution quantity display that differs from the expected state requires both pilots to verify the condition before the next phase of flight. If the Ground Proximity Monitor is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The Center Tank Pumps switch position that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. During an extended ground delay, the pilot monitoring should record the Thrust Reverser selector position unless directed otherwise by the Sample Operations Center.

- The Bleed Air Supply selector position is expected to read within the sample range of 5 to 14 units during taxi.
- If the Pack Temperature Control is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- If the Cargo Smoke Detection is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.
- During landing, the First Officer should verify the Standby Hydraulic indication if a discrepancy is observed.

The Wing Anti-Ice advisory is expected to read within the sample range of 82 to 85 units during preflight. The relief pilot will brief any change in the Transponder switch position and advise the other pilot unless directed otherwise by

the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

The Flight Management Computer status message is expected to read within the sample range of 63 to 75 units during taxi. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will announce any change in the Landing Gear Indication annunciation and advise the other pilot when conditions permit. During descent, the pilot monitoring should verify the Speedbrake Handle advisory unless directed otherwise by the Sample Operations Center.

During a diversion, the pilot monitoring should brief the Nosewheel Steering indication when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will monitor any change in the Window Heat indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Weather Radar advisory that differs from the expected state requires both pilots to brief the condition before the next phase of flight.

03.10.5 Crew Qualification Records Policy 5

The first officer will cross-check any change in the Standby Instruments status message and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The captain will select any change in the Cabin Pressure Controller annunciation and advise the other pilot when conditions permit. The Probe Heat status message is expected to read within the sample range of 24 to 27 units during an extended ground delay. The pilot flying will brief any change in the Bleed Air Supply annunciation and advise the other pilot when the associated caution light remains illuminated. The Speedbrake Handle indication is expected to read within the sample range of 20 to 29 units during descent.

If the Thrust Reverser is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. Both pilots will confirm any change in the Hydraulic System A switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Stall Warning advisory that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval. The Oxygen Distribution annunciation that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Flap Position Indication quantity display	48 units	Monitor
Center Tank Pumps switch position	21 units	Monitor
Flight Management Computer quantity display	15 units	Monitor
Pack Temperature Control status message	62 units	Monitor

CAUTION: The relief pilot will select any change in the Stall Warning selector position and advise the other pilot before the next phase of flight. The pilot flying will brief any change in the Weather Radar annunciation and advise the other pilot once the checklist item is complete.

The Standby Instruments selector position is expected to read within the sample range of 70 to 78 units during a maintenance-requested ground run. The Cabin Pressure Controller indication that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. The Fire Detection Loop selector position is expected to read within the sample range of 65 to 75 units during takeoff. During taxi, the pilot monitoring should monitor the Engine Anti-Ice quantity display when conditions permit. Values in this manual are invented and must not be used for any operational purpose. If the Bleed Air Supply is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

If the Probe Heat is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Wing Anti-Ice switch position is expected to read within the sample range of 41 to 52 units during a turnaround. The Weather Radar selector position is expected to read within the sample range of 94 to 102 units during an extended ground delay. If the Probe Heat is inoperative, continue cruise

only after the pilot monitoring has reviewed the associated sample guidance. The Engine Anti-Ice status message that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed.

NOTE: The Cockpit Voice Recorder switch position is expected to read within the sample range of 22 to 32 units during taxi.

- If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.
- The Probe Heat selector position is expected to read within the sample range of 49 to 60 units during engine start.
- If the Autothrottle is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

03.10.6 Crew Qualification Records Policy 6

If the Flap Position Indication is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will verify any change in the Stall Warning indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Center Tank Pumps advisory is expected to read within the sample range of 37 to 47 units during preflight. Values in this manual are invented and must not be used for any operational purpose. If the Weather Radar is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

CAUTION: During parking, both pilots should cross-check the Pack Temperature Control advisory before the next phase of flight.

Condition	Sample value	Remarks
Auxiliary Power Unit advisory	93 units	Advisory only
Speedbrake Handle status message	23 units	Normal
Autobrake Selector quantity display	6 units	Refer to related topic
Standby Instruments selector position	79 units	Normal
Autobrake Selector advisory	65 units	Refer to related topic
Autopilot Channel A switch position	12 units	Advisory only
Autopilot Channel B status message	76 units	Monitor

Refer to the related topic for additional sample context. The Stall Warning quantity display that differs from the expected state requires the Captain to record the condition once the checklist item is complete. If the Speedbrake Handle is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The relief pilot will verify any change in the Cockpit Voice Recorder advisory and advise the other pilot if a discrepancy is observed. The first officer will record any change in the Standby Hydraulic annunciation and advise the other pilot if a discrepancy is observed.

The Window Heat annunciation that differs from the expected state requires both pilots to announce the condition once the checklist item is complete. The relief pilot will confirm any change in the Engine Anti-Ice status message and advise the other pilot if a discrepancy is observed. If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B status message that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center. The Pack Temperature Control annunciation is expected to read within the sample range of 7 to 14 units during an extended ground delay.

Condition	Sample value	Remarks
Center Tank Pumps advisory	91 units	Refer to related topic

Traffic Advisory Display advisory	55 units	Advisory only
Transponder advisory	83 units	Refer to related topic
Autothrottle status message	73 units	Advisory only
Stall Warning switch position	42 units	Refer to related topic
Window Heat quantity display	3 units	Refer to related topic

CAUTION: The Window Heat quantity display that differs from the expected state requires the relief pilot to monitor the condition before the next phase of flight. The Autobrake Selector selector position that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval.

If the Transponder is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The pilot flying will record any change in the Autobrake Selector indication and advise the other pilot when conditions permit. The Hydraulic System A status message is expected to read within the sample range of 60 to 63 units during landing. During preflight, the Captain should confirm the Engine Anti-Ice status message when operating at a sample station without ground power. Both pilots will record any change in the Thrust Reverser status message and advise the other pilot if a discrepancy is observed. During landing, the First Officer should confirm the Primary Electrical Bus annunciation once the checklist item is complete.

NOTE: If the Fire Detection Loop is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

03.10.7 Crew Qualification Records Policy 7

The Ground Proximity Monitor status message is expected to read within the sample range of 80 to 91 units during cruise. The first officer will verify any change in the Probe Heat indication and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Thrust Reverser switch position	9 units	Monitor
Nosewheel Steering quantity display	40 units	Advisory only
Cockpit Voice Recorder switch position	88 units	Normal
Probe Heat quantity display	55 units	Refer to related topic
Hydraulic System B advisory	66 units	Refer to related topic

During an extended ground delay, the Captain should monitor the Standby Instruments advisory before the next phase of flight. The Fire Detection Loop switch position that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will verify any change in the Bleed Air Supply status message and advise the other pilot unless directed otherwise by the Sample Operations Center. During parking, the pilot monitoring should select the Hydraulic System A status message if the indication does not stabilize within the sample interval. If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

If the Standby Instruments is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Traffic Advisory Display annunciation is expected to read within the sample range of 58 to 70 units during a maintenance-requested ground run. Values in this manual are invented and must not be used for any operational purpose. See 07.20.8 Departure Policy 8.

NOTE: The Window Heat advisory is expected to read within the sample range of 19 to 30 units during approach.

03.10.8 Crew Qualification Records Policy 8

The Flap Position Indication annunciation that differs from the expected state requires both pilots to verify the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Brake Temperature Monitor annunciation is expected to read within the sample range of 36 to 44 units during an extended ground delay. The pilot flying will confirm any change in the Landing Gear Indication indication and advise the other pilot when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. The Speedbrake Handle quantity display is expected to read within the sample range of 78 to 82 units during landing. The captain will record any change in the Engine Anti-Ice advisory and advise the other pilot before the next phase of flight. The Thrust Reverser status message is expected to read within the sample range of 44 to 55 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Cargo Smoke Detection advisory that differs from the expected state requires the pilot monitoring to monitor the condition when conditions permit.
- The Fuel Crossfeed status message is expected to read within the sample range of 67 to 70 units during climb.
- The captain will cross-check any change in the Fire Detection Loop indication and advise the other pilot when operating at a sample station without ground power.

The Cabin Pressure Controller indication is expected to read within the sample range of 49 to 58 units during an extended ground delay. If the Flight Management Computer is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will brief any change in the Bleed Air Supply advisory and advise the other pilot once the checklist item is complete.

NOTE: The first officer will announce any change in the Brake Temperature Monitor advisory and advise the other pilot before the next phase of flight.

The Hydraulic System B annunciation is expected to read within the sample range of 64 to 68 units during takeoff. The Hydraulic System A selector position is expected to read within the sample range of 45 to 53 units during engine start. The Cargo Smoke Detection indication is expected to read within the sample range of 57 to 67 units during parking. Refer to the related topic for additional sample context. The Stall Warning switch position that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete.

CAUTION: During takeoff, both pilots should confirm the Engine Anti-Ice indication when operating at a sample station without ground power.

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Cargo Smoke Detection quantity display that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. If the Flight Management Computer is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Fuel Crossfeed advisory that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit.

- The Stall Warning switch position that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power.
- During parking, the First Officer should cross-check the Flap Position Indication status message if the indication does not stabilize within the sample interval.
- The pilot flying will record any change in the Brake Temperature Monitor quantity display and advise the other pilot when conditions permit.

03.20 Crew Qualification Records: Part B

03.20.1 Crew Qualification Records Policy 1

If the Flight Management Computer is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Stall Warning advisory that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight. The pilot monitoring will verify any change in the Stall Warning annunciation and advise the other pilot when conditions permit. During a diversion, the pilot monitoring should brief the Autothrottle indication when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: Values in this manual are invented and must not be used for any operational purpose. If the Autothrottle is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

CAUTION: The Autothrottle annunciation is expected to read within the sample range of 45 to 55 units during taxi.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Flight Management Computer switch position is expected to read within the sample range of 55 to 61 units during climb.
- The Wing Anti-Ice switch position that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight.
- The Auxiliary Power Unit selector position is expected to read within the sample range of 84 to 91 units during an extended ground delay.
- The Probe Heat switch position is expected to read within the sample range of 4 to 16 units during a maintenance-requested ground run.
- If the Flight Management Computer is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- If the Speedbrake Handle is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Window Heat annunciation	47 units	Monitor
Probe Heat switch position	72 units	Advisory only
Stall Warning selector position	13 units	Normal
Thrust Reverser annunciation	66 units	Monitor
Hydraulic System A status message	28 units	Monitor

During approach, the pilot monitoring should verify the Nosewheel Steering indication when conditions permit. If the Wing Anti-Ice is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The captain will announce any change in the Ground Proximity Monitor selector position and advise the other pilot when the associated caution light remains illuminated. The Autopilot Channel A indication that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete.

If the Fuel Crossfeed is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Hydraulic System A switch position that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power. During approach, the Captain should select the Flap Position Indication status message once the checklist item is complete. Both pilots will monitor any change in the Brake Temperature Monitor advisory and advise the other pilot when conditions permit.

NOTE: During taxi, the First Officer should select the Cockpit Voice Recorder switch position when conditions permit. The Nosewheel Steering switch position that differs from the expected state requires the Captain to select the condition before the next phase of flight.

03.20.2 Crew Qualification Records Policy 2

The Speedbrake Handle switch position that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed. During cruise, the Captain should announce the Flap Position Indication quantity display before the next phase of flight. During preflight, the pilot monitoring should monitor the Flight Management Computer status message when the associated caution light remains illuminated.

- The Traffic Advisory Display quantity display is expected to read within the sample range of 11 to 15 units during taxi.
- If the Fire Detection Loop is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.
- Both pilots will confirm any change in the Cargo Smoke Detection indication and advise the other pilot when the associated caution light remains illuminated.
- The Standby Instruments indication is expected to read within the sample range of 44 to 51 units during preflight.
- The wording here is placeholder content shaped like a procedure, not a procedure.

The Autobrake Selector quantity display that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval. If the Center Tank Pumps is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Center Tank Pumps switch position that differs from the expected state requires the Captain to brief the condition if a discrepancy is observed. Refer to the related topic for additional sample context. If the Autopilot Channel A is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.

- If the Weather Radar is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.
- During climb, the pilot flying should cross-check the Standby Instruments selector position when the associated caution light remains illuminated.
- During engine start, both pilots should announce the Cargo Smoke Detection advisory if the indication does not stabilize within the sample interval.
- The Auxiliary Power Unit quantity display is expected to read within the sample range of 76 to 84 units during a diversion.
- Values in this manual are invented and must not be used for any operational purpose.

If the Fire Detection Loop is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Traffic Advisory Display advisory is expected to read within the sample range of 45 to 55 units during a maintenance-requested ground run. During takeoff, the relief pilot should cross-check the Hydraulic System A quantity display unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller indication is expected to read within the sample range of 20 to 28 units during engine start.

03.20.3 Crew Qualification Records Policy 3

If the Wing Anti-Ice is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the First Officer should brief the Standby Instruments annunciation once the checklist item is complete. The Primary Electrical Bus annunciation is expected to read within the sample range of 6 to 15 units during takeoff. Values in this manual are invented and must not be used for any operational purpose. If the Weather Radar is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

NOTE: Refer to the related topic for additional sample context. The Autopilot Channel B switch position that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight.

CAUTION: If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During preflight, the Captain should verify the Traffic Advisory Display status message unless directed otherwise by the Sample Operations Center.

The Auxiliary Power Unit advisory is expected to read within the sample range of 28 to 36 units during approach. During preflight, the pilot monitoring should confirm the Cabin Pressure Controller status message before the next phase of flight. The Autobrake Selector switch position that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power.

The Transponder quantity display is expected to read within the sample range of 91 to 100 units during cruise. The Autobrake Selector quantity display that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Wing Anti-Ice status message is expected to read within the sample range of 30 to 40 units during cruise.

- The Standby Instruments indication is expected to read within the sample range of 25 to 31 units during a diversion.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During parking, the Captain should announce the Cabin Pressure Controller annunciation once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- The Auxiliary Power Unit indication is expected to read within the sample range of 59 to 62 units during engine start.

Condition	Sample value	Remarks
Autothrottle status message	66 units	Normal
Hydraulic System A advisory	84 units	Advisory only
Oxygen Distribution selector position	14 units	Monitor
Flap Position Indication quantity display	20 units	Monitor
Standby Hydraulic quantity display	35 units	Refer to related topic
Speedbrake Handle status message	82 units	Advisory only

- The first officer will verify any change in the Oxygen Distribution advisory and advise the other pilot before the next phase of flight.
- The Standby Hydraulic advisory that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.
- The Ground Proximity Monitor selector position that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated.
- The captain will verify any change in the Engine Anti-Ice annunciation and advise the other pilot when operating at a sample station without ground power.

03.20.4 Crew Qualification Records Policy 4

Refer to the related topic for additional sample context. The Standby Instruments advisory is expected to read within the sample range of 30 to 33 units during descent. The first officer will brief any change in the Wing Anti-Ice indication and advise the other pilot once the checklist item is complete. The Brake Temperature Monitor advisory is expected

to read within the sample range of 72 to 80 units during an extended ground delay. During an extended ground delay, the pilot monitoring should cross-check the Oxygen Distribution status message if the indication does not stabilize within the sample interval.

Both pilots will monitor any change in the Bleed Air Supply status message and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. If the Traffic Advisory Display is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Pack Temperature Control advisory	72 units	Monitor
Fuel Crossfeed selector position	43 units	Monitor
Window Heat quantity display	91 units	Refer to related topic
Autopilot Channel A selector position	26 units	Refer to related topic
Landing Gear Indication switch position	1 units	Normal
Probe Heat status message	83 units	Monitor

Condition	Sample value	Remarks
Autopilot Channel A quantity display	98 units	Refer to related topic
Nosewheel Steering status message	79 units	Normal
Speedbrake Handle quantity display	6 units	Advisory only
Fuel Crossfeed quantity display	64 units	Monitor
Engine Anti-Ice annunciation	69 units	Monitor
Fuel Crossfeed indication	4 units	Refer to related topic

CAUTION: If the Bleed Air Supply is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

- During landing, the First Officer should cross-check the Cargo Smoke Detection indication before the next phase of flight.
- The Autobrake Selector quantity display that differs from the expected state requires the First Officer to select the condition when conditions permit.
- The Hydraulic System B switch position that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power.
- If the Autobrake Selector is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.
- The Fire Detection Loop switch position that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete.
- The pilot flying will monitor any change in the Standby Hydraulic quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Autopilot Channel B switch position	51 units	Normal
Traffic Advisory Display selector position	85 units	Normal
Primary Electrical Bus annunciation	34 units	Refer to related topic
Primary Electrical Bus switch position	1 units	Refer to related topic
Speedbrake Handle status message	39 units	Normal

Hydraulic System B selector position	94 units	Refer to related topic
Cabin Pressure Controller selector position	10 units	Monitor

NOTE: If the Hydraulic System B is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

- During approach, the pilot monitoring should announce the Autopilot Channel B annunciation once the checklist item is complete.
- The captain will confirm any change in the Standby Instruments indication and advise the other pilot if a discrepancy is observed.
- The Autothrottle advisory that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete.
- The Transponder advisory is expected to read within the sample range of 63 to 69 units during a diversion.

03.20.5 Crew Qualification Records Policy 5

Both pilots will cross-check any change in the Window Heat annunciation and advise the other pilot once the checklist item is complete. If the Autobrake Selector is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. Both pilots will record any change in the Hydraulic System A selector position and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	84 units	Normal
Cargo Smoke Detection advisory	69 units	Normal
Autobrake Selector quantity display	94 units	Refer to related topic
Standby Instruments quantity display	28 units	Advisory only
Speedbrake Handle status message	73 units	Normal
Probe Heat switch position	36 units	Monitor

CAUTION: If the Wing Anti-Ice is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Weather Radar advisory	93 units	Advisory only
Oxygen Distribution advisory	54 units	Normal
Engine Anti-Ice switch position	48 units	Advisory only
Auxiliary Power Unit advisory	2 units	Refer to related topic
Ground Proximity Monitor indication	55 units	Monitor
Standby Instruments advisory	4 units	Advisory only
Oxygen Distribution status message	24 units	Refer to related topic

- The Autopilot Channel A selector position that differs from the expected state requires the Captain to verify the condition before the next phase of flight.
- The first officer will select any change in the Transponder indication and advise the other pilot when operating at a sample station without ground power.
- If the Flap Position Indication is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

During climb, the First Officer should brief the Cabin Pressure Controller annunciation if a discrepancy is observed. The Hydraulic System A advisory that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will confirm any change in the Stall Warning switch position and advise the other pilot when the associated caution light remains illuminated. The relief pilot will verify any change in the Autopilot Channel B selector position and advise the other pilot if a discrepancy is observed.

During landing, both pilots should announce the Pack Temperature Control advisory if a discrepancy is observed. During a turnaround, the Captain should confirm the Stall Warning quantity display when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The captain will confirm any change in the Window Heat selector position and advise the other pilot once the checklist item is complete. See 10.20.8 Adverse Weather Policy Policy 8.

CAUTION: Values in this manual are invented and must not be used for any operational purpose. If the Fuel Crossfeed is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

CAUTION: The pilot monitoring will select any change in the Flap Position Indication quantity display and advise the other pilot when the associated caution light remains illuminated. The Landing Gear Indication status message is expected to read within the sample range of 15 to 26 units during cruise.

03.20.6 Crew Qualification Records Policy 6

The Brake Temperature Monitor status message that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. If the Standby Instruments is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. During takeoff, the relief pilot should record the Probe Heat indication if the indication does not stabilize within the sample interval. If the Standby Hydraulic is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

- During descent, the First Officer should announce the Fuel Crossfeed switch position once the checklist item is complete.
- If the Cockpit Voice Recorder is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- Refer to the related topic for additional sample context.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Both pilots will record any change in the Speedbrake Handle indication and advise the other pilot if a discrepancy is observed.

The captain will cross-check any change in the Oxygen Distribution quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Ground Proximity Monitor selector position that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed. If the Brake Temperature Monitor is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will brief any change in the Landing Gear Indication switch position and advise the other pilot when the associated caution light remains illuminated. The relief pilot will select any change in the Brake Temperature Monitor selector position and advise the other pilot when conditions permit. The Fuel Crossfeed indication that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
-----------	--------------	---------

Flap Position Indication annunciation	16 units	Refer to related topic
Speedbrake Handle quantity display	5 units	Normal
Ground Proximity Monitor quantity display	87 units	Advisory only
Probe Heat advisory	94 units	Normal
Ground Proximity Monitor switch position	7 units	Refer to related topic
Transponder switch position	2 units	Normal
Stall Warning selector position	90 units	Refer to related topic

The Flap Position Indication annunciation that differs from the expected state requires the Captain to select the condition if a discrepancy is observed. The Weather Radar switch position is expected to read within the sample range of 57 to 69 units during parking. The Autobrake Selector advisory is expected to read within the sample range of 88 to 91 units during climb. If the Wing Anti-Ice is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. If the Transponder is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

If the Probe Heat is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Ground Proximity Monitor switch position is expected to read within the sample range of 67 to 72 units during a diversion. If the Hydraulic System A is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. During approach, the Captain should announce the Speedbrake Handle switch position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Cargo Smoke Detection indication	25 units	Normal
Standby Hydraulic quantity display	61 units	Normal
Fuel Crossfeed annunciation	42 units	Monitor
Traffic Advisory Display selector position	34 units	Advisory only
Engine Anti-Ice annunciation	56 units	Refer to related topic

03.20.7 Crew Qualification Records Policy 7

The Primary Electrical Bus annunciation that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. The captain will verify any change in the Fuel Crossfeed advisory and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Flight Management Computer status message is expected to read within the sample range of 34 to 46 units during cruise.

NOTE: The Standby Instruments quantity display is expected to read within the sample range of 7 to 13 units during descent. During descent, the relief pilot should cross-check the Autopilot Channel A switch position when the associated caution light remains illuminated.

The Wing Anti-Ice quantity display is expected to read within the sample range of 47 to 50 units during engine start. During a diversion, the First Officer should confirm the Cargo Smoke Detection advisory once the checklist item is complete. The captain will cross-check any change in the Standby Hydraulic quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: If the Flap Position Indication is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Stall Warning selector position that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. This text is fictional and exists only to give the prototype

realistic volume and structure.

The Auxiliary Power Unit advisory is expected to read within the sample range of 24 to 35 units during parking. If the Bleed Air Supply is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The Fuel Crossfeed status message that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power.

CAUTION: The pilot monitoring will brief any change in the Wing Anti-Ice indication and advise the other pilot when operating at a sample station without ground power.

The Fire Detection Loop annunciation that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete. During takeoff, the pilot flying should brief the Transponder quantity display once the checklist item is complete. If the Primary Electrical Bus is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Flight Management Computer status message is expected to read within the sample range of 16 to 19 units during an extended ground delay.

- Values in this manual are invented and must not be used for any operational purpose.
- During descent, the First Officer should verify the Engine Anti-Ice quantity display if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.

03.20.8 Crew Qualification Records Policy 8

During takeoff, both pilots should monitor the Primary Electrical Bus annunciation when conditions permit. Values in this manual are invented and must not be used for any operational purpose. If the Flight Management Computer is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

The Bleed Air Supply selector position that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete. If the Center Tank Pumps is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Bleed Air Supply switch position that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. The pilot monitoring will cross-check any change in the Cabin Pressure Controller advisory and advise the other pilot once the checklist item is complete.

- The pilot flying will cross-check any change in the Cargo Smoke Detection switch position and advise the other pilot if a discrepancy is observed.
- If the Standby Hydraulic is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- If the Stall Warning is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- During a diversion, the pilot monitoring should select the Stall Warning switch position when conditions permit.
- The relief pilot will brief any change in the Primary Electrical Bus indication and advise the other pilot before the next phase of flight.

CAUTION: During landing, the relief pilot should confirm the Flight Management Computer advisory when conditions permit. The captain will announce any change in the Nosewheel Steering switch position and advise the other pilot when operating at a sample station without ground power.

If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. During descent, the relief pilot should confirm the Traffic Advisory Display switch position once the checklist item is complete. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The wording here is

placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

03.30 Crew Qualification Records: Part C

03.30.1 Crew Qualification Records Policy 1

During approach, both pilots should cross-check the Pack Temperature Control switch position before the next phase of flight. Both pilots will announce any change in the Autopilot Channel A annunciation and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle quantity display is expected to read within the sample range of 3 to 14 units during a maintenance-requested ground run. The Engine Anti-Ice indication is expected to read within the sample range of 48 to 53 units during an extended ground delay.

During approach, the pilot monitoring should cross-check the Bleed Air Supply selector position unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection indication that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval. If the Ground Proximity Monitor is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. If the Traffic Advisory Display is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Standby Instruments switch position and advise the other pilot once the checklist item is complete. The Transponder selector position is expected to read within the sample range of 16 to 25 units during cruise. If the Ground Proximity Monitor is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

The Stall Warning selector position is expected to read within the sample range of 98 to 103 units during landing. The Oxygen Distribution annunciation that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. During landing, the pilot monitoring should monitor the Traffic Advisory Display status message when conditions permit.

During climb, the pilot monitoring should announce the Bleed Air Supply selector position before the next phase of flight. Both pilots will monitor any change in the Probe Heat quantity display and advise the other pilot if a discrepancy is observed. If the Traffic Advisory Display is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The pilot monitoring will brief any change in the Stall Warning indication and advise the other pilot when operating at a sample station without ground power.

- If the Autopilot Channel A is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.
- The Standby Hydraulic selector position that differs from the expected state requires both pilots to monitor the condition when conditions permit.
- Both pilots will record any change in the Hydraulic System B advisory and advise the other pilot when the associated caution light remains illuminated.
- Both pilots will select any change in the Weather Radar selector position and advise the other pilot if the indication does not stabilize within the sample interval.

03.30.2 Crew Qualification Records Policy 2

If the Oxygen Distribution is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The relief pilot will monitor any change in the Speedbrake Handle quantity display and advise the other pilot once the checklist item is complete. The Fuel Crossfeed indication is expected to

read within the sample range of 8 to 17 units during engine start.

During descent, both pilots should brief the Center Tank Pumps indication when the associated caution light remains illuminated. During preflight, the pilot monitoring should monitor the Brake Temperature Monitor quantity display when operating at a sample station without ground power. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Cabin Pressure Controller indication that differs from the expected state requires the pilot monitoring to select the condition when conditions permit.

Condition	Sample value	Remarks
Standby Instruments annunciation	38 units	Refer to related topic
Thrust Reverser advisory	5 units	Refer to related topic
Ground Proximity Monitor selector position	29 units	Normal
Weather Radar advisory	33 units	Refer to related topic
Cargo Smoke Detection selector position	88 units	Advisory only
Center Tank Pumps advisory	12 units	Advisory only

- Values in this manual are invented and must not be used for any operational purpose.
- The Fire Detection Loop status message is expected to read within the sample range of 30 to 33 units during parking.
- The Autopilot Channel B annunciation is expected to read within the sample range of 43 to 47 units during cruise.

If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During a diversion, the pilot flying should select the Standby Hydraulic annunciation unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. If the Autopilot Channel A is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

CAUTION: The Autobrake Selector selector position that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed.

If the Nosewheel Steering is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The Ground Proximity Monitor switch position that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. If the Center Tank Pumps is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. During approach, the relief pilot should confirm the Hydraulic System A status message when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

The pilot flying will cross-check any change in the Thrust Reverser switch position and advise the other pilot once the checklist item is complete. The Cargo Smoke Detection advisory that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated. During approach, the pilot flying should brief the Transponder indication if a discrepancy is observed. The Autopilot Channel B advisory is expected to read within the sample range of 91 to 98 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

03.30.3 Crew Qualification Records Policy 3

Refer to the related topic for additional sample context. The Hydraulic System A indication is expected to read within the sample range of 48 to 60 units during a maintenance-requested ground run. The Window Heat switch position is expected to read within the sample range of 8 to 13 units during descent. The relief pilot will announce any change in the Thrust Reverser selector position and advise the other pilot once the checklist item is complete. Both pilots will announce any change in the Cabin Pressure Controller switch position and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Autothrottle annunciation	85 units	Refer to related topic
Transponder annunciation	95 units	Advisory only
Cabin Pressure Controller indication	12 units	Refer to related topic
Autopilot Channel B advisory	79 units	Monitor

If the Ground Proximity Monitor is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The Oxygen Distribution advisory that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center. The relief pilot will announce any change in the Probe Heat selector position and advise the other pilot when conditions permit. If the Autobrake Selector is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. During a diversion, the relief pilot should brief the Flap Position Indication advisory before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Speedbrake Handle annunciation	5 units	Normal
Hydraulic System A switch position	4 units	Monitor
Standby Hydraulic indication	12 units	Monitor
Flight Management Computer annunciation	11 units	Normal
Stall Warning indication	35 units	Monitor
Autobrake Selector advisory	58 units	Monitor

NOTE: The Engine Anti-Ice indication that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power.

NOTE: If the Autopilot Channel B is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

The Cargo Smoke Detection quantity display is expected to read within the sample range of 75 to 86 units during landing. The Flap Position Indication quantity display that differs from the expected state requires the pilot monitoring to record the condition when the associated caution light remains illuminated. Both pilots will select any change in the Fire Detection Loop status message and advise the other pilot when conditions permit.

Both pilots will cross-check any change in the Ground Proximity Monitor selector position and advise the other pilot when the associated caution light remains illuminated. The Oxygen Distribution advisory is expected to read within the sample range of 14 to 23 units during parking. During engine start, the First Officer should record the Brake Temperature Monitor advisory once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Autopilot Channel A annunciation	14 units	Advisory only
Autopilot Channel A indication	1 units	Refer to related topic
Weather Radar advisory	14 units	Normal
Cockpit Voice Recorder status message	29 units	Monitor
Engine Anti-Ice switch position	3 units	Normal
Auxiliary Power Unit status message	14 units	Monitor

03.30.4 Crew Qualification Records Policy 4

The Flap Position Indication advisory is expected to read within the sample range of 45 to 48 units during approach. The relief pilot will announce any change in the Brake Temperature Monitor advisory and advise the other pilot when operating at a sample station without ground power. The Autothrottle indication is expected to read within the sample range of 62 to 66 units during preflight. The Weather Radar advisory that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. The Oxygen Distribution selector position is expected to read within the sample range of 41 to 45 units during preflight. If the Autobrake Selector is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

CAUTION: The Autothrottle switch position is expected to read within the sample range of 94 to 102 units during cruise.

The Cabin Pressure Controller annunciation that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 73 to 84 units during a turnaround. If the Window Heat is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Autobrake Selector annunciation is expected to read within the sample range of 20 to 23 units during parking.

The relief pilot will cross-check any change in the Traffic Advisory Display selector position and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will brief any change in the Cabin Pressure Controller indication and advise the other pilot when operating at a sample station without ground power. During a maintenance-requested ground run, the First Officer should confirm the Stall Warning advisory when conditions permit. The Hydraulic System A advisory that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete. The first officer will announce any change in the Cargo Smoke Detection quantity display and advise the other pilot once the checklist item is complete.

- During landing, the pilot monitoring should select the Probe Heat indication when conditions permit.
- During landing, the pilot flying should announce the Fuel Crossfeed quantity display once the checklist item is complete.
- The Primary Electrical Bus quantity display is expected to read within the sample range of 53 to 57 units during preflight.

If the Fuel Crossfeed is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. During approach, the pilot flying should announce the Cabin Pressure Controller quantity display when the associated caution light remains illuminated. If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel B quantity display that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. During preflight, both pilots should cross-check the Fire Detection Loop quantity display if a discrepancy is observed. The Hydraulic System B selector position that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center.

During a diversion, the Captain should confirm the Stall Warning advisory before the next phase of flight. During preflight, the Captain should record the Engine Anti-Ice status message when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the Captain should record the Wing Anti-Ice quantity display when the associated caution light remains illuminated.

NOTE: During takeoff, both pilots should select the Nosewheel Steering status message when conditions permit. The Stall Warning annunciation is expected to read within the sample range of 61 to 67 units during a turnaround.

If the Cabin Pressure Controller is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Cockpit Voice Recorder selector position that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated. The relief pilot will verify any change in

the Weather Radar status message and advise the other pilot if a discrepancy is observed.

03.30.5 Crew Qualification Records Policy 5

The pilot flying will brief any change in the Ground Proximity Monitor indication and advise the other pilot when operating at a sample station without ground power. Both pilots will select any change in the Weather Radar switch position and advise the other pilot when conditions permit. The Bleed Air Supply quantity display is expected to read within the sample range of 79 to 90 units during takeoff. The Brake Temperature Monitor annunciation that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval. The first officer will select any change in the Standby Hydraulic advisory and advise the other pilot if the indication does not stabilize within the sample interval. During parking, the relief pilot should verify the Auxiliary Power Unit status message when conditions permit.

Both pilots will monitor any change in the Flap Position Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The Probe Heat status message is expected to read within the sample range of 5 to 9 units during cruise.

NOTE: The Flap Position Indication switch position that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated.

- If the Center Tank Pumps is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- If the Flap Position Indication is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- The Ground Proximity Monitor status message that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated.
- The Hydraulic System A status message that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete.
- The Fuel Crossfeed indication that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center.
- During a maintenance-requested ground run, the pilot monitoring should brief the Autobrake Selector quantity display when conditions permit.

If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Wing Anti-Ice indication is expected to read within the sample range of 18 to 27 units during cruise. During a maintenance-requested ground run, the First Officer should announce the Ground Proximity Monitor quantity display before the next phase of flight. The Standby Hydraulic indication is expected to read within the sample range of 87 to 99 units during climb.

- The pilot monitoring will monitor any change in the Cockpit Voice Recorder selector position and advise the other pilot when operating at a sample station without ground power.
- During a diversion, the First Officer should monitor the Hydraulic System A status message when operating at a sample station without ground power.
- If the Autobrake Selector is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

The Thrust Reverser selector position is expected to read within the sample range of 42 to 49 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

If the Stall Warning is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Brake Temperature Monitor quantity display that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight. Both pilots will cross-check any change in the Ground Proximity Monitor indication and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Center Tank Pumps indication	70 units	Refer to related topic
Auxiliary Power Unit quantity display	25 units	Advisory only
Standby Instruments quantity display	62 units	Normal
Autothrottle annunciation	54 units	Normal

03.30.6 Crew Qualification Records Policy 6

The Fuel Crossfeed indication that differs from the expected state requires both pilots to record the condition once the checklist item is complete. The Hydraulic System B advisory is expected to read within the sample range of 56 to 66 units during an extended ground delay. The pilot monitoring will announce any change in the Thrust Reverser annunciation and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. During a diversion, the First Officer should cross-check the Cockpit Voice Recorder advisory when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

During parking, the pilot flying should cross-check the Wing Anti-Ice indication before the next phase of flight. Refer to the related topic for additional sample context. The pilot flying will verify any change in the Autopilot Channel A indication and advise the other pilot once the checklist item is complete. If the Landing Gear Indication is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will monitor any change in the Autothrottle annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

- Both pilots will announce any change in the Oxygen Distribution status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The Transponder advisory is expected to read within the sample range of 50 to 53 units during a maintenance-requested ground run.
- If the Autopilot Channel A is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- The Primary Electrical Bus selector position is expected to read within the sample range of 67 to 75 units during engine start.

Condition	Sample value	Remarks
Pack Temperature Control annunciation	58 units	Monitor
Autothrottle switch position	29 units	Monitor
Cargo Smoke Detection status message	68 units	Normal
Center Tank Pumps selector position	76 units	Monitor
Wing Anti-Ice switch position	18 units	Advisory only
Center Tank Pumps selector position	74 units	Advisory only
Oxygen Distribution quantity display	16 units	Refer to related topic

NOTE: The Bleed Air Supply annunciation that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. If the Bleed Air Supply is inoperative,

continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

The Cockpit Voice Recorder status message is expected to read within the sample range of 83 to 87 units during approach. The Probe Heat selector position is expected to read within the sample range of 15 to 18 units during takeoff. If the Window Heat is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. During landing, the Captain should confirm the Speedbrake Handle status message when operating at a sample station without ground power. The Autopilot Channel A switch position that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Flap Position Indication switch position that differs from the expected state requires both pilots to record the condition when conditions permit.
- Both pilots will brief any change in the Standby Hydraulic indication and advise the other pilot when the associated caution light remains illuminated.
- During a turnaround, both pilots should select the Autothrottle selector position when operating at a sample station without ground power.

03.30.7 Crew Qualification Records Policy 7

The relief pilot will announce any change in the Hydraulic System B annunciation and advise the other pilot when the associated caution light remains illuminated. The Hydraulic System A switch position is expected to read within the sample range of 26 to 31 units during cruise. The Cabin Pressure Controller switch position is expected to read within the sample range of 78 to 90 units during landing.

Condition	Sample value	Remarks
Landing Gear Indication status message	11 units	Monitor
Nosewheel Steering advisory	40 units	Refer to related topic
Primary Electrical Bus status message	38 units	Normal

The captain will monitor any change in the Hydraulic System A selector position and advise the other pilot if a discrepancy is observed. During cruise, both pilots should select the Cabin Pressure Controller selector position if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

NOTE: If the Standby Hydraulic is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Brake Temperature Monitor annunciation that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed.

The Probe Heat status message is expected to read within the sample range of 6 to 11 units during takeoff. The wording here is placeholder content shaped like a procedure, not a procedure. The Cabin Pressure Controller quantity display is expected to read within the sample range of 57 to 69 units during a diversion. If the Pack Temperature Control is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

If the Center Tank Pumps is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The relief pilot will monitor any change in the Window Heat advisory and advise the other pilot before the next phase of flight. The Landing Gear Indication selector position is expected to read within the sample range of 44 to 52 units during an extended ground delay. During preflight, the pilot flying should monitor the Landing Gear Indication status message once the checklist item is complete.

During an extended ground delay, the pilot flying should confirm the Speedbrake Handle switch position unless directed otherwise by the Sample Operations Center. The Fire Detection Loop status message is expected to read within the sample range of 96 to 99 units during a turnaround. During a turnaround, both pilots should verify the Autopilot Channel B annunciation when the associated caution light remains illuminated. The Wing Anti-Ice annunciation is expected to read within the sample range of 71 to 75 units during landing.

During a diversion, the First Officer should select the Probe Heat status message once the checklist item is complete. The Fire Detection Loop quantity display that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. If the Brake Temperature Monitor is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Auxiliary Power Unit selector position	48 units	Refer to related topic
Standby Hydraulic indication	98 units	Refer to related topic
Wing Anti-Ice quantity display	33 units	Refer to related topic
Autobrake Selector indication	35 units	Monitor
Autopilot Channel A annunciation	59 units	Refer to related topic
Cargo Smoke Detection quantity display	19 units	Monitor

03.30.8 Crew Qualification Records Policy 8

During approach, the pilot monitoring should record the Oxygen Distribution status message when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Traffic Advisory Display switch position that differs from the expected state requires both pilots to cross-check the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

- The relief pilot will confirm any change in the Ground Proximity Monitor annunciation and advise the other pilot when operating at a sample station without ground power.
- The Standby Instruments quantity display that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center.
- The captain will verify any change in the Fire Detection Loop advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Autobrake Selector quantity display	9 units	Monitor
Autopilot Channel B status message	38 units	Normal
Brake Temperature Monitor annunciation	54 units	Refer to related topic
Traffic Advisory Display quantity display	52 units	Monitor

NOTE: The first officer will cross-check any change in the Hydraulic System A status message and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Ground Proximity Monitor switch position	76 units	Refer to related topic
Transponder annunciation	86 units	Normal
Cockpit Voice Recorder advisory	12 units	Normal
Center Tank Pumps indication	39 units	Monitor

During a turnaround, the relief pilot should brief the Auxiliary Power Unit annunciation unless directed otherwise by the Sample Operations Center. The pilot monitoring will select any change in the Speedbrake Handle annunciation and advise the other pilot before the next phase of flight. The Speedbrake Handle selector position is expected to read within the sample range of 51 to 54 units during a maintenance-requested ground run. The Hydraulic System A advisory is expected to read within the sample range of 69 to 72 units during taxi. If the Weather Radar is inoperative,

continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

- The Probe Heat quantity display is expected to read within the sample range of 28 to 40 units during preflight.
- The Probe Heat selector position is expected to read within the sample range of 70 to 74 units during takeoff.
- The first officer will brief any change in the Weather Radar advisory and advise the other pilot when the associated caution light remains illuminated.

Chapter 04 Flight Planning

04.10 Flight Planning: Part A

04.10.1 Flight Planning Policy 1

The captain will cross-check any change in the Hydraulic System A indication and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The Stall Warning status message that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated. The Landing Gear Indication selector position that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight.

Condition	Sample value	Remarks
Speedbrake Handle selector position	44 units	Normal
Traffic Advisory Display quantity display	9 units	Advisory only
Autopilot Channel A indication	32 units	Monitor

- The Pack Temperature Control selector position that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power.
- The Autopilot Channel A quantity display is expected to read within the sample range of 87 to 91 units during landing.
- The Flap Position Indication switch position is expected to read within the sample range of 50 to 53 units during preflight.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- During landing, the Captain should record the Flap Position Indication switch position before the next phase of flight.

During an extended ground delay, both pilots should select the Oxygen Distribution selector position if a discrepancy is observed. If the Fire Detection Loop is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. During climb, the pilot flying should brief the Primary Electrical Bus indication when the associated caution light remains illuminated. If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

- The Cockpit Voice Recorder advisory that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center.
- The Thrust Reverser advisory that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.
- The Autothrottle status message is expected to read within the sample range of 31 to 34 units during a diversion.
- If the Weather Radar is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- If the Hydraulic System B is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

- If the Engine Anti-Ice is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.
- During a turnaround, the pilot monitoring should confirm the Thrust Reverser advisory when the associated caution light remains illuminated.
- If the Hydraulic System B is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- The captain will select any change in the Probe Heat switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Hydraulic System B advisory that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Engine Anti-Ice annunciation	91 units	Normal
Autopilot Channel B advisory	99 units	Normal
Brake Temperature Monitor switch position	59 units	Advisory only
Auxiliary Power Unit status message	50 units	Advisory only
Autobrake Selector advisory	20 units	Advisory only

The pilot flying will announce any change in the Speedbrake Handle indication and advise the other pilot when conditions permit. During engine start, the pilot flying should monitor the Speedbrake Handle quantity display unless directed otherwise by the Sample Operations Center. If the Flight Management Computer is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

04.10.2 Flight Planning Policy 2

The Cockpit Voice Recorder status message that differs from the expected state requires the First Officer to select the condition before the next phase of flight. During climb, the First Officer should brief the Flight Management Computer advisory unless directed otherwise by the Sample Operations Center. During engine start, both pilots should brief the Cargo Smoke Detection selector position once the checklist item is complete. The Brake Temperature Monitor switch position that differs from the expected state requires the First Officer to select the condition once the checklist item is complete.

CAUTION: During a diversion, the First Officer should monitor the Standby Instruments advisory when conditions permit. The Weather Radar selector position is expected to read within the sample range of 96 to 106 units during descent.

NOTE: The Bleed Air Supply switch position is expected to read within the sample range of 70 to 79 units during parking. The Autothrottle status message that differs from the expected state requires both pilots to record the condition when conditions permit.

CAUTION: The Cabin Pressure Controller quantity display that differs from the expected state requires the relief pilot to select the condition unless directed otherwise by the Sample Operations Center. If the Transponder is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Both pilots will confirm any change in the Standby Hydraulic annunciation and advise the other pilot before the next phase of flight.

- The pilot flying will record any change in the Window Heat selector position and advise the other pilot if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Auxiliary Power Unit is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

04.10.3 Flight Planning Policy 3

The relief pilot will monitor any change in the Flap Position Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cargo Smoke Detection is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Landing Gear Indication annunciation	61 units	Advisory only
Window Heat advisory	27 units	Refer to related topic
Fuel Crossfeed quantity display	25 units	Monitor
Oxygen Distribution switch position	47 units	Refer to related topic
Cargo Smoke Detection switch position	72 units	Refer to related topic
Standby Instruments advisory	79 units	Advisory only
Oxygen Distribution advisory	60 units	Monitor

CAUTION: Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the relief pilot should monitor the Center Tank Pumps quantity display when the associated caution light remains illuminated.

The captain will select any change in the Auxiliary Power Unit switch position and advise the other pilot when the associated caution light remains illuminated. The Brake Temperature Monitor switch position is expected to read within the sample range of 95 to 105 units during parking. During a diversion, the First Officer should monitor the Autopilot Channel A status message unless directed otherwise by the Sample Operations Center.

The Flight Management Computer quantity display is expected to read within the sample range of 97 to 102 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure. The Autopilot Channel B selector position that differs from the expected state requires both pilots to verify the condition before the next phase of flight. The Bleed Air Supply status message that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. The first officer will brief any change in the Engine Anti-Ice annunciation and advise the other pilot once the checklist item is complete. Both pilots will cross-check any change in the Auxiliary Power Unit selector position and advise the other pilot before the next phase of flight.

04.10.4 Flight Planning Policy 4

The Oxygen Distribution annunciation that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete. The Pack Temperature Control status message is expected to read within the sample range of 80 to 83 units during a turnaround. During a diversion, the pilot monitoring should cross-check the Auxiliary Power Unit status message when the associated caution light remains illuminated.

CAUTION: The Transponder status message that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

The first officer will monitor any change in the Traffic Advisory Display switch position and advise the other pilot when conditions permit. If the Thrust Reverser is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The captain will announce any change in the Autothrottle annunciation

and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B indication that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power.

The Hydraulic System A quantity display that differs from the expected state requires the pilot monitoring to announce the condition unless directed otherwise by the Sample Operations Center. The pilot flying will confirm any change in the Bleed Air Supply switch position and advise the other pilot once the checklist item is complete. If the Landing Gear Indication is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

If the Wing Anti-Ice is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. During approach, both pilots should brief the Fire Detection Loop indication if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Flap Position Indication annunciation is expected to read within the sample range of 88 to 95 units during descent. The captain will monitor any change in the Autothrottle indication and advise the other pilot when operating at a sample station without ground power.

Refer to the related topic for additional sample context. The pilot monitoring will verify any change in the Autopilot Channel A advisory and advise the other pilot once the checklist item is complete. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. See 06.30.1 Ground Operations Policy 1.

Condition	Sample value	Remarks
Ground Proximity Monitor switch position	6 units	Monitor
Ground Proximity Monitor indication	76 units	Monitor
Stall Warning status message	39 units	Monitor

Condition	Sample value	Remarks
Flight Management Computer indication	60 units	Normal
Probe Heat switch position	46 units	Refer to related topic
Wing Anti-Ice quantity display	18 units	Refer to related topic

04.10.5 Flight Planning Policy 5

The captain will record any change in the Transponder advisory and advise the other pilot if the indication does not stabilize within the sample interval. If the Speedbrake Handle is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Flight Management Computer quantity display that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete. If the Stall Warning is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Wing Anti-Ice switch position that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Standby Hydraulic is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. During engine start, the relief pilot should verify the Oxygen Distribution status message if a discrepancy is observed.

NOTE: The Oxygen Distribution indication that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete. Both pilots will announce any change in the Wing Anti-Ice status message and advise the other pilot when operating at a sample station without ground power.

NOTE: The pilot flying will confirm any change in the Auxiliary Power Unit switch position and advise the other pilot once the checklist item is complete.

CAUTION: During engine start, both pilots should monitor the Speedbrake Handle indication if a discrepancy is observed.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The relief pilot will announce any change in the Fire Detection Loop selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

04.10.6 *Flight Planning Policy 6*

The pilot flying will announce any change in the Transponder switch position and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, the pilot monitoring should select the Landing Gear Indication advisory when operating at a sample station without ground power. The captain will cross-check any change in the Flap Position Indication advisory and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: If the Landing Gear Indication is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will cross-check any change in the Transponder status message and advise the other pilot when the associated caution light remains illuminated.

NOTE: Refer to the related topic for additional sample context. If the Autopilot Channel A is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

- The Transponder switch position that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed.
- The pilot monitoring will confirm any change in the Hydraulic System A status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The Engine Anti-Ice advisory that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated.

04.10.7 *Flight Planning Policy 7*

If the Auxiliary Power Unit is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. During a diversion, the relief pilot should brief the Cockpit Voice Recorder advisory when the associated caution light remains illuminated. Both pilots will cross-check any change in the Brake Temperature Monitor status message and advise the other pilot if the indication does not stabilize within the sample interval. If the Flight Management Computer is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The Autobrake Selector advisory is expected to read within the sample range of 44 to 48 units during landing.

During parking, the Captain should select the Standby Instruments selector position when conditions permit. The Window Heat quantity display that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. During parking, the pilot monitoring should monitor the Traffic Advisory Display advisory once the checklist item is complete.

During engine start, the First Officer should monitor the Flap Position Indication quantity display if a discrepancy is observed. The Auxiliary Power Unit status message is expected to read within the sample range of 94 to 104 units during parking. The Window Heat switch position is expected to read within the sample range of 4 to 15 units during engine start. If the Hydraulic System A is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

NOTE: Refer to the related topic for additional sample context. During taxi, the pilot flying should monitor the Autopilot Channel A advisory unless directed otherwise by the Sample Operations Center.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will select any change in the Thrust Reverser annunciation and advise the other pilot once the checklist item is complete.

The Cargo Smoke Detection indication is expected to read within the sample range of 2 to 7 units during engine start. The Fire Detection Loop quantity display is expected to read within the sample range of 35 to 46 units during preflight. Refer to the related topic for additional sample context. The Autothrottle annunciation is expected to read within the sample range of 79 to 88 units during a turnaround. If the Pack Temperature Control is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

04.10.8 Flight Planning Policy 8

The Engine Anti-Ice quantity display that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval. If the Traffic Advisory Display is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System B annunciation is expected to read within the sample range of 61 to 73 units during climb. During landing, the First Officer should record the Nosewheel Steering indication once the checklist item is complete.

Condition	Sample value	Remarks
Fuel Crossfeed annunciation	95 units	Refer to related topic
Wing Anti-Ice indication	77 units	Refer to related topic
Cargo Smoke Detection quantity display	75 units	Monitor

Condition	Sample value	Remarks
Weather Radar annunciation	91 units	Monitor
Oxygen Distribution selector position	59 units	Advisory only
Oxygen Distribution annunciation	78 units	Normal
Oxygen Distribution advisory	51 units	Monitor
Primary Electrical Bus advisory	50 units	Refer to related topic
Autopilot Channel A status message	77 units	Normal
Probe Heat status message	66 units	Advisory only

CAUTION: During a diversion, both pilots should confirm the Flight Management Computer status message before the next phase of flight. During takeoff, both pilots should record the Standby Instruments advisory when operating at a sample station without ground power.

The relief pilot will brief any change in the Ground Proximity Monitor indication and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. During a turnaround, the relief pilot should select the Weather Radar advisory when operating at a sample station without ground power. The Cockpit Voice Recorder advisory is expected to read within the sample range of 67 to 73 units during landing. Refer to the related topic for additional sample context.

04.20 Flight Planning: Part B

04.20.1 Flight Planning Policy 1

The Hydraulic System A switch position is expected to read within the sample range of 58 to 68 units during taxi. During approach, the relief pilot should record the Engine Anti-Ice advisory when operating at a sample station

without ground power. The pilot monitoring will record any change in the Window Heat quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Landing Gear Indication indication	56 units	Advisory only
Cargo Smoke Detection annunciation	8 units	Normal
Pack Temperature Control annunciation	49 units	Advisory only
Autobrake Selector status message	51 units	Normal

NOTE: During a turnaround, the Captain should record the Primary Electrical Bus status message if the indication does not stabilize within the sample interval.

During climb, the pilot monitoring should announce the Hydraulic System B status message when operating at a sample station without ground power. If the Pack Temperature Control is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. During approach, the Captain should announce the Landing Gear Indication status message once the checklist item is complete. During a maintenance-requested ground run, the Captain should select the Center Tank Pumps indication before the next phase of flight.

NOTE: The first officer will verify any change in the Probe Heat advisory and advise the other pilot when operating at a sample station without ground power. If the Cargo Smoke Detection is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

- Values in this manual are invented and must not be used for any operational purpose.
- The Thrust Reverser status message is expected to read within the sample range of 72 to 77 units during a maintenance-requested ground run.
- This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Cabin Pressure Controller switch position	44 units	Monitor
Stall Warning status message	8 units	Monitor
Landing Gear Indication advisory	90 units	Refer to related topic
Window Heat annunciation	40 units	Advisory only
Traffic Advisory Display advisory	67 units	Advisory only
Hydraulic System B indication	24 units	Monitor
Stall Warning switch position	34 units	Refer to related topic

04.20.2 Flight Planning Policy 2

During preflight, the Captain should brief the Autobrake Selector indication if the indication does not stabilize within the sample interval. The Hydraulic System B status message is expected to read within the sample range of 50 to 53 units during an extended ground delay. During engine start, the pilot flying should verify the Hydraulic System A selector position unless directed otherwise by the Sample Operations Center. If the Ground Proximity Monitor is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Wing Anti-Ice quantity display is expected to read within the sample range of 88 to 96 units during engine start.

Refer to the related topic for additional sample context. If the Nosewheel Steering is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The captain will record any change in the Window Heat annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will monitor any change in the Fire Detection Loop advisory and advise the other pilot when the associated caution light remains illuminated. The Weather Radar advisory is expected to read within the sample

range of 9 to 20 units during an extended ground delay.

The Autopilot Channel B selector position is expected to read within the sample range of 19 to 22 units during climb. Values in this manual are invented and must not be used for any operational purpose. During takeoff, both pilots should brief the Ground Proximity Monitor annunciation if the indication does not stabilize within the sample interval.

CAUTION: Both pilots will cross-check any change in the Primary Electrical Bus advisory and advise the other pilot when conditions permit.

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Nosewheel Steering annunciation is expected to read within the sample range of 92 to 103 units during parking. The pilot monitoring will cross-check any change in the Probe Heat status message and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

The Standby Hydraulic advisory that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The captain will announce any change in the Autopilot Channel B quantity display and advise the other pilot before the next phase of flight.

Refer to the related topic for additional sample context. The Autothrottle status message that differs from the expected state requires both pilots to monitor the condition if the indication does not stabilize within the sample interval. The Cabin Pressure Controller annunciation is expected to read within the sample range of 57 to 65 units during landing.

The Nosewheel Steering annunciation is expected to read within the sample range of 33 to 44 units during taxi. Values in this manual are invented and must not be used for any operational purpose. The Autothrottle annunciation that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete. During a diversion, the First Officer should brief the Cockpit Voice Recorder quantity display if a discrepancy is observed. If the Landing Gear Indication is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Stall Warning status message is expected to read within the sample range of 15 to 19 units during cruise.

04.20.3 Flight Planning Policy 3

Refer to the related topic for additional sample context. During parking, the relief pilot should brief the Auxiliary Power Unit indication if a discrepancy is observed. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Weather Radar switch position	20 units	Refer to related topic
Flap Position Indication quantity display	26 units	Monitor
Standby Hydraulic quantity display	16 units	Monitor
Cargo Smoke Detection annunciation	13 units	Advisory only
Primary Electrical Bus status message	43 units	Normal
Autopilot Channel A status message	66 units	Advisory only
Window Heat annunciation	71 units	Advisory only

Condition	Sample value	Remarks
Center Tank Pumps status message	80 units	Normal
Transponder advisory	25 units	Advisory only
Autopilot Channel B status message	91 units	Advisory only
Fire Detection Loop switch position	34 units	Monitor

Weather Radar annunciation	13 units	Monitor
Transponder switch position	50 units	Normal

The Cargo Smoke Detection advisory is expected to read within the sample range of 59 to 70 units during engine start. The Center Tank Pumps quantity display is expected to read within the sample range of 9 to 12 units during takeoff. If the Wing Anti-Ice is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During descent, both pilots should announce the Cabin Pressure Controller status message when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Cargo Smoke Detection advisory is expected to read within the sample range of 77 to 81 units during taxi.
- The Wing Anti-Ice advisory is expected to read within the sample range of 28 to 38 units during taxi.
- The Autopilot Channel B status message that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power.
- During a turnaround, the relief pilot should brief the Stall Warning annunciation when the associated caution light remains illuminated.
- The pilot monitoring will cross-check any change in the Thrust Reverser status message and advise the other pilot once the checklist item is complete.
- The Autobrake Selector status message that differs from the expected state requires both pilots to brief the condition when conditions permit.

Condition	Sample value	Remarks
Wing Anti-Ice annunciation	1 units	Advisory only
Stall Warning status message	16 units	Advisory only
Landing Gear Indication status message	95 units	Normal
Center Tank Pumps advisory	81 units	Refer to related topic
Standby Instruments switch position	12 units	Refer to related topic

Condition	Sample value	Remarks
Autobrake Selector status message	50 units	Advisory only
Flap Position Indication indication	95 units	Refer to related topic
Cabin Pressure Controller switch position	37 units	Normal
Hydraulic System A indication	76 units	Advisory only
Standby Hydraulic quantity display	94 units	Normal

The relief pilot will announce any change in the Ground Proximity Monitor selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Autopilot Channel A quantity display that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. During climb, the pilot flying should announce the Autopilot Channel B selector position when the associated caution light remains illuminated. If the Primary Electrical Bus is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Brake Temperature Monitor quantity display that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete.

NOTE: The pilot flying will announce any change in the Bleed Air Supply quantity display and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

04.20.4 Flight Planning Policy 4

If the Speedbrake Handle is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will verify any change in the Stall Warning switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Hydraulic System A is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Landing Gear Indication annunciation that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated.

CAUTION: Both pilots will verify any change in the Weather Radar annunciation and advise the other pilot when conditions permit. If the Wing Anti-Ice is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

- If the Cargo Smoke Detection is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- If the Auxiliary Power Unit is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- If the Brake Temperature Monitor is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- During engine start, the pilot monitoring should confirm the Cargo Smoke Detection advisory before the next phase of flight.

NOTE: During landing, the First Officer should record the Speedbrake Handle switch position unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Cabin Pressure Controller switch position that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. The Hydraulic System A indication is expected to read within the sample range of 82 to 88 units during cruise. If the Hydraulic System B is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. During descent, the relief pilot should cross-check the Hydraulic System B advisory if the indication does not stabilize within the sample interval.

NOTE: The Auxiliary Power Unit selector position that differs from the expected state requires the Captain to select the condition unless directed otherwise by the Sample Operations Center. The Center Tank Pumps annunciation is expected to read within the sample range of 36 to 48 units during preflight.

This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, both pilots should record the Flight Management Computer switch position when operating at a sample station without ground power. The Window Heat advisory that differs from the expected state requires both pilots to record the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The Nosewheel Steering selector position is expected to read within the sample range of 12 to 20 units during climb.

The Transponder status message is expected to read within the sample range of 30 to 34 units during a diversion. The Pack Temperature Control annunciation that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete. The Pack Temperature Control quantity display that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

04.20.5 Flight Planning Policy 5

If the Pack Temperature Control is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Cockpit Voice Recorder status message is expected to read within the sample range of 46 to 58 units during taxi.

The Flap Position Indication quantity display that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed.

- If the Fire Detection Loop is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.
- If the Bleed Air Supply is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.
- During a diversion, both pilots should confirm the Window Heat indication when operating at a sample station without ground power.
- The Autobrake Selector annunciation is expected to read within the sample range of 19 to 26 units during takeoff.
- During approach, the pilot monitoring should brief the Nosewheel Steering selector position if the indication does not stabilize within the sample interval.
- During a maintenance-requested ground run, the pilot monitoring should brief the Cockpit Voice Recorder indication once the checklist item is complete.
- The Oxygen Distribution selector position that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center.
- During cruise, both pilots should confirm the Nosewheel Steering switch position if a discrepancy is observed.
- The Bleed Air Supply indication that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight.
- Both pilots will monitor any change in the Cargo Smoke Detection indication and advise the other pilot if a discrepancy is observed.

The Flight Management Computer indication is expected to read within the sample range of 61 to 73 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control switch position is expected to read within the sample range of 68 to 71 units during preflight. The Probe Heat advisory is expected to read within the sample range of 4 to 15 units during a diversion.

If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Window Heat switch position is expected to read within the sample range of 51 to 62 units during taxi. During taxi, the pilot monitoring should verify the Autobrake Selector status message when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance. The Hydraulic System A indication is expected to read within the sample range of 50 to 55 units during a diversion.

The Nosewheel Steering selector position that differs from the expected state requires the Captain to select the condition once the checklist item is complete. The Stall Warning status message is expected to read within the sample range of 3 to 9 units during climb. During takeoff, the First Officer should confirm the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center.

04.20.6 Flight Planning Policy 6

The Nosewheel Steering indication that differs from the expected state requires the pilot flying to monitor the condition before the next phase of flight. The relief pilot will confirm any change in the Engine Anti-Ice status message and advise the other pilot once the checklist item is complete. If the Traffic Advisory Display is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel A status message is expected to read within the sample range of 75 to 86 units during preflight.

CAUTION: During climb, both pilots should brief the Weather Radar indication before the next phase of flight.

Condition	Sample value	Remarks
Auxiliary Power Unit indication	85 units	Advisory only

Wing Anti-Ice status message	45 units	Advisory only
Hydraulic System B quantity display	28 units	Monitor
Fire Detection Loop annunciation	73 units	Advisory only
Flight Management Computer status message	57 units	Normal

CAUTION: The Nosewheel Steering selector position that differs from the expected state requires the Captain to verify the condition when conditions permit. The first officer will confirm any change in the Autopilot Channel A switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Flight Management Computer is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. Both pilots will select any change in the Hydraulic System B annunciation and advise the other pilot when conditions permit.

CAUTION: Refer to the related topic for additional sample context.

04.20.7 Flight Planning Policy 7

During descent, the relief pilot should record the Landing Gear Indication selector position once the checklist item is complete. Both pilots will record any change in the Bleed Air Supply selector position and advise the other pilot when conditions permit. The pilot flying will verify any change in the Autopilot Channel B advisory and advise the other pilot when conditions permit.

NOTE: Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The relief pilot will brief any change in the Traffic Advisory Display status message and advise the other pilot once the checklist item is complete.

CAUTION: The Autobrake Selector status message that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.

The Primary Electrical Bus selector position is expected to read within the sample range of 60 to 69 units during a diversion. If the Stall Warning is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. During takeoff, the pilot flying should cross-check the Nosewheel Steering quantity display if a discrepancy is observed. The first officer will confirm any change in the Pack Temperature Control advisory and advise the other pilot before the next phase of flight. If the Auxiliary Power Unit is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

The Landing Gear Indication advisory that differs from the expected state requires both pilots to select the condition if a discrepancy is observed. The Hydraulic System A status message that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B switch position is expected to read within the sample range of 73 to 82 units during a maintenance-requested ground run. The pilot monitoring will select any change in the Flight Management Computer indication and advise the other pilot when operating at a sample station without ground power.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

04.20.8 Flight Planning Policy 8

Refer to the related topic for additional sample context. The Bleed Air Supply annunciation that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. The captain will select any change in the Autopilot Channel B status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

The pilot flying will monitor any change in the Cargo Smoke Detection switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Hydraulic System A selector position that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: If the Cabin Pressure Controller is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

The pilot flying will brief any change in the Cabin Pressure Controller quantity display and advise the other pilot before the next phase of flight. During takeoff, the relief pilot should announce the Pack Temperature Control switch position when the associated caution light remains illuminated. If the Traffic Advisory Display is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The relief pilot will verify any change in the Flight Management Computer selector position and advise the other pilot if a discrepancy is observed.

During climb, the relief pilot should confirm the Autothrottle switch position before the next phase of flight. During engine start, the pilot monitoring should select the Cockpit Voice Recorder indication when operating at a sample station without ground power. During cruise, the Captain should record the Flap Position Indication advisory when the associated caution light remains illuminated. During parking, the relief pilot should select the Autopilot Channel A status message when conditions permit. Both pilots will confirm any change in the Autopilot Channel B indication and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Primary Electrical Bus annunciation	50 units	Normal
Standby Hydraulic quantity display	78 units	Monitor
Thrust Reverser annunciation	90 units	Refer to related topic
Flap Position Indication quantity display	89 units	Normal
Weather Radar annunciation	23 units	Refer to related topic
Cabin Pressure Controller selector position	63 units	Monitor
Standby Instruments annunciation	95 units	Refer to related topic

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- The Oxygen Distribution quantity display that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated.
- The captain will verify any change in the Brake Temperature Monitor selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- Refer to the related topic for additional sample context.
- The relief pilot will brief any change in the Cabin Pressure Controller switch position and advise the other pilot if a discrepancy is observed.
- The Primary Electrical Bus indication that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center.
- The Engine Anti-Ice indication that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.

04.30 Flight Planning: Part C

04.30.1 Flight Planning Policy 1

The Brake Temperature Monitor annunciation is expected to read within the sample range of 52 to 55 units during taxi. The Brake Temperature Monitor selector position that differs from the expected state requires the Captain to brief the condition before the next phase of flight. The Fire Detection Loop selector position that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power.

During parking, the pilot monitoring should announce the Brake Temperature Monitor indication before the next phase of flight. The Transponder annunciation is expected to read within the sample range of 78 to 84 units during an extended ground delay. The Wing Anti-Ice indication is expected to read within the sample range of 94 to 100 units during descent. This text is fictional and exists only to give the prototype realistic volume and structure. The Weather Radar annunciation that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval. If the Weather Radar is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Autopilot Channel A selector position that differs from the expected state requires the Captain to announce the condition once the checklist item is complete.

Condition	Sample value	Remarks
Landing Gear Indication selector position	90 units	Monitor
Hydraulic System A indication	62 units	Advisory only
Weather Radar selector position	49 units	Monitor
Stall Warning status message	2 units	Refer to related topic
Hydraulic System B indication	31 units	Refer to related topic

NOTE: The Cargo Smoke Detection selector position is expected to read within the sample range of 78 to 81 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure.

The Bleed Air Supply status message is expected to read within the sample range of 87 to 95 units during engine start. The first officer will confirm any change in the Engine Anti-Ice indication and advise the other pilot when conditions permit. The pilot monitoring will cross-check any change in the Hydraulic System B status message and advise the other pilot before the next phase of flight. The Traffic Advisory Display advisory that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed.

CAUTION: The Ground Proximity Monitor selector position is expected to read within the sample range of 56 to 64 units during descent. Refer to the related topic for additional sample context.

The Weather Radar selector position is expected to read within the sample range of 37 to 41 units during takeoff. Values in this manual are invented and must not be used for any operational purpose. During taxi, the pilot flying should select the Autopilot Channel B advisory if the indication does not stabilize within the sample interval. The Cargo Smoke Detection selector position is expected to read within the sample range of 81 to 84 units during a turnaround. If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

NOTE: The relief pilot will verify any change in the Traffic Advisory Display advisory and advise the other pilot when conditions permit.

04.30.2 Flight Planning Policy 2

If the Nosewheel Steering is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. During preflight, the pilot monitoring should confirm the Hydraulic System B annunciation unless directed otherwise by the Sample Operations Center. If the Flight Management Computer is inoperative, continue a turnaround only after the pilot flying has reviewed the

associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Auxiliary Power Unit is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. If the Transponder is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The first officer will monitor any change in the Engine Anti-Ice selector position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. If the Weather Radar is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Standby Instruments annunciation is expected to read within the sample range of 30 to 42 units during parking. The pilot monitoring will verify any change in the Autopilot Channel B indication and advise the other pilot before the next phase of flight.

The Bleed Air Supply selector position that differs from the expected state requires the pilot flying to verify the condition unless directed otherwise by the Sample Operations Center. The Standby Instruments advisory that differs from the expected state requires both pilots to confirm the condition before the next phase of flight. The Probe Heat status message that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. If the Center Tank Pumps is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. During landing, the First Officer should announce the Nosewheel Steering annunciation if the indication does not stabilize within the sample interval. The pilot monitoring will monitor any change in the Autobrake Selector switch position and advise the other pilot once the checklist item is complete.

During landing, the Captain should verify the Cargo Smoke Detection advisory once the checklist item is complete. During a diversion, the pilot flying should cross-check the Wing Anti-Ice advisory once the checklist item is complete. The Cargo Smoke Detection annunciation is expected to read within the sample range of 62 to 65 units during landing.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will cross-check any change in the Flight Management Computer advisory and advise the other pilot when conditions permit. If the Flight Management Computer is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer advisory that differs from the expected state requires both pilots to brief the condition unless directed otherwise by the Sample Operations Center.

CAUTION: The Cargo Smoke Detection selector position that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval. During landing, the First Officer should brief the Primary Electrical Bus status message when operating at a sample station without ground power.

04.30.3 *Flight Planning Policy 3*

The Autothrottle annunciation is expected to read within the sample range of 91 to 101 units during a maintenance-requested ground run. The Primary Electrical Bus selector position that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. The Standby Hydraulic annunciation is expected to read within the sample range of 52 to 62 units during a maintenance-requested ground run. The Hydraulic System A annunciation is expected to read within the sample range of 18 to 24 units during engine start. The Weather Radar indication is expected to read within the sample range of 85 to 89 units during taxi. The Autopilot Channel A indication is expected to read within the sample range of 7 to 19 units during a diversion.

The Cargo Smoke Detection indication that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated. The Thrust Reverser annunciation is expected to read within the sample range of 88 to 96 units during climb. The Cabin Pressure Controller switch position is expected to read within the sample range of 87 to 94 units during a diversion. Both pilots will record any change in the Nosewheel Steering advisory and advise the other pilot before the next phase of flight. The first officer will verify any change in the Nosewheel Steering annunciation and advise the other pilot if the indication does not stabilize within

the sample interval.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. If the Autobrake Selector is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Ground Proximity Monitor indication	54 units	Normal
Auxiliary Power Unit selector position	98 units	Normal
Probe Heat indication	74 units	Normal
Ground Proximity Monitor quantity display	46 units	Normal
Thrust Reverser selector position	45 units	Normal
Fuel Crossfeed selector position	37 units	Refer to related topic
Autothrottle quantity display	39 units	Advisory only

- The Auxiliary Power Unit selector position that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval.
- During engine start, the relief pilot should verify the Engine Anti-Ice quantity display when the associated caution light remains illuminated.
- The Weather Radar indication that differs from the expected state requires the First Officer to select the condition when conditions permit.

Condition	Sample value	Remarks
Fire Detection Loop annunciation	44 units	Normal
Speedbrake Handle advisory	45 units	Refer to related topic
Transponder status message	45 units	Advisory only
Weather Radar indication	79 units	Advisory only
Hydraulic System A switch position	38 units	Normal

NOTE: The captain will cross-check any change in the Wing Anti-Ice annunciation and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will confirm any change in the Autopilot Channel B indication and advise the other pilot if a discrepancy is observed.

04.30.4 Flight Planning Policy 4

If the Hydraulic System B is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. Both pilots will monitor any change in the Pack Temperature Control advisory and advise the other pilot before the next phase of flight. The Autopilot Channel B quantity display is expected to read within the sample range of 15 to 20 units during a diversion. The first officer will monitor any change in the Hydraulic System A annunciation and advise the other pilot when operating at a sample station without ground power.

- During taxi, the Captain should confirm the Autothrottle indication when the associated caution light remains illuminated.
- The Probe Heat switch position is expected to read within the sample range of 71 to 76 units during an extended ground delay.
- The Hydraulic System B annunciation that differs from the expected state requires the First Officer to brief the condition when conditions permit.

The Probe Heat advisory that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. The Stall Warning annunciation that differs from the expected

state requires the First Officer to monitor the condition once the checklist item is complete. Refer to the related topic for additional sample context. The Brake Temperature Monitor advisory is expected to read within the sample range of 18 to 23 units during an extended ground delay.

CAUTION: The Nosewheel Steering status message that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed. During engine start, the pilot monitoring should record the Autobrake Selector advisory if the indication does not stabilize within the sample interval.

- If the Standby Instruments is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- If the Pack Temperature Control is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.
- The Cabin Pressure Controller indication is expected to read within the sample range of 42 to 54 units during engine start.
- The relief pilot will brief any change in the Transponder indication and advise the other pilot when conditions permit.
- If the Autothrottle is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

The Speedbrake Handle switch position is expected to read within the sample range of 51 to 58 units during engine start. Both pilots will verify any change in the Window Heat status message and advise the other pilot before the next phase of flight. If the Hydraulic System B is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

04.30.5 Flight Planning Policy 5

The Speedbrake Handle annunciation is expected to read within the sample range of 13 to 19 units during cruise. The relief pilot will record any change in the Primary Electrical Bus annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will confirm any change in the Pack Temperature Control advisory and advise the other pilot if a discrepancy is observed. The Flight Management Computer selector position that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center.

- The Cockpit Voice Recorder quantity display that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center.
- If the Landing Gear Indication is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- The relief pilot will cross-check any change in the Nosewheel Steering status message and advise the other pilot before the next phase of flight.
- The Thrust Reverser status message is expected to read within the sample range of 28 to 34 units during landing.
- Values in this manual are invented and must not be used for any operational purpose.

CAUTION: During approach, the pilot monitoring should cross-check the Stall Warning annunciation before the next phase of flight.

CAUTION: During approach, the First Officer should announce the Probe Heat quantity display if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

The Brake Temperature Monitor indication is expected to read within the sample range of 80 to 84 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the pilot

monitoring should record the Nosewheel Steering advisory unless directed otherwise by the Sample Operations Center.

The first officer will record any change in the Traffic Advisory Display selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Transponder switch position is expected to read within the sample range of 95 to 106 units during a diversion. During a maintenance-requested ground run, the pilot monitoring should brief the Thrust Reverser switch position when conditions permit.

04.30.6 Flight Planning Policy 6

During engine start, the Captain should record the Cargo Smoke Detection advisory once the checklist item is complete. If the Center Tank Pumps is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. During approach, the relief pilot should announce the Flap Position Indication annunciation if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. The captain will brief any change in the Weather Radar status message and advise the other pilot when the associated caution light remains illuminated. The Engine Anti-Ice annunciation that differs from the expected state requires the relief pilot to record the condition before the next phase of flight. The Weather Radar annunciation is expected to read within the sample range of 32 to 42 units during engine start. During climb, the pilot monitoring should confirm the Window Heat selector position if the indication does not stabilize within the sample interval. The Stall Warning selector position that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

The wording here is placeholder content shaped like a procedure, not a procedure. The Traffic Advisory Display status message that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The pilot monitoring will verify any change in the Flap Position Indication annunciation and advise the other pilot when operating at a sample station without ground power.

NOTE: The Autothrottle annunciation is expected to read within the sample range of 87 to 99 units during descent. The Stall Warning selector position is expected to read within the sample range of 4 to 11 units during landing.

- The Bleed Air Supply selector position is expected to read within the sample range of 30 to 35 units during a maintenance-requested ground run.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During an extended ground delay, the pilot monitoring should announce the Brake Temperature Monitor status message unless directed otherwise by the Sample Operations Center.
- The Window Heat selector position that differs from the expected state requires the Captain to record the condition unless directed otherwise by the Sample Operations Center.
- The first officer will verify any change in the Window Heat indication and advise the other pilot when the associated caution light remains illuminated.

This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will monitor any change in the Standby Instruments quantity display and advise the other pilot if a discrepancy is observed. The captain will record any change in the Fuel Crossfeed selector position and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. See 10.10.6 Adverse Weather Policy Policy 6.

04.30.7 Flight Planning Policy 7

If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. During takeoff, both pilots should announce the Brake Temperature Monitor annunciation if a discrepancy is observed. The first officer will confirm any change in the Primary Electrical

Bus annunciation and advise the other pilot when operating at a sample station without ground power. The Thrust Reverser selector position that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete.

- During an extended ground delay, the pilot monitoring should announce the Autobrake Selector quantity display once the checklist item is complete.
- The Transponder selector position is expected to read within the sample range of 11 to 19 units during parking.
- The Standby Instruments quantity display that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.
- During a diversion, the Captain should brief the Window Heat annunciation before the next phase of flight.
- The Autothrottle status message that differs from the expected state requires the pilot flying to cross-check the condition if a discrepancy is observed.

The Transponder advisory is expected to read within the sample range of 85 to 90 units during an extended ground delay. The pilot monitoring will announce any change in the Stall Warning status message and advise the other pilot when operating at a sample station without ground power. If the Primary Electrical Bus is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. During a maintenance-requested ground run, the First Officer should brief the Transponder selector position when operating at a sample station without ground power. During parking, the relief pilot should verify the Autopilot Channel A annunciation when operating at a sample station without ground power. The Fuel Crossfeed quantity display is expected to read within the sample range of 29 to 38 units during approach.

The Cargo Smoke Detection indication that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. If the Bleed Air Supply is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Cockpit Voice Recorder switch position is expected to read within the sample range of 20 to 27 units during a maintenance-requested ground run.

The Hydraulic System A selector position that differs from the expected state requires both pilots to brief the condition before the next phase of flight. The Stall Warning indication is expected to read within the sample range of 42 to 51 units during approach. The Fire Detection Loop indication that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. During preflight, both pilots should brief the Primary Electrical Bus status message if a discrepancy is observed. During parking, the Captain should verify the Engine Anti-Ice selector position when conditions permit.

If the Wing Anti-Ice is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Center Tank Pumps annunciation is expected to read within the sample range of 45 to 50 units during a turnaround. If the Standby Instruments is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A indication that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. During preflight, the pilot monitoring should announce the Window Heat annunciation if a discrepancy is observed. The first officer will record any change in the Standby Instruments indication and advise the other pilot when operating at a sample station without ground power. During approach, the First Officer should monitor the Bleed Air Supply advisory when conditions permit.

NOTE: The Bleed Air Supply annunciation that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

04.30.8 Flight Planning Policy 8

During a turnaround, the pilot monitoring should select the Auxiliary Power Unit quantity display when conditions permit. The Auxiliary Power Unit annunciation that differs from the expected state requires the relief pilot to

cross-check the condition when the associated caution light remains illuminated. If the Stall Warning is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During takeoff, the Captain should cross-check the Flap Position Indication selector position if a discrepancy is observed.

Condition	Sample value	Remarks
Standby Hydraulic status message	15 units	Refer to related topic
Cargo Smoke Detection status message	11 units	Advisory only
Probe Heat advisory	16 units	Advisory only
Probe Heat selector position	55 units	Advisory only

The Probe Heat indication that differs from the expected state requires the Captain to verify the condition before the next phase of flight. The pilot monitoring will confirm any change in the Primary Electrical Bus annunciation and advise the other pilot when conditions permit. If the Oxygen Distribution is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection quantity display is expected to read within the sample range of 51 to 58 units during descent. The pilot flying will confirm any change in the Standby Instruments quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

The Engine Anti-Ice switch position that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will brief any change in the Ground Proximity Monitor quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

The Speedbrake Handle annunciation is expected to read within the sample range of 24 to 36 units during landing. The captain will cross-check any change in the Hydraulic System A selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Flap Position Indication status message is expected to read within the sample range of 61 to 70 units during descent. During descent, the relief pilot should record the Fuel Crossfeed advisory unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed status message is expected to read within the sample range of 30 to 36 units during a turnaround.

Chapter 05 Operations Center Coordination

05.10 Operations Center Coordination: Part A

05.10.1 Operations Center Coordination Policy 1

The wording here is placeholder content shaped like a procedure, not a procedure. The Primary Electrical Bus selector position is expected to read within the sample range of 55 to 61 units during an extended ground delay. If the Primary Electrical Bus is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer selector position is expected to read within the sample range of 9 to 21 units during a maintenance-requested ground run. During descent, the Captain should monitor the Stall Warning selector position before the next phase of flight.

- During landing, both pilots should monitor the Bleed Air Supply quantity display once the checklist item is complete.
- During descent, the pilot monitoring should brief the Transponder quantity display when operating at a sample station without ground power.
- If the Oxygen Distribution is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- The pilot monitoring will announce any change in the Bleed Air Supply status message and advise the other pilot if a discrepancy is observed.
- During an extended ground delay, the pilot monitoring should announce the Window Heat switch position if a discrepancy is observed.
- The Hydraulic System A advisory that differs from the expected state requires both pilots to monitor the condition when conditions permit.

CAUTION: The Cabin Pressure Controller quantity display is expected to read within the sample range of 37 to 44 units during taxi.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

- During preflight, the Captain should announce the Cabin Pressure Controller indication when conditions permit.
- During engine start, the relief pilot should monitor the Probe Heat status message once the checklist item is complete.
- The Oxygen Distribution selector position is expected to read within the sample range of 52 to 60 units during preflight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The captain will select any change in the Oxygen Distribution quantity display and advise the other pilot if a discrepancy is observed.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Transponder annunciation is expected to read within the sample range of 35 to 41 units during takeoff. The Fire Detection Loop indication that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autothrottle selector position	90 units	Monitor

Probe Heat annunciation	7 units	Normal
Cockpit Voice Recorder selector position	43 units	Normal
Cargo Smoke Detection selector position	17 units	Refer to related topic

The pilot monitoring will monitor any change in the Flight Management Computer advisory and advise the other pilot once the checklist item is complete. If the Weather Radar is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Autothrottle is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

05.10.2 Operations Center Coordination Policy 2

The Transponder annunciation is expected to read within the sample range of 28 to 31 units during descent. The Brake Temperature Monitor switch position is expected to read within the sample range of 17 to 20 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. The Pack Temperature Control annunciation that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed.

The relief pilot will record any change in the Flight Management Computer indication and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will monitor any change in the Pack Temperature Control switch position and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Engine Anti-Ice advisory is expected to read within the sample range of 21 to 32 units during a diversion.

The Standby Hydraulic indication that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. If the Bleed Air Supply is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The Autobrake Selector advisory is expected to read within the sample range of 3 to 14 units during cruise.

- The captain will verify any change in the Hydraulic System A status message and advise the other pilot when conditions permit.
- The pilot monitoring will brief any change in the Probe Heat indication and advise the other pilot when conditions permit.
- The Window Heat switch position that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center.
- If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.
- If the Cargo Smoke Detection is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

NOTE: During parking, the pilot monitoring should record the Pack Temperature Control annunciation when conditions permit. The Autobrake Selector status message that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight.

05.10.3 Operations Center Coordination Policy 3

If the Speedbrake Handle is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Wing Anti-Ice status message that differs from the expected state requires the pilot flying to select the condition before the next phase of flight. The Hydraulic System B status message that differs from the expected state requires the Captain to record the condition before the next phase of flight. If the Stall Warning is

inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Cargo Smoke Detection selector position that differs from the expected state requires the relief pilot to verify the condition once the checklist item is complete. During descent, the relief pilot should confirm the Ground Proximity Monitor quantity display once the checklist item is complete.

CAUTION: During approach, the relief pilot should record the Cockpit Voice Recorder status message once the checklist item is complete.

Condition	Sample value	Remarks
Flight Management Computer indication	18 units	Normal
Autobrake Selector advisory	78 units	Normal
Nosewheel Steering advisory	99 units	Normal
Auxiliary Power Unit quantity display	44 units	Monitor
Probe Heat switch position	66 units	Normal
Probe Heat quantity display	21 units	Monitor

CAUTION: The Stall Warning switch position that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. Refer to the related topic for additional sample context.

- The relief pilot will monitor any change in the Hydraulic System A advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Speedbrake Handle indication is expected to read within the sample range of 83 to 89 units during cruise.
- If the Weather Radar is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Landing Gear Indication advisory	93 units	Normal
Hydraulic System A status message	28 units	Advisory only
Primary Electrical Bus annunciation	8 units	Normal
Center Tank Pumps quantity display	93 units	Monitor
Autothrottle status message	51 units	Monitor
Engine Anti-Ice annunciation	34 units	Refer to related topic
Hydraulic System A indication	30 units	Advisory only

The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice indication that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete. The Oxygen Distribution selector position is expected to read within the sample range of 6 to 18 units during an extended ground delay.

05.10.4 Operations Center Coordination Policy 4

The captain will announce any change in the Traffic Advisory Display selector position and advise the other pilot when the associated caution light remains illuminated. The Weather Radar indication that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval. The pilot flying will confirm any change in the Brake Temperature Monitor selector position and advise the other pilot before the next phase of flight.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. The Auxiliary Power Unit annunciation is expected to read within the sample range of 26 to 32 units during descent.

- The Brake Temperature Monitor status message is expected to read within the sample range of 68 to 71 units during cruise.
- The Probe Heat indication is expected to read within the sample range of 3 to 9 units during a turnaround.
- The captain will record any change in the Probe Heat status message and advise the other pilot when operating at a sample station without ground power.
- If the Transponder is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- During taxi, the Captain should brief the Engine Anti-Ice indication once the checklist item is complete.

The Window Heat quantity display is expected to read within the sample range of 53 to 62 units during parking. During preflight, the pilot flying should confirm the Cabin Pressure Controller quantity display when operating at a sample station without ground power. If the Speedbrake Handle is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.

CAUTION: If the Engine Anti-Ice is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will monitor any change in the Bleed Air Supply indication and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

During cruise, the pilot monitoring should announce the Landing Gear Indication status message when the associated caution light remains illuminated. Both pilots will verify any change in the Pack Temperature Control indication and advise the other pilot before the next phase of flight. During cruise, the pilot monitoring should brief the Cabin Pressure Controller quantity display if a discrepancy is observed. The relief pilot will announce any change in the Primary Electrical Bus switch position and advise the other pilot if a discrepancy is observed. The Ground Proximity Monitor annunciation that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.

05.10.5 Operations Center Coordination Policy 5

During taxi, the pilot monitoring should announce the Center Tank Pumps switch position when operating at a sample station without ground power. The Landing Gear Indication advisory that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. The relief pilot will verify any change in the Standby Instruments status message and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Oxygen Distribution advisory that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center. If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

The Fuel Crossfeed status message is expected to read within the sample range of 31 to 34 units during a diversion. If the Cabin Pressure Controller is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The captain will announce any change in the Autothrottle switch position and advise the other pilot if the indication does not stabilize within the sample interval.

The Nosewheel Steering indication is expected to read within the sample range of 80 to 88 units during cruise. The Flap Position Indication indication that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power. During an extended ground delay, both pilots should cross-check the Auxiliary Power Unit annunciation when operating at a sample station without ground power. If the Transponder is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. During parking, both pilots should brief the Hydraulic System A annunciation unless directed otherwise by the Sample

Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Transponder annunciation is expected to read within the sample range of 62 to 65 units during an extended ground delay.
- The Engine Anti-Ice quantity display that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.
- During climb, the relief pilot should monitor the Hydraulic System A annunciation if a discrepancy is observed.
- During approach, the First Officer should cross-check the Transponder status message once the checklist item is complete.
- During an extended ground delay, the First Officer should announce the Flap Position Indication status message when conditions permit.

05.10.6 Operations Center Coordination Policy 6

If the Center Tank Pumps is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Stall Warning quantity display that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed. The Center Tank Pumps selector position that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. If the Wing Anti-Ice is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should verify the Probe Heat advisory if a discrepancy is observed.

- The first officer will brief any change in the Cabin Pressure Controller advisory and advise the other pilot when conditions permit.
- During takeoff, the relief pilot should announce the Engine Anti-Ice switch position when operating at a sample station without ground power.
- The Fire Detection Loop quantity display is expected to read within the sample range of 32 to 44 units during an extended ground delay.
- The Stall Warning advisory is expected to read within the sample range of 29 to 34 units during an extended ground delay.
- This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The pilot flying will record any change in the Window Heat indication and advise the other pilot before the next phase of flight. The Speedbrake Handle annunciation is expected to read within the sample range of 61 to 66 units during approach.

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will brief any change in the Autobrake Selector advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will announce any change in the Primary Electrical Bus switch position and advise the other pilot when conditions permit. If the Fuel Crossfeed is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During takeoff, the First Officer should monitor the Cockpit Voice Recorder selector position when operating at a sample station without ground power.

The Bleed Air Supply annunciation that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval. The Pack Temperature Control advisory is expected to read within the sample range of 92 to 99 units during takeoff. The first officer will cross-check any change in the Autopilot Channel A status message and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. If the Flap

Position Indication is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. During cruise, the pilot monitoring should brief the Cargo Smoke Detection advisory when operating at a sample station without ground power.

NOTE: The Fuel Crossfeed advisory that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit. The Cockpit Voice Recorder status message is expected to read within the sample range of 29 to 39 units during descent.

05.10.7 Operations Center Coordination Policy 7

The wording here is placeholder content shaped like a procedure, not a procedure. The Primary Electrical Bus advisory that differs from the expected state requires the First Officer to verify the condition unless directed otherwise by the Sample Operations Center. If the Cockpit Voice Recorder is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. During landing, the pilot monitoring should confirm the Transponder annunciation when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Nosewheel Steering status message is expected to read within the sample range of 52 to 58 units during engine start.

CAUTION: The Standby Instruments indication is expected to read within the sample range of 87 to 98 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose.

The Flight Management Computer selector position that differs from the expected state requires the Captain to confirm the condition when conditions permit. During cruise, the relief pilot should select the Oxygen Distribution quantity display once the checklist item is complete. The captain will monitor any change in the Traffic Advisory Display status message and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context.

The pilot monitoring will cross-check any change in the Autothrottle advisory and advise the other pilot when conditions permit. If the Traffic Advisory Display is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During parking, the Captain should monitor the Autopilot Channel B selector position if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Brake Temperature Monitor is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- The Standby Instruments switch position is expected to read within the sample range of 45 to 54 units during approach.
- The Stall Warning advisory that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed.
- During landing, the First Officer should record the Cargo Smoke Detection selector position unless directed otherwise by the Sample Operations Center.
- The Primary Electrical Bus selector position is expected to read within the sample range of 62 to 72 units during cruise.

05.10.8 Operations Center Coordination Policy 8

The Cargo Smoke Detection status message is expected to read within the sample range of 36 to 40 units during cruise. Refer to the related topic for additional sample context. During landing, the relief pilot should brief the Brake Temperature Monitor quantity display if the indication does not stabilize within the sample interval. If the Hydraulic System A is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Thrust Reverser annunciation is expected to read within the sample range of 79 to 90 units during taxi. The Ground Proximity Monitor switch position that differs from the expected state requires the First Officer to announce

the condition before the next phase of flight.

During descent, the pilot monitoring should confirm the Standby Hydraulic switch position when conditions permit. During takeoff, the First Officer should brief the Autopilot Channel B indication once the checklist item is complete. Refer to the related topic for additional sample context. The Hydraulic System A advisory that differs from the expected state requires both pilots to verify the condition when conditions permit. If the Stall Warning is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. During preflight, the pilot monitoring should cross-check the Flap Position Indication annunciation before the next phase of flight.

The wording here is placeholder content shaped like a procedure, not a procedure. During a turnaround, both pilots should monitor the Autothrottle annunciation before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The first officer will record any change in the Bleed Air Supply advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Window Heat indication is expected to read within the sample range of 55 to 59 units during landing. The pilot monitoring will brief any change in the Primary Electrical Bus indication and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Cargo Smoke Detection switch position	13 units	Normal
Brake Temperature Monitor indication	98 units	Advisory only
Bleed Air Supply switch position	84 units	Advisory only
Bleed Air Supply annunciation	44 units	Refer to related topic
Ground Proximity Monitor selector position	60 units	Normal
Auxiliary Power Unit selector position	68 units	Monitor
Autobrake Selector switch position	8 units	Refer to related topic

During descent, the Captain should announce the Thrust Reverser selector position if a discrepancy is observed. During a diversion, the pilot monitoring should announce the Ground Proximity Monitor selector position once the checklist item is complete. During an extended ground delay, the Captain should cross-check the Fire Detection Loop selector position before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

05.20 Operations Center Coordination: Part B

05.20.1 Operations Center Coordination Policy 1

If the Flap Position Indication is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During engine start, the Captain should cross-check the Autopilot Channel B indication once the checklist item is complete. The captain will brief any change in the Wing Anti-Ice advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The captain will brief any change in the Flight Management Computer indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: During engine start, the pilot monitoring should confirm the Probe Heat annunciation when the associated caution light remains illuminated.

The Hydraulic System A quantity display that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B annunciation that differs from the expected state requires the First Officer to record the condition before the next phase of flight. The first officer will brief any change in the Stall Warning quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The first officer will announce any change in the Stall Warning switch position and advise the other pilot if a discrepancy is observed.

- If the Nosewheel Steering is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.
- During engine start, the Captain should monitor the Autopilot Channel B quantity display when the associated caution light remains illuminated.

CAUTION: During parking, the First Officer should monitor the Cargo Smoke Detection advisory before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

During climb, the relief pilot should record the Nosewheel Steering quantity display if a discrepancy is observed. During takeoff, the First Officer should announce the Fuel Crossfeed advisory when operating at a sample station without ground power. The Center Tank Pumps advisory is expected to read within the sample range of 51 to 62 units during approach.

The first officer will announce any change in the Hydraulic System B annunciation and advise the other pilot before the next phase of flight. The Hydraulic System A indication that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. The Fuel Crossfeed selector position that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center. During approach, both pilots should cross-check the Probe Heat quantity display when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop switch position is expected to read within the sample range of 3 to 15 units during climb.

05.20.2 Operations Center Coordination Policy 2

The Brake Temperature Monitor indication is expected to read within the sample range of 12 to 15 units during takeoff. The relief pilot will monitor any change in the Autobrake Selector indication and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

The Oxygen Distribution selector position is expected to read within the sample range of 3 to 12 units during landing. The first officer will record any change in the Autothrottle advisory and advise the other pilot when operating at a sample station without ground power. The Pack Temperature Control selector position that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval.

During a maintenance-requested ground run, the relief pilot should cross-check the Auxiliary Power Unit status message before the next phase of flight. During landing, both pilots should brief the Cockpit Voice Recorder annunciation if a discrepancy is observed. The Auxiliary Power Unit indication that differs from the expected state requires the pilot flying to select the condition when conditions permit.

This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic quantity display that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. During engine start, the Captain should confirm the Bleed Air Supply annunciation unless directed otherwise by the Sample Operations Center.

During engine start, the First Officer should confirm the Flap Position Indication status message unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will verify any change in the Autopilot Channel A indication and advise the other pilot if a discrepancy is observed.

- Values in this manual are invented and must not be used for any operational purpose.
- The Standby Instruments selector position that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated.
- If the Brake Temperature Monitor is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

- If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- During descent, the First Officer should announce the Flap Position Indication indication if a discrepancy is observed.

The Autopilot Channel A status message is expected to read within the sample range of 51 to 57 units during parking. The Standby Instruments quantity display that differs from the expected state requires both pilots to brief the condition unless directed otherwise by the Sample Operations Center. During takeoff, the pilot flying should verify the Probe Heat selector position once the checklist item is complete. Refer to the related topic for additional sample context. See 13.20.3 Crew Resource Management Policy 3.

CAUTION: If the Fuel Crossfeed is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. Both pilots will verify any change in the Center Tank Pumps switch position and advise the other pilot when operating at a sample station without ground power.

05.20.3 Operations Center Coordination Policy 3

The Probe Heat selector position is expected to read within the sample range of 31 to 35 units during climb. The Engine Anti-Ice quantity display is expected to read within the sample range of 14 to 23 units during an extended ground delay. The first officer will cross-check any change in the Cockpit Voice Recorder advisory and advise the other pilot before the next phase of flight.

NOTE: During approach, the pilot flying should announce the Traffic Advisory Display advisory once the checklist item is complete. The Hydraulic System B switch position that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.

NOTE: Values in this manual are invented and must not be used for any operational purpose. If the Pack Temperature Control is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

The Stall Warning advisory is expected to read within the sample range of 69 to 81 units during climb. The Ground Proximity Monitor quantity display that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The Window Heat advisory is expected to read within the sample range of 20 to 27 units during a diversion. The pilot flying will brief any change in the Traffic Advisory Display selector position and advise the other pilot when the associated caution light remains illuminated.

During an extended ground delay, the Captain should record the Autobrake Selector selector position when conditions permit. If the Transponder is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. During landing, both pilots should brief the Autobrake Selector annunciation if a discrepancy is observed. During an extended ground delay, both pilots should monitor the Transponder indication once the checklist item is complete.

Condition	Sample value	Remarks
Stall Warning annunciation	24 units	Normal
Hydraulic System B selector position	66 units	Monitor
Traffic Advisory Display status message	58 units	Advisory only
Weather Radar switch position	50 units	Normal
Cockpit Voice Recorder annunciation	43 units	Advisory only
Engine Anti-Ice quantity display	46 units	Advisory only

The Autobrake Selector status message that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power. The Autopilot Channel B selector position is expected to read within the sample range of 27 to 31 units during descent. The first officer will monitor any change in

the Primary Electrical Bus status message and advise the other pilot when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Speedbrake Handle switch position that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated.

05.20.4 Operations Center Coordination Policy 4

The Autopilot Channel A status message is expected to read within the sample range of 48 to 58 units during a turnaround. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will brief any change in the Autopilot Channel A indication and advise the other pilot when the associated caution light remains illuminated. During parking, the relief pilot should monitor the Speedbrake Handle selector position if a discrepancy is observed. The relief pilot will verify any change in the Cockpit Voice Recorder annunciation and advise the other pilot when operating at a sample station without ground power. The Hydraulic System B status message that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated.

CAUTION: If the Traffic Advisory Display is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.

CAUTION: If the Engine Anti-Ice is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

The Oxygen Distribution quantity display that differs from the expected state requires the First Officer to verify the condition when conditions permit. The Wing Anti-Ice selector position that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Oxygen Distribution indication that differs from the expected state requires both pilots to brief the condition once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Flap Position Indication is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Transponder switch position that differs from the expected state requires both pilots to brief the condition when conditions permit. The captain will select any change in the Traffic Advisory Display annunciation and advise the other pilot once the checklist item is complete. The Speedbrake Handle annunciation is expected to read within the sample range of 13 to 16 units during taxi. If the Landing Gear Indication is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

During an extended ground delay, both pilots should record the Bleed Air Supply switch position before the next phase of flight. Refer to the related topic for additional sample context. The first officer will announce any change in the Oxygen Distribution indication and advise the other pilot when operating at a sample station without ground power. The captain will record any change in the Center Tank Pumps indication and advise the other pilot when the associated caution light remains illuminated. The first officer will brief any change in the Cockpit Voice Recorder status message and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

Refer to the related topic for additional sample context. The Transponder quantity display that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. The captain will select any change in the Bleed Air Supply selector position and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. During engine start, the First Officer should monitor the Traffic Advisory Display selector position once the checklist item is complete.

If the Brake Temperature Monitor is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Flap Position Indication indication that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: The first officer will brief any change in the Autobrake Selector advisory and advise the other pilot before the next phase of flight. The Autopilot Channel B annunciation that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight.

05.20.5 Operations Center Coordination Policy 5

This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Instruments quantity display is expected to read within the sample range of 30 to 40 units during a turnaround. The pilot monitoring will announce any change in the Cargo Smoke Detection annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. During a turnaround, the pilot flying should cross-check the Wing Anti-Ice switch position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Hydraulic System B annunciation	65 units	Monitor
Landing Gear Indication quantity display	96 units	Advisory only
Center Tank Pumps annunciation	31 units	Refer to related topic
Engine Anti-Ice annunciation	21 units	Refer to related topic
Probe Heat switch position	2 units	Refer to related topic

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B switch position is expected to read within the sample range of 30 to 36 units during an extended ground delay.

Condition	Sample value	Remarks
Hydraulic System A annunciation	45 units	Monitor
Standby Hydraulic advisory	42 units	Normal
Window Heat indication	10 units	Monitor
Pack Temperature Control selector position	82 units	Normal
Window Heat quantity display	15 units	Monitor

During approach, the First Officer should select the Autobrake Selector indication when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Cargo Smoke Detection indication that differs from the expected state requires the First Officer to select the condition when conditions permit. The captain will brief any change in the Bleed Air Supply status message and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

If the Speedbrake Handle is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The first officer will select any change in the Transponder switch position and advise the other pilot when operating at a sample station without ground power. The Fire Detection Loop annunciation is expected to read within the sample range of 57 to 60 units during a turnaround. If the Center Tank Pumps is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During descent, the Captain should confirm the Standby Hydraulic indication if a discrepancy is observed.

Both pilots will verify any change in the Primary Electrical Bus quantity display and advise the other pilot when operating at a sample station without ground power. The Fire Detection Loop indication is expected to read within the sample range of 78 to 85 units during an extended ground delay. The Traffic Advisory Display indication is expected to read within the sample range of 69 to 76 units during an extended ground delay. If the Autobrake Selector is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. If the Brake Temperature Monitor is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

05.20.6 Operations Center Coordination Policy 6

During preflight, the pilot monitoring should brief the Fuel Crossfeed indication before the next phase of flight. Refer to the related topic for additional sample context. The Autothrottle selector position is expected to read within the sample range of 79 to 85 units during preflight. The captain will brief any change in the Oxygen Distribution selector position and advise the other pilot when conditions permit.

During landing, the pilot monitoring should announce the Fuel Crossfeed indication if a discrepancy is observed. The captain will cross-check any change in the Probe Heat switch position and advise the other pilot if a discrepancy is observed. The Autopilot Channel B status message that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. The Stall Warning quantity display that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. If the Center Tank Pumps is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. During engine start, both pilots should verify the Autopilot Channel A status message when conditions permit.

If the Probe Heat is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. During cruise, the relief pilot should cross-check the Engine Anti-Ice quantity display when operating at a sample station without ground power. The pilot flying will select any change in the Autobrake Selector quantity display and advise the other pilot before the next phase of flight. The relief pilot will brief any change in the Cargo Smoke Detection selector position and advise the other pilot when operating at a sample station without ground power. If the Autopilot Channel B is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. See 11.20.5 Communications Policy 5.

NOTE: The relief pilot will record any change in the Engine Anti-Ice switch position and advise the other pilot if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, the pilot monitoring should confirm the Thrust Reverser switch position before the next phase of flight.

NOTE: The Cockpit Voice Recorder indication that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. The Primary Electrical Bus switch position that differs from the expected state requires the relief pilot to cross-check the condition when conditions permit.

Condition	Sample value	Remarks
Nosewheel Steering quantity display	38 units	Advisory only
Cargo Smoke Detection annunciation	92 units	Normal
Wing Anti-Ice indication	31 units	Advisory only
Ground Proximity Monitor annunciation	30 units	Monitor
Primary Electrical Bus switch position	35 units	Advisory only

05.20.7 Operations Center Coordination Policy 7

During a diversion, both pilots should select the Cockpit Voice Recorder switch position if the indication does not stabilize within the sample interval. The first officer will confirm any change in the Primary Electrical Bus indication and advise the other pilot if the indication does not stabilize within the sample interval. During descent, the First Officer should announce the Cabin Pressure Controller indication once the checklist item is complete. If the Auxiliary Power Unit is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

NOTE: The Autopilot Channel B selector position is expected to read within the sample range of 9 to 20 units during a maintenance-requested ground run. The Weather Radar indication that differs from the expected state requires both pilots to select the condition before the next phase of flight.

During cruise, the Captain should brief the Speedbrake Handle switch position when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will cross-check any change in the Oxygen Distribution selector position and advise the other pilot if a discrepancy is observed. If the Oxygen Distribution is inoperative, continue an extended ground delay only after the Captain has reviewed the

associated sample guidance.

Condition	Sample value	Remarks
Autopilot Channel B indication	39 units	Refer to related topic
Fire Detection Loop advisory	86 units	Monitor
Stall Warning status message	64 units	Advisory only
Engine Anti-Ice annunciation	29 units	Advisory only
Stall Warning switch position	10 units	Refer to related topic

During takeoff, the pilot flying should cross-check the Nosewheel Steering quantity display before the next phase of flight. Refer to the related topic for additional sample context. Both pilots will confirm any change in the Cabin Pressure Controller selector position and advise the other pilot if a discrepancy is observed. If the Nosewheel Steering is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

05.20.8 Operations Center Coordination Policy 8

The Fuel Crossfeed advisory is expected to read within the sample range of 33 to 42 units during a turnaround. If the Flight Management Computer is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will brief any change in the Standby Instruments advisory and advise the other pilot when operating at a sample station without ground power.

During cruise, the relief pilot should record the Traffic Advisory Display advisory when conditions permit. If the Cockpit Voice Recorder is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel A quantity display is expected to read within the sample range of 73 to 84 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure.

Values in this manual are invented and must not be used for any operational purpose. The Standby Instruments quantity display is expected to read within the sample range of 19 to 26 units during parking. The Flight Management Computer switch position is expected to read within the sample range of 95 to 101 units during taxi. The Primary Electrical Bus annunciation is expected to read within the sample range of 52 to 55 units during takeoff. The Thrust Reverser annunciation that differs from the expected state requires both pilots to record the condition when conditions permit. See 06.10.2 Ground Operations Policy 2.

NOTE: The Autopilot Channel B indication that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center.

CAUTION: If the Hydraulic System B is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

05.30 Operations Center Coordination: Part C

05.30.1 Operations Center Coordination Policy 1

The first officer will cross-check any change in the Hydraulic System B quantity display and advise the other pilot if a discrepancy is observed. The captain will verify any change in the Autothrottle annunciation and advise the other pilot when the associated caution light remains illuminated. The Fire Detection Loop annunciation is expected to read within the sample range of 55 to 61 units during parking. The Brake Temperature Monitor advisory that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. The Hydraulic System B switch position that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight.

Condition	Sample value	Remarks
Fire Detection Loop switch position	8 units	Monitor

Stall Warning status message	12 units	Normal
Brake Temperature Monitor indication	31 units	Normal
Probe Heat advisory	73 units	Normal
Wing Anti-Ice switch position	40 units	Advisory only
Cargo Smoke Detection annunciation	83 units	Normal
Window Heat advisory	39 units	Monitor

Condition	Sample value	Remarks
Pack Temperature Control status message	54 units	Normal
Pack Temperature Control switch position	56 units	Normal
Landing Gear Indication advisory	27 units	Normal
Brake Temperature Monitor switch position	6 units	Normal
Traffic Advisory Display indication	16 units	Monitor
Autopilot Channel A selector position	55 units	Monitor
Hydraulic System B annunciation	19 units	Monitor

The Standby Instruments advisory that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval. The Probe Heat selector position is expected to read within the sample range of 18 to 26 units during a diversion. The relief pilot will record any change in the Bleed Air Supply advisory and advise the other pilot if a discrepancy is observed. If the Stall Warning is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic advisory that differs from the expected state requires the Captain to confirm the condition before the next phase of flight. The Window Heat advisory that differs from the expected state requires the relief pilot to announce the condition when conditions permit. Refer to the related topic for additional sample context. The Stall Warning annunciation is expected to read within the sample range of 13 to 23 units during engine start. The Hydraulic System B quantity display is expected to read within the sample range of 16 to 28 units during parking.

The Fuel Crossfeed status message is expected to read within the sample range of 16 to 27 units during a diversion. During approach, both pilots should select the Autothrottle annunciation once the checklist item is complete. During descent, both pilots should announce the Weather Radar indication when conditions permit.

The Bleed Air Supply selector position that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated. The Bleed Air Supply indication is expected to read within the sample range of 33 to 41 units during cruise. Both pilots will announce any change in the Auxiliary Power Unit selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. During climb, the relief pilot should select the Primary Electrical Bus annunciation before the next phase of flight. During landing, both pilots should monitor the Stall Warning selector position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Primary Electrical Bus advisory	69 units	Advisory only
Bleed Air Supply switch position	44 units	Advisory only
Nosewheel Steering switch position	26 units	Advisory only

NOTE: The Autopilot Channel A switch position that differs from the expected state requires the First Officer to verify the condition when conditions permit. During preflight, both pilots should confirm the Autothrottle indication if a discrepancy is observed.

05.30.2 Operations Center Coordination Policy 2

Both pilots will announce any change in the Wing Anti-Ice indication and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. During a diversion, the pilot flying should monitor the Wing Anti-Ice annunciation if a discrepancy is observed. Both pilots will record any change in the Engine Anti-Ice status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: During a maintenance-requested ground run, the relief pilot should record the Standby Instruments selector position before the next phase of flight. If the Probe Heat is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

NOTE: The Cabin Pressure Controller annunciation that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. The Probe Heat advisory that differs from the expected state requires the First Officer to select the condition before the next phase of flight.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Weather Radar annunciation that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power. The Autopilot Channel B quantity display that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete.

- If the Window Heat is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.
- The Standby Instruments indication is expected to read within the sample range of 78 to 86 units during an extended ground delay.
- The Hydraulic System A switch position that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated.

05.30.3 Operations Center Coordination Policy 3

The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Hydraulic selector position is expected to read within the sample range of 18 to 22 units during a turnaround. The Autopilot Channel B indication is expected to read within the sample range of 20 to 30 units during a diversion. The pilot flying will select any change in the Autopilot Channel A annunciation and advise the other pilot before the next phase of flight. The Nosewheel Steering advisory that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. During parking, the pilot monitoring should confirm the Flight Management Computer switch position when operating at a sample station without ground power.

Condition	Sample value	Remarks
Landing Gear Indication annunciation	93 units	Monitor
Primary Electrical Bus switch position	66 units	Advisory only
Flight Management Computer indication	16 units	Refer to related topic
Flap Position Indication advisory	93 units	Monitor
Weather Radar annunciation	12 units	Normal
Oxygen Distribution indication	70 units	Normal
Probe Heat selector position	31 units	Advisory only

During cruise, the relief pilot should record the Cockpit Voice Recorder selector position when operating at a sample station without ground power. During preflight, the pilot flying should confirm the Flight Management Computer switch position before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication annunciation is expected to read within the sample range of 77 to 83 units

during climb. If the Auxiliary Power Unit is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: During taxi, the pilot monitoring should record the Primary Electrical Bus quantity display when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A annunciation that differs from the expected state requires the Captain to announce the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The pilot monitoring will select any change in the Weather Radar indication and advise the other pilot when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Flap Position Indication is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	61 units	Normal
Standby Hydraulic annunciation	73 units	Normal
Autopilot Channel B selector position	6 units	Refer to related topic
Engine Anti-Ice status message	68 units	Advisory only
Window Heat switch position	69 units	Normal
Probe Heat annunciation	44 units	Normal

If the Nosewheel Steering is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The Hydraulic System A quantity display is expected to read within the sample range of 88 to 91 units during a maintenance-requested ground run. The Flight Management Computer selector position is expected to read within the sample range of 11 to 23 units during climb.

The Transponder selector position that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. The Standby Hydraulic annunciation that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center. During descent, the First Officer should verify the Probe Heat status message before the next phase of flight.

05.30.4 Operations Center Coordination Policy 4

The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat switch position is expected to read within the sample range of 69 to 80 units during a maintenance-requested ground run. Refer to the related topic for additional sample context. If the Pack Temperature Control is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Cabin Pressure Controller advisory that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The Brake Temperature Monitor indication is expected to read within the sample range of 79 to 84 units during parking. The Traffic Advisory Display status message that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. The Center Tank Pumps quantity display is expected to read within the sample range of 12 to 24 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure.

The Transponder advisory is expected to read within the sample range of 39 to 45 units during descent. The Ground Proximity Monitor quantity display that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. The Engine Anti-Ice advisory is expected to read within the sample range of 73 to 78 units during parking. The Autopilot Channel B status message is expected to read within the sample range of 65 to 70 units during cruise. During preflight, the First Officer should verify the Speedbrake Handle annunciation when operating at a sample station without ground power.

The first officer will confirm any change in the Engine Anti-Ice status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will cross-check any change in the Oxygen Distribution quantity display and advise the other pilot before the next phase of flight. The Probe Heat switch position is expected to read within the sample range of 93 to 97 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Oxygen Distribution quantity display	86 units	Refer to related topic
Window Heat annunciation	61 units	Normal
Transponder status message	72 units	Normal
Speedbrake Handle switch position	67 units	Advisory only

If the Wing Anti-Ice is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The captain will monitor any change in the Autopilot Channel A selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Center Tank Pumps selector position that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval. During preflight, the pilot flying should cross-check the Center Tank Pumps switch position if a discrepancy is observed.

During parking, the relief pilot should monitor the Brake Temperature Monitor selector position when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, the First Officer should record the Cargo Smoke Detection indication when the associated caution light remains illuminated. If the Stall Warning is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Thrust Reverser selector position that differs from the expected state requires both pilots to monitor the condition when conditions permit.

The Nosewheel Steering annunciation that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. The Bleed Air Supply selector position is expected to read within the sample range of 59 to 68 units during parking. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. If the Speedbrake Handle is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

During takeoff, both pilots should record the Speedbrake Handle indication unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder switch position that differs from the expected state requires the relief pilot to verify the condition if the indication does not stabilize within the sample interval. The Traffic Advisory Display switch position that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. If the Cabin Pressure Controller is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

05.30.5 Operations Center Coordination Policy 5

The first officer will cross-check any change in the Wing Anti-Ice annunciation and advise the other pilot before the next phase of flight. During a turnaround, the Captain should confirm the Autothrottle annunciation when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The Traffic Advisory Display switch position is expected to read within the sample range of 8 to 16 units during an extended ground delay.

If the Hydraulic System A is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The first officer will confirm any change in the Transponder selector position and advise the other pilot when the associated caution light remains illuminated. The pilot flying will record any change in the Engine Anti-Ice indication and advise the other pilot before the next phase of flight. If the Autothrottle is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

- Both pilots will announce any change in the Brake Temperature Monitor indication and advise the other pilot if a discrepancy is observed.
- If the Weather Radar is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.
- During descent, the relief pilot should select the Nosewheel Steering quantity display when operating at a sample station without ground power.
- During descent, both pilots should select the Flap Position Indication annunciation once the checklist item is complete.
- During parking, both pilots should confirm the Nosewheel Steering indication unless directed otherwise by the Sample Operations Center.
- The Cabin Pressure Controller switch position that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight.

Values in this manual are invented and must not be used for any operational purpose. The Autopilot Channel A quantity display that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

The Standby Hydraulic annunciation that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power. The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete. The Auxiliary Power Unit switch position is expected to read within the sample range of 81 to 90 units during an extended ground delay.

- The Center Tank Pumps annunciation that differs from the expected state requires the Captain to select the condition when conditions permit.
- Both pilots will monitor any change in the Flap Position Indication indication and advise the other pilot when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.
- During descent, both pilots should cross-check the Wing Anti-Ice quantity display unless directed otherwise by the Sample Operations Center.
- Both pilots will cross-check any change in the Hydraulic System A indication and advise the other pilot if the indication does not stabilize within the sample interval.
- The relief pilot will record any change in the Cabin Pressure Controller annunciation and advise the other pilot if the indication does not stabilize within the sample interval.
- If the Pack Temperature Control is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.
- During cruise, the Captain should confirm the Speedbrake Handle annunciation if the indication does not stabilize within the sample interval.
- The wording here is placeholder content shaped like a procedure, not a procedure.

- The Nosewheel Steering advisory that differs from the expected state requires both pilots to verify the condition once the checklist item is complete.
- If the Probe Heat is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor status message is expected to read within the sample range of 14 to 18 units during an extended ground delay. The Fire Detection Loop status message is expected to read within the sample range of 36 to 40 units during parking. The Autobrake Selector selector position that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval.

NOTE: During preflight, the First Officer should select the Stall Warning selector position if the indication does not stabilize within the sample interval.

05.30.6 Operations Center Coordination Policy 6

During a maintenance-requested ground run, the First Officer should select the Flap Position Indication indication when the associated caution light remains illuminated. The pilot flying will brief any change in the Fuel Crossfeed advisory and advise the other pilot when conditions permit. The Ground Proximity Monitor switch position is expected to read within the sample range of 73 to 77 units during landing.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- During engine start, the relief pilot should monitor the Primary Electrical Bus indication before the next phase of flight.
- The relief pilot will verify any change in the Auxiliary Power Unit advisory and advise the other pilot once the checklist item is complete.
- If the Engine Anti-Ice is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.
- The Auxiliary Power Unit advisory is expected to read within the sample range of 80 to 88 units during takeoff.
- The Autopilot Channel A indication that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed.

NOTE: The pilot monitoring will cross-check any change in the Cargo Smoke Detection indication and advise the other pilot if a discrepancy is observed. The first officer will verify any change in the Hydraulic System A status message and advise the other pilot when the associated caution light remains illuminated.

The Traffic Advisory Display status message that differs from the expected state requires both pilots to select the condition once the checklist item is complete. The pilot flying will confirm any change in the Probe Heat status message and advise the other pilot once the checklist item is complete. The Transponder indication is expected to read within the sample range of 18 to 28 units during a diversion. During a diversion, the relief pilot should verify the Hydraulic System B indication when operating at a sample station without ground power. Both pilots will monitor any change in the Auxiliary Power Unit annunciation and advise the other pilot once the checklist item is complete. During preflight, both pilots should verify the Stall Warning advisory once the checklist item is complete.

The captain will record any change in the Autobrake Selector quantity display and advise the other pilot when conditions permit. The Cabin Pressure Controller switch position is expected to read within the sample range of 20 to 23 units during descent. The pilot monitoring will cross-check any change in the Landing Gear Indication indication and advise the other pilot if a discrepancy is observed. During cruise, the pilot flying should select the Thrust Reverser quantity display before the next phase of flight. The first officer will verify any change in the Autothrottle switch position and advise the other pilot when operating at a sample station without ground power.

05.30.7 Operations Center Coordination Policy 7

During an extended ground delay, the pilot flying should record the Autothrottle selector position once the checklist item is complete. If the Hydraulic System A is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Standby Hydraulic quantity display is expected to read within the sample range of 31 to 41 units during a maintenance-requested ground run. If the Autothrottle is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Probe Heat annunciation that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

- The Traffic Advisory Display selector position is expected to read within the sample range of 35 to 38 units during descent.
- If the Bleed Air Supply is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Autothrottle switch position that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Transponder switch position	10 units	Advisory only
Brake Temperature Monitor selector position	28 units	Normal
Standby Hydraulic selector position	79 units	Refer to related topic
Flight Management Computer switch position	60 units	Monitor
Probe Heat quantity display	55 units	Monitor
Nosewheel Steering indication	81 units	Advisory only

The relief pilot will announce any change in the Ground Proximity Monitor advisory and advise the other pilot once the checklist item is complete. The Cargo Smoke Detection annunciation is expected to read within the sample range of 22 to 34 units during engine start. The Oxygen Distribution annunciation is expected to read within the sample range of 12 to 20 units during takeoff. Values in this manual are invented and must not be used for any operational purpose. The Wing Anti-Ice status message is expected to read within the sample range of 49 to 55 units during descent. The Autopilot Channel B indication that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power.

NOTE: The Wing Anti-Ice quantity display is expected to read within the sample range of 59 to 64 units during cruise. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Window Heat indication	77 units	Normal
Standby Instruments quantity display	61 units	Monitor
Autopilot Channel B quantity display	81 units	Monitor
Autothrottle switch position	68 units	Monitor
Flap Position Indication indication	52 units	Advisory only

- The Flap Position Indication annunciation that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center.
- The pilot flying will record any change in the Auxiliary Power Unit indication and advise the other pilot before the next phase of flight.

- The pilot monitoring will select any change in the Hydraulic System A annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Brake Temperature Monitor selector position is expected to read within the sample range of 84 to 96 units during landing.
- The Cabin Pressure Controller quantity display is expected to read within the sample range of 4 to 13 units during approach.
- The relief pilot will verify any change in the Auxiliary Power Unit annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the Captain should verify the Probe Heat annunciation if a discrepancy is observed. If the Hydraulic System A is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Traffic Advisory Display is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

05.30.8 Operations Center Coordination Policy 8

During climb, the relief pilot should verify the Primary Electrical Bus quantity display if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Transponder switch position that differs from the expected state requires the pilot monitoring to select the condition when conditions permit. Both pilots will record any change in the Pack Temperature Control indication and advise the other pilot before the next phase of flight.

NOTE: The Stall Warning annunciation that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated. The Standby Hydraulic switch position that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Flight Management Computer is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The captain will record any change in the Weather Radar status message and advise the other pilot once the checklist item is complete. The pilot monitoring will confirm any change in the Cargo Smoke Detection selector position and advise the other pilot once the checklist item is complete.

The Autobrake Selector selector position that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed. The Speedbrake Handle annunciation is expected to read within the sample range of 13 to 23 units during a diversion. The relief pilot will announce any change in the Speedbrake Handle switch position and advise the other pilot once the checklist item is complete.

CAUTION: The Oxygen Distribution indication is expected to read within the sample range of 38 to 44 units during engine start.

If the Fuel Crossfeed is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Stall Warning switch position is expected to read within the sample range of 11 to 21 units during a diversion. The relief pilot will select any change in the Window Heat status message and advise the other pilot before the next phase of flight.

The Engine Anti-Ice switch position that differs from the expected state requires the pilot flying to select the condition before the next phase of flight. If the Traffic Advisory Display is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Brake Temperature Monitor switch position that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete.

Chapter 06 Ground Operations

06.10 Ground Operations: Part A

06.10.1 Ground Operations Policy 1

During climb, the First Officer should announce the Probe Heat selector position if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. During descent, the First Officer should brief the Center Tank Pumps indication when the associated caution light remains illuminated. If the Transponder is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the Captain should confirm the Thrust Reverser status message if a discrepancy is observed.

Condition	Sample value	Remarks
Thrust Reverser indication	50 units	Monitor
Cabin Pressure Controller switch position	14 units	Normal
Probe Heat advisory	70 units	Refer to related topic
Autopilot Channel A annunciation	52 units	Advisory only
Autobrake Selector advisory	7 units	Normal
Bleed Air Supply annunciation	16 units	Monitor
Autobrake Selector advisory	6 units	Normal

NOTE: The Speedbrake Handle advisory that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Standby Hydraulic quantity display that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. The Weather Radar quantity display that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The pilot flying will brief any change in the Flight Management Computer quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

If the Transponder is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Primary Electrical Bus selector position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Pack Temperature Control quantity display is expected to read within the sample range of 68 to 78 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Ground Proximity Monitor is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, both pilots should cross-check the Transponder annunciation when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will monitor any change in the Autothrottle indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The Nosewheel Steering quantity display that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. The Speedbrake Handle status message that differs from the expected state requires the Captain to record the condition when conditions permit.

06.10.2 Ground Operations Policy 2

During approach, both pilots should select the Cargo Smoke Detection advisory when the associated caution light remains illuminated. The Primary Electrical Bus indication that differs from the expected state requires both pilots to verify the condition before the next phase of flight. The pilot monitoring will record any change in the Thrust Reverser selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Pack Temperature Control advisory that differs from the expected state requires both pilots to record the condition when conditions permit.

The Hydraulic System B advisory that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. Both pilots will monitor any change in the Probe Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval. During parking, the pilot flying should announce the Standby Instruments advisory if a discrepancy is observed. The Flight Management Computer indication is expected to read within the sample range of 31 to 41 units during a turnaround. The Autopilot Channel B indication that differs from the expected state requires both pilots to select the condition if a discrepancy is observed. During taxi, the relief pilot should select the Oxygen Distribution switch position once the checklist item is complete.

If the Autopilot Channel A is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Ground Proximity Monitor is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context.

NOTE: The Fuel Crossfeed status message that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

If the Transponder is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. During a diversion, the Captain should confirm the Speedbrake Handle status message when operating at a sample station without ground power. The Bleed Air Supply advisory is expected to read within the sample range of 47 to 51 units during a diversion. The relief pilot will verify any change in the Probe Heat indication and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. If the Landing Gear Indication is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fuel Crossfeed quantity display	45 units	Refer to related topic
Fire Detection Loop switch position	77 units	Refer to related topic
Hydraulic System A status message	2 units	Refer to related topic

Values in this manual are invented and must not be used for any operational purpose. The Brake Temperature Monitor selector position that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated. The Hydraulic System A indication that differs from the expected state requires the pilot flying to select the condition when conditions permit.

06.10.3 Ground Operations Policy 3

The pilot flying will record any change in the Brake Temperature Monitor advisory and advise the other pilot once the checklist item is complete. If the Cabin Pressure Controller is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. During parking, the Captain should announce the Fuel Crossfeed advisory when operating at a sample station without ground power. If the Landing Gear Indication is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

If the Stall Warning is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Ground Proximity Monitor selector position is expected to read within the sample range of 84 to 94 units during preflight.

- During a diversion, both pilots should record the Center Tank Pumps quantity display when operating at a sample station without ground power.
- If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance.
- If the Hydraulic System B is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.
- Both pilots will cross-check any change in the Bleed Air Supply switch position and advise the other pilot before the next phase of flight.
- The relief pilot will monitor any change in the Autobrake Selector advisory and advise the other pilot when the associated caution light remains illuminated.
- The Flap Position Indication status message is expected to read within the sample range of 17 to 25 units during an extended ground delay.

The Cargo Smoke Detection switch position that differs from the expected state requires the pilot flying to announce the condition before the next phase of flight. If the Landing Gear Indication is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. Both pilots will announce any change in the Bleed Air Supply selector position and advise the other pilot if a discrepancy is observed. The pilot monitoring will brief any change in the Oxygen Distribution selector position and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Flap Position Indication switch position that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete.

CAUTION: If the Cockpit Voice Recorder is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

06.10.4 Ground Operations Policy 4

The Transponder advisory is expected to read within the sample range of 9 to 12 units during climb. If the Flight Management Computer is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The relief pilot will brief any change in the Wing Anti-Ice selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

The pilot flying will cross-check any change in the Engine Anti-Ice quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Autothrottle switch position that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated. During takeoff, both pilots should cross-check the Autopilot Channel A annunciation when conditions permit.

Condition	Sample value	Remarks
Weather Radar indication	46 units	Normal
Fire Detection Loop selector position	53 units	Refer to related topic
Landing Gear Indication switch position	52 units	Monitor
Wing Anti-Ice selector position	45 units	Normal
Flap Position Indication switch position	71 units	Refer to related topic

Autothrottle selector position	88 units	Refer to related topic
Autopilot Channel A advisory	5 units	Advisory only

Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor indication is expected to read within the sample range of 62 to 65 units during an extended ground delay. The Engine Anti-Ice annunciation that differs from the expected state requires the First Officer to monitor the condition if the indication does not stabilize within the sample interval. During descent, the Captain should verify the Standby Hydraulic annunciation when conditions permit.

This text is fictional and exists only to give the prototype realistic volume and structure. The Wing Anti-Ice quantity display is expected to read within the sample range of 26 to 32 units during a maintenance-requested ground run. The Cockpit Voice Recorder annunciation that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. The Engine Anti-Ice status message is expected to read within the sample range of 91 to 97 units during taxi. During engine start, the pilot monitoring should cross-check the Landing Gear Indication switch position when operating at a sample station without ground power.

NOTE: If the Oxygen Distribution is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Thrust Reverser indication that differs from the expected state requires the relief pilot to confirm the condition when conditions permit.

NOTE: The Wing Anti-Ice status message that differs from the expected state requires the First Officer to record the condition once the checklist item is complete.

The Auxiliary Power Unit status message that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. The first officer will select any change in the Stall Warning switch position and advise the other pilot when conditions permit. The Weather Radar indication is expected to read within the sample range of 13 to 20 units during a turnaround.

06.10.5 Ground Operations Policy 5

During landing, the Captain should record the Window Heat indication when the associated caution light remains illuminated. The Transponder indication that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. The Hydraulic System A annunciation that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight.

Refer to the related topic for additional sample context. The Autobrake Selector annunciation is expected to read within the sample range of 36 to 40 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure. If the Engine Anti-Ice is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

The relief pilot will verify any change in the Autobrake Selector status message and advise the other pilot when conditions permit. The first officer will announce any change in the Cabin Pressure Controller selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will record any change in the Autobrake Selector quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

- The Ground Proximity Monitor selector position is expected to read within the sample range of 16 to 28 units during a turnaround.
- The Standby Instruments annunciation is expected to read within the sample range of 73 to 80 units during parking.
- During cruise, the pilot monitoring should announce the Thrust Reverser status message when conditions permit.
- If the Oxygen Distribution is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

- The Speedbrake Handle annunciation is expected to read within the sample range of 25 to 34 units during climb.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The Window Heat indication is expected to read within the sample range of 29 to 41 units during an extended ground delay. The Oxygen Distribution quantity display that differs from the expected state requires the First Officer to brief the condition if a discrepancy is observed. The Ground Proximity Monitor advisory that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. See 06.10.6 Ground Operations Policy 6.

Condition	Sample value	Remarks
Brake Temperature Monitor switch position	52 units	Normal
Fire Detection Loop status message	62 units	Advisory only
Autobrake Selector switch position	17 units	Refer to related topic

- The pilot flying will announce any change in the Probe Heat quantity display and advise the other pilot before the next phase of flight.
- The first officer will cross-check any change in the Pack Temperature Control status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The pilot flying will cross-check any change in the Autobrake Selector advisory and advise the other pilot before the next phase of flight.
- The Weather Radar switch position is expected to read within the sample range of 88 to 92 units during a diversion.
- The wording here is placeholder content shaped like a procedure, not a procedure.

06.10.6 Ground Operations Policy 6

During a maintenance-requested ground run, the relief pilot should cross-check the Thrust Reverser advisory if the indication does not stabilize within the sample interval. Both pilots will monitor any change in the Auxiliary Power Unit indication and advise the other pilot when conditions permit. During approach, the pilot flying should confirm the Auxiliary Power Unit advisory once the checklist item is complete. The Standby Hydraulic indication that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete.

Condition	Sample value	Remarks
Fire Detection Loop switch position	89 units	Monitor
Auxiliary Power Unit status message	49 units	Normal
Fuel Crossfeed annunciation	36 units	Monitor
Cockpit Voice Recorder status message	37 units	Normal
Fuel Crossfeed status message	5 units	Refer to related topic
Autobrake Selector advisory	45 units	Monitor

- The Bleed Air Supply switch position that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed.
- The Standby Instruments switch position that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power.
- The Landing Gear Indication status message is expected to read within the sample range of 93 to 98 units during taxi.
- If the Ground Proximity Monitor is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: During a diversion, the pilot monitoring should verify the Fire Detection Loop status message if the indication does not stabilize within the sample interval.

NOTE: During a diversion, the pilot flying should cross-check the Stall Warning selector position when operating at a sample station without ground power. The Transponder status message is expected to read within the sample range of 90 to 101 units during an extended ground delay.

Refer to the related topic for additional sample context. The Speedbrake Handle switch position is expected to read within the sample range of 89 to 95 units during engine start. During preflight, both pilots should verify the Brake Temperature Monitor annunciation if the indication does not stabilize within the sample interval. If the Hydraulic System A is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The relief pilot will select any change in the Autopilot Channel A switch position and advise the other pilot once the checklist item is complete.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

06.10.7 Ground Operations Policy 7

During approach, the Captain should cross-check the Standby Instruments indication if a discrepancy is observed. During climb, the pilot flying should monitor the Hydraulic System A indication if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. During parking, both pilots should cross-check the Center Tank Pumps advisory unless directed otherwise by the Sample Operations Center. During descent, the relief pilot should confirm the Hydraulic System A selector position if the indication does not stabilize within the sample interval.

CAUTION: The Landing Gear Indication indication that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated. The Fire Detection Loop selector position that differs from the expected state requires the relief pilot to record the condition before the next phase of flight.

Values in this manual are invented and must not be used for any operational purpose. During taxi, the First Officer should monitor the Landing Gear Indication advisory if the indication does not stabilize within the sample interval. During takeoff, the First Officer should confirm the Brake Temperature Monitor selector position once the checklist item is complete.

During an extended ground delay, the pilot monitoring should select the Thrust Reverser indication once the checklist item is complete. The Weather Radar selector position that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Hydraulic System B indication	8 units	Monitor
Flap Position Indication selector position	88 units	Normal
Autopilot Channel A switch position	15 units	Refer to related topic
Oxygen Distribution quantity display	76 units	Normal
Cockpit Voice Recorder indication	37 units	Normal

Condition	Sample value	Remarks
Weather Radar status message	1 units	Monitor
Cockpit Voice Recorder switch position	13 units	Refer to related topic
Wing Anti-Ice status message	95 units	Normal

During an extended ground delay, the Captain should monitor the Stall Warning selector position before the next phase of flight. The Auxiliary Power Unit status message is expected to read within the sample range of 71 to 83 units during takeoff. If the Transponder is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. See 10.30.1 Adverse Weather Policy Policy 1.

06.10.8 Ground Operations Policy 8

During descent, the pilot monitoring should brief the Cargo Smoke Detection advisory if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will verify any change in the Autopilot Channel B annunciation and advise the other pilot when conditions permit.

- If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- The Landing Gear Indication switch position that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power.
- During descent, the relief pilot should record the Autobrake Selector annunciation when operating at a sample station without ground power.
- If the Flap Position Indication is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- The Window Heat indication that differs from the expected state requires the relief pilot to verify the condition when conditions permit.

Condition	Sample value	Remarks
Traffic Advisory Display indication	27 units	Refer to related topic
Pack Temperature Control annunciation	51 units	Normal
Cockpit Voice Recorder indication	10 units	Monitor
Oxygen Distribution annunciation	80 units	Advisory only
Engine Anti-Ice selector position	9 units	Refer to related topic
Auxiliary Power Unit status message	63 units	Advisory only

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Flap Position Indication selector position that differs from the expected state requires the First Officer to cross-check the condition when operating at a sample station without ground power.
- Both pilots will brief any change in the Flap Position Indication annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The Window Heat switch position that differs from the expected state requires the pilot monitoring to record the condition when conditions permit.

The Stall Warning indication is expected to read within the sample range of 17 to 28 units during preflight. Refer to the related topic for additional sample context. The pilot flying will cross-check any change in the Cockpit Voice Recorder advisory and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The Fuel Crossfeed selector position that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight. See 03.20.5 Crew Qualification Records Policy 5.

Condition	Sample value	Remarks
Landing Gear Indication selector position	86 units	Advisory only

Traffic Advisory Display switch position	26 units	Normal
Primary Electrical Bus indication	28 units	Refer to related topic
Speedbrake Handle indication	48 units	Advisory only
Fire Detection Loop advisory	2 units	Refer to related topic
Nosewheel Steering selector position	6 units	Monitor

CAUTION: Both pilots will brief any change in the Landing Gear Indication advisory and advise the other pilot when conditions permit. The Probe Heat annunciation that differs from the expected state requires both pilots to brief the condition unless directed otherwise by the Sample Operations Center.

06.20 Ground Operations: Part B

06.20.1 Ground Operations Policy 1

If the Fuel Crossfeed is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Traffic Advisory Display indication that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power. During parking, the pilot monitoring should monitor the Standby Hydraulic annunciation if a discrepancy is observed.

NOTE: The Autopilot Channel A switch position is expected to read within the sample range of 19 to 25 units during takeoff. The pilot monitoring will select any change in the Cargo Smoke Detection status message and advise the other pilot once the checklist item is complete.

The Standby Hydraulic indication that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete. If the Fire Detection Loop is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During an extended ground delay, the pilot flying should record the Transponder switch position once the checklist item is complete.

During approach, the pilot monitoring should monitor the Oxygen Distribution indication before the next phase of flight. The relief pilot will announce any change in the Stall Warning status message and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will select any change in the Bleed Air Supply advisory and advise the other pilot before the next phase of flight.

NOTE: The first officer will select any change in the Stall Warning status message and advise the other pilot if the indication does not stabilize within the sample interval. The Speedbrake Handle quantity display that differs from the expected state requires the First Officer to select the condition once the checklist item is complete.

Condition	Sample value	Remarks
Thrust Reverser quantity display	76 units	Normal
Primary Electrical Bus selector position	52 units	Normal
Fuel Crossfeed status message	66 units	Advisory only
Cockpit Voice Recorder annunciation	87 units	Monitor
Hydraulic System B switch position	76 units	Advisory only
Speedbrake Handle annunciation	58 units	Monitor

06.20.2 Ground Operations Policy 2

If the Autothrottle is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. If the Probe Heat is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed

the associated sample guidance. Both pilots will record any change in the Stall Warning advisory and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. If the Standby Instruments is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

NOTE: If the Primary Electrical Bus is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The Traffic Advisory Display switch position that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. During a diversion, the relief pilot should verify the Primary Electrical Bus indication unless directed otherwise by the Sample Operations Center. The Center Tank Pumps annunciation that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight. If the Ground Proximity Monitor is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. During engine start, both pilots should announce the Autothrottle status message once the checklist item is complete. The Ground Proximity Monitor advisory is expected to read within the sample range of 20 to 24 units during an extended ground delay.

During engine start, the Captain should select the Engine Anti-Ice quantity display if the indication does not stabilize within the sample interval. During parking, both pilots should record the Ground Proximity Monitor indication if a discrepancy is observed. The Autothrottle advisory is expected to read within the sample range of 96 to 104 units during a diversion. Values in this manual are invented and must not be used for any operational purpose. The Flight Management Computer selector position is expected to read within the sample range of 69 to 74 units during parking.

The first officer will brief any change in the Auxiliary Power Unit annunciation and advise the other pilot once the checklist item is complete. The Probe Heat selector position that differs from the expected state requires the Captain to verify the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Engine Anti-Ice advisory that differs from the expected state requires the pilot flying to confirm the condition when conditions permit.

06.20.3 Ground Operations Policy 3

The Fire Detection Loop indication that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete. The Hydraulic System B quantity display is expected to read within the sample range of 64 to 68 units during climb. During a maintenance-requested ground run, the Captain should announce the Probe Heat switch position if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

Values in this manual are invented and must not be used for any operational purpose. If the Autothrottle is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Speedbrake Handle switch position and advise the other pilot once the checklist item is complete. Both pilots will cross-check any change in the Cargo Smoke Detection quantity display and advise the other pilot when the associated caution light remains illuminated. The Auxiliary Power Unit status message that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Stall Warning annunciation	2 units	Advisory only
Thrust Reverser advisory	76 units	Refer to related topic
Weather Radar status message	30 units	Advisory only
Flap Position Indication selector position	71 units	Monitor

- If the Cabin Pressure Controller is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.
- The Bleed Air Supply annunciation is expected to read within the sample range of 77 to 81 units during approach.
- During a turnaround, the First Officer should record the Fire Detection Loop indication when operating at a sample station without ground power.
- If the Engine Anti-Ice is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- During approach, the pilot flying should record the Bleed Air Supply quantity display when operating at a sample station without ground power.
- If the Stall Warning is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

06.20.4 Ground Operations Policy 4

If the Autopilot Channel A is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. During a turnaround, the First Officer should monitor the Bleed Air Supply selector position when conditions permit. The first officer will cross-check any change in the Landing Gear Indication indication and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will verify any change in the Engine Anti-Ice annunciation and advise the other pilot before the next phase of flight. The Pack Temperature Control quantity display is expected to read within the sample range of 67 to 72 units during descent.

CAUTION: Both pilots will record any change in the Primary Electrical Bus quantity display and advise the other pilot when operating at a sample station without ground power. The Brake Temperature Monitor annunciation is expected to read within the sample range of 46 to 54 units during parking.

- If the Weather Radar is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.
- The Pack Temperature Control switch position that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.

NOTE: If the Standby Hydraulic is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.

The Bleed Air Supply annunciation that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. The pilot flying will brief any change in the Autopilot Channel A status message and advise the other pilot if the indication does not stabilize within the sample interval. During engine start, the pilot monitoring should select the Autopilot Channel A quantity display when operating at a sample station without ground power.

06.20.5 Ground Operations Policy 5

The Autopilot Channel A annunciation that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. The Autobrake Selector quantity display is expected to read within the sample range of 27 to 37 units during landing. This text is fictional and exists only to give the prototype realistic volume and structure. If the Cargo Smoke Detection is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The pilot monitoring will brief any change in the Ground Proximity Monitor annunciation and advise the other pilot when operating at a sample station without ground power. During an extended ground delay, both pilots should cross-check the Brake Temperature Monitor switch position before the next phase of flight.

Condition	Sample value	Remarks
-----------	--------------	---------

Cockpit Voice Recorder switch position	91 units	Normal
Auxiliary Power Unit indication	80 units	Monitor
Window Heat selector position	35 units	Monitor

NOTE: The Nosewheel Steering quantity display that differs from the expected state requires both pilots to brief the condition once the checklist item is complete.

Condition	Sample value	Remarks
Auxiliary Power Unit advisory	85 units	Normal
Brake Temperature Monitor status message	91 units	Refer to related topic
Autobrake Selector advisory	48 units	Refer to related topic
Traffic Advisory Display indication	49 units	Normal

06.20.6 Ground Operations Policy 6

If the Cockpit Voice Recorder is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will announce any change in the Bleed Air Supply quantity display and advise the other pilot once the checklist item is complete. The first officer will monitor any change in the Nosewheel Steering indication and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Probe Heat advisory	89 units	Refer to related topic
Autopilot Channel A quantity display	54 units	Advisory only
Weather Radar status message	11 units	Normal
Hydraulic System B switch position	86 units	Advisory only
Fire Detection Loop status message	24 units	Normal
Fire Detection Loop indication	48 units	Monitor

CAUTION: The Autopilot Channel B switch position that differs from the expected state requires both pilots to cross-check the condition when the associated caution light remains illuminated. If the Center Tank Pumps is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Thrust Reverser status message	65 units	Refer to related topic
Engine Anti-Ice indication	67 units	Refer to related topic
Fire Detection Loop annunciation	22 units	Normal
Pack Temperature Control advisory	3 units	Monitor
Traffic Advisory Display status message	34 units	Normal
Nosewheel Steering annunciation	92 units	Normal

- If the Cabin Pressure Controller is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.
- The Nosewheel Steering annunciation is expected to read within the sample range of 87 to 96 units during taxi.
- The Flight Management Computer switch position that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power.
- Refer to the related topic for additional sample context.

- The Engine Anti-Ice switch position is expected to read within the sample range of 45 to 49 units during engine start.

06.20.7 Ground Operations Policy 7

During a turnaround, the relief pilot should monitor the Pack Temperature Control status message when the associated caution light remains illuminated. Both pilots will announce any change in the Landing Gear Indication status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flap Position Indication indication is expected to read within the sample range of 86 to 97 units during preflight.

The pilot monitoring will select any change in the Cabin Pressure Controller advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cabin Pressure Controller is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During a diversion, the pilot flying should announce the Flight Management Computer quantity display when operating at a sample station without ground power. The captain will monitor any change in the Probe Heat status message and advise the other pilot if the indication does not stabilize within the sample interval.

- The Engine Anti-Ice advisory that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed.
- The Wing Anti-Ice switch position is expected to read within the sample range of 86 to 93 units during engine start.
- The Flight Management Computer quantity display that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight.

Condition	Sample value	Remarks
Window Heat status message	94 units	Refer to related topic
Transponder annunciation	2 units	Monitor
Nosewheel Steering annunciation	5 units	Advisory only
Cargo Smoke Detection indication	19 units	Normal

- The relief pilot will monitor any change in the Cockpit Voice Recorder indication and advise the other pilot when the associated caution light remains illuminated.
- The Window Heat selector position is expected to read within the sample range of 35 to 42 units during a turnaround.
- During a turnaround, the pilot monitoring should announce the Fuel Crossfeed advisory before the next phase of flight.
- If the Hydraulic System A is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The pilot flying will cross-check any change in the Flap Position Indication selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Cabin Pressure Controller switch position	77 units	Advisory only
Nosewheel Steering selector position	35 units	Normal
Brake Temperature Monitor annunciation	53 units	Monitor
Standby Instruments selector position	85 units	Monitor
Weather Radar status message	8 units	Advisory only
Hydraulic System A status message	27 units	Advisory only

The Autopilot Channel B advisory that differs from the expected state requires both pilots to monitor the condition if a discrepancy is observed. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. During cruise, both pilots should brief the Speedbrake Handle status message unless directed otherwise by the Sample Operations Center. During descent, the pilot monitoring should verify the Thrust Reverser indication once the checklist item is complete. The Autothrottle switch position is expected to read within the sample range of 64 to 75 units during a maintenance-requested ground run.

NOTE: If the Traffic Advisory Display is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

06.20.8 Ground Operations Policy 8

The pilot flying will record any change in the Bleed Air Supply advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle selector position that differs from the expected state requires the Captain to record the condition when the associated caution light remains illuminated. The first officer will monitor any change in the Cockpit Voice Recorder status message and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: During approach, the First Officer should monitor the Window Heat selector position when operating at a sample station without ground power. During a diversion, the Captain should select the Landing Gear Indication switch position before the next phase of flight.

During climb, the First Officer should monitor the Standby Hydraulic indication if a discrepancy is observed. The Traffic Advisory Display quantity display that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete. The first officer will monitor any change in the Oxygen Distribution annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Center Tank Pumps selector position that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. If the Stall Warning is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.

During taxi, the Captain should confirm the Traffic Advisory Display annunciation when operating at a sample station without ground power. The Center Tank Pumps advisory that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight. The Autopilot Channel B quantity display is expected to read within the sample range of 59 to 68 units during taxi. The Probe Heat switch position is expected to read within the sample range of 79 to 86 units during an extended ground delay.

CAUTION: The captain will verify any change in the Bleed Air Supply annunciation and advise the other pilot when the associated caution light remains illuminated.

06.30 Ground Operations: Part C

06.30.1 Ground Operations Policy 1

If the Standby Hydraulic is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Fire Detection Loop annunciation is expected to read within the sample range of 15 to 25 units during landing.

- Refer to the related topic for additional sample context.
- The Standby Instruments indication that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval.
- The first officer will monitor any change in the Oxygen Distribution quantity display and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
-----------	--------------	---------

Transponder advisory	73 units	Advisory only
Speedbrake Handle status message	86 units	Monitor
Speedbrake Handle selector position	14 units	Advisory only
Auxiliary Power Unit switch position	13 units	Normal
Bleed Air Supply status message	28 units	Advisory only
Hydraulic System A advisory	50 units	Monitor
Oxygen Distribution annunciation	13 units	Advisory only

NOTE: If the Wing Anti-Ice is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

During an extended ground delay, the relief pilot should record the Engine Anti-Ice indication unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice indication is expected to read within the sample range of 26 to 32 units during approach. The Flap Position Indication status message that differs from the expected state requires both pilots to verify the condition when the associated caution light remains illuminated.

06.30.2 Ground Operations Policy 2

Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. During a turnaround, the pilot flying should announce the Nosewheel Steering annunciation when conditions permit.

NOTE: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Cabin Pressure Controller switch position	28 units	Refer to related topic
Hydraulic System B quantity display	62 units	Normal
Autothrottle annunciation	94 units	Normal

Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. During descent, the pilot flying should confirm the Autopilot Channel A switch position before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, the Captain should cross-check the Thrust Reverser selector position if a discrepancy is observed. The Hydraulic System B quantity display that differs from the expected state requires the pilot flying to select the condition when conditions permit.

Condition	Sample value	Remarks
Cabin Pressure Controller advisory	90 units	Monitor
Transponder selector position	80 units	Refer to related topic
Stall Warning status message	27 units	Refer to related topic
Ground Proximity Monitor indication	78 units	Normal

NOTE: During takeoff, the relief pilot should select the Hydraulic System A status message once the checklist item is complete.

06.30.3 Ground Operations Policy 3

The wording here is placeholder content shaped like a procedure, not a procedure. If the Autopilot Channel B is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The Engine Anti-Ice indication that differs from the expected state requires the pilot monitoring to record the condition when conditions permit.

The first officer will confirm any change in the Bleed Air Supply selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System A advisory that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

If the Probe Heat is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Standby Hydraulic annunciation and advise the other pilot when the associated caution light remains illuminated. The captain will select any change in the Flap Position Indication status message and advise the other pilot when the associated caution light remains illuminated. During takeoff, the pilot flying should monitor the Wing Anti-Ice annunciation when the associated caution light remains illuminated.

During parking, the pilot flying should verify the Primary Electrical Bus advisory once the checklist item is complete. The Fire Detection Loop indication that differs from the expected state requires the relief pilot to brief the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Oxygen Distribution annunciation is expected to read within the sample range of 37 to 41 units during approach.

Condition	Sample value	Remarks
Transponder status message	24 units	Advisory only
Wing Anti-Ice selector position	14 units	Advisory only
Brake Temperature Monitor quantity display	99 units	Monitor

Condition	Sample value	Remarks
Cockpit Voice Recorder advisory	41 units	Refer to related topic
Stall Warning indication	91 units	Monitor
Ground Proximity Monitor annunciation	12 units	Advisory only
Autobrake Selector annunciation	17 units	Normal
Flight Management Computer quantity display	51 units	Advisory only
Flap Position Indication quantity display	19 units	Advisory only
Fuel Crossfeed quantity display	3 units	Refer to related topic

06.30.4 Ground Operations Policy 4

The first officer will monitor any change in the Nosewheel Steering switch position and advise the other pilot before the next phase of flight. During cruise, the First Officer should verify the Autopilot Channel A quantity display if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The Primary Electrical Bus quantity display is expected to read within the sample range of 60 to 70 units during approach.

NOTE: If the Center Tank Pumps is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

NOTE: During takeoff, the Captain should monitor the Cargo Smoke Detection quantity display when the associated caution light remains illuminated. The pilot monitoring will select any change in the Primary Electrical Bus selector position and advise the other pilot if the indication does not stabilize within the sample interval.

If the Fuel Crossfeed is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The relief pilot will brief any change in the Oxygen Distribution switch position and advise the other pilot when conditions permit. The Brake Temperature Monitor status message is expected to read within the sample range of 32 to 40 units during approach. The Weather Radar advisory is expected to read within the sample range of 43 to 50 units during taxi. The Autobrake Selector selector position is expected to read within the sample range of 92

to 95 units during a turnaround.

NOTE: The Cockpit Voice Recorder advisory is expected to read within the sample range of 26 to 29 units during preflight.

Condition	Sample value	Remarks
Primary Electrical Bus status message	94 units	Refer to related topic
Auxiliary Power Unit switch position	89 units	Advisory only
Landing Gear Indication quantity display	51 units	Monitor
Standby Instruments status message	52 units	Refer to related topic

- If the Standby Instruments is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.
- The Oxygen Distribution advisory that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight.
- During preflight, the Captain should announce the Auxiliary Power Unit indication if a discrepancy is observed.
- The captain will record any change in the Traffic Advisory Display annunciation and advise the other pilot when conditions permit.
- If the Bleed Air Supply is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

NOTE: The Speedbrake Handle status message that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. The pilot monitoring will monitor any change in the Nosewheel Steering advisory and advise the other pilot when operating at a sample station without ground power. If the Autobrake Selector is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

06.30.5 Ground Operations Policy 5

The Autopilot Channel B switch position that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated. If the Center Tank Pumps is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Thrust Reverser status message is expected to read within the sample range of 95 to 102 units during climb. The Primary Electrical Bus indication is expected to read within the sample range of 90 to 97 units during approach. If the Cockpit Voice Recorder is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Pack Temperature Control indication	82 units	Refer to related topic
Flap Position Indication quantity display	90 units	Normal
Cabin Pressure Controller quantity display	16 units	Refer to related topic
Cargo Smoke Detection selector position	10 units	Refer to related topic
Auxiliary Power Unit status message	18 units	Advisory only
Flight Management Computer indication	47 units	Normal

Condition	Sample value	Remarks
Primary Electrical Bus annunciation	25 units	Monitor

Cabin Pressure Controller switch position	57 units	Normal
Cabin Pressure Controller quantity display	4 units	Monitor
Cabin Pressure Controller switch position	80 units	Monitor
Brake Temperature Monitor quantity display	70 units	Refer to related topic
Weather Radar annunciation	5 units	Monitor

CAUTION: The Window Heat indication is expected to read within the sample range of 88 to 96 units during an extended ground delay.

- Refer to the related topic for additional sample context.
- During approach, both pilots should cross-check the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center.
- During parking, the relief pilot should record the Engine Anti-Ice quantity display when the associated caution light remains illuminated.
- During approach, the pilot flying should monitor the Traffic Advisory Display status message when conditions permit.
- If the Bleed Air Supply is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance.

06.30.6 Ground Operations Policy 6

Both pilots will verify any change in the Primary Electrical Bus selector position and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. The Brake Temperature Monitor status message is expected to read within the sample range of 61 to 73 units during taxi. The Standby Instruments annunciation is expected to read within the sample range of 45 to 56 units during preflight.

Condition	Sample value	Remarks
Thrust Reverser indication	84 units	Monitor
Autobrake Selector quantity display	89 units	Advisory only
Thrust Reverser indication	77 units	Refer to related topic
Cockpit Voice Recorder switch position	86 units	Monitor

Both pilots will announce any change in the Standby Hydraulic advisory and advise the other pilot when conditions permit. The Weather Radar status message is expected to read within the sample range of 37 to 45 units during parking. The Autobrake Selector advisory is expected to read within the sample range of 90 to 98 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose. The Flap Position Indication indication is expected to read within the sample range of 54 to 58 units during preflight.

Condition	Sample value	Remarks
Wing Anti-Ice annunciation	10 units	Advisory only
Autobrake Selector selector position	16 units	Normal
Stall Warning switch position	88 units	Advisory only
Autopilot Channel B quantity display	88 units	Normal
Flight Management Computer indication	85 units	Monitor

- During parking, the Captain should verify the Weather Radar indication if a discrepancy is observed.
- The first officer will brief any change in the Engine Anti-Ice switch position and advise the other pilot if the indication does not stabilize within the sample interval.

- The Landing Gear Indication switch position is expected to read within the sample range of 96 to 102 units during preflight.

The Flight Management Computer quantity display is expected to read within the sample range of 57 to 68 units during a diversion. If the Stall Warning is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. The Oxygen Distribution selector position is expected to read within the sample range of 24 to 28 units during a turnaround. The Traffic Advisory Display switch position is expected to read within the sample range of 52 to 58 units during approach. If the Cargo Smoke Detection is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

06.30.7 Ground Operations Policy 7

The pilot monitoring will announce any change in the Window Heat quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autobrake Selector advisory is expected to read within the sample range of 46 to 53 units during descent. If the Autopilot Channel A is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The Ground Proximity Monitor indication is expected to read within the sample range of 77 to 83 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. During descent, the pilot monitoring should select the Autopilot Channel B status message when operating at a sample station without ground power. The pilot flying will confirm any change in the Hydraulic System B selector position and advise the other pilot before the next phase of flight.

CAUTION: The pilot flying will verify any change in the Standby Instruments advisory and advise the other pilot when operating at a sample station without ground power.

The first officer will monitor any change in the Autopilot Channel B annunciation and advise the other pilot if a discrepancy is observed. The Hydraulic System A indication that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. The Autobrake Selector selector position that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight.

During takeoff, the relief pilot should confirm the Traffic Advisory Display status message before the next phase of flight. The pilot flying will announce any change in the Engine Anti-Ice quantity display and advise the other pilot when conditions permit. The Probe Heat status message is expected to read within the sample range of 6 to 9 units during climb. Both pilots will cross-check any change in the Center Tank Pumps status message and advise the other pilot before the next phase of flight.

- During approach, the First Officer should select the Ground Proximity Monitor status message once the checklist item is complete.
- The Transponder indication that differs from the expected state requires both pilots to announce the condition unless directed otherwise by the Sample Operations Center.
- The Auxiliary Power Unit status message that differs from the expected state requires the Captain to verify the condition when conditions permit.
- The captain will verify any change in the Auxiliary Power Unit selector position and advise the other pilot when the associated caution light remains illuminated.

06.30.8 Ground Operations Policy 8

During a turnaround, the pilot flying should announce the Primary Electrical Bus selector position before the next phase of flight. The relief pilot will announce any change in the Center Tank Pumps annunciation and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the relief pilot should verify the Center Tank Pumps indication if a discrepancy is observed.

The first officer will monitor any change in the Brake Temperature Monitor status message and advise the other pilot before the next phase of flight. If the Flap Position Indication is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

- Refer to the related topic for additional sample context.
- If the Window Heat is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.
- The Cargo Smoke Detection switch position that differs from the expected state requires the Captain to confirm the condition before the next phase of flight.
- The Fuel Crossfeed status message is expected to read within the sample range of 22 to 25 units during a turnaround.
- The Wing Anti-Ice indication that differs from the expected state requires the pilot monitoring to brief the condition once the checklist item is complete.

Condition	Sample value	Remarks
Fuel Crossfeed annunciation	64 units	Monitor
Fire Detection Loop annunciation	77 units	Monitor
Hydraulic System A status message	32 units	Normal
Wing Anti-Ice quantity display	97 units	Refer to related topic
Window Heat quantity display	52 units	Advisory only
Autothrottle indication	5 units	Monitor
Weather Radar selector position	55 units	Advisory only

CAUTION: The pilot flying will select any change in the Autopilot Channel A indication and advise the other pilot if the indication does not stabilize within the sample interval.

During takeoff, the Captain should cross-check the Flight Management Computer status message before the next phase of flight. The first officer will brief any change in the Wing Anti-Ice status message and advise the other pilot if the indication does not stabilize within the sample interval. The captain will confirm any change in the Landing Gear Indication status message and advise the other pilot when conditions permit.

Refer to the related topic for additional sample context. If the Cargo Smoke Detection is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Oxygen Distribution advisory that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. If the Pack Temperature Control is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Speedbrake Handle switch position that differs from the expected state requires the Captain to confirm the condition before the next phase of flight.

If the Hydraulic System B is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. During engine start, the relief pilot should announce the Autopilot Channel B annunciation once the checklist item is complete. Refer to the related topic for additional sample context. During descent, the First Officer should brief the Oxygen Distribution status message if a discrepancy is observed. See 14.20.1 Irregular Operations Policy 1.

Chapter 07 Departure

07.10 Departure: Part A

07.10.1 Departure Policy 1

This text is fictional and exists only to give the prototype realistic volume and structure. If the Landing Gear Indication is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Stall Warning quantity display is expected to read within the sample range of 90 to 100 units during takeoff. The Ground Proximity Monitor switch position that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed. During cruise, the relief pilot should confirm the Hydraulic System A annunciation unless directed otherwise by the Sample Operations Center.

The Autobrake Selector indication that differs from the expected state requires the pilot flying to confirm the condition when the associated caution light remains illuminated. If the Brake Temperature Monitor is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, the pilot flying should monitor the Wing Anti-Ice advisory before the next phase of flight. The Brake Temperature Monitor status message that differs from the expected state requires the pilot monitoring to monitor the condition before the next phase of flight.

The Autothrottle advisory is expected to read within the sample range of 93 to 100 units during takeoff. During takeoff, the pilot flying should monitor the Pack Temperature Control indication unless directed otherwise by the Sample Operations Center. During takeoff, the relief pilot should confirm the Autobrake Selector status message when operating at a sample station without ground power. The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval.

The pilot monitoring will announce any change in the Speedbrake Handle quantity display and advise the other pilot when the associated caution light remains illuminated. During cruise, the relief pilot should brief the Wing Anti-Ice annunciation when the associated caution light remains illuminated. During a turnaround, the pilot monitoring should cross-check the Hydraulic System A switch position when operating at a sample station without ground power. During a diversion, both pilots should select the Autopilot Channel B switch position when the associated caution light remains illuminated. The Center Tank Pumps annunciation that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. The Brake Temperature Monitor indication is expected to read within the sample range of 73 to 84 units during takeoff.

CAUTION: During preflight, the First Officer should brief the Engine Anti-Ice annunciation once the checklist item is complete.

07.10.2 Departure Policy 2

The wording here is placeholder content shaped like a procedure, not a procedure. During preflight, the relief pilot should cross-check the Brake Temperature Monitor indication before the next phase of flight. The relief pilot will confirm any change in the Nosewheel Steering switch position and advise the other pilot when conditions permit. The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed.

- The Traffic Advisory Display status message that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed.
- The Bleed Air Supply switch position is expected to read within the sample range of 91 to 94 units during parking.
- The Flight Management Computer annunciation that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight.

- The Landing Gear Indication indication is expected to read within the sample range of 52 to 62 units during cruise.
- The Bleed Air Supply indication is expected to read within the sample range of 4 to 7 units during descent.

The first officer will confirm any change in the Ground Proximity Monitor quantity display and advise the other pilot if a discrepancy is observed. The pilot monitoring will cross-check any change in the Engine Anti-Ice selector position and advise the other pilot if the indication does not stabilize within the sample interval. The Standby Instruments advisory that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete. If the Cockpit Voice Recorder is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

The Wing Anti-Ice advisory is expected to read within the sample range of 9 to 16 units during preflight. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Instruments indication that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight. The Pack Temperature Control status message that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. The Autopilot Channel B status message is expected to read within the sample range of 3 to 11 units during engine start.

NOTE: If the Traffic Advisory Display is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The first officer will select any change in the Autothrottle selector position and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Bleed Air Supply annunciation	96 units	Advisory only
Nosewheel Steering quantity display	84 units	Refer to related topic
Fuel Crossfeed switch position	83 units	Normal
Engine Anti-Ice advisory	85 units	Monitor
Auxiliary Power Unit indication	3 units	Refer to related topic
Autothrottle switch position	55 units	Monitor
Landing Gear Indication status message	59 units	Monitor

07.10.3 Departure Policy 3

During parking, the relief pilot should brief the Fire Detection Loop indication if the indication does not stabilize within the sample interval. The pilot monitoring will select any change in the Cargo Smoke Detection annunciation and advise the other pilot if a discrepancy is observed. The captain will confirm any change in the Oxygen Distribution quantity display and advise the other pilot when the associated caution light remains illuminated. During engine start, the First Officer should announce the Stall Warning advisory if a discrepancy is observed. If the Weather Radar is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

During taxi, the First Officer should monitor the Bleed Air Supply selector position unless directed otherwise by the Sample Operations Center. The Flight Management Computer quantity display that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. During cruise, the Captain should verify the Engine Anti-Ice status message if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Cockpit Voice Recorder is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

NOTE: The Engine Anti-Ice switch position that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed.

The Transponder advisory is expected to read within the sample range of 34 to 38 units during cruise. The Primary Electrical Bus annunciation that differs from the expected state requires the First Officer to announce the condition unless directed otherwise by the Sample Operations Center. During takeoff, the pilot monitoring should select the Flight Management Computer annunciation before the next phase of flight.

The relief pilot will brief any change in the Cabin Pressure Controller quantity display and advise the other pilot if a discrepancy is observed. If the Flap Position Indication is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

NOTE: If the Transponder is inoperative, continue a maintenance-requested ground run only after both pilots have reviewed the associated sample guidance. The Hydraulic System B advisory is expected to read within the sample range of 45 to 56 units during climb.

During approach, the pilot monitoring should verify the Fuel Crossfeed selector position unless directed otherwise by the Sample Operations Center. If the Primary Electrical Bus is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

07.10.4 Departure Policy 4

The Wing Anti-Ice status message is expected to read within the sample range of 2 to 9 units during a maintenance-requested ground run. During an extended ground delay, the relief pilot should confirm the Traffic Advisory Display selector position unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The Center Tank Pumps advisory is expected to read within the sample range of 36 to 43 units during climb.

The captain will record any change in the Autobrake Selector indication and advise the other pilot when conditions permit. The captain will confirm any change in the Autobrake Selector advisory and advise the other pilot before the next phase of flight. During parking, the Captain should verify the Weather Radar selector position once the checklist item is complete.

The Center Tank Pumps advisory that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval. The Hydraulic System B quantity display is expected to read within the sample range of 10 to 14 units during a diversion. If the Wing Anti-Ice is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Speedbrake Handle selector position	80 units	Normal
Fire Detection Loop annunciation	70 units	Advisory only
Fire Detection Loop quantity display	28 units	Normal
Standby Hydraulic switch position	8 units	Advisory only
Autopilot Channel B switch position	91 units	Normal

Condition	Sample value	Remarks
Landing Gear Indication advisory	89 units	Refer to related topic
Stall Warning quantity display	93 units	Refer to related topic
Landing Gear Indication advisory	16 units	Normal
Stall Warning selector position	95 units	Normal
Thrust Reverser status message	86 units	Normal

07.10.5 Departure Policy 5

The Bleed Air Supply selector position is expected to read within the sample range of 63 to 68 units during landing. During descent, the Captain should confirm the Wing Anti-Ice selector position unless directed otherwise by the Sample Operations Center. The Window Heat status message that differs from the expected state requires the First Officer to verify the condition if a discrepancy is observed. The pilot flying will cross-check any change in the Transponder indication and advise the other pilot before the next phase of flight. The Landing Gear Indication status message is expected to read within the sample range of 4 to 9 units during a maintenance-requested ground run.

The relief pilot will brief any change in the Engine Anti-Ice advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Speedbrake Handle annunciation is expected to read within the sample range of 61 to 66 units during a maintenance-requested ground run. The captain will monitor any change in the Oxygen Distribution quantity display and advise the other pilot once the checklist item is complete. During engine start, the pilot flying should monitor the Engine Anti-Ice advisory once the checklist item is complete. The Nosewheel Steering indication that differs from the expected state requires the Captain to verify the condition once the checklist item is complete. If the Flap Position Indication is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

The Engine Anti-Ice indication is expected to read within the sample range of 72 to 83 units during landing. The Wing Anti-Ice quantity display is expected to read within the sample range of 64 to 74 units during landing. The pilot flying will verify any change in the Flap Position Indication switch position and advise the other pilot when operating at a sample station without ground power. The pilot monitoring will record any change in the Cargo Smoke Detection selector position and advise the other pilot before the next phase of flight. The pilot flying will brief any change in the Weather Radar status message and advise the other pilot if the indication does not stabilize within the sample interval.

The Primary Electrical Bus switch position that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. If the Autobrake Selector is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Autobrake Selector advisory is expected to read within the sample range of 89 to 92 units during an extended ground delay. The Cockpit Voice Recorder switch position is expected to read within the sample range of 3 to 12 units during a maintenance-requested ground run. During a maintenance-requested ground run, the relief pilot should cross-check the Window Heat status message when conditions permit.

NOTE: Refer to the related topic for additional sample context.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

- The Weather Radar annunciation that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval.
- If the Flight Management Computer is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.
- If the Standby Hydraulic is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.
- During a diversion, the pilot flying should confirm the Hydraulic System A status message unless directed otherwise by the Sample Operations Center.
- The Autothrottle selector position that differs from the expected state requires the First Officer to confirm the condition unless directed otherwise by the Sample Operations Center.

07.10.6 Departure Policy 6

The first officer will record any change in the Speedbrake Handle switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Standby Instruments selector position that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. If the Window Heat is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. The Landing Gear Indication switch position is expected to read within the sample range of 16 to 21 units during parking. During climb, the pilot monitoring should select the Autothrottle advisory when operating at a sample station without ground power.

The Weather Radar advisory is expected to read within the sample range of 65 to 68 units during parking. The Wing Anti-Ice selector position that differs from the expected state requires the pilot monitoring to monitor the condition when conditions permit. The captain will brief any change in the Weather Radar selector position and advise the other pilot before the next phase of flight. During engine start, the First Officer should announce the Autopilot Channel B indication when conditions permit.

Condition	Sample value	Remarks
Pack Temperature Control switch position	22 units	Refer to related topic
Autopilot Channel B indication	8 units	Advisory only
Pack Temperature Control annunciation	98 units	Refer to related topic

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

This text is fictional and exists only to give the prototype realistic volume and structure. During climb, the Captain should confirm the Probe Heat switch position once the checklist item is complete. The Auxiliary Power Unit switch position that differs from the expected state requires the pilot monitoring to record the condition when the associated caution light remains illuminated.

If the Flight Management Computer is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. The Speedbrake Handle indication that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight. Refer to the related topic for additional sample context. During landing, the pilot monitoring should confirm the Autopilot Channel A selector position when the associated caution light remains illuminated. The Autobrake Selector annunciation that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed.

Both pilots will confirm any change in the Cockpit Voice Recorder indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Hydraulic System A status message is expected to read within the sample range of 19 to 28 units during taxi. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will cross-check any change in the Cockpit Voice Recorder selector position and advise the other pilot if a discrepancy is observed.

- The first officer will cross-check any change in the Cockpit Voice Recorder selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Brake Temperature Monitor quantity display that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight.
- The Autopilot Channel B annunciation is expected to read within the sample range of 35 to 38 units during landing.
- The relief pilot will monitor any change in the Speedbrake Handle status message and advise the other pilot if a discrepancy is observed.
- If the Cabin Pressure Controller is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

07.10.7 Departure Policy 7

The Autobrake Selector status message that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. The Nosewheel Steering advisory is expected to read within the sample range of 17 to 28 units during a maintenance-requested ground run. The Hydraulic System B indication is expected to read within the sample range of 71 to 74 units during landing. The Window Heat selector

position is expected to read within the sample range of 30 to 34 units during a maintenance-requested ground run. If the Flap Position Indication is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Flight Management Computer advisory	83 units	Monitor
Autopilot Channel A selector position	48 units	Normal
Fire Detection Loop selector position	60 units	Refer to related topic
Bleed Air Supply switch position	47 units	Advisory only

CAUTION: The Fire Detection Loop advisory that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, the Captain should brief the Brake Temperature Monitor selector position if the indication does not stabilize within the sample interval.

If the Flight Management Computer is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will select any change in the Autothrottle indication and advise the other pilot when the associated caution light remains illuminated. The pilot monitoring will monitor any change in the Flap Position Indication selector position and advise the other pilot when the associated caution light remains illuminated.

CAUTION: During takeoff, both pilots should announce the Stall Warning switch position when the associated caution light remains illuminated.

CAUTION: The pilot flying will announce any change in the Engine Anti-Ice status message and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure.

The Weather Radar advisory is expected to read within the sample range of 51 to 59 units during a turnaround. Both pilots will select any change in the Primary Electrical Bus selector position and advise the other pilot if a discrepancy is observed. The Fuel Crossfeed indication that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete. During landing, the pilot flying should record the Oxygen Distribution indication once the checklist item is complete. The Autobrake Selector selector position is expected to read within the sample range of 60 to 72 units during parking. The Traffic Advisory Display selector position is expected to read within the sample range of 23 to 26 units during landing.

The pilot flying will brief any change in the Weather Radar indication and advise the other pilot once the checklist item is complete. During a turnaround, the pilot flying should select the Stall Warning quantity display when conditions permit. Refer to the related topic for additional sample context. The Transponder advisory is expected to read within the sample range of 36 to 43 units during approach. If the Probe Heat is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

07.10.8 Departure Policy 8

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will verify any change in the Brake Temperature Monitor advisory and advise the other pilot when operating at a sample station without ground power.

NOTE: If the Autothrottle is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.

- During parking, the First Officer should monitor the Flight Management Computer indication when the associated caution light remains illuminated.

- The Flight Management Computer status message is expected to read within the sample range of 55 to 64 units during a diversion.
- The Flap Position Indication advisory is expected to read within the sample range of 2 to 5 units during preflight.
- Refer to the related topic for additional sample context.
- The Landing Gear Indication status message is expected to read within the sample range of 68 to 71 units during climb.
- If the Flight Management Computer is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.
- The Flap Position Indication quantity display is expected to read within the sample range of 35 to 40 units during takeoff.
- If the Traffic Advisory Display is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Wing Anti-Ice selector position is expected to read within the sample range of 13 to 22 units during landing.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Standby Instruments is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.
- The Landing Gear Indication status message that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight.
- During climb, the pilot monitoring should confirm the Traffic Advisory Display quantity display once the checklist item is complete.
- Refer to the related topic for additional sample context.
- The relief pilot will confirm any change in the Hydraulic System A advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- This text is fictional and exists only to give the prototype realistic volume and structure.

The captain will cross-check any change in the Auxiliary Power Unit annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The captain will confirm any change in the Standby Instruments indication and advise the other pilot once the checklist item is complete. If the Fire Detection Loop is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Ground Proximity Monitor quantity display that differs from the expected state requires the Captain to verify the condition when the associated caution light remains illuminated.

NOTE: Both pilots will confirm any change in the Wing Anti-Ice annunciation and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Standby Hydraulic indication	70 units	Normal
Standby Hydraulic indication	63 units	Refer to related topic
Hydraulic System B advisory	94 units	Monitor
Thrust Reverser status message	43 units	Refer to related topic
Primary Electrical Bus quantity display	47 units	Refer to related topic

The Flap Position Indication indication that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete. If the Hydraulic System A is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. See 03.30.2 Crew Qualification Records Policy 2.

07.20 Departure: Part B

07.20.1 Departure Policy 1

The Nosewheel Steering switch position that differs from the expected state requires the Captain to brief the condition when the associated caution light remains illuminated. The pilot monitoring will verify any change in the Flight Management Computer selector position and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

The wording here is placeholder content shaped like a procedure, not a procedure. The Weather Radar switch position that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center. The Autopilot Channel A status message that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. The Fire Detection Loop indication is expected to read within the sample range of 7 to 11 units during climb. If the Transponder is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Flight Management Computer annunciation	24 units	Normal
Autobrake Selector quantity display	45 units	Refer to related topic
Standby Hydraulic quantity display	52 units	Advisory only
Probe Heat indication	94 units	Refer to related topic
Probe Heat switch position	5 units	Monitor
Thrust Reverser indication	58 units	Monitor
Flap Position Indication indication	52 units	Normal

If the Bleed Air Supply is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. During a maintenance-requested ground run, both pilots should announce the Ground Proximity Monitor advisory when operating at a sample station without ground power. During engine start, the pilot flying should record the Autothrottle selector position once the checklist item is complete. The Cargo Smoke Detection switch position that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. During climb, the pilot monitoring should confirm the Wing Anti-Ice advisory if the indication does not stabilize within the sample interval.

- The pilot flying will verify any change in the Cabin Pressure Controller selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Autopilot Channel B advisory that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power.
- During an extended ground delay, the relief pilot should record the Speedbrake Handle selector position if a discrepancy is observed.
- Refer to the related topic for additional sample context.
- The relief pilot will brief any change in the Probe Heat annunciation and advise the other pilot once the checklist item is complete.

NOTE: The Flap Position Indication indication that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval.

- The Hydraulic System A quantity display that differs from the expected state requires the First Officer to announce the condition before the next phase of flight.
- If the Cargo Smoke Detection is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- During a diversion, the pilot monitoring should brief the Wing Anti-Ice status message when conditions permit.

Condition	Sample value	Remarks
Landing Gear Indication indication	1 units	Advisory only
Pack Temperature Control quantity display	99 units	Normal
Primary Electrical Bus indication	6 units	Advisory only

If the Window Heat is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. During landing, the First Officer should select the Ground Proximity Monitor advisory before the next phase of flight. During climb, the pilot flying should cross-check the Probe Heat switch position when operating at a sample station without ground power. During engine start, both pilots should brief the Bleed Air Supply annunciation once the checklist item is complete. If the Primary Electrical Bus is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

07.20.2 Departure Policy 2

If the Cockpit Voice Recorder is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. During climb, the pilot monitoring should verify the Weather Radar switch position when operating at a sample station without ground power. Both pilots will confirm any change in the Window Heat indication and advise the other pilot if a discrepancy is observed. The captain will confirm any change in the Probe Heat selector position and advise the other pilot when the associated caution light remains illuminated.

NOTE: If the Autopilot Channel A is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fuel Crossfeed quantity display	47 units	Monitor
Oxygen Distribution selector position	68 units	Monitor
Primary Electrical Bus advisory	9 units	Monitor
Window Heat selector position	20 units	Advisory only
Standby Hydraulic status message	75 units	Monitor

During parking, the Captain should record the Fire Detection Loop advisory when the associated caution light remains illuminated. The relief pilot will announce any change in the Cabin Pressure Controller annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. If the Wing Anti-Ice is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Flight Management Computer switch position that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete. The pilot flying will announce any change in the Cargo Smoke Detection selector position and advise the other pilot when conditions permit.

If the Hydraulic System B is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Center Tank Pumps status message that differs from the expected state requires the First Officer to select the condition unless directed otherwise by the Sample Operations Center.

07.20.3 Departure Policy 3

During approach, the pilot monitoring should record the Thrust Reverser switch position when conditions permit. The Cockpit Voice Recorder indication that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the pilot monitoring should cross-check the Bleed Air Supply selector position if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

The Autobrake Selector advisory that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. The Ground Proximity Monitor annunciation that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will record any change in the Engine Anti-Ice status message and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Fire Detection Loop is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

During descent, the relief pilot should verify the Cabin Pressure Controller annunciation before the next phase of flight. The Autothrottle indication that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. The Landing Gear Indication quantity display that differs from the expected state requires the pilot flying to record the condition when conditions permit. If the Ground Proximity Monitor is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Pack Temperature Control switch position is expected to read within the sample range of 36 to 43 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: During preflight, the pilot monitoring should confirm the Bleed Air Supply quantity display when operating at a sample station without ground power. The Hydraulic System A indication that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval.

The Pack Temperature Control quantity display that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. The pilot flying will confirm any change in the Stall Warning advisory and advise the other pilot when the associated caution light remains illuminated. During an extended ground delay, the pilot flying should announce the Standby Instruments switch position before the next phase of flight. During descent, the pilot flying should monitor the Autobrake Selector quantity display if the indication does not stabilize within the sample interval.

NOTE: The Standby Hydraulic annunciation that differs from the expected state requires the First Officer to confirm the condition when the associated caution light remains illuminated.

NOTE: If the Oxygen Distribution is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

During cruise, both pilots should record the Nosewheel Steering switch position if the indication does not stabilize within the sample interval. Both pilots will monitor any change in the Traffic Advisory Display indication and advise the other pilot when conditions permit. The pilot flying will confirm any change in the Fuel Crossfeed advisory and advise the other pilot when the associated caution light remains illuminated. The Landing Gear Indication quantity display is expected to read within the sample range of 98 to 105 units during a diversion. During taxi, the relief pilot should announce the Bleed Air Supply selector position once the checklist item is complete.

Both pilots will monitor any change in the Traffic Advisory Display advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Primary Electrical Bus status message is expected to read within the sample range of 20 to 27 units during engine start. If the Autothrottle is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Cargo Smoke Detection advisory is expected to read within the sample range of 29 to 34 units during climb.

07.20.4 Departure Policy 4

If the Window Heat is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. During engine start, the First Officer should select the Standby Instruments indication if a discrepancy is observed. During an extended ground delay, the pilot flying should cross-check the Weather Radar quantity display when operating at a sample station without ground power. The pilot monitoring will announce any change in the Pack Temperature Control indication and advise the other pilot when operating at a sample station without ground power. If the Flight Management Computer is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

During takeoff, the pilot monitoring should confirm the Cargo Smoke Detection advisory unless directed otherwise by the Sample Operations Center. The Standby Hydraulic advisory is expected to read within the sample range of 23 to 30 units during approach. The first officer will select any change in the Center Tank Pumps switch position and advise the other pilot when operating at a sample station without ground power. During engine start, the relief pilot should monitor the Standby Instruments quantity display before the next phase of flight. The pilot monitoring will cross-check any change in the Fuel Crossfeed quantity display and advise the other pilot once the checklist item is complete. The captain will cross-check any change in the Bleed Air Supply indication and advise the other pilot when the associated caution light remains illuminated.

- The pilot monitoring will verify any change in the Nosewheel Steering advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Engine Anti-Ice is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During engine start, the First Officer should monitor the Nosewheel Steering annunciation if a discrepancy is observed.
- During engine start, both pilots should cross-check the Bleed Air Supply quantity display if the indication does not stabilize within the sample interval.

The captain will brief any change in the Brake Temperature Monitor selector position and advise the other pilot when the associated caution light remains illuminated. If the Flap Position Indication is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle advisory that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. The Landing Gear Indication switch position that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete. The captain will select any change in the Engine Anti-Ice status message and advise the other pilot when conditions permit.

NOTE: The pilot flying will cross-check any change in the Oxygen Distribution indication and advise the other pilot when conditions permit. If the Bleed Air Supply is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

07.20.5 Departure Policy 5

The pilot monitoring will select any change in the Flap Position Indication annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The first officer will brief any change in the Primary Electrical Bus selector position and advise the other pilot once the checklist item is complete. The Nosewheel Steering annunciation is expected to read within the sample range of 22 to 26 units during climb.

The pilot flying will brief any change in the Fuel Crossfeed advisory and advise the other pilot once the checklist item is complete. The pilot monitoring will monitor any change in the Cargo Smoke Detection quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During preflight, the First Officer should verify the Center Tank Pumps selector position unless directed otherwise by the Sample Operations Center.

The pilot monitoring will confirm any change in the Hydraulic System B quantity display and advise the other pilot once the checklist item is complete. During parking, the First Officer should monitor the Speedbrake Handle selector

position when the associated caution light remains illuminated. If the Primary Electrical Bus is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. During parking, both pilots should announce the Standby Hydraulic annunciation if a discrepancy is observed. If the Autobrake Selector is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. During landing, the pilot monitoring should announce the Autothrottle advisory if the indication does not stabilize within the sample interval. The Probe Heat quantity display that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete. During engine start, the First Officer should confirm the Autobrake Selector advisory unless directed otherwise by the Sample Operations Center.

CAUTION: The Flap Position Indication selector position that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.

- If the Weather Radar is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.
- During approach, the First Officer should announce the Bleed Air Supply quantity display once the checklist item is complete.
- The Landing Gear Indication annunciation that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete.
- The Thrust Reverser annunciation that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated.
- The Center Tank Pumps selector position is expected to read within the sample range of 38 to 47 units during descent.
- Both pilots will announce any change in the Auxiliary Power Unit advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

07.20.6 Departure Policy 6

The Bleed Air Supply status message is expected to read within the sample range of 34 to 41 units during parking. The relief pilot will verify any change in the Nosewheel Steering switch position and advise the other pilot when operating at a sample station without ground power. The Transponder annunciation that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the pilot monitoring should cross-check the Thrust Reverser advisory if the indication does not stabilize within the sample interval.

NOTE: The Auxiliary Power Unit advisory is expected to read within the sample range of 52 to 56 units during takeoff. If the Window Heat is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

- If the Autobrake Selector is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- The Center Tank Pumps selector position is expected to read within the sample range of 25 to 33 units during taxi.
- The pilot flying will verify any change in the Cargo Smoke Detection quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: During taxi, both pilots should announce the Thrust Reverser advisory when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

The first officer will cross-check any change in the Weather Radar annunciation and advise the other pilot if a discrepancy is observed. During landing, the First Officer should brief the Probe Heat advisory before the next phase of flight. The Hydraulic System B selector position that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval.

- The Flight Management Computer annunciation that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.
- If the Traffic Advisory Display is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- If the Weather Radar is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.
- If the Standby Hydraulic is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- The Transponder indication that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval.
- The Transponder switch position is expected to read within the sample range of 63 to 69 units during engine start.

Condition	Sample value	Remarks
Center Tank Pumps annunciation	98 units	Refer to related topic
Cabin Pressure Controller indication	77 units	Advisory only
Probe Heat switch position	64 units	Monitor

The wording here is placeholder content shaped like a procedure, not a procedure. If the Standby Instruments is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will cross-check any change in the Center Tank Pumps annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. See 09.30.3 Arrival Policy 3.

07.20.7 Departure Policy 7

If the Wing Anti-Ice is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The Oxygen Distribution annunciation that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power. The Flight Management Computer annunciation that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. During a maintenance-requested ground run, the pilot flying should cross-check the Autobrake Selector annunciation if a discrepancy is observed.

NOTE: The Engine Anti-Ice advisory that differs from the expected state requires the pilot flying to select the condition before the next phase of flight. The Autothrottle quantity display that differs from the expected state requires the pilot monitoring to cross-check the condition unless directed otherwise by the Sample Operations Center.

NOTE: Refer to the related topic for additional sample context.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

- If the Autobrake Selector is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.
- If the Pack Temperature Control is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

- If the Thrust Reverser is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Cabin Pressure Controller is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: During an extended ground delay, both pilots should announce the Cabin Pressure Controller annunciation if the indication does not stabilize within the sample interval. If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

The Flight Management Computer advisory that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will select any change in the Autobrake Selector status message and advise the other pilot when the associated caution light remains illuminated. The Standby Hydraulic status message is expected to read within the sample range of 97 to 106 units during parking. The Speedbrake Handle status message is expected to read within the sample range of 45 to 57 units during descent.

07.20.8 Departure Policy 8

Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle annunciation is expected to read within the sample range of 31 to 37 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure. If the Transponder is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The first officer will announce any change in the Cockpit Voice Recorder switch position and advise the other pilot before the next phase of flight. The Landing Gear Indication advisory that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power.

NOTE: During descent, the pilot monitoring should brief the Flap Position Indication quantity display when the associated caution light remains illuminated.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

Values in this manual are invented and must not be used for any operational purpose. If the Landing Gear Indication is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

The pilot monitoring will announce any change in the Standby Hydraulic status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Engine Anti-Ice switch position is expected to read within the sample range of 73 to 80 units during taxi. The relief pilot will record any change in the Speedbrake Handle advisory and advise the other pilot if the indication does not stabilize within the sample interval. During takeoff, both pilots should brief the Primary Electrical Bus status message if the indication does not stabilize within the sample interval.

The Standby Hydraulic quantity display that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. If the Landing Gear Indication is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During taxi, the pilot monitoring should cross-check the Cockpit Voice Recorder annunciation if the indication does not stabilize within the sample interval. The Hydraulic System B annunciation that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete. If the Cabin Pressure Controller is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. If the Brake Temperature Monitor is inoperative, continue climb only after the pilot flying has reviewed the associated sample

guidance.

Both pilots will monitor any change in the Wing Anti-Ice annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will confirm any change in the Autothrottle switch position and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The Pack Temperature Control advisory that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. The Fuel Crossfeed selector position is expected to read within the sample range of 95 to 102 units during preflight. The pilot flying will announce any change in the Nosewheel Steering status message and advise the other pilot before the next phase of flight.

07.30 Departure: Part C

07.30.1 Departure Policy 1

The first officer will monitor any change in the Engine Anti-Ice status message and advise the other pilot when conditions permit. The Primary Electrical Bus status message is expected to read within the sample range of 85 to 93 units during approach. During preflight, the relief pilot should confirm the Bleed Air Supply switch position before the next phase of flight. The Autothrottle advisory that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit. During engine start, the pilot flying should verify the Bleed Air Supply indication when conditions permit.

The Hydraulic System B advisory is expected to read within the sample range of 41 to 51 units during approach. The Hydraulic System B quantity display is expected to read within the sample range of 74 to 86 units during preflight. The Transponder quantity display that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power. The Hydraulic System A indication is expected to read within the sample range of 73 to 84 units during preflight. Refer to the related topic for additional sample context.

CAUTION: The Landing Gear Indication status message that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

Values in this manual are invented and must not be used for any operational purpose. During approach, the Captain should monitor the Bleed Air Supply quantity display when operating at a sample station without ground power. If the Weather Radar is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

If the Window Heat is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will select any change in the Flap Position Indication indication and advise the other pilot if the indication does not stabilize within the sample interval. The Autopilot Channel A annunciation that differs from the expected state requires the relief pilot to select the condition before the next phase of flight.

NOTE: The Ground Proximity Monitor selector position that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated.

NOTE: During preflight, the Captain should monitor the Nosewheel Steering indication once the checklist item is complete. The Window Heat advisory is expected to read within the sample range of 8 to 19 units during engine start.

During parking, the First Officer should monitor the Probe Heat indication when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Thrust Reverser annunciation is expected to read within the sample range of 42 to 45 units during parking. The Autopilot Channel A status message that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed.

The captain will select any change in the Probe Heat advisory and advise the other pilot if a discrepancy is observed. The Standby Instruments selector position that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated. If the Auxiliary Power Unit is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure.

07.30.2 *Departure Policy 2*

The Flap Position Indication quantity display that differs from the expected state requires the Captain to confirm the condition when conditions permit. If the Autopilot Channel A is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Primary Electrical Bus annunciation is expected to read within the sample range of 42 to 46 units during approach. The Flap Position Indication advisory is expected to read within the sample range of 51 to 58 units during takeoff. The Pack Temperature Control status message is expected to read within the sample range of 57 to 68 units during a diversion.

The relief pilot will monitor any change in the Autothrottle advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Standby Hydraulic annunciation is expected to read within the sample range of 77 to 82 units during takeoff. This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will monitor any change in the Cockpit Voice Recorder selector position and advise the other pilot if the indication does not stabilize within the sample interval.

If the Center Tank Pumps is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Transponder advisory is expected to read within the sample range of 22 to 27 units during a maintenance-requested ground run. The wording here is placeholder content shaped like a procedure, not a procedure. If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Oxygen Distribution selector position that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. The Autobrake Selector annunciation is expected to read within the sample range of 72 to 76 units during taxi.

Refer to the related topic for additional sample context. The relief pilot will brief any change in the Hydraulic System A selector position and advise the other pilot once the checklist item is complete. If the Center Tank Pumps is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context.

CAUTION: The Auxiliary Power Unit annunciation that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated. The Cabin Pressure Controller indication that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center.

07.30.3 *Departure Policy 3*

The Auxiliary Power Unit status message that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete. The Autopilot Channel A quantity display is expected to read within the sample range of 71 to 74 units during a maintenance-requested ground run. If the Traffic Advisory Display is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

The Flight Management Computer switch position is expected to read within the sample range of 24 to 31 units during a maintenance-requested ground run. The relief pilot will monitor any change in the Wing Anti-Ice indication and advise the other pilot if the indication does not stabilize within the sample interval. The Thrust Reverser switch position that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. Refer to the related topic for additional sample context. During a maintenance-requested ground run, the relief pilot should verify the Ground Proximity Monitor indication when the

associated caution light remains illuminated.

CAUTION: The Primary Electrical Bus indication is expected to read within the sample range of 40 to 49 units during a turnaround. If the Thrust Reverser is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

The Stall Warning indication is expected to read within the sample range of 33 to 44 units during a diversion. The Landing Gear Indication annunciation is expected to read within the sample range of 8 to 11 units during climb. The Landing Gear Indication quantity display that differs from the expected state requires the pilot flying to announce the condition when conditions permit. During parking, the pilot monitoring should brief the Stall Warning status message when operating at a sample station without ground power. The Landing Gear Indication annunciation that differs from the expected state requires the relief pilot to verify the condition once the checklist item is complete. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Wing Anti-Ice quantity display	2 units	Advisory only
Engine Anti-Ice selector position	61 units	Refer to related topic
Flap Position Indication switch position	38 units	Monitor
Cargo Smoke Detection selector position	36 units	Monitor
Window Heat switch position	42 units	Refer to related topic

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

07.30.4 Departure Policy 4

The Thrust Reverser indication that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power. If the Autothrottle is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. During takeoff, the pilot flying should confirm the Traffic Advisory Display quantity display when operating at a sample station without ground power.

CAUTION: The pilot monitoring will announce any change in the Cargo Smoke Detection annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will record any change in the Weather Radar indication and advise the other pilot when conditions permit. The Ground Proximity Monitor switch position is expected to read within the sample range of 73 to 77 units during an extended ground delay. If the Probe Heat is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Brake Temperature Monitor advisory is expected to read within the sample range of 71 to 80 units during parking. During an extended ground delay, the relief pilot should announce the Hydraulic System A advisory if a discrepancy is observed.

Condition	Sample value	Remarks
Weather Radar selector position	67 units	Monitor
Thrust Reverser advisory	12 units	Normal
Window Heat advisory	3 units	Monitor

The pilot monitoring will cross-check any change in the Cabin Pressure Controller indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will verify any change in the Engine Anti-Ice status message and advise the other pilot once the checklist item is complete.

Both pilots will announce any change in the Bleed Air Supply annunciation and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. If the Flap Position Indication is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance.

NOTE: If the Fire Detection Loop is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

The first officer will cross-check any change in the Cargo Smoke Detection switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Thrust Reverser switch position that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. The Weather Radar indication is expected to read within the sample range of 97 to 105 units during preflight. The captain will record any change in the Pack Temperature Control status message and advise the other pilot once the checklist item is complete. During a maintenance-requested ground run, the relief pilot should announce the Probe Heat indication unless directed otherwise by the Sample Operations Center.

07.30.5 Departure Policy 5

During descent, the relief pilot should brief the Traffic Advisory Display status message when conditions permit. The Hydraulic System B quantity display that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. The pilot monitoring will confirm any change in the Landing Gear Indication switch position and advise the other pilot once the checklist item is complete. If the Cargo Smoke Detection is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. Both pilots will cross-check any change in the Cargo Smoke Detection status message and advise the other pilot before the next phase of flight. The Cockpit Voice Recorder selector position is expected to read within the sample range of 97 to 100 units during taxi.

The Standby Hydraulic advisory that differs from the expected state requires both pilots to confirm the condition when conditions permit. Both pilots will verify any change in the Wing Anti-Ice indication and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Flap Position Indication quantity display is expected to read within the sample range of 97 to 100 units during approach. The Cargo Smoke Detection quantity display is expected to read within the sample range of 68 to 71 units during cruise.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Center Tank Pumps quantity display	1 units	Refer to related topic
Pack Temperature Control quantity display	35 units	Advisory only
Oxygen Distribution indication	50 units	Normal
Cargo Smoke Detection annunciation	2 units	Advisory only

Refer to the related topic for additional sample context. The Traffic Advisory Display status message is expected to read within the sample range of 79 to 90 units during takeoff. The Fire Detection Loop status message that differs from the expected state requires the pilot monitoring to record the condition unless directed otherwise by the Sample Operations Center. The Transponder status message that differs from the expected state requires the relief pilot to record the condition when the associated caution light remains illuminated. If the Hydraulic System B is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. During preflight, the pilot flying should confirm the Weather Radar switch position if the indication does not stabilize within the sample interval.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Stall Warning is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. During takeoff, both pilots should confirm the Auxiliary Power Unit advisory when operating at a sample station without ground power. If the Oxygen Distribution is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The first officer will brief any change in the Bleed Air Supply advisory and advise the

other pilot when conditions permit. Refer to the related topic for additional sample context.

NOTE: If the Flight Management Computer is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

CAUTION: If the Oxygen Distribution is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

07.30.6 Departure Policy 6

The Oxygen Distribution indication that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power. The Thrust Reverser status message that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. The Hydraulic System B annunciation that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. The Bleed Air Supply indication is expected to read within the sample range of 93 to 103 units during a diversion. If the Transponder is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The captain will monitor any change in the Weather Radar selector position and advise the other pilot once the checklist item is complete.

If the Auxiliary Power Unit is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The Flap Position Indication annunciation is expected to read within the sample range of 57 to 60 units during landing. The Auxiliary Power Unit switch position is expected to read within the sample range of 88 to 95 units during preflight.

If the Engine Anti-Ice is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. During descent, the Captain should monitor the Auxiliary Power Unit selector position when the associated caution light remains illuminated. The Cargo Smoke Detection annunciation is expected to read within the sample range of 97 to 100 units during landing.

The Autopilot Channel B quantity display is expected to read within the sample range of 67 to 74 units during a turnaround. The Probe Heat switch position is expected to read within the sample range of 47 to 50 units during preflight. If the Standby Hydraulic is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

During a turnaround, both pilots should announce the Flight Management Computer selector position once the checklist item is complete. During descent, the relief pilot should monitor the Oxygen Distribution annunciation if a discrepancy is observed. The Hydraulic System B indication that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed.

The captain will monitor any change in the Hydraulic System A quantity display and advise the other pilot when conditions permit. During an extended ground delay, the First Officer should record the Ground Proximity Monitor status message once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The relief pilot will record any change in the Autopilot Channel B switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: The Ground Proximity Monitor selector position that differs from the expected state requires the Captain to cross-check the condition once the checklist item is complete.

- During a turnaround, the pilot monitoring should verify the Oxygen Distribution indication if a discrepancy is observed.
- During preflight, the Captain should monitor the Standby Hydraulic annunciation before the next phase of flight.
- The relief pilot will confirm any change in the Brake Temperature Monitor status message and advise the other pilot if the indication does not stabilize within the sample interval.

07.30.7 *Departure Policy 7*

The Traffic Advisory Display indication that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated. The Transponder status message is expected to read within the sample range of 62 to 69 units during a diversion. This text is fictional and exists only to give the prototype realistic volume and structure. During a diversion, both pilots should record the Ground Proximity Monitor selector position when conditions permit. The pilot flying will announce any change in the Autobrake Selector indication and advise the other pilot if a discrepancy is observed.

During a turnaround, the Captain should announce the Landing Gear Indication status message once the checklist item is complete. The Auxiliary Power Unit selector position is expected to read within the sample range of 66 to 71 units during landing. During cruise, the pilot monitoring should brief the Transponder switch position if a discrepancy is observed. If the Stall Warning is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

Both pilots will record any change in the Primary Electrical Bus switch position and advise the other pilot before the next phase of flight. The relief pilot will verify any change in the Cockpit Voice Recorder status message and advise the other pilot if a discrepancy is observed. The pilot monitoring will brief any change in the Brake Temperature Monitor quantity display and advise the other pilot when conditions permit. During landing, the pilot flying should verify the Nosewheel Steering status message when conditions permit. Values in this manual are invented and must not be used for any operational purpose. During takeoff, the pilot flying should brief the Wing Anti-Ice advisory when conditions permit.

- The pilot monitoring will monitor any change in the Standby Hydraulic quantity display and advise the other pilot when operating at a sample station without ground power.
- During descent, the pilot flying should brief the Wing Anti-Ice quantity display if the indication does not stabilize within the sample interval.
- The Speedbrake Handle selector position that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center.
- The Stall Warning status message that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power.
- If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

During a maintenance-requested ground run, the Captain should record the Primary Electrical Bus advisory unless directed otherwise by the Sample Operations Center. The Bleed Air Supply advisory that differs from the expected state requires both pilots to select the condition if a discrepancy is observed. The Thrust Reverser annunciation that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval.

The captain will confirm any change in the Brake Temperature Monitor advisory and advise the other pilot if a discrepancy is observed. During parking, the pilot monitoring should select the Speedbrake Handle quantity display when conditions permit. During cruise, the Captain should brief the Landing Gear Indication annunciation if a discrepancy is observed.

CAUTION: During approach, the pilot monitoring should record the Autopilot Channel B status message when operating at a sample station without ground power. The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot flying to announce the condition when conditions permit.

07.30.8 *Departure Policy 8*

The Window Heat quantity display is expected to read within the sample range of 33 to 39 units during approach. The pilot flying will verify any change in the Oxygen Distribution indication and advise the other pilot once the checklist

item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

- The relief pilot will confirm any change in the Wing Anti-Ice quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- The first officer will cross-check any change in the Cabin Pressure Controller quantity display and advise the other pilot when operating at a sample station without ground power.
- The Cabin Pressure Controller selector position that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power.
- Values in this manual are invented and must not be used for any operational purpose.
- The Flight Management Computer switch position that differs from the expected state requires the First Officer to confirm the condition once the checklist item is complete.

CAUTION: The Autopilot Channel B advisory is expected to read within the sample range of 64 to 67 units during taxi. The Speedbrake Handle switch position is expected to read within the sample range of 20 to 24 units during descent.

If the Pack Temperature Control is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Probe Heat annunciation that differs from the expected state requires the Captain to brief the condition before the next phase of flight. The pilot monitoring will announce any change in the Bleed Air Supply switch position and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Flap Position Indication selector position	32 units	Monitor
Standby Hydraulic indication	57 units	Normal
Nosewheel Steering selector position	82 units	Refer to related topic
Ground Proximity Monitor annunciation	49 units	Normal
Speedbrake Handle indication	47 units	Refer to related topic

- The Center Tank Pumps indication that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete.
- If the Engine Anti-Ice is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The captain will verify any change in the Hydraulic System A quantity display and advise the other pilot when conditions permit.
- If the Weather Radar is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.

Chapter 08 Enroute

08.10 Enroute: Part A

08.10.1 Enroute Policy 1

The Bleed Air Supply status message is expected to read within the sample range of 46 to 54 units during parking. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will verify any change in the Thrust Reverser quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Center Tank Pumps is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. Both pilots will select any change in the Oxygen Distribution annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Pack Temperature Control quantity display	89 units	Normal
Standby Instruments annunciation	2 units	Normal
Thrust Reverser annunciation	26 units	Refer to related topic
Speedbrake Handle advisory	33 units	Refer to related topic
Standby Hydraulic advisory	84 units	Normal
Engine Anti-Ice indication	68 units	Normal
Weather Radar switch position	21 units	Monitor

CAUTION: During climb, the First Officer should select the Brake Temperature Monitor quantity display before the next phase of flight. The Ground Proximity Monitor quantity display that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight.

CAUTION: The captain will select any change in the Window Heat selector position and advise the other pilot if a discrepancy is observed.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Nosewheel Steering selector position is expected to read within the sample range of 36 to 39 units during takeoff. The Cabin Pressure Controller annunciation is expected to read within the sample range of 61 to 70 units during descent. See 09.20.1 Arrival Policy 1.

08.10.2 Enroute Policy 2

The Bleed Air Supply switch position that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed. If the Pack Temperature Control is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. If the Auxiliary Power Unit is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

During descent, both pilots should verify the Hydraulic System A switch position once the checklist item is complete. If the Flight Management Computer is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will monitor any change in the Ground Proximity Monitor advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Stall Warning switch position is expected to read within the sample range of 5 to 8 units during engine start. The pilot monitoring will announce any change in the Standby Hydraulic advisory and advise the other pilot before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Nosewheel Steering is inoperative, continue approach only after the First Officer has reviewed the associated sample

guidance. The pilot monitoring will confirm any change in the Engine Anti-Ice selector position and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During a diversion, the Captain should confirm the Cockpit Voice Recorder status message once the checklist item is complete. Both pilots will record any change in the Auxiliary Power Unit indication and advise the other pilot when conditions permit.

CAUTION: The Fire Detection Loop switch position that differs from the expected state requires the Captain to announce the condition when conditions permit. The Brake Temperature Monitor status message is expected to read within the sample range of 41 to 50 units during takeoff.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic advisory is expected to read within the sample range of 51 to 62 units during a maintenance-requested ground run. During cruise, the pilot flying should announce the Window Heat status message unless directed otherwise by the Sample Operations Center. The Autopilot Channel B status message that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power.

- The Hydraulic System A annunciation that differs from the expected state requires the pilot flying to verify the condition if a discrepancy is observed.
- During taxi, the pilot monitoring should select the Fire Detection Loop indication once the checklist item is complete.
- During a maintenance-requested ground run, the relief pilot should announce the Autothrottle advisory if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The pilot flying will brief any change in the Transponder annunciation and advise the other pilot when the associated caution light remains illuminated.
- If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

08.10.3 Enroute Policy 3

During landing, the relief pilot should confirm the Stall Warning switch position once the checklist item is complete. The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete. The Flap Position Indication status message is expected to read within the sample range of 8 to 18 units during a diversion.

If the Auxiliary Power Unit is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Nosewheel Steering switch position and advise the other pilot if a discrepancy is observed. Both pilots will cross-check any change in the Cockpit Voice Recorder switch position and advise the other pilot when conditions permit. During parking, the Captain should verify the Wing Anti-Ice annunciation before the next phase of flight. The Fire Detection Loop status message that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power. The Wing Anti-Ice advisory is expected to read within the sample range of 79 to 89 units during engine start.

NOTE: Refer to the related topic for additional sample context. Both pilots will brief any change in the Center Tank Pumps switch position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Autopilot Channel B switch position	42 units	Normal
Stall Warning switch position	42 units	Refer to related topic
Autopilot Channel B switch position	62 units	Refer to related topic

Probe Heat advisory	63 units	Normal
---------------------	----------	--------

Refer to the related topic for additional sample context. The Cockpit Voice Recorder selector position that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. The Window Heat annunciation is expected to read within the sample range of 58 to 61 units during approach. During an extended ground delay, the First Officer should announce the Landing Gear Indication annunciation when conditions permit.

08.10.4 Enroute Policy 4

During parking, the pilot monitoring should announce the Center Tank Pumps advisory if a discrepancy is observed. The Autothrottle selector position is expected to read within the sample range of 20 to 26 units during engine start. If the Cabin Pressure Controller is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The first officer will confirm any change in the Fuel Crossfeed switch position and advise the other pilot once the checklist item is complete. The Fuel Crossfeed switch position that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. The Cockpit Voice Recorder status message is expected to read within the sample range of 70 to 77 units during a turnaround.

During taxi, both pilots should verify the Probe Heat quantity display when conditions permit. The Oxygen Distribution status message that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. The Bleed Air Supply quantity display is expected to read within the sample range of 78 to 87 units during approach. The pilot monitoring will brief any change in the Probe Heat quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The Traffic Advisory Display selector position that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. During a turnaround, the Captain should monitor the Standby Hydraulic selector position unless directed otherwise by the Sample Operations Center.

The Landing Gear Indication selector position is expected to read within the sample range of 20 to 32 units during taxi. The Cabin Pressure Controller selector position that differs from the expected state requires the pilot flying to record the condition if the indication does not stabilize within the sample interval. The Primary Electrical Bus annunciation is expected to read within the sample range of 4 to 8 units during approach. The pilot monitoring will cross-check any change in the Cabin Pressure Controller indication and advise the other pilot if a discrepancy is observed.

NOTE: The Standby Instruments quantity display is expected to read within the sample range of 91 to 103 units during parking.

- The captain will record any change in the Primary Electrical Bus indication and advise the other pilot when conditions permit.
- During descent, both pilots should confirm the Transponder advisory if a discrepancy is observed.
- If the Engine Anti-Ice is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During descent, the First Officer should select the Flap Position Indication quantity display once the checklist item is complete.

The Nosewheel Steering advisory that differs from the expected state requires the pilot flying to confirm the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice annunciation is expected to read within the sample range of 83 to 94 units during landing. During a maintenance-requested ground run, the pilot monitoring should monitor the Nosewheel Steering annunciation when the associated caution light remains illuminated. The relief pilot will brief any change in the Center Tank Pumps selector position and advise the other pilot once the checklist item is complete.

CAUTION: The pilot monitoring will monitor any change in the Window Heat indication and advise the other pilot when the associated caution light remains illuminated. Both pilots will brief any change in the Autopilot Channel B indication and advise the other pilot once the checklist item is complete.

CAUTION: The Landing Gear Indication indication that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure.

08.10.5 Enroute Policy 5

During an extended ground delay, both pilots should select the Weather Radar indication when operating at a sample station without ground power. Both pilots will record any change in the Autothrottle switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will select any change in the Weather Radar switch position and advise the other pilot once the checklist item is complete. The first officer will select any change in the Autothrottle switch position and advise the other pilot before the next phase of flight.

The Landing Gear Indication status message that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. If the Cabin Pressure Controller is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The pilot flying will announce any change in the Autothrottle switch position and advise the other pilot when conditions permit.

The pilot monitoring will brief any change in the Primary Electrical Bus quantity display and advise the other pilot if a discrepancy is observed. If the Fire Detection Loop is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Engine Anti-Ice annunciation is expected to read within the sample range of 11 to 18 units during preflight. The Primary Electrical Bus annunciation is expected to read within the sample range of 39 to 48 units during climb.

Condition	Sample value	Remarks
Autobrake Selector status message	40 units	Normal
Primary Electrical Bus indication	71 units	Refer to related topic
Fire Detection Loop advisory	61 units	Monitor
Pack Temperature Control selector position	72 units	Normal
Cockpit Voice Recorder advisory	87 units	Advisory only
Brake Temperature Monitor quantity display	52 units	Normal

NOTE: During climb, the pilot monitoring should brief the Standby Instruments selector position if the indication does not stabilize within the sample interval.

The Window Heat switch position that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated. If the Autobrake Selector is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Fire Detection Loop quantity display is expected to read within the sample range of 11 to 23 units during takeoff.

The captain will select any change in the Cockpit Voice Recorder annunciation and advise the other pilot when conditions permit. If the Autobrake Selector is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Stall Warning indication is expected to read within the sample range of 76 to 87 units during preflight. The first officer will cross-check any change in the Brake Temperature Monitor indication and advise the other pilot when conditions permit. The Brake Temperature Monitor selector position that differs from the expected state requires the Captain to verify the condition when conditions permit. The Hydraulic System A annunciation that differs from the expected state requires the First Officer to brief the condition when conditions permit. See 12.10.6 Fuel Policy Policy 6.

08.10.6 Enroute Policy 6

The Engine Anti-Ice quantity display that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. During a maintenance-requested ground run, the relief pilot should announce the Bleed Air Supply advisory unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. The Ground Proximity Monitor switch position that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight. If the Flight Management Computer is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

The Autothrottle advisory that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. During an extended ground delay, both pilots should brief the Ground Proximity Monitor annunciation unless directed otherwise by the Sample Operations Center. The Thrust Reverser switch position that differs from the expected state requires the relief pilot to monitor the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Brake Temperature Monitor quantity display is expected to read within the sample range of 64 to 72 units during climb.

CAUTION: The first officer will select any change in the Speedbrake Handle selector position and advise the other pilot if the indication does not stabilize within the sample interval. During a turnaround, the pilot monitoring should brief the Cargo Smoke Detection status message unless directed otherwise by the Sample Operations Center.

The Engine Anti-Ice status message is expected to read within the sample range of 93 to 97 units during takeoff. The Cargo Smoke Detection selector position is expected to read within the sample range of 91 to 95 units during approach. The pilot monitoring will select any change in the Probe Heat quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The Flight Management Computer status message is expected to read within the sample range of 80 to 92 units during descent. The Primary Electrical Bus advisory that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated.

08.10.7 Enroute Policy 7

During a diversion, both pilots should select the Traffic Advisory Display advisory once the checklist item is complete. If the Bleed Air Supply is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Flap Position Indication annunciation that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

- The Nosewheel Steering advisory is expected to read within the sample range of 26 to 35 units during climb.
- The Stall Warning selector position is expected to read within the sample range of 63 to 69 units during parking.
- If the Thrust Reverser is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- The captain will verify any change in the Probe Heat switch position and advise the other pilot before the next phase of flight.
- If the Hydraulic System B is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance.

The Wing Anti-Ice advisory that differs from the expected state requires the Captain to verify the condition before the next phase of flight. The Bleed Air Supply quantity display that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval. Both pilots will announce any change in the Fuel Crossfeed indication and advise the other pilot if a discrepancy is observed.

If the Oxygen Distribution is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Auxiliary Power Unit switch position is expected to read within the sample range of 7 to 10 units during engine start. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Flight Management Computer selector position	24 units	Advisory only
Brake Temperature Monitor status message	83 units	Monitor
Fuel Crossfeed annunciation	28 units	Monitor
Hydraulic System B status message	53 units	Normal
Oxygen Distribution status message	61 units	Monitor
Nosewheel Steering indication	56 units	Refer to related topic
Traffic Advisory Display status message	65 units	Monitor

- During engine start, the pilot flying should confirm the Oxygen Distribution switch position when operating at a sample station without ground power.
- If the Flight Management Computer is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.
- The Thrust Reverser indication that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval.
- The relief pilot will monitor any change in the Fuel Crossfeed switch position and advise the other pilot before the next phase of flight.
- The Probe Heat status message that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Bleed Air Supply is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The Cargo Smoke Detection quantity display is expected to read within the sample range of 14 to 18 units during climb.

The Cockpit Voice Recorder quantity display that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval. The Weather Radar annunciation that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The Fuel Crossfeed quantity display is expected to read within the sample range of 14 to 19 units during cruise.

08.10.8 Enroute Policy 8

Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. The Flap Position Indication annunciation that differs from the expected state requires the pilot monitoring to select the condition if a discrepancy is observed. If the Primary Electrical Bus is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. Both pilots will announce any change in the Standby Hydraulic advisory and advise the other pilot when the associated caution light remains illuminated.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During engine start, the relief pilot should verify the Flight Management Computer switch position before the next phase of flight.

- The pilot flying will record any change in the Primary Electrical Bus status message and advise the other pilot before the next phase of flight.
- During taxi, the relief pilot should confirm the Cockpit Voice Recorder quantity display when operating at a sample station without ground power.
- During descent, the relief pilot should cross-check the Flight Management Computer advisory when conditions permit.
- The captain will confirm any change in the Fire Detection Loop status message and advise the other pilot when operating at a sample station without ground power.

This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control status message that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. The Ground Proximity Monitor status message that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, the pilot flying should cross-check the Speedbrake Handle quantity display if a discrepancy is observed.

CAUTION: The Cargo Smoke Detection quantity display that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. If the Traffic Advisory Display is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

The first officer will cross-check any change in the Transponder quantity display and advise the other pilot before the next phase of flight. The Thrust Reverser indication is expected to read within the sample range of 84 to 87 units during a diversion. The Transponder quantity display that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. During takeoff, the pilot monitoring should select the Probe Heat advisory when operating at a sample station without ground power. The Cabin Pressure Controller advisory is expected to read within the sample range of 44 to 55 units during a diversion.

NOTE: The Standby Instruments quantity display is expected to read within the sample range of 25 to 34 units during a turnaround. The Probe Heat switch position that differs from the expected state requires both pilots to brief the condition unless directed otherwise by the Sample Operations Center.

08.20 Enroute: Part B

08.20.1 Enroute Policy 1

During preflight, the pilot flying should cross-check the Cargo Smoke Detection indication before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. If the Speedbrake Handle is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Hydraulic System B indication that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	4 units	Advisory only
Oxygen Distribution switch position	70 units	Normal
Hydraulic System A advisory	91 units	Monitor
Traffic Advisory Display quantity display	28 units	Refer to related topic
Primary Electrical Bus indication	25 units	Advisory only
Stall Warning switch position	25 units	Normal

- The Speedbrake Handle indication that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit.
- The pilot flying will brief any change in the Center Tank Pumps advisory and advise the other pilot when operating at a sample station without ground power.
- Values in this manual are invented and must not be used for any operational purpose.
- During a turnaround, the relief pilot should brief the Landing Gear Indication switch position if a discrepancy is observed.

NOTE: Values in this manual are invented and must not be used for any operational purpose. During parking, the pilot flying should brief the Primary Electrical Bus advisory unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Traffic Advisory Display switch position	83 units	Monitor
Traffic Advisory Display advisory	33 units	Normal
Fuel Crossfeed quantity display	55 units	Normal
Cockpit Voice Recorder status message	48 units	Refer to related topic
Traffic Advisory Display status message	3 units	Normal

08.20.2 Enroute Policy 2

The Fire Detection Loop quantity display is expected to read within the sample range of 97 to 100 units during an extended ground delay. The Standby Hydraulic selector position is expected to read within the sample range of 60 to 66 units during climb. Values in this manual are invented and must not be used for any operational purpose.

NOTE: During takeoff, both pilots should monitor the Autothrottle quantity display when operating at a sample station without ground power. The Standby Instruments status message that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed.

The Engine Anti-Ice advisory is expected to read within the sample range of 13 to 25 units during parking. If the Weather Radar is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Transponder indication that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. During climb, the relief pilot should confirm the Fuel Crossfeed switch position if the indication does not stabilize within the sample interval. During descent, the relief pilot should verify the Ground Proximity Monitor indication when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose.

The Hydraulic System A indication that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power. The relief pilot will record any change in the Nosewheel Steering quantity display and advise the other pilot when the associated caution light remains illuminated. The Landing Gear Indication switch position that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete. The Thrust Reverser quantity display is expected to read within the sample range of 54 to 57 units during taxi. The Standby Hydraulic selector position that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power. If the Standby Hydraulic is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

NOTE: The Thrust Reverser selector position is expected to read within the sample range of 6 to 15 units during descent.

The Weather Radar annunciation that differs from the expected state requires both pilots to record the condition if a discrepancy is observed. During a diversion, the Captain should brief the Window Heat indication once the checklist item is complete. During parking, the pilot flying should cross-check the Autobrake Selector annunciation if the

indication does not stabilize within the sample interval.

The wording here is placeholder content shaped like a procedure, not a procedure. The Speedbrake Handle status message that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. During cruise, the First Officer should cross-check the Transponder annunciation when operating at a sample station without ground power. The Wing Anti-Ice status message is expected to read within the sample range of 38 to 50 units during takeoff. The Autopilot Channel A status message is expected to read within the sample range of 40 to 48 units during climb. The Brake Temperature Monitor annunciation is expected to read within the sample range of 68 to 74 units during engine start.

Condition	Sample value	Remarks
Standby Instruments annunciation	18 units	Advisory only
Hydraulic System A selector position	85 units	Refer to related topic
Window Heat indication	72 units	Normal

08.20.3 Enroute Policy 3

The Bleed Air Supply indication is expected to read within the sample range of 33 to 45 units during descent. During takeoff, the pilot monitoring should record the Autobrake Selector switch position when operating at a sample station without ground power. If the Standby Instruments is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

CAUTION: If the Nosewheel Steering is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Autothrottle annunciation and advise the other pilot when the associated caution light remains illuminated.

During approach, the Captain should cross-check the Standby Instruments switch position if the indication does not stabilize within the sample interval. If the Flight Management Computer is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. During parking, the pilot monitoring should confirm the Flight Management Computer indication if a discrepancy is observed.

The Window Heat selector position that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval. The Standby Instruments switch position that differs from the expected state requires both pilots to record the condition if a discrepancy is observed. During a turnaround, the relief pilot should announce the Flap Position Indication indication when the associated caution light remains illuminated. The Stall Warning indication that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center. The Oxygen Distribution switch position that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power.

The Auxiliary Power Unit annunciation is expected to read within the sample range of 10 to 15 units during climb. The Standby Instruments quantity display that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated. The Nosewheel Steering quantity display is expected to read within the sample range of 48 to 53 units during descent.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

The pilot monitoring will verify any change in the Autopilot Channel A quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Standby Hydraulic is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. The Brake Temperature Monitor status message that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed.

08.20.4 Enroute Policy 4

If the Traffic Advisory Display is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The relief pilot will confirm any change in the Fire Detection Loop selector position and

advise the other pilot when the associated caution light remains illuminated. The Nosewheel Steering annunciation that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated.

The Stall Warning selector position is expected to read within the sample range of 33 to 36 units during parking. If the Bleed Air Supply is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The Window Heat indication that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete. The Weather Radar status message is expected to read within the sample range of 32 to 38 units during a maintenance-requested ground run. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Center Tank Pumps is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The first officer will confirm any change in the Thrust Reverser quantity display and advise the other pilot when operating at a sample station without ground power.

The Nosewheel Steering advisory that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. The first officer will brief any change in the Cargo Smoke Detection advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. During engine start, the relief pilot should confirm the Landing Gear Indication quantity display when conditions permit.

NOTE: If the Transponder is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

NOTE: The captain will brief any change in the Weather Radar switch position and advise the other pilot when conditions permit.

08.20.5 Enroute Policy 5

The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will cross-check any change in the Fuel Crossfeed status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display status message that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center.

NOTE: Refer to the related topic for additional sample context.

The Traffic Advisory Display annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. During preflight, the Captain should record the Oxygen Distribution quantity display if the indication does not stabilize within the sample interval.

Both pilots will announce any change in the Brake Temperature Monitor annunciation and advise the other pilot once the checklist item is complete. If the Transponder is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. During descent, the pilot monitoring should announce the Ground Proximity Monitor annunciation if the indication does not stabilize within the sample interval. The Fire Detection Loop selector position is expected to read within the sample range of 49 to 54 units during an extended ground delay. The pilot flying will monitor any change in the Oxygen Distribution annunciation and advise the other pilot if a discrepancy is observed. If the Flight Management Computer is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

CAUTION: If the Flap Position Indication is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

The Engine Anti-Ice annunciation that differs from the expected state requires the First Officer to record the condition when conditions permit. The Traffic Advisory Display advisory that differs from the expected state requires the pilot monitoring to verify the condition if a discrepancy is observed. The relief pilot will brief any change in the Cockpit

Voice Recorder selector position and advise the other pilot if the indication does not stabilize within the sample interval.

If the Bleed Air Supply is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. The Speedbrake Handle switch position is expected to read within the sample range of 54 to 60 units during an extended ground delay. If the Probe Heat is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Thrust Reverser quantity display is expected to read within the sample range of 98 to 102 units during preflight.

The Fuel Crossfeed indication that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated. The captain will verify any change in the Cargo Smoke Detection quantity display and advise the other pilot when conditions permit. The Ground Proximity Monitor switch position is expected to read within the sample range of 91 to 101 units during preflight. The wording here is placeholder content shaped like a procedure, not a procedure. During a maintenance-requested ground run, the Captain should verify the Oxygen Distribution indication once the checklist item is complete. The Primary Electrical Bus switch position is expected to read within the sample range of 12 to 19 units during climb.

The Engine Anti-Ice advisory that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete. The relief pilot will verify any change in the Engine Anti-Ice switch position and advise the other pilot if the indication does not stabilize within the sample interval. If the Traffic Advisory Display is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The relief pilot will confirm any change in the Window Heat status message and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

08.20.6 Enroute Policy 6

During a maintenance-requested ground run, the pilot monitoring should announce the Transponder indication once the checklist item is complete. The Fire Detection Loop status message that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. The Fuel Crossfeed annunciation is expected to read within the sample range of 40 to 49 units during takeoff. If the Nosewheel Steering is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

The Flap Position Indication quantity display that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. The Center Tank Pumps advisory that differs from the expected state requires the First Officer to select the condition if a discrepancy is observed. The Thrust Reverser annunciation that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, both pilots should confirm the Center Tank Pumps advisory when the associated caution light remains illuminated.

CAUTION: During parking, both pilots should record the Probe Heat advisory when the associated caution light remains illuminated. The relief pilot will brief any change in the Wing Anti-Ice status message and advise the other pilot before the next phase of flight.

The Wing Anti-Ice status message is expected to read within the sample range of 73 to 83 units during descent. The first officer will record any change in the Standby Instruments annunciation and advise the other pilot when conditions permit. If the Landing Gear Indication is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Cabin Pressure Controller indication is expected to read within the sample range of 41 to 53 units during climb. If the Primary Electrical Bus is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Hydraulic System B annunciation is expected to read within the sample range of 70 to 73 units during a diversion.

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	57 units	Advisory only

Weather Radar status message	82 units	Refer to related topic
Hydraulic System A switch position	22 units	Normal
Cockpit Voice Recorder quantity display	53 units	Advisory only
Cargo Smoke Detection switch position	69 units	Advisory only
Hydraulic System B selector position	85 units	Refer to related topic

NOTE: During a maintenance-requested ground run, both pilots should brief the Standby Instruments quantity display if a discrepancy is observed. The Brake Temperature Monitor status message is expected to read within the sample range of 71 to 79 units during a maintenance-requested ground run.

NOTE: The Center Tank Pumps switch position is expected to read within the sample range of 5 to 12 units during parking.

08.20.7 Enroute Policy 7

During approach, the relief pilot should announce the Primary Electrical Bus annunciation if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor advisory is expected to read within the sample range of 39 to 42 units during descent.

NOTE: Both pilots will monitor any change in the Speedbrake Handle annunciation and advise the other pilot when operating at a sample station without ground power. During climb, the First Officer should brief the Autothrottle selector position if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Window Heat quantity display	41 units	Normal
Standby Hydraulic quantity display	19 units	Refer to related topic
Primary Electrical Bus switch position	34 units	Refer to related topic
Pack Temperature Control quantity display	95 units	Monitor
Fire Detection Loop indication	74 units	Advisory only
Auxiliary Power Unit switch position	38 units	Normal
Center Tank Pumps annunciation	15 units	Refer to related topic

NOTE: If the Transponder is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Autopilot Channel A is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autopilot Channel A quantity display	54 units	Normal
Standby Hydraulic quantity display	86 units	Refer to related topic
Brake Temperature Monitor advisory	46 units	Monitor
Wing Anti-Ice quantity display	77 units	Refer to related topic
Weather Radar indication	21 units	Refer to related topic
Traffic Advisory Display switch position	27 units	Monitor
Pack Temperature Control status message	88 units	Normal

NOTE: If the Flight Management Computer is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The relief pilot will confirm any change in the Wing Anti-Ice advisory and advise the other pilot when the associated caution light remains illuminated.

08.20.8 Enroute Policy 8

During takeoff, the pilot flying should announce the Center Tank Pumps switch position unless directed otherwise by the Sample Operations Center. During cruise, the Captain should cross-check the Cabin Pressure Controller quantity display when operating at a sample station without ground power. If the Probe Heat is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

The Autobrake Selector indication is expected to read within the sample range of 62 to 71 units during landing. Both pilots will cross-check any change in the Window Heat quantity display and advise the other pilot once the checklist item is complete. The pilot monitoring will brief any change in the Flight Management Computer selector position and advise the other pilot when operating at a sample station without ground power. The Weather Radar indication that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. During cruise, the pilot monitoring should record the Standby Hydraulic switch position once the checklist item is complete. During descent, the pilot monitoring should select the Traffic Advisory Display switch position when conditions permit.

CAUTION: If the Transponder is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: If the Traffic Advisory Display is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Transponder status message that differs from the expected state requires the pilot flying to select the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Weather Radar switch position	9 units	Refer to related topic
Thrust Reverser advisory	4 units	Refer to related topic
Autopilot Channel A advisory	82 units	Monitor

If the Cabin Pressure Controller is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will brief any change in the Cargo Smoke Detection advisory and advise the other pilot when operating at a sample station without ground power. The Flight Management Computer annunciation is expected to read within the sample range of 78 to 89 units during engine start.

- If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- During parking, the First Officer should cross-check the Thrust Reverser indication if a discrepancy is observed.
- If the Hydraulic System B is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- The pilot monitoring will confirm any change in the Standby Hydraulic status message and advise the other pilot before the next phase of flight.
- Refer to the related topic for additional sample context.

08.30 Enroute: Part C

08.30.1 Enroute Policy 1

If the Landing Gear Indication is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. If the Nosewheel Steering is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, the First Officer should record the Flight Management Computer advisory when operating at a sample station without ground power. During a diversion, the relief pilot should confirm the Standby Hydraulic annunciation when operating at a sample station without ground power.

The relief pilot will announce any change in the Cargo Smoke Detection quantity display and advise the other pilot when conditions permit. The pilot monitoring will record any change in the Stall Warning advisory and advise the other pilot before the next phase of flight. During a maintenance-requested ground run, both pilots should monitor the Transponder quantity display before the next phase of flight.

This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. During approach, both pilots should record the Primary Electrical Bus switch position unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder indication is expected to read within the sample range of 39 to 46 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Primary Electrical Bus status message	48 units	Normal
Engine Anti-Ice advisory	78 units	Refer to related topic
Hydraulic System A indication	77 units	Monitor

Condition	Sample value	Remarks
Autothrottle selector position	45 units	Normal
Autopilot Channel A annunciation	19 units	Monitor
Cabin Pressure Controller status message	22 units	Advisory only

Values in this manual are invented and must not be used for any operational purpose. The Oxygen Distribution quantity display that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During descent, the relief pilot should announce the Speedbrake Handle advisory once the checklist item is complete. The Hydraulic System B annunciation that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval.

08.30.2 Enroute Policy 2

If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The first officer will confirm any change in the Engine Anti-Ice switch position and advise the other pilot once the checklist item is complete. The Hydraulic System B advisory that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power.

- The Ground Proximity Monitor indication is expected to read within the sample range of 49 to 57 units during engine start.
- The Traffic Advisory Display selector position is expected to read within the sample range of 46 to 51 units during climb.
- The Flap Position Indication status message that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center.
- If the Autobrake Selector is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

- If the Cargo Smoke Detection is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- The pilot flying will cross-check any change in the Cabin Pressure Controller indication and advise the other pilot when conditions permit.

NOTE: During cruise, the pilot flying should announce the Probe Heat switch position once the checklist item is complete.

Condition	Sample value	Remarks
Autopilot Channel B annunciation	30 units	Refer to related topic
Oxygen Distribution annunciation	35 units	Refer to related topic
Oxygen Distribution status message	94 units	Normal
Stall Warning quantity display	84 units	Advisory only
Flap Position Indication annunciation	14 units	Advisory only

CAUTION: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Wing Anti-Ice switch position	2 units	Monitor
Autothrottle indication	13 units	Normal
Bleed Air Supply switch position	83 units	Monitor

08.30.3 Enroute Policy 3

During approach, the relief pilot should confirm the Hydraulic System A advisory when conditions permit. The Ground Proximity Monitor switch position that differs from the expected state requires the relief pilot to confirm the condition unless directed otherwise by the Sample Operations Center. During approach, the pilot flying should brief the Flap Position Indication switch position when operating at a sample station without ground power. The Weather Radar quantity display that differs from the expected state requires both pilots to announce the condition before the next phase of flight.

NOTE: The Hydraulic System B switch position is expected to read within the sample range of 40 to 52 units during landing.

If the Nosewheel Steering is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. During descent, the pilot flying should confirm the Cabin Pressure Controller advisory when the associated caution light remains illuminated. The Hydraulic System B selector position that differs from the expected state requires the pilot flying to announce the condition if the indication does not stabilize within the sample interval. The pilot flying will verify any change in the Stall Warning status message and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

The Pack Temperature Control switch position is expected to read within the sample range of 7 to 11 units during climb. During climb, the Captain should select the Landing Gear Indication selector position when the associated caution light remains illuminated. During preflight, the First Officer should confirm the Probe Heat quantity display once the checklist item is complete. The Autopilot Channel A annunciation is expected to read within the sample range of 79 to 83 units during a turnaround. The Stall Warning status message is expected to read within the sample range of 23 to 30 units during climb. The wording here is placeholder content shaped like a procedure, not a procedure.

08.30.4 Enroute Policy 4

The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will verify any change in the Brake Temperature Monitor quantity display and advise the other pilot once the checklist item is complete. If the Stall Warning is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. Both pilots will select any change in the Autopilot Channel B status message and advise the other pilot when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

- The pilot flying will monitor any change in the Traffic Advisory Display advisory and advise the other pilot when the associated caution light remains illuminated.
- During parking, the relief pilot should record the Ground Proximity Monitor switch position before the next phase of flight.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Cockpit Voice Recorder selector position is expected to read within the sample range of 10 to 22 units during a diversion.
- Both pilots will cross-check any change in the Weather Radar status message and advise the other pilot before the next phase of flight.
- Both pilots will cross-check any change in the Speedbrake Handle annunciation and advise the other pilot when operating at a sample station without ground power.
- If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.
- If the Traffic Advisory Display is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.
- During a turnaround, the pilot monitoring should cross-check the Wing Anti-Ice switch position unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.

If the Weather Radar is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. The Autobrake Selector status message that differs from the expected state requires both pilots to brief the condition before the next phase of flight. The relief pilot will announce any change in the Standby Hydraulic annunciation and advise the other pilot when conditions permit.

The first officer will cross-check any change in the Flight Management Computer advisory and advise the other pilot when operating at a sample station without ground power. If the Autothrottle is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Standby Hydraulic switch position is expected to read within the sample range of 19 to 31 units during engine start.

08.30.5 Enroute Policy 5

The Autopilot Channel A annunciation that differs from the expected state requires the Captain to announce the condition if a discrepancy is observed. The Wing Anti-Ice annunciation is expected to read within the sample range of 74 to 84 units during a diversion. During a turnaround, the Captain should monitor the Fuel Crossfeed status message unless directed otherwise by the Sample Operations Center. The Autopilot Channel B switch position is expected to read within the sample range of 86 to 94 units during a diversion. The Oxygen Distribution selector position that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. During engine start, both pilots should confirm the Auxiliary Power Unit annunciation unless directed otherwise by the Sample Operations Center.

The Autothrottle selector position is expected to read within the sample range of 20 to 30 units during climb. The captain will record any change in the Bleed Air Supply status message and advise the other pilot once the checklist item is complete. If the Landing Gear Indication is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue cruise only after the

First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Stall Warning status message	43 units	Advisory only
Fuel Crossfeed indication	26 units	Advisory only
Traffic Advisory Display status message	33 units	Advisory only
Autobrake Selector status message	50 units	Advisory only
Landing Gear Indication annunciation	39 units	Normal
Center Tank Pumps indication	8 units	Advisory only
Autobrake Selector advisory	49 units	Normal

The Transponder status message that differs from the expected state requires the First Officer to brief the condition when conditions permit. During takeoff, the pilot flying should cross-check the Cabin Pressure Controller quantity display if the indication does not stabilize within the sample interval. The Autothrottle indication is expected to read within the sample range of 33 to 41 units during a diversion.

During engine start, both pilots should announce the Center Tank Pumps indication if a discrepancy is observed. The Standby Hydraulic annunciation is expected to read within the sample range of 62 to 72 units during landing. The Speedbrake Handle indication is expected to read within the sample range of 75 to 84 units during climb.

08.30.6 Enroute Policy 6

During a turnaround, both pilots should announce the Probe Heat selector position unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection switch position that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated. The Oxygen Distribution indication that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. The relief pilot will confirm any change in the Landing Gear Indication selector position and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. Both pilots will select any change in the Pack Temperature Control indication and advise the other pilot when conditions permit.

NOTE: The Autothrottle quantity display that differs from the expected state requires the pilot flying to cross-check the condition when the associated caution light remains illuminated.

- The Weather Radar indication is expected to read within the sample range of 74 to 84 units during taxi.
- The Wing Anti-Ice status message is expected to read within the sample range of 66 to 70 units during a diversion.
- If the Flap Position Indication is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.

Both pilots will confirm any change in the Transponder status message and advise the other pilot once the checklist item is complete. The Cabin Pressure Controller annunciation that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

If the Pack Temperature Control is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During preflight, the First Officer should record the Speedbrake Handle quantity display when conditions permit. During preflight, the pilot monitoring should verify the Standby Hydraulic advisory once the checklist item is complete. The Autopilot Channel A selector position is expected to read within the sample range of 53 to 59 units during landing. The first officer will record any change in the Probe Heat switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Cabin Pressure Controller selector

position is expected to read within the sample range of 66 to 78 units during climb.

Refer to the related topic for additional sample context. The Traffic Advisory Display indication that differs from the expected state requires the relief pilot to brief the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Primary Electrical Bus selector position and advise the other pilot before the next phase of flight.

08.30.7 Enroute Policy 7

During approach, both pilots should cross-check the Oxygen Distribution selector position when conditions permit. During landing, the Captain should monitor the Autobrake Selector indication if the indication does not stabilize within the sample interval. The Cabin Pressure Controller advisory is expected to read within the sample range of 97 to 102 units during a diversion. The Weather Radar annunciation that differs from the expected state requires the First Officer to cross-check the condition unless directed otherwise by the Sample Operations Center.

If the Fire Detection Loop is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The Primary Electrical Bus indication that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete. The Engine Anti-Ice quantity display that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed. Both pilots will verify any change in the Hydraulic System B indication and advise the other pilot when conditions permit. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. During parking, the relief pilot should brief the Autopilot Channel B indication when conditions permit.

CAUTION: During parking, the First Officer should select the Autopilot Channel B switch position if the indication does not stabilize within the sample interval. The pilot monitoring will cross-check any change in the Window Heat advisory and advise the other pilot before the next phase of flight.

- If the Engine Anti-Ice is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.
- If the Autopilot Channel A is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.
- The Fire Detection Loop advisory that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval.
- The relief pilot will cross-check any change in the Bleed Air Supply status message and advise the other pilot if the indication does not stabilize within the sample interval.
- The Oxygen Distribution indication that differs from the expected state requires the Captain to select the condition when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.

If the Autothrottle is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. During engine start, both pilots should announce the Transponder switch position once the checklist item is complete. During a maintenance-requested ground run, the Captain should verify the Pack Temperature Control selector position when conditions permit. Refer to the related topic for additional sample context.

NOTE: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Brake Temperature Monitor quantity display	9 units	Monitor
Thrust Reverser status message	81 units	Advisory only
Hydraulic System A switch position	22 units	Monitor

CAUTION: If the Traffic Advisory Display is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autothrottle selector position	52 units	Advisory only
Autopilot Channel A quantity display	87 units	Refer to related topic
Flight Management Computer annunciation	9 units	Normal
Wing Anti-Ice quantity display	52 units	Refer to related topic
Fire Detection Loop switch position	25 units	Normal
Auxiliary Power Unit advisory	21 units	Normal

08.30.8 Enroute Policy 8

The captain will cross-check any change in the Pack Temperature Control advisory and advise the other pilot before the next phase of flight. The Window Heat selector position is expected to read within the sample range of 49 to 59 units during parking. The Autobrake Selector switch position is expected to read within the sample range of 48 to 54 units during engine start. The Cockpit Voice Recorder quantity display that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center. The pilot flying will record any change in the Flight Management Computer annunciation and advise the other pilot when conditions permit. During preflight, both pilots should verify the Flap Position Indication status message if a discrepancy is observed.

NOTE: The Stall Warning annunciation that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval. During an extended ground delay, the relief pilot should announce the Speedbrake Handle annunciation if a discrepancy is observed.

Condition	Sample value	Remarks
Pack Temperature Control selector position	29 units	Advisory only
Speedbrake Handle quantity display	4 units	Monitor
Fire Detection Loop annunciation	40 units	Monitor
Weather Radar quantity display	24 units	Normal
Auxiliary Power Unit indication	87 units	Refer to related topic

NOTE: Both pilots will record any change in the Cargo Smoke Detection switch position and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose.

The captain will cross-check any change in the Hydraulic System B status message and advise the other pilot if a discrepancy is observed. During climb, the pilot monitoring should record the Landing Gear Indication status message if the indication does not stabilize within the sample interval. The first officer will monitor any change in the Autobrake Selector annunciation and advise the other pilot if a discrepancy is observed. If the Brake Temperature Monitor is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

- The Fire Detection Loop indication is expected to read within the sample range of 87 to 91 units during a turnaround.
- During a turnaround, the pilot monitoring should confirm the Cockpit Voice Recorder status message when operating at a sample station without ground power.
- The Hydraulic System A selector position is expected to read within the sample range of 33 to 43 units during landing.

- If the Traffic Advisory Display is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Instruments selector position	85 units	Refer to related topic
Center Tank Pumps status message	59 units	Monitor
Standby Hydraulic advisory	84 units	Monitor
Autopilot Channel B status message	67 units	Monitor

Chapter 09 Arrival

09.10 Arrival: Part A

09.10.1 Arrival Policy 1

During climb, the relief pilot should record the Center Tank Pumps quantity display if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During climb, the Captain should record the Fuel Crossfeed switch position when the associated caution light remains illuminated.

This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed status message is expected to read within the sample range of 3 to 9 units during climb. The Primary Electrical Bus switch position that differs from the expected state requires the pilot monitoring to record the condition when operating at a sample station without ground power. During a diversion, the First Officer should select the Wing Anti-Ice quantity display unless directed otherwise by the Sample Operations Center.

The first officer will select any change in the Hydraulic System A advisory and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The Hydraulic System A switch position that differs from the expected state requires the Captain to brief the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

- If the Brake Temperature Monitor is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- During a diversion, the pilot monitoring should confirm the Cabin Pressure Controller annunciation if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.
- The Nosewheel Steering advisory is expected to read within the sample range of 3 to 12 units during engine start.
- During an extended ground delay, both pilots should verify the Landing Gear Indication selector position unless directed otherwise by the Sample Operations Center.

During a maintenance-requested ground run, the pilot flying should verify the Wing Anti-Ice selector position if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. The Brake Temperature Monitor switch position is expected to read within the sample range of 41 to 48 units during parking. If the Wing Anti-Ice is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

If the Cargo Smoke Detection is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. During parking, both pilots should record the Engine Anti-Ice quantity display if a discrepancy is observed. During taxi, the pilot flying should brief the Pack Temperature Control selector position when the associated caution light remains illuminated.

The Cabin Pressure Controller annunciation is expected to read within the sample range of 31 to 34 units during approach. Values in this manual are invented and must not be used for any operational purpose. The Cockpit Voice Recorder annunciation is expected to read within the sample range of 12 to 19 units during landing.

NOTE: Refer to the related topic for additional sample context.

09.10.2 Arrival Policy 2

The pilot flying will brief any change in the Cockpit Voice Recorder indication and advise the other pilot when the associated caution light remains illuminated. The Cargo Smoke Detection switch position is expected to read within

the sample range of 2 to 13 units during cruise. The pilot monitoring will record any change in the Flight Management Computer indication and advise the other pilot when conditions permit. The Bleed Air Supply indication is expected to read within the sample range of 91 to 98 units during takeoff. Refer to the related topic for additional sample context. If the Cargo Smoke Detection is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

The relief pilot will verify any change in the Traffic Advisory Display annunciation and advise the other pilot if the indication does not stabilize within the sample interval. During takeoff, the pilot flying should monitor the Speedbrake Handle advisory once the checklist item is complete. If the Flap Position Indication is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autobrake Selector annunciation	74 units	Normal
Standby Instruments annunciation	51 units	Monitor
Window Heat indication	55 units	Monitor
Autobrake Selector advisory	47 units	Monitor

- If the Hydraulic System A is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- If the Autopilot Channel A is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- The Wing Anti-Ice status message that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval.
- During preflight, the First Officer should confirm the Speedbrake Handle selector position if a discrepancy is observed.
- The first officer will confirm any change in the Probe Heat advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Autobrake Selector is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- The Thrust Reverser annunciation that differs from the expected state requires the First Officer to select the condition when conditions permit.
- If the Autobrake Selector is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

NOTE: If the Hydraulic System A is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Ground Proximity Monitor is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. If the Pack Temperature Control is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated. The Pack Temperature Control quantity display that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete. During takeoff, the Captain should record the Probe Heat status message once the checklist item is complete. The

first officer will cross-check any change in the Autopilot Channel A annunciation and advise the other pilot when the associated caution light remains illuminated. During climb, the First Officer should cross-check the Speedbrake Handle selector position when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

09.10.3 Arrival Policy 3

During a diversion, the pilot monitoring should confirm the Pack Temperature Control annunciation once the checklist item is complete. The Wing Anti-Ice selector position is expected to read within the sample range of 47 to 53 units during cruise. The first officer will cross-check any change in the Primary Electrical Bus indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. During takeoff, the First Officer should cross-check the Fire Detection Loop indication unless directed otherwise by the Sample Operations Center.

The Thrust Reverser annunciation that differs from the expected state requires the Captain to select the condition before the next phase of flight. The Stall Warning status message is expected to read within the sample range of 76 to 81 units during taxi. The wording here is placeholder content shaped like a procedure, not a procedure. If the Flight Management Computer is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Cargo Smoke Detection advisory and advise the other pilot before the next phase of flight. If the Stall Warning is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

- The captain will monitor any change in the Thrust Reverser annunciation and advise the other pilot once the checklist item is complete.
- If the Autobrake Selector is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Refer to the related topic for additional sample context.

NOTE: If the Bleed Air Supply is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The Engine Anti-Ice annunciation that differs from the expected state requires the pilot flying to cross-check the condition when conditions permit.

NOTE: Refer to the related topic for additional sample context. If the Hydraulic System A is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. During an extended ground delay, the Captain should monitor the Autothrottle indication once the checklist item is complete.

09.10.4 Arrival Policy 4

The Autothrottle annunciation that differs from the expected state requires the pilot monitoring to verify the condition before the next phase of flight. The Cabin Pressure Controller indication is expected to read within the sample range of 80 to 92 units during parking. The pilot flying will confirm any change in the Cargo Smoke Detection status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will cross-check any change in the Brake Temperature Monitor indication and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

The first officer will announce any change in the Autopilot Channel B selector position and advise the other pilot before the next phase of flight. The Flap Position Indication quantity display is expected to read within the sample range of 29 to 37 units during a diversion. The Traffic Advisory Display quantity display that differs from the expected state requires the Captain to select the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Speedbrake Handle status message	14 units	Refer to related topic
Cabin Pressure Controller quantity display	13 units	Advisory only
Standby Instruments annunciation	43 units	Normal
Cockpit Voice Recorder advisory	49 units	Refer to related topic
Autothrottle quantity display	99 units	Advisory only
Pack Temperature Control indication	15 units	Refer to related topic
Standby Instruments switch position	51 units	Normal

- If the Hydraulic System B is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Thrust Reverser annunciation that differs from the expected state requires both pilots to brief the condition if a discrepancy is observed.
- If the Speedbrake Handle is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.
- The Oxygen Distribution advisory that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval.
- If the Cockpit Voice Recorder is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

NOTE: The Autopilot Channel B annunciation is expected to read within the sample range of 49 to 55 units during engine start.

- The pilot monitoring will verify any change in the Pack Temperature Control quantity display and advise the other pilot if the indication does not stabilize within the sample interval.
- The Nosewheel Steering indication that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated.
- If the Cargo Smoke Detection is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- If the Autothrottle is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.
- The captain will announce any change in the Autothrottle selector position and advise the other pilot when the associated caution light remains illuminated.

Refer to the related topic for additional sample context. During a maintenance-requested ground run, the First Officer should cross-check the Hydraulic System B indication once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The Weather Radar selector position that differs from the expected state requires the relief pilot to monitor the condition when conditions permit.

The pilot monitoring will select any change in the Flap Position Indication switch position and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Fuel

Crossfeed advisory is expected to read within the sample range of 58 to 66 units during parking. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will record any change in the Fuel Crossfeed indication and advise the other pilot if the indication does not stabilize within the sample interval. The Nosewheel Steering status message that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed.

09.10.5 Arrival Policy 5

Refer to the related topic for additional sample context. The Autobrake Selector annunciation is expected to read within the sample range of 84 to 87 units during a maintenance-requested ground run. The pilot monitoring will confirm any change in the Auxiliary Power Unit quantity display and advise the other pilot before the next phase of flight. The Flight Management Computer indication is expected to read within the sample range of 66 to 71 units during a turnaround. The captain will cross-check any change in the Autopilot Channel A annunciation and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Autopilot Channel A advisory	20 units	Refer to related topic
Traffic Advisory Display annunciation	29 units	Advisory only
Thrust Reverser indication	72 units	Monitor
Bleed Air Supply advisory	91 units	Advisory only
Stall Warning quantity display	30 units	Monitor
Window Heat indication	18 units	Monitor

The pilot flying will select any change in the Fire Detection Loop advisory and advise the other pilot when the associated caution light remains illuminated. If the Autopilot Channel B is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During parking, the First Officer should announce the Autopilot Channel B switch position if the indication does not stabilize within the sample interval.

The Probe Heat indication that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. The first officer will select any change in the Stall Warning indication and advise the other pilot when operating at a sample station without ground power. The Landing Gear Indication selector position is expected to read within the sample range of 32 to 39 units during approach. If the Standby Instruments is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The pilot flying will select any change in the Cargo Smoke Detection annunciation and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Pack Temperature Control annunciation	58 units	Monitor
Ground Proximity Monitor switch position	69 units	Normal
Fire Detection Loop annunciation	60 units	Refer to related topic

The Probe Heat status message is expected to read within the sample range of 14 to 18 units during preflight. During descent, the Captain should record the Cabin Pressure Controller selector position when the associated caution light remains illuminated. During taxi, the Captain should select the Speedbrake Handle advisory before the next phase of flight.

Condition	Sample value	Remarks
Fuel Crossfeed quantity display	36 units	Advisory only
Standby Hydraulic switch position	52 units	Normal
Autothrottle advisory	90 units	Normal

Wing Anti-Ice quantity display	13 units	Refer to related topic
--------------------------------	----------	------------------------

Both pilots will verify any change in the Weather Radar advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Traffic Advisory Display advisory that differs from the expected state requires the Captain to monitor the condition when operating at a sample station without ground power. The first officer will monitor any change in the Speedbrake Handle indication and advise the other pilot when conditions permit.

- During a diversion, both pilots should brief the Standby Hydraulic annunciation if a discrepancy is observed.
- The Center Tank Pumps annunciation is expected to read within the sample range of 9 to 15 units during cruise.
- The Center Tank Pumps selector position that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power.
- Refer to the related topic for additional sample context.
- The first officer will cross-check any change in the Oxygen Distribution advisory and advise the other pilot before the next phase of flight.

09.10.6 Arrival Policy 6

Both pilots will brief any change in the Nosewheel Steering quantity display and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will confirm any change in the Weather Radar advisory and advise the other pilot when the associated caution light remains illuminated. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Standby Instruments annunciation is expected to read within the sample range of 60 to 69 units during engine start. If the Center Tank Pumps is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Window Heat advisory	51 units	Refer to related topic
Hydraulic System B selector position	4 units	Normal
Bleed Air Supply indication	87 units	Advisory only
Autobrake Selector switch position	79 units	Refer to related topic
Flap Position Indication selector position	44 units	Monitor
Weather Radar quantity display	19 units	Normal

NOTE: The Hydraulic System B indication is expected to read within the sample range of 58 to 67 units during cruise.

CAUTION: If the Traffic Advisory Display is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context.

During approach, the pilot flying should monitor the Hydraulic System A switch position before the next phase of flight. The Standby Hydraulic indication is expected to read within the sample range of 87 to 92 units during landing. The Hydraulic System A quantity display is expected to read within the sample range of 61 to 65 units during takeoff. During parking, the relief pilot should announce the Pack Temperature Control switch position when operating at a sample station without ground power. The first officer will record any change in the Transponder switch position and advise the other pilot before the next phase of flight.

Refer to the related topic for additional sample context. The Standby Instruments quantity display is expected to read within the sample range of 11 to 22 units during approach. Both pilots will brief any change in the Cabin Pressure Controller indication and advise the other pilot when operating at a sample station without ground power. During an extended ground delay, the First Officer should brief the Cabin Pressure Controller switch position when the

associated caution light remains illuminated.

- During an extended ground delay, the First Officer should brief the Autopilot Channel A quantity display unless directed otherwise by the Sample Operations Center.
- If the Stall Warning is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.
- If the Cockpit Voice Recorder is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- The Autobrake Selector quantity display that differs from the expected state requires the Captain to select the condition once the checklist item is complete.
- If the Flight Management Computer is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.
- The Autobrake Selector annunciation is expected to read within the sample range of 36 to 46 units during landing.

The Standby Instruments switch position that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center. During climb, the relief pilot should brief the Pack Temperature Control annunciation when the associated caution light remains illuminated. During parking, both pilots should brief the Autopilot Channel B selector position if a discrepancy is observed.

09.10.7 Arrival Policy 7

The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. If the Autothrottle is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The relief pilot will confirm any change in the Nosewheel Steering indication and advise the other pilot before the next phase of flight. The Cabin Pressure Controller switch position that differs from the expected state requires the pilot flying to monitor the condition once the checklist item is complete. The Traffic Advisory Display advisory is expected to read within the sample range of 66 to 73 units during takeoff.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a diversion, the First Officer should announce the Flight Management Computer quantity display when the associated caution light remains illuminated.
- The Transponder status message that differs from the expected state requires the pilot monitoring to select the condition when the associated caution light remains illuminated.
- The Fuel Crossfeed selector position is expected to read within the sample range of 84 to 88 units during descent.
- The pilot monitoring will cross-check any change in the Engine Anti-Ice status message and advise the other pilot when the associated caution light remains illuminated.
- The pilot flying will select any change in the Ground Proximity Monitor annunciation and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Stall Warning annunciation	22 units	Monitor
Thrust Reverser quantity display	46 units	Advisory only
Flap Position Indication advisory	54 units	Refer to related topic
Thrust Reverser annunciation	99 units	Normal

The captain will verify any change in the Flight Management Computer advisory and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, both pilots should confirm the Standby Hydraulic advisory once the checklist item is complete. The Cabin

Pressure Controller selector position is expected to read within the sample range of 92 to 104 units during engine start. During a maintenance-requested ground run, the First Officer should confirm the Thrust Reverser selector position if the indication does not stabilize within the sample interval.

The Cabin Pressure Controller indication is expected to read within the sample range of 9 to 21 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure. If the Cabin Pressure Controller is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Center Tank Pumps selector position and advise the other pilot when the associated caution light remains illuminated. The Autobrake Selector indication that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed.

Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor switch position that differs from the expected state requires the pilot flying to verify the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autobrake Selector is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Cabin Pressure Controller indication is expected to read within the sample range of 70 to 76 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Standby Hydraulic quantity display	76 units	Advisory only
Engine Anti-Ice annunciation	96 units	Monitor
Primary Electrical Bus selector position	70 units	Monitor
Bleed Air Supply selector position	63 units	Advisory only

CAUTION: If the Auxiliary Power Unit is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will monitor any change in the Primary Electrical Bus selector position and advise the other pilot before the next phase of flight.

09.10.8 Arrival Policy 8

Values in this manual are invented and must not be used for any operational purpose. The Autobrake Selector indication is expected to read within the sample range of 35 to 38 units during cruise. During cruise, both pilots should verify the Ground Proximity Monitor annunciation if a discrepancy is observed.

CAUTION: If the Center Tank Pumps is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

The pilot flying will verify any change in the Transponder selector position and advise the other pilot when operating at a sample station without ground power. The Cabin Pressure Controller indication is expected to read within the sample range of 76 to 86 units during landing. The Autopilot Channel B selector position that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The pilot monitoring will brief any change in the Standby Hydraulic selector position and advise the other pilot if the indication does not stabilize within the sample interval.

- Values in this manual are invented and must not be used for any operational purpose.
- If the Cargo Smoke Detection is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.
- The Fuel Crossfeed advisory is expected to read within the sample range of 77 to 82 units during taxi.
- The pilot monitoring will monitor any change in the Nosewheel Steering status message and advise the other pilot when operating at a sample station without ground power.

- If the Flap Position Indication is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.

If the Pack Temperature Control is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance. During landing, the pilot monitoring should confirm the Pack Temperature Control advisory unless directed otherwise by the Sample Operations Center. Both pilots will confirm any change in the Brake Temperature Monitor status message and advise the other pilot when conditions permit. Both pilots will brief any change in the Center Tank Pumps status message and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will verify any change in the Bleed Air Supply advisory and advise the other pilot when conditions permit.

- The Stall Warning annunciation that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Both pilots will record any change in the Landing Gear Indication annunciation and advise the other pilot once the checklist item is complete.
- The pilot monitoring will record any change in the Fire Detection Loop switch position and advise the other pilot when the associated caution light remains illuminated.
- If the Oxygen Distribution is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

The Ground Proximity Monitor status message that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will record any change in the Speedbrake Handle quantity display and advise the other pilot when conditions permit. If the Window Heat is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

09.20 Arrival: Part B

09.20.1 Arrival Policy 1

If the Standby Instruments is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. During taxi, the Captain should brief the Traffic Advisory Display switch position when the associated caution light remains illuminated. The pilot flying will cross-check any change in the Traffic Advisory Display switch position and advise the other pilot if a discrepancy is observed. The Bleed Air Supply annunciation is expected to read within the sample range of 89 to 99 units during takeoff. The Cargo Smoke Detection quantity display is expected to read within the sample range of 8 to 16 units during taxi. During an extended ground delay, both pilots should verify the Transponder switch position unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Ground Proximity Monitor switch position	9 units	Monitor
Auxiliary Power Unit selector position	32 units	Advisory only
Probe Heat annunciation	93 units	Advisory only

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure.

The relief pilot will select any change in the Cockpit Voice Recorder switch position and advise the other pilot before the next phase of flight. The Oxygen Distribution quantity display that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed. The Stall Warning indication is expected to read within the sample range of 11 to 19 units during preflight. The Bleed Air Supply switch position is expected to read within the sample range of 88 to 92 units during preflight.

Condition	Sample value	Remarks
Hydraulic System A advisory	38 units	Monitor
Cockpit Voice Recorder quantity display	52 units	Normal
Autopilot Channel A annunciation	14 units	Advisory only
Wing Anti-Ice status message	30 units	Normal
Traffic Advisory Display status message	29 units	Advisory only
Pack Temperature Control quantity display	8 units	Normal

09.20.2 Arrival Policy 2

The first officer will select any change in the Cargo Smoke Detection quantity display and advise the other pilot when conditions permit. If the Flap Position Indication is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. During cruise, both pilots should confirm the Pack Temperature Control annunciation before the next phase of flight. The relief pilot will record any change in the Auxiliary Power Unit selector position and advise the other pilot if a discrepancy is observed.

CAUTION: The Autobrake Selector switch position is expected to read within the sample range of 62 to 69 units during approach. The Thrust Reverser switch position that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.

During preflight, the pilot flying should record the Standby Hydraulic advisory if a discrepancy is observed. The Flap Position Indication quantity display is expected to read within the sample range of 73 to 84 units during a turnaround. If the Standby Instruments is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Brake Temperature Monitor selector position that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. During engine start, both pilots should record the Autobrake Selector quantity display unless directed otherwise by the Sample Operations Center.

The Flight Management Computer quantity display that differs from the expected state requires the pilot flying to verify the condition when conditions permit. The Wing Anti-Ice switch position that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel B status message is expected to read within the sample range of 64 to 67 units during approach. During takeoff, the pilot monitoring should confirm the Nosewheel Steering annunciation when operating at a sample station without ground power. During landing, the relief pilot should announce the Ground Proximity Monitor switch position once the checklist item is complete.

Condition	Sample value	Remarks
Hydraulic System A indication	2 units	Refer to related topic
Hydraulic System B quantity display	5 units	Monitor
Autobrake Selector selector position	33 units	Monitor
Autopilot Channel A indication	9 units	Advisory only
Standby Hydraulic switch position	97 units	Advisory only
Cabin Pressure Controller switch position	47 units	Monitor
Autothrottle switch position	91 units	Refer to related topic

09.20.3 Arrival Policy 3

The wording here is placeholder content shaped like a procedure, not a procedure. During landing, the Captain should verify the Transponder annunciation before the next phase of flight. If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Autopilot Channel A annunciation that differs from the expected state requires the pilot flying to

cross-check the condition when conditions permit. The captain will verify any change in the Landing Gear Indication indication and advise the other pilot when the associated caution light remains illuminated.

CAUTION: Both pilots will verify any change in the Cockpit Voice Recorder selector position and advise the other pilot before the next phase of flight.

During a diversion, the relief pilot should verify the Engine Anti-Ice annunciation unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. During engine start, the First Officer should select the Autopilot Channel B indication when operating at a sample station without ground power. The Flap Position Indication status message that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. The relief pilot will verify any change in the Autopilot Channel B advisory and advise the other pilot when conditions permit. Both pilots will confirm any change in the Autopilot Channel B quantity display and advise the other pilot once the checklist item is complete.

The Pack Temperature Control selector position that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated. The Pack Temperature Control quantity display is expected to read within the sample range of 61 to 64 units during preflight. The Autopilot Channel A annunciation that differs from the expected state requires the Captain to announce the condition unless directed otherwise by the Sample Operations Center. If the Standby Hydraulic is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The relief pilot will brief any change in the Probe Heat selector position and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Autopilot Channel A status message that differs from the expected state requires the Captain to monitor the condition before the next phase of flight.

09.20.4 Arrival Policy 4

The Cabin Pressure Controller indication that differs from the expected state requires the First Officer to monitor the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. Both pilots will confirm any change in the Ground Proximity Monitor indication and advise the other pilot if a discrepancy is observed.

This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, the relief pilot should announce the Cockpit Voice Recorder selector position when the associated caution light remains illuminated. The Traffic Advisory Display indication that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete. If the Window Heat is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance.

The pilot flying will confirm any change in the Flap Position Indication annunciation and advise the other pilot if a discrepancy is observed. If the Weather Radar is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication annunciation that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

- The captain will record any change in the Flight Management Computer switch position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Wing Anti-Ice annunciation is expected to read within the sample range of 18 to 26 units during takeoff.
- The first officer will monitor any change in the Primary Electrical Bus advisory and advise the other pilot once the checklist item is complete.

Both pilots will verify any change in the Weather Radar selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The first officer will announce any change in the Engine Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

The Standby Instruments advisory is expected to read within the sample range of 41 to 44 units during preflight. The Fuel Crossfeed selector position that differs from the expected state requires the First Officer to announce the condition when conditions permit. The Window Heat indication that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. The Primary Electrical Bus annunciation is expected to read within the sample range of 52 to 56 units during descent.

During an extended ground delay, the Captain should confirm the Standby Instruments selector position before the next phase of flight. The Weather Radar advisory that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. The Fire Detection Loop switch position is expected to read within the sample range of 91 to 98 units during a turnaround.

The Flight Management Computer advisory is expected to read within the sample range of 42 to 47 units during takeoff. During preflight, both pilots should verify the Transponder selector position once the checklist item is complete. The Brake Temperature Monitor quantity display that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight. The Hydraulic System B quantity display that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval. The Wing Anti-Ice indication is expected to read within the sample range of 66 to 75 units during parking. The Speedbrake Handle switch position that differs from the expected state requires the First Officer to brief the condition when conditions permit.

09.20.5 Arrival Policy 5

The Autothrottle switch position that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. The pilot flying will announce any change in the Standby Hydraulic advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Stall Warning annunciation that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated. During climb, the First Officer should select the Primary Electrical Bus selector position if a discrepancy is observed.

Values in this manual are invented and must not be used for any operational purpose. The Ground Proximity Monitor quantity display that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The first officer will announce any change in the Thrust Reverser quantity display and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Speedbrake Handle indication that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. The Transponder selector position is expected to read within the sample range of 96 to 105 units during a diversion.

The first officer will record any change in the Window Heat quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During parking, both pilots should select the Wing Anti-Ice switch position if the indication does not stabilize within the sample interval. During takeoff, both pilots should monitor the Fuel Crossfeed switch position unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance.

During approach, the pilot flying should confirm the Hydraulic System B switch position unless directed otherwise by the Sample Operations Center. If the Flap Position Indication is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, the pilot monitoring should record the Ground Proximity Monitor annunciation unless directed otherwise by the Sample Operations Center.

The Weather Radar indication is expected to read within the sample range of 79 to 86 units during takeoff. The Standby Instruments selector position that differs from the expected state requires the Captain to verify the condition before the next phase of flight. During descent, both pilots should brief the Fire Detection Loop annunciation if a discrepancy is observed.

- The Standby Hydraulic indication is expected to read within the sample range of 25 to 36 units during a maintenance-requested ground run.
- During parking, the relief pilot should confirm the Fire Detection Loop selector position once the checklist item is complete.
- The pilot flying will select any change in the Fuel Crossfeed advisory and advise the other pilot if the indication does not stabilize within the sample interval.

The Standby Hydraulic quantity display is expected to read within the sample range of 48 to 51 units during preflight. The Oxygen Distribution indication is expected to read within the sample range of 15 to 26 units during taxi. The Autopilot Channel A switch position is expected to read within the sample range of 50 to 57 units during cruise. The captain will monitor any change in the Cargo Smoke Detection advisory and advise the other pilot if the indication does not stabilize within the sample interval.

If the Cargo Smoke Detection is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Traffic Advisory Display switch position is expected to read within the sample range of 89 to 95 units during approach. If the Autobrake Selector is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

09.20.6 Arrival Policy 6

If the Landing Gear Indication is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The Autopilot Channel A advisory that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

- If the Transponder is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.
- The Landing Gear Indication selector position is expected to read within the sample range of 30 to 39 units during approach.
- Refer to the related topic for additional sample context.
- During approach, the relief pilot should brief the Primary Electrical Bus selector position once the checklist item is complete.

NOTE: If the Traffic Advisory Display is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Standby Hydraulic annunciation that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval.

- The Flap Position Indication indication is expected to read within the sample range of 65 to 73 units during approach.
- The Center Tank Pumps annunciation that differs from the expected state requires the First Officer to brief the condition once the checklist item is complete.
- During preflight, both pilots should select the Transponder quantity display if a discrepancy is observed.
- The Cabin Pressure Controller quantity display is expected to read within the sample range of 64 to 74 units during an extended ground delay.
- Values in this manual are invented and must not be used for any operational purpose.
- Both pilots will record any change in the Hydraulic System A quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

Refer to the related topic for additional sample context. The pilot flying will record any change in the Standby Hydraulic quantity display and advise the other pilot when operating at a sample station without ground power. This

text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: Both pilots will confirm any change in the Center Tank Pumps advisory and advise the other pilot if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

09.20.7 Arrival Policy 7

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. If the Hydraulic System A is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Bleed Air Supply quantity display is expected to read within the sample range of 45 to 57 units during a maintenance-requested ground run. The Probe Heat selector position is expected to read within the sample range of 89 to 101 units during descent.

CAUTION: If the Fuel Crossfeed is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Autothrottle annunciation that differs from the expected state requires the pilot monitoring to confirm the condition when operating at a sample station without ground power.

NOTE: The first officer will verify any change in the Thrust Reverser indication and advise the other pilot if a discrepancy is observed. The Bleed Air Supply annunciation is expected to read within the sample range of 50 to 57 units during descent.

The Autobrake Selector switch position that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. The relief pilot will announce any change in the Autobrake Selector switch position and advise the other pilot when conditions permit. During a maintenance-requested ground run, the Captain should announce the Standby Instruments indication once the checklist item is complete. If the Window Heat is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The Pack Temperature Control selector position is expected to read within the sample range of 5 to 15 units during preflight.

- The Landing Gear Indication indication that differs from the expected state requires the Captain to monitor the condition when the associated caution light remains illuminated.
- Refer to the related topic for additional sample context.
- The Oxygen Distribution quantity display that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval.
- During landing, the Captain should cross-check the Wing Anti-Ice switch position unless directed otherwise by the Sample Operations Center.

09.20.8 Arrival Policy 8

This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution selector position is expected to read within the sample range of 79 to 87 units during an extended ground delay. The first officer will select any change in the Window Heat advisory and advise the other pilot if a discrepancy is observed. The Center Tank Pumps selector position that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. During climb, both pilots should monitor the Engine Anti-Ice indication when operating at a sample station without ground power. The Autobrake Selector selector position is expected to read within the sample range of 54 to 62 units during parking.

The Oxygen Distribution selector position that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. The Pack Temperature Control indication is expected to read within the sample range of 51 to 57 units during preflight. If the Ground Proximity Monitor is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The captain will monitor any change in the Weather Radar quantity display and advise the other pilot if a discrepancy is observed. The captain will record any change in the Autothrottle quantity display and advise the other pilot before the next phase of flight.

Condition	Sample value	Remarks
Traffic Advisory Display annunciation	82 units	Refer to related topic
Window Heat quantity display	43 units	Normal
Cargo Smoke Detection status message	89 units	Refer to related topic
Weather Radar advisory	74 units	Monitor
Auxiliary Power Unit selector position	47 units	Advisory only
Flight Management Computer selector position	56 units	Advisory only

The first officer will select any change in the Flight Management Computer indication and advise the other pilot if a discrepancy is observed. During a maintenance-requested ground run, the Captain should confirm the Hydraulic System A indication before the next phase of flight. If the Primary Electrical Bus is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

The relief pilot will brief any change in the Landing Gear Indication annunciation and advise the other pilot when the associated caution light remains illuminated. If the Transponder is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. During climb, both pilots should select the Primary Electrical Bus advisory if a discrepancy is observed. During parking, the Captain should select the Thrust Reverser switch position if a discrepancy is observed. The Brake Temperature Monitor annunciation that differs from the expected state requires the Captain to select the condition before the next phase of flight. During landing, both pilots should announce the Hydraulic System A selector position when operating at a sample station without ground power.

Condition	Sample value	Remarks
Center Tank Pumps status message	47 units	Monitor
Oxygen Distribution selector position	1 units	Advisory only
Window Heat indication	33 units	Monitor

This text is fictional and exists only to give the prototype realistic volume and structure. During an extended ground delay, the relief pilot should monitor the Traffic Advisory Display advisory if a discrepancy is observed. The Pack Temperature Control quantity display is expected to read within the sample range of 65 to 69 units during approach. The Standby Instruments selector position is expected to read within the sample range of 7 to 14 units during a maintenance-requested ground run. During preflight, the pilot monitoring should cross-check the Wing Anti-Ice advisory when the associated caution light remains illuminated. See 02.10.1 Crew Responsibilities Policy 1.

09.30 Arrival: Part C

09.30.1 Arrival Policy 1

The Autothrottle annunciation that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. During cruise, the pilot flying should monitor the Window Heat status message when conditions permit. The Autopilot Channel B switch position that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center. The Fire Detection Loop selector position that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete. The Pack Temperature Control selector position that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power.

The Speedbrake Handle status message that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Oxygen Distribution quantity display is expected to read within the sample range of 3 to 14 units during parking.

Refer to the related topic for additional sample context. The relief pilot will record any change in the Hydraulic System B selector position and advise the other pilot when operating at a sample station without ground power. During a

diversion, the pilot monitoring should select the Cockpit Voice Recorder switch position before the next phase of flight. If the Landing Gear Indication is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The first officer will monitor any change in the Stall Warning quantity display and advise the other pilot if a discrepancy is observed.

NOTE: The Nosewheel Steering quantity display is expected to read within the sample range of 68 to 71 units during approach. The Autobrake Selector quantity display is expected to read within the sample range of 18 to 24 units during descent.

The Center Tank Pumps annunciation is expected to read within the sample range of 72 to 79 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A switch position is expected to read within the sample range of 85 to 92 units during engine start. The first officer will record any change in the Transponder advisory and advise the other pilot if the indication does not stabilize within the sample interval.

09.30.2 Arrival Policy 2

If the Autothrottle is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The pilot flying will announce any change in the Weather Radar switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will monitor any change in the Nosewheel Steering switch position and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The Cargo Smoke Detection status message is expected to read within the sample range of 27 to 39 units during engine start. During a diversion, both pilots should brief the Cockpit Voice Recorder annunciation if the indication does not stabilize within the sample interval.

This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System A annunciation is expected to read within the sample range of 54 to 59 units during parking. During preflight, the pilot flying should brief the Primary Electrical Bus selector position when conditions permit. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will announce any change in the Flap Position Indication annunciation and advise the other pilot before the next phase of flight.

The captain will record any change in the Autothrottle selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. The Cabin Pressure Controller quantity display that differs from the expected state requires the pilot flying to announce the condition once the checklist item is complete. The Autothrottle indication that differs from the expected state requires both pilots to record the condition unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. During climb, the pilot monitoring should announce the Bleed Air Supply selector position if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. The Center Tank Pumps selector position is expected to read within the sample range of 77 to 84 units during a diversion. The Nosewheel Steering quantity display that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated. The Landing Gear Indication indication that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete. During parking, the pilot flying should select the Weather Radar indication when conditions permit.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. If the Landing Gear Indication is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

The pilot flying will verify any change in the Standby Hydraulic indication and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will cross-check any change in the Center Tank Pumps annunciation and advise the other pilot when the associated caution light remains illuminated. The relief pilot will

select any change in the Oxygen Distribution annunciation and advise the other pilot once the checklist item is complete. The Stall Warning indication that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed.

The pilot monitoring will select any change in the Bleed Air Supply selector position and advise the other pilot before the next phase of flight. The Center Tank Pumps quantity display that differs from the expected state requires the Captain to brief the condition once the checklist item is complete. During an extended ground delay, the relief pilot should record the Standby Instruments status message unless directed otherwise by the Sample Operations Center. During cruise, both pilots should confirm the Hydraulic System B switch position when conditions permit.

CAUTION: The Autobrake Selector advisory that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. The Hydraulic System A annunciation that differs from the expected state requires the Captain to record the condition if a discrepancy is observed.

09.30.3 Arrival Policy 3

During parking, the pilot flying should announce the Autothrottle switch position when operating at a sample station without ground power. During descent, both pilots should cross-check the Thrust Reverser indication once the checklist item is complete. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Cockpit Voice Recorder indication	6 units	Monitor
Nosewheel Steering selector position	76 units	Normal
Cargo Smoke Detection switch position	92 units	Normal
Thrust Reverser status message	62 units	Advisory only

The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, the pilot monitoring should brief the Traffic Advisory Display annunciation if a discrepancy is observed. The first officer will cross-check any change in the Hydraulic System A advisory and advise the other pilot before the next phase of flight.

The first officer will verify any change in the Nosewheel Steering switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Flight Management Computer selector position that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval. During engine start, the relief pilot should confirm the Bleed Air Supply selector position when operating at a sample station without ground power. The Landing Gear Indication selector position is expected to read within the sample range of 75 to 79 units during engine start.

- If the Oxygen Distribution is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.
- The Transponder switch position is expected to read within the sample range of 36 to 48 units during a turnaround.
- During a turnaround, the pilot monitoring should brief the Flight Management Computer switch position before the next phase of flight.
- If the Probe Heat is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.
- The captain will verify any change in the Standby Hydraulic indication and advise the other pilot if the indication does not stabilize within the sample interval.

The Standby Instruments switch position is expected to read within the sample range of 40 to 50 units during climb. If the Oxygen Distribution is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. The Flight Management Computer advisory is expected to read within the sample range of 81 to 91 units during an extended ground delay. If the Primary Electrical Bus is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Engine Anti-Ice selector position is expected to read within the

sample range of 27 to 32 units during a turnaround. See 12.20.8 Fuel Policy Policy 8.

- During parking, the pilot flying should announce the Wing Anti-Ice switch position when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Traffic Advisory Display status message that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated.
- The Bleed Air Supply status message is expected to read within the sample range of 4 to 11 units during a diversion.
- During cruise, the relief pilot should monitor the Oxygen Distribution annunciation before the next phase of flight.
- During cruise, the pilot flying should select the Cargo Smoke Detection quantity display unless directed otherwise by the Sample Operations Center.

NOTE: The relief pilot will verify any change in the Autopilot Channel B switch position and advise the other pilot before the next phase of flight. If the Speedbrake Handle is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

09.30.4 Arrival Policy 4

The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, the pilot flying should select the Speedbrake Handle annunciation if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. If the Bleed Air Supply is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution status message is expected to read within the sample range of 44 to 55 units during cruise.

If the Weather Radar is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. During preflight, the pilot monitoring should cross-check the Cockpit Voice Recorder annunciation when conditions permit. During parking, the Captain should verify the Stall Warning indication when operating at a sample station without ground power.

The Speedbrake Handle switch position is expected to read within the sample range of 80 to 89 units during an extended ground delay. The Hydraulic System A selector position that differs from the expected state requires the relief pilot to record the condition once the checklist item is complete. If the Bleed Air Supply is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance. See 15.10.3 Reports and Records Policy 3.

- The pilot monitoring will verify any change in the Oxygen Distribution status message and advise the other pilot when operating at a sample station without ground power.
- If the Auxiliary Power Unit is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- The Cabin Pressure Controller indication is expected to read within the sample range of 11 to 20 units during engine start.

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	34 units	Advisory only
Autobrake Selector annunciation	33 units	Refer to related topic
Nosewheel Steering annunciation	54 units	Normal

- If the Wing Anti-Ice is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.
- If the Pack Temperature Control is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The pilot flying will verify any change in the Autopilot Channel B status message and advise the other pilot once the checklist item is complete.

09.30.5 Arrival Policy 5

If the Flight Management Computer is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Stall Warning status message and advise the other pilot once the checklist item is complete. The Brake Temperature Monitor selector position that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power. During an extended ground delay, the relief pilot should select the Cockpit Voice Recorder indication if a discrepancy is observed.

Refer to the related topic for additional sample context. The first officer will select any change in the Autothrottle selector position and advise the other pilot once the checklist item is complete. The Autopilot Channel A status message is expected to read within the sample range of 4 to 10 units during an extended ground delay. The pilot flying will select any change in the Pack Temperature Control indication and advise the other pilot when conditions permit. The pilot monitoring will select any change in the Autopilot Channel B status message and advise the other pilot if the indication does not stabilize within the sample interval. During descent, both pilots should record the Window Heat quantity display when operating at a sample station without ground power.

The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice switch position that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval. If the Probe Heat is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Auxiliary Power Unit indication that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center.

The relief pilot will select any change in the Center Tank Pumps switch position and advise the other pilot when the associated caution light remains illuminated. If the Thrust Reverser is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will select any change in the Pack Temperature Control quantity display and advise the other pilot once the checklist item is complete. During approach, the pilot monitoring should cross-check the Ground Proximity Monitor advisory if the indication does not stabilize within the sample interval.

CAUTION: During preflight, the Captain should select the Center Tank Pumps indication once the checklist item is complete. During preflight, the Captain should announce the Thrust Reverser annunciation before the next phase of flight.

If the Weather Radar is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. During an extended ground delay, the pilot monitoring should verify the Cabin Pressure Controller annunciation if the indication does not stabilize within the sample interval. The Standby Instruments quantity display is expected to read within the sample range of 11 to 23 units during preflight. The Fuel Crossfeed selector position is expected to read within the sample range of 57 to 64 units during takeoff.

Refer to the related topic for additional sample context. If the Stall Warning is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Flap Position Indication selector position that differs from the expected state requires the Captain to cross-check the condition unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The Traffic Advisory Display annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit. The first officer will brief any change in the Traffic Advisory Display

switch position and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Brake Temperature Monitor quantity display	38 units	Monitor
Oxygen Distribution quantity display	71 units	Normal
Stall Warning indication	42 units	Monitor
Standby Hydraulic switch position	38 units	Advisory only
Traffic Advisory Display advisory	12 units	Advisory only
Standby Hydraulic status message	12 units	Advisory only
Weather Radar selector position	21 units	Normal

09.30.6 Arrival Policy 6

The Weather Radar annunciation that differs from the expected state requires the pilot flying to verify the condition when the associated caution light remains illuminated. The relief pilot will select any change in the Center Tank Pumps annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Speedbrake Handle switch position that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated. If the Transponder is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. During cruise, the pilot flying should cross-check the Stall Warning annunciation if a discrepancy is observed. The Hydraulic System A switch position that differs from the expected state requires the relief pilot to select the condition when the associated caution light remains illuminated.

CAUTION: The Fuel Crossfeed indication is expected to read within the sample range of 11 to 16 units during a maintenance-requested ground run.

If the Wing Anti-Ice is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Cargo Smoke Detection quantity display that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval. If the Standby Hydraulic is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

If the Stall Warning is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During an extended ground delay, the relief pilot should confirm the Oxygen Distribution annunciation when the associated caution light remains illuminated. During an extended ground delay, the First Officer should announce the Oxygen Distribution status message unless directed otherwise by the Sample Operations Center.

NOTE: The pilot monitoring will verify any change in the Landing Gear Indication quantity display and advise the other pilot if a discrepancy is observed. The pilot flying will select any change in the Transponder quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

09.30.7 Arrival Policy 7

The Traffic Advisory Display annunciation is expected to read within the sample range of 22 to 28 units during a diversion. The pilot monitoring will monitor any change in the Wing Anti-Ice indication and advise the other pilot if a discrepancy is observed. The captain will verify any change in the Ground Proximity Monitor selector position and advise the other pilot when operating at a sample station without ground power. During preflight, the First Officer should select the Traffic Advisory Display selector position unless directed otherwise by the Sample Operations Center.

The Engine Anti-Ice selector position is expected to read within the sample range of 92 to 102 units during descent. Both pilots will record any change in the Hydraulic System B status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus selector position is expected to read within the sample range of 50 to 58 units during a turnaround.

Condition	Sample value	Remarks
Weather Radar switch position	95 units	Normal
Stall Warning selector position	11 units	Monitor
Traffic Advisory Display annunciation	78 units	Monitor
Nosewheel Steering advisory	40 units	Advisory only
Oxygen Distribution quantity display	22 units	Normal
Probe Heat quantity display	15 units	Refer to related topic
Engine Anti-Ice status message	53 units	Monitor

- During a turnaround, the pilot monitoring should announce the Flight Management Computer indication if the indication does not stabilize within the sample interval.
- If the Primary Electrical Bus is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- The Hydraulic System A quantity display is expected to read within the sample range of 90 to 97 units during landing.

NOTE: If the Ground Proximity Monitor is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

09.30.8 Arrival Policy 8

If the Autothrottle is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance. The relief pilot will record any change in the Brake Temperature Monitor indication and advise the other pilot if a discrepancy is observed. The Autobrake Selector switch position that differs from the expected state requires the Captain to select the condition before the next phase of flight. The captain will verify any change in the Brake Temperature Monitor advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Cargo Smoke Detection status message	48 units	Monitor
Autothrottle advisory	94 units	Refer to related topic
Nosewheel Steering status message	90 units	Normal

Both pilots will select any change in the Standby Instruments indication and advise the other pilot when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Engine Anti-Ice annunciation is expected to read within the sample range of 63 to 71 units during climb. The Standby Instruments indication is expected to read within the sample range of 90 to 95 units during a turnaround.

This text is fictional and exists only to give the prototype realistic volume and structure. During engine start, the First Officer should announce the Autobrake Selector quantity display if the indication does not stabilize within the sample interval. The Ground Proximity Monitor advisory that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed. If the Autopilot Channel A is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: If the Primary Electrical Bus is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Cockpit Voice Recorder status message	98 units	Normal

Fuel Crossfeed advisory	96 units	Normal
Hydraulic System A selector position	44 units	Refer to related topic
Speedbrake Handle quantity display	51 units	Refer to related topic
Brake Temperature Monitor switch position	7 units	Normal
Autopilot Channel A indication	36 units	Normal
Brake Temperature Monitor annunciation	6 units	Normal

During an extended ground delay, the pilot monitoring should announce the Fuel Crossfeed switch position once the checklist item is complete. Refer to the related topic for additional sample context. The pilot monitoring will record any change in the Primary Electrical Bus selector position and advise the other pilot if a discrepancy is observed. The Landing Gear Indication status message is expected to read within the sample range of 61 to 64 units during descent.

Chapter 10 Adverse Weather Policy

10.10 Adverse Weather Policy: Part A

10.10.1 Adverse Weather Policy Policy 1

The Hydraulic System A selector position that differs from the expected state requires the relief pilot to announce the condition if a discrepancy is observed. The first officer will brief any change in the Autobrake Selector status message and advise the other pilot if a discrepancy is observed. During a maintenance-requested ground run, the pilot flying should monitor the Fuel Crossfeed indication before the next phase of flight. The captain will verify any change in the Stall Warning indication and advise the other pilot if a discrepancy is observed.

CAUTION: The Primary Electrical Bus annunciation is expected to read within the sample range of 90 to 102 units during a diversion. Values in this manual are invented and must not be used for any operational purpose.

During descent, the Captain should cross-check the Engine Anti-Ice switch position unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. During engine start, both pilots should select the Fire Detection Loop advisory when conditions permit. The Window Heat switch position that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power. During landing, the Captain should verify the Hydraulic System B status message once the checklist item is complete. The Autobrake Selector indication is expected to read within the sample range of 4 to 11 units during climb.

CAUTION: If the Flap Position Indication is inoperative, continue landing only after the Captain has reviewed the associated sample guidance.

The Transponder indication that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. Refer to the related topic for additional sample context. The Autopilot Channel B annunciation that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated. See 02.10.6 Crew Responsibilities Policy 6.

10.10.2 Adverse Weather Policy Policy 2

During a diversion, the First Officer should monitor the Autopilot Channel B advisory when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During landing, both pilots should record the Window Heat quantity display when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Speedbrake Handle advisory is expected to read within the sample range of 16 to 28 units during a maintenance-requested ground run.
- The Probe Heat selector position that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed.
- The Autopilot Channel A status message that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.

Both pilots will record any change in the Speedbrake Handle switch position and advise the other pilot once the checklist item is complete. During cruise, the pilot flying should monitor the Autothrottle quantity display once the checklist item is complete. The Standby Instruments selector position that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. During an extended ground delay, the Captain should announce the Autothrottle selector position if a discrepancy is observed.

Condition	Sample value	Remarks
Engine Anti-Ice selector position	26 units	Advisory only
Autopilot Channel B status message	65 units	Advisory only

Speedbrake Handle indication	93 units	Monitor
------------------------------	----------	---------

During an extended ground delay, the pilot flying should announce the Window Heat switch position if the indication does not stabilize within the sample interval. The Pack Temperature Control annunciation is expected to read within the sample range of 94 to 105 units during a diversion. Refer to the related topic for additional sample context. During parking, the pilot monitoring should confirm the Wing Anti-Ice selector position unless directed otherwise by the Sample Operations Center. During takeoff, the relief pilot should monitor the Autobrake Selector indication unless directed otherwise by the Sample Operations Center.

10.10.3 Adverse Weather Policy Policy 3

Refer to the related topic for additional sample context. The pilot monitoring will select any change in the Speedbrake Handle advisory and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will brief any change in the Hydraulic System B advisory and advise the other pilot if the indication does not stabilize within the sample interval. If the Stall Warning is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During approach, the pilot monitoring should brief the Flight Management Computer quantity display before the next phase of flight. If the Wing Anti-Ice is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

CAUTION: The Flap Position Indication switch position that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete.

The Fuel Crossfeed selector position that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval. The pilot monitoring will select any change in the Engine Anti-Ice quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. During takeoff, both pilots should brief the Autopilot Channel A status message when the associated caution light remains illuminated. The captain will monitor any change in the Engine Anti-Ice status message and advise the other pilot when the associated caution light remains illuminated. The Nosewheel Steering quantity display that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. The Stall Warning annunciation is expected to read within the sample range of 67 to 72 units during landing.

NOTE: The Brake Temperature Monitor indication is expected to read within the sample range of 25 to 37 units during a turnaround.

CAUTION: The Auxiliary Power Unit advisory that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. The first officer will select any change in the Standby Hydraulic quantity display and advise the other pilot if a discrepancy is observed.

The captain will announce any change in the Brake Temperature Monitor annunciation and advise the other pilot when the associated caution light remains illuminated. The Fuel Crossfeed switch position is expected to read within the sample range of 44 to 56 units during an extended ground delay. Refer to the related topic for additional sample context.

NOTE: The pilot flying will cross-check any change in the Window Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Flap Position Indication selector position is expected to read within the sample range of 59 to 63 units during taxi.

Condition	Sample value	Remarks
Bleed Air Supply indication	87 units	Refer to related topic
Weather Radar quantity display	35 units	Monitor
Cabin Pressure Controller status message	54 units	Refer to related topic
Weather Radar quantity display	79 units	Refer to related topic
Fire Detection Loop annunciation	62 units	Monitor
Flight Management Computer status message	75 units	Refer to related topic

Both pilots will record any change in the Weather Radar annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. During taxi, the First Officer should brief the Brake Temperature Monitor annunciation when operating at a sample station without ground power. During a turnaround, the relief pilot should cross-check the Fire Detection Loop status message when operating at a sample station without ground power. The Weather Radar selector position is expected to read within the sample range of 8 to 16 units during a maintenance-requested ground run.

10.10.4 Adverse Weather Policy Policy 4

The relief pilot will select any change in the Primary Electrical Bus indication and advise the other pilot if the indication does not stabilize within the sample interval. During climb, the pilot flying should record the Window Heat switch position unless directed otherwise by the Sample Operations Center. The Autopilot Channel A quantity display that differs from the expected state requires the pilot monitoring to brief the condition before the next phase of flight. The Primary Electrical Bus selector position that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval.

If the Hydraulic System B is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Window Heat indication is expected to read within the sample range of 7 to 16 units during descent. The Autothrottle indication is expected to read within the sample range of 39 to 42 units during approach.

CAUTION: The Standby Hydraulic quantity display that differs from the expected state requires the pilot flying to record the condition when conditions permit.

NOTE: The Flight Management Computer annunciation that differs from the expected state requires the relief pilot to brief the condition when the associated caution light remains illuminated. The Brake Temperature Monitor quantity display that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete.

The Fire Detection Loop switch position that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. If the Brake Temperature Monitor is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Cargo Smoke Detection switch position that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight. The pilot flying will announce any change in the Brake Temperature Monitor advisory and advise the other pilot before the next phase of flight.

- During taxi, the Captain should monitor the Primary Electrical Bus indication before the next phase of flight.
- The Hydraulic System A status message is expected to read within the sample range of 13 to 25 units during climb.
- Both pilots will brief any change in the Window Heat quantity display and advise the other pilot before the next phase of flight.
- The Center Tank Pumps indication is expected to read within the sample range of 17 to 20 units during approach.
- During takeoff, the relief pilot should select the Oxygen Distribution selector position when conditions permit.

NOTE: During engine start, the pilot monitoring should select the Flap Position Indication advisory if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

The Window Heat selector position that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. The Flight Management Computer selector position is expected to read within the sample range of 56 to 63 units during parking. During parking, the Captain should verify the Landing Gear Indication advisory if a discrepancy is observed. If the Autopilot Channel B is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. See 14.20.2 Irregular Operations Policy 2.

10.10.5 Adverse Weather Policy Policy 5

The Window Heat switch position that differs from the expected state requires both pilots to announce the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. If the Thrust Reverser is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

The Autothrottle status message is expected to read within the sample range of 56 to 68 units during a turnaround. The Primary Electrical Bus switch position that differs from the expected state requires the Captain to select the condition once the checklist item is complete. The Primary Electrical Bus switch position that differs from the expected state requires the relief pilot to record the condition when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The Weather Radar switch position is expected to read within the sample range of 43 to 54 units during takeoff.

If the Hydraulic System A is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. Both pilots will select any change in the Oxygen Distribution switch position and advise the other pilot when operating at a sample station without ground power. If the Ground Proximity Monitor is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. If the Window Heat is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: During a diversion, the Captain should monitor the Ground Proximity Monitor advisory if the indication does not stabilize within the sample interval. Both pilots will record any change in the Landing Gear Indication quantity display and advise the other pilot once the checklist item is complete.

CAUTION: If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Primary Electrical Bus switch position is expected to read within the sample range of 62 to 69 units during climb.

Condition	Sample value	Remarks
Center Tank Pumps selector position	19 units	Advisory only
Autobrake Selector status message	19 units	Advisory only
Standby Instruments status message	1 units	Advisory only
Flap Position Indication quantity display	37 units	Monitor
Traffic Advisory Display annunciation	15 units	Normal
Fire Detection Loop selector position	13 units	Advisory only

The Weather Radar quantity display that differs from the expected state requires both pilots to record the condition before the next phase of flight. If the Fire Detection Loop is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Bleed Air Supply switch position is expected to read within the sample range of 43 to 49 units during descent. The Autothrottle selector position that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed.

During approach, the pilot flying should confirm the Landing Gear Indication quantity display before the next phase of flight. The Fuel Crossfeed switch position that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. If the Cabin Pressure Controller is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. During approach, both pilots should confirm the Wing Anti-Ice quantity display if the indication does not stabilize within the sample interval.

10.10.6 Adverse Weather Policy Policy 6

The captain will select any change in the Auxiliary Power Unit quantity display and advise the other pilot before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will cross-check any change in the Stall Warning advisory and advise the other pilot before the next phase of flight. If the Flap Position Indication is inoperative, continue a diversion only after both pilots has reviewed the

associated sample guidance.

- If the Center Tank Pumps is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance.
- The Pack Temperature Control selector position is expected to read within the sample range of 41 to 53 units during taxi.
- The captain will announce any change in the Standby Hydraulic advisory and advise the other pilot when conditions permit.

If the Oxygen Distribution is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Fire Detection Loop quantity display and advise the other pilot when conditions permit. Both pilots will cross-check any change in the Cockpit Voice Recorder selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Landing Gear Indication is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The captain will cross-check any change in the Ground Proximity Monitor switch position and advise the other pilot once the checklist item is complete. The Speedbrake Handle advisory that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. During parking, the Captain should announce the Weather Radar status message once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure.

- Both pilots will record any change in the Cargo Smoke Detection advisory and advise the other pilot if the indication does not stabilize within the sample interval.
- During a maintenance-requested ground run, the relief pilot should monitor the Flight Management Computer status message once the checklist item is complete.
- The Window Heat advisory that differs from the expected state requires the Captain to confirm the condition if the indication does not stabilize within the sample interval.
- During engine start, the pilot flying should cross-check the Probe Heat switch position if a discrepancy is observed.
- The Traffic Advisory Display status message that differs from the expected state requires the relief pilot to monitor the condition before the next phase of flight.
- The captain will brief any change in the Engine Anti-Ice annunciation and advise the other pilot if a discrepancy is observed.
- During an extended ground delay, the pilot monitoring should verify the Standby Instruments advisory when conditions permit.
- This text is fictional and exists only to give the prototype realistic volume and structure.

10.10.7 Adverse Weather Policy Policy 7

If the Autopilot Channel A is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. During taxi, the pilot monitoring should record the Hydraulic System A quantity display when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Brake Temperature Monitor annunciation	3 units	Monitor
Pack Temperature Control indication	28 units	Advisory only
Standby Instruments selector position	12 units	Normal
Hydraulic System A advisory	83 units	Advisory only

Pack Temperature Control status message	87 units	Normal
Window Heat indication	96 units	Refer to related topic
Flight Management Computer annunciation	68 units	Refer to related topic

CAUTION: The Wing Anti-Ice status message that differs from the expected state requires the pilot flying to monitor the condition unless directed otherwise by the Sample Operations Center.

The pilot flying will announce any change in the Standby Hydraulic switch position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context. During landing, the pilot monitoring should verify the Autopilot Channel A selector position when conditions permit. The first officer will verify any change in the Speedbrake Handle selector position and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Cabin Pressure Controller advisory	88 units	Refer to related topic
Bleed Air Supply annunciation	34 units	Advisory only
Autobrake Selector selector position	25 units	Monitor
Cockpit Voice Recorder selector position	16 units	Monitor
Cockpit Voice Recorder switch position	26 units	Monitor
Bleed Air Supply selector position	42 units	Monitor
Ground Proximity Monitor quantity display	97 units	Normal

10.10.8 Adverse Weather Policy Policy 8

If the Primary Electrical Bus is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The pilot flying will monitor any change in the Center Tank Pumps selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During takeoff, the First Officer should announce the Transponder selector position unless directed otherwise by the Sample Operations Center.

The wording here is placeholder content shaped like a procedure, not a procedure. The Traffic Advisory Display selector position is expected to read within the sample range of 34 to 43 units during a maintenance-requested ground run. The pilot monitoring will brief any change in the Pack Temperature Control annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Hydraulic System B advisory is expected to read within the sample range of 90 to 98 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Window Heat annunciation	3 units	Refer to related topic
Traffic Advisory Display selector position	6 units	Monitor
Traffic Advisory Display switch position	29 units	Monitor
Autopilot Channel B annunciation	64 units	Advisory only
Landing Gear Indication status message	16 units	Refer to related topic

If the Traffic Advisory Display is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Flight Management Computer indication is expected to read within the sample range of 10 to 21 units during approach. If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. If the Hydraulic System A is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Fire Detection Loop switch position is expected to read within the sample range of 40 to 46 units during a maintenance-requested ground run. The pilot flying will confirm any change in the Fire Detection Loop advisory and advise the other pilot once the checklist item is complete.

CAUTION: The Auxiliary Power Unit quantity display is expected to read within the sample range of 38 to 44 units during an extended ground delay. Refer to the related topic for additional sample context.

NOTE: The pilot monitoring will monitor any change in the Flight Management Computer indication and advise the other pilot if a discrepancy is observed. The Cockpit Voice Recorder status message that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete.

10.20 Adverse Weather Policy: Part B

10.20.1 Adverse Weather Policy Policy 1

If the Standby Instruments is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. During taxi, the Captain should select the Cargo Smoke Detection annunciation if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

If the Autopilot Channel A is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Cargo Smoke Detection switch position and advise the other pilot when the associated caution light remains illuminated. The Wing Anti-Ice status message is expected to read within the sample range of 23 to 28 units during climb.

If the Hydraulic System B is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. During a diversion, the pilot monitoring should brief the Landing Gear Indication advisory if a discrepancy is observed. During a turnaround, both pilots should announce the Window Heat quantity display when operating at a sample station without ground power. If the Nosewheel Steering is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

CAUTION: The Nosewheel Steering advisory that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. The Standby Hydraulic quantity display is expected to read within the sample range of 92 to 96 units during engine start.

The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will verify any change in the Primary Electrical Bus status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Engine Anti-Ice switch position is expected to read within the sample range of 12 to 24 units during climb. The pilot flying will monitor any change in the Cargo Smoke Detection status message and advise the other pilot when the associated caution light remains illuminated.

NOTE: The Wing Anti-Ice switch position is expected to read within the sample range of 43 to 51 units during approach.

CAUTION: During a turnaround, the pilot flying should monitor the Landing Gear Indication advisory unless directed otherwise by the Sample Operations Center.

During a maintenance-requested ground run, the pilot monitoring should cross-check the Cockpit Voice Recorder status message if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. During a maintenance-requested ground run, the pilot monitoring should cross-check the Brake Temperature Monitor advisory when operating at a sample station without ground power. The first officer will cross-check any change in the Auxiliary Power Unit quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During a maintenance-requested ground run, the Captain should brief the Autobrake Selector advisory if the indication does not stabilize within the sample interval.

If the Landing Gear Indication is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The Center Tank Pumps selector position that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. The Primary Electrical Bus selector position is expected to read within the sample range of 58 to 69 units during a turnaround. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

10.20.2 Adverse Weather Policy Policy 2

The relief pilot will confirm any change in the Wing Anti-Ice annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. During climb, both pilots should brief the Flight Management Computer status message when operating at a sample station without ground power. If the Oxygen Distribution is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure.

- Values in this manual are invented and must not be used for any operational purpose.
- During an extended ground delay, the pilot monitoring should announce the Brake Temperature Monitor status message before the next phase of flight.
- The pilot monitoring will confirm any change in the Flight Management Computer switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: During parking, the relief pilot should select the Center Tank Pumps status message if the indication does not stabilize within the sample interval.

CAUTION: The captain will record any change in the Wing Anti-Ice annunciation and advise the other pilot before the next phase of flight.

The Autopilot Channel B advisory that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. The relief pilot will verify any change in the Brake Temperature Monitor indication and advise the other pilot once the checklist item is complete. The Transponder advisory that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated.

10.20.3 Adverse Weather Policy Policy 3

During a diversion, the relief pilot should confirm the Flight Management Computer switch position once the checklist item is complete. If the Flight Management Computer is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. The Window Heat quantity display that differs from the expected state requires the First Officer to record the condition when the associated caution light remains illuminated. The pilot monitoring will confirm any change in the Autobrake Selector quantity display and advise the other pilot when operating at a sample station without ground power. The Probe Heat selector position is expected to read within the sample range of 53 to 60 units during landing.

Condition	Sample value	Remarks
Transponder annunciation	19 units	Normal
Autopilot Channel B status message	78 units	Advisory only
Speedbrake Handle status message	37 units	Normal
Window Heat status message	11 units	Monitor
Wing Anti-Ice annunciation	64 units	Monitor
Autopilot Channel A indication	75 units	Refer to related topic

NOTE: Both pilots will cross-check any change in the Hydraulic System B advisory and advise the other pilot when the associated caution light remains illuminated.

CAUTION: During cruise, both pilots should verify the Speedbrake Handle advisory when operating at a sample station without ground power.

10.20.4 Adverse Weather Policy Policy 4

Refer to the related topic for additional sample context. During approach, both pilots should monitor the Standby Hydraulic annunciation before the next phase of flight. The pilot monitoring will select any change in the Autobrake Selector advisory and advise the other pilot when conditions permit. The Traffic Advisory Display selector position that differs from the expected state requires the pilot monitoring to record the condition before the next phase of flight. During cruise, the pilot flying should brief the Primary Electrical Bus quantity display when the associated caution light remains illuminated.

NOTE: Both pilots will select any change in the Center Tank Pumps annunciation and advise the other pilot when operating at a sample station without ground power. The relief pilot will announce any change in the Traffic Advisory Display status message and advise the other pilot if the indication does not stabilize within the sample interval.

- During parking, the Captain should monitor the Cargo Smoke Detection quantity display before the next phase of flight.
- The Transponder advisory that differs from the expected state requires the pilot flying to record the condition before the next phase of flight.
- The Center Tank Pumps selector position is expected to read within the sample range of 6 to 16 units during takeoff.

CAUTION: The Flight Management Computer status message is expected to read within the sample range of 53 to 62 units during preflight. Values in this manual are invented and must not be used for any operational purpose.

- During a diversion, the First Officer should verify the Hydraulic System B selector position if a discrepancy is observed.
- The relief pilot will select any change in the Autobrake Selector indication and advise the other pilot when the associated caution light remains illuminated.
- The Standby Hydraulic selector position that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval.
- The pilot monitoring will monitor any change in the Transponder advisory and advise the other pilot once the checklist item is complete.

During cruise, the First Officer should announce the Auxiliary Power Unit selector position if the indication does not stabilize within the sample interval. The Bleed Air Supply switch position that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. The captain will record any change in the Flight Management Computer indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will record any change in the Cockpit Voice Recorder quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will record any change in the Cargo Smoke Detection quantity display and advise the other pilot when operating at a sample station without ground power.

NOTE: During a diversion, the First Officer should confirm the Thrust Reverser quantity display if a discrepancy is observed.

10.20.5 Adverse Weather Policy Policy 5

During a diversion, the First Officer should confirm the Oxygen Distribution annunciation once the checklist item is complete. The Pack Temperature Control indication that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed. The Thrust Reverser selector position is expected to read

within the sample range of 86 to 90 units during takeoff. Refer to the related topic for additional sample context. The pilot flying will cross-check any change in the Hydraulic System B switch position and advise the other pilot when conditions permit. During preflight, the pilot monitoring should verify the Brake Temperature Monitor annunciation when the associated caution light remains illuminated.

If the Standby Hydraulic is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The pilot flying will cross-check any change in the Ground Proximity Monitor quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Fuel Crossfeed status message	46 units	Monitor
Center Tank Pumps status message	3 units	Monitor
Hydraulic System B quantity display	51 units	Advisory only
Cockpit Voice Recorder quantity display	45 units	Advisory only

This text is fictional and exists only to give the prototype realistic volume and structure. The Cargo Smoke Detection selector position is expected to read within the sample range of 31 to 35 units during landing. The Bleed Air Supply annunciation that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. If the Oxygen Distribution is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

The captain will brief any change in the Probe Heat annunciation and advise the other pilot once the checklist item is complete. If the Standby Instruments is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During climb, the relief pilot should cross-check the Landing Gear Indication quantity display when the associated caution light remains illuminated. The pilot flying will confirm any change in the Fire Detection Loop annunciation and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

Both pilots will record any change in the Flap Position Indication switch position and advise the other pilot when the associated caution light remains illuminated. During an extended ground delay, the pilot flying should select the Autobrake Selector selector position if a discrepancy is observed. If the Fuel Crossfeed is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Probe Heat is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

The pilot flying will confirm any change in the Fuel Crossfeed status message and advise the other pilot before the next phase of flight. The Brake Temperature Monitor annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power. The Pack Temperature Control annunciation is expected to read within the sample range of 79 to 82 units during engine start.

- NOTE:** If the Engine Anti-Ice is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context.
- NOTE:** The Engine Anti-Ice advisory is expected to read within the sample range of 14 to 20 units during climb.

10.20.6 Adverse Weather Policy Policy 6

Values in this manual are invented and must not be used for any operational purpose. Both pilots will announce any change in the Primary Electrical Bus status message and advise the other pilot once the checklist item is complete. The pilot monitoring will cross-check any change in the Fire Detection Loop indication and advise the other pilot if the indication does not stabilize within the sample interval. The Flight Management Computer switch position that differs from the expected state requires the Captain to announce the condition if the indication does not stabilize within the sample interval. The pilot monitoring will announce any change in the Bleed Air Supply selector position and advise

the other pilot once the checklist item is complete. Refer to the related topic for additional sample context.

If the Standby Hydraulic is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will verify any change in the Center Tank Pumps indication and advise the other pilot if the indication does not stabilize within the sample interval. If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The relief pilot will brief any change in the Auxiliary Power Unit selector position and advise the other pilot when conditions permit. If the Weather Radar is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. See 11.30.5 Communications Policy 5.

CAUTION: The Cabin Pressure Controller status message that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center.

NOTE: The first officer will record any change in the Fuel Crossfeed quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autothrottle advisory that differs from the expected state requires the pilot flying to select the condition when conditions permit.

NOTE: If the Thrust Reverser is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Traffic Advisory Display indication	90 units	Normal
Flight Management Computer advisory	85 units	Advisory only
Auxiliary Power Unit annunciation	17 units	Monitor
Autopilot Channel B annunciation	68 units	Refer to related topic
Stall Warning status message	26 units	Normal
Autobrake Selector annunciation	72 units	Monitor
Fuel Crossfeed status message	4 units	Monitor

10.20.7 Adverse Weather Policy Policy 7

The Fuel Crossfeed advisory is expected to read within the sample range of 36 to 41 units during an extended ground delay. If the Fire Detection Loop is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Landing Gear Indication quantity display that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power.

NOTE: During approach, the pilot monitoring should cross-check the Nosewheel Steering annunciation unless directed otherwise by the Sample Operations Center. The Nosewheel Steering status message that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight.

The first officer will verify any change in the Standby Hydraulic switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will monitor any change in the Thrust Reverser annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Stall Warning advisory that differs from the expected state requires the pilot monitoring to verify the condition once the checklist item is complete. The Hydraulic System A advisory is expected to read within the sample range of 69 to 74 units during a maintenance-requested ground run. During cruise, both pilots should select the Wing Anti-Ice quantity display once the checklist item is complete. The Autopilot Channel A switch position that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated.

During a maintenance-requested ground run, the Captain should select the Weather Radar advisory if a discrepancy is observed. If the Oxygen Distribution is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. If the Window Heat is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The pilot monitoring will confirm any change in the Cockpit Voice Recorder advisory and advise the other pilot once the checklist item is complete. This text is fictional

and exists only to give the prototype realistic volume and structure. If the Autobrake Selector is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

The Engine Anti-Ice status message that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. During climb, the Captain should select the Autopilot Channel B quantity display when operating at a sample station without ground power. Both pilots will record any change in the Engine Anti-Ice advisory and advise the other pilot if the indication does not stabilize within the sample interval.

10.20.8 Adverse Weather Policy Policy 8

Values in this manual are invented and must not be used for any operational purpose. During parking, both pilots should announce the Traffic Advisory Display status message once the checklist item is complete. The Center Tank Pumps annunciation is expected to read within the sample range of 48 to 60 units during engine start.

Condition	Sample value	Remarks
Fuel Crossfeed switch position	10 units	Advisory only
Thrust Reverser switch position	86 units	Normal
Thrust Reverser selector position	47 units	Monitor
Cabin Pressure Controller advisory	28 units	Monitor

- The pilot flying will select any change in the Nosewheel Steering selector position and advise the other pilot when conditions permit.
- The Wing Anti-Ice annunciation that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.
- The first officer will brief any change in the Nosewheel Steering annunciation and advise the other pilot before the next phase of flight.

The Cabin Pressure Controller quantity display is expected to read within the sample range of 18 to 24 units during takeoff. The Autobrake Selector quantity display is expected to read within the sample range of 81 to 84 units during engine start. If the Standby Instruments is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

NOTE: The captain will confirm any change in the Flap Position Indication advisory and advise the other pilot if the indication does not stabilize within the sample interval.

10.30 Adverse Weather Policy: Part C

10.30.1 Adverse Weather Policy Policy 1

During climb, the relief pilot should select the Standby Hydraulic advisory when operating at a sample station without ground power. The Cabin Pressure Controller status message that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. During taxi, the relief pilot should select the Thrust Reverser status message before the next phase of flight.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System A advisory that differs from the expected state requires both pilots to announce the condition when operating at a sample station without ground power.

NOTE: The Bleed Air Supply quantity display that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed.

The Hydraulic System A switch position that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center. The Auxiliary Power Unit annunciation is

expected to read within the sample range of 52 to 56 units during an extended ground delay. The Standby Hydraulic quantity display that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center. If the Thrust Reverser is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

The Engine Anti-Ice switch position that differs from the expected state requires the First Officer to verify the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. If the Primary Electrical Bus is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The captain will cross-check any change in the Center Tank Pumps indication and advise the other pilot when the associated caution light remains illuminated. During preflight, both pilots should select the Weather Radar annunciation when operating at a sample station without ground power.

Condition	Sample value	Remarks
Nosewheel Steering indication	77 units	Refer to related topic
Wing Anti-Ice switch position	71 units	Advisory only
Speedbrake Handle advisory	61 units	Normal
Wing Anti-Ice status message	55 units	Normal
Brake Temperature Monitor advisory	43 units	Refer to related topic
Center Tank Pumps quantity display	56 units	Refer to related topic
Stall Warning quantity display	19 units	Refer to related topic

- During a diversion, the pilot flying should select the Primary Electrical Bus annunciation unless directed otherwise by the Sample Operations Center.
- The Pack Temperature Control annunciation that differs from the expected state requires both pilots to record the condition once the checklist item is complete.
- The relief pilot will confirm any change in the Cockpit Voice Recorder quantity display and advise the other pilot if a discrepancy is observed.

10.30.2 Adverse Weather Policy Policy 2

The first officer will confirm any change in the Autobrake Selector indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat selector position that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle advisory that differs from the expected state requires both pilots to select the condition when conditions permit. During a maintenance-requested ground run, both pilots should verify the Flap Position Indication indication when the associated caution light remains illuminated. If the Traffic Advisory Display is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The pilot flying will record any change in the Wing Anti-Ice selector position and advise the other pilot if the indication does not stabilize within the sample interval. If the Bleed Air Supply is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

The Autopilot Channel B status message is expected to read within the sample range of 45 to 50 units during approach. If the Cockpit Voice Recorder is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Window Heat is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Stall Warning selector position	75 units	Monitor

Hydraulic System A indication	42 units	Refer to related topic
Wing Anti-Ice quantity display	28 units	Normal

The Center Tank Pumps selector position that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval. During a diversion, the First Officer should monitor the Flight Management Computer status message once the checklist item is complete. If the Speedbrake Handle is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

During descent, the relief pilot should select the Pack Temperature Control advisory when the associated caution light remains illuminated. The Pack Temperature Control selector position that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. During a turnaround, the pilot flying should announce the Center Tank Pumps switch position when operating at a sample station without ground power. During engine start, the Captain should cross-check the Auxiliary Power Unit indication when conditions permit. During an extended ground delay, both pilots should monitor the Oxygen Distribution indication if the indication does not stabilize within the sample interval.

- The first officer will verify any change in the Stall Warning indication and advise the other pilot when the associated caution light remains illuminated.
- If the Standby Hydraulic is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.
- The Cargo Smoke Detection annunciation that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete.

CAUTION: During taxi, the pilot monitoring should confirm the Traffic Advisory Display status message if a discrepancy is observed.

During a turnaround, the relief pilot should brief the Traffic Advisory Display selector position when the associated caution light remains illuminated. If the Engine Anti-Ice is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance. The Traffic Advisory Display selector position is expected to read within the sample range of 7 to 15 units during preflight. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

10.30.3 Adverse Weather Policy Policy 3

The wording here is placeholder content shaped like a procedure, not a procedure. The captain will verify any change in the Fire Detection Loop status message and advise the other pilot when operating at a sample station without ground power. During a turnaround, both pilots should record the Brake Temperature Monitor advisory when conditions permit. The Flight Management Computer status message that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center. The Speedbrake Handle switch position is expected to read within the sample range of 63 to 71 units during an extended ground delay.

- The Speedbrake Handle status message that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval.
- Both pilots will announce any change in the Fuel Crossfeed switch position and advise the other pilot if a discrepancy is observed.
- The Standby Instruments quantity display that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete.

The Nosewheel Steering switch position is expected to read within the sample range of 98 to 101 units during approach. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby

Instruments switch position that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed. The Autopilot Channel A indication is expected to read within the sample range of 19 to 28 units during climb.

NOTE: The Oxygen Distribution status message is expected to read within the sample range of 73 to 78 units during preflight.

If the Probe Heat is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. During an extended ground delay, the Captain should cross-check the Bleed Air Supply status message unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. The Transponder indication that differs from the expected state requires the First Officer to monitor the condition before the next phase of flight. If the Hydraulic System A is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: Both pilots will verify any change in the Cabin Pressure Controller switch position and advise the other pilot if a discrepancy is observed. The Bleed Air Supply advisory that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed.

- If the Autopilot Channel B is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.
- The Engine Anti-Ice status message that differs from the expected state requires the pilot monitoring to record the condition if a discrepancy is observed.
- The captain will monitor any change in the Hydraulic System A quantity display and advise the other pilot before the next phase of flight.

NOTE: The Weather Radar selector position that differs from the expected state requires the pilot flying to cross-check the condition before the next phase of flight.

The Traffic Advisory Display advisory that differs from the expected state requires both pilots to confirm the condition if a discrepancy is observed. During approach, the relief pilot should announce the Autobrake Selector indication if the indication does not stabilize within the sample interval. The Standby Hydraulic quantity display that differs from the expected state requires the pilot flying to monitor the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Autobrake Selector annunciation that differs from the expected state requires the First Officer to confirm the condition when conditions permit.

10.30.4 Adverse Weather Policy Policy 4

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will record any change in the Nosewheel Steering status message and advise the other pilot when operating at a sample station without ground power. During approach, the Captain should monitor the Hydraulic System B switch position when the associated caution light remains illuminated. During landing, the pilot monitoring should cross-check the Brake Temperature Monitor switch position when the associated caution light remains illuminated. The Auxiliary Power Unit switch position is expected to read within the sample range of 64 to 68 units during takeoff. The pilot flying will announce any change in the Nosewheel Steering quantity display and advise the other pilot if a discrepancy is observed.

- The Thrust Reverser annunciation is expected to read within the sample range of 55 to 61 units during cruise.
- If the Cabin Pressure Controller is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- The Transponder switch position is expected to read within the sample range of 6 to 10 units during cruise.
- If the Transponder is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.

The Primary Electrical Bus status message that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated. The first officer will confirm any change in the Autothrottle status message and advise the other pilot before the next phase of flight. If the Pack Temperature Control is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. During an extended ground delay, the pilot flying should announce the Oxygen Distribution indication when conditions permit. The Speedbrake Handle indication that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete. During taxi, both pilots should cross-check the Pack Temperature Control quantity display unless directed otherwise by the Sample Operations Center.

CAUTION: If the Standby Hydraulic is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.

CAUTION: If the Autopilot Channel B is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

CAUTION: If the Flight Management Computer is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. During engine start, both pilots should confirm the Traffic Advisory Display advisory once the checklist item is complete.

10.30.5 Adverse Weather Policy Policy 5

If the Pack Temperature Control is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During cruise, the Captain should confirm the Autopilot Channel B switch position once the checklist item is complete. The pilot flying will cross-check any change in the Standby Hydraulic advisory and advise the other pilot when conditions permit.

CAUTION: The Flap Position Indication status message that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight.

NOTE: The Weather Radar indication that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed. If the Cabin Pressure Controller is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose. During taxi, the relief pilot should verify the Auxiliary Power Unit switch position unless directed otherwise by the Sample Operations Center.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The relief pilot will confirm any change in the Flight Management Computer indication and advise the other pilot unless directed otherwise by the Sample Operations Center.
- If the Primary Electrical Bus is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The first officer will cross-check any change in the Fire Detection Loop indication and advise the other pilot before the next phase of flight.

CAUTION: The Transponder annunciation is expected to read within the sample range of 40 to 43 units during approach. If the Thrust Reverser is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

The Autopilot Channel B status message is expected to read within the sample range of 26 to 32 units during parking. The captain will record any change in the Transponder advisory and advise the other pilot when operating at a sample station without ground power. During climb, the pilot flying should announce the Oxygen Distribution status message when the associated caution light remains illuminated. The Engine Anti-Ice selector position that differs from the expected state requires the Captain to cross-check the condition when operating at a sample station without ground power. If the Brake Temperature Monitor is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue climb only after the

pilot flying has reviewed the associated sample guidance.

NOTE: During approach, the pilot flying should announce the Cockpit Voice Recorder switch position when conditions permit.

10.30.6 Adverse Weather Policy Policy 6

The pilot flying will select any change in the Cockpit Voice Recorder switch position and advise the other pilot if a discrepancy is observed. The Engine Anti-Ice quantity display is expected to read within the sample range of 38 to 43 units during a maintenance-requested ground run. During a diversion, the Captain should monitor the Traffic Advisory Display selector position if the indication does not stabilize within the sample interval.

The Engine Anti-Ice status message that differs from the expected state requires the First Officer to cross-check the condition when conditions permit. During a maintenance-requested ground run, the Captain should announce the Autopilot Channel A status message when the associated caution light remains illuminated. During landing, the First Officer should record the Weather Radar advisory once the checklist item is complete.

Condition	Sample value	Remarks
Oxygen Distribution quantity display	33 units	Normal
Cargo Smoke Detection advisory	68 units	Advisory only
Landing Gear Indication annunciation	97 units	Monitor

Condition	Sample value	Remarks
Flight Management Computer annunciation	89 units	Advisory only
Weather Radar indication	4 units	Normal
Traffic Advisory Display advisory	2 units	Normal
Fire Detection Loop selector position	22 units	Advisory only
Oxygen Distribution indication	69 units	Monitor
Hydraulic System B status message	61 units	Refer to related topic
Standby Hydraulic switch position	97 units	Monitor

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. If the Bleed Air Supply is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.

- Values in this manual are invented and must not be used for any operational purpose.
- During taxi, the relief pilot should monitor the Brake Temperature Monitor selector position when operating at a sample station without ground power.
- If the Primary Electrical Bus is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

10.30.7 Adverse Weather Policy Policy 7

During parking, the pilot monitoring should announce the Brake Temperature Monitor switch position when operating at a sample station without ground power. The Window Heat advisory is expected to read within the sample range of 96 to 99 units during a diversion. The pilot monitoring will confirm any change in the Cockpit Voice Recorder status message and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. If the Pack Temperature Control is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The relief pilot will announce any change in the Autopilot Channel A indication and advise the other pilot when the associated caution light remains illuminated.

CAUTION: The Brake Temperature Monitor annunciation is expected to read within the sample range of 74 to 79 units during a turnaround.

CAUTION: The Autopilot Channel A annunciation is expected to read within the sample range of 62 to 68 units during parking. During taxi, the pilot flying should announce the Traffic Advisory Display selector position when the associated caution light remains illuminated.

The Transponder selector position that differs from the expected state requires the pilot monitoring to cross-check the condition once the checklist item is complete. The Auxiliary Power Unit selector position is expected to read within the sample range of 21 to 29 units during parking. The pilot monitoring will cross-check any change in the Cabin Pressure Controller advisory and advise the other pilot if the indication does not stabilize within the sample interval. If the Thrust Reverser is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Weather Radar is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

- If the Fire Detection Loop is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- The pilot monitoring will announce any change in the Traffic Advisory Display status message and advise the other pilot once the checklist item is complete.
- Values in this manual are invented and must not be used for any operational purpose.
- Both pilots will cross-check any change in the Bleed Air Supply advisory and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Brake Temperature Monitor indication	60 units	Normal
Autobrake Selector selector position	99 units	Monitor
Nosewheel Steering status message	37 units	Normal
Autothrottle indication	4 units	Monitor
Flap Position Indication quantity display	86 units	Refer to related topic
Brake Temperature Monitor indication	47 units	Normal
Oxygen Distribution switch position	96 units	Monitor

The relief pilot will verify any change in the Primary Electrical Bus indication and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Instruments advisory that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center. If the Autobrake Selector is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

The Primary Electrical Bus switch position is expected to read within the sample range of 95 to 107 units during climb. If the Hydraulic System B is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The captain will select any change in the Brake Temperature Monitor quantity display and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. If the Fuel Crossfeed is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

10.30.8 Adverse Weather Policy Policy 8

The Nosewheel Steering status message that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated. The pilot flying will brief any change in the Stall Warning indication and advise the other pilot when the associated caution light remains illuminated. The relief pilot will select any change in the Standby Instruments selector position and advise the other pilot if the indication does not stabilize within the sample interval.

During takeoff, the Captain should announce the Window Heat quantity display when operating at a sample station without ground power. During approach, the First Officer should record the Probe Heat quantity display once the checklist item is complete. The relief pilot will select any change in the Standby Instruments annunciation and advise the other pilot once the checklist item is complete. The Window Heat quantity display that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Cargo Smoke Detection is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Primary Electrical Bus switch position that differs from the expected state requires both pilots to confirm the condition unless directed otherwise by the Sample Operations Center.

During descent, the pilot monitoring should record the Wing Anti-Ice status message if a discrepancy is observed. Refer to the related topic for additional sample context. If the Standby Hydraulic is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. The relief pilot will record any change in the Primary Electrical Bus switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cabin Pressure Controller is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

The Nosewheel Steering switch position that differs from the expected state requires the Captain to confirm the condition when conditions permit. The captain will brief any change in the Wing Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The pilot flying will verify any change in the Thrust Reverser selector position and advise the other pilot when the associated caution light remains illuminated. During a turnaround, the relief pilot should brief the Wing Anti-Ice annunciation unless directed otherwise by the Sample Operations Center. Both pilots will record any change in the Thrust Reverser advisory and advise the other pilot once the checklist item is complete. See 11.20.4 Communications Policy 4.

Condition	Sample value	Remarks
Oxygen Distribution advisory	45 units	Refer to related topic
Weather Radar switch position	23 units	Monitor
Cargo Smoke Detection indication	43 units	Refer to related topic

NOTE: Refer to the related topic for additional sample context.

Chapter 11 Communications

11.10 Communications: Part A

11.10.1 Communications Policy 1

If the Center Tank Pumps is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. The Ground Proximity Monitor advisory that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete. During climb, the pilot monitoring should verify the Nosewheel Steering advisory once the checklist item is complete. The Center Tank Pumps selector position that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

If the Cockpit Voice Recorder is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Standby Hydraulic quantity display is expected to read within the sample range of 83 to 92 units during climb. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: During parking, the Captain should select the Weather Radar switch position unless directed otherwise by the Sample Operations Center.

CAUTION: During takeoff, the Captain should cross-check the Oxygen Distribution indication when conditions permit.

CAUTION: If the Hydraulic System A is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.

During a diversion, the pilot flying should record the Cockpit Voice Recorder indication if the indication does not stabilize within the sample interval. The captain will announce any change in the Transponder indication and advise the other pilot if the indication does not stabilize within the sample interval. During cruise, both pilots should record the Bleed Air Supply selector position when the associated caution light remains illuminated. The Auxiliary Power Unit advisory that differs from the expected state requires the Captain to announce the condition when conditions permit. The pilot flying will verify any change in the Landing Gear Indication status message and advise the other pilot when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

11.10.2 Communications Policy 2

This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Brake Temperature Monitor status message that differs from the expected state requires both pilots to record the condition when conditions permit.

Condition	Sample value	Remarks
Bleed Air Supply indication	5 units	Advisory only
Flight Management Computer quantity display	79 units	Monitor
Probe Heat indication	39 units	Advisory only
Bleed Air Supply switch position	26 units	Normal
Probe Heat indication	59 units	Advisory only

CAUTION: The first officer will brief any change in the Primary Electrical Bus switch position and advise the other pilot when operating at a sample station without ground power.

The Auxiliary Power Unit quantity display is expected to read within the sample range of 57 to 61 units during engine start. During parking, the First Officer should confirm the Pack Temperature Control quantity display before the next phase of flight. The captain will verify any change in the Stall Warning indication and advise the other pilot once the checklist item is complete. If the Traffic Advisory Display is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. If the Autobrake Selector is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance.

The first officer will confirm any change in the Speedbrake Handle switch position and advise the other pilot if a discrepancy is observed. Refer to the related topic for additional sample context. During taxi, the relief pilot should select the Center Tank Pumps status message if the indication does not stabilize within the sample interval. During taxi, the pilot monitoring should confirm the Thrust Reverser annunciation when operating at a sample station without ground power. During parking, the pilot monitoring should confirm the Auxiliary Power Unit advisory before the next phase of flight.

11.10.3 Communications Policy 3

The first officer will monitor any change in the Wing Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Window Heat quantity display is expected to read within the sample range of 94 to 104 units during parking. The Bleed Air Supply switch position that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System B quantity display is expected to read within the sample range of 40 to 48 units during climb. During takeoff, the pilot monitoring should verify the Fuel Crossfeed selector position if a discrepancy is observed.

The pilot monitoring will monitor any change in the Engine Anti-Ice annunciation and advise the other pilot if a discrepancy is observed. If the Oxygen Distribution is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will select any change in the Hydraulic System A quantity display and advise the other pilot once the checklist item is complete. The Autobrake Selector selector position is expected to read within the sample range of 20 to 24 units during engine start. If the Landing Gear Indication is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

The Probe Heat quantity display that differs from the expected state requires the pilot monitoring to select the condition if the indication does not stabilize within the sample interval. The Window Heat selector position is expected to read within the sample range of 49 to 61 units during a turnaround. During a maintenance-requested ground run, the relief pilot should announce the Weather Radar status message before the next phase of flight.

- The Window Heat status message that differs from the expected state requires the First Officer to cross-check the condition if the indication does not stabilize within the sample interval.
- During a maintenance-requested ground run, the pilot flying should cross-check the Autobrake Selector quantity display if a discrepancy is observed.
- The relief pilot will cross-check any change in the Autothrottle quantity display and advise the other pilot before the next phase of flight.
- The relief pilot will monitor any change in the Hydraulic System A indication and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: If the Cabin Pressure Controller is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.

Both pilots will verify any change in the Fuel Crossfeed quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The Bleed Air Supply status message that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center. If the Standby Instruments is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The Engine Anti-Ice indication that differs from the expected state requires the First Officer to confirm the condition if a

discrepancy is observed.

Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. If the Center Tank Pumps is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.

11.10.4 Communications Policy 4

If the Hydraulic System B is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Window Heat switch position that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. The pilot monitoring will verify any change in the Fire Detection Loop quantity display and advise the other pilot when operating at a sample station without ground power. The Center Tank Pumps quantity display is expected to read within the sample range of 84 to 94 units during a maintenance-requested ground run.

NOTE: The Nosewheel Steering switch position that differs from the expected state requires the pilot flying to confirm the condition when operating at a sample station without ground power. During cruise, the pilot flying should cross-check the Traffic Advisory Display switch position when the associated caution light remains illuminated.

NOTE: The Brake Temperature Monitor switch position is expected to read within the sample range of 52 to 57 units during a maintenance-requested ground run. The pilot flying will cross-check any change in the Hydraulic System A quantity display and advise the other pilot before the next phase of flight.

If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Bleed Air Supply indication that differs from the expected state requires the Captain to announce the condition when conditions permit. The pilot flying will verify any change in the Traffic Advisory Display quantity display and advise the other pilot when the associated caution light remains illuminated. The Brake Temperature Monitor selector position is expected to read within the sample range of 5 to 11 units during takeoff.

Condition	Sample value	Remarks
Fire Detection Loop advisory	96 units	Normal
Autothrottle quantity display	27 units	Advisory only
Autopilot Channel B selector position	29 units	Advisory only
Bleed Air Supply switch position	46 units	Refer to related topic
Brake Temperature Monitor switch position	69 units	Advisory only
Cockpit Voice Recorder annunciation	24 units	Normal

The Autopilot Channel A switch position is expected to read within the sample range of 43 to 49 units during preflight. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will confirm any change in the Fuel Crossfeed advisory and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Hydraulic System B switch position that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit. Refer to the related topic for additional sample context.

The wording here is placeholder content shaped like a procedure, not a procedure. During taxi, the relief pilot should brief the Cockpit Voice Recorder annunciation if the indication does not stabilize within the sample interval. The Transponder advisory that differs from the expected state requires the Captain to record the condition when operating at a sample station without ground power.

CAUTION: Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure.

11.10.5 Communications Policy 5

The Cargo Smoke Detection annunciation that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power. The Nosewheel Steering quantity display that differs from the expected state requires the Captain to verify the condition when operating at a sample station without ground power. The relief pilot will confirm any change in the Nosewheel Steering status message and advise the other pilot before the next phase of flight. The Standby Instruments quantity display that differs from the expected state requires both pilots to announce the condition when operating at a sample station without ground power. During taxi, the pilot flying should cross-check the Center Tank Pumps advisory before the next phase of flight. The Flight Management Computer status message that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power.

During engine start, both pilots should brief the Traffic Advisory Display indication when the associated caution light remains illuminated. The Stall Warning status message that differs from the expected state requires the relief pilot to monitor the condition unless directed otherwise by the Sample Operations Center. The Bleed Air Supply status message that differs from the expected state requires both pilots to announce the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The captain will monitor any change in the Standby Hydraulic advisory and advise the other pilot once the checklist item is complete. The Ground Proximity Monitor advisory is expected to read within the sample range of 16 to 26 units during takeoff.

The Engine Anti-Ice indication is expected to read within the sample range of 66 to 75 units during climb. The Autobrake Selector advisory is expected to read within the sample range of 68 to 74 units during a maintenance-requested ground run. Values in this manual are invented and must not be used for any operational purpose. If the Probe Heat is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. During cruise, the First Officer should brief the Oxygen Distribution switch position when conditions permit. During descent, the Captain should monitor the Stall Warning advisory if the indication does not stabilize within the sample interval.

During preflight, the relief pilot should select the Standby Hydraulic switch position once the checklist item is complete. The Standby Hydraulic selector position is expected to read within the sample range of 74 to 82 units during taxi. If the Cabin Pressure Controller is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance. During taxi, the relief pilot should confirm the Thrust Reverser annunciation unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The Oxygen Distribution selector position is expected to read within the sample range of 82 to 85 units during taxi.

11.10.6 Communications Policy 6

This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication selector position is expected to read within the sample range of 89 to 98 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose. If the Brake Temperature Monitor is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. During preflight, the Captain should brief the Standby Hydraulic advisory when the associated caution light remains illuminated.

During a diversion, the relief pilot should monitor the Stall Warning status message if the indication does not stabilize within the sample interval. The captain will select any change in the Stall Warning status message and advise the other pilot before the next phase of flight. The Fire Detection Loop switch position that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated. During climb, both pilots should cross-check the Hydraulic System B advisory if a discrepancy is observed.

The pilot flying will announce any change in the Speedbrake Handle annunciation and advise the other pilot if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Primary Electrical Bus advisory that differs from the expected state requires both pilots to verify the condition if the

indication does not stabilize within the sample interval. The Cabin Pressure Controller indication is expected to read within the sample range of 48 to 57 units during landing. The Brake Temperature Monitor status message is expected to read within the sample range of 95 to 103 units during climb.

Both pilots will announce any change in the Oxygen Distribution selector position and advise the other pilot when operating at a sample station without ground power. The pilot flying will select any change in the Ground Proximity Monitor advisory and advise the other pilot if a discrepancy is observed. If the Wing Anti-Ice is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Transponder status message is expected to read within the sample range of 57 to 66 units during parking.

The pilot monitoring will select any change in the Wing Anti-Ice advisory and advise the other pilot before the next phase of flight. If the Flap Position Indication is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The Traffic Advisory Display annunciation is expected to read within the sample range of 34 to 38 units during descent.

The Thrust Reverser switch position is expected to read within the sample range of 72 to 82 units during climb. If the Standby Instruments is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

11.10.7 Communications Policy 7

The Weather Radar quantity display that differs from the expected state requires the pilot monitoring to record the condition when conditions permit. Both pilots will brief any change in the Primary Electrical Bus indication and advise the other pilot before the next phase of flight. If the Autobrake Selector is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. The relief pilot will cross-check any change in the Cargo Smoke Detection status message and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Fire Detection Loop is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

CAUTION: The first officer will confirm any change in the Oxygen Distribution switch position and advise the other pilot when operating at a sample station without ground power.

If the Speedbrake Handle is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Primary Electrical Bus quantity display that differs from the expected state requires the pilot flying to confirm the condition if a discrepancy is observed. The pilot monitoring will cross-check any change in the Primary Electrical Bus advisory and advise the other pilot before the next phase of flight. The Engine Anti-Ice status message is expected to read within the sample range of 59 to 63 units during descent. The Standby Hydraulic quantity display is expected to read within the sample range of 67 to 77 units during descent. If the Cargo Smoke Detection is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

The relief pilot will cross-check any change in the Oxygen Distribution quantity display and advise the other pilot when operating at a sample station without ground power. The Brake Temperature Monitor indication that differs from the expected state requires the Captain to verify the condition once the checklist item is complete. The Ground Proximity Monitor indication that differs from the expected state requires both pilots to record the condition if a discrepancy is observed. During a turnaround, both pilots should confirm the Autobrake Selector status message when the associated caution light remains illuminated.

The Landing Gear Indication quantity display that differs from the expected state requires the relief pilot to record the condition if the indication does not stabilize within the sample interval. The Hydraulic System A indication is expected to read within the sample range of 92 to 104 units during a maintenance-requested ground run. Refer to the related topic for additional sample context. The Auxiliary Power Unit quantity display that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power.

If the Window Heat is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. During takeoff, the pilot flying should confirm the Cabin Pressure Controller quantity display unless directed otherwise by the Sample Operations Center. If the Autothrottle is inoperative, continue a turnaround only after the

Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The relief pilot will confirm any change in the Flap Position Indication switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Primary Electrical Bus annunciation is expected to read within the sample range of 34 to 38 units during parking. See 05.30.2 Operations Center Coordination Policy 2.

11.10.8 Communications Policy 8

The captain will select any change in the Bleed Air Supply status message and advise the other pilot before the next phase of flight. The Autopilot Channel B annunciation that differs from the expected state requires the Captain to cross-check the condition before the next phase of flight. The Wing Anti-Ice indication that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center.

CAUTION: During parking, the First Officer should verify the Autopilot Channel A indication when the associated caution light remains illuminated.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: If the Autothrottle is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue climb only after the pilot flying has reviewed the associated sample guidance.

The pilot monitoring will brief any change in the Engine Anti-Ice status message and advise the other pilot if the indication does not stabilize within the sample interval. During approach, the relief pilot should announce the Engine Anti-Ice advisory if a discrepancy is observed. The Flight Management Computer annunciation is expected to read within the sample range of 79 to 82 units during an extended ground delay. The wording here is placeholder content shaped like a procedure, not a procedure. The Landing Gear Indication selector position that differs from the expected state requires the pilot flying to confirm the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The Wing Anti-Ice switch position that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed.

- The Bleed Air Supply status message that differs from the expected state requires the Captain to confirm the condition when the associated caution light remains illuminated.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- Both pilots will verify any change in the Cockpit Voice Recorder selector position and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Bleed Air Supply switch position	50 units	Monitor
Weather Radar switch position	50 units	Monitor
Ground Proximity Monitor advisory	40 units	Monitor
Brake Temperature Monitor indication	34 units	Advisory only
Thrust Reverser indication	26 units	Advisory only

11.20 Communications: Part B

11.20.1 Communications Policy 1

The Traffic Advisory Display quantity display that differs from the expected state requires the Captain to announce the condition when conditions permit. If the Weather Radar is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The first officer will verify any change in the Probe Heat advisory and advise the other pilot when

the associated caution light remains illuminated. During landing, the pilot flying should brief the Nosewheel Steering advisory when conditions permit.

NOTE: During preflight, the First Officer should announce the Brake Temperature Monitor selector position before the next phase of flight.

The first officer will monitor any change in the Primary Electrical Bus selector position and advise the other pilot once the checklist item is complete. During descent, the pilot monitoring should select the Auxiliary Power Unit selector position once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel A status message that differs from the expected state requires the pilot monitoring to record the condition when conditions permit. The Engine Anti-Ice advisory is expected to read within the sample range of 88 to 96 units during an extended ground delay. During cruise, the pilot flying should verify the Auxiliary Power Unit indication when conditions permit.

NOTE: If the Autothrottle is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Speedbrake Handle is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

The Hydraulic System B quantity display is expected to read within the sample range of 80 to 84 units during takeoff. During cruise, the relief pilot should brief the Nosewheel Steering quantity display when conditions permit. If the Bleed Air Supply is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

- The Center Tank Pumps indication is expected to read within the sample range of 91 to 94 units during taxi.
- During descent, the Captain should announce the Thrust Reverser indication if a discrepancy is observed.
- The first officer will select any change in the Auxiliary Power Unit status message and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Cockpit Voice Recorder advisory that differs from the expected state requires both pilots to verify the condition when conditions permit.
- The captain will monitor any change in the Center Tank Pumps selector position and advise the other pilot when conditions permit.

11.20.2 Communications Policy 2

The first officer will verify any change in the Standby Hydraulic selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Speedbrake Handle quantity display that differs from the expected state requires both pilots to announce the condition when conditions permit. The Landing Gear Indication selector position that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. The Standby Hydraulic indication that differs from the expected state requires the Captain to select the condition if a discrepancy is observed.

During climb, the Captain should select the Flap Position Indication selector position when the associated caution light remains illuminated. During parking, the pilot monitoring should monitor the Standby Instruments switch position if a discrepancy is observed. The Weather Radar quantity display is expected to read within the sample range of 86 to 91 units during a diversion. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

During a diversion, the pilot monitoring should verify the Standby Hydraulic status message when the associated caution light remains illuminated. The pilot flying will record any change in the Autopilot Channel B switch position and advise the other pilot when operating at a sample station without ground power. If the Autopilot Channel A is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The Fire Detection Loop annunciation that differs from the expected state requires the First Officer to monitor the condition unless directed otherwise by the Sample Operations Center. If the Fire Detection Loop is inoperative, continue a

diversion only after the pilot monitoring has reviewed the associated sample guidance. The Speedbrake Handle status message is expected to read within the sample range of 87 to 98 units during landing.

- If the Fire Detection Loop is inoperative, continue descent only after the Captain has reviewed the associated sample guidance.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Ground Proximity Monitor annunciation is expected to read within the sample range of 67 to 76 units during engine start.
- If the Autopilot Channel A is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

11.20.3 Communications Policy 3

During climb, the pilot monitoring should verify the Center Tank Pumps indication when operating at a sample station without ground power. During takeoff, the pilot flying should confirm the Autobrake Selector annunciation unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. If the Cabin Pressure Controller is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. During a turnaround, the relief pilot should confirm the Standby Hydraulic indication once the checklist item is complete. The Pack Temperature Control indication is expected to read within the sample range of 75 to 86 units during takeoff.

The pilot flying will announce any change in the Weather Radar status message and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. During descent, the pilot flying should announce the Fire Detection Loop switch position before the next phase of flight. The captain will record any change in the Fuel Crossfeed quantity display and advise the other pilot when operating at a sample station without ground power. The first officer will cross-check any change in the Standby Instruments status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Brake Temperature Monitor switch position	86 units	Monitor
Center Tank Pumps selector position	16 units	Refer to related topic
Window Heat switch position	99 units	Monitor
Hydraulic System B selector position	38 units	Advisory only
Window Heat quantity display	40 units	Monitor
Autothrottle indication	21 units	Normal
Transponder selector position	92 units	Refer to related topic

The Center Tank Pumps annunciation is expected to read within the sample range of 31 to 43 units during approach. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the relief pilot should verify the Autopilot Channel B selector position if a discrepancy is observed. The relief pilot will select any change in the Cargo Smoke Detection annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Brake Temperature Monitor is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

The Cargo Smoke Detection quantity display that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will announce any change in the Ground Proximity Monitor status message and advise the other pilot if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. See 12.30.1 Fuel Policy Policy 1.

11.20.4 Communications Policy 4

If the Hydraulic System B is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Cargo Smoke Detection quantity display is expected to read within the sample range of 96 to 102 units during approach. The Autobrake Selector quantity display is expected to read within the sample range of 79 to 86 units during parking. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System B selector position is expected to read within the sample range of 54 to 57 units during landing.

During takeoff, the relief pilot should record the Wing Anti-Ice indication when the associated caution light remains illuminated. The Hydraulic System A annunciation that differs from the expected state requires both pilots to select the condition when operating at a sample station without ground power. If the Cabin Pressure Controller is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The Stall Warning indication that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power.

If the Cabin Pressure Controller is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. The pilot flying will announce any change in the Flight Management Computer indication and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context.

If the Center Tank Pumps is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Traffic Advisory Display selector position that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete. During takeoff, the Captain should select the Pack Temperature Control advisory when conditions permit.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the pilot flying should monitor the Primary Electrical Bus annunciation if the indication does not stabilize within the sample interval.

- If the Standby Instruments is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.
- During parking, the relief pilot should select the Primary Electrical Bus annunciation if a discrepancy is observed.
- The Oxygen Distribution switch position is expected to read within the sample range of 80 to 85 units during a turnaround.
- The captain will brief any change in the Hydraulic System A annunciation and advise the other pilot when the associated caution light remains illuminated.

If the Hydraulic System A is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Weather Radar advisory is expected to read within the sample range of 12 to 22 units during an extended ground delay. The first officer will brief any change in the Fire Detection Loop annunciation and advise the other pilot before the next phase of flight. The Brake Temperature Monitor switch position that differs from the expected state requires the pilot flying to select the condition when conditions permit. The pilot monitoring will cross-check any change in the Fuel Crossfeed status message and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Autobrake Selector selector position	28 units	Normal
Standby Hydraulic quantity display	6 units	Advisory only
Autothrottle quantity display	49 units	Normal
Nosewheel Steering indication	34 units	Advisory only
Autopilot Channel B indication	26 units	Refer to related topic

The first officer will cross-check any change in the Autopilot Channel B indication and advise the other pilot before the next phase of flight. The pilot monitoring will cross-check any change in the Auxiliary Power Unit advisory and advise the other pilot when operating at a sample station without ground power. The Cargo Smoke Detection switch position is expected to read within the sample range of 89 to 94 units during a maintenance-requested ground run. Values in this manual are invented and must not be used for any operational purpose.

11.20.5 Communications Policy 5

The relief pilot will brief any change in the Speedbrake Handle advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Autopilot Channel B quantity display that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power. Both pilots will brief any change in the Window Heat status message and advise the other pilot before the next phase of flight. The pilot monitoring will confirm any change in the Engine Anti-Ice indication and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Stall Warning switch position	58 units	Refer to related topic
Nosewheel Steering quantity display	67 units	Advisory only
Flap Position Indication status message	9 units	Refer to related topic
Brake Temperature Monitor annunciation	20 units	Refer to related topic
Engine Anti-Ice status message	75 units	Monitor
Cabin Pressure Controller quantity display	86 units	Refer to related topic

NOTE: The Wing Anti-Ice status message that differs from the expected state requires the relief pilot to confirm the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Thrust Reverser advisory	72 units	Refer to related topic
Cargo Smoke Detection advisory	9 units	Normal
Fuel Crossfeed annunciation	9 units	Normal

During a diversion, the pilot monitoring should brief the Thrust Reverser switch position when the associated caution light remains illuminated. During climb, both pilots should brief the Stall Warning advisory before the next phase of flight. During taxi, the pilot flying should confirm the Thrust Reverser annunciation when the associated caution light remains illuminated. Refer to the related topic for additional sample context. The pilot flying will record any change in the Autothrottle selector position and advise the other pilot if the indication does not stabilize within the sample interval. During preflight, both pilots should select the Standby Hydraulic advisory before the next phase of flight.

The Engine Anti-Ice status message that differs from the expected state requires the relief pilot to record the condition unless directed otherwise by the Sample Operations Center. Both pilots will monitor any change in the Autopilot Channel A quantity display and advise the other pilot when operating at a sample station without ground power. The captain will announce any change in the Autopilot Channel B selector position and advise the other pilot if a discrepancy is observed.

CAUTION: The Autopilot Channel B advisory that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated.

11.20.6 Communications Policy 6

The Cargo Smoke Detection status message that differs from the expected state requires the relief pilot to confirm the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure.

Refer to the related topic for additional sample context.

The Fire Detection Loop switch position is expected to read within the sample range of 51 to 59 units during a diversion. The Pack Temperature Control switch position is expected to read within the sample range of 87 to 98 units during climb. Refer to the related topic for additional sample context.

- If the Transponder is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.
- The pilot flying will monitor any change in the Flight Management Computer quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Standby Hydraulic advisory is expected to read within the sample range of 90 to 100 units during approach.

The pilot flying will select any change in the Ground Proximity Monitor indication and advise the other pilot before the next phase of flight. The captain will select any change in the Thrust Reverser switch position and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. If the Cargo Smoke Detection is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Hydraulic System B status message	46 units	Advisory only
Stall Warning switch position	57 units	Normal
Autopilot Channel B status message	25 units	Normal
Stall Warning status message	50 units	Monitor
Autothrottle selector position	5 units	Monitor

NOTE: During parking, the pilot monitoring should confirm the Auxiliary Power Unit annunciation when the associated caution light remains illuminated. The Cabin Pressure Controller quantity display that differs from the expected state requires the First Officer to select the condition when the associated caution light remains illuminated.

The Autopilot Channel A switch position that differs from the expected state requires both pilots to confirm the condition when conditions permit. If the Primary Electrical Bus is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. The Standby Hydraulic switch position is expected to read within the sample range of 88 to 93 units during climb.

11.20.7 Communications Policy 7

During climb, the relief pilot should monitor the Hydraulic System A quantity display if a discrepancy is observed. If the Autopilot Channel B is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The relief pilot will verify any change in the Primary Electrical Bus status message and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. The Flight Management Computer selector position is expected to read within the sample range of 34 to 39 units during taxi. The Autopilot Channel B selector position is expected to read within the sample range of 85 to 88 units during engine start.

During an extended ground delay, the Captain should verify the Flight Management Computer annunciation once the checklist item is complete. The pilot monitoring will confirm any change in the Flap Position Indication selector position and advise the other pilot if a discrepancy is observed. During approach, the Captain should confirm the Landing Gear Indication status message if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	19 units	Refer to related topic

Cargo Smoke Detection quantity display	16 units	Refer to related topic
Cargo Smoke Detection selector position	12 units	Advisory only
Autothrottle indication	78 units	Advisory only
Hydraulic System A switch position	90 units	Advisory only
Landing Gear Indication indication	56 units	Normal
Cargo Smoke Detection selector position	59 units	Normal

NOTE: The Traffic Advisory Display switch position is expected to read within the sample range of 67 to 76 units during taxi. The Autothrottle quantity display that differs from the expected state requires the pilot monitoring to verify the condition when conditions permit.

The first officer will cross-check any change in the Wing Anti-Ice switch position and advise the other pilot when conditions permit. During climb, the relief pilot should brief the Autopilot Channel A switch position once the checklist item is complete. During a maintenance-requested ground run, the relief pilot should brief the Center Tank Pumps indication unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Speedbrake Handle annunciation is expected to read within the sample range of 50 to 53 units during landing. The captain will verify any change in the Cargo Smoke Detection advisory and advise the other pilot before the next phase of flight.

During a diversion, the pilot flying should monitor the Hydraulic System A selector position if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The Cockpit Voice Recorder annunciation that differs from the expected state requires the pilot flying to announce the condition when the associated caution light remains illuminated. The pilot monitoring will cross-check any change in the Flight Management Computer status message and advise the other pilot if a discrepancy is observed. If the Stall Warning is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: During engine start, the First Officer should monitor the Cockpit Voice Recorder selector position if the indication does not stabilize within the sample interval. The first officer will verify any change in the Probe Heat indication and advise the other pilot before the next phase of flight.

The Stall Warning annunciation is expected to read within the sample range of 93 to 96 units during a turnaround. The Cargo Smoke Detection annunciation that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval. The Autothrottle advisory is expected to read within the sample range of 31 to 42 units during taxi. During an extended ground delay, the pilot flying should monitor the Bleed Air Supply annunciation before the next phase of flight.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

11.20.8 Communications Policy 8

Refer to the related topic for additional sample context. The pilot monitoring will cross-check any change in the Traffic Advisory Display indication and advise the other pilot before the next phase of flight. If the Traffic Advisory Display is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Window Heat quantity display is expected to read within the sample range of 39 to 47 units during parking. Both pilots will brief any change in the Nosewheel Steering switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

During takeoff, the relief pilot should monitor the Autothrottle indication unless directed otherwise by the Sample Operations Center. If the Hydraulic System B is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. The captain will announce any change in the Primary Electrical Bus annunciation and advise the other pilot when conditions permit. Both pilots will record any change in the Engine Anti-Ice advisory and advise the other pilot when the associated caution light remains illuminated. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Flight Management Computer switch position	64 units	Refer to related topic
Bleed Air Supply status message	71 units	Normal
Nosewheel Steering quantity display	86 units	Refer to related topic
Landing Gear Indication annunciation	60 units	Normal
Standby Hydraulic indication	47 units	Advisory only

Condition	Sample value	Remarks
Autopilot Channel A status message	78 units	Monitor
Weather Radar advisory	4 units	Advisory only
Probe Heat switch position	98 units	Normal
Flap Position Indication advisory	35 units	Advisory only
Window Heat quantity display	83 units	Refer to related topic
Engine Anti-Ice indication	37 units	Refer to related topic
Oxygen Distribution annunciation	81 units	Normal

The first officer will brief any change in the Flight Management Computer advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autothrottle advisory that differs from the expected state requires the First Officer to select the condition once the checklist item is complete. During taxi, the Captain should brief the Weather Radar advisory if the indication does not stabilize within the sample interval.

NOTE: The Bleed Air Supply switch position that differs from the expected state requires the Captain to monitor the condition before the next phase of flight. If the Wing Anti-Ice is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

- The Pack Temperature Control selector position that differs from the expected state requires the Captain to verify the condition when conditions permit.
- The Thrust Reverser advisory is expected to read within the sample range of 8 to 14 units during parking.
- If the Window Heat is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

The Auxiliary Power Unit switch position is expected to read within the sample range of 96 to 104 units during takeoff. If the Probe Heat is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The Flap Position Indication advisory is expected to read within the sample range of 53 to 64 units during cruise. The Transponder advisory that differs from the expected state requires the Captain to select the condition before the next phase of flight.

During preflight, the pilot monitoring should announce the Traffic Advisory Display advisory before the next phase of flight. If the Auxiliary Power Unit is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The first officer will brief any change in the Brake Temperature Monitor indication and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will confirm any change in the Standby Instruments indication and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Autopilot Channel B is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. See 03.10.4 Crew Qualification Records Policy 4.

11.30 Communications: Part C

11.30.1 Communications Policy 1

This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor switch position that differs from the expected state requires the First Officer to brief the condition when conditions permit. During a diversion, the relief pilot should record the Standby Hydraulic annunciation once the checklist item is complete. Both pilots will cross-check any change in the Nosewheel Steering selector position and advise the other pilot once the checklist item is complete. During an extended ground delay, the First Officer should select the Autopilot Channel A advisory if a discrepancy is observed.

Condition	Sample value	Remarks
Nosewheel Steering status message	18 units	Refer to related topic
Standby Hydraulic quantity display	38 units	Normal
Thrust Reverser annunciation	56 units	Normal

The Standby Hydraulic indication is expected to read within the sample range of 28 to 36 units during a diversion. During climb, both pilots should cross-check the Autopilot Channel B status message unless directed otherwise by the Sample Operations Center. The relief pilot will announce any change in the Cockpit Voice Recorder selector position and advise the other pilot when the associated caution light remains illuminated. If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. The Autopilot Channel A status message is expected to read within the sample range of 26 to 36 units during a diversion.

During an extended ground delay, the pilot flying should confirm the Autopilot Channel A quantity display unless directed otherwise by the Sample Operations Center. The relief pilot will announce any change in the Brake Temperature Monitor indication and advise the other pilot when operating at a sample station without ground power. The Thrust Reverser indication is expected to read within the sample range of 4 to 10 units during parking. The Center Tank Pumps indication is expected to read within the sample range of 77 to 82 units during engine start. Both pilots will brief any change in the Brake Temperature Monitor quantity display and advise the other pilot before the next phase of flight. During taxi, the Captain should cross-check the Primary Electrical Bus indication when conditions permit.

If the Brake Temperature Monitor is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance. If the Pack Temperature Control is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The Wing Anti-Ice annunciation is expected to read within the sample range of 92 to 95 units during parking. The Stall Warning advisory is expected to read within the sample range of 74 to 80 units during an extended ground delay.

Condition	Sample value	Remarks
Fire Detection Loop status message	38 units	Normal
Ground Proximity Monitor status message	85 units	Monitor
Fire Detection Loop indication	38 units	Advisory only
Standby Instruments selector position	89 units	Monitor

The Bleed Air Supply selector position is expected to read within the sample range of 81 to 90 units during preflight. The Fuel Crossfeed quantity display is expected to read within the sample range of 39 to 45 units during a diversion. The wording here is placeholder content shaped like a procedure, not a procedure. If the Autopilot Channel B is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Ground Proximity Monitor advisory that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated.

If the Thrust Reverser is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure.

11.30.2 Communications Policy 2

If the Traffic Advisory Display is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. If the Transponder is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

CAUTION: The captain will cross-check any change in the Autopilot Channel A quantity display and advise the other pilot when conditions permit. The Thrust Reverser quantity display that differs from the expected state requires both pilots to monitor the condition when conditions permit.

- Refer to the related topic for additional sample context.
- During a diversion, both pilots should monitor the Auxiliary Power Unit status message before the next phase of flight.
- During a maintenance-requested ground run, the Captain should select the Speedbrake Handle status message when operating at a sample station without ground power.

CAUTION: During parking, the First Officer should confirm the Flap Position Indication status message if the indication does not stabilize within the sample interval.

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The captain will record any change in the Hydraulic System A switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Center Tank Pumps status message that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. The Thrust Reverser switch position is expected to read within the sample range of 68 to 80 units during landing. The Landing Gear Indication annunciation that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed.

CAUTION: The first officer will select any change in the Weather Radar annunciation and advise the other pilot when the associated caution light remains illuminated.

The relief pilot will brief any change in the Autopilot Channel A indication and advise the other pilot if a discrepancy is observed. During climb, both pilots should announce the Flight Management Computer status message unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection quantity display that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power. The Center Tank Pumps advisory is expected to read within the sample range of 14 to 23 units during takeoff. During descent, the pilot flying should confirm the Auxiliary Power Unit advisory when the associated caution light remains illuminated.

During climb, both pilots should brief the Ground Proximity Monitor annunciation unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The Center Tank Pumps quantity display is expected to read within the sample range of 91 to 102 units during taxi. If the Auxiliary Power Unit is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Cockpit Voice Recorder switch position is expected to read within the sample range of 47 to 54 units during a maintenance-requested ground run.

11.30.3 Communications Policy 3

During a diversion, the Captain should verify the Engine Anti-Ice advisory when operating at a sample station without ground power. The Autothrottle advisory that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval. The Wing Anti-Ice indication that differs from the expected state requires the Captain to record the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. If the Nosewheel Steering is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Speedbrake Handle selector position is expected to read within the sample range of 90 to 94 units during a turnaround. The first officer will announce any change in the Landing Gear Indication indication and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Fire Detection Loop status message	8 units	Advisory only
Nosewheel Steering switch position	75 units	Monitor
Fuel Crossfeed indication	26 units	Refer to related topic
Autopilot Channel A advisory	89 units	Normal
Standby Hydraulic selector position	47 units	Refer to related topic
Wing Anti-Ice switch position	70 units	Advisory only

Condition	Sample value	Remarks
Standby Instruments quantity display	57 units	Normal
Flap Position Indication annunciation	54 units	Monitor
Cargo Smoke Detection quantity display	41 units	Advisory only
Transponder advisory	49 units	Monitor

NOTE: If the Hydraulic System A is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. During preflight, the pilot flying should record the Center Tank Pumps selector position if a discrepancy is observed.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Values in this manual are invented and must not be used for any operational purpose.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- The pilot monitoring will announce any change in the Oxygen Distribution annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. The first officer will record any change in the Autobrake Selector advisory and advise the other pilot before the next phase of flight. The Oxygen Distribution annunciation is expected to read within the sample range of 20 to 24 units during cruise. The first officer will confirm any change in the Center Tank Pumps annunciation and advise the other pilot before the next phase of flight. If the Standby Hydraulic is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

CAUTION: The pilot monitoring will monitor any change in the Traffic Advisory Display annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

11.30.4 Communications Policy 4

The first officer will record any change in the Brake Temperature Monitor quantity display and advise the other pilot if a discrepancy is observed. The Transponder advisory is expected to read within the sample range of 51 to 55 units during an extended ground delay. Refer to the related topic for additional sample context. The captain will verify any change in the Traffic Advisory Display selector position and advise the other pilot when the associated caution light remains illuminated. The first officer will confirm any change in the Oxygen Distribution selector position and advise the other pilot if the indication does not stabilize within the sample interval. During descent, both pilots should confirm the Center Tank Pumps advisory when conditions permit.

The Weather Radar quantity display is expected to read within the sample range of 92 to 100 units during preflight. During cruise, the pilot monitoring should brief the Traffic Advisory Display advisory when operating at a sample station without ground power. The Hydraulic System A quantity display that differs from the expected state requires the pilot flying to announce the condition when operating at a sample station without ground power.

NOTE: The Speedbrake Handle indication is expected to read within the sample range of 48 to 60 units during cruise.

During parking, the pilot flying should brief the Nosewheel Steering indication before the next phase of flight. If the Fuel Crossfeed is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. During takeoff, the Captain should brief the Center Tank Pumps quantity display when the associated caution light remains illuminated. The Autopilot Channel B switch position is expected to read within the sample range of 58 to 67 units during a maintenance-requested ground run. The Weather Radar switch position that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

During a turnaround, the pilot monitoring should announce the Autobrake Selector status message unless directed otherwise by the Sample Operations Center. If the Bleed Air Supply is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The Oxygen Distribution indication is expected to read within the sample range of 88 to 95 units during parking.

NOTE: During preflight, the Captain should confirm the Window Heat quantity display once the checklist item is complete.

The Cockpit Voice Recorder quantity display that differs from the expected state requires both pilots to announce the condition unless directed otherwise by the Sample Operations Center. The Window Heat quantity display that differs from the expected state requires the Captain to select the condition if a discrepancy is observed. During descent, the relief pilot should verify the Hydraulic System B annunciation when conditions permit.

11.30.5 Communications Policy 5

During engine start, the pilot monitoring should brief the Autothrottle selector position unless directed otherwise by the Sample Operations Center. The pilot monitoring will verify any change in the Ground Proximity Monitor indication and advise the other pilot when operating at a sample station without ground power. During cruise, the pilot flying should select the Hydraulic System B status message unless directed otherwise by the Sample Operations Center. If the Standby Instruments is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

If the Center Tank Pumps is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The Autopilot Channel B status message is expected to read within the sample range of 51 to 55 units during climb. During descent, both pilots should select the Window Heat status message if the indication does not stabilize within the sample interval. During climb, the First Officer should confirm the Autopilot Channel B status message when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Primary Electrical Bus is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fuel Crossfeed switch position	90 units	Advisory only
Autobrake Selector quantity display	21 units	Normal
Autothrottle annunciation	69 units	Monitor
Standby Instruments status message	24 units	Normal
Autobrake Selector switch position	13 units	Monitor

NOTE: Refer to the related topic for additional sample context. The Primary Electrical Bus quantity display is expected to read within the sample range of 37 to 49 units during a diversion.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The Autothrottle selector position is expected to read within the sample range of 10 to 15 units during parking.

- If the Landing Gear Indication is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.
- If the Center Tank Pumps is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.
- During takeoff, the First Officer should brief the Flap Position Indication switch position unless directed otherwise by the Sample Operations Center.
- The pilot flying will record any change in the Standby Hydraulic quantity display and advise the other pilot when the associated caution light remains illuminated.
- If the Standby Hydraulic is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.

If the Autopilot Channel B is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will announce any change in the Probe Heat advisory and advise the other pilot once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. If the Window Heat is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will brief any change in the Wing Anti-Ice quantity display and advise the other pilot when operating at a sample station without ground power.

11.30.6 Communications Policy 6

This text is fictional and exists only to give the prototype realistic volume and structure. If the Ground Proximity Monitor is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. During taxi, the relief pilot should verify the Speedbrake Handle status message when conditions permit. If the Cargo Smoke Detection is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The first officer will verify any change in the Stall Warning advisory and advise the other pilot once the checklist item is complete. The Center Tank Pumps status message that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated.

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will verify any change in the Fuel Crossfeed selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The first officer will cross-check any change in the Auxiliary Power Unit annunciation and advise the other pilot when operating at a sample station without ground power. The first officer will announce any change in the Wing Anti-Ice annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

If the Autobrake Selector is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Standby Hydraulic status message is expected to read within the sample range of 72 to 75 units during approach. During approach, the relief pilot should announce the Probe Heat switch position before the next phase of flight. The Wing Anti-Ice switch position is expected to read within the sample range of 35 to 39 units during preflight.

The Cabin Pressure Controller annunciation is expected to read within the sample range of 24 to 33 units during parking. During parking, the Captain should select the Brake Temperature Monitor quantity display when the associated caution light remains illuminated. The captain will cross-check any change in the Nosewheel Steering selector position and advise the other pilot if a discrepancy is observed.

The Autopilot Channel B indication that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. The Window Heat status message that differs from the expected state requires the relief pilot to confirm the condition before the next phase of flight. The Pack Temperature Control quantity display that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. The Probe Heat selector position is expected to read within the sample range of 63 to 69 units during descent.

Both pilots will confirm any change in the Fuel Crossfeed indication and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will confirm any change in the Wing Anti-Ice quantity display and advise the other pilot before the next phase of flight. The Engine Anti-Ice status message is expected to read within the sample range of 82 to 90 units during engine start. If the Flap Position Indication is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. If the Window Heat is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: If the Engine Anti-Ice is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. During approach, both pilots should monitor the Ground Proximity Monitor advisory if the indication does not stabilize within the sample interval. The Thrust Reverser indication that differs from the expected state requires the Captain to select the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

11.30.7 Communications Policy 7

The Landing Gear Indication status message that differs from the expected state requires the Captain to announce the condition when conditions permit. Refer to the related topic for additional sample context. During a turnaround, the pilot flying should monitor the Flight Management Computer status message once the checklist item is complete. The Ground Proximity Monitor switch position is expected to read within the sample range of 45 to 50 units during cruise. The Fuel Crossfeed status message is expected to read within the sample range of 88 to 92 units during landing.

NOTE: The pilot monitoring will confirm any change in the Brake Temperature Monitor status message and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The Engine Anti-Ice switch position is expected to read within the sample range of 25 to 30 units during landing.

The pilot flying will confirm any change in the Hydraulic System B selector position and advise the other pilot once the checklist item is complete. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. The first officer will monitor any change in the Flight Management Computer annunciation and advise the other pilot if a discrepancy is observed. The Flap Position Indication quantity display is expected to read within the sample range of 71 to 76 units during engine start.

NOTE: The Thrust Reverser selector position is expected to read within the sample range of 2 to 7 units during parking.

If the Autobrake Selector is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Hydraulic System B switch position and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The Transponder switch position that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated.

11.30.8 Communications Policy 8

The Standby Instruments selector position is expected to read within the sample range of 92 to 96 units during preflight. During cruise, the First Officer should verify the Primary Electrical Bus quantity display before the next phase of flight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Autobrake Selector is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance. The Autopilot Channel A advisory that differs from the expected state requires both pilots to cross-check the condition if the indication does not stabilize within the sample interval.

During an extended ground delay, both pilots should cross-check the Cabin Pressure Controller indication when conditions permit. The Oxygen Distribution annunciation is expected to read within the sample range of 56 to 62 units during an extended ground delay. The Autobrake Selector indication is expected to read within the sample range of 88 to 98 units during cruise. The pilot monitoring will record any change in the Standby Instruments selector position

and advise the other pilot once the checklist item is complete. During parking, the Captain should confirm the Landing Gear Indication switch position when conditions permit.

The Oxygen Distribution status message is expected to read within the sample range of 27 to 37 units during takeoff. The Weather Radar switch position that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated. The Window Heat status message that differs from the expected state requires the relief pilot to verify the condition once the checklist item is complete. During descent, the First Officer should record the Landing Gear Indication advisory once the checklist item is complete. The Oxygen Distribution quantity display is expected to read within the sample range of 67 to 72 units during descent. The Center Tank Pumps annunciation is expected to read within the sample range of 54 to 64 units during taxi.

The pilot monitoring will monitor any change in the Standby Instruments annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The captain will brief any change in the Fuel Crossfeed status message and advise the other pilot when conditions permit. The Cargo Smoke Detection advisory is expected to read within the sample range of 58 to 69 units during a diversion. If the Hydraulic System A is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance.

The Brake Temperature Monitor status message that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. If the Cabin Pressure Controller is inoperative, continue landing only after the pilot monitoring has reviewed the associated sample guidance.

Chapter 12 Fuel Policy

12.10 Fuel Policy: Part A

12.10.1 Fuel Policy Policy 1

If the Transponder is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Hydraulic System B advisory is expected to read within the sample range of 44 to 47 units during climb. The first officer will confirm any change in the Engine Anti-Ice switch position and advise the other pilot if the indication does not stabilize within the sample interval. During preflight, the relief pilot should monitor the Nosewheel Steering switch position before the next phase of flight.

During landing, the pilot monitoring should select the Autopilot Channel B status message when the associated caution light remains illuminated. The pilot monitoring will record any change in the Primary Electrical Bus indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The Oxygen Distribution selector position that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power.

- The Cockpit Voice Recorder status message is expected to read within the sample range of 42 to 52 units during taxi.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Center Tank Pumps is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- During approach, the relief pilot should monitor the Cargo Smoke Detection advisory before the next phase of flight.
- The pilot flying will monitor any change in the Speedbrake Handle advisory and advise the other pilot when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Standby Hydraulic indication	48 units	Refer to related topic
Speedbrake Handle quantity display	70 units	Monitor
Fire Detection Loop quantity display	36 units	Refer to related topic

CAUTION: The Nosewheel Steering advisory that differs from the expected state requires the relief pilot to cross-check the condition when operating at a sample station without ground power.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

The Oxygen Distribution indication is expected to read within the sample range of 43 to 52 units during taxi. Both pilots will announce any change in the Engine Anti-Ice advisory and advise the other pilot when operating at a sample station without ground power. The Landing Gear Indication advisory is expected to read within the sample range of 19 to 23 units during climb. If the Stall Warning is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. See 09.10.5 Arrival Policy 5.

Condition	Sample value	Remarks
Stall Warning status message	75 units	Advisory only
Hydraulic System B advisory	87 units	Refer to related topic
Primary Electrical Bus annunciation	48 units	Monitor
Traffic Advisory Display annunciation	45 units	Monitor

Transponder selector position	34 units	Monitor
-------------------------------	----------	---------

CAUTION: The Autopilot Channel B annunciation is expected to read within the sample range of 53 to 65 units during landing. During landing, the pilot flying should select the Auxiliary Power Unit advisory when operating at a sample station without ground power.

12.10.2 Fuel Policy Policy 2

The Brake Temperature Monitor indication is expected to read within the sample range of 83 to 94 units during an extended ground delay. The Flight Management Computer switch position that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. The Autobrake Selector advisory is expected to read within the sample range of 92 to 102 units during preflight. If the Pack Temperature Control is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. During takeoff, the pilot flying should select the Landing Gear Indication advisory if the indication does not stabilize within the sample interval. During climb, the pilot monitoring should verify the Landing Gear Indication indication if a discrepancy is observed.

During approach, the First Officer should announce the Traffic Advisory Display switch position when operating at a sample station without ground power. The Autopilot Channel B advisory is expected to read within the sample range of 2 to 9 units during landing. The first officer will select any change in the Wing Anti-Ice indication and advise the other pilot if a discrepancy is observed. During approach, the pilot flying should brief the Brake Temperature Monitor selector position when the associated caution light remains illuminated. The Cargo Smoke Detection selector position that differs from the expected state requires the First Officer to verify the condition when the associated caution light remains illuminated.

- The pilot monitoring will brief any change in the Autopilot Channel B quantity display and advise the other pilot when the associated caution light remains illuminated.
- The first officer will monitor any change in the Cabin Pressure Controller selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Thrust Reverser annunciation that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center.

Values in this manual are invented and must not be used for any operational purpose. The relief pilot will cross-check any change in the Window Heat quantity display and advise the other pilot when the associated caution light remains illuminated. The relief pilot will cross-check any change in the Hydraulic System A indication and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will monitor any change in the Autopilot Channel B switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Cargo Smoke Detection indication and advise the other pilot once the checklist item is complete.

12.10.3 Fuel Policy Policy 3

If the Autothrottle is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. During climb, the relief pilot should confirm the Standby Hydraulic indication once the checklist item is complete. The Ground Proximity Monitor advisory that differs from the expected state requires the pilot monitoring to confirm the condition once the checklist item is complete. The first officer will cross-check any change in the Bleed Air Supply switch position and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Probe Heat selector position	93 units	Advisory only
Autopilot Channel B quantity display	79 units	Normal

Standby Instruments advisory	24 units	Normal
Thrust Reverser status message	8 units	Refer to related topic

The Autothrottle annunciation is expected to read within the sample range of 40 to 45 units during cruise. If the Thrust Reverser is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Thrust Reverser indication that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated. The captain will announce any change in the Brake Temperature Monitor switch position and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose. The Weather Radar annunciation is expected to read within the sample range of 20 to 30 units during approach.

If the Center Tank Pumps is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Cargo Smoke Detection annunciation is expected to read within the sample range of 23 to 26 units during a turnaround. The Probe Heat quantity display is expected to read within the sample range of 11 to 19 units during taxi. The Window Heat advisory is expected to read within the sample range of 92 to 99 units during climb. The captain will cross-check any change in the Probe Heat switch position and advise the other pilot when the associated caution light remains illuminated.

The Weather Radar indication that differs from the expected state requires both pilots to announce the condition unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will verify any change in the Weather Radar advisory and advise the other pilot when the associated caution light remains illuminated. During engine start, the relief pilot should brief the Auxiliary Power Unit selector position if the indication does not stabilize within the sample interval.

The Thrust Reverser advisory that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. If the Autothrottle is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will record any change in the Brake Temperature Monitor annunciation and advise the other pilot when conditions permit. The Flap Position Indication quantity display that differs from the expected state requires the Captain to announce the condition when conditions permit.

Refer to the related topic for additional sample context. The Autothrottle status message is expected to read within the sample range of 97 to 109 units during approach. The pilot flying will verify any change in the Cabin Pressure Controller quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Hydraulic System A quantity display is expected to read within the sample range of 29 to 38 units during a turnaround. The Center Tank Pumps quantity display is expected to read within the sample range of 14 to 25 units during an extended ground delay.

12.10.4 Fuel Policy Policy 4

If the Standby Instruments is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance.

NOTE: The Traffic Advisory Display advisory is expected to read within the sample range of 86 to 89 units during a diversion. The Probe Heat quantity display is expected to read within the sample range of 40 to 46 units during a turnaround.

CAUTION: If the Hydraulic System B is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Flight Management Computer indication	50 units	Normal

Bleed Air Supply selector position	69 units	Advisory only
Bleed Air Supply selector position	66 units	Refer to related topic
Traffic Advisory Display status message	23 units	Advisory only
Pack Temperature Control indication	28 units	Refer to related topic
Flap Position Indication selector position	92 units	Advisory only

Values in this manual are invented and must not be used for any operational purpose. If the Center Tank Pumps is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Pack Temperature Control status message is expected to read within the sample range of 64 to 73 units during approach. Values in this manual are invented and must not be used for any operational purpose.

NOTE: The first officer will confirm any change in the Window Heat selector position and advise the other pilot when the associated caution light remains illuminated.

12.10.5 Fuel Policy Policy 5

If the Weather Radar is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. If the Pack Temperature Control is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. The pilot flying will brief any change in the Fire Detection Loop annunciation and advise the other pilot when operating at a sample station without ground power. If the Autobrake Selector is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. During engine start, the pilot monitoring should announce the Brake Temperature Monitor indication if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Nosewheel Steering indication	22 units	Advisory only
Nosewheel Steering indication	62 units	Normal
Autobrake Selector selector position	63 units	Normal

Condition	Sample value	Remarks
Primary Electrical Bus quantity display	25 units	Refer to related topic
Autothrottle selector position	2 units	Monitor
Autothrottle selector position	36 units	Refer to related topic
Oxygen Distribution indication	8 units	Monitor
Autobrake Selector quantity display	41 units	Normal

The Landing Gear Indication indication that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. If the Primary Electrical Bus is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The pilot flying will confirm any change in the Ground Proximity Monitor annunciation and advise the other pilot when operating at a sample station without ground power. The Cargo Smoke Detection advisory that differs from the expected state requires both pilots to confirm the condition once the checklist item is complete.

During cruise, the Captain should confirm the Flight Management Computer switch position before the next phase of flight. If the Hydraulic System A is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During a turnaround, the First Officer should confirm the Standby Hydraulic selector position when the associated caution light remains illuminated. The Transponder annunciation is expected to read within the sample range of 55 to 60 units during parking. The Autopilot Channel B selector position is expected to read within the sample range of 18 to 25 units during descent.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

NOTE: The relief pilot will monitor any change in the Bleed Air Supply status message and advise the other pilot before the next phase of flight. The pilot monitoring will brief any change in the Autothrottle quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

12.10.6 Fuel Policy Policy 6

The pilot flying will cross-check any change in the Pack Temperature Control annunciation and advise the other pilot before the next phase of flight. If the Oxygen Distribution is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The captain will select any change in the Primary Electrical Bus selector position and advise the other pilot if a discrepancy is observed. The Hydraulic System A quantity display is expected to read within the sample range of 72 to 84 units during taxi. The Pack Temperature Control switch position is expected to read within the sample range of 3 to 13 units during descent.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Autopilot Channel A is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. The first officer will announce any change in the Auxiliary Power Unit switch position and advise the other pilot if a discrepancy is observed. The Standby Instruments selector position that differs from the expected state requires the pilot flying to select the condition before the next phase of flight. During landing, the pilot monitoring should cross-check the Landing Gear Indication selector position when conditions permit. The Ground Proximity Monitor selector position that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power.

NOTE: The first officer will record any change in the Landing Gear Indication quantity display and advise the other pilot when operating at a sample station without ground power.

The Traffic Advisory Display advisory is expected to read within the sample range of 20 to 31 units during engine start. Values in this manual are invented and must not be used for any operational purpose. Both pilots will verify any change in the Probe Heat quantity display and advise the other pilot before the next phase of flight. The Hydraulic System A switch position is expected to read within the sample range of 94 to 101 units during landing.

NOTE: The Hydraulic System A advisory that differs from the expected state requires both pilots to record the condition when the associated caution light remains illuminated.

12.10.7 Fuel Policy Policy 7

During a turnaround, the relief pilot should cross-check the Landing Gear Indication switch position when operating at a sample station without ground power. If the Nosewheel Steering is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Stall Warning switch position is expected to read within the sample range of 60 to 64 units during landing. The Landing Gear Indication annunciation that differs from the expected state requires the pilot flying to verify the condition once the checklist item is complete. The Flap Position Indication advisory that differs from the expected state requires the Captain to announce the condition before the next phase of flight.

Condition	Sample value	Remarks
Autopilot Channel B advisory	49 units	Advisory only
Flap Position Indication annunciation	45 units	Advisory only
Fire Detection Loop annunciation	3 units	Refer to related topic
Traffic Advisory Display selector position	29 units	Monitor
Engine Anti-Ice advisory	9 units	Normal
Fire Detection Loop advisory	57 units	Normal
Flight Management Computer switch position	72 units	Normal

Condition	Sample value	Remarks
Cabin Pressure Controller switch position	28 units	Advisory only
Standby Instruments status message	20 units	Advisory only
Flap Position Indication selector position	36 units	Monitor
Landing Gear Indication quantity display	79 units	Advisory only
Speedbrake Handle advisory	69 units	Normal
Center Tank Pumps quantity display	86 units	Monitor
Engine Anti-Ice quantity display	88 units	Normal

The Autopilot Channel B indication is expected to read within the sample range of 19 to 24 units during cruise. The Flight Management Computer annunciation that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval. During an extended ground delay, both pilots should announce the Traffic Advisory Display status message unless directed otherwise by the Sample Operations Center. The Flap Position Indication selector position that differs from the expected state requires the relief pilot to select the condition if a discrepancy is observed. See 05.30.5 Operations Center Coordination Policy 5.

NOTE: The captain will select any change in the Thrust Reverser selector position and advise the other pilot when conditions permit. Refer to the related topic for additional sample context.

12.10.8 Fuel Policy Policy 8

If the Window Heat is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. The pilot flying will monitor any change in the Ground Proximity Monitor advisory and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Traffic Advisory Display status message is expected to read within the sample range of 4 to 11 units during a diversion. The Window Heat annunciation is expected to read within the sample range of 13 to 22 units during engine start.

Condition	Sample value	Remarks
Autopilot Channel A selector position	97 units	Refer to related topic
Oxygen Distribution switch position	76 units	Refer to related topic
Standby Instruments indication	63 units	Normal
Autobrake Selector quantity display	72 units	Advisory only

CAUTION: The Hydraulic System A advisory that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated. The Stall Warning switch position is expected to read within the sample range of 18 to 21 units during a diversion.

NOTE: The Oxygen Distribution indication is expected to read within the sample range of 69 to 77 units during descent. The Speedbrake Handle quantity display that differs from the expected state requires both pilots to record the condition if the indication does not stabilize within the sample interval.

Values in this manual are invented and must not be used for any operational purpose. If the Cargo Smoke Detection is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Landing Gear Indication selector position that differs from the expected state requires the pilot flying to cross-check the condition if the indication does not stabilize within the sample interval. The captain will verify any change in the Pack Temperature Control indication and advise the other pilot if a discrepancy is observed. The Standby Hydraulic selector position is expected to read within the sample range of 6 to 13 units during a turnaround. The Nosewheel Steering annunciation that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval.

12.20 Fuel Policy: Part B

12.20.1 Fuel Policy Policy 1

Both pilots will brief any change in the Fuel Crossfeed advisory and advise the other pilot when the associated caution light remains illuminated. The captain will verify any change in the Pack Temperature Control quantity display and advise the other pilot if a discrepancy is observed. If the Nosewheel Steering is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. If the Standby Hydraulic is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The pilot flying will confirm any change in the Thrust Reverser quantity display and advise the other pilot if a discrepancy is observed.

The relief pilot will confirm any change in the Weather Radar annunciation and advise the other pilot when conditions permit. The Bleed Air Supply advisory that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete. The relief pilot will cross-check any change in the Center Tank Pumps annunciation and advise the other pilot if the indication does not stabilize within the sample interval. The Auxiliary Power Unit advisory is expected to read within the sample range of 88 to 97 units during engine start.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will select any change in the Stall Warning indication and advise the other pilot when operating at a sample station without ground power.

The Auxiliary Power Unit advisory that differs from the expected state requires the pilot monitoring to monitor the condition if a discrepancy is observed. The Ground Proximity Monitor annunciation is expected to read within the sample range of 80 to 84 units during a turnaround. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic advisory is expected to read within the sample range of 12 to 16 units during an extended ground delay. The Standby Instruments indication is expected to read within the sample range of 45 to 54 units during parking. During a maintenance-requested ground run, the Captain should verify the Standby Instruments status message if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Probe Heat annunciation	36 units	Monitor
Pack Temperature Control quantity display	3 units	Advisory only
Window Heat annunciation	36 units	Refer to related topic
Hydraulic System B annunciation	51 units	Monitor
Autopilot Channel B switch position	86 units	Advisory only
Stall Warning switch position	84 units	Refer to related topic

Condition	Sample value	Remarks
Thrust Reverser indication	79 units	Monitor
Cargo Smoke Detection indication	44 units	Monitor
Oxygen Distribution annunciation	55 units	Refer to related topic
Pack Temperature Control status message	3 units	Normal

12.20.2 Fuel Policy Policy 2

This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will monitor any change in the Brake Temperature Monitor switch position and advise the other pilot when operating at a sample station without ground power. The Window Heat selector position that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete. Both pilots will monitor any change in the Oxygen Distribution indication and advise the other pilot if a discrepancy is observed.

During takeoff, the relief pilot should cross-check the Traffic Advisory Display quantity display before the next phase of flight. During descent, the pilot flying should record the Standby Hydraulic switch position once the checklist item is complete. The Stall Warning selector position that differs from the expected state requires the pilot monitoring to announce the condition when operating at a sample station without ground power. If the Engine Anti-Ice is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. The Flight Management Computer status message that differs from the expected state requires the pilot flying to confirm the condition once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. If the Probe Heat is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The Fire Detection Loop selector position is expected to read within the sample range of 52 to 61 units during parking. The Fuel Crossfeed indication is expected to read within the sample range of 91 to 100 units during takeoff.

NOTE: If the Flap Position Indication is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Autothrottle quantity display	29 units	Refer to related topic
Oxygen Distribution selector position	82 units	Monitor
Flap Position Indication annunciation	51 units	Refer to related topic
Cockpit Voice Recorder switch position	12 units	Monitor
Hydraulic System B quantity display	67 units	Normal
Wing Anti-Ice quantity display	9 units	Monitor
Autothrottle indication	28 units	Monitor

Condition	Sample value	Remarks
Flap Position Indication quantity display	41 units	Refer to related topic
Hydraulic System A quantity display	49 units	Normal
Hydraulic System B status message	1 units	Normal
Oxygen Distribution quantity display	42 units	Monitor
Nosewheel Steering indication	57 units	Advisory only
Standby Instruments selector position	44 units	Normal
Autothrottle quantity display	9 units	Normal

- During an extended ground delay, the Captain should cross-check the Flap Position Indication status message when the associated caution light remains illuminated.
- During a diversion, the Captain should verify the Cabin Pressure Controller annunciation when conditions permit.
- The Standby Instruments status message is expected to read within the sample range of 52 to 55 units during a diversion.
- The first officer will cross-check any change in the Standby Hydraulic annunciation and advise the other pilot if a discrepancy is observed.

12.20.3 Fuel Policy Policy 3

During landing, both pilots should record the Transponder switch position if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Nosewheel Steering annunciation is expected to read within the sample range of 74 to 83 units during an extended ground delay. If the Fire Detection Loop is inoperative, continue descent only after the pilot flying has reviewed the associated

sample guidance. The Wing Anti-Ice indication is expected to read within the sample range of 38 to 41 units during landing. The Engine Anti-Ice selector position is expected to read within the sample range of 7 to 14 units during a turnaround.

CAUTION: The Wing Anti-Ice status message is expected to read within the sample range of 10 to 21 units during takeoff. The relief pilot will brief any change in the Fuel Crossfeed quantity display and advise the other pilot when conditions permit.

CAUTION: The Window Heat status message is expected to read within the sample range of 63 to 70 units during landing. The Window Heat status message is expected to read within the sample range of 57 to 66 units during preflight.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Flap Position Indication annunciation	60 units	Advisory only
Speedbrake Handle advisory	21 units	Refer to related topic
Autopilot Channel B annunciation	57 units	Monitor
Brake Temperature Monitor advisory	76 units	Advisory only
Standby Hydraulic selector position	47 units	Normal

- The Ground Proximity Monitor switch position that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval.
- The Wing Anti-Ice quantity display that differs from the expected state requires the pilot monitoring to record the condition once the checklist item is complete.
- The Engine Anti-Ice annunciation is expected to read within the sample range of 60 to 65 units during taxi.
- The Fuel Crossfeed indication that differs from the expected state requires the relief pilot to brief the condition once the checklist item is complete.
- The Flap Position Indication quantity display is expected to read within the sample range of 69 to 73 units during climb.
- Refer to the related topic for additional sample context.

NOTE: Refer to the related topic for additional sample context. The Landing Gear Indication switch position that differs from the expected state requires the First Officer to monitor the condition once the checklist item is complete.

Condition	Sample value	Remarks
Weather Radar quantity display	63 units	Advisory only
Autobrake Selector annunciation	57 units	Advisory only
Hydraulic System A status message	28 units	Refer to related topic
Nosewheel Steering selector position	93 units	Normal

12.20.4 Fuel Policy Policy 4

The Oxygen Distribution quantity display is expected to read within the sample range of 37 to 46 units during engine start. The Traffic Advisory Display status message that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed. The Weather Radar advisory is expected to read within the sample range of 30 to 41 units during takeoff. The Autothrottle switch position is expected to read within the sample range of 62 to 74 units during engine start. The Autothrottle status message is expected to read within the sample range of 43 to 46 units during takeoff. During an extended ground delay, the relief pilot should announce the Auxiliary Power Unit

annunciation when conditions permit.

If the Window Heat is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: If the Stall Warning is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The relief pilot will monitor any change in the Autothrottle switch position and advise the other pilot if a discrepancy is observed.

- If the Cargo Smoke Detection is inoperative, continue approach only after both pilots has reviewed the associated sample guidance.
- If the Primary Electrical Bus is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance.
- The Pack Temperature Control indication is expected to read within the sample range of 38 to 48 units during parking.
- Both pilots will verify any change in the Hydraulic System A advisory and advise the other pilot if a discrepancy is observed.
- The Auxiliary Power Unit indication is expected to read within the sample range of 20 to 27 units during taxi.
- Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Oxygen Distribution annunciation	91 units	Advisory only
Oxygen Distribution selector position	87 units	Monitor
Hydraulic System B indication	52 units	Refer to related topic
Ground Proximity Monitor indication	45 units	Normal
Primary Electrical Bus selector position	2 units	Monitor
Window Heat switch position	48 units	Advisory only
Stall Warning selector position	3 units	Refer to related topic

12.20.5 Fuel Policy Policy 5

The Stall Warning status message that differs from the expected state requires both pilots to confirm the condition when conditions permit. The Cabin Pressure Controller advisory that differs from the expected state requires the pilot monitoring to confirm the condition if the indication does not stabilize within the sample interval. The Landing Gear Indication advisory that differs from the expected state requires the relief pilot to confirm the condition if the indication does not stabilize within the sample interval.

- If the Fuel Crossfeed is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- The captain will cross-check any change in the Probe Heat status message and advise the other pilot if a discrepancy is observed.
- Values in this manual are invented and must not be used for any operational purpose.
- During parking, the pilot monitoring should monitor the Autothrottle annunciation when conditions permit.

The Cabin Pressure Controller indication that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. If the Fuel Crossfeed is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. The Autothrottle indication is expected to read within the sample range of 96 to 104 units during approach. If the Transponder is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.

- If the Engine Anti-Ice is inoperative, continue cruise only after the Captain has reviewed the associated sample guidance.
- The Bleed Air Supply quantity display that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed.
- The Fuel Crossfeed switch position is expected to read within the sample range of 96 to 101 units during a maintenance-requested ground run.
- The Autothrottle quantity display is expected to read within the sample range of 6 to 13 units during an extended ground delay.
- The Window Heat switch position that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval.
- If the Fire Detection Loop is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.

During preflight, the relief pilot should record the Center Tank Pumps switch position once the checklist item is complete. If the Engine Anti-Ice is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Speedbrake Handle selector position that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed.

NOTE: If the Traffic Advisory Display is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should brief the Hydraulic System B annunciation before the next phase of flight.

During descent, the Captain should monitor the Fire Detection Loop indication once the checklist item is complete. During takeoff, both pilots should monitor the Speedbrake Handle advisory if a discrepancy is observed. The pilot monitoring will record any change in the Landing Gear Indication advisory and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will confirm any change in the Pack Temperature Control switch position and advise the other pilot when conditions permit. The pilot monitoring will cross-check any change in the Fire Detection Loop advisory and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Bleed Air Supply switch position	73 units	Normal
Standby Instruments switch position	34 units	Normal
Wing Anti-Ice annunciation	62 units	Monitor
Stall Warning selector position	92 units	Monitor
Stall Warning indication	32 units	Monitor
Flight Management Computer switch position	98 units	Normal

12.20.6 Fuel Policy Policy 6

This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Instruments selector position that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center. If the Pack Temperature Control is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The Window Heat indication is expected to read within the sample range of 68 to 77 units during climb. The Stall Warning selector position that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval. The Standby Instruments switch position that differs from the expected state requires the First Officer to cross-check the condition once the checklist item is complete.

Values in this manual are invented and must not be used for any operational purpose. Both pilots will monitor any change in the Weather Radar annunciation and advise the other pilot if a discrepancy is observed. During a turnaround, both pilots should monitor the Flight Management Computer indication when the associated caution light

remains illuminated. The Window Heat indication is expected to read within the sample range of 77 to 89 units during engine start. During descent, the pilot flying should cross-check the Traffic Advisory Display indication when conditions permit.

NOTE: If the Window Heat is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

- The Standby Hydraulic advisory that differs from the expected state requires both pilots to cross-check the condition unless directed otherwise by the Sample Operations Center.
- The Oxygen Distribution advisory is expected to read within the sample range of 94 to 106 units during takeoff.
- The Cockpit Voice Recorder indication that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight.
- The pilot flying will announce any change in the Flap Position Indication annunciation and advise the other pilot when operating at a sample station without ground power.

CAUTION: The Traffic Advisory Display quantity display is expected to read within the sample range of 73 to 77 units during taxi.

The pilot monitoring will brief any change in the Landing Gear Indication switch position and advise the other pilot when conditions permit. The pilot monitoring will select any change in the Cabin Pressure Controller switch position and advise the other pilot when the associated caution light remains illuminated. The Center Tank Pumps switch position that differs from the expected state requires both pilots to announce the condition if the indication does not stabilize within the sample interval.

The Engine Anti-Ice annunciation that differs from the expected state requires the pilot monitoring to verify the condition if the indication does not stabilize within the sample interval. Both pilots will announce any change in the Thrust Reverser annunciation and advise the other pilot if a discrepancy is observed. The captain will confirm any change in the Thrust Reverser indication and advise the other pilot when the associated caution light remains illuminated.

The Nosewheel Steering advisory is expected to read within the sample range of 88 to 97 units during a diversion. During approach, the relief pilot should verify the Wing Anti-Ice quantity display when operating at a sample station without ground power. The first officer will cross-check any change in the Fuel Crossfeed indication and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

12.20.7 Fuel Policy Policy 7

The Landing Gear Indication status message is expected to read within the sample range of 81 to 91 units during landing. The captain will monitor any change in the Flap Position Indication annunciation and advise the other pilot when the associated caution light remains illuminated. During preflight, the pilot monitoring should record the Traffic Advisory Display status message if the indication does not stabilize within the sample interval. If the Stall Warning is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The Stall Warning selector position that differs from the expected state requires the Captain to cross-check the condition when the associated caution light remains illuminated. During takeoff, the First Officer should record the Cargo Smoke Detection advisory when conditions permit. Refer to the related topic for additional sample context.

If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The Probe Heat status message is expected to read within the sample range of 23 to 26 units during engine start. If the Ground Proximity Monitor is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

During preflight, the Captain should brief the Autothrottle annunciation if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. If the Hydraulic System A is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. The Fire Detection Loop quantity display is expected to read within the sample range of 7 to 16 units during cruise. During landing, the pilot monitoring should announce the Autopilot Channel B selector position if the indication does not stabilize within the sample interval. The Cabin Pressure Controller status message is expected to read within the sample range of 70 to 80 units during parking.

During cruise, the pilot monitoring should announce the Cockpit Voice Recorder quantity display when the associated caution light remains illuminated. If the Hydraulic System B is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. During climb, the First Officer should monitor the Autothrottle annunciation if a discrepancy is observed.

- The Autopilot Channel B annunciation is expected to read within the sample range of 75 to 79 units during engine start.
- If the Window Heat is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- The Thrust Reverser switch position that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval.
- During descent, the pilot monitoring should announce the Traffic Advisory Display indication once the checklist item is complete.

Condition	Sample value	Remarks
Standby Instruments switch position	89 units	Refer to related topic
Thrust Reverser selector position	36 units	Refer to related topic
Flight Management Computer switch position	12 units	Monitor
Flight Management Computer switch position	34 units	Normal
Auxiliary Power Unit advisory	52 units	Normal
Probe Heat indication	30 units	Monitor

12.20.8 Fuel Policy Policy 8

During descent, both pilots should record the Hydraulic System B indication if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments switch position is expected to read within the sample range of 6 to 11 units during cruise. If the Auxiliary Power Unit is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Standby Instruments status message	93 units	Advisory only
Auxiliary Power Unit annunciation	16 units	Monitor
Engine Anti-Ice selector position	74 units	Normal
Standby Instruments status message	78 units	Monitor
Ground Proximity Monitor advisory	28 units	Monitor
Cargo Smoke Detection quantity display	70 units	Refer to related topic

CAUTION: The Brake Temperature Monitor quantity display that differs from the expected state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated. During taxi, the pilot monitoring should monitor the Center Tank Pumps selector position if the indication does not stabilize within the sample interval.

During parking, the First Officer should announce the Speedbrake Handle quantity display before the next phase of flight. The Bleed Air Supply indication is expected to read within the sample range of 19 to 22 units during a diversion. Refer to the related topic for additional sample context. During parking, both pilots should select the Cockpit Voice Recorder status message when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	52 units	Monitor
Cabin Pressure Controller selector position	59 units	Normal
Pack Temperature Control switch position	26 units	Refer to related topic
Window Heat quantity display	74 units	Refer to related topic
Wing Anti-Ice switch position	8 units	Refer to related topic

NOTE: The Autothrottle status message that differs from the expected state requires the pilot flying to verify the condition if a discrepancy is observed.

NOTE: The pilot monitoring will record any change in the Weather Radar indication and advise the other pilot before the next phase of flight.

12.30 Fuel Policy: Part C

12.30.1 Fuel Policy Policy 1

The Nosewheel Steering indication that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. The Window Heat indication that differs from the expected state requires the pilot flying to confirm the condition before the next phase of flight. If the Autothrottle is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The Window Heat status message is expected to read within the sample range of 59 to 65 units during a maintenance-requested ground run. The Stall Warning quantity display is expected to read within the sample range of 41 to 49 units during a turnaround.

CAUTION: The Fire Detection Loop status message is expected to read within the sample range of 71 to 82 units during takeoff.

If the Fire Detection Loop is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During cruise, the First Officer should record the Engine Anti-Ice status message before the next phase of flight. The pilot flying will announce any change in the Fuel Crossfeed quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

CAUTION: Refer to the related topic for additional sample context.

The pilot flying will confirm any change in the Fire Detection Loop switch position and advise the other pilot when the associated caution light remains illuminated. The Autobrake Selector selector position is expected to read within the sample range of 50 to 57 units during climb. The captain will confirm any change in the Flap Position Indication switch position and advise the other pilot when the associated caution light remains illuminated. During a diversion, the First Officer should monitor the Pack Temperature Control switch position unless directed otherwise by the Sample Operations Center.

NOTE: During descent, the pilot monitoring should monitor the Ground Proximity Monitor indication if the indication does not stabilize within the sample interval. The relief pilot will monitor any change in the Brake Temperature Monitor status message and advise the other pilot when the associated caution light remains illuminated.

12.30.2 Fuel Policy Policy 2

During descent, the relief pilot should confirm the Probe Heat indication unless directed otherwise by the Sample Operations Center. Values in this manual are invented and must not be used for any operational purpose. The Standby Hydraulic quantity display that differs from the expected state requires both pilots to monitor the condition once the checklist item is complete.

Condition	Sample value	Remarks
Cabin Pressure Controller selector position	70 units	Normal
Standby Instruments selector position	44 units	Refer to related topic
Probe Heat switch position	50 units	Monitor
Fuel Crossfeed selector position	42 units	Advisory only
Cockpit Voice Recorder annunciation	69 units	Monitor
Fuel Crossfeed selector position	43 units	Monitor
Autothrottle quantity display	78 units	Advisory only

CAUTION: During an extended ground delay, the First Officer should brief the Primary Electrical Bus status message once the checklist item is complete.

If the Standby Hydraulic is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. During parking, the Captain should confirm the Landing Gear Indication switch position when operating at a sample station without ground power. During preflight, the pilot monitoring should confirm the Flap Position Indication switch position unless directed otherwise by the Sample Operations Center. If the Stall Warning is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. Both pilots will announce any change in the Wing Anti-Ice indication and advise the other pilot before the next phase of flight. During cruise, the pilot flying should record the Transponder annunciation if the indication does not stabilize within the sample interval.

NOTE: The relief pilot will verify any change in the Bleed Air Supply indication and advise the other pilot when conditions permit.

The Autopilot Channel A advisory is expected to read within the sample range of 62 to 74 units during climb. The Bleed Air Supply indication that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center. If the Nosewheel Steering is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During a diversion, the pilot flying should select the Autopilot Channel A advisory unless directed otherwise by the Sample Operations Center. See 01.30.4 General Policy 4.

CAUTION: The Transponder advisory that differs from the expected state requires the First Officer to cross-check the condition if a discrepancy is observed. The pilot flying will record any change in the Wing Anti-Ice advisory and advise the other pilot if the indication does not stabilize within the sample interval.

12.30.3 Fuel Policy Policy 3

Refer to the related topic for additional sample context. During a diversion, the pilot flying should announce the Wing Anti-Ice annunciation if a discrepancy is observed. Both pilots will announce any change in the Center Tank Pumps indication and advise the other pilot when the associated caution light remains illuminated.

CAUTION: If the Standby Hydraulic is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. During approach, the pilot monitoring should verify the Pack Temperature Control indication if a discrepancy is observed.

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. The first officer will record any change in the Weather Radar status message and advise the other pilot if the indication does not stabilize within the sample interval. The Transponder advisory that differs from the expected state requires the pilot flying to monitor the condition if the

indication does not stabilize within the sample interval. If the Fire Detection Loop is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance. If the Thrust Reverser is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Engine Anti-Ice advisory	10 units	Advisory only
Fuel Crossfeed quantity display	31 units	Normal
Oxygen Distribution quantity display	2 units	Normal
Hydraulic System A quantity display	13 units	Normal
Standby Instruments advisory	23 units	Refer to related topic
Cabin Pressure Controller selector position	97 units	Monitor
Traffic Advisory Display advisory	68 units	Advisory only

The pilot flying will confirm any change in the Nosewheel Steering indication and advise the other pilot when operating at a sample station without ground power. During approach, the Captain should cross-check the Autobrake Selector selector position before the next phase of flight. Both pilots will brief any change in the Stall Warning annunciation and advise the other pilot before the next phase of flight. During takeoff, the pilot monitoring should cross-check the Window Heat advisory if a discrepancy is observed. During preflight, the pilot flying should announce the Center Tank Pumps selector position if a discrepancy is observed.

CAUTION: If the Nosewheel Steering is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Thrust Reverser quantity display is expected to read within the sample range of 3 to 8 units during approach.

If the Probe Heat is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The Cargo Smoke Detection status message that differs from the expected state requires the Captain to select the condition when conditions permit. If the Autothrottle is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

12.30.4 Fuel Policy Policy 4

The first officer will monitor any change in the Cockpit Voice Recorder advisory and advise the other pilot before the next phase of flight. If the Center Tank Pumps is inoperative, continue landing only after the Captain has reviewed the associated sample guidance. The Cargo Smoke Detection quantity display is expected to read within the sample range of 61 to 72 units during descent. During an extended ground delay, the relief pilot should announce the Transponder quantity display if the indication does not stabilize within the sample interval. If the Auxiliary Power Unit is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance. The Pack Temperature Control quantity display that differs from the expected state requires the relief pilot to monitor the condition if a discrepancy is observed.

NOTE: Both pilots will select any change in the Landing Gear Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure.

During landing, the pilot monitoring should verify the Landing Gear Indication switch position when the associated caution light remains illuminated. The Autobrake Selector annunciation that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power. Both pilots will monitor any change in the Auxiliary Power Unit status message and advise the other pilot when operating at a sample station without ground power. During a maintenance-requested ground run, both pilots should select the Cockpit Voice Recorder status message before the next phase of flight. The first officer will verify any change in the Autopilot Channel B quantity display and advise the other pilot if the indication does not stabilize within the sample interval. During taxi, the pilot flying should announce the Cockpit Voice Recorder selector position once the checklist item is

complete.

- During climb, the Captain should select the Standby Instruments switch position when the associated caution light remains illuminated.
- If the Speedbrake Handle is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance.
- If the Nosewheel Steering is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- During parking, the Captain should select the Brake Temperature Monitor annunciation if a discrepancy is observed.
- Refer to the related topic for additional sample context.
- If the Hydraulic System A is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. The Traffic Advisory Display switch position that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose.

NOTE: Both pilots will verify any change in the Primary Electrical Bus indication and advise the other pilot once the checklist item is complete.

12.30.5 Fuel Policy Policy 5

Values in this manual are invented and must not be used for any operational purpose. The Probe Heat selector position that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete. Refer to the related topic for additional sample context. If the Standby Instruments is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. If the Cabin Pressure Controller is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. During cruise, the Captain should record the Nosewheel Steering switch position before the next phase of flight.

The Landing Gear Indication indication that differs from the expected state requires both pilots to announce the condition if a discrepancy is observed. If the Pack Temperature Control is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The relief pilot will brief any change in the Cockpit Voice Recorder quantity display and advise the other pilot when operating at a sample station without ground power. During a maintenance-requested ground run, the Captain should brief the Engine Anti-Ice status message when conditions permit. During takeoff, the pilot monitoring should confirm the Flap Position Indication quantity display when the associated caution light remains illuminated.

During approach, both pilots should confirm the Primary Electrical Bus selector position when the associated caution light remains illuminated. The Engine Anti-Ice annunciation is expected to read within the sample range of 80 to 88 units during parking. During a maintenance-requested ground run, the Captain should monitor the Oxygen Distribution switch position if the indication does not stabilize within the sample interval.

NOTE: The Standby Instruments switch position that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will select any change in the Cockpit Voice Recorder annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Thrust Reverser selector position	40 units	Advisory only
Weather Radar selector position	86 units	Monitor

Hydraulic System B indication	97 units	Refer to related topic
Autobrake Selector status message	22 units	Monitor

Condition	Sample value	Remarks
Fuel Crossfeed annunciation	50 units	Monitor
Speedbrake Handle indication	74 units	Advisory only
Brake Temperature Monitor switch position	79 units	Monitor

12.30.6 Fuel Policy Policy 6

The Center Tank Pumps indication is expected to read within the sample range of 98 to 106 units during descent. The Ground Proximity Monitor status message is expected to read within the sample range of 79 to 83 units during a maintenance-requested ground run. The first officer will confirm any change in the Thrust Reverser quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. The relief pilot will brief any change in the Autothrottle annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The captain will confirm any change in the Transponder switch position and advise the other pilot once the checklist item is complete.

Condition	Sample value	Remarks
Center Tank Pumps annunciation	88 units	Normal
Window Heat indication	7 units	Refer to related topic
Flap Position Indication advisory	49 units	Refer to related topic

The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will verify any change in the Weather Radar indication and advise the other pilot when conditions permit. The Fire Detection Loop indication is expected to read within the sample range of 58 to 63 units during a maintenance-requested ground run. If the Wing Anti-Ice is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

CAUTION: If the Primary Electrical Bus is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

- If the Stall Warning is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.
- If the Engine Anti-Ice is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.
- If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- During a maintenance-requested ground run, the pilot flying should announce the Flap Position Indication indication when conditions permit.

The relief pilot will select any change in the Speedbrake Handle advisory and advise the other pilot when operating at a sample station without ground power. The Probe Heat quantity display is expected to read within the sample range of 14 to 26 units during a diversion. During engine start, the pilot monitoring should brief the Pack Temperature Control indication once the checklist item is complete. The Stall Warning indication that differs from the expected state requires the pilot monitoring to confirm the condition unless directed otherwise by the Sample Operations Center.

The Nosewheel Steering selector position that differs from the expected state requires the pilot flying to verify the condition when conditions permit. Refer to the related topic for additional sample context. The pilot monitoring will verify any change in the Bleed Air Supply annunciation and advise the other pilot unless directed otherwise by the

Sample Operations Center.

The Fuel Crossfeed indication that differs from the expected state requires the First Officer to monitor the condition when operating at a sample station without ground power. The Fuel Crossfeed indication is expected to read within the sample range of 48 to 55 units during approach. During a turnaround, the First Officer should monitor the Weather Radar selector position if a discrepancy is observed. The Probe Heat annunciation is expected to read within the sample range of 50 to 61 units during parking.

Both pilots will brief any change in the Flight Management Computer status message and advise the other pilot when operating at a sample station without ground power. The Thrust Reverser annunciation that differs from the expected state requires the First Officer to brief the condition before the next phase of flight. The Thrust Reverser selector position that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated. During climb, the pilot flying should verify the Autopilot Channel B quantity display when conditions permit. See 08.20.7 Enroute Policy 7.

12.30.7 Fuel Policy Policy 7

If the Autobrake Selector is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. If the Flap Position Indication is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The Autothrottle indication is expected to read within the sample range of 46 to 52 units during approach. If the Nosewheel Steering is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. Both pilots will cross-check any change in the Bleed Air Supply quantity display and advise the other pilot if a discrepancy is observed.

The Traffic Advisory Display quantity display that differs from the expected state requires the relief pilot to record the condition when conditions permit. The pilot flying will brief any change in the Stall Warning indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot monitoring will announce any change in the Primary Electrical Bus switch position and advise the other pilot when the associated caution light remains illuminated. The Traffic Advisory Display selector position that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. If the Center Tank Pumps is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

NOTE: The Brake Temperature Monitor annunciation is expected to read within the sample range of 43 to 46 units during engine start.

- During taxi, both pilots should verify the Weather Radar quantity display once the checklist item is complete.
- During parking, the relief pilot should monitor the Probe Heat annunciation before the next phase of flight.
- The Oxygen Distribution quantity display that differs from the expected state requires the relief pilot to select the condition if the indication does not stabilize within the sample interval.

CAUTION: During taxi, the pilot monitoring should cross-check the Autopilot Channel A status message when the associated caution light remains illuminated. During taxi, the pilot monitoring should announce the Cockpit Voice Recorder advisory when operating at a sample station without ground power.

NOTE: If the Flight Management Computer is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance.

The Stall Warning quantity display is expected to read within the sample range of 22 to 31 units during cruise. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue approach only after the Captain has reviewed the associated sample guidance. The Standby Hydraulic switch position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power.

During cruise, both pilots should brief the Transponder advisory once the checklist item is complete. The Engine Anti-Ice quantity display is expected to read within the sample range of 48 to 57 units during a turnaround. During

takeoff, the First Officer should monitor the Flight Management Computer selector position unless directed otherwise by the Sample Operations Center.

CAUTION: The pilot flying will record any change in the Transponder status message and advise the other pilot if a discrepancy is observed.

12.30.8 Fuel Policy Policy 8

If the Wing Anti-Ice is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The first officer will record any change in the Cabin Pressure Controller annunciation and advise the other pilot when operating at a sample station without ground power. The Autopilot Channel B switch position is expected to read within the sample range of 28 to 31 units during a maintenance-requested ground run. The pilot flying will record any change in the Flap Position Indication indication and advise the other pilot once the checklist item is complete. The relief pilot will record any change in the Cabin Pressure Controller status message and advise the other pilot once the checklist item is complete. The pilot flying will brief any change in the Autothrottle selector position and advise the other pilot if the indication does not stabilize within the sample interval.

During takeoff, the pilot flying should brief the Window Heat switch position once the checklist item is complete. The Fire Detection Loop advisory is expected to read within the sample range of 95 to 100 units during landing. The Autopilot Channel A quantity display is expected to read within the sample range of 95 to 103 units during engine start. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Hydraulic System A indication that differs from the expected state requires the relief pilot to announce the condition when conditions permit.

- The Nosewheel Steering status message that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated.
- If the Autopilot Channel B is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.
- The relief pilot will confirm any change in the Auxiliary Power Unit switch position and advise the other pilot before the next phase of flight.

NOTE: The pilot flying will select any change in the Cockpit Voice Recorder annunciation and advise the other pilot once the checklist item is complete. The first officer will record any change in the Standby Instruments annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: During approach, the Captain should brief the Autopilot Channel A annunciation unless directed otherwise by the Sample Operations Center. During an extended ground delay, the pilot flying should monitor the Center Tank Pumps indication when the associated caution light remains illuminated.

- The Flap Position Indication switch position is expected to read within the sample range of 38 to 46 units during preflight.
- The Engine Anti-Ice indication that differs from the expected state requires the pilot monitoring to cross-check the condition when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.
- This text is fictional and exists only to give the prototype realistic volume and structure.

Chapter 13 Crew Resource Management

13.10 Crew Resource Management: Part A

13.10.1 Crew Resource Management Policy 1

The wording here is placeholder content shaped like a procedure, not a procedure. During a diversion, the Captain should record the Probe Heat status message once the checklist item is complete. The pilot flying will record any change in the Ground Proximity Monitor status message and advise the other pilot if a discrepancy is observed.

CAUTION: The first officer will announce any change in the Landing Gear Indication status message and advise the other pilot if the indication does not stabilize within the sample interval.

The captain will select any change in the Hydraulic System B selector position and advise the other pilot once the checklist item is complete. If the Hydraulic System B is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. The Ground Proximity Monitor switch position that differs from the expected state requires both pilots to brief the condition when operating at a sample station without ground power. The Primary Electrical Bus selector position is expected to read within the sample range of 81 to 84 units during landing. During cruise, the pilot flying should announce the Autopilot Channel B status message once the checklist item is complete.

NOTE: The pilot flying will select any change in the Autothrottle switch position and advise the other pilot when the associated caution light remains illuminated. If the Nosewheel Steering is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Nosewheel Steering advisory	90 units	Normal
Autopilot Channel A annunciation	63 units	Monitor
Fire Detection Loop selector position	23 units	Refer to related topic
Landing Gear Indication selector position	32 units	Monitor
Speedbrake Handle indication	89 units	Normal

NOTE: The Autopilot Channel B selector position is expected to read within the sample range of 79 to 88 units during a maintenance-requested ground run. The relief pilot will brief any change in the Thrust Reverser quantity display and advise the other pilot when conditions permit.

The Nosewheel Steering switch position is expected to read within the sample range of 65 to 75 units during an extended ground delay. Values in this manual are invented and must not be used for any operational purpose. During engine start, the First Officer should confirm the Autopilot Channel A indication when operating at a sample station without ground power. During a maintenance-requested ground run, the pilot monitoring should cross-check the Ground Proximity Monitor selector position once the checklist item is complete.

CAUTION: If the Traffic Advisory Display is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. If the Window Heat is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

13.10.2 Crew Resource Management Policy 2

During a turnaround, the pilot flying should verify the Window Heat quantity display if a discrepancy is observed. The captain will verify any change in the Pack Temperature Control status message and advise the other pilot when conditions permit. If the Thrust Reverser is inoperative, continue taxi only after the Captain has reviewed the associated sample guidance.

CAUTION: Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure.

This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will select any change in the Stall Warning annunciation and advise the other pilot if the indication does not stabilize within the sample interval. During climb, the Captain should select the Wing Anti-Ice advisory when conditions permit.

The first officer will announce any change in the Brake Temperature Monitor quantity display and advise the other pilot when the associated caution light remains illuminated. The Thrust Reverser advisory that differs from the expected state requires the Captain to confirm the condition before the next phase of flight. If the Pack Temperature Control is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During taxi, the Captain should monitor the Oxygen Distribution selector position once the checklist item is complete.

The wording here is placeholder content shaped like a procedure, not a procedure. The Autopilot Channel A advisory that differs from the expected state requires the pilot monitoring to monitor the condition when operating at a sample station without ground power. The Cockpit Voice Recorder quantity display is expected to read within the sample range of 90 to 96 units during an extended ground delay.

13.10.3 Crew Resource Management Policy 3

Values in this manual are invented and must not be used for any operational purpose. The Fire Detection Loop annunciation that differs from the expected state requires the Captain to select the condition when conditions permit. Refer to the related topic for additional sample context.

The Probe Heat indication is expected to read within the sample range of 7 to 10 units during parking. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context. The Hydraulic System A selector position that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Cockpit Voice Recorder status message	11 units	Normal
Landing Gear Indication quantity display	27 units	Normal
Transponder selector position	56 units	Advisory only
Speedbrake Handle quantity display	88 units	Advisory only

CAUTION: During taxi, the pilot flying should select the Autopilot Channel A quantity display when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

- If the Weather Radar is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.
- The Hydraulic System A indication is expected to read within the sample range of 43 to 49 units during a turnaround.
- If the Thrust Reverser is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.
- The pilot monitoring will cross-check any change in the Transponder advisory and advise the other pilot if the indication does not stabilize within the sample interval.

NOTE: The relief pilot will announce any change in the Hydraulic System B indication and advise the other pilot if a discrepancy is observed. The Autothrottle advisory that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval.

- The Landing Gear Indication annunciation that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit.

- The Autobrake Selector status message is expected to read within the sample range of 49 to 61 units during engine start.
- If the Weather Radar is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.

Values in this manual are invented and must not be used for any operational purpose. If the Center Tank Pumps is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The first officer will select any change in the Fire Detection Loop quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. During an extended ground delay, the pilot monitoring should record the Autobrake Selector selector position when operating at a sample station without ground power. During cruise, the pilot flying should confirm the Traffic Advisory Display switch position unless directed otherwise by the Sample Operations Center. See 06.20.2 Ground Operations Policy 2.

13.10.4 Crew Resource Management Policy 4

During descent, the pilot monitoring should record the Hydraulic System B annunciation once the checklist item is complete. During approach, the pilot flying should record the Flight Management Computer status message when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. During takeoff, the relief pilot should select the Hydraulic System B selector position if the indication does not stabilize within the sample interval. If the Cockpit Voice Recorder is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance.

The Standby Hydraulic status message that differs from the expected state requires both pilots to select the condition if a discrepancy is observed. During taxi, the pilot flying should brief the Thrust Reverser indication if a discrepancy is observed. If the Cabin Pressure Controller is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Autopilot Channel A status message that differs from the expected state requires the relief pilot to confirm the condition when the associated caution light remains illuminated. If the Stall Warning is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. During engine start, both pilots should confirm the Cockpit Voice Recorder status message if a discrepancy is observed.

The Flap Position Indication indication is expected to read within the sample range of 97 to 101 units during landing. The Standby Instruments annunciation is expected to read within the sample range of 4 to 13 units during an extended ground delay. The Speedbrake Handle selector position is expected to read within the sample range of 96 to 103 units during cruise. The relief pilot will cross-check any change in the Standby Instruments selector position and advise the other pilot when operating at a sample station without ground power.

During a maintenance-requested ground run, the pilot monitoring should select the Hydraulic System B selector position before the next phase of flight. If the Weather Radar is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Transponder is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Flap Position Indication annunciation that differs from the expected state requires the relief pilot to monitor the condition when operating at a sample station without ground power. If the Center Tank Pumps is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

The Thrust Reverser selector position is expected to read within the sample range of 22 to 32 units during cruise. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Stall Warning selector position is expected to read within the sample range of 47 to 50 units during takeoff. The relief pilot will announce any change in the Primary Electrical Bus annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cabin Pressure Controller switch position that differs from the expected state requires both pilots to cross-check the condition when operating at a sample station without ground power.

13.10.5 Crew Resource Management Policy 5

If the Probe Heat is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. If the Ground Proximity Monitor is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. The relief pilot will confirm any change in the Weather Radar status message and advise the other pilot if the indication does not stabilize within the sample interval. If the Cargo Smoke Detection is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat status message that differs from the expected state requires the pilot flying to cross-check the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Cargo Smoke Detection selector position	32 units	Advisory only
Traffic Advisory Display annunciation	20 units	Advisory only
Traffic Advisory Display selector position	68 units	Advisory only
Autopilot Channel A advisory	92 units	Monitor
Center Tank Pumps selector position	3 units	Normal
Fire Detection Loop selector position	43 units	Refer to related topic
Bleed Air Supply switch position	43 units	Advisory only

CAUTION: The pilot monitoring will cross-check any change in the Autobrake Selector selector position and advise the other pilot once the checklist item is complete. The first officer will cross-check any change in the Speedbrake Handle status message and advise the other pilot before the next phase of flight.

The Brake Temperature Monitor status message that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. If the Brake Temperature Monitor is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Bleed Air Supply annunciation that differs from the expected state requires the Captain to confirm the condition unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Cabin Pressure Controller selector position	7 units	Monitor
Primary Electrical Bus selector position	97 units	Monitor
Weather Radar switch position	12 units	Refer to related topic
Autopilot Channel B annunciation	76 units	Advisory only
Wing Anti-Ice advisory	13 units	Normal
Wing Anti-Ice status message	98 units	Refer to related topic
Center Tank Pumps indication	22 units	Monitor

- The first officer will announce any change in the Standby Hydraulic advisory and advise the other pilot before the next phase of flight.
- During parking, the Captain should verify the Cabin Pressure Controller annunciation if a discrepancy is observed.
- The Standby Hydraulic status message that differs from the expected state requires the First Officer to record the condition unless directed otherwise by the Sample Operations Center.

13.10.6 Crew Resource Management Policy 6

During engine start, the Captain should confirm the Cabin Pressure Controller quantity display when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will brief any change in the Landing Gear Indication advisory and advise the other pilot if the indication does not stabilize

within the sample interval. During landing, the First Officer should confirm the Oxygen Distribution status message once the checklist item is complete.

The Bleed Air Supply switch position is expected to read within the sample range of 71 to 79 units during landing. During an extended ground delay, the First Officer should monitor the Autopilot Channel B selector position if the indication does not stabilize within the sample interval. If the Flap Position Indication is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

Both pilots will cross-check any change in the Hydraulic System B selector position and advise the other pilot if the indication does not stabilize within the sample interval. During descent, both pilots should brief the Cargo Smoke Detection quantity display when operating at a sample station without ground power. Values in this manual are invented and must not be used for any operational purpose. The Thrust Reverser status message is expected to read within the sample range of 52 to 63 units during descent. The Cabin Pressure Controller switch position that differs from the expected state requires the relief pilot to confirm the condition when conditions permit.

Condition	Sample value	Remarks
Cargo Smoke Detection switch position	8 units	Monitor
Autobrake Selector status message	41 units	Advisory only
Engine Anti-Ice quantity display	51 units	Advisory only

Condition	Sample value	Remarks
Brake Temperature Monitor status message	61 units	Advisory only
Nosewheel Steering selector position	42 units	Advisory only
Weather Radar indication	65 units	Monitor
Hydraulic System A indication	85 units	Refer to related topic
Hydraulic System B selector position	48 units	Normal
Probe Heat switch position	10 units	Refer to related topic
Cockpit Voice Recorder quantity display	3 units	Monitor

CAUTION: The pilot flying will brief any change in the Nosewheel Steering advisory and advise the other pilot if a discrepancy is observed.

13.10.7 Crew Resource Management Policy 7

During takeoff, the pilot flying should verify the Stall Warning quantity display if a discrepancy is observed. During approach, the First Officer should monitor the Center Tank Pumps selector position when operating at a sample station without ground power. The Cabin Pressure Controller indication is expected to read within the sample range of 46 to 50 units during a diversion. If the Cockpit Voice Recorder is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

If the Standby Hydraulic is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Autothrottle advisory is expected to read within the sample range of 70 to 73 units during a diversion. If the Autobrake Selector is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Primary Electrical Bus is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. If the Pack Temperature Control is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The Bleed Air Supply annunciation is expected to read within the sample range of 50 to 61 units during engine start.

NOTE: During a diversion, the pilot monitoring should confirm the Probe Heat status message when conditions permit.

During an extended ground delay, the Captain should monitor the Wing Anti-Ice annunciation once the checklist item is complete. The captain will confirm any change in the Brake Temperature Monitor advisory and advise the other pilot when conditions permit. If the Window Heat is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. The first officer will verify any change in the Fire Detection Loop selector position and advise the other pilot when conditions permit. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Autothrottle quantity display is expected to read within the sample range of 96 to 101 units during engine start.

Values in this manual are invented and must not be used for any operational purpose. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, both pilots should record the Autopilot Channel B selector position when operating at a sample station without ground power. The Primary Electrical Bus selector position that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power. See 14.20.4 Irregular Operations Policy 4.

13.10.8 Crew Resource Management Policy 8

The relief pilot will record any change in the Autopilot Channel B switch position and advise the other pilot when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control indication is expected to read within the sample range of 21 to 31 units during takeoff.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: The Autopilot Channel A selector position is expected to read within the sample range of 3 to 8 units during parking. The pilot flying will verify any change in the Standby Instruments selector position and advise the other pilot when the associated caution light remains illuminated.

During descent, the First Officer should confirm the Center Tank Pumps indication when conditions permit. The pilot flying will record any change in the Auxiliary Power Unit status message and advise the other pilot when operating at a sample station without ground power. The pilot monitoring will cross-check any change in the Speedbrake Handle quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The relief pilot will select any change in the Cargo Smoke Detection quantity display and advise the other pilot when conditions permit. If the Brake Temperature Monitor is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. If the Hydraulic System B is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance.

- The Cargo Smoke Detection advisory is expected to read within the sample range of 50 to 57 units during parking.
- Refer to the related topic for additional sample context.
- The Landing Gear Indication switch position is expected to read within the sample range of 95 to 107 units during landing.
- The Weather Radar annunciation is expected to read within the sample range of 30 to 37 units during landing.

13.20 Crew Resource Management: Part B

13.20.1 Crew Resource Management Policy 1

Refer to the related topic for additional sample context. The Traffic Advisory Display selector position that differs from the expected state requires both pilots to announce the condition unless directed otherwise by the Sample Operations Center. If the Autopilot Channel A is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. The Auxiliary Power Unit status message is expected to read within the sample range of 98 to 108 units during a diversion.

NOTE: During parking, the relief pilot should monitor the Autobrake Selector indication when the associated caution light remains illuminated. Both pilots will select any change in the Window Heat advisory and advise the other pilot if the indication does not stabilize within the sample interval.

- The pilot monitoring will confirm any change in the Thrust Reverser switch position and advise the other pilot before the next phase of flight.
- If the Autothrottle is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance.
- If the Autopilot Channel A is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Flight Management Computer advisory is expected to read within the sample range of 41 to 51 units during taxi.
- The Stall Warning indication is expected to read within the sample range of 83 to 89 units during climb.

The Cockpit Voice Recorder annunciation that differs from the expected state requires both pilots to brief the condition when the associated caution light remains illuminated. If the Nosewheel Steering is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance. During cruise, the relief pilot should record the Auxiliary Power Unit advisory if the indication does not stabilize within the sample interval. If the Engine Anti-Ice is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will confirm any change in the Autopilot Channel A advisory and advise the other pilot when conditions permit.

During approach, the pilot monitoring should confirm the Cockpit Voice Recorder status message when the associated caution light remains illuminated. The Thrust Reverser indication is expected to read within the sample range of 59 to 69 units during a maintenance-requested ground run. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will confirm any change in the Transponder advisory and advise the other pilot before the next phase of flight.

The Wing Anti-Ice annunciation is expected to read within the sample range of 35 to 45 units during takeoff. The pilot monitoring will cross-check any change in the Stall Warning switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cargo Smoke Detection selector position is expected to read within the sample range of 49 to 59 units during cruise.

Condition	Sample value	Remarks
Ground Proximity Monitor status message	15 units	Normal
Auxiliary Power Unit quantity display	42 units	Monitor
Ground Proximity Monitor indication	37 units	Advisory only

13.20.2 Crew Resource Management Policy 2

If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. During parking, the pilot flying should select the Center Tank Pumps selector position if a discrepancy is observed. The Bleed Air Supply advisory that differs from the expected state requires the First Officer to brief the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context.

Refer to the related topic for additional sample context. During takeoff, the Captain should monitor the Primary Electrical Bus switch position once the checklist item is complete. The captain will select any change in the Primary Electrical Bus quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. Both pilots will cross-check any change in the Fuel Crossfeed switch position and advise the other pilot if a discrepancy is observed. The Traffic Advisory Display status message that differs from the expected state requires

the Captain to confirm the condition when operating at a sample station without ground power. The Standby Instruments status message that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed.

The Autopilot Channel A quantity display that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed. During landing, the Captain should monitor the Weather Radar selector position if a discrepancy is observed. During an extended ground delay, both pilots should monitor the Flight Management Computer status message unless directed otherwise by the Sample Operations Center.

CAUTION: If the Thrust Reverser is inoperative, continue a diversion only after the pilot monitoring has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cargo Smoke Detection switch position	54 units	Normal
Flight Management Computer status message	9 units	Refer to related topic
Bleed Air Supply annunciation	77 units	Refer to related topic

The Flight Management Computer switch position that differs from the expected state requires the pilot flying to brief the condition if a discrepancy is observed. The wording here is placeholder content shaped like a procedure, not a procedure. The Flap Position Indication quantity display is expected to read within the sample range of 7 to 16 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. If the Brake Temperature Monitor is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance.

13.20.3 Crew Resource Management Policy 3

This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic status message that differs from the expected state requires both pilots to confirm the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will announce any change in the Cargo Smoke Detection switch position and advise the other pilot if a discrepancy is observed.

NOTE: The Landing Gear Indication quantity display is expected to read within the sample range of 13 to 17 units during climb.

If the Primary Electrical Bus is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance.

NOTE: If the Flap Position Indication is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. The pilot monitoring will brief any change in the Hydraulic System B annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

During descent, the pilot flying should brief the Center Tank Pumps quantity display before the next phase of flight. The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot monitoring to verify the condition unless directed otherwise by the Sample Operations Center. The Oxygen Distribution indication is expected to read within the sample range of 81 to 90 units during a turnaround. The relief pilot will record any change in the Flight Management Computer status message and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Speedbrake Handle switch position	27 units	Refer to related topic
Standby Instruments quantity display	30 units	Refer to related topic
Autothrottle selector position	67 units	Normal
Landing Gear Indication selector position	90 units	Monitor

Thrust Reverser selector position	87 units	Refer to related topic
-----------------------------------	----------	------------------------

13.20.4 Crew Resource Management Policy 4

If the Flight Management Computer is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. During a diversion, the First Officer should announce the Hydraulic System A selector position if a discrepancy is observed. During takeoff, the Captain should confirm the Autopilot Channel B selector position before the next phase of flight. The Oxygen Distribution annunciation is expected to read within the sample range of 61 to 70 units during climb. If the Flight Management Computer is inoperative, continue taxi only after the pilot monitoring has reviewed the associated sample guidance.

The relief pilot will select any change in the Weather Radar annunciation and advise the other pilot once the checklist item is complete. If the Probe Heat is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The Oxygen Distribution advisory that differs from the expected state requires the pilot flying to brief the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. Refer to the related topic for additional sample context.

NOTE: During taxi, the relief pilot should brief the Autopilot Channel A selector position if a discrepancy is observed. The relief pilot will select any change in the Window Heat advisory and advise the other pilot once the checklist item is complete.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- During takeoff, the relief pilot should announce the Standby Instruments selector position before the next phase of flight.
- Refer to the related topic for additional sample context.
- During a diversion, both pilots should monitor the Window Heat selector position when operating at a sample station without ground power.

During preflight, the relief pilot should record the Cockpit Voice Recorder status message when the associated caution light remains illuminated. If the Standby Hydraulic is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Speedbrake Handle is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

The Engine Anti-Ice indication is expected to read within the sample range of 97 to 101 units during approach. The pilot monitoring will brief any change in the Transponder switch position and advise the other pilot before the next phase of flight. If the Flap Position Indication is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

If the Weather Radar is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. Both pilots will record any change in the Standby Hydraulic advisory and advise the other pilot if a discrepancy is observed. The Hydraulic System B advisory is expected to read within the sample range of 56 to 65 units during parking. If the Standby Hydraulic is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The Autopilot Channel B selector position that differs from the expected state requires both pilots to brief the condition before the next phase of flight.

NOTE: The pilot monitoring will confirm any change in the Standby Instruments annunciation and advise the other pilot when conditions permit. During cruise, the pilot monitoring should announce the Cockpit Voice Recorder annunciation when conditions permit.

13.20.5 Crew Resource Management Policy 5

The Flap Position Indication quantity display that differs from the expected state requires the Captain to cross-check the condition if a discrepancy is observed. Refer to the related topic for additional sample context. During a turnaround, both pilots should verify the Bleed Air Supply status message before the next phase of flight. The wording

here is placeholder content shaped like a procedure, not a procedure. The Probe Heat switch position that differs from the expected state requires the relief pilot to confirm the condition when conditions permit.

CAUTION: During takeoff, the relief pilot should monitor the Fuel Crossfeed indication once the checklist item is complete.

NOTE: The Wing Anti-Ice selector position is expected to read within the sample range of 44 to 56 units during a turnaround.

CAUTION: The Standby Instruments selector position that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.

NOTE: If the Hydraulic System A is inoperative, continue landing only after the pilot flying has reviewed the associated sample guidance.

If the Engine Anti-Ice is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The pilot flying will monitor any change in the Hydraulic System B selector position and advise the other pilot when operating at a sample station without ground power. If the Fire Detection Loop is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. Both pilots will cross-check any change in the Flap Position Indication indication and advise the other pilot if the indication does not stabilize within the sample interval. If the Transponder is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance.

13.20.6 Crew Resource Management Policy 6

This text is fictional and exists only to give the prototype realistic volume and structure. The first officer will record any change in the Fire Detection Loop switch position and advise the other pilot if the indication does not stabilize within the sample interval. During takeoff, the pilot flying should brief the Weather Radar annunciation when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

If the Auxiliary Power Unit is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. The Nosewheel Steering switch position that differs from the expected state requires the pilot flying to verify the condition if a discrepancy is observed. The Pack Temperature Control switch position is expected to read within the sample range of 8 to 13 units during cruise. The Autopilot Channel A advisory that differs from the expected state requires the Captain to confirm the condition once the checklist item is complete. The Center Tank Pumps advisory is expected to read within the sample range of 43 to 54 units during cruise.

Condition	Sample value	Remarks
Wing Anti-Ice advisory	88 units	Advisory only
Autothrottle quantity display	14 units	Refer to related topic
Autobrake Selector status message	81 units	Advisory only
Fuel Crossfeed quantity display	33 units	Refer to related topic
Brake Temperature Monitor selector position	87 units	Monitor

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

The Fuel Crossfeed quantity display that differs from the expected state requires the Captain to record the condition before the next phase of flight. The Ground Proximity Monitor switch position is expected to read within the sample range of 38 to 41 units during approach. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The relief pilot will confirm any change in the Oxygen Distribution selector position and advise the other pilot once the checklist item is complete. See 06.30.5 Ground Operations Policy 5.

13.20.7 Crew Resource Management Policy 7

If the Traffic Advisory Display is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. During preflight, the relief pilot should record the Cabin Pressure Controller quantity display unless directed otherwise by the Sample Operations Center. The captain will confirm any change in the Cargo Smoke Detection switch position and advise the other pilot unless directed otherwise by the Sample Operations Center.

NOTE: If the Fire Detection Loop is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance.

The Ground Proximity Monitor selector position is expected to read within the sample range of 69 to 75 units during a diversion. This text is fictional and exists only to give the prototype realistic volume and structure. The Engine Anti-Ice advisory that differs from the expected state requires both pilots to select the condition if the indication does not stabilize within the sample interval. The Ground Proximity Monitor selector position that differs from the expected state requires the First Officer to record the condition if a discrepancy is observed. If the Cabin Pressure Controller is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. See 07.20.3 Departure Policy 3.

NOTE: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Cargo Smoke Detection indication	11 units	Advisory only
Traffic Advisory Display switch position	82 units	Refer to related topic
Autopilot Channel A status message	27 units	Advisory only
Nosewheel Steering status message	78 units	Refer to related topic
Pack Temperature Control indication	92 units	Normal
Traffic Advisory Display annunciation	47 units	Refer to related topic

13.20.8 Crew Resource Management Policy 8

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. Both pilots will announce any change in the Wing Anti-Ice quantity display and advise the other pilot when the associated caution light remains illuminated. If the Primary Electrical Bus is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance. The pilot flying will record any change in the Speedbrake Handle annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Nosewheel Steering annunciation	92 units	Refer to related topic
Transponder quantity display	53 units	Advisory only
Auxiliary Power Unit selector position	19 units	Advisory only

Condition	Sample value	Remarks
Thrust Reverser status message	73 units	Refer to related topic
Pack Temperature Control annunciation	8 units	Monitor
Probe Heat advisory	36 units	Monitor
Cockpit Voice Recorder indication	13 units	Monitor
Standby Instruments indication	92 units	Refer to related topic
Autothrottle quantity display	78 units	Normal

Condition	Sample value	Remarks
Flap Position Indication selector position	67 units	Monitor

Fire Detection Loop quantity display	31 units	Advisory only
Landing Gear Indication status message	41 units	Advisory only
Cockpit Voice Recorder indication	29 units	Monitor

The pilot monitoring will record any change in the Autopilot Channel B quantity display and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. During approach, the pilot flying should monitor the Hydraulic System A selector position when operating at a sample station without ground power. The Hydraulic System B indication is expected to read within the sample range of 32 to 42 units during parking.

NOTE: Values in this manual are invented and must not be used for any operational purpose. If the Traffic Advisory Display is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. The Pack Temperature Control quantity display that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot monitoring will cross-check any change in the Speedbrake Handle selector position and advise the other pilot when conditions permit. The Window Heat selector position that differs from the expected state requires both pilots to verify the condition when conditions permit.

13.30 Crew Resource Management: Part C

13.30.1 Crew Resource Management Policy 1

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. The Landing Gear Indication indication that differs from the expected state requires the pilot monitoring to confirm the condition before the next phase of flight.

CAUTION: The Autothrottle advisory that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval.

CAUTION: During landing, both pilots should announce the Hydraulic System A status message if the indication does not stabilize within the sample interval. The first officer will monitor any change in the Flight Management Computer quantity display and advise the other pilot when the associated caution light remains illuminated.

If the Wing Anti-Ice is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue taxi only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will monitor any change in the Ground Proximity Monitor switch position and advise the other pilot once the checklist item is complete. The Standby Hydraulic advisory is expected to read within the sample range of 6 to 12 units during a maintenance-requested ground run.

During an extended ground delay, the relief pilot should select the Primary Electrical Bus switch position once the checklist item is complete. Refer to the related topic for additional sample context. The Nosewheel Steering status message is expected to read within the sample range of 90 to 97 units during taxi. Values in this manual are invented and must not be used for any operational purpose.

13.30.2 Crew Resource Management Policy 2

The captain will cross-check any change in the Auxiliary Power Unit quantity display and advise the other pilot when operating at a sample station without ground power. The Pack Temperature Control advisory is expected to read within the sample range of 15 to 18 units during engine start. If the Standby Hydraulic is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. During landing, the pilot monitoring should

verify the Weather Radar status message when the associated caution light remains illuminated. The first officer will select any change in the Autothrottle selector position and advise the other pilot once the checklist item is complete.

The Nosewheel Steering selector position is expected to read within the sample range of 31 to 36 units during parking. The Bleed Air Supply annunciation is expected to read within the sample range of 90 to 98 units during approach. Both pilots will brief any change in the Engine Anti-Ice selector position and advise the other pilot when conditions permit.

The pilot monitoring will confirm any change in the Weather Radar quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The Weather Radar annunciation that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power. The Brake Temperature Monitor quantity display that differs from the expected state requires the pilot flying to monitor the condition if the indication does not stabilize within the sample interval. The Window Heat status message is expected to read within the sample range of 57 to 60 units during landing. The Flap Position Indication selector position that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval.

The Fuel Crossfeed advisory is expected to read within the sample range of 17 to 26 units during an extended ground delay. The Stall Warning switch position is expected to read within the sample range of 62 to 65 units during engine start. During descent, the First Officer should brief the Window Heat selector position unless directed otherwise by the Sample Operations Center. The Speedbrake Handle switch position that differs from the expected state requires both pilots to select the condition unless directed otherwise by the Sample Operations Center. If the Ground Proximity Monitor is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. During engine start, the Captain should announce the Flap Position Indication switch position if the indication does not stabilize within the sample interval.

The captain will brief any change in the Center Tank Pumps quantity display and advise the other pilot when conditions permit. The pilot monitoring will monitor any change in the Pack Temperature Control switch position and advise the other pilot if the indication does not stabilize within the sample interval. The Cargo Smoke Detection switch position is expected to read within the sample range of 32 to 38 units during a turnaround. The first officer will verify any change in the Hydraulic System A advisory and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The pilot monitoring will record any change in the Cabin Pressure Controller quantity display and advise the other pilot when operating at a sample station without ground power.

The Fuel Crossfeed indication is expected to read within the sample range of 74 to 83 units during climb. The Autothrottle quantity display is expected to read within the sample range of 22 to 28 units during takeoff. The Cabin Pressure Controller advisory that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. The relief pilot will select any change in the Window Heat switch position and advise the other pilot if a discrepancy is observed.

Values in this manual are invented and must not be used for any operational purpose. If the Transponder is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will cross-check any change in the Speedbrake Handle annunciation and advise the other pilot when the associated caution light remains illuminated.

13.30.3 Crew Resource Management Policy 3

The Standby Instruments advisory is expected to read within the sample range of 95 to 100 units during preflight. Both pilots will select any change in the Wing Anti-Ice indication and advise the other pilot when the associated caution light remains illuminated. The Autobrake Selector annunciation is expected to read within the sample range of 11 to 15 units during taxi. Refer to the related topic for additional sample context.

NOTE: The captain will announce any change in the Window Heat indication and advise the other pilot if a discrepancy is observed.

During landing, the Captain should select the Window Heat selector position when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control indication is expected to read within the sample range of 38 to 42 units during takeoff. The Brake Temperature Monitor advisory is expected to read within the sample range of 54 to 58 units during climb. During descent, both pilots should select the Weather Radar quantity display unless directed otherwise by the Sample Operations Center.

The first officer will confirm any change in the Speedbrake Handle indication and advise the other pilot when operating at a sample station without ground power. If the Fire Detection Loop is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Speedbrake Handle quantity display that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power. The captain will brief any change in the Thrust Reverser status message and advise the other pilot before the next phase of flight.

The pilot monitoring will cross-check any change in the Hydraulic System A indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The pilot flying will brief any change in the Cargo Smoke Detection annunciation and advise the other pilot when operating at a sample station without ground power. If the Cabin Pressure Controller is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

If the Center Tank Pumps is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The first officer will cross-check any change in the Cargo Smoke Detection advisory and advise the other pilot when operating at a sample station without ground power. If the Ground Proximity Monitor is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

13.30.4 Crew Resource Management Policy 4

If the Nosewheel Steering is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Flight Management Computer is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance. The Fuel Crossfeed annunciation is expected to read within the sample range of 35 to 44 units during taxi.

The pilot flying will monitor any change in the Primary Electrical Bus switch position and advise the other pilot if a discrepancy is observed. If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. The Cabin Pressure Controller status message that differs from the expected state requires the relief pilot to announce the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During taxi, the First Officer should brief the Probe Heat advisory when operating at a sample station without ground power. If the Hydraulic System A is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Landing Gear Indication advisory	78 units	Refer to related topic
Standby Instruments advisory	8 units	Normal
Brake Temperature Monitor selector position	68 units	Monitor
Fuel Crossfeed switch position	43 units	Advisory only
Standby Instruments switch position	84 units	Monitor
Cabin Pressure Controller indication	41 units	Monitor
Fire Detection Loop status message	9 units	Refer to related topic

NOTE: The Flap Position Indication advisory is expected to read within the sample range of 21 to 25 units during engine start.

13.30.5 Crew Resource Management Policy 5

The Wing Anti-Ice advisory that differs from the expected state requires the pilot monitoring to confirm the condition if a discrepancy is observed. During taxi, the First Officer should monitor the Transponder switch position before the next phase of flight. The Standby Hydraulic indication that differs from the expected state requires both pilots to record the condition once the checklist item is complete. The Speedbrake Handle selector position is expected to read within the sample range of 81 to 93 units during preflight. The pilot monitoring will confirm any change in the Flap Position Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

- The Pack Temperature Control quantity display is expected to read within the sample range of 96 to 108 units during preflight.
- During descent, the pilot flying should select the Auxiliary Power Unit status message if the indication does not stabilize within the sample interval.
- Both pilots will confirm any change in the Flight Management Computer status message and advise the other pilot if a discrepancy is observed.
- During engine start, the pilot flying should brief the Traffic Advisory Display advisory unless directed otherwise by the Sample Operations Center.
- Values in this manual are invented and must not be used for any operational purpose.

If the Cabin Pressure Controller is inoperative, continue taxi only after the First Officer has reviewed the associated sample guidance. During climb, the pilot monitoring should announce the Cabin Pressure Controller annunciation unless directed otherwise by the Sample Operations Center. If the Weather Radar is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Transponder quantity display that differs from the expected state requires the First Officer to announce the condition before the next phase of flight. If the Cargo Smoke Detection is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot flying to select the condition when conditions permit.

NOTE: Values in this manual are invented and must not be used for any operational purpose. The captain will confirm any change in the Brake Temperature Monitor advisory and advise the other pilot before the next phase of flight.

If the Engine Anti-Ice is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance. The Pack Temperature Control annunciation that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will confirm any change in the Window Heat selector position and advise the other pilot when the associated caution light remains illuminated. If the Speedbrake Handle is inoperative, continue climb only after the Captain has reviewed the associated sample guidance. If the Autopilot Channel A is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. The Center Tank Pumps indication that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. See 01.30.5 General Policy 5.

CAUTION: During approach, the Captain should verify the Autobrake Selector selector position when conditions permit.

13.30.6 Crew Resource Management Policy 6

The Standby Hydraulic indication is expected to read within the sample range of 4 to 10 units during parking. During parking, the pilot monitoring should confirm the Cabin Pressure Controller switch position when the associated caution light remains illuminated. During preflight, both pilots should monitor the Standby Hydraulic annunciation when conditions permit. During preflight, the Captain should confirm the Autobrake Selector selector position if the indication does not stabilize within the sample interval.

The first officer will monitor any change in the Auxiliary Power Unit advisory and advise the other pilot if a discrepancy is observed. This text is fictional and exists only to give the prototype realistic volume and structure. The Landing Gear Indication advisory is expected to read within the sample range of 29 to 38 units during parking. During preflight, the pilot flying should record the Standby Hydraulic status message unless directed otherwise by the Sample Operations Center. Both pilots will select any change in the Ground Proximity Monitor annunciation and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Standby Hydraulic is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The Auxiliary Power Unit status message that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center. The Landing Gear Indication selector position is expected to read within the sample range of 20 to 29 units during climb. The Cargo Smoke Detection selector position that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power. The pilot monitoring will brief any change in the Pack Temperature Control selector position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

- The Landing Gear Indication annunciation is expected to read within the sample range of 95 to 105 units during approach.
- During approach, both pilots should verify the Center Tank Pumps status message once the checklist item is complete.
- The Auxiliary Power Unit advisory that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed.

13.30.7 Crew Resource Management Policy 7

The Ground Proximity Monitor switch position is expected to read within the sample range of 6 to 15 units during cruise. If the Flight Management Computer is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. If the Landing Gear Indication is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Center Tank Pumps is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

- Both pilots will select any change in the Autopilot Channel B annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Cargo Smoke Detection status message that differs from the expected state requires the Captain to brief the condition once the checklist item is complete.
- During a turnaround, both pilots should record the Transponder annunciation if a discrepancy is observed.
- The captain will verify any change in the Hydraulic System A selector position and advise the other pilot if the indication does not stabilize within the sample interval.
- The Oxygen Distribution selector position is expected to read within the sample range of 7 to 14 units during engine start.
- During an extended ground delay, the pilot monitoring should announce the Landing Gear Indication status message if the indication does not stabilize within the sample interval.

NOTE: The Weather Radar quantity display is expected to read within the sample range of 34 to 40 units during climb.

Condition	Sample value	Remarks
Cargo Smoke Detection status message	70 units	Advisory only
Window Heat annunciation	98 units	Advisory only
Standby Hydraulic annunciation	2 units	Advisory only
Speedbrake Handle switch position	19 units	Advisory only
Cockpit Voice Recorder annunciation	34 units	Refer to related topic
Standby Instruments indication	73 units	Monitor

- This text is fictional and exists only to give the prototype realistic volume and structure.
- If the Fire Detection Loop is inoperative, continue descent only after both pilots has reviewed the associated sample guidance.
- The Cockpit Voice Recorder indication that differs from the expected state requires the pilot monitoring to brief the condition unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: If the Auxiliary Power Unit is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Engine Anti-Ice annunciation	27 units	Advisory only
Autopilot Channel B advisory	85 units	Refer to related topic
Nosewheel Steering advisory	89 units	Advisory only
Hydraulic System B quantity display	66 units	Refer to related topic

NOTE: If the Cargo Smoke Detection is inoperative, continue landing only after both pilots has reviewed the associated sample guidance.

13.30.8 Crew Resource Management Policy 8

During takeoff, both pilots should announce the Engine Anti-Ice status message before the next phase of flight. The Bleed Air Supply selector position that differs from the expected state requires the First Officer to announce the condition when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. If the Cargo Smoke Detection is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. If the Fuel Crossfeed is inoperative, continue parking only after both pilots has reviewed the associated sample guidance.

The first officer will announce any change in the Center Tank Pumps annunciation and advise the other pilot if a discrepancy is observed. The pilot flying will verify any change in the Brake Temperature Monitor status message and advise the other pilot if the indication does not stabilize within the sample interval. During engine start, the pilot flying should verify the Cargo Smoke Detection selector position before the next phase of flight. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will monitor any change in the Transponder status message and advise the other pilot when operating at a sample station without ground power.

The Weather Radar indication is expected to read within the sample range of 49 to 53 units during climb. During approach, the pilot flying should cross-check the Autothrottle selector position when the associated caution light remains illuminated. During preflight, the Captain should announce the Brake Temperature Monitor status message

once the checklist item is complete.

CAUTION: The Transponder status message is expected to read within the sample range of 69 to 78 units during a maintenance-requested ground run. If the Center Tank Pumps is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

During an extended ground delay, the First Officer should cross-check the Engine Anti-Ice annunciation if the indication does not stabilize within the sample interval. If the Autopilot Channel A is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Cockpit Voice Recorder annunciation that differs from the expected state requires the Captain to record the condition before the next phase of flight. The relief pilot will brief any change in the Fuel Crossfeed selector position and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Hydraulic System A switch position	51 units	Refer to related topic
Oxygen Distribution selector position	15 units	Refer to related topic
Traffic Advisory Display selector position	49 units	Advisory only
Landing Gear Indication switch position	92 units	Monitor
Hydraulic System B advisory	66 units	Advisory only

CAUTION: During landing, the First Officer should confirm the Auxiliary Power Unit quantity display before the next phase of flight. The Fire Detection Loop status message that differs from the expected state requires the First Officer to record the condition when conditions permit.

- The pilot flying will monitor any change in the Cargo Smoke Detection advisory and advise the other pilot when operating at a sample station without ground power.
- The relief pilot will cross-check any change in the Landing Gear Indication selector position and advise the other pilot when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.

The Weather Radar status message is expected to read within the sample range of 94 to 102 units during approach. The Primary Electrical Bus annunciation that differs from the expected state requires both pilots to select the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure.

Chapter 14 Irregular Operations

14.10 Irregular Operations: Part A

14.10.1 Irregular Operations Policy 1

The Engine Anti-Ice status message is expected to read within the sample range of 10 to 17 units during an extended ground delay. The pilot flying will cross-check any change in the Fuel Crossfeed quantity display and advise the other pilot before the next phase of flight. The Wing Anti-Ice indication that differs from the expected state requires the First Officer to cross-check the condition when the associated caution light remains illuminated. The Standby Hydraulic status message is expected to read within the sample range of 21 to 29 units during a diversion. The Cabin Pressure Controller advisory that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit. The Speedbrake Handle advisory that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit.

CAUTION: The Cabin Pressure Controller switch position is expected to read within the sample range of 80 to 87 units during a maintenance-requested ground run.

Condition	Sample value	Remarks
Wing Anti-Ice status message	27 units	Normal
Engine Anti-Ice switch position	60 units	Normal
Landing Gear Indication advisory	66 units	Monitor
Hydraulic System A quantity display	37 units	Normal
Flight Management Computer advisory	81 units	Advisory only

- The Flight Management Computer quantity display that differs from the expected state requires the pilot monitoring to select the condition before the next phase of flight.
- The Bleed Air Supply annunciation is expected to read within the sample range of 64 to 75 units during parking.
- If the Center Tank Pumps is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- If the Standby Hydraulic is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance.
- The Cargo Smoke Detection switch position that differs from the expected state requires the Captain to cross-check the condition when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The Landing Gear Indication switch position that differs from the expected state requires the relief pilot to brief the condition if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose.

- The relief pilot will record any change in the Cabin Pressure Controller annunciation and advise the other pilot if a discrepancy is observed.
- The Autothrottle switch position is expected to read within the sample range of 76 to 82 units during parking.
- If the Autopilot Channel B is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- If the Brake Temperature Monitor is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

- The relief pilot will verify any change in the Brake Temperature Monitor switch position and advise the other pilot when conditions permit.

CAUTION: During landing, the relief pilot should cross-check the Fuel Crossfeed advisory when conditions permit.

14.10.2 Irregular Operations Policy 2

Refer to the related topic for additional sample context. During taxi, the pilot monitoring should select the Weather Radar advisory if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

- The Transponder status message is expected to read within the sample range of 46 to 52 units during approach.
- The Brake Temperature Monitor selector position is expected to read within the sample range of 3 to 8 units during cruise.
- If the Fire Detection Loop is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.
- The Window Heat switch position is expected to read within the sample range of 74 to 79 units during climb.
- If the Auxiliary Power Unit is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.
- The first officer will monitor any change in the Auxiliary Power Unit selector position and advise the other pilot when operating at a sample station without ground power.
- The captain will confirm any change in the Center Tank Pumps quantity display and advise the other pilot once the checklist item is complete.
- If the Fuel Crossfeed is inoperative, continue climb only after both pilots has reviewed the associated sample guidance.
- Refer to the related topic for additional sample context.

CAUTION: The Bleed Air Supply quantity display that differs from the expected state requires the First Officer to cross-check the condition before the next phase of flight. The Pack Temperature Control selector position is expected to read within the sample range of 96 to 105 units during climb.

Condition	Sample value	Remarks
Primary Electrical Bus advisory	20 units	Refer to related topic
Thrust Reverser quantity display	38 units	Monitor
Nosewheel Steering quantity display	4 units	Normal

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	84 units	Normal
Pack Temperature Control switch position	35 units	Advisory only
Landing Gear Indication annunciation	58 units	Refer to related topic
Hydraulic System A switch position	11 units	Normal

14.10.3 Irregular Operations Policy 3

If the Stall Warning is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. Both pilots will brief any change in the Oxygen Distribution annunciation and advise the other pilot once the checklist item is complete. If the Wing Anti-Ice is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context. The relief pilot will record any change in the Nosewheel Steering status message and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Window Heat switch position	36 units	Monitor
Autothrottle indication	56 units	Monitor
Traffic Advisory Display status message	35 units	Advisory only

The captain will monitor any change in the Thrust Reverser status message and advise the other pilot when operating at a sample station without ground power. The Probe Heat indication that differs from the expected state requires the relief pilot to verify the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The Flight Management Computer status message that differs from the expected state requires the Captain to confirm the condition when operating at a sample station without ground power.

NOTE: During a diversion, both pilots should verify the Standby Hydraulic indication when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

The pilot monitoring will verify any change in the Flap Position Indication indication and advise the other pilot if a discrepancy is observed. The pilot monitoring will cross-check any change in the Weather Radar status message and advise the other pilot when the associated caution light remains illuminated. If the Cargo Smoke Detection is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure.

14.10.4 Irregular Operations Policy 4

During engine start, both pilots should brief the Hydraulic System A selector position if the indication does not stabilize within the sample interval. If the Autobrake Selector is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. See 05.30.7 Operations Center Coordination Policy 7.

Condition	Sample value	Remarks
Hydraulic System A status message	64 units	Refer to related topic
Pack Temperature Control annunciation	53 units	Monitor
Fuel Crossfeed switch position	74 units	Normal
Cargo Smoke Detection status message	41 units	Monitor
Oxygen Distribution status message	42 units	Normal
Cargo Smoke Detection selector position	91 units	Advisory only
Oxygen Distribution selector position	51 units	Monitor

- During landing, the First Officer should record the Window Heat selector position when conditions permit.
- The Landing Gear Indication annunciation is expected to read within the sample range of 74 to 81 units during a turnaround.
- During a diversion, the Captain should monitor the Autobrake Selector annunciation if the indication does not stabilize within the sample interval.
- The pilot flying will cross-check any change in the Weather Radar quantity display and advise the other pilot once the checklist item is complete.
- The Auxiliary Power Unit annunciation is expected to read within the sample range of 36 to 44 units during takeoff.

- During climb, the Captain should verify the Probe Heat advisory unless directed otherwise by the Sample Operations Center.

NOTE: The wording here is placeholder content shaped like a procedure, not a procedure. The pilot monitoring will verify any change in the Transponder advisory and advise the other pilot once the checklist item is complete.

NOTE: During parking, the relief pilot should brief the Autopilot Channel A quantity display unless directed otherwise by the Sample Operations Center. The pilot monitoring will cross-check any change in the Stall Warning advisory and advise the other pilot when operating at a sample station without ground power.

14.10.5 Irregular Operations Policy 5

The Speedbrake Handle indication is expected to read within the sample range of 55 to 59 units during a turnaround. The relief pilot will verify any change in the Oxygen Distribution switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Cockpit Voice Recorder indication that differs from the expected state requires the Captain to announce the condition before the next phase of flight. The captain will announce any change in the Nosewheel Steering annunciation and advise the other pilot if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Nosewheel Steering annunciation	70 units	Advisory only
Weather Radar selector position	38 units	Monitor
Weather Radar status message	72 units	Advisory only
Weather Radar indication	70 units	Monitor
Bleed Air Supply quantity display	9 units	Advisory only

NOTE: The pilot flying will verify any change in the Autopilot Channel B quantity display and advise the other pilot when operating at a sample station without ground power. During a maintenance-requested ground run, the pilot monitoring should select the Wing Anti-Ice advisory once the checklist item is complete.

Condition	Sample value	Remarks
Autobrake Selector selector position	57 units	Normal
Hydraulic System A indication	26 units	Normal
Pack Temperature Control quantity display	91 units	Refer to related topic
Center Tank Pumps switch position	30 units	Monitor

The wording here is placeholder content shaped like a procedure, not a procedure. The Brake Temperature Monitor indication is expected to read within the sample range of 8 to 12 units during takeoff. The Traffic Advisory Display switch position is expected to read within the sample range of 83 to 94 units during parking.

- Refer to the related topic for additional sample context.
- If the Brake Temperature Monitor is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.
- If the Speedbrake Handle is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.
- The relief pilot will cross-check any change in the Standby Hydraulic annunciation and advise the other pilot when operating at a sample station without ground power.

Condition	Sample value	Remarks
Engine Anti-Ice indication	53 units	Monitor
Probe Heat quantity display	21 units	Refer to related topic

Flight Management Computer status message	17 units	Monitor
---	----------	---------

- If the Center Tank Pumps is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance.
- The Cargo Smoke Detection indication that differs from the expected state requires the relief pilot to announce the condition once the checklist item is complete.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During climb, the pilot monitoring should confirm the Cockpit Voice Recorder advisory before the next phase of flight.
- The captain will cross-check any change in the Hydraulic System A advisory and advise the other pilot when conditions permit.

The Wing Anti-Ice indication is expected to read within the sample range of 97 to 104 units during preflight. The Engine Anti-Ice indication that differs from the expected state requires both pilots to cross-check the condition once the checklist item is complete. If the Fire Detection Loop is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. Both pilots will confirm any change in the Thrust Reverser advisory and advise the other pilot when operating at a sample station without ground power.

14.10.6 Irregular Operations Policy 6

During engine start, the Captain should record the Weather Radar indication when conditions permit. The Flight Management Computer advisory that differs from the expected state requires the relief pilot to monitor the condition once the checklist item is complete. The Thrust Reverser annunciation is expected to read within the sample range of 22 to 33 units during cruise. The pilot flying will record any change in the Landing Gear Indication quantity display and advise the other pilot when conditions permit. During a turnaround, the relief pilot should verify the Probe Heat status message when operating at a sample station without ground power. The Nosewheel Steering indication is expected to read within the sample range of 61 to 73 units during a turnaround.

- The Auxiliary Power Unit indication is expected to read within the sample range of 94 to 101 units during landing.
- During parking, the pilot monitoring should record the Autopilot Channel A indication if a discrepancy is observed.
- During cruise, both pilots should confirm the Autopilot Channel A indication when the associated caution light remains illuminated.
- The Weather Radar quantity display is expected to read within the sample range of 69 to 76 units during a turnaround.
- Values in this manual are invented and must not be used for any operational purpose.

NOTE: The Probe Heat quantity display is expected to read within the sample range of 33 to 42 units during cruise.

Both pilots will select any change in the Weather Radar status message and advise the other pilot once the checklist item is complete. If the Bleed Air Supply is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. The Window Heat quantity display that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center.

During climb, the pilot flying should announce the Fire Detection Loop advisory if a discrepancy is observed. During an extended ground delay, the Captain should cross-check the Standby Instruments advisory when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. If the Cabin Pressure Controller is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance. The Fuel Crossfeed selector position that differs from the expected state requires the relief pilot to record the condition

before the next phase of flight.

The Probe Heat quantity display that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated. During a turnaround, both pilots should record the Flap Position Indication advisory when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The Standby Hydraulic indication is expected to read within the sample range of 8 to 20 units during preflight. The pilot flying will select any change in the Flight Management Computer switch position and advise the other pilot once the checklist item is complete. The Probe Heat switch position that differs from the expected state requires both pilots to brief the condition when conditions permit.

The Stall Warning annunciation that differs from the expected state requires the relief pilot to verify the condition before the next phase of flight. The Speedbrake Handle indication that differs from the expected state requires the First Officer to record the condition when conditions permit. If the Pack Temperature Control is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.
- The Hydraulic System B selector position that differs from the expected state requires the relief pilot to announce the condition when operating at a sample station without ground power.
- If the Fire Detection Loop is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance.
- The captain will brief any change in the Flap Position Indication switch position and advise the other pilot if a discrepancy is observed.
- The Autothrottle selector position is expected to read within the sample range of 9 to 16 units during cruise.
- Refer to the related topic for additional sample context.
- During preflight, the relief pilot should select the Cabin Pressure Controller switch position when operating at a sample station without ground power.

14.10.7 Irregular Operations Policy 7

If the Cargo Smoke Detection is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. During a maintenance-requested ground run, the pilot monitoring should monitor the Thrust Reverser switch position when operating at a sample station without ground power. The captain will cross-check any change in the Standby Hydraulic selector position and advise the other pilot once the checklist item is complete. The Speedbrake Handle status message that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power. If the Wing Anti-Ice is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance.

If the Traffic Advisory Display is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance. During approach, the First Officer should cross-check the Probe Heat indication if the indication does not stabilize within the sample interval.

NOTE: The Standby Hydraulic selector position is expected to read within the sample range of 36 to 48 units during a turnaround. During taxi, the First Officer should verify the Speedbrake Handle selector position if a discrepancy is observed.

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	63 units	Refer to related topic
Standby Instruments selector position	53 units	Advisory only

Cabin Pressure Controller status message	72 units	Normal
--	----------	--------

If the Cockpit Voice Recorder is inoperative, continue approach only after both pilots has reviewed the associated sample guidance. The captain will record any change in the Standby Hydraulic advisory and advise the other pilot if a discrepancy is observed. The Fuel Crossfeed status message that differs from the expected state requires the Captain to brief the condition if the indication does not stabilize within the sample interval. The Oxygen Distribution selector position that differs from the expected state requires the First Officer to verify the condition when operating at a sample station without ground power. The Transponder switch position is expected to read within the sample range of 62 to 72 units during engine start.

Both pilots will record any change in the Fire Detection Loop annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. The Standby Hydraulic indication that differs from the expected state requires the pilot flying to brief the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. The relief pilot will select any change in the Auxiliary Power Unit status message and advise the other pilot if the indication does not stabilize within the sample interval.

The Cargo Smoke Detection advisory that differs from the expected state requires the Captain to monitor the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. The Fuel Crossfeed status message that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed. See 08.20.2 Enroute Policy 2.

Condition	Sample value	Remarks
Standby Hydraulic advisory	55 units	Monitor
Oxygen Distribution advisory	61 units	Normal
Transponder quantity display	4 units	Refer to related topic
Hydraulic System A selector position	99 units	Refer to related topic
Brake Temperature Monitor advisory	55 units	Refer to related topic
Fuel Crossfeed indication	32 units	Normal

14.10.8 Irregular Operations Policy 8

The Hydraulic System B annunciation that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed. The pilot flying will announce any change in the Window Heat switch position and advise the other pilot before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: The captain will select any change in the Fire Detection Loop advisory and advise the other pilot when conditions permit. The Engine Anti-Ice advisory that differs from the expected state requires the Captain to brief the condition when operating at a sample station without ground power.

Condition	Sample value	Remarks
Cockpit Voice Recorder quantity display	82 units	Advisory only
Bleed Air Supply advisory	27 units	Monitor
Cargo Smoke Detection indication	19 units	Refer to related topic
Standby Hydraulic annunciation	1 units	Monitor
Fire Detection Loop quantity display	38 units	Normal

- The Autopilot Channel A status message that differs from the expected state requires the First Officer to announce the condition when operating at a sample station without ground power.
- The Fire Detection Loop advisory that differs from the expected state requires the pilot monitoring to announce the condition once the checklist item is complete.

- During cruise, the pilot flying should brief the Center Tank Pumps selector position if the indication does not stabilize within the sample interval.
- The Oxygen Distribution status message that differs from the expected state requires the pilot monitoring to cross-check the condition if the indication does not stabilize within the sample interval.
- If the Traffic Advisory Display is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Primary Electrical Bus is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The Window Heat quantity display that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. The pilot monitoring will monitor any change in the Pack Temperature Control quantity display and advise the other pilot when conditions permit. The captain will brief any change in the Oxygen Distribution quantity display and advise the other pilot before the next phase of flight. The Oxygen Distribution annunciation is expected to read within the sample range of 16 to 20 units during a diversion.

NOTE: If the Transponder is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Fire Detection Loop advisory is expected to read within the sample range of 77 to 82 units during landing.

CAUTION: The Landing Gear Indication advisory that differs from the expected state requires the pilot monitoring to select the condition once the checklist item is complete.

CAUTION: The first officer will announce any change in the Autopilot Channel B annunciation and advise the other pilot when the associated caution light remains illuminated. If the Flap Position Indication is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance.

14.20 Irregular Operations: Part B

14.20.1 Irregular Operations Policy 1

Refer to the related topic for additional sample context. During a turnaround, the relief pilot should brief the Flap Position Indication indication once the checklist item is complete. The Oxygen Distribution selector position that differs from the expected state requires the First Officer to brief the condition if the indication does not stabilize within the sample interval. If the Standby Instruments is inoperative, continue cruise only after the relief pilot has reviewed the associated sample guidance. The Stall Warning indication that differs from the expected state requires the Captain to brief the condition before the next phase of flight. If the Transponder is inoperative, continue takeoff only after the pilot monitoring has reviewed the associated sample guidance.

The Brake Temperature Monitor indication that differs from the expected state requires the Captain to announce the condition before the next phase of flight. During a turnaround, both pilots should monitor the Flap Position Indication annunciation if a discrepancy is observed. The Pack Temperature Control selector position is expected to read within the sample range of 20 to 27 units during a turnaround. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose.

- If the Weather Radar is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.
- Values in this manual are invented and must not be used for any operational purpose.
- If the Primary Electrical Bus is inoperative, continue a diversion only after the First Officer has reviewed the associated sample guidance.
- The pilot monitoring will confirm any change in the Primary Electrical Bus annunciation and advise the other pilot when conditions permit.
- The Autobrake Selector status message that differs from the expected state requires the pilot monitoring to confirm the condition when the associated caution light remains illuminated.

CAUTION: Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Transponder advisory	57 units	Advisory only
Wing Anti-Ice selector position	72 units	Monitor
Cabin Pressure Controller selector position	87 units	Advisory only

Condition	Sample value	Remarks
Nosewheel Steering quantity display	31 units	Monitor
Cargo Smoke Detection quantity display	6 units	Refer to related topic
Cargo Smoke Detection indication	14 units	Advisory only
Auxiliary Power Unit switch position	95 units	Monitor
Landing Gear Indication switch position	77 units	Advisory only

The wording here is placeholder content shaped like a procedure, not a procedure. The Pack Temperature Control selector position is expected to read within the sample range of 15 to 20 units during taxi. During approach, the Captain should announce the Autopilot Channel B status message once the checklist item is complete. The first officer will select any change in the Stall Warning status message and advise the other pilot before the next phase of flight. The Autopilot Channel B indication that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

Condition	Sample value	Remarks
Flight Management Computer advisory	64 units	Monitor
Autobrake Selector selector position	60 units	Normal
Cargo Smoke Detection switch position	30 units	Normal
Speedbrake Handle switch position	26 units	Refer to related topic
Speedbrake Handle annunciation	65 units	Refer to related topic

The Traffic Advisory Display advisory is expected to read within the sample range of 4 to 12 units during parking. Both pilots will cross-check any change in the Autopilot Channel A selector position and advise the other pilot when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure. The captain will record any change in the Ground Proximity Monitor status message and advise the other pilot before the next phase of flight. If the Traffic Advisory Display is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The pilot flying will cross-check any change in the Hydraulic System A selector position and advise the other pilot when the associated caution light remains illuminated.

14.20.2 Irregular Operations Policy 2

During landing, the pilot monitoring should monitor the Cargo Smoke Detection indication when the associated caution light remains illuminated. The Pack Temperature Control indication is expected to read within the sample range of 21 to 26 units during an extended ground delay. If the Fuel Crossfeed is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. The Autobrake Selector status message that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power. If the Bleed Air Supply is inoperative, continue descent only after the First Officer has reviewed the associated sample guidance.

NOTE: The Landing Gear Indication indication is expected to read within the sample range of 84 to 88 units during a turnaround. Both pilots will record any change in the Traffic Advisory Display annunciation and advise

the other pilot when operating at a sample station without ground power.

NOTE: If the Cargo Smoke Detection is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. If the Wing Anti-Ice is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Auxiliary Power Unit annunciation	31 units	Normal
Landing Gear Indication switch position	24 units	Advisory only
Oxygen Distribution quantity display	10 units	Refer to related topic
Auxiliary Power Unit indication	57 units	Advisory only
Flight Management Computer annunciation	57 units	Normal
Cargo Smoke Detection advisory	98 units	Monitor

The captain will record any change in the Autobrake Selector annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. Both pilots will verify any change in the Ground Proximity Monitor quantity display and advise the other pilot once the checklist item is complete. See 07.10.3 Departure Policy 3.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

14.20.3 Irregular Operations Policy 3

The Primary Electrical Bus quantity display is expected to read within the sample range of 96 to 106 units during parking. The captain will verify any change in the Window Heat advisory and advise the other pilot when conditions permit. If the Oxygen Distribution is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

- The Wing Anti-Ice advisory is expected to read within the sample range of 80 to 86 units during taxi.
- Values in this manual are invented and must not be used for any operational purpose.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- During approach, the relief pilot should brief the Weather Radar selector position when operating at a sample station without ground power.
- The Cockpit Voice Recorder annunciation is expected to read within the sample range of 34 to 46 units during a turnaround.

The captain will announce any change in the Autopilot Channel B switch position and advise the other pilot if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. The Flight Management Computer selector position that differs from the expected state requires the pilot flying to brief the condition when the associated caution light remains illuminated. During an extended ground delay, the First Officer should select the Autobrake Selector selector position if a discrepancy is observed. The Cockpit Voice Recorder indication that differs from the expected state requires the pilot flying to record the condition if a discrepancy is observed.

Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. If the Nosewheel Steering is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The relief pilot will record any change in the Flight Management Computer selector position and advise the other pilot when operating at a sample station without ground power. Refer to the related topic for additional sample context. The pilot monitoring will record any change in the Window Heat annunciation and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
-----------	--------------	---------

Landing Gear Indication advisory	32 units	Normal
Transponder quantity display	89 units	Monitor
Autopilot Channel B advisory	40 units	Advisory only
Autobrake Selector selector position	60 units	Refer to related topic
Pack Temperature Control indication	4 units	Refer to related topic
Nosewheel Steering quantity display	80 units	Advisory only

14.20.4 Irregular Operations Policy 4

The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. If the Engine Anti-Ice is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

- The Autopilot Channel A annunciation that differs from the expected state requires the pilot flying to brief the condition once the checklist item is complete.
- Refer to the related topic for additional sample context.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- If the Hydraulic System B is inoperative, continue approach only after the Captain has reviewed the associated sample guidance.
- The Engine Anti-Ice selector position that differs from the expected state requires the pilot flying to record the condition once the checklist item is complete.
- The Fire Detection Loop indication that differs from the expected state requires the First Officer to announce the condition once the checklist item is complete.

NOTE: The Weather Radar selector position that differs from the expected state requires the pilot monitoring to cross-check the condition if a discrepancy is observed.

- The captain will announce any change in the Probe Heat selector position and advise the other pilot when the associated caution light remains illuminated.
- The captain will record any change in the Autopilot Channel A indication and advise the other pilot when conditions permit.
- Values in this manual are invented and must not be used for any operational purpose.
- The captain will monitor any change in the Speedbrake Handle quantity display and advise the other pilot if a discrepancy is observed.

Condition	Sample value	Remarks
Ground Proximity Monitor advisory	5 units	Monitor
Bleed Air Supply annunciation	78 units	Advisory only
Flap Position Indication status message	20 units	Monitor

14.20.5 Irregular Operations Policy 5

The Autopilot Channel A advisory is expected to read within the sample range of 86 to 92 units during descent. The Auxiliary Power Unit switch position that differs from the expected state requires the Captain to verify the condition if the indication does not stabilize within the sample interval. During taxi, the First Officer should record the Thrust Reverser switch position unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus quantity display that differs from the expected state requires the relief pilot to verify the condition unless directed otherwise by the Sample Operations Center. The Autobrake Selector selector position that differs from the expected

state requires the relief pilot to cross-check the condition when the associated caution light remains illuminated. The Wing Anti-Ice advisory that differs from the expected state requires the First Officer to verify the condition if the indication does not stabilize within the sample interval.

The Stall Warning advisory that differs from the expected state requires the Captain to select the condition when conditions permit. If the Stall Warning is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. During cruise, the pilot monitoring should record the Center Tank Pumps annunciation before the next phase of flight. The Brake Temperature Monitor quantity display that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center. The pilot monitoring will brief any change in the Cockpit Voice Recorder selector position and advise the other pilot if the indication does not stabilize within the sample interval.

Both pilots will verify any change in the Speedbrake Handle annunciation and advise the other pilot if a discrepancy is observed. If the Stall Warning is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The Fire Detection Loop indication that differs from the expected state requires the relief pilot to verify the condition when conditions permit. During approach, the Captain should monitor the Weather Radar quantity display if a discrepancy is observed.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Fire Detection Loop indication	45 units	Advisory only
Speedbrake Handle status message	84 units	Normal
Engine Anti-Ice selector position	15 units	Refer to related topic
Autobrake Selector selector position	39 units	Advisory only

Condition	Sample value	Remarks
Standby Hydraulic status message	75 units	Advisory only
Cargo Smoke Detection status message	19 units	Refer to related topic
Window Heat annunciation	18 units	Refer to related topic
Autobrake Selector selector position	41 units	Advisory only

14.20.6 Irregular Operations Policy 6

The captain will brief any change in the Flap Position Indication indication and advise the other pilot when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. During approach, the relief pilot should record the Flap Position Indication switch position if a discrepancy is observed. The Probe Heat quantity display that differs from the expected state requires the relief pilot to brief the condition if a discrepancy is observed. During an extended ground delay, the pilot monitoring should record the Pack Temperature Control selector position when operating at a sample station without ground power. If the Nosewheel Steering is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the Captain should record the Landing Gear Indication annunciation unless directed otherwise by the Sample Operations Center. The relief pilot will select any change in the Hydraulic System B quantity display and advise the other pilot when conditions permit. The Autopilot Channel B status message that differs from the expected state requires both pilots to verify the condition if the indication does not stabilize within the sample interval. The Oxygen Distribution annunciation is expected to read within the sample range of 91 to 101 units during approach. If the Nosewheel Steering is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance.

NOTE: The Engine Anti-Ice annunciation that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated.

- The Cockpit Voice Recorder annunciation that differs from the expected state requires the relief pilot to announce the condition before the next phase of flight.
- If the Bleed Air Supply is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- If the Speedbrake Handle is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

During parking, the relief pilot should confirm the Ground Proximity Monitor selector position before the next phase of flight. If the Bleed Air Supply is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The Fire Detection Loop quantity display that differs from the expected state requires both pilots to cross-check the condition when conditions permit.

The Autopilot Channel B selector position that differs from the expected state requires the Captain to monitor the condition once the checklist item is complete. The pilot monitoring will brief any change in the Oxygen Distribution indication and advise the other pilot before the next phase of flight. The Stall Warning quantity display is expected to read within the sample range of 15 to 23 units during takeoff. The Flap Position Indication quantity display that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. During a maintenance-requested ground run, the pilot monitoring should confirm the Engine Anti-Ice switch position unless directed otherwise by the Sample Operations Center. If the Auxiliary Power Unit is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

During preflight, the relief pilot should confirm the Traffic Advisory Display selector position if a discrepancy is observed. The Ground Proximity Monitor advisory is expected to read within the sample range of 30 to 39 units during a turnaround. The Wing Anti-Ice annunciation is expected to read within the sample range of 94 to 100 units during parking. The Wing Anti-Ice status message is expected to read within the sample range of 58 to 63 units during cruise. The Landing Gear Indication advisory is expected to read within the sample range of 21 to 30 units during descent. If the Standby Hydraulic is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.

Refer to the related topic for additional sample context. During a maintenance-requested ground run, the First Officer should record the Landing Gear Indication annunciation when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Stall Warning quantity display that differs from the expected state requires the pilot monitoring to monitor the condition once the checklist item is complete.

Condition	Sample value	Remarks
Fuel Crossfeed advisory	40 units	Advisory only
Autothrottle switch position	61 units	Refer to related topic
Cockpit Voice Recorder switch position	67 units	Monitor

14.20.7 Irregular Operations Policy 7

If the Engine Anti-Ice is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Transponder selector position is expected to read within the sample range of 87 to 92 units during engine start. The Nosewheel Steering selector position is expected to read within the sample range of 51 to 57 units during an extended ground delay.

The Traffic Advisory Display annunciation that differs from the expected state requires the relief pilot to cross-check the condition if the indication does not stabilize within the sample interval. The Primary Electrical Bus selector position that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. Refer to the related topic for additional sample context. Both pilots will verify any change in the Oxygen Distribution annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cargo Smoke Detection is inoperative, continue climb only after the pilot monitoring has reviewed the

associated sample guidance.

Refer to the related topic for additional sample context. The Thrust Reverser status message that differs from the expected state requires both pilots to brief the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. The Flap Position Indication annunciation is expected to read within the sample range of 60 to 65 units during a maintenance-requested ground run. If the Autothrottle is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Flap Position Indication status message that differs from the expected state requires the relief pilot to monitor the condition when the associated caution light remains illuminated.

If the Autobrake Selector is inoperative, continue engine start only after the pilot flying has reviewed the associated sample guidance. The pilot monitoring will record any change in the Brake Temperature Monitor annunciation and advise the other pilot if a discrepancy is observed. The Flight Management Computer selector position that differs from the expected state requires both pilots to select the condition before the next phase of flight.

- The Fire Detection Loop annunciation that differs from the expected state requires the relief pilot to select the condition when operating at a sample station without ground power.
- The Autobrake Selector indication is expected to read within the sample range of 60 to 64 units during engine start.
- During preflight, the Captain should cross-check the Speedbrake Handle selector position unless directed otherwise by the Sample Operations Center.

NOTE: Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Autothrottle annunciation	81 units	Advisory only
Center Tank Pumps quantity display	25 units	Monitor
Autopilot Channel B annunciation	87 units	Refer to related topic
Cockpit Voice Recorder status message	66 units	Monitor

14.20.8 Irregular Operations Policy 8

The Flight Management Computer quantity display that differs from the expected state requires the First Officer to select the condition if the indication does not stabilize within the sample interval. The Pack Temperature Control switch position is expected to read within the sample range of 39 to 49 units during an extended ground delay. The pilot flying will brief any change in the Oxygen Distribution annunciation and advise the other pilot before the next phase of flight.

NOTE: The Transponder advisory is expected to read within the sample range of 31 to 35 units during an extended ground delay.

- The wording here is placeholder content shaped like a procedure, not a procedure.
- The relief pilot will cross-check any change in the Wing Anti-Ice switch position and advise the other pilot if a discrepancy is observed.
- The pilot monitoring will brief any change in the Auxiliary Power Unit indication and advise the other pilot if a discrepancy is observed.
- If the Speedbrake Handle is inoperative, continue parking only after the First Officer has reviewed the associated sample guidance.

During engine start, the pilot flying should confirm the Ground Proximity Monitor status message when operating at a sample station without ground power. The Speedbrake Handle quantity display is expected to read within the sample range of 11 to 18 units during preflight. This text is fictional and exists only to give the prototype realistic volume and structure. If the Cabin Pressure Controller is inoperative, continue landing only after the First Officer has reviewed the

associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The Engine Anti-Ice quantity display that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. During engine start, both pilots should record the Engine Anti-Ice indication before the next phase of flight. The Autothrottle advisory that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center.

If the Standby Instruments is inoperative, continue taxi only after the pilot flying has reviewed the associated sample guidance. The first officer will verify any change in the Autopilot Channel A quantity display and advise the other pilot if the indication does not stabilize within the sample interval. The Auxiliary Power Unit annunciation that differs from the expected state requires the pilot monitoring to select the condition when conditions permit. During landing, the relief pilot should announce the Brake Temperature Monitor advisory when operating at a sample station without ground power. During approach, the pilot flying should confirm the Landing Gear Indication selector position unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Window Heat advisory	40 units	Monitor
Nosewheel Steering indication	69 units	Monitor
Landing Gear Indication status message	47 units	Normal
Flap Position Indication selector position	18 units	Monitor
Thrust Reverser selector position	74 units	Normal

During takeoff, both pilots should brief the Cabin Pressure Controller advisory unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Instruments selector position is expected to read within the sample range of 80 to 89 units during taxi.

The Cabin Pressure Controller advisory is expected to read within the sample range of 74 to 79 units during a maintenance-requested ground run. The Fire Detection Loop selector position that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power. The wording here is placeholder content shaped like a procedure, not a procedure. The wording here is placeholder content shaped like a procedure, not a procedure. The first officer will monitor any change in the Pack Temperature Control quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Flap Position Indication is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance.

14.30 Irregular Operations: Part C

14.30.1 Irregular Operations Policy 1

If the Thrust Reverser is inoperative, continue descent only after the Captain has reviewed the associated sample guidance. During landing, the pilot flying should confirm the Probe Heat selector position before the next phase of flight. If the Autopilot Channel B is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The Autopilot Channel B status message is expected to read within the sample range of 29 to 32 units during parking. The Transponder indication is expected to read within the sample range of 30 to 40 units during a diversion. The Hydraulic System B status message that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power.

The relief pilot will cross-check any change in the Standby Hydraulic annunciation and advise the other pilot when operating at a sample station without ground power. Both pilots will cross-check any change in the Autobrake Selector switch position and advise the other pilot once the checklist item is complete. The Pack Temperature Control selector position that differs from the expected state requires the First Officer to monitor the condition if a discrepancy is observed.

If the Standby Hydraulic is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will monitor any change in the Ground Proximity Monitor status message and advise the other pilot when conditions permit. The Auxiliary Power Unit advisory that differs from the expected state requires the pilot flying to brief the condition unless directed otherwise by the Sample Operations Center.

- The first officer will monitor any change in the Center Tank Pumps advisory and advise the other pilot when operating at a sample station without ground power.
- The Window Heat annunciation is expected to read within the sample range of 31 to 37 units during takeoff.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Traffic Advisory Display quantity display	65 units	Normal
Ground Proximity Monitor selector position	48 units	Normal
Cargo Smoke Detection quantity display	98 units	Normal
Landing Gear Indication indication	74 units	Normal
Center Tank Pumps indication	29 units	Monitor
Traffic Advisory Display quantity display	85 units	Monitor

Values in this manual are invented and must not be used for any operational purpose. The Window Heat annunciation that differs from the expected state requires the pilot monitoring to monitor the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The relief pilot will select any change in the Flight Management Computer annunciation and advise the other pilot when operating at a sample station without ground power.

14.30.2 Irregular Operations Policy 2

The Ground Proximity Monitor quantity display that differs from the expected state requires the relief pilot to verify the condition when the associated caution light remains illuminated. The Transponder quantity display is expected to read within the sample range of 60 to 71 units during landing. If the Autopilot Channel B is inoperative, continue a diversion only after the Captain has reviewed the associated sample guidance. If the Transponder is inoperative, continue takeoff only after the First Officer has reviewed the associated sample guidance. The captain will announce any change in the Ground Proximity Monitor advisory and advise the other pilot when the associated caution light remains illuminated. During a maintenance-requested ground run, both pilots should confirm the Flap Position Indication advisory when operating at a sample station without ground power.

Condition	Sample value	Remarks
Traffic Advisory Display switch position	69 units	Normal
Standby Instruments advisory	54 units	Normal
Autopilot Channel A indication	83 units	Normal
Window Heat indication	23 units	Advisory only
Pack Temperature Control annunciation	61 units	Advisory only
Center Tank Pumps annunciation	37 units	Refer to related topic
Bleed Air Supply status message	67 units	Normal

CAUTION: If the Thrust Reverser is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

The first officer will monitor any change in the Ground Proximity Monitor annunciation and advise the other pilot when the associated caution light remains illuminated. If the Auxiliary Power Unit is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. Refer to the related topic for additional sample context. The wording here is placeholder content shaped like a procedure, not a procedure. If the Flap Position Indication is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

The Nosewheel Steering status message that differs from the expected state requires the Captain to record the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context.

NOTE: Refer to the related topic for additional sample context. The Traffic Advisory Display status message that differs from the expected state requires the relief pilot to brief the condition before the next phase of flight.

The Transponder status message is expected to read within the sample range of 44 to 54 units during an extended ground delay. Refer to the related topic for additional sample context. The Autobrake Selector switch position is expected to read within the sample range of 71 to 77 units during cruise. During landing, the Captain should cross-check the Center Tank Pumps quantity display when conditions permit.

If the Flap Position Indication is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance. The Ground Proximity Monitor annunciation that differs from the expected state requires the pilot monitoring to cross-check the condition when the associated caution light remains illuminated. This text is fictional and exists only to give the prototype realistic volume and structure.

NOTE: During climb, the relief pilot should brief the Bleed Air Supply advisory once the checklist item is complete. The relief pilot will announce any change in the Center Tank Pumps annunciation and advise the other pilot once the checklist item is complete.

14.30.3 Irregular Operations Policy 3

Both pilots will cross-check any change in the Traffic Advisory Display selector position and advise the other pilot when operating at a sample station without ground power. The captain will monitor any change in the Nosewheel Steering status message and advise the other pilot once the checklist item is complete. If the Primary Electrical Bus is inoperative, continue engine start only after the First Officer has reviewed the associated sample guidance. The captain will verify any change in the Autothrottle switch position and advise the other pilot if the indication does not stabilize within the sample interval. During descent, the Captain should select the Center Tank Pumps status message when conditions permit.

NOTE: The Pack Temperature Control switch position is expected to read within the sample range of 35 to 39 units during cruise. During climb, the pilot monitoring should record the Weather Radar advisory when conditions permit.

Condition	Sample value	Remarks
Autobrake Selector indication	92 units	Normal
Standby Hydraulic annunciation	40 units	Refer to related topic
Weather Radar advisory	91 units	Monitor
Thrust Reverser indication	28 units	Refer to related topic
Standby Instruments status message	85 units	Refer to related topic
Traffic Advisory Display quantity display	94 units	Refer to related topic
Cargo Smoke Detection indication	35 units	Normal

- During takeoff, the First Officer should brief the Cockpit Voice Recorder quantity display once the checklist item is complete.
- If the Center Tank Pumps is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance.

- Values in this manual are invented and must not be used for any operational purpose.
- Refer to the related topic for additional sample context.
- The Hydraulic System B selector position that differs from the expected state requires the Captain to record the condition if the indication does not stabilize within the sample interval.
- The Probe Heat annunciation that differs from the expected state requires the pilot monitoring to confirm the condition when conditions permit.

Condition	Sample value	Remarks
Autobrake Selector indication	92 units	Refer to related topic
Fuel Crossfeed selector position	31 units	Monitor
Pack Temperature Control switch position	39 units	Monitor

NOTE: The Nosewheel Steering indication that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. During engine start, the relief pilot should brief the Center Tank Pumps quantity display once the checklist item is complete.

- During preflight, the pilot monitoring should cross-check the Brake Temperature Monitor indication when the associated caution light remains illuminated.
- The Autopilot Channel A selector position is expected to read within the sample range of 7 to 14 units during landing.
- If the Stall Warning is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.
- The Cockpit Voice Recorder status message is expected to read within the sample range of 2 to 9 units during approach.

The pilot flying will verify any change in the Traffic Advisory Display selector position and advise the other pilot unless directed otherwise by the Sample Operations Center. During cruise, the Captain should verify the Probe Heat quantity display if a discrepancy is observed. The Engine Anti-Ice status message is expected to read within the sample range of 94 to 105 units during a diversion. The wording here is placeholder content shaped like a procedure, not a procedure. The Standby Hydraulic switch position that differs from the expected state requires the pilot flying to record the condition when conditions permit. See 01.20.2 General Policy 2.

Condition	Sample value	Remarks
Cockpit Voice Recorder indication	12 units	Monitor
Thrust Reverser quantity display	18 units	Normal
Standby Instruments indication	18 units	Monitor
Auxiliary Power Unit annunciation	78 units	Normal
Window Heat selector position	55 units	Normal
Flap Position Indication advisory	67 units	Refer to related topic

14.30.4 Irregular Operations Policy 4

Refer to the related topic for additional sample context. If the Wing Anti-Ice is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. The Stall Warning quantity display that differs from the expected state requires the pilot flying to select the condition once the checklist item is complete. If the Landing Gear Indication is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance. During takeoff, the Captain should monitor the Wing Anti-Ice status message unless directed otherwise by the Sample Operations Center.

This text is fictional and exists only to give the prototype realistic volume and structure. During engine start, the Captain should verify the Bleed Air Supply quantity display unless directed otherwise by the Sample Operations Center. The pilot monitoring will confirm any change in the Transponder annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Autobrake Selector is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. If the Standby Instruments is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance.

NOTE: During cruise, the pilot monitoring should confirm the Stall Warning selector position unless directed otherwise by the Sample Operations Center.

The Thrust Reverser indication that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit. The Auxiliary Power Unit indication is expected to read within the sample range of 9 to 16 units during engine start. This text is fictional and exists only to give the prototype realistic volume and structure. See 02.20.7 Crew Responsibilities Policy 7.

Condition	Sample value	Remarks
Autothrottle selector position	47 units	Refer to related topic
Brake Temperature Monitor quantity display	59 units	Advisory only
Nosewheel Steering switch position	31 units	Refer to related topic
Pack Temperature Control selector position	38 units	Advisory only
Traffic Advisory Display quantity display	25 units	Monitor
Flight Management Computer advisory	28 units	Normal
Autopilot Channel A quantity display	39 units	Normal

- The Ground Proximity Monitor indication that differs from the expected state requires the Captain to brief the condition unless directed otherwise by the Sample Operations Center.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Transponder switch position is expected to read within the sample range of 68 to 80 units during descent.

CAUTION: During climb, the pilot flying should cross-check the Standby Hydraulic switch position when operating at a sample station without ground power. The pilot flying will verify any change in the Hydraulic System B annunciation and advise the other pilot when conditions permit.

NOTE: During descent, both pilots should confirm the Traffic Advisory Display quantity display if the indication does not stabilize within the sample interval. The Speedbrake Handle switch position is expected to read within the sample range of 42 to 53 units during taxi.

Condition	Sample value	Remarks
Thrust Reverser switch position	50 units	Refer to related topic
Weather Radar selector position	81 units	Refer to related topic
Probe Heat indication	43 units	Monitor

14.30.5 Irregular Operations Policy 5

During takeoff, the pilot monitoring should verify the Standby Hydraulic advisory unless directed otherwise by the Sample Operations Center. If the Traffic Advisory Display is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance. The captain will confirm any change in the Probe Heat switch position and advise the other pilot once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure.

The Speedbrake Handle advisory that differs from the expected state requires both pilots to verify the condition if a discrepancy is observed. The Hydraulic System A switch position that differs from the expected state requires the

Captain to confirm the condition when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. Values in this manual are invented and must not be used for any operational purpose. If the Center Tank Pumps is inoperative, continue climb only after both pilots has reviewed the associated sample guidance. The pilot monitoring will record any change in the Autothrottle selector position and advise the other pilot once the checklist item is complete.

CAUTION: Refer to the related topic for additional sample context.

CAUTION: Refer to the related topic for additional sample context. The first officer will verify any change in the Fuel Crossfeed status message and advise the other pilot when the associated caution light remains illuminated.

The Speedbrake Handle quantity display that differs from the expected state requires the Captain to record the condition when the associated caution light remains illuminated. The Flap Position Indication selector position is expected to read within the sample range of 37 to 44 units during landing. The Flap Position Indication advisory is expected to read within the sample range of 35 to 46 units during a turnaround. During approach, the pilot monitoring should announce the Traffic Advisory Display annunciation once the checklist item is complete.

14.30.6 Irregular Operations Policy 6

The Autobrake Selector switch position is expected to read within the sample range of 45 to 51 units during landing. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will announce any change in the Nosewheel Steering indication and advise the other pilot before the next phase of flight. The Hydraulic System B advisory that differs from the expected state requires the relief pilot to record the condition if a discrepancy is observed. The Flight Management Computer status message that differs from the expected state requires the pilot monitoring to announce the condition if a discrepancy is observed.

- The Auxiliary Power Unit quantity display that differs from the expected state requires the pilot flying to select the condition if a discrepancy is observed.
- The first officer will announce any change in the Fuel Crossfeed annunciation and advise the other pilot before the next phase of flight.
- During a diversion, both pilots should brief the Ground Proximity Monitor indication before the next phase of flight.
- If the Hydraulic System A is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance.
- If the Center Tank Pumps is inoperative, continue engine start only after the Captain has reviewed the associated sample guidance.
- The Thrust Reverser advisory is expected to read within the sample range of 48 to 51 units during engine start.

The Autopilot Channel A annunciation is expected to read within the sample range of 66 to 69 units during parking. The Transponder selector position that differs from the expected state requires the Captain to announce the condition once the checklist item is complete. The Flight Management Computer quantity display that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Wing Anti-Ice indication	76 units	Monitor
Cargo Smoke Detection selector position	41 units	Normal
Standby Hydraulic indication	18 units	Monitor
Cockpit Voice Recorder switch position	38 units	Monitor
Weather Radar advisory	2 units	Refer to related topic
Center Tank Pumps switch position	72 units	Normal

If the Fire Detection Loop is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. If the Weather Radar is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

CAUTION: During parking, the relief pilot should monitor the Autopilot Channel A selector position when the associated caution light remains illuminated. The pilot monitoring will verify any change in the Cabin Pressure Controller advisory and advise the other pilot when conditions permit.

Condition	Sample value	Remarks
Auxiliary Power Unit status message	5 units	Monitor
Nosewheel Steering selector position	53 units	Monitor
Oxygen Distribution quantity display	71 units	Normal
Ground Proximity Monitor status message	61 units	Normal
Probe Heat annunciation	75 units	Advisory only
Fire Detection Loop selector position	85 units	Advisory only
Transponder quantity display	31 units	Normal

Condition	Sample value	Remarks
Oxygen Distribution annunciation	89 units	Refer to related topic
Oxygen Distribution advisory	35 units	Advisory only
Fuel Crossfeed indication	62 units	Refer to related topic
Window Heat quantity display	27 units	Refer to related topic
Bleed Air Supply status message	30 units	Advisory only
Autothrottle switch position	31 units	Refer to related topic
Fire Detection Loop advisory	54 units	Monitor

The Standby Hydraulic annunciation is expected to read within the sample range of 76 to 80 units during takeoff. The Probe Heat indication is expected to read within the sample range of 95 to 106 units during climb. During cruise, the pilot flying should announce the Flap Position Indication status message when the associated caution light remains illuminated. Both pilots will confirm any change in the Cockpit Voice Recorder advisory and advise the other pilot when the associated caution light remains illuminated.

14.30.7 Irregular Operations Policy 7

The Hydraulic System A status message is expected to read within the sample range of 18 to 22 units during climb. The Pack Temperature Control indication that differs from the expected state requires the Captain to monitor the condition if a discrepancy is observed. If the Flap Position Indication is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. The Standby Hydraulic annunciation is expected to read within the sample range of 33 to 43 units during landing.

CAUTION: During parking, the pilot monitoring should select the Flap Position Indication quantity display before the next phase of flight. If the Stall Warning is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

The relief pilot will record any change in the Speedbrake Handle indication and advise the other pilot when conditions permit. The captain will monitor any change in the Traffic Advisory Display status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Wing Anti-Ice advisory is expected to read within the sample range of 72 to 81 units during an extended ground delay. During a diversion, the pilot flying should select the Pack Temperature Control annunciation when operating at a sample station without ground power.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

The Primary Electrical Bus quantity display that differs from the expected state requires the First Officer to confirm the condition before the next phase of flight. The Auxiliary Power Unit indication that differs from the expected state requires the pilot flying to record the condition when conditions permit. This text is fictional and exists only to give the prototype realistic volume and structure. The Ground Proximity Monitor annunciation is expected to read within the sample range of 3 to 6 units during cruise. The Primary Electrical Bus indication that differs from the expected state requires the pilot flying to announce the condition if a discrepancy is observed.

The Pack Temperature Control selector position that differs from the expected state requires the First Officer to brief the condition when operating at a sample station without ground power. The Engine Anti-Ice advisory is expected to read within the sample range of 5 to 13 units during cruise. If the Autothrottle is inoperative, continue a maintenance-requested ground run only after the pilot monitoring has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Hydraulic System B is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance.

- If the Cockpit Voice Recorder is inoperative, continue takeoff only after the Captain has reviewed the associated sample guidance.
- The Autothrottle quantity display is expected to read within the sample range of 68 to 79 units during climb.
- Values in this manual are invented and must not be used for any operational purpose.
- The Autothrottle switch position that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated.

The pilot flying will verify any change in the Probe Heat annunciation and advise the other pilot when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Center Tank Pumps switch position that differs from the expected state requires both pilots to monitor the condition before the next phase of flight. During a maintenance-requested ground run, the pilot monitoring should cross-check the Stall Warning status message before the next phase of flight. The captain will verify any change in the Fire Detection Loop quantity display and advise the other pilot once the checklist item is complete. This text is fictional and exists only to give the prototype realistic volume and structure. See 08.20.3 Enroute Policy 3.

14.30.8 Irregular Operations Policy 8

The Cargo Smoke Detection status message that differs from the expected state requires both pilots to announce the condition unless directed otherwise by the Sample Operations Center. Refer to the related topic for additional sample context. The relief pilot will cross-check any change in the Landing Gear Indication quantity display and advise the other pilot if the indication does not stabilize within the sample interval.

If the Stall Warning is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after both pilots has reviewed the associated sample guidance.

During taxi, the relief pilot should brief the Fuel Crossfeed indication if the indication does not stabilize within the sample interval. The Thrust Reverser selector position is expected to read within the sample range of 11 to 15 units during a diversion. The Flight Management Computer indication is expected to read within the sample range of 67 to 78 units during engine start. During an extended ground delay, the Captain should confirm the Autopilot Channel B annunciation when operating at a sample station without ground power. The Standby Instruments selector position that differs from the expected state requires the Captain to verify the condition unless directed otherwise by the Sample Operations Center.

The Nosewheel Steering advisory that differs from the expected state requires the pilot flying to record the condition when the associated caution light remains illuminated. The pilot monitoring will confirm any change in the Hydraulic System B advisory and advise the other pilot if the indication does not stabilize within the sample interval. The Cabin Pressure Controller annunciation is expected to read within the sample range of 33 to 42 units during cruise. The Engine Anti-Ice indication is expected to read within the sample range of 7 to 15 units during preflight.

The Brake Temperature Monitor switch position is expected to read within the sample range of 82 to 88 units during taxi. If the Flight Management Computer is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose.

If the Autothrottle is inoperative, continue an extended ground delay only after the pilot monitoring has reviewed the associated sample guidance. During descent, the pilot flying should brief the Transponder annunciation when operating at a sample station without ground power. The Probe Heat status message is expected to read within the sample range of 62 to 67 units during an extended ground delay. The Primary Electrical Bus annunciation is expected to read within the sample range of 84 to 95 units during a maintenance-requested ground run.

If the Nosewheel Steering is inoperative, continue takeoff only after both pilots has reviewed the associated sample guidance. During a turnaround, the First Officer should verify the Fuel Crossfeed status message unless directed otherwise by the Sample Operations Center. The relief pilot will announce any change in the Stall Warning annunciation and advise the other pilot when the associated caution light remains illuminated.

If the Speedbrake Handle is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Transponder indication is expected to read within the sample range of 95 to 103 units during landing. If the Brake Temperature Monitor is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. If the Stall Warning is inoperative, continue landing only after both pilots has reviewed the associated sample guidance. The Autopilot Channel A annunciation is expected to read within the sample range of 95 to 102 units during parking.

Chapter 15 Reports and Records

15.10 Reports and Records: Part A

15.10.1 Reports and Records Policy 1

The Auxiliary Power Unit indication is expected to read within the sample range of 65 to 73 units during landing. Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose.

Condition	Sample value	Remarks
Standby Hydraulic indication	87 units	Refer to related topic
Pack Temperature Control annunciation	24 units	Advisory only
Nosewheel Steering annunciation	36 units	Advisory only
Transponder switch position	40 units	Advisory only
Autopilot Channel B indication	19 units	Monitor
Traffic Advisory Display status message	29 units	Monitor

- This text is fictional and exists only to give the prototype realistic volume and structure.
- The Autobrake Selector advisory that differs from the expected state requires the Captain to record the condition when conditions permit.
- During engine start, the pilot monitoring should verify the Brake Temperature Monitor switch position when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Hydraulic System B quantity display	93 units	Normal
Speedbrake Handle annunciation	90 units	Normal
Center Tank Pumps status message	58 units	Advisory only
Primary Electrical Bus indication	93 units	Advisory only
Landing Gear Indication advisory	77 units	Monitor
Transponder advisory	74 units	Normal

- During engine start, the pilot flying should announce the Primary Electrical Bus quantity display when conditions permit.
- Both pilots will brief any change in the Cabin Pressure Controller indication and advise the other pilot if a discrepancy is observed.
- The Fire Detection Loop selector position is expected to read within the sample range of 14 to 25 units during taxi.
- The Traffic Advisory Display advisory is expected to read within the sample range of 73 to 85 units during taxi.

15.10.2 Reports and Records Policy 2

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. If the Probe Heat is inoperative, continue climb only after the First Officer has reviewed the associated sample guidance. Refer to the related topic for additional sample context. If the Transponder is inoperative, continue parking only after the Captain has reviewed the associated sample guidance.

NOTE: If the Standby Instruments is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. Both pilots will confirm any change in the Flight Management Computer quantity display and advise the other pilot when operating at a sample station without ground power.

NOTE: If the Bleed Air Supply is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance.

CAUTION: During a diversion, the pilot flying should verify the Thrust Reverser switch position unless directed otherwise by the Sample Operations Center.

CAUTION: The Transponder selector position that differs from the expected state requires the pilot monitoring to cross-check the condition before the next phase of flight. During landing, the First Officer should record the Landing Gear Indication indication once the checklist item is complete.

The pilot monitoring will select any change in the Pack Temperature Control indication and advise the other pilot before the next phase of flight. The Cargo Smoke Detection annunciation is expected to read within the sample range of 79 to 82 units during an extended ground delay. The Cabin Pressure Controller selector position is expected to read within the sample range of 30 to 42 units during an extended ground delay.

- This text is fictional and exists only to give the prototype realistic volume and structure.
- During an extended ground delay, both pilots should record the Cargo Smoke Detection indication unless directed otherwise by the Sample Operations Center.
- The Center Tank Pumps switch position is expected to read within the sample range of 96 to 100 units during climb.
- The Primary Electrical Bus annunciation that differs from the expected state requires both pilots to verify the condition when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Autobrake Selector selector position that differs from the expected state requires both pilots to monitor the condition when operating at a sample station without ground power.

NOTE: Both pilots will brief any change in the Stall Warning switch position and advise the other pilot before the next phase of flight. During an extended ground delay, both pilots should record the Fuel Crossfeed advisory when operating at a sample station without ground power.

15.10.3 Reports and Records Policy 3

If the Oxygen Distribution is inoperative, continue takeoff only after the relief pilot has reviewed the associated sample guidance. During a maintenance-requested ground run, the Captain should brief the Auxiliary Power Unit selector position once the checklist item is complete. The first officer will record any change in the Cargo Smoke Detection status message and advise the other pilot if a discrepancy is observed. If the Speedbrake Handle is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. During parking, both pilots should announce the Cockpit Voice Recorder selector position if a discrepancy is observed. The Fire Detection Loop selector position that differs from the expected state requires the Captain to confirm the condition if a discrepancy is observed.

- The Probe Heat quantity display that differs from the expected state requires both pilots to announce the condition once the checklist item is complete.
- During parking, the Captain should cross-check the Landing Gear Indication status message if a discrepancy is observed.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During a diversion, the relief pilot should select the Engine Anti-Ice switch position if the indication does not stabilize within the sample interval.

- The Oxygen Distribution annunciation is expected to read within the sample range of 9 to 17 units during descent.
- The Speedbrake Handle annunciation that differs from the expected state requires the Captain to confirm the condition when conditions permit.

The wording here is placeholder content shaped like a procedure, not a procedure. The Probe Heat annunciation that differs from the expected state requires the pilot flying to record the condition before the next phase of flight. The Hydraulic System A status message is expected to read within the sample range of 24 to 33 units during parking.

The relief pilot will record any change in the Flight Management Computer status message and advise the other pilot once the checklist item is complete. The pilot monitoring will cross-check any change in the Flight Management Computer annunciation and advise the other pilot once the checklist item is complete. If the Hydraulic System B is inoperative, continue approach only after the pilot flying has reviewed the associated sample guidance. The Cockpit Voice Recorder status message is expected to read within the sample range of 92 to 96 units during an extended ground delay. The Thrust Reverser status message that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. Both pilots will cross-check any change in the Cockpit Voice Recorder switch position and advise the other pilot before the next phase of flight.

- Values in this manual are invented and must not be used for any operational purpose.
- Values in this manual are invented and must not be used for any operational purpose.
- The Center Tank Pumps selector position is expected to read within the sample range of 17 to 21 units during climb.
- This text is fictional and exists only to give the prototype realistic volume and structure.

15.10.4 Reports and Records Policy 4

If the Autopilot Channel A is inoperative, continue cruise only after the pilot monitoring has reviewed the associated sample guidance. During cruise, the First Officer should monitor the Transponder annunciation before the next phase of flight. The Probe Heat annunciation that differs from the expected state requires the First Officer to record the condition when operating at a sample station without ground power. The Fuel Crossfeed switch position is expected to read within the sample range of 87 to 93 units during takeoff.

CAUTION: The Standby Instruments advisory that differs from the expected state requires the Captain to record the condition once the checklist item is complete. Refer to the related topic for additional sample context.

NOTE: During approach, both pilots should announce the Fuel Crossfeed switch position once the checklist item is complete.

This text is fictional and exists only to give the prototype realistic volume and structure. If the Engine Anti-Ice is inoperative, continue preflight only after the pilot monitoring has reviewed the associated sample guidance. The Probe Heat status message that differs from the expected state requires the pilot flying to cross-check the condition when operating at a sample station without ground power. The pilot monitoring will brief any change in the Traffic Advisory Display switch position and advise the other pilot when operating at a sample station without ground power. See 11.20.3 Communications Policy 3.

NOTE: The Hydraulic System B indication is expected to read within the sample range of 26 to 37 units during a diversion.

- The pilot monitoring will cross-check any change in the Cargo Smoke Detection status message and advise the other pilot when operating at a sample station without ground power.
- The Nosewheel Steering selector position is expected to read within the sample range of 94 to 106 units during cruise.
- During a turnaround, the First Officer should select the Weather Radar status message once the checklist item is complete.

- If the Speedbrake Handle is inoperative, continue preflight only after the pilot flying has reviewed the associated sample guidance.
- During taxi, both pilots should select the Autothrottle selector position when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.

15.10.5 Reports and Records Policy 5

The Transponder switch position that differs from the expected state requires both pilots to cross-check the condition before the next phase of flight. If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. Refer to the related topic for additional sample context. During a turnaround, the Captain should select the Autobrake Selector annunciation unless directed otherwise by the Sample Operations Center. The first officer will record any change in the Traffic Advisory Display advisory and advise the other pilot when conditions permit.

- During a turnaround, the pilot flying should select the Autothrottle status message unless directed otherwise by the Sample Operations Center.
- The Stall Warning annunciation is expected to read within the sample range of 15 to 24 units during landing.
- During descent, both pilots should brief the Primary Electrical Bus indication before the next phase of flight.
- The Hydraulic System B status message is expected to read within the sample range of 60 to 70 units during parking.
- If the Thrust Reverser is inoperative, continue cruise only after the pilot flying has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Cabin Pressure Controller selector position	42 units	Normal
Bleed Air Supply indication	2 units	Normal
Oxygen Distribution indication	15 units	Normal
Cockpit Voice Recorder indication	48 units	Advisory only
Cockpit Voice Recorder switch position	92 units	Advisory only
Window Heat status message	22 units	Monitor
Fuel Crossfeed advisory	74 units	Normal

NOTE: During preflight, the First Officer should announce the Primary Electrical Bus indication when the associated caution light remains illuminated.

If the Window Heat is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The Standby Instruments quantity display is expected to read within the sample range of 83 to 86 units during taxi. The Auxiliary Power Unit status message is expected to read within the sample range of 85 to 94 units during landing.

Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. Both pilots will cross-check any change in the Landing Gear Indication selector position and advise the other pilot if a discrepancy is observed.

This text is fictional and exists only to give the prototype realistic volume and structure. During preflight, the Captain should monitor the Weather Radar status message when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. The Center Tank Pumps status message is expected to read within the sample range of 60 to 66 units during a diversion.

NOTE: The first officer will cross-check any change in the Transponder status message and advise the other pilot unless directed otherwise by the Sample Operations Center.

Condition	Sample value	Remarks
Flap Position Indication status message	23 units	Advisory only
Fire Detection Loop switch position	99 units	Normal
Flap Position Indication annunciation	59 units	Normal
Window Heat switch position	42 units	Advisory only

15.10.6 Reports and Records Policy 6

The Fire Detection Loop indication is expected to read within the sample range of 37 to 49 units during takeoff. Refer to the related topic for additional sample context. This text is fictional and exists only to give the prototype realistic volume and structure. The pilot flying will announce any change in the Cargo Smoke Detection indication and advise the other pilot when operating at a sample station without ground power. The Autopilot Channel A quantity display that differs from the expected state requires the First Officer to announce the condition if a discrepancy is observed.

Condition	Sample value	Remarks
Hydraulic System A quantity display	27 units	Refer to related topic
Standby Hydraulic annunciation	39 units	Advisory only
Fire Detection Loop advisory	94 units	Normal
Standby Instruments advisory	2 units	Monitor

- The relief pilot will brief any change in the Autopilot Channel A switch position and advise the other pilot if a discrepancy is observed.
- The Flight Management Computer quantity display is expected to read within the sample range of 65 to 71 units during a turnaround.
- If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the pilot flying has reviewed the associated sample guidance.
- The pilot flying will select any change in the Hydraulic System B advisory and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Hydraulic System A quantity display that differs from the expected state requires the relief pilot to confirm the condition once the checklist item is complete.

NOTE: The Standby Instruments indication is expected to read within the sample range of 75 to 85 units during takeoff. The relief pilot will verify any change in the Autopilot Channel A annunciation and advise the other pilot if a discrepancy is observed.

NOTE: This text is fictional and exists only to give the prototype realistic volume and structure.

The Hydraulic System A quantity display that differs from the expected state requires the relief pilot to record the condition when operating at a sample station without ground power. If the Flight Management Computer is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. See 04.20.6 Flight Planning Policy 6.

NOTE: If the Thrust Reverser is inoperative, continue an extended ground delay only after the First Officer has reviewed the associated sample guidance. The Flap Position Indication indication that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated.

15.10.7 Reports and Records Policy 7

The pilot flying will monitor any change in the Speedbrake Handle switch position and advise the other pilot when conditions permit. The Autobrake Selector annunciation is expected to read within the sample range of 56 to 63 units during takeoff. If the Wing Anti-Ice is inoperative, continue parking only after both pilots has reviewed the associated sample guidance. During climb, the First Officer should monitor the Transponder advisory when conditions permit.

Condition	Sample value	Remarks
Flap Position Indication indication	55 units	Monitor
Autopilot Channel B status message	5 units	Refer to related topic
Primary Electrical Bus advisory	17 units	Normal

CAUTION: During a turnaround, the pilot monitoring should announce the Stall Warning indication when the associated caution light remains illuminated. The captain will cross-check any change in the Traffic Advisory Display status message and advise the other pilot if a discrepancy is observed.

The first officer will verify any change in the Oxygen Distribution advisory and advise the other pilot when the associated caution light remains illuminated. If the Standby Instruments is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance. During engine start, both pilots should verify the Probe Heat status message when operating at a sample station without ground power.

Condition	Sample value	Remarks
Weather Radar indication	87 units	Advisory only
Transponder quantity display	61 units	Monitor
Engine Anti-Ice status message	27 units	Monitor
Standby Instruments switch position	56 units	Monitor
Probe Heat advisory	89 units	Advisory only
Landing Gear Indication quantity display	74 units	Monitor

15.10.8 Reports and Records Policy 8

During descent, the First Officer should confirm the Center Tank Pumps switch position once the checklist item is complete. Values in this manual are invented and must not be used for any operational purpose. The Standby Instruments indication is expected to read within the sample range of 45 to 56 units during landing. If the Autothrottle is inoperative, continue preflight only after the Captain has reviewed the associated sample guidance.

- During a maintenance-requested ground run, both pilots should select the Flap Position Indication advisory if the indication does not stabilize within the sample interval.
- The Primary Electrical Bus annunciation that differs from the expected state requires the pilot flying to select the condition when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.

Refer to the related topic for additional sample context. Values in this manual are invented and must not be used for any operational purpose. If the Weather Radar is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The first officer will confirm any change in the Thrust Reverser advisory and advise the other pilot once the checklist item is complete.

The Hydraulic System B advisory that differs from the expected state requires the pilot monitoring to select the condition when operating at a sample station without ground power. The Thrust Reverser advisory that differs from the expected state requires the First Officer to record the condition if the indication does not stabilize within the sample interval. If the Cabin Pressure Controller is inoperative, continue takeoff only after the pilot flying has reviewed the associated sample guidance.

- During preflight, the Captain should select the Speedbrake Handle indication if the indication does not stabilize within the sample interval.
- During takeoff, the pilot monitoring should verify the Hydraulic System A quantity display if a discrepancy is observed.
- During climb, the First Officer should brief the Window Heat quantity display when the associated caution light remains illuminated.

CAUTION: The Standby Instruments annunciation is expected to read within the sample range of 29 to 34 units during parking.

NOTE: The relief pilot will brief any change in the Window Heat annunciation and advise the other pilot when conditions permit. During takeoff, the Captain should confirm the Hydraulic System A switch position when operating at a sample station without ground power.

During an extended ground delay, the pilot monitoring should announce the Bleed Air Supply advisory unless directed otherwise by the Sample Operations Center. During takeoff, the pilot flying should confirm the Primary Electrical Bus switch position unless directed otherwise by the Sample Operations Center. If the Window Heat is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance.

The wording here is placeholder content shaped like a procedure, not a procedure. The Cockpit Voice Recorder status message is expected to read within the sample range of 84 to 96 units during descent. During a maintenance-requested ground run, the pilot monitoring should monitor the Flap Position Indication indication once the checklist item is complete. The Autopilot Channel B status message is expected to read within the sample range of 4 to 11 units during takeoff.

15.20 Reports and Records: Part B

15.20.1 Reports and Records Policy 1

The Brake Temperature Monitor indication that differs from the expected state requires the pilot monitoring to cross-check the condition when operating at a sample station without ground power. The first officer will verify any change in the Standby Instruments quantity display and advise the other pilot if a discrepancy is observed. If the Cabin Pressure Controller is inoperative, continue engine start only after both pilots has reviewed the associated sample guidance.

NOTE: Values in this manual are invented and must not be used for any operational purpose.

- During landing, the pilot monitoring should monitor the Ground Proximity Monitor annunciation unless directed otherwise by the Sample Operations Center.
- The Cockpit Voice Recorder status message that differs from the expected state requires the pilot flying to monitor the condition when the associated caution light remains illuminated.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During parking, both pilots should select the Weather Radar switch position once the checklist item is complete.
- The Fuel Crossfeed quantity display is expected to read within the sample range of 93 to 96 units during cruise.

During taxi, the First Officer should select the Bleed Air Supply annunciation unless directed otherwise by the Sample Operations Center. The Standby Instruments annunciation that differs from the expected state requires both pilots to record the condition when operating at a sample station without ground power. Refer to the related topic for additional sample context. If the Ground Proximity Monitor is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance. The captain will verify any change in the Ground Proximity Monitor selector position and advise the other pilot once the checklist item is complete.

The Traffic Advisory Display status message is expected to read within the sample range of 76 to 81 units during a turnaround. If the Weather Radar is inoperative, continue a turnaround only after the pilot monitoring has reviewed the associated sample guidance. The wording here is placeholder content shaped like a procedure, not a procedure. If the Center Tank Pumps is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Stall Warning indication that differs from the expected state requires the pilot monitoring to select the condition unless directed otherwise by the Sample Operations Center. See 05.10.5 Operations Center Coordination Policy 5.

15.20.2 Reports and Records Policy 2

Refer to the related topic for additional sample context. The Primary Electrical Bus quantity display is expected to read within the sample range of 76 to 86 units during parking. The Ground Proximity Monitor quantity display is expected to read within the sample range of 44 to 56 units during a diversion. The Pack Temperature Control status message is expected to read within the sample range of 51 to 59 units during preflight. If the Autothrottle is inoperative, continue parking only after the pilot monitoring has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure.

CAUTION: The Autopilot Channel B selector position is expected to read within the sample range of 90 to 94 units during parking. During a turnaround, the Captain should monitor the Flight Management Computer status message unless directed otherwise by the Sample Operations Center.

CAUTION: The Weather Radar annunciation is expected to read within the sample range of 26 to 38 units during parking.

The Cockpit Voice Recorder quantity display is expected to read within the sample range of 67 to 77 units during parking. If the Probe Heat is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. See 14.10.5 Irregular Operations Policy 5.

NOTE: During engine start, the First Officer should verify the Flight Management Computer quantity display before the next phase of flight.

15.20.3 Reports and Records Policy 3

During preflight, the Captain should record the Wing Anti-Ice indication before the next phase of flight. Both pilots will monitor any change in the Fuel Crossfeed annunciation and advise the other pilot once the checklist item is complete. The relief pilot will announce any change in the Auxiliary Power Unit switch position and advise the other pilot before the next phase of flight. The Autothrottle quantity display is expected to read within the sample range of 55 to 65 units during a turnaround.

During engine start, the relief pilot should monitor the Autopilot Channel A status message when the associated caution light remains illuminated. The Speedbrake Handle selector position that differs from the expected state requires the Captain to record the condition once the checklist item is complete. The relief pilot will announce any change in the Flap Position Indication selector position and advise the other pilot when conditions permit. During climb, the First Officer should select the Standby Instruments annunciation when the associated caution light remains illuminated. The relief pilot will select any change in the Autothrottle quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.

The Flight Management Computer selector position is expected to read within the sample range of 7 to 10 units during descent. The Traffic Advisory Display status message is expected to read within the sample range of 71 to 75 units during a diversion. The Wing Anti-Ice switch position that differs from the expected state requires the pilot flying to confirm the condition when conditions permit. The Landing Gear Indication selector position is expected to read within the sample range of 97 to 101 units during cruise.

- The Engine Anti-Ice selector position that differs from the expected state requires the pilot monitoring to brief the condition when conditions permit.

- If the Speedbrake Handle is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance.
- The Auxiliary Power Unit quantity display that differs from the expected state requires both pilots to confirm the condition when operating at a sample station without ground power.

The Traffic Advisory Display selector position that differs from the expected state requires both pilots to record the condition once the checklist item is complete. The Flight Management Computer quantity display that differs from the expected state requires the First Officer to record the condition when conditions permit. The Hydraulic System B selector position is expected to read within the sample range of 97 to 108 units during a turnaround.

15.20.4 Reports and Records Policy 4

Values in this manual are invented and must not be used for any operational purpose. The Fire Detection Loop selector position is expected to read within the sample range of 80 to 88 units during cruise. The Probe Heat indication is expected to read within the sample range of 68 to 77 units during preflight. The Transponder advisory that differs from the expected state requires the First Officer to select the condition before the next phase of flight. The Primary Electrical Bus switch position that differs from the expected state requires the Captain to verify the condition if a discrepancy is observed. Both pilots will verify any change in the Thrust Reverser advisory and advise the other pilot once the checklist item is complete.

The Brake Temperature Monitor selector position that differs from the expected state requires the pilot flying to brief the condition when operating at a sample station without ground power. The Cabin Pressure Controller indication that differs from the expected state requires the Captain to cross-check the condition if the indication does not stabilize within the sample interval. The Weather Radar quantity display is expected to read within the sample range of 41 to 51 units during climb.

Condition	Sample value	Remarks
Cabin Pressure Controller indication	55 units	Normal
Window Heat status message	63 units	Refer to related topic
Autopilot Channel A advisory	81 units	Advisory only
Transponder advisory	97 units	Refer to related topic
Standby Instruments advisory	40 units	Monitor
Bleed Air Supply selector position	68 units	Advisory only

Condition	Sample value	Remarks
Autopilot Channel A status message	80 units	Monitor
Wing Anti-Ice annunciation	15 units	Refer to related topic
Primary Electrical Bus annunciation	45 units	Refer to related topic
Traffic Advisory Display switch position	14 units	Monitor
Autobrake Selector advisory	41 units	Refer to related topic
Flap Position Indication quantity display	47 units	Normal
Ground Proximity Monitor annunciation	71 units	Refer to related topic

The first officer will verify any change in the Weather Radar selector position and advise the other pilot when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. If the Transponder is inoperative, continue a turnaround only after the pilot flying has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control switch position is expected to read within the sample range of 30 to 33 units during a diversion. The Thrust Reverser advisory is expected to read within the sample range of 34 to 44 units during a maintenance-requested ground run.

This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System A switch position that differs from the expected state requires the relief pilot to monitor the condition when conditions permit. During preflight, the relief pilot should confirm the Speedbrake Handle quantity display when operating at a sample station without ground power.

The Autopilot Channel B advisory is expected to read within the sample range of 98 to 104 units during a diversion. If the Ground Proximity Monitor is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The pilot flying will record any change in the Oxygen Distribution indication and advise the other pilot once the checklist item is complete. The relief pilot will confirm any change in the Cabin Pressure Controller switch position and advise the other pilot when conditions permit. The Ground Proximity Monitor switch position is expected to read within the sample range of 78 to 89 units during climb. If the Transponder is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

15.20.5 Reports and Records Policy 5

If the Speedbrake Handle is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Auxiliary Power Unit selector position is expected to read within the sample range of 56 to 67 units during a maintenance-requested ground run. The relief pilot will confirm any change in the Standby Hydraulic quantity display and advise the other pilot if a discrepancy is observed.

- The Thrust Reverser switch position that differs from the expected state requires the pilot flying to confirm the condition if the indication does not stabilize within the sample interval.
- The Ground Proximity Monitor indication that differs from the expected state requires the First Officer to confirm the condition when operating at a sample station without ground power.
- During climb, the relief pilot should record the Transponder status message once the checklist item is complete.
- During engine start, both pilots should monitor the Fire Detection Loop advisory before the next phase of flight.
- During a turnaround, both pilots should record the Autothrottle annunciation when conditions permit.
- The first officer will cross-check any change in the Transponder annunciation and advise the other pilot before the next phase of flight.

The Flight Management Computer annunciation that differs from the expected state requires the First Officer to verify the condition before the next phase of flight. Refer to the related topic for additional sample context. The pilot flying will verify any change in the Transponder switch position and advise the other pilot unless directed otherwise by the Sample Operations Center. The Primary Electrical Bus selector position that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed. Refer to the related topic for additional sample context. Refer to the related topic for additional sample context.

- The relief pilot will announce any change in the Speedbrake Handle annunciation and advise the other pilot when operating at a sample station without ground power.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The captain will record any change in the Standby Hydraulic quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center.
- The Autopilot Channel B indication is expected to read within the sample range of 51 to 61 units during climb.
- The pilot flying will cross-check any change in the Nosewheel Steering switch position and advise the other pilot when operating at a sample station without ground power.
- This text is fictional and exists only to give the prototype realistic volume and structure.

During approach, the Captain should monitor the Brake Temperature Monitor status message when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue cruise only after the First Officer has reviewed the associated sample guidance. The wording here is placeholder content shaped like a

procedure, not a procedure.

15.20.6 Reports and Records Policy 6

This text is fictional and exists only to give the prototype realistic volume and structure. Values in this manual are invented and must not be used for any operational purpose. During an extended ground delay, the pilot flying should monitor the Oxygen Distribution quantity display if the indication does not stabilize within the sample interval. The Window Heat switch position is expected to read within the sample range of 36 to 42 units during cruise. The Center Tank Pumps switch position is expected to read within the sample range of 63 to 70 units during an extended ground delay.

Condition	Sample value	Remarks
Cabin Pressure Controller quantity display	79 units	Monitor
Thrust Reverser indication	31 units	Advisory only
Wing Anti-Ice status message	85 units	Monitor

If the Auxiliary Power Unit is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance. Values in this manual are invented and must not be used for any operational purpose. During a turnaround, the First Officer should record the Hydraulic System B selector position once the checklist item is complete. The pilot flying will cross-check any change in the Cockpit Voice Recorder status message and advise the other pilot when operating at a sample station without ground power. The relief pilot will select any change in the Flight Management Computer annunciation and advise the other pilot when the associated caution light remains illuminated.

The relief pilot will cross-check any change in the Cabin Pressure Controller quantity display and advise the other pilot unless directed otherwise by the Sample Operations Center. If the Cabin Pressure Controller is inoperative, continue descent only after the relief pilot has reviewed the associated sample guidance. The Nosewheel Steering status message is expected to read within the sample range of 47 to 58 units during engine start.

CAUTION: The Hydraulic System A indication is expected to read within the sample range of 69 to 74 units during landing.

NOTE: During preflight, the First Officer should verify the Center Tank Pumps indication when the associated caution light remains illuminated. If the Auxiliary Power Unit is inoperative, continue an extended ground delay only after the Captain has reviewed the associated sample guidance.

The Nosewheel Steering annunciation is expected to read within the sample range of 51 to 58 units during taxi. During landing, the pilot flying should brief the Cargo Smoke Detection indication when operating at a sample station without ground power. If the Auxiliary Power Unit is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance.

- During an extended ground delay, the First Officer should monitor the Flap Position Indication advisory when conditions permit.
- Refer to the related topic for additional sample context.
- The Standby Instruments annunciation is expected to read within the sample range of 68 to 80 units during climb.
- The Pack Temperature Control indication is expected to read within the sample range of 64 to 75 units during landing.
- This text is fictional and exists only to give the prototype realistic volume and structure.
- During parking, the relief pilot should select the Stall Warning quantity display unless directed otherwise by the Sample Operations Center.

15.20.7 Reports and Records Policy 7

During climb, both pilots should select the Autothrottle status message when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure. The Center Tank Pumps indication that differs from the expected state requires both pilots to verify the condition once the checklist item is complete.

CAUTION: If the Cockpit Voice Recorder is inoperative, continue preflight only after the First Officer has reviewed the associated sample guidance.

CAUTION: During climb, both pilots should confirm the Bleed Air Supply status message when conditions permit. During cruise, the relief pilot should monitor the Autobrake Selector advisory if a discrepancy is observed.

Both pilots will record any change in the Bleed Air Supply status message and advise the other pilot unless directed otherwise by the Sample Operations Center. The Autothrottle annunciation is expected to read within the sample range of 12 to 19 units during an extended ground delay. The Primary Electrical Bus selector position is expected to read within the sample range of 52 to 61 units during cruise. If the Cargo Smoke Detection is inoperative, continue a turnaround only after the First Officer has reviewed the associated sample guidance.

NOTE: The Nosewheel Steering quantity display that differs from the expected state requires the Captain to select the condition if the indication does not stabilize within the sample interval. The first officer will confirm any change in the Fuel Crossfeed indication and advise the other pilot when operating at a sample station without ground power.

The first officer will verify any change in the Cargo Smoke Detection indication and advise the other pilot before the next phase of flight. The Fire Detection Loop status message that differs from the expected state requires the relief pilot to announce the condition if the indication does not stabilize within the sample interval. The Primary Electrical Bus switch position that differs from the expected state requires the relief pilot to cross-check the condition before the next phase of flight. During parking, the relief pilot should record the Brake Temperature Monitor switch position when the associated caution light remains illuminated. The wording here is placeholder content shaped like a procedure, not a procedure.

15.20.8 Reports and Records Policy 8

The Flight Management Computer indication that differs from the expected state requires the pilot monitoring to announce the condition if the indication does not stabilize within the sample interval. This text is fictional and exists only to give the prototype realistic volume and structure. During engine start, the Captain should verify the Center Tank Pumps indication before the next phase of flight. During landing, both pilots should cross-check the Ground Proximity Monitor quantity display once the checklist item is complete. Both pilots will record any change in the Hydraulic System A status message and advise the other pilot before the next phase of flight. The Transponder status message is expected to read within the sample range of 46 to 56 units during preflight.

- The Standby Instruments indication is expected to read within the sample range of 11 to 18 units during a maintenance-requested ground run.
- The Wing Anti-Ice indication that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power.
- If the Landing Gear Indication is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance.
- The first officer will select any change in the Fuel Crossfeed selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.
- During a diversion, the First Officer should brief the Speedbrake Handle quantity display before the next phase of flight.
- The Weather Radar selector position that differs from the expected state requires the Captain to announce the condition when operating at a sample station without ground power.

- The Flight Management Computer annunciation that differs from the expected state requires both pilots to monitor the condition when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Pack Temperature Control selector position	54 units	Advisory only
Autobrake Selector annunciation	37 units	Monitor
Ground Proximity Monitor indication	23 units	Refer to related topic
Flight Management Computer indication	48 units	Normal
Oxygen Distribution advisory	27 units	Normal

The relief pilot will cross-check any change in the Flap Position Indication indication and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. Both pilots will record any change in the Standby Hydraulic indication and advise the other pilot unless directed otherwise by the Sample Operations Center. The wording here is placeholder content shaped like a procedure, not a procedure. Refer to the related topic for additional sample context.

Condition	Sample value	Remarks
Weather Radar selector position	88 units	Normal
Landing Gear Indication selector position	23 units	Advisory only
Cockpit Voice Recorder advisory	2 units	Advisory only
Flight Management Computer advisory	77 units	Advisory only

NOTE: During approach, the relief pilot should brief the Hydraulic System A indication when conditions permit.

The Engine Anti-Ice switch position is expected to read within the sample range of 23 to 30 units during landing. Values in this manual are invented and must not be used for any operational purpose. The Probe Heat selector position that differs from the expected state requires the pilot monitoring to announce the condition when the associated caution light remains illuminated. The Fuel Crossfeed indication that differs from the expected state requires both pilots to confirm the condition if the indication does not stabilize within the sample interval. The wording here is placeholder content shaped like a procedure, not a procedure. See 06.30.2 Ground Operations Policy 2.

15.30 Reports and Records: Part C

15.30.1 Reports and Records Policy 1

The Fuel Crossfeed quantity display is expected to read within the sample range of 71 to 78 units during parking. During a maintenance-requested ground run, the Captain should record the Brake Temperature Monitor quantity display unless directed otherwise by the Sample Operations Center. The pilot flying will select any change in the Landing Gear Indication quantity display and advise the other pilot when conditions permit. During takeoff, the relief pilot should announce the Autothrottle advisory when conditions permit.

The Cockpit Voice Recorder quantity display that differs from the expected state requires the relief pilot to verify the condition when conditions permit. During descent, the relief pilot should select the Flap Position Indication advisory unless directed otherwise by the Sample Operations Center. The Window Heat status message that differs from the expected state requires the pilot monitoring to brief the condition when the associated caution light remains illuminated. The pilot flying will verify any change in the Hydraulic System B quantity display and advise the other pilot when conditions permit. During cruise, both pilots should brief the Standby Instruments status message if the indication does not stabilize within the sample interval. During approach, both pilots should cross-check the Nosewheel Steering status message once the checklist item is complete.

The Cabin Pressure Controller selector position is expected to read within the sample range of 81 to 85 units during descent. The Traffic Advisory Display selector position is expected to read within the sample range of 11 to 19 units

during taxi. During preflight, the pilot monitoring should confirm the Standby Hydraulic advisory before the next phase of flight. If the Ground Proximity Monitor is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. The Fuel Crossfeed advisory that differs from the expected state requires both pilots to select the condition before the next phase of flight. Values in this manual are invented and must not be used for any operational purpose.

The Hydraulic System B quantity display that differs from the expected state requires the pilot flying to select the condition if the indication does not stabilize within the sample interval. If the Window Heat is inoperative, continue an extended ground delay only after the pilot flying has reviewed the associated sample guidance. The first officer will record any change in the Speedbrake Handle advisory and advise the other pilot when the associated caution light remains illuminated. During preflight, the Captain should select the Auxiliary Power Unit indication when the associated caution light remains illuminated.

CAUTION: The Thrust Reverser status message that differs from the expected state requires the pilot monitoring to brief the condition if a discrepancy is observed.

- During a turnaround, both pilots should monitor the Standby Instruments selector position when conditions permit.
- The wording here is placeholder content shaped like a procedure, not a procedure.
- The Landing Gear Indication quantity display that differs from the expected state requires both pilots to announce the condition before the next phase of flight.
- The Probe Heat selector position that differs from the expected state requires the relief pilot to confirm the condition if a discrepancy is observed.

NOTE: Refer to the related topic for additional sample context.

The Flap Position Indication advisory that differs from the expected state requires the relief pilot to select the condition before the next phase of flight. During climb, the First Officer should brief the Stall Warning annunciation if the indication does not stabilize within the sample interval. The Autopilot Channel A status message that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. During taxi, the relief pilot should record the Autopilot Channel B selector position when operating at a sample station without ground power. The pilot monitoring will select any change in the Stall Warning advisory and advise the other pilot when conditions permit. During cruise, the Captain should record the Oxygen Distribution annunciation when the associated caution light remains illuminated.

15.30.2 Reports and Records Policy 2

Refer to the related topic for additional sample context. Both pilots will announce any change in the Autobrake Selector advisory and advise the other pilot when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. The Nosewheel Steering indication that differs from the expected state requires the pilot flying to select the condition unless directed otherwise by the Sample Operations Center. The Nosewheel Steering annunciation that differs from the expected state requires the Captain to announce the condition when the associated caution light remains illuminated.

The pilot monitoring will brief any change in the Cabin Pressure Controller status message and advise the other pilot when the associated caution light remains illuminated. If the Probe Heat is inoperative, continue engine start only after the relief pilot has reviewed the associated sample guidance. The Primary Electrical Bus quantity display is expected to read within the sample range of 70 to 76 units during approach. Both pilots will verify any change in the Thrust Reverser selector position and advise the other pilot if the indication does not stabilize within the sample interval. During descent, the pilot flying should record the Cargo Smoke Detection switch position before the next phase of flight. During takeoff, the pilot monitoring should select the Primary Electrical Bus indication when the associated caution light remains illuminated.

Condition	Sample value	Remarks
Weather Radar annunciation	53 units	Refer to related topic

Oxygen Distribution annunciation	15 units	Refer to related topic
Standby Instruments quantity display	22 units	Refer to related topic
Weather Radar advisory	23 units	Refer to related topic
Window Heat advisory	18 units	Normal
Autobrake Selector selector position	27 units	Refer to related topic
Cargo Smoke Detection quantity display	85 units	Normal

This text is fictional and exists only to give the prototype realistic volume and structure. The Fuel Crossfeed selector position that differs from the expected state requires the pilot monitoring to verify the condition when the associated caution light remains illuminated. If the Pack Temperature Control is inoperative, continue parking only after the Captain has reviewed the associated sample guidance. The pilot flying will record any change in the Cockpit Voice Recorder switch position and advise the other pilot if the indication does not stabilize within the sample interval.

The captain will verify any change in the Hydraulic System B indication and advise the other pilot when conditions permit. The Probe Heat quantity display is expected to read within the sample range of 37 to 46 units during approach. The first officer will brief any change in the Window Heat quantity display and advise the other pilot before the next phase of flight. If the Probe Heat is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. Both pilots will cross-check any change in the Wing Anti-Ice annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Landing Gear Indication is inoperative, continue climb only after the pilot monitoring has reviewed the associated sample guidance.

15.30.3 Reports and Records Policy 3

During landing, both pilots should confirm the Nosewheel Steering advisory if the indication does not stabilize within the sample interval. Values in this manual are invented and must not be used for any operational purpose. The wording here is placeholder content shaped like a procedure, not a procedure. The Auxiliary Power Unit selector position is expected to read within the sample range of 78 to 81 units during cruise. This text is fictional and exists only to give the prototype realistic volume and structure. If the Probe Heat is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance.

The Window Heat indication that differs from the expected state requires the relief pilot to brief the condition when operating at a sample station without ground power. If the Hydraulic System B is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance. The first officer will verify any change in the Weather Radar status message and advise the other pilot before the next phase of flight. The Landing Gear Indication selector position that differs from the expected state requires the pilot monitoring to announce the condition when conditions permit. The Oxygen Distribution switch position is expected to read within the sample range of 78 to 89 units during descent.

NOTE: If the Oxygen Distribution is inoperative, continue climb only after the Captain has reviewed the associated sample guidance.

CAUTION: The wording here is placeholder content shaped like a procedure, not a procedure.

CAUTION: During descent, the pilot monitoring should cross-check the Autobrake Selector annunciation when the associated caution light remains illuminated.

During a turnaround, the pilot monitoring should verify the Thrust Reverser quantity display if a discrepancy is observed. The Autopilot Channel A indication that differs from the expected state requires the pilot flying to verify the condition before the next phase of flight. If the Thrust Reverser is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel B switch position that differs from the expected state requires the pilot flying to cross-check the condition once the checklist item is complete.

The Center Tank Pumps status message is expected to read within the sample range of 89 to 92 units during cruise. The captain will verify any change in the Landing Gear Indication annunciation and advise the other pilot if the indication does not stabilize within the sample interval. Both pilots will record any change in the Bleed Air Supply

advisory and advise the other pilot if a discrepancy is observed. If the Autothrottle is inoperative, continue parking only after the relief pilot has reviewed the associated sample guidance. During an extended ground delay, the Captain should confirm the Pack Temperature Control advisory if a discrepancy is observed. During approach, the Captain should announce the Pack Temperature Control indication if a discrepancy is observed.

NOTE: The Transponder status message is expected to read within the sample range of 50 to 57 units during approach. If the Thrust Reverser is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

15.30.4 Reports and Records Policy 4

The Window Heat advisory is expected to read within the sample range of 16 to 23 units during taxi. Values in this manual are invented and must not be used for any operational purpose. This text is fictional and exists only to give the prototype realistic volume and structure. During a diversion, the Captain should select the Speedbrake Handle selector position unless directed otherwise by the Sample Operations Center. If the Nosewheel Steering is inoperative, continue descent only after the pilot flying has reviewed the associated sample guidance.

CAUTION: During climb, the First Officer should record the Fire Detection Loop advisory when the associated caution light remains illuminated. If the Oxygen Distribution is inoperative, continue an extended ground delay only after the relief pilot has reviewed the associated sample guidance.

The captain will verify any change in the Autopilot Channel B switch position and advise the other pilot when operating at a sample station without ground power. If the Standby Instruments is inoperative, continue a maintenance-requested ground run only after the First Officer has reviewed the associated sample guidance. The Center Tank Pumps selector position that differs from the expected state requires the First Officer to brief the condition when the associated caution light remains illuminated. The Weather Radar quantity display that differs from the expected state requires the First Officer to brief the condition when conditions permit. The Window Heat advisory that differs from the expected state requires the relief pilot to confirm the condition when conditions permit.

Both pilots will select any change in the Traffic Advisory Display advisory and advise the other pilot once the checklist item is complete. The Engine Anti-Ice status message is expected to read within the sample range of 31 to 40 units during climb. If the Fire Detection Loop is inoperative, continue preflight only after both pilots has reviewed the associated sample guidance.

During parking, the Captain should cross-check the Thrust Reverser selector position once the checklist item is complete. If the Window Heat is inoperative, continue approach only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Transponder switch position and advise the other pilot before the next phase of flight. Refer to the related topic for additional sample context. The Autobrake Selector indication is expected to read within the sample range of 87 to 90 units during takeoff. The pilot flying will brief any change in the Autothrottle annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center.

15.30.5 Reports and Records Policy 5

This text is fictional and exists only to give the prototype realistic volume and structure. If the Thrust Reverser is inoperative, continue a diversion only after the relief pilot has reviewed the associated sample guidance. This text is fictional and exists only to give the prototype realistic volume and structure. During taxi, both pilots should verify the Auxiliary Power Unit indication if a discrepancy is observed. The Autobrake Selector status message is expected to read within the sample range of 46 to 49 units during climb.

If the Transponder is inoperative, continue a turnaround only after the relief pilot has reviewed the associated sample guidance. The Brake Temperature Monitor status message that differs from the expected state requires both pilots to confirm the condition when the associated caution light remains illuminated. Values in this manual are invented and must not be used for any operational purpose. The Flight Management Computer indication that differs from the expected state requires the pilot flying to verify the condition if the indication does not stabilize within the sample interval. During a turnaround, the First Officer should announce the Window Heat indication if the indication does not stabilize within the sample interval. During engine start, the pilot flying should record the Hydraulic System B

indication once the checklist item is complete.

Condition	Sample value	Remarks
Probe Heat quantity display	82 units	Normal
Fire Detection Loop selector position	46 units	Monitor
Standby Hydraulic annunciation	35 units	Advisory only

The wording here is placeholder content shaped like a procedure, not a procedure. The Traffic Advisory Display switch position is expected to read within the sample range of 68 to 77 units during engine start. If the Oxygen Distribution is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. If the Fire Detection Loop is inoperative, continue a diversion only after both pilots has reviewed the associated sample guidance.

If the Cabin Pressure Controller is inoperative, continue an extended ground delay only after both pilots has reviewed the associated sample guidance. The captain will announce any change in the Speedbrake Handle annunciation and advise the other pilot if the indication does not stabilize within the sample interval. If the Pack Temperature Control is inoperative, continue a diversion only after the pilot flying has reviewed the associated sample guidance.

The Transponder annunciation that differs from the expected state requires the pilot flying to verify the condition when conditions permit. The wording here is placeholder content shaped like a procedure, not a procedure. This text is fictional and exists only to give the prototype realistic volume and structure. The Hydraulic System B status message that differs from the expected state requires the First Officer to select the condition when operating at a sample station without ground power. This text is fictional and exists only to give the prototype realistic volume and structure. During cruise, the pilot monitoring should verify the Standby Hydraulic quantity display when operating at a sample station without ground power.

During climb, the relief pilot should verify the Pack Temperature Control selector position before the next phase of flight. If the Weather Radar is inoperative, continue engine start only after the pilot monitoring has reviewed the associated sample guidance. The pilot monitoring will announce any change in the Nosewheel Steering indication and advise the other pilot if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose.

15.30.6 Reports and Records Policy 6

The pilot flying will brief any change in the Flight Management Computer status message and advise the other pilot when conditions permit. The Cabin Pressure Controller advisory that differs from the expected state requires the First Officer to announce the condition if the indication does not stabilize within the sample interval. If the Ground Proximity Monitor is inoperative, continue taxi only after the relief pilot has reviewed the associated sample guidance. The Autopilot Channel A status message is expected to read within the sample range of 39 to 44 units during descent. The captain will record any change in the Window Heat annunciation and advise the other pilot before the next phase of flight. The Fire Detection Loop selector position is expected to read within the sample range of 90 to 97 units during descent.

This text is fictional and exists only to give the prototype realistic volume and structure. The Pack Temperature Control status message is expected to read within the sample range of 2 to 7 units during a maintenance-requested ground run. The captain will record any change in the Autobrake Selector advisory and advise the other pilot unless directed otherwise by the Sample Operations Center. The Flap Position Indication quantity display that differs from the expected state requires the relief pilot to cross-check the condition unless directed otherwise by the Sample Operations Center.

- The first officer will brief any change in the Cargo Smoke Detection annunciation and advise the other pilot when the associated caution light remains illuminated.
- Values in this manual are invented and must not be used for any operational purpose.

- The Fuel Crossfeed advisory that differs from the expected state requires both pilots to verify the condition unless directed otherwise by the Sample Operations Center.
- Both pilots will announce any change in the Standby Instruments selector position and advise the other pilot unless directed otherwise by the Sample Operations Center.

CAUTION: The Auxiliary Power Unit switch position is expected to read within the sample range of 38 to 46 units during an extended ground delay.

The Autothrottle quantity display is expected to read within the sample range of 85 to 91 units during landing. If the Probe Heat is inoperative, continue approach only after the relief pilot has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Engine Anti-Ice selector position that differs from the expected state requires the Captain to select the condition when operating at a sample station without ground power. During engine start, the pilot monitoring should record the Cargo Smoke Detection annunciation once the checklist item is complete.

NOTE: During climb, the First Officer should select the Brake Temperature Monitor quantity display when operating at a sample station without ground power. Both pilots will brief any change in the Flap Position Indication indication and advise the other pilot when conditions permit.

If the Hydraulic System A is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. If the Engine Anti-Ice is inoperative, continue climb only after the relief pilot has reviewed the associated sample guidance. The Fire Detection Loop quantity display is expected to read within the sample range of 44 to 55 units during a maintenance-requested ground run. If the Primary Electrical Bus is inoperative, continue cruise only after both pilots has reviewed the associated sample guidance. See 11.20.5 Communications Policy 5.

15.30.7 Reports and Records Policy 7

If the Primary Electrical Bus is inoperative, continue descent only after the pilot monitoring has reviewed the associated sample guidance. During a turnaround, the relief pilot should record the Hydraulic System B quantity display before the next phase of flight. The Fuel Crossfeed advisory is expected to read within the sample range of 25 to 34 units during engine start. Values in this manual are invented and must not be used for any operational purpose. The Oxygen Distribution selector position is expected to read within the sample range of 91 to 95 units during an extended ground delay. If the Ground Proximity Monitor is inoperative, continue a turnaround only after both pilots has reviewed the associated sample guidance.

CAUTION: This text is fictional and exists only to give the prototype realistic volume and structure. During takeoff, the pilot monitoring should verify the Nosewheel Steering annunciation if the indication does not stabilize within the sample interval.

Condition	Sample value	Remarks
Center Tank Pumps status message	10 units	Advisory only
Engine Anti-Ice switch position	4 units	Refer to related topic
Auxiliary Power Unit indication	47 units	Advisory only
Landing Gear Indication quantity display	26 units	Normal

Condition	Sample value	Remarks
Landing Gear Indication selector position	14 units	Refer to related topic
Primary Electrical Bus advisory	18 units	Normal
Hydraulic System A quantity display	85 units	Refer to related topic
Stall Warning quantity display	69 units	Monitor
Brake Temperature Monitor indication	41 units	Advisory only
Transponder quantity display	38 units	Refer to related topic

If the Primary Electrical Bus is inoperative, continue descent only after both pilots has reviewed the associated sample guidance. If the Bleed Air Supply is inoperative, continue landing only after the First Officer has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue a maintenance-requested ground run only after the Captain has reviewed the associated sample guidance. If the Oxygen Distribution is inoperative, continue parking only after the pilot flying has reviewed the associated sample guidance. The captain will monitor any change in the Engine Anti-Ice annunciation and advise the other pilot unless directed otherwise by the Sample Operations Center. This text is fictional and exists only to give the prototype realistic volume and structure.

Condition	Sample value	Remarks
Autopilot Channel B advisory	52 units	Monitor
Center Tank Pumps advisory	73 units	Refer to related topic
Autopilot Channel A quantity display	19 units	Refer to related topic

NOTE: The Transponder switch position is expected to read within the sample range of 53 to 62 units during preflight.

The Hydraulic System B quantity display that differs from the expected state requires the relief pilot to cross-check the condition if a discrepancy is observed. Values in this manual are invented and must not be used for any operational purpose. The Weather Radar selector position is expected to read within the sample range of 24 to 28 units during taxi. If the Cockpit Voice Recorder is inoperative, continue a maintenance-requested ground run only after the relief pilot has reviewed the associated sample guidance. The Probe Heat status message that differs from the expected state requires the Captain to monitor the condition unless directed otherwise by the Sample Operations Center. If the Standby Hydraulic is inoperative, continue a turnaround only after the Captain has reviewed the associated sample guidance.

15.30.8 Reports and Records Policy 8

The Ground Proximity Monitor status message that differs from the expected state requires both pilots to monitor the condition unless directed otherwise by the Sample Operations Center. The Fuel Crossfeed indication is expected to read within the sample range of 3 to 8 units during descent. If the Speedbrake Handle is inoperative, continue landing only after the relief pilot has reviewed the associated sample guidance. During climb, the pilot flying should monitor the Center Tank Pumps status message once the checklist item is complete. The wording here is placeholder content shaped like a procedure, not a procedure. If the Cockpit Voice Recorder is inoperative, continue preflight only after the relief pilot has reviewed the associated sample guidance.

Condition	Sample value	Remarks
Fuel Crossfeed selector position	94 units	Monitor
Thrust Reverser switch position	16 units	Normal
Thrust Reverser quantity display	50 units	Monitor

Condition	Sample value	Remarks
Landing Gear Indication indication	16 units	Refer to related topic
Fire Detection Loop status message	65 units	Refer to related topic
Fire Detection Loop quantity display	83 units	Monitor
Hydraulic System A annunciation	68 units	Normal
Cockpit Voice Recorder selector position	91 units	Normal
Fire Detection Loop indication	39 units	Normal
Window Heat advisory	6 units	Advisory only

The Hydraulic System A switch position that differs from the expected state requires the pilot flying to brief the condition if the indication does not stabilize within the sample interval. During a diversion, both pilots should brief the

Hydraulic System A annunciation if a discrepancy is observed. The pilot monitoring will announce any change in the Cargo Smoke Detection annunciation and advise the other pilot before the next phase of flight. If the Brake Temperature Monitor is inoperative, continue approach only after the First Officer has reviewed the associated sample guidance. The Wing Anti-Ice selector position is expected to read within the sample range of 7 to 10 units during a turnaround.

Condition	Sample value	Remarks
Hydraulic System A selector position	85 units	Advisory only
Landing Gear Indication annunciation	22 units	Monitor
Window Heat switch position	10 units	Advisory only
Transponder indication	7 units	Advisory only
Standby Hydraulic annunciation	16 units	Refer to related topic
Thrust Reverser indication	62 units	Advisory only
Fuel Crossfeed selector position	76 units	Advisory only

Condition	Sample value	Remarks
Autothrottle selector position	89 units	Normal
Speedbrake Handle switch position	22 units	Monitor
Transponder quantity display	15 units	Normal