To enter the settings menu, simultaneously press both buttons. Press right button to go through menu items and press the left button to increment values.

Menu Item	Action
Н	Set Hours (00 – 23)
М	Set Minutes (00 – 59)
у	Set Years (2000 – 2050)
m	Set Months (01 – 12)
d	Set Day (01 – 31)
%	12/24h time format (00 = $12h$ time format, 01 = $24h$ time format)
f	Font style (show # of font in select font style 01 - 05)
:	Dot style (0 - hidden, 1 - shown, 2 - blinking)
b	Backlight intensity (00 - 15)
R	Font turning 1 (turn each character; 00 = off, 01 = on)
r	Font turning 2 (turn all display; 00 = off, 01 = on)
U	Turn font Upside-down (00 = off, 01 = on)
V	Vertical mode (00 - standard horizontal, 01 - vertical mode)
i	Invert display (00 - no invert, 01 - invert display)
Strt	Reset seconds (set to 00) after releasing the button and then show the actual time

December 2022