

TROUBLESHOOTING

Exhaust Smoke

White smoke from the exhaust when the engine is cold is normal condensation and will stop once the engine warms up. Persistent thick white smoke may indicate engine oil or coolant entering the combustion chamber. Check the engine oil level. If smoke persists, contact an authorised service centre.

Black smoke indicates a rich fuel mixture or a clogged air filter. Inspect the air filter element.

ENGINE DOES NOT START

Check that the engine kill switch is in the RUN position. Ensure there is sufficient fuel in the tank.

Check that the side stand is up and the transmission is in neutral. If the battery is weak, the starter motor will crank slowly; charge the battery.

MAINTENANCE

Engine Oil Level Check

Park the motorcycle upright on level ground. Run the engine for 2 minutes and stop. Wait 1 minute. The oil level must be between the MIN and MAX marks on the dipstick. Use SAE 15W-50 oil.

WARNING: Do not overfill.

CLUTCH

Clutch lever free play should be 2-3 mm at the lever end. Adjust using the adjuster at the lever.