

Welcome

Thank you for choosing the Acme Roadster 150.
Read this manual before riding.

Specifications

Fuel tank capacity: 11 litres

Curb weight: 142 kg

Spark plug gap: 0.8 - 0.9 mm

Battery: 12 V, 5 Ah

Spark plug

CPR8EA-9 (NGK)

BATTERY

YTZ5S / GTZ5S

Tyre Pressure

Front: 25 psi

Rear: 29 psi (solo), 32 psi (with pillion)

Check tyre pressure when tyres are cold.

Checking Engine Oil

Park the motorcycle on the centre stand on level ground.
Remove the dipstick, wipe it and reinsert it without screwing in.
The oil level should be between the upper and lower marks.
Recommended oil: SAE 10W-30 JASO MA.

Clutch Lever Play

Clutch lever free play should be 10 - 20 mm at the lever tip.
Adjust using the adjuster at the clutch lever.

Trouble Shooting

Problem: Engine does not start

Possible cause: Fuel tank empty. Remedy: Refuel.

Possible cause: Engine stop switch in OFF position. Remedy: Set switch to RUN.

Possible cause: Battery discharged. Remedy: Charge the battery or contact a dealer.

Problem: Headlamp dim

Possible cause: Weak battery. Remedy: Contact an authorised dealer.

Periodic Maintenance Schedule

Carry out the following at the odometer reading shown, whichever comes first.

I = Inspect R = Replace C = Clean L = Lubricate

Item	750	3,000	6,000	9,000	12,000
Months	1	4	8	12	16
Engine oil	R	I	R	I	R
Oil filter	R		R		R
Spark plug		I		R	
Air filter element	C	C	R	C	R
Drive chain	L	L	L	L	L

Odometer readings are in km.

Periodic Maintenance Schedule

Items	Pre-ride Check						Refer to page
	× 1,000 km	1	6	12	18		
Brake shoes	I		I		I		.
Clutch cable	I	I	I	I	I		7
Drive chain lube	I	500 km: I					5