

Fusion Compiler Tool Invocation Commands

Version X-2025.06-SP3, March 2026



Contents

1.	Fusion Compiler Tool Invocation Commands	3
	fc_shell	3

1

Fusion Compiler Tool Invocation Commands

This document describes the tool invocation commands supported by the Fusion Compiler tool.

fc_shell

Runs the Fusion Compiler tool.

Syntax

fc_shell

```
[-file file_name]  
[-no_init]  
[-no_local_init]  
[-no_home_init]  
[-no_log]  
[-output_log_file file_name]  
[-no_motd]  
[-x command_string]  
[-version]  
[-batch]  
[-gui]
```

Data Types

<i>file_name</i>	string
<i>display_env_var</i>	string
<i>command_string</i>	string

Arguments

-file file_name

Runs the specified script before displaying the initial *fc_shell* prompt.

If the last command in the script file is *quit*, no prompt is displayed and the command shell exits after running the script.

`-no_init`

Prevents the execution of any .synopsys_fc.setup startup files before displaying the initial fc_shell prompt. This option is only used when you want to include a command log or other script file to reproduce a previous fc_shell session.

Include the script file either by using the -file option or by issuing the include command from within the fc_shell.

`-no_local_init`

Does not run any .synopsys_fc.setup startup files from local directory path before displaying the initial fc_shell prompt.

`-no_home_init`

Does not run any home directory setup files before displaying the initial fc_shell prompt.

`-no_log`

Does not create any log files such as command log file and output log file.

`-output_log_file file_name`

Specifies the name of the output log file for the session.

`-no_motd`

Does not print the message of the day.

`-x command_string`

Executes the fc_shell commands before displaying the initial fc_shell prompt. You can enter multiple commands by separating each command with a semicolon and enclosing the entire set of commands with quotation marks.

If you also use the -file option, the tool executes the commands specified in the -x option first, and then executes the script specified in the -file option. If the last statement entered is *quit*, no prompt is displayed and the command shell exits after running the commands.

`-version`

Displays the version number and build date information, and then exits.

`-batch`

Exits after processing -file *file_name* and/or -x *command_string*. This also sets the gui.batch_x_display option to offscreen. If you start the GUI in a batch run using this setting, it does not require a DISPLAY and no windows are shown on your DISPLAY. This is recommended when generating screenshots in your batch flows.

`-gui`

Invokes the Fusion Compiler GUI immediately upon startup.

Description

This command starts the Fusion Compiler shell, `fc_shell`, which interprets and executes Fusion Compiler commands. The `fc_shell` command interpreter is based on Tool Command Language (Tcl).

The shell executes commands until it is terminated by a *quit* or *exit* command. In interactive mode, you can also terminate the `fc_shell` session by typing Ctrl+d.

To cancel (interrupt) the command currently executing in `fc_shell`, type Ctrl+c. The time it takes for a command to process an interrupt (stop what it is doing and continue with the next command) depends upon the size of the design and the type of command. If you type Ctrl+c three times before a command responds to the interrupt, `fc_shell` displays the following message and exits:

Information: Process terminated by interrupt.