1. Create project
2. File name
3. Create a folder
4. Press Next
5. Rtl project default
5. Create file
6. Verilog
7. Name.v
8. Constain file again we have to create a file
9. Connect the board and the switch have different name and also led's
10. Give a name to the constraint file
11. Press Next 2 times
12. Searc xc7a35tcpg236-1
13. Press Next
14. Finish(family artrix 7)
15. Ulla create aitu project manager la nikkum
16. Press ok and yes(define modules)
17. Ledflash ah double click panni code write pannanum
18.code writr pannanum constraints ku(three steps irukku)
19. Synthesis (run synthesis)
20. Run implementation
21. After sometime it will show some options you have to select runbitstream(it will take some time)
22. Open hardware manager in the left side click
23. Click Open target and right click and select auto connect
24. Program device (automatic ah varum)
25. Then after clicking program then it will be send output to the board.

1. File new create a folder
2. File new source verilog
3. Write the program and save the file with the same name we used for the module in the program
4. Compile this file and load the module
5. View signals
6. Signals-> edit force and change the values and in that view click wave signals in region or selected signals
7. After editing the values click run on the wave window
8. Repeat the process for various inputs

____Modelsim Software___

1. Mp lap ide open
2. Project - project wizard
3. Create a folder and file in desktop
4. Click file new
5. Write the program
6. Add the program in the source
7. Build or Press F10
8. Then open Pic tiny bootloader

9. Then browse the file and choose the file (hex)
10. Then check the port and press reset in pic controller
11. Then writeflash and press reset that's all u B
____Mp Lab Software ,ithu vanthu PIC controller ku___

1. Create new project
2. RL78
3. R5F100GE(48 pin)
4. Desktop la make new folder
5. Press Create
6. Clock generator left side , double click then
7. Fix setting
8. Clock setting la enable high speed system clock(fmain) setting athula Fmx
9. OCO disable
10. Enable external oscillator
11. 20 in the Mhz box
12. Watchdog timer in the left side
13. Enable Subsystem clock
14. Watchdog timer unused
15. Select port on left side then go to port 6
16. Port 63 port 62 Select out
17. Code generate _____