USER MANUAL · VERSION 2.4

Legion Go Toolbox

The Lenovo Legion Go's hardware controls in the Steam Quick Access menu: power and automatic TDP, fan, lights, battery, buttons and gyro.

Home | Power | Fan | Lights | Controls | Gyro

For the Lenovo Legion Go (83E1) on SteamOS with Decky Loader

MIT licensed

Contents

1 **Before you start**
What the plugin does, what it needs, what it will not touch

2 **Installing, updating and removing**
Decky developer mode, moving over from Legion Go Gyro

3 **Finding your way around**
Tabs, status lines, "not available" messages

4 **Home and battery**
Overview, 80 % charge limit, reset

5 **Power**
Power modes, TDP, Auto TDP for a frame rate, per-game profiles

6 **Fan**
Custom curve, presets, full speed, safety limits

7 **Lights**
Stick lights, power-button light

8 **Controls**
Swapped menu buttons, back-button remapping, touchpad

9 **Gyro**
Gyro in Steam games, gyro in emulators (Wii Sports, Switch Sports)

10 **Troubleshooting**
Symptoms and fixes

11 **Reference**
Files, limits, what is re-applied when, credits

1 Before you start

Legion Go Toolbox is a Decky Loader plugin. It puts the hardware settings Lenovo's Windows app (Legion Space) offers, plus a few extras, into the Quick Access menu of SteamOS. Everything is arranged in six tabs.

Three promises

- **Nothing changes until you switch it on.** A fresh install leaves power, fan, lights, buttons and battery exactly as they were. The one exception is the controller type Steam sees, which defaults to a Steam Deck controller so Steam offers gyro (see chapter 9).
- **Every change is checked.** After writing a setting the plugin reads it back. If the hardware did not accept it you see a *Problem* line with the reason instead of a switch that looks on but does nothing.
- **Settings stay applied.** They are applied again at start-up, after sleep, when a controller reconnects, and when something else (Steam, another tool, the firmware) changes them back - also while the menu is closed.

What you need

Item	Details
Device	Lenovo Legion Go (model 83E1). Legion Go 2 and Legion Go S are recognised for the parts known to be identical (power limits, charge limit, power light); everything else stays off on those.
System	SteamOS with Decky Loader installed.
For the fan curve only	The `acpi_call` kernel module (see chapter 6). Everything else works on a stock SteamOS.

What each feature depends on

Feature	Works when
Gyro, stick lights, remapping, touchpad	The controllers are connected (attached or detached)
Power-button light	Always on a Legion Go; three different ways to reach it are tried
80 % charge limit	SteamOS exposes the battery's *Long Life* mode (current versions do)
Power modes and TDP	SteamOS has Lenovo's power-limit driver (current versions do)
Auto TDP	The above, in Gaming Mode (the frame rate is read from the SteamOS compositor)
Swapped menu buttons, gyro in Steam games	InputPlumber is running (it is on SteamOS)
Custom fan curve	**The `acpi_call` module is installed - SteamOS does not include it**

One controller of each thing. Two plugins steering the same hardware keep overwriting each other. Remove (or switch off) SimpleDeckyTDP, Legion Center, HueSync, DeckyPlumber, LegionGoRemapper and the stand-alone Legion Go Gyro before using the matching tab here. Also turn off Steam's own *TDP limit* in the Performance menu if you use the Power tab.

2 Installing, updating and removing

Install

1. Install Decky Loader if you do not have it yet.
2. If **Legion Go Gyro** is installed, uninstall it first. Its tuning and calibration are copied over automatically the first time Legion Go Toolbox starts.
3. Copy `legion-go-toolbox.zip` onto the Legion Go (Downloads is fine).
4. In Gaming Mode open the Quick Access menu … → Decky (plug icon) → gear icon → **General** → turn on **Developer mode**.
5. In the same settings open **Developer** → **Install plugin from ZIP file** → choose the zip.
6. Open **Legion Go Toolbox** from the Decky list.

Update

Install the new zip the same way. Decky replaces the old version; your settings are kept and carried forward automatically (for example, version 2.2 moves an untouched controller type to the new Steam Deck default and adds the default swap layout).

Remove

Uninstall it from Decky's plugin list. Before that, switch off *Manage power*, *Custom fan curve* and *Swap menu buttons* if you want the firmware and SteamOS defaults back straight away - the plugin hands these back to the firmware when they are switched off. Lights, remapping and the charge mode are stored in the hardware and stay as last set.

3 Finding your way around

The plugin opens on **Home**. Switch tabs with LB / RB or by tapping the icons along the top.

Icon	Tab	What it holds
House	**Home**	One status line per module (tap one to jump there), battery and 80 % charge limit, device, version, reset
Lightning bolt	**Power**	Power mode, TDP, Auto TDP for a frame rate, per-game profiles, CPU boost
Fan	**Fan**	Custom fan curve, presets, full speed, temperature
Light bulb	**Lights**	Stick lights, power-button light
Gamepad	**Controls**	Swapped menu buttons, back-button remapping, touchpad
Rotating screen	**Gyro**	Gyro in Steam games and per-controller gyro for emulators

Reading the screens

- **"... is not available"** - the device or SteamOS cannot do this. The text underneath names the reason, and where there is a way to get it, says how.
- **Problem** (orange) - the last change did not take effect; the text is what the hardware or system reported.
- **Now** - what the hardware is actually doing at this moment, read from the device, not what was requested.

Changes are saved as you make them; there is no Save button.

4 Home and battery

Overview

Five rows - Power, Fan, Lights, Buttons, Gyro - each show a one-line summary, for example *Custom · 12 W · auto · 60 fps*. If a module has a problem, its row shows that instead. Select a row to open its tab.

Battery

Shows the charge level and whether it is charging.

Limit charge to 80 %

Turns on the battery's *Long Life* mode: charging stops at about 80 %. Worth it if the Legion Go spends a lot of time on the charger. The setting is stored in the firmware and survives reboots; turn it off before a long trip to get a full charge.

About

Reset hardware settings returns Power, Fan, Lights, Battery and Controls to their defaults (all off, Steam Deck controller, default swap layout). It does not touch the gyro's calibration and tuning - those have their own reset in the Gyro tab's advanced options.

5 Power

> **First:** open Steam's Performance menu and turn off its *TDP limit*. If both set the power limit they keep overwriting each other.

Manage power

Hands power control to the plugin. The **Now** line shows the firmware's actual mode and limit. When you switch *Manage power* off again, the device is put back into the firmware's *Balanced* mode.

Power mode

Mode	What happens
Custom (set the watts)	You choose the TDP with a slider, within the range the firmware allows. Needed for Auto TDP and for a custom fan curve.
Quiet / Balanced / Performance	The firmware's own modes, the same as Legion Space's. The firmware picks limits and fan curve itself.

Auto TDP for a frame rate

You choose a frame rate; the plugin keeps the power as low as possible while still reaching it. Lower power means a cooler, quieter device and longer battery life.

Setting it up

1. Power mode: **Custom**.
2. Turn on **Auto TDP for a frame rate**.
3. Choose a **Target frame rate** (30, 40, 45, 50, 60, 72, 90, 120 or 144 fps).
4. Set **Maximum TDP** - the most it may use - and **Minimum TDP** - the least it may use.
5. Set a frame limit at the same number, in the game or in Steam's Performance menu. Without a limit the game simply runs as fast as it can and Auto TDP brings the power down until it reaches the target.

How it decides

Situation	What Auto TDP does
Frame rate below 90 % of the target	Adds 3 W at once
Frame rate between 90 and 97 % of the target	Adds 1 W
Target held for 6 seconds	Tries 1 W less
That lower setting cannot hold the target	Goes straight back and leaves that setting alone for 45 seconds - longer each time it fails again, up to 10 minutes. This is what makes it settle instead of bouncing.
Just after a change	Ignores 2.5 seconds of readings while the game adjusts
Menu, loading screen, paused game	Keeps the last setting
No game running	Uses your Maximum TDP

Status line

Shows	Meaning
at the lowest power that holds the target	Settled - this is the result you want
target held – trying less power	Testing one watt lower
below target – adding power	The game needs more power right now
at your maximum	The target needs more than your Maximum TDP allows: raise the maximum or lower the target
at your minimum	The game is light; it reaches the target at your Minimum TDP
waiting for the game to draw frames	No frame rate to measure (menu, paused, not in Gaming Mode)

Separate settings per game

With this on, the profile you edit belongs to the game that is running, and is used whenever that game runs. Games without their own profile use the default one. **Use the default for this game** deletes the game's profile.

CPU boost

Turning boost off keeps the processor at its base clock. It runs cooler and quieter and often costs only a few frames, especially together with a frame limit.

6 Fan

> **Requirement.** The Legion Go only accepts a fan curve through a Lenovo firmware call, and Linux can make that call only with the `acpi_call` kernel module. SteamOS does not include it, and this plugin deliberately does not install kernel modules (that means modifying the read-only system after every SteamOS update). If the module is present - for example installed with Legion Center's *Install Fan Support*, or on Bazzite - the curve editor appears by itself. Without it the fan follows the firmware's own curve, which is safe.

Custom fan curve

The firmware keeps control of the fan and of overheating protection; the plugin only changes the curve it follows. The firmware uses a custom curve only in the *Custom* power mode. If the Power tab has a firmware mode selected, the Fan tab says *Not in use right now*.

Presets

Fan level per temperature (°C). The firmware's scale goes up to 115.

Preset	10	20	30	40	50	60	70	80	90	100
Silent	44	48	55	60	71	79	87	87	100	100
Balanced	44	50	58	66	78	88	96	100	105	110
Cool	50	56	64	74	86	96	105	110	115	115

Pick a preset, or move the ten *At … °C* sliders yourself (the preset then shows *Custom*). The small graph shows the curve and, as a dashed line, the current temperature.

Safety limits

- No point can be set below Lenovo's own minimum for the Legion Go - the *Silent* row above. Handheld Daemon enforces the same limit.
- The curve always rises with temperature: raising a point lifts the points after it, lowering a point lowers the ones before it.
- Saved curves from older versions are raised to this minimum automatically.

Full speed

Runs the fan at maximum, ignoring the curve.

Per game and on charger

Two switches let the fan setting depend on what you are doing:

- **Separate settings per game** - a game can have its own setting.
- **Separate settings on charger** - one setting on battery, another while plugged in.

With both on there are up to four kinds of setting. The plugin uses the most specific one that exists:

Order	Setting	Example
1	This game, on the charger	Elden Ring plugged in: full speed
2	This game	Elden Ring on battery: Balanced
3	All games, on the charger	Anything else plugged in: Cool
4	All games	Anything else on battery: Silent

It switches by itself when a game starts or closes and within two seconds of plugging in or unplugging.

Making a setting

1. Get into the situation you want to set up - start the game, and plug in or unplug.
2. Open the Fan tab. The heading names what you are editing, for example *ELDEN RING · on charger*. Until you change something it says *Using the general setting* and which one.
3. Change the preset, the curve or full speed. From then on that case has its own setting.

Use the general setting here removes the setting you are looking at. **Saved fan settings** lists every setting with its preset; selecting one removes it.

Why a setting can "turn itself off" - and what the plugin does

The firmware throws away *full speed* and the custom curve whenever the power mode changes - no matter whether Steam, another tool, Auto TDP or a manual change caused it. The fan then quietly falls back to the stock curve and temperatures climb.

The plugin therefore reads both back from the firmware every 5 seconds, and one second after each of its own power changes, and puts them back when they are gone. When this has happened the Fan tab shows a **Kept on** line, for example *The firmware dropped the fan setting 3 times (last just now); the plugin put it back.*

7 Lights

Stick lights

The rings around both sticks. Until you change something here the plugin leaves them as they are; the first change takes control.

Setting	Options
Effect	Solid colour · Pulse · Rainbow · Spiral
Colour	Hue and Saturation sliders (Solid and Pulse only). Saturation all the way down gives white.
Brightness	5 – 100 %
Speed	0 – 100 % (all effects except Solid)

The setting is stored in the controllers and sent again whenever they reconnect.

Power-button light

- **Power light** - on or off.
- **Off while sleeping** - switches the light off when the Legion Go goes to sleep, so it does not glow in a dark room, and back on when it wakes. If you keep the light off anyway, it stays off.

8 Controls

Swap menu buttons

Exchanges the two Legion buttons (Steam on the left controller, Quick Access on the right) with View and Menu. Choose the **Layout**:

Layout	Press	You get
Steam ↔ Menu, QAM ↔ View (default)	Menu	Steam menu
	View	Quick Access menu
	Legion L (Steam)	Menu
	Legion R (Quick Access)	View
Steam ↔ View, QAM ↔ Menu	View	Steam menu
	Menu	Quick Access menu
	Legion L (Steam)	View
	Legion R (Quick Access)	Menu

The swap is a small profile loaded into InputPlumber (SteamOS's controller layer) on top of the active one, so the other mappings stay. If InputPlumber restarts, the plugin loads it again within a few seconds. Switching it off restores the previous profile.

Remap back buttons

Gives Y1, Y2 (left controller), Y3, M2 and M3 (right controller) a different function, using Lenovo's own remapping stored in the controllers.

Can become
No action · A · B · X · Y · LB · RB · LT · RT · View · Menu · D-pad up / down / left / right · Left or right stick click · Left or right stick up / down / left / right

> **Note.** Steam also sees the back buttons as extra buttons. In games where you use this remapping, leave them unassigned in Steam Input, otherwise a press does both. Switching remapping off sets all five back to *No action* in the controllers.

Touchpad

Switches the touchpad on the right controller off (or on again), for example if your palm keeps touching it.

9 Gyro

The Legion Go has three motion sensors: one in each detachable controller and one in the tablet. The Gyro tab uses them in two separate ways.

Gyro in Steam games
Any game, through Steam Input. Uses the tablet's sensor, so it works with the controllers attached - like a Steam Deck.

Gyro for emulators
Dolphin, Ryujinx, Eden, Cemu and others. Each controller's own sensor, so detached controllers work like Wii Remotes or Joy-Cons.

Gyro in Steam games

Steam offers gyro settings only for controllers that have a gyro. On its own, InputPlumber presents the Legion Go as an Xbox controller, which has none. The plugin therefore presents it as a **Steam Deck controller** by default.

Type	Result
Steam Deck controller (default)	Steam's full gyro options; A/B/X/Y lettering like Xbox
Xbox controller (no gyro)	No gyro in Steam; what InputPlumber does without this plugin
DualSense / DualSense Edge	Gyro; PlayStation symbols in Steam's menus and in games with their own PlayStation support

A different type for one game

While a game is running, a second list with the game's name appears. Choose a type there and it is remembered for that game: the plugin switches to it whenever the game starts and back to the all-games type when it closes. *Same as all games* removes the game's own choice; so does selecting the game under **Games with their own type**.

> **Note.** Switching type reconnects the virtual controller, so Steam may briefly show a controller notification as a game starts.

Button symbols

Most games show **Xbox symbols** whatever type you pick, because Steam Input hands every game an Xbox-style controller. Games with their own PlayStation support may switch to PlayStation symbols when Steam sees a DualSense; most of them have a button-prompt option in their own settings. Steam's own menus and the controller-settings screen always show the type you picked. The Steam Deck type keeps A/B/X/Y lettering, which makes it the best all-round choice.

Setting up gyro in a game

1. Pick the type before starting the game - changing it reconnects the controller once.
2. In the game press the Steam button → **Controller settings** → **Gyro** and set it up like on a Steam Deck (for example *As mouse* or *As joystick*, enabled while touching the right stick).

> **Layouts per controller type.** Steam stores controller layouts separately for each controller type. After switching type, a game may start with that type's default layout.

Gyro for emulators

The plugin runs a motion server in the DSU / CemuHook format on `127.0.0.1`, port `26760`. Add it once in each emulator.

Slot	Device	Use it for
1	Left controller	Nunchuk, left Joy-Con, player 2's remote
2	Right controller	Wii Remote, right Joy-Con
0	Whole handheld	Gyro aiming with the controllers attached (right controller's sensor, else left, else the tablet)

Calibrate once

Press **Calibrate** and leave the controllers alone for a few seconds - on a table is best. It finishes as soon as it sees a calm second; if the sensors never get perfectly quiet it uses the calmest second it saw. After that, drift is removed automatically whenever a controller rests.

Dolphin - Wii Sports and other Wii games

1. **Controllers** → **Alternate Input Sources** → enable **DSU Client** → add server `127.0.0.1`, port `26760`.
2. **Wii Remote 1** → *Emulated Wii Remote* → **Configure**.
3. Open the **Motion Input** tab, choose the device `DSUClient/2/…` (right controller) and press **Default**.
4. Map the buttons on the other tabs - from the same device or from your normal gamepad.
5. For a Nunchuk, set the extension's motion to `DSUClient/1/…`. For two players, give the second remote slot 1.

Hold the controller like a remote: buttons up, the top edge pointing at the screen.

Switch emulators - Switch Sports and other motion games

Ryujinx / Ryubing

Settings → Input → configure the player → **Motion** → enable, tick **Use CemuHook compatible motion**, host `127.0.0.1`, port `26760`, **Controller Slot 1**. Leave *Mirror Input* off and set **Right JoyCon Slot 2**.

Eden / Citron / other yuzu forks

Configure → Controls → Advanced → **Motion/Touch** → Configure → add `127.0.0.1:26760`. On the player page click **Motion 1** and shake the left controller, then **Motion 2** and shake the right one.

Advanced options

Turn on **Advanced options** at the bottom of the tab for per-slot settings. Turning it off again only hides them; if anything was changed the simple view offers **Use default settings**.

Setting	What it does
Enabled	Switch one slot off; a controller's sensor is powered only while something uses it
Sensitivity	0.2 – 3 × the rotation
Deadzone	Ignores rotation below 0 – 5 °/s; keep at 0 for pointing and sports games
How it is held	For a controller held turned (sideways or upside down)
Invert pitch / yaw / roll	Flip one axis if a game moves the wrong way
Motion source	Slot 0 only: Automatic, right, left or tablet sensor
Auto-calibrate when resting	Removes drift whenever a controller lies still
Port	26760 (default) – 26763, if another motion server already uses 26760
Allow other devices	Lets emulators on other computers in your network use the motion data (off by default)

10 Troubleshooting

Symptom	What to do
A feature says "not available"	The text under it gives the reason. Most often: no `acpi_call` (fan), not in Gaming Mode (Auto TDP), or InputPlumber not running (buttons, Steam gyro).
TDP keeps jumping back	Turn off Steam's own TDP limit (Performance menu) and remove other TDP plugins.
Auto TDP stays "at your maximum"	The game cannot reach the target within your Maximum TDP. Raise the maximum or lower the target.
Auto TDP says "waiting for the game to draw frames"	No game is in focus, it is paused, or you are in Desktop Mode.
Fan full speed or curve switches itself off	The firmware drops them when the power mode changes. The plugin restores them within about 5 seconds; the Fan tab's *Kept on* line shows when it did.
No fan curve editor	The `acpi_call` module is missing (chapter 6).
Stick lights or remapping: "controllers not found"	Wake the controllers by pressing a button, then change the setting again.
Menu buttons back to normal	InputPlumber restarted; the swap is re-applied within a few seconds.
No gyro option in Steam's controller settings	Gyro tab → the type for *All games* (or for that game) must not be *Xbox controller*. Restart the game after changing it.
PlayStation symbols in a game	The game supports PlayStation controllers natively. Use its button-prompt setting, or give that game the Steam Deck type.
Emulator gets no motion	Check the server address and slot; the Gyro tab shows "1 emulator connected" once it works. `tools/dsu_monitor.py` prints the live data without an emulator.
"Port 26760 is already used"	Another motion server is running (EmuDeck can install one). Stop it, or pick another port here and in the emulator.
Motion drifts	Lay the controllers down and press Calibrate.
An axis moves the wrong way	Gyro → Advanced options → that slot → Tuning → Invert.

Logs for a bug report are in `~/homebrew/logs/Legion Go Toolbox/`.

11 Reference

Files

What	Where
Hardware settings	`~/homebrew/settings/Legion Go Toolbox/toolbox.json`
Gyro settings and calibration	`~/homebrew/settings/Legion Go Toolbox/gyro.json`
Logs	`~/homebrew/logs/Legion Go Toolbox/`

What is applied when

Event	Applied again
Plugin start	Everything you switched on
Waking from sleep	Everything, 3 seconds after waking; the power light is restored right away
Controllers reconnect	Stick lights, remapping, touchpad
A game starts or closes	Its power profile, fan setting and controller type (only what differs)
Charger plugged in or out	The fan setting, within 2 seconds (when *Separate settings on charger* is on)
Every 5 seconds	Fan full speed / curve (if dropped), menu-button swap and controller type (if InputPlumber restarted)
Every 10 seconds	Power mode and TDP, if something else changed them

Fixed limits

Fan curve minimum	44 / 48 / 55 / 60 / 71 / 79 / 87 / 87 / 100 / 100 at 10 … 100 °C
TDP range	As reported by the firmware for each limit
Motion server	UDP, `127.0.0.1:26760` (local only unless *Allow other devices* is on)

Testing status

Besides use on a Legion Go (83E1), every module is covered by automated tests with simulated hardware (131 tests), and every module reads the hardware back after a change and reports it when a change did not take.

Credits

Legion Go Toolbox is its own code, built on what these projects worked out about the hardware: Handheld Daemon and hwinfo (controller protocol, Lenovo firmware methods and fan minimum), Legion Center and LegionGoRemapper (remapping, fan table, charge limit), HueSync (power light), SimpleDeckyTDP (power limits), DeckyPlumber and InputPlumber (menu-button swap), Panel de Control (frame times from gamescope), decky-lsfg-vk (tabs) and Legion Go 2 Companion (overview layout).