

| Supported<br>Targets | ESP32 | ESP32-<br>C2 | ESP32-<br>C3 | ESP32-<br>C5 | ESP32-<br>C6 | ESP32-<br>C61 | ESP32-<br>H2 | ESP32-<br>P4 | ESP32-<br>S2 | ESP32-<br>S3 | Linux |
|----------------------|-------|--------------|--------------|--------------|--------------|---------------|--------------|--------------|--------------|--------------|-------|
|----------------------|-------|--------------|--------------|--------------|--------------|---------------|--------------|--------------|--------------|--------------|-------|

## Hello World Example

Starts a FreeRTOS task to print "Hello World".

(See the README.md file in the upper level 'examples' directory for more information about examples.)

### How to use example

Follow detailed instructions provided specifically for this example.

Select the instructions depending on Espressif chip installed on your development board:

- [ESP32 Getting Started Guide](#)
- [ESP32-S2 Getting Started Guide](#)

### Example folder contents

The project **hello\_world** contains one source file in C language [hello\\_world\\_main.c](#). The file is located in folder [main](#).

ESP-IDF projects are built using CMake. The project build configuration is contained in [CMakeLists.txt](#) files that provide set of directives and instructions describing the project's source files and targets (executable, library, or both).

Below is short explanation of remaining files in the project folder.

```

├── CMakeLists.txt
├── pytest_hello_world.py      Python script used for automated testing
├── main
│   ├── CMakeLists.txt
│   └── hello_world_main.c
└── README.md                 This is the file you are currently reading

```

For more information on structure and contents of ESP-IDF projects, please refer to Section [Build System](#) of the ESP-IDF Programming Guide.

### Troubleshooting

- Program upload failure
  - Hardware connection is not correct: run `idf.py -p PORT monitor`, and reboot your board to see if there are any output logs.
  - The baud rate for downloading is too high: lower your baud rate in the `menuconfig` menu, and try again.

### Technical support and feedback

Please use the following feedback channels:

- For technical queries, go to the [esp32.com](#) forum
- For a feature request or bug report, create a [GitHub issue](#)

We will get back to you as soon as possible.

result!!

linux x86 is little endian! sizeof(null): 8 sizeof(char): 1 sizeof(short): 2 sizeof(int): 4 sizeof(long int): 4 sizeof(long long int): 8 sizeof(float): 4 sizeof(double): 8 sizeof(char \*): 8 sizeof(size\_t): 8 sizeof(ssize\_t): 8 sizeof(data): 11 sizeof(data\_p): 8

var a is greater than b! char is SIGNED!!!

data allocated at: 00007FF7D5CB4010 data points to: 00007FF7D5CB4010 data contents: "3DUfw • data[0]: as hex: 0x11 data[1]: " as hex: 0x22 data[2]: 3 as hex: 0x33 data[3]: D as hex: 0x44 data[4]: U as hex: 0x55 data[5]: f as hex: 0x66 data[6]: w as hex: 0x77 data[7]: • as hex: 0xffffffff88 data[8]: • as hex: 0xffffffff99 data[9]: as hex: 0x00

data\_as\_int, allocated at: 000000762C9FF7D0 data as int points to: 00007FF7D5CB4010 data\_as\_int[0]: 44332211 data\_as\_int[1]: 88776655 data\_as\_int[2]: 99

location: 00007FF7D5CB4011, value: 55443322 float location: 00007FF7D5CB4011, value: 13482743300096.000000