# Phone Dialplan Guide
# Nuts and Bolts

How Asterisk and AllStarLink 3 route a phone call, line by line: the stock ASL3 dialplan, the one the ASL-DVS Dashboard writes for its Phone tab, and why each piece is there.

DIALPLAN · APP_RPT · AUTOPATCH · SIP / IAX2 · PHONE TAB

| COVERS | FILE | VERSION |
|---|---|---|
| Dashboard Pi02w | `asl_dvs_dashboard_pi02w_v9_3_71_14_20261012.py` | 9.3.71.14-pi02w |
| SysMon Pi02w | `sysmon_pi02w_v6_13_67_12_20261012.py` | 6.13.67.12-pi02w |
| Dashboard (full) | `asl_dvs_dashboard_v9_3_75_20261012.py` | 9.3.75 |
| SysMon (full) | `sysmon_v6_13_78_20261012.py` | 6.13.78 |
| Stock reference | AllStarLink app_rpt sample `rpt.conf` / `extensions.conf` | ASL3 |

KD8PGK · written with Claude (Anthropic) · CC BY-NC 4.0 · github.com/kd8pgk/ASL-DVS

# In this guide

1. **The big picture**: the three parts of a phone call and how they meet
2. **Where the files live**: load order, includes, reloads and who owns what
3. **Anatomy of a dialplan line**: contexts, extensions, steps, labels
4. **Patterns**: how Asterisk decides which line matches a number
5. **Variables, functions and tests**: ${EXTEN}, CALLERID, DB(), $[ ] and GotoIf
6. **The applications**: every app this dialplan uses, argument by argument
7. **Channels and calls**: PJSIP, IAX2, Local, bridges and Originate
8. **The app_rpt side**: node settings, function codes, rpt() options, duplex and VOX
9. **Inside autopatch**: call states, digit collection and the dead key
10. **The stock ASL3 dialplan**: what ships, and how you would turn it on
11. **The ASL-DVS dialplan, context by context**
12. **The phone nodes in rpt.conf**: and the three helper scripts
13. **The SIP account file**
14. **Call flows**: dashboard dial, radio *61, incoming, tones, hang-up
15. **Switches and the dashboard's part**: AstDB keys, Originate, the dial poll
16. **Stock and ASL-DVS side by side**
17. **Hands-on**: watching a call, commands, common problems
18. **Quick reference**

## How to read the examples

Config and dialplan lines are shown in green. Text after a `;` is a comment (grey): Asterisk ignores it. Commands you type on the Pi start with `sudo`. Numbers such as `555-123-4567` and passwords are examples.

**NOTE** Every ASL-DVS excerpt in this guide was generated by the current Dashboard code for two example networks: **Hams Over IP** on node 1001 (extension dialing, incoming open) and **VoIP.ms** on node 1002 (phone numbers, E911, PIN on incoming). Your own file has the same shape with your names, numbers and nodes.

**TIP** You don't need to edit any of this by hand. The Dashboard rewrites its files on every Save Phone. This guide is for understanding what you see in SysMon's Phone tab, in the files, and in Asterisk's log.

1 · OVERVIEW

# The big picture

A phone call on an AllStar node is handled by three parts of the same Asterisk program. Each has its own config file and its own job:

| PART | CONFIG | JOB |
|---|---|---|
| The dialplan | `extensions.conf` | Decides what happens to every call: which number goes where, what is checked first, when to answer, ring or hang up. |
| app_rpt (AllStar) | `rpt.conf` | Runs the nodes: radio audio, links between nodes, DTMF codes, keying the transmitter. Its `rpt()` app joins a call to a node; its autopatch places calls from the radio. |
| The channel drivers | `pjsip.conf`, `iax.conf` | Talk to the outside world: SIP providers (VoIP.ms, Hams Over IP, AmateurWire) and IAX2 servers, including signing in. |

A call always **enters the dialplan** somewhere (a context), follows its steps, and usually ends in one of two places: `Dial()` (ring the outside world) or `rpt()` (join an AllStar node). The radio is never connected to a phone directly; it is always the node in the middle.

**1 Radio**
Your handheld or mobile, on the node's radio interface (SimpleUSB on node 652702 in the examples).

▼

**2 Radio node**
app_rpt node 652702. Keys the transmitter when a linked node or call has audio for it.

▼

**3 Phone node**
A private node (1001) with no radio of its own. Linked to the radio node while the Phone tab is open.

▼

**4 The call**
Joined to the phone node with rpt(1001,Pv), or (stock) carried by the node's autopatch.

▼

**5 Phone network**
PJSIP or IAX2 channel to the provider, created by Dial().

**WHY** ASL-DVS keeps the phone on its own node so the radio node's settings (simplex, hang time, links to the DMR and M17 bridges) are never mixed with phone settings, and so each phone network can have its own codes and rules.

2 · FILES

# Where the files live

Everything is in `/etc/asterisk`. Asterisk reads each file when its module loads, and again when you reload that module.

| FILE | READ BY | RELOAD WITH | OWNED BY |
|---|---|---|---|
| `extensions.conf` | pbx_config | `dialplan reload` | You (stock file). ASL-DVS adds one include line at the end. |
| `dvs_phone_extensions.conf` | pbx_config (included) | `dialplan reload` | The Dashboard. Rewritten on every Save Phone. |
| `rpt.conf` | app_rpt | `module reload app_rpt` | You. ASL-DVS writes only between its two marker lines. |
| `pjsip.conf` + `dvs_phone_pjsip.conf` | res_pjsip | `module reload res_pjsip.so` | You / the Dashboard (included file). |

| FILE | READ BY | RELOAD WITH | OWNED BY |
|---|---|---|---|
| `iax.conf` + `dvs_phone_iax*.conf` | chan_iax2 | `iax2 reload` | You / the Dashboard (included files). |
| `modules.conf` | Asterisk at start | restart Asterisk | You. ASL-DVS adds `load =>` lines for the phone modules. |

### Includes

A config file can pull in another file. ASL-DVS uses the safe form, which is silently skipped if the file is missing:

EXTENSIONS.CONF

```
; last line of /etc/asterisk/extensions.conf
#tryinclude dvs_phone_extensions.conf
```

An included file behaves exactly as if its text were pasted at that spot. Its contexts become part of the one big dialplan, so a stock context and an ASL-DVS context can jump to each other with `Goto`.

### The rpt.conf markers

The phone nodes are written into `rpt.conf` itself, because app_rpt needs every node in that one file. The Dashboard only ever touches the text between these two lines:

RPT.CONF

```
; >>> dvs-phone (managed by asl_dvs_dashboard - edits inside are overwritten) >>>
[1001](node-main)
 ...
; <<< dvs-phone <<<
```

It also adds each phone node to the `[nodes]` list (`1001 = radio@127.0.0.1/1001,NONE`) so the radio node can link to it over the Pi's own IAX2 port.

**CAREFUL** Edits you make inside the markers, or inside `dvs_phone_*.conf`, are lost on the next Save Phone. Put your own contexts and nodes outside them; the Dashboard refuses to save if it finds a hand-made section with the same name as one of its own.

### When changes take effect

- The Dashboard reloads what it changed after Save Phone: dialplan, app_rpt, PJSIP or IAX2.
- New SIP *modules* need one Asterisk restart (tick **Restart Asterisk if needed** on the Edit page).
- About 20 seconds after the Dashboard starts, it compares what it would write with what is on disk and refreshes anything stale. That is how upgrades to the dialplan reach your Pi.

3 · SYNTAX

## Anatomy of a dialplan line

The dialplan is a list of **contexts**. Each context is a list of **extensions**. Each extension is a numbered list of **steps** (Asterisk calls them priorities). Each step runs one **application**.

THE PARTS

```
[dvs-node-dvshoip]                          ; the context name, in square brackets
exten => _X.,1,Set(DVSNET=dvshoip)          ; extension _X., step 1, app Set
 same => n,Set(DVSOPT=)                     ; same extension, next step
 same => n(net),GotoIf(...)                 ; next step, with the label "net"
 same => n,Goto(dvs-net-dvshoip,${EXTEN},1) ; jump to another context
exten => i,1,Goto(dvs-invalid,s,1)          ; a second extension: "i" (invalid)
```

| PIECE | MEANING |
|---|---|
| `[name]` | Starts a context. Everything below belongs to it until the next `[...]`. |

| PIECE | MEANING |
|---|---|
| `exten =>` | Starts an extension: `exten => what-was-dialed, step, App(arguments)`. |
| `_X.` | The extension. A leading `_` makes it a pattern (section 4); without it, it is matched literally, e.g. `911` or `s`. |
| `1` | The first step. Every extension must have a step 1. |
| `same =>` | Continue the extension above, so you don't repeat the pattern. |
| `n` | “Next”: the step after the previous one. Asterisk numbers them 2, 3, 4… for you. |
| `n(net)` | Next step, and give it the label `net` so `Goto` / `GotoIf` can jump to it by name. |
| `App(args)` | The application and its arguments, separated by commas. |
| `; text` | A comment. Ignored by Asterisk. |

### How a call walks through it

1. The call arrives in a context with a number (the *extension*).
2. Asterisk finds the best matching `exten =>` line and runs its step 1.
3. It then runs step 2, 3… in order, unless a step jumps somewhere else (`Goto`, `GotoIf`).
4. An application such as `Dial` or `rpt` holds the call while it runs; when it returns, the next step runs.
5. Running off the end, or `Hangup()`, ends the call.

### Jumps

| FORM | GOES TO |
|---|---|
| `Goto(label)` | A label in the same extension. |
| `Goto(exten,step)` | Another extension in the same context. |
| `Goto(context,exten,step)` | Another context. ASL-DVS uses this to pass a call along: `Goto(dvs-net-dvshoip,${EXTEN},1)` keeps the dialed number. |
| `GotoIf($[test]?yes:no)` | Jump to `yes` if the test is true, `no` if false. Either side may be left out: `GotoIf($[test]?open)` simply carries on when false. |

**TIP** Read a context from the top of the matching extension downwards, and follow each Goto. That is exactly what SysMon's Dialing rules card does for you.

4 · SYNTAX

## Patterns

An extension that starts with `_` is a pattern: it matches many numbers. Each character stands for one digit position, except `.` and `!`.

| CHARACTER | MATCHES |
|---|---|
| `X` | Any digit 0–9. |
| `Z` | Any digit 1–9. |
| `N` | Any digit 2–9 (the first digit of a North American area code or exchange). |
| `[15-7]` | One digit from the set: here 1, 5, 6 or 7. |
| `.` | One or more of anything (digits, `*`, `#`). |
| `!` | Zero or more of anything, and match as soon as possible. |
| Any other character | Itself, e.g. `_1800NXXXXXX` needs a literal 1800. |

### Patterns used in these dialplans

| PATTERN | MATCHES | USED FOR |
|---|---|---|
| `_NXXNXXXXXX` | 10 digits, valid area code and exchange | US/Canada number without the 1 |
| `_1NXXNXXXXXX` | 1 + 10 digits | the same number with the 1 |
| `_NXXXXXX` | 7 digits | stock: local number (adds your area code) |
| `_X11` | 211, 311 … 911 | stock: service codes |
| `_1800NXXXXXX` | toll-free 800 numbers | blocked list |
| `_1NXX555XXXX` | any 555 exchange | blocked list (directory and fictional numbers) |
| `_011.` | 011 and more | international (only if allowed) |
| `_X.` | a digit then anything | “everything else”: catch-alls and extension dialing |
| `_[+0-9].` | a digit or + then anything | incoming caller ID or DID numbers |
| `_XXXX!` | 4 or more digits | stock: node numbers in radio-secure |

### Which line wins

When several patterns match, Asterisk picks the **most specific** one: an exact number beats a pattern, and a pattern with fewer possibilities beats a looser one. So in the VoIP.ms context below, `911` wins over `_X.` even though both match, and the blocked `_1800NXXXXXX` wins over the general `_1NXXNXXXXXX`.

DVS_PHONE_EXTENSIONS.CONF

```
[dvs-net-dvsvoipms]
exten => 911,1,NoOp(911 - E911 is set up on this network)
 same => n,Set(CALLERID(num)=5550001111)
 same => n,Dial(PJSIP/911@dvsvoipms,60)
 same => n,Hangup()
exten => _NXXNXXXXXX,1,Goto(dvs-net-dvsvoipms-r,1${EXTEN},1)
exten => _1NXXNXXXXXX,1,Goto(dvs-net-dvsvoipms-r,${EXTEN},1)
exten => _X.,1,Goto(dvs-invalid,s,1)
exten => i,1,Goto(dvs-invalid,s,1)
```

### Special extensions

| EXTENSION | WHEN IT RUNS |
|---|---|
| `s` | “Start”: a call that arrives with no number (many incoming SIP calls). |
| `i` | “Invalid”: a number that matches no line in this context. |
| `t` | “Timeout”: the caller didn't enter anything in time. |
| `h` | “Hang-up”: runs after the call ends (not used here). |

**CAREFUL** A single digit never matches `_X.` : the dot needs at least one more character. That is why the autopatch waits for at least two digits.

5 · SYNTAX

## Variables, functions and tests

Anything inside `${ }` is replaced by its value before the step runs.

| WRITTEN | VALUE |
|---|---|
| `${EXTEN}` | The number being handled, e.g. `15551234567`. |
| `${EXTEN:1}` | The same, minus its first character: `5551234567`. ( `:2` drops two, and so on.) |

| WRITTEN | VALUE |
|---|---|
| `${CALLERID(num)}` | The caller's number. |
| `${CALLERID(num):-10}` | Its last 10 characters, so `+15551234567` and `15551234567` both become `5551234567`. |
| `${DB(dvsphone/active)}` | Reads a value from Asterisk's database (AstDB): family `dvsphone`, key `active`. |
| `${DB_EXISTS(dvsphone/then)}` | 1 if the key exists, 0 if not. |
| `${DB_DELETE(dvsphone/then)}` | Returns the value *and* deletes the key, so it is used exactly once. |
| `${DVSNET}`, `${DVSOPT}` | Variables set earlier in the same call with `Set()`. |

### Setting variables

EXAMPLES

```
same => n,Set(DVSNET=dvshoip)                        ; a channel variable
same => n,Set(CALLERID(num)=5550001111)               ; a function can be written to
same => n(then),Set(DVSOPT=D(${DB_DELETE(dvsphone/then)}))   ; read-and-delete
```

### Tests

`$[ ... ]` works out an expression: `=`, `!=`, `<`, `>`, `&` (and), `|` (or), `+ - * /`. Text on both sides of `=` is compared as text, so ASL-DVS puts quotes around values that might be empty:

TESTS USED HERE

```
; incoming: only if the Phone tab is open AND this network is the picked one
same => n,GotoIf($["${DB(dvsphone/open)}" = "1" & "${DB(dvsphone/active)}" = "dvshoip"]?open)

; outgoing: stop if the phone patch is switched off
same => n(net),GotoIf($["${DB(dvsphone/patch)}" = "0"]?bad)

; PIN: count the tries
same => n,Set(TRIES=$[${TRIES} + 1])
same => n,GotoIf($[${TRIES} >= 3]?bye)
```

**WHY** Reading switches from AstDB lets the dialplan react the moment you change something on the Phone tab, with no reload: the Dashboard writes `dvsphone/open` when you open the tab, `dvsphone/active` when you pick a network, and `dvsphone/patch` when you turn the patch on or off.

6 · SYNTAX

## The applications

These are every application the stock and ASL-DVS phone dialplans use. Arguments are separated by commas; empty ones keep their default.

| APPLICATION | ARGUMENTS AS USED HERE | WHAT IT DOES |
|---|---|---|
| `Answer()` | — | Picks up an incoming call. Audio can now flow both ways. |
| `Wait(1)` | seconds | Pauses. Used so a greeting isn't clipped right after answering. |
| `Playback(rpt/connected)` | sound file(s), joined with `&` | Plays recordings: `rpt/connected`, `ss-noservice`, `confbridge-pin-bad`. |
| `Read(PIN,beep,8,,1,10)` | variable, prompt, max digits, options, attempts, timeout | Plays a beep and collects up to 8 digits (ended by #) into `PIN`, waiting 10 s. |

| APPLICATION | ARGUMENTS AS USED HERE | WHAT IT DOES |
|---|---|---|
| `Dial(PJSIP/${EXTEN}@dvsvoipms,60,${DVSOPT})` | Tech/number@account, ring seconds, options | Rings the number through that account for up to 60 s. Option `D(digits)` sends tones after answer. |
| `Busy(20)` | seconds | Plays a busy signal, then hangs up. |
| `Hangup()` | — | Ends the call. |
| `Goto` / `GotoIf` | see section 3 | Jump to another step, extension or context. |
| `NoOp(text)` | any text | Does nothing; the text shows in the Asterisk log. Handy as a label for humans. |
| `Set(VAR=value)` | assignment | Sets a variable or writable function (section 5). |
| `System(command)` | a shell command | Runs a program on the Pi. ASL-DVS uses it once: to hand a radio-dialed number to the Dashboard. |
| `rpt(1001,Pv)` / `Rpt(...)` | node, options | Joins the call to an AllStar node (section 8). |

### Dial in detail

DIAL

```
Dial(PJSIP/${EXTEN}@dvsvoipms,60,D(ww*99))
;    \_____________________________/ \/ \_______/
;     who to ring                  ring  after answer: wait 1 s (each w = 0.5 s),
;     (technology/number@account)  60 s  then send the tones *99
```

| TECHNOLOGY STRING | MEANING |
|---|---|
| `PJSIP/5551234567@dvsvoipms` | SIP: send the number to the PJSIP endpoint `dvsvoipms` (section 13). |
| `PJSIP/*97@dvshoip` | SIP: an extension or feature code on Hams Over IP (here voicemail). |
| `IAX2/dvsclub/2001` | IAX2: ring 2001 through the IAX2 peer `dvsclub` . |
| `IAX2/allstar-autopatch/${EXTEN}` | Stock example: the AllStarLink autopatch service. |

**NOTE** ASL-DVS fills `D()` only for a favorite with saved tones, and only when **Send keypad tones** is set to **Through the call**. Otherwise the Dashboard sends the tones itself once the call is answered.

7 · CALLS

# Channels and calls

Every leg of a call is a **channel**. A channel has a technology, a name, and a place in the dialplan. Two channels talking to each other are in a **bridge**.

| CHANNEL NAME LOOKS LIKE | WHAT IT IS |
|---|---|
| `PJSIP/dvsvoipms-0000002a` | A SIP call leg to or from the VoIP.ms account. |
| `IAX2/dvsclub-1234` | An IAX2 call leg to or from an IAX2 phone network. |
| `Local/5551234567@dvs-node-dvsvoipms-00000003;1` | Half of a Local channel: a call Asterisk places to *itself*, into a context. |
| `...;2` | The other half of the same Local channel. It runs the context's steps (here, Dial). |

### Local channels

`Local/number@context` lets a program start a call into any context as if someone had dialed `number`. It always comes as a pair:

**1 Half ;1**
Runs whatever the caller asked for: here the app rpt(1002,Pv), once the call is answered.

▼

**2 Half ;2**
Walks the context: dvs-node-dvsvoipms → dvs-net-dvsvoipms → -r → Dial().

▼

**3 PJSIP leg**
Created by Dial(). When the far end answers, ;2 answers, which answers ;1.

The `/n` at the end ( `Local/...@dvs-node-dvsvoipms/n` ) tells Asterisk not to optimise the pair away after answer, so the call keeps a stable shape the Dashboard can follow.

### Originate: placing a call from a program

The Dashboard talks to Asterisk over the Asterisk Manager Interface (AMI). To place a call it sends:

AMI ORIGINATE (SENT BY THE DASHBOARD)

```
Action: Originate
Channel: Local/5551234567@dvs-node-dvsvoipms/n   ; dial this, through this context
Application: Rpt                                  ; once answered, run this app ...
Data: 1002,Pv                                     ; ... with these arguments
Timeout: 65000                                    ; give up after 65 s of ringing
Async: true                                       ; don't wait; report back later
```

So a Dashboard call is really two things glued together: the ordinary dialing rules (on `;2`) and `rpt(1002,Pv)` (on `;1`). If the far end is busy or never answers, `;1` is never answered and `rpt()` never runs: nothing touches the radio.

**TIP** In `core show channels` during a Dashboard call you will see three lines: the PJSIP (or IAX2) leg running `AppDial`, `Local/...;2` running `Dial`, and `Local/...;1` running `Rpt`.

8 · ALLSTAR

# The app_rpt side

### Node settings that matter for phones

| SETTING | MEANING |
|---|---|
| `context = dvs-node-dvshoip` | The node's default dialing context (used by autopatch when a code doesn't name one). |
| `functions = functions1001` | Codes keyed on the node's own radio (this node has none) and by default from links. |
| `link_functions = functions1001` | Codes arriving over a link, i.e. keyed on your radio node and passed along. |
| `phone_functions = functions1001` | Codes keyed by a caller joined with `rpt(node,P...)`. |
| `rxchannel = Local/pseudo` | No radio hardware: a software-only node. |
| `duplex`, `vox*`, `simplex*` | Keying behaviour (below). |

### Function codes

A function table maps a DTMF code (keyed after the node's `*`) to an action:

| ACTION | EXAMPLE | DOES |
|---|---|---|
| `autopatchup` | `61 = autopatchup,noct=1,...,quiet=1` | Starts the autopatch and collects the number. |
| `autopatchdn` | `62 = autopatchdn` | Ends the autopatch (stock). |
| `cmd` | `62 = cmd,/var/lib/asterisk/dvs_phone_hangup` | Runs a program on the Pi. |
| `cop,6` | `99 = cop,6` | Phone-mode PTT: lets a phone caller key the radio with *99. |
| `cop,9` / `cop,10` | `63 = cop,9` | Autopatch enable / disable. |
| `ilink` | `3 = ilink,3` | Link commands on the radio node (3 connects two-way, 2 monitor, 1 disconnects). |

### autopatchup options

| OPTION | MEANING |
|---|---|
| `context=name` | Dial through this context instead of the node's `context =`. |
| `dialtime=20000` | Give up if no digit arrives for this many ms. |
| `farenddisconnect=1` | End the autopatch when the far end (or the dialplan) hangs up. |
| `noct=1` | No courtesy tone during the call. |
| `quiet=1` | No dial tone or spoken messages. |
| `voxalways=1` | Use VOX on the patch audio even on a full-duplex node. |
| `exten=number` | Dial a fixed number instead of collecting digits. |

### rpt() options

The first letter picks the mode, later letters modify it:

| OPTION | MODE |
|---|---|
| `P` | **Phone control.** The caller has audio and DTMF control through `phone_functions`; PTT with the `cop,6` code (*99), unkey with #. |
| `D` | **Dumb phone.** Keys the transmitter for the whole call. |
| `S` | **Dumb simplex.** The caller toggles transmit with *; # turns it off. |
| `R` | **Reverse autopatch.** Parks the caller and announces the call on the radio. |
| `X` | Normal node link without the security check (stock `[iaxrpt]`). |
| add `v` | **VOX:** also key while the caller's voice is present. ASL-DVS uses `Pv`. |
| add `m` | Monitor: the phone gets no transmit or functions. |

### Duplex and VOX

| DUPLEX | BEHAVIOUR |
|---|---|
| 0 | Half duplex, no telemetry or hang time. Your radio node 652702 uses this. |
| 1 | Half duplex with telemetry and hang time. The phone nodes use this. |
| 2 | Full duplex repeater (the ASL3 template default). |
| 3 | Full duplex, no repeated audio. |
| 4 | Full duplex, repeat only when autopatch is down. |

| VOX SETTING | DEFAULT | MEANING |
|---|---|---|
| `voxtimeout` | 10000 ms | Longest the VOX may hold the transmitter. |

| VOX SETTING | DEFAULT | MEANING |
|---|---|---|
| `voxrecover` | 2000 ms | Forced gap after a timeout, so the radio side can break in. |
| `simplexpatchdelay` | 25 × 20 ms | Audio delay before transmitting patch audio, so the first word isn't clipped. |
| `simplexphonedelay` | 25 × 20 ms | The same, for a phone-mode caller's audio. |

9 · ALLSTAR

# Inside autopatch

Autopatch is app_rpt's built-in phone patch. Knowing its states explains both how stock dialing works and why ASL-DVS stopped using it for the call itself.

| STATE | WHAT IS HAPPENING |
|---|---|
| `DOWN` | No patch. |
| `DIALING` | *61 was keyed; digits are being collected (dial tone unless quiet=1). |
| `CONNECTING` | The number is complete; the dialplan is running ( `Dial()` is ringing). |
| `UP` | The call is connected. |
| `FAILED` | The dialplan couldn't start or ended badly; congestion until *62. |

## How it knows the number is complete

1. Each digit is added to the number and checked against the context's patterns.
2. If the number matches a line and **no longer number could match**, it dials at once.
3. If a longer number could still match (always the case with `_X.`), it waits **1.5 seconds** after the last digit, then dials.
4. If no digit arrives for `dialtime` (20 s here), it gives up.

## How it ends

With `farenddisconnect=1`, or on any half-duplex node, the patch goes down as soon as the dialplan finishes or the far end hangs up. Otherwise it waits for the `autopatchdn` code.

## The dead key

While a patch is in DIALING, CONNECTING or UP, app_rpt sends **keyed** to every linked node, for the whole call, whether or not anyone is talking. The code that would gate this by voice exists but is compiled out, because it clipped the first syllable on links.

**1 Phone node 1001 is in autopatch**
callmode is not DOWN, so it keys its link for the whole call.

▼

**2 Radio node 652702 sees the link keyed**
It transmits the link audio, continuously.

▼

**3 Your simplex radio can't receive**
The hotspot is transmitting, so it never hears you key up.

▼

**4 Result**
Receive audio works, but nothing you say reaches the call. *99 seems dead.

**WHY** This is a long-standing app_rpt behaviour, reported on the AllStarLink forum back to 2009. A full-duplex repeater doesn't mind; a simplex hotspot can't work with it. Settings such as `duplex`, `vox*` or `voxalways` only affect the phone node's own (pseudo) transmitter, never the link, so they can't fix it.

### What ASL-DVS does instead

It keeps autopatch only for collecting digits from the radio, and ends it at once. The call itself joins the node with `rpt(node,Pv)`, the same phone mode the stock `[iax-client]` context uses. In phone mode the link is keyed only while the caller's voice is present (VOX), with a short buffer so the first word survives.

10 · STOCK

## The stock ASL3 dialplan

A fresh ASL3 install has phone calling turned off. The pieces are there, commented out or pointed at a “no service” message.

STOCK RPT.CONF (EXCERPT)

```
[node-main](!)
functions = functions               ; Repeater Function stanza
link_functions = functions          ; Link Function stanza
phone_functions = functions         ; Phone Function stanza
context = radio                     ; dialing context for phone
duplex = 2

[functions-main](!)
99 = cop,6                          ; PTT (phone mode only)
;61 = autopatchup,noct = 1,farenddisconnect = 1,dialtime = 20000  ; Autopatch up
;62 = autopatchdn                                                 ; Autopatch down
```

STOCK EXTENSIONS.CONF (EXCERPT)

```
[radio]
exten => _X11,1,Goto(check_route,${EXTEN},1)
exten => _NXXXXXX,1,Goto(check_route,1${HOMENPA}${EXTEN},1)   ; 7 digits: add your area code
exten => _1XXXXXXXXXX,1,Goto(check_route,${EXTEN},1)
exten => _07XX,1,Goto(parkedcalls,${EXTEN:1},1)
exten => 00,1,Goto(my-ip,s,1)                                 ; speaks the node's IP address

[check_route]
exten => _X.,1,NoOp(${EXTEN})
exten => _1800NXXXXXX,2,Goto(invalidnum,s,1)                  ; also 888 877 866 855
exten => _1X00XXXXXXX,2,Goto(invalidnum,s,1)                  ; X00 area codes
exten => _1X11XXXXXXX,2,Goto(invalidnum,s,1)
exten => _X11,2,Goto(invalidnum,s,1)
exten => _1NXX555XXXX,2,Goto(invalidnum,s,1)
exten => _1NXX976XXXX,2,Goto(invalidnum,s,1)
exten => _1809XXXXXXX,2,Goto(invalidnum,s,1)
exten => _1900XXXXXXX,2,Goto(invalidnum,s,1)
exten => _1NXXXXXXXXX,2,Goto(pstn-out,${EXTEN:1},1)           ; okay, route it
exten => _X.,2,Goto(invalidnum,s,1)

; Comment-out the following clause if you want Allstar Autopatch service
[pstn-out]
exten => _NXXNXXXXXX,1,Wait(1)
 same => n,Playback(ss-noservice)
 same => n,Hangup

[invalidnum]
exten => s,1,Wait(3)
 same => n,Playback(ss-noservice)
 same => n,Wait(1)
 same => n,Hangup
```

Note the trick in `[check_route]`: every number first hits step 1 of `_X.`; step 2 is then taken from the most specific matching line, so the blocked kinds win over the final “route it” line.

### Other stock contexts

| CONTEXT | PURPOSE |
|---|---|
| `[radio-secure]` | Node-to-node connections, with allow and deny lists in AstDB; ends in `Rpt(${EXTEN})`. |

| CONTEXT | PURPOSE |
|---|---|
| `[iaxrpt]` | IAX apps that log in with a user/password; `Rpt(${EXTEN},X)`. |
| `[iax-client]` | IAX VoIP clients: rings, answers, then `Rpt(${EXTEN},P,${CALLSIGN}-P)`: phone mode. |
| `[allstar-public]`, `[allstar-sys]` | Public AllStar connections and system use. |
| `[telemetry]` | Telemetry helpers. |

### Turning stock autopatch on

1. Uncomment `61` and `62` in your node's function table.
2. In `[pstn-out]`, replace the “no service” lines with a `Dial()` to your provider (stock suggests `IAX2/allstar-autopatch`).
3. Set `HOMENPA` in `[globals]` to your area code, then reload app_rpt and the dialplan.

**CAREFUL** Done on the radio node itself, a stock autopatch call keys that node and every node linked to it for the whole call: your DMR and M17 bridges would hear the phone too.

11 · ASL-DVS

## The ASL-DVS dialplan, context by context

The Dashboard writes one file, `dvs_phone_extensions.conf`. It starts with a few shared contexts, then a block of contexts per phone network.

| CONTEXT | REACHED FROM | JOB |
|---|---|---|
| `dvs-invalid` | any “bad number” jump | “No service”, then hang up. |
| `dvs-phone-out` | Phone Bridge node's `context =` when no network owns it | Outgoing front door that reads the picked network from AstDB. |
| `dvs-radio-out` | *61 on that Phone Bridge node | Hands the number to the Dashboard. |
| `dvs-tones` | the Dashboard only | Plays touch-tone recordings into a call (“As sound”). |
| `dvs-node-<net>` | Originate; node `context =` | Outgoing front door for one network. |
| `dvs-radio-<net>` | *61 on that network's node | Hands the number to the Dashboard. |
| `dvs-net-<net>` | dvs-node- | The network's dialing rules. |
| `dvs-net-<net>-r` | dvs-net- (phone numbers only) | Blocked list, then Dial(). |
| `dvs-in-<net>` | the SIP or IAX2 account | Incoming calls. |

### Shared contexts

DVS-INVALID

```
[dvs-invalid]
exten => s,1,Wait(1)
 same => n,Playback(ss-noservice)
 same => n,Hangup()

; Outgoing (autopatch): the live network is read from AstDB 'dvsphone/active'.
```

DVS-RADIO-OUT

```
[dvs-radio-out]
exten => _X.,1,NoOp(radio dial)
 same => n,System(/var/lib/asterisk/dvs_phone_dialreq "${EXTEN}" "${DB(dvsphone/active)}")
 same => n,Hangup()
exten => i,1,Hangup()
exten => t,1,Hangup()

; Tones as sound (v9.3.16): plays touch-tone recordings, whispered into
; the live call by ChanSpy.  Only the dashboard starts this.
```

DVS-TONES

```
[dvs-tones]
exten => s,1,Answer()
 same => n,Wait(0.5)
 same => n,Playback(${DVSTONES})
 same => n,Wait(0.3)
 same => n,Hangup()

; ---- HOIP (Hams Over IP) -- node 1001 ----
```

`dvs-tones` is started by the Dashboard with `Originate` and whispered into the live call with ChanSpy, when **Send keypad tones** is set to **As sound**. `${DVSTONES}` is the list of digit recordings to play.

## The outgoing front door

DVS-NODE-DVSHOIP

```
[dvs-node-dvshoip]
exten => _X.,1,Set(DVSNET=dvshoip)
 same => n,Set(DVSOPT=)
 same => n,GotoIf($[${DB_EXISTS(dvsphone/then)}]?then:net)
 same => n(then),Set(DVSOPT=D(${DB_DELETE(dvsphone/then)}))
 same => n(net),GotoIf($["${DB(dvsphone/patch)}" = "0"]?bad)
 same => n,Goto(dvs-net-dvshoip,${EXTEN},1)
 same => n(bad),Goto(dvs-invalid,s,1)
exten => i,1,Goto(dvs-invalid,s,1)
exten => t,1,Hangup()
```

| STEP | WHY |
|---|---|
| `Set(DVSNET=dvshoip)` | Records which network this is (for the log and later steps). |
| `Set(DVSOPT=)` | Starts with no Dial options. |
| `GotoIf(DB_EXISTS(dvsphone/then)...)` | A favorite with saved tones is waiting: put `D(...)` in `DVSOPT` and delete the key so it is used once. |
| `GotoIf(... patch = 0 ...?bad)` | The Phone patch switch is off: refuse. |
| `Goto(dvs-net-dvshoip,${EXTEN},1)` | On to the network's rules, keeping the number. |
| `exten => i` , `t` | Anything strange: “no service” or hang up. |

## The radio hand-off

DVS-RADIO-DVSHOIP

```
[dvs-radio-dvshoip]
exten => _X.,1,NoOp(radio dial)
 same => n,System(/var/lib/asterisk/dvs_phone_dialreq "${EXTEN}" dvshoip)
 same => n,Hangup()
exten => i,1,Hangup()
exten => t,1,Hangup()
```

The number is passed in quotes, so `*` or `#` can't be read by the shell as anything else; the script then refuses anything that isn't plain digits. `Hangup()` ends the autopatch straight away (section 9), so the radio is never keyed by it.

### Dialing rules: an extension network (Hams Over IP)

DVS-NET-DVSHOIP

```
[dvs-net-dvshoip]
exten => 0098,1,NoOp(test call)
 same => n,Dial(PJSIP/3191@dvshoip,60,${DVSOPT})
 same => n,Hangup()
exten => 0097,1,NoOp(voicemail)
 same => n,Dial(PJSIP/*97@dvshoip,60,${DVSOPT})
 same => n,Hangup()
exten => _X.,1,NoOp(extension call)
 same => n,Dial(PJSIP/${EXTEN}@dvshoip,60,${DVSOPT})
 same => n,Hangup()
exten => i,1,Goto(dvs-invalid,s,1)
```

| LINE | MEANING |
|---|---|
| `0098` | The Phone tab's **Test call** row: dials the network's saved test number (3191 here, the HOIP tone read-back). |
| `0097` | The **Voicemail** row: dials the saved voicemail access code. |
| `_X.` | Any extension you dial: sent as typed. |
| `i` | Anything else: “no service”. |

### Dialing rules: a phone-number network (VoIP.ms)

DVS-NET-DVSVOIPMS

```
[dvs-net-dvsvoipms]
exten => 911,1,NoOp(911 - E911 is set up on this network)
 same => n,Set(CALLERID(num)=5550001111)
 same => n,Dial(PJSIP/911@dvsvoipms,60)
 same => n,Hangup()
exten => _NXXNXXXXXX,1,Goto(dvs-net-dvsvoipms-r,1${EXTEN},1)
exten => _1NXXNXXXXXX,1,Goto(dvs-net-dvsvoipms-r,${EXTEN},1)
exten => _X.,1,Goto(dvs-invalid,s,1)
exten => i,1,Goto(dvs-invalid,s,1)
```

- `911` exists only because **E911 is set up** is ticked for this network. It skips the blocked list and the saved-tones option.
- 10 digits get a leading 1, then both forms go to the `-r` context.
- `Set(CALLERID(num)=...)` sends your caller ID number, if you filled one in.
- The number format the provider wants (10 digits, 1+10, +1+10) is chosen per network on the Edit page and decides the `${EXTEN}` / `${EXTEN:1}` / `+${EXTEN}` in Dial.

DVS-NET-DVSVOIPMS-R

```
[dvs-net-dvsvoipms-r]
exten => _1800NXXXXXX,1,Goto(dvs-invalid,s,1)
exten => _1888NXXXXXX,1,Goto(dvs-invalid,s,1)
exten => _1877NXXXXXX,1,Goto(dvs-invalid,s,1)
exten => _1866NXXXXXX,1,Goto(dvs-invalid,s,1)
exten => _1855NXXXXXX,1,Goto(dvs-invalid,s,1)
exten => _1N00XXXXXX,1,Goto(dvs-invalid,s,1)
exten => _1N11XXXXXX,1,Goto(dvs-invalid,s,1)
exten => _1NXX555XXXX,1,Goto(dvs-invalid,s,1)
exten => _1NXX976XXXX,1,Goto(dvs-invalid,s,1)
exten => _1809XXXXXXX,1,Goto(dvs-invalid,s,1)
exten => _1900XXXXXXX,1,Goto(dvs-invalid,s,1)
exten => _1NXXNXXXXXX,1,NoOp(dialing)
 same => n,Set(CALLERID(num)=5550001111)
 same => n,Dial(PJSIP/${EXTEN}@dvsvoipms,60,${DVSOPT})
 same => n,Hangup()
```

The blocked kinds match stock `check_route`. They win over the general `_1NXXNXXXXXX` line because they are more specific (section 4).

### Incoming: open (Hams Over IP)

DVS-IN-DVSHOIP (THE S EXTENSION REPEATS THE SAME STEPS)

```
[dvs-in-dvshoip]
exten => _[+0-9].,1,NoOp(incoming call from ${CALLERID(num)})
 same => n,GotoIf($["${DB(dvsphone/open)}" = "1" & "${DB(dvsphone/active)}" = "dvshoip"]?open)
 same => n,Busy(20)
 same => n,Hangup()
 same => n(open),NoOp()
 same => n(connect),Answer()
 same => n,Wait(1)
 same => n,Playback(rpt/connected)
 same => n,rpt(1001,Pv)
 same => n,Hangup()
```

### Incoming: PIN and trusted numbers (VoIP.ms)

DVS-IN-DVSVOIPMS

```
[dvs-in-dvsvoipms]
exten => _[+0-9].,1,NoOp(incoming call from ${CALLERID(num)})
 same => n,GotoIf($["${DB(dvsphone/open)}" = "1" & "${DB(dvsphone/active)}" = "dvsvoipms"]?open)
 same => n,Busy(20)
 same => n,Hangup()
 same => n(open),NoOp()
 same => n,GotoIf($["${CALLERID(num):-10}" = "5551234567"]?connect)
 same => n,Answer()
 same => n,Wait(1)
 same => n,Set(TRIES=0)
 same => n(ask),Read(PIN,beep,8,,1,10)
 same => n,GotoIf($["${PIN}" = "1234"]?connect)
 same => n,Set(TRIES=$[${TRIES} + 1])
 same => n,GotoIf($[${TRIES} >= 3]?bye)
 same => n,Playback(confbridge-invalid)
 same => n,Goto(ask)
 same => n(bye),Playback(confbridge-pin-bad)
 same => n,Hangup()
 same => n(connect),Answer()
 same => n,Playback(rpt/connected)
 same => n,rpt(1002,Pv)
 same => n,Hangup()
```

| STEP | WHY |
|---|---|
| `GotoIf(... open ... active ...?open)` | Answer only while the Phone tab is open and this network is the picked one; otherwise `Busy(20)`. |
| `GotoIf(CALLERID(num):-10 = ...?connect)` | A trusted number skips the PIN (one line per number). |
| `Read(PIN,beep,8,,1,10)` | Beep, then up to 8 digits ending in #; three tries. |
| `rpt(1002,Pv)` | Join the network's node in phone mode with VOX. |

**NOTE** With incoming set to **Hang up**, the context is just `exten => _[+0-9].,1,Hangup()` and `exten => s,1,Hangup()`.

12 · ASL-DVS

# The phone nodes in rpt.conf

RPT.CONF, BETWEEN THE DVS-PHONE MARKERS (ONE NETWORK)

```
[1001](node-main)
rxchannel = Local/pseudo
context = dvs-node-dvshoip
```

```
callerid = "Phone" <0000000000>
functions = functions1001
phone_functions = functions1001
link_functions = functions1001
duplex = 1
voxtimeout = 10000
voxrecover = 2000
simplexpatchdelay = 25
simplexphonedelay = 25

[functions1001]
61 = autopatchup,noct=1,farenddisconnect=1,dialtime=20000,context=dvs-radio-dvshoip,quiet=1
62 = cmd,/var/lib/asterisk/dvs_phone_hangup
63 = cop,9
64 = cop,10
65 = cmd,/var/lib/asterisk/dvs_phone_hangup
99 = cop,6
980 = cmd,/var/lib/asterisk/dvs_phone_tonecode 0
981 = cmd,/var/lib/asterisk/dvs_phone_tonecode 1
982 = cmd,/var/lib/asterisk/dvs_phone_tonecode 2
```

| LINE | WHY |
|---|---|
| `[1001](node-main)` | A private node (1000–1999), built on the stock template. |
| `rxchannel = Local/pseudo` | No radio: audio only comes from links and the call. |
| `context = dvs-node-dvshoip` | Where this node's dialing starts (also where SysMon's Dialing rules card begins). |
| `callerid = "Phone" <0000000000>` | Caller ID the node presents. |
| `functions` / `phone_functions` / `link_functions` | All three use the node's own table, so your radio (over the link) and a phone caller see the same codes. |
| `duplex = 1` + VOX lines | Simplex with the default VOX values, so call audio passes cleanly to a simplex radio. |
| `61 = autopatchup,...,context=dvs-radio-dvshoip,quiet=1` | *61 from the radio: collect digits, hand them to the Dashboard, end quietly. |
| `62` / `65` = hang-up script | Hang up any phone call. |
| `63` / `64` | Phone patch on / off. |
| `99 = cop,6` | Phone-mode PTT, kept as shipped. |
| `980` / `981` / `982` | Send *, # or *99 into the call (the Dashboard plays them). |

## The three helper scripts

All live in `/var/lib/asterisk`, are written by the Dashboard, and are removed by Revert.

DVS_PHONE_DIALREQ (*61 HAND-OFF)

```
#!/bin/bash
# asl_dvs_dashboard - radio dial request (written by the dashboard)
# Leaves a note for the dashboard; the dashboard places the call.
case "$1" in ''|*[!0-9]*) exit 0 ;; esac
[ ${#1} -le 20 ] || exit 0
case "$2" in ''|*[!a-z0-9]*) exit 0 ;; esac
d=/run/asl_dvs_tones/req
[ -d "$d" ] || exit 0
: > "$d/dial_$1_$2" 2>/dev/null
exit 0
```

DVS_PHONE_TONECODE (*980-*982)

```
#!/bin/bash
# asl_dvs_dashboard - radio tone code (written by the dashboard)
# Leaves a note for the dashboard; the dashboard sends the tones.
case "$1" in [0-2]) ;; *) exit 0 ;; esac
d=/run/asl_dvs_tones/req
[ -d "$d" ] || exit 0
: > "$d/code$1" 2>/dev/null
exit 0
```

DVS_PHONE_HANGUP (*62, *65)

```
#!/bin/bash
# asl_dvs_dashboard - hang up every Phone-tab call (written by the dashboard)
asterisk -rx "core show channels concise" | awk -F'!' '{print $1}' \
  | grep -E '^(IAX2|PJSIP)/dvs' | while read -r ch; do
    asterisk -rx "channel request hangup $ch"
done
```

The first two only leave an empty file named after the request in `/run/asl_dvs_tones/req` (for example `dial_5551234567_dvsvoipms`). The Dashboard checks that folder every two seconds, deletes each file and acts on its name. Nothing else is passed, so nothing else can be injected.

13 · ASL-DVS

# The SIP account file

`dvs_phone_pjsip.conf` defines each SIP network as a small group of PJSIP objects. All share the network's id as their name, told apart by `type=`.

DVS_PHONE_PJSIP.CONF (HAMS OVER IP PART)

```
; asl_dvs_dashboard - Phone tab SIP accounts (rewritten on every apply)

[dvs-transport]
type=transport
protocol=udp
bind=0.0.0.0:5060
local_net=192.168.1.0/24
local_net=127.0.0.1/32

; ---- HOIP ----
[dvshoip-auth]
type=auth
auth_type=userpass
username=kd8pgk
password=secret

[dvshoip-reg]
type=registration
outbound_auth=dvshoip-auth
server_uri=sip:hoip.example.net:5160
client_uri=sip:kd8pgk@hoip.example.net
expiration=3600
line=yes
endpoint=dvshoip

[dvshoip]
type=aor
contact=sip:hoip.example.net:5160

[dvshoip]
type=endpoint
context=dvs-in-dvshoip
disallow=all
allow=ulaw
aors=dvshoip
```

```
direct_media=no
rtp_symmetric=yes
force_rport=yes
rewrite_contact=yes
dtmf_mode=rfc4733
outbound_auth=dvshoip-auth
from_user=kd8pgk
from_domain=hoip.example.net

[dvshoip]
type=identify
endpoint=dvshoip
match=hoip.example.net
```

| OBJECT | JOB |
|---|---|
| `type=transport` | The UDP socket on port 5060. Written only if your pjsip.conf has no transport; `local_net` and the public address help behind a router. |
| `type=auth` | Username and password for the account. |
| `type=registration` | Signs in so incoming calls can reach you. Written **only for the picked network**, so two accounts for one number never compete. |
| `type=aor` | Where to send calls (the provider's address); `qualify_frequency` checks it every 60 s. |
| `type=endpoint` | The account itself: codecs, NAT handling, tone mode, and `context=dvs-in-dvshoip` for incoming calls. |
| `type=identify` | Recognises incoming traffic from the provider's address as this account. |

| ENDPOINT LINE | WHY |
|---|---|
| `context=dvs-in-<net>` | Incoming calls enter the dialplan here (section 11). |
| `disallow=all` + `allow=ulaw/alaw/gsm` | Only codecs app_rpt handles well on a small Pi. |
| `direct_media=no` | Audio always goes through Asterisk (it must, to reach the node). |
| `rtp_symmetric`, `force_rport`, `rewrite_contact` | Behind-a-router (NAT) friendliness. |
| `dtmf_mode=rfc4733` | Keypad tones go as tone packets (RFC 2833/4733). Fixed for every SIP network since 9.3.71.5 / 9.3.73. |

**NOTE** IAX2 networks are written to `dvs_phone_iax.conf` (one peer each, `context=dvs-in-<net>`) and `dvs_phone_iax_reg.conf` (one `register =>` line, for the picked network only).

# Call flows

## A. You press Dial, a favorite, Test call or Voicemail

**1 The Dashboard checks**
Phone tab open, patch on, a network picked and linked, number rules (911/E911, blocked kinds, international).

▼

**2 It sends Originate**
Local/@dvs-node-/n, Application Rpt, Data ,Pv, Timeout 65 s.

▼

**3 dvs-node → dvs-net (→ -r)**
Patch switch, saved tones, rules, then Dial() on the network.

▼

**4 The far end answers**
The Local pair answers; rpt(,Pv) joins the call to the phone node.

▼

**5 VOX keys the link**
The radio transmits only while the far end talks; in the gaps your radio is heard.

## B. You key *61 and a number on the radio

**1 DTMF crosses the link**
Your radio node passes *61 and the digits to the phone node (link_functions).

▼

**2 Autopatch collects the digits**
Unique match, or 1.5 s after the last digit; context dvs-radio-.

▼

**3 System() leaves a note**
dvs_phone_dialreq writes dial__; Hangup() ends the autopatch silently.

▼

**4 The Dashboard dials**
Within about 2 s, exactly as route A. The result shows as a Phone tab notice.

## C. Someone calls you

**1 The provider sends the call**
The account's endpoint (context=dvs-in-) puts it in the dialplan.

▼

**2 Tab open and network picked?**
No: Busy. Yes: trusted number, PIN or straight through.

▼

**3 rpt(,Pv)**
Joined with VOX; the Phone tab shows the caller and lights a matching favorite.

## D. Keypad tones during a call

| SEND KEYPAD TONES | HOW THE TONES TRAVEL |
|---|---|
| Straight to the provider | The Dashboard plays them on the SIP/IAX2 leg (AMI PlayDTMF); SIP sends them as RFC 2833 packets. |
| Through the call | Played on the node side so they pass through the call like the radio's own tones; saved favorite tones go in Dial's D() option. |

| SEND KEYPAD TONES | HOW THE TONES TRAVEL |
|---|---|
| As sound | Touch-tone recordings played into the call by dvs-tones and ChanSpy. |

### E. Hanging up

| YOU USE | WHAT HAPPENS |
|---|---|
| Hang up (Phone tab) | The Dashboard hangs up every PJSIP/IAX2 `dvs` channel and sends `rpt cmd <node> autopatchdn` to cancel a radio dial still collecting digits. |
| `*62` or `*65` (radio) | The hang-up script ends every phone call. |
| The far end hangs up | The call legs close; `rpt()` returns and the call is gone. |



# Switches and the Dashboard's part

### AstDB keys

| KEY | SET WHEN | READ BY |
|---|---|---|
| `dvsphone/open` | The Phone tab is open (1) or closed (deleted). | dvs-in-: answer or Busy. |
| `dvsphone/active` | You pick a network. | dvs-in-; dvs-phone-out; dvs-radio-out. |
| `dvsphone/patch` | Phone patch on (1) / off (0). | dvs-node-, dvs-phone-out: refuse when 0. |
| `dvsphone/then` | A favorite with saved tones is dialed (Through the call). | dvs-node-: becomes Dial's D(); deleted on use. |

WHAT IT LOOKS LIKE (EXAMPLE)

```
sudo asterisk -rx "database show dvsphone"
/dvsphone/active                                  : dvshoip
/dvsphone/open                                    : 1
/dvsphone/patch                                   : 1
```

### What the Dashboard does around the dialplan

- **Save Phone:** writes the files, reloads what changed, checks each phone node is running.
- **Phone tab open:** links the picked network's node to the radio node (two-way, or monitor in Listen only), sets `open` and turns the transmitter time-out off with a safety cap.
- **Every 2 seconds:** reads the link list ( `RPT_ALINKS` ), fixes a link in the wrong mode, checks the request folder for *61 dials and *980–*982 tones.
- **Dial:** Originate (section 7). **Hang up:** section 14E.
- **Start-up:** compares what it would write with the files and refreshes anything stale.

### Listen only

With **Listen only** ticked, the phone node is linked as a monitor link ( `ilink 2` instead of `ilink 3` ). app_rpt never keys or sends audio over a monitor link, so nothing from your radio, including DTMF codes, reaches the phone node. Check it with:

LINK MODE

```
sudo asterisk -rx "rpt xnode 652702" | grep ALINKS
RPT_ALINKS=1,1001RU        ; R = listen only (monitor), T = two-way; K/U = keyed/unkeyed
```

# Stock and ASL-DVS side by side

| | STOCK ASL3 | ASL-DVS |
|---|---|---|
| Out of the box | Off: codes commented out, pstn-out says “no service” | Off until you Activate it on the Edit page |
| Where the patch lives | On your radio node | A private node per phone network, linked only while the Phone tab is open |
| Files | You edit rpt.conf and extensions.conf | Its own included files, a marked block, one include line |
| Several providers | Your own contexts | One block of contexts per network; one picked at a time |
| Dialing from the radio | *61: autopatch dials | *61: autopatch collects, the Dashboard dials |
| Dialing from a browser | — | Dial, favorites, Test call, Voicemail |
| How the call joins | Autopatch (link keyed all call) | rpt(node,Pv): phone mode with VOX |
| Simplex hotspot | Dead key | Keys only while the far end talks |
| Blocked numbers | check_route | Same kinds, per network (-r context) |
| 911 | Routed like any X11 if enabled | Only with “E911 is set up” |
| Incoming | Your own (example: iax-client) | Only while the tab is open; PIN or trusted numbers |
| Tones | Radio DTMF only | Keypad, favorites, *980–*982; three routes |
| Listen only | — | Monitor link option |
| Ringing on the air | Yes | No: you hear the call once answered |
| Seeing it | Asterisk CLI | Asterisk CLI, SysMon Phone tab, Dashboard report |

**WHY** Both use the same building blocks: contexts, patterns, Dial() and rpt(). ASL-DVS writes more of them, keeps them in its own file, and moves the call from autopatch to phone mode so a simplex radio can talk back.

**CAREFUL** Trade-offs of phone mode: no ringback on the air; after 10 s of nonstop far-end talk the radio unkeys for 2 s (voxtimeout / voxrecover); and radio-dialed calls need the Phone tab open, which is also the only time your radio is linked to the phone node.



# Watching a call and fixing problems

## Watch a call step by step

CONSOLE

```
sudo asterisk -rvvv          ; open the console with more detail (Ctrl-C to leave)
core set verbose 3           ; or set it inside a running console
```

Each step the dialplan runs is printed as `Executing [number@context:step] App(...)`. A Dashboard call to VoIP.ms looks like this (trimmed, illustrative):

A CALL IN THE LOG

```
-- Executing [15551234567@dvs-node-dvsvoipms:1] Set("Local/15551234567@dvs-node-dvsvoipms-00000004;2",
"DVSNET=dvsvoipms")
-- Executing [15551234567@dvs-node-dvsvoipms:6] Goto("Local/...;2", "dvs-net-dvsvoipms,15551234567,1")
-- Executing [15551234567@dvs-net-dvsvoipms:1] Goto("Local/...;2", "dvs-net-dvsvoipms-r,15551234567,1")
-- Executing [15551234567@dvs-net-dvsvoipms-r:3] Dial("Local/...;2", "PJSIP/15551234567@dvsvoipms,60,")
-- Called PJSIP/15551234567@dvsvoipms
-- PJSIP/dvsvoipms-0000000a answered Local/...;2
-- Executing [...] Rpt("Local/...;1", "1002,Pv")
```

## Useful commands

| COMMAND | SHOWS |
|---|---|
| `sudo asterisk -rx "dialplan show dvs-net-dvsvoipms"` | The loaded rules for one context. |
| `sudo asterisk -rx "dialplan show 15551234567@dvs-net-dvsvoipms-r"` | Which line a number would match. |
| `sudo asterisk -rx "dialplan reload"` | Re-read extensions.conf and its includes. |
| `sudo asterisk -rx "database show dvsphone"` | The four switches. |
| `sudo asterisk -rx "core show channels concise"` | Live call legs. |
| `sudo asterisk -rx "rpt xnode 652702" \| grep -E "ALINKS\|TXKEYED"` | Link mode and whether the radio is keyed. |
| `sudo asterisk -rx "pjsip show endpoint dvsvoipms"` | One SIP account, including dtmf_mode. |
| `sudo asterisk -rx "pjsip show registrations"` | Sign-in state (the picked network only). |
| `sudo journalctl -u asl_dvs_dashboard -n 50 \| grep -i phone` | The Dashboard's phone log (dials, radio codes, link fixes). |

## Common problems

| YOU SEE | LIKELY CAUSE | CHECK OR FIX |
|---|---|---|
| “No service” on every call | Patch switched off, or the number fits no rule | `database show dvsphone` (patch = 1?); `dialplan show <number>@dvs-net-<net>` |
| Incoming callers get busy | Phone tab closed, or another network picked | Open the tab and pick that network |
| Radio *61 does nothing | Tab closed, Listen only on, or app_system not loaded | `module show like app_system` ; the Dashboard log |
| Radio keyed for the whole call | An old autopatch call (before 9.3.71.8 / 9.3.73) | Update; check TXKEYED drops to 0 in silence |
| Far end can't hear you | Hotspot can't hear you, or Listen only | TXKEYED = 0 in the gaps? ALINKS shows T, not R? |
| Tones not recognised | Provider wants another tone route | Try the other Send keypad tones choices |
| Your own context vanished | It was inside a dvs file or the markers | Keep your edits outside them |

18 · REFERENCE

# Quick reference

| RADIO CODE | DOES | SPECIAL NUMBER | MEANS |
|---|---|---|---|
| `*61<number>` | Dial (through the Dashboard) | `0098` | Test call |
| `*62` / `*65` | Hang up | `0097` | Voicemail |
| `*63` / `*64` | Patch on / off | `911` | Only with E911 set up |

| RADIO CODE | DOES |
|---|---|
| `*980` | Send * |
| `*981` | Send # |
| `*982` | Send *99 |
| `*99` | Phone-mode PTT (stock) |

| SPECIAL NUMBER | MEANS |
|---|---|
| `s` | Call with no number |
| `i` | Matched nothing |
| `t` | Timed out |

| PATTERN CHAR | MATCHES |
|---|---|
| `X` | 0–9 |
| `Z` | 1–9 |
| `N` | 2–9 |
| `[...]` | one of the set |
| `.` | one or more of anything |
| `!` | zero or more, match at once |

| FILE | OWNER | RELOAD |
|---|---|---|
| `extensions.conf` | you (+1 include line) | `dialplan reload` |
| `dvs_phone_extensions.conf` | Dashboard | `dialplan reload` |
| `rpt.conf` | you (+ marked block) | `module reload app_rpt` |
| `dvs_phone_pjsip.conf` | Dashboard | `module reload res_pjsip.so` |
| `dvs_phone_iax*.conf` | Dashboard | `iax2 reload` |
| `/var/lib/asterisk/dvs_phone_*` | Dashboard | — |

| RPT() OPTION | MEANS |
|---|---|
| `P` | phone control |
| `D` | dumb phone (keyed all call) |
| `S` | dumb simplex (* toggles) |
| `R` | reverse autopatch |
| `X` | link without security check |
| `v` | add VOX |
| `m` | monitor only |

Sources: AllStarLink app_rpt (sample configs, `app_rpt.c`, `rpt_functions.c`), Asterisk dialplan documentation, and the ASL-DVS Dashboard and SysMon code named on the cover.