ERRORS

MCAPI_ERR_NODE_NOTINIT	The node is not initialized.
MCAPI_ERR_ENDP_INVALID	Argument is not an endpoint descriptor.
MCAPI_ERR_ATTR_NUM	Unknown attribute number.
MCAPI_ERR_ATTR_SIZE	Incorrect attribute size.
MCAPI_ERR_ATTR_NOTSUPPORTED	Attribute not supported by the implementation.
MCAPI_ERR_PARAMETER	Incorrect `attribute` parameter.
MCAPI_ERR_GENERAL	Implementation specific error not covered by other status codes. Specifics must be documented.

SEE ALSO

mcapi_endpoint_set_attribute()