MCAPI_ERR_CHAN_OPENPENDING	An open request is pending
MCAPI_ERR_CHAN_CLOSEPENDING	A close request is pending.
MCAPI_ERR_CHAN_NOTOPEN	The channel is not open (cannot be closed)
MCAPI_ERR_CHAN_INVALID	Argument is not a channel handle
MCAPI_ERR_PKT_SIZE	The packet size exceeds the maximum size allowed by the MCAPI implementation
MCAPI_ERR_TRANSMISSION	Transmission failure
MCAPI_ERR_PRIORITY	Incorrect priority level
MCAPI_ERR_BUF_INVALID	Not a valid buffer descriptor
MCAPI_ERR_MEM_LIMIT	Out of memory
MCAPI_ERR_REQUEST_INVALID	Argument is not a valid request handle
MCAPI_ERR_REQUEST_LIMIT	Out of request handles
MCAPI_ERR_REQUEST_CANCELLED	The request was already canceled
MCAPI_ERR_WAIT_PENDING	A wait is pending
MCAPI_ERR_GENERAL	To be used by implementations for error conditions not covered by the other status codes
MCAPI_STATUSCODE_END	This should always be last

3.16.16   API parameter readability

MCAPI_IN and MCAPI_OUT are used only for clarity to distinguish between input and output parameters.