4.7.1 MRAPI_DISPLAY_STATUS

NAME

mrapi_display_status

SYNOPSIS

```
char* mrapi_display_status(
  MRAPI_IN mrapi_status_t mrapi_status,
  MRAPI_OUT char* status_message,
  MRAPI_IN size_t size
);
```

DESCRIPTION

`mrapi_display_status()` displays the status parameter as a string by copying it into the user supplied buffer: `status_message`.

RETURN VALUE

mrapi_true is returned on success, otherwise mrapi_false is returned. If the status is an unknown status, `status_message` will be set to "UNKNOWN".

ERRORS

NONE DEFINED	N/A

NOTE

SEE ALSO