



Kellfri®



**27-MMSV
SWEEPWE ROLLER**



**27-MMS
SCYTHE MOWER**



**27-MMJF
SOIL CULTIVATOR**



**27-MMSNB
SNOWBLADE**



**27-MMRS
ROTARY MOWER**



**27-MMSS
SNOW BLOWER**

**READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT !!!
TRANSLATED FROM THE ORIGINAL**

SAFETY INFORMATION

Before using the product, please read the safety information and instruction manual and understand its contents for your own and others' safety. Always keep the safety information and instruction manual easily accessible to the user of the product. Remember that it may be good for your own and others' safety to read the safety information every now and then. If the instructions manual is damaged or otherwise unusable, please contact and order a new one from: Your retailer

The general safety instruction is also available from Kellfri's website: www.kellfri.co.uk

Do not use this equipment if you are feeling sick, tired or in influence of alcohol. Nor if you are under the influence of strong medications or drugs, suffering from strong depression or severe mental illness. Always follow the general traffic rules and regulations and the rules of the Animal Welfare Act. Persons under 15 years old and people with mental illness may not use these products.



The product must not in any circumstances be modified without permission from the manufacturer. Unauthorized modification of the machine and/or accessories can cause fatal injuries or death to operator or others.

IMPORTANT!

PRODUCT SAFETY INFORMATION

To maintain safety, the machine shall not be used in any other manner than described in this manual. The user is responsible for that the instruction manual is read through and followed.

- Please read the user manual carefully before using the machine!
- Always check the performance of the machine combination that will be used to ensure safety and function
- Danger zone is 15 meters. No one other than the operator may be present within the danger zone while working with the equipment.
- For maintenance and service, support should always be used.
- The equipment must always be disconnected during maintenance / service.
- The operator or other person are never allowed to stand underneath a suspended load
- NEVER allow children or inexperienced persons to run the equipment.
- NEVER stick hands or feet under the machine without first turning off the engine
- NEVER attempt to remove the things that stuck when the machine is running!
- NEVER leave the equipment with the engine running - even for a short while.
- Make sure that all guards are always installed correctly and can not come loose.
- Reduce speed when working on slopes and uneven terrain.
- Check the area before starting the operation, clear the area from large objects that could get caught inside the machine.



Never use a equipment or product with defect safety equipment.

Warning!

INSTRUCTION FOR EMERGENCIES

In case of an emergency please dial 112.

Keep cell phone or emergency phone available specially when working alone. First aid kit and fire extinguishers must be kept easily accessible during all work, maintenance and service.

WARNING DECALS

Make sure that the warning labels are always visible, clean the warning labels if necessary. Do not wash with high pressure washer directly on the warning label. If any part of the decal is worn or label becomes frayed or otherwise unreadable, order new decals.

SYMBOL	EXPLANATION
	Read the manual Turn off the engine and remove the key from the ignition when repairing or when leaving the machine even for a short moment.
	Danger zone 15 m Warning! Ejection of objects
	Rotating parts! Warning! Risk of crushing!
	Prohibition to stay on the machine
	Risk of child accident! Children is not allowed to be near the machine
	The product is CE marked

INCASE OF EMERGENCIES

In case of an emergency please dial 112.

Keep cell phone or emergency phone available specially when working alone. First aid kit and fire extinguishers must be kept easily accesable during all work, maintenance and service.



PERSONAL PROTECTION

Always use suitable protection equipment. Do not wear loose clothing or jewellery while working with the equipment. Long hair should be tied up when working equipment that has moving parts. Use protective gloves as there is a risk of burns if any hot surfaces are touched such as exhaust pipes, and avoid getting oil and petrol on skin. Ear defenders must be worn whilst the engine is running.




SURROUNDINGS

Make sure your working area is clear from people, children and objects before installing and using the machine. Risk of serious injuries can occur during operation. Take an extra caution when children are in the area where the equipment/ product is being use or stored. Check the area for low hanging electrical wires. Be careful when working on slopes and near ditches.

Always work alone with single - purpose tools/products. Never have junk lying in your area. Keep working areas clean. Always respect the risk zone.



Under no circumstances should young children be allowed to work with this equipment. Do not allow persons to use or assemble this unit until they have read this manual and have developed a thorough understanding of the safety precautions and of how it works. Review the safety instructions with all users annually



STEPS BEFORE USE

Carefully read the safety instructions and the operating instructions. Make sure that you understand the safety instructions, operating instructions and warning decals. Use common sense when using the product and suitable personal protective equipment. Always check the performance of the machine combination to be used. It is important that these are in harmony and work satisfactorily. This is done to ensure the equipment or product work as expected, and to guarantee the safety of yourself and others. Carry out a visual inspection of the equipment or product before use. Repair or replace damaged or worn parts to reduce the risk of injury.

Grease moving parts and check that all nuts and bolts are tightened. Correct if necessary. Learn and remember the correct working method. Beginners must work slowly until they have learned how the machine or product works. Users/customers are responsible for ensuring users can handle the situation. If users feel that the machine is dangerous to use, it should not be used.



To ensure safety, the product must be used only in the manner prescribed in this instruction. The user is responsible for the instruction being read through and followed.

Warning!

- Perform a safety check of the machine before each use. If you notice any errors or omissions, the machine should immediately be repaired.
- Make sure there are no foreign objects in the machine before using it.
- During operation, the machine must be on a hard, flat surface. Avoid working on slippery surfaces, especially in winter
- Check the work area before operation. Make sure there are no people or animals nearby.
- Clear working area of stones, branches or hidden obstacles that might be hooked or snagged, causing injury or damage. Use only in daylight or good artificial light. Be sure machine is properly mounted, adjusted and in good operating condition. Ensure that all safety shielding and safety signs are properly installed and in good condition.



For safety, this product should only be used in the manner described in this manual. The user is responsible for the instruction to be read through and followed.

Warning!

OPERATING THE MACHINE

Only people who understand the safety information and instructions in this manual may operate the equipment. Be alert and careful when working with the machine and only use the equipment or product in the manner described in this manual.

When working with equipment that has moving parts, there is always the risk of injury. Be careful when working with equipment equipped with hydraulic hoses ,oil under pressure can penetrate the skin. Seek medical attention immediately if this occurs. Always work alone with the equipment that are defined as single purpose equipment. Respect the equipment's danger zone.

SAFETY TRAINING

Safety is a primary concern in the design and manufacture of our products. Unfortunately, our efforts to provide safe equipment can be wiped out by a single careless act of an operator or bystander. In addition to the design and configuration of equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence and proper training of personnel involved in the operation, transport, maintenance and storage of this equipment.

It has been said, "The best safety feature is an informed, careful operator." We ask you to be that kind of an operator. It is the operator's responsibility to read and understand ALL Safety and using instructions in the manual and to follow these. Accidents can be avoided.

Working with unfamiliar equipment can lead to careless injuries. Read this manual before assembly or using, to acquaint yourself with the machine. If this machine is used by any person other than yourself, or is loaned or rented, it is the machine owner's responsibility to make certain that the operator, prior to using:

- a. Read and understand the operator's manuals.
- b. Is instructed in safe and proper use.


Know your controls and how to stop the machine quickly in an emergency. Train all new personnel and review instructions frequently with existing workers. Be certain only a properly trained and physically able person will use the machinery. A person who has not read and understood all using and safety instructions is not qualified to use the machine. An untrained operator exposes himself and bystanders to possible serious injury or death. If the elderly are assisting with the work, their physical limitations need to be recognized and accommodated.

Coupling an uncoupling


- The equipment is connected to Kellfri multi-machine, read the manual before starting and using the equipment.
- Adjust the handrail according to the equipment to be connected.

CONNECTING THE EQUIPMENT

To make it easier to connect an accessory lift the multi-machine motor about 20 cm from the ground to keep the machine in a horizontal position. Make sure that the machine is stable.



- Pull out the locking pin on the connecting tube and connect the selected accessory to the machine. When the parts reach the bottom refit the locking pin. Make sure the equipment is secure and that the locking pin is placed in the correct location by pulling the equipment lightly.



TRANSPORT AND STORING

Make sure that the area is clear of people, children and objects before transportation. Always be extra careful during transport and movement. Ensure that the product is well secured and that existing transport safety devices are mounted. Always place the load as low as possible. Respect the danger zones even during transport and movement. When lifting, don't go under the suspended load. Trailer used for transport should have functioning brakes.

Always store the tool or product in a dry place, preferably underneath a roof when not in use. Make sure that the equipment or product stands stable and not likely to tip over. Never let children play at the storage site. Bear in mind the risk of tipping over!

MAINTENANCE AND SERVICE

Always turn off the engine before maintenance or servicing. Ensure that the unit is stable and cannot tip over. Replace damaged or worn parts immediately to reduce the risk of abrasion. Always perform maintenance, service and inspection, as recommended. Use only original replacement parts or spare parts with equivalent performance to reduce the risk of damage. All repairs and connections with electricity must be performed by a qualified person.

- Disconnect the equipment from the multi machine when the problem needs to be fixed.
- Regularly check the condition of the equipment before the failure is a fact. Discovered cracks, twisting, bending, glitches or fatigue stop work and correct the error.
- Worn parts are exchanged. Re-tighten all nuts and bolts after a few hours of driving, and after a day of operation.
- Check all bolts and nuts are tightened after maintenance and service. Always test the machine before work is started.
- Lubricate all lubrication points regularly. Lubrication points are lubricated every 20th hours.

For spare parts contact Kellfri Service.

RECYCLING

Disposal of the product, disassemble and transport to the municipality's recycling station. Contact your local authority for further information.

MAINTENANCE AND SERVICE

SERVICE	INTERVAL	
Sweeper	<ul style="list-style-type: none"> • Before each run • While driving • After each run 	<ul style="list-style-type: none"> • Check that there is nothing stuck in the sweeper • Listen for noises • Flush with water if necessary • Lubrication
Rotor	<ul style="list-style-type: none"> • Every 20h operating hours 	
Cultivator	<ul style="list-style-type: none"> • Before each run • While driving • After each run 	<ul style="list-style-type: none"> • Check all blades. Replace any defective blades. Sharp blades yield better results. When replacing, bolts are tightened properly • Listen for noises
Rotor	<ul style="list-style-type: none"> • Every 20h operating hours 	<ul style="list-style-type: none"> • Clean and lubricate the moving parts • Lubrication
Rotary mower	<ul style="list-style-type: none"> • Before each run • While driving • After each run 	<ul style="list-style-type: none"> • Check all blades. Sharpen the blades if necessary. • Listen for noises. • Clean and lubricate the blades

TROUBLESHOOTING

PROBLEM	CAUSE	MEASURE
The equipment does not rotate	<ul style="list-style-type: none"> - The equipment is not properly connected. - The connection is incorrectly adjusted 	<ul style="list-style-type: none"> - Check that the equipment is properly connected to the multi-machine. - Check the clutch, adjust. (See multi-user machine manual)
Poor sweeping result	<ul style="list-style-type: none"> - The broom incorrectly set - Sweeper RPM is too low 	<ul style="list-style-type: none"> - Check the RPM and brush setting, adjust the brush lever. The distance between the brush and the ground should not be less than 3 cm.
Rotor mower cuts poorly	<ul style="list-style-type: none"> - The knife is unsharp 	<ul style="list-style-type: none"> - Make sure the blade and sharpen if necessary.

INTRODUCTION

Thank you for choosing a product from Kellfri AB. By following general safety information, operating instructions and common sense, you will have many years of enjoyable use of the product. Kellfris equipment and products are aimed to be used by active farmers with high demands on functionality.

PRODUCT INFORMATION

Kellfri multi-machine's 27-MM different equipment

27-MMSV is excellent tool for cleaning streets, squares and courtyards. It can clean both large and small areas. Easy to install onto the multi-machine. The sweeper roller can be adjusted in three different working positions.

INTENDED USE

The machine is used for cleaning dirty solid surfaces, suitable to use on the streets. Can also be used for snow removal.

27-MMSV SWEEPER



L x W x H	950 x 430 x 730 mm
Working width	90 cm
Brush Diameter	320 mm
Pivoting brush right - left	±25°
Roller speed	400 rpm
Weight	38,1 kg




FILLING PLUG-GEARBOX OIL SAE 80-90



ASSEMBLY





NO	DESCRIPTION	QTY.	NO	DESCRIPTION	QTY.	NO	DESCRIPTION	QTY.
1	Lock ring φ12	1	26	Pin φ4 × 20	1	51	Lock ring φ52	2
2	Washer	1	27	Spring	1	52	Sealing washer	2
3	Connector	1	28	Attachment	1	53	Shaft - brush	2
4	Spring	1	29	Brush - straight	1	54	Bolt M8 × 40	2
5	Washer large	1	30	Nut M6	4	55	Pin	2
6	Bushing	1	31	Brush Holder	1	56	Brush	2
7	Spline shaft	1	32	Fixing plate to brush	1	57	Brush Holder	2
8	Washer φ20	2	33	Clamp	4	58	Flat washer φ12	2
9	Bearing 6004-2Z	2	34	Bolt M6 × 20	4	59	Nut M12	2
10	Pipe	1	35	Bolt M8 × 16	10	60	Oil plug	1
11	Universal coupling	1	36	Nut M8	6	61	Rubber Washer	1
12	Pin φ6 × 36	2	37	Bolt M8 × 25	10	62	Bevel gear	1
13	Claw coupling	1	38	Attachment	1	63	Wheel complete	2
14	Pin φ4 × 35	1	39	Protection sweeper	1	64	Bolt M8 × 20	2
15	Spline bushing	1	40	Spacer A	4	65	Wheel bracket	1
16	Bolt M8 × 30	8	41	Bearing 61904-2RS	1	66	Adjustable washer	1
17	Spring washer φ8	18	42	Sealing	1	67	Square Profile	2
18	Washer φ8	14	43	Bearing 6204-2RS	1	68	Attachment	2
19	Handle	1	44	Helical gears	1	69	Spring washer φ8	4
20	Lever for handles	1	45	Gear bearing base	1	70	Locking handle	1
21	Nut M6	1	46	Oil seal	1	71	Nut M12	1
22	Flat washer φ6	5	47	Gearbox	1	72	Angle	1
23	Pin	1	48	Bevel gear shaft	1	73	Support plate	1
24	Hex Bolt B	1	49	Connector	1	74	Threaded rod	1
25	Hex Bolt A	1	50	Bearing 6205	2			

PRODUCT INFORMATION

27-MMSB Scythe Mower, excellent for an easy way to cut areas where you can not access with the tractor. A strong and robust design that is capable of cutting tall grass and small twigs without problems. Good stability with two strong wheels.

APPLICATION AREA


Only suitable for cutting and trimming of grass and green space.




27-MMSB SCYTHE MOWER


L x W x H	970 x 520 x 580 mm
Working width	97 cm
Cutting height	20 – 60 mm
Weight	30 kg




ASSEMBLY







NO	DESCRIPTION	QTY.
1	Protection - gearbox	1
2	Bolt M6 × 25	6
3	Washer φ24 × φ6.3 × 2	6
4	Rubber Washer	12
5	Flat washer φ6	6
6	Spring washer φ6	6
7	Nut M6	6
8	Protection _ mount	1
9	Spring washer φ8	8
10	Flat washer φ8	8
11	Nut M8	4
12	Junction plate	1
13	Bolt M8 × 20	2
14	Gearbox	1
15	Bolt M8x25	2
16	Lever	1
17	Screw	1
18	Gasket	1
19	Nut	1
20	Bushing	1
21	Support	1
22	Cutter	1
23	Knife	5
24	Knife Protection	1



NO	DESCRIPTION	QTY.
14,001	Lock ring φ12	1
14,002	Washer	1
14,003	Connection bushing	1
14,004	Spring	1
14,005	Washer	1
14,006	Bushing	1
14,007	Lock ring φ20	1
14,008	Bearing 6004-2RS	1
14,009	Connecting pipe	1
14,010	Bolt M10 × 25	4
14,011	Spring washer φ10	4
14,012	Flat washer φ10	4
14,013	Seal φ47 × φ30 × 7	1
14,014	Bearing 6306	1
14,015	Spline shaft	1
14,016	Gasket	1
14,017	Bolt M8 × 20	4
14,018	Rubber washer φ23 × 3 × φ16.2	1
14,019	Oil plug M16 × 1.5 × 12	1
14,020	Bearing NK35 / 20	1
14,021	Seal φ45 × φ35 × 7	1
14,022	Swing arm	1
14,023	Gearbox	1
14,024	Bolt M10 × 22	5
14,025	Sealing Gasket	1
14,026	Bolt M6x10	1
14,027	Wedge	1
14,028	Support	1
14,029	Bushing	1
14,030	support washer	1
14,031	Bearing 6204-2Z	1
14,032	Nut	1
14,033	Sealing Gasket	1
14,034	Bolt M8x20	4

PRODUCT INFORMATION

Process soil easily with the 27-MMJF cultivator. The equipment is suitable for ground milling smaller surfaces and weed control, preparation of field and other types of less tillage. Two different working widths of 480 mm and 620 mm. Mounted behind Kellfri Multi Machine.

APPLICATION AREA

Used only for the cultivation of soil.


27-MMJF CULTIVATOR

L x B x H	630 x 610 x 320 mm
Arbetsbredd	480mm - 620 mm
Antal knivar	24 st
Diameter	330 mm
Fräsdjup	200 mm
Hastighet	475 rpm
Vikt	28,1 kg




PÅFYLLNINGSPLUGG-VÄXELLÅDSOLJA
SAE 80-90

ASSEMBLY



MOUNT PROTECTIVE COVER





NO	DESCRIPTION	QTY.
1	Gearbox	1
2	Searbox shaft	1
3	Bevel gear	1
4	Bevel gear shaft	1
5	Sealing Gasket	1
6	Connector	1
7	Washer	1
8	Cut	1
9	Bushing Connection	1
10	Bearing 6004-2rs	1
11	Bearing 6204	1
12	The bearing 6205	2
13	Rubber Washer	1
14	Cover plate	1
15	Cover plate	2
16	Spring washer φ12	1
17	Spring washer φ20	1
18	Lock ring φ52	2
19	Spring washer φ8	4
20	Nut M8	36
21	Bolt M8 × 16	12
22	Bolt M8 × 30	4
23	Oil plug M16 × 1.5 × 12	1
24	Washer	1

NO	DESCRIPTION	QTY.
25	Bushing	1
26	Spring	1
27	Knife 1	12
28	Knife 2	12
29	Metal cover	1
30	Right cover	1
31	Left cover	1
32	Right cover board	1
33	Left cover board	1
34	Shaft L = 595	1
35	Hex Head Bolt M8 × 25	24
36	Hex Bolt M12 × 65	1
37	Washer φ8	16
38	Washer φ12	1
39	Nut M12	1
40	Hex sbricka	1
41	Spring washer	1
42	Nut M12	1
43	O-ring Φ45 × 2.65	1
44	Left blade support 2	1
45	Left blade support 1	1
46	Right blade support 1	1
47	Right blade support 2	1
48	Junction plate	1

PRODUCT INFORMATION

Clear away snow easily with the 22-MMSNB blades, easy to install on Kellfri Multi Machine. Blades can be folding clasp in three different working positions.

APPLICATION AREA


Only used for snow removal.

27-MMSNB SNOWBLADE


L x W x H	900 x 550 x 450 mm
Working width	85 cm
Adjustable in height	0 – 50 mm
Weight	22,5 kg




ASSEMBLY



Lever for adjusting the snow blade's working angle.





NO	DESCRIPTION	QTY.
1	Cylinder	1
2	Lever	1
3	Handle	1
4	Pipe Pin $\varphi 4 \times 20$	1
5	Fixing screw	1
6	Bolt	1
7	Spring	1
8	Bolt	1
9	Nut M8	1
10	Junction plate	1
11	Flat washer $\varphi 10$	4
12	Spring washer $\varphi 10$	4
13	Screw M10 $\times 25$	4
14	Wear skid	2
15	Snow blades	1
16	Bolt M8 $\times 25$	2
17	Washer $\varphi 20 \times 2 \times \varphi 8$	6
18	Nut M8	8
19	Loop	1
20	Wear Blade - Plastic	1
21	Flat washer $\varphi 8$	6
22	Bolt M8 $\times 16$	6

PRODUCT INFORMATION


With one easy grip you can change the function of your machine. Convenient rotary mower to multi-machine 27-MM. Mowing unit for cutting grass. Two rotating discs with four blades each. Working width 800 mm and adjustable height up to 50 mm.

APPLICATION AREA

The equipment is intended to cut grass. Make sure that no stones or obstacles are sticking up in the way.

27-MMSRS ROTARY MOWER



L x W x H	945 x 690 x 330 mm
Rotor Plate	2 st
Disc diameter	404 mm
Cutting height	up to 50 mm
Weight	29 kg



27-MMRS ROTARY MOWER


CONNECTING SHAFT


BOLT M8X20



KNOBS To adjust the cutting height

Raise the working height by turning knobs
counterclockwise and lower by turning the
knobs clockwise.





NO	DESCRIPTION	QTY.	NO	DESCRIPTION	QTY.
1	Housing - transmission shaft	1	34	Gear	1
2	Drive shaft	1	35	Bushing B	2
3	Gear drive	2	36	Gasket - paper B	2
4	Bushing	1	37	Lock ring φ16	2
5	Connector	1	38	Lock ring φ47	2
6	Bearing Bush	1	39	Spacer B φ16 × 1	2
7	Washer	1	40	Nut M10 × 1.25	1
8	Spring	1	41	Knife	8
9	Washer	1	42	Pin	8
10	Spacer φ20 × 0.3x0.5	2	43	Locking pin φ4 × 20	8
11	Bearing 6004-2Z	2	44	Rotor Protection	2
12	Lock ring φ12	1	45	Bearing ring	2
13	Lock ring φ20	1	46	Frame - support in front	1
14	Flat washer φ10	7	47	Frame - support in the rear	1
15	Spring washer φ10	5	48	Protection - rear	1
16	Nut M10 × 1.25	4	49	Mudflaps	1
17	Bearing housing	2	50	Bracket	1
18	Gearbox	3	51	Tube A	1
19	Lid	2	52	Tube B	2
20	Gear	1	53	Side mount	2
21	Gear	1	54	Bushing D	4
22	Gear	1	55	Locking handle	2
23	Bushing A	1	56	Adjustment brace	2
24	Spacer shim A φ10 × 0.2x0.5	4	57	Split pin φ3 × 35	2
25	Spacer shim B φ16 × 0.2x0.5	4	58	Nut M8	9
26	Gasket	2	59	Nut M6	5
27	Bearing 6303-2Z	8	60	Washer φ24 × φ8.5 × 2	4
28	Flat washer φ8	78	61	Flat washer φ6	12
29	Spring washer φ8	64	62	Spring washer φ6	2
30	Bolt M8 × 20	56	63	Bolt M8 × 25	8
31	Transmission - lower	2	64	Bolt M8 × 35	5
32	Lower gear case	2	65	Bolt M8 × 40	4
33	Gear	1	66	Bolt M6 × 16	7

PRODUCT INFORMATION

Two-stage snow thrower for multi-machine 27-MM. Throws effective snow up to 6m. Change snow blower chute direction simply by cranking lever. Delivered with cleaning equipments. The working width is 56 cm and the snow blower can handle up to 50cm deep snow. The funnel is adjustable 270 degrees.

APPLICATION AREA

The equipment is intended for removal of snow


27-MMSS SNOW BLOWER

Snow snow blower chute	600 cm
Working height max	51 cm
Working width max	56 cm
Chute	vridbar 270 °
Weight	

CONTROLS FOR CHUTE DIRECTION

Turning to the right - crank clockwise

Turning to the left - cranking counterclockwise




CLEANING EQUIPMENT

WARNING! Never use your hands to clean a snow filled chute! Turn off the motor and ensure that all moving parts have stopped rotating before cleaning it .

SKIDS

Placement of components is based on the basis of a flat surface. Adjust upwards for hard-packed snow and down while driving in places with loose gravel or uneven terrain.

27-MMSS SNÖSLUNGA



NO	DESCRIPTION
1	Cover
2	Fixation of knife
6	Knife blade A
8	Knife blade B
11	Gear Cover - left
12	Gasket
13	Spacer
15	Gear
17	Shaft
20	Spline shaft
25	Fan

NO	DESCRIPTION
28	Skids
31	Cleaning plate
34	Cleaning Equipments
36	Bracket
40	Crank
44	Plastic fluted disc
45	Intermediate plate
47	Chute
48	Ejecting protection
52	Support- chute
63	Gear Cover - right



Complaint form

We are grateful for your help pointing out any inaccuracies in the Kellfri product delivered to you. Before making a complaint read Kellfri's general warranty and sales conditions in our catalog as well as the enclosed User's manual that comes with the machine.

Please fill in the details below and attach photo and other information in order to process your request.

Buyer:	Customer number:	
Address:	Invoice number:	
E-mail:	Phone nr:	
When was the product delivered?	When was the product taken into operation?	Did the product functioned as it should upon the first operation?

Defect product / part:
.....

Problem description:
.....
.....

Describe the sequence of events:
.....
.....
.....
.....

Other:
.....
.....

*Submit Complaint form and photo to:
Kellfri AB
Division of Services : Contact Kellfri retailer
Or e-mail service.
info@kellfri.se*

Signature:	Date:
------------	-------

WARRANTY TERMS AND CONDITIONS

Validity of the warranty - Kelifri's Warranty is valid 12 months from the date of purchase.

This warranty replaces - Compensation for spare parts after acknowledgment that the fault lies on the material or manufaturing defects.

This guarantee do not cover

- Labour costs
- Travel expenses
- Any modification that the buyer himself has/had made.
- Any consequential damages that occurred due to damage to the machine.
- Damage due to normal deterioration of the machine, inadequate: service, user inexperience or use of spare parts which are not original.
- Wear parts such as hoses, seals, oils, and mechanical belts



EG-FÖRSÄKRAN OM MASKINENS ÖVERENSTÄMMELSE, ORIGINAL

EC-DECLARATION OF CONFORMITY

According to 2006/42/EC, Annex 2A

Kellfri AB

Munkatorpsgatan 6

532 37 Skara, Sweden

Declares that the machine

Name: 27- MMSV, 27-MMSB, 27-MMJF, 27-MMSNB, 27-MMSS, 27-MMRS

Type: Sweeper roller, Scythe mower, Cultivator, Snowblade, Snowblower, Rotary Mower

Complies with all applicable provisions of the Machinery Directive 2006/42/EC.

Other equipment must meet the hardware requirements of the Directive.

Tina Baudtler, CEO 2015-09-08

Kellfri AB is constantly working on further developing their products and therefore reserves the right to modify, among other things the design and appearance without further notice.

CUSTOMER SERVICE

You are always welcome to give your feedbacks, reviews or ask us about our equipments and products.

Kellfri AB

Phone: 0046 (0)511 - 242 50

Fax: 0046 (0)511 - 168 33

E-mail: info@kellfri.se