

Whipped Cream Dispenser Cheat Sheet

For both Otis Classic 500 ml (one pint) dispensers. Print it and tape it inside a cabinet door.

Fill • Charge • Shake • Serve

About 60 seconds,
start to finish

THE ROUTINE

- 1 Chill.** Cold cream whips better. Chill the empty dispenser too if you have a few minutes.
- 2 Fill.** Up to one pint of heavy cream, never past the max fill line. The gas needs room.
- 3 Sweeten.** 2 tbsp powdered sugar + 1 tsp vanilla. Use powdered sugar or syrup, not granulated.
- 4 Seal.** Check the gasket sits flat inside the head. Screw the head on firmly and evenly. Add a tip.
- 5 Charge.** One 8 g N₂O charger in the holder. Screw it on until you hear the hiss.
- 6 Shake.** Four to six firm shakes, then stop. More is not better.
- 7 Dispense.** Fully upside down, tip pointing at the plate. Squeeze gently. Soft? Shake once or twice more.

RECIPE RATIOS

MAKE	WHAT GOES IN	SHAKES
Classic vanilla	1 pint heavy cream • 2 tbsp powdered sugar • 1 tsp vanilla (the base for the next four)	4–6
Maple	Classic base with 2 tbsp maple syrup in place of the sugar	4–6
Mocha	Classic base, vanilla swapped for 1 tbsp cocoa + 1 tsp instant espresso (whisk, strain)	4–6
Cinnamon	Classic base, vanilla swapped for ½ tsp ground cinnamon (whisk, strain)	4–6
Bourbon vanilla	Classic base + 1 tbsp bourbon	4–6
Cold foam	½ cup heavy cream • ¼ cup milk • 1–2 tbsp vanilla syrup (keep it pourable)	2–3
Chocolate mousse	1 cup warm heavy cream + 3 oz dark chocolate, melted and sweetened (chill fully, strain)	4–6
Rapid infusion	1 cup spirit + aromatics (swirl 1 min, rest 1–2 min, vent upright slowly, strain)	Swirl

FIX IT

PROBLEM	LIKELY CAUSE → FIX
Runny	Cream not cold or not rich enough → use cold heavy cream. Or it needs 1–2 more shakes.
Stiff or sputtering	Over-shaken → next time stop at four shakes and test.
Gas escaping at the head	Gasket missing or not flat → release pressure, reseal it.
Nothing comes out	Clogged tip (sugar or spice) → release pressure, brush the tip and valve.

THE THREE RULES

N₂O
ONLY

Cream chargers must be **N₂O** (nitrous oxide). CO₂ (soda) and N₂ (nitro coffee) cartridges look alike but won't whip cream.

30–36%
FAT

Heavy cream or heavy whipping cream. Half-and-half, milk and low-fat creams come out thin and foamy.

≤ 50°F
COLD

Straight from the fridge. **One charger per pint**, even if you only fill it halfway.

CLEAN & STORE

Release all pressure before opening. Upright over the sink, squeeze until there's no cream and no hiss. Then unscrew the head.

Remove the tip, tip base and gasket. Wash in warm soapy water, brush out the tips and valve, and dry fully.

Storing? A charged dispenser keeps in the fridge for up to about a week, within the cream's use-by date. Shake once or twice before use.

Safety: cream chargers are for food preparation only. Never open a dispenser that's under pressure, never use more chargers than it calls for, and keep chargers away from heat. Strain anything with seeds, zest or sugar before filling.