







































FAETURE TAGS AND BUILD CONFIGURATIONS

Each part is tagged with a faeature asignment property: BASE, COM1, COM2, 1WIRE, INT ANTENNA, EXT ANTENNA, DC-DC, 5V PWR, SENSORS, DEBUG, PCB

BASE = Common to all configurations

COM1 = First serial port feature (console)

COM2 = Second serial port feature

1WIRE = 1-Wire panel probe sensor interface

INT ANTENNA = On PCB internal 433MHz antenna

EXT ANTENNA = Extranal 433MHz antenna connector

DC-DC = On board (internal) DC-DC housekeeping power supply

5V PWR = Off board (external) 5V power housekeeping supply

SENSORS = On board curren, voltage and temperature sensors

DEBUG = Parts are only used inhouse for test and bring up

PCB = Parts that are a feature of the PCB and therefore are not purchased or stuffed

The SM (String Manager) configuration includes the following features (and excludes all others):

SM = BASE + COM1 + 1WIRE + INT ANTENNA + DC-DC + SENSORS + PCB

The ACA (Array Controller Apliance) and ACM (AC Meter Manager) configurations include the following features (and excludes all others):

ACA = BASE + COM1 + COM2 + EXT ANTENNA + 5V PWR + PCB

Note: Prior to Rev 8 the ACA and ACM configurations differed.

The DEBUG configuration includes the following features (and excludes all others):

DEBUG = BASE + COM1 + 1WIRE + INT ANTENNA + EXT ANTENNA + DC-DC + DEBUG + SENSORS + PCB

