

BATTERY JUNCTION BOX COMPONENTS LEGEND

2008 Ford Edge SE

2008 ELECTRICAL Fuse & Relay Information - Edge & MKX

Fuse/Relay Location	Fuse Amp Rating	Battery Junction Box Description
Mega	100	
F1	-	Not used
F3	-	Not used
F5	60 ⁽¹⁾	Cooling fan module - without trailer tow
	40 ⁽¹⁾	Cooling fan module - with trailer tow
F6	40 ⁽¹⁾	Cooling fan module - with trailer tow
F7	30 ⁽¹⁾	Heated seat module, left rear
F8	10 ⁽²⁾	Generator
F9	20 ⁽²⁾	Trailer tow park lamp relay
F12	-	Not used
F15	40 ⁽¹⁾	Anti-lock Brake System (ABS) module
F16	30 ⁽¹⁾	Dual Climate controlled Seat Module (DCSM). Heated seat module passenger side front
F17	20 ⁽¹⁾	Power point, instrument panel - Edge, Power point, console 1 - MKX
F18	20 ⁽¹⁾	Roof opening panel motor assembly
F21	7.5 ⁽²⁾	EVAP canister vent control solenoid. Powertrain Control Module (PCM)
F23	-	Not used
F24	10 ⁽²⁾	Trailer tow left stop/turn lamp relay
F27	10 ⁽²⁾	Rear seat release relay
F28	15 ⁽²⁾	Heated mirror relay
F30	15 ⁽²⁾	Powertrain Control Module (PCM)
F31	10 ⁽²⁾	Not Used
F32	10 ⁽²⁾	Brake Pedal Position (BPP) switch. Mass Air Flow/Intake Air Temperature (MAF/IAT) sensor. EVAP canister purge valve. Variable Camshaft Timing (VCT) valves. Heated oxygen sensors
F33	15 ⁽²⁾	Coil on Plugs, Ignition transformer capacitors - early production
F34	-	Not used
F35	10 ⁽²⁾	A/C clutch relay
F36	-	Not used
F39	40 ⁽¹⁾	Rear window defrost grid
F40	-	Not used
F41	30 ⁽¹⁾	Starter relay
F44	10 ⁽²⁾	Auto-dimming interior mirror, Reversing lamps
F45	-	Not used
F46	10 ⁽²⁾	Trailer tow right stop/turn lamp relay

2008 Ford Edge SE

2008 ELECTRICAL Fuse & Relay Information - Edge & MKX

F49	10 ⁽²⁾	Powertrain Control Module (PCM)
F50	10 ⁽²⁾	Anti-lock Brake System (ABS) module, ABS test connector
F51	5 ⁽²⁾	Headlamp, left-with adaptive headlamps
F52	5 ⁽²⁾	Fuel pump relay
F53	30 ⁽¹⁾	Smart Junction Box (SJB) - F29, F30, F31, F32, F33, F34, F35, F36, F37, F46
F57	40 ⁽¹⁾	Anti-lock Brake System (ABS) module, ABS test connector
F58	30 ⁽¹⁾	Smart wiper module
F59	30 ⁽¹⁾	Liftgate/Trunk Module (LTM)
F50	30 ⁽¹⁾	Driver Seat Module (DSM) - with memory, Power seat switch, left - without memory
F61	30 ⁽¹⁾	Power seat switch, right
F62	-	Not used
F63	40 ⁽¹⁾	Blower motor relay
F64	20 ⁽¹⁾	Power point console 2
F65	20 ⁽¹⁾	Power point console, rear
F66	20 ⁽¹⁾	Power point, cargo area
F67	-	Not used
F68	15 ⁽²⁾	Fuel pump relay
F69	-	Not used
F70	-	Not used
F71	10 ⁽²⁾	Brake Pedal Position (BPP) switch
F72	-	Not used

(1) Cartridge fuse

(2) Mini fuse

SMART JUNCTION BOX (SJB)

NOTE: For component location, see appropriate ELECTRICAL COMPONENT LOCATIONS article.

2008 ELECTRICAL Fuse & Relay Information - Edge & MKX



Fuse/Relay Location	Fuse Amp Rating	Smart Junction Box Description
F1	30	Power window motor, passenger side front - MKX
F2	15	Not used
F3	15	Rear Entertainment Module (RETM) - with DVD rear entertainment center, Accessory Protocol Interface Module (APIM) - with SYNC
F4	30	Power window motor, driver side front
F5	10	Keyless entry keypad, Rear seat release relay, Floor shifter

2008 Ford Edge SE

2008 ELECTRICAL Fuse & Relay Information - Edge & MKX

F6	20	Rear park/stop/turn lamps. Trailer tow left stop/turn lamp relay, Trailer tow right stop/turn lamp relay, Front park/turn lamps - Edge, Headlamps - MKX
F7	10	Low beam lamp, left front - Edge, Headlamp, left - MKX
F8	10	Low beam lamp, right front - Edge, Headlamp, right - MKX
F9	15	Cargo lamp, Overhead console, Interior lamps
F10	15	Exterior rear view mirrors, Floor shifter, Message center switch, Hazard/PAD/Traction switch, Headlamp switch, HVAC module, EMTC - with manual a/c, Steering wheel switches, Roof opening panel switch, Window adjust switches, Seat heater switches, Door lock switches, Memory set switch, Power liftgate release switch
F11	10	All Wheel Drive (AWD) module
F12	7.5	Exterior rear view mirror switch, Driver Seat Module (DSM), Left power seat switch
F13	5	Satellite Digital Audio Receiver System (SDARS) module
F14	10	Liftgate/Trunk Module (LTM)
F15	10	HVAC module, EMTC-with manual a/c, HVAC module, DATC - with automatic a/c
F16	15	Not used
F17	20	Door lock actuators, Roof opening panel motor assembly, Power window motors, Liftgate ajar switch - without power liftgate, Liftgate/Trunk Module (LTM)
F18	20	Audio Digital Signal Processing (DSP) module
F19	25	Rear window wiper motor
F20	15	Data Link Connector (DLC)
F21	15	Headlamp switch, Fog lamps
F22	15	Side lamps, Front park/turn lamps - Edge, Headlamps - MKX, Trailer tow park lamp relay, Rear park/stop/turn lamps, Rear marker lamps, License lamps/liftgate release switch - Edge, License plate lamps - MKX Illuminated liftgate applique - MKX
F23	15	High beam lamps - Edge, Headlamps - MKX
F24	20	Horn
F25	10	Vanity mirror lamps, Overhead console, Interior lamps
F26	10	Instrument Cluster (C)
F27	20	Ignition switch
F28	5	Audio Control Module (ACM)
F29	5	Instrument Cluster (C)
F30	5	Floor shifter
F31	10	Not used
F32	10	Not used
F33	10	Not used
F34	5	Steering Angle Sensor Module (SASM)
F35	10	All Wheel Drive (AWD) module, Parking Aid Module (PAM), Stability control sensor cluster, Heated seat modules

2008 Ford Edge SE

2008 ELECTRICAL Fuse & Relay Information - Edge & MKX

F36	5	Passive anti-theft transceiver
F37	10	Air inlet door actuator, HVAC module, EMTC - with manual a/c, HVAC module, DATC - with automatic a/c
F38	20	Radio amplifier, Audio Digital Signal Processing (DSP) module
F39	20	Audio unit
F40	20	Not used
F41	15	Audio Control Module (ACM), Roof opening panel, Door lock switches Power window motors, Master window adjust switch, Auto-dimming interior mirror unit
F42	10	Not used
F43	10	Rear window wiper motor
F44	10	Not used
F45	5	Smart wiper module, Blower motor relay, Rear window defrost relay, Heated mirror relay
F46	7.5	Restraints Control Module (RCM), Hazard/Pad/Traction switch, Occupant Classification System Module (OCSM)
F47	30c.b.	Master window adjust switch