

j4_controller

Firmware for the **Johnny 4 robot controller/transmitter**. Runs on a LILYGO TTGO T-Display v1.1 (ESP32). Reads potentiometers and two 4x4 keypads, ingests four more pots from the j4_display_right board, transmits control data to the robot receiver over ESP-NOW, and mirrors live data to the two XIAO display boards over UART.

What is Johnny 4?

Johnny 4 is a prop robot controlled wirelessly. This board is the handheld controller that the operator uses to drive the robot's servos, select audio phrases, and monitor battery status.

What this firmware does

- Reads analog potentiometers via four local ADS1115 ADC modules: the eyes joystick (eyes_x / eyes_y), the neck joystick (neck X / jaw Y), and the eight middle face pots (Eyebrow L/R, Basket Eyebrow L/R, Nose, Nose Basket, Bottom Eyelid L/R); the fourth module carries the neck-pivot pot and the two linear faders
- Reads the four panel toggle switches (LASER, VENT, EYE POP, and the AUX toggle by the right joystick) on GPIOs 32/33/13/15 with internal pull-ups
- Ingests four more pots (iris, color, brightness, volume) from [j4_display_right](#)'s dedicated ADS1115 over Serial2 as 25 Hz P: lines
- Reads two 4x4 matrix keypads via PCF8574 I2C expanders using a custom scan routine
- Left keypad: jukebox-style audio phrase selection: press a letter (A-D) then a digit (0-9) to queue a phrase, or press a digit alone to queue a 0x phrase (e.g. pressing 8 queues "08.wav")
- Right keypad: face presets. Tap a key to recall its saved face; hold a key 3 seconds to save the current face to it (j4_display_right shows a confirm prompt, * confirms). Faces persist on j4_talk's microSD and are re-loaded in the background whenever the talk link is up
- Press * to send a STOP command, press # to clear the buffer
- Mixes the joystick into differential neck-left / neck-right values over a 0-3200 range
- Transmits all control data to the robot receiver via ESP-NOW (fixed-size packed structs, no String members so they survive the wireless memcpy)
- Receives the jukebox file list from the robot receiver in chunks and forwards it to the display board; carries a need_filelist flag so the receiver re-sends the list if this board boots late
- Answers LIST? requests from the display board out of its cached copy, so a display reboot recovers the list without a full round trip
- Displays live pot values, keypress state, and battery voltage on the built-in TFT
- The TTGO's built-in button (GPIO 35) cycles the TFT through three screens: live data, WiFi MAC address, and a connection-status screen showing ESP-NOW LINK, j4_stepper_neck, j4_stepper_eyes, j4_talk, j4_display_left, and j4_display_right as CONNECTED (green) / DISCONNECTED (red)
- Sends a 49-byte binary status packet to the j4_display_left board at 25 fps over UART
- Shows a STATUS line on the built-in TFT: "ONLINE" when the ESP-NOW link is up and the steppers are healthy, "OFFLINE" if no status packet arrives, or the reported stepper fault (e.g. "NL OT", "EYES OFFLINE"); green when healthy, red on any fault

Hardware

Component	Details
Microcontroller	LILYGO TTGO T-Display v1.1 (ESP32 with built-in 1.14" ST7789 TFT)
ADC modules	Four ADS1115 (I2C addresses 0x48, 0x49, 0x4A, 0x4B); a fifth lives on j4_display_right
Toggle switches	LASER, VENT, EYE POP, AUX -- GPIOs 32/33/13/15, INPUT_PULLUP, switch closes to GND

Keypad expanders	Two PCF8574 I2C I/O expanders: 0x21 (keypad_left, A0 jumper high) and 0x20 (keypad_right)
Keypads	Two 4x4 matrix keypads, headers soldered directly into P0-P7; left = phrase select, right = face presets
Displays	j4_display_left (jukebox, Serial1) + j4_display_right (pot labels, Serial2)

Pin assignments

GPIO	Function
21	I2C SDA (ADS1115 x4, PCF8574 keypads x2)
22	I2C SCL
17	Serial1 TX to j4_display_left (XIAO D7)
27	Serial1 RX from j4_display_left (XIAO D6)
25	Serial2 TX to j4_display_right (XIAO D7, face-preset messages)
26	Serial2 RX from j4_display_right (XIAO D6, pot feed)
32	LASER toggle (INPUT_PULLUP, switch closes to GND)
33	VENT toggle (INPUT_PULLUP, switch closes to GND)
13	EYE POP toggle (INPUT_PULLUP, switch closes to GND)
15	AUX toggle, next to the right joystick (INPUT_PULLUP, unassigned)
34	Battery voltage sense (ADC input, read-only)
35	Screen-cycle button (TTGO built-in; data / MAC / connection status)

GPIO 35 is the TTGO's on-board button, so it needs no wiring. Potentiometer inputs are routed through the ADS1115 modules. GPIO 12 causes boot/flash issues when connected to a pot and is avoided. GPIO 17 is unreliable as an input and is used only as TX. Pins 36, 37, and 38 are input-only. The four toggles use the internal pull-ups, so each switch just shorts its GPIO to GND when flipped ON -- no external resistors.

Pin diagram

Physical layout, display facing AWAY from you (rails visible), USB-C at the TOP (matching how the board is mounted). The two header rails read top-to-bottom as shown.

LEFT rail		RIGHT rail
	+ - - [USB-C] - - +	
I2C SDA (ADS x4 + keypad) -- 21		5V
I2C SCL -- 22		GND ground
DISP-L TX -> XIAO D7 -- 17	TTGO	27 DISP-L RX <- XIAO D6
(free) -- 2	T-Display	26 DISP-R RX <- XIAO D6
AUX toggle -- 15	v1.1	25 DISP-R TX (face msgs)
EYE POP toggle -- 13		33 VENT toggle
(avoid: boot/flash) -- 12	[ST7789	32 LASER toggle
ground -- GND	TFT on	39 (input only)
3.3V -- 3V3	back]	38 (input only)

```

5V -- 5V | | 37 (input only)
ground -- GND | | 36 (input only)
+-----+

```

on-board (no header pin): GPIO34 = battery sense, B00T = GPIO00,
 GPIO35 = screen-cycle button, TFT on 4/5/16/18/19/23
 I2C bus: ADS_01 @ 0x48, ADS_02 @ 0x49, ADS_03 @ 0x4A, ADS_04 @ 0x4B,
 PCF8574 keypad_left @ 0x21, keypad_right @ 0x20
 toggles: INPUT_PULLUP, switch closes to GND (ON = LOW)

ESP-NOW (wireless) links this board to j4_receiver.

ADS1115 pin diagrams

All four modules share the TTGO's I2C bus (SDA = GPIO 21, SCL = GPIO 22, 3.3V, GND); only the ADDR strap and the four analog channels differ. Every pot's wiper goes to its A-pin; the outer legs go to 3.3V and GND.

ADS_01 @ 0x48 (ADDR -> GND) four face pots, left bank

```

+-----+
| VDD | 3.3V
| GND | GND
| SCL | TTGO GPIO 22 (I2C SCL)
| SDA | TTGO GPIO 21 (I2C SDA)
| ADDR | GND = address 0x48
| ALRT | not connected
| A0 | Eyebrow L pot wiper -> PCA9685 ch 6
| A1 | Eyebrow R pot wiper -> PCA9685 ch 7
| A2 | Basket Eyebrow L pot wiper -> PCA9685 ch 8
| A3 | Basket Eyebrow R pot wiper -> PCA9685 ch 9
+-----+

```

ADS_02 @ 0x49 (ADDR -> VDD) both joysticks

```

+-----+
| VDD | 3.3V
| GND | GND
| SCL | TTGO GPIO 22 (I2C SCL)
| SDA | TTGO GPIO 21 (I2C SDA)
| ADDR | VDD = address 0x49
| ALRT | not connected
| A0 | eyes joystick X wiper -> eyes pan servo (PCA9685 ch 3)
| A1 | eyes joystick Y wiper -> eyes tilt servo (PCA9685 ch 4)
| A2 | neck joystick X wiper -> neck L/R differential mix
| A3 | neck joystick Y (jaw) wiper -> neck L/R base height
+-----+

```

ADS_03 @ 0x4A (ADDR -> SDA) four face pots, right bank

```

+-----+
| VDD | 3.3V
| GND | GND
| SCL | TTGO GPIO 22 (I2C SCL)
| SDA | TTGO GPIO 21 (I2C SDA)
| ADDR | SDA = address 0x4A
| ALRT | not connected

```

```

| A0 | Nose pot wiper (up/down)    -> PCA9685 ch 10
| A1 | Nose Basket pot wiper       -> PCA9685 ch 11
| A2 | Bottom Eyelid L pot wiper   -> PCA9685 ch 12
| A3 | Bottom Eyelid R pot wiper   -> PCA9685 ch 13
+-----+

ADS_04 @ 0x4B (ADDR -> SCL)          neck-pivot + linear faders
+-----+
| VDD | 3.3V
| GND | GND
| SCL | TTGO GPIO 22 (I2C SCL)
| SDA | TTGO GPIO 21 (I2C SDA)
| ADDR | SCL = address 0x4B
| ALRT | not connected
| A0 | neck-pivot pot wiper      -> nP on the stepper link (0-3200)
| A1 | fader_left wiper          -> Nose Basket (doubles ADS_03 A1)
| A2 | fader_right wiper         -> iris (doubles j4_display_right IRIS)
| A3 | spare
+-----+

```

Analog inputs

Local, on the four ADS1115 modules over I2C:

Module	Channel	Control
ADS_01 (0x48)	A0	Eyebrow L pot
ADS_01 (0x48)	A1	Eyebrow R pot
ADS_01 (0x48)	A2	Basket Eyebrow L pot (was eye-pop, now a toggle)
ADS_01 (0x48)	A3	Basket Eyebrow R pot
ADS_02 (0x49)	A0	Eyes joystick X / eyes_x (was left arm)
ADS_02 (0x49)	A1	Eyes joystick Y / eyes_y (was right arm)
ADS_02 (0x49)	A2	Neck joystick X
ADS_02 (0x49)	A3	Neck joystick Y (jaw, feeds neck mixer)
ADS_03 (0x4A)	A0	Nose pot (up/down)
ADS_03 (0x4A)	A1	Nose Basket pot (up/down)
ADS_03 (0x4A)	A2	Bottom Eyelid L pot
ADS_03 (0x4A)	A3	Bottom Eyelid R pot
ADS_04 (0x4B)	A0	Neck-pivot pot (silver knob below j4_display_left, 0-3200)
ADS_04 (0x4B)	A1	fader_left (linear fader, doubles the Nose Basket pot)
ADS_04 (0x4B)	A2	fader_right (linear fader, doubles the IRIS pot)

ADS_04 (0x4B)	A3	Spare
---------------	----	-------

The eight face pots ride the ESP-NOW control packet to PCA9685 channels 6-13 on j4_receiver (Eyebrow L/R = ch 6/7, Basket Eyebrow L/R = ch 8/9, Nose = ch 10, Nose Basket = ch 11, Bottom Eyelid L/R = ch 12/13). The neck-pivot pot rides the packet in its own field and leaves the receiver as the nP slot of the stepper stream.

The two linear faders each double an existing rotary pot, arbitrated last-mover-wins: whichever control of the pair moved last (beyond a small claim threshold) is the active source and its value is used, so the two never fight. fader_right pairs with the IRIS pot on j4_display_right; fader_left pairs with the Nose Basket pot. A source that is absent (module unplugged, display feed down) can neither claim nor hold active status.

Remote, streamed from j4_display_right's dedicated ADS1115 (raw counts over Serial2, scaled here with the same processPot ()):

Channel	Control	Destination
A0	Iris	270-deg iris servo (PCA9685 on j4_receiver)
A1	Color	WS2812B strip color (j4_receiver)
A2	Brightness	WS2812B strip brightness (j4_receiver)
A3	Volume	j4_talk audio volume

eyes_x, eyes_y, and iris drive servos on the receiver's PCA9685. The neck joystick mixes into neck-L / neck-R as before. color and brightness drive the receiver's WS2812B strip.

Toggle switches

Four panel toggles, each wired between its GPIO and GND (internal pull-up, ON = LOW). Their states travel in the control packet as a bitmask:

GPIO	Toggle	Bit	Action on the robot
32	LASER	0	Laser servo, PCA9685 ch 14 on j4_receiver
33	VENT	1	Vent-fin servo, PCA9685 ch 15 on j4_receiver
13	EYE POP	2	Eye-pop steppers: sends 0 (normal) or 3200 (popped) down the stepper chain (j4_stepper_neck to j4_stepper_eyes)
15	AUX	3	Next to the right joystick; read and transmitted, not yet assigned

Keypad wiring

Two 4x4 keypads, each on its own PCF8574 backpack on the shared I2C bus:

- **keypad_left** (the newer keypad, left of the panel) at **0x21** -- set the backpack's A0 jumper high. If that backpack turns out to be a PCF8574A, the same jumper lands at 0x39; change the two 0x21 s in main.cpp .
- **keypad_right** (the original keypad) at **0x20** -- all jumpers low.

The left keypad drives phrase select; the right keypad drives face presets (tap = recall, 3s hold = save prompt, * confirms). Each can be absent or hot-plugged without affecting the other. Each has its own keymap string (keymap_left starts as a copy of keymap_right ; if the new model's matrix ordering differs, re-derive just that string by pressing each key and rearranging).

Each keypad is plugged straight into its PCF8574 P0-P7 (keypad pin 1 into P0, in order). The I2CKeyPad library's fixed scan pattern does not match this wiring, so the firmware uses a custom scan via the PCF8574 library directly.

Actual pin-to-wire mapping (derived on the original keypad):

PCF pin	Keypad wire
P0	Column 3 (3, 6, 9, #)
P1	Column 2 (2, 5, 8, 0)
P2	Column 1 (1, 4, 7, *)
P3	Row 4 (*, 0, #, D)
P4	Row 3 (7, 8, 9, C)
P5	Row 2 (4, 5, 6, B)
P6	Row 1 (1, 2, 3, A)
P7	Column 4 (A, B, C, D)

The scanner drives P0, P1, P2, P7 one at a time LOW and reads P3, P4, P5, P6.

Face presets

A **face** is a snapshot of the robot's facial expression: iris, eye color, eye brightness, the eight middle face pots, and the LASER / VENT / EYE POP toggle states. Volume, the neck values, and eyes X/Y are deliberately not part of a face.

On the **right keypad**:

- **Tap a key:** recall that key's saved face. Every face channel jumps to the saved value and holds there; turning any face pot takes just that channel back (frozen-baseline takeover, so even a slow turn works), and flipping a toggle takes that toggle back. The rest of the face stays put.
- **Hold a key for 3 seconds** (any key except *): j4_display_right shows "SAVE FACE ON <key> ? PRESS * TO CONFIRM". * saves, any other key cancels, and an unanswered prompt times out after 10 seconds.

Faces persist in `FACES.TXT` on j4_talk's microSD, so they survive power-off. The sync is fully background and never blocks anything:

- After boot (or whenever the talk link appears) this board re-requests the saved-face dump every 2.5s until a complete one lands.
- A save made while j4_talk is offline stays in RAM flagged dirty ("PENDING SD" on the display) and is pushed automatically when the link comes up; the display shows "FACE <key> ON SD" when the Teensy confirms the write.
- If the Teensy reports an SD write failure, the face stays usable in RAM for the session and auto-retry stops until it is re-saved.

Slots are keyed by the keypad **character**, so re-deriving a keymap keeps every saved face on the same printed key. 15 keys are usable as slots (* is the confirm key). Face traffic is its own ESP-NOW packet type (0x04) translated by j4_receiver to text lines on the Teensy UART; see those repos for the protocol.

Dependencies

Managed via PlatformIO (`platformio.ini`):

Library	Version
RobTillaart/PCF8574	0.3.9
RobTillaart/ADS1X15	0.3.13
TFT_eSPI	bundled in lib/ (pre-configured for TTGO T-Display v1.1)

Built-in ESP-IDF components used: `esp_now` , `WiFi` .

Building and uploading

```
# Build
pio run

# Upload
pio run --target upload

# Monitor serial output
pio device monitor
```

Upload speed is 921600 baud. Serial monitor is 115200 baud. Both are set in `platformio.ini` .

The TFT_eSPI copy in `lib/TFT_eSPI/` is pre-configured for the TTGO T-Display v1.1. Do not replace it with the registry version without reconfiguring.

Receiver

The robot receiver's MAC address is set in `broadcastAddress[]` near the top of `main.cpp` . Update this if the receiver board is swapped.

Related projects

- [j4 display left](#) -- the XIAO ESP32S3 jukebox display (portrait, left of the panel)
- [j4 display right](#) -- the XIAO ESP32S3 pot-label display (landscape, right of the panel) that streams the iris/color/brightness/volume pots to this board
- [j4 receiver](#) -- the robot-side TTGO that receives this controller's ESP-NOW packets and returns status