

j4_talk

Audio and mouth LED firmware for the Johnny 4 robot. Runs on a Teensy 4.1 with an Audio Shield Rev D. Plays WAV files from SD card as a serial-controlled jukebox and drives 18 mouth LEDs that react to the audio amplitude in real time.

What this board does

- Scans the SD card for WAV files at boot and serves them as a jukebox
- Plays, stops, and reports tracks over a serial link from the j4_receiver (PLAY / STOP / LIST? in, PLAYING: out)
- Reports end of track over serial so the now-playing highlight clears on the controller display
- Sends a PING heartbeat once per second so j4_receiver (and the controller) can show j4_talk as connected on the status screen
- Applies the controller's volume pot to the SGTL5000 codec (previously fixed at 0.8)
- Analyzes live audio amplitude using the AudioAnalyzePeak library
- Drives 18 LEDs across 5 amplitude tiers -- the mouth opens progressively as audio gets louder
- PWM brightness on the leading tier is gamma-corrected so the ramp looks visually linear

LED layout

18 PWM-capable Teensy pins drive 18 LEDs, one per pin, named after their physical position: **10 across the front** (front_LED_01 on the far left up to front_LED_10 on the far right) and **8 down the side** (side_LED_01 at the top down to side_LED_08).

Front row, left to right:

Name	f01	f02	f03	f04	f05	f06	f07	f08	f09	f10
Pin	2	3	4	5	6	9	16	17	22	14

Side, top to bottom:

Name	s01	s02	s03	s04	s05	s06	s07	s08
Pin	15	28	29	33	36	37	10	11

Each tier of LEDs lights up as amplitude crosses its threshold, spreading outward from the middle of the front row:

Tier	LEDs	Pins	Description
1	front 05, 06	6, 9	innermost front pair -- first to light
2	front 04, 07 + side 01, 02	5, 16, 15, 28	
3	front 03, 08 + side 03, 04	4, 17, 29, 33	
4	front 02, 09 + side 05, 06	3, 22, 36, 37	
5	front 01, 10 + side 07, 08	2, 14, 10, 11	outermost (full open)

Four channels were moved in v1_8: pins 24/25 are Serial6 to the receiver (driving them as PWM killed the serial link), and pins 38/39 have no PWM hardware on the Teensy 4.1 (they could only snap on/off). Those four LED channels now live on 14/15 and 10/11.

Hardware

Component	Details
Microcontroller	Teensy 4.1
Audio	Teensy Audio Shield Rev D (SGTL5000 codec)
Storage	microSD card (in Teensy 4.1 built-in slot)
LED switching	RFP30N06LE N-channel MOSFET (one per LED channel)

The MAX98357A used in earlier versions is no longer part of this build.

MOSFET wiring

Each of the 18 LED channels uses a RFP30N06LE N-channel MOSFET to switch a 12V LED supply from 3.3V Teensy logic. The RFP30N06LE is rated 30A / 60V and fully enhances at $V_{gs} \sim 2V$, so the 3.3V output drives it with margin to spare.

Repeat this wiring for each channel:

MOSFET pin	Connection
Gate	Teensy PWM pin
Source	GND (shared with Teensy)
Drain	LED cathode (-)

The LED anode (+) connects to 12V through a current-limiting resistor sized for the LED forward voltage and desired current.

Amplitude tiers

The amplitude-to-tier mapping uses piecewise linear thresholds defined in `THRESHOLDS[]`. Tune those five values to match your audio levels. Uncomment the `Serial.print` lines in `updateLEDs()` to watch the smoothed peak and level values in real time while tuning.

The smoothing constant `PEAK_SMOOTHING` (default 0.80) controls how fast the display reacts. Lower values respond faster but look noisier. Higher values smooth out transients but feel sluggish.

Pin assignments

Teensy Pin	Function
2	front_LED_01 (tier 5)
3	front_LED_02 (tier 4)
4	front_LED_03 (tier 3)
5	front_LED_04 (tier 2)
6	front_LED_05 (tier 1, innermost)

9	front_LED_06 (tier 1, innermost)
10	side_LED_07 (tier 5)
11	side_LED_08 (tier 5)
14	front_LED_10 (tier 5)
15	side_LED_01 (tier 2)
16	front_LED_07 (tier 2)
17	front_LED_08 (tier 3)
22	front_LED_09 (tier 4)
24	Serial6 TX to j4_receiver (receiver GPIO 2)
25	Serial6 RX from j4_receiver (receiver GPIO 17)
28	side_LED_02 (tier 2)
29	side_LED_03 (tier 3)
33	side_LED_04 (tier 3)
36	side_LED_05 (tier 4)
37	side_LED_06 (tier 4)

Audio Shield Rev D occupies 7, 8, 20, 21, 23 (I2S) and 18, 19 (I2C); the SD card uses the Teensy 4.1 built-in slot. All LED pins are chosen to avoid those.

Pin diagram

Standard Teensy 4.1 layout, component side up, USB at the TOP. The two long edges read top-to-bottom; * marks a pin this firmware uses.

```

+===== [ USB ] =====+
      GND  - |  GND          5V  | -  5V
      0    - |  0          GND  | -  GND
      1    - |  1          3.3V | -  3.3V
front_LED_01 (T5) 2 * - | 2          23  | -  (audio I2S)
front_LED_02 (T4) 3 * - | 3          22  | - * front_LED_09 (T4)
front_LED_03 (T3) 4 * - | 4          21  | -  (audio I2S)
front_LED_04 (T2) 5 * - | 5          20  | -  (audio I2S)
front_LED_05 (T1) 6 * - | 6          19  | -  (audio I2C)
(audio)          7  - | 7          18  | -  (audio I2C)
(audio)          8  - | 8          17  | - * front_LED_08 (T3)
front_LED_06 (T1) 9 * - | 9          16  | - * front_LED_07 (T2)
side_LED_07 (T5) 10 * - | 10         15  | - * side_LED_01 (T2)
side_LED_08 (T5) 11 * - | 11         14  | - * front_LED_10 (T5)
              12  - | 12         13  | -  (LED_BUILTIN)
Serial6 TX      24 * - | 24         41  | -
Serial6 RX      25 * - | 25         40  | -
              26  - | 26         39  | -

```

```

                27  -| 27          38  |-
side_LED_02 (T2) 28  *-| 28          37  |-* side_LED_06 (T4)
side_LED_03 (T3) 29  *-| 29          36  |-* side_LED_05 (T4)
                30  -| 30          35  |-
                31  -| 31          34  |-
                32  -| 32          (bottom: SD card + SMD pads)
side_LED_04 (T3) 33  *-| 33          |
                +=====+

```

```

Serial6: 24 (TX) -> j4_receiver GPIO 2 ; 25 (RX) <- j4_receiver GPIO 17
Audio Shield Rev D uses 7, 8, 20, 21, 23 (I2S) + 18, 19 (I2C) + built-in SD.
front_LED_01..10 = front row left to right (pins 2,3,4,5,6,9,16,17,22,14);
front 05/06 light first. side_LED_01..08 = down the side, top to bottom
(pins 15,28,29,33,36,37,10,11).

```

Jukebox serial protocol

The board talks to j4_receiver over Serial6 at 115200 baud:

Direction	Message	Meaning
in	volume,neck	CSV of volume (0-100) and neck value each frame
in	PLAY:<id>	start the track with that two-character ID
in	STOP	stop playback
in	LIST?	re-send the file list
out	PLAYING:<id>	a track started (empty payload = stopped / finished)
out	LIST_START:<n> ... <id> <name> ... LIST_END	the SD-card file list
in	FACES?	dump every saved face preset
in	FACESAVE:<key>,<11 values>,<toggles>	save/overwrite one face and rewrite FACES.TXT
out	FACE:<key>,<11 values>,<toggles> ... FACE_END:<n>	the saved-face dump
out	FACEOK:<key> / FACEERR:<key>	SD write confirmed / failed

Face presets (FACES.TXT)

The controller's right keypad saves and recalls facial expressions ("faces"); this board is their persistent home because it has the only microSD in the system. FACES.TXT in the SD root holds one CSV line per face: <key>,<11 values>,<toggles> -- the keypad character, the 11 face-pot values (iris, color, brightness, eyebrows, nose, eyelids; the controller owns the meaning and order), and a LASER/VENT/EYE POP toggle bitmask. The whole file is rewritten on every save (it is at most 16 short lines). A missing or unreadable FACES.TXT simply means zero saved faces; every malformed line is skipped field-by-field, and boot never hangs on any of it.

WAV files

Place WAV files in the root of the SD card. The firmware scans them at boot and plays a file when it receives a matching PLAY:<id> command. 16-bit PCM, 44100 Hz stereo is the standard format for the Teensy Audio library.

Building and uploading

```
# Build
pio run

# Upload
pio run --target upload

# Monitor serial output
pio device monitor
```

Related projects

- [j4_controller](#) -- the TTGO T-Display transmitter that sends control data
- [j4_receiver](#) -- the ESP32 receiver board on the robot that feeds this board over serial