



## XDS110 Debugger Interface

P10 selects the voltage source for the level shifters When powering CC1350 from the XDS suppl, connect jumper between pins 1 and 2. When powering CC1350 from the external supply, connect jumper between pins 2 and 3.





