Raspberry Pi Learning Resources

Teachers' Guide to Raspberry Pi > Worksheet

Help / Teach / Learn / Make

REMOTE WORKING ON RASPBERRY PIS



So long as your Raspberry Pis are networked, either via WiFi or a network switch, you can operate them remotely from any existing networked computer.

Virtual **N**etwork **C**omputing is a protocol that allows you to control one computer from another computer. The advantage of using VNC is that you gain access to the full desktop of the Raspberry Pi, meaning you can use graphical programs from the connected computer.


• First, you'll need to install a VNC server on the Raspberry Pi. Open the terminal and type the following:

sudo apt-get install tightvncserver


• With the server installed, you need to start it running with the following command:

tightvncserver

• You'll need to create a password at this point:



• When the VNC server starts, it will tell you which desktop you can use. Normally, this will be :1 but it may be a different number:



- Now you can use another computer to control the Raspberry Pi. Depending on the OS of the client machine, there are a variety of apps you can use.
- You might find it useful to have the TightVNC server start every time the Raspberry Pi boots. To do this, you'll need to be root so open a terminal and type the following:

```
sudo su
```

Next, you need to navigate to the directory /etc/init.d/ with the following command:

```
cd /etc/init.d/
```

Create a new file for the boot script:

```
nano vncboot
```

• Then copy and paste the following script into the editor:

```
#! /bin/sh
# /etc/init.d/vncboot
### BEGIN INIT INFO
# Provides: vncboot
# Required-Start: $remote_fs $syslog
# Required-Stop: $remote fs $syslog
# Default-Start: 2 3 4 5
# Default-Stop: 0 1 6
# Short-Description: Start VNC Server at boot time
# Description: Start VNC Server at boot time.
### END INIT INFO
USER=pi
HOME=/home/pi
export USER HOME
case "$1" in
start)
 echo "Starting VNC Server"
  # Insert your preferred settings for a VNC session
 su - $USER -c "/usr/bin/vncserver :1 -geometry 1280x800 -depth 16 -pixelformat rgb565"
 ;;
stop)
  echo "Stopping VNC Server"
```

```
/usr/bin/vncserver -kill :1
;;

*)
  echo "Usage: /etc/init.d/vncboot {start|stop}"
  exit 1
  ;;
  esac

exit 0
```

- To exit nano, type Ctrl+x Press Y to confirm the save and exit.
- Now you need to make the file executable:

```
chmod 755 vncboot
```

Then enable dependency-based boot sequencing:

```
update-rc.d lightdm remove
update-rc.d vncboot defaults
```

• If enabling dependency-based boot sequencing was successful, you will see this:

```
update-rc.d: using dependency based boot sequencing
```

- Now reboot your Raspberry Pi and you should find a VNC server already started.
- To connect to the Raspberry Pi from another computer, you can follow the instructions in one of the links below:

On Windows

On OS X

On Chrome OS

On iOS

 Note - Currently, software such as Minecraft, Picamera (preview) and omxplayer won't work over VNC. RealVNC are working on an experimental server to rectify this.



OPTION 2 - REMOTE WITH SSH

If your students don't need access to a graphical user interface (GUI), then SSH is an easy way of connecting to, and using, Raspberry Pis.

LINUX-BASED OPERATING SYSTEMS

• If your students are using OS X or a Linux-based OS, then SSH is native to the operating system. Simply open a terminal and type:

```
ssh pi@10.10.10.10
```

- Don't forget to use the IP address of the Raspberry Pi.
- Then you can type in the password when prompted, usually raspberry unless you have changed it.

CHROME OS AND CHROME BROWSER

• If your students are using Chrome OS or have access to the Chrome browser, then there's a Chrome app that allows access over SSH. You can find the Secure Shell App in the Chrome Web Store.




• Once installed, click on the app to open it:



Secure Shell

• Now you can access the Raspberry Pi by typing in the IP address:




■ Then type in the password:

```
Namer's to Preparetly Assed Questions: http://goo.gl/TX7876
Namer'
```


PUTTY (ON WINDOWS)

PuTTY is an app that provides SSH access on Windows.

- Download PuTTY from this site.
- Once installed, you can open PuTTY from the Start menu and type in the IP address:



• If it's your first time connecting to this Raspberry Pi, you'll get a warning dialogue box, so click Yes to connect:



Then you need to enter the username and password for the Raspberry Pi (usually pi and raspberry):



This learning resource is provided for free by the Raspberry Pi Foundation under a Creative Commons licence. Find more at raspberrypi.org/resources and github.com/raspberrypilearning.