









UCC EN 27 CL K 26 DOUT 25 24 23 DOT4 22 GND DOT3 21 T4−K9 20 T4−K8 19 T4−K7 18 T4−K6 17 T4−K5 16 T4−K4 15  DOUT EN DRIVER U2  DRIVER U2  NIXIE TUBE DRIVER U2  NIXIE TUBE DRIVER V2  K22  K21  K20  K19  K18  K17  K16  K17  K16  K17	K01 K02 K03 K04 K05 K06 K07 K08 K09 K10 K11 K12 K13 K14	1 T3-K0 2 T3-K1 3 T3-K2 4 T3-K3 5 T3-K4 6 T3-K5 7 T3-K6 8 T3-K7 9 T3-K8 10 T3-K9 11 T4-K0 12 T4-K1 13 T4-K2 14 T4-K3
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------



HOW TO DRIVE	W TO DRIVE NIXIE TUBE DRIVER	
NIXIE TUBES	SERIAL CONNECTION	
WWW.NIXIETESTER.COM	Design: Marcin Saj	
Date: 13 JANUARY 2021	Sheet: 1/1	V4