

Maintenance Items			Month	12	24	36	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216	228	240			
			KM	10000 KM	20000 KM	30000 KM	40000 KM	50000 KM	60000 KM	70000 KM	80000 KM	90000 KM	100k KM	110k KM	120k KM	130k KM	140k KM	150k KM	160k KM	170k KM	180k KM	190k KM	200k KM			
1	Engine																									
	Oil & Filter Change \ تغير زيت + فلتر زيت**			R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R		
	Inspect engine for leakage (coolant, fuel, oil) \ فحص وجود تسريب بالمحرك (مياه تبريد، وقود، زيت)			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	Inspect Engine Idling & operation (with diagnostic tool) \ فحص حالة المحرك على السلاسيه وفحص جهاز تشخيص الأعطال			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	Air Filter \ فلتر الهواء			I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R	I.C.R		
	Fuel Filter Replace \ تغيير فلتر الوقود			Maintenance-free (except for the cause of failure)																						
	Spark plugs \ بوجيهات					R			R			R			R			R			R					
	Canister Replace \ تغيير كانبستر			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
	Inspect Cooling System (Radiator,Hoses.Connction) \ فحص منظومة التبريد (ردياتير، خرطوم، وصلات)			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
	Replace Engine Coolant \ تغيير سائل التبريد			Replace every 2 years or 40,000 km (whichever comes first)																						
Inspect Fuel System (Tank,Pipes,Connections) \ فحص منظومة الوقود (تلك الوقود، خرطوم، وصلات)			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I			
Inspect Exhaust system and heat shields \ فحص منظومة العادم والحرل الحرارى			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
2	Power Train																									
	Electric drive system reducer lubricating oil			Replace reducer oil at first 2 years or 30,000km (whichever comes first). And then replace reducer oil every 3 years or 40,000 km (whichever comes first).																						
	Generator oil			First maintenance every 2 years or 30,000km (whichever comes first) Regular maintenance every 3 years or 40,000km (whichever comes first)																						
	E-drive ASSY connector (loose, damaged)			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	E-drive ASSY grounding bolts and its wiring harness			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	E-drive ASSY cooling system (leakage, damaged, loose water pipe connection)			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	E-drive ASSY reducer housing surface, half-axle oil seal, oil filler plug, oil drain plug, exhaust plug (oil leakage, damaged)			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
E-drive ASSY surface (clean, no attached dirt)			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I			
3	Brake System																									
	Inspect Disc Brakes \ فحص التيل والمكابير			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	Inspect Brake booster, lines, hoses and connections, \فحص خطوطا ومواسير ووصلات الفرامل			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	Brake Fluid \ زيت الفرامل			Replace every 2 year or 40,000 km (whichever comes first)																						
4	Air Condition																									
	A/C Filter\ فلتر التنكيف (if equipped)			Replace every 1 year or 10,000 km (whichever comes first)																						
5	Electric System																									
	Inspect Battery\فحص البطارية			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	Inspect All Lights Operation and sunroof (If equipped) \فحص جميع الاوار وعمل فتحة السقف (في حالة وجود فتحة سقف)			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	High-voltage wiring harness connecting bolts (loose, damaged)			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	High voltage wiring harness connection terminal (damaged)			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	High voltage wiring harness surface (damaged)			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	Is the surface of the battery assembly damaged?			I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A		
	Battery assembly mounting bolts (loose, damaged)			I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A	I.A		
	Insulation resistance			I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R		
	Battery cell pressure difference			I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R	I.A.R		
	Inspect Horn Operation \ فحص عمل الكلاكس			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
Inspect Wiper Blades Operation& Fluid \ فحص ريش المساحات ومستوى سائل المساحات			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I			
6	Chassis																									
	Inspect (CV) universal joint boot damage \ فحص حالة كاوتش الكوبلن			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
	Inspect Tires Condition, Pressure & Adjust \ فحص حالة الاطارات وغطب ضغط الاطارات			Rotate	Rotate	Rotate	R	Rotate	Rotate	Rotate	R	Rotate	Rotate	Rotate	R	Rotate	Rotate	Rotate	R	Rotate	Rotate	Rotate	R	Rotate		
Inspect and tighten Suspension \ فحص وربط منظومة التعليق			I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I		
			I:inspect, R: replace, C: clean, A: Adjustment **Check the engine oil level and leak every 500 km or before starting long trip																							