
Installation of the Bluetooth board in the ATS25 series

Important! The creator of this document assumes no liability for the correctness of the installation and schematics shown. You are responsible for your own actions and if the device is damaged.



PIN 27 ESP

necessary to redesign the connections to the relay itself by checking the component

used.

©Manuel Lausmann My YouTube Channel

Activate the Bluetooth interface in the software 4.16 of the ATS25

In the setting.ini file you have to make the following changes. Remove the two // at BTenable and audioMutePin. Then set the audioMutePin value to 0. Then upload the setting.ini to the ATS25 with the A Explorer.

```
21
22
12
17
                                                                    I2C bus SDA pin on ESP32
 //SDAPin
 //SCLPin
                                                                    I2C bus SCL
                                                                                         pin on ESP32
 //resetPin
                                                                    reset pin ESP32
  //encoderPinA
                                                                    encoder rotate pin A ESP32
                                            16
33
35
36
 //encoderPinB
                                                                    encoder rotate pin B ESP32
 //encoderSwitchPin
                                                                    encoder switch pin ESP32
                                                               // battery voltage divider pin ESP32

// battery charge divider pin ESP32

// beeper pin ESP32

// display led control pin ESP32
 //batteryInfoPin
 //batteryChargePin
 //baccerycharge
//beeperPin
//displayLedPin
                                            13
                                             14
                                                        // display led control pin ESP32
// hardware audio mute pin ESP32
// decoder CW & RTTY pin ESP32
// input audio pin ESP32
// LNA enable pin ESP32
// switching antenna input impedance pin ESP32
// functional button pin ESP32
// bluetooth enable pin ESP32
// bluetooth pair pin ESP32
                                             39
audioMutePin
 //decoderPin
                                            32
26
25
 //audioInputPin
 //LNAenable
 //antHiZ
  /lockSwitch
BTenable |
 //BTpair
                                                               // bluetooth pair pin ESP32
```

Links:

ATS25 Telegramgroup

https://t.me/+BOQmKPgV4IM2NDZi

Facebook Groups:

https://www.facebook.com/groups/1237052770198191

https://www.facebook.com/groups/532613604253401

https://www.facebook.com/groups/sdreverywhere

Harduino:

http://harduino.ru/index.php/en/software/software-h-radio-for-the-receiver-ats25-version-4-1-air

Antonino Russo:

https://github.com/IU4ALH/IU4ALH

©Manuel Lausmann My YouTube Channel