getEKp

Get the Proportional Gain (Kp) in EEP of the Herkulex motor

Contents

- Syntax
- Description
- Input Arguments
- Output Arguments
- Function Codes

Syntax

```
EKp = getEKp(sObject,pID)
```

Description

EKp = getEKp(sObject,pID) gets the Proportional Gain (Kp) in the EEPROM.

■ EEP address for Kp: 0x35(53).

Refer to Herkulex Manual pg28 for EEP map of gains.

Input Arguments

- sObject serial port object
- pID integer

Output Arguments

EKp - integer

Function Codes

```
function EKp = getEKp(sObject, pID)

packet = pkGen(pID,02,'1E02'); % EEP Addr: 0x1E(30), read 2 bytes data

inHkx(sObject,packet);

msg = outHkx(sObject);

EKp = hex2dec(strcat(msg(21:22),msg(19:20))); % Bytes in reverse order by Little
Endian Rule
```

end

Published with MATLAB® R2016a