

Common Hardware Issues and Resolutions

Issue

Symptoms

Causes

Fix

Device Will Not Power On

- . No lights or fan noise
- . Screen remains black
- . Device unresponsive to power button

- . Faulty or unplugged power cable
- . Dead battery or faulty charger
- . Power supply failure

- . Check power cable and outlet
- . Try a known-working charger
- . Remove battery (if possible) and power cycle
- . Escalate for hardware repair if no response

Overheating / Loud Fan

- . Device becomes very hot
- . Fan running constantly or loudly
- . Sudden shutdowns or throttling

- . Dust buildup blocking airflow
- . Poor ventilation
- . High CPU usage or failing fan

- . Clean vents and fans
- . Ensure adequate airflow
- . Close unnecessary applications
- . Escalate if overheating persists

Peripheral Not Detected (Keyboard / Mouse / USB)

- . Device not recognised
- . Intermittent disconnects
- . Error messages when plugged in

- . Faulty USB port or cable
- . The device has low storage space.
- . Driver issues
- . Device hardware failure

- . Try a different port or cable
- . Test device on another machine
- . Update or reinstall drivers
- . Replace device if faulty

Display Issues (No Signal / Flickering / Low Resolution)

- . "No signal" message
- . Screen flickering or distorted
- . Incorrect resolution

- . Loose or faulty display cable
- . Incorrect display settings
- . Failing monitor or GPU

- . Reseat or replace display cable
- . Check display settings
- . Test with another monitor
- . Escalate if hardware fault suspected