

远程控制

📅 2025-08-05 ★ ★ ★ ★ ★ 5分 1 用户已评分

[Github Edit](#)

- 拍照信息上报
- 相机状态上报
- 飞行器状态信息上报
- 摄像头 osd 推送
- 负载控制—切换相机模式
- 强制降落
- 急停
- 紧急降落
- 负载控制—红外联动变焦
- 负载控制—视频分辨率设置

Event

拍照信息上报

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_camera_photo_info_push

Data:

Column	Name	Type	constraint
countdown_time	定时 拍倒 计时	int	
result	拍照 结果	int	

status	状态	enum_string	{"fail":"失败","in_progress":"执行中","ok"
progress	进度	struct	
»current_step	执行步骤	enum_int	{"3000":"全景图拍摄未开始或者已结束","3002":"全景图正在拍摄","3005":"全中"}
»percent	进度值	int	{"max":"100","min":"0","step":"","unit_ná
ext	扩展内容	struct	
»camera_mode	当前相机模式	enum_int	{"3":"全景拍照"}

Example:

```

{
  "data": {
    "countdown_time": 4,
    "ext": {
      "camera_mode": 2
    },
    "progress": {
      "current_step": 0,
      "percent": 100
    },
    "result": 0,
    "status": "in_progress"
  },
  "method": "drc_camera_photo_info_push",
  "seq": 1
}

```

相机状态上报

变化时推送相机信息（seq 是递增的序号，保证指令顺序执行，与 data 同级）

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Data.

Column	Name	Type	constraint
payload_index	相机枚举	text	
camera_state	相机状态信息	struct	
»camera_mode	相机状态	enum_int	{ "0": "拍照", "1": "录像", "2": "智能光", "3": "全景拍照", "4": "定时拍照" }
»interval_photo_interval	定时拍照间隔	int	{ "max": "", "min": "", "step": "", "unit": "s" }
»video_resolution	视频分辨率大小	enum_string	{ "0": "19201080 ", "1": "38402160" }
»linkage_zoom_state	联动变焦状态	bool	{ "0": "关闭", "1": "开启" }
»photo_size	照片大小	enum_int	{ "0": "默认大小", "1": "特小", "2": "小", "3": "中", "4": "大", "5": "超大" }
»record_time	视频录制时长	int	{ "max": "", "min": "", "step": "", "unit": "s" }
»recording_state	录像状态	enum_int	{ "0": "空闲", "1": "录像中" }
»photo_state	拍照状态	enum_int	{ "0": "空闲", "1": "拍照中" }
»remain_photo_num	剩余拍照	int	

»remain_record_duration	剩余录像时间	int	{"max":"","min":"","step":"","unit": "s"}
media_storage	媒体存储信息	struct	
»photo_storage_settings	照片存储设置集合	array	{"size": -, "item_type": text}
»video_storage_settings	视频存储设置集合	array	{"size": -, "item_type": text}

Example:

```

{
  "data": {
    "camera_state": {
      "camera_mode": 0,
      "interval_photo_interval": 2.5,
      "linkage_zoom_state": 0,
      "photo_size": 1,
      "photo_state": 0,
      "record_time": 0,
      "recording_state": 0,
      "remain_photo_num": 6727,
      "remain_record_duration": 0,
      "video_resolution": 0
    },
    "media_storage": {
      "photo_storage_settings": [
        "current",
        "ir"
      ],
      "video_storage_settings": [
        "current",
        "ir"
      ]
    },
    "payload_index": "81-0-0"
  },

```

飞行器状态信息上报

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_drone_state_push

Data:

Column	Name	Type	constraint	Descr
stealth_state	隐蔽模式状态	bool	{"0":"关闭","1":"开启"}	
night_lights_state	夜航灯状态	bool	{"0":"关闭","1":"开启"}	
mode_code	飞行器状态	enum_int	{"0":"待机","1":"起飞准备","2":"起飞准备完毕","3":"手动飞行","4":"自动起飞","5":"航线飞行","6":"全景拍照","7":"智能跟随","8":"ADS-B 躲避","9":"自动返航","10":"自动降落","11":"强制降落","12":"三桨叶降落","13":"升级中","14":"未连接","15":"APAS","16":"虚拟摇杆状态","17":"指令飞行"}	
landing_type	降落类型	enum_int	{"0":"未降落","1":"机场内降落","2":"备降点降落","3":"用户主动触发"}	

触发降落"}
}

Example:

```
{
  "data": {
    "landing_protection_type": 0,
    "landing_type": 1,
    "mode_code": 0,
    "night_lights_state": 0,
    "stealth_state": 0
  },
  "method": "drc_drone_state_push",
  "seq": 1
}
```

摄像头 osd 推送

用于推送摄像头参数信息 (seq 是递增的序号, 保证指令顺序执行, 与 data 同级)

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_camera_osd_info_push

Data:

Column	Name	Type	
payload_index	相机枚 举	text	

wide_lense	广角镜头信息	struct	
»wide_exposure_mode	广角镜头曝光模式	enum_int	{"1":"自动","2":"快门"
»wide_iso	广角镜头感光度	enum_int	{"0":"Auto","1":"Aut
»wide_shutter_speed	广角镜头快门速度	enum_int	{"0":"1/8000 s","1":"s","65534":"Auto"}
»wide_exposure_value	广角镜头曝光值	enum_int	{"1":"-5.0EV","2":"-4
»wide_aperture_value	光圈值	enum_int	{"0":"F_AUTO","50":
zoom_lense	变焦镜头信息	struct	
»zoom_exposure_mode	变焦镜头曝光模式	enum_int	{"1":"自动","2":"快门"
»zoom_iso	变焦镜头感光度	enum_int	{"0":"Auto","1":"Aut
»zoom_shutter_speed	变焦镜头快门速度	enum_int	{"0":"1/8000 s","1":"s","65534":"Auto"}
»zoom_exposure_value	变焦镜头曝光值	enum_int	{"1":"-5.0EV","2":"-4

»zoom_focus_mode	变焦镜头对焦模式	enum_int	{"0":"MF","1":"AFS",
»zoom_focus_value	变焦镜头对焦值	int	
»zoom_max_focus_value	变焦镜头最大对焦值	int	
»zoom_min_focus_value	变焦镜头最小对焦值	int	
»zoom_calibrate_farthest_focus_value	变焦镜头标定的最远对焦值	int	
»zoom_calibrate_nearest_focus_value	变焦镜头标定的最近对焦值	int	
»zoom_focus_state	变焦镜头对焦状态	int	
»zoom_factor	变焦倍数	int	
»zoom_aperture_value	变焦光圈值	enum_int	{"440":"F4.4"}
measure_target	目标测距和测高	struct	
»measure_target_longitude	激光测距目标经度	double	{"max":"180","min":
»measure_target_latitude	激光测距目标纬度	double	{"max":"90","min":

»measure_target_altitude	激光测距目标海拔	double	{"unit": "米 / m"}
»measure_target_distance	激光测距距离	double	{"unit": "米 / m"}
ir_lense	红外信息	struct	
»screen_split_enable	分屏是否使能	bool	{"false": "分屏使能关
»ir_zoom_factor	红外变焦倍数	float	{"max": 20, "min": 2}
»thermal_supported_palette_styles	设备支持的调色盘样式集合	array	{"size": -, "item_typ
»thermal_gain_mode	增益模式	enum_int	{"0": "自动", "1": "低增
»thermal_isotherm_state	是否开启等温线	enum_int	{"0": "关闭", "1": "开启
»thermal_isotherm_upper_limit	测温区间上限	int	{"unit": "摄氏度 / °C
»thermal_isotherm_lower_limit	测温区间下限	int	{"unit": "摄氏度 / °C
»thermal_global_temperature_min	全局画面中测量的最低温度	float	{"unit": "摄氏度 / °C
»thermal_global_temperature_max	全局画面中测量的最高温度	float	{"unit": "摄氏度 / °C

liveview	直播视图区域信息	struct	
»liveview_world_region	视场角 (FOV) 在 liveview 中的区域	struct	
»»left	左上角的 x 轴起始点	float	
»»top	左上角的 y 轴起始点	float	
»»right	右下角的 x 轴起始点	float	
»»bottom	右下角的 y 轴起始点	float	

Example:

```

{
  "data": {
    "ir_lense": {
      "ir_zoom_factor": 2,
      "screen_split_enable": false,
      "thermal_current_palette_style": 11,
      "thermal_gain_mode": 2,
      "thermal_global_temperature_max": 40.0373764038086,
      "thermal_global_temperature_min": 31.65154457092285,
      "thermal_isotherm_lower_limit": -20,
      "thermal_isotherm_state": 0,
      "thermal_isotherm_upper_limit": 150
    },
    "liveview": {
      "liveview_world_region": {
        "bottom": 0.5609484910964966,
        "left": 0.43238765001297,

```

```

    },
    "measure_target": {
      "measure_target_altitude": 34.60000228881836,
      "measure_target_distance": 0,
      "measure_target_error_state": 1,
      "measure_target_latitude": 22.907619920797877,
      "measure_target_longitude": 113.70345426744846
    },
    "payload_index": "81-0-0",
    "wide_lense": {
      "wide_aperture_value": 10,
      "wide_exposure_mode": 1,
      "wide_exposure_value": 16,
      "wide_iso": 8,
      "wide_shutter_speed": 45
    },
    "zoom_lense": {
      "zoom_aperture_value": 10,
      "zoom_calibrate_farthest_focus_value": 34,
      "zoom_calibrate_nearest_focus_value": 64,
      "zoom_exposure_mode": 1,
      "zoom_exposure_value": 16,
      "zoom_factor": 6.999994214380596,
      "zoom_focus_mode": 0,
      "zoom_focus_state": 0,
      "zoom_focus_value": 34,
      "zoom_iso": 8,
      "zoom_max_focus_value": 64,
      "zoom_min_focus_value": 33,
      "zoom_shutter_speed": 45
    }
  },
  "method": "drc_camera_osd_info_push",
  "seq": 1
}

```

Service

负载控制—切换相机模式

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_camera_mode_switch

Column	Name	Type	constraint	Description
payload_index	相机枚举	text	{"length":""}	相机枚举值。非标准的 device_mode_key, 格式为 {type-subtype-gimbalindex}, 可以参考 产品支持
camera_mode	模式	enum_int	{"0":"拍照","1":"录像","2":"智能低光","3":"全景拍照","4":"定时拍"}	

Example:

```
{
  "data": {
    "camera_mode": 2,
    "payload_index": "81-0-0"
  },
  "method": "drc_camera_mode_switch",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/services_reply

Direction: up

Method: drc_camera_mode_switch

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```
{
  "data": {
    "result": 0
  }
}
```

}

强制降落

调用后，无论是否有障碍飞行器都会直接降到地面，用 `drone_emergency_stop` 命令可取消。降落完成后只能人工拾取飞行器，慎用！（seq 是递增的序号，保证指令顺序执行，与 data 同级）

Topic: `thing/product/{gateway_sn}/drc/down`

Direction: down

Method: `drc_force_landing`

Data: null

Example:

```
{
  "data": {},
  "method": "drc_force_landing",
  "seq": 1
}
```

Topic: `thing/product/{gateway_sn}/drc/up`

Direction: up

Method: `drc_force_landing`

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```
{
  "data": {
    "result": 0
  },
}
```

急停

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drone_emergency_stop

Data: null

Example:

```
{
  "data": {},
  "method": "drone_emergency_stop",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drone_emergency_stop

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```
{
  "data": {
    "result": 0
  },
  "method": "drone_emergency_stop",
  "seq": 1
}
```

紧急降落

调用后，飞行器会开始降落，在开启避障时可能会因触发避障而中止。

用 `drone_emergency_stop` 命令可取消。降落完成后只能人工拾取飞行器，慎用！（seq 是递增的序号，保证指令顺序执行，与 data 同级）

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_emergency_landing

Data: null

Example:

```
{
  "data": {},
  "method": "drc_emergency_landing",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_emergency_landing

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```
{
  "data": {
    "result": 0
  },
  "method": "drc_emergency_landing",
}
```

负载控制—红外联动变焦

红外联动变焦仅支持 Matrice 3TD 机型（seq 是递增的序号，保证指令顺序执行，与 data 同级）

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_linkage_zoom_set

Data:

Column	Name	Type	constraint	Description
payload_index	相机枚举	text		相机枚举值。非标准的 device_mode_key，格式为 {type-subtype-gimbalindex}，可以参考产品支持
state	联动变焦状态	bool	{"0":"关闭","1":"开启"}	

Example:

```
{
  "data": {
    "payload_index": "81-0-0",
    "state": 0
  },
  "method": "drc_linkage_zoom_set",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_linkage_zoom_set

Data:

result	返回码	int	非 0 代表错误
--------	-----	-----	----------

Example:

```

{
  "data": {
    "result": 0
  },
  "method": "drc_linkage_zoom_set",
  "seq": 1
}

```

负载控制—视频分辨率设置

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_video_resolution_set

Data:

Column	Name	Type	constraint	
payload_index	相机枚举	text		相机分辨率设置
video_resolution	视频分辨率	enum_string	{"0":"19201080","1":"38402160"}	可分3840x2160

Example:

```
        "payload_index": "81-0-0",
        "video_resolution": 0
    },
    "method": "drc_video_resolution_set",
    "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_video_resolution_set

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```
{
  "data": {
    "result": 0
  },
  "method": "drc_video_resolution_set",
  "seq": 1
}
```

负载控制—视频存储设置

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_video_storage_set

Data:

payload_index	相机枚举	text		相机枚举值。非标准的 device_mode_key, 格式为 {type-subtype-gimbalindex}, 可以参考产品支持
video_storage_settings	视频存储	array	{ "size": -, "item_type": text }	视频存储类型 {current, vision, ir}, 根据机型可多选

Example:

```

{
  "data": {
    "payload_index": "81-0-0",
    "video_storage_settings": [
      "current",
      "ir",
      "vision"
    ]
  },
  "method": "drc_video_storage_set",
  "seq": 1
}

```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_video_storage_set

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```

{
  "data": {
    "result": 0
  }
}

```

}

负载控制—照片存储设置

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_photo_storage_set

Data:

Column	Name	Type	constraint	Description
payload_index	相机枚举	text		相机枚举值。非标准的 device_mode_key, 格式为 {type-subtype-gimbalindex}, 可以参考产品支持 🔗
photo_storage_settings	照片存储设置	array	{"size": -, "item_type": text}	拍照存储类型 {current, vision, ir}, 根据机型可多选

Example:

```
{
  "data": {
    "payload_index": "81-0-0",
    "photo_storage_settings": [
      "current",
      "ir",
      "vision"
    ]
  },
  "method": "drc_photo_storage_set",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Method: drc_photo_storage_set

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```

{
  "data": {
    "result": 0
  },
  "method": "drc_photo_storage_set",
  "seq": 1
}

```

负载控制—设置定时拍

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_interval_photo_set

Data:

Column	Name	Type	
payload_index	相机枚举	text	
interval	定时拍照间隔	enum_string	{"1":"1s","2":"2s","3":"3s","5":"5s","7":"7s","

Example:

```
{
  "data": {
    "interval": 1,
    "payload_index": "80-0-0"
  },
  "method": "drc_interval_photo_set",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_interval_photo_set

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```
{
  "data": {
    "result": 0
  },
  "method": "drc_interval_photo_set",
  "seq": 1
}
```

DRC初始状态订阅

seq 是递增的序号，保证指令顺序执行，与 data 同级

Direction: down

Method: drc_initial_state_subscribe

Data: null

Example:

```
{
  "data": {},
  "method": "drc_initial_state_subscribe",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_initial_state_subscribe

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```
{
  "data": {
    "result": 0
  },
  "method": "drc_initial_state_subscribe",
  "seq": 1
}
```

夜航灯设置

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/down

Method: drc_night_lights_state_set

Data:

Column	Name	Type	constraint	Description
night_lights_state	状态	enum_int	{"0":"关闭","1":"开启"}	

Example:

```

{
  "data": {
    "night_lights_state": 0
  },
  "method": "drc_night_lights_state_set",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_night_lights_state_set

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```

{
  "data": {
    "result": 0
  },
  "method": "drc_night_lights_state_set",
  "seq": 1
}
```


Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_stealth_state_set

Data:

Column	Name	Type	constraint	Description
stealth_state	隐蔽模式	enum_int	{"0":"关闭","1":"开启"}	隐蔽模式状态

Example:

```
{
  "data": {
    "stealth_state": 0
  },
  "method": "drc_stealth_state_set",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_stealth_state_set

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```
{
  "data": {
    "result": 0
  },
  "method": "drc_stealth_state_set",
}
```

负载控制—相机光圈

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_camera_aperture_value_set

Data:

Column	Name	Type	
payload_index	相机枚举	text	
camera_type	相机类型	enum_string	{"wide": "广角", "zoom": "变焦"}
aperture_value	光圈值	enum_int	{"0": "F_AUTO", "50": "F0_5", "70": "F0_7", "80": "F0_8"}

Example:

```
{
  "data": {
    "aperture_value": 5,
    "camera_type": "zoom",
    "payload_index": "39-0-7"
  },
  "method": "drc_camera_aperture_value_set",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```

{
  "data": {
    "result": 0
  },
  "method": "drc_camera_aperture_value_set",
  "seq": 1
}
```

负载控制—相机快门

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_camera_shutter_set

Data:

Column	Name	Type	constraint	Description
payload_index	相机枚举	text		相机枚举值。非标准的 device_mode_key, 格式为 {type-subtype-gimbalindex}, 可以参考产品支持 🔗
camera_type	相机类型	enum_string	{"wide": "广角", "zoom": "变焦"}	相机类型枚举

shutter_value	快门设置	enum_int	{"0": "1/8000", "1": "1/6400", "2": "1/6000", "3": "1/5000", "4": "1/4000", "5": "1/3200", "6": "1/3000", "7": "1/2500", "8": "1/2000", "9": "1/1600", "10": "1/1500", "11": "1/1250", "12": "1/1000", "13": "1/800", "14": "1/725", "15": "1/640", "16": "1/500", "17": "1/400", "18": "1/350", "19": "1/320", "20": "1/250", "21": "1/240", "22": "1/200", "23": "1/180", "24": "1/160", "25": "1/125", "26": "1/120", "27": "1/100", "28": "1/90", "29": "1/80", "30": "1/60", "31": "1/50", "32": "1/40", "33": "1/30", "34": "1/25", "35": "1/20", "36": "1/15", "37": "1/12.5", "38": "1/10", "39": "1/8", "40": "1/6.25", "41": "1/5", "42": "1/4", "43": "1/3", "44": "1/2.5", "45": "1/2", "46": "1/1.67"}	根据不同机型范围不一样
---------------	------	----------	---	-------------

			s", "48": "1.0" s", "49": "1.3" s", "50": "1.6" s", "51": "2.0" s", "52": "2.5" s", "53": "3.0" s", "54": "3.2" s", "55": "4.0" s", "56": "5.0" s", "57": "6.0" s", "58": "7.0" s", "59": "8.0" s", "60": "Auto"}	
--	--	--	---	--

Example:

```

{
  "data": {
    "shutter_value": 5,
    "camera_type": "zoom",
    "payload_index": "39-0-7"
  },
  "method": "drc_camera_shutter_set",
  "seq": 1
}

```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_camera_shutter_set

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```

{
  "data": {
    "result": 0
  }
}

```

```
}

```

负载控制—ISO设置

seq 是递增的序号，保证指令顺序执行，与 data 同级

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_camera_iso_set

Data:

Column	Name	Type	
payload_index	相机枚举	text	
camera_type	相机类型	enum_string	{"wide": "广角", "zoom": "变焦"}
iso_value	ISO值	enum_int	{"0": "ISO_AUTO", "2": "ISO_50", "3": "ISO_100"}

Example:

```

{
  "data": {
    "camera_type": "zoom",
    "iso_value": 5,
    "payload_index": "39-0-7"
  },
  "method": "drc_camera_iso_set",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Method: drc_camera_iso_set

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```
{
  "data": {
    "result": 0
  },
  "method": "drc_camera_iso_set",
  "seq": 1
}
```

负载控制—机械快门

支持用户手动关闭机械快门，提高设备作业寿命，Matrice 3D 广角模式下机械快门开关（seq 是递增的序号，保证指令顺序执行，与 data 同级）

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_camera_mechanical_shutter_set

Data:

Column	Name	Type	constraint	Description
payload_index	相机枚举	text		相机枚举值。非标准的 device_mode_k 格式为 {type-subtype-gimbalindex}, 参考产品支持
camera_type	相机类型	enum_string	{"wide": "广角"}	相机类型枚举

mechanical_shutter_state	是否使能机械快门	enum_int	{"0":"关闭","1":"开启"}	开启还是关闭机械快门
--------------------------	----------	----------	---------------------	------------

Example:

```

{
  "data": {
    "camera_type": "wide",
    "mechanical_shutter_state": 1,
    "payload_index": "39-0-7"
  },
  "method": "drc_camera_mechanical_shutter_set",
  "seq": 1
}

```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_camera_mechanical_shutter_set

Data:

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```

{
  "data": {
    "result": 0
  },
  "method": "drc_camera_mechanical_shutter_set",
  "seq": 1
}

```

负载控制—镜头去畸变

Topic: thing/product/{gateway_sn}/drc/down

Direction: down

Method: drc_camera_dewarping_set

Data:

Column	Name	Type	constraint	Description
payload_index	相机枚举	text		相机枚举值。非标准的 device_mode_key, 格式为 {type-subtype-gimbalindex}, 可以参考产品支持
camera_type	相机类型	enum_string	{"wide": "广角"}	相机类型枚举
dewarping_state	是否使能去畸变	enum_int	{"0": "关闭", "1": "开启"}	开启还是关闭畸变

Example:

```
{
  "data": {
    "camera_type": "wide",
    "dewarping_state": 1,
    "payload_index": "39-0-7"
  },
  "method": "drc_camera_dewarping_set",
  "seq": 1
}
```

Topic: thing/product/{gateway_sn}/drc/up

Direction: up

Method: drc_camera_dewarping_set

Column	Name	Type	constraint	Description
result	返回码	int		非 0 代表错误

Example:

```
{
  "data": {
    "result": 0
  },
  "method": "drc_camera_dewarping_set",
  "seq": 1
}
```

远程解禁

请问您的文档阅读体验如何？