

Description of real-time message with trajectory

1. XML format:

```
<?xml version="1.0" ?>
  <Metrics Devicename="DeviceName" DeviceId="DeviceID" Sitename="StoreName"
  SiteId="StoreID">
    <!--          DeviceName                DeviceID                StoreName
  StoreID -->
    <Properties>
      <MacAddress>26:17:e9:b0:a8:fe</MacAddress>
      <!-- Device MAC Address -->
      <IpAddress>192.168.1.16</IpAddress>
      <!-- Device IP Address -->
      <HttpPort>80</HttpPort>
      <!-- Device Web Server Port -->
      <HttpsPort>443</HttpsPort>
      <!-- HTTPS Port (No Practical Action) -->
      <HostName>Ritz-dev</HostName>
      <!-- Host Name -->
      <HwPlatform>2000</HwPlatform>
      <!-- Device Model -->
      <TimeZone>8</TimeZone>
      <!-- Device Time Zone (-12 to 12, Interval 0.5) -->
      <DST>0</DST>
      <!-- Daylight saving time (0: no, 1: yes) -->
      <DeviceType>0</DeviceType>
      <!-- Device Type (no practical effect)-->
      <SerialNumber>202018000032</SerialNumber>
      <!-- Devise Serial Number -->
      <ImageWidth>320</ImageWidth>
      <!-- ImageWidth -->
      <ImageHeight>240</ImageHeight>
      <!-- ImageHeight -->
    </Properties>
    <ReportData>
      <RealTimeReport Date="2018-04-25" Time="16:13:51">
        <!--          RealTimeReport Date                RealTimeReport Time-->
        <Object ObjectType="1" Name="Zone-PS1" Id="0">
          <!--      Zone Type *   Zone Name      ID -->
          <RealTimeCount Enters="1" Exits="0" />
          <!--          Enters      Exits      -->
        </Object>
        <Object ObjectType="5" Name="Zone-PS1" Id="8">
```

```

<!-- Zone Type * Zone Name ID -->
    <RealTimeService NumberServed="0" Threshold="1" />
    <!-- Served Number Trigger Number -->
</Object>
<Object ObjectType="6" Name="Zone-PS1" Id="8">
    <!-- Zone Type * Zone Name ID --> -->
    <Track Id="1" Height="175">
        <!-- Track Id Height (cm) -->
        <Position X="120" Y="150" />
        <!-- Position X # Position Y#-->
        <Position X="122" Y="150" />
        <Position X="124" Y="150" />
        <Position X="124" Y="154" />
        <Position X="124" Y="158" />
        <Position X="124" Y="155" />
        <Position X="122" Y="154" />
        <Position X="120" Y="150" />
        <Position X="120" Y="150" />
        <Position X="117" Y="152" />
        <Position X="121" Y="159" />
    </Track>
    <Track Id="2" Height="164">
        <Position X="200" Y="100" />
        <Position X="210" Y="110" />
        <Position X="220" Y="100" />
        <Position X="230" Y="100" />
        <Position X="225" Y="100" />
        <Position X="222" Y="105" />
        <Position X="220" Y="112" />
        <Position X="222" Y="105" />
        <Position X="220" Y="100" />
    </Track>
</Object>
</RealTimeReport>
</ReportData>
</Metrics>

```

<!-- * Object Type 0: Counting In&Out, 1: Real Time In&Out, 4: Served, 5: Real Time Served 6: Served Zone Trajectory -->

<!-- # The origin of coordinates is at the top left corner in the image, it need to reference ImageWidth and ImageHeight for value range-->

2. How to enable the function:

It is need to activate secondary report, fill in the correct IP address and port, and fill in the path if necessary.

Secondary Report Server Address		☒ Activate
Secondary Report Server Port		
Secondary Report Server Directory		
Upload Setting Clear Report		

On the Customer Stay Statistics page, select Zone and click the "Modify" button to draw the Retention Zone:

management of stay area									
Num	Zone Name	Zone ID	Zone Occupied Time (s)	Total Serving Number	Average Serving Time (s)	Active State	Operation	Reset	
1	Zone-PS1	8	0	0	0		Modify	Reset	

Click the "Modify"

Activate the area and save it;

Click on "Advanced Settings"

Maximum Counting Height	200	☒ Activate
Minimum Counting Height	120	
RealTime Report Sampling Interval (s)	1	☒ Activate
RealTime Report Type	RealTime Number Service ☒ RealTime Tracklet Service ☐	
RealTime Report Trigger Threshold	1	
Save Return		

Activate the realtime report and select "Real Time Tracklet Service". Click "Save"

The real-time message function with trajectory is successfully turned on.

Attention: It's necessary to activate one option at least in RealTime Report Type.

Real-time report trigger threshold is only used for real-time number service.