USB <-> RS232 SJ2 FIBER RX TO RS232 SJ6, SJ7 SJ3 FIBER RX TO USB SJ4 RS232 RX TO FIBER SJ5 USB RX TO FIBER USB <-> RS485 SJ10, SJ11, SJ15 SJ6 USB RX TO RS232 SJ7 RS232 RX TO USB USB <-> FIBER SJ8 RS485 RX TO FIBER SJ3, SJ5 SJ9 FIBER RX TO RS485 SJ10 RS485 RX TO USB RS232 <-> RS485 SJ11 USB RX TO RS485 SJ12, SJ13, SJ14 SJ12 RS232 RX TO RS485 SJ13 RS485 RX TO RS232 RS232 <-> FIBER SJ14 CARRIER SENSE TO RX485 TXEN SJ2, SJ4 SJ15 USB TXEN TO RS485 TXEN

FIBER <-> RS485 SJ8, SJ9, SJ14 SJ17 FTDI POWER SELECT (UP=BUS, DOWN=SELF)

