Kinoshi-Tiny Key 25 MIDI Implementation Chart

Model: Kinoshi-Tiny Key 25 / Version 1.1.0 (Oct. 29 2026)

For details, see MIDI_Implementation.md.

Function		Transmitted	Recognized	Remarks
Basic Channel	Default	1	1	*1, *2
	Changed	1-16	X	
Mode	Default	Mode 3	X	
	Messages	X	X	
	Altered	**********		
Note Number		0-127	X	*3
	True Voice	**********	X	
Velocity	Note On	O 9n v=1-127	X	*4
	Note Off	X 8n v=0	X	
After Touch	Key's	X	X	
	Ch's	X	X	
Pitch Bend		O	X	*5
Control Change	0-127	O	X	Mod / Pitch+ / Pitch- / Sustain buttons *6
	1	O	X	Modulation (Mod button default)
	64	O	X	Hold 1 (Sustain button default)
	6	O	O	Data Entry MSB *2
	98, 99	O	O	NRPN LSB, MSB *2
	100, 101	O	O	RPN LSB, MSB (Null only) *2
Program Change		X	X	
	True #	**********		
System Exclusive		X	X	
System Common	Song Pos	X	X	

Function		Transmitted	Recognized	Remarks
	Song Sel	X	X	
	Tune	X	X	
System Real Time	Clock	X	X	
	Commands	X	X	
Aux Messages	All Sound Off	X	X	
	Reset All Controllers	O	X	*7
	Local On/Off	X	X	
	All Notes Off	O	X	*7
	Active Sensing	X	X	
	System Reset	X	X	

Notes

- ***1**: Channel messages are transmitted on both USB MIDI and TRS MIDI. Each has its own channel (default 1, changeable to 1-16 with the settings editor).
- ***2**: Setting data (NRPN) only. It is transmitted and recognized on USB MIDI, channel 1 only, regardless of the channel settings. TRS MIDI has no receive function. Performance messages are not recognized.
- ***3**: Note number = (Octave + 1) * 12 + Key. Octave is -1 to 9 (4 at power on), so the keyboard transmits 60-84 at power on. Keys above 127 transmit nothing.
- ***4**: Velocity is fixed to the setting value (1-127, default 100).
- ***5**: Pitch+ / Pitch- buttons with Function = Pitch Bend. The value moves from center to the end in about 250 ms and returns to center on release.
- ***6**: CC number, On value, Off value and mode (Momentary / Toggle) can be set for each button. Pitch+ / Pitch- buttons transmit CC when Function = CC.
- ***7**: Transmitted on USB MIDI and TRS MIDI when the device receives TRANSFER START from the settings editor.

Mode 1: OMNI ON, POLY	Mode 2: OMNI ON, MONO
Mode 3: OMNI OFF, POLY	Mode 4: OMNI OFF, MONO

O: Yes, X: No