1) , (
J>Jk:
() J p 2 x 1 x p+ =2
2
1) , (

1.1.3 Where the compartment or groups of compartments considered extends over the entire subdivision length (Ls):

p(x1, x2) = 1

1.2 The factor r(x1, x2, b) shall be determined by the following formulae:

=) , (1) 1 (1) , , (2 x 1 x pGCb 2 x 1 x r

where:

() 4 45 12+ = bb J J C , where

---CHUNK---

SOURCE: MSC.194(80).pdf
RESOLUTION MSC.194(80)
(adopted on 20 May 2005)
AMENDMENTS TO THE INTERNATIONAL CONVENTION FOR THE SAFETY OF LIFE AT SEA, 1974, AS AMENDED-
21 -

where:

() 4 45 12+ = bb J J C , where

BbJb = 15

1.2.1 Where the compartment or groups of compartments considered extends over the entire subdivision length (Ls):

bb J b J b G G12
2
111
2
1 + = =

1.2.2 Where neither limits of the comp artment or group of compartments under consideration coincides with the aft or forward terminals:

() 0 12
2
0 1211
3

0 112
2
1
3
1 JJ b J b J b J b G G+ + = = , where
() bJ J J, min0 =

1.2.3 Where the aft limit of the compar tment or group of compartments under consideration coincides with the aft terminal or the forward limit of the compartment or group of compartments under consideration coincides with the forward terminal:

() J G G G + =1 2
2
1

Regulation 7-2
Calculation of the factor si

1 The factor si shall be determined for each case of assumed flooding, involving a compartment or group of compartments, in accordance with the following notations and the provisions in this regulation:

---CHUNK---

SOURCE: MSC.194(80).pdf
Calculation of the factor si

1 The factor si shall be determined for each case of assumed flooding, involving a compartment or group of compartments, in accordance with the following notations and the provisions in this regulation:

e is the equilibrium heel angle in any stage of flooding, in degrees;

v is the angle, in any stage of fl ooding, where the righting lever becomes negative, or the angle at which an opening incapable of being closed weathertight becomes submerged;

GZmax is the maximum positive righting lever, in metres, up to the angle v;

Range is the range of positive righting levers, in degrees, measured from the angle e. The positive range is to be taken up to the angle v;

Flooding stage is any discrete step during the flooding process, including the stage before equalization (if any) until final equilibrium has been reached.

1.1 The factor si, for any damage case at any initial loading condition, di, shall be obtained from the formula:

si = minimum { sintermediate,i or sfinal,i smom,i }
RESOLUTION MSC.194(80)
(adopted on 20 May 2005)

---CHUNK---

SOURCE: MSC.194(80).pdf
1.1 The factor si, for any damage case at any initial loading condition, di, shall be obtained from the formula:

si = minimum { sintermediate,i or sfinal,i smom,i }
RESOLUTION MSC.194(80)
(adopted on 20 May 2005)
AMENDMENTS TO THE INTERNATIONAL CONVENTION FOR THE SAFETY OF LIFE AT SEA, 1974, AS AMENDED-
22 -

where:

sintermediate,i is the probability to survive all intermediate flooding stages until the final equilibrium stage, and is calculated in accordance with paragraph 2;

sfinal,i is the probability to survive in the fina l equilibrium stage of flooding. It is calculated in accordance with paragraph 3;

smom,i is the probability to survive heel ing moments, and is calculated in accordance with paragraph 4.

2 The factor sintermediate,i is applicable only to passenger ships (for cargo ships sintermediate,i should be taken as unity) and shall be taken as the least of the s-factors obtained from all flooding stages including the stage before equalization, if any, and is to be calculated as follows:

sintermediate,i =
4
1
max
7 05 . 0

RangeGZ

where GZmax is not to be taken as more than 0.05 m and Range as not more than 7°.

---CHUNK---

SOURCE: MSC.194(80).pdf
be calculated as follows:

sintermediate,i =
4
1
max
7 05 . 0

RangeGZ

where GZmax is not to be taken as more than 0.05 m and Range as not more than 7°.
sintermediate = 0, if the intermediate heel angle exceeds 15. Where cross-flooding fittings

are required, the time for equalization shall not exceed 10 min.

3 The factor sfinal,i shall be obtained from the formula:

sfinal,i =
4
1
max
16 12 . 0

RangeGZK

where:

GZmax is not to be taken as more than 0.12 m;

Range is not to be taken as more than 16°;

K = 1 if e min

K = 0 if e max

K =
minmax
max