Aeroccino

Price

Aeroccino 3 Milk Frother = 99.00
Aeroccino 4 Milk Frother = 149.00
Aeroccino XL Milk Frother = 149.00

Specifications

Aeroccino 3 Milk Frother

- Capacity = 120 ml
- Dimensions = Diameter 9 cm x height 17cm
- Warranty = 1 year
- Milk Recipes = 3 recipes: Hot froth, cold foam, and steamed milk
- Weight = 450 g
- Automatic Power Off = To save energy

Aeroccino 4 Milk Frother

- Capacity = 120 ml for frothed milk & 240 ml for hot milk
- Dimensions = Diameter 10 cm x Height 17 cm
- Warranty = 1 year
- Automatic Power Off = To save energy
- Milk Recipes = 4 recipes: 2 types of hot froth, hot milk, cold foam
- Weight = 1.03 kg
- Dishwasher Safe = Max 70 degrees Celsius

Aeroccino XL Milk Frother

- Capacity = 225 ml for hot froth and cold foam. 400 ml of steamed milk.
- Dimensions = Diameter 11.8 cm x Height 20.4 cm
- Warranty = 1 year
- Automatic Power Off = To save energy
- Milk Recipes: 3 recipes: Hot froth, cold foam, and steamed milk
- Weight = 0.85 kg
- Dishwasher Safe = Max 70 degrees Celsius

Premise

Milk Guidelines (For All Frothers)

- **Fresh & Cold:** Milk should be as fresh and cold as possible (milk close to expiring will not froth well)
- **High Protein:** Protein content should be high as protein allows milk to froth. Shake the carton before attempting to froth to evenly distribute the proteins.

- **Stiff or Silky Foam?:** Low fat milk creates dry, stiff foam and high fat milk creates wet silky foam. Your choice.
- **Milk Alternatives:** Cow's milk works best - conventional or organic. Alternative milks can be tried, but there is no guarantee that they will froth like cow's milk.

Aeroccino 3 Milk Frother

- Best for those who want the simplest Frother.
- Makes hot froth and cold foam with a single button.
- Not dishwasher safe.
- Milk Frother capacity of 120 ml.
- Steamed milk capacity of 230 ml.
- Diameter of 9cm and height of 17cm.

Use Case
- Perfect for: The one who wants the simplest frother.
- Preparations: Makes hot froth and cold foam.
- Care: Clean by hand.

Features
- A single button to make 3 different milk preparations.
- For hot drinks, make light and silky foam, or remove the whisk for steamed milk.
- Compact and retro design.
- Make cold foam by keeping the button pressed until it turns blue.

Description
For those who love simplicity.
- The Aeroccino 3 milk frother offers a quick and simple way of preparing perfect milk froth with a light and airy consistency for hot and cold specialities. And it's not just for coffee — use the Aeroccino 3 for other beverages such as matcha and hot chocolate.
- Create light, creamy hot milk in approx. 70 - 80 seconds by pressing the button once.
- For cold milk froth, perfect for an iced recipe, press the button for 2 seconds until it lights up blue. Your cold frothed milk will be ready in approximately 60 seconds.

Aeroccino 4 Milk Frother

- Best for those who like some variety in their coffee & milk recipes.
- 4 separate buttons for 2 types of hot foam, hot milk and cold foam.
- Dishwasher safe.
- Milk froth capacity of 120 ml.
- Steamed milk capacity of 240 ml.
- Diameter of 10 cm and height of 17 cm.

Use Case
- Perfect For: A variety of milk recipes
- Preparations: Makes 2 types of hot froth, milk, and cold foam
- Care: Dishwasher safe

Milk Preparations
- Warm & Airy Froth
- Warm & Dense Froth
- Hot Milk
- Cold Foam

Description
- For those who love variety
- Just pour the milk and select the desired button to obtain a divine milk froth for your favorite coffee & milk recipes.
- And it's not just for coffee - use the Aeroccino for other Frother beverages like matcha and hot chocolate.

Aeroccino XL Frother

- Best for households that consume multiple coffees per day.
- Makes hot froth, cold foam, and steamed milk with a single button.
- Dishwasher safe.
- Milk froth/Cold foam capacity of 225 ml.
- Diameter of 11.8 cm and Height of 20.4 cm.

Use Case
- Perfect for: The one who loves generous amount of milk froth.
- Preparations: Makes hot froth and cold foam.
- Care: Dishwasher safe

Features
- A simple Frother for a coffee-loving household
- A little more frothed goes a long way with the Nespresso Aeroccino XL. Whether for a large, creamy Macchiato or for three indulgent Cappuccinos, this milk Frother does it all for you in a single preparation.
- Hot foam, cold foam, or generous measures of steamed milk… All the coffee recipes you can imagine are simply a touch away.
- And once you're done, just pop it in the dishwasher to clean it up. Because sometimes, we all feel like indulging in extra.

Cleaning

Aeroccino 3 Milk Frother

Please ensure that the Aeroccino 3 is cleaned immediately after each use. You have to clean the appliance by hand : remove the base container and clean the inner container, seal, lid, whisk and mixer with detergent and rinse with warm/hot water. Do not use abrasive materials that could damage its surface and do not submerge it completely in water. Make sure the underside of the milk frother is dry before placing it back on its base.

Aeroccino 4 Milk Frother & Aeroccino XL Milk Frother

Please ensure that the Aeroccino 4/Aeroccino XL is cleaned immediately after each use. If using the dishwasher, place all components except the base in the dishwasher at a maximum of 70°C, making sure not to place the container directly on the rack as this may cause damage to the inner layer of the container.

If you choose to clean the appliance by hand, remove the base container and clean the inner container, seal, lid, whisk and mixer with detergent and rinse with warm/hot water. Do not use abrasive materials that could damage its surface and do not submerge it completely in water. Make sure the underside of the milk frother is dry before placing it back on its base.

Helpful Links

Name of Link	URL
Aeroccino 3 Manual	https://www.nespresso.com/ecom/medias/sys_master/public/28752601350174/UM-AEROCCINO-3-Z1-JAB-WEB-2022-02-21.pdf
Aeroccino 4 Manual	https://www.nespresso.com/shared_res/manuals/aeroccino/UM_AEROCCINO%204_REFRESH_Z3_WEB_2022_03_09.pdf
Aeroccino XL Manual	https://www.nespresso.com/ecom/medias/sys_master/public/29014150578206/UM-AEROCCINO-XL-Z1-WEB-2021-12-16.pdf
Machine Assistance Aeroccino 3	https://www.nespresso.com/ca/en/machine-assistance#!/Aeroccino-3/troubleshooting
Machine Assistance Aeroccino 4	https://www.nespresso.com/ca/en/machine-assistance#!/Aeroccino-4/troubleshooting
Aeroccino 3 Presentation Video	https://youtu.be/mR1rtyGsbGA?feature=shared
Aeroccino 3 Care & Cleaning Video	https://youtu.be/sk1ro_zQLIE?feature=shared
Aeroccino 4 YouTube Playlist	https://youtube.com/playlist?list=PLQ2eIUsAVWUwKAWSU7USf3PQsgNe7yZ0u&feature=shared
Aeroccino XL Presentation Video	https://youtu.be/59K9SmY41vc?feature=shared

FAQS

- The main differences between Aeroccino 3 & Aeroccino 4 are as follows:
  - Aeroccino 4 has an additional texture for hot milk foam that is ideal for cappuccino recipes.
  - Aeroccino 4 can be cleaned using the dishwasher.
  - The Aeroccino 3 only has one button to prepare all recipes.
  - The Aeroccino 4 has a handle for easier handling of the device.
  - Only one whisk for Aeroccino 4 is needed to prepare all recipes.

- The main differences between Aeroccino 4 & Aeroccino XL are as follows:
  - The Aeroccino 4 has an additional options for milk foam, ideal for cappuccino recipes, whereas to prepare hot foam with the Aeroccino XL, the whisk must be removed.
  - The Aeroccino XL has a single button for all recipes.
  - The Aeroccino 4 is equipped with a handle for easy handling.
  - The Aeroccino XL has a capacity of 225 ml for milk foam and 400 ml for hot milk.

Aeroccino 3 Milk Frother

- The Aeroccino 3 milk frother has two max lines inside the container, indicating the maximum amount of milk you should pour for different types of froth:
  - Lower Max Line: This line is for frothing hot milk. When making a cappuccino or a similar beverage that requires more froth, fill the milk up to this line. The lower max line ensure there's enough space for the milk to expand as it froths.
  - Upper Max Line: This line is for heating up milk without creating much forth, typically used for latte or hot chocolate. Fill the milk up to this line when you want to heat the milk with minimal frothing.
- The Aeroccino 3 milk frother is designed to turn off automatically once it has completed frothing or heating the milk. This automatic shut-off feature ensures that the milk doesn't overheat or overflow and provides a consistent result every time. When the Aeroccino 3 finishes its cycle, the button light will turn off, indicating that the process is complete and it's safe to remove the lid and pour the milk.
- It is not recommended to put sugar directly into the Aeroccino 3 milk frother. The Aeroccino 3 is designed specifically for frothing and heating milk, and adding sugar or other ingredients may interfere with its performance, cause damage to the non-stick coating, or make it difficult to clean. Instead, you can add sugar or sweeteners to your coffee or beverage separately after frothing the milk using the Aeroccino 3. This way, you can ensure the proper functioning and longevity of your milk frother while still enjoying a sweetened drink.
- The preparation of hot milk or cold milk foam takes about 80 sec. In the case of hot milk, the preparation time is approximately 150 sec. These values can be influenced by different factors, such as the nominal power that can fluctuate throughout the day, the number of consecutive preparations or the cleaning level of the container.
- To prepare hot milk without foam, remove the whisk, fill the container to the level indicated by "max milk" and press the button.
- Fill the container with milk up to the "max Foam" indicator to prepare hot or cold milk foam. Press the button until you see the red light. For cold milk foam, press it until it turns blue.

Aeroccino 4 Milk Frother

- The maximum capacity of the device is 240 ml for preparing hot milk. In the case of preparing milk foam, hot or cold, the maximum capacity is 120 ml, suitable for preparing two Nespresso Cappuccino recipes or one Nespresso Latte Macchiatto recipe. The maximum level is indicated on the inside of the container.
- The preparation of hot milk or cold milk foam takes about 80 sec. In the case of hot milk, the preparation time is approximately 150 sec. These values can be influenced by different factors, such as the nominal power that can fluctuate throughout the day, the number of consecutive preparations or the cleaning level of the container.
- To prepare hot milk without foam, fill the container to the level indicated by "max milk" and press the second button on the left.
- Fill the container with milk up to the "max Foam" indicator to prepare hot or cold milk foam. Press the button until you see the red light. For cold milk foam, press it until it turns blue.

Aeroccino XL Milk Frother

- The maximum capacity of the device is 400 ml for preparing hot milk. In the case of preparing milk foam, hot or cold, the maximum capacity is 225 ml. The maximum level is indicated on the inside of the container.
- The preparation of hot milk or cold milk foam takes about 80 sec. In the case of hot milk, the preparation time is approximately 150 sec. These values can be influenced by different factors, such as the nominal power that can fluctuate throughout the day, the number of consecutive preparations or the cleaning level of the container.

- To prepare hot milk without foam, remove the whisk, fill the container to the level indicated by "max milk" and press the button.
- Fill the container with milk up to the "max Foam" indicator to prepare hot or cold milk foam. Press the button once for a warm, airy milk froth, or keep the button press until the light turns blue for cold milk froth.

Images

Product Name	Product Image
Aeroccino 3	
Aeroccino 4	

Aeroccino

Product Name	Product Image
Aeroccino XL	