# Inissia

## Price

Price = 209.00
Bundle Price with Milk Frother = 279.00
=> Milk Frother: Aeroccino 3

## Cup Sizes

| Espresso | Lungo |
|---|---|
| **40 ml** Espresso | **110 ml** Lungo |

## Premise

Two programmable coffee selection with automatic flow stop for Espresso and Lungo coffees. Simply choose your Original capsule, pop it in, and it's ready at the touch of a button.

## Specifications

- Dimensions (W x D x H): 12 x 32.1 x 23 cm
- Weight: 2.4 kg
- Warranty: 1 year
- Removable Water Tank: 0.7 L
- Automatic Power Off: after 9 minutes of use
- Heat-Up Time: 25 sec
- Capsule Container Capacity: 9 - 11 capsules

## First Time Use Procedure

1. Rinse the water tank before  with potable water.
2. Place a container (min. 1 L) under coffee outlet.
3. Plug into mains
4. Press the Espresso or Lungo button to activate the machine.

5. Blinking Lights: heating up (25 sec.). Steady Lights: ready.
6. Press the Lungo button to rinse the machine. Repeat 3 times.

# Factory Reset Instructions

1. With machine being turned off, press and hold down the Lungo button for 5 seconds.
2. LEDS will blink fast 3 times to confirm machine has been reset to factory settings.
3. LEDS will then continue to blink normally, as heating up, until ready. Steady lights: machine ready.
4. Factory settings: Espresso Cup: 40 ml, Lungo Cup: 110 ml, Power Off mode: 9 min.

# Helpful Links

| Name of Link | URL |
|---|---|
| Machine Manual | https://www.nespresso.com/shared_res/manuals/inissia/inissia_D_zone1.pdf |
| Machine Maintenance Inissia | https://www.nespresso.com/ca/en/machine-assistance#!/Inissia/instructions |
| YouTube Playlist | https://youtube.com/playlist?list=PLQ2eIUsAVWUwUhZ2r6vIoiuXrcU6OV07N&feature=shared |
| Descaling Guide | Nespressohttps://www.nespresso.com › ...PDFInissia Descaling Guide |

# Colour Variations

Inissia

| Machine Name | Machine Photo |
| --- | --- |
| Inissia - Black | |

Inissia

| Machine Name | Machine Photo |
| --- | --- |
| Inissia - Red | |