Lattissima

Price

Gran Lattissima

Price = 749.00

Lattissima Touch

Price = 499.00

Lattissima One

Price = 479.00

Cup Sizes

Size and/or Milk Recipe	Ristretto	Espresso	Lungo	Cappuccino	Flat White	Latte Macchiato	Caffe Latte	Hot Milk	Espresso Macchiato
Image	25 ml Ristretto	40 ml Espresso	110 ml Lungo	Cappuccino	Flat White	Latte macchiato	Caffè Latte	Hot milk	Espresso Macchiato
Machine	Gran Lattissima, Lattissima Touch	Gran Lattissima, Lattissima Touch, Lattisima One	Gran Lattissima, Lattisima Touch, Lattissima One	Gran Lattissima, Lattisima Touch, Lattissima One	Gran Lattissima	Gran Lattisima, Lattissima Touch, Lattisima One	Gran Lattissima	Gran Lattissima	Lattisima One

Premise

All the Nespresso Original machines are equipped with a 19-bar pressure pump, which provides the power needed to pierce the film of the capsule and release the coffee's 900 or so different aromas. The shape of the Nespresso capsule has been specially designed to ensure that the pressurized water flows evenly through the ground coffee during extraction. The temperature and flow time are also set to ensure each precious aroma is expressed.

Gran Lattissima

Coffee Shop Recipes at a Finger Touch

- More recipes doesn't have to mean more effort. Whether you're in the mood for a cappuccino, a latte, a flat white, or even if you just want to add a bit more milk froth to your coffee, just say the word, and let the Gran Lattissima do the work. Bringing the aromas of the Nespresso coffee to the recipe of your choice.

This machine allows the preparation of several beverages: 3 different coffee selections: Ristretto, Espresso, and Lungo, and 6 milk-based beverages: Cappuccino, Latte Macchiato, Flat White, Caffe Latte, Hot Milk, and Hot Foam. All beverages are accessible at the touch of a button. There is one button per beverage.

The machine is equipped with a multi-serve milk system, based on the double Venturi technology. The milk jug has a capacity of 500ml and allows multiple preparations in a row, with only constraint to rinse the milk system between two preparations, with the easy rinsing function.

All the coffee beverages are preprogrammed with factory setting but can be reprogrammed to fit one's taste.

The machine integrates a movable drip tray allowing the use of a wide range of cups, mugs, and recipe glasses. The maximum height of the jug must be 148 mm.

Lattissima Touch

Endless possibilities in coffee & milk preparations, including those with you own touch.

- Just when you thought you couldn't add any more coffee and milk recipes to your personal repertoire… With the new Lattissima Touch, they're essentially all at your fingertips. Espresso, Cappuccino, Latte Macchiato? Choose between six coffee and milk recipes using the tactile control panel.

The machine is pre-programmed at 40 ml Espresso and 110 ml for Lungo. Milk froth quantity for coffee & milk drinks is driven by the quantity of milk in the jug. All the milk in the jug is completely used for the beverage (single-serve system). A pictogram at 30 ml, a pictogram at 60ml and a pictogram at 135ml and a "maximum" pictogram (165ml) are marked on the milk jug to indicate the milk quantity needed to prepare the perfect Espresso Macchiato, Cappuccino or Latte Macchiato — or the maximum level you should not exceed. For coffee & milk drinks, coffee quantity is always 40ml and cannot be programmed.

The machine integrates a sliding drip tray allowing the use of a wide range of cups, mugs, and jug sizes. The maximum height of the jug must be 145 mm.

Specifications

Gran Lattissima

- Dimensions (W x D x H): 20.3 x 36.7 x 27.6 cm
- Weight: 5.2 kg
- Warranty: 2 years
- Removable Water Tank: 1.3 L
- Automatic Power Off: After 9 minutes of non-use
- Clean System: Descaling Alert

- Capsule Container Capacity: 14 capsules
- Removable Milk Jug: 500 ML

Lattissima Touch

- Dimensions (W x D x H): 17.3 x 32.0 x 25.8 cm
- Weight: 4.5 kg
- Warranty: 2 years
- Removable Water Tank: 0.9 L
- Energy Saving Mode: Auto-off after 9 minutes
- Heat Up Time: 25 seconds (coffee, + 15 seconds for milk beverages)
- Capsule Container Capacity: 9 - 11 capsules
- Removable Milk Jug: 0.35 L

Lattissima One

- Dimensions (W x D x H): 15.4 x 32.4 x 25.6 cm
- Weight: 4.17 kg
- Warranty: 2 years
- Removable Water Tank: 1 L
- Automatic Power Off: After 9 minutes of non-use
- Clean System: Descaling alert
- Capsule Container Capacity: 8 - 10 capsules
- Removable Milk Jug: 165 ML

Reprogram Cup Size

Gran Lattissima

Volume programming with the machine is very easy. For Ristretto, Espresso or Lungo, simply touch and hold the button for at least 3 seconds to enter the programming mode. Brewing starts and button blinks fast (programming mode). Release button when desired volume is reached. If the recipe includes other ingredients, press again the button and keep pressed until the desired volume is reached, then release. When the last ingredient is delivered, button blinks 3 times to confirm the new drink volume. Drink volume is now stored for the next preparations.

Coffee volume can be programmed:

- Ristretto = min 15ml, max. 35ml
- Espresso = min. 35ml, max. 70ml
- Lungo = min. 70ml, max. 130ml
- Cappuccino (coffee volume) = min. 35ml, max. 70ml
- Latte Macchiato (coffee volume) = min. 35ml, max. 70ml
- Flat White (coffee volume) = min. 35ml, max. 70ml
- Caffe Latte (coffee volume) = min. 70ml, max. 130ml

We recommend you to keep factory settings for Espresso and Lungo to ensure the best in cup results for each of our coffee varieties.

Lattissima One

Volume programming with the machine is very easy. For Espresso or Lungo, simply touch and old the button for at least 3 seconds to enter the programming mode. Brewing starts and button blinks fast (programming mode). Release button when desired volume is reached. Coffee volume can be programmed from 25 to 150 ml.

Rapid Cappuccino System

The cleaning of the Rapid Cappuccino System must be performed after each use.

To clean the Rapid Cappuccino System…
1. Disassemble the 6 components of the milk jug.
2. Remove the milk container by pressing the button on the side of the milk jug.
3. Unplug the aspiration tube.
4. Position the milk spout vertically to disassemble and to reassemble.
5. Press the button on the side of milk jug and pull to unlock the connector.
6. Remove the lid.

First Time Use Procedure

Gran Lattissima
1. NOTE: to turn off the machine, press the On-Standby button (standby mode consumption: 0.22 Wh).
2. CAUTION: Please ensure ground continuity when plugging the machine in the power outlet.
3. When unpacking the machine, remove the plastic film, water tank, drip tray, and capsule container. Adjust the cable length and store the excess in the cable guide under the machine.
4. Rinse the water tank before filling with fresh potable water up to maximum level. Plug machine into mains.
5. Switch the machine on by pressing the on-standby button-Blinking lights (coffee buttons): heating-up (25 seconds) - Steady lights: ready.
6. Rinsing: place a container (not provided with the machine) under coffee outlet and press the (Lungo) button. Repeat three times. Machines are fully tested after being produced. Some traces of coffee powder could be found in rinsing water.
7. Disassemble the Rapid Cappuccino System and clean all 6 components in the upper level of your dishwasher. In case a dishwasher is not available, refer to the “Hand Washing of Rapid Cappuccino System” section of the machine manual. After reassemble and re-attach the R.C.S. To the machine, use the (Clean) function before preparing milk beverage. Refer to section “Assembling/Disassembling of Rapid Cappuccino System” section of the machine manual.

Lattissima Touch
1. Remove the capsule container, drip tray and water tank. Adjust the cable length and store the excess in the cable guide under the machine.
2. Place machine in upright position and plug machine into power outlet.
3. The water tank can be carried by its cover.
4. Rinse the water tank before filling with potable water up to maximum level.
5. Switch the machine on. For the first 2 seconds, the automatic power off and water hardness setting are indicated with steady light.
6. Place a container under coffee outlet and press the Lungo button. Repeat three times.
7. Disassemble the Rapid Cappuccino System (R.C.S.) and clean all 6 components in the upper level of your dishwasher. In case a dishwasher is not available refer to the <<Hand washing of Rapid Cappuccino System (R.C.S.)>> section in the machine manual.

Lattissima One
1. Plug machine into the mains. Rinse the water tank before filling with drinking water up to maximum level.

2. Switch the machine on by pressing any buttons:
• Blinking lights: heating-up (18 seconds)
• Illuminates white: ready to use
3. Rinse the machine by placing a 500 ml container under the coffee outlet and pressing the Lungo button. Repeat three times. Machines are fully tested after being produced. Some traces of coffee powder could be found in rinsing water.
4. Clean the milk jug, refer to Cleaning Rapid Cappucino System section.

Factory Reset Instructions

Gran Lattissima

1. CAUTION: if coffee volumes higher than 150 ml are programmed: let the machine cool down for 5 minutes before making the next coffee. Risk of overheating!
2. NOTE: the milk froth volume depends on the kind of milk that is used and its temperature.
3. NOTE: we recommend you to keep factory settings for Espresso and Lungo to ensure the best in cup results for each of our coffee varieties.
4. Coffee volume can be programmed from 25 to 150 ml.
5. Max mil (+ milk foam, if required by the recipe) volume programmable: 400 ml.

Lattissima Touch

1. Switch the machine ON. Note: remove the milk jug.
2. Press the Latte Macchiato and Warm Milk Froth buttons simultaneously for 3 seconds to enter Menu mode; Descaling and clean alerts will start blinking.
3. Touch in a single continuous movement the following buttons: Warm Milk Froth -> Cappuccino -> Lungo -> Espresso -> Ristretto.
4. The Warm Milk Froth button blinks to indicate reset mode. Press it to confirm. All buttons will blink 3 times: all cup volumes are reset.
5. The machine will exit out of menu mode automatically and will return to ready mode.

Lattissima One

1. Remove the milk jug and switch the machine on. NOTE: This procedure reset coffee volumes & power off timing to the default values.
2. Press the milk drink button for 3 seconds to enter Menu mode: descaling and clean alert start blinking.
3. Press the milk button. The milk button blinks to indicate reset mode. Press it to confirm. All buttons blink 3 times: all volumes are reset and restoring quantity to default settings. The menu exits automatically and machine returns to ready mode.

Helpful Links

Name of Link	URL
Gran Lattissima Machine Manual	https://www.nespresso.com/ecom/medias/sys_master/public/14480850583582/GRAN-LATTISSIMA-User-Manual.pdf
Lattissima Touch Machine Manual	https://www.nespresso.com/shared_res/manuals/lattissima_touch/www_LattissimaTouch_Z1A(EN_FR_ES_BR).pdf

Name of Link	URL
Lattissima One Machine Manual	https://www.nespresso.com/shared_res/manuals/lattissima_one/New_Lattissima%20One_F121_UM_Z1A_2020_10_15.pdf
Machine Assistance Gran Lattissima	https://www.nespresso.com/ca/en/machine-assistance#!/Gran-Lattissima/troubleshooting
Machine Assistance Lattissima Touch	https://www.nespresso.com/ca/en/machine-assistance#!/Lattissima-Touch/troubleshooting
Machine Assistance Lattissima One	https://www.nespresso.com/ca/en/machine-assistance#!/Lattissima-One/troubleshooting
Gran Lattisima YouTube Playlist	https://www.youtube.com/playlist?list=PLQ2eIUsAVWUx-7q7rYEoqZzNQuH4vtzGs
Lattisima Touch YouTube Playlist	https://www.youtube.com/playlist?list=PLQ2eIUsAVWUwJv_PywgVNcSdBqQPEpJnJ
Lattisima One YouTube Playlist	https://www.nespresso.com/ca/en/machine-assistance#!/Nespresso-Lattissima-One/troubleshooting
Gran Lattissima Descaling Guide	https://www.nespresso.com/static/us/documents/Gran%20Lattissima%20Descaling%20Guide%20FINAL.pdf
Lattissima Touch Descaling Guide	https://www.nespresso.com/static/us/documents/Lattissima%20Touch%20Descaling%20Guide.pdf
Lattissima One Descaling Guide	https://www.nespresso.com/static/us/documents/Lattissima%20One%20Descaling%20Guide.pdf

Colour Variations

Gran Lattissima

Lattissima

Machine Name	Machine Photo
Gran Lattissima - White	

Lattissima

Machine Name	Machine Photo
Gran Lattissima - Black	

Lattissima Touch

Machine Name	Machine Photo
Lattissima Touch Silver	

Lattissima One

Lattissima

Machine Name	Machine Photo
Lattissima One - Black	

Lattissima

Machine Name	Machine Photo
Lattissima One - White	