Vertuo Pop+

Prices

Standard Pop+ Model

Price = 169.00
Bundle Price with Milk Frother = 239.00
=> Milk Frother: Aeroccino 3

Deluxe Pop+ Model

Price = 189.00
Bundle Price with Milk Frother = 259.00
=> Milk Frother: Aeroccino 3

Cup Sizes

Espresso	Double Espresso	Gran Lungo	Long Coffee	Alto
40 ml Espresso	80 ml Double Espresso	150 ml Gran Lungo	230 ml Long Coffee	355 ml (Alto)

Carafe/Craft Brew (535 ml) capsules may be compatible with the Vertuo Pop+, however the “Carafe” accessory does not fit appropriately under the machine. Thus, it is not recommended to extract Carafe coffee with the Vertuo Pop+ machine as you will not be able to enjoy the full coffee experience.

There is the possibility of buying the Aeroccino 3 or the Aeroccino 4 alongside the Vertuo machine to create the ultimate milk frothing experience. These devices help to create milk recipes such as Cappuccinos and Latte Macchiatos.

Specifications

- Dimensions (W x D x H): 8.6 x 14 x 10.4 in
- Weight:
  - Standard Model = 3.6 kg
  - Deluxe Model = 3.7 kg
- Warranty: 1 year
- Removable Water Tank:
  - Standard Model = 750 ml
  - Deluxe Model = 1.1 L
- Connected Machines: Ensures software updates
- Automatic Power Off: After 2 minutes of non-use
- Heat-Up Time: 30 sec
- Capsule Container Capacity: 5 - 8 capsules

Premise

The New Vertuo Pop+ is Nespresso's smallest, and most stylish & colourful Vertuo ever. You can brew five sizes coffee— hot or with ice —without sacrificing precious counter space. And with eight colours to choose from, like soothing Pacific Blue and Spicy Red, you'll finally have a machine that perfectly compliments your unique style.

Vertuo Pop+ is available in 2 different finishing & 8 colours:
- Vertuo Pop+ with 6 permanent colours.
- Vertuo Pop+ Deluxe with 2 permanent colours.

The Vertuo Pop+ utilizes the CENTRIFUSION brewing technology. It can gently and fully brew the following coffee sizes: Espresso, Double Espresso, Gran Lungo, Mug, Alto & Cold Brew Style.

Factory Reset Instructions

1. Open the machine head and let the used capsule be ejected.
2. Close the head. Leave the handle in "UNLOCKED" position.
3. Push the button 5 times within 3 seconds. The button blinks 5 times orange and then changes to steady white.

First Time Use Procedure

1. CAUTION: Before operating your coffee machine, please refer to the safety instructions leaflet to avoid possible harm and damage.
2. ON: With machine plugged, turn on by clicking on the button once. If the machine head is open, close the lever. The light will blink for approximately 30 seconds while the machine is heating up. The steady light indicates when the machine is ready.
3. OFF: To save energy, the machine will turn off automatically after 2 minutes of non-use. The machine can be turned "OFF' manually at any time (when not in use) by pressing and holding the button for 3 seconds (machine unlock).
4. Rinse the water tank before filling with only fresh water.
5. Close the water tank with the lid and put the water tank back in position on the machine.

6. Plug the power cord, remove the cup support and place an empty container (at least 1 L / 34 fl oz) under the coffee outlet.
7. Open and close the machine. Ensure the lever is in the lock position.
8. Turn on the machine by clicking on the button once.
9. Press the button 3 times within 2 seconds. The machine will start rinsing. This procedure may take up to 7 minutes.

Descaling

See User Manual or Tutorial video for detailed procedure. You can also use the Nespresso app if your machine is paired. Tanks to the step-by-step procedure, descaling your machine is super easy.

The descaling frequency depends on the machine usage and the water hardness, which varies based on how often coffee is consumed in the household and the water of that particular location. The general rule is every 300 cups of coffee. The most reliable way to ensure it is ready to descale is through the descaling alert or by checking the status through the App.

Descaling Alert: The main coffee button will blink orange 3 times and then steady white.

Helpful Links

Name of Link	URL
Machine Manual	https://www.nespresso.com/ecom/medias/sys_master/public/26829739294750/Nespresso-Vertuo-Pop-Digital-User-Manual.pdf
Machine Maintenance Vertuo Pop+	https://www.nespresso.com/ca/en/machine-assistance#!/Vertuo-POP-Plus/instructions
YouTube Playlist	https://youtube.com/playlist?list=PLQ2eIUsAVWUy0lYtfWszd0CeuMmOasVKR&feature=shared
Descaling Guide	https://www.nespresso.com/static/us/documents/VertuoPopDescalingGuide.pdf
Factory Reset Instructions	https://www.mymorningespresso.com/how-to-reset-nespresso-machine/#aioseo-vertuo-pop-or-vertuo-pop-deluxe

FAQS

- Power Rating = 120 Volts
- Cable length from coffee machine to the plug = 90 cm / 35.4 in
- Cup support is movable with 2 different positions.
- Pairing your Vertuo Pop+ machine and connecting it to you WIFI network using your smartphone will enable your machine to update itself automatically, ensuring you always get the best possible coffee experience. On top of this, the Nespresso app will become a great interface on which you can check your machine's status, access tutorial videos and even

step by step procedures for the maintenance of your machine. By allowing the push notification, you will receive messages when your machine needs your attention and dedicated screens explaining you how to solve any issues you may encounter.
- The machine's removable parts are not dishwasher safe. They may be hand washed with mild soap and water.
- The machine can be manually turned "OFF" at any time (when not operating) by holding the button for 3 seconds.
- It is possible to preselect a beverage during heat up time. You can press the button wile the machine is still heating up. The coffee will then flow automatically when the machine is ready.
- The temperature of the Vertuo Pop+ cannot be regulated. The temperature varies for each blend and cannot be altered. If you would like warmer coffee, it is recommended to preheat your cup by rinsing it in hot water to help maintain the temperature and mix the coffee with the crema once brewed.
- The Original Nespresso capsules cannot be used in the Vertuo machine system. They interact with the systems in different ways. These are two separate lines that will appeal to different types of coffee lovers.

Notes

- The Vertuo Pop+ was created with the intent to attract new customers to the Nespresso brand. Historically, Nespresso has been perceived as a luxury brand that caters to high calibre customers. With the introduction of the compact & affordable Pop+, Nespresso aims to cater to a wider range of customers that are of diverse socio-economic classes.
- Vertuo Pop+ can be perceived as a small & compact version of the Vertuo Next, however with all of the underlying "issues" & "bugs".
- The budget entry level pricing was meant to entice millennials & generation Z customers. These type of customers are on a budget and may not be living in spacious houses with ample tabletop space. The Vertuo Pop+ is economical in terms of both price and space.
- The Vertuo Pop+ has the ability to perform concentrated brews whereby the coffee drinker gains a smaller volume of coffee that typically yields higher volume of coffee albeit with a concentrated caffeine kick!
- The vibrant colour variations were also meant to communicate vibrant modern look that represented Nespresso as a growing brand.

Colour Variations

Standard Pop+ Model

Vertuo Pop+

Machine Name	Machine Photo
Vertuo Pop+ - Liquorice Black	
Vertuo Pop+ — Aqua Mint	

Vertuo Pop+

Machine Name	Machine Photo
Vertuo Pop+ — Spicy Red	
Vertuo Pop+ — Pacific Blue	

Vertuo Pop+

Machine Name	Machine Photo
Vertuo Pop+ — Mango Yellow	
Vertuo Pop+ — Dark Grey	

Deluxe Pop+ Model

Machine Name	Machine Photo
Vertuo Pop+ Deluxe — Titan	

Vertuo Pop+

Machine Name	Machine Photo
Vertuo Pop+ Deluxe — Silver	