

MJF Production Floor — Operator Quick Reference

Tap any job to open its details panel. Confirm prompts protect against accidental taps.

JOB ACTIONS

 Start Now	Records the actual start time of a print. Opens a picker defaulted to now. You can adjust up to 24 hours back if you missed clicking it earlier. Sets Print Status to Running and cascades downstream jobs.
 End Now	Marks the print complete and moves it to Print Completed. Sets Print Status to Complete. Use when the print AND any annealing time is finished.
 Schedule	Queue a job behind existing jobs on a printer. Default option when moving or assigning jobs.
 Start Next	Move a job to be the NEXT print on a printer (after the currently active one finishes). Use for expedited work.
 Delay Job	Schedule a job to start on a specific date and hour (24H format). Use for planning starts on weekends or off-hours. Downstream jobs cascade if they now overlap.
 Move to Queue	Send a job back to the Queue. Clears scheduled dates and Print Status so it can be reassigned later.

OVERDUE INDICATORS

 START?	Green border with badge on top-LEFT of a job block. Scheduled start is more than 1 hour past and Print Status is not Running. Someone forgot Start Now — tap the job and click Start Now.
 END?	Yellow border with badge on top-RIGHT of a job block. Scheduled end is more than 2 hours past and Print Status is not Complete. Someone forgot End Now — tap the job and click End Now.

OVERDUE PROMPT — When Starting Next Job

When you tap Start Now on a job whose printer lane has an overdue job ( END?), you will see a warning: **"Previous job not marked complete."**

Yes Mark complete and continue	Marks the previous job complete using its scheduled end time, then opens the Start Now picker for your new job. Use when the previous print actually finished.
Cancel Stop and verify	Closes the prompt. Verify the correct printer and job on the shop floor. If the schedule doesn't match reality, correct it first (move to right printer or clean up the previous job).

PRINTER STATUS

 Production Ready	Printer is available to accept jobs. Click the status badge to change it.
 Idle	Printer is Production Ready but no job is currently running. Assign a job to start production.
 Maintenance Required	Printer is operational but needs maintenance. Existing jobs continue; new jobs blocked.
 Down for	Printer is unavailable. All scheduled jobs automatically move to the Queue. Hidden from

Service	assignment dropdowns.
---------	-----------------------

QUEUE & ADDING JOBS

+ Add Job	Create a new job from the Queue header. Fill in name, material, build height, and priority. Optionally assign directly to a printer with Schedule, Start Next, or Delay Job.
★ Priority Order	Queue is auto-sorted by priority: Critical (red) → High (orange) → Medium (blue) → Low (green). Critical jobs also show red on the printer lanes.
■ Material Color	TPU jobs appear green, PA12 jobs appear yellow. Counts above legend show total material demand.

OPERATOR TIPS

- Tap Start Now when you begin a print — this keeps the schedule accurate for everyone else viewing the board. If you forgot to click it at the right moment, use the time picker to record the actual start time (up to 24 hours back).
- Tap End Now when the print finishes — even if it ended early (e.g. shortened TPU annealing). The actual end time is recorded.
- Overdue indicators (⚠ START? and ⚠ END?) show when someone forgot to tap the corresponding button. Address them as soon as you see them.
- If the shop floor reality doesn't match the app (e.g. wrong printer showing an active job), fix the schedule first before trying to Start Now. The app is a reflection of reality, not the source of truth.
- Completed jobs remain visible on the timeline for 14 days as faded hatched blocks. Click to see planned vs actual duration.
- Pending changes show as pulsing dashed blocks while Monday processes them. Display refreshes within seconds.