

MJF Production Planner — Quick Reference

Nothing here touches the production floor until you press Send. Plan freely.

THE THREE KINDS OF BUILD

■ Live	Mirrored from the production board. Solid fill, padlock. Locked — planned builds pack in <i>after</i> these, never on top of them.
■ Committed	A real job sitting in the floor <i>queue</i> . Orange border, half fill. It will run — it just has no printer yet. Bring it into the plan with Place committed queue .
▨ Planned	Hypothetical. Dashed hatch. Exists only in the sandbox. Move it, re-order it, delete it — the floor never sees it.
■ Sent	Written to the production board. Once the floor echoes it back it draws as a Live block with a violet ring and a ↻ marker. Click that to recall it.

BUILDING A PLAN

+ Add build	Name, material, height, priority, and how many . A quantity above 1 creates a batch — <i>Bracket #1 ... Bracket #7</i> . The batch is derived from the name, so keep the numbering intact.
⚡ Auto-place	Opens the planner. Choose sort order, whether batches stay together, which printers, and which jobs. Only touches unplaced planned builds — never your hand-placed work, never committed jobs.
Place committed queue	Mirrors the floor queue into the plan and packs it onto printers. Explicit, never automatic. Nothing on the floor changes.
► Schedule	Queue a build behind everything already on that printer.
►► Start Next	Make it the next build on that printer, after whatever is live.
🕒 Delay Job	Pin a build to a specific date and hour. Everything behind it cascades.

AUTO-PLACE OPTIONS

Order jobs by	A first and second key: Priority , Material , Batch , or Shortest , plus which material leads. A batch ranks by its <i>most urgent</i> member — one Critical build makes the whole batch urgent.
Keep batches together	Off — batches ignored, packed for the earliest finish. On → one printer — the whole batch runs back to back on one machine. On → across fleet — the batch finishes as a block before the next one starts.
Printers to use	Fleet-wide by default. In <i>one printer</i> mode it starts empty, so you aim the batch deliberately. Printers that are not Production Ready are struck through and cannot be chosen.
Jobs to place	Grouped by batch. Place a subset now and the rest later, on different settings.

SENDING TO THE FLOOR

Selecting	Click builds on the chart — they go solid with a violet ring and a ✓. Send to floor turns green when something is selected. Double-click a build for its detail panel.
Printer lanes	Creates real jobs, scheduled , at the exact start and end times shown. Operators see them immediately.
Production queue	Creates real jobs with no dates, no times, no status . Operators assign them.
Action column	create — a new job on the floor. move from queue — a committed job moves out of the queue into its lane. Never duplicated.

↩ Recall	A job we created is deleted from the floor. A job that came <i>from</i> your floor queue is returned to the queue with its schedule cleared — never deleted. Reversible until an operator acts on it: once a print is Running, recall is refused.
----------	---

THE START WINDOW

Blackout	No build may <i>start</i> between 2:00 AM and 6:00 AM . A build already running prints straight through — the rule gates starts, not runs.
Block weekends	Optional, in the gear menu. No starts from Sat 2:00 AM until Mon 6:00 AM . Saturday before 2 AM is still Friday's shift and stays open.
Material affinity	A soft preference for keeping the same material on the same printer. Worth this many hours of earlier start when auto-place breaks a tie.

WHEN THE APP WARNS YOU

⚠ Duration mismatch	The floor board's Duration formula disagrees with this app's duration table. The scheduler uses the <i>formula</i> — so every forecast and every sent end time is wrong by the difference. Fix this before trusting the plan.
⚠ Ghost builds	Builds in the plan whose floor jobs completed or were deleted. Remove from plan drops them; Re-plan returns the deleted ones to the sandbox queue.
⚠ Builds shifted	Shown when sending. The floor genuinely moved since you planned — a job ran long, or a printer changed status. The times shown are current and are what will be written.
✗ Not Production Ready	You cannot send to a printer set to Maintenance or Down. The floor scheduler would bounce those jobs straight into the queue.

PLANNER TIPS

- **Print hours, not build count, is the number that matters.** TPU runs two hours longer than PA12 at every height. Ten TPU builds is 140h; ten PA12 builds is 120h — same count, two builds' worth of difference in capacity.
- **Committed jobs are real work.** If the floor queue has jobs that are not in your plan, your utilization figure is understating the true load. The strip tells you how many are missing.
- **Clear** sends placed builds back to the queue — nothing is deleted. **Clear queue** then deletes what you can see. Two steps, on purpose.
- **Delete a sent job in Monday and the planner notices.** It asks the board where every linked job actually lives, so deleted and completed jobs surface in the ghost bar instead of lingering as phantoms.
- **The plan is written back to the sandbox board.** Sim Start, Sim End, Duration, and Sequence are all filled in, so someone who never opens this app still sees the schedule.