



DNP — test signal integrity without the active pullups and populate them if necessary



DNP — test signal integrity without the active pullups and populate them if necessary



DNP — test signal integrity without the active pullups and populate them if necessary

